


Installer manual  
**NIBE™ F1155PC**  
Ground source heat pump

## Quick guide


### Navigation



A detailed explanation of the button functions can be found on page 34.


How to scroll through menus and make different settings is described on page 36.

### Set the indoor climate



The mode for setting the indoor temperature is accessed by pressing the OK button twice, when in the start mode in the main menu.

### Increase hot water volume



To temporarily increase the amount of hot water (if a hot water heater is installed to your F1155PC), first turn the control knob to mark menu 2 (water droplet) and then press the OK button twice.

### In event of disturbances in comfort

If a disturbance in comfort of any type occurs there are some measures that can be taken before you need to contact your installer. See page 56 for instructions.

# Table of Contents

|                                      |           |  |           |
|--------------------------------------|-----------|--|-----------|
| <b>1 Important information</b>       | <b>4</b>  | Start guide                            | 30        |
| Safety information                   | 4         | Post adjustment and venting            | 31        |
| <b>2 Delivery and handling</b>       | <b>8</b>  | Setting the cooling/heating curve      | 32        |
| Transport                            | 8         | <b>7 Control - Introduction</b>        | <b>34</b> |
| Assembly                             | 8         | Display unit                           | 34        |
| Supplied components                  | 9         | Menu system                            | 35        |
| Removing the covers                  | 9         | <b>8 Control - Menus</b>               | <b>38</b> |
| <b>3 The heat pump design</b>        | <b>10</b> | Menu 1 - INDOOR CLIMATE                | 38        |
| General                              | 10        | Menu 2 - HOT WATER                     | 38        |
| Distribution boxes                   | 12        | Menu 3 - INFO                          | 38        |
| Cooling section                      | 13        | Menu 4 - HEAT PUMP                     | 39        |
| <b>4 Pipe connections</b>            | <b>14</b> | Menu 5 - SERVICE                       | 40        |
| General                              | 14        | <b>9 Service</b>                       | <b>50</b> |
| Dimensions and pipe connections      | 15        | Service actions                        | 50        |
| Brine side                           | 15        | <b>10 Disturbances in comfort</b>      | <b>56</b> |
| Heating medium side                  | 16        | Info menu                              | 56        |
| Water heater                         | 16        | Manage alarm                           | 56        |
| Docking alternatives                 | 16        | Troubleshooting                        | 56        |
| <b>5 Electrical connections</b>      | <b>19</b> | <b>11 Accessories</b>                  | <b>58</b> |
| General                              | 19        | <b>12 Technical data</b>               | <b>60</b> |
| Connections                          | 20        | Dimensions and setting-out coordinates | 60        |
| Settings                             | 23        | Technical specifications               | 61        |
| Optional connections                 | 24        | Energy labelling                       | 66        |
| Connecting accessories               | 28        | <b>Index</b>                           | <b>71</b> |
| <b>6 Commissioning and adjusting</b> | <b>29</b> |  |           |
| Preparations                         | 29        |  |           |
| Filling and venting                  | 29        |  |           |

# 1 Important information

## Safety information

This manual describes installation and service procedures for implementation by specialists.

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

Rights to make any design or technical modifications are reserved.

©NIBE 2015.

## Symbols



### NOTE

This symbol indicates danger to machine or person.



### Caution

This symbol indicates important information about what you should observe when maintaining your installation.



### TIP

This symbol indicates tips on how to facilitate using the product.


## Marking

The CE marking means that NIBE ensures that the product meets all regulations that are placed on it based on relevant EU directives. The CE mark is obligatory for most products sold in the EU, regardless where they are made.

## Serial number

The serial number can be found at the bottom right of the front cover and in the info menu (menu 3.1).

You can also find the serial number on the type plate PF1, for location see the section for the Heat pump design in the installer manual.



### Caution

Always give the product's serial number (14 digits) when reporting a fault.

## Recovery



Leave the disposal of the packaging to the installer who installed the product or to special waste stations.

Do not dispose of used products with normal household waste. It must be disposed of at a special waste station or dealer who provides this type of service.

Improper disposal of the product by the user results in administrative penalties in accordance with current legislation.

## Country specific information

### Installer manual

This installer manual must be left with the customer.

## Inspection of the installation

Current regulations require the heating installation to be inspected before it is commissioned. The inspection must be carried out by a suitably qualified person. In addition, fill in the page for the installation data in the User Manual.

| ✓                        | Description                          | Notes | Signature | Date |
|--------------------------|--------------------------------------|-------|-----------|------|
| Brine (page 15)          |                                      |       |           |      |
|                          | System flushed                       |       |           |      |
|                          | System vented                        |       |           |      |
|                          | Antifreeze                           |       |           |      |
|                          | Level/Expansion vessel               |       |           |      |
|                          | Particle filter                      |       |           |      |
|                          | Safety valve                         |       |           |      |
|                          | Shut off valves                      |       |           |      |
|                          | Circulation pump setting             |       |           |      |
| Heating medium (page 16) |                                      |       |           |      |
|                          | System flushed                       |       |           |      |
|                          | System vented                        |       |           |      |
|                          | Expansion vessel                     |       |           |      |
|                          | Particle filter                      |       |           |      |
|                          | Safety valve                         |       |           |      |
|                          | Shut off valves                      |       |           |      |
|                          | Circulation pump setting             |       |           |      |
| Electricity (page 19)    |                                      |       |           |      |
|                          | Connections                          |       |           |      |
|                          | Main voltage                         |       |           |      |
|                          | Phase voltage                        |       |           |      |
|                          | Fuses heat pump                      |       |           |      |
|                          | Fuses property                       |       |           |      |
|                          | Outside sensor                       |       |           |      |
|                          | Room sensor                          |       |           |      |
|                          | Current sensor                       |       |           |      |
|                          | Safety breaker                       |       |           |      |
|                          | Earth circuit-breaker                |       |           |      |
|                          | Setting of emergency mode thermostat |       |           |      |
| Miscellaneous            |                                      |       |           |      |

| ✓ | Description         | Notes | Signature | Date |
|---|---------------------|-------|-----------|------|
|   | Guarantee submitted |       |           |      |

## Contact information

- AT KNV Energietechnik GmbH**, Gahberggasse 11, 4861 Schörfling  
Tel: +43 (0)7662 8963-0 Fax: +43 (0)7662 8963-44 E-mail: mail@knv.at www.knv.at
- CH NIBE Wärmetechnik c/o ait Schweiz AG**, Industriepark, CH-6246 Altishofen  
Tel: (52) 647 00 30 Fax: (52) 647 00 31 E-mail: info@nibe.ch www.nibe.ch
- CZ Druzstevni zavody Drazice s.r.o.**, Drazice 69, CZ - 294 71 Benátky nad Jizerou  
Tel: +420 326 373 801 Fax: +420 326 373 803 E-mail: nibe@nibe.cz www.nibe.cz
- DE NIBE Systemtechnik GmbH**, Am Reiherpfahl 3, 29223 Celle  
Tel: 05141/7546-0 Fax: 05141/7546-99 E-mail: info@nibe.de www.nibe.de
- DK Vølund Varmeteknik A/S**, Member of the Nibe Group, Brogårdsvej 7, 6920 Videbæk  
Tel: 97 17 20 33 Fax: 97 17 29 33 E-mail: info@volundvt.dk www.volundvt.dk
- FI NIBE Energy Systems OY**, Juurakkotie 3, 01510 Vantaa  
Puh: 09-274 697 0 Fax: 09-274 697 40 E-mail: info@nibe.fi www.nibe.fi
- FR NIBE Energy Systems France Sarl**, Zone industrielle RD 28, Rue du Pou du Ciel, 01600 Reyrieux  
Tel : 04 74 00 92 92 Fax : 04 74 00 42 00 E-mail: info@nibe.fr www.nibe.fr
- GB NIBE Energy Systems Ltd**, 3C Broom Business Park, Bridge Way, Chesterfield S41 9QG  
Tel: 0845 095 1200 Fax: 0845 095 1201 E-mail: info@nibe.co.uk www.nibe.co.uk
- NL NIBE Energietechniek B.V.**, Postbus 634, NL 4900 AP Oosterhout  
Tel: 0168 477722 Fax: 0168 476998 E-mail: info@nibenl.nl www.nibenl.nl
- NO ABK AS**, Brobekkveien 80, 0582 Oslo, Postadresse: Postboks 64 Vollebakk, 0516 Oslo  
Tel. sentralbord: +47 23 17 05 20 E-mail: post@abkklima.no www.nibeenergysystems.no
- PL NIBE-BIAWAR Sp. z o. o.** Aleja Jana Pawła II 57, 15-703 BIAŁYSTOK  
Tel: 085 662 84 90 Fax: 085 662 84 14 E-mail: sekretariat@biawar.com.pl www.biawar.com.pl
- RU © "EVAN"** 17, per. Boynovskiy, Nizhny Novgorod  
Tel./fax +7 831 419 57 06 E-mail: info@evan.ru www.nibe-evan.ru
- SE NIBE AB Sweden**, Box 14, Hannabadsvägen 5, SE-285 21 Markaryd  
Tel: +46-(0)433-73 000 Fax: +46-(0)433-73 190 E-mail: info@nibe.se www.nibe.se

For countries not mention in this list, please contact Nibe Sweden or check [www.nibe.eu](http://www.nibe.eu) for more information.

## 2 Delivery and handling

### Transport

F1155PC should be transported and stored vertically in a dry place. When being moved into a building, F1155PC may be leant back 45°.




#### NOTE

The product can be tail heavy!

If the cooling module is pulled out and transported upright, F1155PC can be transported on its back.

Remove the outer panels in order to protect them when moving in confined spaces inside buildings.




### Pulling out the cooling module

To simplify transport and service, the heat pump can be separated by pulling the cooling module out from the cabinet.

See page 52 for instructions about the separation.

### Assembly

- Position F1155PC on a firm base that can take the weight, preferably on a concrete floor or foundation. Use the product's adjustable feet to obtain a horizontal and stable set-up.




- The area where F1155PC is located must be equipped with floor drainage.
- Install with its back to an outside wall, ideally in a room where noise does not matter, in order to eliminate noise problems. If this is not possible, avoid placing it against a wall behind a bedroom or other room where noise may be a problem.

- Wherever the unit is located, walls to sound sensitive rooms should be fitted with sound insulation.
- Route pipes so they are not fixed to an internal wall that backs on to a bedroom or living room.

### Installation area


Leave a free space of 800 mm in front of the product. Approx. 50 mm free space is required on each side, to remove the side panels. The panels do not need to be removed during service, all service on F1155PC can be carried out from the front. Leave space between the heat pump and the wall behind (and any routing of supply cables and pipes), to reduce the risk of any transmission of vibrations.



\* A normal installation needs 300 - 400 mm (any side) for connection equipment, i.e. level vessel, valves and electrical equipment.



## Supplied components




## Location


The kit of supplied items is placed in packaging on top of the heat pump.

## Removing the covers

### Front cover



1. Remove the screws from the lower edge of the front cover.
2. Lift the cover out at the bottom edge and up.




The side covers can be removed to facilitate the installation.


1. Remove the screws from the upper and lower edges.
2. Twist the cover slightly outward.
3. Move the hatch outwards and backwards.
4. Assembly takes place in the reverse order.

# 3 The heat pump design

## General



## View from behind



## Pipe connections

|      |                                   |
|------|-----------------------------------|
| XL 1 | Connection, heating medium flow   |
| XL 2 | Connection, heating medium return |
| XL 6 | Connection, brine in              |
| XL 7 | Connection, brine out             |
| XL 9 | Connection, hot water heater      |

## HVAC components

|       |  |
|-------|--|
| QM 31 | Shut-off valve, heating medium flow        |
| QM 32 | Shut off valve, heating medium return      |
| QM 33 | Shut off valve, brine out                  |
| QM 34 | Shut-off valve, brine in                   |
| QN 10 | Shuttle valve, climate system/water heater |

## Sensors etc.

|      |  |
|------|--|
| BF 1 | Flow meter**                             |
| BT 1 | Outdoor temperature sensor*              |
| BT 2 | Temperature sensors, heating medium flow |

\*\*Only heat pumps with energy meter

\* Not illustrated

## Electrical components


|       |                                      |
|-------|--------------------------------------|
| AA 4  | Display unit                         |
|       | AA4-XJ3 USB socket                   |
|       | AA4-XJ4 Service outlet (No function) |
| EB 1  | Immersion heater                     |
| SF 1  | Switch                               |
| W 130 | Network cable for NIBE Uplink™       |

## Miscellaneous

|      |                                   |
|------|-----------------------------------|
| PF 1 | Rating plate                      |
| PF 2 | Type plate, cooling section       |
| UB 1 | Cable gland, incoming electricity |
| UB 2 | Cable gland                       |
| UB 3 | Cable gland, rear side, sensor    |

Designations in component locations according to standard IEC 81346-1 and 81346-2.

## Distribution boxes




### Electrical components

- AA 1 Immersion heater card
- AA 2 Base card
- AA 3 Input circuit board
- AA 7 Extra relay circuit board
- AA 23 Communication board
- FA 1 Miniature circuit-breaker
- FD 1 Temperature limiter/Emergency mode thermostat


Designations in component locations according to standard IEC 81346-1 and 81346-2.

## Cooling section

1X230V, 3X400V, 6 kW



1X230V, 3X400V, 6 kW



## Pipe connections

- XL 20 Service connection, high pressure
- XL 21 Service connection, low pressure

## HVAC components

- GP 1 Circulation pump
- GP 2 Brine pump
- QM 1 Drainage, climate system
- QM 2 Draining, brine side

## Sensors etc.

- BP 1 High pressure pressostat
- BP 2 Low pressure pressostat
- BT 3 Temperature sensors, heating medium return
- BT 10 Temperature sensor, brine in
- BT 11 Temperature sensor, brine out
- BT 12 Temperature sensor, condenser supply line
- BT 14 Temperature sensor, hot gas
- BT 15 Temperature sensor, fluid pipe
- BT 17 Temperature sensor, suction gas

## Electrical components

- AA 100 Joint card
- EB 10 Compressor heater
- QA 40 Inverter

## Cooling components

- EP 1 Evaporator
- EP 2 Condenser
- EP 6 Heat exchanger, cooling
- GQ 10 Compressor
- HS 1 Drying filter
- QN 1 Expansion valve
- QN 18 Mixing valve, cooling

Designations in component locations according to standard IEC 81346-1 and 81346-2.

# 4 Pipe connections

## General

Pipe installation must be carried out in accordance with current norms and directives. F1155PC can operate with a return temperature of up to 58 °C and an outgoing temperature from the heat pump of 70(65 °C with only the compressor).

F1155PC is not equipped with external shut off valves; these must be installed to facilitate any future servicing.



### Caution

Any high points in the climate system, must be equipped with air vents.



### NOTE

The pipe system needs to be flushed out before the heat pump is connected so that debris cannot damage component parts.



### NOTE

The climate system must be adjusted for both heating and cooling operation.

## Symbol key


| Symbol | Meaning  |
|--------|--|
|        | Venting valve                                  |
|        | Shut-off valve                                 |
|        | Non-return valve                               |
|        | Level vessel                                   |
|        | Trim valve                                     |
|        | Shunt / shuttle valve                          |
|        | Safety valve                                   |
|        | Temperature sensor                             |
|        | Expansion vessel                               |
|        | Pressure gauge                                 |
|        | Circulation pump                               |
|        | Particle filter                                |
|        | Auxiliary relay                                |
|        | Flow meter (only heat pumps with energy meter) |
|        | Compressor                                     |
|        | Heat exchanger                                 |

## System diagram

F1155PC consists of heat pump, immersion heater, circulation pumps and control system. F1155PC is connected to the brine and heating medium circuits.


In the heat pump evaporator, the brine (water mixed with anti-freeze, glycol or ethanol) releases its energy to the refrigerant, which is vaporised in order to be compressed in the compressor. The refrigerant, of which the temperature has now been raised, is passed to the condenser where it gives off its energy to the heating medium circuit and, if necessary, to any docked water heater. If there is a greater need for heating/hot water than the compressor can provide there is an integrated immersion heater.

The brine can also be circulated via a mixing valve to a heat exchanger. There the brine cools the heating system's water so that comfort cooling can be maintained during the hotter periods of the year.



- XL 1 Connection, heating medium flow
- XL 2 Connection, heating medium return
- XL 6 Connection, brine in
- XL 7 Connection, brine out
- XL 9 Connection, hot water heater

## Dimensions and pipe connections



### Pipe dimensions

| Connection                                   |      |    |
|--|------|----|
| (XL6)/(XL7) Brine in/out ext Ø               | (mm) | 28 |
| (XL1)/(XL2) Heating medium flow/return ext Ø | (mm) | 22 |
| (XL3)/(XL4) Cold/hot water Ø                 | (mm) | 22 |

\* Can be angled for side connection.

## Brine side

### Collector



#### Caution

The length of the collector hose varies depending on the rock/soil conditions, climate zone and on the climate system (radiators or under-floor heating).

Max length per coil for the collector should not exceed 400 m.

In those cases where it is necessary to have several collectors, these should be connected in parallel with the possibility for adjusting the flow of the relevant coil.

For surface soil heat, the hose should be buried at a depth determined by local conditions and the distance between the hoses should be at least 1 metre.

For several bore holes, the distance between the holes must be determined according to local conditions.

Ensure the collector hose rises constantly towards the heat pump to avoid air pockets. If this is not possible, airvents should be used.

As the temperature of brine system can fall below 0 °C it must be protected against freezing down to -15 °C. 1 litre of ready mixed brine per meter of collector hose (applies when using PEM-hose 40x 2.4 PN 6.3) is used as a guide value when making the volume calculation.

### Side connection

It is possible to angle the brine connections, for connection to the side instead of top connection.

To angle out a connection:

1. Disconnect the pipe at the top connection.
2. Angle the pipe in the desired direction.
3. If necessary, cut the pipe to the desired length.

### Connecting the brine side

- Insulate all indoor brine pipes against condensation.
- The level vessel must be installed as the highest point in the brine system on the incoming pipe before the brine pump (Alt. 1).

If the level vessel cannot be placed at the highest point an expansion vessel must be used (Alt. 2).




#### NOTE

Note that condensation may drip from the level vessel. Position the vessel so that this does not harm other equipment.

- Details of the antifreeze used must be shown on the level vessel.
- Install the supplied safety valve under the level vessel as illustrated. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost proof.

- Install shut off valves as close to the heat pump as possible.
- Fit the supplied particle filter on the incoming pipe.

In the case of connection to an open groundwater system, an intermediate frost-protected circuit must be provided, because of the risk of dirt and freezing in the evaporator. This requires an extra heat exchanger.




## Heating medium side

### Connecting the climate system

A climate system is a system that regulates indoor comfort with the help of the control system in F1155PC and for example radiators, underfloor heating/cooling, fan convectors etc.

- Install all required safety devices, shut-off valves (as close to the heat pump as possible), and supplied particle filter.
- The safety valve must have a maximum 0.25 MPa (2.5 bar) opening pressure and be installed on the heating medium return as illustrated. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost proof.
- When connecting to a system with thermostats on all radiators, a relief valve must be fitted, or some of the thermostats must be removed to ensure sufficient flow.



## Water heater

### Connecting the hot water heater



#### NOTE

If F1155PC is not docked to a water heater or if it is to work with fixed condensing, the connection for the water heater (XL9) must be plugged.

- Any docked hot water heater must be fitted with necessary set of valves.
- The mixing valve must be installed if the setting is changed so that the temperature can exceed 60 °C.
- The setting for hot water is made in menu 5.1.1.
- The safety valve must have a maximum 1.0 MPa (10.0 bar) opening pressure and be installed on the incoming domestic water line as illustrated. The entire length of the overflow water pipe from the safety valves must be inclined to prevent water pockets and must also be frost proof.



#### Caution

Hot water production is activated in menu 5.2 or in the start guide.

### Fixed condensing

If F1155PC is to work towards the water heater with fixed condensing you must connect an external flow sensor (BT25) according to the description on page 22. In addition, you must perform the following menu settings.

| Menu                                   | Menu setting (local variations may be required) |
|--|---|
| 1.9.3.1 - min. flow line temp. heating | Desired temperature in the tank.                |
| 5.1.2 - max flow line temperature      | Desired temperature in the tank.                |
| 5.1.10 - op. mod heat med pump         | intermittent                                    |
| 4.2 - op. mode                         | manual  |

## Docking alternatives


F1155PC can be connected in several different ways, some of which are shown below.

Further option information is available at [www.nibe.eu](http://www.nibe.eu) and in the respective assembly instructions for the accessories used. See page 58 for a list of the accessories that can be used with F1155PC.



## Buffer vessel


If the climate system volume is too small for the heat pump output, the radiator system can be supplemented with a buffer vessel, for example NIBE UKV.



## Ground water system

An intermediate heat exchanger is used to protect the heat pump's exchanger from dirt. The water is released into a buried filtration unit or a drilled well. See page 27 for more information about connecting a ground water pump.


If this docking alternative is used, "min. brine out" in menu 5.1.7 "br pmp al set." must be changed to a suitable value to prevent freezing in the heat exchanger.



## Ventilation recovery

The installation can be supplemented with the exhaust air module FLM to provide ventilation recovery.


- Pipes and other cold surfaces must be insulated with diffusion-proof material to prevent condensation.
- The brine system must be supplied with a pressure expansion vessel (CM3). If there is a level vessel (CM2) this should be replaced.



## Under floor heating systems

The external circulation pump is dimensioned for the under floor heating system's demand.


To ensure a heating supply during hot water production, the heating system can be supplemented with a NIBE UKV vessel, e.g. when there is a water coil in the FTX ventilation.



## Two or more climate systems


When more than one climate system, with a lower temperature, is to be heated up, the following connection can be used. The shunt valve lowers the temperature to, for example, the under floor heating system.

The ECS 40/ECS 41 accessory is required for this connection.



## Pool

Charging of the pool is controlled by the pool sensor. In the case of low pool temperatures, the shuttle valve reverses direction and opens towards the pool exchanger. The POOL 40 accessory is required for this connection.



# 5 Electrical connections

## General

All electrical equipment, except the outdoor sensors, room sensors and the current sensors are ready connected at the factory.


- Disconnect the heat pump before insulation testing the house wiring.
- If the building is equipped with an earth-fault breaker, F1155PC should be equipped with a separate one.
- If a miniature circuit breaker is used this should have at least motor characteristic "C". See page 61 for fuse size.
- Electrical wiring diagrams for the heat pump, see separate installation handbook for electrical wiring diagrams.
- Communication and sensor cables to external connections must not be laid close to high current cables.
- The minimum area of communication and sensor cables to external connections must be 0.5 mm<sup>2</sup> up to 50 m, for example EKKX or LiYY or equivalent.
- When cable routing in F1155PC, cable grommets (e.g. UB1-UB3, marked in image) must be used. In UB1-UB3 the cables are inserted through the heat pump from the back to the front.

### NOTE

- The switch (SF1) must not be moved to "I" or "Δ" until the boiler has been filled with water. Component parts of the product can be damaged.

### NOTE

- Electrical installation and service must be carried out under the supervision of a qualified electrician. Cut the current with the circuit breaker before carrying out any servicing. Electrical installation and wiring must be carried out in accordance with the stipulations in force.



## Miniature circuit-breaker

The heat pump operating circuit and a large proportion of its internal components are internally fused by a miniature circuit breaker (FA1).

## Temperature limiter

The temperature limiter (FD1) cuts the power to the electric additional heat if the temperature exceeds 89°C and is reset manually.

## Resetting

The temperature limiter (FD1) is accessible behind the front cover. Reset the temperature limiter by pressing the button (FD1-SF2) using a small screwdriver.

## Accessibility, electrical connection

The plastic cap of the electrical boxes is opened using a screwdriver.




### NOTE


- The cover for the input card is opened without a tool.

## Removing the cover, input circuit board


1. Unscrew the screws and angle out the cover.



2. Pull off the cover.




3. Pull off the cover.




### Removing the hatch, electrical cabinet

1. Disconnect the contacts.




2. Unscrew the screws and angle out the cover.



### Cable lock

Use a suitable tool to release/lock cables in the heat pump terminal blocks.



## Connections



### NOTE




To prevent interference, unscreened communication and/or sensor to external connections cables must not be laid closer than 20 cm to high voltage cable when cable routing.

### Power connection

F1155PC must be installed with a disconnection option on the supply cable. Minimum cable area must be sized according to the fuse rating used. Enclosed cable for incoming supply electricity is connected to terminal block X1 on the immersion heater board (AA1). All installations must be carried out in accordance with current norms and directives.

**NOTE**

F1155PC is not reconnectable between 1-phase and 3-phase.

**Connection 3x400V****Connection 1x230V**

If separate supply to the compressor and immersion heater is required, see section "Switch for external blocking of addition and/or compressor" on page 26.

**Tariff control**

If the voltage to the immersion heater and/or the compressor disappears during a certain period, there must also be blocking via the AUX-input, see "Connection options - Possible selection for AUX inputs" page 25

**Connecting external operating voltage for the control system****NOTE**


Only applies to power connection of 3x400V.

**NOTE**

Mark up any junction boxes with warnings for external voltage.

If you wish to connect external operating voltage for the control system to F1155PC on the immersion heater circuit board (AA1) the edge connector at AA1:X2 must be moved to AA1:X9 (as illustrated).

Operating voltage (1x230V ~ 50Hz) is connected to AA1:X11 (as illustrated).




## Outside sensor

Install the outdoor temperature sensor (BT1) in the shade on a wall facing north or north-west, so it is unaffected by the morning sun for example.

Connect the sensor to terminal block X6:1 and X6:2 on the input board (AA3). Use a twin core cable of at least 0.5 mm<sup>2</sup> cable area.

If a conduit is used it must be sealed to prevent condensation in the sensor capsule.




## Temperature sensor, hot water charging

The temperature sensor, hot water charging (BT6) is placed in the submerged tube on the water heater.

Connect the sensor to terminal block X6:7 and X6:8 on the input board (AA3). Use a 2 core cable of at least 0.5 mm<sup>2</sup> cable area.

Hot water charging is activated in menu 5.2 or in the start guide.




## Temperature sensor, hot water top

A temperature sensor for hot water top (BT7) can be connected to F1155PC via soft inputs for showing the water temperature at the top of the tank.

See page 25 for connecting the sensor.


## Temperature sensor, external flow line

If temperature sensor, external flow line (BT25) needs to be used, connect it to terminal block X6:5 and X6:6 on the input card (AA3). Use a 2 core cable of at least 0.5 mm<sup>2</sup> cable area.



## Temperature sensor, external return line

If temperature sensor, external return line (BT71) needs to be used, connect it to one of the AUX inputs on the input board (AA3). Use a 2 core cable of at least 0.5 mm<sup>2</sup> cable area.



## Room sensor

F1155PC is supplied with a room sensor enclosed (BT50). The room sensor has up to three functions:


1. Show current room temperature in F1155PC's display.
2. Option of changing the room temperature in °C.
3. Makes it possible to change/stabilise the room temperature.

Install the sensor in a neutral position where the set temperature is required. A suitable location is on a free inner wall in a hall approx. 1.5 m above the floor. It is important that the sensor is not obstructed from measuring the correct room temperature by being located, for example, in a recess, between shelves, behind a curtain, above or close to a heat source, in a draft from an external door or in direct sunlight. Closed radiator thermostats can also cause problems.

The heat pump operates without the sensor, but if one wishes to read off the accommodation's indoor temperature in F1155PC's display, the sensor must be installed. Connect the room sensor to X6:3 and X6:4 on the input board (AA3).

If the sensor is to be used to change the room temperature in °C and/or to change/stabilise the room temperature, the sensor must be activated in menu 1.9.4.


If the room sensor is used in a room with under floor heating it should only have an indicative function, not control of the room temperature.



#### Caution

Changes of temperature in accommodation take time. For example, short time periods in combination with underfloor heating will not give a noticeable difference in room temperature.

## Settings



### Electrical addition - maximum output

| F1155PC | Max    | Number of connection steps |
|---------|--------|----------------------------|
| 1x230V  | 4.5 kW | 9                          |
| 3x400V  | 6.5 kW | 13                         |

#### Setting max electrical output

Setting maximum output in the electric additional heat is done in menu 5.1.12.

The table displays the total phase current for the immersion heater at start up. If an immersion heater has already been started and is not used for its full capacity the values in the table can be changed because the control initially uses this immersion heater.

### 3x400V, F1155PC

| Max electrical addition (kW) | Max phase current L1(A) | Max phase current L2(A) | Max phase current L3(A) |
|------------------------------|-------------------------|-------------------------|-------------------------|
| 0.0                          | –                       | –                       | –                       |
| 0.5                          | 2.2                     | –                       | –                       |
| 1.0                          | –                       | 4.3                     | –                       |
| 1.5                          | 2.2                     | 4.3                     | –                       |
| 2.0                          | –                       | –                       | 8.7                     |
| 2.5                          | 2.2                     | –                       | 8.7                     |
| 3.0                          | –                       | 4.3                     | 8.7                     |
| 3.5                          | 2.2                     | 4.3                     | 8.7                     |
| 4.0                          | 7.5                     | 4.3                     | 7.5                     |
| 4.5                          | 9.7                     | 4.3                     | 7.5                     |
| 5.0                          | 7.5                     | –                       | 16.2                    |
| 5.5                          | 9.7                     | –                       | 16.2                    |
| 6.0                          | 7.5                     | 4.3                     | 16.2                    |
| 6.5                          | 9.7                     | 4.3                     | 16.2                    |

### 1x230V, F1155PC

| Max electrical addition (kW) | Max phase current L1(A) |
|------------------------------|-------------------------|
| 0.0                          | –                       |
| 0.5                          | 2.2                     |
| 1.0                          | 4.3                     |
| 1.5                          | 6.5                     |
| 2.0                          | 8.6                     |
| 2.5                          | 10.8                    |
| 3.0                          | 13.0                    |
| 3.5                          | 15.2                    |
| 4.0                          | 17.3                    |
| 4.5                          | 19.5                    |

If the current sensors are connected, the heat pump monitors the phase currents and allocates the electrical steps automatically to the least loaded phase.

### Emergency mode

When the heat pump is set to emergency mode (SF1 is set to  $\Delta$ ) only the most necessary functions are activated.

- The compressor is off and heating is managed by the immersion heater.
- Hot water is not produced.
- The load monitor is not connected.



#### NOTE

The switch (SF1) must not be moved to "I" or " $\Delta$ " until F1155PC has been filled with water. Components in the product can be damaged.

## Power in emergency mode


### 3x400V for F1155PC

| kW  | 1   | 2   | 3   | 4   | 5   | 6   |
|-----|-----|-----|-----|-----|-----|-----|
| 0.5 | on  | off | off | off | off | off |
| 1.0 | off | off | on  | off | off | off |
| 1.5 | on  | off | on  | off | off | off |
| 2.0 | off | off | off | off | on  | off |
| 2.5 | on  | off | off | off | on  | off |
| 3.0 | off | off | on  | off | on  | off |
| 3.5 | on  | off | on  | off | on  | off |
| 4.0 | off | on  | on  | off | off | on  |
| 4.5 | on  | on  | on  | off | off | on  |
| 5.0 | off | on  | off | off | on  | on  |
| 5.5 | on  | on  | off | off | on  | on  |
| 6.0 | off | on  | on  | off | on  | on  |
| 6.5 | on  | on  | on  | off | on  | on  |

### 1x230V for F1155PC

| kW  | 1   | 2   | 3   | 4   | 5   | 6   |
|-----|-----|-----|-----|-----|-----|-----|
| 0.5 | on  | off | off | off | off | off |
| 1.0 | off | off | on  | off | off | off |
| 1.5 | on  | off | on  | off | off | off |
| 2.0 | off | off | off | off | on  | on  |
| 2.5 | on  | off | off | off | on  | off |
| 3.0 | off | off | on  | off | on  | off |
| 3.5 | on  | off | on  | off | on  | off |
| 4.0 | off | off | on  | off | on  | on  |
| 4.5 | on  | off | on  | off | on  | on  |

### 1x230V and 3x400V for F1155PC




AA1-SF2

The image shows the dip-switch (AA1-SF2) in the factory setting, that is 3.5 kW for F1155PC.

## Emergency mode thermostat

The supply temperature in emergency mode is set using a thermostat (FD1-BT30). It can be set to 35 (pre-set, for example under floor heating) or 45 °C (for example radiators).



## Optional connections

### Load monitor

When many electrical appliances are connected in the property at the same time as the electric additional heat is operating, there is a risk of the property's main fuse tripping. The heat pump has integrated load monitors that control the electrical steps for the electrical addition by redistributing the power between the different phases or disengaging the electrical addition in event of overload in a phase. If the overload remains despite the electrical addition being disengaged, the compressor winds down. Reconnection occurs when other current consumption is reduced.




## Connecting current sensors

A current sensor should be installed on each incoming phase conductor in to the distribution box to measure the current. The distribution box is an appropriate installation point.

Connect the current sensors to a multi-core cable in an enclosure next to the electrical distribution unit. The multi-core cable between the enclosure and the heat pump must have a cable area of at least 0.5 mm<sup>2</sup>.


Connect the cable to the input board (AA3) on terminal X4:1-4 block - where X4:1 is the common terminal block for the three current sensors.

The size of the property's main fuse is set in menu 5.1.12.



## NIBE Uplink™

Connect the network connected cable (straight, Cat.5e UTP) with RJ45-contact (male) to RJ45 contact (female) on the rear of the heat pump.



## External connection options

F1155PC has software controlled inputs and outputs on the input card (AA3), for connecting the external switch function or sensor. This means that when an external switch function or sensor is connected to one of six special connections, the correct function must be selected to the correct connection in the software in F1155PC.





### Caution

If an external switch function or sensor is connected to F1155PC, the function to use input or output must be selected in menu 5.4, see page 48.

Selectable inputs on the input board for these functions are:

|      |          |
|------|----------|
| AUX1 | X6:9-10  |
| AUX2 | X6:11-12 |
| AUX3 | X6:13-14 |
| AUX4 | X6:15-16 |
| AUX5 | X6:17-18 |

Selectable outputs are AA3:X7.



The example above uses the inputs AUX1 (X6:9-10) and AUX2 (X6:11-12) on the input circuit board (AA3).



### Caution

Some of the following functions can also be activated and scheduled via menu settings.

## Possible selection for AUX inputs

### Temperature sensor, hot water top

A temperature sensor for hot water top can be connected to F1155PC for showing the water temperature at the top of the tank.

The temperature sensor, hot water top (BT7) is connected to the selected input (menu 5.4, see page 48) on terminal block X6 on the input card (AA3) which is located behind the front cover and in a submerged tube on the water heater.

Use a 2 core cable of at least 0.5 mm<sup>2</sup> cable area.

### **Temperature sensor, cooling/heating**

An extra temperature sensor (BT74) can be connected to F1155PC in order to determine when it is time to switch between heating and cooling operation.

The temperature sensor is connected to the selected input (menu 5.4) on terminal block X6 on the input board (AA3) which is located behind the front cover and is positioned in a suitable place in the climate system.

Use a 2 core cable of at least 0.5 mm<sup>2</sup> cable area.

### **Switch for external blocking of addition and/or compressor**

Blocking for addition heat and compressor is connected on two different AUX inputs.

If external blocking of additional heat and/or compressor is wanted, this can be connected to terminal block X6 on the input board (AA3), which is positioned behind the front cover.

The additional heat and/or the compressor are disconnected by connecting a potential-free switch function to the input selected in menu 5.4, see page 48.

External blocking of addition and compressor can be combined.

A closed contact results in the electrical output being disconnected.

### **Contact for external tariff blocking**

In those cases where external tariff blocking is used, it can be connected to terminal block X6 on the input board (AA3), which is positioned behind the front cover.

Tariff blocking means that the additional heat, the compressor, the heating and hot water are blocked by connecting a potential-free switch function to the input selected in menu 5.4, see page 48.

Closed switch means that tariff blocking is activated.



#### **NOTE**

When tariff blocking is activated, the min. supply line does not apply.

### **Switch for "SG ready"**



#### **NOTE**

This function can only be used in mains networks that support the "SG Ready"-standard.  
"SG Ready" requires two AUX inputs.

In cases where this function is required, it must be connected to terminal block X6 on the input card (AA3).

"SG Ready" is a smart form of tariff control where your electricity supplier can affect the indoor, hot water and/or pool temperatures (if applicable) or simply block the additional heat and/or compressor in the heat pump at certain times of the day (can be selected in menu 4.1.5 after the function is activated). Activate the function by connecting potential-free switch functions to two inputs selected in menu 5.4 (SG Ready A and SG Ready B), see page 48.

Closed or open switch means one of the following:

#### ■ **Blocking (A: Closed, B: Open)**

"SG Ready" is active. The compressor in the heat pump and additional heat is blocked like the day's tariff blocking.

#### ■ **Normal mode (A: Open, B: Open)**

"SG Ready" is not active. No effect on the system.

#### ■ **Low price mode (A: Open, B: Closed)**

"SG Ready" is active. The system focuses on costs savings and can for example exploit a low tariff from the electricity supplier or over-capacity from any own power source (effect on the system can be adjusted in the menu 4.1.5).

#### ■ **Overcapacity mode (A: Closed, B: Closed)**

"SG Ready" is active. The system is permitted to run at full capacity at over capacity (very low price) with the electricity supplier (effect on the system is settable in menu 4.1.5).

(A = SG Ready A and B = SG Ready B)

### **Switch for +Adjust**

Using +Adjust, the installation communicates with the underfloor heating's control centre\* and adjusts the heat curve and calculated supply temperature according to the underfloor heating system's reconnection.

Activate the climate system you want +Adjust to affect by highlighting the function and pressing the OK button.

\*Support for +Adjust required



#### **NOTE**

+Adjust must first be selected in menu 5.4 "soft inputs/outputs".



#### **NOTE**

Circuit board AA3 in the installation must have at least "input version" 34 and the software version must have "display version 5539 or later for +Adjust to work. Version can be checked in menu 3.1 under "input version" respectively "display version". New software can be downloaded for free from [www.nibeuplink.com](http://www.nibeuplink.com).



#### **NOTE**

In systems with both underfloor heating and radiators, NIBE ECS 40/41 should be used for optimum operation.

### Switch for external blocking of heating

In those cases where external blocking of heat is used, it can be connected to terminal block X6 on the input board (AA3), which is positioned behind the front cover.

Heating operation is disconnected by connecting a potential-free switch function to the input selected in menu 5.4, see page 48.

A closed switch results in blocked heating operation.



#### NOTE

When heat blocking is activated, the min. supply line does not apply.

### Switch for external forced control of brine pump

In those cases external forced control of brine pump is used, this can be connected to terminal block X6 on the input board (AA3), which is positioned behind the front cover.

The brine pump can be force controlled by connecting a potential free switch function to the input selected in menu 5.4, see page 48.

A closed switch means that the brine pump is active.

### Contact for activation of "temporary lux"

An external switch function can be connected to F1155PC for activation of the hot water function "temporary lux". The switch must be potential-free and connected to the selected input (menu 5.4, see page 48) on terminal block X6 on the input board (AA3).

"temporary lux" is activated for the time that the contact is connected.

### Contact for activation of "external adjustment"

An external contact function can be connected to F1155PC to change the supply temperature and the room temperature.

When the switch is closed the temperature changes in °C (if the room sensor is connected and activated). If a room sensor is not connected or activated, the desired change of "temperature" (heating curve offset) with the number of steps selected is set. The value is adjustable between -10 and +10.

#### ■ climate system 1

The switch must be potential-free and connected to the selected input (menu 5.4, see page 48) on terminal block X6 on the input board (AA3).

The value for the change is set in menu 1.9.2, "external adjustment".

#### ■ climate system 2 to 8

External adjustment for climate systems 2 to 8 requires accessories ((ECS 40 or ECS 41).

See the accessory's installer handbook for installation instructions.

### Contact for activation of fan speed



#### Caution

The external contact function functions only if the accessory FLM is installed and activated.

An external contact function can be connected to F1155PC for activation of one of the four fan speeds. The switch must be potential free and connected to the selected input (menu 5.4, see page 48) on terminal block X6 on the input circuit board (AA3). When the switch closes, the selected fan speed is activated. Normal speed is resumed when the contact is opened again.

### NV 10, pressure/level/flow monitor brine

If the level sensor (accessory NV10) is desired for the brine installation it can be connected on the selected input (menu 5.4, see page 48) on terminal block X6 on the input circuit board (AA3).

Pressure and flow sensors can also be connected to the input.

The input must be closed during normal operation.

### Possible selection for AUX output (potential free variable relay)

It is possible to have an external connection through the relay function via a potential free variable relay (max 2 A) on the input circuit board (AA3), terminal block X7.

Optional functions for external connection:

- Indication of buzzer alarm.
- Controlling ground water pump.
- Cooling mode indication.
- Control of circulation pump for hot water circulation.
- External circulation pump (for heating medium).
- External, reversing valve for hot water.


If any of the above is installed to terminal block X7 it must be selected in menu 5.4, see page 48.

The common alarm is preselected at the factory.



#### NOTE

An accessory board is required if several functions are connected to terminal block X7 at the same time the common alarm is activated).



The picture shows the relay in the alarm position.


When switch (SF1) is in the "⏏" or "⚠" position the relay is in the alarm position.

External circulation pump, ground water pump or hot water circulation pump connected to the buzzer alarm relay as illustrated below.



**NOTE**

Mark up any junction boxes with warnings for external voltage.



**Caution**

The relay outputs can have a max load of 2 A (230V ~).

## Connecting accessories

Instructions for connecting accessories are in the installation instructions provided for the respective accessory. See information at [www.nibe.eu](http://www.nibe.eu) for the list of the accessories that can be used with F1155PC.

# 6 Commissioning and adjusting

## Preparations

1. Ensure that F1155PC has not been damaged during transport.
2. Check that the switch (SF1) is in position "⏻".
3. Check for water in any hot water heater and climate system.



### Caution

Check the miniature circuit-breaker and the motor protection breakers. They may have tripped during transportation.



### NOTE

Do not start the heat pump, if there is a risk that the water in the system has frozen.

## Filling and venting



### Caution

Insufficient venting can damage internal components in F1155PC.

### Filling and venting the climate system

#### Filling

1. Open the filling valve (external, not included with the product). Fill the climate system with water.
2. Open the venting valve (QM22).
3. When the water that exits the venting valve (QM22) is not mixed with air, close the valve. After a while the pressure starts to rise.
4. Close the filling valve when the correct pressure is obtained.

#### Venting



### NOTE

Insufficient venting can cause damage to internal components.

1. Bleed the heat pump via a vent valve and the rest of the climate system via their relevant vent valves.
2. Keep topping up and venting until all air has been removed and the pressure is correct.

### Filling and venting the brine system




### NOTE

Insufficient venting can cause damage to the brine pump.

When filling the brine system, mix the water with anti-freeze in an open container. The mixture should be protected against freezing down to about -15 °C. The brine is filled by connecting a filling pump.







1. Check the brine system for leakage.

2. Connect the filling pump and return line on the brine system's filler connector as illustrated.
3. If alternative 1 (level vessel) is used, close the valve under the level vessel (CM2).
4. Close the three way valve in the filler connector (accessory).
5. Open the valves on the filler connector.
6. Start the filling pump.
7. Fill until liquid enters the return pipe.
8. Close the valves on the filler connector.
9. Open the three way valve in the filler connector.
10. If alternative 1 (level vessel) is used, open the valve under the level vessel (CM2).



|      |                                   |
|------|-----------------------------------|
| XL 1 | Connection, heating medium flow   |
| XL 2 | Connection, heating medium return |
| XL 6 | Connection, brine in              |
| XL 7 | Connection, brine out             |
| XL 9 | Connection, hot water heater      |

## Symbol key

| Symbol  | Meaning          |
|---|------------------|
|  | Shut-off valve   |
|  | Safety valve     |
|  | Level vessel     |
|  | Expansion vessel |
|  | Pressure gauge   |
|  | Particle filter  |

## Start guide



### NOTE

There must be water in the climate system before the switch is set to "I".

1. Set the heat pump's switch (SF1) to "I".
2. Follow the instructions in the start guide in the heat pump display. If the start guide does not start when you start the heat pump, start it manually in menu 5.7.



### TIP

See page 34 for a more in-depth introduction to the heat pump's control system (operation, menus etc.).

If the building is cooled when F1155PC starts, the compressor may not be able to meet the entire demand without having to use additional heating.

## Commissioning

The first time the heat pump is started a start guide is started. The start guide instructions state what needs to be carried out at the first start together with a run through of the heat pump's basic settings.

The start guide ensures that the start-up is carried out correctly and cannot be bypassed. The start guide can be started later in menu 5.7.



### Caution


As long as the start guide is active, no function in the installation will start automatically.

The guide will appear at each installation re-start until it is deselected on the last page.

## Operation in the start guide

A. Page

B. Name and menu number



C. Option / setting

### A. Page

Here you can see how far you have come in the start guide.

Scroll between the pages of the start guide as follows:

1. Turn the control knob until one of the arrows in the top left corner (at the page number) has been marked.
2. Press the OK button to skip between the pages in the start guide.

### B. Name and menu number

Read what menu in the control system this page of the start guide is based on. The digits in brackets refer to the menu number in the control system.

If you want to read more about affected menus either consult the help menu or read the user manual.

### C. Option / setting

Make settings for the system here.

### D. Help menu



In many menus there is a symbol that indicates that extra help is available.

To access the help text:

1. Use the control knob to select the help symbol.
2. Press the OK button.

The help text often consists of several windows that you can scroll between using the control knob.

## Post adjustment and venting

### Pump adjustment, automatic operation

#### Brine side

To set the correct flow in the brine system, the brine pump must run at the correct speed. F1155PC has a brine pump that can be automatically controlled in standard mode. Certain functions and accessories may require that they are run manually and the correct speed must then be set, see section Pump adjustment, manual operation.

This automatic control occurs when the compressor is running and sets the speed of the brine pump to obtain the optimal temperature difference between the supply and return lines. For passive cooling operation, for example, the brine pump must run at a set speed, which is set in menu 5.1.9.

#### Heating medium side

To set the correct flow in the heating medium system, the heating medium pump must run at the correct speed. F1155PC has a heating medium pump that can be automatically controlled in standard mode. Certain functions and accessories may require that they are run manually and the correct speed must then be set, see section Pump adjustment, manual operation.

This automatic control occurs when the compressor is running and sets the speed of the heating medium pump, for the present operating mode, to obtain the optimal temperature difference between the supply and return lines. During heating operation, the set DOT (dimensioned outdoor temperature) and temperature differential in menu 5.1.14 are used instead. If necessary, the maximum speed of the circulation pump can be limited in menu 5.1.11.

### Pump adjustment, manual operation

#### Brine side


F1155PC has a brine pump that is automatically controlled. If a manual speed is required, open menu 5.1.9 (see page 42) and deactivate "auto" and set the pump's speed according to the diagram below.



#### Caution

When passive cooling is used, the brine pump speed must be set in menu 5.1.9.

#### F1155PC




#### Heating medium side

F1155PC has a heating medium that is automatically controlled. If a manual speed is required, open menu 5.1.11 (see page 43) and deactivate "auto" and set the pump's speed according to the diagram below.




#### Caution

When passive cooling is used, the heating medium pump speed must be set in menu 5.1.11.



#### F1155PC



#### Readjusting, venting, heat medium side

Air is initially released from the hot water and venting may be necessary. If gurgling sounds can be heard from the heat pump or climate system, the entire system will require additional venting.




## Readjusting, venting, collector side

### Level vessel

Check the fluid level in the level vessel (CM2). If the fluid level has dropped, top up the system.


1. Close the valve under the vessel.
2. Disconnect the connection on top of the vessel.
3. Fill with brine until approx 2/3 of the vessel is full.
4. Reconnect the connector at the top of the vessel.
5. Open the valve under the vessel.



If the pressure in the system needs to be raised, it is raised by closing the valve on the incoming main line when the brine pump (GP2) is running and the level vessel (CM2) is open, so that liquid is drawn down from the vessel.

### Expansion vessel

If a pressure expansion vessel (CM3) is used instead of a level vessel, the pressure level is checked. If the pressure drops, the system should be replenished.



## Post adjusting the room temperature

If the required room temperature is not obtained, re-adjustment may be necessary.



### Cold weather conditions

- When the room temperature is too low, increase "heating curve" in menu 1.9.1.1 by one increment.
- When the room temperature is too high, reduce "heating curve" in menu 1.9.1.1 by one increment.

### Warm weather conditions

- When the room temperature is too low, increase "temperature" (offset heating curve) in menu 1.1.1 by one increment.
- When the room temperature is too high, reduce "temperature" (offset heating curve) in menu 1.1.1 by one increment.

## Setting the cooling/heating curve



### heating curve

Setting range: 0 - 15

Default value: 9

### cooling curve

Setting range: 0 - 9


Default value: 0

You can select heating or cooling in the **curve** menu. The next menu (heating curve/cooling curve) shows the heating and cooling curves for your house. The task of the curve is to give an even indoor temperature, regardless of the outdoor temperature, and thereby energy efficient operation. It is from these heat curves that the heat pump's control computer determines the temperature of the water to the system, the supply temperature, and therefore the indoor temperature. Select the curve and read off how the supply temperature changes at different outdoor temperatures here. The number to the far right of "system" displays which system you have selected the heating curve/cooling curve for.

### Curve coefficient

The slopes of the heating /cooling curves indicate how many degrees the supply temperature is to be increased/reduced when the outdoor temperature drops/increases. A steeper slope means a higher supply temperature for heating or a lower supply temperature for cooling at a certain outdoor temperature.





The optimum slope depends on the climate conditions in your location, if the house has radiators or under floor heating and how well insulated the house is.

The curve is set when the heating installation is installed, but may need adjusting later. Normally, the curve will not need further adjustment.



#### Caution

In the event of making fine adjustments of the indoor temperature, the curve must be offset up or down instead, this is done in menu 1.1 **temperature**.

### Curve offset

An offset of the curve means that the supply temperature changes as much for all the outdoor temperatures, e.g. that a curve offset of +2 steps increases the supply temperature by 5 °C at all outdoor temperatures.

### Flow line temperature– maximum and minimum values

Because the flow line temperature cannot be calculated higher than the set maximum value or lower than the set minimum value the heating curve flattens out at these temperatures.



#### Caution

Underfloor heating systems are normally **max flow line temperature** set between 35 and 45 °C.

Must be restricted with underfloor cooling min. flow line temp. to prevent condensation.

Check the max temperature for your floor with your installer/floor supplier.

The figure at the end of the curve indicates the curve slope. The figure beside the thermometer gives the curve offset. Use the control knob to set a new value. Confirm the new setting by pressing the OK button.

Curve 0 is an own curve created in menu 1.9.7.

### To select another curve (slope):



#### NOTE

If you only have one climate system, the number of the curve is already marked when the menu window opens.

1. Select the climate system (if more than one) for which the curve is to be changed.

2. When the climate system selection has been confirmed, the curve number is marked.
3. Press the OK button to access the setting mode
4. Select a new curve. The curves are numbered from 0 to 15, the greater the number, the steeper the slope and the greater the supply temperature. Curve 0 means that **own curve** (menu 1.9.7) is used.
5. Press the OK button to exit the setting.

### To read off a curve:

1. Turn the control knob so that the ring on the shaft with the outdoor temperature is marked.
2. Press the OK button.
3. Follow the grey line up to the curve and out to the left to read off the value for the supply temperature at the selected outdoor temperature.
4. You can now select to take read outs for different outdoor temperatures by turning the control knob to the right or left and read off the corresponding flow temperature.
5. Press the OK or Back button to exit read off mode.



#### TIP

Wait 24 hours before making a new setting, so that the room temperature has time to stabilise.

If it is cold outdoors and the room temperature is too low, increase the curve slope by one increment.


If it is cold outdoors and the room temperature is too high, lower the curve slope by one increment.

If it is warm outdoors and the room temperature is too low, increase the curve offset by one increment.

If it is warm outdoors and the room temperature is too high, lower the curve offset by one increment.

# 7 Control - Introduction

## Display unit



### A Display

Instructions, settings and operational information are shown on the display. The easy-to-read display and menu system, facilitates navigation between the different menus and options to set the comfort or obtain the information you require.

### B Status lamp

The status lamp indicates the status of the heat pump. It:

- lights green during normal operation.
- lights yellow in emergency mode.
- lights red in the event of a deployed alarm.

### C OK button

The OK button is used to:

- confirm selections of sub menus/options/set values/page in the start guide.

### D Back button

The back button is used to:

- go back to the previous menu.
- change a setting that has not been confirmed.

### E Control knob

The control knob can be turned to the right or left. You can:

- scroll in menus and between options.
- increase and decrease the values.
- change page in multiple page instructions (for example help text and service info).

### F Switch (SF1)

The switch assumes three positions:

- On (I)
- Standby (⏻)
- Emergency mode (⚠)

Emergency mode must only be used in the event of a fault on the heat pump. In this mode, the compressor switches off and the immersion heater engages. The heat pump display is not illuminated and the status lamp illuminates yellow.

### G USB port


The USB port is hidden beneath the plastic badge with the product name on it.

The USB port is used to update the software.

Visit <http://www.nibeuplink.com> and click the "Software" tab to download the latest software for your installation.

## Menu system

When the door to the heat pump is opened, the menu system's four main menus are shown in the display as well as certain basic information.



### Menu 1 - INDOOR CLIMATE

Setting and scheduling the indoor climate. See information in the help menu or user manual.

### Menu 2 - HOT WATER

Setting and scheduling hot water production. See information in the help menu or user manual.

This menu only appears if a water heater is docked to the heat pump.

### Menu 3 - INFO

Display of temperature and other operating information and access to the alarm log. See information in the help menu or user manual.

### Menu 4 - HEAT PUMP

Setting time, date, language, display, operating mode etc. See information in the help menu or user manual.


### Menu 5 - SERVICE

Advanced settings. These settings are only intended for installers or service engineers. The menu is visible when the Back button is pressed for 7 seconds, when you are in the start menu. See page 40.

## Symbols in the display

The following symbols can appear in the display during operation.

| Symbol | Description  |
|--------|--|
|        | This symbol appears by the information sign if there is information in menu 3.1 that you should note.  |
|        | These two symbols indicate whether the compressor or addition is blocked in F1155PC.<br><br>These can, for example, be blocked depending on which operating mode is selected in menu 4.2, if blocking is scheduled in menu 4.9.5 or if an alarm has occurred that blocks one of them.<br><br>Blocking the compressor.<br>Blocking additional heat. |
|        | This symbol appears if periodic increase or lux mode for the hot water is activated.   |
|        | This symbol indicates whether "holiday setting" is active in 4.7.  |
|        | This symbol indicates whether F1155PC has contact with NIBE Uplink™.   |
|        | This symbol indicates the actual speed of the fan if the speed has changed from the normal setting.<br><br>Accessory NIBE FLM required.  |
|        | This symbol indicates whether solar heating is active.<br><br>Accessory needed.  |
|        | This symbol indicates whether pool heating is active.<br><br>Accessory needed.   |
|        | This symbol indicates whether cooling is active.<br><br>Accessory needed.  |



## Operation

To move the cursor, turn the control knob to the left or right. The marked position is white and/or has a turned up tab.



## Selecting menu

To advance in the menu system select a main menu by marking it and then pressing the OK button. A new window then opens with sub menus.

Select one of the sub menus by marking it and then pressing the OK button.

## Selecting options



Alternative

In an options menu the current selected option is indicated by a green tick.

To select another option:

1. Mark the applicable option. One of the options is pre-selected (white).
2. Press the OK button to confirm the selected option. The selected option has a green tick.

## Setting a value




Values to be changed


To set a value:

1. Mark the value you want to set using the control knob. 01
2. Press the OK button. The background of the value becomes green, which means that you have accessed the setting mode. 01
3. Turn the control knob to the right to increase the value and to the left to reduce the value. 04
4. Press the OK button to confirm the value you have set. To change and return to the original value, press the Back button. 04

## Use the virtual keyboard



In some menus where text may require entering, a virtual keyboard is available.




Depending on the menu, you can gain access to different character sets which you can select using the control knob. To change character table, press the Back button. If a menu only has one character set the keyboard is displayed directly.

When you have finished writing, mark "OK" and press the OK button.

## Scroll through the windows

A menu can consist of several windows. Turn the control knob to scroll between the windows.



## Scroll through the windows in the start guide



Arrows to scroll through window in start guide

1. Turn the control knob until one of the arrows in the top left corner (at the page number) has been marked.
2. Press the OK button to skip between the steps in the start guide.

## Help menu



In many menus there is a symbol that indicates that extra help is available.

To access the help text:

1. Use the control knob to select the help symbol.
2. Press the OK button.

The help text often consists of several windows that you can scroll between using the control knob.

# 8 Control - Menus

## Menu 1 - INDOOR CLIMATE

|                    |                     |                              |
|--------------------|---------------------|------------------------------|
| 1 - INDOOR CLIMATE | 1.1 - temperature   | 1.1.1 - heating              |
|                    |                     | 1.1.2 - cooling              |
|                    | 1.2 - ventilation * |                              |
|                    | 1.3 - scheduling    | 1.3.1 - heating              |
|                    |                     | 1.3.2 - cooling              |
|                    |                     | 1.3.3 - ventilation *        |
|                    | 1.9 - advanced      | 1.9.1 - curve                |
|                    |                     | 1.9.1.1 heating curve        |
|                    |                     | 1.9.1.2 - cooling curve      |
|                    |                     | 1.9.2 - external adjustment  |
|                    |                     | 1.9.3 - min. flow line temp. |
|                    |                     | 1.9.3.1 - heating            |
|                    |                     | 1.9.3.2 - cooling            |
|                    |                     | 1.9.4 - room sensor settings |
|                    |                     | 1.9.5 - cooling settings     |
|                    |                     | 1.9.6 - fan return time *    |
|                    |                     | 1.9.7 - own curve            |
|                    |                     | 1.9.7.1 - heating            |
|                    |                     | 1.9.7.2 - cooling            |
|                    |                     | 1.9.8 - point offset         |
|                    |                     | 1.9.9 - night cooling        |
|                    |                     | 1.9.11 - +Adjust             |

## Menu 2 - HOT WATER

|               |                             |
|---------------|-----------------------------|
| 2 - HOT WATER | 2.1 - temporary lux         |
|               | 2.2 - comfort mode          |
|               | 2.3 - scheduling            |
|               | 2.9 - advanced              |
|               | 2.9.1 - periodic increase   |
|               | 2.9.2 - hot water recirc. * |

## Menu 3 - INFO

|          |                        |
|----------|------------------------|
| 3 - INFO | 3.1 - service info     |
|          | 3.2 - compressor info  |
|          | 3.3 - add. heat info   |
|          | 3.4 - alarm log        |
|          | 3.5 - indoor temp. log |

\* Accessories are needed.

# Menu 4 - HEAT PUMP

|               |                       |                               |
|---------------|-----------------------|-------------------------------|
| 4 - HEAT PUMP | 4.1 - plus functions  | 4.1.1 - pool *                |
|               |                       | 4.1.3 - internet              |
|               |                       | 4.1.3.1 - nibe uplink         |
|               |                       | 4.1.3.8 - tcp/ip settings     |
|               |                       | 4.1.3.9 - proxy settings      |
|               |                       | 4.1.4 - sms *                 |
|               |                       | 4.1.5 - SG Ready              |
|               |                       | 4.1.6 - smart price adaption  |
|               | 4.2 - op. mode        |                               |
|               | 4.3 - my icons        |                               |
|               | 4.4 - time & date     |                               |
|               | 4.6 - language        |                               |
|               | 4.7 - holiday setting |                               |
|               | 4.9 - advanced        | 4.9.1 - op. prioritisation    |
|               |                       | 4.9.2 - auto mode setting     |
|               |                       | 4.9.3 - degree minute setting |
|               |                       | 4.9.4 - factory setting user  |
|               |                       | 4.9.5 - schedule blocking     |

\* Accessory needed.

## Menu 5 - SERVICE

### Overview

|             |                               |                                       |
|-------------|-------------------------------|---------------------------------------|
| 5 - SERVICE | 5.1 - operating settings      | 5.1.1 - hot water settings *          |
|             |                               | 5.1.2 - max flow line temperature     |
|             |                               | 5.1.3 - max diff flow line temp.      |
|             |                               | 5.1.4 - alarm actions                 |
|             |                               | 5.1.5 - fan sp. exhaust air *         |
|             |                               | 5.1.7 - br pmp al set.                |
|             |                               | 5.1.8 - operating mode brine pump     |
|             |                               | 5.1.9 - brine pump speed              |
|             |                               | 5.1.10 - op. mod heat med pump        |
|             |                               | 5.1.11 - pump speed heating medium    |
|             |                               | 5.1.12 - internal electrical addition |
|             |                               | 5.1.14 - flow set. climate system     |
|             |                               | 5.1.22 - heat pump testing            |
|             |                               | 5.1.24 - blockFreq                    |
|             | 5.2 - system settings         |                                       |
|             | 5.3 - accessory settings      | 5.3.1 - FLM *                         |
|             |                               | 5.3.2 - shunt controlled add. heat *  |
|             |                               | 5.3.3 - extra climate system *        |
|             |                               | 5.3.4 - solar heating *               |
|             |                               | 5.3.6 - step controlled add. heat     |
|             |                               | 5.3.8 - hot water comfort *           |
|             |                               | 5.3.11 - modbus *                     |
|             | 5.4 - soft in/outputs         |                                       |
|             | 5.5 - factory setting service |                                       |
|             | 5.6 - forced control          |                                       |
|             | 5.7 - start guide             |                                       |
|             | 5.8 - quick start             |                                       |
|             | 5.9 - floor drying function   |                                       |
|             | 5.10 - change log             |                                       |

\* Accessory needed.

Go to the main menu and hold the Back button in for 7 seconds to access the Service menu.

### Sub-menus

Menu **SERVICE** has orange text and is intended for the advanced user. This menu has several sub-menus. Status information for the relevant menu can be found on the display to the right of the menus.

**operating settings** Operating settings for the heat pump.

**system settings** System settings for the heat pump, activating accessories etc.

**accessory settings** Operational settings for different accessories.

**soft in/outputs** Setting software controlled in and outputs on the input circuit board (AA3).

**factory setting service** Total reset of all settings (including settings available to the user ) to default values.

**forced control** Forced control of the different components in the heat pump.

**start guide** Manual start of the start guide which is run the first time the heat pump is started.

**quick start** Quick starting the compressor.



#### NOTE

Incorrect settings in the service menus can damage the heat pump.

### Menu 5.1 - operating settings

Operating settings can be made for the heat pump in the sub menus.



## Menu 5.1.1 - hot water settings

### **economy**

Setting range start temp. economy: 5 – 55 °C

Factory setting start temp. economy: 38 °C

Setting range stop temp. economy: 5 – 60 °C

Factory setting stop temp. economy: 48 °C

### **normal**

Setting range start temp. normal: 5 – 60 °C

Factory setting start temp. normal: 41 °C

Setting range stop temp. normal: 5 – 65 °C

Factory setting stop temp. normal: 50 °C

### **luxury**

Setting range start temp. lux: 5 – 70 °C

Factory setting start temp. lux: 44 °C

Setting range stop temp. lux: 5 – 70 °C

Factory setting stop temp. lux: 53 °C

### **stop temp. per. increase**

Setting range: 55 – 70 °C

Factory setting: 55 °C

### **high power**

Setting range: on/off

Factory setting: off

Here you set the start and stop temperature of the hot water for the different comfort options in menu 2.2 as well as the stop temperature for periodic increase in menu 2.9.1.

For a higher charge output click the high output selection.

With "high power" activated, the hot water is charged at a higher output than in the standard mode and thus gives a higher hot water capacity.

## Menu 5.1.2 - max flow line temperature

### **climate system**

Setting range: 5-70 °C

Default value: 60 °C

Set the maximum supply temperature for the climate system here. If the installation has more than one climate system, individual maximum supply temperatures can be set for each system. Climate systems 2 - 8 cannot be set to a higher max supply temperature than climate system 1.



### **Caution**

Underfloor heating systems are normally **max flow line temperature** set between 35 and 45 °C.

Check the max floor temperature with your floor supplier.

## Menu 5.1.3 - max diff flow line temp.

### **max diff compressor**

Setting range: 1 – 25 °C

Default value: 10 °C

### **max diff addition**

Setting range: 1 – 24 °C

Default value: 3 °C

Here you set the maximum permitted difference between the calculated and actual supply temperature during compressor respectively add. heat mode. Max diff. additional heat can never exceed max diff. compressor

### **max diff compressor**

When the current supply temperature **deviates** from the set value compared to that calculated, the heat pump is forced to stop irrespective of the degree-minute value.

If the current supply temperature **exceeds** the calculated flow with set value, the degree minute value is set to 0. The compressor in the heat pump stops when there is only a heating demand.

### **max diff addition**

If "addition" is selected and activated in menu 4.2 and the present supply temp **exceeds** the calculated with set value, the additional heat is forced to stop.

## Menu 5.1.4 - alarm actions

Select how you want the heat pump to alert you that there is an alarm in the display here.

The different alternatives are that the heat pump stops producing hot water (default setting) and/or reduces the room temperature.



### **Caution**

If no alarm action is selected, it can result in higher energy consumption in the event of an alarm.

### Menu 5.1.5 - fan sp. exhaust air (accessory is required)

#### **normal and speed 1-4**

Setting range: 0 – 100 %

Set the speed for the five different selectable speeds for the fan here.



#### **Caution**

An incorrectly set ventilation flow can damage the house and may also increase energy consumption.

### Menu 5.1.7 - br pmp al set.

#### **min. brine out**

Setting range: -12 – 15 °C

Default value: -8 °C

#### **min. brine out**

Set the temperature at which the heat pump is to activate the alarm for low temperature in outgoing brine. If "automatic reset" is selected, the alarm resets when the temperature has increased by 1 °C below the set value.

The compressor winds down when the brine temperature reaches the set minimum value for brine temperature. Compressor control attempts to maintain the brine at a temperature 2 ° greater than the set value for brine out.

### Menu 5.1.8 - operating mode brine pump

#### **op. mode**

Setting range: intermittent, continuous, 10 days continuous

Default value: intermittent

Set the operating mode of the brine pump here.

**intermittent:** The brine pump starts approx. 20 seconds before and stops approx. 20 seconds after the compressor.

**continuous:** Continuous operation.

**10 days continuous:** Continuous operation for 10 days. Then the pump shifts to intermittent operation.



#### **TIP**

You can use "10 days continuous" at start-up to obtain continuous circulation during a start-up time in order to make it easier to bleed the system.

### Menu 5.1.9 - brine pump speed

#### **brine pump speed**

Setting range: auto / manual

Default value: auto

#### **speed in wait mode**

Setting range: 1 - 100 %

Factory setting: 70 %

#### **manual**

Setting range: 1 - 100 %

Factory setting: 100 %

#### **speed passive cooling**

Setting range: 1 - 100 %

Factory setting: 100 %

Set the speed of the brine pump here. Select "auto" if the speed of the brine pump is to be regulated automatically (factory setting) for optimal operation.

For manual operation of the brine pump deactivate "auto" and set the value to between 1 and 100%.

The brine pump speed during passive cooling operation (the brine pump then runs in manual operation) can also be set here.

If the continuous operating mode (see "Menu 5.1.8 - operating mode brine pump", page 42) has been selected one can also choose waiting mode. The circulation pump continues to run while the compressor stops.

### Menu 5.1.10 - op. mod heat med pump

#### **op. mode**

Setting range: auto, intermittent

Default value: auto

Set the operating mode of the heating medium pump here.

**auto:** The heating medium pump runs according to the current operating mode for F1155PC.

**intermittent:** The heating medium pump starts approx. 20 seconds before and stops at the same time as the compressor.

### Menu 5.1.11 - pump speed heating medium

#### **Operating status**

Setting range: auto / manual

Default value: auto

#### **Manual setting, hot water**

Setting range: 1 - 100 %

Default values: 70 %

#### **Manual setting, heating**

Setting range: 1 - 100 %

Default values: 70 %

#### **Manual setting, pool**

Setting range: 1 - 100 %

Default values: 70 %

#### **wait mode**

Setting range: 1 - 100 %

Default values: 30 %

#### **max. allowed speed**

Setting range: 50 - 100 %

Default values: 100 %

#### **speed passive cooling**

Setting range: 1 - 100 %

Default values: 70 %

Set the speed at which the heating medium pump is to operate in the present operating mode. Select "auto" if the speed of the heating medium pump is to be regulated automatically (factory setting) for optimal operation.

If "auto" is activated for heating operation you can also make the setting "max. allowed speed", which restricts the heating medium pump and does not allow it to run at a higher speed than the set value.

For manual operation of the heating medium pump, deactivate "auto" for the current operating mode and set the value to between 0 and 100% (the previously set value for "max. allowed speed" no longer applies).

"**heating**" means operating mode heating for the heating medium pump.

"**wait mode**" means heating or cooling operating modes for the heating medium pump but when the heat pump has neither a need for compressor operation nor electrical addition and slows down.

"**hot water**" means operating mode hot water for the heating medium pump.

"**pool**" (accessory required) means operating mode pool heating for the heating medium pump.

"**cooling**" means operating mode cooling for the heating medium pump.

The heat pump speed during active and passive cooling operation respectively (the brine pump then runs in manual operation) can also be set here.

### Menu 5.1.12 - internal electrical addition

#### **fuse size**

Setting range: 1 - 200 A

Default values: 25 A

#### **transformation ratio**

Setting range: 300 - 3000

Factory setting: 300

Here you set the max. electrical output of the internal electrical addition in F1155PC and the fuse size for the installation.

Here you can also check which current sensor is installed on which incoming phase to the property (this requires current sensors to be installed, see page 24). This is achieved by marking "detect phase order" and pressing the OK button.

The results of these checks appear just below where the checks were activated.

### Menu 5.1.14 - flow set. climate system

#### **presettings**

Setting range: radiator, floor heat., rad. + floor heat., DOT °C

Default value: radiator

Setting range DOT: -40.0 – 20.0 °C

Factory setting DOT: -18.0 °C

#### **own setting**

Setting range dT at DOT: 0.0 – 25.0

Factory setting dT at DOT: 10.0

Setting range DOT: -40.0 – 20.0 °C

Factory setting DOT: -18.0 °C

The type of heating distribution system the heating medium pump (GP1) works towards is set here.

dT at DOT is the difference in degrees between flow and return temperatures at dimensioned outdoor temperature.

## Menu 5.1.22 - heat pump testing



### NOTE

This menu is intended for testing F1155PC according to different standards.

Use of this menu for other reasons may result in your installation not functioning as intended.

This menu contains several sub-menus, one for each standard.

## Menu 5.1.24 - blockFreq

### **blockFreq 1**

Selectable setting range in the display:

start: 17 – 115 Hz

stop: 22 – 120 Hz

Maximum setting range: 50 Hz.

### **blockFreq 2**

Selectable setting range in the display:

start: 17 – 115 Hz

stop: 22 – 120 Hz

Maximum setting range: 50 Hz.

Here you can set a frequency range where the compressor is blocked. The parameters for the setting range differ depending on which product is controlled by the setting.



### NOTE

A large blocked frequency range can cause the compressor to run jerkily.

## Menu 5.2 - system settings

Make different system settings for the heat pump here, e.g. which accessories are installed.

If the water heater is docked to F1155PC hot water charging must be activated here.

There are two ways of activating connected accessories. You can either highlight the alternative in the list or use the automatic function "search installed acc."

### **search installed acc.**

Mark "search installed acc." and press the OK button to automatically find connected accessories for F1155PC.



### Caution

Certain accessories are not found automatically but must be ticked off by hand, see menu 5.4.



### NOTE

Only mark the option for ground water pump if the accessory AXC 40 is to be used to control the circulation pump.

## Menu 5.3 - accessory settings

The operating settings for accessories that are installed and activated are made in the sub-menus for this.

### Menu 5.3.1 - FLM

#### **continuous pump op.**

Setting range: on/off

Factory setting: off

#### **time between defrosts**

Setting range: 1 – 30 h

Default value: 10 h

#### **months btwn filter alarms**

Setting range: 1 – 12

Default value: 3

#### **activate cooling**

Setting range: on/off

Factory setting: off

**continuous pump op.:** Select for continuous operation of the circulation pump in the exhaust air module.

**time between defrosts:** Set the minimum time that must pass between defrostings of the heat exchanger in the exhaust air module.

When the exhaust air module is in operation the heat exchanger is cooled so that ice builds up on it. When too much ice builds up the heat transfer capacity of the heat exchanger is reduced and defrosting is required. Defrosting warms up the heat exchanger so that the ice melts and runs off via the condensation hose.

**months btwn filter alarms:** Set how many months should pass before the heat pump informs that it is time to clean the filter in the exhaust air module.

Clean the exhaust air module's air filter regularly, how often depends on the amount of dust in the ventilation air.

**activate cooling:** Activate cooling via the exhaust air module here. When the function has been activated, the cooling settings are displayed in the menu system.

See the accessory installation instructions for function description.

### Menu 5.3.2 - shunt controlled add. heat

#### ***prioritised additional heat***

Setting range: on/off

Factory setting: off

#### ***start diff additional heat***

Setting range: 0 – 2000 GM

Default values: 400 GM

#### ***minimum running time***

Setting range: 0 – 48 h

Default value: 12 h

#### ***min temp.***

Setting range: 5 – 90 °C

Default value: 55 °C

#### ***mixing valve amplifier***

Setting range: 0.1 – 10.0

Default value: 1.0

#### ***mixing valve step delay***

Setting range: 10 – 300 s

Default values: 30 s

Set when the addition is to start, the minimum run time and the minimum temperature for external addition with shunt here. External addition with shunt is for example a wood/oil/gas/pellet boiler.

You can set shunt valve amplification and shunt valve waiting time.

Selecting "prioritised additional heat" uses the heat from the external additional heat instead of the heat pump. The shunt valve is regulated as long as heat is available, otherwise the shunt valve is closed.

See the accessory installation instructions for function description.

### Menu 5.3.3 - extra climate system

#### ***use in heating mode***

Setting range: on/off

Factory setting: on

#### ***use in cooling mode***

Setting range: on/off

Factory setting: off

#### ***mixing valve amplifier***

Setting range: 0.1 – 10.0

Default value: 1.0

#### ***mixing valve step delay***

Setting range: 10 – 300 s

Default values: 30 s

In menu 5.3.3, you choose the climate system (2 - 8) you wish to set. In the next menu you can make settings for the climate system that you have selected.

If the heat pump is connected to more than one climate system, condensation may occur in these, if they are not intended for cooling.

To prevent condensation, check that "use in heating mode" is checked for the climate systems that are not intended for cooling. This means that the sub-shunts to the extra climate systems close, when cooling operation is activated.



#### **Caution**

This setting option only appears if "passive/active cooling 2-pipe" or "passive cooling 2-pipe" is activated in menu 5.2.

The shunt amplification and shunt waiting time for the different extra climate systems that are installed are also set here.

See the accessory installation instructions for function description.

## Menu 5.3.4 - solar heating

### ***start delta-T***

Setting range: 1 - 40 °C

Default value: 8 °C

### ***stop delta-T***

Setting range: 0 - 40 °C

Default value: 4 °C

### ***max. tank temperature***

Setting range: 5 - 110 °C

Default value: 95 °C

### ***max. solar collector temp.***

Setting range: 80 - 200 °C

Default value: 125 °C

### ***anti-freeze temperature***

Setting range: -20 - +20 °C

Default value: 2 °C

### ***start solar collector cooling***

Setting range: 80 - 200 °C

Default value: 110 °C

### ***passive recharging - activation temperature***

Setting range: 50 - 125 °C

Default value: 110 °C

### ***passive recharging - deactivation temperature***

Setting range: 30 - 90 °C

Default value: 50 °C

### ***active recharging - activating dT***

Setting range: 8 - 60 °C

Default value: 40 °C

### ***active recharging - deactivating dT***

Setting range: 4 - 50 °C

Default value: 20 °C

**start delta-T, stop delta-T:** Here you can set the temperature difference between solar panel and solar tank at which the circulation pump is to start and stop.

**max. tank temperature, max. solar collector temp.:** Here you can set the maximum temperatures in tank respectively solar panel at which the circulation pump is to stop. This is to protect against excess temperatures in the solar tank.

If the unit has an anti-freeze function, solar panel cooling and/or passive/active recharging you can activate them here. When the function has been activated, you can make settings for them. "solar panel cooling", "passive recharging" and "active recharging" cannot be combined, only one function can be activated.

### ***freeze protection***

**anti-freeze temperature:** Here you can set the temperature in the solar panel at which the circulation pump is to start to prevent freezing.

### ***solar panel cooling***

**start solar collector cooling:** If the temperature in the solar panel is greater than this setting at the same time that the temperature in the solar tank is greater than the set maximum temperature, the external function for cooling is activated.

### ***passive recharging***

**activation temperature:** If the temperature in the solar panel is greater than this setting, the function activates. The function is blocked for an hour if the temperature of the brine in the heat pump (BT10) is higher than the set value for "max brine in" in menu 5.1.7

**deactivation temperature:** If the temperature in the solar panel is less than this setting, the function deactivates.

### ***active recharging***

**activating dT:** If the difference between the temperature in the solar panel (BT53) and the temperature of the brine in the heat pump (BT10) is greater than this setting the function is activated. The function is blocked for an hour if the temperature of the brine in the heat pump (BT10) is higher than the set value for "max brine in" in menu 5.1.7

**deactivating dT:** If the difference between the temperature in the solar panel (BT53) and the temperature of the brine in the heat pump (BT10) is less than this setting the function deactivates.

See the accessory installation instructions for function description.

### Menu 5.3.6 - step controlled add. heat

#### ***start diff additional heat***

Setting range: 0 – 2000 GM

Default values: 400 GM

#### ***diff. between additional steps***

Setting range: 0 – 1000 GM

Default values: 100 GM

#### ***max step***

Setting range  
(binary stepping deactivated): 0 – 3

Setting range  
(binary stepping activated): 0 – 7

Default value: 3

#### ***binary stepping***

Setting range: on/off

Factory setting: off

Make settings for step controlled addition here. Step controlled addition is for example an external electric boiler.

It is possible, for example, to select when the additional heat is to start, to set the maximum number of permitted steps and whether binary stepping is to be used.

When binary stepping is deactivated (off), the settings refer to linear stepping.

See the accessory installation instructions for function description.

### Menu 5.3.8 - hot water comfort

#### ***activating imm heater***

Setting range: on/off

Factory setting: off

#### ***activ. imm heat in heat mode***

Setting range: on/off

Factory setting: off

#### ***activating the mixing valve***

Setting range: on/off

Factory setting: off

#### ***outgoing hot water***

Setting range: 40 - 65 °C

Default value: 55 °C

#### ***mixing valve amplifier***

Setting range: 0.1 – 10.0

Default value: 1.0

#### ***mixing valve step delay***

Setting range: 10 – 300 s

Default values: 30 s

Make settings for the hot water comfort here.

See the accessory installation instructions for function description.

**activating imm heater:** The immersion heater is activated here if installed in the water heater.

**activ. imm heat in heat mode:** Activate here whether the immersion heater in the tank (required if the alternative above is activated) will be permitted to charge hot water, if the compressors in the heat pump prioritise heating.

**activating the mixing valve:** Activate here whether a mixer valve for limiting the temperature of hot water from the water heater is installed.

If this alternative has been activated, you can set the outgoing hot water temperature, shunt amplification and shunt waiting time for the mixer valve.

**outgoing hot water:** Set the temperature at which the mixing valve is to restrict hot water from the water heater.

See the accessory installation instructions for function description.



### Menu 5.3.11 - modbus

#### **address**

Factory setting: address 1

From and including Modbus 40 version 10 the address can be set between 1 - 247. Earlier versions have a static address.

See the accessory installation instructions for function description.

### Menu 5.4 - soft in/outputs

Here you can select which in/output on the terminal block (X6) the external contact function (see installation manual) must be connected to.

Here you can select the in/output on the input circuit board (AA3) the external contact function (page 24) is to be connected to.

Selectable inputs on terminal block AUX1-5 (AA3-X6:9-18) and output AA3-X7 (on the input circuit board).

### Menu 5.5 - factory setting service

All settings can be reset (including settings available to the user) to default values here.



#### **NOTE**

When resetting, the start guide is displayed the next time the heat pump is restarted.

### Menu 5.6 - forced control

You can force control the different components in the heat pump and any connected accessories here.



#### **NOTE**

Forced control is only intended to be used for troubleshooting purposes. Using the function in any other way may cause damage to the components in your climate system.

### Menu 5.7 - start guide

When the heat pump is started for the first time the start guide starts automatically. Start it manually here. See page 30 for more information about the start guide.

### Menu 5.8 - quick start

It is possible to start the compressor from here.



#### **Caution**

There must be a heating or hot water demand to start the compressor.



#### **Caution**

Do not quick start the compressor too many times over a short period of time as this may damage the compressor and its surrounding equipment.

### Menu 5.9 - floor drying function

#### **length of period 1 – 7**

Setting range: 0 – 30 days

Factory setting, period 1 – 3, 5 – 7: 2 days

Factory setting, period 4: 3 days

#### **temp. period 1 – 7**

Setting range: 15 – 70 °C

Default value:

|                |       |
|----------------|-------|
| temp. period 1 | 20 °C |
| temp. period 2 | 30 °C |
| temp. period 3 | 40 °C |
| temp. period 4 | 45 °C |
| temp. period 5 | 40 °C |
| temp. period 6 | 30 °C |
| temp. period 7 | 20 °C |

Set the function for under floor drying here.

You can set up to seven period times with different calculated flow temperatures. If less than seven periods are to be used, set the remaining period times to 0 days.

Mark the active window to activate the underfloor drying function. A counter at the bottom shows the number of days the function has been active. The function counts degree minutes as during normal heating operation but for the supply temperatures that are set for the respective period.



#### **NOTE**

During under floor drying, the heating medium pump in 100% runs, regardless of the setting in menu 5.1.10.



**TIP**

If operating mode "add. heat only" is to be used, select it in menu 4.2.

For a more even flow temperature the addition can be started earlier by setting "start for addition" in menus 4.9.2 to -80. When set under floor drying periods have stopped, reset the menus 4.2 and 4.9.2 as per previous settings.

**Menu 5.10 - change log**

Read off any previous changes to the control system here.

The date, time and ID no. (unique to certain settings) and the new set value is shown for every change.

**NOTE**

The change log is saved at restart and remains unchanged after factory setting.

# 9 Service

## Service actions



### NOTE

Servicing should only be carried out by persons with the necessary expertise.

When replacing components on F1155PC only replacement parts from NIBE may be used.

## Emergency mode





### NOTE

The switch (SF1) must not be moved to "I" or "Δ" until F1155PC has been filled with water. Component parts in the product can be damaged.

Emergency mode is used in event of operational interference and in conjunction with service. Hot water is not produced in emergency mode.

Emergency mode is activated by setting switch (SF1) in mode "Δ". This means that:

- The status lamp illuminates yellow.
- The display is not lit and the control computer is not connected.
- The temperature at the immersion heater is controlled by the thermostat (FD1-BT30). It can be set either to 35 or 45 °C.
- The compressor and the brine system are off and only the heating medium pump and the electric additional heat are active. The additional heat power in emergency mode is set in the immersion heater board (AA1). See page 23 for instructions.



## Draining the water heater (if docked)

The siphon principle is used to empty the hot water heater. This can be done either via the drain valve on the incoming cold water pipe or by inserting a hose into the cold water connection.

## Draining the climate system

In order to carry out service on the climate system, it may be easier to drain the system first. This can be done in different ways depending on what needs doing:



### NOTE

There may be some hot water when draining the heating medium side/climate system. There is a risk of scalding.

## Draining the heating medium side in the cooling module

If, for example, the heating medium pump requires replacing or the cooling module requires servicing, drain the heating medium side as follows:

1. Close the shut-off valves to heating medium side (QM31) and (QM32).
2. Connect a hose to the bleed valve (QM1) and open the valve. Some liquid will run out.

3. Air must get into the system for the remaining liquid to run out. To let in air, slacken off the connection slightly at the shut-off valve (QM32) that joins the heat pump with the cooling module.

When the heating medium side is drained, the required service can be performed and/or replacement of any components carried out.

### **Draining the heating medium system in the heat pump**

If the heat pump requires servicing, drain the heating medium side as follows:

1. Close the shut-off valves outside the heat pump for the heating medium side (return and flow line).
2. Connect a hose to the bleed valve (QM1) and open the valve. Some liquid will run out.
3. Air must get into the system for the remaining liquid to run out. To let in air, slacken off the connection slightly at the shut-off valve that joins the heat pump with the cooling module (XL2).

When the heating medium side is empty the requisite service can be carried out.

### **Draining the entire climate system**

If the entire climate system requires draining, do this as follows:

1. Connect a hose to the bleed valve (QM1) and open the valve. Some liquid will run out.
2. Air must get into the system for the remaining liquid to run out. To allow air in, unscrew the bleed screw on the highest radiator in the house.

When the climate system is empty the requisite service can be carried out.

### **Emptying the brine system**

In order to service the brine system it may be easier to drain the system first. This can be done in different ways depending on what needs doing:

#### **Draining the brine system in the cooling module**

If, for example, the brine pump requires replacing or the cooling module requires servicing, drain the brine system by:

1. Close the shut-off valves to brine system (QM33) and (QM34).
2. Connect a hose to the drain valve (QM2), place the other opening of the hose in a container and open the valve. A small amount of brine will flow into the container.
3. Air must get into the system for the remaining brine to run out. To let in air, slacken off the connection slightly at the shut-off valve (QM33) that joins the heat pump with the cooling module.

When the brine side is empty the requisite service can be carried out.

#### **Draining the brine system in the heat pump**

If the heat pump requires servicing, drain the brine system by:


1. Close the shut-off valve outside the heat pump for the brine system.
2. Connect a hose to the drain valve (QM2), place the other opening of the hose in a container and open the valve. A small amount of brine will flow into the container.
3. Air must get into the system for the remaining brine to run out. To let in air, slacken off the connection slightly at the shut-off valve that joins the brine side with the heat pump at connection (XL7).

When the brine side is empty the requisite service can be carried out.

### **Helping the circulation pump to start**

1. Shut off, F1155PC by setting the switch ((SF1)) to "O".
2. Remove the front cover
3. Remove the cover for the cooling module.
4. Loosen the venting screw (QM5) with a screwdriver. Hold a cloth around the screwdriver blade as a small amount of water may run out.
5. Insert a screwdriver and turn the pump motor around.
6. Screw in the venting screw (QM5).
7. Start F1155PC by setting the switch (SF1) to "I" and check whether the circulation pump works.

It is usually easier to start the circulation pump with F1155PC running, switch (SF1) set to "I". If the circulation pump is helped to start while F1155PC is running, be prepared for the screwdriver to jerk when the pump starts.



The image shows an example of what a circulation pump can look like.


## Temperature sensor data

| Temperature (°C) | Resistance (kOhm) | Voltage (VDC) |
|------------------|-------------------|---------------|
| -40              | 351.0             | 3.256         |
| -35              | 251.6             | 3.240         |
| -30              | 182.5             | 3.218         |
| -25              | 133.8             | 3.189         |
| -20              | 99.22             | 3.150         |
| -15              | 74.32             | 3.105         |
| -10              | 56.20             | 3.047         |
| -5               | 42.89             | 2.976         |
| 0                | 33.02             | 2.889         |
| 5                | 25.61             | 2.789         |
| 10               | 20.02             | 2.673         |
| 15               | 15.77             | 2.541         |
| 20               | 12.51             | 2.399         |
| 25               | 10.00             | 2.245         |
| 30               | 8.045             | 2.083         |
| 35               | 6.514             | 1.916         |
| 40               | 5.306             | 1.752         |
| 45               | 4.348             | 1.587         |
| 50               | 3.583             | 1.426         |
| 55               | 2.968             | 1.278         |
| 60               | 2.467             | 1.136         |
| 65               | 2.068             | 1.007         |
| 70               | 1.739             | 0.891         |
| 75               | 1.469             | 0.785         |
| 80               | 1.246             | 0.691         |
| 85               | 1.061             | 0.607         |
| 90               | 0.908             | 0.533         |
| 95               | 0.779             | 0.469         |
| 100              | 0.672             | 0.414         |

## Remove the motor on the shuttle valve

The motor on the shuttle valve can be removed to facilitate servicing.

- Disconnect the cable from the motor and remove the motor from the shuttle valve as illustrated.



## Pulling out the cooling module

The cooling module can be pulled out for service and transport.



### NOTE

Shut off the heat pump and turn off the current on the safety breaker.



### Caution

The cooling module is easy to remove if it is drained first (see page 50).




### Caution


Remove the front cover according to the description on page 9.

- 1 Close the shut-off valves (QM31), (QM32), (QM33) and (QM34).

Drain the compressor module according to the instructions on page 50




- ② Pull off the lock catches.




- ③ Disconnect the pipe connection at the shut-off valve (QM31).


- ④ Remove the two screws.



- ⑤ Remove the connection from the base card (AA2) using a screwdriver.




- ⑥ Disconnect the switches (A), (B) and (E) from the underside of the base card cabinet.



- ⑦ Disconnect the connector (C) from the immersion heater circuit board (AA1) using a screwdriver.

- ⑧ Disconnect the connector (D) from the joint circuit board (AA100).

- ⑨ Carefully pull out the cooling module.




#### TIP

The cooling module is installed in reverse order.




#### NOTE



At reinstallation, the supplied O-rings must replace the existing ones at the connections to the heat pump (see image).



## USB service outlet




F1155PC is equipped with a USB socket in the display unit. This USB socket can be used to connect a USB memory to update the software, save logged information and handle the settings in F1155PC.



When a USB memory is connected a new menu (menu 7) appears in the display.

## Menu 7.1 - update firmware



This allows you to update the software in F1155PC.



### NOTE

For the following functions to work the USB memory must contain files with software for F1155PC from NIBE.

The fact box at the top of the display shows information (always in English) of the most probable update that the update software has selected from the USB memory.

This information states which product the software is intended for, the software version and general information about them. If you wish to select another file than the one selected, the correct file can be selected by "choose another file".

### start updating

Select "start updating" if you want to start the update. You are asked whether you really want to update the software. Respond "yes" to continue or "no" to undo.

If you responded "yes" to the previous question the update starts and you can now follow the progress of the update on the display. When the update is complete F1155PC restarts.



### NOTE

A software update does not reset the menu settings in F1155PC.



### NOTE


If the update is interrupted before it is complete (for example power cut etc.) the software can be reset to the previous version if the OK button is held in during start up until the green lamp starts to illuminate (takes about 10 seconds).

### choose another file



Select "choose another file" if you do not want to use the suggested software. When you scroll through the files, information about the marked software is shown in a fact box just as before. When you have selected a file with the OK button you will return to the previous page (menu 7.1) where you can choose to start the update.

### Menu 7.2 - logging




Setting range: 1 s – 60 min  
Factory setting range: 5 s

Here you can choose how current measurement values from F1155PC should be saved onto a log file on the USB memory.

1. Set the desired interval between loggings.
2. Tick "activated".
3. The present values from F1155PC are saved in a file in the USB memory at the set interval until "activated" is unticked.

**NOTE**  
Untick "activated" before removing the USB memory.

### Menu 7.3 - manage settings



Here you can manage (save as or retrieve from) all the menu settings (user and service menus) in F1155PC with a USB memory.

Via "save settings" you save the menu settings to the USB memory in order to restore them later or to copy the settings to another F1155PC.

**NOTE**  
When you save the menu settings to the USB memory you replace any previously saved settings on the USB memory.

Via "recover settings" you reset all menu settings from the USB memory.

**NOTE**  
Reset of the menu settings from the USB memory cannot be undone.


# 10 Disturbances in comfort

In most cases, the heat pump notes operational interference (operational interference can lead to disturbance in comfort) and indicates this with alarms and shows action instructions in the display.

## Info menu

All the heat pump measurement values are gathered under menu 3.1 in the heat pump menu system. Looking through the values in this menu can often simplify finding the source of the fault. See help menu or user manual for more information about menu 3.1.

## Manage alarm



In the event of an alarm, some kind of malfunction has occurred, which is indicated by the status lamp changing from green continuously to red continuously. In addition, an alarm bell appears in the information window.

### Alarm

In the event of an alarm with a red status lamp a malfunction has occurred that the heat pump cannot remedy itself. In the display, by turning the control knob and pressing the OK button, you can see the type of alarm it is and reset it. You can also choose to set the heat pump to aid mode.

**info / action** Here you can read what the alarm means and receive tips on what you can do to correct the problem that caused the alarm.

**reset alarm** In most cases it is enough to select "reset alarm" to correct the problem that caused the alarm. If a green light illuminates after selecting "reset alarm" the alarm has been remedied. If a red light is still visible and a menu called "alarm" is visible in the display, the problem that caused the alarm remains. If the alarm disappears and then returns, see the troubleshooting section (page 56).

**aid mode** "aid mode" is a type of emergency mode. This means that the heat pump produces heat and/or hot water despite there being some kind of problem. This can mean that the heat pump's compressor is not running. In this case the immersion heater produces heat and/or hot water.



#### NOTE

To select aid mode an alarm action must be selected in the menu 5.1.4.



#### Caution

Selecting "aid mode" is not the same as correcting the problem that caused the alarm. The status lamp will therefore continue to be red.

## Troubleshooting

If the operational interference is not shown in the display the following tips can be used:

### Basic actions

Start by checking the following possible fault sources:

- The switch's (SF1) position.
- Group and main fuses of the accommodation.
- The property's earth circuit breaker.
- The heat pump's miniature circuit breaker (FA1).
- The heat pump's temperature limiter (FD1).
- Correctly set load monitor (if installed).

### Low hot water temperature or a lack of hot water

This part of the fault-tracing chapter only applies if the heat pump is docked to the hot water heater.

- Closed or choked filling valve for the hot water heater.
  - Open the valve.
- Heat pump in incorrect operating mode.
  - If mode "manual" is selected, select "addition".
- Large hot water consumption.
  - Wait until the hot water has heated up. Temporarily increased hot water capacity (temporary lux) can be activated in menu 2.1.
- Too low hot water setting.
  - Enter menu 2.2 and select a higher comfort mode.
- Too low or no operating prioritisation of hot water.
  - Enter menu 4.9.1 and increase the time for when hot water is to be prioritised.



### Low room temperature

- Closed thermostats in several rooms.
  - Set the thermostats to max, in as many rooms as possible. Adjust the room temperature via menu 1.1, instead of choking the thermostats.
- Heat pump in incorrect operating mode.
  - Enter menu 4.2. If mode "auto" is selected, select a higher value on "stop heating" in menu 4.9.2.
  - If mode "manual" is selected, select "heating". If this is not enough, select "addition".
- Too low set value on the automatic heating control.
  - Enter menu 1.1 "temperature" and adjust the offset heating curve up. If the room temperature is only low in cold weather the curve slope in menu 1.9.1 "heating curve" needs adjusting up.
- Too low or no operating prioritisation of heat.
  - Enter menu 4.9.1 and increase the time for when heating is to be prioritised.
- "Holiday mode" activated in menu 4.7.
  - Enter menu 4.7 and select "Off".
- External switch for changing the room heating activated.
  - Check any external switches.
- Air in the climate system.
  - Vent the climate system (see page 29).
- Closed valves (QM20), (QM32) to the climate system.
  - Open the valves.

### High room temperature

- Too high set value on the automatic heating control.
  - Enter menu 1.1 (temperature) and reduce the offset heating curve. If the room temperature is only high in cold weather the curve slope in menu 1.9.1 "heating curve" needs adjusting down.
- External switch for changing the room heating activated.
  - Check any external switches.

### Uneven room temperature.

- Incorrectly set heating curve.
  - Adjust the heating curve in menu 1.9.1.
- Too high set value on "dT at DOT"..
  - Enter menu 5.1.14 (flow set. climate system) and reduce the value of "dT at DOT".
- Uneven flow over the radiators.
  - Adjust the flow distribution between the radiators.

### Low system pressure

- Not enough water in the climate system.
  - Top up the water in the climate system (see page 29).

### Low or a lack of ventilation

This part of the fault-tracing chapter only applies if the NIBE FLM accessory is installed.

- The ventilation is not adjusted.
  - Order/implement ventilation adjustment.

- Filter (HQ10) blocked.
  - Clean or replace the filter.
- Exhaust air device blocked or throttled down too much.
  - Check and clean the exhaust air devices.
- Fan speed in reduced mode.
  - Enter menu 1.2 and select "normal".
- External switch for changing the fan speed activated.
  - Check any external switches.

### High or distracting ventilation

This part of the fault-tracing chapter only applies if the NIBE FLM accessory is installed.

- The ventilation is not adjusted.
  - Order/implement ventilation adjustment.
- Fan speed in forced mode.
  - Enter menu 1.2 and select "normal".
- External switch for changing the fan speed activated.
  - Check any external switches.
- Filter blocked.
  - Clean or replace the filter.

### The compressor does not start

- There is no heating requirement.
  - The heat pump does not call on heating nor hot water.
- Temperature conditions tripped.
  - Wait until the temperature condition has been re-set.
- Minimum time between compressor starts has not been reached.
  - Wait 30 minutes and check if the compressor has started.
- Alarm tripped.
  - Follow the display instructions.

### Whining noise in the radiators

- Closed thermostats in the rooms and incorrectly set heating curve.
  - Set the thermostats to max in as many rooms as possible. Adjust the heating curve via menu 1.1 instead of choking the thermostats.
- Circulation pump speed set too high.
  - Enter menu 5.1.11 (pump speed heating medium) and reduce the speed of the circulation pump.
- Uneven flow over the radiators.
  - Adjust the flow distribution between the radiators.

### Gurgling sound

This part of the fault-tracing chapter only applies if the NIBE FLM accessory is installed.

- Not enough water in the water seal.
  - Refill the water seal with water.
- Choked water seal.
  - Check and adjust the condensation water hose.

# 11 Accessories

## Accessory card AXC 40

An accessory card is required if step controlled addition (e.g. external electric boiler) or if shunt controlled addition (e.g. wood/oil/gas/pellet boiler) is to be connected to F1155PC.

An accessory card is also required if the ground water pump or external circulation pump is connected to F1155PC at the same time that the buzzer alarm is activated.

Part no. 067 060

## Auxiliary relay HR 10

Part no. 067 309

## Base extension EF 45

Part no. 067 152

## Buffer vessel UKV

### UKV 40

Part no. 088 470

### UKV 100

Part no. 088 207

### UKV 200

Part no. 080 300

### UKV 300

Part no. 080 301

### UKV 500

Part no. 080 302

## Communications module MODBUS 40

MODBUS 40 enables F1155PC to be controlled and monitored using a DUC (computer sub-center) in the building. Communication occurs using MODBUS-RTU.

Part no. 067 144

## Communications module SMS 40

SMS 40 enables operation and monitoring of F1155PC, via a GSM module, using a mobile phone via SMS messages. If the mobile telephone also has the Android operating system the mobile application "NIBE Mobile App" can be used.

Part no. 067 073

## Exhaust air module FLM

FLM is an exhaust air module specially designed to combine recovery of mechanical exhaust air with an energy collector in rock.

### FLM

Part no. 067 011

### Bracket pack FLM

Part no. 067 083

## External electric additional heat ELK

These accessories require accessories card AXC 40 (step controlled addition).

### ELK 5

Immersion heater

5 kW, 1 x 230 V

Part no. 069 025

### ELK 8

Immersion heater

8 kW, 1 x 230 V

Part no. 069 026

### ELK 15

Immersion heater

15 kW, 3 x 400 V

Part no. 069 022

### ELK 213

Immersion heater

7-13 kW, 3 x 400 V

Part no. 069 500

## Extra shunt group ECS 40/ECS 41

This accessory is used when F1155PC is installed in houses with two or more different climate systems that require different supply temperatures.

ECS 40 (Max 80 m<sup>2</sup>)      Part no. 067 287

ECS 41 (Min 80 m<sup>2</sup>)      Part no. 067 288

## Filling valve kit KB 32

Filling valve kit for filling brine in the collector hose for rock heat pumps. Includes dirt filter and insulation.

### KB 32 (max 30 kW)

Part no. 089 971

## Level monitor NV 10

Part no. 089 315

## Pool heating POOL 40

POOL 40 is an accessory that enables pool heating with F1155PC.

Part no. 067 062

## Room unit RMU 40

RMU 40 means that control and monitoring of the heat pump can be carried out in a different part of the accommodation to where F1155PC is located.

Part no. 067 064

### **Solar 40**

Solar 40 means that F1155PC (together with VPAS) can be connected to solar heating.

Part no. 067 084

### **Solar 42**

Part no. 067 153

### **Water heater/Accumulator tank**

#### **AHPS**

Accumulator tank with a solar coil (copper) and a combined pre-heating and post-heating coil (stainless steel) for hot water production.

Part no. 056 283

#### **AHP**

Volume expansion vessel that is primarily used for expanding the volume together with AHPS.

Part no. 056 284

#### **VPA 300/200**

Water heater with double-jacketed vessel.

Copper     Part no. 088 710

Enamel     Part no. 088 700

#### **VPA 450/300**

Water heater with double-jacketed vessel.

Copper     Part no. 088 660

Enamel     Part no. 088 670

#### **VPB 200**

Water heater with charge coil.

Placed to the left of F1155PC for easy installation.

Copper     Part no. 088 515

Enamel     Part no. 088 517

Stainless steel     Part no. 088 518

#### **VPB 300**

Water heater with charge coil.

Copper     Part no. 083 009

Enamel     Part no. 083 011

Stainless steel     Part no. 083 010

#### **VPBS 300**

Water heater with charge and solar coil.

Copper     Part no. 083 012

Enamel     Part no. 083 015

### **VPB 500**

Copper lined water heater with charge coil

Part no. 083 220

### **VPAS 300/450**


Water heater with double-jacketed vessel and solar coil.

Copper     Part no. 087 720

Enamel     Part no. 087 710

# 12 Technical data

## Dimensions and setting-out coordinates



\* This dimension applies at 90° angle on the brine pipes (side connection). The dimension can vary approx.  $\pm 100$  mm in height as the brine pipes partially consist of flexible pipes.

## Technical specifications



**1x230V**

| F1155PC  |                  |                                 |
|--|------------------|---------------------------------|
| Electrical data  |                  |                                 |
| Rated voltage  |                  | 230V ~ 50Hz                     |
| Max operating current including 0 – 0.5 kW immersion heater (Recommended fuse rating). | A <sub>rms</sub> | 15(16)                          |
| Max operating current including 1 – 1.5 kW immersion heater (Recommended fuse rating). | A <sub>rms</sub> | 20(20)                          |
| Max operating current including 2 – 2.5 kW immersion heater (Recommended fuse rating). | A <sub>rms</sub> | 24(25)                          |
| Max operating current including 3 – 4 kW immersion heater (Recommended fuse rating).   | A <sub>rms</sub> | 31(32)                          |
| Max operating current including 4.5 kW immersion heater (Recommended fuse rating).     | A <sub>rms</sub> | 33(40)                          |
| <b>Additional power</b>  | kW               | 0.5/1/1.5/2/2.5/3<br>/3.5/4/4.5 |

**3x400V**

| F1155PC  |                  |   |
|--|------------------|---|
| Electrical data  |                  |   |
| Rated voltage  |                  | 400V 3N ~ 50Hz                              |
| Max operating current including 0 kW immersion heater (Recommended fuse rating). | A <sub>rms</sub> | 12(16)                                      |
| <b>Additional power</b>  | kW               | 0.5/1/1.5/2/2.5/3<br>/3.5/4/4.5/5/5.5/6/6.5 |

## 1x230V and 3x400V

| F1155PC   |       |                   |
|---|-------|-------------------|
| Output data according to EN 14511 nominal (50 Hz)   |       |                   |
| <b>0/35</b>   |       |                   |
| Rated output  | kW    | 3.15              |
| Installed electrical output   | kW    | 0.67              |
| COP   |       | 4.72              |
| <b>0/45</b>   |       |                   |
| Rated output  | kW    | 2.87              |
| Installed electrical output   | kW    | 0.79              |
| COP   |       | 3.61              |
| <b>10/35</b>  |       |                   |
| Rated output  | kW    | 4.30              |
| Installed electrical output   | kW    | 0.66              |
| COP   |       | 6.49              |
| <b>10/45</b>  |       |                   |
| Rated output  | kW    | 3.98              |
| Installed electrical output   | kW    | 0.83              |
| COP   |       | 4.79              |
| <b>SCOP according to EN 14825</b>   |       |                   |
| Nominal heating output (designh)  | kW    | 6                 |
| SCOP <sub>EN14825</sub> cold climate, 35 °C / 55 °C   |       | 5.5 / 4.1         |
| SCOP <sub>EN14825</sub> average climate, 35 °C / 55 °C  |       | 5.2 / 4.0         |
| <b>Energy rating, average climate</b>   |       |                   |
| Efficiency class for space heating 35 °C / 55 °C  |       | A++ / A++         |
| Space heating efficiency class of the system 35 °C / 55 °C <sup>1)</sup>                                      |       | A+++ / A+++       |
| Efficiency class hot water / charging profile with water heater   |       | A / XL<br>VPB 300 |
| <b>Sound power level (L<sub>WA</sub>)</b> acc to EN 12102 at 0/35   | dB(A) | 36 – 43           |
| <b>Sound pressure level (L<sub>PA</sub>)</b> calculated values according to EN ISO 11203 at 0/35 and 1m range | dB(A) | 21 – 28           |
| <b>Electrical data</b>  |       |                   |
| Output, Brine pump  | W     | 10 – 87           |
| Output, Heating medium pump   | W     | 2 – 63            |
| IP class  |       | IP21              |
| <b>Refrigerant circuit</b>  |       |                   |
| Type of refrigerant   |       | R407C             |
| Volume  | kg    | 1.16              |
| Cut-out value pressostat HP   | MPa   | 3.2 (32 bar)      |
| Difference pressostat HP  | MPa   | -0.7 (-7 bar)     |
| Cut-out value pressostat LP   | MPa   | 0.15 (1.5 bar)    |
| Difference pressostat LP  | MPa   | 0.15 (1.5 bar)    |
| <b>Brine circuit</b>  |       |                   |
| Energy class Brine pump   |       | low energy        |
| Max system pressure brine   | MPa   | 0.45 (4.5 bar)    |
| Min system pressure brine   | MPa   | 0.05 (0.5 bar)    |
| Nominal flow (50 Hz)  | l/s   | 0.18              |
| Max external avail. press at nom flow   | kPa   | 64                |
| Max/Min incoming Brine temp   | °C    | see diagram       |
| Min. outgoing brine temp.   | °C    | -12               |
| <b>Heating medium circuit</b>   |       |                   |
| Energy class circ-pump  |       | low energy        |

| F1155PC                               |     |                |
|---------------------------------------|-----|----------------|
| Max system pressure heating medium    | MPa | 0.45 (4.5 bar) |
| Min system pressure heating medium    | MPa | 0.05 (0.5 bar) |
| Nominal flow (50 Hz)                  | l/s | 0.08           |
| Max external avail. press at nom flow | kPa | 69             |
| Max/Min heating medium temp           | °C  | see diagram    |
| <b>Pipe connections</b>               |     |                |
| Brine ext diam. CU pipe               | mm  | 28             |
| Heating medium ext diam. CU pipes     | mm  | 22             |
| Connection, hot water heater ext diam | mm  | 22             |
| <b>Dimensions and weight</b>          |     |                |
| Width                                 | mm  | 600            |
| Depth                                 | mm  | 620            |
| Height                                | mm  | 1500           |
| Required ceiling height <sup>2)</sup> | mm  | 1670           |
| Weight complete heat pump             | kg  | 155            |
| Weight only cooling module            | kg  | 95             |
| Part number, 1x230V                   |     | 065 279        |
| Part number, 3x400V                   |     | 065 276        |

<sup>1)</sup>Reported efficiency for the system takes the product's temperature regulator into account.


<sup>2)</sup>With feet removed the height is approx. 1650 mm for F1155PC.

## Working range heat pump, compressor operation

The compressor provides a supply temperature up to 65 °C, at 0 °C incoming brine temperature, the remainder (up to 70°C) is obtained using the additional heat.


### F1155PC

This diagram shows the working range below 75 % for F1155PC.




### F1155PC

This diagram shows the working range above 75 % for F1155PC




## Diagram, passive cooling

Passive cooling, 21 °C return temperature nominal flow brine/heating medium



Passive cooling, 23 °C return temperature nominal flow brine/heating medium




## Diagram, dimensioning compressor speed

### Heating mode

Use this diagram to dimension the heat pump. The percentages show approximate compressor speed.

### F1155PC

Specified heating output, kW







### Caution

For operation of F1155PC above 75% compressor speed, unlocking in menu 5.1.24 is required. This can produce a louder noise level than the value stated in the technical specifications.

## Cooling operation




### Caution

To dimension heating dump, see the diagram for heating operation.

## Supply temperature, heating medium 35 °C

### F1155PC


Specified cooling output, kW



## Supply temperature, heating medium 50 °C

### F1155PC

Specified cooling output, kW



# Energy labelling

## Information sheet

|   |     |                  |
|---|-----|------------------|
| Supplier  |     | NIBE AB          |
| Model   |     | F1155PC 1x230V   |
| Model hot water heater  |     | VPB 300          |
| Temperature application   | °C  | 35 / 55          |
| Declared load profile for water heating                         |     | <b>XL</b>        |
| Seasonal space heating energy efficiency class, average climate |     | <b>A++ / A++</b> |
| Water heating energy efficiency class, average climate          |     | <b>A</b>         |
| Rated heat output (P <sub>designh</sub> ), average climate      | kW  | 6                |
| Annual energy consumption space heating, average climate        | kWh | 2,188 / 2,875    |
| Annual energy consumption water heating, average climate        | kWh | 1,697            |
| Seasonal space heating energy efficiency, average climate       | %   | 200 / 150        |
| Water heating energy efficiency, average climate                | %   | 99               |
| Sound power level L <sub>WA</sub> indoors                       | dB  | 42               |
| Rated heat output (P <sub>designh</sub> ), cold climate         | kW  | 6                |
| Rated heat output (P <sub>designh</sub> ), warm climate         | kW  | 6                |
| Annual energy consumption space heating, cold climate           | kWh | 2,481 / 3,287    |
| Annual energy consumption water heating, cold climate           | kWh | 1,697            |
| Annual energy consumption space heating, warm climate           | kWh | 1,408 / 1,852    |
| Annual energy consumption water heating, warm climate           | kWh | 1,697            |
| Seasonal space heating energy efficiency, cold climate          | %   | 211 / 157        |
| Water heating energy efficiency, cold climate                   | %   | 99               |
| Seasonal space heating energy efficiency, warm climate          | %   | 201 / 151        |
| Water heating energy efficiency, warm climate                   | %   | 99               |
| Sound power level L <sub>WA</sub> outdoors                      | dB  | -                |

|   |     |                  |
|---|-----|------------------|
| Supplier  |     | NIBE AB          |
| Model   |     | F1155PC 3x400V   |
| Model hot water heater  |     | VPB 300          |
| Temperature application   | °C  | 35 / 55          |
| Declared load profile for water heating                         |     | <b>XL</b>        |
| Seasonal space heating energy efficiency class, average climate |     | <b>A++ / A++</b> |
| Water heating energy efficiency class, average climate          |     | <b>A</b>         |
| Rated heat output (P <sub>designh</sub> ), average climate      | kW  | 6                |
| Annual energy consumption space heating, average climate        | kWh | 2,188 / 2,875    |
| Annual energy consumption water heating, average climate        | kWh | 1,697            |
| Seasonal space heating energy efficiency, average climate       | %   | 200 / 150        |
| Water heating energy efficiency, average climate                | %   | 99               |
| Sound power level L <sub>WA</sub> indoors                       | dB  | 42               |
| Rated heat output (P <sub>designh</sub> ), cold climate         | kW  | 6                |
| Rated heat output (P <sub>designh</sub> ), warm climate         | kW  | 6                |
| Annual energy consumption space heating, cold climate           | kWh | 2,481 / 3,287    |
| Annual energy consumption water heating, cold climate           | kWh | 1,697            |
| Annual energy consumption space heating, warm climate           | kWh | 1,408 / 1,852    |
| Annual energy consumption water heating, warm climate           | kWh | 1,697            |
| Seasonal space heating energy efficiency, cold climate          | %   | 211 / 157        |
| Water heating energy efficiency, cold climate                   | %   | 99               |
| Seasonal space heating energy efficiency, warm climate          | %   | 201 / 151        |
| Water heating energy efficiency, warm climate                   | %   | 99               |
| Sound power level L <sub>WA</sub> outdoors                      | dB  | -                |

## Data for energy efficiency of the package

|  |    |                |
|--|----|----------------|
| Model  |    | F1155PC 1x230V |
| Model hot water heater   |    | VPB 300        |
| Temperature application  | °C | 35 / 55        |
| Controller, class  |    | VI             |
| Controller, contribution to efficiency   | %  | 4              |
| Seasonal space heating energy efficiency of the package, average climate       | %  | 204 / 154      |
| Seasonal space heating energy efficiency class of the package, average climate |    | <b>A+++</b>    |
| Seasonal space heating energy efficiency of the package, cold climate          | %  | 215 / 161      |
| Seasonal space heating energy efficiency of the package, warm climate          | %  | 205 / 155      |

|  |    |                |
|--|----|----------------|
| Model  |    | F1155PC 3x400V |
| Model hot water heater   |    | VPB 300        |
| Temperature application  | °C | 35 / 55        |
| Controller, class  |    | VI             |
| Controller, contribution to efficiency   | %  | 4              |
| Seasonal space heating energy efficiency of the package, average climate       | %  | 204 / 154      |
| Seasonal space heating energy efficiency class of the package, average climate |    | <b>A+++</b>    |
| Seasonal space heating energy efficiency of the package, cold climate          | %  | 215 / 161      |
| Seasonal space heating energy efficiency of the package, warm climate          | %  | 205 / 155      |

The reported efficiency of the package also takes the controller into account. If an external supplementary boiler or solar heating is added to the package, the overall efficiency of the package should be recalculated.

## Technical documentation

|   |   |                |     |   |                    |      |      |
|---|---|----------------|-----|---|--------------------|------|------|
| Model   |   | F1155PC 1x230V |     |   |                    |      |      |
| Model hot water heater  |   | VPB 300        |     |   |                    |      |      |
| Type of heat pump   | <input type="checkbox"/> Air-water<br><input type="checkbox"/> Exhaust-water<br><input checked="" type="checkbox"/> Brine-water<br><input type="checkbox"/> Water-water |                |     |   |                    |      |      |
| Low-temperature heat pump   | <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No   |                |     |   |                    |      |      |
| Integrated immersion heater for additional heat   | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No   |                |     |   |                    |      |      |
| Heat pump combination heater  | <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No   |                |     |   |                    |      |      |
| Climate   | <input checked="" type="checkbox"/> Average <input type="checkbox"/> Cold <input type="checkbox"/> Warm   |                |     |   |                    |      |      |
| Temperature application   | <input checked="" type="checkbox"/> Average (55 °C) <input type="checkbox"/> Low (35 °C)  |                |     |   |                    |      |      |
| Applied standards   | EN-14825 & EN-16147   |                |     |   |                    |      |      |
| <b>Rated heat output</b>  | Prated  | 5,5            | kW  | <b>Seasonal space heating energy efficiency</b>   | $\eta_s$           | 150  | %    |
| <i>Declared capacity for space heating at part load and at outdoor temperature <math>T_j</math></i> |   |                |     | <i>Declared coefficient of performance for space heating at part load and at outdoor temperature <math>T_j</math></i> |                    |      |      |
| $T_j = -7\text{ °C}$  | Pdh   | 5.0            | kW  | $T_j = -7\text{ °C}$  | COPd               | 3.06 | kW   |
| $T_j = +2\text{ °C}$  | Pdh   | 3.0            | kW  | $T_j = +2\text{ °C}$  | COPd               | 3.97 | kW   |
| $T_j = +7\text{ °C}$  | Pdh   | 2.0            | kW  | $T_j = +7\text{ °C}$  | COPd               | 4.63 | kW   |
| $T_j = +12\text{ °C}$   | Pdh   | 1.2            | kW  | $T_j = +12\text{ °C}$   | COPd               | 4.86 | kW   |
| $T_j = \text{biv}$  | Pdh   | 5.4            | kW  | $T_j = \text{biv}$  | COPd               | 2.84 | kW   |
| $T_j = \text{TOL}$  | Pdh   | 5.4            | kW  | $T_j = \text{TOL}$  | COPd               | 2.84 | kW   |
| $T_j = -15\text{ °C}$ (if TOL < -20 °C)   | Pdh   |                | kW  | $T_j = -15\text{ °C}$ (if TOL < -20 °C)   | COPd               |      | kW   |
| Bivalent temperature  | $T_{\text{biv}}$  | -10            | °C  | Min. outdoor air temperature  | TOL                | -10  | °C   |
| Cycling interval capacity   | Pcyc  |                | kW  | Cycling interval efficiency   | COPcyc             |      | -    |
| Degradation coefficient   | Cdh   | 0.99           | -   | Max supply temperature  | WTOL               | 65   | °C   |
| <i>Power consumption in modes other than active mode</i>  |   |                |     | <i>Additional heat</i>  |                    |      |      |
| Off mode  | $P_{\text{OFF}}$  | 0.002          | kW  | Rated heat output   | Psup               | 0.1  | kW   |
| Thermostat-off mode   | $P_{\text{TO}}$   | 0.007          | kW  |   |                    |      |      |
| Standby mode  | $P_{\text{SB}}$   | 0.007          | kW  | Type of energy input  | Electric           |      |      |
| Crankcase heater mode   | $P_{\text{CK}}$   | 0.009          | kW  |   |                    |      |      |
| <i>Other items</i>  |   |                |     |   |                    |      |      |
| Capacity control  | Variable  |                |     | Rated airflow (air-water)   |                    |      | m³/h |
| Sound power level, indoors/outdoors   | $L_{\text{WA}}$   | 42 / -         | dB  | Nominal heating medium flow   |                    |      | m³/h |
| Annual energy consumption   | $Q_{\text{HE}}$   | 2,875          | kWh | Brine flow brine-water or water-water heat pumps  |                    | 0.68 | m³/h |
| <i>For heat pump combination heater</i>   |   |                |     |   |                    |      |      |
| <b>Declared load profile for water heating</b>  | XL  |                |     | <b>Water heating energy efficiency</b>  | $\eta_{\text{wh}}$ | 99   | %    |
| Daily energy consumption  | $Q_{\text{elec}}$   | 7.73           | kWh | Daily fuel consumption  | $Q_{\text{fuel}}$  |      | kWh  |
| Annual energy consumption   | AEC   | 1,697          | kWh | Annual fuel consumption   | AFC                |      | GJ   |

| Model  |          | F1155PC 3x400V   |     |  |  |          |      |      |   |
|--|----------|--|-----|--|--|----------|------|------|---|
| Model hot water heater   |          | VPB 300  |     |  |  |          |      |      |   |
| Type of heat pump  |          | <div><input type="checkbox"/> Air-water</div> <div><input type="checkbox"/> Exhaust-water</div> <div><input checked="" type="checkbox"/> Brine-water</div> <div><input type="checkbox"/> Water-water</div> |     |  |  |          |      |      |   |
| Low-temperature heat pump  |          | <div><input type="checkbox"/> Yes</div> <div><input checked="" type="checkbox"/> No</div>  |     |  |  |          |      |      |   |
| Integrated immersion heater for additional heat                                |          | <div><input checked="" type="checkbox"/> Yes</div> <div><input type="checkbox"/> No</div>  |     |  |  |          |      |      |   |
| Heat pump combination heater   |          | <div><input checked="" type="checkbox"/> Yes</div> <div><input type="checkbox"/> No</div>  |     |  |  |          |      |      |   |
| Climate  |          | <div><input checked="" type="checkbox"/> Average</div> <div><input type="checkbox"/> Cold</div> <div><input type="checkbox"/> Warm</div>   |     |  |  |          |      |      |   |
| Temperature application  |          | <div><input checked="" type="checkbox"/> Average (55 °C)</div> <div><input type="checkbox"/> Low (35 °C)</div>   |     |  |  |          |      |      |   |
| Applied standards  |          | EN-14825 & EN-16147  |     |  |  |          |      |      |   |
| Rated heat output  |          | Prated   | 5,5 | kW   | Seasonal space heating energy efficiency   |          | ηs   | 150  | % |
| Declared capacity for space heating at part load and at outdoor temperature Tj |          |  |     |  | Declared coefficient of performance for space heating at part load and at outdoor temperature Tj |          |      |      |   |
| Tj = -7 °C   | Pdh      | 5.0  | kW  | Tj = -7 °C                                       |  | COPd     | 3.06 | kW   |   |
| Tj = +2 °C   | Pdh      | 3.0  | kW  | Tj = +2 °C                                       |  | COPd     | 3.97 | kW   |   |
| Tj = +7 °C   | Pdh      | 2.0  | kW  | Tj = +7 °C                                       |  | COPd     | 4.63 | kW   |   |
| Tj = +12 °C  | Pdh      | 1.2  | kW  | Tj = +12 °C                                      |  | COPd     | 4.86 | kW   |   |
| Tj = biv   | Pdh      | 5.4  | kW  | Tj = biv   |  | COPd     | 2.84 | kW   |   |
| Tj = TOL   | Pdh      | 5.4  | kW  | Tj = TOL   |  | COPd     | 2.84 | kW   |   |
| Tj = -15 °C (if TOL < -20 °C)  | Pdh      |  | kW  | Tj = -15 °C (if TOL < -20 °C)                    |  | COPd     |      | kW   |   |
|  |          |  |     |  |  |          |      |      |   |
| Bivalent temperature   | Tbiv     | -10  | °C  | Min. outdoor air temperature                     |  | TOL      | -10  | °C   |   |
| Cycling interval capacity  | Ppsych   |  | kW  | Cycling interval efficiency                      |  | COPcyc   |      | -    |   |
| Degradation coefficient  | Cdh      | 0.99   | -   | Max supply temperature                           |  | WTOL     | 65   | °C   |   |
| Power consumption in modes other than active mode                              |          |  |     |  | Additional heat  |          |      |      |   |
| Off mode   | POFF     | 0.002  | kW  | Rated heat output                                |  | Psup     | 0.1  | kW   |   |
| Thermostat-off mode  | PTO      | 0.007  | kW  |  |  |          |      |      |   |
| Standby mode   | PSB      | 0.007  | kW  | Type of energy input                             |  | Electric |      |      |   |
| Crankcase heater mode  | PCK      | 0.009  | kW  |  |  |          |      |      |   |
| Other items  |          |  |     |  |  |          |      |      |   |
| Capacity control   | Variable |  |     | Rated airflow (air-water)                        |  |          |      | m³/h |   |
| Sound power level, indoors/outdoors  | LWA      | 42 / -   | dB  | Nominal heating medium flow                      |  |          |      | m³/h |   |
| Annual energy consumption  | QHE      | 2,875  | kWh | Brine flow brine-water or water-water heat pumps |  |          | 0.68 | m³/h |   |
| For heat pump combination heater   |          |  |     |  |  |          |      |      |   |
| Declared load profile for water heating  |          | XL   |     | Water heating energy efficiency                  |  | ηwh      | 99   | %    |   |
| Daily energy consumption   | Qelec    | 7.73   | kWh | Daily fuel consumption                           |  | Qfuel    |      | kWh  |   |
| Annual energy consumption  | AEC      | 1,697  | kWh | Annual fuel consumption                          |  | AFC      |      | GJ   |   |

# 13 Item register

## Item register

- A**
  - Accessibility, electrical connection, 19
  - Accessories, 58
  - Alarm, 56
  - Assembly, 8
- B**
  - Back button, 34
  - Brine side, 15
- C**
  - Cable lock, 20
  - Commissioning and adjusting, 29
    - Filling and venting, 29
    - Post adjustment and bleeding, 31
    - Preparations, 29
    - Start guide, 30
  - Connecting accessories, 28
  - Connecting current sensors, 25
  - Connecting external operating voltage for the control system, 21
  - Connecting the climate system, 16
  - Connecting the hot water heater, 16
  - Connections, 20
  - Contact for activation of fan speed, 27
  - Contact for activation of "external adjustment", 27
  - Contact for activation of "temporary lux", 27
  - Contact for external tariff blocking, 26
  - Contact information, 7
  - Control, 34, 38
    - Control - Introduction, 34
    - Control - Menus, 38
  - Control - Introduction, 34
    - Display unit, 34
    - Menu system, 35
  - Control knob, 34
  - Controlling ground water pump, 27
  - Control - Menus, 38
    - Menu 5 - SERVICE, 40
  - Cooling mode indication, 27
  - Cooling section, 13
- D**
  - Data for energy efficiency of the system, 68
  - Delivery and handling, 8
    - Assembly, 8
    - Drawing out the cooling module, 8
    - Installation area, 8
    - Removing the covers, 9
    - Supplied components, 9
    - Transport, 8
  - Diagram, dimensioning compressor speed, 64
  - Diagram, passive cooling output, 64
  - Dimensions and pipe connections, 15
  - Dimensions and setting-out coordinates, 60
  - Display, 34
  - Display unit, 34
    - Back button, 34
    - Control knob, 34
    - Display, 34
    - OK button, 34
    - Status lamp, 34
    - Switch, 34
  - Disturbances in comfort, 56
    - Alarm, 56
    - Manage alarm, 56
    - Troubleshooting, 56
  - Docking alternatives, 16
    - Ground water system, 17
    - Neutralization vessel, 17
    - Pool, 18
    - Two or more climate systems, 18
    - Under floor heating systems, 17
    - Ventilation recovery, 17
  - Draining the climate system, 50
  - Draining the hot water heater, 50
  - Drawing out the cooling module, 8, 52
- E**
  - Electrical addition - maximum output, 23
    - Setting max electrical output, 23
  - Electrical cabinets, 12
  - Electrical connections, 19
    - Accessibility, electrical connection, 19
    - Cable lock, 20
    - Connecting accessories, 28
    - Connecting external operating voltage for the control system, 21
    - Connections, 20
    - Electrical addition - maximum output, 23
    - External connection options, 25
    - General, 19
    - Load monitor, 24
    - Miniature circuit-breaker, 19
    - NIBE Uplink™, 25
    - Optional connections, 24
    - Outdoor sensor, 22
    - Power connection, 20
    - Removing the hatch, electrical cabinet, 20
    - Removing the hatch, input circuit board, 19
    - Room sensor, 22
    - Settings, 23
    - Standby mode, 23
    - Temperature limiter, 19
    - Temperature sensor, external flow line, 22
    - Temperature sensor, hot water charging, 22
  - Emptying the brine system, 51
  - Energy labelling, 66
    - Data for energy efficiency of the package, 68
    - Information sheet, 66–67
    - Technical documentation, 69–70
  - External connection options, 25
    - Contact for activation of fan speed, 27
    - Contact for activation of "external adjustment", 27
    - Contact for activation of "temporary lux", 27
    - Contact for external tariff blocking, 26
    - Controlling ground water pump, 27
    - Cooling mode indication, 27
    - Extra circulation pump, 27
    - Hot water circulation, 27
    - NV 10, pressure/level/flow monitor brine, 27
    - Possible selection for AUX inputs, 25
    - Possible selection for AUX output (potential free variable relay), 27
    - Switch for "Smart Grid ready", 26
    - Switch for external blocking of addition and/or compressor, 26
    - Switch for external blocking of heating, 27
    - Switch for external forced control of brine pump, 27
    - Temperature sensor, cooling/heating, 26
    - Temperature sensor, hot water top, 22, 25
  - Extra circulation pump, 27
- F**
  - Filling and venting, 29
    - Filling and venting the brine system, 29
    - Filling and venting the climate system, 29
    - Symbol key, 30

Filling and venting the brine system, 29  
Filling and venting the climate system, 29

## H

Heating medium side, 16  
    Connecting the climate system, 16  
Helping the circulation pump to start, 51  
Help menu, 30, 37  
Hot water circulation, 27  
Hot water heater, 16  
    Connecting the hot water heater, 16

## I

Important information, 4  
    Recovery, 4  
    Safety information, 4  
Information sheet, 66  
Inspection of the installation, 5  
Installation area, 8

## M

Manage alarm, 56  
Marking, 4  
Menu 5 - SERVICE, 40  
Menu system, 35  
    Help menu, 30, 37  
    Operation, 36  
    Scroll through the windows, 37  
    Selecting menu, 36  
    Selecting options, 36  
    Setting a value, 36  
    Use the virtual keyboard, 37  
Miniature circuit-breaker, 19

## N

NIBE Uplink™, 25  
NV 10, pressure/level/flow monitor brine, 27

## O

OK button, 34  
Operation, 36  
Optional connections, 24  
Outdoor sensor, 22

## P

Pipe connections, 14  
    Brine side, 15  
    Dimensions and pipe connections, 15  
    Docking alternatives, 16  
    General, 14  
    Heating medium side, 16  
    Hot water heater, 16  
    Pipe dimensions, 15  
    Symbol key, 14  
    System diagram, 14  
Pipe dimensions, 15  
Possible selection for AUX inputs, 25  
Possible selection for AUX output (potential free variable relay), 27  
Post adjusting the room temperature, 32  
Post adjustment and bleeding, 31  
    Post adjusting the room temperature, 32  
    Pump adjustment, automatic operation, 31  
    Pump adjustment, manual operation, 31  
    Pump capacity diagram, brine side, manual operation, 31  
    Readjusting, venting, heat medium side, 31–32  
Power connection, 20  
Preparations, 29  
Pump adjustment, automatic operation, 31  
    Brine side, 31  
    Heating medium side, 31  
Pump adjustment, manual operation, 31  
    Heating medium side, 31  
Pump capacity diagram, brine side, manual operation, 31

## R

Readjusting, venting, heat medium side, 31–32  
Remove the motor on the shuttle valve, 52  
Removing the covers, 9  
Removing the hatch, electrical cabinet, 20  
Removing the hatch, input circuit board, 19  
Room sensor, 22

## S

Safety information, 4  
    Contact information, 7  
    Inspection of the installation, 5  
    Marking, 4  
    Serial number, 4  
    Symbols, 4  
Scroll through the windows, 37  
Selecting menu, 36  
Selecting options, 36  
Serial number, 4  
Service, 50  
    Service actions, 50  
Service actions, 50  
    Draining the climate system, 50  
    Draining the hot water heater, 50  
    Drawing out the cooling module, 52  
    Emptying the brine system, 51  
    Helping the circulation pump to start, 51  
    Remove the motor on the shuttle valve, 52  
    Standby mode, 50  
    Temperature sensor data, 52  
    USB service outlet, 54  
Setting a value, 36  
Settings, 23  
Standby mode, 50  
    Power in emergency mode, 24  
Start guide, 30  
Status lamp, 34  
Supplied components, 9  
Switch, 34  
Switch for "Smart Grid ready", 26  
Switch for external blocking of addition and/or compressor, 26  
Switch for external blocking of heating, 27  
Switch for external forced control of brine pump, 27  
Symbol key, 14, 30  
Symbols, 4  
System diagram, 14

## T

Technical data, 60  
    Dimensions and setting-out coordinates, 60  
    Energy labelling, 66  
        Data for energy efficiency of the system, 68  
    Information sheet, 66  
    Technical documentation, 69  
        Technical Data, 61  
Technical Data, 61  
    Diagram, dimensioning compressor speed, 64  
    Diagram, passive cooling output, 64  
    Working range heat pump, 64  
Technical documentation, 69  
Temperature limiter, 19  
    Resetting, 19  
Temperature sensor, cooling/heating, 26  
Temperature sensor, external flow line, 22  
Temperature sensor, hot water charging, 22  
Temperature sensor, hot water top, 22, 25  
Temperature sensor data, 52  
The heat pump design, 10  
    Component list cooling section, 13  
    Component list electrical cabinets, 12  
    Component location cooling section, 13



- Component location electrical cabinets, 12
- Component locations, 10
- List of components, 10
- Transport, 8
- Troubleshooting, 56

## **U**

- USB service outlet, 54
- Use the virtual keyboard, 37

## **W**

- Working range heat pump, 64





NIBE AB Sweden  
Hannabadsvägen 5  
Box 14  
SE-285 21 Markaryd  
info@nibe.se  
www.nibe.eu

