

# IM Series Counter Service Scales



# Service Instructions

ENGLISH

# 

17-09-2007

©Avery Berkel, 2007. All rights reserved.

The information contained herein is the property of AveryBerkel (a division of ITW Ltd) and is supplied without liability for errors or omissions. No part may be reproduced or used except as authorized by contract or other written permission. The copyright and the foregoing restriction on reproduction and use extend to all media in which the information may be embodied.

#### Trademarks and acknowledgements

Avery Berkel is a registered trademark in certain jurisdictions. All brands and product names used within this document are trademarks or registered trademarks of their respective holders.

#### IMPORTANT

When programming or configuring the equipment you must ensure that you comply with all relevant standards and legislation. The example settings given in this book may not be legal for trade with the public.

## Contents

1	Safety and Warnings	5
1.1	Warnings	6
2	Installation	9
2.1	Installation	10
2.2	Cable management	11
2.3	Self service keyboards (IM300)	12
3	Displays and keys	13
3.1	Display	14
3.2	Keyboard overlay	15
4	Service mode	17
4.1	Service mode overview	18
4.2	Enter/Exit service mode	19
4.3	Navigating service mode menus	21
4.4	Diagnostics	22
4.5	Configuration	24
4.6	Calibration	31
4.7	Site gravity	32
4.8	Service PIN	33
4.9	Alternative currency setup	34
4.10	Clone machine	36
4.11	Data clone	37
4.12	Label editor menu	38
4.13	Service setup	43
4.14	Diagnostic logs	49
5	Service procedures	51
5.1	Power up/power down	52
5.2	Calibration	52
5.3	Firmware update	53
5.4	Weighplate, cross and top cover	54
5.5	Customer display assemblies	56
5.6	Front module/vendor displays	59
5.7	Column mounting	63
5.8	Main board	65
5.9	Loadcell	66

5.10	Printer	67
6	Exploded views	69
6.1	IM100 models	70
6.2	IM202 models	71
6.3	IM300 models	73
6.4	IM400 models	74
7	Schematics and wiring	77
7.1	External connections	78
7.2	Internal connections	80
8	Module information	85
8.1	Main board	86
8.2	Display PCB	88
9	Networking	91
9.1	Typical networks	92
9.2	Network protocol	94
9.3	Wiring/terminations	94
9.4	Network setup	95
9.5	Network map	99
9.6	Backup server operation	100
9.7	Local mode	101

# **Safety and Warnings**

# 1

This chapter contains information about possible hazards and precautions you should take.

#### Contents

1.1 - Warnings (page 6)

#### 1.1 Warnings

#### 1.1.1 Installation and service

THE EQUIPMENT CONTAINS NO USER SERVICEABLE COMPONENTS.

Installation and maintenance of the equipment must only be carried out by trained and authorised personnel.

#### 1.1.2 Electrical installation



The mains lead must be connected to a supply outlet with a protective earth contact. The electrical supply at the socket outlet must provide over current protection of an appropriate rating.

Pluggable equipment must be installed near an easily accessible socket outlet. Permanently connected equipment must have a readily accessible disconnect device incorporated in the fixed wiring.

#### USA

If the scale is connected to a 240V supply, the receptacle must be protected by a 15 amp circuit breaker.

#### 1.1.3 Risk of electric shock



To avoid the possibility of electric shock or damage to the machine, always switch off the machine and isolate from the power supply before carrying out any routine maintenance.

Always completely isolate from the power supply before:

- removing the machine cover(s)
- performing any routine maintenance
- cleaning the machine.



#### 1.1.4 Safe handling

To avoid the risk of the machine falling, where applicable, ensure that it is placed securely on a flat and level surface.

When lifting, moving or supporting the machine, take its weight into consideration.

#### 1.1.5 Additional service precautions

- When the covers are removed, do not apply power to the unit unless specifically instructed to do in this handbook.
- When working on live equipment, exercise great care, use insulated tools and test equipment, and do not work alone.
- When testing or fault finding, exercise extreme care. Ensure that any test equipment used is in good condition and capable of withstanding the existing voltages.

- 1.1 Warnings
  - All tools used must have insulated handgrips. Test probes and jumper leads must be in good condition with adequate insulation. Test probes with claw ends and jumper leads must not have insecure parts that may fail during use.

#### 1.1.6 Replacing batteries

**CAUTION:** Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to instructions.

#### 1.1.7 Cleaning the machine



**CAUTION:** Harsh abrasives, solvents, scouring cleaners and alkaline cleaning solutions, such as washing soda, should not be used especially on the display windows. Under no circumstances should you attempt to wipe the inside of the machine.

The outside of standard products may be wiped down with a clean cloth moistened with water containing a small amount of washing up liquid. The outside of products waterproofed to IP65, IP66 and IP67 may be washed down with water containing a small amount of a proprietary detergent.

#### **Cleaning the print head**

**CAUTION:** Do not use metallic objects on the print head. Only use the recommended print head cleaning kit.

#### 1.1.8 Training

To avoid the risk of RSI (Repetitive Strain Injury) it is important to ensure that the machine is placed on a surface which is ergonomically satisfactory to the user. It is recommended that frequent breaks are taken during prolonged usage.

#### 1.1.9 EMC compliance

The following warning may be applicable to your machine.

#### WARNING:

This is a class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

# Installation

IM300 and IM500 models have additional installation instructions. You should read the relevant instructions before installing those models.

**CAUTION:** IM300 and IM500 models should **not** be installed by one person alone.

#### Contents

- 2.1 Installation (page 10)
- 2.2 Cable management (page 11)
- 2.3 Self service keyboards (IM300) (page 12)

## 2.1 Installation

#### 2.1.1 Check list

Kit List
Scale
Power supply
Documentation CD
Quick User Guide
Self service keyboard (IM300 only)
Installation Instructions (IM300 and IM500 only)

#### 2.1.2 Location

Make sure that the work surface or counter is:

- strong enough to support the weight of the scale
- stable, steady and free from draughts and vibrations.

#### 2.1.3 Handling

Mis-handling of the scale can affect the scale's ability to weigh accurately.



#### 2.1.4 Levelling



Installation

## 2.2 Cable management



Figure 2.1 External cable routes

#### 2.3 Self service keyboards (IM300)

#### Single and twin keyboard models

The self service keyboard is supplied as a separate item. It must be connected before the scale will operate.

Follow the installation instructions (part number AWT35-000308) supplied with the IM300 kit.

**CAUTION:** Do not attempt to fix the self service keyboards by yourself. Get assistance from a second person.

**Note:** After installation you may need to configure the keyboard from within Manager Mode.

Refer to the User Instructions for further information.

# **Displays and keys**

# 3

This chapter describes the keyboard and basic key functions.

#### Contents

3.1 - Display (page 14)3.2 - Keyboard overlay (page 15)

### 3.1 Display



Figure 3.1 Typical weighing display

## 1. Metrological information

- 2. Price per unit
- 3. Price of goods
- 4. Product description (PLU text)
- 5. Weight information (net/tare weight)
- 6. Model number

### 3.2 Keyboard overlay



Figure 3.2 IM202 programming overlay

#### 3.2.1 Keys

Reset the weight display to zero



Subtracts the weight of the container when weighing goods.



In **receipt** mode, retains the PLU until the transaction is entered. Retains a tare, if in operation, until it is cancelled. In **label** mode, the PLU is retained until it is cancelled. Sets the scale to pre-pack if the machine configuration allows it.



Cancels a PLU or hand entered price. Depending on the function in use, clears messages or characters from the display.



Totalises transaction. In **receipt** mode, when the subtotal is displayed, prints a receipt.

In label mode, prints a label.

#### Displays and keys

Confirms data entry. Enables you to change the number of items when serving non-weighed items.

1,×3

Override the programmed price of a PLU.



Cancels an unwanted transaction from an operator subtotal. In **label** mode, when set to print totals labels only for ADD key transactions, it cancels an unwanted transaction from the subtotal.



Depending on machine configuration, allows totals labels or totals and individual labels to be printed.



Initiates a display test sequence. Pressed again during the test sequence prints a test report. Press operator key and type in PIN during test sequence to gain access to Manager Mode.



Double zero key.



Move to the item above in the displayed list



Move to the item below in the displayed list

# Service mode

# 4

**CAUTION:** When programming the scale you must ensure that you comply with all relevant standards. The example settings given in this book may not be legal for trade.

#### Contents

- 4.1 Service mode overview (page 18)
- 4.2 Enter/Exit service mode (page 19)
- 4.3 Navigating service mode menus (page 21)
- 4.4 Diagnostics (page 22)
- 4.5 Configuration (page 24)
- 4.6 Calibration (page 31)
- 4.7 Site gravity (page 32)
- 4.8 Service PIN (page 33)
- 4.9 Alternative currency setup (page 34)
- 4.10 Clone machine (page 36)
- 4.11 Data clone (page 37)
- 4.12 Label editor menu (page 38)
- 4.13 Service setup (page 43)
- 4.14 Diagnostic logs (page 49)

#### 4.1 Service mode overview

Setting the scale into service mode allows you to configure many aspects of the scales functionality.



Figure 4.1 Service mode menu structure

#### 4.2 Enter/Exit service mode

There are two levels of service mode available.

• Full service access

Full access to all service options including calibration.

#### • Restricted service access

Limited access to certain service options. Calibration is not available.

Note: For all service options, you will need the programming overlay on the keyboard.

#### 4.2.1 Full service access

Full service mode allows unrestricted access to the service mode configuration menus.

To enter full service mode:

- 1. Switch on the scale.
- 2. On the underside of the scale, locate the access hole for the service switch.
- 3. Carefully insert a narrow bladed screwdriver until it just touches the service switch



Figure 4.2 Location of service switch access hole.

#### 4.2.2 Restricted service access

Restricted access limits the changes you can make to the scale.

Restricted access **excludes** the following:

- 1. Changing the capacity
- 2. Changing the gravity zone compensation
- 3. Calibrating the scale.

To enter restricted service mode:

- 1. Switch off the scale and then switch it on again.
- 2. During the display countdown, enter the service PIN. (Default PIN is 9467.)

Note: To change the service PIN see Service PIN on page 33

#### 4.2.3 Exit service mode

To return to manager or sales mode

Press

龠

龠

to return to manager mode.

Press

twice to return to sales mode.

## 4.3 Navigating service mode menus

Use the following keys to navigate the menus:

	Enter
T	Select the item
	Enter a value
or	
	Back
	Move up one menu level
	•
	Previous
	Select previous item
	Next
	Select next item
	<b>-</b> · · ·
	Quick save
	Save data entered up to this point
	11
	Home/Exit
	Return to manager mode
	Exit service mode
000	Numeric keypad
000	Select numbered menu item
<b>66•</b>	

#### 4.4 Diagnostics



#### Figure 4.3 Diagnostics menu

The diagnostics menu allows you to perform a number of tests.

#### 4.4.1 Weighing test



#### 4.4.2 Keyboard test



- Press each key on the keyboard in turn starting from the top left and working towards the right for each row of keys.
- Press the same key three times to exit test.

#### 4.4.3 Network test

This tests that the scale's network is working correctly.

The scale will talk to another device on the network over a number of cycles. A successful test indicates that the network configuration is working correctly.

#### 4.4.4 USB test

This hardware test checks that the USB port is working correctly.

#### 4.4.5 Printhead life

This is for factory testing purposes only.

#### 4.4.6 Dynamic and static RAM, and Flash test

Checks that the memory is functioning correctly.

## 4.5 Configuration

The configuration tables determine many of the scale's operating parameters.



#### Figure 4.4 Configuration display

#### Software version 7.0

Bank 1					
Digit					
1	Capacity (Not available	in restricted access mode)			
	0 Not used	8 15kg x 5g			
	1 Not used	9 15kg AVR			
	2 30lb x 0.01	A Not used			
	3 50lb x 0.01	B 30kg x5g			
	4 6kg x 1g	C Not used			
	5 Not used	D 30lb/15kg			
	6 6kg AVR	E - T Not used			
	7 Not used				
2	Tare system				
	0 Free	4 Free, Stored			
	1 Free, Graduated	5 Free, Graduated, Stored			
	2 Free, Cumulative, Graduated	6 Free, Cumulative, Graduated, Stored			
	3 Free, Cumulative, Graduated, Proportional	7 Free, Cumulative, Graduated, Proportional,			
		Stored			
3	Tare	display			
	0 No tare display	2 Separate tare display only			
	1 Negative weight display	3 Separate tare and negative weight			
4	Minimum wei	ght disturbance			
	0 1 division	2 10 divisions			
	1 4 divisions	3 20 divisions			
5	Bleep behind zero, ov	er range and balance lost			
	0 Disabled	1 Enabled			
6	Numeric e	entry timeout			
	0 Disabled	1 Enabled			
7	PLU auto i	ecall timeout			

	Bank 1					
	0	None	5	0.5 seconds.		
	1	0.6 seconds	6	2.0 seconds		
	2	1.0 seconds	7	3.0 seconds		
	3	0.3 seconds	8	4.0 seconds		
	4	0.4 seconds	9	5.0 seconds		
8		Receipt t	ах	printing		
	0	None	2	Itemised tax		
	1	Totals tax				
9		Weight	filt	er type		
	0	Settling time 0.2s (71.2Hz)	4	Settling time 0.2s (81.2Hz)		
	1	Settling time 0.5s (71.2Hz)	5	Settling time 0.5s (81.2Hz)		
	2	Settling time 1.0s (71.2Hz)	6	Settling time1.0s (81.2Hz)		
	3	Settling time 1.9s (71.2Hz)	7	Settling time1.9s (81.2Hz)		
10		Price	e b	ase		
	0	Single price base (lb/kg)	2	Dual price base (lb/kg)		
	1	Single price base (1/4lb/100g)	3	Dual price base (1/4lb/100g)		
11		Print	er f	type		
	0	None	2	Label only		
	1	Receipt only	3	Label and Receipt		
12		Default sales mod	e a	and machine type		
	0	Hand price mode, weighing	2	Hand price mode, non-weighing		
	1	PLU price mode, weighing	3	PLU price mode, non-weighing		
13		Add f	uno	ction		
	0	None	3	Receipt only		
	1	Transaction + total	4	Transaction and receipt		
	2	Total only				
14		Date	e ty	/pe		
	0	Numeric	1	Alpha		
15		Date	for	rmat		
	0	DD MM YY	3	DD MM YYYY		
	1	MM DD YY	4	MM DD YYYY		
	2	YY MM DD	5	YYYY MM DD		
16		Maximum transacti	on	sequence number		
	0	999999	3	999		
	1	99999	4	99		
	2	9999	5	9		

			Bank 2	
Digit				
1		Dum	nmy zero in unit price)	
	0 6 digit UP, 6 digi	t TP, no dummy zero	2 5 digit UP, 6 digit TP, no dummy zero	
	1 6 digit UP, 6 digi	t TP, dummy zero	3 7 digit UP, 7 digit TP, no dummy zero	
2		Tra	ansaction rounding	
	0 Round to neares	st 1	3 Round to nearest 25	
	1 Round to neare	st 5	4 Round to nearest 50	
	2 Round to neares	st 10		
3		Num	ber of decimal places	
	0 No decimal plac	es	3 3 decimal places	
	1 1 decimal place		4 0 on unit price, 1 on total price	
	2 2 decimal places	5	5 I nousands separators	
4			Punctuation	
	0 Decimal point		2 Inverted comma	
<b>F 9 C</b>	i Comma		Curren ou overhol	
200			Currency symbol	
	00. User defined	15. D	30. Won 45. JD	
	01. £	16. RM	31. bt 46. KD	
	02. \$	17. L	32. Pts 47. LL	
	03. R	18. N\$	33. EEK 48. RO	
	04. F (French)	19. Esc	34. Lt 49. QR	
	05. Kr	20. Pta	35. € 50. SR	
	06. DM	21. Rp	36. Eur 51. YR	
	07. S	22. mk	37. R\$ 52. Ft	
	08. Fr	23. PX	38. B 53. kn	
	09. f	24. SR	39. C 54. Lm	
	10. Lit	25. zt	40. Q 55. Ksh	
	11. P	26. Kc	41. TL 56. RON	
	12. E	27. SK	42. F (Belgian) 57. ROL	
	13. K	28. kr	43. BD 58. LEI	
	14. M	29. DHS	44. LE	
7		PLI	Lauto recall timeout	
•	0 None		15 0.5 seconds	
	1 0.6 seconds		6 2.0 seconds	
	2 1.0 seconds		7 3.0 seconds	
	3 0.3 seconds		8 4.0 seconds	
	4 0.4 seconds		9 5.0 seconds	
8		R	Receipt tax printing	
	0 None		2 Itemised tax	
	1 Totals tax			
9			Weight filter type	

		Bank 2	
	<ul> <li>0 Settling time 0.2s (71.2Hz)</li> <li>1 Settling time 0.5s (71.2Hz)</li> <li>2 Settling time 1.0s (71.2Hz)</li> <li>3 Settling time 1.9s (71.2Hz)</li> </ul>	<ul> <li>4 Settling time 0.2s (81.2Hz)</li> <li>5 Settling time 0.5s (81.2Hz)</li> <li>6 Settling time1.0s (81.2Hz)</li> <li>7 Settling time1.9s (81.2Hz)</li> </ul>	
10	10 Price base		
	0 Single price base (lb/kg) 1 Single price base (1/4lb/100g)	<ul><li>2 Dual price base (lb/kg)</li><li>3 Dual price base (1/4lb/100g)</li></ul>	
11		Printer type	
	0 None 1 Receipt only	2 Label only     3 Label and Receipt	
12	Default	sales mode and machine type	
	<ul><li>0 Hand price mode, weighing</li><li>1 PLU price mode, weighing</li></ul>	<ul><li>2 Hand price mode, non-weighing</li><li>3 PLU price mode, non-weighing</li></ul>	
13		Add function	
	0 None 1 Transaction + total 2 Total only	<ul><li>3 Receipt only</li><li>4 Transaction and receipt</li></ul>	
14		Date type	
	0 Numeric	1 Alpha	
15		Date format	
	0 DD MM YY 1 MM DD YY 2 YY MM DD	3 DD MM YYYY 4 MM DD YYYY 5 YYYY MM DD	
16	Maximu	m transaction sequence number	
	0 999999 1 99999 2 9999	3 999 4 99 5 9	

# Country configuration



Bank 3				
Digit				
1		Balance key range		
	0 ± 2%	1 ± 5%		
2		+15% -5% Balance at power up		
	0 Disabled	1 Enabled		
3	Large step behind zero			
	0 Disabled	1 Enabled		

IM series Service Instructions

		Bank 3
4	Re	duced zero tracking
	0 Disabled	1 Enabled
5	F	Retained tare mode
	0 Disabled	1 Enabled
6	Ма	nual tare calculation
	0 None	2 Zero key
	1 tare key	3 Tare and zero key
7	Price i	nterlock/NTEP operation
	0 Disabled	2 NTEP operation.
	1 Price and tare	
8		Fix tare options
	0 Fix tare and unit price	1 Fix tare only
9	Open ca	ash drawer with zero total
	0 Disabled	1 Enabled
10	Price 1/price	ce 2 swap positions on label
	0 Disabled	1 Enabled
11	Receip	t total currency symbols
	0 Disabled	1 Enabled
12	Min	imum prepack weight
	0 1 division	1 20 divisions
13	Prepace	allows stored/grad tares
	0 Disabled	1 Enabled
14		Triple zero key
	0 Disabled	1 Enabled
15		Tax system
	0 Inclusive	2 Inclusive, PoS only
	1 Exclusive	3 Exclusive, PoS only
16	Tax r	eference in description
	0 Disabled	1 Enabled

Service mode

		Bank 4	
Digit			
1 & 2	Language		
	00 English (UK)	14 Greek	
	01 Spanish	15 Croatia	
	02 RSA	16 Hungary	
	03 French	17 Sweden	
	04 German	18 Arabic	
	05 Italian	19 English (US)	
	06 Dutch	20 Romanian	
	07 Danish	21 Estonian	
	08 Polish	22 Bulgarian	
	09 Czech	23 Russian	
	10 Portuguese	24 Ukrainian	
	11 Finnish	25 English (Arabic)	
	12 Norwegian		
	13 Turkish		
3		Sales key layout	
	0 IM All markets Price Base		
4		Manager key layout	
	0 IM European	2 IM Arabic	
	1 IM Greek	3 IM Cyrillic	
5	Receipt algorithms - transac	ction count on receipt / display per transaction assigned	
	Algorithm Weighed	n x (+ve non-weighed) n x (-ve non-weighed)	
	0 A 1/1 1/1	0/1	
	1 B 1/1 1/1	1/1	
	2 C 1/1 n/1	0/1	
	3 D 1/1 n/1	n/1	
	4 E 1/1 n/1	0/0	
6		Receipt formats	
	0 Receipt format 0 - Italian format w	hich includes tare weight	
	1 Receipt format 1 - No symbols lin	e, symbols printed with transaction data. First line contains text and	
	total price. Second line contains v	veight/multiplier and unit / item price.	
	2 Receipt format 2 - As receipt form	at 1 except total price printed on third line for weighed.	
	3 Receipt format 3 - Symbols line. F	irst line contains text. Second line contains weight/multiplier, unit / item	
	price and total price.		
	4 Receipt format 4 - Each transaction	on contains its own symbols line.	
	5 Receipt format 5 - USA receipt for	rmat. Identical to format 1 except that 'X' and 'Items' is replaced by '@'	
	6 Receipt format 6 - Australian rece	ipt format. Identical to format 5 except description not allowed to	
	encroach on the total prices colur	nn.	
7		Condensed format	
	0 Disabled	1 Enabled	
8		Change calculation	
	0 Disabled	1 Enabled	
9		Direct entry prepack	
	0 Disabled	1 Enabled	

Bank 4				
10	Net weight			
	0	Grams	1	oz - lb/oz
11		USA total	pric	e legend
	0	Disabled	3	Using net weight (per kg)
	1	Using net weight (per 100g)	4	By product type
	2	Using actual weight (Danish)		
12		Back calculat	ion	of unit price
	0	1 division	1	20 divisions
13 & 14		Co	unt	ry
	00	UK	21	Australia
	01	Spain	22	New Zealand
	02	South Africa	23	USA
	03	France	24	Ireland
	04	Germany	25	UAE
	05	Italy	26	Canada
	06	Netherlands	27	Malaysia
	07	Denmark	28	Zimbabwe
	80	Poland	29	Lithuania
	09	Czech Republic	30	Estonia
	10	Portugal	31	Egypt
	11	Finland	32	Mexico
	12	Norway	33	Panama
	13	Turkey	34	Belgium
	14	Greece	35	Switzerland
	15	Croatia	36	Austria
	16	Hungary	37	Tunisia
	17	Sweden	38	Romania
	18	Saudi Arabia	39	Bulgaria
	19	General Export	40	Russia
	20	Indonesia	41	Ukraine
15		Frequent sho	ppe	er algorithm
	0	Compute frequent shopper price from printed	2	Compute frequent shopper price from saving and
		weight	1	back-calculated weight
	1	Compute frequent shopper price from back-	3	Frequent shopper price scheme 3
40	1		<u> </u>	- d
16		Not	us	ea

#### 4.6 Calibration



#### 4.7 Site gravity

If the scale has been moved to a different gravity zone, enter the site gravity compensation factor. Refer to the local authority for details.



Note: This is the gravity factor for the location where the scale is to be used

#### 4.8 Service PIN

You can change the four digit restricted service access PIN from this menu. Only change the PIN if you think that the user knows the service PIN and is tampering with the machine's configuration.

#### 4.9 Alternative currency setup

#### 4.9.1 Currency rate and symbol

The currency rate and symbol setup options are used to configure a second currency.



#### 4.9.2 Euro wizard

This converts the PLU file from the local currency to Euro currency. The scale will then use the Euro as its **primary currency**.

CAUTION: Only a factory reset can undo this operation.

#### Euro rate and symbol procedure



Service mode

#### 4.10 Clone machine

This function allows you to update another machine on the network so that it is functionally identical to the one you are using.

The clone function will copy the following information:

- Executable files (application program)
- PLU file
- Label formats
- Logos
- Configuration and keyboard layouts

**Note:** Machine specific information is excluded. (e.g. capacity, calibration data or gravity compensation factors)

#### **Network ID restrictions**

- Application program can be cloned irrespective of the network IDs of the two machines.
- Data can be cloned only if both machines are using the same network ID

#### **Clone procedure**


#### 4.11 Data clone

# 4.11 Data clone

Data clone allows you to transfer all the data in one machine to another machine (or machines) on the network.

The data clone function will copy the following information:

- PLU file
- Label formats
- Logos
- Configuration and keyboard layouts

#### **Network ID restrictions**

Data - can be cloned only if both machines are using the same network ID

For more information see Scale groups (Network ID) on page 93.

#### **Clone procedure**



# 4.12 Label editor menu



The scale has 12 (0 - 11) standard label formats and four (12 - 15) nutritional label formats. This menu allows the label formats to be edited as required. Each label can have up to 26 fields on it.

Note: The maximum printable area on a label is 160mm x 60mm.

#### 4.12.1 Copy Format

Copy format allows you to create an identical copy of an existing label format. The copy can then be modified using the Edit Format option (see below).

#### 4.12.2 Edit Format

This allows you to edit the label formats.

At any time you may:

- Use the 'List Format' function to print the current settings.
- Use the 'Test' key to print a sample layout.

Use the `List Format' function to print the current settings.



6 Enter the number of the field to be edited. (e.g. 8)		
IM   Max 15 kg Min 100 g e=5 g   7   8     8   4   5   6     Enter Field   0   0   Image: Comparison of the second secon		
7 Use 'Previous' or 'Next' arrows to select the information that field is to display. (e.g Unit		
Price)		
IM   Max 15 kg Min 100 g e=5 g		
8 Use 'Previous' or 'Next' arrows to select the angle of rotation for the selected field		
IM     Max 15 kg Hin 100 g e=5 g       8     90       Field Rotation     .		
9 Enter the number (or letter) for the font to be used		
III   Hax 15 kg Hin 100 g e=5 g   7   8   4   3   6     Befault Font D   0   0   0   0   1   2   3		
10 Enter the X1 and Y1 distances in mm (See field positioning XX)		
(Use 'Previous' and 'Next' arrow keys to select between X1 & Y1)		
IM Max 15 kg Hin 100 g e=5 g 7 8 9   8 4 5 6   1 2 3   X1Y1= 02, 22.9 0 6		
X1 = distance from left		
Y1 = distance from top		







# **Field position notes**

The position of the fields on a label are set by a bounding box. This uses the distances X1, Y1, X2, Y2; illustrated as follows.



Note: The distances are entered for the direction in which the label is being viewed.

# 4.12.3 Restore format

This option allows you to restore the specified label format to its factory default.

# 4.12.4 List format

This option will print out details about all the fields that are used on the specified label format



# 4.13 Service setup



#### 4.13.1 Printer setup

Do not adjust these settings unless there is a problem with the printer.

#### Density

This allows you to set the print density on the print out.

1 = light

9 = dark (default = 5).

If the print quality is poor check that the print head is clean. Poor quality printing can be caused by using inferior quality paper.

**Note:** For machines with two printers, set the print density for the receipt (second) printer using the Printer 2 menu option.

#### Sensor distance

This allows the parking position distance to be adjusted (mm). Default setting is 48.5mm

**Note:** You will need to reset the opto sensor distancefollowing a Factory Reset or replacing the main board.

#### Label threshold (10 - 250)

Set the sensitivity of the label gap sensor.

10 = Very sensitive to gaps between labels.

250 = Not very sensitive to gaps between labels.

Default value = 50

#### Paper threshold (10 - 250)

Set the sensitivity of the paper sensor.

10 = Very sensitive to presence of paper.

250 = Not very sensitive to presence of paper.

Default value = 100

#### 4.13.2 Initialise M/C

This allows you to:

- Restart the machine
- Set up the memory allocations.

The options are:

#### Warm restart

This is the equivalent of switching off the machine and then switching on.

#### **Cold Start**

This will restart the machine and clear all the battery-backed RAM. This will delete **ALL** records except:

Service PIN	Sub net mask
Label formats and logos	Gateway IP address
Configuration banks	Number of receipts and transactions
Euro rate	Print density
IP address	Distance from sensor
Network ID	Diagnostic log size
Host port number	LCD contrast
Calibration and gravity factors	

#### Factory reset USE WITH CAUTION!

This will restore the machine to its factory default settings.

Factory reset will delete **ALL** records except for the MAC (Media Access Control) address, calibration constants, gravity factors and bank 1, digit 1 of the machine configuration.

*Note:* You will need to reset the opto sensor distance after a factory reset.

#### **Factory reset values**

IP Address	Reset to 88.200.100.5
Network ID	Reset to 0
Host port number	Reset to 3001
Sub net mask	Reset to 255.0.0.0
TCP/IP Gateway Address	Reset to 0.0.0.0 (disabled)
Logos	All (user logos) deleted
Label formats	Reset to default settings
Calibration	Unchanged
Gravity	Unchanged
Configuration banks	Reset to default settings except for digit 1 bank 1
Alt. Cncy. conversion rate	Reset to 1.00
Print density	Reset to 5
Number of receipts and trans.	Reset to 20 receipts and 8 transactions
Distance from sensor to printhead	Reset to 48.5mm
LCD contrast	Reset, but no change until machine is switched off and on.
Service PIN	Reset to 9467
Diagnostic log size	Reset to small
Audit mode	Enabled
Distance printed (mm)	Reset to zero

#### **Delete PLU file**

This option deletes all the PLUs stored in the PLU file.

#### Set Trans Memory

This allows you to set the amount of memory allocated for transactions and receipts.

#### Memory setting guidelines

**Note:** Changing memory settings will induce a cold start and should therefore be done **before** other (customer) data is set.

Each machine will store transactions according to the '**Set Trans Memory**' option (selected from within the 'Initialise M/C menu).

You can set the following:

• Num Receipts (Default = 20)

The max number of receipts stored.

• Num Trans / Recpt (Default = 8, Max = 99)

The max number of individual transactions stored for each receipt.

#### Audit settings

The Trans memory required is closely associated with the Audit settings defined within manager mode. See the separate user instructions for more information.

#### **Trans memory - Client machines**

The memory allocated should reflect the requirements of the installation.

Example:1 - Label

Example scale requirements:

50 labels per hour (1 transaction per label

8 hours trading required in local mode (network fail)

Memory requirements would be

Num Receipts = 400 Num Trans per receipt = 2

#### Example:2 - Receipt

Example scale requirements:

20 receipts per hour Average of 4 transactions per receipt 8 hours trading required in local mode (network fail)

Memory requirements would be:

Num Receipts = 160

Num Trans per receipt = 4

#### **Trans memory - Server machines**

#### Settings notes - single servers

For a server, receipts are only stored when live (prior to being totalised). Consequently, the maximum number of receipts stored will be the same as the number of operators using the system at any one time.

Example:server requirements:

10 operators on system

Up to 100 live transactions at any one time

(assume equal split between operators)

Memory requirements would be:

#### Num Receipts = 10

#### Num Trans per receipt = 10

This would also limit the largest receipt, on the system, to 100 transactions (i.e. 10 x 10).

**Note:** If an audit trail is required, the number of receipts and transaction stores should be set according to the length of trail required

#### Settings notes - dual servers Linear / Circular Buffer

The server buffer can be set to either linear or circular.



Set to linear - If totals and/or audit trail integrity is vital.

The number of receipt stores and transaction stores will determine how long trading can continue before an *audit full* condition is reached.

Set to circular - If the ability to continue trading is more important.

The number of receipt & transaction stores will dictate after how long information will start to be overwritten.

The buffer type is set within manager mode. See the separate user guide for more information on circular / linear buffers.

#### **Consolidation of dual servers**

When communications between dual servers breaks down, both will continue as servers, potentially with clients. As trading continues on both, totals, receipts and transactions will be generated. When the servers are reunited, transactions and receipts will be consolidated, so that both servers will now have a complete set of receipts and transactions. Totals data will not be collected. It will be regenerated from the receipt and transaction data.

Note: For server consolidation, audit mode must be enabled.

#### Delete firmware USE WITH CAUTION!

This option deletes the .uboot file.

Before selecting this option make sure you have a USB memory stick containing the new firmware in the root directory connected to the scale. The firmware must have the filename appimage.uboot.

#### 4.13.3 Currency text

The user defined currency text is 3 digit field that can be used instead of the default currency text (as set in config bank 2 digits 5 & 6). See *Configuration* on page 24 for more information.

*Note:* To use this user defined currency text, set config bank 2 digits 5 & 6 to 00.

# 4.13.4 Serial Number, Config Wizard, Model Number

#### Serial number

Factory set scale serial number.

# Config wizard.

Enables streamlined Country Configuration on reboot.

#### Model number

Allows you to enter the three digit model number on the display.

# 4.14 Diagnostic logs

The scale stores a number of logs to record various events. This option is used to print and configure the logs.

#### **Print Logs**

Select from the following

- Print system log
- Print key log
- Printcomms. log
- Print all logs

**System log**: This prints a report showing all the events that have occurred with the machine, including the number of times that the machine has been switched on and off.

Log number \_\_\_\_



Key log: This prints a report showing which keys have been pressed.



Comms log: This prints a report showing the history of the scale network traffic.



#### Set log size

This option sets the size of the log. If you select a different log size, then you must cold start the machine. Log size options are:

- None No logs will be stored
- Small 100 events. (Uses 30K of the available memory)
- Medium\* 500 events. (Uses 160K of the available memory)
- Large\* 1000 events. (Uses 650K of the available memory)

*Note:* A larger log size will reduce the amount of memory that can be used for PLUs.

\* These require a RAM expansion board to be fitted.

# **Clear All Logs**

This clears all the data from the logs.

### 4.14.1 Printhead life

This is for factory testing purposes only.

# **Service procedures**

This chapter describes common service and maintenance procedures.

#### Contents

- 5.1 Power up/power down (page 52)
- 5.2 Calibration (page 52)
- 5.4 Weighplate, cross and top cover (page 54)
- 5.3 Firmware update (page 53)
- 5.5 Customer display assemblies (page 56)
- 5.6 Front module/vendor displays (page 59)
- 5.7 Column mounting (page 63)
- 5.8 Main board (page 65)
- 5.9 Loadcell (page 66)
- 5.10 Printer (page 67)

# 5.1 Power up/power down



Figure 5.1 Location of On/Off switch

#### Service notes:

• Power up / down using the switch shown above.

**CAUTION:** Even when the unit is switched off, mains voltage is still present inside the unit.

# 5.2 Calibration

For the calibration procedure see Calibration on page 31

#### 5.3 Firmware update

The application firmware can be upgraded in one of three ways.

#### Ethernet connection to MX050

Connect the scale to a PC and select a \*.uboot file to be programmed into the scale. Refer to MX050 Service Instructions for more detail.

#### USB memory stick (scale service menu)

You must have a USB memory stick containing the new firmware to be programmed into the scale. See *Delete firmware*, *section 4.13.2*.

**Note:** the new firmware must have a fixed filename of "appimage.uboot", this file must be located in the root of the memory stick

#### USB memory stick (service mode switch)

You must have a USB memory stick containing the new firmware to be programmed into the scale.

- 1. Plug the memory stick into the scale then switch on the scale, whilst holding down the service mode switch on the Main board for 3 seconds.
- After 3 seconds you can release the switch and the new firmware will be read from the memory stick and burnt into the scale. (The process will take approximately 2 minutes to complete)

**Note:** When the update has been successfully completed the scale will reboot and return to the normal weighing display.

# 5.4 Weighplate, cross and top cover



Figure 5.2 Exploded view of plate, cross and top cover

#### Service notes:

- The cross must be fitted with the arrow pointing to the front of the scales.
- 3. Weigh plate.
- 4. Rubber seal fitted over cap head screw recess.
- 5. M6 x 20 cap head screws (2 off).
- 6. Rubber foot (4 off).
- 7. Cross.

- 8. Weights and Measures seal
- 9. Rubber bung

#### 5.4.1 Removing the weighplate and cross

The weigh plate rests on the four rubber feet on the cross.

- 1. Remove the rubber seal to gain access to the two cap head screws in the centre of the cross.
- 2. Remove the two cap head screws retaining the cross and lift off the cross.

#### 5.4.2 Removing the top cover and printer door

- 1. Remove the five rubber bungs and the screws from the top of the cover and the retaining screw in the printer housing.
- 2. Remove the Weights and Measures seal and the screw beneath the seal.

**Note:** Once this seal has been broken or removed certain procedures, such as calibration or load cell replacement, may require the scale to be re-verified. You should ensure that all procedures comply with local/national weights and measures requirements.

3. Carefully lift off the top cover.

# 5.5 Customer display assemblies

# 5.5.1 IM100



Figure 5.3 Removing the customer display

#### Service notes:

- 1. Remove weigh plate, cross and top cover (see *Weighplate, cross and top cover* on pages *54* and *55*).
- 2. Disconnect the rear display cable assembly.
- 3. Lift the customer display assembly clear of the base cover.



# 5.5.2 IM300 keyboard assembly

Figure 5.4 Disassembling the self service keyboard

#### Service notes:

The spacers (1) are an essential part of the assembly and must be replaced when reassembling the unit.

The connection between the keyboard loom and keyboard tail must be sealed with adhesive tape.

- 1. Remove the four screws retaining the rear cover support plate.
- 2. Disconnect the keyboard cable assembly from the rear cover support plate.
- 3. Remove the six screws securing the keyboard assembly and keyboard mat to the front cover assembly.

Note: Reverse the procedure to assemble the self service keyboard.

#### 5.5.3 IM400 customer display



Figure 5.5 Disassembling the customer display

#### Service notes:

It is not necessary to remove the complete head assembly.

For easier access you can place the scale upside down on a suitable surface with the column and head assembly hanging down over the edge.

- 1. Remove the two screws securing the lower cover and remove the cover.
- 2. Disconnect the two display cable assemblies for the display interface.
- 3. Remove the two screws securing the upper cover and bezel assemblyand remove them from the head.
- 4. Remove the star washer and unclip the display assembly and bezel from the upper cover.
- 5. Remove the two screws securing the display interface assembly to the bezel.

Note: Reverse the procedure to assemble the customer display assembly.

# 5.6 Front module/vendor displays

#### 5.6.1 Front module IM100, IM202, IM300



Figure 5.6 Removing the front cover and display interface

#### Service notes:

Removal of the front cover allows access to the vendor display and keyboard.

1. Disconnect the following cables from the main board:

Front and rear display cable assemblies

Power input power assembly

Earthing strap

Load cell cable assembly

USB cable assembly

Printer assembly cables

- 2. Carefully free the main board assembly from the two retaining clips and lift it clear.
- 3. Remove the two screws retaining the front module.

4. Unclip the front module and slide it forward until it is clear of the base moulding.

**Note:** It may not be necessary to completely remove the main board before removing the front module. Disconnect the earth strap and the USB cable assembly from the main board then stand the main board up to access the two screws.

# 5.6.2 Vendor display and keyboards



Figure 5.7 Removing/replacing the display interface assembly

#### Service notes:

#### Monobloc and tower models

- 1. Remove weigh plate, cross and top cover (see *Weighplate, cross and top cover* on pages 54 and 55).
- 2. Follow steps 1 to 4 of Front module IM100, IM202, IM300 on page 59
- 3. Disconnect the front display cable assembly and the keyboard screen cable assemblies.
- 4. Remove the two retaining screws and lift the display assembly clear of the front cover.

#### Two piece models (IM400)

- 1. Follow steps 1 to 3 on *page 58* to remove the lower cover and the customer display and bezel assembly.
- 2. Disconnect the display cable assembly, the keyboard and screen cableassemblies.
- 3. Remove the two retaining screws and lift the display assembly clear of the front cover.

**Note:** For better access you can remove the keyboard/display module from the mounting plate.

1. Remove the two screws and washers securing the module to the mounting plate

2. slide the module off the mounting plate.

#### 5.6.3 Vendor display (IM202)



Figure 5.8 Tower display

#### Service notes:

- 1. Gently insert a 7mm flat bladed screwdriver into one of the access holes in the lower cover until it locates in the slot in the clip. Turn it hrough 90 degrees and push upwards. Repeat with the other access hole.
- 2. Lift the upper cover to remove it.
- 3. Lift out the display interface assembly and disconnect the display cable assembly.
- 4. To remove the lower cover undo the four socket head cap screws securing it to the column.

# Replacing a display interface

Take care to replace the display interface in the correct position. The customer and vendor displays are not interchangeable as they have different jumper settings.

# 5.7 Column mounting

#### 5.7.1 IM202, 400



Figure 5.9 Attaching the column mounted display

#### Service notes:

It is advisable to remove the display pod from the column before attempting to attach or remove the column from the scale body. The display and column assembly is top heavy when separated from the scale body.

- 1. Remove weigh plate, cross and top cover (see *Weighplate, cross and top cover* on pages 54 and 55)).
- 2. Push up the column bracket cowl to unclip it from the base cover.
- 3. Remove the socket head cap screw and the earth strap.
- 4. Slide the column support bracket backwards away from the base cover to release it.
- 1. Remove the four socket screws attaching the column support bracket to the column.
- 2. Slide the column bracket cowl off the column.

When replacing looms, thread them through from the top of the column and through the holes provided in the column support bracket.

#### 5.7.2 IM300



Figure 5.10 Attaching the IM300 column and display (single keyboard configuration)

#### Service notes:

For details of IM300 twin keyboard configuration and assembly see the IM300 installation kit instructions AWT35-000308

#### 5.8 Main board



Figure 5.11 Removing the main board.

#### Service notes:

- 1. Remove weigh plate, cross and top cover (see *Weighplate, cross and top cover* on pages 54 and 55)).
- 2. Disconnect the following cables from the main board:

Front and rear display cable assemblies

Power input power assembly

- Earthing strap
- Load cell cable assembly
- USB cable assembly
- Printer assembly cables
- 3. Carefully free the main board assembly from the two retaining clips and lift it clear.

**Note:** The two screws shown are not fitted. Should the retaining clips break, then use two self tapping screws of an appropriate size (M3 or smaller, less than 8mm length) to secure the main board.

# 5.9 Loadcell



Figure 5.12 Removing the loadcell

#### Service notes:

- 1. Remove weigh plate, cross and top cover (see *Weighplate, cross and top cover* on pages 54 and 55)).
- 2. Remove the pan head retaining screw and the earth straps.
- 3. Disconnect the load cell cable assembly from the main board.
- 4. Remove the four cap head screws retaining the load cell assembly and remove the load cell.

# 5.10 Printer

# 5.10.1 Printer assembly



#### Figure 5.13 Removing the printer

#### Service notes:

- 1. Remove the USB support bracket.
- 2. Disconnect the earth strap from the printer.
- 3. Disconnect from the main board:

the printer optical sensor cable assembly

the printer stepper motor cable assembly

the printhead interface cable assembly.

4. Remove the three screws securing the printer assembly to the base cover.

# **Exploded views**

# 6

This chapter contains exploded views of the main assemblies. Full explodes views and part numbers can be found in the IM series Parts List

#### Contents

- 6.1 IM100 models (page 70)
- 6.2 IM202 models (page 71)
- 6.3 IM300 models (page 73)
- 6.4 IM400 models (page 74)

# 6.1 IM100 models

# 6.1.1 Scale body



Figure 6.1 Monobloc model scale body

# 6.2 IM202 models

# 6.2.1 Scale body



Figure 6.2 Scale body for head up/tower display models





Figure 6.3 Head up/tower customer and vendor display
#### 6.3 IM300 models

# 6.3 IM300 models

This model uses the same scale body as the IM100 except that the rear display interface is replaced by an overlay. (see *Scale body* on page 70)

# 6.3.1 Keyboard



Figure 6.4 Single keyboard configuration

# 6.4 IM400 models

# 6.4.1 Scale body



Figure 6.5 IM400 body



# 6.4.2 Head up display and keyboard

Figure 6.6 IM400 keyboard and vendor/customer display.

# **Schematics and wiring**

# 7

**CAUTION:** When programming the scale you must ensure that you comply with all relevant standards. The example settings given in this book may not be legal for trade.

#### Contents

- 7.1 External connections (page 78)
- 7.2 Internal connections (page 80)

# 7.1 External connections

## 7.1.1 Overview



Figure 7.1 Overview of external connections

- 1. On/Off switch
- 2. Cash drawer
- 3. Power supply
- 4. Expansion interface (Wifi)
- 5. USB (scanner)
- 6. Ethernet network connector

#### 7.1.2 Scanner connection

The scanner should be connected to the USB port or the extended USB connector underneath the scale.

#### **Serial setting**

- 9600 Baud
- No parity
- 1 stop bit

The scanner must be configured to interpret EAN/UPC family barcodes or Code 39 barcodes. The type of barcode will depend on the application to be used.

Refer to the instructions supplied by the scanner manufacturer for details of how to do this.

# 7.1.3 Expansion Interface (P11)

Pin	Function	
1	+VS	
2		
3	+3V3	
4	0V.	
5	EXP I/O pin 1 (SCLK)	
6	EXP I/O pin 2 (SDI)	
7	EXP I/O pin 3 (SDO)	
8	EXP I/O pin 4 (CS_bar)	
9	USB serial data+	
10	USB serial data-	
11	RESET_bar	
12		
13	RS232-RXD	
14	RS232-TXD	
15	RS232-RTS	
16	RS232-CTS	

# 7.2 Internal connections

# 7.2.1 IM100



Figure 7.2 Main board, displays, keyboard, transducer and printer

# 7.2.2 IM202



Figure 7.3 Main board, displays, keyboard, transducer and printer

## 7.2.3 IM300 body



Figure 7.4 Main board, loadcell, front display/keyboard, printer.



# 7.2.4 IM300 keyboards

Figure 7.5 IM300keyboards

IM series Service Instructions



# 7.2.5 IM400 loadcell, displays and keyboard

Figure 7.6 Main board, loadcell, displays and keyboard

# **Module information**

# 8

This chapter contains layout and electrical information for PCBs and hardware within the scale.

#### Contents

- 8.1 Main board (page 86)
- 8.2 Display PCB (page 88)

## 8.1 Main board



#### Figure 8.1 AWT25-000094

- 1. J7 Cash drawer
- 2. J1 Power supply
- 3. P15 On/Off switch
- 4. P8 Printer opto sensor
- 5. J6, J4 Front and rear displays (interchangeable)
- 6. P7 Printer stepper motor
- 7. P6 Print head interface
- 8. P10 Load cell
- 9. P9 USB
- 10. P5 Multi-ICE (not fitted)
- 11. P3 Battery back-up (normally on)
  - P2 Reset (normally off)
  - P12 Debug (normally off)

- P4 Debug (normally off)
- 12. BT1 Battery
- 13. J5 Ethernet
- 14. J3 USB (usually scanner)
- 15. P11 Expansion interface (Wifi)
- 16. P13 Wlan (not used)

#### 8.1.1 Pin outs

#### Loadcell connector

Pin	Function	
1	Load cell power	
2	0V	
3	Serial data from load cell	
4	Serial data to load cell	
5	Serial clock to load cell	
6	Load cell select	

# 8.2 Display PCB

There are two variants of the display interface depending on whether the interface board is driving screens/screens and keyboard or keyboard only.

Model	Description	Module 1	Module 2	Module 3
IM100	Mono scale	Display and keyboard	Display	
IM202	Tower scale	Keyboard	Display	Display
IM300 (1)	Self service scale	Display and keyboard	Keyboard	
IM300 (2)	Self service twin head scale	Display and keyboard	Keyboard	Display
IM400	Two piece scale	Display and keyboard	Display	
IM500	Hanging scale	Display and keyboard	Display	

# 8.2.1 Display/keyboard variant

This PCB is used for both customer and vendor displays.

It drives the graphics panel and can be connected to a membrane keyboard.



#### Figure 8.2 AWT25-000092

 To main board or another display board These connectors are interchangeable.

- 2. Keyboard screen tail
- 3. Keyboard earth
- 4. Bleeper
- 5. Address configuration links (see table)
- 6. Not fitted (programming factory use only).
- 7. Not fitted on display variant.

#### 8.2.2 Keyboard only variant

This PCB can be connected to a membrane keyboard and a self service keyboard. It does not support a graphics panel.



#### Figure 8.3 AWT25-000235

1. To main board or another display board

These connectors are interchangeable.

- 2. Keyboard screen tail
- 3. Keyboard earth

- 4. Bleeper
- 5. Address configuration links (see table)
- 6. Not fitted (programming factory use only).
- 7. Self service keyboard connector (P3).

# 8.2.3 Link settings for display interface

#### AWT25-000092

Module 1	LI	K1	LI	<2	Resistor link
Front display and keyboard IM100, IM300, IM400	Keyboard on	ON	Front	ON	Not fitted
Front display only IM202	Keyboard off	OFF	Front	ON	Not fitted
Test mode		ON		OFF	Not fitted
Rear display only IM100, IM202, IM400	Keyboard off	OFF	Rear	OFF	Not fitted

#### AWT25-000235

Module 1	Lł	K1	Lł	٢2	Resistor link
linternal keyboard IM202	Keyboard 1	ON	Internal	ON	Fitted
Test mode		OFF		ON	Fitted
Self service 1 IM300	Keyboard 1	ON	Self service	OFF	Fitted
Self service 2 IM300	Keyboard2	OFF	Self service	OFF	Fitted

# Networking

# 9

A network allows a number of scales to be connected together. Scales on a network can share resources and information

#### Contents

- 9.1 Typical networks (page 92)
- 9.2 Network protocol (page 94)
- 9.3 Wiring/terminations (page 94)
- 9.4 Network setup (page 95)
- 9.5 Network map (page 99)
- 9.6 Backup server operation (page 100)
- 9.7 Local mode (page 101)

# 9.1 Typical networks

#### 9.1.1 Introduction

A network allows a number of scales to be connected together. Scales on a network can share resources and information (operators, PLUs etc.).

Networked scales are assigned to groups. The network can contain up to 99 groups, each having up to 10 scales. See

The machines can be connected to either one physical network hub or to several hubs.

Two scales can be connected together without the use of a hub. A simple cross cable is used to connect the two machines together.

#### 9.1.2 Multi scale network

Scales are connected together using one or several hubs as required. The number and position of the hubs required is determined by the store layout and the type of hub used.

For example, hub arrangement could be affected by:

- Proximity of machines to each other.
- Number of network inputs available at each hub.



Figure 9.1 Typical multi-scale network



# 9.1.3 Scale groups (Network ID)

Figure 9.2 Network with scale groups

- Machines can be put into groups of up to ten scales.
- The scale group is assigned by the **network ID** number.
- Up to 99 groups of scales can be connected to a network, giving a total of 990 scales.
- Each group of scales will have a server and a number of client scales.

**Note:** For scales to share PLU information etc. with each other, they must be within the same group. (I.E. have the same network ID number

See *Manual network configuration* on page 96 for details of network ID and other settings.

#### 9.2 Network protocol

IM series scales' network protocol and speed are as follows:

- TCP ICP protocol.
- 10Mbs or 100 Mbs, 10 base T ethernet connection.

#### 9.3 Wiring/terminations

**Note:** Before setting up an in-store network, obtain the appropriate IP addresses from the store IT administrator.

Enter the addresses at the machines before connecting the network. See 9.4, Network setup for more information.

For wiring and termination details refer to the 'Connecting PC networks' book, part number 76102-559.

#### 9.3.1 Cable lengths

The maximum cable length between each machine and the hub is one hundred metres.

*Note:* It is usual to allow 5m at either end for the patch cable from the scale to the wall socket. This allows 90m for the cable run between network wall socket and patch panel.

If the connections between hubs use 10 base T connections, then there should be no more than four hubs in series.

#### 9.4 Network setup

The network settings are configured from within manager mode.

To enter manager mode you can:

- 1. Enter service mode (see page 19).
- 2. Press the  $|_{\widehat{\boxplus}}|$  key on the programming overlay.

or

- 1. From sales mode, press 💓 and enter the manager PIn.
- 2. Follow the steps on screen.

For more detailed information on the manager menu operation see the separate user instructions.

#### Set up notes:

• For DHCP networks, set the IP address at each scale to 0.0.0.0.

IP addresses will then be allocated by the DHCP server for the network.

- For new installations, using Auto Configure to install machines to a network is a very quick way of getting all the machines working.
- Where Auto Configure is not suitable you can manually alter each machine's network settings.

## 9.4.1 Auto Configure

You can use this function to set up a stand-alone network of scales 'out of the box'.

Auto configure will:

- Detect all the machines that are connected to the network and have the same network ID.
- If there are no servers, it will make the machine that you are using into the server. The machine ID will be made into ID1 or the next available ID number. The server will then find each client machine in turn and give it a machine ID.
- If a server already exists, then the machine you are using will become a client machine and be given the next available machine ID.

*Note:* This option will only assign scales within a single group. (i.e up to 10 scales, having the same network ID.

For greater than 10 scales, only 10 will be auto-configured. The remainder must be manually configured to be in a different group (with a different network ID).

 Machine IDs will be allocated in no particular order, so may not follow any logical pattern.

#### Auto configuration procedure:

- 1. Connect all the scales to the network hub and switch on.
- 2. Ensure that the network ID at each scale is set.
- 3. At the **server** scale, go to 'Auto configure' and press



The scale that you are using will automatically detect the other scales within the group. This machine will become the server and the rest of the machines will be client machines.

Auto configure can also be used to add a new scale into an existing group. When doing this you may need to update the scale's PLU file by performing a network dump.

- 1. Connect all the scales to the network hub and switch on.
- 2. Ensure that the network ID at each scale is set.
- 3. At the **server** scale, go to 'Auto configure' and press



The scale that you are using will automatically detect the other scales within the group. This machine will become the server and the rest of the machines will be client machines.

Auto configure can also be used to add a new scale into an existing group. When doing this you may need to update thescale's PLU file by performing a network dump.

#### 9.4.2 Manual network configuration

For each scale, you may manually configure the settings described in this section.

#### **Machine ID**

Used to set the scale's ID within its group.

Setting	Description
Machine ID	0 = stand alone scale (not networked). 1 - 10 = The machine ID within its group of scales.
Server / Client	Set the scale to be either a server or a client scale.

Before setting a client machine to be a server you should:

- clear all transactions.
- clear all totals.

If a server already exists on the network then:

- the new server becomes the back up server.
- an existing back up server will revert to client status.

• If you change a back up server to be a server, the old server becomes the back up.

*Note:* See *Backup server operation on page 100, for more information.* 

#### **Network dump**

For a group of scales (all sharing the same network ID); this option synchronises all data held at the client machines with that of the server.

#### M/c Setup dump

This option transfers all machine information (not system data) to the specified scale.

#### 9.4.3 Advance settings

If you are installing a scale to an established network, then you must gather information about the network. The easiest way to do this is to use an existing scale to print a test report (press the test key twice). The settings of the new scale must be set so it will communicate with the existing scales on the network.

#### IP Address / Sub net mask

The IP address of the scale consists of two parts, the network address and the machine address. The network address must be the same as all the other scales on the same network, and the machine address must be different from the other scales on the same network.

The network address depends on which sub-net mask is used, for example for an IP address of 88.1.1.7:

Sub-net mask	255.0.0.0	255.255.0.0	255.255.255.0
Network address	<b>88</b> .1.1.7	<b>88.1</b> .1.7	88.1.1.7
Machine address	88.1.1 <b>.7</b>	88.1. <b>1.7</b>	88.1.1 <b>.7</b>

For DHCP networks, set the IP address at each scale to 0.0.0.0. IP addresses will then be allocated by the DHCP server for the network.

**Note:** When manually setting up a network (i.e. DHCP is not applicable), obtain the IP addresses from the store IT administrator. Enter the addresses at the machines before connecting the network.

#### Host name

For networks using DHCP, a unique text identifier may be programmed for each scale on the network.

#### **Gateway IP address**

A gateway can be used to bridge between 2 devices with different network addresses.

The gateway will have a network address the same as the scale's and will re-route communications as required.

#### **Network ID**

A number 0-99 which is used to assign a scale to a particular group. See *Scale groups* (*Network ID*) on page 93.

#### Host port number

The host port number should only be changed if there is a conflict between the scale and some other piece of equipment. All machines in the same network must have the same base port number.

#### **Ping IP Address**

Used to test communications between the scale and another known IP address.

#### Data clone

Clones data from this scale to another within the same group. See *Data clone* on page 37.

#### 9.4.4 Removing a scale

A scale can be removed from the network using the following option:

#### Manager mode >> Communication >> Machine ID

#### In brief

To remove a client scale from the network:

• Go to the client to be removed and set the **machine ID** to **0**.

This will remove the client from the network and also inform the server of the change.

To remove a scale that is already off-line (fault reported at the server):

1. Go to the server and view the network map.

2. Press **c** to accept the map.

3. Press Yes to save the change (and clear the fault)

9.5 Network map

# 9.5 Network map

The network map shows the status of all the machines in the network group.

IM 100	Max 15kg Min 100g e=5g		
1 - 10			
SCCOXXCCCX			

S = Server B = Back up server C = Client O = Off-line E = PLU file error X = No machine presentL = Local mode



*Note:* If a machine has been removed from the network, pressing 'Yes' to save will remove it from the network map.

## 9.6 Backup server operation

The backup server is a backup of the primary server. It is synchronised with the primary and hence contains identical information. It is used as a fail-safe for when the primary server is off line.

- If the primary server goes down, the backup server will become the primary server. When restored, the previous primary server will become the backup server.
- The receipt and transaction memory settings on the backup server must be identical to the main server.
- Although the backup and server continuously synchronise, the system should not be operated for extended periods with one server switched off. If this is the case (e.g. repair) the totals, transactions and the audit list should be cleared before reinstating a second server to ensure that they are synchronised.
- The date and time of synchronisation start and finish is stored in the system log.
- If you attempt to clear totals or transactions with backup off-line, a warning message is given.
- If more than one server is set the server that powers up first will be the primary server with the second set to the backup server.
- In the instance of a communications failure between backup and primary servers, the backup server will become primary, when the cable is reconnected there will be two servers. In this instance the first server to detect this will demote the other to backup server.
- The backup server acts as client in terms of clearing totals etc. i.e. the request is sent to the primary server, the backup server will also perform the request locally.
- If both servers have failed the client will ask if the user wishes to enter local mode. on confirmation all totals and transactions will be cleared from the client local memory. The first transaction or total request, for each operator on the local machine will display a warning to re-enter transactions.

#### 9.7 Local mode

#### 9.7 Local mode

If a client scale becomes disconnected from the server (e.g. because of a network fault). It will operate in local mode.

A machine operating in local mode will generate and store, totals, receipts and transactions locally.

#### 9.7.1 Local mode recovery

When the network is restored, the server will recover transaction data from all machines in local mode, and restore all local machines as clients.

The server will then re-generate the local machine totals using the transaction data collected.

**Note:** If the local mode machine fails to store all transactions (e.g. because of insufficient memory) then the totals generated by the server will be incorrect.

#### 9.7.2 Transaction memory in local mode

For a scale operating in local mode, the transaction memory stores both live and cleared transactions until the server is back on line and able to synchronise the data. It is therefore important that sufficient transaction memory is allocated. See *Memory setting guidelines* on page 45.

# Index

# A

ADD key 16 Alternative currency 34 currency rate and symbol 34 Auto Configure 96

#### В

Backup server 100

# С

Calibration 31 Clear key 15 Client 93 Clone data 37 machine 36 Cold Start 44 Comms log 49 Configuration tables 24 country configuration 27 Currency text 47

# D

Data clone 98 DHCP 95, 97 Diagnostics 22, 23 dynamic RAM test 23 keyboard test 22 network test 23 printhead life 23 weighing test 22 Dual server 47

# Ε

Edit Format 38 Enter key 16 Euro wizard 35 setup 35 Explode views IM100 body 70 IM202 head up display 72 IM202 scale body 71 IM300 self service keyboard 73 IM400 display and keyboard 75 IM400 scale body 74

# F

Factory reset 44 Factory reset values 45 Field position 41 Fix key 15

# G

Gravity 32

# 

Initialise 44 Initialise machine 44 IP Address 97 IP addresses 95

# K

Key log 49

# L

Label editor 38 Log size 50

# Μ

M/c Setup dump 97 Machine address 97 Machine ID 96 Memory settings 45 guidelines 45

# Ν

Network 92 Advance settings 97 auto configure 95 backup server 100 cable lengths 94 data clone 98 gateway 97 host name 97 host port number 98 local mode 101 local mode recovery 101 local mode transaction memory 101 map 99 primary server 100 setup 95 sub net mask 97

wiring 94 Network address 97 Network dump 97 Network ID 93, 98

# 0

Override key 16

# Ρ

Price base key 16 Primary currency 35 Print Logs 49 Printer setup 43 density 43 sensor 43 Printhead life 50

# R

Restart 44

# S

Secondary currency 34 Server 93 Service mode 17, 51, 77, 91 enter/exit 19 full service access 19 navigating menus 21 overview 18 restricted service access 20 Service PIN 33 Service procedures column mounting 63 customer display 56 firmware update 53 front module/vendor displays 59 loadcell 66 main board 65 replacing a display 62 tower display 61 vendor display and keyboards 60 Service setup 43 Single server 46 System log 49

# Т

Total/print key 15 Trans memory client 46 server 46

# V

Void key 16

## W

Warm restart 44 Wiring networks 94

#### Ζ

Zero key 15

#### Avery Berkel

Foundry Lane, Smethwick, West Midlands, England B67 9DF Tel: +44 (0)870 903 2000

Email: info@averyberkel.com www.averyberkel.com

