

# **MICREX-SX** *series*

## **SPH**

### **USER'S MANUAL**

---

## **General Purpose Communication Module**

**Type: NP1L-RS1 (RS-232C: 1CH, RS-485: 1CH)**

**NP1L-RS2 (RS-232C: 1CH)**

**NP1L-RS3 (RS-232C: 2CH)**

**NP1L-RS4 (RS-485: 1CH)**

**NP1L-RS5 (RS-485: 2CH)**

This User's Manual explains the system configuration of SPH general purpose communication module, the specifications and operation of the modules.

Read this manual carefully to ensure correct operation. When using modules or peripheral devices, be sure to read the corresponding user's manuals listed below.

## <Relative manuals for the SX-Programmer Expert (D300win)>

Title	Manual No.	Contents
User's Manual Instruction, MICREX-SX series	FEH200	Explains the memory, language and system definitions of the MICREX-SX series.
User's Manual Hardware, MICREX-SX series SPH	FEH201	Explains the system configuration, the specifications and operations of modules in the MICREX-SX series.
User's Manual D300win <Reference>, MICREX-SX series	FEH254	Explains the menu and icon of D300winV2 and all of the operations of D300winV2.
User's Manual D300win <Reference>, MICREX-SX series	FEH257	Explains the menu and icon of D300winV3 and all of the operations of D300winV3.
User's Manual Standard Extended FB, MICREX-SX series	FEH255	Explains the specification of Standard Extended FB of the attachment to D300win.

## <Relative manuals for the SX-Programmer Standard (Standard Loader)>

Title	Manual No.	Contents
User's Manual Instruction, MICREX-SX series	FEH588	Explains the memory, language and system definitions of the MICREX-SX series.
User's Manual Hardware, MICREX-SX series SPH	FEH201	Explains the system configuration, the specifications and operations of modules in the MICREX-SX series.
User's Manual SX-Programmer Standard <Reference>, MICREX-SX series	FEH590	Explains the menu and icon of the SX-Programmer Standard and all of the operations of the SX-Programmer Standard.

\*This manual is structured to be applicable to both D300win and Standard Loader.

\*In addition to the above manuals, the following Fuji Electric FA Components & Systems Co., Ltd. site offers various manuals and technical documents associated with MICREX-SX.

**URL** <http://www.fujielectric.co.jp/fcs/eng/index.html>

### Notes

1. This manual may not be reproduced in whole or part in any form without prior written approval by the manufacturer.
2. The contents of this manual (including specifications) are subject to change without prior notice.
3. If you find any ambiguous or incorrect descriptions in this manual, please write them down (along with the manual No. shown on the cover) and contact FUJI.

# Safety Precautions

Be sure to read the “Safety Precautions” thoroughly before using the module.  
Here, the safety precaution items are classified into “Warning” and “Caution.”



**Warning**

: Incorrect handling of the device may result in death or serious injury.



**Caution**

: Incorrect handling of the device may result in minor injury or physical damage.

Even some items indicated by “Caution” may also result in a serious accident.

Both safety instruction categories provide important information. Be sure to strictly observe these instructions.

## **Warning**

- ◇ Never touch any part of charged circuits as terminals and exposed metal portion while the power is turned ON.  
It may result in an electric shock to the operator.
- ◇ Turn OFF the power before mounting, dismounting, wiring, maintaining or checking, otherwise, electric shock, erratic operation or troubles might occur.
- ◇ Place the emergency stop circuit, interlock circuit or the like for safety outside the PLC.  
A failure of PLC might break or cause problems to the machine.
- ◇ Do not connect in reverse polarity, charge (except rechargeable ones), disassemble, heat, throw in fire or short-circuit the batteries, otherwise, they might burst or take fire.
- ◇ If batteries have any deformation, spilled fluids, or other abnormality, do not use them. The use of such batteries might cause explosion or firing.
- ◇ Do not open the FG terminal with the LG-FG short circuited.  
(It must be grounded, otherwise it might cause electric shock.)

# Safety Precautions

## Caution

- ◇ Do not use one found damaged or deformed when unpacked, otherwise, failure or erratic operation might be caused.
- ◇ Do not shock the product by dropping or tipping it over, otherwise, it might be damaged or troubled.
- ◇ Follow the directions of the operating instructions when mounting the product.  
If mounting is improper, the product might drop or develop problems or erratic operations.
- ◇ Use the rated voltage and current mentioned in the operating instructions and manual. Use beyond the rated values might cause fire, erratic operation or failure.
- ◇ Operate (keep) in the environment specified in the operating instructions and manual. High temperature, high humidity, condensation, dust, corrosive gases, oil, organic solvents, excessive vibration or shock might cause electric shock, fire, erratic operation or failure.
- ◇ Select a wire size to suit the applied voltage and carrying current. Tighten the wire terminals to the specified torque. Inappropriate wiring or tightening might cause fire, malfunction, failure, or might cause the product to drop from its mounting.
- ◇ Contaminants, wiring chips, iron powder or other foreign matter must not enter the device when installing it, otherwise, erratic operation or failure might occur.
- ◇ Remove the dust-cover seals of modules after wiring, fire, accidents, failure or fault might occur.
- ◇ Connect the ground terminal to the ground, otherwise, an erratic operation might occur.
- ◇ Periodically make sure the terminal screws and mounting screws are securely tightened.  
Operation at a loosened status might cause fire or erratic operation.
- ◇ Put the furnished connector covers on unused connectors, otherwise, failure or erratic operation might occur.
- ◇ Install the furnished terminal cover on the terminal block, otherwise, electric shock or fire might occur.
- ◇ Sufficiently make sure of safety before program change, forced output, starting, stopping or anything else during a run.  
The wrong operation might break or cause machine problems.
- ◇ Engage the loader connector in a correct orientation, otherwise, an erratic operation might occur.
- ◇ Before touching the PLC, discharge any static electricity that may have been collected on your body.  
To discharge it, touch a grounded metallic object. Static electricity might cause erratic operation or failure of the module.
- ◇ Be sure to install the electrical wiring correctly and securely, observing the operating instructions and manual. Wrong or loose wiring might cause fire, accidents, or failure.
- ◇ When disengaging the plug from the outlet, do not pull the cord, otherwise, break of cable might cause fire or failure.
- ◇ Do not attempt to change system configurations (such as installing or removing I/O modules) while the power is ON, otherwise, failure or erratic operation might occur.
- ◇ Do not attempt to repair the module by yourself contact your Fuji Electric agent. When replacing the batteries, correctly and securely connect the battery connectors, otherwise, fire, accidents or failure might occur.
- ◇ To clean the module, turn power off and wipe the module with a cloth moistened with warm water. Do not use thinner or other organic solvents, as the module surface might become deformed or discolored.
- ◇ Do not remodel or disassemble the product, otherwise, a failure might occur.
- ◇ Follow the regulations of industrial wastes when the device is to be discarded.
- ◇ The modules covered in these operating instructions have not been designed or manufactured for use in equipment or systems which, in the event of failure, can lead to loss of human life.
- ◇ If you intend to use the modules covered in these operating instructions for special applications, such as for nuclear energy control, aerospace, medical, or transportation, please consult your Fuji Electric agent.
- ◇ Be sure to provide protective measures when using the module covered in these operating instructions in equipment which, in the event of failure, may lead to loss of human life or other grave results.
- ◇ External power supply (such as 24V DC power supply) which is connected to DC I/O should be strongly isolated from AC power supply.

# Revisions

\*Manual No. is shown on the cover.

Printed on	*Manual No.	Revision contents
Sep. 1998	FEH225	First edition
Jan. 2002	FEH225a	Contents changed according to changes of extended FB specifications. <ul style="list-style-type: none"><li>• Contents changed according to inclusion of a part of the non-procedural FB in the firmware and reduction of the capacity of the non-procedural FB.</li><li>• Contents changed according to addition of the modem loader function.</li><li>• Descriptions of the standard extended FB in Appendix 2 deleted and reprinted in "Standard Extended FBs for General Purpose Communication Module (FEH255)."</li></ul>
Mar. 2004	FEH225b	<ul style="list-style-type: none"><li>• The content of "6-2 Wiring method" was reviewed.</li><li>• Wrong description in paragraph 3-2-7 was corrected.</li><li>• Communication specifications for "Modem loader" and "Programming loader" modes were added to paragraph 2-3-2.</li></ul>
Jan. 2005	FEH225c	<ul style="list-style-type: none"><li>• NP1L-RS3 was added</li><li>• Wrong description in paragraph 3-4-1 was corrected.</li><li>• Paragraph 4-3-1 Note2 was added.</li><li>• Wrong description in paragraph 6-2-2 was corrected.</li><li>• Appendix 2-3-1 Memory type code 00h, 01h deleted.</li></ul>
Jul. 2006	FEH225d	<ul style="list-style-type: none"><li>• NP1L-RS5 was added (Appendix 4)</li></ul>

## Preface

## Safety Precautions

## Revisions

## Contents

Page

<b>Section 1 General .....</b>	<b>1-1</b>
<b>1-1 General .....</b>	<b>1-1</b>
<b>1-2 Selections and Programs for the Communication .....</b>	<b>1-2</b>
<b>1-3 General Purpose Communication Package for Factory Automation Machine .....</b>	<b>1-3</b>
<b>1-4 Product Versions and Supported Functions .....</b>	<b>1-4</b>
1-4-1 Supported functions .....	1-4
1-4-2 Available standard extended FB .....	1-4
<b>Section 2 Specifications .....</b>	<b>2-1</b>
<b>2-1 General Specifications .....</b>	<b>2-1</b>
<b>2-2 Communication Specifications .....</b>	<b>2-2</b>
<b>2-3 Names and Functions .....</b>	<b>2-3</b>
2-3-1 Names .....	2-3
2-3-2 Functions .....	2-4
<b>2-4 Dimensions .....</b>	<b>2-7</b>
<b>Section 3 System Configuration .....</b>	<b>3-1</b>
<b>3-1 Mounting Restrictions .....</b>	<b>3-1</b>
3-1-1 Mounting position .....	3-1
3-1-2 Number of mountable modules .....	3-1
<b>3-2 System Configurations .....</b>	<b>3-2</b>
3-2-1 1:1 Connection using RS-232C port .....	3-2
3-2-2 1:N Connection using RS-485 port (N = max. 31 modules) .....	3-3
3-2-3 Connecting independently to RS-232C and RS-485 ports .....	3-4
3-2-4 Connection using RS-232C and RS-485 ports (2) .....	3-5
3-2-5 Connecting a personal computer loader to the RS-232C port and RS-485 port .....	3-7
3-2-6 Loader network configuration using RS-485 .....	3-7
3-2-7 Loader network configuration using modems (1) .....	3-8
<b>3-3 Loader Connecting Cable .....</b>	<b>3-9</b>
3-3-1 When connecting to RS-232C port .....	3-9
3-3-2 When connecting to RS-485 port .....	3-9
<b>3-4 Self-diagnosis .....</b>	<b>3-10</b>
3-4-1 Self-diagnosis mode 1 .....	3-10
3-4-2 Self-diagnosis mode 2 .....	3-11
<b>Section 4 Software Interface .....</b>	<b>4-1</b>
<b>4-1 General .....</b>	<b>4-1</b>
<b>4-2 Specifications for Non-procedural FB .....</b>	<b>4-3</b>
4-2-1 Communication specification .....	4-3
4-2-2 FB format .....	4-4
4-2-3 FB terminals .....	4-5

# Contents

	Page
<b>4-3 Initialization</b> .....	<b>4-7</b>
4-3-1 Initialization parameters .....	4-7
4-3-2 Initialization procedure .....	4-10
4-3-3 OPEN status list .....	4-10
<b>4-4 Data Sending</b> .....	<b>4-11</b>
4-4-1 Data sending procedure .....	4-11
4-4-2 Send status list .....	4-12
<b>4-5 Data Receiving</b> .....	<b>4-13</b>
4-5-1 Data receiving procedure .....	4-13
4-5-2 Receiving status list .....	4-14
<b>4-6 RAS Information</b> .....	<b>4-15</b>
<b>Section 5 Programming</b> .....	<b>5-1</b>
<b>5-1 Communication Program</b> .....	<b>5-1</b>
<b>5-2 Installation Procedure of Standard Extended FB</b> .....	<b>5-2</b>
<b>5-3 Registration in Library</b> .....	<b>5-5</b>
<b>5-4 Pasting Non-procedural FB</b> .....	<b>5-6</b>
<b>5-5 Communication Parameters Setting</b> .....	<b>5-7</b>
<b>5-6 Writing the Send Data</b> .....	<b>5-8</b>
<b>5-7 Connecting Variables and Commands to FB Terminals</b> .....	<b>5-9</b>
5-7-1 Connecting variable to "PARA" terminal .....	5-9
5-7-2 Operation for starting FB .....	5-9
5-7-3 Operation for sending data .....	5-10
5-7-4 Data receiving operation .....	5-10
<b>Section 6 Wiring</b> .....	<b>6-1</b>
<b>6-1 Precautions</b> .....	<b>6-1</b>
<b>6-2 Wiring Method</b> .....	<b>6-2</b>
6-2-1 When RS-485 is used (2-wire) .....	6-2
6-2-2 When RS-485 is used (4-wire system) .....	6-2
6-2-3 When RS-232C is used .....	6-3
<b>Section 7 RAS</b> .....	<b>7-1</b>
<b>7-1 RAS Information of General Purpose Communication Module</b> .....	<b>7-1</b>
<b>Appendix 1 JIS Code</b> .....	<b>App.1-1</b>
■ <b>JIS 7-bit Codes</b> .....	<b>App.1-1</b>
■ <b>JIS 8-bit Codes</b> .....	<b>App.1-1</b>
<b>Appendix 2 Data Access by Command</b> .....	<b>App.2-1</b>
<b>Appendix 2-1 Command Overview</b> .....	<b>App.2-1</b>
<b>Appendix 2-2 Send Data Format of Commands</b> .....	<b>App.2-2</b>
<b>Appendix 2-3 Loader Command Details</b> .....	<b>App.2-4</b>
Appendix 2-3-1 Read data .....	App.2-4
Appendix 2-3-2 Write data .....	App.2-6
Appendix 2-3-3 Batch Start of CPUs .....	App.2-7
Appendix 2-3-4 Batch Initialization Start of CPUs .....	App.2-7
Appendix 2-3-5 Batch Stop of CPUs .....	App.2-7
Appendix 2-3-6 Batch Reset of CPUs .....	App.2-8

Appendix 2-3-7 Individual Start of CPU .....	App.2-8
Appendix 2-3-8 Individual Initialization Start of CPU .....	App.2-8
Appendix 2-3-9 Individual Stop of CPU .....	App.2-9
Appendix 2-3-10 Individual Reset of CPU .....	App.2-9

## **Appendix 3 Additional Explanation for NP1L-RS3 ..... App.3-1**

<b>Appendix 3-1 Applicable Version for NP1L-RS3 .....</b>	<b>App.3-1</b>
<b>Appendix 3-2 General Specifications .....</b>	<b>App.3-1</b>
<b>Appendix 3-3 Names and Functions .....</b>	<b>App.3-1</b>
Appendix 3-3-1 Names .....	App.3-1
Appendix 3-3-2 Functions .....	App.3-2
<b>Appendix 3-4 Self-diagnosis .....</b>	<b>App.3-3</b>
Appendix 3-4-1 Self-diagnosis mode 1 .....	App.3-3
Appendix 3-4-2 Self-diagnosis mode 2 .....	App.3-3
<b>Appendix 3-5 Initialization Parameters .....</b>	<b>App.3-3</b>
<b>Appendix 3-6 Detailed RAS .....</b>	<b>App.3-4</b>

## **Appendix 4 Additional Explanation for NP1L-RS5 ..... App.4-1**

<b>Appendix 4-1 Applicable Version for NP1L-RS5 .....</b>	<b>App.4-1</b>
<b>Appendix 4-2 General Specifications .....</b>	<b>App.4-1</b>
<b>Appendix 4-3 Names and Functions .....</b>	<b>App.4-1</b>
Appendix 4-3-1 Names .....	App.4-1
Appendix 4-3-2 Functions .....	App.4-2
<b>Appendix 4-4 Self-diagnosis .....</b>	<b>App.4-4</b>
Appendix 4-4-1 Self-diagnosis mode 1 .....	App.4-4
Appendix 4-4-2 Self-diagnosis mode 2 .....	App.4-4
<b>Appendix 4-5 Initialization Parameters .....</b>	<b>App.4-4</b>
<b>Appendix 4-6 Loader Network Functions .....</b>	<b>App.4-4</b>
<b>Appendix 4-7 Detailed RAS .....</b>	<b>App.4-5</b>

---

# Section 1 General


---

	Page
<b>1-1 General.....</b>	<b>1-1</b>
<b>1-2 Selections and Programs for the Communication .....</b>	<b>1-2</b>
<b>1-3 General Purpose Communication Package for Factory Automation Machine .....</b>	<b>1-3</b>
<b>1-4 Product Versions and Supported Functions .....</b>	<b>1-4</b>
1-4-1 Supported functions .....	1-4
1-4-2 Available standard extended FB .....	1-4

NP1L-RS1/2/4 are communication modules which enable data communication between a CPU module and external devices, and which are connected to the base board (on the SX bus) of MICREX-SX series. (NP1L-RS1/2/4 are sometimes abbreviated as RS1/2/4.)


The port type and the number of ports are as follows:

Type	No. of ports
NP1L-RS1	RS-232C: 1 channel, RS-485: 1 channel
NP1L-RS2	RS-232C: 1 channel
NP1L-RS4	RS-485: 1 channel




<Overview of SX bus connection>

Loader software package for a personal computer




# 1-2 Selections and Programs for the Communication

The following preparations are necessary for RS1/2/4 to communicate between a CPU module of MICREX-SX series and external devices.



<CPU modules side>

- Initializing parameters for a RS-232C port and a RS-485 port. (Transmission speed, data length, parity bit, stop bits etc.,)
- Application software for the communication.




FA packages are optionally provided for each external device.

<RS1/2/4 side>

- Selection switch of the module is used.
- RS-485 station No. selection switch (0 to F)  
If RS-485 port is not used, the selection is not necessary.
  - Mode selection switch  
Device selection of RS-232C port and RS-485 port, Data conversion
  - RS-485 terminating resistor ON/OFF switch  
ON/OFF of terminating resistor is selected.  
If RS-485 port is not used, this switch is ignored.

External device



<External device side>

- Transmission speed, data length, parity bit, stop bits etc.
- Application software for the communication.

# 1-3 General Purpose Communication Package for Factory Automation Machine

Nonsequenced FB is provided for NP1L-RS1/2/4 to communicate with external serial devices. (Included in D300win.)  
General purpose communication package for Factory Automation machine (NP4N-COMF) is provided to communicate with specified external serial devices.

NP4N-COMF includes following function blocks.

Procedure	FB name	Device
Temperature controller	_CrkREX	RIKA KOGYOU CO., LTD. REX-F, REX-D, FAREX-SR series
	_Com AX	OMRON Corporation. Digital temperature controller E5AX, E5XJ series
	_ComCK	OMRON Corporation. Digital temperature controller E5CK series
	_CymSDC	Yamatake Corporation. Digitronic temperature controller SDC40A/40G series
ID system	_ComV6	OMRON Corporation. V600 series
	_CshDS	SHARP MANUFACTURING SYSTEM CORPORATION. Microwave ID plate system DS series
	_CymWAM	Yamatake Corporation. Code distinguish ID system WAM120 series
	_CizFP	IDEAC IZUMI CORPORATION. Data carrier system FP1A series
Bar code reader	_CtkTCD	THOKEN Co., Ltd. TCD8200/8500, TLMS-3200RV series
	_CndBCC	NIPPON ELECTRIC INDUSTRY CO., LTD. BCC2600 series, BL500, BL700
	_CkyBL	KEYENCE CORPORATION. BL180 series
	_CizDS	IZUMI DATA LOGIC CO., LTD. Bar code reader DS series
SECS	_C_SECS	SECS procedure semiconductor manufacturing system (for SECS-I only)

Note: General purpose communication FB in the table below is included in D300win.

Type	FB name	FB Overview
Non-procedural FB	_C_free (Note 1)	Non-procedural FB Send: 512 words Receive: 512 words
	_Cfr252 (Note 1)	Non-procedural FB Send: 252 words Receive: 252 words
	_Cfr128 (Note 1)	Non-procedural FB Send: 128 words Receive: 128 words
	_Cfr64 (Note 1)	Non-procedural FB Send: 64 words Receive: 64 words
	_Cfr32 (Note 1)	Non-procedural FB Send: 32 words Receive: 32 words
	_Cfrpr (Note 1)	Non-procedure FB which built into communication protocol Send: 512 words Receive: 512 words The program capacity is reduced by performing a part of the communication processing with the module.
	_Cfrp2 (Note 2)	Non-procedure FB which built into communication protocol Send: 512 words Receive: 512 words The program capacity is reduced by performing a part of the communication processing with the module. In addition, communication processing can be made high-speed by using two SX bus message ports.
For FUJI Inverter	_CfdFRN (Note 2)	For FUJI Inverter FRENIC series
	_CfdFVR (Note 2)	For FUJI Inverter FVR-C11 series (FGI-BUS)
	_Cfvrpr (Note 2)	For FUJI Inverter FVR-C11 series (FGI-BUS) The program capacity is reduced by performing a part of the communication processing with the module.
For FUJI heater	_CfdPYX (Note 2)	For FUJI heater PYX series and PYH series
For FUJI bar code	_CfdPK (Note 2)	For FUJI bar code reader PK2 series

Note 1: Refer to Section 4 in this manual.

Note 2: For \_Cfrp2, \_CfdFRN, \_CfdFVR, \_Cfvrpr, \_CfdPYX, and \_CfdPK, refer to "MICREX-SX USER'S MANUAL STANDARD EXTENDED FB (FEH255)."

# 1-4 Product Versions and Supported Functions

For the general purpose communication module, supported functions and available FBs depend on the product version.

## 1-4-1 Supported functions

Note 2: ○: supported ×: Not supported

Format and version	Modem-based loader function 1	Modem-based loader function 2
Earlier than NP1L-RS1 V.1031	×	×
Earlier than NP1L-RS2 V.1031	×	×
Earlier than NP1L-RS4 V.1031	—Note 1	—Note 1
NP1L-RS1 V.1031 or later	○	×
NP1L-RS2 V.1031 or later	○	×
NP1L-RS4 V.1031 or later	—Note 1	—Note 1
NP1L-RS1 V.2535 or later	○	○
NP1L-RS2 V.2535 or later	○	○
NP1L-RS4 V.2535 or later	—Note 1	—Note 1

Note 1: The modem-based loader functions are functions which realize remote operation and programming by connecting a modem to the RS-232C port and using the public circuit. These functions cannot be used with the NP1L-RS4 which is provided only with the RS-485 port.

Note 2: With modem-based function 1, the transmission rate between this module and a commercial modem is fixed to 19200 bps. With modem-based function 2, the transmission rate can be selected from 9600, 19200, and 38400 bps.

## 1-4-2 Available standard extended FB

FB Name	FB Overview	Applicable version of general purpose communication module
_C_free	Non-procedural FB Send: 512 words Receive: 512 words	All versions
_Cfr252	Non-procedural FB Send: 252 words Receive: 252 words	
_Cfr128	Non-procedural FB Send: 128 words Receive: 128 words	
_Cfr64	Non-procedural FB Send: 64 words Receive: 64 words	
_Cfr32	Non-procedural FB Send: 32 words Receive: 32 words	
_Cfrpr	Non-procedure FB which built into communication protocol Send: 512 words Receive: 512 words The program capacity is reduced by performing a part of the communication processing with the module.	V.2535 or later
_CfrP2	Non-procedure FB which built into communication protocol Send: 512 words Receive: 512 words The program capacity is reduced by performing a part of the communication processing with the module. In addition, communication processing can be made high-speed by using two SX bus message ports.	V.2536 or later
_CfdFRN	For FUJI Inverter FRENIC series	All versions Note 1
_CfdFVR	For FUJI Inverter FVR-C11 series (FGI-BUS)	All versions Note 1
_Cfvrpr	For FUJI Inverter FVR-C11 series (FGI-BUS) The program capacity is reduced by performing a part of the communication processing with the module.	V.2536 or later Note 1
_CfdPYX	For FUJI heater PYX series and PYH series	All versions Note 1
_CfdPK	For FUJI bar code reader PK2 series	All versions Note 2

Note 1: This FB uses the RS-485 port. Cannot be used with the NP1L-RS2 which is provided only with the RS-232C port.

Note 2: This FB uses the RS-232C port. Cannot be used with the NP1L-RS4 which is provided only with the RS-485 port.

---

## Section 2 Specifications

---

	Page
<b>2-1 General Specifications .....</b>	<b>2-1</b>
<b>2-2 Communication Specifications .....</b>	<b>2-2</b>
<b>2-3 Names and Functions .....</b>	<b>2-3</b>
2-3-1 Names .....	2-3
(1) NP1L-RS1 .....	2-3
(2) NP1L-RS2 .....	2-3
(3) NP1L-RS4 .....	2-4
2-3-2 Functions .....	2-4
<b>2-4 Dimensions .....</b>	<b>2-7</b>

Item		Specification
Physical environmental conditions	Operating ambient temperature	0 to 55° C
	Storage temperature	-25 to +70° C
	Relative humidity	20 to 95%RH no condensation
	Pollution degree	2
	Corrosion immunity	Free from corrosive gases. Not stained with organic solvents.
	Operating altitude	2000m or less above sea level (Transport condition: 70kPa or more)
Mechanical service conditions	Vibration	Half amplitude: 0.15mm, Constant acceleration: 19.6m/s <sup>2</sup>
	Shock	Acceleration peak: 147m/s <sup>2</sup>
Electrical service conditions	Noise immunity	1.5kV (1kV: clamping to transmission line) , rise time 1ns, pulse width 1μs (noise simulator)
	Electrostatic discharge	Contact discharge: ±6kV Aerial discharge: ±8kV
	Radioelectromagnetic field	10V/m (80MHz to 1000MHz)
Construction	Panel-mounted type	
Cooling	Air cooling	
Isolation method	Photocoupler	
Dielectric strength	445V AC 1 minute (between I/O connector pins and ground)	
Insulation resistance	10MΩ or more with 500V DC megger (between I/O connector pins and ground)	
Internal current consumption	NP1L-RS1: 24V DC, 110mA or less NP1L-RS2: 24V DC, 90mA or less NP1L-RS4: 24V DC, 80mA or less	
Mass	NP1L-RS1: Approx. 170g NP1L-RS2: Approx. 160g NP1L-RS4: Approx. 160g	
Dimensions	Described in 2-4	

Item		Specification		
		RS-232C	RS-485	
Type		NP1L-RS1, NP1L-RS2, NP1L-RS4		
External interface	Port	NP1L-RS1	1 channel	1 channel
		NP1L-RS2	1 channel	—
		NP1L-RS4	—	1 channel
	Communication method	half-duplex communication (Note 1)		
	Synchronization method	Start-stop synchronous transmission		
	Transmission speed	1200/2400/4800/9600/19200/38400/57600 bps (Note 2) (for RS1, max. 57600bps or less in total of 2 channels) (Note 3)		
	Transmission distance	15m or less	1km or less (transmission speed: 19.2kbps or less)	
	No. of connectable modules	1:1 (One external device)	1:31 (Max.)	
Connection method	D-sub, 9-pin connector (female)	D-sub, 9-pin connector (male)		
Transmission protocol	Depends on the application program (FB) in the CPU module. Non-procedural FB (Included in D300win)			
Occupied slot	1 slot			
Status indication LED	ONL: Normally running — Green			
	ERR: General purpose communication module — Red			
	ALM: Communication error — Red RXD: Signal receiving — Green TXD: Signal sending — Green	ALM: Communication error — Red RXD: Signal receiving — Green TXD: Signal sending — Green		
	TS1, TS2: Self-diagnosis — Green			

Note 1: The use of the non-procedural FB allows this mode to be used like the full-duplex mode on applications.


Note 2: Transmission rates 300, 600, 76800, and 115200 bps can be used in the following combinations:

Version of general purpose communication module	Standard extended FB
V.2535 or later	_Cfrpr (Non-procedural FB with built-in protocol)
V.2536 or later	_Cfrp2 (Non-procedural FB with built-in protocol, 2-message version) _Cfvpr (Inverter procedure FB with built-in protocol)


Note 3: This limitation is applied to RS1 before version V2535.

2-3-1 Names


(1) NP1L-RS1



(2) NP1L-RS2



### (3) NP1L-RS4



### 2-3-2 Functions

#### 1) Status indication LED

This LED indicates the running status of NP1L-RS1/2/4.

#### NP1L-RS1

ONL	RS232	TS1
ALM	RXD TXD	
ERR	RS485	TS2

#### NP1L-RS2

ONL	RS232	TS1
ALM	RXD TXD	
ERR		TS2

#### NP1L-RS4

ONL	RXD TXD	TS1
ALM	RS485	
ERR		TS2

Symbol	Color	Description
ONL	Green	Turns on when the module is ready to communicate with the SX bus.
ERR	Red	Turns on when the module is abnormal.
RS232C ALM	Red	Turns on when the communication data via RS-232C is abnormal.
RS232C RXD	Green	Turns on when the RS-232C port is receiving data.
RS232C TXD	Green	Turns on when data is being sent from the RS-232C port.
RS485 ALM	Red	Turns on when the communication data via RS-485 is abnormal.
RS485 RXD	Green	Turns on when the RS-485 port is receiving data.
RS485 TXD	Green	Turns on when data is being sent from the RS-485 port.
TS1	Green	Blinks when internal RAM error is detected in self-diagnosis mode 7. Blinks when RS-232C turning back test is abnormal in self-diagnosis mode 8. (RST-CTS turning-back error)
TS2	Green	Blinks when RS-232C turning back test is abnormal in self-diagnosis mode 8. (DTR-DSR turning-back error)

#### \* Example of LED status by module status

	ONL	ERR	ALM
Fatal fault of module	OFF	ON	—
Nonfatal fault of module	ON	ON	—
Data error	ON	OFF	ON

**2) Mode selection switch**

This switch is used to select a connectable device, the signal conversion and the self-diagnosis for the RS-232C port and the RS-485 port.



Switch No.	Mode			Remarks
	RS-232C port	RS-485 port	RS-232C ↔ RS-485 Signal conversion	
0	General purpose device	General purpose device	Not available	
1	Programming loader	General purpose device	Not available	
2	General purpose device	Programming loader	Not available	
3	Programming loader	Programming loader	Not available	Applies to V2535 or later.
4	General purpose device	General purpose device	Available	
5	Not used			
6	Modem-loder 19200 bps	General purpose device	Not available	Applies to V1031 or later.
7	Self-diagnosis mode 1 (diagnoses internal memory and LED)			
8	Self-diagnosis mode 2 (diagnoses RS-232C, RS-485 turning back)			
9	Modem-loder 19200 bps	Programming loader	Not available	Applies to V1031 or later.
A	Modem-loder 9600 bps	General purpose device	Not available	Applies to V2535 or later.
B	Modem-loder 9600 bps	Programming loader	Not available	
C	Modem-loder 38400 bps	General purpose device	Not available	
D	Modem-loder 38400 bps	Programming loader	Not available	
E	Modem-loder 76800 bps	General purpose device	Not available	Applies to V2536 or later.
(Note 5) F	Modem-loder 115200 bps	Modem-loder 115200 bps	—	

Note 1: For details of the function mode, refer to “3-2 System configuration.”

Note 2: For the self-diagnosis, refer to “3-4 Self-diagnosis.”


Note 3: “Programming loader” is the mode for connecting to D300win. Communication specifications are fixed to “38400 bps” for transmission speed, “8 bits” for data length, “1 bit” for stop bits, and “even” for parity.

Note 4: “Modem-loder” is the mode that is basically used to connect to D300win loader via a modem. In general, for modems, “none” is specified for parity. Therefore, in this mode, communication specifications become “8 bits” for data length, “1 bit” for stop bits, and “none” for parity.

Note 5: Either channel is selected and used.


**3) RS-485 station No. selection switch**

This switch used to select a RS-485 station number of NP1L-RS1 or NP1L-RS4. Selecting range is 0 to F.



### 4) RS-232C port

This port is D-sub, 9-pin connector (female). This connector is connected to D-sub, 9-pin connector (male).



Pin No.	Signal name	Signal direction RS1/2 to external device	Description
1	CD	←	Carrier detect
2	RD	←	Receive data
3	SD	⇒	Send data
4	ER	⇒	Data terminal ready
5	SG		Signal ground (common return)
6	DR	←	Data set ready
7	RS	⇒	Request to send
8	CS	←	Clear to send
9	RI	←	Call indication

### 5) RS-485 terminating resistor ON/OFF switch


This switch used to select the ON/OFF of the RS-485 terminating resistor. There are three positions for this switch.



Switch position	Status
Left	2-wire type, Terminating resistor is available.
Center	Terminating resistor is not available.
Right	4-wire type, Terminating resistor is available.

### 6) RS-485 port


This port is D-sub, 9-pin connector (male). This connector is connected to D-sub, 9-pin connector (female).



Pin No.	Signal name	Signal direction RS1/4 to External device	Description
1	SDB	⇒	Send data signal line (-)
2	SDA	⇒	Send data signal line (+)
3	(SDB)	⇒	(Send data signal line (-))
4	(SDA)	⇒	(Send data signal line (+))
5	SG		Signal ground (common return)
6	FG		Frame ground
7			
8	RDB	←	Receive data signal line B (-)
9	RDA	←	Receive data signal line A (+)

Note: For wiring, refer to “6-2 Wiring.”

Dimensions are same for NP1L-RS1, NP1L-RS2 and NP1L-RS4.



Note: Front formation depends on each type.

---

## Section 3 System Configuration

---


	Page
<b>3-1 Mounting Restrictions .....</b>	<b>3-1</b>
3-1-1 Mounting position .....	3-1
3-1-2 Number of mountable modules .....	3-1
<b>3-2 System Configurations .....</b>	<b>3-2</b>
3-2-1 1:1 Connection using RS-232C port .....	3-2
3-2-2 1:N Connection using RS-485 port (N = max. 31 modules) .....	3-3
3-2-3 Connecting independently to RS-232C and RS-485 ports .....	3-4
3-2-4 Connection using RS-232C and RS-485 ports (2) .....	3-5
3-2-5 Connecting a personal computer loader to the RS-232C port and RS-485 port .....	3-7
3-2-6 Loader network configuration using RS-485 .....	3-7
3-2-7 Loader network configuration using modems (1) .....	3-8
<b>3-3 Loader Connecting Cable .....</b>	<b>3-9</b>
3-3-1 When connecting to RS-232C port .....	3-9
3-3-2 When connecting to RS-485 port .....	3-9
<b>3-4 Self-diagnosis .....</b>	<b>3-10</b>
3-4-1 Self-diagnosis mode 1 .....	3-10
3-4-2 Self-diagnosis mode 2 .....	3-11
(1) RS to CS signal check .....	3-11
(2) ER to DR signal check .....	3-11
(3) RS-232C/RS-485 data check .....	3-11
(4) Preservation of the result of the check .....	3-11

### 3-1-1 Mounting position


NP1L-RS1/2/4 is a general purpose communication module which is connected to the SX bus of MICREX-SX series. The mounting position on the base board is restricted as follows:

They can be mounted in any slot except those for the power supply module (the two slots from the left on the base board).


#### <Base board other than 6-slots base board>



#### <6-slots base board>



Note: The general purpose communication modules cannot be mounted on T-link or OPCN-1 slave station base boards.




### 3-1-2 Number of mountable modules

A maximum of 16 modules per configuration can be connected. However, when other communication related modules are used in the same configuration, the maximum number of 16 is the total of these and NP1L-RS1/2/4 modules.


- P-link module (NP1L-PL1)
  - PE-link module (NP1L-PE1)
  - FL-net (OPCN-2) module (NP1L-FL1)
  - General purpose communication module (NP1L-RS1/2/4)
  - PC card interface module (NP1F-PC2)
  - Memory card interface module (NP1F-MM1)
- Maximum of 16 modules per configuration.

## 3-2-1 1:1 Connection using RS-232C port

This configuration connects to an external device having an RS-232C interface via the RS-232C port. The mode selection switch is set to "0" (zero).




\* With RS1, a D300win personal computer loader can be connected to an RS-485 port which is not used. In this case, the mode selection switch needs to be set to "2."




**3-2-2 1:N Connection using RS-485 port (N = max. 31 modules)**

This configuration connects to external devices having an RS-485 interface via the RS-485 port. The mode selection switch is set to "0." A maximum of 31 external devices can be connected. However, when all external devices are RS1 or RS4, the maximum number is limited to 15 because only 0 to F are available for addressing.



Note: External devices A , B and C must be the same in type as well as communication protocol. For example, this connection is not available when A and B are temperature controllers and C is a bar code reader.


\* With NP1L-RS1, a D300win personal computer loader can be connected to an RS-232C port which is not in use. In this case, the mode selection switch needs to be set to "1."



For the connection, refer to "3-3-1 When connecting to RS-232C port."


## 3-2-3 Connecting independently to RS-232C and RS-485 ports

This configuration connects to external devices using the RS-232C port and RS-485 port. In this case, communication through these ports is performed independently.



**3-2-4 Connection using RS-232C and RS-485 ports (2)**

This configuration connects to external devices using the RS-232C port and RS-485 port.




With this configuration, the following communications can be performed :


- 1) Communication between external device A and external device B, C or D (not via the CPU module)
- 2) Communication between external device A and CPU module
- 3) Communication between external device B, C or C and CPU module

**<1) Communication between external device A and external device B, C or D>**


This communication is performed directly, namely not via the CPU module.



## <2) Communication between external device A and the CPU module>




## <3) Communication between external device B, C or D and the CPU module>




**3-2-5 Connecting a personal computer loader to the RS-232C port and RS-485 port**

This configuration connects a D300win personal computer loader to each of RS-232C and RS-485 ports.




**3-2-6 Loader network configuration using RS-485**

This configuration connects a D300win personal computer loader to the RS-232C port of RS1 on System 1. A D300win can communicate with both CPUs of System 1 and System 2.



## 3-2-7 Loader network configuration using modems (1)


This configuration enables remote programming using the public circuit by connecting a modem to the RS-232C port.



To connect a D300win personal computer loader to the RS-232C or RS-485 port of the general purpose communication module, the cable must be connected in the following manner.


**3-3-1 When connecting to RS-232C port**

Because the RS-232C connector of the general purpose communication module is “female,” attach the male connector onto the cable connector for the general purpose communication module, as shown in the figure below:



**3-3-2 When connecting to RS-485 port**


Because the RS-485 connector of the general purpose communication module is “male,” attach the female connector onto the cable connector for the general purpose communication module, as shown in the figure below:



**3-4-1 Self-diagnosis mode 1**

Setting the mode selection switch of the module to “7” activates Self-diagnosis Mode “1.” This mode is used to check the internal memory and the lighting condition of LEDs.

**<Diagnosis flow>**




**1) Internal memory check**

After the completion of LED lighting check, automatically returns to the diagnosis of the internal memory of general purpose communication module. If an internal memory error is detected, “TS1” blinks.

**2) LED lighting check**

Of the external LEDs of the module, the lighting condition of those operated by the general purpose communication module are checked. When the mode selection switch is set to “7,” “TS1,” “TS2,” “RS-485 ALM” and “RS-232C ALM” LEDs light up in this order.

**<Normal lighting condition of LEDs>**



**3-4-2 Self-diagnosis mode 2**

This mode is used to check the completeness of communications by looping back sent data and control signals via the communication port.

**(1) RS to CS signal check**

In this check, the general purpose communication module turns RS signal ON to check whether CS signal is looped back and turns ON, and then checks that this signal turns OFF.

When normal, "TS2" lights up; proceeds to step (2).

If abnormal, "TS2" blinks (at 0.5-second intervals) after 5 seconds; proceeds to step (2).

**(2) ER to DR signal check**

In this check, the general purpose communication module turns ER signal ON to check whether DR signal is looped back and turns ON, and then checks that this signal turns OFF.

When normal, "TS1" lights up; proceeds to step (3).

If abnormal, "TS1" blinks (at 0.5-second intervals) after 5 seconds; proceeds to step (3).

**(3) RS-232C/RS-485 data check**

The general purpose communication modules sends 16 bytes of data once and checks the looped back data received.

If both ports are normal, "RS-232C ALM" and "RS-485 ALM" light up; proceeds to step (4).

If RS-485 is abnormal, "RS-232C ALM" lights up after 10 seconds and "RS-485 ALM" blinks (at 0.5-second intervals); proceeds to step (4).

If RS-232C is abnormal, "RS-232C ALM" blinks (at 0.5-second intervals) after 10 seconds and "RS-485 ALM" lights up (at 0.5-second intervals); proceeds to step (4).

If both ports are abnormal, "RS-232C ALM" and "RS-485 ALM" blinks (at 0.5-second intervals); proceeds to step (4).

**(4) Preservation of the result of the check**

After 10 seconds of displaying the results from (3) above, the module returns to step (1). Here, if the setting of the mode selection switch has been changed, Self-diagnosis Mode 2 is ended to enter the designated mode.


Note 1: When an RS-232C dedicated module (NP1L-RS2) is used, "RS-485 ALM" is kept turned off. When an RS-485 dedicated module (NP1L-RS4) is used, "RS-232C ALM," "TS1" and "TS2" are kept turned off.

Note 2: When judged as "normal," the next operation is started without any waiting time. Therefore, after all LEDs have turned off at the start of diagnosis, the corresponding LED lights up instantaneously.

<RS-232C loop-back connector>



<RS-485 loop-back connector>



---

## Section 4 Software Interface

---

	Page
<b>4-1 General</b> .....	<b>4-1</b>
<b>4-2 Specifications for Non-procedural FB</b> .....	<b>4-3</b>
4-2-1 Communication specification .....	4-3
4-2-2 FB format .....	4-4
4-2-3 FB terminals .....	4-5
<b>4-3 Initialization</b> .....	<b>4-7</b>
4-3-1 Initialization parameters .....	4-7
4-3-2 Initialization procedure .....	4-10
4-3-3 OPEN status list .....	4-10
<b>4-4 Data Sending</b> .....	<b>4-11</b>
4-4-1 Data sending procedure .....	4-11
4-4-2 Send status list .....	4-12
<b>4-5 Data Receiving</b> .....	<b>4-13</b>
4-5-1 Data receiving procedure .....	4-13
4-5-2 Receiving status list .....	4-14
<b>4-6 RAS Information</b> .....	<b>4-15</b>

# Section 4 Software Interface

## 4-1 General

The non-procedural FB supplied with the D300wind is used for communication between the NP1L-RS1/2/4 and external devices. The non-procedural FB performs data communication between the CPU module and external devices based on the start-stop synchronous transmission protocol.

The following seven types of non-procedural FBs are offered.

FB Name	Specification Overview
_C_free	Non-procedural FB Send: 512 words, Receive: 512 words
_Cfr252	Non-procedural FB Send: 252 words, Receive: 252 words
_Cfr128	Non-procedural FB Send: 128 words, Receive: 128 words
_Cfr64	Non-procedural FB Send: 64 words, Receive: 64 words
_Cfr32	Non-procedural FB Send: 32 words, Receive: 32 words
_Cfrpr	Non-procedural FB Send: 512 words, Receive: 512 words A part of communication processing is processed by the firmware in the module.
_Cfrp2	Non-procedural FB Send: 512 words, Receive: 512 words A part of communication processing is processed by the firmware in the module and two message boards are used to increase the processing speed.

Note 1: \_Cfrpr FB can be used with V.2535 or later versions of the NP1L-RS1, JP1L-RS2, and NP1L-RS4. The functions of the non-procedural FB are shown below.

Note 2: \_Cfrp2 FB can be used with V.2536 or later versions of the NP1L-RS1, JP1L-RS2, and NP1L-RS4. For the specifications of \_Cfrp2, refer to "EXTENDED FB FOR COMMUNICATION USER'S MANUAL FH255."

### 1) Initialization of communication ports

Initializes RS-232C and RS-485 ports (sets transmission speed, data bit length, parity bits, etc., so as to match the external device.)


### 2) Data sending/receiving function

Sends the data from an application program in the CPU of MICREX-SX series via RS1 to an external device, or outputs the data received via the general purpose communication module to an application program.

### 3) Monitoring of transmission condition

Monitors the condition of data transmission and, if abnormal, outputs error information.

### <Function diagram of Non-procedural FB>




# 4-1 General

## <FB operating conditions>

### System configuration:

One FB is necessary for each external device which is connected by RS-232C or RS-485 to one general purpose communication module. However, when RS-232C/RS-485 signal conversion is enabled (the mode selection switch is set to 4) for the general purpose communication module, each FB is used by two channels.



\* When used in RS-232C/RS-485 conversion mode, channel number for the parameter (PARA [1]) is 1 (= RS-485).

### Memory capacity:

FB Name	Program capacity (Step)	Instance memory for user FB	Standard memory	Retain memory	Instance memory for system
_C_free	2656	402 words	3656 words	0 words	82 words
_Cfr252	2757	474 words	2174 words	0 words	82 words
_Cfr128	2757	474 words	1886 words	0 words	82 words
_Cfr64	2757	474 words	1758 words	0 words	82 words
_Cfr32	2757	474 words	1672 words	0 words	82 words
_Cfrpr	1190	122 words	1608 words	0 words	82 words

Note 1: The above memory capacity includes that of non-procedural FB itself as well as of the sub-FB which is called from non-procedural FB.

Note 2: "Standard memory" or "Retain memory" includes the memory capacity necessary for data transmissin.

## 4-2 Specifications for Non-procedural FB

### 4-2-1 Communication specification


Item		Specification
Transmission speed		1200/2400/4800/9600/19200/38400/57600 bps (Note)
Data bits		Selected from 7/8 bits
Parity bit		None/odd/even
Stop bits		Selected from 1/2 bits
DCE		Selected from DTE/DCE/modem DTE mode Modem DTE mode: Turn CD ON when receiving
Signal control	DTE mode	ER: always ON
	DCE mode	DR: always ON
Signal flow control	DTE mode	Off RS: always ON; Sending: unconditional On RS: ON during sending; Sending: when CS is ON
	DCE mode	Off CS: always ON; Sending: unconditional On CS: ON when RS is ON; Sending: when ER is ON
XON/XOFF control		Selectable
RS-485 mode		Selected from 4-wire/2-wire
Code conversion		Selected from None/ASCII conversion/ EBCDIC conversion (Convert binary data into character string variable.)
Frame detection	None	Disable frame detection function.
	Fixed length	Designate the number of receive data bytes
	Variable length	Designate start and end codes.
Horizontal parity (BCC)	None	None
	Upper order/Lower order	Calculation range designation. Designate position. Formula: Selected from add/add and invert/EOR/CRC
	Lower order/Upper order	BCC code: Selected from character code/binary code
Transmission timer value		x10ms

Note: Transmission rates 300, 600, 76800, and 115200 bps can be used in the following combinations:

Version of general purpose communication module	Standard extended FB
V.2535 or later	_Cfrpr (Non-procedural FB with built-in protocol)
V.2536 or later	_Cfrp2 (Non-procedural FB with built-in protocol, 2-message version)

## 4-2 Specifications for Non-procedural FB

### 4-2-2 FB format



Note 1: All non-procedural FBs have the same pin assignment.

Note 2: Only the FB pins necessary for control are used by connecting variables to them. However, be sure to connect variables to the IN-OUT pins.

## 4-2 Specifications for Non-procedural FB

### 4-2-3 FB terminals

#### <Terminal list>

Terminal name	Terminal name	Data type	I/O	Description
Open	OPEN	BOOL	IN	ON: Sends the "communication parameters" to the general purpose communication module to initialize communication. When communication becomes possible, "communication ready" turns ON. OFF: Performs the processing for ending communication. "Communication ready" turns OFF.
Send request	S_REQ	BOOL	IN	Starts to send data. When sending has ended, this needs to be turned OFF by the application program.
Send data length	S_LEN	INT	IN	Designates the length of send data by the number of bytes.
Send data	S_DAT	Array of WORD (Note)	IN_OUT	Stores send data.
Communication parameter	PARA	Array of INT (Note)	IN	Stores the initialization parameters.
Communication ready	OK	BOOL	OUT	Turns ON when initialization has ended normally to indicate that the system is ready for sending/receiving data.
Open status	O_STS	WORD	OUT	2-digit hexadecimal code to indicate the result of initialization.
Send end	S_END	BOOL	OUT	Turns ON when sending has completed.
Send error	S_ERR	BOOL	OUT	Turn ON if a send error has occurred.
Send status	S_STS	WORD	OUT	Code to indicate the result of sending
Receive end	R_END	BOOL	OUT	Turns ON when receiving has completed.
Receive error	R_ERR	BOOL	OUT	Turns ON if a receive error has occurred.
Receive status	R_STS	WORD	OUT	Code to indicate the result of receiving
Receive data length	R_LEN	INT	OUT	Outputs the received data length.
Receive data	R_DAT	Array of WORD (Note)	IN_OUT	Stores received data.
RS-485 station No.	STN_NO	INT	OUT	The condition of the RS-485 station number setup switch of the general purpose communication module is output to this pin.
RAS information	RAS	Structure (Note)	IN_OUT	Operating information of this FB. For details, refer to 4-6, "RAS Information."

Note: The data format differs for each non-procedural FB.

#### <Send data S\_DAT(WORD array)>

##### <Variable declaration example>

```
VAR
  S_DAT:_C_SND_TYP11;
END_VAR
```

##### <Data type list>

FB Name	Data type of S_DAT
_C_free	_C_SND_TYP11
_Cfr252	_C_SND_TYP16
_Cfr128	_C_SND_TYP14
_Cfr64	_C_SND_TYP13
_Cfr32	_C_SND_TYP15
_Cfrpr	_C_SND_TYP11PR

	Upper order	Lower order	
S_DAT [0]	Data 2	Data 1	
S_DAT [1]	Data 4	Data 3	
⋮	⋮	⋮	
S_DAT [31]	Data 64	Data63	← Up to here is assigned to <u>_Cfr32</u> .
⋮	⋮	⋮	
S_DAT [63]	Data 128	Data127	← Up to here is assigned to <u>_Cfr64</u> .
⋮	⋮	⋮	
S_DAT [127]	Data 256	Data255	← Up to here is assigned to <u>_Cfr128</u> .
⋮	⋮	⋮	
S_DAT [251]	Data 504	Data503	← Up to here is assigned to <u>_Cfr252</u> .
⋮	⋮	⋮	
S_DAT [511]	Data 1024	Data1023	← Up to here is assigned to <u>_C_free, _Cfrpr</u> .

## 4-2 Specifications for Non-procedural FB

### <Receive data R\_DAT(WORD array)>

#### <Variable declaration example(\_C\_free)>

```
VAR
  R_DAT:_C_RCV_TYP11;
END_VAR
```

```
R_DAT [0]
R_DAT [1]
  ⋮
R_DAT [31]
  ⋮
R_DAT [63]
  ⋮
R_DAT [127]
  ⋮
R_DAT [251]
  ⋮
R_DAT [511]
```

Upper order	Lower order
Data 2	Data 1
Data 4	Data 3
⋮	⋮
Data 64	Data63
⋮	⋮
Data 128	Data127
⋮	⋮
Data 256	Data255
⋮	⋮
Data 504	Data503
⋮	⋮
Data 1024	Data1023

← Up to here is assigned to \_Cfr32.

← Up to here is assigned to \_Cfr64.

← Up to here is assigned to \_Cfr128.

← Up to here is assigned to \_Cfr252.

← Up to here is assigned to \_C\_free,\_Cfrpr.

#### <Data type list>

FB Name	Data type of R_DAT
_C_free	_C_RCV_TYP11
_Cfr252	_C_RCV_TYP16
_Cfr128	_C_RCV_TYP14
_Cfr64	_C_RCV_TYP13
_Cfr32	_C_RCV_TYP15
_Cfrpr	_C_RCV_TYP11PR

### <Communication parameter PARA(INT array)>

#### <Variable declaration example(\_C\_free)>

```
VAR
  PARA:_C_PAR_TYP11;
END_VAR
```

#### <Data type list>

FB Name	Data type of PARA
_C_free	_C_PAR_TYP11
_Cfr252	_C_PAR_TYP16
_Cfr128	_C_PAR_TYP14
_Cfr64	_C_PAR_TYP13
_Cfr32	_C_PAR_TYP15
_Cfrpr	_C_PAR_TYP11PR

PARA[16]	Code conversion
PARA[17]	Frame detection
PARA[18]	Number of receive data bytes
PARA[19]	Number of start code bytes
PARA[20]	Start code 1
PARA[21]	Start code 2
PARA[22]	Start code 3
PARA[23]	Start code 4
PARA[24]	Start code 5
PARA[25]	Number of end code bytes
PARA[26]	End code 1
PARA[27]	End code 2
PARA[28]	End code 3
PARA[29]	End code 4
PARA[30]	End code 5
PARA[31]	BCC designation
PARA[32]	Calculation range, position
PARA[33]	Formula
PARA[34]	Code type
PARA[35]	Send timer value
PARA[36]	Reserved
PARA[37]	Reserved
PARA[38]	Reserved
PARA[39]	Reserved

\* After FBopens, the parameter from "PARA [16]" to "PARA [35]" is effective.

#### Variable name

PARA[ 0]	General purpose communication module station No.
PARA[ 1]	Port No.
PARA[ 2]	Message port No.
PARA[ 3]	Reserved
PARA[ 4]	Transmission speed
PARA[ 5]	Data bit
PARA[ 6]	Parity bit
PARA[ 7]	Stop bit
PARA[ 8]	DCE designation
PARA[ 9]	DTR/DSR signal control
PARA[10]	RTS/CTS signal flow control
PARA[11]	XON/XOFF control
PARA[12]	RS-485 mode
PARA[13]	Reserved
PARA[14]	Reserved
PARA[15]	Reserved

## 4-3-1 Initialization parameters

In order to initialize each individual port of the general purpose communication module, it is necessary to set values which match the communication specifications of the object external device to the individual communication parameters. The table below shows the setting contents of these parameters.

No.	Item	Description
0	General purpose communication module station No.	Sets the station number of the general purpose communication module on the SX bus.
1	Port No.	Designates an interface port on general purpose communication module. 0: RS-232C port 1: RS-485 port
2	Message port No.	Designates a port No. for sending/receiving messages to/from a general purpose communication module (1 to 127). Note: Avoid designating a port No. which is already used for sending/receiving messages to/from other module.
3	Reserved	Not used.
4	Transmission speed	Designates the transmission speed. 0: 1200 1: 2400 2: 4800 3: 9600 4: 19200 5: 38400 6: 57600 bps
5	Data bit	Designates the data bit length. When "7" is selected, 7 bits make up one data; when "8," 8 bits make up one data. 0: 7 bits 1: 8 bits
6	Parity bit	This is a bit which is added to data for the purpose of error detection. Designate the proper one to match the setting of the device at the other end. 0: None 1: Odd 2: Even
7	Stop bit	This bit indicates the end of data. Designate the proper one to match the setting of the device at the other end. 0: 1 bit 2: 2 bits
8	DCE designation	When signal line control is not performed, there is no difference in functions between DCE and DTE modes. The RS-232C of the general purpose communication module is of DTE specification, however, it can be used as a DCE specification interface when signal lines are converted as follows: No. 7 pin (RS) to CS No. 8 pin (CS) to RS No. 6 pin (DR) to ER No. 4 pin (ER) to DR 0: DTE 1: DCE 2: Modem DTE
9	ER/DR signal control	0: None
10	Signal flow control	DTE mode 0: Off RS: always ON; Sending: unconditional 1: On RS: ON while sending; Sending: when CS is ON
		DCE mode 0: Off CS: always ON; Sending: unconditional 1: On CS: ON when RTS is ON; Sending: when ER is ON
11	XON/XOFF control	Because communication between sender and receiver is performed asynchronously, flow control may be necessary. The receiver sends an XOFF signal to indicate that it cannot receive data for a while and then sends an XON signal to cancel the XOFF condition. To use XON/OFF control, the device at the other end must also have this function. 0: NO 1: YES
12	RS-485 mode	Selects 4-wire or 2-wire for RS-485. 0: 4-wire 1: 2-wire
13	Reserved	Not used
14	Reserved	
15	Reserved	
16	Code conversion	Converts binary data into a character string variable. 0: None 1: ASCII conversion 2: EBCDIC conversion
17	Frame detection	Designates data receiving method. 0: None Receiving completes when data is received. 1: Variable length Receiving completes when the data in a range between start and end codes is received. 2: Fixed length Receiving completes when receive data reaches the specified number of receive data bytes.

## 4-3 Initialization

No.	Item	Description
18	Number of receive data bytes	Designates the number of receive data bytes when "Fixed length" is selected for frame detection. When "Variable length" is selected, set this item to "0."
19	Number of start code bytes	Designates the number of start code bytes when "Variable length" is selected. "0" means no start code.
20	Start code 1	Designates start code when "Variable length" is selected.
21	Start code 2	
22	Start code 3	
23	Start code 4	
24	Start code 5	
25	Number of end code bytes	Designates the number of end code bytes when "Variable length" is selected.
26	End code 1	Designates end code when "Variable length" is selected.
27	End code 2	
28	End code 3	
29	End code 4	
30	End code 5	
31	BCC designation	<p>Sets whether or not to add horizontal parity for checking text data transmission error.</p> <p>0: None</p> <p>1: Set in the order of upper- and lower-order byte</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin: 5px;">Upper byte of BCC   Lower byte of BCC</div> <p>2: Set in the order of lower and upper byte</p> <div style="border: 1px solid black; padding: 2px; display: inline-block; margin: 5px;">Lower byte of BCC   Upper byte of BCC</div>
32	Calculation range, position	<p>Sets the calculation range and BCC position. <span style="float: right;">↔ : Calculation range</span></p> <p>0: Calculates the text part and enters it ahead of the end code.</p> <div style="border: 1px dashed black; padding: 2px; display: inline-block; margin: 5px;">Start code</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">TEXT</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">BCC</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">End code</div> (Note) <p>1: Calculates text part and end code and inserts them behind the end code.</p> <div style="border: 1px dashed black; padding: 2px; display: inline-block; margin: 5px;">Start code</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">TEXT</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">End code</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">BCC</div> <p>2: Calculates start code and text part and inserts them ahead of the end code.</p> <div style="border: 1px solid black; padding: 2px; margin: 5px;">Start code</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">TEXT</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">BCC</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">End code</div> (Note) <p>3: Calculates start code, text part and end code and inserts them behind the end code.</p> <div style="border: 1px solid black; padding: 2px; margin: 5px;">Start code</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">TEXT</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">End code</div> <div style="border: 1px solid black; padding: 2px; margin: 5px;">BCC</div> <p>Note: In this case, the BCC code type cannot be designated as "binary." Specify other than CRC-16 for the BCC expression.</p>

No.	Item	Description
33	BCC calculation formula	Calculation method to check for transmission error. <div style="text-align: center;">  </div> 0: Add $D1 + D2 + \dots + Dn$ 1: Add and invert Inversion of $(D1 + D2 + \dots + Dn)$ 2: EOR $D1 \text{ EOR } D2 \text{ EOR } \dots \text{ EOR } Dn$ 3: CRC * When CRC is selected, specify "BCC Code Format" to "0: Binary." $\text{CRC-16: } X^{16} + X^{15} + X^2 + 1$
34	BCC code type	Designates the code type of BCC data. 0: Binary 1: ASCII 2: EBCDIC
35	Send timer value	The timer value for monitoring transmission since the data send request has been sent from the CPU module onto the RS-232C line until sending is completed. Normally set to 100 (1 second) (in 0.01-second steps).
36 ⋮ 39	Reserved ⋮ Reserved	Not used.

Note 1: Parameter Nos. 16 to 35 are valid even if changed after opening.

After opening, if parameter Nos.16 to 35 are changed and a setup error occurs, or if other parameters are changed, an open error results and communication "OK" is turned OFF.

Note 2: If you use "EBCDIC" at parameter No. 16 and/ or 34, make sure to select "8 bit" at parameter No. 5.

Note 3: This module ignore data when error detected while receiving data.


We recommend to use No. 6 (Parity), No. 31 (BCC) to detect data error if you use this module on noise environment.

In this case, external device also support parity, BCC.

## 4-3 Initialization

### 4-3-2 Initialization procedure


When the OPEN terminal of FB is turned ON, communication parameters are transferred to the general purpose communication module, which executes processing for initialization. If initialization is impossible due to a communication parameter setting error or hardware error, FB outputs the corresponding error code (word type) to the OPEN Status (O\_STS).



### 4-3-3 OPEN status list

No.	Result of initialization	Remarks
'00'	Ended normally	
'01'	Transmission speed error	Error detection on general purpose communication module
'02'	Data bit length error	Error detection on general purpose communication module
'03'	Parity bit error	Error detection on general purpose communication module
'04'	Stop bit error	Error detection on general purpose communication module
'05'	DCE designation error	Error detection on general purpose communication module
'06'	Signal flow control setting error	Error detection on general purpose communication module
'07'	XON/XOFF control setting error	Error detection on general purpose communication module
'08'	RS-485 mode setting error	Error detection on general purpose communication module
'3F'	Parameter modification error	Parameter modification error after OPEN
'40'	Code conversion setting error	
'41'	Frame detecting method setting error	
'42'	Start code setting error	
'43'	End code setting error	
'44'	BCC code setting error	
'45'	BCC calculation range setting error	
'46'	BCC calculation formula setting error	
'47'	BCC code type setting error	
'48'	Transmission timer specify setting error	Do not specify a minus value for the send timer
'80'	General purpose communication module station No. setting error	
'81'	Channel No. setting error	
'82'	Message port No. setting error	
'93'	Open error	SX bus is abnormal.
'94'	Open error	Failed the general purpose communication module initialization
'A3'	Processing impossible because in code conversion mode.	Error detection on general purpose communication module
'A5'	Processing impossible because in loader mode.	Error detection on general purpose communication module
'A6'	Processing impossible because self-diagnosis is being executed.	Error detection on general purpose communication module

## 4-4-1 Data sending procedure




After setting send data and its data length, turn S\_REQ (send request) ON by the application program. Then FB detects the rising edge to execute the processing for sending. When sending has ended, S\_END (send end) flag is turned ON (for only one pulse). If a send error has occurred, S\_END (send end) and S\_ERR (send error) are turned ON (for only one pulse), and the corresponding error code is output to S\_STS (send status) ("00" when ended normally).

## 4-4 Data Sending

### 4-4-2 Send status list

No.	Result of sending	Remarks
'00'	Normally ended	
'01'	Send buffer has overflowed.	
'02'	Reserved	
'03'	Reserved	
'04'	Reserved	
'05'	Reserved	
'06'	Reserved	
'40'	Data send time-out	
'41'	Protocol response error	
'42'	Reserved	
'90'	General purpose communication module disconnected.	Not detected
'91'	SX bus send error	
'92'	SX bus receive error	Not detected
'A0'	Object port error	Specified port No. is neither 0 nor 1.
'A3'	Processing impossible because in code conversion mode.	
'A5'	Processing impossible because in loader mode.	
'A6'	Processing impossible because self-diagnosis is being executed.	Error detection on general purpose communication module
'C0'	Hardware error detected during receiving	Error detection on general purpose communication module
'C1'	Receive buffer has overflowed.	Error detection on general purpose communication module
'C2'	Send buffer has overflowed.	Error detection on general purpose communication module
'C3'	Send data size over	Error detection on general purpose communication module

## 4-5-1 Data receiving procedure



While the communication ready flag is turned ON, whether the data to be received exists or not is checked continuously and, when it exists, the operation for receiving is executed. When a delimiter between data frames is detected, the received data and the number of receive data bytes are stored in R\_DAT (receive data) and R\_LEN (receive data length), respectively, and the R\_END (receive end) flag is turned ON (for only one pulse). The result of receiving is stored in R\_STS (receive status). If a receive error has occurred, R\_END (receive end) and E\_ERR (receive error) are turned ON (for only one pulse).

## 4-5 Data Receiving

### 4-5-2 Receiving status list

No.	Result of receiving	Remarks
'00'	Ended normally	
'01'	Reserved	
'02'	Receive buffer has overflowed.	
'03'	Reserved	
'04'	Reserved	
'05'	Reserved	
'06'	Reserved	
'40'	Reserved	
'41'	Reserved	
'42'	BCC error	
'90'	General purpose communication module disconnected.	
'91'	SX bus send error	
'92'	SX bus receive error	
'A0'	Object port error	Error detection on general purpose communication module
'A3'	Processing impossible because in code conversion mode.	Error detection on general purpose communication module
'A5'	Processing impossible because in loader mode.	Error detection on general purpose communication module
'A6'	Processing impossible because self-diagnosis is being executed.	Error detection on general purpose communication module
'C0'	Hardware error detected during receiving (Parity error, Framing error, etc.)	Error detection on general purpose communication module
'C1'	Receive buffer has overflowed.	Error detection on general purpose communication module
'C2'	Send buffer has overflowed.	Error detection on general purpose communication module
'C3'	Send data size over	Error detection on general purpose communication module

**Note:** Receiving conditions

The processing for receiving differs with the setting of parameter "Frame detection."

None: Receiving completes when data is received.

Fixed length: Receiving completes when receive data reaches the specified number of receive data bytes.

Variable length: Receiving completes when the data in a range between start and end codes is received.

Operating status of FB is stored in the RAS information area.

### <Variable declaration example of RAS (\_C\_free)>

```
VAR
  RAS:  _C_work_TYPE11;
END_VAR
```

### < Data type list >

FB Name	Data type of RAS
_C_free	_C_work_TYPE11
_Cfr252	_C_work_TYPE16
_Cfr128	_C_work_TYPE14
_Cfr64	_C_work_TYPE13
_Cfr32	_C_work_TYPE15
_Cfrpr	_C_work_TYPE11PR

### <RAS information area (INT array)>

RAS.RAS[ 0]	Port status	→ Refer to next page.
RAS.RAS[ 1]	Status of general purpose communication module	→ Refer to next page.
RAS.RAS[ 2]	Send request count	
RAS.RAS[ 3]	Send end count	
RAS.RAS[ 4]	Receive count	
RAS.RAS[ 5]	Frame detection count	
RAS.RAS[ 6]	M_OPEN status	
RAS.RAS[ 7]	M_SEND status	
RAS.RAS[ 8]	M_RECEIVE status	
RAS.RAS[ 9]	M_SEND error count	
RAS.RAS[10]	M_RECEIVE error count	
RAS.RAS[11]	Reserved	
RAS.RAS[12]	Reserved	
RAS.RAS[13]	Reserved	
RAS.RAS[14]	Reserved	
RAS.RAS[15]	Reserved	
RAS.RAS[16]	Reserved	
RAS.RAS[17]	Reserved	
RAS.RAS[18]	Reserved	
RAS.RAS[19]	Reserved	



---

## Section 5 Programming

---

	Page
<b>5-1 Communication Program Creating Procedure .....</b>	<b>5-1</b>
<b>5-2 Installation Procedure of Standard Extended FB .....</b>	<b>5-2</b>
<b>5-3 Registration in Library .....</b>	<b>5-5</b>
<b>5-4 Pasting Non-procedural FB .....</b>	<b>5-6</b>
<b>5-5 Communication Parameters Setting .....</b>	<b>5-7</b>
<b>5-6 Writing the Send Data .....</b>	<b>5-8</b>
<b>5-7 Connecting Variables and Commands to FB Terminals .....</b>	<b>5-9</b>
5-7-1 Connecting variable to "PARA" terminal .....	5-9
5-7-2 Operation for starting FB .....	5-9
5-7-3 Operation for sending data .....	5-10
5-7-4 Data receiving operation .....	5-10

# Section 5 Programming

## 5-1 Communication Program Creating Procedure

Taking non-procedural FB (\_C\_free) for example, the procedure for creating a communication program is explained below:

- 1) Install the standard expansion FB.  
Refer to "5-2 Installation Procedure of Standard Extended FB."
- 2) Register the library in the project tree.  
Refer to "5-3 Registration in Library."
- 3) Paste non-procedural FB (\_C\_free) onto the program work sheet.  
Refer to "5-4 Pasting Non-procedural FB."
- 4) Assign values (baud rate, start/end cord, etc.) to the communication parameters.  
Refer to "5-5 Setting Communication Parameters."
- 5) Write send data.  
Refer to "5-6 Writing Send Data."
- 6) Connect variables or commands to each terminal of the expansion FB.  
Refer to "5-7 Connecting Variables and Commands to FB Terminals."

The standard extended FB is included in the Programming Support Tool D300win System Software Package (CD-ROM).

< Operating Procedure >


(1) Activate Windows and then insert the product CD-ROM into the CD-ROM drive. The following dialog appears.



Note: If the installation dialog box does not appear, perform the following operations.


Click [Start] and then [Run], enter: \autorun.exe, then click the [OK] button.

(2) When you click [Standard Expansion FB Setup], the following [Welcome] dialog box appears.




Click here first.


(3) When you click the [Next>] button in the [Welcome] dialog box, the [Choose Destination Location] dialog box appears.




To change the target folder, click the [Browse...] button. The following [Choose Directory] dialog box appears. Specify a folder and then click the [OK] button. Control returns to the [Choose Destination Location] dialog box.



(4) When you click the [Next>] button in the [Choose Destination Location] dialog box, the installation processing is started.



(5) When installation is completed, the following [Setup Complete] dialog box appears. Click the [OK] button to complete the installation procedure.



When you check here and then click the [OK] button, the product information of the standard extended FB appears.

<Example of release note>

```

README - Notepad
File Edit Search Help

                STANDARD EXPANSION FB RELEASE NOTE  U2.0.1.0E

Thank you for using this FB. This is an update description.


U2.0.1.0E
_Cfrp2 library      :U2.0.0.1 added
_Cfvrpr library     :U2.0.0.2 added
-----
U2.0.0.2E
_C_COM library      :U2.0.0.1 comment change
_C_free library     :U2.0.0.1 bug fixed for bit length7 BCC,comment change
_Cfr32 library      :U2.0.0.1 bug fixed for bit length7 BCC,comment change
_Cfr64 library      :U2.0.0.1 bug fixed for bit length7 BCC,comment change
_Cfr128 library     :U2.0.0.1 bug fixed for bit length7 BCC,comment change
_Cfr252 library     :U2.0.0.1 bug fixed for bit length7 BCC,comment change
_C_frpr library     :U2.0.0.2 new FB
_CfdFRN library     :U2.0.0.1 comment change
_CfdFUR library     :U2.0.0.1 comment change
_CfdPK library      :U2.0.0.1 comment change
_CfdPYX library     :U2.0.0.1 bug fixed for MAX. word length
_MHCNT library      :U2.0.0.0 no change
_MSPOS library      :U2.0.0.0 no change
-----

U2.0.0.1E
This is the original.


```

Individual communication FBs included in the standard expansion FB package can be used when registered in a library under a created project.

- (1) Left-click the [Libraries], a subtree in the “Project” tree, and then on the [Insert...] button. Then the [Include library] dialog box will appear on the screen.




- (2) Select an FB (file name) which you want to register in the library, and left-click the [Insert] button.
- (3) The FB is registered in the library, as shown in the figure below.



Note: The common FB “\_C\_COM” is required when using any communication FB. “\_C\_COM” is used inside each extended communication FB. It is not necessary to call it on the code worksheet and use it.

- (4) FBs in the project registered in the library can be selected from the [Function/Function Block] dialog box. In this case, child FBs (FBs which start with “C” like \_CBCC11, etc.) used inside \_C\_free or other extended communication FBs are also displayed. However, use only parent FBs (\_C\_free, etc.) on the code worksheet.




## 5-4 Pasting Non-procedural FB



The following procedure pastes non-procedural FB “\_C\_free” on the LADDER code worksheet.

### <Pasting procedure>

1) Open the code work sheet on which you want to paste “\_C\_free.”



2) Select non-procedural FB “\_C\_free”.




Parameter values are assigned to the variables (INT type array data) which are connected to the communication parameter terminal "PARA" of non-procedural FB. In this paragraph, how to do this using ST language is described.


**<Sample variable declaration>**

Because it is used by the POU on which an expansion FB is pasted, communication parameter variable "PARA" must be global. Therefore, it is necessary to make a variable declaration in 2 locations, as below:

**Local variable declaration**




**Global variable declaration**



**<Sample setting program>**

This sample program assigns necessary communication parameter values to INT type array data "PARA." When no setting changes are required, setting is made during the first scan. It is not necessary for each scan.



Send data is written in the variables (WORD type array data) which are connected to send data terminal "S\_DAT." When the volume of send data is small, the send data writing program is created on the same work sheet as that for expansion FB; when the volume is large, it is better to create the program on separate work sheet or POU. This paragraph describes how to create a send data writing program on a POU other than that including the non-procedural FB.

### <Sample variable declaration>

Because it is used by the POU on which an expansion FB is pasted, the send data variable "SDAT" must be global. Therefore, it is necessary to make variable declaration at 2 locations, as below:

#### Local variable declaration

<pre>VAR_EXTERNAL   SDAT : _C_SND_TYP11;   SSET : BOOL ; END_VAR</pre>	Data type "_C_SND_TYP11" is automatically declared when non-procedural FB is pasted.
	Setting operation flag

#### Global variable declaration


<pre>VAR_GLOBAL   PARA : _C_PAR_TYP11;   PSET : BOOL := TRUE ;   SDAT : _C_SND_TYP11 ;   SSET : BOOL := TRUE ; END_VAR</pre>	Used by the POU for setting parameter values
--	--

### <Sample setting program>

To set a desired value for WORD type array data "SDAT"


<pre>IF SSET THEN   SDAT[0] := WORD#16#0000 ;   SDAT[1] := WORD#16#0001 ;   SDAT[2] := WORD#16#0002 ;   SDAT[3] := WORD#16#0003 ;   SDAT[4] := WORD#16#0004 ;   SDAT[5] := WORD#16#0005 ;   SDAT[6] := WORD#16#0006 ;   SDAT[7] := WORD#16#0007 ;   SDAT[8] := WORD#16#0008 ;   SSET := FALSE ; END_IF</pre>	After all necessary values are set, the processing for the above setting will not be executed from the next scan when the flag is set to "FALSE."
--	---

This paragraph describes how to program for each expansion FB terminal.



### 5-7-1 Connecting variable to "PARAM" terminal


The variable which was assigned data in "5-5 Communication Parameter Setting" is connected to communication parameter terminal "PARAM."



Because data was assigned to array data type variable "PARAM" in "5-5 Communication Parameter Setting", connection is made only by writing variable name "PARAM" at the terminal.

### 5-7-2 Operation for starting FB

After all necessary communication parameters are set, initialization will start when the input terminal "OPEN" is turned ON. When initialization ends, the output terminal "OK" turns ON, and communication becomes possible.




PSET is a flag which is programmed to turn OFF when parameter setting ends. Refer to "<Sample setting program>" in 5-5.

Note: FB starting conditions need to be programmed such that the ON status is kept.

# 5-7 Connecting Variables and Commands to FB Terminals

## 5-7-3 Operation for sending data

Send request is made after send data and its byte length are set.




Note: When data sending is completed, send end flag "S\_END" turns ON only for one scan. In case of sending error, send error flag "S\_ERR" turns ON only for one scan.

As the content of sending error is stored in send status "S\_STS," judge the occurred error according to the S\_STS data stored when S\_ERR has turned ON.

## 5-7-4 Data receiving operation

When communication ready terminal "OK" is turned ON, non-procedural FB continuously checks whether there is any data to be received and, when it exists, executes operations for data receiving. When the delimiter between received data frames is detected, R\_END (receive end) turns ON for one scan, and receive data and receive status are stored in R\_DAT and R\_STS, respectively.

In case of receiving error, R\_ERR (receive error) also turns ON for one scan.



---

## Section 6 Wiring


---

	Page
<b>6-1 Precautions .....</b>	<b>6-1</b>
<b>6-2 Wiring Method .....</b>	<b>6-2</b>
6-2-1 When RS-485 is used (2-wire) .....	6-2
6-2-2 When RS-485 is used (4-wire system) .....	6-2
6-2-3 When RS-232C is used .....	6-3

# Section 6 Wiring

## 6-1 Precautions


- (1) Before removing the connector, remove the fixing screws.
- (2) Communications cables must be isolated from high-voltage cables and power cables as far as possible. Communication cables must not be run parallel with those cables.
- (3) These cables should be installed as shown in the following figure. Shielding cables should be used.



# 6-2 Wiring Method

## 6-2-1 When RS-485 is used (2-wire)


To make a 2-wire system, as shown in the figure below, 4) and 9) as well as 3) and 8) are short-circuited in the connector, and 1) (SDB), 2) (SDA) and 5) (SG) are used to connect to external devices.



\* To set a terminating resistor for a 2-wire system, change the "RS-485 Terminating resistor ON/OFF" switch to "1"(left side when facing the front panel).

## 6-2-2 When RS-485 is used (4-wire system)


To make a 4-wire system, 1), 2), 5), 8) and 9) are used as in the figure below:



\* To set a terminating resistor for 4-wire system, change the "RS-485 Terminating resistor ON/OFF" switch to "3" (left and right side when facing the front panel).


### Note: Precaution when there is no SG terminal on the external device

SG wire cannot be connected if there is no SG terminal on the external device. Depending on the ambient environment, in the worst, module internal element might be damaged. To avoid this, connect a Zener diode (of 6 V Zener voltage, RD6.2F from NEC or equivalent) between signal cable and SG terminal in the connector on this module side.



\* RS1, RS4 V2738 or later version has built-in zener diode.  
RS5 has zener diode.

## 6-2-3 When RS-232C is used



Note 1: Generally, a plastic cover is used for connection as shown in the above figure.

Commercially available plastic cover :1) DE-C4-J6 from JAE

2) HDE-CTF or HDE-CTF1 from Hirose Electric Co., Ltd.

Or their equivalent

Note 2: When the on-site operating environment requires stricter EMC measures, it is more effective to make this cable using commercially available metallic covers.

Metallic cover : 1) DE-CE-J6 from JAE (aluminum die cast)

2) HDB-CTH1 from Hirose Electric (Ni coated plastic)

3) 17JX-09H-1A from DDK, Ltd. (Ni coated plastic)

Or their equivalent

---

## **Section 7 RAS**

---


	Page
<b>7-1 RAS Information of General Purpose Communication Module .....</b>	<b>7-1</b>

# Section 7 RAS

## 7-1 RAS Information of General Purpose Communication Module

The following describes the procedure for monitoring and analyzing the RAS information of the general purpose communication module using the D300win.


### < Example system configuration >




### < Monitoring/analysis procedure >

The following describes the monitoring/analysis procedure using the above system as an example.


(1) Connect the D300win to the MICREX-SX series CPU module to display the following [Control] dialog box.




(2) The following [Failure diagnosis] dialog box appears.




# 7-1 RAS Information of General Purpose Communication Module



(3) The following [Detail RAS] dialog box of the general purpose communication module appears. First, the "Module intensive status information" appears.




(4) When you select [Type information], the module format, software version number, and other information appear in Contents, as shown below.



# 7-1 RAS Information of General Purpose Communication Module

(5) When you select [General purpose communication module RS1 detail RAS], the detailed RAS information appears in Contents, as shown below.



	No.1	No.2						No.7	
0000 :	1000	9000	0000	0000	0000	0000	0000	0000	No.15
0008 :	1000	0000	0000	0000	0000	0000	0000	0000	No.23
0010 :	1000	0000	0000	0000	0000	0000	0000	0000	No.31
0018 :	1000	0000	0000	0000	0000	0000	0000	0000	


\* One word (16 bits) represents each detailed RAS item. The detailed RAS corresponding to each number is shown below.

< Detailed RAS information >


0	Status of general purpose communication module	14,15	Not used	
1	Status of RS-232C port	16	Number of parity error occurrences	RS-485
2	Status of RS-485 port	17	Number of framing error occurrences	
3-5	Not used	18	Number of overrun error occurrences	
6,7	Not used	19	Send buffer overflow	
8	Number of parity error occurrences	20	Receive buffer overflow	SX bus
9	Number of framing error occurrences	21	Loopback buffer overflow	
10	Number of overrun error occurrences	22,23	Not used	
11	Send buffer overflow	24	Number of SX bus send error interrupts	
12	Receive buffer overflow	25	Number of SX bus receive error interrupts	
13	Loopback buffer overflow	26	Number of error message data receptions	
		27	Number of invalid message data receptions	
		28-31	Not used	

# 7-1 RAS Information of General Purpose Communication Module

## • RS-232C/RS-485 Port status



## • General purpose module communication status



- Framing error: It becomes ON when stop bit is not detected while receiving data.
- Overrun error: It becomes ON when data receive process of firmware failed while receiving data.
- Parity error: It becomes ON when parity error detected while receiving data.

Those error bit remains until initialize this module or power off.

---

# Appendix 1 JIS Code

---

	Page
■ JIS 7-bit Codes .....	App.1-1
■ JIS 8-bit Codes .....	App.1-1

The following table shows the character-code in Japan Industrial Standards (JIS).

### ■ JIS 7-bit Codes

	b7 b6 b5	0 0 0	0 0 1	0 1 0	0 1 1	1 0 0	1 0 1	1 1 0	1 1 1
b4 to b1		0	1	2	3	4	5	6	7
0000	0	NUL	TC7(DLE)	SP	0	@	P	,	p
0001	1	TC1(SOH)	DC1	!	1	A	Q	a	q
0010	2	TC2(STX)	DC2	"	2	B	R	b	r
0011	3	TC3(ETX)	DC3	#	3	C	S	c	s
0100	4	TC4(EOT)	DC4	\$	4	D	T	d	t
0101	5	TC5(ENQ)	TC8(NAK)	%	5	E	U	e	u
0110	6	TC6(ACK)	TC9(SYN)	&	6	F	V	f	v
0111	7	BEL	TC10(ETB)	'	7	G	W	g	w
1000	8	FE0(BS)	CAN	(	8	H	X	h	x
1001	9	FE1(HT)	EM	)	9	I	Y	i	y
1010	10	FE2(LF)	SUB	*	:	J	Z	j	z
1011	11	FE3(VT)	ESC	+	;	K	[	k	{
1100	12	FE4(FF)	IS4(FS)	,	<	L	¥	l	
1101	13	FE5(CR)	IS3(GS)	-	=	M	]	m	}
1110	14	SO	IS2(RS)	.	>	N	`	n	~
1111	15	SI	IS1(US)	/	?	O	_	o	DEL

### ■ JIS 8-bit Codes

Unlike 7-bit codes, JIS 8-bit codes assign different codes for alphabetic characters than for katakana characters. (The table below shows the codes for alphabetic characters.)

	b8 b7 b6 b5	0 0 0 0	0 0 0 1	0 0 1 0	0 0 1 1	0 1 0 0	0 1 0 1	0 1 1 0	0 1 1 1
b4 to b1		0	1	2	3	4	5	6	7
0000	0	NUL	TC7(DLE)	SP	0	@	P	,	p
0001	1	TC1(SOH)	DC1	!	1	A	Q	a	q
0010	2	TC2(STX)	DC2	"	2	B	R	b	r
0011	3	TC3(ETX)	DC3	#	3	C	S	c	s
0100	4	TC4(EOT)	DC4	\$	4	D	T	d	t
0101	5	TC5(ENQ)	TC8(NAK)	%	5	E	U	e	u
0110	6	TC6(ACK)	TC9(SYN)	&	6	F	V	f	v
0111	7	BEL	TC10(ETB)	'	7	G	W	g	w
1000	8	FE0(BS)	CAN	(	8	H	X	h	x
1001	9	FE1(HT)	EM	)	9	I	Y	i	y
1010	10	FE2(LF)	SUB	*	:	J	Z	j	z
1011	11	FE3(VT)	ESC	+	;	K	[	k	{
1100	12	FE4(FF)	IS4(FS)	,	<	L	¥	l	
1101	13	FE5(CR)	IS3(GS)	-	=	M	]	m	}
1110	14	SO	IS2(RS)	.	>	N	`	n	~
1111	15	SI	IS1(US)	/	?	O	_	o	DEL

---

## Appendix 2 Data Access by Command

---

	Page
<b>Appendix 2-1 Command Overview .....</b>	<b>App.2-1</b>
<b>Appendix 2-2 Send Data Format of Commands .....</b>	<b>App.2-2</b>
<b>Appendix 2-3 Loader Command Details .....</b>	<b>App.2-4</b>
Appendix 2-3-1 Read data .....	App.2-4
Appendix 2-3-2 Write data .....	App.2-6
Appendix 2-3-3 Batch Start of CPUs .....	App.2-7
Appendix 2-3-4 Batch Initiazation Start of CPUs .....	App.2-7
Appendix 2-3-5 Batch Stop of CPUs .....	App.2-7
Appendix 2-3-6 Batch Reset of CPUs .....	App.2-8
Appendix 2-3-7 Individual Start of CPU .....	App.2-8
Appendix 2-3-8 Individual Initialization Start of CPU .....	App.2-8
Appendix 2-3-9 Individual Stop of CPU .....	App.2-9
Appendix 2-3-10 Individual Reset of CPU .....	App.2-9

# Appendix 2 Data Access by Command

## Appendix 2-1 Command Overview

When accessing data inside the MICREX-SX series CPU module from a personal computer or other intelligent devices, data read and write operations are possible by issuing request commands from the personal computer, without preparing send and receive application programs in the CPU module. The following 10 commands are prepared.

Function	Command name	Command	Mode	Overview
Read	Read Data	00h	00h	Reads data from the specified data memory.
Write	Write Data	01h	00h	Writes data to the specified data memory.
PC control	Activate All CPUs at One Time	04h	00h	Activates all the CPUs in the configuration at one time.
	Initialize and Activate All CPUs at One Time		01h	Initializes and activates all the CPUs in the configuration at one time
	Deactivate All CPUs at One Time		02h	Deactivates all the CPUs in the configuration at one time.
	Reset All CPUs at One Time		03h	Resets all the CPUs in the configuration at one time.
	Activate a CPU Separately		04h	Activates a specified CPU in the configuration separately.
	Initialize and Activate a CPU Separately		05h	Initializes and activates a specified CPU in the configuration separately
	Deactivate a CPU Separately		06h	Deactivates a specified CPU in the configuration separately.
	Reset a CPU Separately	07h	Resets a specified CPU in the configuration separately.	


Note: When the "Initialize and Activate All CPUs at One Time" command or "Initialize and Activate a CPU Separately" command is executed, the retain memory is cleared before activation.

### < Data access image >

Create request commands by means of an application program in the personal computer and then send them to the CPU module via the general purpose communication module. The CPU which receives request commands returns response commands.


The data communication program is not required as an application program in the CPU module.

\* Set the MODE switch of the general communication module to "1".



# Appendix 2-2 Send Data Format of Commands

The send data of request and response commands consist of the “transmission header”, “loader command”, and “checksum code”. The format of a request command is the same as that of response command. All data are transmitted as HEX code (Not ASCII code).



< Detailed send data >

**1) START code**

Starting code of send data (request command and response command). Fixed to “5Ah”.

**2) Data counter**

Indicates the number of bytes in command plus one (checksum code (BCC)).

**3) Processing status**

Indicates the result of execution of each processing requested by commands. Checked by response commands. Request commands are issued with the processing status fixed to “FFh.”

## Appendix 2-2 Send Data Format of Commands

### < Status list >

Code	Status	Description
00h	Normal end	Command processing is normally completed.
10h	CPU error	The CPU failed and command cannot be executed.
11h	CPU is operating	Cannot execute command because the CPU is operating.
12h	Command execution not possible	Cannot execute command because of CPU key switch condition.
20h	Undefined command	The CPU received an undefined command or mode.
22h	Parameter error	The command header contains a wrong specification.
23h	Transmission interlocked	Transmission is interlocked by a loader command from other device.
28h	Command processing in progress	Processing other command. Cannot execute the request command.
2Bh	Other loader processing in progress	Processing the D300win loader. Cannot execute the request command.
2Fh	Initialization not completed	System initialization in progress. Cannot execute the request command.
40h	Data specification error	An invalid data type/number was specified.
41h	Specified data not found	The specified data does not exist.
44h	Memory address specification error	The specified address is out of the valid range.
45h	Memory size exceeded	The number of addresses and read/write words exceeds the valid range.
A0h	Command target specification error	The specified target station number is assigned no module.
A2h	No command response	No response data from the target module.
A4h	SX bus send error	An error occurred on the SX bus. Cannot send or receive commands.
A5h	SX bus send NAK	A NAK occurred on the SX bus. Cannot send or receive commands.
FFh	When the request-command is specified	

### 4) Target module specification, connection ID

Specifies the target module.

Target module	Connection mode	Connection ID (L)	Connection ID (H)
CPU0	7Ah	00h	00h
CPU1 to CPU7	7Bh	SX bus station number for the target CPU	00h
P/PE link FL-net	7Bh	SX bus station number for the target module	00h

### 5) Command, mode

Command: Major category code of commands

Mode: Detailed code of commands

For details on commands and modes, refer to "Appendix 2-3 Loader Command Details."

### 6) Number of bytes in data

Indicates the number of bytes in data. The total number of bytes in the request command during data write operation and the response command during data read operation must not exceed 492 bytes.

### 7) BCC (block check character)

Checksum code for send data check. The BCC, consisting of one byte, is obtained by the following expression:

$$\text{BCC} = 00\text{h} - \{ (\text{Data counter}) + (\text{Connection status}) + \dots + (\text{Data}) \}$$

# Appendix 2-3 Loader Command Details

## Appendix 2-3-1 Read data

### 1) Function

This command reads the specified number of words from the specified address of the specified data memory. If the requested number of words exceeds the range of the specified memory, up to the end of the specified memory is read.

### 2) Command/mode code

Command: 00h, Mode: 00h

### 3) Data format of request command/response command

Data format of request command


Memory type
Memory address (L)
Memory address (M)
Memory address (H)
Number of words of read data (L)
Number of words of read data (H)

Data format of response command

Memory type
Memory address (L)
Memory address (M)
Memory address (H)
Number of words of read data (L)
Number of words of read data (H)
Read data
.
.
.

### 4) Arrangement of read data

The read data is arranged as shown below.



### 5) Example of Read Data command

When reading 2-word data from standard memory %MW1.1000 of the CPU module (CPU station No.0), request and response commands are as shown below. (Data: %MW1.1000=WORD#16#1234, %MW1.1001=WORD#16#5678)

Request command : FF7A00001100000000000000001060002E803000200

Response command : 007A000011000000000000000010A0002E80300020034127856

## Appendix 2-3 Loader Command Details

### < Memory type code >

The memory type code for each memory of the MICREX-SX module is shown below.

Target module	Memory type	Area name	Remarks
CPU module	02h	Standard memory (%MW1)	
	04h	Retain memory (%MW3)	
	08h	System memory (%MW10)	
PE link module	FFh	Broadcast area (%MW □ .1)	(Note 1)
P link module	FFh	Broadcast area (%MW □ .1)	(Note 2)
FL-net module	FFh	Common memory, etc. (%MW □ .1)	

Note 1: When accessing the broadcast area of the PE link module by means of a command, the address does not start with 0. Refer to the following address correspondence table.

Note 2: When accessing the broadcast area of the P link module by means of a command, the high-speed bit area, high-speed word area, and low-speed word area are not continuous. Refer to the following address correspondence table.

### < Address correspondence table of PE link >

	Access from application	Access from loader command		
		H	M	L
High-speed 1 area (high-speed bit area)	%MW □ .1.0	00	1E	00
	%MW □ .1.511	00	1F	FF
High-speed 2 area	%MW □ .1.512	00	20	00
	%MW □ .1.8703	00	3F	FF
Low-speed 1 area	%MW □ .1.8704	00	40	00
	%MW □ .1.12799	00	4F	FF
Low-speed 2 area	%MW □ .1.12800	00	50	00
	%MW □ .1.25087	00	7F	FF

### < Address correspondence table of P link >

	Access from application	Access from loader command		
		H	M	L
High-speed 1 area (high-speed bit area)	%MW □ .1.0	00	00	00
	%MW □ .1.511	00	01	FF
High-speed 2 area	%MW □ .1.512	00	02	00
	%MW □ .1.1663	00	06	7F
Low-speed 1 area	%MW □ .1.1664	00	08	00
	%MW □ .1.14735	00	13	FF
Low-speed 2 area	%MW □ .1.14736	00	14	00
	%MW □ .1.17807	00	1F	FF

# Appendix 2-3 Loader Command Details

## Appendix 2-3-2 Write data

### 1) Function

This command writes the specified number of words to the specified address of the specified data memory.

### 2) Command/mode code

Command: 01h, Mode: 00h

### 3) Data format of request command/response command

Data format of request command


Data format of response command

Memory type
Memory address (L)
Memory address (M)
Memory address (H)
Number of words of write data (L)
Number of words of write data (H)
Write data
.
.
.

Memory type
Memory address (L)
Memory address (M)
Memory address (H)
Number of words of write data (L)
Number of words of write data (H)

### 4) Arrangement of write data

The write data is arranged as shown below.



### 5) Example of Write Data command

When writing 1-word data to retain memory %MW3.0 of the CPU module (CPU station No.0), request and response commands are as shown below. (Write data: WORD#16#1234)

Request command : FF7A00001100000000000100000108000400000001003412

Response command : 007A0000110000000000010000010800040000000100

## Appendix 2-3-3 Batch Start of CPUs

### 1) Function

This command activates all the CPUs in the configuration at one time.

Each CPU cold-starts or warm-starts depending on the condition. CPUs already activated or CPUs with the key switch set to the "RUN" position do not perform any processing. They respond normally without error.

### 2) Command/mode code

Command: 04h, Mode: 00h

### 3) Data format of request command/response command

None

### 4) Batch start command of CPUs

When activating all the CPUs at one time, request and response commands are as shown below.

Request command : FF7A000011000000000040000010000

Response command : 007A000011000000000040000010000

## Appendix 2-3-4 Batch Initialization Start of CPUs

### 1) Function

This command initializes and activates all the CPUs in the configuration at one time.

Each CPU cold-starts. CPUs already activated or CPUs with the key switch set to the "RUN" position do not perform any processing. They respond normally without error.

### 2) Command/mode code

Command: 04h, Mode: 01h

### 3) Data format of request command/response command

None

### 4) Batch initialization start command of CPUs

When initializing and activating all the CPUs at one time, request and response commands are as shown below.

Request command : FF7A000011000000000040100010000

Response command : 007A000011000000000040100010000

## Appendix 2-3-5 Batch Stop of CPUs

### 1) Function

This command deactivates all the CPUs in the configuration at one time.

CPUs already activated or CPUs with the key switch set to the "RUN" position do not perform any processing. They respond normally without error.

### 2) Command/mode code

Command: 04h, Mode: 02h

### 3) Data format of request command/response command

None

### 4) Batch stop loader command of CPUs

When deactivating all the CPUs at one time, request and response commands are as shown below.

Request command : FF7A000011000000000040200010000

Response command : 007A000011000000000040200010000

# Appendix 2-3 Loader Command Details

## Appendix 2-3-6 Batch Reset of CPUs

### 1) Function

This command Resets all the CPUs in the configuration at one time.  
This command is executed regardless of the key switch position of the CPU.

### 2) Command/mode code

Command: 04h, Mode: 03h

### 3) Data format of request command/response command

None

### 4) Batch reset command of CPUs

When resetting all the CPUs at one time, request and response commands are as shown below.

Request command : FF7A000011000000000040300010000

Response command : 007A000011000000000040300010000

## Appendix 2-3-7 Individual Start of CPU

### 1) Function

This command activates a specified CPU in the configuration separately.  
Each CPU cold-starts or warm-starts depending on the condition. If the specified CPU has already been activated, an error result. CPU specification is made with the connection mode and connection ID.

### 2) Command/mode code

Command: 04h, Mode: 04h

### 3) Data format of request command/response command

None

### 4) Example of individual start command of CPU

When activating a CPU separately (CPU1 in a multi-CPU system), request and response commands are as shown below.

Request command : FF7BFD0011000000000040400010000

Response command : 007BFD0011000000000040400010000

## Appendix 2-3-8 Individual Initialization Start of CPU

### 1) Function

This command Initializes and activates a specified CPU in the configuration separately.  
The specified CPU cold-starts. If the specified CPU has already been activated or the key switch is set to the RUN/STOP position, an error result. CPU specification is made with the connection mode and connection ID.

### 2) Command/mode code

Command: 04h, Mode: 05h

### 3) Data format of request command/response command

None

### 4) Example of individual initialization start command of CPU

When initializing and activating a CPU separately (CPU1 in a multi-CPU system), request and response commands are as shown below.

Request command : FF7BFD0011000000000040500010000

Response command : 007BFD0011000000000040500010000

## Appendix 2-3-9 Individual Stop of CPU

### 1) Function

This command deactivates a specified CPU in the configuration separately. If the specified CPU has already been deactivated or the key switch is set to the RUN/STOP position, an error result. CPU specification is made with the connection mode and connection ID.

### 2) Command/mode code

Command: 04h, Mode: 06h

### 3) Data format of request command/response command

None

### 4) Example of individual stop command of CPU

When deactivating a CPU separately (CPU1 in a multi-CPU system), request and response commands are as shown below.

Request command : FF7BFD00110000000000040600010000

Response command : 007BFD00110000000000040600010000

## Appendix 2-3-10 Individual Reset of CPU

### 1) Function

This command resets a specified CPU in the configuration separately. If the key switch is set to the RUN/STOP position, an error result. CPU specification is made with the connection mode and connection ID.

### 2) Command/mode code

Command: 04h, Mode: 07h

### 3) Data format of request command/response command

None

### 4) Example of individual reset command of CPU

When resetting a CPU separately (CPU1 in a multi-CPU system), request and response commands are as shown below.

Request command : FF7BFD00110000000000040700010000

Response command : 007BFD00110000000000040700010000

---

## Appendix 3 Additional Explanation for NP1L-RS3

---

	Page
<b>Appendix 3-1 Applicable Version for NP1L-RS3 .....</b>	<b>App.3-1</b>
<b>Appendix 3-2 General Specifications .....</b>	<b>App.3-1</b>
<b>Appendix 3-3 Names and Functions .....</b>	<b>App.3-1</b>
Appendix 3-3-1 Names .....	App.3-1
Appendix 3-3-2 Functions .....	App.3-2
<b>Appendix 3-4 Self-diagnosis .....</b>	<b>App.3-3</b>
Appendix 3-4-1 Self-diagnosis mode 1 .....	App.3-3
(1) LED lighting check .....	App.3-3
Appendix 3-4-2 Self-diagnosis mode 2 .....	App.3-3
(1) RS to CS signal check .....	App.3-3
(2) ER to DR signal check .....	App.3-3
(3) RS-232C data check .....	App.3-3
(4) Preservation of the result of the check .....	App.3-3
<b>Appendix 3-5 Initialization Parameters .....</b>	<b>App.3-3</b>
<b>Appendix 3-6 Detailed RAS .....</b>	<b>App.3-4</b>

# Appendix 3 Additional Explanation for NP1L-RS3

Communication module (Type: NP1L-RS3) has two RS-232C port. Function is almost same as other modules (Type: NP1L-RS1/RS2/RS4).

Here explains difference between NP1L-RS3 and other modules (NP1L-RS1/RS2/RS4).

As for common function with other modules, please read main chapter of this manual.

## Appendix 3-1 Applicable Version for NP1L-RS3

(Related page: p1-4)

Type		Support version
CPU	SPH200	**30 or later (include NP1L-RS1/2/4)
	SPH300	**25 or later (include NP1L-RS1/2/4)
Loader	D300win V2	V2.2.6.0 or later
	D300win V3	V3.1.4.0 or later
	Standard Loader	V2.1.0.0 or later

If you use NP1L-RS3, you need to use with above mentioned version CPU and Loader.

\* NP1L-RS3 supports "Modem-based loader function" and "Standard extended FB".

## Appendix 3-2 General Specifications


(Related page: p2-1)

Item	Specification
Isolation method	Not isolated
Internal current consumption	110mA or less
Mass	Approx. 140g

## Appendix 3-3 Names and Functions

(Related page: p2-3 to 2-6)

### Appendix 3-3-1 Names



# Appendix 3 Additional Explanation for NP1L-RS3

## Appendix 3-3-2 Functions

### 1) Status indication LED

Here explains difference for NP1L-RS3.

Symbol	Color	Description
CH1 ALM	Red	Turns on when the communication data via CH1 is abnormal.
CH1 RXD	Green	Turns on when the CH1 is receiving data.
CH1 TXD	Green	Turns on when data is being sent from CH1.
CH2 ALM	Red	Turns on when the communication data via CH2 is abnormal.
CH2 RXD	Green	Turns on when the CH2 is receiving data.
CH2 TXD	Green	Turns on when data is being sent from CH2.

### 2) Mode selection switch

Switch No.	Mode		Remarks
	CH1	CH2	
0	General purpose device	General purpose device	
1	Programming loader	General purpose device	
2	General purpose device	Programming loader	
3	Programming loader	Programming loader	
4	Not used		
5	Not used		
6	Modem-loader 19200 bps	General purpose device	
7	Self-diagnosis mode 1 (diagnoses internal memory and LED)		
8	Self-diagnosis mode 2 (diagnoses CH1, CH2 turning back)		
9	Modem-loader 19200 bps	Programming loader	
A	Modem-loader 9600 bps	General purpose device	
B	Modem-loader 9600 bps	Programming loader	
C	Modem-loader 38400 bps	General purpose device	
D	Modem-loader 38400 bps	Programming loader	
E	Modem-loader 76800 bps	General purpose device	
F	Modem-loader 115200 bps	Modem-loader 115200 bps	

\* In case of switch No. F, use either CH1 or CH2 (Can't be used simultaneously).

### 3) RS-232C port

Same type connector and pin assignment as NP1L-RS2.

In case of NP1L-RS3, SG (Pin No. 5) and FG (M2.6 Screw) are internally connected. Generally, connect shield wire of RS-232C cable to FG of NP1L-RS3. However, if communication failed because of noise, connect shield wire of RS-232C cable to both FG of NP1L-RS3 and FG of external device (Ground on both device).

# Appendix 3 Additional Explanation for NP1L-RS3

## Appendix 3-4 Self-diagnosis

(Related page: p3-10 to p3-11)

### Appendix 3-4-1 Self-diagnosis mode 1

Function of self-diagnosis is same as NP1L-RS1/2/4. However, LED name is different.

#### (1) LED lighting check

Of the external LEDs of the module, the lighting condition of those operated by general purpose communication module are checked. When the mode selection switch is set to "7," "TS1," "TS2," "CH2 ALM" and "CH1 ALM" LEDs light up in this order.

### Appendix 3-4-2 Self-diagnosis mode 2

#### (1) RS to CS signal check

In this check, the general purpose communication module turns RS signal ON to check whether CS signal is looped back and turns ON, and then checks that this signal turns OFF.

When both CH1 and CH2 are normal, "TS2" lights up; proceeds to step (2).

IF CH1 and/or CH2 is abnormal, "TS2" blinks (at 0.5-second intervals) after 5 seconds ; proceeds to step (2).

If CH1 is abnormal, "ERR" lights up while "TS2" blinks.

If CH2 is abnormal, "CH2 ALM" lights up while "TS2" blinks.

#### (2) ER to DR signal check

In this check, the general purpose communication module turns ER signal ON to check whether DR signal is looped back and turns ON, and then checks that this signal turns OFF.

When both CH1 and CH2 are normal, "TS1" lights up; proceeds to step (3).

IF CH1 and/or CH2 is abnormal, "TS1" blinks (at 0.5-second intervals) after 5 seconds ; proceeds to step (3).

If CH1 is abnormal, "ERR" lights up while "TS1" blinks.

If CH2 is abnormal, "CH2 ALM" lights up while "TS1" blinks.

#### (3) RS-232C data check

The general purpose communication modules sends 16 bytes of data once and checks the looped back data received.

When both CH1 and CH2 are normal, "CH1 ALM" lights up; proceeds to step (4).

IF CH1 and/or CH2 is abnormal, "CH1 ALM" blinks (at 0.5-second intervals) after 10 seconds ; proceeds to step (4).

If CH1 is abnormal, "ERR" lights up while "CH1 ALM" blinks.

If CH2 is abnormal, "CH2 ALM" lights up while "CH1 ALM" blinks.

#### (4) Preservation of the result of the check

After 10 seconds of displaying the results from (3) above, the module returns to step (1). Here, if the setting of the mode selection switch has been changed, Self-diagnosis Mode 2 is ended to enter the designated mode.

## Appendix 3-5 Initialization Parameters

(Related page: p4-7)

No.	Item	Specification
1	Port No.	Designates an interface port on general purpose communication module. 0: CH1 1: CH2
12	RS-485 mode	Not used in case of NP1L-RS3.

# Appendix 3 Additional explanation for NP1L-RS3

## Appendix 3-6 Detailed RAS

(Related page: p7-3)

No. 4 and No. 5 information newly added to detailed RAS information.

(To NP1L-RS3 module. Currently, NP1L-RS1/RS2/RS4 doesn't support this information.)

0	Status of general purpose communication module
1	Status of CH1
2	Status of CH2
3	Not used
4	Self-diagnostic 1
5	Self-diagnostic 2
6	Not used
7	Not used
8	Number of parity error occurrences
9	Number of framing error occurrences
10	Number of overrun error occurrences
11	Send buffer overflow
12	Receive buffer overflow
13	Loopback buffer overflow


} RS-232C

No.4 (Self-diagnostic 1)

Bit 0: External RAM abnormal

Bit 1 to 15: Not used

No.5 (Self-diagnostic 2)



---

## Appendix 4 Additional Explanation for NP1L-RS5

---

	Page
<b>Appendix 4-1 Applicable Version for NP1L-RS5</b> .....	<b>App.4-1</b>
<b>Appendix 4-2 General Specifications</b> .....	<b>App.4-1</b>
<b>Appendix 4-3 Names and Functions</b> .....	<b>App.4-1</b>
Appendix 4-3-1 Names .....	App.4-1
Appendix 4-3-2 Functions .....	App.4-2
<b>Appendix 4-4 Self-diagnosis</b> .....	<b>App.4-4</b>
Appendix 4-4-1 Self-diagnosis mode 1 .....	App.4-4
(1) LED lighting check .....	App.4-4
Appendix 4-4-2 Self-diagnosis mode 2 .....	App.4-4
(1) RS-485 data check .....	App.4-4
(2) Preservation of the result of the check .....	App.4-4
<b>Appendix 4-5 Initialization Parameters</b> .....	<b>App.4-4</b>
<b>Appendix 4-6 Loader Network Functions</b> .....	<b>App.4-4</b>
<b>Appendix 4-7 Detailed RAS</b> .....	<b>App.4-5</b>

# Appendix 4 Additional Explanation for NP1L-RS5

Communication module (Type: NP1L-RS5) has two RS-485 port. Function is almost same as other modules (Type: NP1L-RS1/RS2/RS4).

Here explains difference between NP1L-RS5 and other modules (NP1L-RS1/RS2/RS4).

As for common function with other modules, please read main chapter of this manual.

## Appendix 4-1 Applicable Version for NP1L-RS5

(Related page: p1-4)

Type		Support version
CPU	SPH200	**30 or later (include NP1L-RS1/2/4)
	SPH300	**25 or later (include NP1L-RS1/2/4)
Loader	D300win V2	Not supported
	D300win V3	V3.3.2.0 or later
	Standard Loader	V2.2.2.1 or later

If you use NP1L-RS5, you need to use with above mentioned version CPU and Loader.

\* NP1L-RS5 supports "Modem-based loader function" and "Standard extended FB".

## Appendix 4-2 General Specifications

(Related page: p2-1)

Item	Specification
Internal current consumption	110mA or less
Mass	Approx. 190g

## Appendix 4-3 Names and Functions

(Related page: p2-3 to 2-6)

### Appendix 4-3-1 Names


Status indication LED

Mode selection switch

RS-485 station number switch

Terminating resistor ON/OFF switch

RS-485  
Terminals block



# Appendix 4 Additional Explanation for NP1L-RS5

## Appendix 4-3-2 Functions

### 1) Status indication LED

Here explains difference for NP1L-RS5.

Symbol	Color	Description
CH1 ALM	Red	Turns on when the communication data via CH1 is abnormal.
CH1 RXD	Green	Turns on when the CH1 is receiving data.
CH1 TXD	Green	Turns on when data is being sent from CH1.
CH2 ALM	Red	Turns on when the communication data via CH2 is abnormal.
CH2 RXD	Green	Turns on when the CH2 is receiving data.
CH2 TXD	Green	Turns on when data is being sent from CH2.
TS1	Green	Blinks when internal RAM error is detected in self-diagnosis mode 7.
TS2	Green	Not used

### 2) Mode selection switch


Switch No.	Mode		Remarks
	CH1	CH2	
0	General purpose device	General purpose device	
1	Programming loader	General purpose device	
2	General purpose device	Programming loader	
3	Programming loader	Programming loader	
4	Not used		
5	Not used		
6	Modem-loader 19200 bps	General purpose device	
7	Self-diagnosis mode 1 (diagnoses internal memory and LED)		
8	Self-diagnosis mode 2 (diagnoses CH1, CH2 turning back)		
9	Modem-loader 19200 bps	Programming loader	
A	Modem-loader 9600 bps	General purpose device	
B	Modem-loader 9600 bps	Programming loader	
C	Modem-loader 38400 bps	General purpose device	
D	Modem-loader 38400 bps	Programming loader	
E	Modem-loader 76800 bps	General purpose device	
F	Modem-loader 115200 bps	Modem-loader 115200 bps	

\* In case of switch No. F, use either CH1 or CH2 (Can't be used simultaneously).

# Appendix 4 Additional Explanation for NP1L-RS5

### 3) RS-485 station No. switch

Used to set RS-485 station No. for CH1, CH2 individually.  
Range: 00 to 1F (HEX)



The second digit is set by dip switch.

OFF: 0

ON: 1

The first digit is set by rotary switch. (0 to F)

### 4) Terminating resistor ON/OFF switch


This switch used to select the ON/OFF of the RS-485 terminating resistor. There are three positions for this switch.



Switch position	Status
Right	2-wire type, terminating resistor is available.
Center	Terminating resistor is not available.
Left	4-wire type, terminating resistor is available.

### 5) RS-485 terminal block

It is used to connect RS-485 cable (20 poles, M3 screw).



Signal name	Signal direction	RS5 ↔ External device	Description
SDA		⇒	Send data signal line (+)
SDB		⇒	Send data signal line (-)
RDA		⇐	Receive data signal line (+)
RDB		⇐	Receive data signal line (-)
SG			Signal ground (Common return)
FG			Frame ground

For wiring, please refer "6-2 Wiring Method".

However, in case of 2-wire, short SDA and RDA (+), SDB and RDB (-) and connect to other device.

In case of RS5, no need to connect zener diode as it is already included in module.

# Appendix 4 Additional Explanation for NP1L-RS5

## Appendix 4-4 Self-diagnosis

(Related page: p3-10 to p3-11)

### Appendix 4-4-1 Self-diagnosis mode 1

Function of self-diagnosis is same as NP1L-RS1/2/4. However, LED name is different.

#### (1) LED lighting check

Of the external LEDs of the module, the lighting condition of those operated by general purpose communication module are checked. When the mode selection switch is set to “7,” “TS1,” “TS2,” “CH2 ALM” and “CH1 ALM” LEDs light up in this order.

### Appendix 4-4-2 Self-diagnosis mode 2

#### (1) RS-485 data check

The general purpose communication modules sends 16 bytes of data once and checks the looped back data received.

When both CH1 and CH2 are normal, “CH1 ALM” lights up; proceeds to step (2).

If CH1 is abnormal, “CH1 ALM” blinks (at 0.5-second intervals) and “ERR” turns ON after 10 seconds; proceeds to step 2.

If CH2 is abnormal, “CH2 ALM” blinks (at 0.5-second intervals) and “ERR” turns ON after 10 seconds; proceeds to step 2.

#### (2) Preservation of the result of the check

After 10 seconds of displaying the results from (1) above, the module returns to step (1). Here, if the setting of the mode selection switch has been changed, Self-diagnosis Mode 2 is ended to enter the designated mode.

## Appendix 4-5 Initialization Parameters

(Related page: p4-7)

No.	Item	Specification
1	Port No.	Designates an interface port on general purpose communication module. 0: CH1 1: CH2
8	DCE designation	Not used in case of NP1L-RS5
9	ER/DR signal control	Not used in case of NP1L-RS5
10	Signal flow control	Not used in case of NP1L-RS5

## Appendix 4-6 Loader Network Functions

(Related page: p3-7)


If you use this module on loader network configuration, connect cable to CH2.

# Appendix 4 Additional Explanation for NP1L-RS5

## Appendix 4-7 Detailed RAS

(Related page: p7-3)

RS-485 station No. switch setting appears on bit 5 to 9, 0 to 4 on communication status area.



No. 4 and No. 5 information newly added to detailed RAS information.  
(Almost same as RS3 specification)


0	Status of general purpose communication module	
1	Status of CH1	
2	Status of CH2	
3	Not used	
4	Self-diagnostic 1	
5	Self-diagnostic 2	
6	Not used	
7	Not used	
8	Number of parity error occurrences	} RS-232C
9	Number of framing error occurrences	
10	Number of overrun error occurrences	
11	Send buffer overflow	
12	Receive buffer overflow	
13	Loopback buffer overflow	

No.4 (Self-diagnostic 1)

Bit 0: External RAM abnormal

Bit 1 to 15: Not used

No.5 (Self-diagnostic 2)



---

## **Fuji Electric FA Components & Systems Co., Ltd.**

Mitsui Sumitomo Bank Ningyo-cho Bldg.,  
5-7, Nihonbashi Odemma-cho, Chuo-ku, Tokyo 103-0011, Japan  
Phone: +81-3-5847-8011  
Fax: +81-3-5847-8172  
URL <http://www.fujielectric.co.jp/fcs/eng/>