

**CTR**

**COMPLETE TRANSPORT  
REFRIGERATION SERVICES, INC.**

**MIDWEST**



**ZANOTTI**

*UNO<sup>o</sup>*

**USE AND MAINTENANCE INSTRUCTIONS**



## CONTENTS

1. **Safety recommendations**
2. **Table of warning and attention plates**
3. **Description of the machine**
4. **Description of the controller**
  - 4.1. Starting the controller
    - 4.1.1. Standard
    - 4.1.2. Multi-temperature version
  - 4.2. Setting diesel operation
  - 4.3. Setting the work set point
    - 4.3.1. Standard
    - 4.3.2. Multi-temperature version
  - 4.4. Enabling and disabling evaporators (only Multi-temperature version)
  - 4.5. Starting the refrigerating unit
  - 4.6. Manual defrost
  - 4.7. Alarms
  - 4.8. Alarm list
  - 4.9. Description of alarms
  - 4.10. Diesel operation lock (engine lock)
  - 4.11. Service
  - 4.12. Maintenance
    - 4.12.1. Maintenance A
    - 4.12.2. Maintenance B
    - 4.12.3. Maintenance C
    - 4.12.4. Maintenance D
    - 4.12.5. Further maintenance instructions
5. **Storage and stacking**
6. **Mobile partitions**
7. **How to use the refrigerating unit in the best way**
8. **Safe use**
  - 8.1. Engine coolant
  - 8.2. Refrigerant
  - 8.3. Battery
9. **Troubleshooting**
10. **How to order spare parts**
11. **Warranty**
12. **How to dispose of the packing**
13. **How to dispose of the unit**

Thank you for choosing Transblock. Please read these instructions carefully. They provide details and advice on the correct method of installing, using and maintaining this unit, in order to obtain maximum reliability, efficiency and long life

## 1. Safety recommendations

When installing and using the unit please follow the recommendations listed here below.

- The machine should be installed according to the diagrams and instructions given by the manufacturer.
- Any damage due to improper connections is excluded.
- The neutral conductor, even if grounded, is not accepted as a safety conductor.
- The electric installation of the place where the unit is installed must comply with the regulations in force applicable to electrical installations.
- Maintenance shall be effected by trained personnel or by the manufacturer according to the provisions supplied by EN378.



### **ATTENTION**

***Use safety gloves to protect your hands from possible cuts.***

The user is strongly recommended to contact the manufacturer before attempting any intervention on the unit and any use not corresponding to the manufacturer's indications (in particular as for the field of application) and to enquire about the possible dangers and contra-indications connected with an improper use of the machine.

- The unit shall be used following these instructions and sticking to the destination of use indicated by the supplier. Any incorrect use can result in damage to the unit and represents a serious danger for people's health.



### **ATTENTION**

**The unit is not suitable for working in explosive environments.**

**Therefore the use of the unit in an explosion-dangerous atmosphere is absolutely forbidden.**



### **ATTENTION**

***The unit is not suitable for working in salty environments. In such a case protect condenser and evaporator with appropriate means.***

When maintenance involves operations on the cooling circuit, drain the system and let it reach the atmospheric pressure.



### **WARNING**

***Do not discharge the refrigerant in the atmosphere. It must be recovered by specialised technicians using a suitable equipment.***

- Quantity and quality of the refrigerant to be charged are indicated on the data plate.
- Do not use refrigerants of different kind (especially inflammable refrigerants, for example hydrocarbons) or air.
- No modifications or changes in the refrigerating circuit or in components (such as: welding on compressor body) are allowed.
- The final user shall protect the unit from external fire dangers.

- The unit has been so built as to maintain a constant temperature in the cold room during transport.
- This requires the load compartment to be equipped with a closing system ensuring perfect tightness, so that on unloading the product has a correct temperature; in addition when loading and arranging the product in the cold room make sure that it is perfectly ventilated.
- Should a product be loaded at an excessive temperature, the unit will not be able to cool it, as this operation does not fall within the use it is intended for.

The following recommendations are supplied for a safe use of the refrigerating unit:



**ATTENTION**

- Do not use any water or steam jets for cleaning purposes: they could damage the electric components of the unit.
- Keep the radiating masses of condenser and evaporator clean and free from obstructions.
- When the unit is connected to the mains, and in particular when it is in a closed environment, check that the condenser is not obstructed or too near the walls; in addition make sure that air circulation is adequate.
- Check that all securing screws are properly tightened and suitable for the intended use.
- When boring the unit or the vehicle frame, pay attention not to bore any refrigerating pipe, electric wire or any other component.
- Never close the compressor relief valves when the unit is operating.
- In case of operations on the unit, only use pressure gauges in good conditions. Do not put them in contact with any belts, with the pulley or the fan.





**WARNING**











- Carry out cleaning and maintenance operations only when the unit is still.
- After a certain period of operation the condenser and the high-pressure delivery pipes are particularly hot; wait for the unit to cool before any operation on it.
- The unit includes moving parts such as fans, belts and pulleys. Pay special attention to them: work on the unit only when it is still and prevent accidental starting.
- When working in the battery area (condenser and evaporator), be careful not to be cut by fin edges.
- When the unit is operating, keep your hands far from fans and pulleys.
- Handle the refrigerant taking all necessary safety measures.
- When the refrigerant is placed near a source of heat it produces a gas with an unpleasant smell, which irritates the respiratory system.
- Never use fire to heat a refrigerating circuit containing refrigerant.
- Be careful when servicing the refrigerating circuit. On contact with the air, the refrigerant evaporates and immediately frosts whatever is in close contact with it.
- First-aid measures in case of frostbite:
  - a) Cover the affected area.
  - b) Quickly heat the frostbitten area by plunging it into cold water.
  - c) If there is no water available, wrap up the affected area carefully with a clean cloth.
  - d) If the refrigerant comes into contact with the eyes, rinse them immediately with clean water and call a doctor.
  - e) Call a doctor.
- Cooling oil  
Synthetic types  
Avoid long and repeated contact with the skin.  
After handling wash your hands thoroughly.

The unit starts automatically; keep far from moving parts (belts, pulleys, fans).

## 2. Table of warning and attention plates

 <b>ZANOTTI S.p.A.</b> Via Martin L. King nr.30 46020 PEGOGNAGA (Mantova) - Italy		 <b>0486</b> 2005
Modello Model	_____	
Matricola Serial number	_____	
Tensione Voltage	_____	
Assorb. Marcia Run Absorption	_____ A	_____ Kw
Assorb. Max Max Absorption	_____ A	Ass. Pspunto Start Abs. _____ A
Potenza Compress. Compressor Power	_____ Kw	
Refrigerante Refrigerant	_____ Kg	_____ Kg
Massa C Mass C	_____ Kg	Massa E Mass E _____ Kg
Schemi Diag.	_____	
PSHP	30 bar	PSLP 20 bar
TSHP	100 °C	TSLP -35 °C
PSV	30 bar	

- 1) Year of manufacture
- 2) Zanotti unit code
- 3) Serial number
- 4) Voltage
- 5) Ride absorption
- 6) Max. absorption
- 7) Starting absorption
- 8) Rated power of compressor
- 9) Refrigerant: Type, Quantity
- 10) Unit mass
- 11) Wiring diagram number

	<i>Refrigerant</i>
	<i>Condensate drain line</i>
	<i>Attention: hot or cold parts</i>
	<i>Attention: danger of electrocution. Cut out the unit before opening the electric panel.</i>
	<i>Direction of rotation</i>
	<i>Colours of supply cable wires</i>
	<i>Attention: switch off before servicing the unit</i>
	<i>Attention: rotating fans</i>
	<i>Diesel fuel delivery pipe</i>
	<i>Diesel fuel return pipe</i>

### 3. Description of the machine

The UNO° refrigeration units are made up of the following main components:

1. a condensing unit installed outside the isothermal box;
2. an evaporating unit installed inside the isothermal box;
3. an electronic central control unit located in the driver's cab of the vehicle.

All models are suitable to store products both at positive and negative temperatures.

### 4. Description of the controller

ZANOTTI UNO° refrigerating units are equipped with a microprocessor-based electronic controller (cabin control) which manages operation in a fully automatic way. In particular the electronic controller supervises the operations for starting and stopping the diesel engine and the electric motor depending on the set temperature. The operating mode (diesel or electric) is selected automatically by connecting the plug to the mains

#### 4.1. Starting the controller

Keep the first button on the right (ON/OFF) pressed until the display in on. Follow the same procedure to turn off the unit.





After the introductory view, the state of the unit will be displayed.

#### 4.1.1. Standard

Press  to start or stop the refrigerating unit; the display is left on.


Electric operation  
n° 2 Evaporators

Diesel operation  
n° 3 Evaporators




#### 4.1.2. Multi-temperature version


Electric operation  
n° 2 Evaporators




n° 3 Evaporators



Diesel operation  
n° 2 Evaporators



n° 3 Evaporators



#### 4.2. Setting diesel operation

Press **AUTO**  
**CONT** to select the operating mode:

- automatic (start/stop): the unit starts and stops according to the set temperature (set point);
- continuous: temperature is kept steady without stopping the engine.

Press **HIGH**  
**LOW** to select high or low speed (only for start/stop operating mode).

#### ATTENTION

Diesel operation is replaced with electric operation every time the unit is connected to the mains and switched on.

In case of voltage drop during electric operation, diesel operation is resumed after about 5 minutes.

#### 4.3. Setting the work set point

Press **SET** and the following screen will appear:


##### 4.3.1. Standard




Press **- +** to decrease or increase value.

#### 4.3.2. Multi-temperature version

n° 2 Evaporators



n° 3 Evaporators




Press to reach the different set points (SP..)

Press to decrease or increase value.


To reach the main view press .

#### 4.4. Enabling and disabling evaporators (only Versione Multi-temperature version)

To enable or disable an evaporator press




and the following screen will appear




Then press to obtain the evaporator enabling/disabling screen.

n° 2 Evaporators



n° 3 Evaporators




Use to select the evaporator you are going to enable/disable and press to change its state.


To go back to the main view press .



The main view will show the note **Dis** indicating the disabled evaporator.  
n° 2 Evaporators





n° 3 Evaporators




#### 4.5. Starting the refrigerating unit

Press  to start or stop the refrigerating unit; the display is left on.

#### 4.6. Manual defrost

Keep  pressed for 5 seconds in the main view. Defrost start is subject to defrost end thermostat (clixon) consent. During defrost icon  appears and at the same time the button starts blinking.





Defrost is followed by the dripping phase: the unit is still and the display blinks.

#### 4.7. Alarms


There are three types of alarm:


- 1) warning only,
- 2) lock with automatic reset,
- 3) lock with manual reset.


Warning only: icon  appears on the display, indicating that an alarm is on (see here below):





The warning is accompanied with the activation of buzzers placed on the unit and on the controller.


Press  once to mute the buzzer on the controller.




Press  again to visualize the type of alarm in course.

Icon  indicates the alarm state: when it is displayed, the alarm is still active.





To mute the buzzer on the unit press .


To clear the displayed warning and restore the default state, press  again.


To reach the main view press . When the alarm ceases automatically, the buzzers are muted but the warning on the display is left active. To clear the displayed warning and restore the default state go to the alarm screen and press . To go back to the main view press .

Automatic reset alarm: the same as in “simple warning” occurs, with the only difference that the unit stops and starts again automatically when the alarm ceases.

Manual reset alarm: icon  and writing **Locked** appear. Buzzers are activated.




- Press  twice to have alarm type displayed.




- When the cause for the alarm is removed, press  and “no alarm” will appear. In the locked state icon  is left on even when the alarm has ceased.



- Press  to go back to the main view.




- When the alarm has ceased, press  to start the unit.

#### 4.8. Alarm list

Code	Description	Type
A01	Room sensor failure alarm	Manual reset
A04	Pressure switch alarm (min)	Automatic reset
A05	Oil level alarm	Warning only
A06	Air filter alarm	Warning only
A07	Water temperature alarm	Manual reset
A08	Open door microswitch alarm	Automatic reset
A09	Open door alarm	Automatic reset
A10	Oil pressure alarm	Manual reset
A11	Pressure switch alarm	Automatic reset
A12	Max. temperature alarm	Warning only
A13	Min. temperature alarm	Warning only
A14	Thermal relay alarm	Automatic reset
A15	Low battery alarm	Manual reset
A16	Failed starting	Manual reset
A17	Alternator failure alarm	Manual reset
A18	Water sensor failure alarm	Warning only

#### 4.9. Description of alarms

##### A01 Room sensor failure alarm

This alarm causes the unit to stop permanently until the sensor has been repaired. To start the unit again reset the alarm following the instructions supplied above and press the on/off button .

##### A04/11 Pressure switch alarm

This alarm occurs when either the high or low pressure switch trips due to poor cleaning of the condenser or loosened condenser fan belts. The low pressure switch may also trip due to refrigerant leaks. The alarm interrupts the operation of the unit until the cause is removed.

##### A05 Oil Level alarm

It is a warning alarm which has no consequences on unit operation.

##### A06 Air filter alarm

It is a warning alarm which has no consequences on unit operation

##### A07 Water temperature alarm

This alarm occurs when the radiator water temperature exceeds the permitted value. It causes the diesel engine to stop until water temperature returns to normal values.


### A08 Open door microswitch alarm

This alarm occurs when the engine compartment door is opened. It prevents the engine from starting.

### A09 Open door alarm

When there is the door microswitch, this alarm indicates that the load compartment door is open.


### A10 Oil pressure alarm

This alarm occurs in case of engine oil pressure drop and it causes the diesel engine to stop permanently. To restart the unit reset the alarm as described in above paragraph and press the on/off button .

### A12/13 Max/Min. temperature alarm

This alarm occurs when the difference between the actual cold room temperature and the temperature set using the control exceeds a factory-set limit.


### A14 Thermal relay alarm

This alarm occurs in case of abnormal power absorption of the electric motor and it causes the unit to stop. To reset the alarm disconnect the unit, open the electric panel and reset the thermal relay by pressing the blue button. Close the electric panel and connect the unit to the mains. Then press the on/off button  on the controller.

### A15 Low battery alarm

This alarm occurs when battery voltage is lower than 11,5V. It causes the unit to stop until voltage is higher than 11,5V for at least 1'.




### A16/17 Failed starting or alternator failure alarm

This alarm occurs when all starting attempts with the diesel engine (5, factory-set) have failed. Possible causes include: broken alternator, slacked belts, no fuel [flooded engine]. If the same alarm occurs during electric operation, it can be caused by alternator failure. To start the unit again reset the alarm following the instructions supplied above and press the on/off button .




### A18 Water sensor failure alarm



It is a warning alarm which has no consequences on unit operation

#### 4.10. Diesel operation lock (engine lock)

To lock diesel engine operation keep  pressed for some seconds, until icon  appears on the display indicating that diesel engine operation is impossible. Press  to go back to the main view.


#### 4.11. Service




- Press  to reach the mask that includes the maintenance button .
- Press  to have the following information displayed:
  - Alternator voltage
  - Battery voltage
  - Water temperature
  - Diesel engine hours
  - Electric motor hours




#### 4.12. Maintenance

When a maintenance operation is necessary, icon  appears in the main view.



- Press  to reach the mask that includes the maintenance button .
- Press  to have the code of the maintenance operation required displayed (see relevant paragraph in this manual).



##### 4.12.1. Maintenance A

- Replace diesel engine oil (1).
- Replace oil filter.
- Check air filter: clean it if necessary.
- Check engine cooling system (2).
- Check tightening of bolts securing the unit.
- Check belt state and tension (3).
- Check if condenser is clean.
- Check controller operation.
- Replace diesel oil filter.

TIME NECESSARY FOR ABOVE OPERATIONS: 2 HOURS

#### **4.12.2. Maintenance B**

- Check diesel fuel pump filter.
- Replace air filter cartridge.
- Check oil level in compressor.
- Check alternator brushes.
- Check battery terminals.
- Check and adjust valve rockers.
- Check refrigerant level.
- Check operation of diesel engine thermostat.
- Check defrost cycle.
- Check brushes and operation of evaporator fans.
- Replace belts, if necessary (3).
- Check controller operation.

TIME NECESSARY FOR ABOVE OPERATIONS: 3 HOURS

#### **4.12.3. Maintenance C**

- Clean radiator and condenser (2).
- Check refrigerant level.
- Check diesel engine RPM (see technical data).
- Check tightener pulley.
- Check alternator charge.
- Check evaporator fan brushes.
- Check controller operation.

TIME NECESSARY FOR ABOVE OPERATIONS: 3 HOURS

#### **4.12.4. Maintenance D**

- Check all tighteners (3).
- Replace antifreeze in diesel engine (2).
- Check electric motor bearings.

TIME NECESSARY FOR ABOVE OPERATIONS: 3 HOURS

#### **4.12.5. Further maintenance instructions**

**Before any maintenance operation make sure that the controller is OFF and the refrigerating unit can not start.**

**In addition to the above-listed operations, we strongly recommend to follow these further instructions:**

**(1) Replace engine oil at least one a year, even if the engine has not reached the prescribed operating hours.**

**Recommended oils:**

**ZANOTTI 10W – 40**

**ELF Multiperformance 4D – 10W - 40**

**AGIP SIGMA TURBOSHPD 10W – 40**

**MOBIL DELVAC SHC 10W – 40 DELVAC**

**1400 SUPER**

**FIAT URANIA TURBO 10W 40**

**SHELL MYRINA TX 10W 40**

**BP VANELLUS C3 EXTRA 10W 40**

**(2) The coolant (protection down to –36°C Long Life “B”) must be replaced at least every 2 years.**

### **(3) BELTS**

**A correct belt tension enables better transmission and reduces belt wear.**

**Attention: when two belts are mounted together and one of them needs replacement, replace BOTH belts.**

## **5. Storage and stacking**

One of the main concerns when storing goods is how to ensure proper air circulation in the isothermal cold room. If air cannot circulate freely throughout the cargo, ice or warm areas will almost certainly develop which could irreparably damage the goods.

The first action to be taken is to store the goods on pallets. If loaded in a proper way, goods on pallets let air circulate freely in and out of the evaporator. Furthermore, they will be protected by the pallet from the heat passing through the floor of the trailer.

Proper air circulation is extremely important too when stacking the goods. In fact some goods tend to produce heat, while others don't.

Fruit and vegetables, for example, belong to the first group. In this case the goods should be stacked in such a way as to ensure good air circulation through the cargo. On the contrary, items which do not generate any heat (such as meat, deep frozen products and fresh packaged products) should be stacked in the middle of the cold room.

Do not lean the goods against the cold room walls: as they filter heat from the environment they would cause damage to the goods.

ZANOTTI UN0° refrigerating units are designed to keep the goods at their loading temperature; they are not suitable to refrigerate warm products

## **6. Mobile partitions**

There are different minimum clearances at which mobile partitions should be placed, depending on the UN0° ZANOTTI refrigeration unit model. Such clearances are:

- UN0° 080: 1400 mm / about 4' 7 1/2"
- UN0° 100: 1800 mm / about 6'
- UN0° 120: 2700 mm / about 9'

The air pipes of the evaporator should always be left undisturbed.

## **7. How to use the refrigerating unit in the best way**

- Open the doors as briefly as possible.
- Before selecting the required cold room temperature, check the temperature of the goods to be carried.
- Keep a minimum distance of 10/15 cm. between cargo and cold room walls.

- Park your vehicle in the shade and make sure that the ZANOTTI UNO° refrigeration unit does not remain idle for a long time.

## 8. Safe use

ZANOTTI UNO° units are built to ensure the operator's total safety. Nevertheless, for any operation carried out inside the unit (checks, repair or maintenance work) the operator should wear safety gloves to prevent burns due to the accidental contact with hot components and cuts due to contact with condenser or evaporator fins.

### 8.1. Engine coolant

ZANOTTI UNO° units, like all engines, operate with a coolant which, under normal operation conditions, is subject to high pressures and temperatures in the engine and radiator. For this reason a spill or release of coolant can cause severe scalds. Never remove the cap from a hot radiator. Should this be absolutely necessary, unscrew it very carefully so that pressure can stabilise slowly and evenly.

### 8.2. Refrigerant

The refrigerant contained in the refrigeration system can cause serious injuries if it comes into contact with any part of the body, and burns, frostbite and even blindness if it comes into direct contact with the eyes. For this reason the regulations applicable to the handling of refrigerants during maintenance operations provide for the customer to call the nearest service centre to have the unit serviced or repaired.

### 8.3. Battery

It is strictly forbidden to smoke while checking the unit. Batteries, in fact, release small amounts of hydrogen which can ignite and cause the battery to explode and the operator to be seriously injured or blinded.

## 9. Troubleshooting

Zanotti UNO° units are tested and certified for correct operation. Nevertheless, should a problem occur, check the following table before contacting a Service Centre.

Trouble	Checks to carry out
On turning on, the engine does not start	Check flat battery. Check battery connections. Check fuses.
The unit won't start	Check fuel level. Check engine oil level. Check fuses.
The unit jams	Check belts tension. Check engine oil level. Check coolant level. Check fuel level. Check fuses.
The unit does not cool properly	Defrost the unit. Check something hinders the proper ventilation of the evaporator. Check Something hinders the proper ventilation of the condenser. Check The isothermal cold room might be damaged or have leaks.



## 10. How to order spare parts

When ordering spare parts make reference to the serial number written on the unit plate.



### **WARNING**

*Worn parts should be replaced only by qualified personnel or by the manufacturer.*

## 11. Warranty

Keep your warranty certificate carefully; you will be required to show it whenever your refrigeration unit needs servicing. The machine should be installed according to the diagrams and instructions given by the manufacturer. Any damage due to improper connections is excluded from the warranty.

The neutral conductor, even if grounded, is unacceptable as a safety conductor.

The electrical installation of the place where the unit is installed must comply with the regulations in force applicable to electrical installations.

The machine must be used according to the user's instructions and only for the use the manufacturer intended it for.

## 12. How to dispose of the packing

Wooden, plastic, polystyrene packing shall be disposed of according to the regulations in force in the country where the unit is used.

## 13. How to dispose of the unit

Do not discharge scrapped components in the environment. They should be disposed of by companies dealing with special waste collection and recovery, according to the regulations in force in the country where the unit is used.



### **WARNING**

*Do not discharge the refrigerant in the atmosphere. It should be disposed of by companies dealing with special waste collection and recovery.*

