



Thinking of you
Electrolux



EHL8840FOG

EN HOB

USER MANUAL



CONTENTS

1. SAFETY INFORMATION	3
2. SAFETY INSTRUCTIONS	4
3. PRODUCT DESCRIPTION	6
4. DAILY USE	8
5. HELPFUL HINTS AND TIPS	11
6. CARE AND CLEANING	13
7. TROUBLESHOOTING	13
8. INSTALLATION	15
9. TECHNICAL INFORMATION	17
10. SAUDI ARABIA - CUSTOMER SERVICE	17

WE'RE THINKING OF YOU

Thank you for purchasing an Electrolux appliance. You've chosen a product that brings with it decades of professional experience and innovation. Ingenious and stylish, it has been designed with you in mind. So whenever you use it, you can be safe in the knowledge that you'll get great results every time.

Welcome to Electrolux.

Visit our website for:



Get usage advice, brochures, trouble shooter, service information:
www.electrolux.com



Register your product for better service:
www.electrolux.com/productregistration



Buy Accessories, Consumables and Original spare parts for your appliance:
www.electrolux.com/shop

CUSTOMER CARE AND SERVICE

We recommend the use of original spare parts.
When contacting Service, ensure that you have the following data available.
The information can be found on the rating plate. Model, PNC, Serial Number.



Warning / Caution-Safety information



General information and tips



Environmental information

Subject to change without notice.

1. SAFETY INFORMATION

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible if an incorrect installation and use causes injuries and damages. Always keep the instructions with the appliance for future reference.

1.1 Children and vulnerable people safety



WARNING!

Risk of suffocation, injury or permanent disability.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they are supervised by an adult or a person who is responsible for their safety.
- Do not let children play with the appliance.
- Keep all packaging away from children.
- Keep children and pets away from the appliance when it operates or when it cools down. Accessible parts are hot.
- If the appliance has a child safety device, we recommend that you activate it.
- Cleaning and user maintenance shall not be made by children without supervision.

1.2 General Safety

- The appliance and its accessible parts become hot during use. Do not touch the heating elements.
- Do not operate the appliance by means of an external timer or separate remote-control system.
- Unattended cooking on a hob with fat or oil can be dangerous and may result in fire.

- Never try to extinguish a fire with water, but switch off the appliance and then cover flame e.g. with a lid or a fire blanket.
- Do not store items on the cooking surfaces.
- Do not use a steam cleaner to clean the appliance.
- Metallic objects such as knives, forks, spoons and lids should not be placed on the hob surface since they can get hot.
- If the glass ceramic surface is cracked, switch off the appliance to avoid the possibility of electric shock.
- After use, switch off the hob element by its control and do not rely on the pan detector.

2. SAFETY INSTRUCTIONS

2.1 Installation



WARNING!

Only a qualified person must install this appliance.

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Obey the installation instruction supplied with the appliance.
- Keep the minimum distance from the other appliances and units.
- Always be careful when you move the appliance because it is heavy. Always wear safety gloves.
- Seal the cut surfaces with a sealant to prevent moisture to cause swelling.
- Protect the bottom of the appliance from steam and moisture.
- Do not install the appliance adjacent to a door or under a window. This prevents hot cookware to fall from the appliance when the door or the window is opened.
- If the appliance is installed above drawers make sure that the space, between the bottom of the appliance and the up-

per drawer, is sufficient for air circulation.

- Make sure that the ventilation space of 2 mm, between the worktop and the front of the below unit, is free. The warranty does not cover damages caused by the lack of an adequate ventilation space.
- The bottom of the appliance can get hot. We recommend to install a non-combustible separation panel under the appliance to prevent access to the bottom.

Electrical connection



WARNING!

Risk of fire and electrical shock.

- All electrical connections must be made by a qualified electrician.
- The appliance must be earthed.
- Before carrying out any operation make sure that the appliance is disconnected from the power supply.
- Use the correct electricity mains cable.
- Do not let the electricity mains cable tangle.
- Make sure the mains cable or plug (if applicable) does not touch the hot ap-

pliance or hot cookware, when you connect the appliance to the near sockets

- Make sure the appliance is installed correctly. Loose and incorrect electricity mains cable or plug (if applicable) can make the terminal become too hot.
- Make sure that a shock protection is installed.
- Use the strain relief clamp on cable.
- Make sure not to cause damage to the mains plug (if applicable) or to the mains cable. Contact the Service or an electrician to change a damaged mains cable.
- The electrical installation must have an isolation device which lets you disconnect the appliance from the mains at all poles. The isolation device must have a contact opening width of minimum 3 mm.
- Use only correct isolation devices: line protecting cut-outs, fuses (screw type fuses removed from the holder), earth leakage trips and contactors.

2.2 Use



WARNING!

Risk of injury, burns or electric shock.

- Use this appliance in a household environment.
- Do not change the specification of this appliance.
- Do not let the appliance stay unattended during operation.
- Do not operate the appliance with wet hands or when it has contact with water.
- Do not put cutlery or saucepan lids on the cooking zones. They can become hot.
- Set the cooking zone to "off" after each use. Do not rely on the pan detector.
- Do not use the appliance as a work surface or as a storage surface.
- If the surface of the appliance is cracked, disconnect immediately the appliance from the power supply. This to prevent an electrical shock.
- Users with a pacemaker must keep a distance of minimum 30 cm from the

induction cooking zones when the appliance is in operation.



WARNING!

Risk of fire or explosion.

- Fats and oil when heated can release flammable vapours. Keep flames or heated objects away from fats and oils when you cook with them.
- The vapours that very hot oil releases can cause spontaneous combustion.
- Used oil, that can contain food remnants, can cause fire at a lower temperature than oil used for the first time.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.



WARNING!

Risk of damage to the appliance.

- Do not keep hot cookware on the control panel.
- Do not let cookware to boil dry.
- Be careful not let objects or cookware fall on the appliance. The surface can be damaged.
- Do not activate the cooking zones with empty cookware or without cookware.
- Do not put aluminium foil on the appliance.
- Cookware made of cast iron, aluminium or with a damaged bottom can cause scratches on the glass ceramic. Always lift these objects up when you have to move them on the cooking surface.

2.3 Care and Cleaning



WARNING!

Risk of damage to the appliance.

- Clean regularly the appliance to prevent the deterioration of the surface material.
- Do not use water spray and steam to clean the appliance.
- Clean the appliance with a moist soft cloth. Only use neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.

2.4 Disposal




WARNING!
Risk of injury or suffocation.

- Contact your municipal authority for information on how to discard the appliance correctly.


- Disconnect the appliance from the mains supply.
- Cut off the mains cable and discard it.

3. PRODUCT DESCRIPTION

3.1 General overview









3.2 Control panel layout




Use the sensor fields to operate the appliance. The displays, indicators and sounds tell which functions operate.


Sensor field	Function
1 Display	To show the functions that operate.
2 Control bar	To set heat settings.







Sensor field	Function
3 	To set the Timer (Automatic Counter , Power-off timer , Minute Minder).
4 	To set a setting.
5 OK	To confirm the setting.
6 	To activate and deactivate the appliance.
7 	To activate and deactivate the Connect Function.
8 	To lock / unlock the control panel.
9 	To activate and deactivate the STOP +GO function.
10 P	To activate the Power Boost function.



3.3 Display

Messages in the display and sounds tell which functions operate.



- A) The cooking zones
- B) Automatic Counter
- C) Power-off timer
- D) Minute Minder
- E) Minute Minder indicator
- F) The Key lock function operates.
- G) The  function operates.

The cooking zone in the display	Description
	The cooking zone operates. Above: heat setting, below: the timer.
	Keep Warm / Stop+Go function operates.
	Power Boost is activated.
	Power Boost operates.
	Zone in adjustment.
	There is no cookware on the cooking zone.

The cooking zone in the display	Description
	The Automatic Heat Up function operates.
	OptiHeat Control. The cooking zone is off. The Dimension and colours show the residual heat : <ul style="list-style-type: none">• Big red - still cooking• Big bright red - keep warm• Small bright red - still hot• Small white - the cooking zone is cold

3.4 Residual heat




WARNING!

After, a cooking session the cooking zone stay hot. The risk of burns!

The induction cooking zones make the heat necessary for cooking directly in the bottom of the cookware. The glass ceramic is hot from the heat of the cookware.


4. DAILY USE

4.1 Activation and deactivation

Touch  for 1 second to activate or deactivate the appliance.




4.2 Automatic Switch Off

The function deactivates the appliance automatically if:

- All cooking zones are deactivated.
- You do not set the heat setting after you activate the appliance.
- You spill something or put something on the control panel for more than 10 seconds, (a pan, a cloth, etc.). The sound operates some time and the appliance deactivates. Remove the object or clean the control panel.
- The appliance gets too hot (e.g. when, a saucepan boils dry). Before you use the hob again, the cooking zone must be cool.
- You use incorrect cookware. The symbol  comes on and the cooking zone deactivates automatically after 2 minutes.
- You do not deactivate a cooking zone or change the heat setting. After some time, the appliance deactivates. See the table.


- The relation between heat setting and times of the Automatic Switch Off function:
 - 1 – 3 – 6 hours
 - 4 – 7 – 5 hours
 - 8 – 9 – 4 hours
 - 10 – 14 – 1.5 hours

4.3 Language selection

To change the language, start the appliance with  and than touch **OK**. Set the language menu with arrows. Touch **OK** to confirm. The display shows the list of languages. Touch  or  to set the language. Touch **OK** to confirm.

4.4 The heat setting

Touch the control bar at the heat setting. Move your finger along the control bar to change the setting. Do not release before you have a correct heat setting.



4.5 Connect Function



Use the Connect Function with the Infinite Plancha accessory¹⁾.

The Connect Function connects two right side cooking zones under the accessory and they operate as one. First set the heat setting for one of the cooking zones.

To activate the Connect Function, touch



. To set or change the heat setting, touch one of the control sensors.

To deactivate the Connect Function, touch . The cooking zones operate independently.


4.6 Automatic Heat Up

You can get a necessary heat setting in a shorter time if you activate the Automatic Heat Up function. This function sets the highest heat setting for some time (see the diagram), and then decreases to the necessary heat setting.

To start the Automatic Heat Up function for a cooking zone:

1. Touch **P** (**P**) comes on in the display).
2. Immediately touch the necessary heat setting. After 3 seconds **A** comes on in the display.

To stop the function change the heat setting.



4.7 Power Boost


Power Boost makes more power available to the induction cooking zones. Power Boost can be activated for a limited period of time (see Technical information chapter). After that, the induction cooking zone automatically sets back to highest heat setting.

To activate the function, touch **P** . **P** in the ring comes on. As the zone gets more hot, the color of the ring changes.

To deactivate, change the heat setting.


4.8 Power management

The power management divides the power between two cooking zones in a pair (see the illustration). Power Boost increases the power to the maximum level for one cooking zone in the pair. The power in the second cooking zone automatically decreases. The heat setting display for the reduced zone changes between two levels.





¹⁾ The Infinite Plancha accessory is not supplied with the appliance. For more information, please contact your local supplier.

4.9 Timer

There are 3 timer functions: Automatic Counter , Power-off timer and Minute Minder . To set the timer function touch  again and again until the indicator of a necessary function comes on.


Automatic Counter

Use this function to monitor how long the cooking zone operates. It starts automatically and comes on below heat setting in the cooking zone on the display.

- **To reset** the Automatic Counter , touch  to get the Automatic Counter  . Then set the cooking zone from the list with arrows and touch **OK** to confirm .


|→| Power-off timer

Use the Power-off timer to set how long the cooking zone operates for only this one time.

Touch  two times to get the Power-off timer . Then set the cooking zone from the list with arrows and touch **OK** to confirm. Set the time with arrows and touch **OK** to confirm. When the time comes to an end , the zone deactivates.



- **To stop the sound:** touch 


Minute Minder


Touch  three times to get the Minute Minder . Set the time with arrows. The Minute Minder indicator comes on. When the time comes to an end, the sound operates.



- **To stop the sound:** touch 


4.10 STOP+GO

The  function sets all cooking zones that operate to the lowest heat setting ().


When  operates, you cannot change the heat setting.

The  function does not stop the timer function.



- **To activate** this function touch  . The symbol  comes on.


- **To deactivate** this function touch  . The heat setting that you set before comes on.

4.11 Lock

When the cooking zones operate, you can lock the control panel, but not  . It prevents an accidental change of the heat setting.

First set the heat setting.

To activate this function touch  . The symbol  comes on. The Timer stays on.



To deactivate this function touch  . The heat setting that you set before comes on.

When you deactivate the appliance, you also deactivate this function.



4.12 The Child Safety Device

This function prevents an accidental operation of the appliance.





To activate The Child Safety Device:

- Touch  for 4 seconds when all zones are off or when the appliance is shutting down. The display shows the message, that The Child Safety Device operates.
- Deactivate the appliance with .

To deactivate The Child Safety Device

- Activate the appliance with .
- Touch  and than **OK**.

To override The Child Safety Device for only one cooking time

- Activate the appliance with  . Touch  and .
- **Set the heat setting in 10 seconds.** You can operate the appliance. When you deactivate the appliance with  , The Child Safety Device operates again.

4.13 Deactivation and activation of the sounds

Activate the appliance. Touch **OK** and then set the sound menu with arrows.

Touch **OK** to confirm . Set the option with the arrows. Touch **OK** to confirm.

When this function operates, you can hear the sounds only when:

- you touch 

- the Minute Minder comes down
- the Power-off timer comes off

5. HELPFUL HINTS AND TIPS



INDUCTION COOKING ZONES

For induction cooking zones a strong electro-magnetic field creates the heat in the cookware very quickly.

5.1 Cookware for induction cooking zones



Use the induction cooking zones with correct cookware.

Cookware material

- **correct:** cast iron, steel, enamelled steel, stainless steel, the bottom made of multi-layer (with correct mark from a manufacturer).
- **not correct:** aluminium, copper, brass, glass, ceramic, porcelain.

Cookware is correct for an induction hob if ...

- ... some water boils very quickly on a zone set to the highest heat setting..
- ... a magnet pulls on to the bottom of the cookware.



The bottom of the cookware must be as thick and flat as possible.

5.2 Use of the cooking zones



IMPORTANT

Put the cookware on the cross which is on the surface that you cook. Cover the cross fully. The magnetic part of the bottom of the cookware must be 125 mm minimum. Induction cooking zones adapt to the dimension of the bottom of the cookware automatically. You can cook with the large cookware on two cooking zones at the same time.

- you put something on the control panel.

5.3 The noises during operation

If you can hear

- crack noise: cookware is made of different materials (Sandwich construction).
- whistle sound: you use one or more cooking zones with high power levels and the cookware is made of different materials (Sandwich construction).
- humming: you use high power levels.
- clicking: electric switching occurs.
- hissing, buzzing: the fan operates.

The noises are normal and do not refer to appliance malfunction.

5.4 Energy saving



How to save energy

- If it is possible, always put the lids on the cookware.
- Put cookware on a cooking zone before you start it.
- Use the residual heat to keep the food warm or to melt it.



The cooking zone efficiency

The cooking zone efficiency is related to the diameter of the cookware. The cookware with a smaller diameter than the minimum receives only a part of the power generated by the cooking zone. For the minimum diameters see the Technical Information chapter.

5.5 Öko Timer (Eco Timer)



To save energy, the heater of the cooking zone deactivates before the count down timer sounds. The difference in the operation time depends on the heat setting level and the length of the cooking operation.

5.6 The Examples of cooking applications


The relation between the heat setting and the cooking zone consumption of power is not linear.

When you increase the heat setting it is not proportional to the increase of the cooking zone consumption of power.

It means that the cooking zone with the medium heat setting uses less than a half of its power.



The data in the table is for guidance only.

Heat setting	Use to:	Time	Hints	Nominal power consumption
 1	Keep warm the food you cooked	as required	Put a lid on a cook-ware	3 %
1 - 3	Hollandaise sauce, melt: butter, chocolate, gelatine	5 - 25 min	Mix from time to time	3 – 8 %
1 - 3	Solidify: fluffy ome-lettes, baked eggs	10 - 40 min	Cook with a lid on	3 – 8 %
3 - 5	Simmer rice and milk-based dishes, heating up ready-cooked meals	25 - 50 min	Add the minimum twice as much liquid as rice, mix milk dishes part procedure through	8 – 13 %
5 - 7	Steam vegetables, fish, meat	20 - 45 min	Add some table-spoons of liquid	13 – 18 %
7 - 9	Steam potatoes	20 - 60 min	Use max. ¼ l water for 750 g of potatoes	18 – 25 %
7 - 9	Cook larger quantities of food, stews and soups	60 - 150 min	Up to 3 l liquid plus ingredients	18 – 25 %
9 - 12	Gentle fry: escalope, veal cordon bleu, cut-lets, rissoles, saus-ages, liver, roux, eggs, pancakes, doughnuts	as necessary	Turn halfway through	25 – 45 %
12 - 13	Heavy fry, hash browns, loin steaks, steaks	5 - 15 min	Turn halfway through	45 – 64 %
14	Boil water, cook pasta, sear meat (goulash, pot roast), deep-fry chips			100 %
P	Boil large quantities of water. Power function is activated.			

6. CARE AND CLEANING

Clean the appliance after each use.
Always use cookware with clean bottom.




Scratches or dark stains on the glass-ceramic cause no effect on how the appliance operates.

To remove the dirt:

- – **Remove immediately:** melted plastic, plastic foil, and food with sugar. If not, the dirt can cause damage to the appliance.
- **Remove after the appliance is sufficiently cool:** limescale rings, water rings, fat stains, shiny metallic discolorations. Use a special cleaning agent for glass ceramic.
- The surface of the hob has horizontal grooves. Clean the appliance with a moist cloth and some detergent with a smooth movement **from left to right**.
- At the end **rub the appliance dry with a clean cloth**.

7. TROUBLESHOOTING

Problem	Possible cause	Remedy
You cannot activate the appliance or operate it.		Activate the appliance again and set the heat setting in less than 10 seconds.
	You touched 2 or more sensor fields at the same time.	Touch only one sensor field.
	The STOP+GO function operates.	Refer to the chapter “Daily Use”.
	There is water or fat stains on the control panel.	Clean the control panel.
An acoustic signal sounds and the appliance deactivates. An acoustic signal sounds when the appliance is deactivated.	You put something on one or more sensor fields.	Remove the object from the sensor fields.
The residual heat indicator does not change colours.	The cooking zone is not hot because it operated only for a short time.	If the cooking zone operated sufficiently long to be hot, speak to the service centre.
The Automatic Heat Up function does not operate.	The cooking zone is hot.	Let the cooking zone become sufficiently cool.
	The highest heat setting is set.	The highest heat setting has the same power as the Automatic Heat Up function.

Problem	Possible cause	Remedy
The heat setting changes between two levels.	The Power management is activated.	Refer to "Power management".
The sensor fields become hot.	The cookware is too large or you put it too near to the controls.	Put large cookware on the rear cooking zones if necessary.
There is no signal when you touch the panel sensor fields.	The signals are deactivated.	Activate the signals (refer to "Deactivation and activation of the sounds").
The backlight is on, but the contrast of the display is bad.	The hot cookware is on the display.	Remove the object and let the appliance become sufficiently cool. If the contrast is not clear, speak to the service centre.
II and text come on.	The Automatic Switch Off operates.	Deactivate the appliance and activate it again.
 comes on.	The Child Safety Device or the Lock function operates.	Refer to the chapter "Daily Use".
? comes on.	No cookware is on the cooking zone.	Put cookware on the cooking zone.
	The cookware is incorrect.	Use the correct cookware.
	The diameter of the bottom of the cookware is too small for the cooking zone.	Use cookware with correct dimensions.
	The cookware does not cover the cross / square.	Cover the cross / square fully.
E and a number come on.	There is an error in the appliance.	Disconnect the appliance from the electrical supply for some time. Disconnect the fuse from the electrical system of the house. Connect it again. If E comes on again, speak to the service centre.

Problem	Possible cause	Remedy
E4 comes on.	There is an error in the appliance because a cookware boils dry. The overheating protection for the cooking zones and the Automatic Switch Off operate.	Deactivate the appliance. Remove the hot cookware. After approximately 30 seconds, activate the cooking zone again. If the cookware was the problem, the error message goes out of the display, but the residual heat indicator can stay. Let the cookware become sufficiently cool and refer to "Cookware for the induction cooking zones" to see if your cookware is compatible with the appliance.

If you tried the above solutions and cannot repair the problem, speak to your dealer or the customer service. Give the data from the rating plate, three digit letter code for the glass ceramic (it is in the corner of the glass surface) and an error message that comes on.

Make sure, you operated the appliance correctly. If not the servicing by a customer service technician or dealer will not be free of charge, also during the warranty period. The instructions about the customer service and conditions of guarantee are in the guarantee booklet.

8. INSTALLATION



WARNING!

Refer to the Safety chapters.



Before the installation

Before the installation of the appliance, record the information below from the rating plate. The rating plate is on the bottom of the appliance casing.

- Model
- PNC
- Serial number

built-in units and work surfaces that align to the standards.









8.2 Connection cable


- The appliance is supplied with the connection cable.
- Replace the damaged mains cable with a special cable (type H05BB-F Tmax 90°C; or higher). Speak to your local Service Centre.

8.1 Built-in appliances

- Only use the built-in appliances after you assemble the appliance into correct

8.3 Assembly





If you use a protection box (an additional accessory¹⁾), the front airflow space of 2 mm and protective floor directly below the appliance are not necessary. You can not use the protection box if you install the appliance above an oven.

- ¹⁾ The protection box accessory may not be available in some countries. Please contact your local supplier.

9. TECHNICAL INFORMATION

Modell EHL8840FOG

Typ 58 GBD C3 AU

Induction 7,4 kW

Ser.Nr.

Electrolux

Prod.Nr. 949 596 051 00

220 - 240 V 50 - 60 Hz

Made in Germany

7,4 kW



Cooking zones power

Cooking zone	Nominal Power (Max heat setting) [W]	Power Function activated [W]	Power function maximum duration [min]	Minimum cookware diameter [mm]
Right rear	2300 W	3200 W	10	125
Right front	2300 W	3200 W	10	125
Left rear	2300 W	3200 W	10	125
Left front	2300 W	3200 W	10	125

The power of the cooking zones can be different in some small range from the da-

ta in the table. It changes with the material and dimensions of the cookware.

10. SAUDI ARABIA - CUSTOMER SERVICE

10.1 Further after-sales service agencies overseas

In these countries our respective agents' own guarantee conditions are applicable. Please obtain further details directly.

Bader Hassan AL-Hussaini Trading Est.

Main service center address:

Al Khalidiya area – Port Street – Building name: Mussa 4
AL Dammam, Kingdom of Saudi Arabia.


Postal address:


P.O Box 4076
AL-Khobar 31952 – Kingdom of Saudi Arabia

National Service center:

tel. 920026800

11. ENVIRONMENT CONCERNS

Recycle the materials with the symbol . Put the packaging in applicable containers to recycle it. Help protect the environment and human health and to recycle waste of electrical

and electronic appliances. Do not dispose appliances marked with the symbol  with the household waste. Return the product to your local recycling facility or contact your municipal office.

www.electrolux.com/shop



892958199-A-012013