



CPB902

**3.5" Highly Integrated
Low Power SBC**

User Manual

Rev. 1.4a E

November 2005

Product Title: CPB902
Document name: CPB902 User Manual
Manual version: 1.4a E

Copyright © 2005 Fastwel Co. Ltd. All rights reserved.

Revision History

Rev. Index	Brief Description of Changes	Board Index	Date of Issue
1.4 beta	Initial version	CPB902	November 2005
1.4a	Errors corrections, design and styling changes, figures and tables modification	CPB902	November 2005

Contact Information

Fastwel Co. Ltd.

Address: 108 Profsoyuznaya st., Moscow 117437, Russian Federation

Tel.: +7 (095) 234-0639

Fax: +7 (095) 232-1654

E-mail: info@fastwel.com

For more details, please visit our Web-site:

<http://www.fastwel.com/>

Table of Contents

Table of Contents.....	0-1
List of Tables.....	0-3
List of Figures	0-4
Notation Conventions.....	0-5
General Safety Precautions	0-6
Unpacking, Inspection and Handling.....	0-7
Three Year Warranty	0-9
1 Introduction.....	1-1
1.1 Module Introduction	1-1
1.2 CPB902 Versions	1-2
1.3 Delivery Checklist	1-2
1.4 Additional Accessories.....	1-2
1.5 Supplementary Information.....	1-3
1.5.1 Related Publications	1-3
2 Technical Specifications	2-1
2.1 General.....	2-1
2.2 Power Requirements	2-2
2.3 Environmental.....	2-2
2.4 Mechanical	2-2
2.5 Dimensions and Weight.....	2-3
2.6 MTBF	2-3
3 External Connections	3-1
3.1 Safety Regulations.....	3-1
3.2 Connection of Peripheral Devices.....	3-2
3.2.1 CompactFlash Cards Installation	3-4
3.2.2 USB Devices Connection.....	3-4
3.2.3 Battery Replacement	3-5
3.3 Software Installation	3-5
4 Functional Description	4-1
4.1 Structure and Layout	4-1
4.2 Address Mapping.....	4-4
4.2.1 Memory Addressing	4-4
4.2.2 I/O Addressing	4-4
4.2.3 Interrupt settings	4-12
4.2.4 DMA channels	4-14
4.3 Functional Description	4-15
4.3.1 Microprocessor	4-15
4.3.2 SDRAM Memory.....	4-15
4.3.3 Reserved Flash BIOS	4-15
4.3.4 UIDE/Compact Flash Interface	4-15
4.3.5 CompactFlash Socket.....	4-16
4.3.6 NAND Flash.....	4-17
4.3.7 Video Controller and VGA/TFT Adapter Module.....	4-17
4.3.7.1 Video Controller Operation Modes and Connection of Monitors	4-17

4.3.7.2	Sharp LQ104V1DG51 TFT Panel Connection	4-21
4.3.7.3	CVM01 Expansion Module	4-22
4.3.8	Keyboard and Mouse Interface	4-23
4.3.9	USB Interface	4-23
4.3.10	Fast Ethernet Interface	4-24
4.3.11	Serial Ports	4-24
4.3.12	FDD/LPT Port	4-27
4.3.13	LCD and Matrix Keyboard Port	4-29
4.3.13.1	LCD Connection.....	4-29
4.3.13.2	Matrix Keypad Connection	4-31
4.3.13.3	Using Keyboard Interface by the Discrete I/O Unit.....	4-32
4.3.14	Optoisolated Reset/Interrupt	4-34
4.3.15	FBUS Connector.....	4-35
4.3.16	RTC and Serial FRAM	4-35
4.3.17	J19 Configuration Jumpers	4-36
4.3.18	PC/104 Header	4-36
4.3.19	Diagnostic LEDs	4-39
4.3.20	Power Supply Connector	4-39
4.4	Overall and Mounting Dimensions	4-40
4.4.1	Mounting on a Panel	4-41
5	General Software® BIOS	5-1
5.1	BIOS Setup Program. Introduction	5-1
5.2	Main Menu	5-1
5.3	Basic CMOS configuration.....	5-3
5.4	Custom Configuration	5-5
5.5	PnP Configuration.....	5-7
5.6	Shadow Configuration	5-8
5.7	Manufacturing Link Mode	5-9
5.8	The Rest Main Menu Commands	5-10
5.8.1	Reset CMOS to last known values	5-10
5.8.2	Reset CMOS to Factory Defaults.....	5-10
5.8.3	Write to CMOS and Exit.....	5-10
5.8.4	Exit without changing CMOS	5-10
5.9	Reset CMOS to Factory Defaults from a Remote PC	5-11
5.10	Extended BIOS Functions	5-11
5.10.1	User Programs Interface with FRAM memory units	5-11
5.10.2	User LEDs Control	5-12
5.10.3	SuperIO FDC37B787 Watchdog Timer Operation	5-13
5.10.4	ADM8697 Supervisor's Watchdog Timer Operation	5-14
5.10.5	Using INT 17H BIOS Extension to Control the Watchdog Timers.....	5-15
A	Jumper Settings by Function.....	A-1
B	Jumper Settings by Assignment	B-1

List of Tables

Table 1.1:	CPB902 Versions.....	1-2
Table 1.2:	CPB902 Supplied Set	1-2
Table 1.3:	CPB902 Additional Accessories.....	1-2
Table 1.4:	Related Publications	1-3
Table 4.1:	Memory Address Mapping	4-4
Table 4.2:	I/O Address Space	4-4
Table 4.3:	System I/O ports (FPGA)	4-6
Table 4.4:	Interrupt Settings.....	4-13
Table 4.5:	DMA Request Map.....	4-14
Table 4.6:	J1 HDD Connector Pinout.....	4-15
Table 4.7:	J2 Compact Flash Socket Pinout.....	4-16
Table 4.8:	S1 Settings: Display Type and Video Mode Selection	4-17
Table 4.9:	Different Types of TFT/STN Panels Connection	4-18
Table 4.10:	TFT/STN Panels Connector J16 Pinout	4-19
Table 4.11:	P7 D-Sub VGA Connector Pinout	4-19
Table 4.12:	CVM02 J2 Pin Assignments.....	4-22
Table 4.13:	CVM01 J5 Connector Pinout.....	4-23
Table 4.14:	PS/2 Keyboard/Mouse Connector P5 Pinout	4-23
Table 4.15:	Serial Ports Pin Assignments.....	4-25
Table 4.16:	LPT/FDD J15 Connector Pinout.....	4-28
Table 4.17:	J18 DIP-Switch Pinout	4-31
Table 4.18:	J17 Connector Pinout.....	4-34
Table 4.19:	J13 Settings: Switching Reset/IRQ Source	4-35
Table 4.20:	RJ45 FBUS Connector P6 Pinout	4-35
Table 4.21:	J19 Pins Designation	4-36
Table 4.22:	PC/104 P4 (Rows A and B) Contacts Designation.....	4-37
Table 4.23:	PC/104 P4 (Rows C and D) Contacts Designation	4-38
Table 4.24:	CPB902 Diagnostic LEDs Function	4-39
Table 4.25:	J20 Power Connector Pinout	4-39
Table 5.1:	Main Menu Items	5-2
Table 5.2:	Basic CMOS Configuration Menu Items.....	5-3
Table 5.3:	Custom Configuration Menu Items.....	5-5
Table A.1:	Jumper Settings by Function.....	A-1
Table B.1:	Jumper Settings by Assignment.....	B-1

List of Figures

Figure 1.1:	CPB902 Module Appearance.....	1-1
Figure 3.1:	External Devices Connection	3-2
Figure 3.2:	Cables 3 and 4 (Fig. 3.1) Connection for Console Operation.....	3-4
Figure 4.1:	CPB902 Functional Block Diagram	4-1
Figure 4.2:	Top Side: Connectors and Main Components Layout.....	4-3
Figure 4.3:	Bottom Side: Connectors and Main Components Layout.....	4-3
Figure 4.4:	Interrupt Source Multiplexing Diagram	4-12
Figure 4.5:	DMA Request Channels Multiplexing Diagram	4-14
Figure 4.6:	Connection of 16-bit DSTN Panel	4-20
Figure 4.7:	Connection of 24-bit DSTN Panel	4-20
Figure 4.8:	Connection of a TFT Panel with 1 Pixel per FPSCLK Period	4-21
Figure 4.9:	Connection of a TFT Panel with 2 Pixels per FPSCLK Period	4-21
Figure 4.10:	SHARP LQ104V1DG51 TFT Panel Connection and Setup	4-21
Figure 4.11:	CVM01 Expansion Module.....	4-22
Figure 4.12:	IDC10 Pins Numbering	4-24
Figure 4.13:	COM3 – COM6 Ports Jumpers	4-25
Figure 4.14:	Point-to-Point Connection of Two Modules in RS-422 Mode	4-26
Figure 4.15:	Connection of Several Devices in RS-485 Mode	4-26
Figure 4.16:	COM3-COM6 Ports: Simplified Interface Circuit Diagram.....	4-27
Figure 4.17:	POWERTIP PC1604-A Alphanumeric LCD Connection Diagram	4-30
Figure 4.18:	POWERTIP PG12864-A Graphics LCD Connection Diagram	4-30
Figure 4.19:	J18 Pinpad Connection Circuit Diagram	4-31
Figure 4.20:	Discrete I/O Channel Block Diagram.....	4-33
Figure 4.21:	Discrete I/O Unit: Ports Binding Diagram.....	4-33
Figure 4.22:	Reset Source Selection and Optoisolated Input Circuit Diagram	4-34
Figure 4.23:	J19 Circuit Diagram.....	4-36
Figure 4.24:	PC/104 P4 Contacts Layout.....	4-36
Figure 4.25:	CPB902 Top Side: Overall and Mounting Dimensions.....	4-40
Figure 4.26:	CPB902 Bottom Side: Overall and Mounting Dimensions.....	4-40
Figure 5.1:	Main Menu Screen Image	5-2
Figure 5.2:	Basic CMOS Configuration Screen Image	5-3
Figure 5.3:	Custom Configuration Menu Screen	5-5
Figure 5.4:	Plug-n-Play Configuration Menu Screen Image	5-7
Figure 5.5:	Shadow Configuration Menu Screen Image.....	5-8

All information in this document is provided for reference only, with no warranty of its suitability for any particular purpose. This information has been thoroughly checked and is believed to be entirely reliable and consistent with the product that it describes. However, Fastwel accepts no responsibility for inaccuracies, omissions or the their consequences, as well as liability arising from the use or application of any product or example described in this document.

Fastwel Co. Ltd. reserves the right to change, modify, and improve this document or the products described in it, at Fastwel's discretion without further notice. Software described in this document is provided on an "as is" basis without warranty. Fastwel assumes no liability for consequential or incidental damages originated by the use of this software.

This document contains information, which is property of Fastwel Co. Ltd. It may not be copied, reproduced, or transmitted by any means, stored in any information retrieval system, translated or converted to any electronic or machine-readable form in full or in parts without antecedent written approval of Fastwel Co. Ltd. or one of its officially authorized agents.

Fastwel and Fastwel logo are trademarks owned by Fastwel Co. Ltd., Moscow, Russian Federation. CompactPCI is a trademark of the PCI industrial Computers Manufacturers Group. Ethernet is a registered trademark of Xerox Corporation. IEEE is a registered trademark of the Institute of Electrical and Electronics Engineers Inc. Intel is a trademark of Intel Corporation. Pentium M and Celeron M are trademarks of Intel Corporation. Microsoft is a trademark of the Microsoft corporation. In addition, this document may include names, company logos and trademarks, which are registered trademarks and, therefore, are property of their respective owners.

Fastwel welcomes suggestions, remarks and proposals regarding the form and the content of this Manual.

Notation Conventions

**Caution: Electric Shock!**

This symbol and title warn of hazards due to electrical shocks (> 60 V) when touching products or parts of them. Failure to observe the precautions indicated and/or prescribed by the law may endanger your life/health and/or result in damage to your product.

**Warning, ESD Sensitive Device!**

This symbol and title inform that electronic modules and their components are sensitive to static electricity. Therefore, care must be taken during all handling operations and inspections of this product, in order to ensure product safety.

**Warning!**

The surface of the heatsink and some components can get very hot during operation. Take due care when handling, avoid touching hot surfaces!

**Warning!**

This symbol and title emphasize points, which, if not fully understood and taken into consideration by the reader, may endanger your health and/or result in damage to your product.

**Note...**

This symbol and title emphasize aspects the reader should read through carefully for his or her own advantage.

General Safety Precautions

Fastwel has developed and carefully tested this product to provide all features necessary to ensure its conformance to electrical safety requirements. It was also designed for a long fault-free life. However, the expected life time of your product can be considerably reduced by improper handling during unpacking, installation and operation. Therefore, for the sake of your own safety and of the correct operation of this product, you are requested to conform to the following rules.



Warning!

All operations on this device must be carried out by sufficiently skilled personnel only.



Warning!

When handling this product, special care must be taken not to hit the heatsink (if installed) against another rigid object. Also, be careful not to drop the product, since this may cause damage to the heatsink, CPU or other sensitive components as well.

Please, keep in mind that any physical damage to this product is not covered under warranty.



Note:

This product is guaranteed to operate within the published temperature ranges and relevant conditions. However, prolonged operation near the maximum temperature is not recommended by Fastwel or by electronic chip manufacturers due to thermal stress related failure mechanisms. These mechanisms are common to all silicon devices, they can reduce the MTBF of the product by increasing the failure probability. Prolonged operation at the lower limits of the temperature ranges has no limitations.



Caution, Electric Shock!

Before installing your Fastwel product into a system always ensure that your mains power is switched off. This applies also to the installation of other devices on the module.

Serious electrical shock hazards can exist during all installation, repair and maintenance operations with this product. Therefore, always unplug the power cable and any other cables, which provide external voltages before handling the product.

Unpacking, Inspection and Handling

Please read the manual carefully before unpacking the module or mounting the device into your system. Keep in mind the following:



ESD Sensitive Device!

Electronic modules and their components are sensitive to static electricity. Even a non-perceptible by human being static discharge can be sufficient to destroy or degrade a component's operation! Therefore, all handling operations and inspections of this product must be performed with due care, in order to keep product integrity and operability:

- Preferably, unpack or pack this product only at EOS/ESD safe workbenches. Otherwise, it is important to be electrically discharged before touching the product. This can be done by touching a metal part of your system case. It is particularly important to observe anti-static precautions when setting jumpers or replacing components.
- If the product contains batteries for RTC or memory back-up, ensure that the board is not placed on conductive surfaces, including anti-static mats or sponges. They can cause short circuits and damage the batteries or conductive circuits of the product.
- Store this product in its protective packaging while it is not used for operational purposes.

Unpacking

The product is carefully packed in an antistatic bag and in a carton box to protect it against possible damage and harmful influence during shipping. Unpack the product indoors only at a temperature not less than +15°C and relative humidity not more than 70%. Please note, that if the product was exposed to the temperatures below 0°C for a long time, it is necessary to keep it at normal conditions for at least 24 hours before unpacking. Do not keep the product close to a heat source.

Following ESD precautions, carefully take the product out of the shipping carton box. Proper handling of the product is critical to ensure correct operation and long-term reliability. When unpacking the product, and whenever handling it thereafter, be sure to hold the board preferably by the front panel, card edges or the ejector handles. Avoid touching the components and connectors.

Keep all original packaging material for future storage or warranty shipments of the product.

Initial Inspection

Although the product is carefully packaged, it is still possible that shipping damages may occur. Careful inspection of the shipping carton can reveal evidence of damage or rough handling. Should you notice that the package is damaged, please notify the shipping service and the manufacturer as soon as possible.

After unpacking the product, you should inspect it for visible damage that could have occurred during shipping or unpacking. If damage is observed (usually in the form of bent component leads or loose socketed components), contact Fastwel's official distributor from which you have purchased the product for additional instructions. Depending on the severity of the damage, the product may need to be returned to the factory for repair. DO NOT apply power to the product if it has visible damage. Doing so may cause further, possibly irreparable damage, as well as result in a fire or electric shock hazard.

If the product contains socketed components, they should be inspected to make sure they are seated fully in their sockets.

Handling

In performing all necessary installation and application operations, please follow only the instructions supplied by the present manual.

In order to maintain Fastwel's product warranty, this product must not be altered or modified in any way. Changes or modifications to the device, which are not explicitly approved by Fastwel Co. Ltd. and described in this manual or received from Fastwel's Technical Support Service as a special handling instruction, will void your warranty.

This device should only be installed in or connected to systems that fulfill all necessary technical and specific environmental requirements. This applies also to the operational temperature range of the specific module version, which must not be exceeded. If batteries and storage devices are present, their temperature restrictions must be taken into account.

Keep all the original packaging material for future storage or warranty shipments. If it is necessary to store or ship the board, please re-pack it as nearly as possible in the manner in which it was delivered.

When handling the product, please, remember that the board, its components and connectors require delicate care.

Three Year Warranty

Fastwel Co. Ltd. (Fastwel), warrants that its standard hardware products will be free from defects in materials and workmanship under normal use and service for the currently established warranty period. Fastwel's only responsibility under this warranty is, at its option, to replace or repair any defective component part of such products free of charge.

Fastwel neither assumes nor authorizes any other liability in connection with the sale, installation or use of its products. Fastwel shall have no liability for direct or consequential damages of any kind arising out of sale, delay in delivery, installation, or use of its products.

If a product should fail through Fastwel's fault during the warranty period, it will be repaired free of charge. For out of warranty repairs, the customer will be invoiced for repair charges at current standard labor and materials rates.

Warranty period for Fastwel products is 36 months since the date of purchase.

The warranty set forth above does not extend to and shall not apply to:

1. Products, including software, which have been repaired or altered by other than Fastwel personnel, unless Buyer has properly altered or repaired the products in accordance with procedures previously approved in writing by Fastwel.
2. Products, which have been subject to power, supply reversal, misuse, neglect, accident, or improper installation.

Returning a product for repair

1. Apply to Fastwel company or to any of the Fastwel's official representatives for the Product Return Authorization.
2. Attach a failure inspection report with a product to be returned in the form, accepted by customer, with a description of the failure circumstances and symptoms.
3. Carefully package the product in the antistatic bag, in which the product had been supplied. Failure to package in antistatic material will VOID all warranties. Then package the product in a safe container for shipping.
4. The customer pays for shipping the product to Fastwel or to an official Fastwel representative or dealer.

1 Introduction

This document presents general information on CPB902 processor module, the details of its proper and safe installation, configuration and operation. The issues of PC/104 modules and external devices connection are also considered.

1.1 Module Introduction

CPB902 processor module is a 3.5" highly integrated single board computer with full PC functionality. It is designed for applications where high-performance and low power consumption are required. CPB902 incorporates numerous I/O ports and interfaces: serial ports; IDE interface; CompactFlash socket; printer/FDD connector; digital I/O port combined with LCD monitor/matrix keypad interface; two USB ports; PS/2 mouse/keyboard connector; video port; two Fast Ethernet ports and PC/104 interface.

The module is supplied with installed FDOS 6.22 operating system and is compatible with Windows 2000, Windows CE5, Linux, QNX6.x, RTOS32 и MSDOS operating systems.

Figure 1.1: CPB902 Module Appearance



The appearance may vary for different versions of the module.

1.2 CPB902 Versions

Table 1.1: CPB902 Versions

Version	Decimal ID	SDRAM Size	SVGA
CPB90201	467444.001	128 MB	+
CPB90202	467444.002	32 MB	–

1.3 Delivery Checklist

Table 1.2: CPB902 Supplied Set

Code	Description	Note
CPB90201 or CPB90202	Processor module (467444.001 or 467444.002)	–
ACS0006	FCD-9F (685611.012-02) adapter cable DB9-IDC10 for connection to COM1	–
ACS00010	FC44 (685611.051) cable for connection of a 2.5" HDD to 44-pin onboard header	–
CDM02	Adapter module for connection of 3.5" HDD or CD-ROM drive (469535.023).	–
–	Y-cable for simultaneous connection of PS/2 keyboard and mouse (1700060202)	Is not supplied with CPB90202 version
–	CD ROM with documentation and service software	
	Antistatic bag and consumer carton box	



Note:

Keep the antistatic bag and the original package at least until the warranty period is over. It can be used for future storage or warranty shipments.

1.4 Additional Accessories

Peripheral devices are attached to the module directly or via additional accessories and cables listed in the following table.

Table 1.3: CPB902 Additional Accessories

Code	Description
ACS00011	FCD25F LPT connection cable, IDC26 – DB25
ACS0002	FC26-60 FDD connection cable, IDC26 – IDC26
CDM01	FDD connection adapter (469535.030)
CVM01	VGA monitor or TFT/STN panel adapter module (469535.024)
CVM02	Sharp LQ104V1DG51 LCD panel connection module (469535.031)
ACS00022	Cable for connection of CVM02 to CPB90201 (685611.050)
CC902	CPB902 mounting cage (301152.011)

Additional accessories are not supplied with the processor module, ordered separately.

1.5 Supplementary Information

1.5.1 Related Publications

The following publications contain information relating to this product.

Table 1.4: Related Publications

Product	Publication
CompactFlash Cards	CF+ and CompactFlash Specification Revision 1.4
Processor	STPC Vega Programming manual
Graphics controller	LynxEM+ DataBook
Super I/O	SuperIO FDC37B787 Data sheet

2 Technical Specifications

2.1 General

- CPU: STPC Vega 200 MHz
 - 32-bit x86 PII core
 - 64-bit coprocessor
 - 64-bit memory bus
- System memory
 - SDRAM 32/128 MB
- Flash BIOS
 - 256 KB, reserved
 - In-system modification
- Solid State Disk
 - 16/32 MB with Fastwel file system
- Storage:
 - Compact Flash Type I/II socket on board (bottom side)
 - Support for two UltraATA/66 IDE devices
- Serial ports
 - Six serial ports
 - High speed NS16C550 compatible
 - COM1: RS232, 3 wires (null-modem), up to 115 Kb/s
 - COM2: RS232, complete, up to 115 Kb/s
 - COM3-COM6: RS232/422/485, up to 921.6 Kb/s, FIFO buffer for each channel – 64 bytes
- USB
 - Two USB 1.1 channels
- Ethernet
 - Two Fast Ethernet ports 10/100 Mb/s
- VGA controller
 - Video memory 4 MB
 - LCD (TFT or DSTN) panels support, resolution up to 1024×768
 - Analog display support
 - DualApp and DualView modes support
- Watchdog timers
 - Two Watchdog timers with LED indication
- Safety
 - System configuration settings stored in CMOS+SFRAM
 - Saving essential user data in SFRAM in case of power failure

- RTC
 - On-board real time clock with Li battery
- PS/2
 - PS/2 keyboard and mouse interface
- FDD
 - Floppy disk interface
- Parallel port
 - SPP/ECP/EPP compatible. Header, shared with FDD controller
- LCD Display and Matrix keyboard ports
- Connector for devices with FBUS interface
- Optoisolated Reset/IRQ input
- PC/104 Expansion Header
- Software Support:
 - General Software® BIOS
 - DOS, QNX® 6.3x, RTOS32, Windows CE4, Windows XPe, Linux®, Windows 2000

2.2 Power Requirements

The module is powered by an external DC power source providing the following characteristics:

- Voltage: +5 V (from +4.75 V to +5.25 V)
- Consumption current (without external devices):
 - CPB90201 – 1.3 A
 - CPB90202 – 1.2 A



Important:

+12 V voltage is not used by the module.

+12 V line from power supply connector is routed to the PC/104 header contact.

2.3 Environmental

- Operating temperature range from: -40°C to +85°C
- Storage temperature: -55°C to +90°C
- Relative humidity: 5% to 95% at 25°C, noncondensing

2.4 Mechanical

- Vibration – 5g;
- Single shock, peak acceleration – 100 g;
- Multiple shock, peak acceleration – 50 g.

2.5 Dimensions and Weight

- Dimensions, not more: 107 × 147 × 26 mm (4.21" × 5.79" × 1.02")
(see also [section 4.4](#))
- Weight, not more: 0.22 kg

2.6 MTBF

- MTBF for CPB902 is 120000 hours.
*The value is calculated according to: Telcordia Issue 1, Method I Case 3,
for continuous operation at ambient temperature 30°C.*

3 External Connections

The following precautions must be observed to ensure proper installation and to avoid damage to the module, other system components, or harm to personnel.

3.1 Safety Regulations

The following safety regulations must be observed when installing or operating the module. Fastwel assumes no responsibility for any damage resulting from infringement of these rules.



Warning!

When handling or operating the module, special attention should be paid to the heatsink, because it can get very hot. Do not touch the heatsink when installing or removing the module.

In addition, the module should not be placed on any surface or in any kind of storage container until the module and its heatsink have cooled down to room temperature.



ESD Sensitive Equipment!


This product contains electrostatically sensitive components. Please observe the necessary precautions to avoid damage to the module:

- Discharge your clothing before touching the assembly. Tools must also be discharged before use.
- Do not touch components, contacts or traces.
- If working at an anti-static workbench with professional discharging equipment, please do not omit to use it.

Extra caution should be taken in cold and dry weather.

3.2 Connection of Peripheral Devices

Figure 3.1: External Devices Connection



Please, find notes on callouts on the next page.

Callouts of the Figure 3.1:

1. CDM02 adapter for CD-ROM connection
2. ASC00010 FCC44 cable
3. Null-modem cable with DB9 connectors
4. IDC10-DB9 adapter cable
5. PS/2 Y-cable

The following standard equipment can be connected to the module (Figure 3.1):

CD-ROM drive
HDD
SVGA monitor
Personal computer
Power supply

The following devices are necessary to put the module into operation:


- Power supply unit with +5 V and 1 to 1.5 A output is connected to J20 power connector. If the module is intended for operation with PC/104 modules requiring +12 V power supply, then this supply should be connected to the appropriate J20 contact. For checkout and adjustment purposes the AT or ATX power supply units are recommended;
- Y-cable allowing to connect a mouse and a keyboard to the module's J5 connector. It is enough to connect only a keyboard directly to J5 connector for CPB90202 version of the module;
- The following devices may be connected to the module to serve as a display unit:
 - Monitor of a remote PC (console operation) connected via a null-modem cable and FCD9F adapter to J4 connector;
 - SVGA monitor directly attached to P7 connector.

The operating system is loaded from the on-board NAND Flash memory. The operating system on this flash-disk is FDOS supplemented with utilities.

Before starting to work with CPB902 it is necessary to close the 1-2 jumper of J19 switch to enable the battery of the RTC for both versions of the module. See [subsection 4.3.17](#) for details.

For CPB90201 version (with graphics controller) a console (remote PC) connected via a null-modem cable to J4 and/or VGA monitor connected to P7 can be used as a display unit. A keyboard and a mouse are connected via a Y-cable to J5.

For CPB90202 version (without graphics controller) a remote PC (console operation) connected via a null-modem cable and FCD9F adapter to J4 connector can be used as a display unit. Figure 3.2 illustrates the cables connection. PS/2 keyboard is connected directly to J5 connector, Y-cable is not supplied with this version of the module.

Figure 3.2: Cables 3 and 4 (Fig. 3.1) Connection for Console Operation

The Hyperterminal program running on the PC to support console operation should have the following settings:

Transfer rate – 115200 bit/s
 Data bits – 8
 Stop bits – 1
 Parity check – Off

3.2.1 CompactFlash Cards Installation

CompactFlash socket of CPB902 supports any 3.3 V or 5 V CompactFlash ATA type I/II cards. Carefully slide in the correctly oriented card and gently press to engage the contacts completely. To disengage the card, use the ejector button.



Note:

Connection of the CompactFlash cards while the power is on may damage your system.

3.2.2 USB Devices Connection

The CPB902 supports all USB 1.1 Plug&Play computer peripherals (e.g. keyboard, mouse, printer, etc.)



Note

All USB devices may be connected or disconnected while the host or other peripherals are powered up.

3.2.3 Battery Replacement

The lithium battery must be replaced with an identical battery or a battery with similar characteristics. Suitable batteries include the Panasonic BR2032 and compatible models.

The typical life expectancy of a 190 mAh battery (Panasonic BR2032) is about 5 - 6 years with an average on time of 8 hours per working day at an operating temperature of 30°C. However, this typical value may vary because battery lifetime depends on the operating temperature and the standby time (shutdown time) of the system in which the battery is installed.

**Note...**

It is recommended to exchange the battery after 4 - 5 years to guarantee its operability.

**Note:**

The polarity must be observed when the battery is replaced.

The battery should be replaced only with an identical or equivalent type recommended by the manufacturer.

Dispose of used batteries according to the manufacturer's instructions and local regulations.

3.3 Software Installation

The installation of the on-board peripheral drivers is described in detail in the relevant Driver Kit files.


Installation of an operating system is a function of the OS software and is not addressed in this manual. Refer to appropriate OS software documentation for installation instructions.

4 Functional Description

4.1 Structure and Layout

Functional block diagram of the CPB902 module is shown in Figure 4.1.

Figure 4.1: CPB902 Functional Block Diagram



- Serial ports:
 - COM2: RS232, 9 wires (complete), maximum exchange rate – 115.2 Kbit/s;
 - COM1: RS232, 3 wires (null-modem), for console I/O and file exchange, maximum exchange rate – 115.2 Kbit/s;
 - COM3 – COM6: RS232/RS422/RS485, maximum exchange rate 921.6 Kbit/s;
- Two Fast Ethernet channels 10/100 Mbit/s;
- Two USB 1.1 channels;
- Two watchdog timers;
- CMOS+SFRAM for BIOS configuration storage;
- Real time clock with Li battery;
- PS/2 keyboard/mouse port;
- FDD/LPT shared header. Universal parallel port supports EPP and ECP modes;
- LCD/matrix keypad ports;
- FBUS port;
- Graphics controller:
 - Video memory 4 MB;
 - LCD (TFT or DSTN) panels support, resolution up to 1024×768;
 - Analog RGB display support;
 - DualApp and DualView modes support (under Windows 95/98/NT only)
- Optoisolated Reset/IRQ input

The layout of main CPB902 components and connectors on top and bottom sides is presented in Figures 4.2 and 4.3 respectively.

Figure 4.2: Top Side: Connectors and Main Components Layout





Figure 4.3: Bottom Side: Connectors and Main Components Layout



4.2 Address Mapping

4.2.1 Memory Addressing

Table 4.1: Memory Address Mapping

Address Range	Size	Description
00000H – 09FFFH	640 K5	System memory
A0000H – BFFFFH	128 K5	Video memory
C0000H – C7FFFH	32 K5	Display BIOS memory
C8000H – EFFFFH	160 K5	BIOS extensions 16K blocks can be copied into system memory. See section 5.6 for details.
F0000H – FFFFFH	64 K5	System BIOS area
10000H – 4FFFFFFH	127 M5	Extended system memory
FE0000 – FFFFFFFF	128 K5	System BIOS area

4.2.2 I/O Addressing

Table 4.2: I/O Address Space

Address Range	Function
000h – 0A7h	System I/O ports
0A8h – 0AFh	System I/O ports
0B0h – 0FFh	System I/O ports
100h – 107h	COM3 (default)
108h – 10Fh	COM4 (default)
110h – 117h	COM5 (default)
118h – 11Fh	COM6 (default)
120h – 141h	Reserved
142h	COM3-COM6 ID register (default)
143h – 2F7h	Reserved (alternative address space for COM3-COM6 and LPT1)
2F8h – 2FFh	COM2
300h – 31Fh	System and user I/O ports (FPGA)
370h – 377h	System I/O ports (SIO)
378h – 37Bh	LPT1 (default range; 278h address is allowed, unless allocated for COM3-COM6)
3F0h – 3F7h	FDD controller
3F8h – 3FFh	COM1
CF8h – CFFh	Host PCI controller configuration registers

Base addresses of COM3-COM6 ports can be changed by bits 5, 6 of COM_ID identification register, the ID register address itself changes along with it.

By default, the LPT port is set to ECP mode and has base address 378h.

System I/O ports allocated in 000h–0FFh range have standard IBM PC addressing. Non-standard ports within 300h–31Fh range are used for module resource management. FPGA ports description is presented in the table below.

**Attention!**

These ports description is intended for use by system programmers.

Application programs should not address these ports!

Table 4.3: System I/O ports (FPGA)

Port (hex)	Bit	Read	Write	Value	Comment
300	0	yes	yes	0	NAND flash: read/write data, write address, write commands
				1	
	1	yes	yes	0	
				1	
	2	yes	yes	0	
				1	
	3	yes	yes	0	
				1	
301	4	yes	yes	0	NAND flash: read/write data, write address, write commands
				1	
	5	yes	yes	0	
				1	
	6	yes	yes	0	
				1	
	7	yes	yes	0	
				1	
301	0	yes	no	0	—
	1	yes	no	0	
	2	yes	no	0	
				1	
	3	yes	yes	0	
				1	
	4	yes	yes	0	
				1	
310*	5	yes	no	0	Reserved. Permanent logic "0"
	6	yes	yes	0	
				1	
	7	yes	yes	0	
				1	
	0	yes	yes	0	/PDOWN_VIDEO line status set/read
				1	
	1	yes	no	0	WDT_READ line status: read
				1	
	2	yes	yes	0	WDT_RES line status: set/read
				1	
	3	yes	no	0	/SV_PFO line status: read
				1	
	4	yes	yes	0	/PC104_MEMW line mask bit status: set/read (1 – Set mask, 0 – Clear mask)
				1	
	5	yes	yes	0	/SV_PFO line mask bit status: set/read (1 – Set mask, 0 – Clear mask)
				1	
	6	yes	yes	0	KEY_R[5...0] and KEY_C[5...0] lines switching between matrix keypad and discrete I/O units. 0 – Matrix keypad unit connected to KEY_R[5...0] and KEY_C[5...0] lines 1 – Discrete I/O unit connected to KEY_R[5...0] and KEY_C[5...0] lines
				1	
	7	yes	no	0	—

Port (hex)	Bit	Read	Write	Value	Comment
311*	0	yes	yes	0	Switching DMA acknowledgement (DACENC=2) to /FDC_DACK2 line
				1	Switching DMA acknowledgement (DACENC=2) to /PC104_DACK2 line
	1	yes	yes	0	Switching DMA acknowledgement (DACENC=3) to /FBUS_DACK1 line
				1	Switching DMA acknowledgement (DACENC=3) to /PC104_DACK3 line
	2	yes	yes	0	Switching DMA acknowledgement (DACENC=5) to /FBUS_DACK2 line
				1	Switching DMA acknowledgement (DACENC=5) to /PC104_DACK5 line
	3	yes	yes	0	DMA request (DRQ2) received via FDC_DRQ2 line
				1	DMA request (DRQ2) received via PC104_DRQ2 line
	4	yes	yes	0	DMA request (DRQ3) received via FBUS_DRQ1 line
				1	DMA request (DRQ3) received via PC104_DRQ3 line
312* (read)	5	yes	yes	0	DMA request (DRQ5) received via FBUS_DRQ2 line
				1	DMA request (DRQ5) received via PC104_DRQ5 line
	6	no	no	–	–
				–	–
	7	no	no	–	–
				–	–
	0	yes	–	0	FBUS unit: FAULT line status (1 – "Data Unreliable" error)
				1	
	1	yes		0	FBUS unit: FERR line status (1 – "Frame Error")
				1	
	2	yes		0	FBUS unit: T_ERR line status (1 – "Timeout" error)
				1	
	3	yes		0	FBUS unit: TXMODE line status (1 – FBUS unit in data transmission mode)
				1	
	4	yes		0	FBUS unit: RXMODE line status (1 – FBUS unit in data reception mode)
				1	
312* (write)	5	yes		0	FBUS unit: CHECKMODE line status (1 – FBUS unit in data validity check mode)
				1	
	6	yes		0	FBUS unit: OVR line status (1 – FBUS "Input Buffer Overflow" error)
				1	
	7	yes		0	FBUS unit: HISPEED line status
				1	
	0	–	yes	0	FBUS unit: Set DAISY line status to 0
				1	FBUS unit: Set DAISY line status to 1
	1		no	–	–
				–	–
	2		no	–	–
				–	–
	3		yes	0	FBUS unit: Clear Reset
				1	FBUS unit: Set Reset
313* (write)	4		no	–	–
				–	–
	5		no	–	–
				–	–
	6		no	–	–
				–	–
	7		no	–	–
				–	–
313* (write)	0	–	yes	–	FBUS unit: Received/Transmitted bytes counters loading. Loading order: 1) Transmit counter lower byte; 2) Transmit counter upper byte; 3) Receive counter lower byte; 4) Receive counter upper byte
	1		yes		
	2		yes		
	3		yes		
	4		yes		
	5		yes		
	6		yes		
	7		yes		

Port (hex)	Bit	Read	Write		Value	Comment
314* (write)	0	–	yes		0	FBUS unit: Disable interrupt on completion of transmission cycle
					1	FBUS unit: Enable interrupt on completion of transmission cycle
					0	FBUS unit: Disable interrupt on error
	1		yes		1	FBUS unit: Enable interrupt on error
	2		yes		0	–
					1	Start transmission cycle via FBUS
	3		no		–	–
	4		yes		0	FBUS unit: Set transmission rate coefficient (TRC). The FBUS unit transmission rate (BR) is calculated using the following equation: $BR = 2 / (1 + TRC) \text{ (Mbit/s)}$
					1	
	5		yes		0	
					1	
	6		yes		0	
					1	
	7		yes		0	
					1	
314* (read)	0	yes	–		0	FBUS unit: DAISY line status
					1	
	1	yes			0	FBUS unit: Interrupt line status
					1	
	2	no			–	–
	3	no			–	
	4	no			–	
	5	no			–	
	6	no			–	
	7	no			–	
315	0	yes	310.6=0	no	0	1 – Matrix keypad column "0" scanning in progress
					1	
			310.6=1	yes	0	Write: Set status of the KEY_R0 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_R0 discrete I/O channel status
	1	yes	310.6=0	no	0	1 – Matrix keypad column "1" scanning in progress
					1	
			310.6=1	yes	0	Write: Set status of the KEY_R1 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_R1 discrete I/O channel status
	2	yes	310.6=0	no	0	1 – Matrix keypad column "2" scanning in progress
					1	
			310.6=1	yes	0	Write: Set status of the KEY_R2 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_R2 discrete I/O channel status
	3	yes	310.6=0	no	0	1 – Matrix keypad column "3" scanning in progress
					1	
			310.6=1	yes	0	Write: Set status of the KEY_R3 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_R3 discrete I/O channel status
	4	yes	310.6=0	no	0	1 – Matrix keypad column "4" scanning in progress
					1	
			310.6=1	yes	0	Write: Set status of the KEY_R4 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_R4 discrete I/O channel status
	5	yes	310.6=0	no	0	1 – Matrix keypad column "5" scanning in progress
					1	
			310.6=1	yes	0	Write: Set status of the KEY_R5 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_R5 discrete I/O channel status
	6	yes	310.6=0	no	0	–
					1	
			310.6=1	yes	0	Write: Set status of the KEY_C0 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_C0 discrete I/O channel status
	7	yes	310.6=0	yes	0	Read: Matrix keypad interrupt indicator 1 – Unprocessed interrupt exists (cleared after read) 0 – No interrupts
					1	Write: Controls matrix keypad interrupt generation (KBD_IRQ) 1 – Interrupts enabled; 0 – Interrupts disabled
					0	Write: Set status of the KEY_C1 discrete I/O channel trigger (gray indicates trigger status after reset)
			310.6=1	yes	1	Read: KEY_C1 discrete I/O channel status

Port (hex)	Bit	Read	Write		Value	Comment
316	0	yes	310.6=0	no	0	Matrix keypad row 0: 0 – No key pressed
					1	1 – Key pressed
		yes	310.6=1	yes	0	Write: Set status of the KEY_C2 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_C2 discrete I/O channel status
	1	yes	310.6=0	no	0	Matrix keypad row 1: 0 – No key pressed
					1	1 – Key pressed
		yes	310.6=1	yes	0	Write: Set status of the KEY_C3 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_C3 discrete I/O channel status
	2	yes	310.6=0	no	0	Matrix keypad row 2: 0 – No key pressed
					1	1 – Key pressed
		yes	310.6=1	yes	0	Write: Set status of the KEY_C4 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_C4 discrete I/O channel status
	3	yes	310.6=0	no	0	Matrix keypad row 3: 0 – No key pressed
					1	1 – Key pressed
		yes	310.6=1	yes	0	Write: Set status of the KEY_C5 discrete I/O channel trigger (gray indicates trigger status after reset)
					1	Read: KEY_C5 discrete I/O channel status
317*	0	yes	yes		0	IRQ1 source selection: SIO_IRQ1
					1	IRQ1 source selection: KBD_IRQ (matrix keypad)
	1	yes	yes		0	IRQ5 source selection: FBUS_IRQ (FBUS unit)
					1	IRQ5 source selection: PC104_IRQ5
	2	yes	yes		0	IRQ6 source selection: SIO_IRQ6
					1	IRQ6 source selection: PC104_IRQ6
	3	yes	yes		0	IRQ7 source selection: SIO_IRQ7
					1	IRQ7 source selection: PC104_IRQ7
	4	yes	yes		0	IRQ8 source selection: SIO_IRQ8
					1	IRQ8 source selection: PC104_IRQ4
	5	yes	yes		0	IRQ9 source selection: UART_IRQ (internal)
					1	IRQ9 source selection: PC104_IRQ9
	6	yes	no		0	–
					1	–
	7	yes	yes		0	IRQ11 source selection: UART_IRQ (internal)
					1	IRQ11 source selection: PC104_IRQ11
318*	0	yes	yes		0	IRQ12 source selection: SIO_IRQ12
					1	IRQ12 source selection: PC104_IRQ12
	1	yes	yes		0	IRQ14 source selection: OPTO_IRQ
					1	IRQ14 source selection: PC104_IRQ14
	2	yes	yes		0	IRQ15 source selection: FL_RB (NAND FLASH available)
					1	IRQ15 source selection: PC104_IRQ15
	3	yes	no		0	–
	4	yes	no		0	–
	5	yes	no		0	–
	6	yes	no		0	–
	7	yes	no		0	–


Port (hex)	Bit	Read	Write	Value	Comment
319	0	yes	yes	0 1	LCD: read/write data, write commands, read status
	1	yes	yes	0 1	
	2	yes	yes	0 1	
	3	yes	yes	0 1	
	4	yes	yes	0 1	
	5	yes	yes	0 1	
	6	yes	yes	0 1	
	7	yes	yes	0 1	
31A	0	yes	no	Always 1	LCD read available
	1	yes	no	0	–
	2	yes	no	0	–
	3	yes	yes	0 1	/lcd_cs2 line status
	4	yes	yes	0 1	lcd_e line status
	5	yes	yes	0 1	lcd_rs line status
	6	yes	yes	0 1	lcd_rw line status
	7	yes	yes	0 1	/lcd_cs1 line status
31B	0	yes	no	0 1	KEY_R4 discrete I/O channel trigger status (bit 6 of port 310 is set to 1)
	1	yes	no	0 1	KEY_R5 discrete I/O channel trigger status (bit 6 of port 310 is set to 1)
	2	yes	no	0 1	KEY_C0 discrete I/O channel trigger status (bit 6 of port 310 is set to 1)
	3	yes	no	0 1	KEY_C1 discrete I/O channel trigger status (bit 6 of port 310 is set to 1)
	4	yes	no	0 1	KEY_C2 discrete I/O channel trigger status (bit 6 of port 310 is set to 1)
	5	yes	no	0 1	KEY_C3 discrete I/O channel trigger status (bit 6 of port 310 is set to 1)
	6	yes	no	0 1	KEY_C4 discrete I/O channel trigger status (bit 6 of port 310 is set to 1)
	7	yes	no	0 1	KEY_C5 discrete I/O channel trigger status (bit 6 of port 310 is set to 1)
31C*	0	yes	no	0 1	TXEN_485_COM3 line status
	1	yes	no	0 1	TXEN_485_COM4 line status
	2	yes	no	0 1	TXEN_485_COM5 line status
	3	yes	no	0 1	TXEN_485_COM6 line status
	4	yes	yes	0 1	HF_485_COM3 line status
	5	yes	yes	0 1	HF_485_COM4 line status
31C*	6	yes	yes	0 1	HF_485_COM5 line status
	7	yes	yes	0 1	HF_485_COM6 line status

Port (hex)	Bit	Read	Write	Value	Comment
31D*	0	yes	yes	0 1	EN_232_COM3 line status
	1	yes	yes	0 1	EN_232_COM4 line status
	2	yes	yes	0 1	EN_232_COM5 line status
	3	yes	yes	0 1	EN_232_COM6 line status
	4	yes	no	0	–
	5	yes	no	0	–
	6	yes	no	0	–
	7	yes	no	0	–
31E	0	yes	yes	0 1	FPGA registers (marked with *) access control. To allow access to FPGA registers it is necessary to write 55h to the port. After reset contains FFh
	1	yes	yes	0 1	
	2	yes	yes	0 1	
	3	yes	yes	0 1	
	4	yes	yes	0 1	
	5	yes	yes	0 1	
	6	yes	yes	0 1	
	7	yes	yes	0 1	
142, 1C2, 242, 2C2 (ID register)	0	yes	no	0 1	COM3 port interrupt request line status
	1	yes	no	0 1	COM4 port interrupt request line status
	2	yes	no	0 1	COM5 port interrupt request line status
	3	yes	no	0 1	COM6 port interrupt request line status
	4	yes	yes	0 1	UART reference frequency is 1.8432 MHz UART reference frequency is 14.7456 MHz
	6,5	yes	yes	00	UART base address – 100h, ID register address – 142h
				01	UART base address – 180h, ID register address – 1C2h
				10	UART base address – 200h, ID register address – 242h
				11	UART base address – 280h, ID register address – 2C2h
	7	yes	yes	0 1	Direct interrupt lines status output Inverted interrupt lines status output
Notes: Gray color marks the values after reset The ports marked with "*" are not available for read/write after hardware reset (see port 31E , Table 4.3)					

4.2.3 Interrupt settings

By default, interrupts are generated by the devices belonging to the CPB902 module. The interrupt source multiplexing diagram is presented in Figure 4.4. Table 4.4 contains interrupt settings. Among the alternative interrupt generating devices are: expansion modules on ISA system bus (PC/104 connector), optoisolated Reset input, NAND flash memory, and keyboard.

Figure 4.4: Interrupt Source Multiplexing Diagram



Interrupt request configuration is performed in BIOS Setup, see description in sections [5.4](#) and [5.5](#).

Table 4.4: Interrupt Settings

IRQ	Default Source	Alternative Source
IRQ0	System timer	–
IRQ1	Keyboard (main port)	Matrix keypad
IRQ2	Cascading to IRQ9	–
IRQ3	COM2	–
IRQ4	COM1	–
IRQ5	PC/104	FBUS controller
IRQ6	FDD	PC/104
IRQ7	PC/104	LPT1
IRQ8	RTC	–
IRQ9	Serial interfaces COM3 – COM6	PC/104
IRQ10	–	PCI bus devices
IRQ11	PC/104	Serial interfaces COM3 – COM6
IRQ12	Mouse	PC/104
IRQ13	Reserved for math. coprocessor	–
IRQ14	Primary IDE controller	External optoisolated input or PC/104
IRQ15	Secondary IDE controller	Flash-disk or PC/104

4.2.4 DMA channels

Figure 4.5: DMA Request Channels Multiplexing Diagram




Table 4.5: DMA Request Map

DMA Channel	Main Function	Alternative Source
0	Reserved for memory regeneration	—
1	PC/104 (DRQ1)	—
2	FDD (SIO)	PC/104 (DRQ2)
3	FBUS	PC/104 (DRQ3)
4	Slave controller	—
5	FBUS	PC/104 (DRQ5)
6	PC/104 (DRQ6)	—
7	PC/104 (DRQ7)	—

4.3 Functional Description

4.3.1 Microprocessor

The module is based on STPC Vega 180 (200) MHz microprocessor, which includes 32-bit x86 PII core, 64-bit coprocessor and 64-bit memory bus (SDRAM). The processor also includes MAC connected to PCI bus, the MAC is not used in the current version. Programmable I/O port JPIO[0...7] of the processor is used for system and application purposes. The detailed description of the microprocessor can be found in STPC Vega Programming Manual.

4.3.2 SDRAM Memory

Four SDRAM memory chips are soldered on board, two – on the top side, two – on the bottom side of the PCB. Total memory size is 128 MB (CPB90201) or 32 MB (CPB90202).

4.3.3 Reserved Flash BIOS

The CPB902 takes advantage of flash-memory based BIOS. Flash BIOS storage capacity is 512 KB. The main (working) copy of BIOS occupies 256 KB, the rest 256 KB is used for reserve BIOS copy. The reserve BIOS is enabled by setting jumper into position 5-6 at the J19 pinpad.

It is possible to upgrade BIOS in system. It is done with the help of **fwflash.exe** program. For example:

```
fwflash.exe b902v1_3.bin
      where b902v1_3.bin – BIOS image binary file name.
```

4.3.4 UIDE/Compact Flash Interface

J1 connector of CPB902 (Figure 4.2) allows connection of two UDMA-66 compatible devices (master and slave) to the primary IDE channel. J1 connector is a 44-pin 2 mm pitch header. Its pinout is shown in the following table.

Table 4.6: J1 HDD Connector Pinout

Pin#	Signal	Pin#	Signal	Pin#	Signal	Pin#	Signal
1	/RESET	12	DD12	23	/IOW	34	–
2	GND	13	DD2	24	GND	35	DA0
3	DD7	14	DD13	25	/IOR	36	DA2
4	DD8	15	DD1	26	GND	37	/CS1
5	DD6	16	DD14	27	/IOCHRDY	38	/CS3
6	DD9	17	DD0	28	GND	39	DASP
7	DD5	18	DD15	29	/DACK	40	GND
8	DD10	19	GND	30	GND	41	+5V
9	DD4	20	–	31	IRQ	42	+5V
10	DD11	21	DRQ	32	/CS16	43	GND
11	DD3	22	GND	33	DA1	44	–

The ACS00010 FC44 cable allows direct connection of a 2.5" HDD to the J1 connector. Other IDE devices (3.5" HDD, CD-ROM) having 40-contact 2.5 mm pitch connector can be connected to CPB902 via the CDM02 adapter. This adapter is connected to the 40-pin contact connector of the IDE device, and with the ACS00010 FC44 cable to CPB902 J1 connector.

4.3.5 CompactFlash Socket

CompactFlash Type I/II cards can be connected to J2 socket on the bottom side of CPB902. The device in this socket will be detected by the system as Secondary Master disk drive. This device can be assigned as a bootable disk in BIOS Setup program. The pinout of the J2 socket is presented in the following table.

Table 4.7: J2 Compact Flash Socket Pinout

Pin #	Function	Pin #	Function
1	GND	26	/CD1
2	D03	27	D11
3	D04	28	D12
4	D05	29	D13
5	D06	30	D14
6	D07	31	D15
7	/CS0	32	/CS1
8	A10 (NC)	33	/VS1 (NC)
9	/ATA SEL	34	/IORD
10	A09 (NC)	35	/IOWR
11	A08 (NC)	36	/WE
12	A07 (NC)	37	INTRQ
13	VCC (+5V)	38	VCC (+5V)
14	A06 (NC)	39	/CSEL
15	A05 (NC)	40	/VS2 (NC)
16	A04 (NC)	41	/RESET
17	A03 (NC)	42	IORDY
18	A02	43	/INPACK
19	A01	44	/REG
20	A00	45	/DASP (NC)
21	D00	46	/PDIAG (NC)
22	D01	47	D08
23	D02	48	D09
24	/IOCS16	49	D10
25	/CD2	50	GND
Note: (NC) indicates that this contact is not connected to the module's circuits			

4.3.6 NAND Flash

The capacity of the on-board NAND flash memory chip is 16 MB. It can be used as a bootable disk or can be disabled in BIOS Setup (see [section 5.3](#) for details).

4.3.7 Video Controller and VGA/TFT Adapter Module

4.3.7.1 Video Controller Operation Modes and Connection of Monitors

The module utilizes Silicon Motion SM712GE graphics controller with the following main features:

- Video memory size 4 MB;
- Connection of TFT or DSTN LCD-panels with resolution up to 1024×768;
- Connection of VGA RGB monitors;
- Dual display capability. Possibility to direct video output from two applications to two monitors simultaneously (in Windows 95/98/NT only).

The details on architecture and programming of the video controller can be found in "LynxEM+ DataBook".

The S1 DIP-switch allows to choose the video mode for the display. The table below presents the available display types and video controller operation modes.

Table 4.8: S1 Settings: Display Type and Video Mode Selection

S1 Setting 8 7 6 5 4 3 2 1	Display Type and Video Mode
0 0 0 0 0 0 0 0	VGA monitor in RGB mode
x x x x x x x 0	LCD type – Color TFT
x x x x x x x 1	LCD type – Color STN
x x x x x x 0 1	TFT FPCLK : normal
x x x x x x 1 1	TFT FPCLK : inverted
x x x x 0 0 x x	LCD resolution set to 640×480
x x x x 0 1 x x	LCD resolution set to 800×600
x x x x 1 0 x x	LCD resolution set to 1024×768
x x x x 1 1 x x	LCD resolution set to 1280×1024
x 0 0 0 x x x x	Color resolution 9 bpp (3 bits per color channel)
x 0 0 1 x x x x	Color resolution 12 bpp (4 bits per color channel)
x 0 1 0 x x x x	Color resolution 18 bpp (6 bits per color channel)
x 0 1 1 x x x x	Color resolution 24 bpp (8 bits per color channel)
x 1 0 0 x x x x	24 bit per pixel (12+12 bit, 2 pixels + clock)
x 1 0 1 x x x x	Analog TFT display (RGB)
x 1 1 0 x x x x	36 bit per pixel (18+18 bit, 2 pixels + clock)
0 x x x x x x x	16-bit DSTN interface
1 x x x x x x x	24-bit DSTN interface

The module's video controller supports color STN and TFT panels with digital interface. These panels are connected to J16 connector (AMP P/N: 147377-4, counterpart AMP P/N:111196-9).

The correspondence between the video controller interface lines (FDATA[23...0]) and TFT/STN panels' interfaces is given in the table below. The pin destinations of J16 connector is presented in the next table.

Table 4.9: Different Types of TFT/STN Panels Connection

Pin Name	Color DSTN			Color TFT			
	16-bit	24-bit	9-bit	12-bit	18-bit	24-bit	12-bit x2
FHSYNC	LP	LP	HSYNC	HSYNC	HSYNC	HSYNC	HSYNC
FVSYNC	FP	FP	VSYSN	VSYSN	VSYSN	VSYSN	VSYSN
FPSCLK	XCK	XCK	CK	CK	CK	CK	CK
DE			ENAB	ENAB	ENAB	ENAB	ENAB
FPEN	FPEN	FPEN	FPEN	FPEN	FPEN	FPEN	FPEN
FDATA23		UD11				R7	RB3
FDATA22		UD10				R6	RB2
FDATA21		UD9			R5	R5	RB1
FDATA20		UD8			R4	R4	RB0
FDATA19	UD7	UD7		R3	R3	R3	RA3
FDATA18	UD6	UD6	R2	R2	R2	R2	RA2
FDATA17	UD5	UD5	R1	R1	R1	R1	RA1
FDATA16	UD4	UD4	R0	R0	R0	R0	RA0
FDATA15	UD3	UD3				G7	GB3
FDATA14	UD2	UD2				G6	GB2
FDATA13	UD1	UD1			G5	G5	GB1
FDATA12	UD0	UD0			G4	G4	GB0
FDATA11		LD11		G3	G3	G3	GA3
FDATA10		LD10	G2	G2	G2	G2	GA2
FDATA9		LD9	G1	G1	G1	G1	GA1
FDATA8		LD8	G0	G0	G0	G0	GA0
FDATA7	LD7	LD7				B7	BB3
FDATA6	LD6	LD6				B6	BB2
FDATA5	LD5	LD5			B5	B5	BB1
FDATA4	LD4	LD4			B4	B4	BB0
FDATA3	LD3	LD3		B3	B3	B3	BA3
FDATA2	LD2	LD2	B2	B2	B2	B2	BA2
FDATA1	LD1	LD1	B1	B1	B1	B1	BA1
FDATA0	LD0	LD0	B0	B0	B0	B0	BA0
FPVDDEN	VDD	VDD	VDD	VDD	VDD	VDD	VDD
VBIASEN	VEE	VEE	VEE	VEE	VEE	VEE	VEE

Table 4.10: TFT/STN Panels Connector J16 Pinout

Pin #	Signal	Pin #	Signal
1	GND	21	FDATA16
2	LVDS_MCKIN	22	FDATA17
3	VBIASEN	23	FDATA18
4	FPVDDEN	24	FDATA19
5	FDATA0	25	FDATA20
6	FDATA1	26	FDATA21
7	FDATA2	27	FDATA22
8	FDATA3	28	FDATA23
9	FDATA4	29	FPEN
10	FDATA5	30	DE
11	FDATA6	31	FPCLK
12	FDATA7	32	FVSYNC
13	FDATA8	33	GND
14	FDATA9	34	FHSYNC
15	FDATA10	35	+5V
16	FDATA11	36	+5V
17	FDATA12	37	–
18	FDATA13	38	–
19	FDATA14	39	–
20	FDATA15	40	–

Color DSTN panels with 16-bit or 24-bit interface and resolution up to 1024×768 are supported. For color TFT panels the color resolutions of 9, 12, 18, and 24 bits per pixel or 24 bits per two pixels at screen resolution 1280×1024 are supported. The video controller also supports 36-bit interface, but J16 connector provides only 24 data lines, thus the two-pixel mode for TFT panels with 18-bit interface is not supported.

A VGA analog monitor can be connected to the 15-contact D-Sub connector P7. Its pinout is presented in the table below.

Table 4.11: P7 D-Sub VGA Connector Pinout

Pin #	Signal	Pin #	Signal
1	OUTR	9	–
2	OUTG	10	GND
3	OUTB	11	–
4	–	12	SDA
5	GND	13	HSYNC
6	GND	14	VSYNC
7	GND	15	SCL
8	GND	–	–

The following four diagrams explain how different types of TFT/STN panels are connected to the module.

Figure 4.6: Connection of 16-bit DSTN Panel




Figure 4.7: Connection of 24-bit DSTN Panel




Figure 4.8: Connection of a TFT Panel with 1 Pixel per FPSCLK Period





Figure 4.9: Connection of a TFT Panel with 2 Pixels per FPSCLK Period



4.3.7.2 Sharp LQ104V1DG51 TFT Panel Connection

SHARP LQ104V1DG51 TFT panel can be connected to J16 header of the module using ACS00022 40-thread ribbon cable and CVM02 adapter card, which is installed directly on the panel's connector. The CVM02 adapter card has a DIP-switch J2 used to set display orientation on the panel screen and for backlight control. The diagram on the figure below shows how this panel type is connected to CPB902.

Figure 4.10: SHARP LQ104V1DG51 TFT Panel Connection and Setup




Table 4.12: CVM02 J2 Pin Assignments


J2 Pins	Assignment
1-6	Panel screen display orientation (see figure above)
7	FPVDDEN signal is used for backlight control
8	GND

SHARP LQ104V1DG51 backlight lamp is powered by the TDK CXA-P1212B-WJL external converter.

4.3.7.3 CVM01 Expansion Module

The CVM01 (469535.004) is an expansion module, which allows to connect TFT/STN panels via the 40-pin 2.54 mm pitch J5 connector or additional RGB monitor with standard VGA interface via P1 D-Sub connector. CVM01 has a DAC which converts digital input into analog VGA signal. This expansion module is connected to CPB902 J16 header with 40-thread cable. The following figure presents the location of CVM01 connectors and other components.

Figure 4.11: CVM01 Expansion Module



The CVM01 P1 VGA connector has the same pin assignments as CPB902 P7 connector (see [P7 Pinout Table](#) in subsection 4.3.7.1). The pinout of CVM01 J5 connector is given in the table below.

CVM01 provides possibility to adjust the display driver power voltage (VEEP) with R5 potentiometer, and to set the digital interface power voltage with J2-J4 jumpers. Closing J3 and J4 sets VDDP = +3.3 V, closing J2 and J3 sets VDDP = +5 V.

Table 4.13: CVM01 J5 Connector Pinout

Pin #	Signal	Pin #	Signal
1	VEEP	21	FDATA14
2	VDDP	22	GND
3	GND	23	GND
4	FDATA1	24	FDATA17
5	FDATA0	25	FDATA16
6	FDATA3	26	FDATA19
7	FDATA2	27	FDATA18
8	FDATA5	28	FDATA21
9	FDATA4	29	FDATA20
10	FDATA7	30	FDATA23
11	FDATA6	31	FDATA22
12	GND	32	GND
13	GND	33	GND
14	FDATA9	34	NP_FPVS
15	FDATA8	35	NP_FPSCLK
16	FDATA11	36	NP_FPHS
17	FDATA10	37	GND
18	FDATA13	38	GND
19	FDATA12	39	NP_FPEN
20	FDATA15	40	NP_FPDE

4.3.8 Keyboard and Mouse Interface

CPB902 is provided with a 6-contact PS/2 mini-DIN connector for mouse and/or keyboard. Simultaneous connection of mouse and keyboard is possible via Y-cable.

Table 4.14: PS/2 Keyboard/Mouse Connector P5 Pinout

Pin Number	Name	Function	In/Out
1	KDATA	Keyboard data	In/Out
2	MDATA	Mouse data	In/Out
3	GND	GND signal	–
4	VCC	VCC signal +5 V	–
5	KCLK	Keyboard clock	Out
6	MCLK	Mouse clock	Out

4.3.9 USB Interface

The module is equipped with two USB 1.1 ports. Each channel has separate power control circuit. These ports are available via P3 USB-A duplex connector at the edge of the board.

4.3.10 Fast Ethernet Interface

The CPB902 has two 10Base-TX/100Base-TX Ethernet channels provided by two National Semiconductor DP83815 controllers. They are available via two RJ45 (P1 and P2) connectors at the edge of the board (see [Figure 4.2](#)). Their pinout conforms to IEEE 802.3 Ethernet specification.


4.3.11 Serial Ports

The CPB902 is finished with six serial ports. COM1 and COM2 ports have standard PC AT base addresses. The base address of COM3 – COM6 group of ports can be changed.

COM1 is routed to J4 IDC10 connector (pitch 2.54 mm). It has only three lines (RXD, TXD and GND) and is intended for console operation and file exchange. To connect this port to a remote PC a null-modem cable is needed. COM2 is a full function RS232 port and is routed to DB9 J3 connector. Maximum transfer rate for COM1 and COM2 ports is 115.2 Kb/s. They are fully compatible with UART16550.

COM3 – COM6 ports allow data transmission rates up to 921,6 Kb/s and support RS-232/RS-422/RS-485 interfaces. The transmission clock frequency and operation modes for these ports are set in BIOS Setup, see [section 5.4](#). These four ports are routed to IDC10 on-board connectors (J5, J7, J9 and J11 correspond to COM3, COM4, COM5 and COM6 respectively). IDC10 connector pins numbering is shown on figure below.

Figure 4.12: IDC10 Pins Numbering




The following table gives information on COM ports pin assignments for all serial ports and different interfaces. Empty cells (dashes in cells) mean that in the current mode the pins are not used, but it is not allowed to connect any signals to them.

Table 4.15: Serial Ports Pin Assignments

Pin #	COM2	COM1	COM3/COM4/COM5/COM6		
	RS-232	RS-232	RS-232	RS-422	RS-485
1	DCD	–	DCD	RX+	–
2	DSR	–	DSR	RX-	–
3	RXD	RXD	RXD	–	–
4	RTS	–	RTS	–	–
5	TXD	TXD	TXD	–	–
6	CTS	–	CTS	–	–
7	DTR	–	DTR	TX+	D+
8	RI	–	RI	TX-	D-
9	GND	GND	GND	GND	GND
10	–	–	+5V	+5V	+5V

COM2, COM3 – COM6 ports have ESD and overload protection. COM1 port has no protection. The jumpers of the DIP-switches J6 (COM3), J8 (COM4), J10 (COM5) and J12 (COM6) connect terminators to RS-485/RS-422 signal lines. In RS-232 mode the terminators should not be connected. The pins of all DIP-switches have identical designation shown in the following figure.

Figure 4.13: COM3 – COM6 Ports Jumpers

To use any of the COM3 – COM6 ports in RS-422 or RS-485 mode, do the following:

- Set jumpers on the DIP-switch, corresponding to the port;
- Initialize the port by software

The figures 4.14 and 4.15 show the RS-422 and RS-485 interfaces structure respectively. Figure 4.14 shows two modules connected in RS-422 mode. The jumper connecting terminator is set on receive lines only (lines RX+ and RX-). In RS-485 mode the terminators are connected only on devices at the ends of the line (see Figure 4.15). The terminators' resistance is 120 Ohm. The complete description of jumpers can be found in [Appendix A](#) and [Appendix B](#).

Figure 4.14: Point-to-Point Connection of Two Modules in RS-422 Mode




Figure 4.15: Connection of Several Devices in RS-485 Mode





Figure 4.16 presents a diagram explaining functioning and mode selection for one of COM3 – COM6 ports.

TXD_COM and RXD_COM are TTL level signals and are routed to UART16550 compatible serial interface controller. RS-232 converter is activated on setting EN_COM="1" and RS-422/RS-485 converter is activated when EN_COM="0". RXD_COM signal is multiplexed from the appropriate converter. In RS-485 mode the TXEN_485 signal determines the data transfer direction, it switches the channel between "receive" and "transmit" modes. This signal status can only be read. When EN_COM="0", HF_485 allows to select RS-485 or RS-422 mode: HF_485="1" corresponds to RS-485 mode, HF_485="0" – to RS-422.

Figure 4.16: COM3-COM6 Ports: Simplified Interface Circuit Diagram



In RS-232 mode the terminators should not be enabled. In RS-485 or RS-422 modes the jumpers should be set on appropriate DIP-switches: J6 (COM3), J8 (COM4), J10 (COM5) and J12 (COM6). Switching to RS-422/RS-485 modes is done in BIOS Setup. For COM1 – COM6 ports base addresses, please, refer to Tables 4.2 and 4.3.

4.3.12 FDD/LPT Port

The LPT1 port of CPB902 supports EPP and ECP operation modes. ECP is the default mode. LPT is routed to J15 connector shared with FDD port. Switching between LPT and FDD ports is performed in BIOS Setup.

LPT1 uses IRQ7 interrupt line, IRQ6 is assigned to FDD port. Interrupts from these ports can be disabled and switched for use by ISA bus devices in BIOS Setup program (see sections [5.4](#) and [5.5](#)).

A printer is connected to J15 header via ACS00011 FCD25F cable with DB25F connector.

A floppy disk drive is connected to J15 header via the ACS0002FC26-60 26-thread ribbon cable and CDM01 (469535.030) transition module, which is installed directly on 34-pin FDD connector.

The table below describes pin assignments of the J15 connector.

Table 4.16: LPT/FDD J15 Connector Pinout

Pin #	LPT1 Signals	FDD Signals
1	/STROBE	/DS0
2	/ALF	/DRV DEN0
3	PD0	/INDEX
4	/ERROR	/HDSEL
5	PD1	/TRK0
6	/INIT	/DIR
7	PD2	/WP
8	/SLCTIN	/STEP
9	PD3	/RDATA
10	GND	GND
11	PD4	/DSKCHG
12	GND	GND
13	PD5	—
14	GND	GND
15	PD6	/MTR0
16	GND	GND
17	PD7	—
18	GND	GND
19	/ACK	/DS1
20	GND	GND
21	BUSY	/MTR1
22	GND	GND
23	PE	WDATA
24	GND	GND
25	SLCT	WGATE
26	+5V	+5V

4.3.13 LCD and Matrix Keyboard Port

LCD monitors and matrix keypads share J17 header on the top side of CPB902 processor module.

4.3.13.1 LCD Connection

The CPB902 connector J17 is used for connection of LCD monitors based on HD44780, S6A0069, S6B0108 or compatible controllers. Sample LCD connection diagrams are shown in the figures below (4.17, 4.18). The driver power voltage is controlled by R154 adjustable potentiometer and J18 DIP-switch jumper (see description and a diagram below in this section).

Two ports in I/O address space are dedicated for data transmission and control purposes when working with LCDs. They are Command/Data port (319h) and Control port (31Ah).

Commands/Data port:

Port address – **319h**

The port is available for read/write

Assignment: read/write data to/from LCD, write commands to LCD, read LCD status.

Control Port:

Port Address: **31Ah**

The control bits of this port are used to set the required timing chart for data exchange between the processor and LCD.

Control Port Bits Designation:

Bit	Read/Write	Function
0	Read	Always 1. LCD available for read.
1	Read	Always 0
2	Read	Always 0
3	Read/Write	/LCD_CS2 line control
4	Read/Write	LCD_E line control
5	Read/Write	LCD_RS line control
6	Read/Write	LCD_R/W line control
7	Read/Write	/LCD_CS1 line control

Figure 4.17: POWER TIP PC1604-A Alphanumeric LCD Connection Diagram

Signal	Contact		LCD Contact	Signal
GND	J17.14		1	Vss
+5V	J17.15		2	Vdd
LCD_TRIM*	J17.16		3	Vo
LCD_RS	J17.17		4	RS
LCD_R/W	J17.18		5	R/#W
LCD_E	J17.19		6	E
LCD_D0	J17.20		7	DB0
LCD_D1	J17.21		8	DB1
LCD_D2	J17.22		9	DB2
LCD_D3	J17.23		10	DB3
LCD_D4	J17.24		11	DB4
LCD_D5	J17.25		12	DB5
LCD_D6	J17.26		13	DB6
LCD_D7	J17.27		14	DB7

**Note:**

LCD_TRIM voltage should be set to the range from -1 V to -3 V using R154 potentiometer and J18.3–J18.4 jumper.

Figure 4.18: POWER TIP PG12864-A Graphics LCD Connection Diagram

Signal	Contact		LCD Contact	Signal
GND	J17.14		1	Vss
+5V	J17.15		2	Vdd
LCD_TRIM*	J17.16		3	Vo
LCD_RS	J17.17		4	D/#I
LCD_R/W	J17.18		5	R/#W
LCD_E	J17.19		6	E
LCD_D0	J17.20		7	DB0
LCD_D1	J17.21		8	DB1
LCD_D2	J17.22		9	DB2
LCD_D3	J17.23		10	DB3
LCD_D4	J17.24		11	DB4
LCD_D5	J17.25		12	DB5
LCD_D6	J17.26		13	DB6
LCD_D7	J17.27		14	DB7
/LCD_CS1	J17.28		15	CS1
/LCD_CS2	J17.29		16	CS2
/LCD_RST	J17.30		17	#RST

**Note:**

LCD_TRIM voltage should be set to -7 V using R154 potentiometer and J18.3–J18.4 jumper.


Table 4.17 presents designation of contacts of the J18 pinpad, which is used to set the LCD driver power voltage. J17 connector pinout is given in Table 4.18.

Table 4.17: J18 DIP-Switch Pinout

Pin #	Name	Function
1	VEE	Driver power input
2	GND	Common ground
3	VEE	Driver power input
4	" -7 V "	-7 V supply from module

The figure below (4.19) shows circuit diagram explaining the function of the J18 pinpad. If a commercial temperature range LCD module is used, the LCD TRIM line voltage should be 0 to $+5\text{ V}$ (J18 jumper in position 1-2, voltage adjusted by R154). If an extended temperature range LCD module is used, it is possible that the LCD TRIM voltage should have negative value (J18 jumper in position 3-4, voltage adjusted by R154).

Figure 4.19: J18 Pinpad Connection Circuit Diagram



4.3.13.2 Matrix Keypad Connection

A matrix keypad can be connected to the J17 header. It is possible to use a matrix keypad having 16 (4x4), 20 (4x5 or 5x4), 25 (5x5), 30 (6x5 or 5x6) or 36 (6x6) keys. To interface with a keypad CPB902 has two ports in I/O address area – one is column scanning and interrupt control port, another one is row scanning port.

The keyboard interface can also be used as a discrete input/output.

Column scanning and interrupt control port:

Port address – **315h**

Bits 5...0 – available for read only. "1" in one of the bits indicates the number of the currently scanned column;

Bit 6 – not used;

Bit 7 – available for read/write. When read, this bit indicates the presence of keypad interrupt.

"1" – keypad interrupt is present, cleared after read;

"0" – no interrupt.

In "write" mode controls the matrix keypad generation.

"0" – interrupt disabled;

"1" – interrupt enabled.

Row scanning port:

Port address – **316h**

Bits 5...0 available for read only. "0" in one of the bits indicates the column, where the key is pressed. If no key is pressed, all these bits are set to "1".

There are two ways to access a keypad in a user program – by reading bit 7 of 315h port or using IRQ1 interrupt. By default, this interrupt is used by a PS/2 keyboard at P5 connector. To use it for matrix keypad, it is necessary to switch it in BIOS Setup program (see [section 5.4](#)).

Upon receipt of the "key pressed" attribute or enabling the IRQ1 interrupt handler, the user program should read the 315h and 316h ports and generate the code of the pressed key. The way the keys are coded depend on the type of the keypad, on the KEY_R[5...0] and KEY_C[5...0] lines connection diagram and therefore is not described in this Manual.

4.3.13.3 Using Keyboard Interface by the Discrete I/O Unit

The discrete I/O unit consists of 12 I/O channels (KEY_R[5...0] and KEY_C[5...0]), routed to J17 header. The unit is enabled by writing 1 to the bit 6 of 310h port, and at the same time the matrix keyboard unit is disconnected from KEY_R[5...0] and KEY_C[5...0] lines.

All the 12 channels are identical. Each channel allows to read the line status and, if pull-up resistors are connected, to set the required logical state.

The line status is read from the ports 315h (bits 7...0 correspond to the channels KEY_C[1...0] and KEY_R[5...0]) and 316h (bits 3...0 correspond to the channels KEY_C[5...2]).

For each channel logical zero is set by writing "0" to the corresponding bit of 315h and 316h ports.

Logical one is set by writing "1" to the corresponding bit of 315h and 316h ports, if pull-up resistors are connected.

For each channel the trigger status is retrieved via the ports 316h (bits 7...4 correspond to KEY_R[3...0] lines) and 31Bh (bits 7...0 correspond to KEY_C[5...0] and KEY_R[5...4] lines).

I/O channel block diagram is shown in Figure 4.20.

The I/O unit structure is presented in Figure 4.21.

Figure 4.20: Discrete I/O Channel Block Diagram




Figure 4.21: Discrete I/O Unit: Ports Binding Diagram




Table 4.18: J17 Connector Pinout

Pin #	Function	Pin #	Function
1	KEY R0	16	LCD TRIM
2	KEY C2	17	LCD_RS
3	KEY C1	18	LCD_R/W
4	KEY R1	19	LCD_E
5	KEY R2	20	LCD_D0
6	KEY C0	21	LCD_D1
7	KEY C3	22	LCD_D2
8	KEY R3	23	LCD_D3
9	KEY R4	24	LCD_D4
10	KEY C4	25	LCD_D5
11	KEY C5	26	LCD_D6
12	KEY R5	27	LCD_D7
13	GND	28	/LCD_CS1
14	GND	29	/LCD_CS2
15	+5V	30	/LCD_RST

4.3.14 Optoisolated Reset/Interrupt

The module has one optoisolated discrete input J14, which can be used for remote reset or for interrupt generation. This interrupt is served by IRQ14 line of the interrupt controller. Use J13 jumpers to select the microprocessor reset source and to enable the interrupt generation by the signal from the optoisolated input. Remote reset source voltage is 3 – 5 V. Figure 4.22 presents a simplified diagram of the circuits. J13 jumper settings are described in the Table 4.19.

Figure 4.22: Reset Source Selection and Optoisolated Input Circuit Diagram




Table 4.19: J13 Settings: Switching Reset/IRQ Source

Closed contacts	Function
1-2	Enable Reset from supervisor's WDT
3-4	Enable Reset from SIO WDT
5-6	Enable the optoisolated input as a Reset source Enable Reset from the optoisolated input
7-8	Enable the optoisolated input as an IRQ14 interrupt source. IRQ14 interrupt can be used only if Primary IDE channel is disabled in BIOS Setup (see section 5.4)

It is not allowed to close the contacts 5-6 and 7-8 simultaneously, the optoisolated input can have only one assignment. The jumpers 1-2, 3-4, and 5-6 can be set closed together. In this case, the resulting active low Reset signal for the microprocessor is formed as logic OR function based on incoming signals. The supervisor issues Reset signal when the power voltage drops below the specified value or when the connected to the supervisor SW1 button is pressed (see Components Layout Diagram, [Figure 4.2](#)).

4.3.15 FBUS Connector

FBUS is an interface bus, which enables CPB902 to be a part of FBUS networks. FBUS interface controller is routed to P6 vertical RJ45 on-board connector. FBUS physical level is identical to the one of RS485 interface. The addresses 0x312–0x314 are used to manipulate the FBUS controller. The power voltage (+5 V) is supplied to FBUS by closing pins 3-4 at the J18 DIP-switch. The P6 contacts assignment is given in Table 4.20.

Table 4.20: RJ45 FBUS Connector P6 Pinout

Pin #	Signal	Pin #	Signal
1	D+	5	GND
2	D-	6	GND
3	DAISY OUT	7	VCC_FBUS
4	HISPEED	8	VCC_FBUS

4.3.16 RTC and Serial FRAM

The module is equipped with a standard Real Time Clock. FRAM is non-volatile memory with I2C serial interface. It serves as a back-up storage for BIOS Setup parameters and for restoration of the RTC memory if an error is detected. Free FRAM memory units (7 KB) are available to the user via INT17H BIOS function. See also [subsection 5.8.1](#) in BIOS Setup description.

For long-term storage of the CPB902 module the on-board battery can be disconnected by removing the jumper from the J19 contacts 1-2 (see next subsection).

4.3.17 J19 Configuration Jumpers

Some of the system configuration jumpers are integrated at the J19 DIP-switch. They allow switching between main and reserve BIOS copies, switching of the RTC battery, and switching of +5 V power voltage on VCC_FBUS line of FBUS interface. The J19 circuit diagram is shown in Figure 4.23 and the jumpers' function is given in Table 4.21 below.

Figure 4.23: J19 Circuit Diagram




Table 4.21: J19 Pins Designation

Jumper Position	Function
1-2	Closed: RTC battery is connected; open: the battery is disconnected
3-4	Closed: +5 V power voltage is supplied to VCC_FBUS line of FBUS interface. If modules providing other power supply voltages to VCC_FBUS lines are connected to FBUS, this jumper must be removed!
5-6	When closed, the reserve BIOS copy is enabled (EEPROM lower addresses area). When open, the main BIOS copy is enabled (EEPROM high addresses area)

4.3.18 PC/104 Header

P4 header mounted on CPB902 allows connection of PC/104 expansion modules. The processor module can accommodate 3 PC/104 expansion modules maximum. The contact configuration of P4 header is shown in Figure 4.24. Tables 4.22 and 4.23 give the designation of P4 contacts.

Figure 4.24: PC/104 P4 Contacts Layout




Table 4.22: PC/104 P4 (Rows A and B) Contacts Designation

Pin #	Signal	In/Out	Pin #	Signal	In/Out
A1	/IOCHK	–	B1	GND	Power
A2	SD7	In/Out	B2	RESET	Out
A3	SD6	In/Out	B3	+5V	Power
A4	SD5	In/Out	B4	IRQ9	In
A5	SD4	In/Out	B5	-5V	–
A6	SD3	In/Out	B6	DRQ2	In
A7	SD2	In/Out	B7	-12V	Power
A8	SD1	In/Out	B8	0WS	In
A9	SD0	In/Out	B9	+12V	Power
A10	IOCHRDY	In	B10	GND	Power
A11	AEN	Out	B11	/SMEMW	Out
A12	SA19	Out	B12	/SMEMR	Out
A13	SA18	Out	B13	/IOW	Out
A14	SA17	Out	B14	/IOR	Out
A15	SA16	Out	B15	/DACK3	Out
A16	SA15	Out	B16	DRQ3	In
A17	SA14	Out	B17	/DACK1	Out
A18	SA13	Out	B18	DRQ1	In
A19	SA12	Out	B19	/REFRESH	Out
A20	SA11	Out	B20	BCLK	Out
A21	SA10	Out	B21	IRQ7	In
A22	SA9	Out	B22	IRQ6	In
A23	SA8	Out	B23	IRQ5	In
A24	SA7	Out	B24	IRQ4	In
A25	SA6	Out	B25	IRQ3	In
A26	SA5	Out	B26	/DACK2	Out
A27	SA4	Out	B27	TC	Out
A28	SA3	Out	B28	BALE	Out
A29	SA2	Out	B29	+5V	Power
A30	SA1	Out	B30	OSC	Out
A31	SA0	Out	B31	GND	Power

Table 4.23: PC/104 P4 (Rows C and D) Contacts Designation

Pin #	Signal	In/Out	Pin #	Signal	In/Out
C0	GND	In	D0	GND	In
C1	/SBHE	Out	D1	/MEMCS16	In
C2	LA23	Out	D2	/IOCS16	In
C3	LA22	Out	D3	IRQ10	In
C4	LA21	Out	D4	IRQ11	In
C5	LA20	Out	D5	IRQ12	In
C6	LA19	Out	D6	IRQ13	In
C7	LA18	Out	D7	IRQ14	In
C8	LA17	Out	D8	/DACK0	Out
C9	/MEMR	Out	D9	DRQ0	In
C10	/MEMW	Out	D10	/DACK5	Out
C11	SD8	In/Out	D11	DRQ5	In
C12	SD9	In/Out	D12	/DACK6	Out
C13	SD10	In/Out	D13	DRQ6	In
C14	SD11	In/Out	D14	/DACK7	Out
C15	SD12	In/Out	D15	DRQ7	In
C16	SD13	In/Out	D16	+5V	In
C17	SD14	In/Out	D17	/MASTER	In
C18	SD15	In/Out	D18	GND	In
C19	KEY	–	D19	GND	In

**Note:**

In tables 4.22 and 4.23:

"—" - Not used;

"Power" - The power is supplied to the module installed into a crate

In/Out column shows the data transfer direction for a processor module being the bus master.

4.3.19 Diagnostic LEDs

CPB902 has four diagnostic LEDs (D9, D10, D11, D20 - upper-right corner in [Figure 4.2](#)). If the processor module is installed into the mounting cage, additional light pipes can be installed to conduct the light to the front panel. The following table describes the function of these LEDs.

Table 4.24: CPB902 Diagnostic LEDs Function

LED	Function
D9	IDE HDD activity
D10	User LED1
D11	User LED2
D20	Processor reset by WDT. This LED lights up when the processor was reset on WDT timeout expiry. It should not lit during normal operation.

LED1 and LED2 user LEDs are linked directly with GPIO5 and GPIO6 microprocessor ports. They are switched on and off by a BIOS procedure, which can be invoked from user application programs. The description of the procedure can be found in [subsection 5.10.2](#).

4.3.20 Power Supply Connector

The power is supplied to CPB902 via the J20 connector. The main power voltage of the processor module is +5V. +12 V is supplied via J20 connector, but is not used in CPB902. It is routed to P4 PC/104 connector. The PC/104 connector contacts corresponding to -5 V and -12 V voltages are not connected to the board circuitry. The following table gives J20 contacts' assignments.

Table 4.25: J20 Power Connector Pinout

Pin	Assignment
1	+12 B
2	GND
3	GND
4	+5 B

4.4 Overall and Mounting Dimensions

Figure 4.25: CPB902 Top Side: Overall and Mounting Dimensions





Figure 4.26: CPB902 Bottom Side: Overall and Mounting Dimensions

A (Heat-conducting Plate View)



4.4.1 Mounting on a Panel

It is possible to provide additional heat removal, when CPB902 is installed on a metallic mounting panel using 9 mm high stud spacers. For better heat transfer results use thermal paste or heat-conducting pad.

In case the additional heat dissipation is not needed, the stud spacers' height should be not less than 10 mm.

To install CPB902 on a panel, it is recommended to use the CC902 mounting card cage. It provides mechanical protection for CPB902 and its components, as well as easy accommodation of a 2.5" HDD and PS902 power converter.

5 General Software® BIOS

CPB902 uses an adapted version of a standard General Software® BIOS for IBM PC AT-compatible personal computers. It supports the Intel®x86 and compatible processors. The BIOS provides critical low-level support for the system central processing, memory, and I/O subsystems.

With the help of BIOS Setup program, you can modify BIOS parameters and control the special features of your module.

The last section of this chapter gives instructions on usage of extended BIOS functions.

5.1 BIOS Setup Program. Introduction

With the BIOS Setup program, you can modify BIOS settings and control the special features of the module. The Setup program uses a number of menus for making changes and turning the special features on or off. These settings are stored in a dedicated battery-backed memory, CMOS RAM, that retains the information when the power is switched off.

5.2 Main Menu

To start the BIOS Setup program switch on the power or restart the system. By default the startup screen looks like this:


```
General Software Embedded BIOS 2000 (tm) Revision 5.2
Copyright (C) 2003 General Software, Inc.
Fastwel adaptation for CPB902/CPC106 boards Revision 1.0
Copyright (C) 2005 Fastwel Co., Ltd.
```

```
Hit <Del> if you want to run SETUP.
```

```
Fastwel Flash Disk (FFD) Version 3.0
Copyright (C) 1999-2004 Fastwel, Inc.
```

```
Starting MS-DOS...
```

To start BIOS Setup, press "Del" key on a keyboard while the message "Hit if you want to run SETUP" is seen on the screen. This will lead you to the Main Menu screen, shown in Figure below.

Figure 5.1: Main Menu Screen Image

The Main Menu items and their functions are described in the table below.

Table 5.1: Main Menu Items

Menu Item	Purpose
Basic CMOS Configuration	This item lead you to the menu which allows you to setup the main system parameters, such as System date and time; Disk drives types definition and letter assignments, Boot sequence and others.
Custom Configuration	This item opens a menu screen, where you can setup DMA and interrupt levels, I/O ports base addresses and select console I/O devices.
PnP Configuration	This menu item gives you access to Plug-and-Play related IRQ and DMA settings.
Shadow Configuration	Shadow memory configuration item allows you to select BIOS extensions memory blocks to copy into RAM on module initialization.
Start RS232 Manufacturing Link	This menu item starts the service mode, which allows to explore the disk drives of the CPB902 from a remote PC using a RS232 link between the module and a remote PC (see section 5.7).
Reset CMOS to last known values	This menu command allows you to reset the BIOS configuration parameters to the values, with which the system has switched on last time, and continue with BIOS Setup.
Reset CMOS to factory defaults	This command allows you to reset the BIOS configuration parameters to the values set by the manufacturer.
Write to CMOS and Exit	This command lets you write the configuration parameters into CMOS memory and exit BIOS Setup.
Exit without changing CMOS	This command allows you to exit the Setup program without writing any possible changes into the CMOS memory, thus keeping intact the previously saved configuration.

Use "Up" and "Down" cursor keys or <Tab> key to move between menu items. <Enter> selects the item and allows to proceed with the command or opens the submenu screen.

5.3 Basic CMOS configuration

On selection of this Main menu item the following screen is shown:

Figure 5.2: Basic CMOS Configuration Screen Image

System BIOS Setup - Basic CMOS Configuration (C) 2003 General Software, Inc. All rights reserved	
Date:>Jan 01, 1980 Time: 04 : 47 : 27	IDE DRIVE GEOMETRY: Sect Hds Cyls Master: AUTOCONFIG, LBA Slave: Not installed CompactFlash: Not installed
First Boot From : C: F1 Error Wait : Enabled NumLock : Disabled Typematic Delay : 250 ms Typematic Rate : 30 cps	Onboard Flash Disk: Enabled 1st Disk (Disk C:) IDE Master Floppy Disk Drive: 1.44 MB, 3.5"
Boot Method : Boot Sector	Memory Base : 601KB Ext. : 127MB
↑/↓/→/←/CR/Tab to select or <PgUp>/<PgDn>/+/- to modify w<Esc> to return to main menu	

Use arrow keys, <Tab> key and <Enter> to move between items and for selection.
<PgUp>, <PgDn>, <+> or <-> are used to change the selected parameter,
<Esc> – to return to the Main Menu.

The following table presents explanations on "Basic CMOS Configuration" menu screen

Table 5.2: Basic CMOS Configuration Menu Items

Menu Item	Function
Date Time	These items allow you to set system date and time.
First Boot From	Selection of disk name to boot from first. Choice set: A:, C:, CDROM:
F1 Error Wait	Enables or disables waiting for pressing of <F1> key on error
NumLock	Allows to control the state of a numeric keypad after boot Enabled – NumLock On; Disabled – NumLock Off
Typematic Delay	Sets typematic delay of the keyboard in milliseconds
Typematic Rate	Keyboard: autorepeat rate setting in characters per second
Boot Method	Operating system boot mode. Options: Boot Sector – for operating systems using boot sector to load; Windows CE – to load Windows CE image using the internal loader
Onboard ROM Disk	–
Onboard Flash Disk	Enables or disables the on-board flash-disk

Menu Item	Function
IDE DRIVE GEOMETRY: Master Slave Compact Flash	IDE disk drive geometry selection for Primary Master (Master), Primary Slave (Slave) and Secondary Master (Compact Flash). Options: Not installed – disk drive not connected; Autoconfig, Normal – automatic geometry detection without disk parameters translation; Autoconfig LBA – automatic geometry detection with translation of disk parameters into linear address; Large – disk parameters translation using Phoenix algorithm; CDROM – CDROM drive installed
1 st Disk (Disk C:)	Selection of a disk drive to assign "C:" Choice set: IDE Master; IDE Slave; Compact Flash; On Board Flash Disk
Floppy Disk Drive	FDD (Floppy 0) type selection. Options: Not Installed – FDD is not connected 360 KB, 5.25"; 1.2 MB, 5.25"; 720 KB, 3.5"; 1.44 MB, 3.5"; 2.88 MB, 3.5"
Memory: Base: Ext:	Base and Extended memory size indication

5.4 Custom Configuration

Custom Configuration menu screen is shown on the following figure:

Figure 5.3: Custom Configuration Menu Screen

System BIOS Setup - Custom Configuration						
(C) 2003 General Software, Inc. All rights reserved						
Console Input		:	KBD	IRQ1	:	PS/2 Kbd
Console Output		:	VGA	IRQ6	:	FDC
PS/2 Mouse		:	Disabled	IRQ7	:	LPT
COM3..COM6 Base Address		:	100h	IRQ9	:	COM3..COM6
COM3..COM6 Clock, MHz		:	1.8432	IRQ11	:	COM3..COM6
COM3..COM6 IRQ Inversion		:	OFF	IRQ12	:	PS/2 Mouse
COM3 Mode		:	RS232	IRQ14	:	OPTO_IRQ
COM4 Mode		:	RS232	IRQ15	:	NAND_FLASH
COM5 Mode		:	RS232	DRQ2	:	FDC
COM6 Mode		:	RS232	FDC/LPT Pins	:	FDC
PFO -> NMI		:	>Disabled			
<CR>/<Tab> to select or <PgUp>/<PgDn>/+/- to modify <Esc> to return to main menu						

Custom Configuration menu items are described in the table below.

Table 5.3: Custom Configuration Menu Items

Menu Item	Options	Description
Console Input	COM1 COM1+KBD KBD	Input via COM1(default). Terminal setting should be: 115200, n, 8, 1; Input via PS/2 keyboard port and COM1; Input via PS/2 keyboard port
Console Output	COM1 COM1+VGA VGA	Output to COM1 (default). Transmission parameters: 115200, n, 8, 1; Output to COM1 and video-controller; Output to video-controller
COM3...COM6 Base Address	100H 180H 200H 280H	COM3...COM6 ports base address selection
COM3...COM6 Clock, MHz	1.8432 MHz 14.7456 MHz	COM3...COM6 ports frequency selection. When frequency of 14.7456 is selected, the exchange rate is eight times as much compared to standard one.
COM3...COM6 IRQ Inversion	Disabled Enabled	IRQ request lines bits inversion in interrupts ID register. The inversion may be needed to provide compatibility with multi-port card drivers.

Menu Item	Options	Description
COM3 Mode COM4 Mode COM5 Mode COM6 Mode	RS232 RS422 RS485	COM3...COM6 ports operation mode selection
FDC/LPT Pins	FDC LPT Disabled	J15 connector device selection. When "Disabled" is selected, the LPT and FDD address ranges can be used by other interface devices.
IRQ1	PS/2 Kbd Matrix Kbd	Interrupt source: PS/2 keyboard Matrix keypad, connected to J17 connector
IRQ6	FDC PC/104	IRQ6 from floppy disk controller IRQ6 from PC/104 interface
IRQ7	LPT PC/104	IRQ7 from printer controller IRQ7 from PC/104 interface
IRQ9	COM3...COM6 PC/104	IRQ9 from COM3...COM6 ports IRQ9 from PC/104 interface
IRQ11	COM3...COM6 PC/104	IRQ11 from COM3...COM6 ports IRQ11 from PC/104 interface
IRQ12	PS/2 mouse PC/104	IRQ12 from PS/2 mouse IRQ12 from PC/104 interface
IRQ14	OPTO_IRQ PC/104	IRQ14 from optoisolated input IRQ14 from PC/104 interface This interrupt is available only if IDE Primary channel is disabled: Master – Not Installed, Slave – Not Installed
IRQ15	NAND_FLASH PC/104	IRQ15 from NAND Flash IRQ15 from PC/104 interface This interrupt is available only if IDE Secondary channel is disabled: Compact Flash – Not Installed
DRQ2	FDC PC/104	DMA channel is used by floppy disk controller DMA channel is available for external devices via PC/104 interface
PFO->NMI	Disabled Enabled	If enabled, connects the PFO signal to NMI. PFO (Power Fail Output) signal is issued by a supervisor if power voltage becomes lower than nominal value.
Remember! Wrong or incorrect settings may lead to abnormal system performance. To correct possible errors, restart the BIOS Setup program and restore manufacturer's settings by selection of "Reset CMOS to factory defaults" command in Main menu.		

5.5 PnP Configuration

This BIOS Setup section provides access to Plug-and-Play related IRQ and DMA assignments. The menu screen is shown in the figure below.

Figure 5.4: Plug-n-Play Configuration Menu Screen Image


System BIOS Setup - Plug-n-Play Configuration (C) 2003 General Software, Inc. All rights reserved			
Enable PnP Support	:>Enabled	Enable PnP O/S	: Enabled
Assign IRQ0 to PnP	: Disabled	Assign IRQ8 to PnP	: Disabled
Assign IRQ1 to PnP	: Disabled	Assign IRQ9 to PnP	: Enabled
Assign IRQ2 to PnP	: Disabled	Assign IRQ10 to PnP	: Enabled
Assign IRQ3 to PnP	: Enabled	Assign IRQ11 to PnP	: Enabled
Assign IRQ4 to PnP	: Enabled	Assign IRQ12 to PnP	: Disabled
Assign IRQ5 to PnP	: Enabled	Assign IRQ13 to PnP	: Enabled
Assign IRQ6 to PnP	: Disabled	Assign IRQ14 to PnP	: Disabled
Assign IRQ7 to PnP	: Enabled	Assign IRQ15 to PnP	: Disabled
Assign DMA0 to PnP	: Disabled	Assign DMA4 to PnP	: Enabled
Assign DMA1 to PnP	: Disabled	Assign DMA5 to PnP	: Enabled
Assign DMA2 to PnP	: Disabled	Assign DMA6 to PnP	: Enabled
Assign DMA3 to PnP	: Enabled	Assign DMA7 to PnP	: Enabled
↑/↓/→/←/<CR>/<Tab> to select or <PgUp>/<PgDn>/+/- to modify <Esc> to return to main menu			

All items allow to choose between the two options – “Enabled” or “Disabled”. Use arrow keys, <Tab> key and <Enter> to move between items and for selection. <PgUp>, <PgDn>, <+> or <-> are used to change the selected parameter, <Esc> – to return to the Main Menu.

5.6 Shadow Configuration

The figure below presents the Shadow Configuration menu screen.

Figure 5.5: Shadow Configuration Menu Screen Image



All items allow to choose between the two options – “Enabled” or “Disabled”. Use arrow keys, <Tab> key and <Enter> to move between items and for selection. <PgUp>, <PgDn>, <+> or <-> are used to change the selected parameter, <Esc> – to return to the Main Menu.

If "Enabled" is selected, Shadow Configuration menu items allow to copy extension modules' BIOS into operating memory by 16 KB blocks on initialization of the processor module.

5.7 Manufacturing Link Mode

Manufacturing Link mode allows to exchange files between the module and a remote PC via RS232 link. To do so the driver mfgdrv.sys should be loaded into PC memory. In this case the disk drives of the CPB902 become available at the PC as logical units. The config.sys initialization string for loading mfgdrv.sys into PC memory should look like this:

```
DEVICE=MFGDRV.SYS /BAUD=115K /PORT=COMn /UNIT=u
```

where:

PORT – PC COM port number (COM1, COM2)

UNIT – Module's disk drive, which will be available at the PC via COM port
(u=0 – disk A; u=1 – disk B; u=80 – disk C; u=81 – disk D etc.)

For example, if C: is the last PC disk drive, then in Manufacturing Link mode after mfgdrv.sys is loaded with the following parameters:

```
DEVICE=MFGDRV.SYS /BAUD=115K /PORT=COM2 /UNIT=0
```

```
DEVICE=MFGDRV.SYS /BAUD=115K /PORT=COM2 /UNIT=80
```

the drives D: and E: corresponding to the devices A: and C: of the module will appear on the PC.

The Manufacturing Link mode can also be used for formatting of the CPB902 disks and transferring of MS DOS or FDOS 6.22 operating systems.

To format a CPB902 disk and transfer MS DOS operating system:

- 1) Boot a PC with the operating system, which is to be transferred onto a CPB902 disk, and start the Manufacturing link mode;
- 2) On the PC enter the command

```
FORMAT Z: /S
```

where Z is a CPB902 drive name
- 3) Wait until the message "System transferred" appears.

To format a CPB902 disk and transfer FDOS 6.22 operating system:

- 1) Establish a connection between CPB902 and a PC in Manufacturing Link mode;
- 2) If Windows is running on the PC, enter the following command

```
LOCK Z:
```

where Z stands for a CPB902 disk name
- 3) From FDOS system directory on the PC enter the next command

```
SYS Z: /F:. /C
```
- 4) Wait until the messages "System transferred" and "COMMAND.COM transferred" appear.

5.8 The Rest Main Menu Commands

5.8.1 Reset CMOS to last known values

If you changed your mind and decided not to write the changes you have made in BIOS Setup program and have not yet saved the values in CMOS memory, you may select this command to return to the last saved parameters (i.e. to those with which the system was successfully booted last time) and continue with BIOS Setup.

On selection of this command the following message appears:

```
Reset CMOS to last known values? (Y/N):
```

Pressing “Y” resets the parameters in CMOS memory, “N” – returns you to the Main menu.

5.8.2 Reset CMOS to Factory Defaults

To reset the BIOS parameters to the values defined by the manufacturer, select this Main menu command. The program responds with this message:

```
Reset CMOS to Factory Defaults? (Y/N):
```

Pressing “Y” resets the values stored in CMOS to the Factory defaults and returns you to the Main menu, “N” returns you to the Main menu without changing anything.

5.8.3 Write to CMOS and Exit

After making your changes on the BIOS Setup menus, always select "Write to CMOS and Exit" to store the selections displayed in the menus in CMOS (short for "battery-backed CMOS RAM") a special section of nonvolatile memory that stays on after you power down your system. The next time you boot your computer, the BIOS configures your system according to the Setup parameters stored in CMOS memory.

On selection of this Main menu command, the program displays this message:

```
Save changes and exit? (Y/N):
```

If you choose “Y”, the program saves the BIOS Setup parameters to CMOS, exits BIOS Setup and reboots the system. “N” returns you to the Main menu.

During boot up, General Software® BIOS attempts to load and use the values stored in CMOS. If system does not boot with those values, reboot and press to enter BIOS Setup. In Setup, you can try to change the parameters that caused the boot failure or get the Factory Default Values.

5.8.4 Exit without changing CMOS

Use this option to exit Setup without storing in CMOS any changes you may have made. The previous parameters remain in effect.

The program displays this message:

```
Exit without changing CMOS? (Y/N):
```

“Y” confirms exiting without saving any changes, “N” – returns you to the Main menu.

5.9 Reset CMOS to Factory Defaults from a Remote PC

CMOS_RST.COM is a software utility, which allows to reset the BIOS setup parameters stored in CMOS memory to factory defaults from a remote PC. To do so, follow the procedure below.

1. Connect COM1 port of CPB902 to a PC COM port with a null-modem cable;
2. Start CMOS_RST.COM on a remote PC with the parameter:
`CMOS_RST.COM COM2`
where COM2 is a name of a PC COM port, to which the module is connected;
3. Switch on the module power. The PC monitor should display the following message:
"reset" acknowledged

5.10 Extended BIOS Functions

5.10.1 User Programs Interface with FRAM memory units

INT17H BIOS function is used to address FRAM memory. FRAM size, available to the user is 7 KB.

For read mode the following parameters are set:

ah = 0;
bx = address (offset) in the FRAM user area (0...1BFFh);
cx = number of bytes to read;
dx = 4657h ('FW');
es:[di] = <read data buffer>

For write mode the following parameters are set:

ah = 1;
bx = address (offset) in the FRAM user area (0...1BFFh);
cx = number of bytes to write;
dx = 4657h ('FW');
ds:[si] = write data buffer

On completion the functions return the result in C (CF) tag: NC = OK; CY = Error.

5.10.2 User LEDs Control

USER_LED1 and USER_LED2 user LEDs are switched on and off by writing logical 1 or 0 respectively to GPIO4 and GPIO5 lines of the GPIO processor unit. Sample LED control program code fragments are given below.

Attention! GPIO3 ... GPIO0 lines are used by the system.

Incorrect handling of these lines may lead to system failure.

```
//Enable GPIO processor unit
//32-bit output of the value 0x80006040 to 0xCF8 port
    outpd(0xCF8,0x80006040);
//32-bit input from 0xCFC port
    SB_MISC_REG_cont = inpd(0xCFC);
    if(!(SB_MISC_REG_cont & 0x2))
    {
        outpd(0xCF8,0x80006040);
//Enable GPIO unit
        outp(0xCFC,SB_MISC_REG_cont|0x02);
    }
//Obtaining GPIO base address and saving it to gpio_base variable
    outpd(0xCF8,0x80006044);
    gpio_base = inpw(0xCFC)&0xFFFE;
//Check the lines direction
    direction_reg_cont = inp(gpio_base);
    if(direction_reg_cont&0x30)
    {
//Set GPIO4 and GPIO5 lines to output
        outp(gpio_base,direction_reg_cont&0xCF);
    }
//Get GPIO lines state from data source
    read_control_reg_cont = inp(gpio_base+1);
    if(read_control_reg_cont)
//GPIO state read directly from GPIO lines
        outp(gpio_base+1,0x00);
//Switch USER_LED1 on/off
    if(inp(gpio_base+6)&0x10)
//Switch USER_LED1 off
        outp(gpio_base+6,inp(gpio_base+6)&0xEF);
    else
//Switch USER_LED1 on
        outp(gpio_base+6,inp(gpio_base+6)|0x10);
//Switch USER_LED2 on/off
    if(inp(gpio_base+6)&0x20)
//Switch USER_LED2 off
        outp(gpio_base+6,inp(gpio_base+6)&0xDF);
    else
// Switch USER_LED2 on
        outp(gpio_base+6,inp(gpio_base+6)|0x20);
```

More details on GPIO unit operation can be found in STPC Vega Programming manual.

5.10.3 SuperIO FDC37B787 Watchdog Timer Operation

The SuperIO FDC37B787 internal WDT has software adjustable (programmable) timeout period from 1 second up to 255 minutes. Upon expiry of the timeout the RESET signal is issued by the WDT, unless it is reset by the user program. Sample program code fragments setting and clearing the WDT are given below.

```
//SuperIO configuration register setting function
void write_cfg_reg(BYTE log_dev,BYTE reg_ind,BYTE value)
{
    asm{
        mov dx,0x370
        mov al,0x55
        cli
        out dx,al
        sti
        mov dx,0x370
        mov al,0x07
        out dx,al
        mov dx,0x371
        mov al,log_dev
        out dx,al
        mov dx,0x370
        mov al,reg_ind
        out dx,al
        mov dx,0x371
        mov al,value
        out dx,al
        mov dx,0x370
        mov ax,0xAA
        out dx,al
    }
}

//Watchdog timer setup
//WDT timeout variable
wdt_timeout=10;
//WDT timeout in seconds (write to configuration register WDT_UNITS)
write_cfg_reg(0x08,WDT_UNITS,0x80);
//Set GP12 line to work with the WDT (GP12 configuration register)
write_cfg_reg(0x08,GP12,0x0A).
//Reset the WDT in a user program
do
{
    //Any actions ...
    //Write the timeout value to WDT_VAL configuration register
    write_cfg_reg(0x08,WDT_VAL,wdt_timeout);
    // Any actions ...
}while(!Exit);
```

More details on SuperIO FDC37B787 operation can be found in SuperIO FDC37B787 Data sheet.

5.10.4 ADM8697 Supervisor's Watchdog Timer Operation

This watchdog timer has fixed timeout period from 4.5 to 10.5 seconds depending on supervisor chip parameters. Upon expiry of the timeout the WDT resets the system, unless it is reset by the user program. Sample program code fragments for setting and recurring resetting the ADM8697 WDT are given below. To reset the WDT the GPIO6 line of the GPIO processor unit is used.

Attention! GPIO3 ... GPIO0 lines are used by the system.

Incorrect handling of these lines may lead to system failure.

```
//Enable GPIO unit
//32-bit output of the value 0x80006040 to 0xCF8 port
outpd(0xCF8,0x80006040);
//32-bit input from 0xCFC port
SB_MISC_REG_cont = inpd(0xCFC);
if(!(SB_MISC_REG_cont & 0x2))
{
    outpd(0xCF8,0x80006040);
}
//Enable GPIO unit
outp(0xCFC,SB_MISC_REG_cont|0x02);
}
//Obtaining GPIO base address and saving it to gpio_base variable
outpd(0xCF8,0x80006044);
gpio_base = inpw(0xCFC)&0xFFFE;
//Check the GPIO line direction
direction_reg_cont = inp(gpio_base);
if(direction_reg_cont&0x40)
{
    //Set GPIO6 line to output
    outp(gpio_base,direction_reg_cont&0xBF);
}
//Get GPIO lines state from data source
read_control_reg_cont = inp(gpio_base+1);
if(read_control_reg_cont)
//GPIO state read directly from GPIO lines
    outp(gpio_base+1,0x00);
//Reset the WDT in a user program
do
{
    //Any actions ...

    //WDT reset
    outp(gpio_base+6, inp(gpio_base+6)|0x40);
    outp(gpio_base+6, inp(gpio_base+6)&0xBF);

    //Any actions ...

}while(!Exit);
```

More details on GPIO unit operation can be found in STPC Vega Programming manual.

5.10.5 Using INT 17H BIOS Extension to Control the Watchdog Timers

INT 17H extensions which allow to access the watchdog timers and to support their operation are described below.

SIO WDT1 control

- **WDT1 enable;**

Input parameters:

AH=11h;

CX=TIMEOUT in seconds. If CX > 255, the value is rounded down to a number, divisible by 60;

DX=4657h.

Returned value:

CF=NC (on successful completion);

CF=CY (if incorrect value is specified in CX).

- **WDT1 strobing**

Input parameters:

AH=12h;

DX=4657h.

- **Disable WDT1**

Input parameters:

AH=13h;

DX=4657h.

Supervisor's WDT control (WDT2)

- **Enable WDT2**

Input parameters:

AH=21h;

DX=4657h.

- **WDT2 strobing**

Input parameters:

AH=22h;

DX=4657h.

- **Disable WDT2**

Input parameters:

AH=23h;

DX=4657h.

To control the WDT2 the OCTAGON interface can be used as well:

- **Enable WDT2**

Input parameters:

AX=0FD01h;

DX=0FFFFh.

- **WDT2 strobing**

Input parameters:

AX=0FD02h4

DX=0FFFFh.

- **Disable WDT2**

Input parameters:

AX=0FD03h;

DX=FFFFh.

INT17H call

Input parameters:

AH=0Fh;

DX=4657H.

Returned value:

AL=310h register state after FPGA is loaded.

Bit 1 set to "1" indicates that the module has rebooted at the command of WDT.

Appendix A

A Jumper Settings by Function

Table A.1: Jumper Settings by Function

Function	Jumper	Short Description (*)
Terminators on COM3 in RS-422/RS-485 modes	J6: 1-2	Enable terminator between RX+ and RX- lines of COM3 port in RS422 mode
	J6: 3-4	Enable terminator between TX+ and TX- lines of COM3 port in RS422 mode or between D+ and D- lines of COM3 port in RS485 mode
Terminators on COM4 in RS-422/RS-485 modes	J8: 1-2	Enable terminator between RX+ and RX- lines of COM4 port in RS422 mode
	J8: 3-4	Enable terminator between TX+ and TX- lines of COM4 port in RS422 mode or between D+ and D- lines of COM4 port in RS485 mode
Terminators on COM5 in RS-422/RS-485 modes	J10: 1-2	Enable terminator between RX+ and RX- lines of COM5 port in RS422 mode
	J10: 3-4	Enable terminator between TX+ and TX- lines of COM5 port in RS422 mode or between D+ and D- lines of COM5 port in RS485 mode
Terminators on COM6 in RS-422/RS-485 modes	J12: 1-2	Enable terminator between RX+ and RX- lines of COM6 port in RS422 mode
	J12: 3-4	Enable terminator between TX+ and TX- lines of COM6 port in RS422 mode or between D+ and D- lines of COM6 port in RS485 mode
Microprocessor RESET signal source selection	J13: 1-2	Enable module reset by supervisor's WDT
	J13: 3-4	Enable module reset by SIO internal WDT
	J13: 5-6	Enable module reset by optoisolated input signal
	J13: 7-8	Enable the optoisolated input as IRQ14 source
Connection of the battery to RTC	J19: 1-2	If closed the battery is connected to RTC
ROM1 addressing. Switching between main and reserve BIOS copies	J19: 5-6	Enable lower ROM BIOS part addressing. If the jumper is not set, the upper part of ROM BIOS is addressed (with main BIOS copy). Closing the jumper enables the reserve copy of BIOS.
Connection of +5 V to FBUS connector	J19: 3-4	If the jumper is closed +5 V is supplied to FBUS connector power contacts (VCC_FBUS)
		(*) The action described in this column corresponds to the closed jumper contacts

Appendix B

B Jumper Settings by Assignment

Table B.1: Jumper Settings by Assignment

Jumper	Assignment
J13: 1-2	Enable module reset by supervisor's WDT
J13: 3-4	Enable module reset by SIO WDT
J13: 5-6	Enable module reset by optoisolated input signal
J13: 7-8	Enable the optoisolated input as IRQ14 source
J6: 1-2	Enable terminator between RX+ and RX- lines of COM3 port in RS422 mode
J6: 3-4	Enable terminator between TX+ and TX- lines of COM3 port in RS422 mode or between D+ and D- lines of COM3 port in RS485 mode
J8: 1-2	Enable terminator between RX+ and RX- lines of COM4 port in RS422 mode
J8: 3-4	Enable terminator between TX+ and TX- lines of COM4 port in RS422 mode or between D+ and D- lines of COM4 port in RS485 mode
J10: 1-2	Enable terminator between RX+ and RX- lines of COM5 port in RS422 mode
J10: 3-4	Enable terminator between TX+ and TX- lines of COM5 port in RS422 mode or between D+ and D- lines of COM5 port in RS485 mode
J12: 1-2	Enable terminator between RX+ and RX- lines of COM6 port in RS422 mode
J12: 3-4	Enable terminator between TX+ and TX- lines of COM6 port in RS422 mode or between D+ and D- lines of COM6 port in RS485 mode
J19: 1-2	Enable connection of battery to the RTC
J19: 3-4	Enable +5 V on FBUS connector power contacts (VCC_FBUS)
J19: 5-6	Switch addressing to lower part of ROM BIOS
Note: The Assignment column describes the action corresponding to the closed jumper position	