



# GD50 HYDRAULIC ROD DRIVER


## **⚠ WARNING**

SERIOUS INJURY OR DEATH  
COULD RESULT FROM IM-  
PROPER REPAIR OR SERVICE  
OF THIS TOOL.

REPAIRS AND/OR SERVICE  
TO THIS TOOL MUST ONLY  
BE DONE BY AN AUTHORIZED  
AND CERTIFIED DEALER.

## **⚠ WARNING**

To avoid serious injury or death



## SAFETY, OPERATION AND MAINTENANCE USER'S MANUAL



© Stanley Hydraulic Tools 2005  
OPS/MAINT USA / CE  
Printed in U.S.A.  
39234 5/2005 ver 4

Stanley Hydraulic Tools  
3810 SE Naef Road  
Milwaukie OR 97267-5698  
503-659-5660  
FAX 503-652-1780  
[www.stanley-hydraulic-tools.com](http://www.stanley-hydraulic-tools.com)

---

---

---

# TABLE OF CONTENTS

---

SAFETY SYMBOLS.....	4
SAFETY PRECAUTIONS.....	5
TOOL STICKERS & TAGS.....	6
HYDRAULIC HOSE REQUIREMENTS.....	7
HOSE TYPES.....	7
HOSE SAFETY TAGS.....	7
HTMA REQUIREMENTS.....	8
OPERATION.....	9
PREOPERATION PROCEDURES.....	9
PREPARATION FOR INITIAL USE.....	9
CHECK TOOL.....	9
CHECK TRIGGER MECHANISM.....	9
CONNECT HOSES.....	9
OPERATING PROCEDURES.....	9
INLINE CONTROL VALVE OPERATION.....	9
SETTING FOR OPEN CENTER (O.C.) OR CLOSED CENTER (C.C.).....	9
INSTALLING THE VALVE.....	10
OPERATING THE VALVE.....	10
COLD WEATHER OPERATION.....	10
CHARGING THE ACCUMULATOR.....	11
TESTING THE ACCUMULATOR PRESSURE.....	11
EQUIPMENT PROTECTION & CARE.....	12
TROUBLESHOOTING.....	13
SPECIFICATIONS.....	14
SPECIAL TOOLS.....	14
PARTS ILLUSTRATION.....	15
PARTS LIST.....	16
WARRANTY.....	17

**SERVICING THE STANLEY HYDRAULIC Rod Driver.** This manual contains safety, operation, and routine maintenance instructions. Stanley Hydraulic Tools recommends that servicing of hydraulic tools, other than routine maintenance, must be performed by an authorized and certified dealer. Please read the following warning.

**⚠ WARNING**

**SERIOUS INJURY OR DEATH COULD RESULT FROM THE IMPROPER REPAIR OR SERVICE OF THIS TOOL.**

**REPAIRS AND / OR SERVICE TO THIS TOOL MUST ONLY BE DONE BY AN AUTHORIZED AND CERTIFIED DEALER.**

For the nearest authorized and certified dealer, call Stanley Hydraulic Tools at the number listed on the back of this manual and ask for a Customer Service Representative.

---

# SAFETY SYMBOLS

---

Safety symbols and signal words, as shown below, are used to emphasize all operator, maintenance and repair actions which, if not strictly followed, could result in a life-threatening situation, bodily injury or damage to equipment.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



This safety alert and signal word indicate an imminently hazardous situation which, if not avoided, will result in death or serious injury.



This safety alert and signal word indicate a potentially hazardous situation which, if not avoided, could result in death or serious injury.



This safety alert and signal word indicate a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



This signal word indicates a potentially hazardous situation which, if not avoided, may result in property damage.



This signal word indicates a situation which, if not avoided, will result in damage to the equipment.



This signal word indicates a situation which, if not avoided, may result in damage to the equipment.

Always observe safety symbols. They are included for your safety and for the protection of the tool.

## LOCAL SAFETY REGULATIONS

Enter any local safety regulations here. Keep these instructions in an area accessible to the operator and maintenance personnel.

---

---

---

---

---

---

---

---


---

---

---

# SAFETY PRECAUTIONS

---



Tool operators and maintenance personnel must always comply with the safety precautions given in this manual and on the stickers and tags attached to the tool and hose.


These safety precautions are given for your safety. Review them carefully before operating the tool and before performing general maintenance or repairs.

Supervising personnel should develop additional precautions relating to the specific work area and local safety regulations. If so, place the added precautions in the space provided in this manual.

The GD50 Hydraulic Rod Driver will provide safe and dependable service if operated in accordance with the instructions given in this manual. Read and understand this manual and any stickers and tags attached to the tool and hoses before operation. Failure to do so could result in personal injury or equipment damage.

- Operator must start in a work area without bystanders. The operator must be familiar with all prohibited work areas such as excessive slopes and dangerous terrain conditions.
- Establish a training program for all operators to ensure safe operation.
- Do not operate the tool unless thoroughly trained or under the supervision of an instructor.
- Always wear safety equipment such as goggles, ear and head protection, and safety shoes at all times when operating the tool.
- Do not inspect or clean the tool while the hydraulic power source is connected. Accidental engagement of the tool can cause serious injury.
- Always connect hoses to the tool hose couplers before energizing the hydraulic power source. Be sure all hose connections are tight.
- Do not operate the tool at oil temperatures above 140°F/60°C. Operation at higher temperatures can cause higher than normal temperatures at the tool which can result in operator discomfort.
- Do not operate a damaged, improperly adjusted, or incompletely assembled rod driver.
- Do not weld, cut with an acetylene torch, or hardface the rod driver anvil or guide housing.
- To avoid personal injury or equipment damage, all tool repair, maintenance and service must only be performed by authorized and properly trained personnel.
- Always replace parts with replacement parts recommended by Stanley Hydraulic Tools.
- Check fastener tightness often and before each use daily.

# TOOL STICKERS & TAGS



## GD50 ROD DRIVER

FLOW: 26-34 LPM/7-9 GPM  
 PRESS: 105-140 BAR  
 1500-2000 PSI  
 ACCUMULATOR CHG:  
 42 BAR/600 PSI NITROGEN



The safety tag (p/n 15875) at right is attached to the tool when shipped from the factory. Read and understand the safety instructions listed on this tag before removal. We suggest you retain this tag and attach it to the tool when not in use.

**DANGER**

1. FAILURE TO USE HYDRAULIC HOSE **LABELED AND CERTIFIED AS NON-CONDUCTIVE** WHEN USING HYDRAULIC TOOLS ON OR NEAR ELECTRICAL LINES MAY RESULT IN DEATH OR SERIOUS INJURY.

BEFORE USING HOSE **LABELED AND CERTIFIED AS NON-CONDUCTIVE** ON OR NEAR ELECTRICAL LINES BE SURE THE HOSE IS **MAINTAINED AS NON-CONDUCTIVE**. THE HOSE SHOULD BE REGULARLY TESTED FOR ELECTRIC CURRENT LEAKAGE IN ACCORDANCE WITH YOUR SAFETY DEPARTMENT INSTRUCTIONS.

2. A HYDRAULIC LEAK OR BURST MAY CAUSE OIL INJECTION INTO THE BODY OR CAUSE OTHER SEVERE PERSONAL INJURY.

A **DO NOT** EXCEED SPECIFIED FLOW AND PRESSURE FOR

**IMPORTANT**

**READ OPERATION MANUAL AND SAFETY INSTRUCTIONS FOR THIS TOOL BEFORE USING IT.**

**USE ONLY PARTS AND REPAIR PROCEDURES APPROVED BY STANLEY AND DESCRIBED IN THE OPERATION MANUAL.**

**TAG TO BE REMOVED ONLY BY TOOL OPERATOR.**

**DANGER**

D **DO NOT** LIFT OR CARRY TOOL BY THE HOSES. **DO NOT** ABUSE HOSE. **DO NOT** USE KINKED, TORN OR DAMAGED HOSE.

3. MAKE SURE HYDRAULIC HOSES ARE PROPERLY CONNECTED TO THE TOOL BEFORE PRESSURING SYSTEM. SYSTEM PRESSURE HOSE MUST ALWAYS BE CONNECTED TO TOOL "IN" PORT. SYSTEM RETURN HOSE MUST ALWAYS BE CONNECTED TO TOOL "OUT" PORT. REVERSING CONNECTIONS MAY CAUSE REVERSE TOOL OPERATION WHICH CAN RESULT IN SEVERE PERSONAL INJURY.

4. **DO NOT** CONNECT OPEN-CENTER TOOLS TO CLOSED-CENTER HYDRAULIC SYSTEMS. THIS MAY RESULT IN LOSS OF OTHER HYDRAULIC FUNCTIONS POWERED BY THE SAME SYSTEM AND/OR SEVERE PERSONAL INJURY.

5. BYSTANDERS MAY BE INJURED IN YOUR WORK AREA. KEEP BYSTANDERS CLEAR OF YOUR WORK AREA.

**IMPORTANT**

**READ OPERATION MANUAL AND SAFETY INSTRUCTIONS FOR THIS TOOL BEFORE USING IT.**

**USE ONLY PARTS AND REPAIR PROCEDURES APPROVED BY STANLEY AND DESCRIBED IN THE OPERATION MANUAL.**

**TAG TO BE REMOVED ONLY BY TOOL OPERATOR.**

SAFETY TAG P/N 15875 (shown smaller than actual size)

# HYDRAULIC HOSE REQUIREMENTS

## HOSE TYPES

Hydraulic hose types authorized for use with Stanley Hydraulic Tools are as follows:

- ❶ Certified non-conductive
- ❷ Wire-braided (conductive)
- ❸ Fabric-braided (not certified or labeled non-conductive)

Hose ❶ listed above is the only hose authorized for use near electrical conductors.


Hoses ❷ and ❸ listed above are **conductive** and **must never** be used near electrical conductors.

## HOSE SAFETY TAGS


To help ensure your safety, the following DANGER tags are attached to all hose purchased from Stanley Hydraulic Tools. **DO NOT REMOVE THESE TAGS.**

If the information on a tag is illegible because of wear or damage, replace the tag immediately. A new tag may be obtained from your Stanley Distributor.

### THE TAG SHOWN BELOW IS ATTACHED TO “CERTIFIED NON-CONDUCTIVE” HOSE



### THE TAG SHOWN BELOW IS ATTACHED TO “CONDUCTIVE” HOSE.



## HOSE PRESSURE RATING

The rated working pressure of the hydraulic hose **must be equal to or higher than** the relief valve setting on the hydraulic system.

# HTMA REQUIREMENTS

## TOOL CATEGORY



## HYDRAULIC SYSTEM REQUIREMENTS

**TYPE I**

**TYPE II**

**TYPE III**

**TYPE RR**

FLOW RATE	4-6 gpm (15-23 lpm)	7-9 gpm (26-34 lpm)	11-13 gpm (42-49 lpm)	9-10.5 gpm (34-40 lpm)
TOOL OPERATING PRESSURE (at the power supply outlet)	2000 psi (138 bar)	2000 psi (138 bar)	2000 psi (138 bar)	2000 psi (138 bar)
SYSTEM RELIEF VALVE SETTING (at the power supply outlet)	2100-2250 psi (145-155 bar)	2100-2250 psi (145-155 bar)	2100-2250 psi (145-155 bar)	2200-2300 psi (152-159 bar)
MAXIMUM BACK PRESSURE (at tool end of the return hose)	250 psi (17 bar)	250 psi (17 bar)	250 psi (17 bar)	250 psi (17 bar)
Measured at a max. fluid viscosity of: (at min. operating temperature)	400 ssu* (82 centistokes)	400 ssu* (82 centistokes)	400 ssu* (82 centistokes)	400 ssu* (82 centistokes)
TEMPERATURE Sufficient heat rejection capacity to limit max. fluid temperature to: (at max. expected ambient temperature)	140° F (60° C)	140° F (60° C)	140° F (60° C)	140° F (60° C)
Min. cooling capacity at a temperature difference of between ambient and fluid temps	3 hp (2.24 kW) 40° F (22° C)	5 hp (3.73 kW) 40° F (22° C)	7 hp (4.47 kW) 40° F (22° C)	6 hp (5.22 kW) 40° F (22° C)
<b>NOTE:</b> Do not operate the tool at oil temperatures above 140° F (60° C). Operation at higher temperatures can cause operator discomfort at the tool.				
FILTER Min. full-flow filtration Sized for flow of at least: (For cold temp. startup and max. dirt-holding capacity)	25 microns 30 gpm (114 lpm)	25 microns 30 gpm (114 lpm)	25 microns 30 gpm (114 lpm)	25 microns 30 gpm (114 lpm)
HYDRAULIC FLUID Petroleum based (premium grade, anti-wear, non-conductive) VISCOSITY (at min. and max. operating temps)	100-400 ssu*	100-400 ssu* (20-82 centistokes)	100-400 ssu*	100-400 ssu*
<b>NOTE:</b> When choosing hydraulic fluid, the expected oil temperature extremes that will be experienced in service determine the most suitable temperature viscosity characteristics. Hydraulic fluids with a viscosity index over 140 will meet the requirements over a wide range of operating temperatures.				

\*SSU = Saybolt Seconds Universal

### NOTE:

These are general hydraulic system requirements. See tool Specification page for tool specific requirements.



---

# OPERATION

---

## PREOPERATION PROCEDURES

---

### PREPARATION FOR INITIAL USE

Each unit as shipped has no special unpacking or assembly requirements prior to usage. Inspection to assure the unit was not damaged in shipping and does not contain packing debris is all that is required.  
Check Hydraulic Power Source

1. Using a calibrated flowmeter and pressure gauge, check that the hydraulic power source develops a flow of 7-9 gpm/26-34 lpm for HTMA type II tools/EHTMA category D at 2000 psi/105-140 bar.
2. Make certain the hydraulic power source is equipped with a relief valve set to open at 2100-2250 psi/145-155 bar minimum.
3. Check that the hydraulic circuit matches the tool for open-center (OC) operation.

### CHECK TOOL

1. Make sure the tool contains the correct anvil for the rod size to be driven. Use the 5/8 inch anvil (standard in the model GD50132RF Rod Driver) for 5/8 inch diameter rod. Use the 1 inch anvil (standard in the model GD50133RF Rod Driver) for 3/4 inch to 1 inch diameter rod. Failure to use the correct anvil with the appropriate rod size can result in damage to the tool or personal injury.
2. There should be no signs of leaks.
3. The tool should be clean, with all fittings and fasteners tight.

### CHECK TRIGGER MECHANISM

1. Check that the trigger operates smoothly and is free to travel between the "ON" and "OFF" positions.

### CONNECT HOSES

1. Wipe all hose couplers with a clean lint-free cloth before making connections.
2. Connect the hoses from the hydraulic power source to the hose couplers on the rod driver. It is a good practice to connect the return hose first and disconnect it last to minimize or avoid trapped pressure within the rod driver.

3. Observe flow indicators stamped on hose couplers to be sure that oil will flow in the proper direction. The female coupler is the inlet coupler.

#### Note:

**The pressure increase in uncoupled hoses left in the sun may result in making them difficult to connect. When possible, connect the free ends of operating hoses together.**

---

## OPERATING PROCEDURES

---

1. Observe all safety precautions.
2. Move the hydraulic circuit control valve to the "ON" position.
3. Place the anvil of the rod driver over the rod to be driven.
4. Ensure adequate down pressure is applied to the rod driver before starting the rod driver. To start the rod driver, press the button on the control valve to the "ON" position. Adequate down pressure is very important. When you wish to stop the tool, press the button on the control valve to the "OFF" position.

---

## INLINE CONTROL VALVE OPERATION

---

The 38632 Inline Control Valve is designed to provide the ON/OFF functions for a hydraulic tool connected to either an OPEN CENTER (O.C.) hydraulic system or an CLOSED CENTER (C.C.) hydraulic system. The valve is to be used with tools which do not have an ON/OFF trigger control. The 38632 Control Valve can be used on hydraulic systems producing up to 10 gpm/38 lpm with a maximum relief valve setting of 2500 psi/172 bar. The valve ports are -8 SAE (3/4-16 thread) o-ring ports.

### SETTING FOR OPEN CENTER (O.C.) OR CLOSED CENTER (C.C.)

Set the valve to O.C. or C.C. before connecting it to the hydraulic system. To set the valve for open center operation, use a straight blade screw driver to turn the selector screw counter clockwise until it stops. To set the valve for closed center operation, turn the selector screw clockwise until it stops.

### CAUTION

**Be sure you know if you have an OPEN CENTER (O.C.) OR CLOSED CENTER (C.C.) hydraulic system, DO NOT attempt to install or operate the 38632 Valve until you do. Incorrect installation or operation of the valve can result in seal failures in the tool, cause excessive heat in the hydraulic system, and may damage the tool and hydraulic system. Understand which type of hydraulic system you are using before installing or operating this valve.**

# OPERATION

## INSTALLING THE VALVE


Connect the valve to the hydraulic system as shown in the illustration.

## OPERATING THE VALVE

Connect the valve to the tool using the illustration below as a guide. Make sure the valve spool on the valve is pushed OFF before connecting the valve to the hydraulic system. Make sure the hydraulic system is OFF before connecting the valve to the hydraulic system. Connect the valve to the hydraulic system. Turn ON the hydraulic system. Place the tool to be operated in its operating position. Push the valve spool ON to begin operating the tool. Push the valve spool OFF to stop operating the tool. Turn the hydraulic system OFF before disconnecting the valve.

## COLD WEATHER OPERATION

If the rod driver is to be used during cold weather, preheat the hydraulic fluid at low engine speed. When using the normally recommended fluids, fluid temperature should be at or above 50° F/10° C (400 ssu/82 centistokes) before use.



# CHARGING THE ACCUMULATOR

To check or charge the accumulator the following equipment is required:

- Charge kit (Part Number 31254) Includes the following:
  - Accumulator tester (Part Number 02835).
  - Charge assembly (Part Number 15304). Includes a liquid-filled gauge with snub valve, hose and fittings.
- NITROGEN bottle with a 800 psi/56 bar minimum charge (not a part of 31254 kit).

1. Holding the chuck end of the Stanley tester (p/n 02835), turn the gauge fully counterclockwise to ensure the stem inside the chuck is completely retracted.

2. Thread the tester onto the charging valve of the tool accumulator (do not advance the gauge-end into the chuck end. Turn as a unit). Seat the chuck on the accumulator charging valve by hand tightening only.

3. Advance the valve stem by turning the gauge- end clockwise.

4. Connect the charging assembly to the valve on the tester.

5. Adjust the regulator on the nitrogen bottle to 600 psi/42 bar.

## Note:

**It may be necessary to set the regulator at 650-700 psi/41-48 bar to overcome any pressure drop through the charging system.**

6. Open the valve on the charging assembly hose. When the tester gauge reads 600-700 psi/41-48 bar, close the valve on the charging assembly hose and remove the charging assembly.

7. Turn the gauge end of the tester fully counterclockwise to retract the plunger in the chuck. Remove the tester from the charge valve.


8. Replace the valve cap.

## TESTING THE ACCUMULATOR PRESSURE

1. Follow instructions 1 through 3 under "CHARGING THE ACCUMULATOR".

2. Read the pressure on the gauge. It should be between 500-700 psi/35-48 bar.

3. If the pressure is low, recharge the tool.



---

# EQUIPMENT PROTECTION & CARE

---

## NOTICE

In addition to the Safety Precautions in this manual, observe the following for equipment protection and care.

- Make sure all couplers are wiped clean before connection.
- The hydraulic circuit control valve must be in the “OFF” position when coupling or uncoupling hydraulic tools. Failure to do so may result in damage to the quick couplers and cause overheating of the hydraulic system.
- Always store the tool in a clean dry space, safe from damage or pilferage.
- Make sure the circuit PRESSURE hose (with male quick disconnect) is connected to the “IN” port. The circuit RETURN hose (with female quick disconnect) is connected to the opposite port. Do not reverse circuit flow. This can cause damage to internal seals.
- Always replace hoses, couplings and other parts with replacement parts recommended by Stanley Hydraulic Tools. Supply hoses must have a minimum working pressure rating of 2500 psi/172 bar.
- Do not exceed the rated flow (see Specifications) in this manual for correct flow rate and model number. Rapid failure of the internal seals may result.
- Always keep critical tool markings, such as warning stickers and tags legible.
- Tool repair should be performed by experienced personnel only.
- Make certain that the recommended relief valves are installed in the pressure side of the system.
- Do not use the tool for applications for which it was not intended.

# TROUBLESHOOTING

If symptoms of poor performance develop, the following chart can be used as a guide to correct the problem.

When diagnosing faults in operation of the spike driver, always check that the hydraulic power source is supplying the correct hydraulic flow and pressure to the spike driver as listed in the table. Use a flowmeter known to be accurate. Check the flow with the hydraulic oil temperature at least 80°F/27°C.

PROBLEM	CAUSE	SOLUTION
Rod driver does not run.	Power unit not functioning.	Check power unit for proper flow and pressure (7-9 gpm / 26-34 lpm at 2000 psi / 140 bar).
	Couplers or hoses blocked.	Remove restriction.
	Pressure and return line hoses reversed at ports.	Be sure hoses are connected to their proper ports.
	Mechanical failure of piston or automatic valve.	Have inspected and repaired by an authorized dealer.
Rod driver does not hit effectively.	Power unit not functioning.	Check power unit for proper flow and pressure (7-9 gpm / 26-34 lpm at 2000 psi / 140 bar).
	Couplers or hoses blocked.	Remove restriction.
	Low accumulator charge (pressure hose will pulse more than normal).	Have recharged by an authorized dealer.
	Fluid too hot. (above 140° F / 60° C)	Provide cooler to maintain proper fluid temperature.
	Rod anvil is not sliding freely in the anvil guide.	Remove, clean and replace as necessary.
Rod driver operates slow.	Low oil flow from power unit.	Check power source for proper flow.
	High back-pressure.	Check hydraulic system for excessive back-pressure and correct as required.

# SPECIFICATIONS

Capacity (Rod Anvil)

1/2 to 5/8 inch/12 to 16 mm diameter rod (model GD50132RF)

3/4 to 1 inch/19 to 25 mm diameter rod (model GD50133RF)

Pressure Range ..... 1500-2000 psi/105-140 bar

Maximum Back Pressure ..... 250 psi/17 bar

Flow Range ..... 7-9 gpm/26-34 lpm

Couplers ..... HTMA/EHTMA Flush Face Type Male & Female

Hose Whips ..... Yes

 Weight ..... 57.3 lbs./26 kg

Overall Length ..... 25.5 inches/64.8 cm


Overall Width ..... 10 inches/25.4 cm

Maximum Fluid Temperature ..... 140° F/60° C

# SPECIAL TOOLS

DESCRIPTION	PART NUMBER	USAGE
O-ring Tool Kit	04337	General Service of Seals
Split Rings	04908	Used with 04910
Flow Sleeve Removal Tool	04919	Flow Sleeve Removal
Flow Sleeve Removal Tube	04910	Used with 04908 & 05508
Bearing Puller Kit	05064	General Bearing Pulling
Accumulator Disassembly Tool	05508	Used with 04910
Tamper Sleeve Tool	01120	Used to Pull Porting Block from Valve Block
Accumulator Cylinder Puller	05640	An Aluminum Disk (handy for protecting parts when using an arbor press)

# PARTS ILLUSTRATION



# PARTS LIST

Item	Part No.	Qty.	Description
1	35770	2	Handle Bar
2	70351	4	Capscrew
3	07493	1	O-Ring Plug-Male
4	05243	1	Orifice Plug (Included with Item 13)
5	20499	1	Charge Valve
6	04374	4	Lock Nut
7	15190	1	Top Plate
8	00720	4	Set Screw
9	07479	1	Diaphragm
10	00293	1	O-ring
11	15188	1	Valve Spool
12	04058	1	Spring
13	11588	1	Accumulator Valve Block
14	01605	2	O-ring (Included with Item 15)
15	350000	2	Elbow, 45° (Included with item 14)
16	10536	1	Selector Screw
17	04381	2	Back-up Ring
18	04379	2	O-ring
19	04378	1	Porting Block
20	35784	2	Hose Assy
21	07480	1	Automatic Valve Body
22	16070	1	Retaining Ring
23	01003	2	Valve Button
24	13568	2	Back-up Ring
25	13567	2	O-ring
26	38631	1	Valve Spool
27	00936	2	Adaptor
28	24059	1	Male Coupler Body
29	24058	1	Female Coupler Body
30	04382	1	Automatic Valve
31	04571	2	Push Pin
32	02900	2	Roll Pin
33	37425	1	Name Tag
34	04383	1	Flow Sleeve Tube
35	04384	1	Flow Sleeve
36	04605	4	Push Pin

Item	Part No.	Qty.	Description
37	04954	1	Piston
38	02022	1	O-ring
39	04387	1	Wiper Ring
40	04780	1	Back-up Washer
41	04386	1	Cup Seal
42	12139	4	Side Rod
43	43527	1	Adaptor Block
44	12143	1	Upper Anvil Stop
45	12146	1	Spring
46	36106	1	Rod Anvil, 5/8 inch rods (Model GD50132)
	35751	1	Rod Anvil, 3/4 to 1 in. Rods (Model GD50133)
47	35752	1	Anvil Guide (Serial No. 429 & Below)
	65812	1	Anvil Guide (Serial No. 430 & Above)
48	35753	1	Guide Housing
49	38629	1	Valve Body Assy.
50	00026	1	O-ring
51	65813	1	Bumper (Used on Serial No. 430 & Above)
52	371071	2	Washer

Model GD50132RF - 1/2 and 5/8 inch rods.

Model GD50133RF - 3/4 and 1 inch rods.

**Verify the correct model number before ordering.**

## Seal Kit

**GD50 Rapid Fire Model - 04595**

**All Other Models - 13552**



---

# WARRANTY

---

Stanley Hydraulic Tools (hereinafter called "Stanley"), subject to the exceptions contained below, warrants new hydraulic tools for a period of one year from the date of sale to the first retail purchaser, or for a period of 2 years from the shipping date from Stanley, whichever period expires first, to be free of defects in material and/or workmanship at the time of delivery, and will, at its option, repair or replace any tool or part of a tool, or new part, which is found upon examination by a Stanley authorized service outlet or by Stanley's factory in Milwaukie, Oregon to be DEFECTIVE IN MATERIAL AND/OR WORKMANSHIP.

## EXCEPTIONS FROM WARRANTY

**NEW PARTS:** New parts which are obtained individually are warranted, subject to the exceptions herein, to be free of defects in material and/or workmanship at the time of delivery and for a period of 6 months after the date of first usage. Seals and diaphragms are warranted to be free of defects in material and/or workmanship at the time of delivery and for a period of 6 months after the date of first usage or 2 years after the date of delivery, whichever period expires first. Warranty for new parts is limited to replacement of defective parts only. Labor is not covered.

**FREIGHT COSTS:** Freight costs to return parts to Stanley, if requested by Stanley for the purpose of evaluating a warranty claim for warranty credit, are covered under this policy if the claimed part or parts are approved for warranty credit. Freight costs for any part or parts which are not approved for warranty credit will be the responsibility of the individual.

**SEALS & DIAPHRAGMS:** Seals and diaphragms installed in new tools are warranted to be free of defects in material and/or workmanship for a period of 6 months after the date of first usage, or for a period of 2 years from the shipping date from Stanley, whichever period expires first.

**CUTTING ACCESSORIES:** Cutting accessories such as breaker tool bits are warranted to be free of defects in material and or workmanship at the time of delivery only.

**ITEMS PRODUCED BY OTHER MANUFACTURERS:** Components which are not manufactured by Stanley and are warranted by their respective manufacturers.

- a. Costs incurred to remove a Stanley manufactured component in order to service an item manufactured by other manufacturers.

**ALTERATIONS & MODIFICATIONS:** Alterations or modifications to any tool or part. All obligations under this warranty shall be terminated if the new tool or part is altered or modified in any way.

**NORMAL WEAR:** any failure or performance deficiency attributable to normal wear and tear such as tool bushings, retaining pins, wear plates, bumpers, retaining rings and plugs, rubber bushings, recoil springs, etc.

**INCIDENTAL/CONSEQUENTIAL DAMAGES:** To the fullest extent permitted by applicable law, in no event will STANLEY be liable for any incidental, consequential or special damages and/or expenses.

**FREIGHT DAMAGE:** Damage caused by improper storage or freight handling.

**LOSS TIME:** Loss of operating time to the user while the tool(s) is out of service.

**IMPROPER OPERATION:** Any failure or performance deficiency attributable to a failure to follow the guidelines and/or procedures as outlined in the tool's operation and maintenance manual.

**MAINTENANCE:** Any failure or performance deficiency attributable to not maintaining the tool(s) in good operating condition as outlined in the Operation and Maintenance Manual.

**HYDRAULIC PRESSURE & FLOW, HEAT, TYPE OF FLUID:** Any failure or performance deficiency attributable to excess hydraulic pressure, excess hydraulic back-pressure, excess hydraulic flow, excessive heat, or incorrect hydraulic fluid.

**REPAIRS OR ALTERATIONS:** Any failure or performance deficiency attributable to repairs by anyone which in Stanley's sole judgement caused or contributed to the failure or deficiency.

**MIS-APPLICATION:** Any failure or performance deficiency attributable to mis-application. "Mis-application" is defined as usage of products for which they were not originally intended or usage of products in such a manner which exposes them to abuse or accident, without first obtaining the written consent of Stanley. PERMISSION TO APPLY ANY PRODUCT FOR WHICH IT WAS NOT ORIGINALLY INTENDED CAN ONLY BE OBTAINED FROM STANLEY ENGINEERING.

**WARRANTY REGISTRATION:** STANLEY ASSUMES NO LIABILITY FOR WARRANTY CLAIMS SUBMITTED FOR WHICH NO TOOL REGISTRATION IS ON RECORD. In the event a warranty claim is submitted and no tool registration is on record, no warranty credit will be issued without first receiving documentation which proves the sale of the tool or the tools' first date of usage. The term "DOCUMENTATION" as used in this paragraph is defined as a bill of sale, or letter of intent from the first retail customer. A WARRANTY REGISTRATION FORM THAT IS NOT ALSO ON RECORD WITH STANLEY WILL NOT BE ACCEPTED AS "DOCUMENTATION".

## NO ADDITIONAL WARRANTIES OR REPRESENTATIONS

This limited warranty and the obligation of Stanley thereunder is in lieu of all other warranties, expressed or implied including merchantability or fitness for a particular purpose except for that provided herein. There is no other warranty. This warranty gives the purchaser specific legal rights and other rights may be available which might vary depending upon applicable law.



Stanley Hydraulic Tools  
3810 SE Naef Road  
Milwaukie, Oregon  
503-659-5660 / Fax 503-652-1780  
[www.stanley-hydraulic-tools.com](http://www.stanley-hydraulic-tools.com)

---