

User's Manual

Gladius Smart 15" All in one POS PC

Version 1.5

Copyright © 2011. All rights reserved.
All other brand names are registered trademarks of their respective owners.

Copyright Notice

This document is copyrighted, © 2011. All rights are reserved. FIRICH ENTERPRISES CO., LTD. has the right to make improvements of the product described in this manual at any time without notice.

No part of this manual may be reproduced, copied, translated, or transmitted in any form or by any means without the prior written permission from FIRICH ENTERPRISES CO., LTD.. Information provided in this manual is intended to be accurate and reliable. However, FIRICH ENTERPRISES CO., LTD. assumes no responsibility for its use, nor for any infringements upon the rights of third parties, which may result from its use.

The material in this document is for product information only and is subject to change without notice. While reasonable efforts have been made in the preparation of this document to assure its accuracy, FIRICH ENTERPRISES CO., LTD., assumes no liabilities resulting from errors or omissions in this document, or from the use of the information contained herein.

The software described in this guide is furnished under a license agreement or nondisclosure agreement. The software may be used or copied only in accordance with the terms of the agreement.

Product names mentioned herein may be trademarks and/or registered trademarks of their respective companies.

First Edition Nov. 2011

Safety and Warranty

1. Read these safety instructions carefully.
2. Keep this user's manual for later reference.
3. Disconnect this equipment from any AC outlet before cleaning. Do not use liquid or spray detergents for cleaning. Use a damp cloth.
4. For pluggable equipment, the power outlet must be installed near the equipment and must be easily accessible.
5. Keep this equipment away from humidity.
6. Put this equipment on a reliable surface during installation. Dropping it or letting it fall could cause damage.
7. The openings on the enclosure are for air convection. Protect the equipment from overheating. **DO NOT COVER THE OPENINGS.**
8. Make sure the voltage of the power source is correct before connecting the equipment to the power outlet.
9. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
10. All cautions and warnings on the equipment should be noted.
11. If the equipment is not used for a long time, disconnect it from the power source to avoid damage by transient over-voltage.
12. Never pour any liquid into an opening. This could cause fire or electrical shock.
13. Never open the equipment. For safety reasons, only qualified service personnel should open the equipment.
14. If any of the following situations arises, get the equipment checked by service personnel :
 - a. The power cord or plug is damaged.
 - b. Liquid has penetrated into the equipment.
 - c. The equipment has been exposed to moisture.
 - d. The equipment does not work well, or you cannot get it to work according to the user manual.
 - e. The equipment has been dropped and damaged.
 - f. The equipment has obvious signs of breakage.
15. **DO NOT LEAVE THIS EQUIPMENT IN AN UNCONTROLLED ENVIRONMENT WHERE THE STORAGE TEMPERATURE IS BELOW -20° C (-4°F) OR ABOVE 60° C (140° F). IT MAY DAMAGE THE EQUIPME**

Table of Content

Chapter 1	Introduction	5
	<i>Gladius Smart Characteristics.....</i>	5
	<i>A Quick Tour of Gladius Smart.....</i>	7
	<i>Gladius Smart Dimension.....</i>	8
Chapter 2	Hardware Setup	12
	<i>Gladius Smart Assembly.....</i>	12
	<i>Adapter Installatio.....</i>	13
	<i>2.5" Hard Disk Drive Installation.....</i>	13
	<i>Magnetic Card Reader Installation.....</i>	14
	<i>VFD Customer Display Installation.....</i>	15
	<i>Second Display Installation.....</i>	15
	<i>Cash Drawer Installation.....</i>	16
Chapter3	Software Installatio	17
	<i>Intel Chipset Driver Installation for Windows XP.....</i>	18
	<i>VGA Driver Installation.....</i>	20
	<i>Audio Driver Installation.....</i>	23
	<i>Lan Driver Installation.....</i>	24
	<i>ELO Touch Tools Installation.....</i>	25
	<i>Wireless LAN Driver Installation.....</i>	31
Chapter 4	Specifications	34
	<i>Gladius Smart Specifications.....</i>	34
	<i>I/O Pin Definition.....</i>	36
	<i>Second I/O Pin Definition.....</i>	40
Chapter 5	Troubleshooting	43
	<i>Touch Panel does not Work.....</i>	43
	<i>Touch Panel Cannot Calibrate Correctly.....</i>	43
	<i>LCD Panel is Not Functioning Properly.....</i>	43
	<i>MCR is not functioning properly.....</i>	43
	<i>VFD/LCM Pole Display is not functioning properly.....</i>	44
	<i>LAN is not functioning properly.....</i>	44
	<i>Cash Drawer Port is not functioning properly.....</i>	44

About this Manual

This manual contains all the information you need to set up and use Gladius Smart.

- Chapter 1** Provides an introduction to Gladius Smart and this manual.
- Chapter 2** Provides all necessary information for all hardware setup.
- Chapter 3** Provides the necessary information for installing for chipset and its accessories.
- Chapter 4** Lists all Gladius Smart specifications includes the information of Second I/O Optional Specifications
- Chapter 5** Troubleshooting of Gladius Smart


Chapter 1

Introduction


Gladius Smart Characteristics

Gladius Smart is a dual core mobile POS and all-in-one fan-less POS system of FIRICH ENTERPRISES CO., LTD. The extensible, robust and fan-less design makes it a perfect solution for retail and hospitality market.


- **System:** A high speed fan-less processor enables to process a high capacity of data efficiently.
- **Housing:** The solid aluminum housing dissipates the heat inside the system and makes it a perfect fan-less solution; additionally it also assures the compliance to EMI radiation testing.
- **Display:** The LCD display can be tilted at multiple angles for operator ease of use.
- **Extensibility:** There are five optional second I/O that customer can choose by their requirement. In addition to, the VESA mount can be others transforming of this system.




**Gladius Smart with
VFD**



**Gladius Smart with 2nd
Display**





Detachable Stand





Optional LCM


A Quick Tour of Gladius Smart



Gladius Smart Dimension



Rear I/O Panel (with 5 types of Second IO board)



Type A

I/O Port	Connector Type	Description
COM3 COM5	RJ45 Connector	COM3/COM5 are optional to connect to other devices.
DC 24V OUT	3 PIN Socket	24V power out support.
Mic In	Microphone Connector	This is used for allowing usage of microphone.

Type B

I/O Port	Connector Type	Description
COM3 COM5	RJ45 Connector	COM3/COM5 are optional to connect to other devices.
Power USB 24V	Power DIN 4P	The power 24V out is for printer.
Mic In	Microphone Connector	This is used for allowing usage of microphone.

Type C

I/O Port	Connector Type	Description
COM3/COM5	RJ45 Connector	COM3/COM5 are optional to connect to other devices.
Power USB 12V	Power DIN 4P	The power 12V out is for printer.
Mic In	Microphone Connector	This is used for allowing usage of microphone.

Type D

I/O Port	Connector Type	Description
Power USB 12V/24V	Power DIN 4P	The power 24V out is for printer.
Mic In	Microphone Connector	This is used for allowing usage of microphone.

Type E

I/O Port	Connector Type	Description
Cash Drawer 24V	RJ11 Connector X 2	Cash Drawer connector, 24V as default
Mic In	Microphone Connector	This is used for allowing usage of microphone.

Packaging List

- Gladius Smart Main System and pedestal integrated with 12V-150w adaptor



- AC power cord



- RJ45-DB9




Chapter 2

Hardware Setup

Gladius Smart Assembly



Please make sure that the system power is turned off and the power supply is disconnected when making any hardware changes to Gladius Smart.

1. Turn off system power
2. It's not necessary for detach the base and the main system,
just for your convenience.




Suggestion : It's not required to detach the base from the main system. To detach them will be more helpful for your convenience.

Remove the back cover and access to the M/B
(Please refer to the Jumper Setting in the 4th chapter.)




Adapter Installation

1. Turn off system power and unplug the cable
2. Release the bracket with one screw
3. Beware of the direction when replacing the adapter



2.5" Hard Disk Drive Installation

1. Turn off system power
2. Open the HDD door on the left of terminal
3. Release HDD carrier with one screw
4. Pull out whole HDD carrier with finger
5. Fix HDD with 4 screws
6. Slide in the HDD carrier to the system and lock back the screw



Note: If the HDD does not work normally, please refer to [troubleshooting](#)

Magnetic Card Reader Installation

1. Turn off system power.
2. The socket to connect Identification Devices can be found on the right side of terminal
3. Attach the MCR module to terminal and connect the MCR cable to the MCR socket.
4. Lock MCR module to terminal with 2 screws.



Note: If the MCR does not work normally, please refer to [troubleshooting](#).

VFD Customer Display Installation


1. Turn off system power.
2. Important, make sure that the jumpers on the M/B are set correctly.
It's important to note that COM4 supplies voltage for the VFD customer display is set to +12V. If a LCM customer display is chosen, please change it to +5V.
3. Please refer to jumper setting in the 4th chapter.
4. Attach the VFD Mounting stand to the terminal and lock with one screw.
5. Connect the VFD RJ45 cable to COM4 on the I/O board.
6. Turn on VFD power switch and turn on system power.



Second Display Installation

1. Turn off system power.
2. Connect the VGA cable to VGA connector and the DC in cable connect to 12V out.
3. Turn on OSD switch power on and turn on system power.


Note: If the VFD does not display correctly after an application is loaded, please refer to [troubleshooting](#).



Cash Drawer Installation

Before connecting the cash drawer to the **Gladius Smart**, please make sure the **driving voltage** and cable pin assignment of the cash drawer matches the definition of the cash drawer port of **Gladius Smart**.

Plug cash drawer cable into cash drawer port.



Note: If the cash drawer cannot be detected by the system, please refer to **troubleshooting**.


Up to two cash drawers may be driven from this port. Driving voltage of the solenoid is DC+12V. I/O port 284 is used for drawer operation. A test program is supplied, for Linux and Windows, source code of which is available on request by software developers.

Value	Description
0x284	Output address.
0x284 read 8bit	Bit 2 => 0: low 1: high
0x200	Sleep 200ms
0x01	Open cashdrawer1 value.
0x02	Open cashdrawer2 value.
0x04	Close cash-drawer value.
0x04	Cash-drawer status mask.

CHAPTER 3

Software Installation

A. Please go to FEC website and download AL-7435 driver.



B. The installation sequence: Chipset Driver -> VGA Driver -> LAN Driver -> Audio Driver -> Touch Driver -> Other Driver(optional)

C. Then, you can start to install.

Please follow this installation sequence accordingly.


Intel Chipset Driver Installation for Windows XP

Step 1. Please double confirm the Intel chipset driver from website.


Step 2. Click Next




Step 3. Read the License Agreement and click "Yes" to continue




Step 4. Click "Next" to continue



Step 5. Click "Next" to continue



Step 6. Click “Finish” to complete setup




VGA Driver Installation

Step 1. Please double confirm the VGA driver from website


Step 2. Click “Next” to continue




Step 3. Read the License Agreement and click “Yes” to continue



Step 4. Click “Next” to continue



Step 5. Click “Next” to continue




Step 6. Click “Finish” to complete setup




Audio Driver Installation

Step 1. Please double confirm the Audio driver from website.

Step 2. Click “Next” to continue




Step 3. Click “Finish” to complete setup




Lan Driver Installation

Step 1. Please double confirm the LAN driver from website.


Step 2. Click “Next” to continue



Step 3. Click “Next” to continue



Step 4. Click “Finish” to complete setup



ELO Touch Tools Installation

ELO Touch Tools Installation for Windows XP/ Windows Vista/ Windows 7


Step 1. Please double confirm the ELO driver from website

Step 2. Click “Next” to continue






1. Install Elo Touch drivers and utilities.




2. Tick the **Install USB Touchscreen Drivers** and click **Next** to continue



3. Read the “**License Agreement**” and click **Yes** if you accept it.




4. Select “**Auto-detect Elo devices.**” and click **Next**.



5. Click **Calibrate Elo Touchscreen monitors**



6. Using a soft tip object such as finger to calibrate the touch screen (Red bull's eye will pop up three time on different position)



ELO Control Panel

This section explains the different options in the ELO control Panel.

General tab


The General tab allows you to calibrate the touch screen with the **Align** button.



Mode tab

The Mode tab allows you to:


- Adjust all mouse emulation controls.
- Change cursor properties
- Enable or disable right mouse button utility.



Sound tab

The Sound tab allows you to:


- To change sound properties for ELO touch tools.



Properties tab


The Properties tab allows you to:

- View Controller Information.



About tab


The About tab displays Information about ELO Touch systems




Wireless LAN Driver Installation

Step 1. Please double confirm the Wireless LAN driver from website.


Step 2. Click “Next” to continue




1. Select “Install driver and Ralink WLAN Utility”




2. Select “Ralink Configuration Tool” Select “Optimize for WiFi mode”



3. Select “Install”



4. Click “Finish”



CHAPTER 4

Specifications

Gladius Smart Specifications

System Configuration (Default)

Processor	Intel D525 1.8GHz (Dual Core, L2 cache 1MB)
Chipset	D525+ICH8M
Memory	1 x DDRIII 800MHz SO-DIMM (Up to 4GB)
Size / Resolution	15" / 1024 x 768
Brightness	450 nits (Option:250 nits)
Touch Screen	5W Resistive touch
Serial Port	2 x COM ports (DB-9 male) 1 x COM port (RJ-45) for 12V Customer display
Parallel Port	1 x Parallel port
Standard USB Port	5 x USB 2.0
Keyboard / Mouse Port	1 x PS/2 port
VGA Port	1 x VGA port for 2nd LCD Display
Audio Port	1 x Line-out
Hard Disk Drive	1 x 2.5" SATA type
Speaker	Integrated 2W x 2 stereo speakers
Power Supply	150W 12V External Power Adaptor
Construction	Aluminum
Housing Color / ID	Black

Optional LCM	Use COM6 with 5V as default
Thermal Conditions	Fanless Thermal Design
Operating Temperature	0°C ~ 40°C
O/S Supported	Windows XP (Pro, Embedded), WEPOS, POS Ready2009, Windows 7
Dimensions (W x H xD)	258.61mm x 358.11mm x 269.31mm
EMI/Safety	CE, FCC, RoHS

Second I/O Optional Specifications


I/O Optional-Type A	
COM3/COM5	2XCOM Port (RJ45)
Mic In	1X Line in
Power Supply	150W 12V External Power Adaptor

I/O Optional-Type B	
COM3/COM5	2XCOM Port (RJ45)
Powered USB Port	24V supported
Mic In	1X Line in

I/O Optional-Type C	
COM3/COM5	2XCOM Port (RJ45)
Powered USB Port	12V supported
Mic In	1X Line in

I/O Optional-Type D**Powered USB Port** 24supported**Powered USB Port** 12V supported**Mic In** 1X Line in**I/O Optional-Type E****Cash Drawer Port** 1 x 12V RJ11 port (Option: 24V x 2)**Mic In** 1X Line in**I/O Pin Definition****A. DC_IN (DC Adapter 12V in)**


DC_IN



Pin	Definition
1	12V
2	GND
3	12V
4	GND

B. +12V_OUT (12V OUT)


+12V_OUT



Pin	Definition
1	12V
2	GND


C. COM4_USB1 (VFD & RS-232 port + USB 2.0/1.1 port)

COM4_USB1




Pin	Definition
1	RI/ 5V /12V
2	CTS & RTS
3	GND
4	RTS & GND
5	DTR
6	DSR
7	TXD
8	RXD


D. USB 2.0/1.1 Port



E. COM2




F. VGA



G. USB_LAN1 (LAN connector RJ45+USB 2.0/1.1 Port)

Connection/
Speed LED Activity LED



USB_LAN1

Connection/Speed LED:


State	Description
Orange	Speed: 1 Gbps
Green	Speed: 1 00 Mbps

Activity LED:

State	Description
On	Transmitting
Off	Not Transmitting


Pin	Definition
1	Data 0+
2	Data 0-
3	Data 1+
4	Data 1-
5	Data 2+
6	Data 2-
7	Data 3+
8	Data 3-

H. LPT Port




Pin	Definition	Pin	Definition
1	STB-	14	AFD-
2	PD0	15	ERR-
3	PD1	16	INIT-
4	PD2	17	SLIN-
5	PD3	18	GND
6	PD4	19	GND
7	PD5	20	GND
8	PD6	21	GND
9	PD7	22	GND
10	ACK-	23	GND
11	BUSY	24	GND
12	PE	25	GND
13	SLCT		

I. KB_MS1 (PS/2 Connector)



Pin	Definition
1	Keyboard Data
2	Mouse Data
3	GND
4	Mouse Clock
5	5V
6	Keyboard Clock


J. RJ11 Port



Pin	Definition
1	GND
2	GPIO-0
3	CASH Drawer Switch
4	12V
5	GPIO-1
6	GND

K. AUDIO_JACK (Audio Line Out)

Audio Jack



5 4 1 3 2

Pin	Definition
1	GND
2	Line Out (L)
3	AUDIO_JD
4	-ACZ_DET
5	Line Out (R)

Second I/O Pin Definition

A. Type A

Pin	Definition	Pin	Definition	Pin	Definition	Pin	Definition
A1	NC	A16	GND	B1	NC	B16	GND
A2	NC	A17	GND	B2	NC	B17	GND
A3	NC	A18	GND	B3	NC	B18	GND
A4	NC	A19	GND	B4	NC	B19	GND
A5	DSR_5	A20	GND	B5	DSR_3	B20	GND
A6	DCD_5	A21	12V	B6	DCD_3	B21	12V
A7	RXD_5	A22	12V	B7	RXD_3	B22	12V
A8	RI_5	A23	12V	B8	RI_3	B23	12V
A9	CTS_5	A24	12V	B9	CTS_3	B24	12V
A10	TXD_5	A25	12V	B10	TXD_3	B25	12V
A11	RTS_5	A26	12V	B11	RTS_3	B26	12V
A12	DTR_5	A27	12V	B12	DTR_3	B27	12V
A13	GND	A28	12V	B13	GND	B28	12V
A14	5V	A29	GND	B14	5V	B29	GND
A15	GND	A30	MIC_L	B15	GND	B30	MIC_R

B. Type B

Pin	Definition	Pin	Definition	Pin	Definition	Pin	Definition
A1	NC	A16	GND	B1	USB5V	B16	GND
A2	NC	A17	GND	B2	D-	B17	GND
A3	NC	A18	GND	B3	D+	B18	GND
A4	NC	A19	GND	B4	USB_GND	B19	GND
A5	DSR_5	A20	GND	B5	DSR_3	B20	GND
A6	DCD_5	A21	12V	B6	DCD_3	B21	12V
A7	RXD_5	A22	12V	B7	RXD_3	B22	12V
A8	RI_5	A23	12V	B8	RI_3	B23	12V
A9	CTS_5	A24	12V	B9	CTS_3	B24	12V
A10	TXD_5	A25	12V	B10	TXD_3	B25	12V
A11	RTS_5	A26	12V	B11	RTS_3	B26	12V
A12	DTR_5	A27	12V	B12	DTR_3	B27	12V
A13	GND	A28	12V	B13	GND	B28	12V
A14	5V	A29	GND	B14	5V	B29	GND
A15	GND	A30	MIC_L	B15	GND	B30	MIC_R

C. Type C

Pin	Definition	Pin	Definition	Pin	Definition	Pin	Definition
A1	NC	A16	GND	B1	USB5V	B16	GND
A2	NC	A17	GND	B2	D-	B17	GND
A3	NC	A18	GND	B3	D+	B18	GND
A4	NC	A19	GND	B4	USB_GND	B19	GND
A5	DSR_5	A20	GND	B5	DSR_3	B20	GND
A6	DCD_5	A21	12V	B6	DCD_3	B21	12V
A7	RXD_5	A22	12V	B7	RXD_3	B22	12V
A8	RI_5	A23	12V	B8	RI_3	B23	12V
A9	CTS_5	A24	12V	B9	CTS_3	B24	12V
A10	TXD_5	A25	12V	B10	TXD_3	B25	12V
A11	RTS_5	A26	12V	B11	RTS_3	B26	12V
A12	DTR_5	A27	12V	B12	DTR_3	B27	12V
A13	GND	A28	12V	B13	GND	B28	12V
A14	5V	A29	GND	B14	5V	B29	GND
A15	GND	A30	MIC_L	B15	GND	B30	MIC_R

D. Type D

Pin	Definition	Pin	Definition	Pin	Definition	Pin	Definition
A1	USB5V	A16	GND	B1	USB5V	B16	GND
A2	D-	A17	GND	B2	D-	B17	GND
A3	D+	A18	GND	B3	D+	B18	GND
A4	USB_GND	A19	GND	B4	USB_GND	B19	GND
A5	NC	A20	GND	B5	NC	B20	GND
A6	NC	A21	12V	B6	NC	B21	12V
A7	NC	A22	12V	B7	NC	B22	12V
A8	NC	A23	12V	B8	NC	B23	12V
A9	NC	A24	12V	B9	NC	B24	12V
A10	NC	A25	12V	B10	NC	B25	12V
A11	NC	A26	12V	B11	NC	B26	12V
A12	NC	A27	12V	B12	NC	B27	12V
A13	GND	A28	12V	B13	GND	B28	12V
A14	NC	A29	GND	B14	NC	B29	GND
A15	GND	A30	MIC_L	B15	GND	B30	MIC_R

E. Type E

Pin	Definition	Pin	Definition	Pin	Definition	Pin	Definition
A1	NC	A16	GND	B1	NC	B16	GND
A2	NC	A17	GND	B2	NC	B17	GND
A3	NC	A18	GND	B3	NC	B18	GND
A4	NC	A19	GND	B4	NC	B19	GND
A5	NC	A20	GND	B5	NC	B20	GND
A6	NC	A21	12V	B6	NC	B21	12V
A7	NC	A22	12V	B7	NC	B22	12V
A8	NC	A23	12V	B8	NC	B23	12V
A9	CTS_5	A24	12V	B9	CTS_3	B24	12V
A10	TXD_5	A25	12V	B10	TXD_3	B25	12V
A11	NC	A26	12V	B11	NC	B26	12V
A12	NC	A27	12V	B12	NC	B27	12V
A13	GND	A28	12V	B13	GND	B28	12V
A14	5V	A29	GND	B14	5V	B29	GND
A15	GND	A30	MIC_L	B15	GND	B30	MIC_R

CHAPTER 5

Troubleshooting

Please note that the following troubleshooting guide is designed for people with strong computer hardware knowledge such as System Administrators and Engineers.

Touch Panel does not Work

- A) Check if the touch driver has been properly installed. Or try to reinstall again (Please refer to the touch driver installation).
- B) Move back cover, check all relative cables for touch controller.
- C) If touch controller does not appear green light, it could be defective.

Touch Panel Cannot Calibrate Correctly

- A) Please try to re-install touch driver and re-calibrate again. If not, the touch controller and touch panel could be defective.

LCD Panel is Not Functioning Properly

- A) Check that the LCD driver is installed properly (Please refer to the LCD driver installation section).
- B) Connect a LCD or CRT monitor to the VGA connector, if there is a display, then the LCD panel could be defective or is not installed properly.
- C) Move back cover, check all the LCD relative cables. (For example: check LVDS, inverter whether they are properly.)

MCR is not functioning properly

- A-1)** Check if the MCR is properly connected to the MCR connector board on main system.
- A-2)** Make sure the MCR 12PIN cable is properly connected to the right side wafer (which is USB hub board) of LCD.
- A-3)** The USB hub board could be defective.
- A-4)** The MCR module could be defective.

VFD/LCM Pole Display is not functioning properly

- A) Ensure that COM4 is enabled in the CMOS setup, and data is written to COM4 in the application.
- B) Ensure the jump setting of COM4 ,please refer the M/B manual.
- C) Check if there is any display when system power is ON, if the screen is blank, please follow the steps below.
 - B-1) Make sure the power switch on the VFD display is on before powering the main system.
- D) Check RJ-45 cable is properly connected to I/O
- E) Check the cable is properly connected to main board
- F) The on-board COM4 I/O chips could be defective.

LAN is not functioning properly

- A) Check if the LAN driver is installed properly. (Please refer to the LAN driver installation)
- B) Check if there are any IRQ conflicts.
- C) Check if the RJ45 cable is properly connected.
- D) The on board LAN chip could be defective.

Cash Drawer Port is not functioning properly

- A) Make sure the pin assignment matches between the cash drawer and the RJ11 cash drawer port
- B) Verify the digit I/O port address is 284
- C) The motherboard could be defective

Value	Description
0x284	Output address.
0x284 read 8bit	Bit 2 => 0: low 1: high
0x200	Sleep 200ms
0x01	Open cashdrawer1 value.
0x02	Open cashdrawer2 value.
0x04	Close cash-drawer value.
0x04	Cash-drawer status mask.