



WLR8950

User Manual

Table of Contents


Chapter 1.	Introduction	1
Chapter 2.	Barcode Symbologies	2
Chapter 3.	Installation	3
Chapter 4.	Quick Start	4
Chapter 5.	Setup & Configuration	5
	Factory Default	5
	Auto-Sense Stand Mode	6
	Keyboard Connection	6
	Interface Selections	6
	Beep Settings	7
	Beep and Delay	7
	Interblock Delay	8
	Upper/Lower Case	9
	Keyboard Language	9
	Preamble/Postamble	10
	Terminator	10
	Label Type Positive/Negative	11
	Code ID	11
	Bi-color light source settings	12
	Enable/Disable Barcode Symbologies	13
	Code 39 Settings	14
	Interleaved 2 of 5 and Code 93 settings	15
	Code 128 and UCC/EAN 128 Settings	16
	MSI Plessey Settings	17
	Codabar Settings	18
	UPC-A and UPC-A Supplement Settings	19
	UPC-E and UPC-E Supplement Settings	20
	EAN-8 and EAN-8 Supplement Settings	21
	EAN-13 and EAN-13 Supplement Settings	22
Appendix A	Barcode Test Symbols	23
Appendix B	ASCII Table	25
Appendix C	Function Codes for PC	29
Appendix D	Technical Specifications	30
	Warranty Information	31
	FAQ	32
	Product Support	33

Introduction

Barcoding is the most common Automated Data Collection (ADC) technology providing timely, error-free information that can be used to increase productivity, accuracy, and efficiency in the workplace. Virtually every type of industry is using barcodes to replace keyboard data entry. Studies have shown that a proficient data entry operator will make one error for every 300 characters that are manually entered. The error rate using barcodes is almost negligible and can be error-free using barcode symbologies with the check digit enabled.

The Wasp Charged Coupled Device (CCD) technology is a technique whereby a barcode is photographed, digitized, and electronically sampled by built-in photodetectors. The detectors process the measurement of every bar and space using the number of adjacent photodetectors which contrast a black mark and a white space. Wasp WLR8950 series scanners are extremely rugged since they have no moving parts. Wasp WLR8950 series scanners support PS/2 or USB keyboard interfaces and easily wedges between the computer and keyboard. Barcode data is passed directly into the keyboard buffer as if it had been typed in by hand by a data entry operator.

Of all the hand held barcode scanning devices on the market, the CCD reader is the easiest to use and most cost effective for the typical business user. The Wasp WLR8950 series scanners are extended distance scanners with a depth of reading of up to one foot depending on the mil size of the barcode. To activate the scanner, the user simply points the scanning aperture towards the barcode, pulls the trigger, and aims the red LED beam across the barcode.



Barcode Symbologies

Barcodes are symbols consisting of a series of bars and spaces which can be applied to packages, cartons, bottles, and other commercial products. The bars and spaces in each symbol are grouped in such a way to represent a specific ASCII character or function. The interpretation of these groups is based on a particular set of rules called symbologies. Various symbologies have been developed for particular applications. Some examples are shipping and receiving, manufacturing, retail, healthcare, transportation, document processing and tracking, and libraries.


The resolution of a barcode is dependent on the narrowest element of a barcode (X dimension), and can vary from high density (nominally less than 0.009 in./0.23 mm), medium density (between 0.009 in./0.23 mm and 0.020 in./0.50 mm), and low density (greater than 0.020 in./0.50 mm). Medium and low densities are the most common since these are the easiest to read (scan) with nearly all scanning devices. Wasp WLR8950 Scanners can read barcodes with X-dimensions as low as 5 mils (0.005 in/0.13mm).

Wasp WLR8950 Scanners can read the most popular barcode symbologies including Code 39, Code 93, Code 128, Interleaved 2 of 5, UPC-A, UPC-E, EAN/JAN-8, EAN/JAN-13, Codabar, and MSI/Plessey.

Please see test chart on pages 25-26.


Installation

WLR8950 PS2 Scanner



1. Turn off your computer.
2. Unplug your PC keyboard cable and plug the male end (Din 6) of the WLR8950 Scanner directly into your PC keyboard port. Plug your keyboard cable into the other end (female Din 6) of the the scanner.
3. Turn your computer on.

WLR8950 USB Scanner




1. Plug the USB of the WLR8950 Scanner directly into your PC's USB port.

Quick Start

Your Wasp WLR8950 Scanners are ready for use. The default settings of the scanners have been pre-programmed for the most common barcode configurations. Use the “WLR8950 Setup & Configuration” sections only to customize the scanners settings. Please review the “Enable Barcode Symbologies” configuration beginning on page 15 to see the list of barcode symbologies which are enabled by default.

Tip:

- Use the pre-printed “Barcode Test Symbols” in Appendix A on pages 25-26 as a test chart to practice scanning.



Setup & Configuration

In order to configure Wasp WLR8950 Scanners, you must familiarize yourself with the setup procedures on the following pages. The default settings of the Wasp WLR8950 Scanners are identified on each page and clearly marked using an asterisk (*). **The default settings have been preprogrammed for the most common barcode configurations. Use the Setup & Configuration only to customize the Wasp WLR8950 Scanners settings.** If you need to configure the scanner, the default settings will be overwritten. All the programmed settings are stored permanently in non-volatile memory; therefore, your configuration will be maintained even if the keyboard power to Wasp WLR8950 Scanners is removed by turning off your PC.

In order to configure Wasp WLR8950 Series Scanners, two basic steps need to be followed:

- (1) Locate the group that contains the options to be changed.
- (2) Scan the barcode representing the option to be changed.
The scanner will sound two beeps.

To change Minimum/Maximum Length:

- (1) Scan the Minimum or Maximum Length barcode.
- (2) Scan a 2 digit value from the ASCII table on pages 27-30.
- (3) Scan the Minimum or Maximum Length barcode again.

Example: To have a minimum length barcode of 1, you must scan a 0 then 1, then scan the minimum barcode again. To have a maximum length barcode of 10, you must scan a 1 then 0, then scan the maximum barcode again.

Factory Default

Use the **Factory Default** barcode to reset the scanner to the Default settings.



Factory Default

Auto-Sense Stand Mode

Scan the Auto-Sense Stand Mode barcode to enable the hands-free autosense feature of the WLR8950 Scanners. If you desire to turn this mode “off,” scan the Trigger Only barcode.

**Auto-Sense Mode Enable****Trigger Only**

Magnetic Switch is available after activating Auto-Sense Stand Mode.

- The Magnetic Switch is automatically activated when Auto-Sensing Mode is on.
- To enable Magnetic Switch, the scanner should be paired with an Auto-Sense Stand to perform the Auto-Sensing function.
- When Magnetic Switch is disabled, the scanner will perform the Auto-Sensing function without an Auto-Sense Stand.

**Magnetic Switch On****Magnetic Switch Off****Keyboard Connection**

The Keyboard Connection is used to program the Wasp WLR8950 Scanners for the type of computer to which it is attached.

**PC (USB or PS/2) *****Notebook****Interface Selections**

The Interface Selections barcodes allow you to switch interfaces based on your connection type.

The scanner is designed to switch easily between interface options. To switch from one interface to another, the appropriate cable must be installed. After changing to a new cable, be sure to reset the interface setting.

**USB KB****PS2**

*Default

The 'Beep and Delay' configuration supports the general control options for the Wasp WLR8950 Scanners. These options include the tone, intercharacter delay, and interblock delay. The High, Low and Med settings refer to the tone of the beep, not the volume.

Interblock delay is the minimum time interval between two adjacent scans. If the processing speed of your host device is slower than your scanning speed, a longer interblock delay may ensure the data integrity.

Intercharacter delay is the time period that the scanner will wait before transmitting the next character. If data sent by the scanner has incorrect or missing characters, a longer intercharacter delay may solve the problem. The intercharacter delay should be changed only if the transfer rate cannot be maintained between the scanner and the keyboard buffer of the computer.

Note: The default for the intercharacter delay is set to '140us' and is the most common configuration; however, your PC may be different. When you scan a barcode, if some stray or scrambled characters appear, increase the intercharacter delay to slow down the transfer rate.

Beep Settings



Beep Off



Beep High



Beep Med*



Beep Low

Interblock Delay



0ms *



10ms



50ms



100ms



200ms



500ms

Intercharacter Delay



140us *



500us



1ms



4ms



16ms

*Default

Upper/Lower Case

- **Caps Lock Auto** (For PC XT/AT only):
In Auto Trace mode, the scanner will keep track of the Caps Lock status automatically. For some PCs, the scanning performance may be compromised because of the auto tracing. If the scanning performance is poor (or cannot scan) or the scanner cannot output the upper/lower case characters correctly, try to select one of the next two choices instead of auto tracing.
- **Caps Lock Off:**
When the keyboard is in the unshifted state (Caps Lock is not pressed), select “Lower Case.”
- **Caps Lock On:**
When the keyboard is in the shifted state (Caps Lock is on), select “Upper Case.”

**Caps Lock On****Caps Lock Auto****Caps Lock Off *****Keyboard Language**

The ‘Keyboard Language’ setting controls the key codes for your keyboard’s language.

**U.S.*****English UK****French****German****Italian****Czech (QWERTY)****Japan (106 Key Only)****Spanish****Swiss****Universal Code**

*Default

Preamble/Postamble

The 'Preamble/Postamble' configuration is used to add a prefix or suffix set of characters to the barcode value. Up to 8 characters may be added for each option separately. Preamble and postamble characters can function concurrently, but need to be configured separately.

To add preamble or postamble characters, follow the steps below:

- 1) Scan the 'Clear Pre/Postamble' barcode on this page.
- 2) Scan the 'Preamble' or 'Postamble' barcode.
- 3) Use Appendix B on pages 27-30 to locate the characters you want to add as preamble or postamble characters. Make sure that you scan the barcode associated with each letter before preceding to the next character. For example, to add the letter "A," scan the barcode corresponding to the letter "A". The letter "A" will always appear in your data as prefix or suffix to the barcode value.
- 4) Scan the corresponding 'Pre/Postamble' barcode on this page to exit this setting.



Clear Pre/Postamble



Postamble



Preamble

Terminator

The 'Terminator' option is used to specify the end-of-text message and is primarily used to denote the end of the barcode value.



CR *



Tab



Space



None



LF



ESC



CR + LF

Label Type Positive/Negative**Disable Negative Label
(Positive Label Enable)****Enable Negative Label
(Positive & Negative Enable)****Code ID**

The 'Code ID' option sends a specific value when a particular barcode symbology is scanned. For example, if 'Code ID' is enabled and Code 39 is scanned, an "M" will appear in the data stream in front of the barcode value.

**Code ID On****Code ID Off ***

O - MSI/Plessey	T - EAN 128
S - EAN 8	K - Code 128
E - UPC E	N - Codabar
A - UPC A	D - Full ASCII Code 39
F - EAN 13	M - Std. Code 39
L - Code 93	I - Interleaved 2 of 5

Cycle Mode

The following settings are supported by bi-color models.



GREEN > RED



RED > GREEN



GREEN > BI-COLOR



RED > BI-COLOR

NOTES:

1. Illumination color will switch back and forth from one to the other when a good read does not occur.
2. Illumination color will remain as the one used at the last good read.

Single Mode



BI-COLOR



GREEN



RED

NOTE: Illumination color will remain single.

Enable



Enable All



MSI Plessey *



Interleaved 2 of 5 *



Code 128 *



Codabar *



Code 39 *



UPC A *



UPC E *



EAN 8 *



EAN 13 *



Code 93

Disable



Disable All



MSI Plessey *



Interleaved 2 of 5



Code 128



Codabar



Code 39



UPC A



UPC E



EAN 8



EAN 13



Code 93 *

*Default

Code 39 is variable length and is the most frequently used symbology in industrial barcode systems today. It is extensively used within the Department of Defense (DOD). The principal feature is to encode messages using the full alphanumeric character set. Standard Code 39 contains only 43 characters (0-9, A-Z, \$, /, %, +, -, ., SPACE) and can be extended to a 128 character symbology (full ASCII) by combining one of the special characters (S, /, %, +) with a letter (A-Z) to form the characters that are not present in the standard Code 39 symbology.

See page 7 for information on setting the minimum and maximum lengths.



Enable Code 39 *



Disable Code 39



**Enable Code 39
Full ASCII ***



**Disable Code 39
Full ASCII**



**Check Digit Do
Not Calculate ***



**Check Digit Calculate
And Send**



**Check Digit Calculate
But Do Not Send ***



Minimum Length (1 *)



Maximum Length (48 *)

Interleaved 2 of 5 is a variable length, even numbered, numeric barcode.

It is typically used in industrial and master carton labeling and also in the automobile industry. The symbology uses bars to represent the first digit of a pair and the interleaved (white) spaces to represent the second digit of a character pair.

See page 7 for information on setting the minimum and maximum lengths.



**Enable Interleaved
2 of 5 ***



**Disable Interleaved
2 of 5**



**Check Digit Do
Not Calculate ***



**Check Digit Calculate
And Send**



**Check Digit Calculate
But Do Not Send**



Minimum Length (6 *)



Maximum Length (48 *)

Code 93 encodes the full 128 ASCII character set using 9 modules arranged into 3 bars with adjacent spaces. Two of the characters are check characters. Code 93 is similar to Code 39 but encodes more characters per inch.



Enable Code 93



Disable Code 93 *



Minimum Length (6 *)



Maximum Length (48 *)

Code 128 is the most flexible of all the common linear symbologies. It supports alpha and numeric characters easily, has the highest number of characters per inch, and is variable length.

See page 7 for information on setting the minimum and maximum lengths.



Enable Code 128 *



Minimum Length (5 *)



Disable Code 128



Maximum Length (48 *)



**UCC/EAN 128
Enable ***



**UCC/EAN 128
Disable**



**UCC/EAN 128
Code ID Enable**



**UCC/EAN 128
Code ID Disable ***



**Function 1
Character Send**



**Function 1
Character Do Not Send ***



**Define UCC/EAN 128
Group Separator**

To Define UCC/EAN 128 Group Separator:

1. Scan Define UCC/EAN 128 Group Separator
2. Scan ASCII code from pages 27-30
3. Scan Define UCC/EAN 128 Group Separator

Note: Default Group Separator is GS

MSI Plessey is a variable length numeric symbology and is primarily used in marking retail shelves. Each character consists of four bars with intervening spaces for each encoded digit, one or two symbol check digits, and a reverse start code.

See page 7 for information on setting the minimum and maximum lengths.

**Enable****Disable *****Check Digit Verify
And Send *****Check Digit Verify
And Do Not Send****Check Digit Double
MOD 10****Check Digit Double 11
Plus MOD 10****Check Digit Single
MOD 10****Minimum Length (6 *)****Maximum Length (48 *)**

Codabar is a variable length symbology capable of encoding six special alphanumeric characters, capital letters A through D, T, N, *, E, and all numeric digits. Codabar is one of the oldest barcode symbologies and is still used in some library applications. It should not be considered for new applications except under unusual circumstances.

See page 7 for information on setting the minimum and maximum lengths.



Codabar Enable *



Codabar Disable



Send Start/Stop *



**Do Not Send
Start/Stop**



**Check Digit
Do Not Verify ***



**Check Digit
Verify And Send**



**Check Digit Verify
And Do Not Send**



Minimum Length (6 *)



Maximum Length (48 *)

*Default

UPC-A (Universal Product Code-A) is fixed length and is the most common UPC barcode for retail product labeling. It is seen in most grocery stores across the United States. The symbology encodes a 12-digit number. The first six digits are assigned from the Uniform Code Council (UCC). The next five digits are assigned by the manufacturer, and the final digit is a modulo 10 check digit. The nominal height for the UPC-A barcode is one inch. The reduced size is 80% of the nominal size.

**UPC-A Enable *****UPC-A Disable****Send Leading Digit *****Do Not Send
Leading Digit****Send Check Digit *****Do Not Send
Check Digit**

UPC-A Supplement

This option enables the two and five digit supplements for the UPC and EAN/JAN barcode symbologies.

**5 Digit Supplement
Enable****5 Digit Supplement
Disable *****2 Digit Supplement
Enable****2 Digit Supplement
Disable *****Transmit if Present****Must Be Present ***

*Default

UPC-E (Universal Product Code-E) is fixed length and is a compressed six digit code used for marking small packages, including magazines and paperback books. UPC-E symbols are UPC-A symbols that have been zero suppressed (i.e. consecutive zeros are not included in the symbol). The printed value of the UPC-E code is a twelve digit code. The nominal height for the UPC-E barcode is one inch. The reduced size is 80% of the nominal size.



UPC-E Enable *



UPC-E Disable



Send Leading Digit *

Do Not Send
Leading Digit

Send Check Digit *

Do Not Send
Check DigitExpand to UPC-A
OnExpand to UPC-A
Off *

UPC-E Supplement

This option enables the two and five digit supplements for the UPC and EAN/JAN barcode symbologies.

5 Digit Supplement
Enable5 Digit Supplement
Disable *2 Digit Supplement
Enable2 Digit Supplement
Disable *

Transmit if Present



Must Be Present *

*Default

The EAN/JAN-8 is fixed length and is similar to the UPC-E code, but includes two more digits for the country code. The nominal height for the EAN/JAN-8 barcode is one inch. The reduced size is 80% of the nominal size.

**EAN-8 Enable *****EAN-8 Disable****Send Leading Digit *****Do Not Send
Leading Digit****Send Check Digit *****Do Not Send
Check Digit**

EAN-8 Supplement

This option enables the two and five digit supplements for the UPC and EAN/JAN barcode symbologies.

**5 Digit Supplement
Enable****5 Digit Supplement
Disable *****2 Digit Supplement
Enable****2 Digit Supplement
Disable *****Transmit if Present****Must Be Present ***

*Default

The EAN/JAN-13 (European Article Number/Japanese Article Number) is fixed length and is similar to the UPC-A symbology, but encodes a 13th digit. The nominal height for the EAN/JAN-8 barcode is one inch.

The reduced size is 80% of the nominal size.



EAN-13 Enable *



EAN-13 Disable



Send Leading Digit *



**Do Not Send
Leading Digit**



Send Check Digit *



**Do Not Send
Check Digit**



ISBN Enable



ISBN Disable *



ISSN Enable



ISSN Disable *

EAN-13 Supplement

This option enables the two and five digit supplements for the UPC and EAN/JAN barcode symbologies.



**5 Digit Supplement
Enable**



**5 Digit Supplement
Disable ***



**2 Digit Supplement
Enable**



**2 Digit Supplement
Disable ***



Transmit if Present



Must Be Present *

*Default

Note: Make sure that the appropriate barcode symbology is configured properly and enabled before trying to scan. Use the 'Barcode Symbologies' configuration beginning on page 15 to enable specific symbologies.

Code 39*



Code 93



Interleaved 2 of 5 *



Codabar *



Code 128*



MSI/Plessey



UPC-A*



UPC-A
w/5 digit supplement



UPC-A
w/2 digit supplement



*Default

UPC-E*



UPC-E
w/5 digit supplement



UPC-E
w/2 digit supplement



EAN/JAN-13*



EAN/JAN-13
w/5 digit supplement



EAN/JAN-13
w/2 digit supplement



EAN/JAN-8*



EAN/JAN-8
w/5 digit supplement



EAN/JAN-8
w/2 digit supplement



*Default

Use this ASCII Table to add preamble and postamble characters to your barcode value. Please refer to the appropriate configuration section for the number of characters that can be configured.



NUL



LF



DC4



SOH



VT



NAK



STX



FF



SYN



ETX



CR



ETB



EOT



SO



CAN



ENQ



SI



EM



ACK



DLE



SUB



BEL



DC1



ESC



BS



DC2



FS



HT



DC3



GS





?



J



U



@



K



V



A



L



W



B



M



X



C



N



Y



D



O



Z



E



P



[



F



Q



\



G



R



]



H



S



^



I



T



-



\



k



v



a



l



w



b



m



x



c



n



y



d



o



z



e



p



{



f



q



|



g



r



}



h



s



~



i



t



DEL



j



u



F1



F10



Cursor Right



F2



F11



Cursor Up



F3



F12



Cursor Left



F4



Tab



Cursor Down



F5



Back Tab



Page Up



F6



Esc



Page Down



F7



End



Ins



F8



Home



Enter



F9



Back Space



Del

MODEL	WLR8950
PERFORMANCE	
Sensor	2660 pixels CCD linear imager sensor
Depth of Field	30mm to 330mm (40 mil) ± 20mm
Best Resolution	0.127mm (5mil).
Scan Rate	45 scan / sec
Decoding Rate	100 scan / sec (10m / sec)
Scanning Width	120mm (1 mm barcode)
Sunlight	5000 Lux / Max (Flourescent Light)
MECHANICAL	
Dimensions	106 (L) x 62 (W) x 160 (H) mm
Weight	Approximately 160g (without cable)
Cable	210 cm in length (Interchangeable cable)
ELECTRICAL	
Operating Voltage	+ 5 VDC ± 10%
POWER CONSUMPTION	
Standby	<100mA
Working	<220mA
Surge	<1000mA
ENVIRONMENTAL	
Operating Temperature	0°C to 50°C
Storage Temperature	-20°C to 60°C
Relative Humidity	0% to 95% non-condensing
Mechanical Shock	1.5m drop onto concrete
Conformance	FCC class A and CE approval in progress
SYMBOLOGIES	
UPC-E, UPC-A, EAN-8, EAN13, UCC/EAN128, JAN, ISBN, ISSN, Code 39, Code 93, Code 128, Interleave 2 of 5, Industrial 2 of 5, Matrix 2 of 5, IATA 2 of 5, China Post Code (Toshiba Code), MSI, Codabar, ABC Codabar, CX Codabar, Code 11, UK Plessey, Telepen, Code 128, RSS	

Wasp Barcode Technologies products are warranted against defects in workmanship and materials for a period of one year from the date of shipment, provided that the product remains unmodified and is operated under normal and proper conditions.

This warranty is limited to repair or replacement at Wasp Barcode Technologies option, with reasonable promptness after being notified. These provisions do not prolong the original warranty term for any product which has been repaired or replaced by Wasp Barcode Technologies.

This warranty applies to the original owner and does not extend to any product which has been subject to misuse, neglect, accidental damage, unauthorized repair, or tampering.

No other express warranty is given. The replacement or repair of a product is your exclusive remedy. Any other implied warranty of merchantability or fitness is limited to the duration of this written warranty. Some states, provinces, and countries do not allow limits on how long an implied warranty lasts, so the above limitation may not apply to you.

In no event shall Wasp Barcode Technologies be liable for consequential damages. Some states, provinces, and countries do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.

Q: How do I configure the scanner for a notebook (or laptop) computer?

A: Scan the “Notebook” barcode on page 8.

Q: How do I change the terminator to a Tab?

A: Scan the “Tab” barcode on page 12.

Q: How do I remove the terminator?

A: Scan the “None” barcode on page 12.

Q: How do I enable the Full ASCII character set for the Code 39 barcode symbology?

A: Scan the following “Enable Code 39 Full ASCII” bar code on page 15.

If you experience any problems with the Wasp WLR8950 Series Scanners that you are unable to resolve, call for technical assistance at (214) 547-4100 ext 2, Monday through Friday, 8:00 AM - 5:00 PM Central Standard Time. Visit www.waspbarcode.com/support anytime.

Wasp Barcode Technologies

1400 10th Street

Plano, TX 75074

www.waspbarcode.com