

Bewator

Entro

Installation manual

Version 5.3

Liefermöglichkeiten und technische Änderungen vorbehalten.
Data and design subject to change without notice. / Supply subject to availability.
© 2007 Copyright by Bewator AB, a Siemens Company

Wir behalten uns alle Rechte an diesem Dokument und an dem in ihm dargestellten Gegenstand vor. Der Empfänger erkennt diese Rechte an und wird dieses Dokument nicht ohne unsere vorgängige schriftliche Ermächtigung ganz oder teilweise Dritten zugänglich machen oder außerhalb des Zweckes verwenden, zu dem es ihm übergeben worden ist.

We reserve all rights in this document and in the subject thereof. By acceptance of the document the recipient acknowledges these rights and undertakes not to publish the document nor the subject thereof in full or in part, nor to make them available to any third party without our prior express written authorization, nor to use it for any purpose other than for which it was delivered to him.

Contents

1	What is Bewator Entro?	7
1.1	Network and Internet	7
1.2	Reservation system	7
1.3	DVR integration	7
1.4	Intrusion alarm system control	7
1.5	Before commissioning the system	8
2	System components	9
3	Communication with PC in Bewator Entro	12
3.1	Local Area Network	12
3.1.1	Directly connected – without LAN	12
3.1.2	Directly connected – without LAN	12
3.1.3	Local area network with InfoPoint IP810 or IP811	13
3.2	RS232	13
3.3	Modem	13
3.4	System connections	14
3.4.1	One computer	14
3.4.2	Several computers	14
3.5	Multi-user database	15
4	Global communication between several SR34i	16
4.1	RS485	16
4.2	Ethernet with TCP/IP	16
4.3	Example of SR34i with RS485	17
4.3.1	Small application – with one SR34i	17
4.3.2	Larger application – with several SR34i	17
4.4	Example of SR34i used in Local Area Networks	18
4.5	Example of SR34i using Internet	19
5	Dynamic IP-address (DHCP) and dynamic DNS	20
5.1	Background	20
5.2	Prerequisites	21
5.3	Static IP-addresses	21
5.4	Dynamic IP-addresses	22
6	Installation procedure	23
6.1	Recommended system cables	24
6.2	Choice of communication for readers	25
6.2.1	BCLINK	25
6.2.2	Clock&Data	25
6.2.3	Wiegand	26
7	Wiring the system	27
7.1	Entro Hardware components	27
7.2	Housings	27
7.3	Using cable glands	28
7.4	Installing door readers	29
7.5	Installing the door controllers	29
7.6	Installing PD30-EM or PD40-EM	29
7.7	Installing the segment controllers	29
7.8	Connecting the SR34i Segment controller	30
7.8.1	SR34i installations details	31
7.8.2	IP-addresses	31
7.8.3	Status information in the display	31

7.9	Connecting the DC22 Controller	32
7.9.1	DC22 installation details.....	33
7.9.2	Intrusion Alarm Zones with DC22	34
7.9.3	Connecting Alarm Status Feedback in DC22 (ASF).....	35
7.10	Connecting the DC12 controller	36
7.10.1	DC12 installation details.....	37
7.11	Connecting the IOR6 Relay central	38
7.11.1	IOR6 Installation details	39
7.12	Connecting the DC01 door controller.....	40
7.13	Connecting the BC43 remote card reader	41
7.14	Connecting keypad M43	42
7.15	Connecting the BC18 remote card reader	42
7.16	Connection of other readers.....	43
7.16.1	Connection of 500-series proximity readers (BCLINK).....	43
7.16.2	Connection of Hands-Free reader HF500 (Clock&Data).....	43
7.17	Connecting DC800 controller	44
8	Special installations.....	45
8.1	Anti-pass back using BCLINK readers.....	45
8.2	Anti-pass back using CLOCK&DATA and WIEGAND readers.....	46
8.3	Installation of Interlock doors	47
8.3.1	Access from Door A to Door B	47
8.3.2	Access from Door B to Door A.....	47
9	Install the connection to the PC	48
9.1.1	Local Area Network to PC.....	48
9.1.2	Connect PC or printer with direct cable (RS232).....	49
9.2	Installing USB-RIF/2.....	50
10	Power supplies and communication.....	51
10.1	Central power supply	51
10.2	Local reader power supply for doors.....	52
10.3	Considerations concerning earthing & screening	52
10.4	Check the communications circuit RS485	53
10.5	Check the power supply.....	53
10.6	Check communication.....	53
11	Configuring.....	54
12	Bewator Entro Reservation.....	55
12.1	Integrated Web server.....	55
12.2	How the Reservation system is installed	56
12.3	Installing the CF8 flash memory card	56
12.4	Connecting the InfoPoint IP811/IP810.....	57
13	DVR Installation.....	58
13.1	Implementation in Entro	58
13.2	Planning and installing DVR and cameras.....	58
14	Expanding and modifying the system	59
14.1	RS485	59
14.2	Networking	59
14.3	Installing another PC.....	60
14.3.1	Prepare the existing database	60
14.3.2	Configure the new PC	60
14.3.3	Installing another SR34i.....	61

14.4	Installing more readers	61
14.5	SR34i firmware control.....	62
14.6	Door controller firmware control.....	62
14.7	Printout of system configuration.....	62
15	Installing modem based systems.....	63
15.1	Installing the modem based system.....	64
15.1.1	Configuring a system equipped with TD35 modem (recommended)	64
15.1.2	Configuring a system equipped with a custom modem	64
15.2	Configuring the modem based system on site.....	65
15.3	Installing the modem.....	67
15.4	Transferring the new system's information to the central PC	68
16	Integrating with external applications (BAPSI).....	69
16.1	General	69
16.2	What is BAPSI used for?	69
16.3	Field applications	69
16.3.1	Application example - External Reservation system.....	70
17	Checklist	71
18	Technical information.....	72
19	Appendix 1 – DVR models and settings	76
19.1	SISTORE™ MX	76
19.1.1	MX Parameters	76
19.1.2	MX Live Viewer software	76
19.1.3	Additional considerations for the MX	77
19.2	SISTORE AX.....	77
19.2.1	General	77
19.2.2	AX Parameters.....	77
19.2.3	Additional considerations for the AX	78
19.2.4	AX Live Viewer software	78
19.3	SISTORE™ CX.....	78
19.3.1	General	78
19.3.2	CX Parameters.....	78
19.3.3	CX Live Viewer software.....	79
19.3.4	Additional considerations for the CX.....	79
20	Keyword index.....	80

1 What is Bewator Entro?

Bewator Entro is an access control system. It is designed for use in both small companies and large ones; wherever there is a need to control which people should have access to the different doors and departments in the premises.

There is an advanced function for reservation (e.g. in sports arenas, conference rooms etc). It works in co-operation with the access control functions.

Next to the doors, card readers with keypads (optional) are installed. They are connected to segment controllers, which are then configured from a PC.

If needed, Bewator Entro can control up to 10 000 access control systems installed in different buildings. The systems may be connected directly to the PC or be connected via a modem and/or local area network.

1.1 Network and Internet

Bewator Entro has the ability to communicate between units via local or global networks and also the Internet. This document describes how the connections and addressing of Bewator Entro are done and assumes that the external network components (routers, switches etc) are configured correctly.



NOTE

It is very important that the IT-manager of the end-user has participated in and has approved of all aspects of this part of the installation.

1.2 Reservation system

There is information on how to use Reservation together with the rest of the Bewator Entro Access Control System.

1.3 DVR integration

The Entro system can be integrated with an external Siemens SISTORE™ DVR for camera recording. You can also playback recordings from the Entro program.

There are no special components (for Entro) required to manage the DVR system because all information is communicated via TCP/IP network (which already is supported by the SR34i).

1.4 Intrusion alarm system control

A common application for the Entro is, beside access control, to control an external intrusion alarm system by means of an access card. Read more about the installation requirements for this in the DC22 section – and in the *User manual* describing e.g alarm zones.


1.5 Before commissioning the system

Before commissioning the Bewator Entro system, the installer should read and complete the checklist at the back of this manual.

2 System components


Bewator Entro consists of the following equipment:

- **The Bewator Entro software.** The software runs on a Pentium 266 MHz PC with 64 Mbytes of RAM with Windows 2000/XP. It controls up to 512 doors and can manage 40 000 cards. When the software package is installed there is three program parts:
 - **Installer** program for setup of hardware.
 - **Entro** program for setup and administration.
 - **Door Monitor** program for status monitoring.
- **SR34i Segment controllers.** Up to 16 segment controllers can be connected to the PC in a “daisy chain” configuration. Each segment controller can control 4, 8, 16 or 32 doors. The information you program in the PC is stored in all segment controllers. This has the advantage of being able to use the PC for other purposes or shut it off when it is not configuring or monitoring Entro.




Each segment controller is delivered with 4 termination resistors (120 Ω).

- **Door controllers with remote card readers.** The door controllers are connected to the segment controllers. A door controller controls one door where one or two (in/out) remote card readers can be installed. This combination (split installation) is designed for external doors or other doors with higher requirements on function and security, e.g. alarm by-pass and door control.



1.	Magnetic card or proximity readers.
2.	Proximity reader.
3.	Hands-Free reader.

- **Proximity Codoor PD30-EM/PD40-EM.** Electromechanical unit equipped with a proximity reader for EM technology. Connects to the Segment controllers. PD30-EM fits primary Scandinavian lock cases and PD40-EM the Eurostandard.




- **Door centrals without remote terminals.** In some cases there is a need for monitoring or opening a door by time schedule. The DC01 can be used as a timer controlled relay or monitoring unit.



Door central DC01

- **Relay central.** To control e.g. a lift the IOR6 can be used. Any reader can control which relays to activate. The IOR6 can be used in reservation applications. Version 5 also offers functions like Common alarm, Lift control, emergency opening and power failure monitoring.




Relay central IOR6

- **CF8.** If Reservation is to be used a CF8 memory card must be installed in one of the SR34i segment controllers.




CF8 Memory card

- **Reservation terminal.** An InfoPoint IP811 or IP810 can be used in a reservation system enabling reservation local to the object. Includes an integrated card reader function for identification.




InfoPoint IP811


- **Cards.** Every person would use either a card or proximity tag.




- **Modem.** If multiple Bewator Entro systems make up the installation, a modem may be connected for communication between the systems and the central PC.



- **Battery backup.** One or more battery backup power supplies are needed for the system's power.



- **Cables.** See recommended cables on page 24.



3 Communication with PC in Bewator Entro

Bewator Entro SR34i offers three ways of communication with a **PC computer**.

By default the software installation assumes that only one computer shall log on to the system. If several computers (users) shall log on at the same time more so called *connections* must be setup. Read more in the chapter *System connections* in this manual and in the *User manual*.


3.1 Local Area Network

In this configuration, the Local Area Network (Ethernet 10/100 Mbit) is used for TCP/IP communication with the PC. See also *Technical Information* for more information.

Note that the SR34i has an **integrated network switch with two connectors (RJ45)** where a PC and an SR34i can form a local area network without any extra equipment (except for the cable)


3.1.1 Directly connected – without LAN

In this case the PC has static IP address and is connected directly to the SR34i as an alternative to RS232 where longer distance (<100 m) is required.




3.1.2 Directly connected – without LAN

In this example the integrated network switch is also used to connect the PC onto the LAN.




3.1.3 Local area network with InfoPoint IP810 or IP811

The InfoPoint can be connected directly to the SR34i segment controller.




3.2 RS232

SR34i communicates with the PC via cable directly to the COM-port.



3.3 Modem

The PC is used to control a remote site using a dial-up modem. The SR34i is also connected to a modem, which also can dial up the PC if necessary.



3.4 System connections

The concept *Connections* is used in Bewator Entro to define which computers, printers and/or modems that are used to send command or retrieve events to or from the system.

The physical communication method (TCP/IP, RS232 or modem) must also be defined when setting up a connection.

3.4.1 One computer

In some sites only one computer is enough to administrate an Entro system. This is also the **default level** when the software is installed (according to the *User manual*) which results in a very easy, rapid start-up as possible. Still a choice is done on the way of communication, e.g. TCP/IP.

3.4.2 Several computers

In a multi-user environment where several computers are to be logged on simultaneously, e.g. to log on or delete cards, a setup must be performed in the software to make it possible to create more *connections*.



You need **software licenses for each computer** that is connected. Otherwise there will be problems with event storing etc.

Proceed like this:

1. Go to **System** and **System settings** in the *Installer* program.
2. Select **Connections**.
3. Check the tick box that several computers shall be used concurrently. A new window is displayed.
4. Click **New** and follow the wizard.

See also the chapter *Installing another PC* at the end of this manual how to transfer an existing database to another computer.

In the next chapter there is some concise information how the database is managed in systems with more computers.

3.5 Multi-user database


Every Entro system uses a **database** (with cards, time schedules etc.), which is stored in every segment controller and PC. The Entro version 5 database allows for **multiple users** to be working with the same database.

The prerequisites for this are that the system knows which Users are using which computer. E.g a Security manager can have their own PC (with a dedicated license) while a Receptionist has another PC (with another license). For every PC there must exist a 'connection' in Entro where the license number and communication ports are defined.

At the same time the applied filter events will only be sent to each PC respectively. i.e. if the Security manager temporarily log on to the Receptionist's PC no events will be received to this PC.

For every new System user you create you have to specify also the connection and which event filter is to be used.

The simplified illustration below shows how it works.



Instead, if only one PC is used with several users the different filtered events will be stored in different folders on the PC (dependant of the user logged on).

4 Global communication between several SR34i

The global communication between several **controllers** can be done through two separate physical cables – twisted pair **RS485** and/or **Ethernet 10/100 Mbit**.

4.1 RS485

Uses RS485 to communicate between a maximum of 16 SR34i controllers. Maximum distance is 1200 meters from the first SR34i to the last one.

It is possible for one or more of these SR34i to use TCP/IP as described below. The controllers are then configured with an IP-address and proxy function (with SNTP).

4.2 Ethernet with TCP/IP

Generally known as TCP/IP that uses the Ethernet connection (10/100 Mbit) that connects to the Local Area Network. TCP involves a controlled way of sending messages through a network. The maximum distance depends on the structure of the network itself.

Requires that the SR34i is configured with its unique **IP-address** and having the **Proxy** function (with SNTP). This ensures that only the relevant units (SR34i or PC) receive the messages. See also *Technical Information*.

In version 5 also dynamic IP addresses can be used for SR34i. See chapter *Dynamic IP-address (DHCP) and dynamic DNS* where the prerequisites are described.


Notes when using SR34i and TCP

Remember that any zones (e g Alarm zones) will work best if they reside in the same sub-net when several SR34i use TCP/IP (between related SR34i).


4.3 Example of SR34i with RS485

This solution gives a more closed system with dedicated wiring (RS485) between the segment controllers.

4.3.1 Small application – with one SR34i




4.3.2 Larger application – with several SR34i



4.4 Example of SR34i used in Local Area Networks

This version of Bewator Entro gives the possibility that several SR34i can communicate through local area networks and the system can be software controlled from any PC on the network. No separate connections are needed between the controllers.


Note that it is possible to connect the PC directly (RS232) - or via the network.



4.5 Example of SR34i using Internet

In this case the Internet, Local Area Network as well as RS485 are used for communication between units.

For example, some PCs can be used only for login to a Reservation system via the Internet – and other PCs could be used also for system administration.



5 Dynamic IP-address (DHCP) and dynamic DNS

Some network applications requires the SR34i to be able to use dynamic IP-addresses and where every controller is referred as a “name” and that the SR34i itself can login to the ISP.



NOTE

In the User manual you find more on how to set up and program these functions.

5.1 Background

Dynamic IP-addresses

In earlier versions of the Entro software, the Segment Controller is supposed to be addressed with a static *IP-address* – which is still the preferred method as long as the local area network (LAN) allow for this. (Think of a having the same telephone number all the time). Static IP-addresses are both faster and more secure.

In some facilities only one Internet Service Provider (ISP) is contracted, offering only accounts and connections using **DHCP** (*Dynamic Host Configuration Protocol*). These means that the host environment (at the ISP) “lease out” an IP-address e.g. Broadband connection. However that means the IP-address can be changed when the ISP renews the lease time. (We describe further on how this mechanism works in Entro).

As IP-addresses are not static, there must be a function that refers to a fixed name which can be “translated” to a concept the Internet still can understand – i.e. IP-addresses. This function is generally called **DNS** (*Domain Name Service*) and can be seen as a “name directory” with IP-addresses. The directory normally resides with the ISP and will itself also be accessed through an IP-address (which normally is supported together with the leased IP-addresses).

E.g. a web browser can use the name www.xyz.com instead of the IP-address to XYZ. This works as long as the www.xyz.com always have the same IP-address (i.e. the DNS supersedes the need for remembering the IP-address to XYZ home page).

When DHCP is used – and the ISP often changes the connected users’/computers’ leased IP-address – also the DNS must be updated with new information. This is called **dynamic DNS** (DDNS) – and means that equipment can “ask” this service for the latest IP-address for a specific name.

Think of e.g. changing your telephone number sometimes (because the amount of telephone is limited and an own line with a fixed number is more expensive). Still your friends have to be informed about the change – the telephone directory must be updated – each time the name is changed.

Login

The Internet Service Provider (ISP) sometimes need to be sure that it is an authenticated user (SR34i) before any communication can be allowed. This requires a login with **User name** and **Password**. This is setup in each SR34i. Note that login procedures can be used/required even if static IP-addresses are used.

5.2 Prerequisites

Following chapter describes the requirements needed to get different configurations working in a Bewator Entro system. See also further chapters how the installation is performed.



The End Users'/Buyers' IT-manager should always participate in the planning of a TCP/IP based Entro system. General knowledge about networking is also recommended.

Simplified you can use handled IP-addresses in three different ways:

- **All** SR34i's have **static** IP-addresses (decided by IT-manager or ordered from ISP).
- **One** SR34i has **static** IP-address (with name directory) – all others normally get leased, dynamic addresses (DHCP).
- **All** SR34i's gets **dynamic** addresses (DHCP).

5.3 Static IP-addresses

Static IP-addresses can exist in both local area networks and/or where also Internet is used (e g for reservation functions). Some ISP's unfortunately do not allow for using static IP-addresses.

In a local area network environment **in a company no special arrangements are needed**. The only aspect is how "isolated" the security system should be compared to an office network. I e if any routers, firewalls or similar separating the Bewator Entro from any other network equipment.

Of course the same applies for an apartment building if using the same type of network. However, a company installation can use the advantage of the DHCP functions described in next section.

E g a SR34 can get a fixed IP-address (from IT-manager) and act as a host for the other SR34i's (leasing the IP from an internal DHCP-server in the company).

5.4 Dynamic IP-addresses

At the moment few apartment/small office buildings have a complete local area network installed. Instead an ISP offers a connection e.g. broadband, cable or telephone modem and every tenant uses the Internet for communication to/from a home computer.


To get Bewator Entro running in an environment where **DHCP** and **Login** are used – some prerequisites must be fulfilled.

- At least one ISP account (and physical connection) must exist. The goal is that every SR34i shall be able to access the Internet as well as being accessed from outside. Depending on the ISP this can offered in different ways.
- The function for "**dynamic**" **DNS** (*Dynamic Domain Name Service*) must be established. The "Name directory" can the be stored in one of two possible places:
 - One dedicated SR34i will act as "Dynamic DNS" requiring a static IP-address (from ISP), so that other SR34i's (and PC) knows where the name directory is. The chosen SR34i will still be able to control door environments.
 - An externally offered public service called *DynDNS.org* is used to store the directory (with network identities and IP-addresses).

In this case an account with User name and Password has to be requested from this organization.

At the moment five different names are offered free-of-charge and five SR34i's can immediately be used. If more SR34i's are to be used additional 20 names can be ordered for approx \$10 (Approx £5.50) annual fee (December 2004).

6 Installation procedure



6.1 Recommended system cables

The table below shows what kind of connections could be done in Bewator Entro.



Bewator will not warrant systems where other types of cable are used for these connections. Cable types must not be mixed in the different cable segments.

From unit	To unit	Type of cable	Maximum length (m)
PC	SR34i	RS232 Cable between PC/printer and segment controller. Maximum length: 25 meters. Specified cable: Straight screened cable (4 + screen), e.g. Belden 9534.	25 m
	SR34i	Network Cat-5 cable, 10/100 Mbit. If in doubt - consult the IT-manager.	Depends on the network structure but normally 100 m to router/switch/hub.
SR34i	SR34i	RS485: The "global" circuit between the segment controllers. Specified cable: Pair twisted screened (1 pair + screen), e.g. Belden 9502.	1200 m
	SR34i	Network: Cat-5 cable, 10/100 Mbit. If in doubt - consult the IT-manager.	Depends on the network structure but normally 100 m to router/switch/hub.
SR34i	DC22 DC12 IOR6 PD30-EM PD40-EM	RS485: The "local" circuit between a segment controller and its subordinate door readers/door controllers. Pair twisted screened (1 pair + screen), e.g. Belden 9502 or Cat-5 (communication) and 1.5mm ² (power) OR PAARFLEX CY (custom cable comprising communication and power in one cable).	1200 m
DC22 DC12	BC43 M43 PR500 HD500 SP500 PM500	BCLINK: Specified cable: Straight screened cable (4 + screen), e.g. Belden 9534	100 m
	HF500 BC5511 BC5515	CLOCK&DATA: Specified cable: Straight screened cable (6 + screen), e.g. Belden 9536.	50 m
	Wiegand readers	WIEGAND: Specified cable: Straight screened cable (6 + screen), e.g. Belden 9536	50 m


6.2 Choice of communication for readers

In the Bewator Entro there are several types of door controllers and readers where the method of communication (protocols) varies. We use mainly three types of interfaces BCLINK, CLOCK&DATA or WIEGAND.

6.2.1 BCLINK

BCLINK enables several readers to exist on the same cable and they are addressed on another level. BCLINK can control LEDs and buzzers. The interface can send information in both directions (**Tx** and **Rx**).

The most common case is a DC22, which has a main address in Bewator Entro. Two BC43 readers are mounted on each side of the door with cables in parallel. The readers are then addressed as ENTRY and EXIT – they have sub-addresses.




1.	ENTRY Reader
2.	EXIT Reader

6.2.2 Clock&Data

Means every reader has its own cables and cannot be addressed. This is addressed by using the door central. This is a more “open” interface consisting of a clock signal and a data signal (**Clock** and **Data**). Data is sent in one direction (from reader). Any LEDs etc are controlled by hardware signals.

6.2.3 Wiegand

Uses the same interface as Clock&Data but the protocol differs. The most common formats are 26-bit and 32-bit but also 8-bit burst is used (e.g. for managing a PIN-code).



NOTE

You need to install the door controllers DC22 or DC12, to use the Wiegand interface.

7 Wiring the system

7.1 Entro Hardware components


Entro version 5 means that SR32i is replaced with **SR34i**, DC21 with **DC22** and DC11 with **DC12**.

Note that **all Segment controllers must be of type SR34i** – whilst the door controllers can be mixed (e.g. when upgrading from an older system).

7.2 Housings

The Entro components have designed housing offering an even easier and tidier installation. The different components have several nice features but the most important details are:

- Special corner elements are designed to be removed but then again hiding and sealing the cable entry when re-fixed again. Also ideal when mounting via trunking-list. See figure 1.
- The cable entry can be solved in many ways. There are knockouts in both the base and the corner elements. See figure 2.
- Secured cable entry can easily be achieved by entering the cable over edge (before the corner elements are re-fixed). See figure 3.
- Integrated fixing details for securing the cables with cable ties.



1.	With trunking-list.
2.	Cable entry via knockouts.
3.	Secured cable entry over edge

7.3 Using cable glands

In some cases it is desired to secure the cables via glands. The housing allows for using glands of M12 dimension (12 mm).

When the controllers are shipped there are washers mounted at the screw holes to allow for different kind of screw types when fixing it to e.g. a wall (see item C in the picture). If glands instead shall be used, proceed like below:


1. Remove the default washer(s).
2. Place the gland bracket(s) (on the little location pin) to decide which knockout to cut out. There are two different positions of the bracket.
3. Cut out approx. 12-13 mm and mount the supplied gland bracket(s).
4. Place the gland in the big hole of the bracket and fix it with the nut.
5. The cable is then mounted through the outer sleeve and connected to the desired terminal blocks on the PCB.
6. Optionally fix the cable even further using cable ties and then fix the sleeve.

In the picture below is shown how to mount the gland bracket.



NOTE

The glands are not supplied with the housing (only the brackets).



7.4 Installing door readers

Install the door readers at a height of 120–140 cm (from the floor to the bottom edge of the door reader). To adapt the installation to disabled people, a suitable height is approximately 95 cm (please contact Bewator for details on complying with the Disability Discrimination Act).

7.5 Installing the door controllers

Install the door controllers within recommended distance from the unit/s to be controlled by the door controller (see the cable instructions). The door controllers may be installed above a false ceiling or in an adjacent riser cupboard.

7.6 Installing PD30-EM or PD40-EM

These door units consist of both a controller- and reader-function and are mounted directly on the lock case. They also include a drop box to be installed above the door. How to mount it mechanically is also described in more details in the manual supplied with the unit.

7.7 Installing the segment controllers

Install the SR34i segment controllers as centrally as possible to the door readers/door controllers to be connected to the SR34i. As with door controllers, a suitable place is above a false ceiling or in an adjacent riser cupboard.

Note that there must be approximately 70 mm free space around the SR34i to be able to open the front covers.

If any of the segment controllers will be used for the reservation function it must be equipped with a memory card (see item H, page 31).

7.8 Connecting the SR34i Segment controller

In Entro version 5 the segment controller SR34i is used, which offers some nice features:

- Only screw terminal blocks for local and global communication.
- Integrated network switch (for LAN) with two RJ45 connectors for Ethernet.
- RS232 connection through 9-in D-sub connector.
- Configurable via keypad and display (e.g. for setting the IP-address).
- No jumpers to configure.
- Housing that protect the electronics parts.

Note that the IOR6 relay unit now instead supports functions for Power failure warning and Common alarm.




Fig. 1 SR34i overview. See next page for a more detailed information

7.8.1 SR34i installations details

A	Lock to be opened with supplied special key. (The door is not shown).
B1 B2	The corner details can be lifted and are prepared with knockouts used for sealing or hiding cable entry. The position of these should not be changed (due to mechanical differences). They are numbered like this: 81284 (B1) = Lower left + upper right corner. 81285 (B2) = Upper left + lower right corner.
C	The box is fastened on the wall with four screws. Remember to leave approx. 70 mm space around the controller.
D	The cables can either be safely mounted (cable goes over the edge) - or via knockouts in the same edge). Prepared with fixing details for securing the cable with cable ties.
E	Local circuit (RS485). Power supply: Terminal 1 and 2. Communication: Terminal 3 and 4. Screen: Terminal 5. The controller can be disconnected without interrupting the global circuit. Do not forget to use termination resistors in the circuit ends.
F	Global circuit (RS485) Communication: Terminal 6 and 7. Screen: Terminal 8.
G	Three addressing knobs (001-016)
H	Socket for compact flash memory card.
I	RS232 connection for PC, modem or printer.
J	1st RJ45 Ethernet connection. 10/100 Mbit/s. Note! Switch function (autosense)
K	2nd RJ45 Ethernet connection. 10/100 Mbit/s. Note! Switch function (autosense).
L	Battery socket. Type CR2032. Note! Remove the isolating plastic band to activate the battery poles.
M	Display used for configuring, address or error information.
N	Tamper switch.

7.8.2 IP-addresses

An SR34i, which is not yet configured, will at power-up automatically create its own IP-address **10.1.200.1xx**, where xx is the physical address knobs.

Example: 005 -> IP-address = 10.1.200.105.

The IP address should always be checked and may have to be changed according to the IT-Manager.

Remember that, as soon as the IP-address is chosen, it will be stored into the SR34i. If you then power it up again, it will still use the configured IP-address – not the default.

7.8.3 Status information in the display

The SR34i have some messages (in English) that automatically – or by menu commands - can be displayed. E g that the database is not updated or that the communication does not operate properly.

7.9 Connecting the DC22 Controller

DC22 is a door controller with the following functions:

- Separate terminal block for **BCLINK** readers e.g the BC43, M43 or xx500 (xx=PR, SP, HD, PM).
- Separate terminal block for **CLOCK&DATA** or **WIEGAND** readers.
- Double relay outputs for locks. E.g electric strikes and motor lock.
- Separate outputs for door held warning and pre-warning alarm.




Fig. 2 DC22 overview. Please see next page for details.

7.9.1 DC22 installation details

A	Lock to be opened with supplied special key. (The door is not shown).
B1	The corner details can be lifted and are prepared with knockouts used for sealing or hiding cable entry. The position of these should not be changed (due to mechanical differences). They are numbered like this:
B2	81284 (B1) = Lower left + upper right corner. 81285 (B2) = Upper left + lower right corner.
C	The box is fastened on the wall with four screws.
D	The cables can either be safely mounted (cable goes over the edge) - or via knockouts in the same edge. Prepared with fixing details for securing the cable with cable ties.
E	Local circuit (RS485). Power supply: Terminal 1 and 2. Communication: Terminal 3 and 4. Screen: Terminal 5. The controller can be disconnected without interrupting the local circuit. Do not forget to use termination resistors in the circuit ends.
F	Opening relay. Voltage free contacts. Max load 2 A. The voltage output on 6 & 7 is always the same as power supply on 1 & 2 it is rectified. Max 1.4 A.
G	Connection of BCLINK type reader. The voltage output on 11 & 12 is always the same as power supply on no 1 & 2 it is rectified.
H	Connection of CLOCK&DATA or WIEGAND type reader.
I	Selection of power output to CLOCK&DATA or Wiegand reader. +5V or Vin = same as terminal 1 & 2 but rectified.
J	Remote opening input. For connection of an exit request button (push to make).
K	Door monitor input for door contact Indicates open or closed door.
L	Lock monitor input for locks with status contact. Must be closed within 15 seconds after the door connector (see K) input has been closed; otherwise the alert relay is activated.
M	Door held warning relay. Controlled by door monitor contact. Activated if the door is not closed when the door opening time has expired.
N	Alert relay. Activated if the door still open when the door held warning time has expired.
O	Voltage free motor lock control relay output. Only supported by Entro version 5.
P	Pre-warning signal activated during alarm control activation cycle. Only supported by Entro version 5.
Q	Input for activation of the alarm by-pass relay through closing (pulse). Used for activation of intruder alarm system from e.g. timers. Only in bistable mode and bistable pulse mode.
R	Alarm by-pass relay. Monostable (by-pass time = opening time + door held warning time), bistable or bistable pulse. Max load 2A.
S	Alarm Status Feedback signal (ASF). Used to synchronize Entro and e.g. an intruder alarm system. See separate section how to connect.
T	Input for external control of red LED on readers configured in a bistable alarm zone. Terminals 37 (+5V) and 38 (0V) can be used.
U	Set the door controller's address by placing the link on the appropriate address range 1-16 or 17-32 and the address on required number. Note! 2 door controllers connected to the same segment controller must not have the same address.
V	Display used for address and error information. Normally the address is displayed and the right dot is flashing. The display can be turned ON/OFF from software where the left dot lit. Error codes The display is alternating the address with any fault code R = Autonomous mode (no comm. with Segment Controller) R3 = Slow-poll state. Not yet any fast-poll (addressing). R4 = Autonomous mode - but communication error R5 = Messages are detected but unit is not yet on-line. F1 = No address jumper detected. F2 = Address conflict - used by another unit. F4 = On-line - but communication error. d = Downloading firmware.
W	Tamper switch 1. Alarm message is sent when the controller's door is opened.
X	Tamper switch 2. Alarm message is sent when the housing is removed from the wall. Note! The mechanical parts must be ordered (and mounted) separately to make this function work

7.9.2 Intrusion Alarm Zones with DC22

The DC22 door controller must be used if any bistable intrusion alarm system shall be controlled by the Entro system.

To gain highest security, you normally install and use **card readers with PIN-pad** in all doors that are used for entrance to the particular section of the intrusion alarm system. You may then use the security level *Card* for turning ON the alarm and *Card+PIN* for turning OFF.

If any section area of the intrusion alarm system includes several doors, the Entro must be configured with one or more **Alarm zones**. Each zone must then consist of at least one DC22 (with the relay) while the other doors can remotely control it via the Entro system bus.

The illustration below shows how two separate zones may look like:




Fig. 3 Alarm zones in Entro

1.	Activation signal for Zone A (from DC22)
2.	Status signal for synchronization between systems (to DC22).
3.	Activation signal for Zone B (from DC22)
4.	Status signal for synchronization between systems (to DC22)

7.9.3 Connecting Alarm Status Feedback in DC22 (ASF)

When the DC22 is used to synchronize Entro and an external intrusion controller a feedback signal *from* the intrusion system can be used. Depending on the status of the signal, the Entro recognize the intrusion system as activated or deactivated and perform relevant operations as e g “blocking” or locking doors.

The connection between the systems can be done in two ways:

- With a voltage signal.
- With closing signal (voltage free).

Below drawings shows the different methods which both controls the input (ASF).

With voltage signal

In this case the intrusion controller must send a voltage signal (maximum 24VDC) and a minus reference must be available.




Fig. 4 Voltage controlled ASF.

With closing signal

The intrusion controller makes the closing. Note that a jumper has to be installed in the DC22 between 35 & 37.




Fig. 5 Closing signal ASF.

7.10 Connecting the DC12 controller

DC12 is a door controller to be used in the Bewator Entro. DC12 can substitute and simulate the earlier DC11. The DC12 is designed to fulfill many practical issues as well as offering a nice and tidy installation.




Fig. 6 DC12 Overview. Please see next page for details.

7.10.1 DC12 installation details

A	Lock to be opened with supplied special key. (The door is not shown).
B1 B2	The corner details can be lifted and are prepared with knockouts used for sealing or hiding cable entry. The position of these should not be changed (due to mechanical differences). They are numbered like this: 81284 (B1) = Lower left corner. 81285 (B2) = Upper left corner.
C	The box is fastened on the wall with four screws.
D	The cables can either be safely mounted (cable goes over the edge) - or via knockouts in the same edge). Prepared with fixing details for securing the cable with cable ties.
E	Local circuit (RS485). Power supply: Terminal 1 and 2. Communication: Terminal 3 and 4. Screen: Terminal 5. Do not forget termination resistors in the circuit ends.
F	Opening relay. Voltage free contacts. Max load 2 A. The voltage output on 6 & 7 is always the same as power supply on 1 & 2 but rectified. Max 1.4 A.
G	Connection of BCLINK type reader. The voltage output on 11 & 12 is always the same as power supply on no 1 & 2 - but rectified.
H	Connection of CLOCK&DATA or WIEGAND type reader.
I	Selection of power output to CLOCK&DATA or WIEGAND reader. +5V or Vin = same as terminal 1 & 2 but rectified.
J	Remote opening input. For connection of an exit request button (push to make).
K	Door monitor input for door contact. Indicates open or closed door.
L	Set the door controller's address by placing the link on the appropriate address range 1-16 or 17-32 and the address on required number. Note! 2 door controllers connected to the same segment controller must not have the same address.
M	Tamper switch. Alarm message is sent when the controller's door is opened.
N	Display used for address and error information. Normally the address is displayed and the right dot is flashing. The display can be turned ON/OFF from software where the left dot lit. Error codes The display is alternating the address with any fault code A = Autonomous mode (no comm. with Segment Controller) A3 = Slow-poll state. Not yet any fast-poll (addressing). A4 = Autonomous mode - but communication error A5 = Messages are detected but unit is not yet on-line. F1 = No address jumper detected. F2 = Address conflict - used by another unit. F4 = On-line - but communication error. d = Downloading firmware.

7.11 Connecting the IOR6 Relay central

In Bewator Entro, as well as the inputs & outputs in the door centrals DC22, DC12 or DC01, you can also use inputs & outputs in the IOR6 to control different functions (like doors). There are different ways to use them:

- For lift control (button control)
- For Reservation functions (door opening)
- For Reservation functions (machine control)
- For timer control (general).
- Common alarm, emergency opening and power failure warning.

Note that in lift control applications, up to 32 IOR6 relay centrals can be connected to the Bewator Entro system. Each IOR6 is addressed as per the other units.

Mount the IOR6 as below and program it according to the *User Manual*.




Fig. 7 IOR6 Overview – Please see next page for details.

7.11.1 IOR6 Installation details

A	Lock to be opened with supplied special key. (The door is not shown).
B1 B2	The corner details can be lifted and are prepared with knockouts used for sealing or hiding cable entry. The position of these should not be changed (due to mechanical differences). They are numbered like this: 81284 (B1) = Lower left corner. 81285 (B2) = Upper left corner.
C	The box is fastened on the wall with four screws.
D	The cables can either be safely mounted (cable goes over the edge) - or via knockouts in the same edge). Prepared with fixing details for securing the cable with cable ties.
E	Local circuit (RS485). Power supply: Terminal 1 and 2. Communication: Terminal 3 and 4. Screen: Terminal 5. Do not forget termination resistors in the circuit ends.
F	Power output. Max load: 500 mA.
G	Relay outputs. Voltage free contacts. Max load: 60V, 0,9A (30V, 2A).
H	Remote controlling inputs. For connection of push buttons for direct control of the relay outputs 1-4. Input 1 controls relay 1, input 2 controls relay 2 etc.
I	Tamper switch 1. Alarm message is sent when the relay central lid is opened.
J	Optional tamper switch 2. Alarm message is sent when the housing is removed from the wall. Note! The mechanical parts for this function have to be ordered separately (and mounted) to get this tamper work.
K	Extra relay outputs, switches parallel with each relay output. Can be used for controlling a light panel etc.
L	POWER: Green LED indicates power on/off. COM: Yellow indication LED. Flashes quickly when communication is working properly, slowly when interrupted (autonomous mode).
M	Choose the address for 1-16 or 17-32.
N	Set the relay central address by placing the link on the required number. Note! 2 relay central units connected to the same segment controller must not have the same address

7.12 Connecting the DC01 door controller




Fig. 8 DC01 Overview

A	Local circuit. Power supply: Terminal 1 and 2. Communication: Terminal 3 and 4. Screen: Terminal 5. Do not forget termination resistors in the circuit ends.
B	POWER: Green LED indicates power on/off. COM: Yellow indication LED. Flashes quickly when communication is working properly, slowly when interrupted (autonomous mode).
C	Choose the address for 1-16 or 17-32
D	Set the door controller's address by placing the link on the required number. Note! 2 door controllers connected to the same segment controller must not have the same address.
E	Remote opening input. For connection of an exit request button (push to make).
F	Door monitor input for door contact. Indicates open or closed door. Configured by the installer program.
G	Opening relay. Voltage free contacts. Max load 2 A. (----- = fail safe operation e.g. magnetic lock).
H	Power supply for electric locking device. Max 500 mA.
I	Tamper switch. Alarm message is sent when the controller's lid is opened

7.13 Connecting the BC43 remote card reader




Fig. 9 BC43 Overview

A	Connection between door controller and BC43 remote card reader (max 100 m).
B	Set the link to ENTRY if BC43 is used for entrance. Set the link to EXIT if BC43 is used for exit.
C	Tamper switch control: Set the links to "Internal" when BC43 is part of a Bewator Entro system. No connection on reader terminal 5 and 6 is then allowed. Two links are used.
D	Tamper switch.
E	Connect the screen in case of long distances or disturbing environment.

7.14 Connecting keypad M43




Fig. 10 M43 Overview

A	Connection between door controller and M43 keypad (max 100m).
B	Set the link on ENTRY if M43 is used for entrance. Set the link on EXIT if M43 is used for exit.
C	Tamper switch.
D	Buzzer.
E	Connect the screen in case of long distances or disturbing environment.

7.15 Connecting the BC18 remote card reader




Fig. 11 BC18 Overview



NOTE

The J4 jumper in the door controller must be set to +5V before the door controller is powered, otherwise the reader may be damaged.

7.16 Connection of other readers

It is fully possible to connect other reader types, e.g. Entro range of proximity readers and Hands-Free readers. You will find instructions in the reader's manuals. The following examples show shorthand information for some typical readers.

Note that the DC22 & DC12 door controller supports Wiegand readers.

7.16.1 Connection of 500-series proximity readers (BCLINK)

Note that there is an optional way of controlling the red LED in these readers. You may have it always lit when the door is locked. See more in the chapter *Changing the red LED function on readers* in the User manual.

See page 45 for using these readers in Anti-pass back applications.




Fig. 12 BCLINK connections for HD500, PM500, PR500 & SP500

7.16.2 Connection of Hands-Free reader HF500 (Clock&Data)

This hands-free reader is connected to DC22/DC12 and is always mounted in-doors. However - the reading distance permits both entry and exit functions in the same reader.



NOTE

The jumper J4 in the DC22/DC12 must be linked on +Vin.




Fig. 13 Clock & Data connections for Hands-Free HF500

7.17 Connecting DC800 controller

The DC800 controller is a stand alone unit that also can be connected to an Entro system. Remember to set the jumper **J3** on **Entro** (see item N) and address it in the range 1-8.

The mechanical design is exactly as the DC12 (see page 37). See the table below for the electrical installation and setup.




Fig. 14 DC800 Overview


E	Power in: Terminal block nos. 1 and 2. 10-40V DC or 8-28V AC
F	Opening relay. Voltage free contacts. Maximum load 2 A.
G	Relay for Warning, Monostable Alarm by-pass, Alert or Duress . Software controlled. When Alert is selected also the tamper switch will activate this relay.
H	RS485 connection for system communication Com A & Com B to USB-RIF/2 (Entro Lite), next DC800 or SR34i (Entro).
I	Input for door monitor contact. Indicates open or closed door.
J	Remote opening input. For connection of an exit request button (push to make).
K	Connection of card reader/keypad. Maximum load 300 mA. Maximum distance for BCLINK readers 100 m (dependant on cabling). Maximum distance for Clock & Data readers, e.g. proximity reader: 50 m
L	Jumper for output voltage selection to reader/keypad +5V or Vin= incoming supply. Warning! Make sure the setting is correct, otherwise readers may be damaged <i>Default: +5V.</i>
M	Jumper for interface selection - CLOCK & DATA, BCLINK or WIEGAND (26bit, 32bit or 8bit PIN code). <i>Default: BCLINK.</i>
N	Jumper for system configuration - Stand-Alone, Entro Lite or Entro. <i>Default: Stand-Alone.</i>
O	Jumper for address selection 1-8 for Entro Lite or Entro. <i>Default: Address 1</i>
P	Tamper switch. Gives warning if the DC800 controller's lid is opened. Note! Will also activate the relay in item G when this is setup as Alert.
Q	Keypad 0-9 plus A & B to configure the DC800.
R	The LEDs red, yellow & green (together with the buzzer) indicates the different steps in the configuring sequences. When the DC800 is in idle mode, the green LED will flash with approx. 5 seconds interval to verify that the DC800 is powered.

8 Special installations

8.1 Anti-pass back using BCLINK readers

When BCLINK readers are installed for anti-pass back function a sub-addressing technique is used. This means that e.g. in a PR500, for example; The ENTRY PR500 and the link for EXIT PR500 are controlled internally by the door controller that decides upon the direction.


Wiring the door monitor contact and lock are done as usual.



1.	EXIT reader
2.	ENTRY reader
3.	Door monitor contact
4.	Electric lock

8.2 Anti-pass back using CLOCK&DATA and WIEGAND readers

If the readers do not support sub-addressing the door monitor contacts and opening relays be connected as follows:



1.	ENTRY
2.	EXIT
3.	Power supply
4.	Opening relay
5.	Lock
6.	Remote opening
7.	Door contact
8.	Opening relay. Note! Voltage free contacts
9.	Reader

Only connect the door contact on the ENTRY reader. Connect the EXIT reader's opening relay with voltage free contacts to the ENTRY reader's remote opening input. If needed, disable event registration of "Valid access – Exit button" in Bewator Entro event filter settings.

8.3 Installation of Interlock doors

Bewator Entro offers the possibility for two doors to co-operate in order to form an interlock zone. This means that the first door has to be closed before the next door can be unlocked.

To be able to monitor the status of the doors, both must be equipped with door monitor contacts.

We strongly recommend that also some suitable mechanical, emergency opening equipment is mounted in the interlock zone (*from within the interlock zone*).




Fig. 15 Example with two BCLINK readers PR500

1.	Door monitor contacts.
2.	Electric Lock.

8.3.1 Access from Door A to Door B

When entering door A, which is then closed *during* the opening time, door B will be automatically unlocked.

8.3.2 Access from Door B to Door A

Because the installation is the same in both doors the entrance will be work in the same way for both directions.

9 Install the connection to the PC

It is possible to use either RS232 or Ethernet for communication between a PC and controllers.

9.1.1 Local Area Network to PC

If Local Area Network (Ethernet 10/100 Mbit) is used for communication between PC and SR34i – you connect the network cable from the Ethernet connector in the SR34i to the Local Area Network.

The distance to the PC depends on the cable configuration of the network itself (hubs, switches etc). You must confirm with the IT Manager the correct IP-addresses and installation settings for the system.

It is also possible to form a dummy "local area network" which only consists of a directly connected SR34i and a PC. In this case you use a network cable between the PC and the network switch in the SR34i.



NOTE

If you connect a **temporary PC** with network cable direct to SR34i, we recommend that also the PC use a **static IP-address**. Preferably in the range **10.1.200.xxx** (with Netmask 255.255.255.0) because the SR34i initially is set to an IP-address in this range.




Fig. 16 Example of connecting a PC via Local Area Network.

9.1.2 Connect PC or printer with direct cable (RS232)

The segment controller must be installed close (max 25 meters) to the PC.

The illustration below shows an available, complete kit consisting of a wall socket (IF1), a standard RS232 cable (approx. 1.2 m) and 25 meter cable with one free end to connect to the screw terminal block of the wall socket. You can use the standard cable directly (alt. 2) between the PC and the SR34i - or make a more fixed installation (alt 1.).

RS232 needs fewer settings in the PC, which simplifies the set-up. You can also temporarily use RS232 – and then change to Ethernet later.




Fig. 17 Two alternatives for RS232 cabling.

The total distance between PC or printer and the segment controller must not exceed 25 meters maximum.



NOTE

The RS232 port can also be connected to a printer. Note that either a PC **or** a printer can be connected to a segment controller – **not** both.

9.2 Installing USB-RIF/2

In Entro, an enrolment reader can be connected directly to a PC via the reader interface USB-RIF/2. It can be used for:

- Login of cards
- Login to system software with card.
- Fast search of card holders.

USB-RIF/2 connects to a standard USB-port in the PC. It is supported of a software driver (USB-Agent) installed along with the Entro software is loaded when booting the computer.

There are also Kits available with the proximity reader PR500 (Cotag or EM4102 technology) together with a desk stand.





Fig. 18 USB-RIF/2 to PC.

10 Power supplies and communication

Connect the power supply according to the instructions below, but do not connect the power to outgoing cables. Apply power when you start the system (see the *Check the communications circuit* section on page 53)



1.	Power supply.
2.	Mains 2 + earth.
3.	Local bus (4 + screen).
4.	Power supply failure connected to IOR6.

The system cables screen can be earthed at the power supply. Connect the screen to protective earth, but remember that the system cables' screen must be earthed at **one point only** in the system.

Also remember that metal parts in doors or vehicle barriers can be in contact with earth. For readers installed on these surfaces, the screen must not be connected to the metalwork.

10.1 Central power supply


If central power supply is used, you should take precautions against voltage drop. Dimension the power supply equipment and cables so that the voltage at the last door is not below the tolerance of the lock and reader.

A 24V electric locking device has a tolerance of + -15% which is equivalent to 20,4V. A 12V electric locking device has a tolerance of + -10% which is equivalent to 10,8V.

One way of reducing unnecessary voltage drop is to place the power supply equipment somewhere in the middle of the circuit. Thus, the load will be equal on each side of the power supply. If the distances or the load are too great, multiple power supply units are required.

10.2 Local reader power supply for doors


Whenever one or several readers are connected to a local power supply, remember to join the negative wires (0 volt) to avoid potential differences. See example below.



10.3 Considerations concerning earthing & screening

The cable screens on each circuit must be connected to protective earth, **but only in one place** in the system (see picture). Also remember that metal parts in doors or vehicle barriers can be in contact with earth. For readers installed on these surfaces, the screen must not be connected to the metalwork.

Avoid placing the cables close to heavy current installations, (e.g. lifts and power doors) since they may cause disturbance.



10.4 Check the communications circuit RS485

When all units are connected (but with all removable terminal blocks disconnected in drop boxes and door controllers), check on reader block nos. 3 and 4 in drop boxes, door controllers and segment controllers that the resistance on the global and the local communication circuit respectively, is 60Ω (ohm) plus the cable resistance. If the resistance is 120Ω plus the cable resistance, one termination resistor is missing. If the resistance is much less than 60Ω , there is a short circuit in the communications circuit. If the resistance is much greater than 120Ω (open circuit), there is a break in the circuit or the termination is missing in both ends.

10.5 Check the power supply

Connect the power supplies. Check that the voltage is approximately that of the power supply output and that + and – are in the right positions.

Remember that a voltage drop (between the highest and lowest potential) larger than 5V between units may influence the quality of the RS485 communication.

10.6 Check communication

Go to all units in the system and check that they are communicating.

If using a LAN, check that all cables are correctly connected to the LAN.

11 Configuring

This manual only describes mounting and installation of different system components. Software installation and configuring is explained in the *User Manual*.

The software consists of three main parts:

Installer

Normally the first program you use, to configure different type of functions related to physical units like door monitor contacts, alarm zones and connections to PC.

Entro

This program is used for managing access groups and card holders. It can be treated as main program because it is used for daily operations.

Door and event monitor

Used for status information and event logging but can also be used for unlocking doors via the PC.

12 Bewator Entro Reservation

Bewator Entro includes reservation functions (e.g. in sports arenas, tennis courts, conference rooms etc) and works together with the integrated access control system.

The System Administrator sets which objects (such as card readers/doors) are to be included and chooses the relevant reservation time schedules.

The users wanting to reserve times can use an ordinary web-browser (such as Explorer or Netscape) and login to the SR34i containing the reservation system. Alternatively use his/her card in a reservation terminal (InfoPoint IP811/ IP810) – depending on how the system is configured.


12.1 Integrated Web server

The SR34i has an integrated (embedded) web server function, which is used for reservation applications. It requires that the dedicated SR34i have a permanent connection to the Internet (when Internet is used).



NOTE

At least one of the SR34i must be equipped with a Memory card for web reservation (see item H, page 31 – which will contain the reservation information).



12.2 How the Reservation system is installed

First, all the doors and any IOR6 (for doors and machine control in the objects) are installed according to earlier sections. Afterwards the CF8 is mounted in the SR34i intended for reservations.

Depending on how the reservation function is specified, one or more InfoPoint IP811, IP810 or touch-screen terminals can be connected to the system through the network. I.e. a combination of PC and these terminals is possible. Technically the entire reservation information is stored in an integrated website (in a SR34i) with its own IP-address on a network.



NOTE

Configuring is described the *User Manual*.

The address to this website is **<http://xxx.xxx.xxx.xxx/login.html>** which should be notified to the users of the Reservation system.

12.3 Installing the CF8 flash memory card

The CF8 memory acts similar to a hard disk unit for storing files. When delivered it contains the HTML-files used in the Reservation system.

1. Remove the power from the actual SR34i.
2. Install the CF8 card.
3. Reconnect the power to the SR34i.

When all other necessary parameters and units for Reservation are configured, you can connect to the IP-address of the SR34i (<http://xxx.xxx.xxx.xxx./login.html>) – and the login page should be displayed.

12.4 Connecting the InfoPoint IP811/IP810




Fig. 19 Rear view of the InfoPoint terminal

A	Power supply input via RJ45 type connector.
B	Supplied cable with RJ45 type connector and free end. Length is 3 meters.
C	Polarity \oplus = 24V, \ominus = 0V.
D	Standard TCP/IP network connection.
E	Standard Cat-5 IP-cable for LAN connection
F	Reserved for external units.

The InfoPoint IP811/IP810 is mounted local to the reservation object and works as a terminal with a simple, embedded web browser. You can mount it on the wall (using the supplied fixing parts) – or flush mount it in a separate box.

In the terminal there are some keys to navigate on the screen as well as a card reader to identify the user. The InfoPoint has a TCP/IP interface which requires an IP-address to work (just like a PC).

The installation manual supplied with the InfoPoint describes the steps to mount and set-up the terminal.



High Voltage

The InfoPoint housing does not normally need to be opened for proper operation. However – if needed be aware that the InfoPoint includes high voltage components.

13 DVR Installation

The Entro software can communicate with up to 16 DVR systems via TCP/IP. It supports DVR units in the Siemens SISTORE™ AX-, CX- and MX- range.

We recommend that the installer have good knowledge about DVR system in general and SISTORE™ systems in particular before any DVR functionality is introduced into the Entro system.

13.1 Implementation in Entro

The integration of DVR and Entro indeed consists of two separate hardware systems which are connected via TCP/IP and remote software functions. This means that you initially **install software components for both systems in the same PC**.

When you then configure functions (like filtered and timed triggering to start recording) in the Entro, these are then sent to the DVR. When the conditions for a certain action then are met the DVR starts recording images.

You may then replay these directly from the Entro Door monitor with some optional command options.

13.2 Planning and installing DVR and cameras

The main procedure for using DVR in Entro is that all components for the DVR system (cameras, storage units, video cabling, power supply etc) are **planned and installed separately** according to its documentation.

Remember to carefully document the IP-address, password etc for the DVR before any setup is performed in Entro. The numbering of cameras will also be needed to bring into the Entro.

Some parameters must also be configured in the DVR to get communication work in Entro. See *Appendix 1 – DVR models and settings* for different models.

When the DVR itself have been configured – please carry on with the installation by reading in the Entro *User manual* how to configure the Entro software.

14 Expanding and modifying the system

Expansion and modification of a Bewator Entro system can of course be performed in many ways. Sometimes more doors are needed (sometimes also requiring more SR34i controllers) – or more PCs are needed. In addition software updates and upgrades may apply.

Naturally, an expansion needs at least one working PC connection to handle the necessary setup. If local area network is used, be sure to **reset to the factory crypto key** before any expansion is done.

14.1 RS485

In a system only using RS485 communication (RS232 for PC), just install new segment controllers and door centrals together with new cabling and power supplies. All units will start to communicate immediately.

14.2 Networking

In a TCP/IP based system the segment controllers and PCs must be installed correctly with correct IP-addresses and encryptions keys. Door controllers and readers are installed as before.



NOTE

The easiest methods when expanding the system is to temporarily reset to the factory installed Default crypto key – and then change it later on when the system installation is finished.

All controllers must be of type **SR34i**. I.e. the older SR32i (or SR32) cannot be used.

If *new* SR34i controllers or PCs are to be connected to a TCP/IP based Bewator Entro system, they must be configured correctly. There are two "channels" used for information:

- Between PC and SR34i – through RS232, modem or TCP/IP.
- Between SR34i and SR34i – through RS485 or TCP/IP.

The basic rule is that if the communication is done via TCP/IP the **crypto key** must be loaded into all units. However, if RS232 is used instead for PC-communication, the controller can be reached.

14.3 Installing another PC

Entro 5.3 allows that several PCs concurrently can administrate the system:

- Only one PC can be online (the tab **Connection** not displayed in Installer).
- Several PC on-line concurrently (more *Connections*).

Regardless of which above, the new PC must fulfill certain requirements:

- A separate Bewator Entro software license must be available for this PC.
- The Bewator Entro program should be installed on the PC, which also must have its own, valid IP-address for LAN connection.
- The PC must have a valid crypto key installed – if used.

We assume below that the system is reset to the factory installed **Default crypto key** before any new units are connected to the system and that no preparations for more connections are done.

14.3.1 Prepare the existing database

Proceed as follows:

1. Start the Installer program on the existing working PC.
2. Go to the **Connection** tab in the **System/System settings** and select that several computers can be connected concurrently.
3. Click OK – and a new tab appears in the main window in the Installer. The default, earlier hidden connection is now displayed as #1. Change the name of it before going further.
4. Click the tab **Connections** and start the wizard by clicking **New**.
5. Select **System administration** and enter the parameters:
 - Name of the connection (any name)
 - Which SR34i – we recommend to use the same SR34i for all PCs unless a serial port (RS232) is to be used in the new PC.
 - **License number** – I.e the number for the new computer. This is noted on the CD case for the new software license.
 - Type of communication – TCP/IP, RS232 (or modem).
6. You have now created a new connection for Entro and can exit the program in the existing PC.

14.3.2 Configure the new PC

Because this PC does not yet have any database stored nor know the way of communicating with Entro, you have to create a *connection*.

1. Start the **new PC** and install the Bewator Entro software according to instructions in the User manual. **Note! A separate software license is needed.**
2. Start the Installer and select at login that a **new connection** shall be created. Follow the instructions on the screen (similar to above). You have now defined in which way the computer will communicate, entered the system name etc.
3. Exit and start *Bewator Entro* and **Change Crypto key**.

14.3.3 Installing another SR34i

There are several ways to configure an SR34i before connecting it to a system. Sometimes it is easiest to use the RS232 port.

Remember that the SR34i have built-in menu commands for checking editing different parameters.

It is important that the set-up is correct. This means:

- Correct System name.
- Correct network parameters (IP address, Netmask and Gateway).
- Correct crypto key. – if used

In some network solutions you will get help from the software to “find” a new SR34i (node).

The condition for this is that it exists within the same “subnet” as the PC (which sends a request when starting the *Installer* program). If an SR34i is found you can add it and configure it like the other controllers.

If the conditions for the above are not met - proceed as follows:

1. Be sure the PC has an updated database.
2. Change to **Standard crypto key** (temporarily) for the whole system.
3. Select the address on the new SR34i – and power it up.
4. Set up the networking parameters (e g IP address) using the keypad and display. (Eventually you must erase the memory of the SR34i.)
5. Connect the network cable and start *Installer* – and the new controller will be found by the software and is shown as **Cxx. The database and the crypto key are sent from the PC - to the controller. Note that firewalls etc may require that some SR34i have to be setup manually (no **Cxx displayed).
6. Change name and set-up the parameters for this controller.
7. Exit.
8. Start *Bewator Entro* and **Change Crypto key**.

14.4 Installing more readers

It is very easy to install more readers in the system. You only need the necessary cabling and ensure the following:

- The DC12 or DC22 are available for the reader. (Does not apply for the PD30-EM/PD40-EM).
- That the hosting SR34i does have enough addressing capacity.
- That the power supply is enough.
- That the bus termination resistors are installed properly.

14.5 SR34i firmware control

Sometimes when a system is expanded or upgraded there maybe need for patching the firmware in the segment controllers.

In the Installer program there are improved functions for controlling the mechanism for patching the segment controllers. The status of the different units is displayed.

In a system you are now able to use the **same PC** for updating all controllers at the same time. In addition you can indeed select which controller to update and which data file ("SR_firmware.hex") to use.

Also there is better information about the status of each updating process. You can actually see the estimated time. This applies for all controllers – not only the one connected to the PC.



NOTE

The download is using the current files stored in the Entro program folder.

Proceed like this for the actions you want to do:

1. Start *Installer* and choose **System/System information**.
2. All controllers are listed on the screen showing the status for the different units (address, product, version, voltage level). If any controller fails to communicate there is a cross over the unit.
3. Click on **Update firmware** – and select which version to download (stored in the Entro program folder). It is possible to download an old version.
4. Click on **Next** and mark the SR to be updated.
5. Click on **Finish**. A progress bar is displayed for each controller showing the remaining time
You cancel the process at any time by clicking **Cancel update** – no update is performed and the old version remains.
6. Finished.

14.6 Door controller firmware control

If the door controllers DC12/DC22 and the PD40-EM/PD40-EM have firmware **version 1.20** or later, the Installer program can download new firmware via the system bus. This requires that the units are on-line.



NOTE

During download the door is unlocked if this is defined in the *Security level in off-line condition*. All other selections results in a locked door.

14.7 Printout of system configuration


In the *Installer* program you can generate a graphic view of installed components for easier control of e g current firmware versions etc. Proceed like this:

1. Start Installer and go to **System/System information**.
2. Click on **Save as** – as an image in JPG format is stored on disk.

15 Installing modem based systems

Up to 10 000 Bewator Entro systems may be controlled from one PC. If several systems are to be connected **directly** to a PC, the PC must have as many COM ports as there are Bewator Entro systems. PCs communicating with one system directly and with another via modem must have one COM port for connection of a segment controller and another for connection of a modem.

Below is an example of a configuration where a PC has direct contact with one Bewator Entro system and modem contact with another.



1.	System #1
2.	System #2

15.1 Installing the modem based system

Having named the new Bewator Entro system and stated how it should communicate with the PC, you should complete a doors chart and install card readers, segment controllers etc according to the instructions given earlier in this manual.

15.1.1 Configuring a system equipped with TD35 modem (recommended)

We strongly recommend to use the TD35 at the site when using modem communication because it has e.g. a watch-dog.

If you have installed a modem TD35 at the remote site (and its telephone number is available) there is no need to do the configuring on site. You can connect the SR34i to the modem, hook on the line but do the configuring at the host computer instead (even if this may take longer time). See more in chapter *Transferring the new system's information to the central PC*.

However – if you still want to configure it on site, you do this through the RS232 link and then switch to modem when it is done. Proceed according to the chapter *Configuring the modem based system on site*.

15.1.2 Configuring a system equipped with a custom modem

If another modem (not TD35) is used there may be a need of changing the init string of the modem and configured on site (via RS232).

You should then, temporarily, connect a PC with the Bewator Entro software to one of the segment controllers to be able to configure the system (see the next chapter). When the configuring is finished you can disconnect the PC and connect the modem instead.

Do not forget to test the communications circuit and the power supply according to the instructions on page 53.

15.2 Configuring the modem based system on site

You have now installed card readers, segment controllers and a PC. For the system to work you should also program information about doors and segment controllers. Configuring the new system should be done on location, i.e. with the PC connected (with RS232) to a segment controller in the new system.

1. Start *Installer* and click the tab **New connection** and you start a wizard to establish the connection between the PC and the controller. No login is needed because the system (database) is probably new and will use the default user name *bewa* and password *pass*.
2. Select **New system** and proceed.
3. Select **RS232** and proceed. The software automatically detects the correct COM-port.
4. Enter a name for the new system in the **Site name** field, e.g. Oak lane. This name will be displayed in the Bewator Entro Login windows, for the user to choose whichever system he or she wants to work with.
5. Enter the system's name in the **System name** field. This name must be **unique and identical** with the name you will be asked to enter when setting up the main computer (see page 68).



It is very important that you make note of the system name. If the PC has to be replaced you must enter the same system name once again.

6. Exit the wizard by clicking **Finish**. Now the *Installers* main window is displayed.
7. You perform the set up of doors etc when you are on site according to the instructions given in the *User manual*. (Instead of later on via the modem connection).
8. Now the main configuring is done and you now prepare to connect the modem.
9. In *Installer* click on the **Connection** tab.
10. Mark the tick box Modem and a new tab is displayed.
11. Enter the **modem telephone number**.
12. A suggestion for the modem's so called init string is automatically displayed in the **Init string for SR34i modem** field. This string means "command echo disabled", "auto answer off", and "DTR disconnected". The string can be modified if needed.
13. If the modem needs to be able to call the PC, enter the desired telephone number in the **Telephone number to PC** field.

14. If the modem needs to be able to call the PC, you enter the name of the **System user** who shall dial up the PC (so that the PC know where to store the events). Set also for which circumstances. The following alternatives exist:
- **After (desired number) events.** Means that the segment controller calls the PC following the desired number of events.
 - **On every event set to alarm.** Means that the segment controller calls the PC following each alarm event.
 - **On database changes.** Means that the segment controller calls the PC following each modification in the database. This only applies if another PC is connected to any of the new system's segment controllers. A call is made every 15 minutes if the database is modified.

NOTE 1

Activation and deactivation of alarms as well as PIN code alterations are a database modification, which means that calls will be made every time this occurs.



NOTE 2


Entrosor must be running in the PC for Bewator Entro to be able to receive calls about database modifications.

15. Click **OK**.

Now you have configured all the information about the new system. Disconnect the PC you have used for configuring the system and connect the modem instead (see next page).

15.3 Installing the modem

The illustration below shows how to connect a modem to the segment controller used for communication with the PC.



When the modem is installed the installation is completed. The only thing remaining is to transfer the information configured for the new system to the central PC used to configure both systems.

Minimum requirements for modem:

- 9600 bit/s
- Auto answer off
- DTR disconnected
- Command echo disabled

Recommendation:

The modem should have Watchdog built-in. Watchdog resets the modem automatically in case of an interrupted connection or power failure.



NOTE

If the modem runs on 12-24V, it can be powered by the system's supply, in which case it will also make use of the system's battery backup.

15.4 Transferring the new system's information to the central PC

Go to the PC to be used for configuring and monitoring both systems.

If this PC has not Bewator Entro Installed install it from the CD provided (see User manual – Installing Software).

Then you will need to **create an initial connection** in the PC (to the modem) to be able to transfer the information. Later on you only have to select which system/connection, login and dial up as usual.

1. Start *Bewator Entro Installer*

Note that if the PC has no system installed, the wizard starts automatically and you start the wizard directly (without login).

2. Enter the **User name & Password**.

3. Go to tab **New connection** and start the wizard.

4. Select **Existing system** and proceed.

5. Mark the modem choice and enter the telephone number of the modem. Now the connection is set up and you might proceed dialing up the remote site as below - or later you can log in and dial up.

6. Enter the **Site name** and **System name**.



NOTE

It is very important that you enter the same system name as when you installed the modem. If the PC has to be replaced you must enter the same system name once again.

7. Exit.

The wizard will now try to connect (dial-up) the remote site. If this fails – proceed as below.

8. The Bewator Entro Installer main window is displayed. The name of the chosen system is displayed in the window's title bar. Since you have not yet called the new system you are OFF-LINE.

9. Click the lifted handset symbol on the tool bar or choose **Call** on the **Modem** menu. A message is displayed while the system tries to establish a connection.

When the connection is established the systems are in direct contact, i.e. the green ON-LINE indicator is lit. When all information is transferred (this may take a couple of minutes) the DB UP TO DATE indicator will also turn green.

The new system is now ready to receive information about time schedules, persons, access groups and doors according to the *User manual*.



NOTE

Bewator Entro should always be ONLINE (connected via modem) when configuring a modem-controlled system. This way information transfer will be quicker and safer.

16 Integrating with external applications (BAPSI)

16.1 General

Normally access control system software is quite proprietary to its system components and is seldom open for customized applications. This is quite natural because it is also a security system to be used for controlling e.g. access to doors in different kind of facilities.

Bewator Entro can use a well-defined configuring interface to communicate with other, external software packages (like Time & Attendance, Alarm control or similar). E.g. to import/export cards, get time stamps or events.

An ordinary **TCP/IP** link is used for transferring the data between the different software components.

The external software must be modified/completed according to the specification we call BAPSI. Remember, this not a program just guidelines to the programming interface.


With BAPSI this is done in a specified and safe (encrypted) way that still keeps the access control system on a secure and integral level.

The specification can be requested from Bewator.

16.2 What is BAPSI used for?

Normally the User interface in access control software allows for functions like card registering, time schedule configuring and standard event logging (and searching).

Using BAPSI, custom application software can take advantage of sending/receiving messages to/from the access control system – and easily add new functions into the overall system. This could be Time& Attendance, Reservation systems etc.



16.3 Field applications

At the moment there are already systems running in the reservation applications area – using the BAPSI software interface. In this case the supplier of the external reservation software made a modification to their software module, which writes data into a file – and Bewator developed a special module that reads this file and forwards this information to the access control system

16.3.1 Application example - External Reservation system

Bewator have, mainly for the Swedish market, developed an application (based on BAPSI) called BAPSER, which allows for sending data between Bewator Entro and external reservation software (at the moment Idavall-Fri and Argentum-Booking).

The module is installed in the external PC that uses a TCP/IP link to send the reservations to Bewator Entro.

If you intend to use BAPSI in some way the Bewator Entro must have some parameters set up.

This is described in the documentation supplied with the BAPSER but you can invoke the menus by proceeding as follows:

1. Start the *Installer* program and click on **Connections**.
2. Click on **New**.
3. Select **BAPSI – external application integration** and proceed.
4. Enter the necessary parameters applying to the actual application.
5. Click **OK**

17 Checklist

The checklist below is a useful aid when installing Bewator Entro. It will also make sure the implementation will run smoothly. If you have questions, do not hesitate to contact technical support.

The operating system in the system's PC is: 2000 XP

If RS232 is to be used - are there free serial COM ports (9/25-pin plug) in the system's PC? Yes

Is the wall socket (RS232) installed close to the system's PC and connected to a suitable SR34i and is the total distance between PC and SR34i less than 25 meters? Yes

If local area network is to be used – does the PC have a correct connection? Yes

Have the SR34i got correct IP-addresses – authorized by the IT-Manager? Yes

Have all connected segment controllers, readers and door controller's proper addresses? Yes

Is the reader connected to correct terminal block in DC22/DC12 and is the power link correctly fitted? Yes

Is a 120-ohm resistor fitted at the end of each RS485 communication circuit? Yes

Does the resistance in all communication circuits comply with the values recommended in the manual? Yes

Is each circuit's screen connected to earth in one place only? Yes

Are the power supply equipment and cables properly dimensioned? Yes

When Reservation is used – is at least one CF8 installed in an SR34i? Yes

Is time and date properly set when the system is on-line? Yes

18 Technical information

Bewator Entro software

- Software for control of up to 10 000 systems, each capable of managing up to
 - 512 doors
 - 40 000 cards
 - 240 time schedules
 - 480 access groups
 - 128 zones (alarm, anti pass back, roll call, interlock and entrance limitation zones)
 - 16 system users in 4 levels + installer level
 - 14 holidays, 7 half days and 4 holiday periods in each time schedule
- Supplied on CD with accompanying manuals

Reservation functions

- 64 reservation objects (machine groups).
- Maximum of 30 doors and/or IOR6 relays in each Reservation object.
- 32 time schedules with 24 intervals in each.
- Flexible interval reservation.
- Maximum number of reservations is 6 100.

Basic requirements for PC:

- Pentium processor 266 MHz
- 64 Mb RAM
- At least 20 MB free hard disk space
- CD-ROM drive
- VGA color monitor
- Serial port for connection of segment controller/modem
- Local Area Network connection
- Windows 2000 SP4, XP SP2 - or later
- MS Internet Explorer 5.0 or Netscape 4.7 (or above) is recommended as Web browser.

Basic requirements for network:

- Twisted pair Ethernet 10/100 Mbit connection.
- Communication between SR34i is done through TCP/IP.
- We recommend static/permanent IP-address for every SR34i (In some cases also Netmask and Gateway is needed).
- We recommend permanent, active Internet connection of SR34i (when Internet is used).

Note - when Internet connection is used, the following ports have to be open (in fire-walls or similar) and configured as follows:

- 4002 if communication is used between PC and the chosen SR34i.
- HTTP (port 80) when using reservation via Internet.
- 4011 for TCP when several SR34i communicates through LAN.

- SNTP (port 123) for fetching correct time, if SR34i uses TCP protocol between each other. SR34i Segment controller

DVR integration

- Maximum 16 DVR
- Maximum 128 cameras

InfoPoint IP811/IP810

- Reservation terminal for Bewator Entro.
- Color screen with 400 x 200 resolution in 256 colors.
- Integrated proximity reader.
- Numeric keypad 0-9 (IP810) and 10 function keys.
- Temperature range: +5 – 40 °C
- Power supply: 10 – 35 V DC/AC.
- Power consumption: 350 mA (24 V DC).
- Dimensions:
 - InfoPoint: 154 x 350 x 52 mm (H x W x D).
 - Flush mount box: 211 x 388 x 43 mm (H x W x D).
Cut out hole: 140 x 354 x 40 mm (H x W x D).

Segment controller for 4, 8, 16 or 32 doors

- Four built-in communication interfaces:
 - RS232 – for connection of PC, printer or modem. Max 25 m
 - RS485 global – for interconnection of up to 16 segment controllers
 - **Two** TCP/IP network connections 10/100 Mbit for communication via WAN/LAN
 - RS485 local – for connection of door readers
- Integrated network switch with one 'internal' and two external ports.
- Display and keypad for configuring.
- Memory for 10 000 events.
- Lockable housing for wall mounting
- For installation inside in a dry environment only
- Temperature range: 0 – 50 °C
- Housing fitted with tamper switch
- Dimensions: 182 x 248 x 66 mm (H x W x D)
- Power supply: 8 – 40 V DC or 8 – 30 V AC
- Power consumption: 100 mA, 24 V DC.
- RS232 interface:
 - 9600 baud alt 57 600 baud.
 - No parity
 - 8 bits
 - 1 start bit
 - 1 stop bit
 - Printer output with hardware handshaking (character table ISO 8859-1)

DC22 Door controller

- Door controller for 1 door and connection of up to two Entro readers.
- 6 voltage free relay contacts.
 - Change over contact for control of electrical locking devices or similar.
 - Closing contact for control of a motor lock.
 - Change over contact for alarm by-pass, (Monostable, Bistable or Bistable pulse).
 - Closing contact for pre-warning during alarm activation cycle.
 - Closing contact for door held warning i.e. if a door remains open beyond the set time.
 - Alert relay for door alarm (e.g. when doors are forced open) or for motor lock control.
- Maximum load over the relay contacts: 2 A, 30 V DC.
- Opening time: 1 – 99 second.
- Exit request input with delay.
- Input for indication of intruder alarm status (red LED).
- Input for alarm by-pass activation e.g. from a time clock or the Alarm status feedback signal (ASF).
- Separate inputs for door & lock monitoring for closed/open door and locked/unlocked lock.
- Maximum reader load: 500 mA.
- Rectified DC output for door locks (input voltage less 1.5 volts at 500 mA maximum).
- Lockable housing for wall mounting.
- For installation inside in a dry environment only.
- Housing fitted with tamper switch.
- Temperature range: –35 °C to +50 °C.
- Dimensions: 182 x 248 x 55 mm (H x W x D).
- Power supply: 8 – 40 V DC or 8 – 30 V AC.
- Power consumption: Max 60 mA, 24 V DC (excl reader).

DC12 Door controller

- Door controller for 1 door and connection of up to two Entro readers.
- Opening relay for control of electric locking device or similar.
- Maximum load over the relay contacts: 2 A, 30 V DC.
- Opening time: 1 – 99 seconds.
- Exit request input with delay.
- Input for door monitoring. Indicates closed/open door.
- Maximum reader load: 500 mA.
- Lockable housing for wall mounting.
- For installation inside in a dry environment only.
- Housing fitted with tamper switch.
- Temperature range: –35° to +50 °C.
- Dimensions: 128 x 250 x 54 mm (H x W x D).
- Power supply: 8 – 40 V DC or 8 – 30 V AC.
- Power consumption: Max 60 mA, 24 V DC (excl reader).

DC01 Door controller

- Door controller for 1 door and control of door without reader.
- Opening relay for control of electric locking device or similar.
- Maximum load over the relay contacts: 2 A, 30 V DC.
- Opening time: 1 – 99 seconds.
- Exit request input with delay.
- Input for door monitoring. Indicates closed/open door.
- Lockable housing for wall mounting.
- For installation inside in a dry environment only.
- Housing fitted with tamper switch.
- Temperature range: –35 °C to +50 °C.
- Dimensions: 80 x 120 x 40 mm (H x W x D).
- Power supply: 10 – 40 V DC or 8 – 30V AC.
- Power consumption: 100 mA.

IOR6 Relay central

- Relay central for
 - Lift control
 - Reservation function or
 - Timer control
 - Common alarm
 - Emergency opening
 - Power failure warning
- 6 voltage free relay outputs.
- Maximum load over the relay contacts: 60 V, 0,9 A (30 V, 2 A).
- 4 inputs.
- In Lift Control applications, up to 32 IOR6 can be connected in a system.
- Lockable housing for wall mounting.
- For installation inside in a dry environment only.
- Housing fitted with tamper switch.
- Temperature range: –35 °C to +50 °C.
- Dimensions: 140 x 200 x 60 mm (H x W x D).
- Power supply: 8 – 40 V DC or 8 – 30 V AC.
- Power consumption: 50 mA in standby mode, 200 mA with all relays activated.

19 Appendix 1 – DVR models and settings

This appendix describes which parameters to set in the different SISTORE™ models and which additional cautions to consider getting them work in the Entro environment.



NOTE

For all models - it is recommended to print the documentation on the CD (supplied with the DVR) before any configuration is done.

19.1 SISTORE™ MX

There are some initial steps to carry out via the SISTORE™ MX software before any Entro software can communicate.

Normally you probably install the whole MX software suite to be able to both control the detailed settings of the MX DVR - as well as viewing. It is however possible to only install the RemoteView module to view recordings from Entro.

We recommend that the MX software is installed on the C-drive.

19.1.1 MX Parameters

You must confirm (or re-configure) the use of and note down the following parameters in the MX type of DVR:

Parameter	Default value	Optional User Value:	Comment
User name:	Administrator		Entro parameter
Password:	Administrator		Entro parameter
IP address	<Not set>		Entro parameter
Port	40	N/A	<Fixed in Entro>
Port SR <-> DVR	8080	N/A	<Fixed in Entro>
Port range	1100 - 1109	N/A	<Fixed in Entro>
Camera no's and names	<Not set>		Entro parameter



NOTE

It is a good idea to name the cameras equally in both the DVR and the Entro environment because otherwise it is a risk that the on-screen name differs from the name seen in the Entro event log.

When the parameters are configured – enter them into the Entro *Installer* program when creating connections and cameras. Read more how to do in the Entro *User Manual*.

19.1.2 MX Live Viewer software

If you only want to do the basic viewing from Entro, just install the RemoteView module on the actual PC where Entro is installed. Otherwise no view will be displayed

19.1.3 Additional considerations for the MX

Following settings must be performed in the MX:

- In the configuration "software trigger" has to be activated to start recording. You have to activate that at the MX itself. It's not possible with the remote configuration.
- Continuous recording has to be activated. This can also **only** be activated at the MX itself.

19.2 SISTORE AX

19.2.1 General

- Note that if you connect a VGA monitor to display the on-screen menus (and images) – check that the rear selector switch are set to VGA.
- You also install the supplied **PC software** for remote control of the AX in the actual PC where Entro is installed. Otherwise no views will be displayed.
- Although you will see the AX Admin, AX Watch and AX Search software commands in the PC – you should be careful using them when the Entro application is running.

19.2.2 AX Parameters

You must confirm (or re-configure) the use of and note down the following parameters in the AX type of DVR.

It is possible to use the buttons on the AX front panel to configure the basic parameters (e.g. the IP parameters) according to the AX Quick start guide. As soon as you have established a LAN connection to the AX you can optionally configure the parameters from the PC.

Parameter	Default value	Optional User Value:	Comment
User name:	<Not set>		Entro parameter
Password:	12345678		Entro parameter
IP address	192.168.1.129		Entro parameter
Gateway	192.168.1.254.		Entro parameter
Subnet mask	255.255.255.0		Entro parameter
Port: SR <-> DVR	17655	N/A	<Fixed in Entro>
Port: Watch	8016	N/A	<Fixed in Entro>
Port: Admin	8200	N/A	<Fixed in Entro>
Port: Search	10016	N/A	<Fixed in Entro>
Port: Callback	8201	N/A	<Fixed in Entro>
Camera no's and names	<Not set>		Entro parameter



NOTE

It is a good idea to name the cameras equally in both the DVR and the Entro environment because otherwise it is a risk that the on-screen name differs from the name seen in the Entro event log.

19.2.3 Additional considerations for the AX

Following settings must be performed in the AX:

- Continuous recording have to be activated
- No recording configuration in the time laps recording setup.
- AX 9/16: The REC button has to be activated at the AX device.

When the parameters are configured – enter them into the Entro *Installer* program when creating connections and cameras. Read more how to do in the Entro *User Manual*.

19.2.4 AX Live Viewer software

Note that only **one live view window at a time** can be displayed using the AX Watch remote software.

This means e.g that if Entro is displaying a view in the *Installer* when setting up a camera you cannot concurrently view an image in the Door Monitor (by clicking on a camera icon).

19.3 SISTORE™ CX

19.3.1 General

The CX model uses PC software module for configuring and viewing. Read more in the *Quick setup* or the *DVR Configuration manual*.

We recommend that the SX-CX software is installed on the C-drive.

Note that the CX includes an integrated “homepage” which can be browsed for more information about the actual unit. As soon as the “device list” is configured it is possible to connect.

19.3.2 CX Parameters

The DVR does not have any front panel buttons to re-configure e.g its network settings locally. Therefore it is recommended to initially use a PC with the *SX-CX-Config* software installed (without any other network connected) and connect the network cables only to the DVR.

As soon as the steps according to the DVR manual are done you then confirm (or re-configure) the use of and note down the following parameters in the CX type of DVR using the **SX-CX Config** program:

Parameter	Default value	Optional User Value:	Comment
User name:	admin		Entro parameter
Password:	admin		Entro parameter
IP address	169.254.16.9		Entro parameter
Subnet mask	255.255.0.0		Entro parameter
Gateway	0.0.0.0		Entro parameter
Port	12050	N/A	<Fixed in Entro>
Port SR <-> DVR	12050	N/A	<Fixed in Entro>
Camera no's and names	<Not set>		Entro parameter



NOTE

It is a good idea to name the cameras equally in both the DVR and the Entro environment because otherwise it is a risk that the on-screen name differs from the name seen in the Entro event log.

When the parameters are configured – enter them into the Entro *Installer* program when creating connections and camera settings. Read more how to do in the Entro *User Manual*.

19.3.3 CX Live Viewer software

The software for remote viewing, currently named **SX-CX Client**, on the DVR must be installed in the actual PC where Entro is installed. Otherwise no view will be displayed.

19.3.4 Additional considerations for the CX

The IVM rules (standard) have to be activated to get the pre- and post-recording functionality in the DVR to work.

20 Keyword index

A

Alarm Status Feedback, 35
Alarm Zones, 34
Anti-pass back, 43, 45, 46
AX, 77

B

BAPSI, 69
BC18, 42
BC43, 41
BCLINK, 25, 43

C

cables, 24
cameras, 58
central power supply, 51
CF8, 56
Clock&Data, 25
Common alarm, 38
Connection, 60
Connections, 14
crypto key, 61
Crypto key, 60

D

database, 15, 60
DC01, 40
DC12, 36
DC22, 32
DC800, 44
DHCP, 20, 22
display, 31
DNS, 20
Door held warning, 33
door monitor contact, 45
Door monitor input, 33, 37
download, 62
DVR, 58, 76
dynamic DNS, 20

E

encryptions, 59
enrolment, 50
ENTRY reader, 46
Ethernet, 16, 31, 48
EXIT reader, 46

F

factory crypto key, 59
firmware, 62

G

glands, 28

H

HF500, 43
HTML, 56

I

InfoPoint, 55, 57
init string, 65
interlock, 47
intrusion, 7, 34, 35
IOR6, 38
IP-addresses, 31

K

knockouts, 27

L

LED, 43
license, 15, 60
License, 60
lift control, 38
Local Area Network, 48
local power supply, 52
Lock monitor input, 33

M

M43, 42
machine control, 38, 56
Memory card, 55
modem, 63, 64, 65
motor lock, 33
MX, 76

P

Password, 68
patching, 62
power supply, 51
proximity, 43, 50

R

readers, 61
reservation, 55

RS232, 49
RS485, 16

S

Sistore, 76
SISTORE, 58
software, 54
SR34i, 30
Static IP-addresses, 21
switch, 30

T

TCP/IP, 16

termination resistor, 53

U

USB-RIF/2, 50
User name, 68

V,W

wall socket, 49
web server, 55
Wiegand, 26
voltage drop, 51, 53

Issued by
Bewator AB
SE-171 24 Solna
Sweden

www.bewator.com

© 2007 Copyright by
Bewator AB, a Siemens company

Data and design subject to change without notice.
Supply subject to availability.

Document no. **81328-4**
Edition 03.2007