

manuale d'installazione ed uso • installation and use manual • installations- und bedienungsanleitung
manuel d'installation et d'utilisation • manual de instalación y uso

SENTINEL DUAL

SDL 3300 - 4000



GB

SAFETY

6

USER'S MANUAL

41

www.upsdirect.com

Thanks you for choosing this product of the *Sentinel Dual* range.

Riello UPS are renowned specialists in the development and production of uninterruptible power supplies (UPS). The UPS in this range are high quality products, designed and built with care in order to give you the best performance.

This equipment can be installed by anyone, subject to **CAREFULLY AND THOROUGHLY READING THIS MANUAL.**

The manual contains detailed instructions on how to use and install the UPS.

For information on using and getting the best performance from your UPS, this manual should be kept safely in the vicinity of the UPS and CONSULTED BEFORE TAKING ANY ACTION ON THE UPS.

ENVIRONMENTAL PROTECTION

During the development of its products, the company uses extensive resources with regards to all environmental aspects.

All our products pursue the objective defined in the environmental management system developed by the company in compliance with standards in force.

No hazardous materials such as CFC, HCFC or asbestos are used in this product.

When evaluating packaging, the choice of material has been made favouring recyclable materials.

For correct disposal, please separate and identify the type of material of which the packaging is made in the table below. Dispose of all material in compliance with standards in force in the country in which the product is used.


<i>Description</i>	<i>Material</i>
Pallet	Heat-treated pine
Packaging corner	Stratocell/cardboard
Box	Cardboard
Adhesive pad	Stratocell
Protective bag	HD Polyethylene

DISPOSING OF THE PRODUCT


The UPS contains internal material that (in case of dismiss / disposal) are considered TOXIC and HAZARDOUS WASTE, such as electronic circuit boards and batteries. Treat these materials according to the laws applicable referring to qualified service personnel. Their proper disposal contributes to respect the environment and human health.

PRESENTATION	5
UPS VIEWS	6
DISPLAY MASK VIEW	7
INSTALLATION	8
OPENING THE PACKING AND CHECKING CONTENTS	8
TOWER VERSION	9
RACK VERSION	10
USE	11
CONNECTIONS AND SWITCHING ON FOR THE FIRST TIME	11
SWITCHING ON FROM THE MAINS	11
SWITCHING ON FROM THE BATTERY	11
SWITCHING THE UPS OFF	11
DISPLAY PANEL INDICATIONS	12
UPS status indicators	12
Measurements display area	13
Configuration area	15
MODES OF OPERATION	16
UPS CONFIGURATION	17
COMMUNICATION PORTS	19
RS232 and USB connectors	19
Communication Slot	19
SOFTWARE	20
Monitoring and control software	20
Configuration software	20
BATTERY PACK	21
REPLACEMENT OF THE BATTERY PACK	21
PROBLEM SOLVING	22
ALARM CODES	24
TECHNICAL DATA TABLE	26
FERRITE INSTALLATION ADDENDUM	27

The new *Sentinel Dual* UPS family has been designed with a special eye to versatility. These UPS, depending on the user's requirements, can in fact be installed either in tower version or in rack version (by means of a suitable *handles kit* option). The 2 different product versions are shown below:



Tower



Rack



The UPS also has a dedicated battery pack that permits easy replacement of the batteries (hot swap), entirely safely for the operator, thanks to the protected connection system.

		<i>SDL 3300</i>	<i>SDL 4000</i>
Nominal power	[VA]	3300	4000
Nominal voltage	[Vac]	220 / 230 / 240	
Dimensions H x L x D	[mm]	455 x 175 x 520 ⁽¹⁾	
Weight	[Kg]	38	



⁽¹⁾ In the rack version, with the handles installed, the H dimension changes as follows: 483mm x 175mm x 520mm (H x L x D)

Note: 175mm = 4U
483mm = 19"

UPS VIEWS



DISPLAY MASK VIEW




LCD Display

- | | |
|------------------------------|-------------------------------|
| ① Operating normally | ⑦ Configuration area |
| ② Operating on mains power | ⑧ Maintenance action required |
| ③ Operating on battery power | ⑨ Timer |
| ④ Load powered from bypass | ⑩ Measurements display area |
| ⑤ Battery back-up indicator | ⑪ Stand-by/alarm |
| ⑥ Load level indicator | |


OPENING THE PACKING AND CHECKING CONTENTS

After opening the pack, the first thing to do is make a check of the contents.
The pack should contain:


- UPS




- 2 plastic covers (top panels)




- Power cord (Schuko plug – IEC 16A socket)




- 2 plastic keys for releasing the display




- 2 IEC 10A connection cables





- RS232 serial cable



- IEC 16A spare socket



- User manual + CD-ROM with software



TOWER VERSION

This chapter describes the work needed to prepare the UPS for use in tower version.

WARNING: *for your own safety and that of your product, it is important that you follow the instructions given below exactly.*



BEFORE PROCEEDING TO PERFORM THE SEQUENCE OF OPERATIONS DESCRIBED, MAKE SURE THAT THE UPS IS SWITCHED OFF COMPLETELY AND IS NOT CONNECTED TO THE ELECTRICAL MAINS OR LOAD OF ANY KIND




Once removed from its packaging, the UPS is already prepared for installation in tower configuration. To complete the configuration, all that is needed is to fit the two plastic covers provided on the top part of the UPS, as described below:

the 2 covers have a snap-fit fastening system:

identify the special holes for mounting of the covers in the top part of the UPS and, taking the utmost care, fit the covers exerting a slight pressure (see figure to the side).

Note: as the covers are perfectly identical, they can both be fitted in either of the areas (front/back) on the top of the UPS without any problem.



www.upsdirect.com


RACK VERSION

This following describes the work needed to convert the UPS into rack version.


WARNING: *for your own safety and that of your product, it is important that you follow the instructions given below exactly.*

BEFORE PROCEEDING TO PERFORM THE SEQUENCE OF OPERATIONS DESCRIBED, MAKE SURE THAT THE UPS IS SWITCHED OFF COMPLETELY AND IS NOT CONNECTED TO THE ELECTRICAL MAINS OR LOAD OF ANY KIND

- 1 - First and foremost, remove the 4 feet on the bottom of the UPS. Set the UPS horizontal, taking the utmost care and using a small, flat blade screwdriver lift gently the pin placed in the centre of the foot. Once raised, take the pin out from the base of the UPS. Repeat this sequence for the other remaining feet. The exact sequence is depicted in the figure to the side:



- 2 - With all the feet removed, now proceed to rotate the display mask. Slip the keys provided into the release slots on the sides of the display mask and exert a slight pressure, just enough to release the mask from the UPS, as demonstrated in the drawing on the side.




- 3 - **WARNING:** The display mask is connected to the UPS by a special cable. This means that you must extract the mask taking extreme care and avoiding violent jerks or other brusque movements, so as to avoid possibly damaging the display and/or the UPS. DO NOT TRY IN ANY WAY TO SEPARATE THE DISPLAY MASK FROM THE UPS.

- 4 - Rotate the mask by 90° in the anti-clockwise direction and fasten it to the UPS again, inserting it gently into the housing until a slight clicking noise is heard and the mask remains in position.


- 5 - Rotate the UPS by 90° clockwise taking the utmost care.

- 6 - At this point, with the UPS in the horizontal position, attach the handles to the side of the UPS with the appropriate screws as depicted in the figure to the side. (handles and screws are include in the *handles kit* option)



NOTE: The UPS is compatible with assembly in standard rack cabinets of 600mm x 800mm or greater (in depth). In rack type installation, given the weight of the UPS, use of the support brackets is compulsory (guide with L-shape support). For the same reason, it is recommended that you install the UPS in the bottom part of the rack cabinet.


CONNECTIONS AND SWITCHING ON FOR THE FIRST TIME

- 1) Install upstream of the apparatus a 16A magneto-thermal switch with intervention curve B or C.
- 2) Connect the power cord supplied with the UPS to the IEC 16A inlet socket.
- 3) Connect the power cord from the UPS to the mains.
- 4) Press the main switch on the front panel.
- 5) After a short time, the UPS comes on, the display lights, a beep sounds and the  icon blinks. The UPS is in stand-by mode: this means that the UPS is in a minimum consumption condition. The microcontroller is powered and performs its supervision and self-test task; the batteries are charging; everything is ready for activation of the UPS. There is also a stand-by operating mode when in battery-powered operation, provided the timer has been activated.
- 6) Connect the item(s) of equipment to be powered to the outlets on the rear of the UPS using the cable supplied or another cable of max. length 10 metres.
WARNING: do not connect equipment that absorbs more than 10A to the IEC 10A outlets. For equipment items exceeding this level of absorption, use only the IEC 16A socket.
- 7) Check the machine settings on the display (see the section: *Configuration area*)

SWITCHING ON FROM THE MAINS

- 1) Press the “ON” button. After it has been pressed, all the icons on the del display light for 1 second and the UPS sounds a beep.
- 2) Switch on the equipment item(s) connected to the UPS.


Only when switching on for the first time: after about 30 sec. have elapsed, check that the UPS is working properly:

1. Simulate a black-out by opening the switch placed upstream of the UPS.
2. The load must continue to be powered, the  icon on the display must light, and a beep must be heard every 4 seconds.
3. When the upstream switch is closed again, the UPS should return to mains-powered operation.

SWITCHING ON FROM THE BATTERY

- 1) Press the main switch on the front panel.
- 2) Hold the “ON” button down for at least 5 seconds. All the icons on the display light for 1 second and the UPS sounds a beep.
- 3) Switch on the equipment item(s) connected to the UPS.

SWITCHING THE UPS OFF

To switch the UPS off, hold down the “STBY” button for at least 1.5 seconds. The UPS returns to stand-by mode and the  icon starts blinking:










- a. If the mains line is up, to switch the UPS off completely, press the main switch, bringing this switch back into its original position (raised position).
- b. If the UPS is on battery-powered operation and the timer has not been set, it switches off completely and automatically after 5 seconds. If on the other hand, the timer is set, to switch the UPS off, hold the “STBY” button down for at least 5 seconds. If you want the UPS to remain switched off completely when the mains power returns, then press the main switch (see step a.).

DISPLAY PANEL INDICATIONS

This chapter will describe in depth all the items of information that may be posted on the LCD. For easier understanding, we can divide the information displayed into three main groups:

- UPS status indicators
- Measurements display area
- Configuration area

UPS status indicators

ICON	STATUS	DESCRIPTION
	Fixed	Indicates presence if a problem
	Blinking	The UPS is in stand-by mode
	Fixed	Indicates UPS operating normally
	Fixed	The UPS is working on mains power
	Blinking	The UPS working on mains power, but the output voltage is not synchronized with the mains voltage
	Fixed	The UPS is working on battery power. When in this condition, the UPS emits a beep at 4-second regular intervals.
	Blinking	End of discharge early warning. Indicates that the battery's back-up is running out. In this condition, the UPS emits a beep at 1-second regular intervals.
	Fixed	Indicates that the loads connected to the UPS are being powered by the bypass
	Dynamic	Indicates the estimated percentage back-up
	Dynamic	Indicates the % load applied to the UPS with respect to the nominal value
	Blinking	Maintenance action is needed
	Fixed	Indicates that the timer is activated (programmed switch-on or switch-off). The timer can be activated/de-activated through the software supplied
	Blinking	1 minute to go before the UPS is switched on again or 3 minutes until it is switched off

Measurements display area

The most important measurements relating to the UPS may be displayed on the display screen. When the UPS is switched on, the display shows the mains voltage value. To move on to display something else, press the “SEL / SET” button repeatedly until the desired measurement value appears. If a failure/alarm occurs (FAULT) or the machine stops (LOCK), the display will automatically display the type of problem and the corresponding alarm code.

A number of examples are shown below:

SAMPLE GRAPHIC ⁽¹⁾	DESCRIPTION
	Mains voltage
	Mains frequency
	UPS output voltage
	Output voltage frequency
	Remaining battery backup
	Battery charge percentage

	Current absorbed by the load
	Temperature of the cooling system of the UPS internal electronics
	Fault / Alarm ⁽²⁾ : the corresponding code is displayed
	Lock ⁽²⁾ : the corresponding code is displayed

SAMPLE GRAPHIC ⁽¹⁾	DESCRIPTION
	Total battery voltage
	Percentage load applied

- ⁽¹⁾ The values given in the pictures of the table are purely indicative.
- ⁽²⁾ The FAULT / LOCK codes will only be displayed if they are active at that time (in presence of a failure/alarm or machine stoppage).


www.upsdirect.com

Configuration area

The configuration area contains the main operating parameters of the UPS and displays its current status. The parameters found in this area can be modified by taking action directly from the display panel.

SETTABLE PARAMETERS:

- Frequency:** output voltage frequency
- Voltage:** Output voltage
- Mode:** UPS operating mode



The picture to the side depicts the area of the display reserved for settings (configuration area), with the three settable parameters in view.

How to proceed:

- To enter the configuration area hold down the “SEL / SET” button for at least 2 sec.
- The word “SET” lights and an arrow (▶) appears to the left of *Frequency*.
- The arrow indicates the setting selected. To change the selection of the parameter to be modified, press the “SEL / SET” button.
- To change the item selected, press the “ON” button.
- To exit from the configuration area, hold the “SEL / SET” button down for at least 2 sec.

POSSIBLE SETTINGS

Frequency: **50 Hz** **60 Hz** **Off** (frequency self-teach)

Voltage: **220 V** **230 V** **240 V**

Mode: **ON LINE** **ECO** **SMART** **STBYOFF**

NOTE: For the change in configuration of output frequency to become effective, the UPS must be switched off completely and switched on again (by the main switch).



THE PARAMETERS *VOLTAGE* AND *OUTPUT FREQUENCY* MUST BE COMPATIBLE WITH THOSE OF THE LOAD POWERED BY THE UPS



MODES OF OPERATION

The mode that gives the load maximum protection is ON LINE mode (default), where the energy intended for the load undergoes a double conversion and is reconstructed on the output in a perfectly sinusoidal way with frequency and voltage fixed by the precision digital control provided by a microprocessor fully independently of the input (V.F.I.). *

Besides the traditional ON LINE double conversion operating mode, it is also possible to set the following modes:

- ECO (LINE INTERACTIVE)
- SMART ACTIVE (shown on the display as “SMART”)
- STAND-BY OFF (shown on the display as “STBYOFF”)

For optimized efficiency, in ECO mode, the load is powered normally from the bypass. If the mains exits from its specified tolerances, the UPS switches to the normal ON LINE double conversion operating mode. About five minutes after the mains has returned inside tolerance, the load is again switched to bypass.

Where a user is unable to decide between the most suitable operating mode (ON LINE or ECO), he can leave the choice to SMART ACTIVE mode in which, in relation to statistics regarding the quality of the mains power supply, the UPS autonomously decides which mode to configure itself in.

Finally in STAND-BY OFF mode, operation is as a back-up device: with mains line present, the load is powered down, whereas when a black-out occurs the load is powered by the inverter through the batteries.

* The output voltage rms value is fixed by precision, microprocessor control independently of the input voltage, whereas the output voltage frequency is synchronised (inside a tolerance that is user-settable) with that of the input to allow use of the bypass. Outside this tolerance range, the UPS desynchronises, adopting the nominal frequency and the bypass cannot be used any more (free running mode).

UPS CONFIGURATION

The following table illustrates all the possible configurations that users have at their disposal to best adapt the UPS to their needs.

LEGEND:










=





Indicates that the configuration can be modified, both via the configuration software supplied and also by means of action on the display panel.









=

Indicates that the configuration can be modified only through the configuration software supplied.

FUNCTION	DESCRIPTION	PREDEFINED	POSSIBLE CONFIGURATIONS	MODE
Output frequency	Selects the nominal output frequency	Auto	<ul style="list-style-type: none"> • 50 Hz • 60 Hz • Auto: automatic self-teaching of the input frequency 	
Output voltage	Selects the nominal output voltage	230V	<ul style="list-style-type: none"> • 220V • 230V • 240V • 220 ÷ 240 in steps of 1V (only through the software) 	
Operating mode	Selects one of the 4 different modes of operation	ON LINE	<ul style="list-style-type: none"> • ON LINE • ECO • SMART ACTIVE • STAND-BY OFF 	
Switch-on delay	Delay time for automatic switching on again after the mains returns	5 sec.	<ul style="list-style-type: none"> • Disabled • 1 ÷ 255 in steps of 1 sec. 	
Switch-off due to minimum load	Automatic UPS switch-off when in battery-powered operation, if the load is less than 5%	Disabled	<ul style="list-style-type: none"> • Enabled • Disabled 	
Back-up limitation	Maximum battery operation time	Disabled	<ul style="list-style-type: none"> • Disabled (full battery discharge) • 1 ÷ 65000 in steps of 1 sec. 	
End of discharge early warning	Estimated remaining back-up time for the end of discharge early warning	3 min.	1 ÷ 255 in steps of 1 min.	

FUNCTION	DESCRIPTION	PREDEFINED	POSSIBLE CONFIGURATIONS	MODE
Battery test	Time interval for the automatic battery test	40 hours	<ul style="list-style-type: none"> • Disabled • 1 ÷ 1000 in steps of 1 hour 	
Alarm threshold for maximum load	Selects the overload user limit	Disabled	<ul style="list-style-type: none"> • Disabled • 0 ÷ 103 in steps of 1% 	
Display brightness	Selects the level of brightness of the LCD	Maximum	Minimum ÷ Maximum in 20 steps	
Sound alarm	Selects the mode of operation of the sound alarm	Reduced	<ul style="list-style-type: none"> • Normal • Reduced: does not sound for momentary intervention of the bypass 	

ADVANCED FUNCTIONS



Input frequency tolerance	Selects the permitted range for the input frequency for switchover to bypass and for output synchronization	± 5%	<ul style="list-style-type: none"> • ± 0.25% • ± 0.5% • ± 0.75% • ± 1 ÷ ±10 in steps of 1% 	
Bypass voltage thresholds	Selects the permitted voltage range for switchover to bypass	Low: 180V High: 264V	Low : 180 ÷ 200 in steps of 1V High: 250 ÷ 264 in steps of 1V	
Bypass voltage thresholds for ECO	Selects the permitted voltage range for ECO mode operation	Low: 200V High: 253V	Low: 180 ÷ 220 in steps of 1V High: 240 ÷ 264 in steps of 1V	
Sensitivity of intervention for ECO mode	Selects the sensitivity of intervention during operation in ECO mode	Normal	<ul style="list-style-type: none"> • Low • Normal • High 	
Load power supply in stand-by	Power supply of the load on bypass with UPS switched of (stand-by status)	Disabled (load NOT powered)	<ul style="list-style-type: none"> • Disabled (not powered) • Enabled (powered) 	
Bypass operation	Selects the mode for use of the bypass line	Normal	<ul style="list-style-type: none"> • Normal • Disabled with input/output synchronization • Disabled without input/output synchronization 	

COMMUNICATION PORTS

The following communication ports are found on the rear of the UPS (see *UPS Views*):

- RS232 connector
- USB connector
- Expansion slots for additional COMMUNICATION SLOT interface cards

RS232 and USB connectors



* Optoisolated contact max. +30Vdc / 10mA


Communication Slot

The UPS is provided with an expansion slot for optional communication cards (see the figure to the side) that enable the machine to carry out dialog using the main communication standards.


Some examples:

- Second RS232 port
- Serial port duplexer
- Ethernet network agent with TCP/IP, HTTP and SNMP protocol
- RS232 + RS485 port with JBUS / MODBUS protocol

For more information on the accessories available, consult the manufacturer's web site.



SOFTWARE



Monitoring and control software

The **PowerShield³** software provides effective and intuitive management of the UPS, displaying all the most important information, such as input voltage, load applied, and battery capacity.

It is also able to automatically effect operations such as shutdown, transmission of e-mails, SMS and network messages when particular events that can be selected by the user occur.

Installation procedure:

- Connect the UPS's RS232 communication port to a COM communication port on the PC by means of the serial cable provided* or connect the USB port on the UPS to a USB port on the PC using a USB standard cable*.
- Download the software from www.riello-ups.com, selecting the desired operating system.
- Follow the installation program instructions.
- For more detailed information about installation and use, refer to the software manual which can be downloaded from our website www.riello-ups.com.

Configuration software

Using special software, it is possible to configure the most important UPS parameters.

For a list of possible configurations, refer to the *UPS configuration* paragraph.

* You are advised to use a cable of max. length 3 metres.

REPLACEMENT OF THE BATTERY PACK

As indicated in the presentation, the UPS is provided with a dedicated battery pack that permits easy replacement of the batteries (*hot swap*), entirely safely for the operator, thanks to the protected connection system.


WARNING: *for your own safety and that of your product, it is important that you follow the instructions given below exactly.*



**WHEN THE BATTERY PACK IS DISCONNECTED, THE LOADS CONNECTED TO THE UPS ARE NOT PROTECTED AGAINST A MAINS FAILURE.
THE BATTERY PACK IS VERY HEAVY. TAKE ALL DUE CARE WHEN PERFORMING SUBSTITUTION.**




- 1 - The battery pack is located behind the front panel of the UPS. Take the panel centrally by the sides and pull gently outwards as shown in the figure to the side. In doing so, do not force the panel fastening pins too much.




- 2 - Put the manual bypass switch located under the front panel to position "II" (see figure to the side).

WARNING: in this condition, the load is powered by the bypass and the display must show the message **FAULT: C02**.


WARNING: *For proper operation of the UPS, it is recommended that you replace the battery pack only with the UPS switched on.*



- 3 - The battery pack is connected to the rest of the UPS by means of a cable with terminal. See the figure on the side: press the 2 tabs on the sides of the terminal (A) and take it out pulling gently upwards. With your thumbs, together press the 2 fastening catches (B) and, keeping them pressed, put your index fingers into the slot located under the connector (C).



- 4 - Maintaining the position described in the previous step, take out the battery pack pulling outwards as shown in the figure to the side. Take great care when extracting the battery pack as it is very heavy. **WARNING:** the new battery pack and the one to be replaced must contain the same number and type of batteries (see the label next to the connector on the battery pack).



- 5 - Insert the new battery pack in its seat by sliding until it clicks into the UPS. Connect the cable with terminal again to its connector, put the switch back to position "I" and close the front panel. Make sure that the display returns to the normal display mode.

Very often improper operation of the UPS does not indicate a failure, but is due solely to banal problems, drawbacks or lack of attention.

You are therefore recommended to carefully consult the table below which summarizes the information needed to solve the most common problems.

PROBLEM	POSSIBLE CAUSE	SOLUTION
THE DISPLAY DOES NOT LIGHT	MAIN SWITCH NOT PRESSED	Press the main switch on the front panel.
	THE BATTERY PACK CONNECTOR IS DISCONNECTED	Connect the battery pack connector, following the instructions in the section "REPLACEMENT OF THE BATTERY PACK".
	MAINS CONNECTION CABLE MISSING	Check that the power cord is connected properly.
	MAINS VOLTAGE MISSING (BLACK-OUT)	Check that there is live voltage in the outlet the UPS is connected to (by testing, for example, with a table lamp).
	INPUT THERMAL PROTECTION TRIGGERED	Reset the protection by pressing the button on the rear of the UPS (CIRCUIT BREAKER). WARNING: Check that there is no overloading on the UPS outlet.
THE DISPLAY IS ON BUT THE LOAD IS NOT BEING POWERED	THE UPS IS IN STAND-BY MODE	Press the "ON" button on the front panel to power the loads.
	THE STAND-BY OFF MODE IS SELECTED	You must change mode. STAND-BY OFF mode (back-up) powers the loads only when there is a black-out.
	CONNECTION TO THE LOAD IS MISSING	Check the connection to the load.
THE UPS IS WORKING ON BATTERY POWER DESPITE THE FACT THAT MAINS VOLTAGE IS PRESENT	INPUT THERMAL PROTECTION TRIGGERED	Reset the protection by pressing the button on the rear of the UPS (CIRCUIT BREAKER). WARNING: Check that there is no overloading on the UPS outlet.
	INPUT VOLTAGE OUTSIDE THE PERMITTED VOLTAGE RANGE FOR MAINS-POWERED OPERATION	Problem depending on the mains. Wait for the input mains to come back into tolerance. The UPS will automatically go back into mains-powered operation.
THE UPS DOES NOT COME ON AND THE DISPLAY SHOWS ONE OF THE CODES: A06, A08	UPS TEMPERATURE LESS THAN 0°C	Check the UPS surrounding ambient temperature; if too low, bring temperature to above the minimum threshold (0°C).
THE DISPLAY SHOWS CODE: A11	INPUT RELAY STUCK	This fault does not produce any particular malfunctions. However, if the problem occurs again the next time the UPS is switched on, get in touch with the service centre.

PROBLEM	POSSIBLE CAUSE	SOLUTION
THE BUZZER SOUNDS CONTINUOUSLY AND THE DISPLAY POSTS ONE OF THE CODES: A54, F50, F51, F52, F55, L50, L51, L52	THE LOAD APPLIED TO THE UPS IS TOO HIGH	Lower the load to inside the 100% threshold (or user threshold in case of code A54).
THE DISPLAY SHOWS CODE: A61	BATTERIES NEED TO BE REPLACED	Replace the battery pack with a new one (as indicated in the chapter <i>BATTERY PACK</i>).
THE DISPLAY SHOWS CODE: A62	BATTERY PACK MISSING OR NOT CONNECTED	Check that the battery pack is inserted and connected correctly (see the chapter <i>BATTERY PACK</i>).
THE DISPLAY SHOWS CODE: A63	BATTERIES ARE DISCHARGED; THE UPS IS WAITING FOR THE BATTERY VOLTAGE TO EXCEED THE SET THRESHOLD	Wait for the batteries to recharge or manually force switching-on by holding the "ON" button down for at least 2 sec.
THE BUZZER SOUNDS CONTINUOUSLY AND THE DISPLAY POSTS ONE OF THE CODES: F03, F05, F07, F10, F13, F21, F40, F41, F42, F43	A UPS MALFUNCTION IS TAKING PLACE; SHUTDOWN IMMINENT	If it is possible to power down the load, switch off the UPS and switch it on again; if the problem occurs again, contact the service centre.
THE BUZZER SOUNDS CONTINUOUSLY AND THE DISPLAY POSTS ONE OF THE CODES: F04, L04	TEMPERATURE OF THE HEAT SINKS INSIDE THE UPS IS TOO HIGH	Check that the UPS surrounding ambient temperature is not in excess of 40°C.
THE BUZZER SOUNDS CONTINUOUSLY AND THE DISPLAY POSTS ONE OF THE CODES: F53, L53	FAULT DETECTED ON ONE OR MORE LOADS POWERED BY THE UPS	Disconnect all the loads and connect them up again one by one to identify the faulty one.
THE BUZZER SOUNDS CONTINUOUSLY AND THE DISPLAY POSTS ONE OF THE CODES: F60, L03, L05, L07, L10, L13, L20, L21, L40, L41, L42, L43	A UPS MALFUNCTION HAS OCCURRED	If it is possible to power down the load, switch off the UPS and switch it on again; if the problem occurs again, contact the service centre.
THE DISPLAY SHOWS ONE OF THE CODES: C01, C02, C03	A REMOTE COMMAND IN PROGRESS	If undesired, check the position of the manual bypass switch or status of the control inputs of an optional contacts card.

ALARM CODES

By using a sophisticated self-test system, the UPS can check and report on the display panel any problems and/or failures that could occur during normal operation of the equipment. In case of a problem, the UPS signals the event by posting on the display the code and type of alarm present (FAULT and/or LOCK).

FAULT

The FAULT type reports may be divided into three categories:

- **Failures:** these are “minor” problems that do not result in the UPS stopping but they limit its performance or prevent certain features being used.

CODE	DESCRIPTION
A06	Temperature sensor1 less than 0°C
A08	Temperature sensor2 less than 0°C
A11	Input relay stuck (does not open)
A54	ON LINE: load > of the user threshold - ECO: load > 16A *
A61	Batteries need replacement
A62	Battery pack missing or not connected
A63	Waiting for batteries to recharge

- **Alarms:** these problems are more critical than the failures because – if they continue – they could cause the UPS to stop, even in a very short time frame.

CODE	DESCRIPTION
F03	Auxiliary power supply incorrect
F04	High temperature on heat sinks
F05	Temperature Sensor1 broken
F07	Temperature Sensor2 broken
F10	Input fuse broken or input relay stuck (does not close)
F13	Capacitor precharging failure
F21	Capacitor bank overvoltage
F40	Inverter overvoltage
F41	D-C voltage on output
F42	Inverter voltage not right
F43	Inverter undervoltage
F50	Overload: load > 103%
F51	Overload: load > 110%
F52	Overload: load > 150%
F53	Short-circuit
F55	Waiting for load reduction before return to inverter
F60	Battery overvoltage

➤ **Commands in progress:** Indicates presence of a remote command in progress.

CODE	DESCRIPTION
C01	Remote shutdown command
C02	Remote load on bypass command
C03	Remote switch-on command
C04	Battery test in progress

LOCK

The LOCK (block) type report signals are usually preceded by an alarm signal and, on account of their importance, result in the inverter being switched off and the load being powered through the bypass line (the procedure is excluded in case of lockouts due to strong and persistent overloads and lockouts following a short-circuit).

CODE	DESCRIPTION
L03	Auxiliary power supply incorrect
L04	High temperature on heat sinks
L05	Temperature Sensor1 broken
L07	Temperature Sensor2 broken
L10	Input fuse broken or input relay stuck (does not close)
L13	Capacitor precharging failure
L20	Capacitor bank undervoltage
L21	Capacitor bank overvoltage
L40	Inverter overvoltage
L41	D-C voltage on output
L42	Inverter voltage not right
L43	Inverter undervoltage
L50	Overload: load > 103%
L51	Overload: load > 110%
L52	Overload: load > 150%
L53	Short-circuit

* In ECO mode, the load is normally powered by the bypass. Therefore, in the presence of a load of constant power, the current absorbed depends on the mains voltage, which may accordingly be in excess of the value allowed by the input plug and the protection upstream.

When this situation arises, the UPS reports a failure which automatically disappears if the input voltage increases and/or the output load is reduced.

TECHNICAL DATA TABLE

MODELS	SDL 3300	SDL 4000
--------	----------	----------

INPUT

Nominal voltage	[Vac]	220 / 230 / 240	
Accepted range	[Vac]	0 ÷ 276	
Voltage range ruling out battery intervention	[Vac]	Maximum: 276	
	[Vac]	Minimum: 164 ÷ 84 (from 100% to 50% of load in linear mode)	
	[Vac]	Return to mains-powered operation: 180	
Nominal frequency	[Hz]	50 - 60 ±5	
Maximum current ⁽¹⁾	[A]	15	16
Nominal current ⁽²⁾	[A]	11	12
Power factor		≥ 0.98	
Current distortion @ maximum load		≤ 7%	

BYPASS

Accepted voltage range for switching	[Vac]	180 ÷ 264	
Accepted frequency range for switching		Frequency selected ±5 %	
Switching time	[msec]	Typical: 2 - Maximum: 4	

BATTERY

Back-up time	[min / W]	6' / 2300	5'30 / 2400
No. batteries / V / Ah		9 / 12 / 7 high rate discharge	
Recharge time	[h]	4 ÷ 8	

OUTPUT

Nominal voltage ⁽⁷⁾	[Vac]	220 / 230 / 240 ±1.5%	
Static variation ⁽³⁾		1.5%	
Dynamic variation ⁽⁴⁾		≤ 5% in 20 msec	
Waveform		Sinusoidal	
Voltage distortion @ linear load		≤ 3%	
Voltage distortion @ distorting load		≤ 6%	
Frequency ⁽⁵⁾		50 or 60 Hz selectable	
Current crest factor		≥ 3 : 1	
Nominal power	[VA]	3300	4000
Nominal power	[W]	2300	2400


MISCELLANEOUS

Leakage current to earth	[mA]	≤ 1	
AC/AC efficiency		92%	
Ambient temperature ⁽⁶⁾	[°C]	0 - 40	
Humidity		< 90% non-condensing	
Protections		Excessive battery discharge – Overcurrent – short-circuit – Overvoltage – undervoltage - thermal	
Hold-up time	[msec]	≥ 40	
Noise level		< 40 dB(A) at 1 mt.	
Dimensions H x L x D	[mm]	455 x 175 x 520	
Weight	[Kg]	38	38

OVERLOAD TIMES	OPERATION POWERED BY	
	BYPASS	INVERTER
100% < Load ≤ 110%	Activates bypass after 2 sec Stoppage after 120 sec	Stoppage after 60 sec
110% < Load ≤ 150%	Activates bypass after 2 sec Stoppage after 4 sec	Stoppage after 4 sec
Load > 150%	Activates bypass instantaneously Stoppage after 1 sec	Stoppage after 0.5 sec

- (1) @ nominal load, minimum voltage of 164 Vac, battery charging
- (2) @ nominal load, nominal voltage of 230 Vac, battery charging
- (3) Mains/Battery @ load 0% -100%
- (4) @ Mains/battery/mains @ resistive load 0% / 100% / 0%
- (5) If the mains frequency is within ± 5% of the value selected, the UPS is synchronized with the mains. If the frequency is outside the tolerances or operation is battery-powered, the frequency is the selected frequency ±0.1%
- (6) 20 - 25 °C for longer battery life
- (7) To maintain the output voltage inside the precision range indicated, a recalibration may be necessary after a long period in operation

Ferrite installation addendum



When using a RS232 or USB communication cable to reduce EMI interference fit the ferrite supplied with the UPS as follow:

- 1) Open the clip;
- 2) Place the ferrite as close as possible to the connector on the UPS side;
- 3) Place the communication cable inside ferrite groove with a turn (see figure);
- 4) Close the clip with communication cable inside (the cable must be remain in the ferrite hole).