

**SCADAPack ES Quick Start
Guide**



Documentation

Table of Contents

Part I SCADAPack ES Quick Start Guide	3
1 Technical Support.....	3
2 Safety Information.....	4
3 Preface.....	6
4 Layout of Manual.....	8
5 Hardware & Software Requirements.....	9
6 Installing SCADAPack E Configurator.....	10
7 Initial Power Up of the SCADAPack ES RTU.....	11
8 Establishing a PC to RTU Communication Link.....	13
8.1 RS-232 Serial Communication	14
8.1.1 Configuring an RS-232 Serial Communication Link.....	15
8.1.2 Testing the RS-232 Serial Communication Link.....	16
8.2 Ethernet Communication	19
8.2.1 Configuring an Ethernet Communication Link.....	20
8.2.2 The IP Routing Table.....	20
8.2.3 Testing the Ethernet Connection.....	24
9 Command Line Diagnostics.....	26
10 Reading and Writing RTU DNP Data	31
10.1 Reading RTU DNP Data	32
10.2 Writing RTU DNP Data	34
11 Accessing Physical I/O Data via Modbus.....	36
11.1 Configuring a Modbus Serial Interface	37
11.1.1 Reading/Writing to Modbus Registers.....	40
12 Related Documentation.....	41
12.1 SCADAPack ES External Data	43

I SCADAPack ES Quick Start Guide



Documentation

©2013 Control Microsystems Inc.
All rights reserved.
Printed in Canada.

Version: 8.05.4

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed. Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

1 Technical Support

Support related to any part of this documentation can be directed to one of the following support centers.

Technical Support: The Americas

Available Monday to Friday 8:00am – 6:30pm Eastern Time

Toll free within North America 1-888-226-6876

Direct Worldwide +1-613-591-1943

Email TechnicalSupport@controlmicrosystems.com

Technical Support: Europe

Available Monday to Friday 8:30am – 5:30pm Central European Time

Direct Worldwide +31 (71) 597-1655

Email euro-support@controlmicrosystems.com

Technical Support: Asia

Available Monday to Friday 8:00am – 6:30pm Eastern Time (North America)

Direct Worldwide +1-613-591-1943

Email TechnicalSupport@controlmicrosystems.com


Technical Support: Australia


Inside Australia 1300 369 233

Email au.help@schneider-electric.com

2 Safety Information

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.

	The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.
---	--

	This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.
---	--

⚠ DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, **will result in** death or serious injury.

⚠ WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, **can result in** death or serious injury.

⚠ CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, **can result in** minor or moderate injury.

CAUTION

CAUTION used without the safety alert symbol, indicates a potentially hazardous situation which, if not avoided, **can result in** equipment damage..

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and the installation, and has received safety training to recognize and avoid the hazards involved.

BEFORE YOU BEGIN

Do not use this product on machinery lacking effective point-of-operation guarding. Lack of effective point-of-operation guarding on a machine can result in serious injury to the operator of that machine.

⚠ CAUTION**EQUIPMENT OPERATION HAZARD**

- Verify that all installation and set up procedures have been completed.
- Before operational tests are performed, remove all blocks or other temporary holding means used for shipment from all component devices.

- Remove tools, meters, and debris from equipment.

Failure to follow these instructions can result in injury or equipment damage.

Follow all start-up tests recommended in the equipment documentation. Store all equipment documentation for future references.

Software testing must be done in both simulated and real environments.

Verify that the completed system is free from all short circuits and grounds, except those grounds installed according to local regulations (according to the National Electrical Code in the U.S.A, for instance). If high-potential voltage testing is necessary, follow recommendations in equipment documentation to prevent accidental equipment damage.

Before energizing equipment:

- Remove tools, meters, and debris from equipment.
- Close the equipment enclosure door.
- Remove ground from incoming power lines.
- Perform all start-up tests recommended by the manufacturer.

OPERATION AND ADJUSTMENTS

The following precautions are from the NEMA Standards Publication ICS 7.1-1995 (English version prevails):

- Regardless of the care exercised in the design and manufacture of equipment or in the selection and ratings of components, there are hazards that can be encountered if such equipment is improperly operated.
- It is sometimes possible to misadjust the equipment and thus produce unsatisfactory or unsafe operation. Always use the manufacturer's instructions as a guide for functional adjustments. Personnel who have access to these adjustments should be familiar with the equipment manufacturer's instructions and the machinery used with the electrical equipment.
- Only those operational adjustments actually required by the operator should be accessible to the operator. Access to other controls should be restricted to prevent unauthorized changes in operating characteristics.

3 Preface

Scope

This document is intended as a quick start guide to help new users setup and configure a SCADAPack ES RTU in a timely fashion. Note that the simple tasks presented in this guide therefore do not include all important information necessary for the control of real life applications.

Assumed Knowledge

Familiarity with a personal computer running the Windows Operating System is recommended.

Target Audience

- Systems Engineers
- Commissioning Engineers
- Maintenance Technicians

If any problems arise during the exercise, please consult with the appropriate manual or call the Schneider Electric Technical Support Department for assistance.

If you have any comments or suggestions on how this manual could be further improved please contact Technical Support Department for assistance.

Related Documentation

The list of documents provide in detail all necessary information required to install, operate and program the SCADAPack ES RTU.

- SCADAPack ES Hardware Manual.
- SCADAPack E Configurator User Manual.
- SCADAPack E ISaGRAF User Manual.

4 Layout of Manual

The purpose of this document is to guide a new user through setup and configuration of a SCADAPack ES controller in a timely fashion.

The tasks to be performed are as follows:

- Installation of the SCADAPack E Configurator software. The SCADAPack E Configurator is used for configuring the SCADAPack ES RTU.
- Initial power up of the RTU.
- Establishing serial and Ethernet communication to RTU.
- Executing simple command line functions.
- Reading and Writing RTU data.

The rest of the manual is arranged as follows:

Section [Hardware and Software Requirements](#)^[9] lists the hardware and software required to perform this exercise.

Section [Installing the SCADAPack E Configurator](#)^[10] covers the installation of the SCADAPack E Configurator software.

Initial power up of the SCADAPack ES RTU is covered in Section [Initial Power Up of the SCADAPack ES RTU](#)^[11].

Two methods of establishing communication to the RTU are covered in Section [Establishing a PC to RTU Communication Link](#)^[13].

In Section [Command Line Diagnostics](#)^[26] the user is guided through connecting to an RTU serial port configured for command line functionality and executing three simple command line functions.

Reading and writing to RTU DNP physical I/O and derived points is covered in Section [Reading and Writing RTU Data](#)^[31].

Reading and writing to Modbus registers is covered in Section [Accessing Physical I/O Data via Modbus](#)^[36].

Related and Relevant documentation necessary to explore the features of the SCADAPack ES is provided in Section [Related Documentation](#)^[41].

5 Hardware & Software Requirements

Hardware Requirements

The following hardware items are required to complete this exercise:

- 1x SCADAPack ES Controller Unit
- A 9-30V DC power supply with a minimum power rating of 8.8W
- A digital multi-meter
- RJ-11 to DB-9 crossed cable (Schneider Electric part # 297324)
- PC or laptop with the following minimum requirements:
 - Intel (or equivalent) Pentium III CPU, 1.0 GHz
 - 256MB RAM (512MB recommended)
 - 100MB free disk space
 - Microsoft 2000 / XP / Vista 32-bit or 64-bit Operating System
 - 1024x768 VGA recommended
 - Mouse (or other pointing device)
 - CD-ROM drive
- A DB-9 RS-232 serial port
- Ethernet network port (optional)
- For Ethernet Connection (optional),
 - A switch, hub or access to a wall jack on a LAN.
 - A Category 5 (UTP) LAN cable with standard RJ-45 modular terminal connectors

A USB to RS-232 adapter may be used if PC or laptop is only equipped with a USB port.

Software Requirements

- SCADAPack E Configurator Software Package.
- HyperTerminal (or other terminal emulator)

6 Installing SCADAPack E Configurator

SCADAPack E Configurator is a Windows® based software configuration tool for use with the SCADAPack E RTUs.

To install SCADAPack E Configurator software:

1. Insert the SCADAPack E Utilities Installation DVD into the DVD/CD-ROM drive of the PC or laptop.
2. If the installation wizard launches automatically, skip to step 5.
3. Using Windows Explorer, locate setup.exe on the root directory of the DVD/CD ROM.
4. Double click on the icon to launch the installation wizard.
5. Follow through the steps in the setup wizard and install the application in the default directory 'C:\Program Files\Schneider Electric\SCADAPack E'.

SCADAPack E Configurator can be installed into another directory. However, it is recommended you install the software in the default directory for ease of troubleshooting, if necessary, in the future.

- Click on **Start | All Programs | Schneider Electric SCADAPack E | Configurator** to confirm a successful install.

The SCADAPack E Configurator main window opens displaying the default page selection tabs as shown below.




Figure 6.1: SCADAPack E Configurator Main Page

The pages in the SCADAPack E Configurator are accessed by clicking on the appropriate tab at the top of the page display area displayed in the red rectangle in the above figure.

7 Initial Power Up of the SCADAPack ES RTU

The SCADAPack ES is powered through a 3 part (SL3) terminal connector located directly beneath the enclosure label **DC I/P ±** as illustrated in the [Figure 7.1](#).

A 9-30 Vdc power supply capable of producing 8.8W is required to complete this exercise.




Figure 7.1: Top Panel View of the SCADAPack ES

If possible, wiring connections should be made with the DC source unplugged from the mains power supply. Only apply power when requested

1. Remove the lid from the SCADAPack ES
2. Identify the two rotary HEX switches adjacent to Port 0.
3. Check that the switches are set to 00.
4. Identify the DC input connector from the enclosure label **I/P ±**.
5. Connect the output leads from your power supply to **I/P ±** respecting voltage polarity.
6. Locate the **Run** LED (located below Port 3).

7. Apply power (connect DC Power source to mains) to the RTU and wait for approximately 15 seconds. while observing the status of the Run LED.
8. The controller is in normal operation mode when the Run LED steadily emits approximately 1 blink every 3 seconds.

8 Establishing a PC to RTU Communication Link

Communication with a SCADAPack ES RTU can be accomplished through its serial or Ethernet interfaces.

In this section, an RS-232 serial communication link will be established to the RTU. Optionally, an Ethernet communication link will be established to the RTU in Section [Ethernet Communication](#)^[19]. Configuration of the physical communication interfaces are performed using the SCADAPack E Configurator.

- [RS-232 Serial Communication](#)^[14]
 - [Configuring an RS-232 Serial Communication Link](#)^[15]
 - [Testing the RS-232 Serial Communication Link](#)^[16]
 - [Ethernet Communication](#)^[19]
 - [Testing the Ethernet Connection](#)^[24]

8.1 RS-232 Serial Communication

In this section of the guide, an RS-232 serial communication link will be established between the PC and the SCADAPack ES RTU.

Access to CMI part # 297324 will facilitate this setup. If this cable is not available, please refer to [Figure 8.1](#)⁽¹⁴⁾ on how to create a simple 3-wire crossed cable for connecting a SCADAPack ES RTU to a PC.





Figure 8.1: 3 wire connection between SCADAPack ES and RS-232 DTE

8.1.1 Configuring an RS-232 Serial Communication Link

1. Click on **Start | Programs | Schneider Electric SCADAPack E | Configurator** to launch the software.
2. The SCADAPack E Configurator main window opens displaying the default property pages.
3. Locate and click on the *Ports* folder in the Navigator.

The factory default configuration of RTU Port 1 as indicated below.



1. Select **Communication | Communication Type** from the SCADAPack E Configurator menu bar.
2. From the *Communication Type* dialog, perform the following:
 - a. Select the RS-232 Serial (COM Port) option.
 - b. Click **OK**.
3. From the Communication Settings dialog:
 - a. From the General tab, set the fields as follows:
 - Com Port = The COM Port on the PC attached to Port 1 of the SCADAPack ES
 - Baud Rate = 9600
 - Parity = None
 - Stop Bits = 1

- Ignore CTS = True
- b. Click **OK** to save changes and close the dialog.

Returning to the *Ports* page, the communication link details are now displayed in the *PC Comm Port* field in the Target RTU Connection Information at the bottom right of the SCADAPack E Configurator window.

8.1.2 Testing the RS-232 Serial Communication Link

The RS-232 serial communication link will be tested by downloading the factory default configuration from RTU battery-backed RAM onto the PC hard drive.

1. Connect Port 1 on the RTU to a RS-232 serial port on the PC using cable # 297234 or a 3-wire crossed cable.

With the default factory settings, serial RS-232 communication is not possible on Port 0, Port 3 and Port 4.

2. From the SCADAPack E Configurator Menu bar, select **File | Read RTU Configuration...**

A dialog box appears titled *Read Configuration From RTU* as shown in [Figure 8.5](#)¹⁶ below.

3. Confirm that fields in this dialog are populated as follows:

- *File name* = 'config.rtu'
- DNP address = 0




Figure 8.5: Read Configuration File Dialog

4. Click on **Save**.
5. If prompted, select **Yes** to replacing the existing 'config.rtu' file.

A dialog titled *SCADAPack E Configurator File Read* will appear within a few seconds, displaying the progress of the file download. A successful download status will subsequently be presented in a dialog as shown below.



Figure 8.6: Communication Success Message Dialog

6. Click **OK** to acknowledge the successful transaction.

The factory default configuration has successfully been downloaded from RTU memory to the PC hard drive confirming an operational RS-232 serial communication link.

In the event that the above dialog does not appear within a few seconds or displays a indicates a timeout message (after about 3 minutes) as indicated in [Figure 8.7](#) below.



Figure 8.7: Communication Failure Message Dialog

The communication channel has not been successfully established. If the previous steps in section [Configuring an RS-232 Serial Communication Link](#) have been thoroughly executed, it may be necessary to reset the RTU to its factory default settings by following these steps:

- 1 Identify the two HEX switches on the side of the RTU.
- 2 Set the switches to 'FC'. The HEX switch closest to serial Port 0 is set to 'F' and that closest to the DC O/P connector is set to 'C'.
- 3 Cycle power to the RTU and wait for approximately 15 seconds for the Run LED to indicate normal operation..
- 4 Return the HEX switches to 00 and try connecting again via the serial Port 1 using the steps in [Configuring an RS-232 Serial Communication Link](#). Return the HEX switches to 00 and wait for approximately 15 seconds for the Run LED to indicate normal operation
- 5 Once the Run LED indicates normal operation, RTU has been initialized to factory default settings.
- 6 Try connecting again via the serial Port 1 using the steps in [Configuring an RS-232 Serial Communication Link](#).

8.2 Ethernet Communication

In this section, SCADAPack E Configurator will be used to configure one of the 10/100 Base-T Ethernet interfaces available on the SCADAPack ES RTU.

This port is identified as E1 on the RTU enclosure.

Changes are made to the configuration file 'config.rtu' uploaded earlier, saved and written to RTU memory via the RS-232 serial communication link.

Before proceeding, please obtain a valid IP address and subnet mask from your Network Administrator.

- [Configuring an Ethernet Communication Link](#)^[20]
- [The IP Routing Table](#)^[20]

8.2.1 Configuring an Ethernet Communication Link

1. Using a CAT5 UTP cable, establish a physical connection between the RTU and the PC via a switch, hub or by connecting the RTU to a wall outlet from your LAN.
2. Confirm that the PC is also connected to a LAN.
3. Launch SCADAPack E Configurator and select the *TCP/IP* page from the navigator.
4. Enter the IP address and subnet mask obtained from your Network Administrator into the Ethernet 1 IP Address and Subnet Mask fields as shown in the sample screen shot below.




Figure 8.8: RTU Ethernet Interface Settings

8.2.2 The IP Routing Table

If the SCADAPack ES is communicating with a peer or host devices residing on a different IP subnet than the RTU, the IP Routing table needs to be configured.

If not, skip to step 5.

For example, consider the following configuration:

- RTU Ethernet port 1 (E1) is configured with IP address 10.10.10.120 and subnet mask 255.255.255.0.
- Ethernet port on a peer device/PC is configured with IP address 10.10.10.125 and subnet mask 255.255.255.0.

In this case, both devices are on the same IP subnet and therefore, the IP Routing table does not need

to be configured.

On the other hand, consider the peer device/PC with IP address 172.16.22.10 and subnet mask 255.255.0.0. In this case, the RTU and peer device/PC are on different subnets. The IP Routing table of the RTU needs to be configured to allow communication between the RTU and the peer device/PC. In this case an IP address on the RTU's sub-network will be a gateway to the PC device's sub-network, This is the address that needs to be configured.

Performing the following steps is necessary only if the PC and SCADAPack ES RTU are communicating from different subnets.

1. Ask your network administrator for the IP Address of the *gateway* and the subnet the SCADAPack ES is located on.
2. Select the *Advanced TCP/IP* page from the SCADAPack E Configurator TCP/IP navigator folder.
3. Fill out row 1 of the IP Route Table with the following information:
 - **Dest. IP Addr:** 0.0.0.0
 - **Subnet Mask:** 0.0.0.0
 - **Dest. Port:** Ethernet 1
 - **Gateway IP:** Provided by your network administrator - gateway IP address on the RTU's sub-network
 - **Metric:** 0
4. Click on **File | Save** from the menu bar to save the changes.

The sample screen shot below shows the IP Route Table filled with the IP Configuration settings of a PC communicating with a SCADAPack ES RTU. The RTU is setup to communicate to the remote PC through Ethernet port 1.




Figure 8.9: Static IP Routing Table Filled with Host PC 'ipconfig' Details

5. Select **File | Write RTU Configuration...** from the menu bar to the configuration changes to RTU memory.
6. Confirm the DNP address on the *Write RTU Configuration* dialog. If no other changes have been made, this field should record 0 as shown in the screen shot below.




Figure 8.10: Write RTU Configuration Dialog

7. Click on **OK** to initiate the download.
8. A status bar similar to Figure 611 will be displayed followed by a dialog indicating the write request.
9. Click on **OK** to close the status dialog,




Figure 8.11: Write RTU Configuration Progress Dialog

10. Upon completion of the configuration change, SCADAPack E Configurator will prompt for the RTU to be restarted to have the configuration changes take effect.

8.2.3 Testing the Ethernet Connection

The *Comm Status* LEDs located in the status bar of SCADAPack E Configurator visually describe the status of the communication request initiated by the user. The function of each LED is summarized as follows:




Figure 8.12: Request Status Indicators

These LEDs will be used in this section to monitor the status of the Ethernet communication between the RTU and the PC. Alternately, LEDs RX and TX on the RTU casing will blink during TCP/IP communication across any RTU communication interface.

To confirm operation of the Ethernet communication channel between the SCADAPack ES RTU and the PC,

1. Select **Communication | Communication Type** from the SCADAPack E Configurator menu bar.
 - a. Select **UDP/IP (Network)**
2. Select **Communication | Communication Settings** from the SCADAPack E Configurator menu bar.
 - a. Enter the Controller details (see your Network Administrator for the IP Address or name and the UDP port number).
 - b. Select the **Advanced Tab**.
 - c. Make changes to the default values as required.
 - d. Click on **OK** to close the dialog.
3. The *Configurator to RTU Connection Information* panel will be updated with the current communication method as shown below.



4. From the SCADAPack E Configurator menu bar, Select **Transfer | Get RTU Time**.
5. Confirm the time source to use.



6. Click **OK**.

Observe that the *Comms Status* LEDs on the bottom right hand corner of the screen changes from green to yellow and back to green indicating a successful read.

The time from the RTU real time clock will be displayed in a dialog similar to the one shown below indicating a successful read request using the Ethernet communication channel.

7. Select **Transfer | Write RTU Time...** from the SCADAPack E Configurator menu bar.
8. Confirm the time source to use.
9. Repeats steps 3-5 to read the RTU time and confirm it is same as the PC time.

9 Command Line Diagnostics

The **command line mode** presents a standard prompt to the user, allowing a selected range of commands that can be used to determine the current operating status and configuration details of the RTU, in addition to providing a detailed configuration interface. The exercise in this section involves connecting to a SCADAPack ES RTU serial port configured for command line functionality from an ASCII terminal and executing three useful commands: *whoami*, *ver* and *status*.

1. Connect Port 4 on the RTU to an RS-232 serial port on the PC using cable # 297234 or a 3-wire crossed cable.

Pay particular notice to the serial Port labels.

2. Launch a terminal emulator program, such as the Hyper Terminal on Windows PCs.
3. Configure the Hyper Terminal communication interface as follows:
 - Com Port = The COM Port on the PC attached to Port 1 of the SCADAPack ES
 - Port Baud Rate = 9600
 - Data Bits = 8
 - Parity = None
 - Stop Bits = 1
 - Flow Control = None

The following is a screen shot of a sample terminal emulator program running of a Windows PC.




Figure 9.1: Configuring Communication Settings in Terminal Emulator Program

- Click on **OK** on the Terminal Emulator Communication dialog.
- Press **ENTER** on your keyboard to connect to the RTU command prompt as shown below.



Figure 9.2: SCADAPack ES Command Prompt

- Type **help** to display the available list of command.



```


Terminal - (Untitled)
File Edit Settings Phone Transfers Help

C:\>help
AGAl2diag  Filter AGA12 diagnostics
ATTRIB    Display file attributes
APPEND    Append file to end of another
BOOTP     Manipulates BOOTP configuration table
BYE       Disconnect command session (ISAGRAF / Telnet)
CD        Change working directory
CHKDSK    Check a specified drive for errors
CLEAR     Clear specified RTU information
COMdiag   Filter CONITEL protocol diagnostics
COPY      Duplicate a file
DATE      Display RTU clock Date
DEL       Delete a file
DELTREE   Delete files and directories
DEVINFO   Lists drive information
DIAG      Connect to diagnostic display
DIR       Lists existing files
DSKSEL    Select current drive
DNPdiag   Filter DNP3 diagnostics
DUMP      Dump the contents of a file as HEX
EDIT      Create ASCII file from console input
FILEDIAG  Writes diagnostics to log file (rtudiag.log)
FILLFILE  Fill a file with a supplied string
FORMAT    Format the selected drive (FB HEX mode only)
GETconfig Get active RTU configuration into a file
HELP      Display this information
IFCONFIG  Set interface IP address and subnet
M103diag  Filter 60870-5-103 Driver diagnostics
MD        Make a new directory
NTPdiag   Filter NTP diagnostics
PING      Send IP network test messages
PLCdiag   Filter PLC protocols diagnostics
PPPecho   Send PPP test message
RENAME    Rename a file
RESTART   Restart specified RTU facilities
ROUTE     Manipulates IP network routing table
RMDIR    Remove a directory
S101diag  Filter IEC60870-5-101/-104 Slave diagnostics
STATUS    Display RTU operational status
SYSdiag   Filter RTU system diagnostics
TASKS     Display RTU task information
TCPdiag   Filter TCP/IP diagnostics
TIME      Display RTU clock Time
TYPE      Dump the contents of a file as ASCII
VER       Display RTU firmware versions
WhoAmI    Display RTU identity

```

Figure 9.3: Command Summary

- Type **whoami** to display configuration details licensed services and port configuration details.



```
Untitled - Notepad
File Edit Format View Help
C:\>whoami

Schneider Electric SCADAPack ES Model (586) - SCADAPack E RTU
Serial Number      4169
CPU ID Number      07AC43470036560C
Ethernet MAC Addr  00-03-74-01-10-49
Ethernet MAC Addr 2 00-03-74-02-10-49
Ethernet IP Addr   172.16.24.1 Subnet-Mask 255.255.0.0
Ethernet IP Addr 2 0.0.0.0 Subnet-Mask 0.0.0.0


Enabled IP Services: ISaGRAF/TCP Modbus/IP(client) Modbus/TCP(server) Telnet FTP BOOTP NTP 104

Licenced Services: DNP3 Data Concentrator (Limited to 10 devices), Dual Ethernet, ISaGRAF, TCP/IP

Main RTU Unit - Group # 0
RTU DNP3 Address # 0 (0000 Hex)
DNP3 Master 1 Address # 30000, Local Address # 0
Mod/TCP Svr Unit ID # 1
RTU Switch Setting # 00 Hex (0 Dec)
Hardware Revision ID # DE Hex
PORT 0 ( 9600 bps): ISaGRAF
PORT 1 ( 9600 bps): DNP3 - RS232
PORT 2 ( 9600 bps): DNP3 - RS232
PORT 3 ( 9600 bps): DNP3 - RS232
PORT 4 ( 9600 bps): Command Line
```

Figure 9.4: 'whoami' command output

Type **ver** to display the version of major RTU facilities e.g. firmware version



```
Terminal - SPES.TRM
File Edit Settings Phone Transfers Help
C:\>ver


SCADAPack E Firmware 8.05.2
Build 5.2.78
Copyright (C) Control Microsystems Inc. and licensors

Controller      SCADAPack ES Model (586)
Firmware        Version 8.05.2.78
DNP3            Version 3.10.0001
ISaGRAF 3       Version 3.55
ISaGRAF 5       Version 2010.5.23.710_(100908)
RTOS            Version G1.13
TCP/IP          Version 4.1
BOOT MONITOR    Version 2.15
RTU PAL         Version 1.4
I/O INTERFACE   Version 2.01

C:\>
```

Figure 9.5: 'ver' command output

- Type **status** to display the RTU status as shown below.



```
Terminal - SPES.TRM
File Edit Settings Phone Transfers Help
C:\>status
RTU Uptime:           7 days, 20:56:57

ISaGRAF5 Resource 1: Stopped
ISaGRAF5 Resource 2: Stopped

Reset Counter:       4
Reset Reason mask:   0x020E
Task Watchdog mask:  0x0002
Sys Last Error:      4028
Sys Memory Free:     127034904 bytes
Sys Memory Size:     128779804 bytes

Security:
DNP3 Secure Authentication: Not licensed
AGA12 Encryption for DNP3: Not licensed
Master Key:           Not set

C:\>
```

Figure 9.6: 'status' command output

- Close the Hyper Terminal session.
-

10 Reading and Writing RTU DNP Data

The SCADAPack ES is a native DNP3 device. Consequently, the attributes and properties of *derived* and *physical* points are internally recorded in the RTU's DNP point address space.

- *Physical* points are internal representation of electrical terminations on a Main RTU or SCADAPack ES Remote I/O Unit. These may be either *Input* points or *Output* points.
- *Derived* points are for RTU internal data. These may be either *User* points (created by a user defined configuration) or *System* points (managed by the RTU operating system)

Each point has a set of *Point Attributes*, which define how the RTU processes the point. Points with the same *point type* (Analog Input for example) share a common set of point attributes. Different point types have a different set of attributes. The *DNP3 Point Data Class* and *DNP3 Object Type* are examples of point attributes.

Point Properties are generally read only point database fields describing (to the SCADA Master, SCADAPack E Configurator and an ISaGRAF application) a status or characteristic of a point. The *current state* of a digital point or *current value* of an analog point is an example of a point attribute.

The exercise in this section involves reading and writing to physical and derived points.

10.1 Reading RTU DNP Data

The *current state* of a digital point or *current value* of an analog point, amongst others, are examples of DNP point attributes that will be read by a user application. The exercise in this section involves reading the current state or value of some RTU system points.

Table 10.1: Sample RTU DNP System Points

Type	Point #	System Point Name
Float In	50060	Input Supply Voltage
Float Out	63200	Low Volts Alarm Level
Binary In	50206	Local Input Power Supply Low Alarm
Binary In	50207	Local On Board Battery Low
Analog In	50082	RTU Serial Number
Analog Out	50300	RTU DNP Node Address
Analog In	50010	RTU Up Time (Secs)

1. Apply power to the SCADAPack ES if necessary.
2. Launch the SCADAPack E Configurator software.
3. Select the *Point Browser* page.
4. Complete the table with the entries [Table 10.1](#)^[32] above.

Only the point type and point number need to be entered in the table. Clicking on the **Decimal** or **Hex** columns for the corresponding DNP point will automatically populate these fields with the current value or state properties of the point.

5. Check that the serial cable is connected to Port 1 if using the serial communication link.
6. Click on **Read** from the *Point Browser* page to read the DNP point properties.

A sample screen shot of a populated Point Browser is shown in [Figure 10.1](#)^[32] below.




Figure 10.1: Reading RTU Data using the SCADAPack E Configurator Point Browser

7. Select the option **Perform Automatic Read** from *Point Browser* page.




Figure 10.2: Automatic Read Dialog

8. Enter a read interval of **1** second.
9. Observe DNP point # 50010 increment every second (RTU Up Time system point).

10.2 Writing RTU DNP Data

The exercise in this section involves writing the *current state* or *value property* of the configurable predefined system and physical I/O digital and analog points.

1. Using digital multi-meter, measure the DC current in mA across analog output channel **AO±** on the RTU. The multi-meter will display a reading of 4mA representing the factory calibrated minimum analog output current.
2. Make the following changes to the Point Browser table.
 - a. Add the additional entries from [Table 10.2](#)^[34] into the table.
 - b. Change the **Decimal** value of DNP Point # **63200** to **24**.
 - c. Change the **Decimal** value of DNP Point # **50300** to **250**.
3. The completed table should look similar to the screen in [Figure 10.3](#)^[34].

Table 10.2: Writeable RTU DNP System Points

Type	Point #	Decimal	System Point Name
Analog Out	50120	19200	Port 0 Data Rate
Binary Out	1	1	Physical Binary Output Point 1
Binary Out	2	1	Physical Binary Output Point 2
Analog Out	1	10000	Physical Analog Output Point 1

The screenshot shows the 'Point Browser' window with buttons for 'Write', 'Write All', and 'Read'. There is a checkbox for 'Perform Automatic Read' and a field for 'Every 1 Seconds'. Below the controls is a table with columns: Type, Point #, Decimal, Hex, Description, and Comment. The table contains 13 rows of data, with the last row (13) being empty.

	Type	Point #	Decimal	Hex	Description	Comment
2		63200	11.5	41380000		Low Volts Alarm Level
3		50206	0	0		Local Input Power Supply Low
4		50207	1	1		Local On Board Battery Low
5		50082	4169	1049		RTU Serial Number
6		50300	0	0		RTU DNP Node Address
7		50010	685207	A7497		RTU Up Time (Secs)
8		50120	19200	4B00		Port 0 Data Rate
9		1	1	1		Physical Binary Output Point 1
10		2	1	1		Physical Binary Output Point 2
11		1	10000	2710		Physical Analog Output Point 1
12						
13						

Figure 10.3: Writing RTU DNP Data using the SCADAPack E Configurator

4. Click on **Write** from the *Point Browser* page to write changes to the RTU.
5. Observe the digital outputs relay LEDs 1 and 2 light up.
6. Measure the DC current in mA across analog output channel **AO±** on the RTU. The multi-meter will display 20mA denoting the maximum analog output current.

7. Select the *Ports* page and observe the value of *Port 0 Baud* rate field.
8. Issue a **Reinitialize DNP3** from the Commands menu. This is required for the DNP node address change to take effect.
9. Return to the **Point Browser**.
10. Change the *Target DNP3 Address* at the top of the SCADAPack E Configurator window to **250**.




Figure 10.4: Remote DNP Address Dialog

1. **Read** the RTU data.
2. Observe the current state of Digital DNP point **50206**, indicating a low voltage alarm.
3. Change the value of Analog DNP 63200 back to default in DNP Data table
4. Change the value of Analog DNP 50300 back to default **0**.
5. Change the value of Physical Analog Output point 1 back to **0**.
6. Write changes to controller.
7. Issue a **Reinitialize DNP3** to the controller for DNP node address change to take effect.

11 Accessing Physical I/O Data via Modbus

The SCADAPack E RTUs support a native Modbus Slave driver which supports an automatic one to one mapping of DNP points into corresponding Modbus addresses thus allowing communication with other Modbus devices. The 'Modbus address' conforms to the Modicon PLC client style register address (protocol address + 1).

- Digital input DNP points 1 to 16 are mapped to Modbus registers 10001-10016.
- Digital output DNP points 1 to 16 are mapped to Modbus registers 00001-00016.
- 16-bit analog input DNP points 1 to 16 are mapped to Modbus registers 30001 to 30016.
- 16-bit analog outputs DNP points 1 to 16 are mapped to corresponding holding registers 40001 to 40016.

32-bit analog DNP points have to be mapped manually to Modbus registers using the Modbus Register/32-Bit Point Map located in the **Slave | Modbus** Page of SCADAPack E Configurator.

The exercise in this section comprises of:

- Configuring a serial port as a Modbus Slave.
 - Performing a DNP to Modbus address mapping for 32-bit analog RTU points.
-

11.1 Configuring a Modbus Serial Interface

To configure a Modbus serial interface on the SCADAPack ES,

1. Launch the SCADAPack E Configurator.
2. Select the *Port* page.
3. Assign the *Modbus Slave* function to a port from the drop down list as shown in the figure below.
4. View the remaining port parameters.




Figure 11.1: Configuring Serial Port 3 for Modbus Communication

5. Select **Slave / Modbus** page
6. Enter analog I/O DNP points to Modbus register mapping using the table if using 32-bit analog points
7. Confirm the Modbus Slave station address and make changes if necessary.

The same Modbus station number applies if multiple ports on the RTU are configured for Modbus Slave

9. Save Configuration file and write the updated file to the controller.
10. Restart the controller.

A master station can now poll data from the SCADAPack ES controller, from the assigned Modbus registers.

A sample screen shot is shown below. In this example, the SCADAPack ES is assigned a Modbus

slave address of 246.




Figure 11.2: Analog DNP Point to Modbus Register Mapping

In [Figure 11.2](#) 32-bit analog input and output points 1 and 2 have been mapped to 16-bit Modbus registers as illustrated below:




Figure 11.3: Analog Input Point to Modbus Address Mapping




Figure 11.4: Analog Output Point to Modbus Address Mapping

11.1.1 Reading/Writing to Modbus Registers

Reading and writing to the SCADAPack ES Modbus registers is relatively straight forward once a Modbus Slave serial interface has been defined as above.

Using 5-digit Modicon PLC addressing,

- Digital inputs are referenced using Modbus registers 10001-19999.
- Digital outputs are referenced using Modbus registers 00001–09999.
- Analog inputs are referenced using Modbus registers 30001-39999.
- Analog outputs are referenced using Modbus holding registers 40001–65535.

When referencing 32-bit analog I/O via Modbus registers two consecutive Modbus holding registers are used to store a 32-bit analog value as illustrated in the previous section.

12 Related Documentation

This quick start guide does not cover all features and capabilities of the SCADAPack ES RTU but rather serves as a brief introduction on how to configure the unit. Additional information on major SCADAPack E RTU features is available in the SCADAPack E Technical Reference section of the Schneider Electric hardware manual index.

The table below provides a list of manuals that cover in detail each RTU feature presented in this quick start guide.

Subject Matter	Recommended Reading
Installation and description of the SCADAPack E Configurator Software	<i>SCADAPack E Configurator User Manual</i>
Powering the SCADAPack ES	<ul style="list-style-type: none"> <li data-bbox="846 703 1459 751">• <i>SCADAPack ES Hardware Manual</i> This manual describes the hardware aspects of the SCADAPack ES. Topics covered include features, physical description serial cable specifications and power requirements. An initial read. <li data-bbox="846 898 1459 961">• <i>SCADAPack ES Operational Reference Manual</i> This manual describes in details the operation of the major RTU facilities. Topics covered include Serial Port assignments, I/O operation, a brief introduction to ISaGRAF operation and the functions of the RTU Hex Switches.
Establishing Communication to the SCADAPack ES from a PC or peer device	<ul style="list-style-type: none"> <li data-bbox="846 1150 1459 1423">• <i>SCADAPack E Communication Interface Reference Manual</i> This manual provides more of a general overview of the configurations options and operations of SCADAPack E communication interfaces. Specifically, RS-232/RS-485 interoperability of the serial ports and communication via a Hayes modem can be found in this manual. <li data-bbox="846 1444 1459 1745">• <i>SCADAPack E TCP/IP Technical Reference</i> This manual deals exclusively with the TCP/IP implementation in the SCADAPack E RTUs. Topics covered include configuration of the dual Ethernet interfaces for communication with peer devices, the RTU Routing Table and serial PPP communication. Major configuration and operation of TCP/IP Services such as TELNET and, FTP Server, available with the SCADAPack E RTU is covered in this manual. <li data-bbox="846 1766 1459 1913">• <i>SCADAPack E Modbus Interfaces Reference</i> This manual deals exclusively with the Modbus implementation in the SCADAPack E RTU's. Topics covered include configuration of the SCADAPack E

	RTU to communicate with peer Modbus devices.
Reading and Writing RTU data.	<ul style="list-style-type: none">• <i>SCADAPack E Configuration Technical Reference</i> Contains a wealth of information on the properties and attributes of DNP points within the RTU database. An exploration of the complete functionality of the DNP3 and data processing implementation in the SCADAPack E RTU.• <i>SCADAPack E DNP3 Technical Reference</i> Covers the range of features provided by the SCADAPack E implementation of the DNP3 protocol. Topics covered include: SCADA data configuration, simultaneous DNP3 operation on multiple Ports, routing DNP3 frames, Peer-to-Peer communication and DNP3 over TCP/IP LAN & WAN networks.

12.1 SCADAPack ES External Data

SCADAPack ES Remote I/O

The Remote I/O capability of the SCADAPack ES RTU greatly enhances the I/O capability of a single SCADAPack ESRTU. Details can be found in the [SCADAPack ES Remote I/O Technical Reference](#) manual.

SCADAPack E Data Concentrator

The SCADAPack E RTUs can be licenced for use as a data concentrator.

With these features enabled, the SCADAPack E RTU will communicate to external equipment such as other SCADAPack E Smart RTUs, protection relays, power meters, other small RTUs, IEDs, etc.

When configured as a Data Concentrator, the SCADAPack E RTU is capable of the following:

- mapping of controls & inputs between the data concentrator and outstations
- integration of remote device event lists with RTU event list
- use of configurable serial ports or Ethernet (via TCP/IP) for outstation communications.
- communication to multiple outstations supported on same, or different communication channels
- quality information from outstation object flags (where available) or status results from communication with an outstation are to mapped to RTU database point quality
- time synchronization for devices providing time stamped data
- communication status' that can be mapped to SCADAPack E database points (includes outstation status, protocol status codes, communication counters, etc.)
- configurable timeout / retry settings
- configurable "health poll type" (protocol dependant) & poll interval after lost communications.
- DNP3 Routing for direct Master Station or maintenance terminal to remote outstation.

Details can be found in the [SCADAPack E Data Concentrator Technical Reference](#) manual.

