

## Preface

Thank you very much for purchasing A&D's ADSD-S series servo products. This manual provide related contents on how to use our ADSD-S servo drive and ADSM-S motor. It includes:

1. Installation of AC servo drives and motors
2. Configuration and wiring
3. Trial run steps
4. Control functions and adjusting methods of servo drives
5. Parameter settings
6. Inspection and maintenance
7. Troubleshooting
8. Application examples

Who should use this manual :

1. Those who are responsible for designing.
2. Those who are responsible for installing or wiring.
3. Those who are responsible for operating or programming.
4. Those who are responsible for maintaining or troubleshooting.

Before using the product, please read this user manual thoroughly to ensure correct use and store this manual in a safe and handy place for quick reference whenever necessary. Besides, please observe the following precautions:

1. Install the product in a clean and dry location free from corrosive and inflammable gases or liquids.
2. Do not connect a commercial power supply to the U, V, W terminals of motor. Failure to observe this precaution will damage either the Servo motor or drive.
3. Ensure that the motor and drive are correctly connected to a ground.
4. Do not attach, modify and remove wiring when power is applied to the AC servo drive and motor.
5. Before starting the operation with a mechanical system connected, make sure the emergency stop equipment can be energized and work at any time.
6. Do not touch the drive heat sink or the servo motor during operation. Otherwise, it may result in serious personnel injury

If you have other questions , Please consult our distributors or our customer services center.

## safety precautions:

Carefully note and observe the following safety precautions when receiving, inspecting, installing, operating, maintaining and troubleshooting.

### Receiving inspecting

-  **attention** ☆ In order to prevent fire hazard and accidents, please form the wiring by the cable specifications outlined in this user manual.

### Installation

-  **attention** ☆ Do not use the product in a wet location or where have corrosive and inflammable gases or liquids. Failure to observe this caution may result in electric shock, fire, or personal injury.

### Wiring

-  **warning** ☆ The drive and motor's grounding terminal should correctly connect to the ground according country electrical safty requirements. Failure to observe this caution may result in electric shock, fire, or personal injury.

-  **attention** ☆ Do not connect any power supplies to the U, V, W terminals. Failure to observe this precaution may result in serious injury, damage to the drive or fire.  
☆ Ensure that all screws, connectors and wire terminations are secure on the power supply, servo drive and motor. Failure to observe this caution may result in damage, fire or personal injury.

### Operation

-  **warning** ☆ In order to prevent accidents, the initial trial run for servo motor should be conducted under no load conditions (separate the motor from its couplings and belts).  
☆ Do not approach or touch any rotating parts (e.g. shaft) while the motor is running. Failure to observe this precaution may cause serious personal injury.  
☆ Before starting the operation with a mechanical system connected, change the drive parameters to match the user-defined parameters of the mechanical system. Starting the operation without matching the correct parameters may result in servo drive or motor damage, or

damage to the mechanical system.

- ☆ Ensure that the emergency stop equipment or device is connected and working correctly before operating the motor that is connected to a mechanical system.
- ☆ Do not touch either the drive heat sink during operation as they may become hot and personal injury may result.

## Maintenance and Inspection



### warning

- ☆ Do not touch any internal or exposed parts of servo drive and servo motor as electrical shock may result.
- ☆ Do not remove the operation panel while the drive is connected to an electrical power source otherwise electrical shock may result.
- ☆ Wait at least 5 minutes after power has been removed before touching any drive or motor terminals as an electrical charge may still remain in the servo drive and servo motor with hazardous voltages even after power has been removed.
- ☆ Do not disassemble the servo drive or motor as electric shock may result. otherwise electrical shock personal injury may result.
- ☆ Do not connect or disconnect wires or connectors while power is applied to the drive and motor. otherwise electrical shock personal injury may result.

## Main Circuit Terminal Wiring



### attention

- ☆ Please perform the wiring after the terminal blocks are all removed from the drive.
- ☆ Insert only one wire into one terminal on the terminal block.
- ☆ When inserting wires, please ensure that the conductors are not shorted to adjacent terminals or wires.

## Main Circuit Terminal Wiring



### attention

- ☆ Do not install the motor power cables and encoder cables together, install the encoder cables in a separate conduit from the motor power cables to avoid signal noise. Separate the conduits by 30cm above.
- ☆ Use multi-stranded twisted-pair wires or multi-core shielded-pair wires for signal, encoder (PG) feedback cables. The maximum length of command input cable is 3m and the maximum length of encoder (PG) feedback cables is 20m.
- ☆ As a charge may still remain in the drive with hazardous voltages even after power has been removed, be sure to wait at least 5 minutes after power has been removed before performing any wiring and/or inspection.
- ☆ It is not recommended to frequently power the drive on and off. Do not turn the drive off and on more than once per minute as high charging currents within the internal capacitors may cause damage (within 0.2 minutes).

## Servo motor perform trial run separately



### attention

- ☆ Please perform trial run without load first and then perform trial run with load connected. After the servo motor is running normally and regularly without load, then run servo motor with load connected.

Ensure to perform trial run in this order to prevent unnecessary danger.

## Servo motor and mechanical system trial run in team




### attention

- ☆ In order to prevent accidents, the initial trial run for servo motor should be conducted under no load conditions (separate the motor from its couplings and belts), that mean, just let the motor work separately, do not operate the servo motor while it is connected to its mechanical system, because connecting the motor to its mechanical system may cause damage or result in personal injury during the trial run.

# Contents

Chapter 1 Unpacking Check and Model Explanation .....	1
1-1 Unpacking Check .....	1
1-2 Model Explanation .....	2
1-2-1 Servo Drive Nameplate Explanation.....	2



1-2-2 Servo Motor nameplate explanation .....	2
1-2-3 Servo Drive and Servo Motor Combinations .....	3
1-3 parts of Servo Drive.....	4
1-4 Servo Drive operation mode.....	5

Chapter 2 Installation .....	7
------------------------------	---

2-1 Safty and Precautions .....	7
2-2 Storage conditions .....	7
2-3 Installation conditions.....	7
2-4 Installation Procedure and Minimum Clearances .....	8

Chapter 3 Connections and Wiring .....	10
--	----

3-1 peripheral devices connect with main circuit.....	10
3-1-1 connecting to Peripheral Devices.....	10
3-1-2 Control circuit terminals.....	11
3-1-3 Power supply connections for control circuit.....	12
3-2 Input / Output Interface Connector CN1 .....	13
3-3 CN2 encoder signal connections .....	15
3-4 CN3 communication signal connection .....	16

3-5 interface circuit .....	16
3-5-1 input switching interface.....	16
3-5-2 output switching interface .....	17
3-5-3 analog input interface.....	18
3-5-4 analog output interface.....	18
3-5-5 Pulse input interface .....	18
3-5-6 Pulse output interface .....	19

3-6 standard connection.....	20
3-6-1 P position pulse control mode .....	20
3-6-2 Pi internal position control mode.....	21
3-6-3 S/Si speed control mode.....	22
3-6-4 T/Ti torque control mode .....	23

3-7 servo motor connection .....	24
Chapter 4 Display and Operation.....	25

4-1 display and operation.....	25
4-1-1 parts of the Digital Keypad .....	25
4-1-2 Display parameter Flowchart .....	27
4-1-3 parameter setting description.....	27
4-1-4 keyboard operation .....	28
4-2 user parameter.....	31

Chapter 5 Trial Run and TuningProcedure.....	32
--	----

5-1 Inspection without load .....	33
5-2 Main parameter setting .....	34
5-2-1 Control mode confirmation .....	34
5-2-2 I/O Interface defination.....	36
5-2-3 Motor parameter setting.....	39
5-2-4 Corresponding parameter set for each control mode.....	39
5-2-4-1 .....	39
5-2-4-2 Speed control mode .....	43
5-2-4-3 Torque control mode .....	45
5-2-4-4 Rotation table control mode.....	47

Chapter 6 Servo Parameters function struction.....	51
--	----

6-1. Monitor parameter (status group) .....	51
6-2. Fault parameter (fault group) .....	53
6-3. Basic parameter (base Group) .....	54
6-4. High parameter (high group) .....	65

6-5. System parameter (sys group) .....	76
6-6. User parameters (User group) .....	78
6-7. EEPROM Parameter (super group) .....	79
Chapter 7 Communication Function.....	80
7-1 Introduction of communication hardware RS-485、RS-232、RS-422.....	80
7-1-1 RS-232.....	80
7-1-2 RS-422/RS485.....	81
7-2 Communication protocol.....	82
7-3 Communication operation.....	84
Chapter 8 Maintenance and Inspection.....	87
8-1 Basic Inspection .....	87
8-2 Maintenance.....	88
8-3 Lifespan of Replacement Components.....	88
Chapter 9 Troubleshooting.....	89
9-1 Fault Messages Table .....	89
9-2 Potential Cause and Corrective Actions .....	90
Chapter 10 Specifications.....	94
10-1 Specifications of Servo Drive.....	94
10-2 Specification of ADSM Servo Motor.....	96
Chapter 11 Application examples .....	100
11-1 Internal position register control (including origin regression function) .....	100
11-2 Rotation table control.....	102
11-3 ADSD-S drive and numerical control system accessories.....	104
11-3-1 The accessories schematic chart with HNC-21T/Dalian CNC .....	104
11-3-2.The schematic chart of matching with Guangzhou NC GSK218M. ....	107
Addendum.....	108
Drive matched cable.....	108
Pinboard of interface (optional) .....	108

## Chapter 1 Unpacking Check and Model Explanation

### 1-1 Unpacking Check

In case of any parts missing during purchasing or shipping, after receiving servo drive, please check for the following:

Check item	description
Ensure that the product is what you have ordered.	Please refer to Section 1.2 for details about the model explanation
Ensure that the servo motor shaft rotates freely.	Rotate the motor shaft by hand; a smooth rotation will indicate a good motor. However, a servo motor with an electromagnetic brake can not be rotated manually.
Check for damage.	Visual inspect the unit to insure it was not damaged during shipment.
Check for loose screws.	Visual inspect if there are screws loose or loosen off.


If any problem mentioned above happened, please inform the distributor whom you purchased the product from or our company.

A complete and workable AC servo system should be including the following parts:


- (1) Servo drive and Servo motor.
- (2) One power cable, which is used to connect servo motor and U, V, W terminals of servo drive. This power cable is with one green grounding cable. Please connect the green grounding cable to the ground terminal of the servo drive.
- (3)One encoder cable, which is used to connect the encoder of servo motor and CN2 terminal of servo drive.
- (4)Connector CN1: 44 PIN Connector.
- (5)Connector CN2: 15 PIN Connector.
- (6)Connector CN3: 8 PIN Connector

## 1-2 Model Explanation

### 1-2-1 Servo Drive Nameplate Explanation




### 1-2-2 Servo Motor nameplate explanation



## 1-2-3 Servo Drive and Servo Motor Combinations

power	Servo Drive model	Servo Motor model
<b>400W</b>	<b>ADSD-S23-0.4K</b>	<b>ADSM-S80-013M30</b>
		<b>ADSM-S80-024M30</b>
<b>750W</b>	<b>ADSD-S23-0.75K</b>	<b>ADSM-S80-033M30</b>
		<b>ADSM-S110-020M30</b>
		<b>ADSM-S130-040M25</b>
		<b>ADSM-S130-050M20</b>
		<b>ADSM-S110-040M30</b>
<b>1500W</b>	<b>ADSD-S23-1.5K</b>	<b>ADSM-S130-050M25</b>
		<b>ADSM-S110-060M20</b>
		<b>ADSM-S110-050M30</b>
		<b>ADSM-S110-060M30</b>
		<b>ADSM-S130-077M20</b>
		<b>ADSM-S130-077M25</b>
		<b>ADSM-S130-100M15</b>
		<b>ADSM-S130-077M30</b>
		<b>ADSM-S130-100M25</b>
		<b>ADSM-S130-150M15</b>
<b>2200W</b>	<b>ADSD-S23-2.2K</b>	<b>ADSM-S130-150M15</b>
		<b>ADSM-S150-150M25</b>
		<b>ADSM-S150-180M20</b>
		<b>ADSM-S150-230M20</b>
		<b>ADSM-S150-270M20</b>
<b>4000W</b>	<b>ADSD-S23-4.0K</b>	

## 1-3 parts of Servo Drive



## 1-4 Servo Drive operation mode

This servo drive can provide multiple operation modes for user's option as follows:

Mode	Mode Code	Description
External Position Control	P	Position control for the servo external pulse command.
Internal Position Control	Pi	Position control for the servo motor is achieved commands stored within the servo controller. Ex the 8 positions is via Digital Input (DI) signals.
Speed Control	S	Speed control for the servo motor can be achieved via parameters set within the controller or from an external analog -12 ~ +12 V command. Control of the internal speed parameters is via the Digital Inputs (DI). (A maximum of three speeds can be stored internally).
internal Speed Control	Si	Speed control for the servo motor is only achparameters set within the controller. Control of speed parameters is via the Digital Inputs (DI) of three speeds can be stored internally).
Torque Control	T	Torque control for the servo motor can be achieved via parameters set within the controller or from an external analog -12 ~ +12 V command. Control of the internal torque parameters is via the Digital Inputs (DI).
Internal Torque Control	Ti	Torque control for the servo motor is only achieved via parameters set within the controller. Control of the internal torque parameters is via the Digital Inputs (DI).
Index mode		Controller accept external DI signal and perform index mode control according the setting parameter.
Dual mode	P-S	Either P or S control inputs (DI)
	P-T	Either P or T control mode can be selected via the Digital Inputs (DI)

	Pi-S	Either Pi or S control mode can be selected via the Digital Inputs (DI)
	Pi-T	Either Pi or T control mode can be selected via the Digital Inputs (DI)
	S-T	Either S or T control mode can be selected via the Digital Inputs (DI)

The above control modes can be accessed and changed via parameter B01. If the control mode is changed, switch the drive off and on after the new control mode has been entered.

## Chapter 2 Installation

### 2-1 Safety and Precautions

Please pay close attention to the following installation notes:

- 1) Do not bend or strain the connection cables between servo drive and motor.
- 2) When mounting servo drive, make sure to tighten screws to secure the drive in place.
- 3) If the servo motor shaft is coupled directly to a rotating device ensure that the alignment specifications of the servo motor, coupling, and device are followed.
- 4) If the length of cable connected between servo drive and motor is more than 20m, please increase the wire gauge of the encoder cable and motor connection cable (connected to U, V, W terminals).
- 5) Make sure to tighten the screws for securing motor.

The product should be kept in the shipping carton before installation. In order to retain the warranty coverage, the servo drive should be stored properly when it is not to be used for an extended period of time. Some storage suggestions are:

### 2-2 Storage conditions

- Store in a clean and dry location free from dust.
- Store within an ambient temperature range of -20°C to +65°C.  
Store within a relative humidity range of 0% to 95% and non-condensing.
- Do not store in a place subjected to corrosive gases and liquids.  
Correctly packaged and placed on a solid surface.

### 2-3 Installation conditions

The ambient temperature of servo drive for long-term reliability should be within under -10°C~55°C. If the ambient temperature of servo drive is greater than 45°C, please install the drive in a well-ventilated location and do not obstruct the airflow for the cooling fan.

If they are installed in a control panel, please ensure sufficient space around the units for heat dissipation. Pay particular attention to vibration of the units and check if the vibration has impacted the electric devices in the control panel. What's more, please observe the following precautions when selecting a mounting location:

Do not mount the servo drive or motor adjacent to heat-radiating elements or under high temperature.

Avoid dropping water, steam, dust or oil.

Prohibit use in dangerous environment where is subject to inflammable or combustible or explosive gas or liquid.

Do not mount the servo drive or motor in a location subjected to airborne dust or metallic particles.

Do not mount the servo drive or motor in a location where vibration and shock will exceed specification.

Do not mount the servo drive or motor in a location where it will be subjected to high levels of electromagnetic radiation.

The ambient temperature of servo motor for long-term reliability should be within under 0°C~40°C.

please observe the following precautions:

Do not mount the motor adjacent to heat-radiating elements or under high temperature,

Avoid droping water , steam , dust or oil.


Prohibit use in dangerous environment where is subject to inflammable or combustible or explosive gas or liquid.

Do not mount the servo drive or motor in a location subjected to airborne dust or metallic particles. □

## 2-4 Installation Procedure and Minimum Clearances


### Important Attentions:

Please follow the guidelines in this manual when installing the servo drive and motor. Incorrect installation may result in a drive malfunction or premature failure of the drive and or motor. The servo drive should be mounted perpendicular to the wall or in the control panel. In order to ensure the drive is well ventilated, ensure that the all ventilation holes are not obstructed and sufficient free space is given to the servo drive. Do not install the drive in a horizontal position or malfunction and damage will occur.



### Installation Procedure:

In order to help the cooling fan subject to a lower wind block so as to discharge the heat more effectively, we suggest users to observe below minimum installation clearance.




## Chapter 3 Connections and Wiring

This chapter provides information on wiring ADSD-S series servo products, the descriptions of I/O signals and gives typical examples of wiring diagrams.

### 3-1 peripheral devices connect with main circuit

#### 3-1-1 CONNECTING TO PERIPHERAL DEVICES



Safety precautions:

1. Check if the wiring of control circuit power (L1, L2) and main circuit power (R, S, T) are correct.
2. Check if the phase of U, V, W cables is connected correctly.

3. When using an external resistor, connect it to RB and RB1, and ensure an open circuit between RB and RB2. When using an internal resistor, ensure the circuit is closed between RB and RB2, and the circuit is open between RB and RB1.
4. If a fault or emergency stop occurs, using ALARM or WARN output can control electromagnetic contactor and cut off the power of the servo drive.

#### 3-1-2 CONTROL CIRCUIT TERMINALS

Terminal Identification	Terminal description	Functions
L1,L2	control circuit input terminals	connect to Single-Phase AC power
R,S,T	main circuit input terminals	connect to 3-phase AC power
U,V,W	main circuit output terminals	connect to motor power input terminal
RB,RB1, RB2	connection point for breaking resistance	When using an internal resistor, ensure the circuit is closed between RB and RB2, and the circuit is open between RB and RB1; When using an external resistor, connect it to RB and RB1, and ensure an open circuit between RB and RB2.
CN1	servo drive terminal	connect to controller
CN2	encoder terminal	connector to encoder
CN3	communication terminal	connector to PC


Wiring connection should pay close attention to follows:

- 1) As a residual hazardous voltage may remain inside the drive, please do not immediately touch any of the "power" terminals (R, S, T, U, V, & W) and/or the cables connected to them after the power has been turned off and the charge LED is lit
- 2) The cables connected to R, S, T and U, V, W terminals should be placed in separate conduits from the encoder or other signal cables. Separate them by at least 30cm.
- 3) If the encoder cable is too short, please use a twisted-shield signal wire with grounding conductor. The wire length should be 20m or less. For lengths greater than 20m, the wire gauge should be doubled in order to lessen any signal attenuation.


### 3-1-3 POWER SUPPLY CONNECTIONS FOR CONTROL CIRCUIT

Servo drives wiring connections include single phase connection and three phase connection. Single phase connection can only fit for the unit whose power is under 1KW. In below drawing, Power ON is on "a" position, OFF and Processing is on "b" position. 1MC/x is electromagnetic contacting coil, 1MC/a is self-protection power, 1MC is main circuit interface.

Three phase connection fit for unit whose power is 1KW or above




Single phase connection fit for unit whose power is under 1KW



### 3-2 Input / Output Interface Connector CN1

#### CN1 Terminal Signal Identification



General signal

Signal	Signal code	Pin No.	Function
Analog Signal Input	VII	40	Speed analog input signal
	VI2	41	Torque analog input signal
Analog Monitor Output	M2	36	the MON1 and MON2 can be assigned drive and motor parameters that can be monitored via an analogue voltage.
	M1	37	
Position Pulse output	OA+	10	The motor encoder signals are available through the terminals. The encoder output pulse count can be set via parameter.
	OA-	11	
	OB+	12	
	OB-	13	
	OZ+	14	
	OZ-	15	
Position Pulse input	P+	34	input pulse
	P-	35	
	N+	32	
	N-	33	
Power	+24V	42,43,44	supply 24V source
	COM	28,29,30	24V ground
Power	+12V	38	+12V source
	-12V	39	-12V source
	12VGND	25,26,27	+12V/-12V ground

## DI signal


signal	signal code	Pin No.	Function
DI	DI1	16	External terminal input 1.
	DI2	1	External terminal input 2.
	DI3	17	External terminal input 3.
	DI4	2	External terminal input 4.
	DI5	18	External terminal input 5.
	DI6	3	External terminal input 6.
	DI7	19	External terminal input 7.
	DI8	4	External terminal input 8.

## DO signal

signal	signal code	Pin No.	Function
DO	DO1+	24	External terminal input 1+
	DO1-	9	External terminal input 1-
	DO2+	23	External terminal input 2+
	DO2-	8	External terminal input 2-
	DO3+	22	External terminal input 3+
	DO3-	7	External terminal input 3-.
	DO4+	21	External terminal input 4+
	DO4-	6	External terminal input 4-.
	DO5+	20	External terminal input 5+.
	DO5-	5	External terminal input 5-.

## 3-3 CN2 encoder signal connections


CN2 interface signal description



Signal Identification	Footnote	function
A+	7	Encoder A +phase input
A-	8	Encoder A - phase input
B+	9	Encoder B +phase input
B-	10	Encoder B- phase input
Z+	15	Encoder Z +phase input
Z-	14	Encoder Z - phase input
U+	5	Encoder U +phase input
U-	4	Encoder U - phase input
V+	3	Encoder V +phase input
V-	2	Encoder V - phase input
W+	1	Encoder W - phase input
W-	6	Encoder W - phase input
+5V	13	Encoder using 5V source
GND	11,12	Encoder using 5V ground source

## 3-4 CN3 communication signal connection

CN3 interface signal description




Signal	Pin No.	functions
R1+	8	Controller terminal data receiving line drive + terminal
R1-	7	Controller terminal data receiving line drive - terminal
T1-	6	Controller terminal data sending line driver - terminal
T1+	5	Controller terminal data sending line driver + terminal
RX232	4	
TX232	3	
GND	1,2	ground signal

## 3-5 interface circuit

### 3-5-1 input switching interface


using servo drive internal source

interface drawing





## 3-5-2 output switching interface



(1) using external source




(2) using servo drive internal source





NOTE: the 24V AD source can either be supplied by servo dirver or external source.



**3-5-3 analog input interface****3-5-4 analog output interface****3-5-5 Pulse input interface**



(1) Line Drive input



(2) Collector input

**3-5-6 Pulse output interface****Line Drive Output**

**3-6 standard connection****3-6-1 P position pulse control mode****3-6-2 Pi internal position control mode**


**3-6-3 S/Si speed control mode**

**3-6-4 T/Ti torque control mode**



**3-7 servo motor connection**

Motor wiring socket	Wiring	U			V			W			FG					
	Socket no.	2			3			4			1					
Encoder socket	Signal	5V	0V	A+	A-	B+	B-	Z+	Z-	U+	U-	V+	V-	W+	W-	FG
	Socket no.	2	3	4	7	5	8	6	9	10	13	11	14	12	15	1
Break unit	Socket no.	1				2				3						
	Power	24VDC(-15%~+10%)												FG		

**Chapter 4 Display and Operation**

This chapter describes ADSD-S servo drive panel display and the basic operation of the digital keypad.


**4-1 display and operation****4-1-1 parts of the Digital Keypad**

**4-1-2 Display parameter Flowchart****4-1-3 parameter setting description**


LED display	Description
<b>1.2.3.4.R</b>	Showing that the current value is 16 M (the black dot means 16 M)
<b>30000</b> <b>50.00</b>	Showing that the current value is 10 M

#### 4-1-4 keyboard operation

ADSD-S servo drive works according multi-level menu, the first level is main menu, which including seven kinds of parameters: monitoring parameter, fault parameter ,basic parameter, high-level parameter, system parameter, factory parameter, user parameter. The operation procedure of these parameters is as follows:




Letter A stands for monitoring parameters. Each monitoring parameter can be setted according below operation procedure.you can set 22 kinds of different monitoring parameters according your choosed software version, speed command, analog command, moter feedback pulse, commanded pulse, differential value, torque value, moter control mode, DC bus voltage and alarm code.



mornitoring parameter list:

No	E <sup>2</sup>	RAM	parameter name	function
A00		0000H	VER	Firmware version
A01		0001H	ALM_FLG	Drive fault alarm code
A02		0002H	ALM_FLG1	Drive fault alarm code 1
A03		0003H	SPD_FB_H	Motor speed feedback
A04		0004H	SPD_CMD	Speed command
A05		0005H	SPD_REF	Analog speed reference input
A06		0006H	POS_FB_H	Motor feedback pulse NO.
A07		0006H	POS_FB_L	
A08		0007H	POS_CMD_H	Position command pulse NO.
A09		0007H	POS_CMD_L	
A10		0008H	POS_ERR_H	Position command and feedback warp
A11		0008H	POS_ERR_L	
A12		0009H	TRQ_CMD	Torque command
A13		000AH	TRQ_REF	Analog torque reference
A14		000BH	TRQ_FB	Actual torque
A15		000CH	DC_V	Main circuit voltage
A16		000DH	IN_ST	Input status
A17		000EH	OUT_ST	Output status
A18		000FH	MODE	Control mode
A19		0010H	SV_ON	Servo on mark
A20		0011H	CPLD ver	CPLD version
A21		0012H	IU_FB	IU Feedback current instant value
A22		0013H	IV_FB	IV Feedback current instant value

Parameters whose name is with initial letter B is called basic paraters. You can set the parameters according below setting steps, after set, you should repower the unit to make the parameters working. The details of the parameters definition is stated in following description.




Other parameters can be set according above setting procedure.

#### **4-2 user parameter**

user parameter								
No.	Contain	description		upper limitation	Lower limitation	factory setting		
U00	driver->key	0	no function		1	0		
		1	Control EEPROM, store data to keyboard EEPROM					
U01	key->driver	0	no function		1	0		
		1	Keyboard EEPROM, store data to control EEPROM.					
U02	Reset factory	0	no function		1	0		
		1	low inertia parameter					
		2	medium inertia parameter					
U03	paramters group shielded.	0bit	shielded, mortoring parameters group.		3Fh	0		
		1bit	shielded, fault parameter group					
		2bit	shielded, basic, parameter group					
		31bit	shielded, high-level parameter group					
		4bit	shielded, system parameter group					
		5bit	shielded, factory parameter group					
U04	User password	setting correct passwork, permit to modify parameters.			FFFFh	0		

## Chapter 5 Trial Run and Tuning Procedure



### 5-1 Inspection without load

In order to prevent accidents and avoid damaging the servo drive and mechanical system, the trial run should be performed under no load condition (no load connected, including disconnecting all couplings and belts). Do not run servo motor while it is connected to load or mechanical system because the unassembled parts on motor shaft may easily disassemble during running and it may damage mechanical system or even result in personnel injury. After removing the load or mechanical system from the servo motor, if the servo motor can runs normally following up the normal operation procedure (when trial run without load is completed), then the users can connect to the load and mechanical system to run the servo motor.

***In order to prevent accidents, the initial trial run for servo motor should be conducted under no load conditions(separate the motor from its couplings and belts).***

***Caution: Please perform trial run without load first and then perform trial run with load connected. After the servo motor is running normally and regularly without load, then run servo motor with load connected. Ensure to perform trial run in this order to prevent unnecessary danger.***

After power is connected to AC servo drive, the charge LED will light and it indicates that AC servo drive is ready. Please check the followings before trial run:

Inspection before operation (Control power is not applied)	<input type="checkbox"/> Inspect the servo drive and servo motor to insure they were not damaged. <input type="checkbox"/> To avoid an electric shock, be sure to connect the ground terminal of servo drive to the ground terminal of control panel. <input type="checkbox"/> Before making any connection, wait 10 minutes for capacitors to discharge after the power is disconnected, alternatively, use an appropriate discharge device to discharge. <input type="checkbox"/> Ensure that all wiring terminals are correctly insulated. <input type="checkbox"/> Ensure that all wiring is correct or damage and or malfunction may result. <input type="checkbox"/> Visually check to ensure that there are not any unused screws, metal strips, or any conductive or inflammable materials inside the drive. <input type="checkbox"/> Never put inflammable objects on servo drive or close to the external regenerative resistor. <input type="checkbox"/> Make sure control switch is OFF. <input type="checkbox"/> If the electromagnetic brake is being used, ensure that it is correctly wired. <input type="checkbox"/> If required, use an appropriate electrical filter to eliminate noise to the servo drive. <input type="checkbox"/> Ensure that the external applied voltage to the drive is correct and matched to the controller.
---	---

Inspection during operation (Control power is applied)	<ul style="list-style-type: none"> <li><input type="checkbox"/> Ensure that the cables are not damaged, stressed excessively or loaded heavily.</li> </ul> <p>When the motor is running, pay close attention on the connection of the cables and notice that if they are damaged, frayed or over extended.</p> <ul style="list-style-type: none"> <li><input type="checkbox"/> Check for abnormal vibrations and sounds during operation. If the servo motor is vibrating or there are unusual noises while the motor is running, please contact the dealer or manufacturer for assistance.</li> <li><input type="checkbox"/> Ensure that all user-defined parameters are set correctly. Since the characteristics of various machinery equipment are different, in order to avoid accident or cause damage, do not adjust the parameter abnormally and ensure the parameter setting is not an excessive value.</li> <li><input type="checkbox"/> Ensure to reset some parameters when the servo drive is off (Please refer to Chapter 7). Otherwise, it may result in malfunction.</li> <li><input type="checkbox"/> If there is no contact sound or there be any unusual noises when the relay of the servo drive is operating, please contact your distributor for assistance or contact with Delta.</li> <li><input type="checkbox"/> Check for abnormal conditions of the power indicators and LED display. If there is any abnormal condition of the power indicators and LED display, please contact your distributor for assistance or contact with Delta.</li> </ul>						
	2	P External Position Control	Position control for the servo motor is achieved via an external pulse command.				
	3	P/S	Switch via input signal MODE status		OFF:P MODE	ON:S MODE	
	4	P/T	Switch via input signal MODE status		OFF:P MODE	ON:T MODE	
	5	S/T	Switch via input signal MODE status		OFF:S MODE	ON:T MODE	
	6	Pi-Internal Position Control	Position control for the servo motor is achieved via by 8 commands stored within the servo controller. Execution of the 8 positions is via Digital Input (DI) signals. Can choose the running sequence via parameter setting.				
	7	Si-Internal Speed control	Speed control for the servo motor can be achieved via parameters set within the controller o. Control of the internal speed parameters is via the Digital Inputs (DI). (A maximum of three speeds can be stored internally).				
	8	Ti Internal torque control	Torque control for the servo motor is only achieved via parameters set within the controller. Control of the internal torque parameters is via the Digital Inputs (DI). (A maximum of three torque levels can be stored internally).				
	9	Pi/S	Either Pi or S control mode can be selected via the input signals MODE.		OFF:Pi MODE	ON:S MODE	
	10	Pi/T	Either Pi or T control mode can be selected via the input signals MODE.		OFF:Pi MODE	ON:T MODE	
	11	Toe index	Control mode for turning charactor, according to input terminal commands, to proceed with graduation orientation control.				

## 5-2 Main parameter setting

### 5-2-1 Control mode confirmation

Before operation, system control mode should be confirmed. Set the control mode by setting B01(Control mode)

b01	11	0101H	CTRL_MOD	Control Mode	—	1	0~8
There are 6 single control modes and 6 dual control modes, besides,also some special mode(for special toe index mode (can be used for rotation table control))							
	Valu e	Control mode	Mode instruction				
	0	T Analog Torque control	Torque control for the servo motor can be achieved via parameters set within the controller or from an external analog -10 ~ +10 Vdc command. Control of the internal torque parameters is via the Digital Inputs (DI). (A maximum of three torque levels can be stored internally).				
	1	S-External Speed control	Speed control for the servo motor can be achieved from an external analog -10 ~ +10 Vdc command only. Control of the internal speed parameters is via the Digital Inputs (DI). (A maximum of three speeds can be stored internally).				

	2	P External Position Control	Position control for the servo motor is achieved via an external pulse command.		
	3	P/S	Switch via input signal MODE status		OFF:P MODE      ON:S MODE
	4	P/T	Switch via input signal MODE status		OFF:P MODE      ON:T MODE
	5	S/T	Switch via input signal MODE status		OFF:S MODE      ON:T MODE
	6	Pi-Internal Position Control	Position control for the servo motor is achieved via by 8 commands stored within the servo controller. Execution of the 8 positions is via Digital Input (DI) signals. Can choose the running sequence via parameter setting.		
	7	Si-Internal Speed control	Speed control for the servo motor can be achieved via parameters set within the controller o. Control of the internal speed parameters is via the Digital Inputs (DI). (A maximum of three speeds can be stored internally).		
	8	Ti Internal torque control	Torque control for the servo motor is only achieved via parameters set within the controller. Control of the internal torque parameters is via the Digital Inputs (DI). (A maximum of three torque levels can be stored internally).		
	9	Pi/S	Either Pi or S control mode can be selected via the input signals MODE.		OFF:Pi MODE      ON:S MODE
	10	Pi/T	Either Pi or T control mode can be selected via the input signals MODE.		OFF:Pi MODE      ON:T MODE
	11	Toe index	Control mode for turning charactor, according to input terminal commands, to proceed with graduation orientation control.		

## 5-2-2 I/O Interface definition


I/O Interface definition, define DI1~DI8 input interface needed through high parameter H14~H17 (including SVON, ALMRST、CW/CCW prohibited) , H18~H20output interface definition (Including RDY、SVON、ALM) 。

H14	5B	040EH	DI2-DI1	Input terminal DI2,DI1 definition		0601H	0~FFFFH
H15	5C	040FH	DI4-DI3	Input terminal DI4,DI3 definition		0B0AH	0~FFFFH
H16	5D	0410H	DI6-DI5	Input terminal DI6,DI5 definition		0D0CH	0~FFFFH
H17	87	0411H	DI8-DI7	Input terminal DI8,DI7 definition		0208H	0~FFFFH

Input function definition chart

symbol	Set value	Function instruction
P/PI	00H	Switch on, speed loop is ratio tache,else ratio intergral tache.
SVON	01H	Switch on,servo enable
ALMRST	02H	Alarm reposition. After alarm,alarm reason removed, then switch it on,it shows alarm signal removed.
MODE	03H	Mode selection under dual mode: OPEN,select MODE1;SHORT,select MODE2
DIR_REV	04H	Command input reverse control,Under internal position register andSpeed&torque mode, after it switches on,input commands turn to reverse.
GAIN_CHG	05h	Plus switch. Under speed&postion mode, after switch on, plus turns to Primary plus* changing ratio.
TRQLM	06H	Under speed or postion mode,it switch on, Motor torque will be confined., Torque confine command selection : OPEN—internal register ( 4FH,50H ) , SHORT—external torque analog commands.
SPDLM	07H	Speed confine commands selection: Under torque mode, switch on, motor speed will be confined. Confine speed commands will be internal resigster or external analog voltage commands. OPEN—internal register (44H) , SHORT—external speed analog command
EMG	08H	Switch on, motor urgency stop.
SV_LOCK	09H	Servo lockup,apply Pt.Pr, S, Sz
CWSTE	0AH	Reverse forbidden limitation
CCWSTE	0BH	FWD forbidden limitation
SP0	0CH	Internal speed command selection

	SP1	0DH						
	DISPN	0EH	Under position mode, switch on, external pulse input invalid					
	ORG_ST	0FH	Switch on, origin searching function will be activated					
	ORG_SW	10H	When origin searching, switchon, motor speed-down, regress to origin according to parameter regress mode.					
	TC0	11H	Internal torque command selection					
	TC1	12H						
	JOGU	13H	Switch on,motor FWD inching, inching speed parameter is JOG_SP(56H)					
	JOGD	14H	Switch on, motor reverse inching					
	HOLD	15H	Under internal position register mode,switch on,motor stops.					
	POSU	16H	Under internal position register mode,switch on, run to next internal register position command.					
	POSD	17H	Under internal position register mode,switch on, run to next internal register position command.					
	POSR	18H	Under internal position register mode,switch on, back to first internal register position command.					
	ATRIG	19H	Under internal register mode , after setting internal position control commands(POS0~2) , switch on will trigger motor to move according to internal position control register command., after digital output 0 speed signal (ZSPD=1) Then incept next trigger internal position command					
	POS_AUTO	1AH	Under internal position register mode,switch on, will auto-move according to internal position control register commands,moving spacing time refers to POST0~POST7,moving speed refers to POSV0~POSV7 将					
	PS0	1BH	Internal register position command selection					
			Position command	PS2	PS1	PS0	ATRIG	Corresponding parameter
			Positon register 0	0	0	0	↑	H42
								H43

	PS1	1CH	Positon register 1	0	0	1	↑	H44 H45		
			Positon register 2	0	1	0	↑	H46 H47		
			Positon register 3	0	1	1	↑	H48 H49		
			Positon register 4	1	0	0	↑	H50 H51		
	PS2	1DH	Positon register 5	1	0	1	↑	H52 H53		
			Positon register 6	1	1	0	↑	H54 H55		
			Positon register 7	1	1	1	↑	H56 H57		
ZCLAMP	1FH	When speed is under zero-speed set value(B38),this signal ON,motor stops.  								
TB0	20H	Toe index selection input : TB0—bit0; TB1—bit1; TB2—bit2; TB3—bit3; TB4—bit4;								
TB1	21H									
TB2	22H									
TB3	23H									
TB4	24H									
CTRIG	25	Internal spring,used for graduation								
H18	5E	0412H	DO2-DO1	Output terminal DO2,DO1 defination		0100H	0-FFFFH			
H19	5F	0413H	DO4-DO3	Output terminal DO4,DO3 defination		0502H	0-FFFFH			
H20	60	0414H	DO5	Output terminal DO5 defination		0003H	0-FFFFH			
Output function chart defination										
Symbol		Set value	Function instruction							
RDY		0	Control power and main power ready, if no fault, RDY switch on							
SON		1	Servo enable, if no fault, SON switch on							

	ZS	2	Motor speed<zero speed, ZS switch on
	ARRV	3	Motor speed> setting target speed, ARRV switch on
	TLM	4	Torque is confined, TLM switch on
	ALM	5	Alarm occur, ALM switch on
	BRK	6	Electromagnet brake on
	HOME	7	Origion regress
	POSIN	8	Under position control mode,when error pulse NO.< setting position range,POSIN switch on

### 5-2-3 Motor parameter setting

Firstly set motor basic parameter to system parameter according to servo motor fixed, e.g.

Current ratio coefficient Y13 (Set the calculation according to module current and motor rated current  $Y13=256*\text{module current crest value}/\text{motor rated current}/1.414$ )

Motor pulse NO. per revolution Y14(Set according to coder pulse NO. per revolution)

Motor poles Y15 (according to motor nameplate)

Electric angle biasing Y18 (Offset angle between phase Z and phase U /360\*2048;) , A/D speed input limit Y19 (4000H corresponding 3000rpm)

Above paramters must be confirmed correct before run, or else faulse alarm will occur.

Confirmation parameter correct must be after restarting control power on drive.

### 5-2-4 Corresponding parameter set for each control mode

According to control mode set, need to set according parameter while trial run.

now introduce several frequency-used modesas below


#### 5-2-4-1 Position control mode.

The position control mode (P or Pi mode) is usually used for the applications requiring precision positioning, such as industry positioning machine, indexing table etc. It supports two kinds of command sources in position control mode. One is an external pulse train(P:Position Terminals, External Position Control) and the other is internal parameter(Pi: Position Register, i.e. internal parameters H41~H43, Internal Position Control). The external pulse train with direction which can control the rotation angle of servo motor. The max. input frequency for the external pulse command is 500Kpps and it is equal to rotation speed of 3000r/min. In order to provide a convenient position control function, AD servo drive provides eight internal preset parameters for position control. There are two setting methods of internal parameters, one is to set different position command into these eight internal parameters before operation and then use POS0~POS2 of DI signals of CN1 to perform positioning control. The other setting method is to use serial communication to change the setting value of these

eight internal parameters.

Position control structure as below:

To make the servo motor and load operate more smoothly, loop gain and feed forward compensation.



The position control mode includes P and Pi: The command source of P mode is external pulse train input form terminals. The command sources of Pi mode are H41~H73 built-in parameters.

Under position control mode, below parameter needs to be set (Take external position as example)

#### (a) Pulse input style setting,


	10	0100H	PMOD	Pulse input style	—	0	0~4
	0: CW/CCW Pulse (rising edge)	1: Pulse and sign (rising edge)	2: AB Phase pulse	3: CW/CCW Pulse (trailing edge)	4: Pulse and sign (trailing edge)	e.g (positive logic)	CW/CCW Pulse (Positive rotation)

PP  
PN  
DP  
DN

AB Phase pulse  
PP  
PN  
DP  
DN

Positive rotation  
Negative rotation

Pulse and sign



(b) Electronic Gear Ratio



b02	12	0102H	GRN	Electronic Gear Ratio molecular	—	1	1~32767
	150≤(GRN / GRM)≤200, Set the denominator of position command pulse ratio under absolute mode, electronic gear ratio must be 1						
b03	13	0103H	GRM	Electronic Gear Ratio denominator	—	1	1~32767
	150≤(GRN / GRM)≤200, Set the denominator of position command pulse ratio under absolute mode, electronic gear ratio must be 1						

(c) position deviation setting during control

b04	14	0104H	POS_COIN_H	Position coincidence pulse	Pulse	0	0~0
b05	15	0104H	POS_COIN_L	Position coincidence pulse	Pulse	20	0~50000
	Set Position coincidence pulse range When pulse warp absolute value<b05, Position-fix signal output						
b06	16	0105H	POS_LMP_H	CCW max warp pulse NO.	Pulse	7H	0~7H
b07	17	0105H	POS_LMP_L	CCW max warp pulse NO.	Pulse	0A120H	0~0FFFFH 1~500000
	When wap of command position and actual positon >b07, servo drive gives over-position warp alarm						
b08	18	0106H	POS_LMN_H	CW max warp pulse NO.	Pulse	0FFF8H	8000~0FFFFH
b09	19	0106H	POS_LMN_L	CW max warp pulse NO.	Pulse	5EE0H	0~0FFFFH (-500000~-1)

	When command and actual position warp>b09, servo drive gives over-position warp alarm						
<b>(d) Positon loop parameter set</b>							
b10	1A	0107H	KPP	Position loop proportional gain	1/s	10	1~500
Set according to concrete servo drive system and loads condition, set value is bigger, response faster; too big value arouse oscillating							
b11	1B	0108H	KPF	Position loop feed forward proportional gain	%	0	0~100
Set according to concrete servo drive system and loads condition, set value is bigger, response faster; too big value arouse oscillating							
b13	1D	010AH	PFLT_TM	Position loop feed forward smooth filtering time constant	ms	0	0~10000
Set position command filtering time constant							
b14	1E	010BH	PFLLT_TM	Position loop smooth filtering time constant	ms	10	0~10000

When Position loop proportional gain(KPP) is too big, position open loop bandwith rises to reduce phase limit, then motor roter will oscillate. KPP must be reduced till rotor stop oscillating. When external torque joins, too low KPP can't meet reasonable position following warp requirement. Then feed forward gain b11 can reduce position dynamic following warp.

**(e) Speed loop parameter set**

b28	2A	0203H	DFLT	Velocity loop default low pass filtering time constant	0.1ms	0	0~10000
Speed default low pass filtering time constant, valid when ACCEL_MODE=0							
b32	2E	0207H	KVD	Velocity loop integral time constant	0.1ms	0	1~1000
Velocity loop integral time constant, set value is bigger, response faster; too big value arouse oscillating							
b36	32	020BH	KVP	velocity loop proportional gain	%	60	10~3000
Set velocity loop proportional gain set value is bigger, response faster; too big value arouse oscillating Under the condition that system does not produce oscillating, set as big as possible Set according to concrete servo drive system and loads condition,							
b37	33	020CH	KVI	Velocity loop integral time constant	ms	33	1~1000

- Note:
- 1、Debug the speed loop first, and then debug the position loop while debugging.
  - 2、Try your best to increase speed loop plus till there is no abnormal libration or noise, and speed is stable on the load(motor).
  - 3、Try your best to increase speed loop plus, till there is no abnormal libration or noise, and speed is stable on the load(motor), to ensure the load has good tailing character under the system running.

**5-2-4-2 Speed control mode**

Speed control (e.g. External control mode as example)

b28	2A	0203H	DFLT	Velocity loop default filtering time constant	0.1ms	0	0~10000
Velocity loop default filtering time constant, speedup/down mode, Valid when (ACCEL_MODE) =0							
b29	2B	0204H	FLT	Velocity loop smooth low pass filtering time constant	ms	10	1~10000
Velocity loop smooth low pass filtering time constant, speedup/down mode, Valid when (ACCEL_MODE) =1							
b30	2C	0205H	LNR	Beeline speedup time	ms	30	1~50000
0~3000rpm beeline speed up/down time							

b31	2D	0206H	SLNR	S-curve speed up/down time constant	ms	100	1~50000
Speed command S-shape curve speed up/down time constant,speed up/down mode (ACCEL_MODE)=3 时有效							
b32	2E	0207H	KVD	Velocity loop differential time constant	0.1ms	0	1~1000
Velocity loop differential time constant, set value is bigger, response faster;too big value arouse oscillating							
b33	2F	0208H	SV1	S yielding point speed 1	0555 H	-16384~16384 (0C000H~4000H)	
S-shape curve flixion speed 1, 4000H~3000RPM, valid when ACCEL_MODE=3							
b34	30	0209H	SV2	S yielding point speed 2	3AA BH	-16384~16384 (0C000H~4000H)	
S-shape curve flixion speed 2, 4000H~3000RPM, valid when ACCEL_MODE=3							
b35	31	020AH	ACEL_MOD	Speedup/down mode	0	0~3	
Speed command speedup/down mode 0:Default 1:Smooth speed up/down 2:Beeline speed up/down , 3:S-curve speed up/down							
Smooth speed up/down Beeline speed up/down S-curve speed up/down							
Use default under positon mode, Use beeline under JOGRUN							
b36	32	020BH	KVP	velocity loop proportional gain	%	60	10~3000
Set velocity loop proportional gain ,set value is bigger, response faster;too big value arouse oscillating。Under the condition that system does not produce oscillating, set as big as possible							
Set according to concrete servo drive system and loads condition							
b37	33	020CH	KVI	Velocity loop integral time constant	ms	33	1~1000

	set value is lower, response faster;too low value arouse oscillating Under the condition that system does not produce oscillating, set as low as possible  Default : , when inertia is small: 33ms, when inertia is big:100ms						
b38	34	020DH	ZSPD	Zero-speed RTS	—	54	0~3000
When motor speed < b38, output 0 speed signal 4000H~3000RPM							
b39	35	020EH	G_SPD	External speed commands Scaling(10V conversion)	3121	100~30000	
4000000H*(K/3000)/21504, K=100~30000<3000>[rpm/10V], (4000000H=4000h*2^12) Speed corresponding with Analog voltage input 10V, setting the ratio.							
b40	36	020FH	SP_OFST	External speed command biasing	0	-9999~9999 (0D8F1H~270FH)	
21504/10*K/000 1. Set speed command offset voltage, set value=servo drive internal offset voltage 2.Speed command working voltage =speed command input voltage+offset voltage.							
b41	37	0210H	ASPD	Speed reach RTS	4000H	0~4000H	
When actual speed > b41, Speed coincidence signal output, 4000H~3000RPM							
b42	38	0211H	KVPR	velocity loop gain fluctuation ratio	%	100	10~1000
According to gain switch condition (24H) , to adjust velocity loop proportional gain fluctuation							
b43	39	0212H	KVPF	velocity loop feed forward gain	%	0	10~1000
Set according to concrete servo drive system and loads condition, set value is bigger, response faster;too big value arouse oscillating							
b53	3F	0300H	TRQ_SW	Torque command selection	0	0,1	
External torque command input switch, 0:Defective 1:Effective Under torque control mode, it must be set to 1.Under speed control mode, when it is 0, external input torque command ADDL: When it set to 1,external input torque adds to actual torque command.							
b54	40	0301H	TFLT	Torque command input Filter time constant	ms	10	0~10000
Torque command input smooth filter time constant							

b55	41	0302H	G_TRQ	External torque command Scaling(10V conversion)	—	1170	30~3000																											
1800000H*(K/300)/21500, K=30~3000<300>[%/10V] 1170 input 10V, output torque is triple rated torque. Set conversion constant of torque command input voltage and output torque (Ratio to rated torque). At command voltage 10V, corresponding(output torque/rated torque) percentage to set this value [e.g.] At command voltage 10V, output torque=rated torque, input set value as 100. [Note] Output torque must be less than 300% rated torque.																																		
b56	42	0303H	TRQ_OFST	Outer torque command offset	0	-3000H~3000H (0D000~3000H)																												
1000H~100% rating torque. Set torque command offset voltage. Set value=Servo drive internal torque offset voltage Output torque working voltage=torque command input voltage+offset voltage																																		
b57	43	0304H	TRQ_GSP	velocity loop gain under torque mode	%	100	10~1000																											
RAM 的 T_GSP=SPD_STD×T_GSP /100/2 <sup>4</sup> Speed limitation control proportional gain under torque mode																																		
b58	44	0305H	TRQ_SPLM	Internal speed limit value	2AAAH	0~4000H																												
Internal speed limit value setting under torque mode. AV only under torque control mode 4000H~3000RPM																																		
b59	45	0306H	TRQ1	Internal torque command 1	0	-3000H~3000H (0D000~3000H)																												
b60	46	0307H	TRQ2	Internal torque command 2	0	-3000H~3000H																												
b61	47	0308H	TRQ3	Internal torque command 3	0	-3000H~3000H																												
Set internal torque command value Select via input terminal torque: 1、Torque selection2, to select internal torque 1、Internal torque2、Internal torque 3。 <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <td>Control mode</td> <td>Torque selection 2</td> <td>Torque selection 1</td> <td>Torque command</td> </tr> <tr> <td rowspan="4">0 (T)</td> <td>OFF</td> <td>OFF</td> <td>External analog</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>Internal torque1</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>Internal torque2</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>Internal torque3</td> </tr> <tr> <td rowspan="3">3 (Ti)</td> <td>OFF</td> <td>OFF</td> <td>0</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>Internal torque1</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>Internal torque2</td> </tr> </table>								Control mode	Torque selection 2	Torque selection 1	Torque command	0 (T)	OFF	OFF	External analog	ON	ON	Internal torque1	ON	OFF	Internal torque2	ON	ON	Internal torque3	3 (Ti)	OFF	OFF	0	OFF	ON	Internal torque1	ON	OFF	Internal torque2
Control mode	Torque selection 2	Torque selection 1	Torque command																															
0 (T)	OFF	OFF	External analog																															
	ON	ON	Internal torque1																															
	ON	OFF	Internal torque2																															
	ON	ON	Internal torque3																															
3 (Ti)	OFF	OFF	0																															
	OFF	ON	Internal torque1																															
	ON	OFF	Internal torque2																															

	1000H~100% rated torque						
b62	4A	0309H	FLG_T	Torque command selection	0	0, 1, 2, 3	
0: External analog/0 torque (control mode=0, external analog; When control mode=3,0 torque) 1: Internal torque command1 2: Internal torque command 2 3: Internal torque command 3 Note: When torque selection is included within external terminals, external input priority. Viz:torque selection is determined by external input terminal ON or OFF							
b63 4B 030AH TSPLM_F Speed limit selection 030BH T_DIR Torque direction selection							
BIT0: Speed confine selection(TSPLM_F) 0 : Internal speed confine AV Speed limitation is 44H(TRQ_SPLM) set value 1 : External speed confine AV Speed limitation is external speed command analog input BIT1: Torque direction selection(T_DIR) 0: Torque A/D positive CW 1: Torque A/D positive CCW AV only to external analog torque command BIT2:Reserved							

#### 5-2-4-4 Rotation table control mode

##### 1、Parameter setting

I Control mode: 11

b01	11	0101H	CTRL_MOD	Control mode	—	11	0~8
-----	----	-------	----------	--------------	---	----	-----


##### Rotation table graduation parameter

b59	45	0306H	TRQ1	Internal torque command1	1000H	-3000H~3000H (0D000~3000H)
H35	52	0422H	TB_MD	Rotation table control mode	0/1	
H36	AA	0423H	TB_NUM	Rotation table stations	2~32	2~32
H37	AB	0424H	TB_GRN	Rotation table gear ratio numerator	1~8	1~5000
H38	AC	0425H	TB_GRM	Rotation table gear ratio denominator	1~8	1~5000

H39	AD	0426H	TB_TM	Rotation table speed up/down time	10ms	10	0~10000
H40	AE	0427H	BLAS	Graduation control backlash compensation	Pulse	0	8000~7FFFF (-32768~32767)
H41	AF	0428H	POSS_MD	Position commands control mode		2/3/4	0~8

**Input/Output IO setting**

H14	5B	040EH	DI2-DI1	Input terminal DI2,DI1 defination		2401H	0~FFFFH
H15	5C	040FH	DI4-DI3	Input terminal DI4,DI3 defination		201FH	0~FFFFH
H16	5D	0410H	DI6-DI5	Input terminal DI6,DI5 defination		2221H	0~FFFFH
H17	87	04111H	DI8-DI7	Input terminal DI8,DI7 defination		0F10H	0~FFFFH
H18	5E	0412H	DO2-DO1	Input terminal DO2,DO1 defination		0100H	0~FFFFH
H19	5F	0413H	DO4-DO3	Input terminal DO4,DO3 defination		0803H	0~FFFFH
H20	60	0414H	DO5	Input terminal DO5 defination		0004H	0~FFFFH

**2、 Action timing sequence diagram:**

**Remarks:**

Power Supply : Servo input power supply

SVON: Servo enable (input commands)

TB NO: Graduation selection input (input commands)

CTRIG: Graduation spring (input commands)

Motor Speed : Motor speed

TLM: Torque limited commands (output commands)

POSIN: Postion reach commands (output commands)

**3、 Instruction:**

Parameter related: TRQ1(B59),SP1 (B25) , TB\_MD(H35), TB\_NUM (H36), TB\_GRN(H37), TB\_GRM(H38), TB\_TM(H39), BLAS(H40), POSS\_MD(H41).

1.) Motor controls the graduation begaining with the origin.

2.) Rotation table graduation can control motor rotor angle accurately, define station number of rotation table per cycle by TB\_NUM, define periodic quantity by TB\_GRN (rotation table gear ratio numerator)and TB\_GRM (rotation table gear ratio denominator). Specific station of rotation table is defined by TB0~TB4 and

their assemble. E.g.:

IF TB\_GRN/ TB\_GRM=1, one rotation of motor corresponding to one circle of table,if TB\_GRN/ TB\_GRM=2, half a rotation corresponding to one circle,if TB\_GRN/ TB\_GRM=1/2, two rotation corresponding to one circle,

3.) rotor angle TB0=1/2TB1=1/4TB2=1/8TB3=1/16TB,so Rotation table stations maximum can define 32 bits. Theoretic rotor must be less than 1 cycle, otherwise it invalid. E.g.

If TB\_GRN/ TB\_GRM=1, TB\_NUM =2 ,2 stations are avaibale,viz.0°(only CTRIG), 180° (trigger TB0) , other trigger points ADL.

If TB\_GRN/ TB\_GRM =1, TB\_NUM =3 ,3 stations are avaibale, viz. 0°, 120°(trigger TB0) , 240° (trigger TB1) , other trigger points ADL.

If TB\_GRN/ TB\_GRM =1, TB\_NUM =4,4 stations are avaibale,viz.0°, 90° (trigger TB0) , 180°(trigger TB1) , 270 (trigger TB0+TB1) °, other trigger point ADL.

Above rotor angle is forward direction (Anticlockwise facing motor axe)

4.) Note:

Graduation speed is defined by B25 SP1.

When H35 TB\_MD=1, dislocation ends,torque limitation. limitation value is set by B59 TRQ1.

H40 BLAS Graduation control backlash compensation. The pluse NO. set should be less than 1 cyc pulse NO.

## Chapter 6 Servo Parameters function struction

### 6-1. Monitor parameter (status group)

Series NO	E <sup>2</sup> address	RAM address	Parameter	Function	Unit	Default	Range
A00		0000H	VER	Firmware version	—	—	—
A01		0001H	ALM_FLG	Drive fault alarm code	—	—	—
A02		0002H	ALM_FLG1	Drive fault alarm code 1	—	—	—
							Drive fault alarm code A01: Alarm codes in address 0001H display in BCD code.
							0001: CPU error Bit 0~15 correspond to alarm 01~16
							0002: RAM error Corresponding bit =0 à No this alarm
							0004: EEPROM error Corresponding bit =1 à This alarm occurs
							0008: CW/CCW prohibited fault
							0010: Encoder fault 0002H:
							0020: Overcurrent Bit 0~4 is corresponding with alarm 17~21
							0040: Overload Corresponding bit=0 à NO this alarm
							0080: Undervoltage Corresponding bit =1 à This alarm occurs.
							0100: Overvoltage
							0200: Regeneration error 0001H, 0002H boths show “0” à No alarm
							0400: IPM error The first 5 alarm of A01 occurs,can not relieve via alarm reposition.,need to reset power.
							0800: Overspeed Alarm reposition must be under servo enable
							1000: Emergency stop
							2000: Excessive deviation
							4000: Motor over hot
							8000: Drive over hot
							A02:
							0001: Input power phase loss
							0002: Dynamic braking relay fault
							0004: CW limitation alarm
							0008: CCW limitation alarm
							0100: Communication abnormal
A03		0003H	SPD_FB_H	Motor speed feedback	—	—	—
				Keyboard displays motor actual speed			
				Communication gets corresponding data conversion relation 4000h à 3000rpm ( Data read by upper monitor			

	communication firmware )												
A04	0004H	SPD_CMD	Speed command	—	—	—	—						
Keyboard displays speed loop command input													
Communication gets corresponding data conversion relation 4000h→3000rpm													
A05	0005H	SPD_REF	Analog speed reference input	—	—	—	—						
Keyboard displays external analog speed command input 4000h→3000rpm													
Communication gets corresponding data conversion relation 4000h→3000rpm													
A06	0006H	POS_FB_H	Motor feedback pulse NO.	—	—	—	—						
A07	0006H	POS_FB_L		—	—	—	—						
Addup pulse NO.feedback by motor, totally 32bit, display hight 16bits and low 16bits respectively													
A08	0007H	POS_CMD_H	Position command pulse NO.	—	—	—	—						
A09	0007H	POS_CMD_L		—	—	—	—						
Addup pulse NO. of input command, 32bit, display hight 16bits and low 16bits respectively													
A10	0008H	POS_ERR_H	Position command and feedback warp	—	—	—	—						
A11	0008H	POS_ERR_L		—	—	—	—						
Warp between addup pulse NO. of input command and Addup pulse NO.feedback by motor													
Totally 32bit, display hight 16bits and low 16bits respectively													
A12	0009H	TRQ_CMD	Torque command	—	—	—	—						
Keyboard display current loop torque command input, communication gets data 1000h→100% rated current													
A13	000AH	TRQ_REF	Analog torque reference	—	—	—	—						
Keyboard display external analog torque command input, communication gets data 1000h→100% keyboard display rated current													
A14	000BH	TRQ_FB	Actual torque	—	—	—	—						
Keyboard display motor actual torque, communication gets data 1000h→100% rated current													
A15	000CH	DC_V	Main circuit voltage	—	—	—	—						
Keyboard display main loop WB voltage, communication gets data. DC actual voltage= DC_V*400/8192													
A16	000DH	IN_ST	Input status	—	—	—	—						
Input signal status:													
0bit—DI1		1bit—DI2		2bit—DI3									
3bit—DI4		4bit—DI5		5bit—DI6									
6bit—DI7		7bit—DI8											
Corresponding bit =0→ With input													
Corresponding bit =1→ without input													
A17	000EH	OUT_ST	Output status	—	—	—	—						



	Output signal status display						
	0BIT—DO1		1BIT—DO2		2BIT—DO3		
	3BIT—DO4		4BIT—DO5				
Corresponding bit=0→							
	Corresponding bit =1→ No output						
A18	000FH	MODE	Control mode	—	—	—	—
Current control mode display: 0: Torque 1: Speed 2: Position							
A19	0010H	SV_ON	Servo on mark	—	—	—	—
Current Servo enable status, 0: Servo status is OFF 1: Servo status is ON							
A20	0011H	CPLD ver	CPLD version				
A21	0012H	IU_FB	IU Feedback current instant value				
A22	0013H	IV_FB	IV Feedback current instant value				

## 6-2. Fault parameter (fault group)

序号	E <sup>2</sup> address	RAM address	Parameter name	funtion	Unit	Default	Range
F00	00		ALM_0	Fault record 0	—	0	0~15
F01	01		ALM_1	Fault record 1	—	0	0~15
F02	02		ALM_2	Fault record 2	—	0	0~15
F03	03		ALM_3	Fault record 3	—	0	0~15
F04	04		ALM_4	Fault record 4	—	0	0~15
F05	05		ALM_5	Fault record 5	—	0	0~15
F06	06		ALM_6	Fault record 6	—	0	0~15
F07	07		ALM_7	Fault record 7	—	0	0~15
F08	08		ALM_8	Fault record 8	—	0	0~15
F09	09		ALM_9	Fault record 9	—	0	0~15
	Drive fault alarm fault						
	01: CPU fault	02: RAM fault	03: EEP fault	04: CW/CCW prohibited fault			
	05: Coder abnormal	06: Overcurrent	07: Overload	08: Undervoltage			
	09: Overvoltage	10: Regeneration error	11: IPM	12:Overspeed			
	13: Emergency stop	14: Excessive deviation	15: Moter overhot	16: Drive overhot			
	17: Input power phase loss	18: dynamic braking relay fault	19: CCW limitation alarm	20: CCW			

	limitation alarm 21: Communication abnormal						
F10	0A		ALM_ADR	Latest fault address	—	0	0~9
EEPROM 的 ALM0-9updated fault address							
F11	0B		Reserved	Reserved	—	0FFFFH	—
F12							
F13	0C		Reserved	Reserved	—	0FFFFH	—
F14	0D		Reserved	Reserved	—	0FFFFH	—
F15	0E		Reserved	Reserved	—	0FFFFH	—
F16	0F		Reserved	Reserved	—	0FFFFH	—


### 6-3. Basic parameter (base Group)

Serie s NO.	E <sup>2</sup> address	RAM address	Parameter	Function	Unit	Default	Range
b00	10	0100H	PMOD	Pulse input style	—	0	0~4
0: CW/CCW Pulse (Rising edge) 1: Pulse and direction (Rising edge) 2: AB phase pulse 3: CW/CCW pulse (Trailing edge) 4: Pulse and direction (Trailing edge) e.g: (Positive logic) CW/CCW pulse (							
 <p>PP PN DP DN</p> <p>Positive rotation      Negative rotation</p>							
Pulse and sign  <p>PP PN DP DN</p> <p>H      L</p> <p>Positive rotation      Negative rotation</p>							
AB Phase pulse							


	PP	Positive	PP	Positive	PP	Positive	PP	
	PN		PN		PN		PN	
	DP		DP		DP		DP	
	DN		DN		DN		DN	
	rotation				rotation			
b01	11	0101H	CTRL_MOD	Control mode	—	1	0~8	
Series can be programmed to provide six single and five dual modes of operation. Their operation and description is listed in the following table and special graduation mode(available for rotation table control)								
Value	Control mode	Mode instruction						
0	T-Analog torque control mode	Torque control for the servo motor is achieved via by 3 commands stored within the servo controller , or input analog voltage via external terminals (-10V~+10V) .Commands selection is according to DI. Drive receives torque commands, to control the motor till target torque.						
1	S-Analog speed control mode	Speed command is offered by internal servo controller. (3 commands stored within the servo controller) , or input alalog voltage via terminals (-10V~+10V). Select commands according to DI signal.Drive receives speed commands, to control the motor till target speed.						
2	P-Pulse position control mode	Position command is input by terminal, signal aspect is pulse.Drive receives position commands, to control the motor till target position.						
3	P/S	Selected by input signal MODE	OFF:P MODE	ON:S MODE				
4	P/T	Selected by input signal MODE	OFF:P MODE	ON:T MODE				
5	S/T	Selected by input signal MODE	OFF:S MODE	ON:T MODE				
6	Pi Internal position control mode	Position control for the servo motor is achieved via by 8 commands stored within the servo controller, can use DI signal to select register NO. can also set the run order according to parameter setting. Drive receives positon commands, to control the motor till target positon.						
7	Si Internal speed contro mode	Speed control for the servo motor is only achieved via by 3 commands stored within the servo contolle , can't be achieved by external terminals.Commands selection is according to DI.Drive receives speed commands, to control the motor till target speed.						
8	Ti Internal torque control mode	Torque control for the servo motor is only achieved via by 3 commands stored within the servo contolle , can't be achieved by external terminals.Commands selection is according to DI. Drive receives torque						

			commands, to control the motor till target torque.				
9	Pi/S	Selected by input signal MODE	OFF:Pi mode	ON:S mode			
10	Pi/T	Selected by input signal MODE	OFF:Pi mode	ON:T mode			
11	Toe index	Control mode for tuning character, according to input terminal commands, to proceed with graduation orientation control.					
<p>Attention: After changing control mode parameters, must power off then power on before running. Otherwise accident will occur!!</p>							
b02	12	0102H	GRN	Electronic gear ratio numerator	—	1	1~32767
b03	13	0103H	GRM	Electronic gear ratio denominator	—	1	1~32767
	<p><math>1/50 \leq (GRN / GRM) \leq 200</math>  Set the denominator of position command pulse ratio  Under absolute mode (parameter H41 is 1、5、7), Electronic gear ratio denominator must be 1</p>						

	<p>Remarks: 1、Please set electronic gear ratio under SERVO OFF, if set it wrongly servo motor easy to cause violent motion  2、Drive 4<sup>th</sup> DF coder input pulse internally,viz. coder send each 2500 pulses to drive, after 4<sup>th</sup> DF,totally 10000 pulses.</p> <p style="text-align: center;"> </p> <p>If 10000 pulses enter drive from coderper ERV when electronic gear ratio=1, one command pulse is corresponding to one motor pulse. when electronic gear ratio=0.5, two command pulse is corresponding to one motor pulse</p>							
b04	14	0104H	POS_COIN_H	Position coincidence pulse	Pulse	0	0~0	
b05	15	0104H	POS_COIN_L	Position coincidence pulse	Pulse	14H	0~C350H	
Set Position coincidence pulse range When pulse warp absolute value<b05, Position-fix signal output								
b06	16	0105H	POS_LMP_H	CCW max warp pulse NO. (High 16 bit)	Pulse	7H	0~7H	
b07	17	0105H	POS_LMP_L	CCW max warp pulse NO. (Low 16 bit)	Pulse	0A120H	0~0FFFFH 1~500000	
When wap of command position and actual positon >b07, servo drive gives over-position warp alarm								
b08	18	0106H	POS_LMN_H	CW max warp pulse NO. (High 16 bits)	Pulse	0FFF8H	8000~0FFFFH	
b09	19	0106H	POS_LMN_L	CW max warp pulse NO. (Low 16 bits)	Pulse	5EE0H	0~0FFFFH (-500000~-1)	
When command and actual position warp>b09,servo drive gives over-position warp alarm								
b10	1A	0107H	KPP	Position loop proportional gain	1/s	10	1~500	
Set according to concrete servo drive system and loads condition, set value is bigger, response faster; too big value arouse oscillating								
b11	1B	0108H	KPF	Position loop feedforward proportional gain	1/s	0	1~500	
Set according to concrete servo drive system and loads condition, set value is bigger, response faster; too big value arouse oscillating								
b12	1C	0109H	KPPR	Position loop gain fluctuation ratio	%	100	10~500	

	Adjust Position loop proportional gain fluctuation according to Position loop gain switch condition						
b13	ID	010AH	PFLT_TM	Position smooth filtering time constant	ms	0	0~10000
	Set position command filtering time constant 						
b14	IE	010BH	PFFLT_TM	Position feedforward smooth filtering time constant	ms	10	0~10000
	Set Position feedforward smooth filtering time constant						
b15	1F	010CH	Reserved	Reserved		0	-
b16	20	010DH	Reserved	Reserved		0	-
b17	21	010EH	BIAS_SPD	Speed biasing function under positon control		0	-16384~16384 (0C000H~4000H)
	Position pulse warp > POS_COIN+POS_HIST, speed offset setting C000H~4000H(-3000rpm~3000rpm)						
b18	22	010FH	POS_HIST	Max speed warp under position mode	Pulse	10	0~30000
	Available or invalid of speed offset Position pulse warp > POS_COIN+POS_HIST, speed offset AV; Position pulse warp < POS_COIN, speed offset ADL;						
b19	23	0110H	Reserved	Reserved		0	-
b20		0111H	PDIR	Positon command logic switch		1H	0,1H
b21		0112H	PINH	Position reference input prohibited		0	0,1H
	BIT0: Reserved BIT1: Position command logic switch (PDIR) 0:when position add CW 1:CCW BIT2: Position reference input prohibited(PINH)						

	0: command pulse input AV(default) 1: prohibited, command pulse input ADL						
b22	24	0113H	GCC	Gain switch condistion selection		2H	00~55H
	XY X: Position loop(bit4~7 correspoinding Position loop) Y: Speed loop(bit0~3 correspoinding speed loop) 0: Gain switch function OFF 1: Gain switch function ON 2: Under position control mode,when position error less than the value of parameter b24 3: Under position control mode,when position pulse frequency less than the value of parameter b24 4: when the motor speed less than the value of parameter b52 5: when the motor speed warp less than the value of parameter b52						
b23	25	0114H	PGCT	Position loop gain switch time constant	ms	10	1~10000
	For position loop gain switch smooth						
b24	26	0115H	PGCV	Gain switch conditon	Pulse	000AH	1~FFFFH
	b24 finally determined by b22 selection						
b25	27	0200H	SP1	Internal speed 1		64H	C000H~4000H
b26	28	0201H	SP2	Internal speed 2		0F00H	C000H~4000H
b27	29	0202H	SP3	Internal speed 3		3E8H	C000H~4000H
	Set internal speed command value 4000H>3000RPM Speed selection via external input terminals, Speed selection 1 and 2 ,to selction internal AV WHEN FLG_SP=1~3						
b28	2A	0203H	DFLT	Speed default low pass filtering time constant	0.1m s	0	0~50000
	Speed command default low pass filtering time constant AV WHEN ACCEL_MODE=0						
b29	2B	0204H	FLT	Speed smooth low pass filtering time constant	1ms	10	1~50000
	Speed command smooth low pass filtering time constant Valid WHEN ACCEL_MODE=1						

							
b30	2C	0205H	LNR	Beeline speedup time	1ms	30	1~50000
0 to 3000rpm Beeline speedup time							
b31	2D	0206H	SLNR	S-curve speed up/down time constant	1ms	100	1~50000
S speed up/down time constant AV WHEN ACCEL_MODE=3							
b32	2E	0207H	KVD	Speed loop differential time constant	0.1ms	0	1~1000
Speed loop differential time constant, response faster;too big value arouse oscillating							
b33	2F	0208H	SV1	S yielding point speed 1		0555H	-16384~16384 (0C000H~4000H)
S yielding point speed 1 4000H~3000RPM AV WHEN ACCEL_MODE=3							
b34	30	0209H	SV2	S yielding point speed 2		3AABH	-16384~16384 (0C000H~4000H)
S yielding point speed 2 4000H~3000RPM AV WHEN ACCEL_MODE=3							
b35	31	020AH	ACEL_MOD	Acc/Dec mode		0	0~3
Acceleration/deceleration mode 0:Default 1:speed smooth up/down 2:Beeline speed up/down 3:S-curve speed up/down Use default under positon mode Use beeline speed up/down when JOG mode							

b36	32	020BH	KVP	Velocity loop proportional gain	%	60	10~3000
Set proportional speed loop proportional gain set value is bigger, response faster;too big value arouse oscillating Under the condition that system does not produce oscillating, set as big as possible Set according to concrete servo drive system and loads condition,							
b37	33	020CH	KVI	Velocity loop integral time constant	ms	33	1~1000
set value is lower, response faster;too low value arouse oscillating Under the condition that system does not produce oscillating, set as low as possible Default : when inertia is small:33ms, when inertia is big:100ms							
b38	34	020DH	ZSPD	Zero-speed RTS	—	54	0~3000
When motor speed < b38, output 0 speed signal 4000H~3000RPM							
b39	35	020EH	G_SPD	External speed command conversion ratio (10V conversion)		3121	100~30000
4000000H*(K/3000)/21504, K=100~30000<3000>[rpm/10V], (4000000H=4000h * 2^12) Speed corresponding with Analog voltage input 10V, setting the ratio.							
b40	36	020FH	SP_OFST	External speed command offset	mV	0	-9999~9999 (0D8F1H~270FH)
21504/10*K/1000 2. Set speed command offset voltage 3. Set value=Internal servo drive offset voltage 4. Speed command working voltage=speed command input voltage+offset voltage [e.g] speed command input voltage =1V speed command offset voltage =0.5V speed command working voltage =1.5V Offset minimum input unit =1mv Offset input range is +/-10V							
b41	37	0210H	ASPD	Speed coincidence RTS		4000H	0~4000H
When actual speed > b41, Speed coincidence signal output 4000H~3000RPM							
b42	38	0211H	KVPR	velocity loop gain switching ratio	%	100	10~1000
According to gain switch condition (24H) , to adjust velocity loop proportional gain fluctuation							
b43	39	0212H	KVPF	velocity loop feed forward gain	%	0	10~1000

	Set according to concrete servo drive system and loads condition, set value is bigger, response faster; too big value arouse oscillating																					
b44	3A	0213H	FLG_SP	Speed command selection mark	0	0~3																
	0: External analog/0 speed (When control mode=1, external analog; When control mode=4, 0 speed) 1: Internal speed 1 2: Internal speed 2 3: Internal speed 3 Note: When speed selection is included within external terminals, external input priority. Viz: speed selection is determined by external input terminal ON or OFF																					
B45	3B	0214H	FLGSTK	CW/CCW prohibited mark	0	0~3																
	0: invalid, 1: CW prohibited, 2: CCW prohibited, 3: CW and CCW prohibited(drive forbid) Note: When drive prohibiting is included within external terminals, external input priority. Viz: drive prohibiting is determined by external input terminal ON or OFF, as below: <table border="1"><tr><td>CCW terminal</td><td>CW terminal</td><td>selection</td></tr><tr><td>ON</td><td>ON</td><td>invalid</td></tr><tr><td>ON</td><td>OFF</td><td>CW prohibited</td></tr><tr><td>OFF</td><td>ON</td><td>CCW prohibited</td></tr><tr><td>OFF</td><td>OFF</td><td>CW and CCW prohibited</td></tr></table>							CCW terminal	CW terminal	selection	ON	ON	invalid	ON	OFF	CW prohibited	OFF	ON	CCW prohibited	OFF	OFF	CW and CCW prohibited
CCW terminal	CW terminal	selection																				
ON	ON	invalid																				
ON	OFF	CW prohibited																				
OFF	ON	CCW prohibited																				
OFF	OFF	CW and CCW prohibited																				
b46	3C	0215H	P_CTL	P/PI switch	0	0,1																
b47		0216H	ZCLAMP	Zero clamp	0	0,1																
b48		0217H	STK_OFF	CW/CCW prohibited invalid	0	0,1																
b49		0218H	DIR_CTL	Positive/negative rotation switch	1	0,1																
b50		0219H	reserved	Reserved	0	0,1																
	Bit0: P/PI switch (P_CTL) Velocity loop proportional / Proportional Integral control switch 0: Velocity loop is PI control(default) 1: Velocity loop is P control Bit1: Zero clamp(ZCLAMP) 0:Zero speed command output ADL 1:AV																					

	When bit1=1, and speed command value < zero speed set value, Force speed command is 0 Bit2: CW/CCW prohibited invalid (STK_OFF) 0:drive prohibiting DI AV 1:ADL When bit2=1, the drive prohibiting input terminals ADL. Bit3: Positive/negative rotation switch(DIR_CTL) Speed command (Internal,external) Facing the motor axis, rotation direction reference input symbol setting B0=0:Speed A/D positive CW, B0=1:CCW, Bit4: Reserved						
b51	3D	021AH	SGCT	Velocity gain switch time constant	ms	000AH	1~FFFFH
	Used for velocity loop gain switch smooth transition						
b52	3E	021BH	SGCV	Velocity gain switch condition		000AH	0~4000H
	b52 is determined by 24H selection 4000H~3000RPM						
b53	3F	0300H	TRQ_SW	Torque command selection		0	0,1
	External torque command input switch, 0: AD; 1:AV Under torque control mode, it must be set to 1. Under speed control mode, when it is 0, external input torque command ADL: When it set to 1, external input torque adds to actual torque command.						
b54	40	0301H	TFLT	Torque command input Filter time constant	ms	10	0~10000
	Torque command input smooth filter time constant						
b55	41	0302H	G_TRQ	External torque command Scaling(10V conversion)	—	1170	30~3000
	1800000H*(K/300)/21500, K=30~3000<300>[%/10V] 1170 input 10V, output torque is triple rated torque. Set conversion constant of torque command input voltage and output torque (Ratio to rated torque). At command voltage 10V, corresponding(output torque/rated torque) percentage to set this value [e.g.] At command voltage 10V, output torque=rated torque, input set value as 100. [Note] Output torque must be less than 300% rated torque.						
b56	42	0303H	TRQ_OFST	External torque command offset		0	-3000H~3000H (0D000~3000H)

	11000H à 100% rating torque. Set torque command offset voltage. Set value=Servo drive internal torque offset voltage Output torque working voltage=torque command input voltage + offset voltage [e.g] Torque command output voltage=1V Torque command offset voltage =0.5V Output torque working voltage =1.5V																																				
b57	43	0304H	TRQ_GSP	Volecity gain under torque mode	%	100	10~1000																														
	RAM 的 T_GSP=SPD_STD×T_GSP /100/2 <sup>4</sup> Speed limitation control proportional gain under torque mode																																				
b58	44	0305H	TRQ_SPLM	Internal speed limit value		2AAAH	0~4000H																														
	Internal speed limit value setting under torque mode. AV only under torque control mode 4000H à 3000RPM																																				
b59	45	0306H	TRQ1	Internal torque command 1		0	-3000H~3000H (0D000~3000H)																														
b60	46	0307H	TRQ2	Internal torque command 2		0	-3000H~3000H																														
b61	47	0308H	TRQ3	Internal torque command 3		0	-3000H~3000H																														
	Set internal torque command value Torque selection via external input terminals:1、Torque selection 2, to select intemal torque 1, internal torque 2, internal torque <table border="1" style="margin-left: auto; margin-right: auto;"> <tr> <th>Control mode</th> <th>Torque selection 2</th> <th>Torque selection 1</th> <th>Torque command</th> </tr> <tr> <td rowspan="4">0 (T)</td> <td>OFF</td> <td>OFF</td> <td>External analog</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>Internal torque 1</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>Internal torque 2</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>Internal torque 3</td> </tr> <tr> <td rowspan="4">3 (Ti)</td> <td>OFF</td> <td>OFF</td> <td>0</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>Internal torque 1</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>Internal torque 2</td> </tr> <tr> <td>ON</td> <td>ON</td> <td>Internal torque 3</td> </tr> </table> 3.1000H à 100% rated voltage							Control mode	Torque selection 2	Torque selection 1	Torque command	0 (T)	OFF	OFF	External analog	OFF	ON	Internal torque 1	ON	OFF	Internal torque 2	ON	ON	Internal torque 3	3 (Ti)	OFF	OFF	0	OFF	ON	Internal torque 1	ON	OFF	Internal torque 2	ON	ON	Internal torque 3
Control mode	Torque selection 2	Torque selection 1	Torque command																																		
0 (T)	OFF	OFF	External analog																																		
	OFF	ON	Internal torque 1																																		
	ON	OFF	Internal torque 2																																		
	ON	ON	Internal torque 3																																		
3 (Ti)	OFF	OFF	0																																		
	OFF	ON	Internal torque 1																																		
	ON	OFF	Internal torque 2																																		
	ON	ON	Internal torque 3																																		
b62	4A	0309H	FLG_T	Torque command selection		0	0, 1, 2, 3																														

	0: External analog/0 torque (when control mode=0, external analog: when control mode=3, 0 torque) 1: Internal torque command 1 2: Internal torque command 2 3: Internal torque command 3 Note: When torque selection is included within external terminals, external input priority. Viz:torqueselection is determined by external input terminal ON or OFF						
b63		030AH	TSPLM_F	Speed limit selection		0	0,1
b64	4B	030BH	T_DIR	Torque direction selection		0	0,1
	BIT0: Speed limit selection (TSPLM_F) 0 : Internal speed limit AV Speed limit value is 44H(TRQ_SPLM) set value 1 : External speed limit AV Speed limit value is external speed command analog input						
	BIT1: Torque direction switch (T_DIR) 0: Torque A/D positive CW 1: Torque A/D positive CCW Only valid to external analog torque command						
	BIT2: Reserved						
b65	4C	FFFFH	Reserved	Reserved	—	0FFFFH	
b66	4D	FFFFH	Reserved	Reserved	—	0FFFFH	

#### 6-4. High parameter (high group)

Series NO	E <sup>2</sup> address	RAM address	Parameter name	Function	Unit	Default	Range
H00	4E	0400H	CARRY_F	Control period		10	4, 7, 10, 15
	Control period set: 4: 4KHZ 7: 7KHZ 10: 10KHZ 15: 15KHZ						
H01	4F	0401H	TLM_PCCW	CCW internal torque limit		3000H	0~3000H
	Set servo motor CCW internal torque limit value. Parameter value is percentage of rated torque. [e.g] limit is twice rated torque,settings=2000H [Note] When the external and internal torque limit both AV, the lower value is available.						

	Max torque setting 1000H=rated torque						
H02	50	0402H	TLM_NCW	CW internal torque limit		0D000H (-3000H~0)	
	Set servo motor CW internal torque limit value. Parameter value is percentage of rated torque. [e.g] limit is twice rated torque,settings=-2000 (E000H) [Note] When the external and internal torque limit both AV, the higher value is available. Max torque setting 1000H=rated torque						
H03	51	0403H	BRK_TM	Brake order time		0 (-2000~+2000)	0F830~07D0H
	RAM value: BRK_TM=CARRY_F*BRK_TM Set the timen between brake signal and servo on or servo off. BRK_TM>0 时  BRK_TM<0 时  Timing fit between Brake and Drive RAM computing: BRK_TM=CTRL_F*BRK_TM_EP 2000.0~2000.0msec						
H04	53	0404H	EST_LVL	Electronic load protection	%	120	0~300
	Overload protection Setting value is percentage of rated current. When current> this value and last for some time, overload alarm will occur. Current higher, last time shorter. Twice current,10 second; triple current 5 second.						

H05	54	0405H	MON_MODE	Analog inspection output	—	1H	0~4H
	Analog output selection setting. XY:X:MON1,Y:MON2 output 0: Motor speed ( $\pm 10V$ /full-range speed) ; 1: Motor torque ( $\pm 10V$ / full-range speed) ; 2: Speed command ( $\pm 10V$ / full-range speed) ; 3: Torque command ( $\pm 10V$ / full-range torque) 4: Generatrix voltage (DC_V) Note: full-range speed set by 6FH full-range torque set by 70H full-range voltage set by 71H						
H06	55	0406H	RG_LVL	Regenerative resistor protection value	—	200	0~10000
	Set the value of Regenerative resistor protection. Set value = (resistor value $\times$ resistor power $\times$ 100/1332) Resistor value: ohm resister power: watt Using internal regenerative resistor,H06 default is 100 Using external regenerative resistor,setting value through caculation						
H07	56	0407H	JOG_SP	JOG speed		0	0C000~4000H (-16384~16384)
	Speed setting value when JOG run This value AV only when JOG run (1BH=1)						
H08	57	0408H	TRQ_FIL	Torque filtering time constant	0.1ms	0~1000	0~0
H09		0409H	Reserved				
	Current loop torque filtering time constant, setting to 0, low pass filter function OFF.						
H10	58	040AH	SPFB_FIL	Speed inspection filtering time constant	0.1ms	10	0~1000
H11		040BH	Reserved		—		
	Speed feedback low pass filtering time constant. set to 0, low pass filter function OFF.						
H12	59	040CH	ID	Drive ID ADD No	—	0	0~0FH
	The ID ADD No. when several servo drive communicate in RS485						
H13	5A	040DH	DLY_VAL	RS485 answering delay time		11	0~255
	RS485 set by Transmit and Receiving switch delay time						

H14	5B	040EH	DI2-DI1	Input terminal DI2,DI1 definition		0601H	0~FFFFH
H15	5C	040FH	DI4-DI3	Input terminal DI4,DI3 definition		0B0AH	0~FFFFH
H16	5D	0410H	DI6-DI5	Input terminal DI6,DI5 definition		0D0CH	0~FFFFH
H17	87	0411H	DI8-DI7	Input terminal DI8,DI7 definition		0208H	0~FFFFH
	Input function definition chart						
	Symbol	Value	Function instruction				
	P/PI	0H	ON:Velocity loop is proportional component,OFF: velocity loop is proportional integral component				
	SVON	1H	ON: servo enable				
	ALMRST	2H	Alarm reset				
	MODE	3H	Mode selection under dual mode, OPEN:MODE1;SHORT:MODE2				
	DIR_REV	4H	Motor reverse.				
	GAIN_CHG	5H	Gain switch				
	TRQLM	6H	Speed limit command selection under speed&position control mode. OPEN—Internal register (4FH,50H) , SHORT—External torque analog command				
	SPDLM	7H	Speed limit command selection , OPEN—Internal register ( 44H ) , SHORT—external speed analog command				
	EMG	8H	ON, motor urgent brake				
	SV_LOCK	9H	Motor lock, available for Pt,Pr, S, Sz				
	CWSTE	AH	CW prohibited fault				
	CCWSTE	BH	CCW prohibited fault				
	SP0	CH	Internal speed command selection				
	SP1	DH					
	DISPN	EH	ON,external pulse input ADL under positon mode.				
	ORG_ST	FH	ON, activate origin searching function				
	ORG_SW	10H	when origin searching, switch ORG_SW on, take this point as origin.				
	TC0	11H					
	TC1	12H	Internal torque command selection				
	JOGU	13H	JOGU on,motor inching, inching parameter is JOG_SP(56H)				
	JOGD	14H	JOGD on, motor inverse inching.				

	TLM	4H	Torque is confined, TLM switch on					
	ALM	5H	Alarm accur, ALM switch on					
	BRK	6H	Electromagnet brake on					
	HOME	7H	Origion regress					
	POSIN	8H	Under position control mode,when error pulse NO.< setting position range,POSIN switch on					
		9H	Reserved					
		AH	Reserved					
		BH	Reserved					
		CH	Reserved					
		DH	Reserved					
		EH	Reserved					
		FH	NC					
H21	61	0415H	ORG_EN	Origin activation mode selection	0	Bit0~3		
H22		0416H	ORG_DIR	Origin regression direction	0	Bit4~7		
H23		0417H	ORG_ZM	Origin regression phase Z pulse counting method	0	Bit8~11		
	Bit0~3: Activation mode selection ORG_EN 0:External I/O 1:Internal mode Bit4~7: Origin regression direction ORG_DIR 0:CW 1:CCW Bit8~11: Origin regression phase Z pulse counting method ORG_ZM 0: After slowdown switch on, servo motor decelerates to zero, then reverse to leave slowdown switch, phase Z pulse cuonting start. 1: After slowdown switch on, servo motor decelerates to zero, till leaving slowdown switch, phase Z pulse cuonting start.							
H24	62	0418H	ORG_SPH	Origin regression high speed	1555H	0~4000H (0~16384)		
	Origin regression high speed setting 4000H~3000rpm							
H25	63	0419H	ORG_SPL	Origin regression low speed	222H	0~4000H		
	Origin regression low speed setting							
H26	64	041AH	ORG_ZP	Z Phase pulse NO.	2	0~128		

	Z Phase pulse NO. After slowdown switch off,phase Z pulse NO. up to the value, offset start,the offset value defined by 65H,66H.							
H27	65	041BH	ORG_OFST_H	Origin offset high bits		0	7FFF~8000H (32767~32768)	
H28	66		ORG_OFST_L	Origin offset low bits		0	7FFF~8000H	
	$ORG\_OFST = ORG\_OFST\_H * 2^{16} + ORG\_OFST\_L$ , setting offset value, total 32 bits, formed by high 16 bits and low 16 bits.							
H29	67	041CH	NOTCH_Q	Notch attenuation quotient		0		
H30	68	041DH	NOTCH_FRE_Q	Notch frequency	Hz	0		
	Mechanical resonance frequency setting, close the function if the value is 0							
H31	6E	041EH	ORG_TIME	Origin regression Acc/Dec time constant	ms	10	2~10000	
	AV when origin regression							
H32	6F	041FH	G_MON_SPD	MON output speed Scaling		512		
	Setting when 10V corresponding with 6000rpm: $256/(4000H \times 2) \times 2^{16} = 512$ 4000H—3000rpm							
H33	70	0420H	G_MON_TRQ	MON output torque Scaling		1170		
	Setting when 10V corresponding with 3.5 times rated torque: $256/(1000H \times 3.5) \times 2^{16} = 1170512$							
H34	71	0421H	G_MON_V	MON output DC current Scaling		171		
	Setting when 10V corresponding with 600V: $(256 \times 400)/600 = 171$							
H35	52	0422H	TB_MD	Rotation table control mode		0		
	Bit0:Torque reducing when rotation table stop 0: Invalidable 1: Available							
H36	AA	0423H	TB_NUM	Rotation Table positions number		0	2~16	
	Setting rotation table positions number, the max value is 16							

	After setting, the drive should be restarted.						
H37	AB	0424H	TB_GRN	Rotation Table gear ratio numerator	0	1~5000	
B_GRN/TB_GRM: 1/50~50							
H38	AC	0425H	TB_GRM	Rotation Table gear ratio denominator	0	1~5000	
B_GRN/TB_GRM: 1/50~50							
H39	AD	0426H	TB_TM	Rotation table speed up/down time	10ms	0	0~10000
speed up/down time from 0—3000rpm							
H40	AE	0427H	BLAS	Devision control cleaance compansion	Pulse	0	8000~7FFFH (-32768~32767)
Unit is pulse NO. Positive: Positive direction compansation Negtive: Negtive direction compansation							
H41	AF	0428H	POSS_MD	Position reference control mode	0	0~8	
Internal position command control mode 0: INC increase position command 1: ABS absolute position command 2: Positive rotation devision 3: Negtive rotation devision 4: Toe index through the nearest path of rotation table 5: Absolute continious trigger arresting 6: Relative continious trigger arresting 7: Relative auto cycle arresting 8: Relative auto cycle arresting 1/5/7, Requires electronic gear ratio must be 1							
H42	B0	0429H	POS0_H	Position internal register 0	Pulse	0	7FFF~8000H (32767~-32768)
H43	B1		POS0_L	Position internal register 0	Pulse	0	7FFF~8000H
IN RAM POS0= POS0H*2^16+ POS0L Interal positon 0 position pulse NO. setting							
H44	B2	042AH	POS1_H	Position internal register 1	Pulse	0	7FFF~8000H

H45	B3		POS1_L	Position internal register 1	Pulse	0	7FFF~8000H
In RAM POS1= POS1H*2^16+ POS1L Interal positon 1 position pulse NO. setting							
H46	B4	042BH	POS2_H	Position internal register 2	Pulse	0	7FFF~8000H
H47	B5		POS2_L	Position internal register 2	Pulse	0	7FFF~8000H
In RAM POS2= POS2H*2^16+ POS2L Interal positon 2 position pulse NO. setting							
H48	B6	042CH	POS3_H	Position internal register 3	Pulse	0	7FFF~8000H
H49	B7		POS3_L	Position internal register 3	Pulse	0	7FFF~8000H
In RAM POS3= POS3H*2^16+ POS3L Interal positon 3 position pulse NO. setting							
H50	B8	042DH	POS4_H	Position internal register 4	Pulse	0	7FFF~8000H
H51	B9		POS4_L	Position internal register 4	Pulse	0	7FFF~8000H
In RAM POS4= POS4H*2^16+ POS4L Interal positon 4 position pulse NO. setting							
H52	BA	042EH	POS5_H	Position internal register 5	Pulse	0	7FFF~8000H
H53	BB		POS5_L	Position internal register 5	Pulse	0	7FFF~8000H
RAM 中 POS5= POS5H*2^16+ POS5L Interal positon 5 position pulse NO. setting							
H54	BC	042FH	POS6_H	Position internal register 6	Pulse	0	7FFF~8000H
H55	BD		POS6_L	Position internal register 6	Pulse	0	7FFF~8000H
IN RAM POS6= POS6H*2^16+ POS6L Interal positon 6 position pulse NO. setting							

H56	BE	0430H	POS7_H	Position internal register 7	Pulse	0	7FFF~8000H
H57	BF		POS7_L	Position internal register7	Pulse	0	7FFF~8000H
IN RAM POS7= POS7H*2^16+ POS7L internal positon 7 position pulse NO. setting							
H58	C0	0431H	POSV0	Position internal register 0 moving speed	RPM	0	0~4000H (0~16384)
Internal positon 0 moving speed setting							
H59	C1	0432H	POSV1	Position internal register 1 moving speed	RPM	0	0~4000H
Internal positon 1 moving speed setting							
H60	C2	0433H	POSV2	Position internal register 2 moving speed	RPM	0	0~4000H
Internal positon 2 moving speed setting							
H61	C3	0434H	POSV3	Position internal register 3 moving speed	RPM	0	0~4000H
Internal positon 3 moving speed setting							
H62	C4	0435H	POSV4	Position internal register 4 moving speed	RPM	0	0~4000H
Internal positon 4 moving speed setting							
H63	C5	0436H	POSV5	Position internal register 5 moving speed	RPM	0	0~4000H
Internal positon 5 moving speed setting							
H64	C6	0437H	POSV6	Position internal register 6 moving speed	RPM	0	0~4000H
Internal positon 6 moving speed setting							
H65	C7	0438H	POSV7	Position internal register 7 moving speed	RPM	0	0~4000H
Internal positon 7 moving speed setting							
H66	C8	0439H	POST0	Position internal register 0 stop latency time	0.1s	0	0~7530H (0~30000)
Internal 0 latency time setting under auto cyclic fixed channel assignment mode							
H67	C9	043AH	POST1	Position internal register 1 stop latency time	0.1s	0	0~7530H
Internal 1 latency time setting under auto cyclic fixed channel assignment mode							

H68	CA	043BH	POST2	Position internal register 2 stop latency time	0.1s	0	0~7530H
Internal 2 latency time setting under auto cyclic fixed channel assignment mode							
H69	CB	043CH	POST3	Position internal register 3 stop latency time	0.1s	0	0~7530H
Internal 3 latency time setting under auto cyclic fixed channel assignment mode							
H70	CC	043DH	POST4	Position internal register 4 stop latency time	0.1s	0	0~7530H
Internal 4 latency time setting under auto cyclic fixed channel assignment mode							
H71	CD	043EH	POST5	Position internal register 5 stop latency time	0.1s	0	0~7350H
Internal 5 latency time setting under auto cyclic fixed channel assignment mode							
H72	CE	043FH	POST6	Position internal register 6 stop latency time	0.1s	0	0~7530H
Internal 6 latency time setting under auto cyclic fixed channel assignment mode							
H73	CF	0440H	POST7	Position internal register 7 stop latency time	0.1s	0	0~7530H
Internal 7 latency time setting under auto cyclic fixed channel assignment mode							
H74	0441H	JOG_FLG	JOG mark			0	0,1
JOG run, H74=1							
H75	0442H	RM_SVON	Remote servo enable mark			0	0,1
On condition of SVON_CH (D6H) =1, IF H75=1, Servo enable							
H76	0443H	RM_ALM_RS T	Remote servo alarm clearance mark			0	0,1
On condition of servo NO enable, if H76=1, reposition will clear alarm. (alarms besides CPU fault/RAM fault /EEP fault /CW/CCW prohibited fault/coder fault)							

## **6-5. System parameter (sys group)**

	BIT7: Torque limit selection (EX_TCLM_FLG)						
	Torque limit selection under position,speed mode						
	0: Internal torque limit (TLM_P,TLM_N AV )						
	1: External torque limit(Torque command AV)						
y08	81	044CH	PHE_EN	Phase loss inspection		0	0,1
y09		044DH	LV_EN	Under voltage inspection		0	0,1
y10		044EH	ENC_EN	Coder inspection		0	0,1
y11		044FH	AHOT_EN	Drive overhot inspection		0	0,1
y12		0450H	MHOT_EN	Motor overhot inspection		0	0,1
	BIT4: Phase loss inspection (PHE_EN)						
	0: ADL 1: AV						
	BIT5 :Low voltage inspection (LV_EN)						
	0: ADL 1: AV						
	BIT6 :Coder inspection (ENC_EN)						
	0: ADL 1: AV						
	BIT7 :Drive overhot inspection (AHOT_EN)						
	0: ADL 1: AV						
	BIT8 :Motor overhot inspection (MHOT_EN)						
	0: ADL 1: AV						
y13	97	0451H	G_CUR	Current scaling coefficient		906	128~1FFFF
	Y13=256*Module current crest value /Motor rated current/1.414)						
y14	9F	0452H	ENC_PPR	Motor pulse NO. per rotation		2500	0~10000
	Motor coder resolution/prm						
y15	E6	0453H	MOTOR_POL_E	Motor poles	Pole	8	6,8,14
	Set motor poles						
y16	7F	0454H	ENC_TYPE	Encoder type		3	0~3
	0:DART LINE INC, 2:ABS, 3:Standard INC						
y17	D6	0455H	SVON_CH	Internal servo enable setting		0	0,1
	0: DI trigger servo enable						
	1: Servo enable can be set internally						
y18	8E	0456H	E_ANG_OFST	Electric angle offset		-123	-200~200H
	E_ANG_OFST =(Offset angle between phase Z and phase U /360)*2048;						
							0~7FFF

y19	8F	0457H	MAX_SPD	A/D speed input LIMIT	Speed	2BBCH	
	4000H~3000rpm						
	SPD_REF limit value						
y20	-	0458H	JOG_FLG_IN	Inching direction mark	-		0,1,2
	0:Stop	1:CCW	2:CW				
y21		0505H	SPD_ADTEST	speed command analog input read			-
	Used for speed command analog linear adjustment						
y22		0506H	TRQ_ADTEST	Torque command analog input read			-
	Used for torque command analog linear adjustment						
y23	F5	0507H	SPD_B_OFST	Analog CH A2 OFFSET updating		F800	
	Used for speed command analog linear adjustment						
y24	F6	0508H	SPD_S_OFST	Analog CH B2 OFFSET updating		FA00	
	Used for speed command analog linear adjustment						
y25	EF	0509H	G_SPD_B	Analog CH A2 OFFSET updating		0B06	
	Used for speed command analog linear adjustment						
y26	F0	050AH	G_SPD_S	Analog CH B2 OFFSET updating		02C2	
	Used for speed command analog linear adjustment						
y27	F1	050BH	G_T	Analog CH A3 OFFSET updating		0B06	
	Used for torque command analog linear adjustment						
y28	F7	050CH	T_OFST	Analog CH A3 OFFSET updating		F800	
	Used for torque command analog linear adjustment						
y29	FB	050DH	MON1_OFST	Analog output CH \OFFSET updating		0100	

## 6-6. User parameters (User group)

Series NO	Parameter name	Function		Default	Upper limit	Lower limit
U0 0	board->key	0	Ignore	0	1	0
		1	Controller EEPROM Data Store to keyboard EEPROM			
U0	key->board	0	Ignore	0	1	0

1		1	Keyboard EEPROM Data store to controller EEPROM			
U0 2	Reset->factor y	0	Ignore	0	1	0
		1	Reset			
U0 3	Authority set ( Parameter group mask )	0bit	1: Mask Status group	0	03FH	0
		1bit	1: Mask Fault group			
		2bit	1: Mask Basic group			
		3bit	1: Mask High group			
		4bit	1: Mask Sys group			
		5bit	1: Mask Monitor group			
U0 4	PASSWORD (User's password)	Set correct password, parameter remind is available			0FFF FH	0FFF FH 0

## 6-7. EEPROM Parameter (super group)

Series NO.	E <sup>2</sup> address	RAM address	Parameter name	Function	Range
5-00		0500H	EEP_COM	EEPROM operation commands	0~2
			0 : Operation possible status		
			1 : Write operation		
			2 : Read operation		
5-01		0501H	EEP_WR_AD	Write operation EEPROM address	
			Used for EEPROM write.		
5-02		0502H	EEP_WR_DATA	Write Date	
			Used for EEPROM write		
5-03		0503H	EEP_RD_ADDRESS	Read operation EEPROM address	
			Used for EEPROM read		
5-04		0504H	EEP_RD_DAT	Read data	
			Used for EEPROM read		


## Chapter 7 Communication Function

### 7-1 Introduction of communication hardware RS-485、RS-232、RS-422.

This servo drive has three modes of communication :RS-485、RS-232、RS-422. All aspects of control, operation and monitoring as well as programming of the controller can be achieved via communication. However, only one communication mode can be used at a time. The method of cable connection is as following:

#### 7-1-1 RS-232

Configuration




PC DB-9 Socket

1 CD
2 RXD
3 TXD
4 DTR
5 GND
6 DSR
7 RTS
8 CTS
9 RI

3 RS232_TX
4 RS232_RX
1 GND
2 GND

#### 7-1-2 RS-422/RS485

Configuration



Cable Connection

## 7-2 Communication protocol

### 1. Intention:

By using of this communication protocol software, epigynous computer can monitor servor status, change, load and save servor interior parameters.

### 2. Working condition:

Hardware: Epigynous computer,digital servor and connecting cable (RS232).

Operating system: Superior than WINDOWS95.

### 3. Communication format:

#### (1) Communication condition:

- ① Speed: 9600bps
- ② Parity inspection: NO
- ③ Data lenght: 8bit
- ④ Stop bit: 1bit

All datas will divided into “4bit”fragment, and each one will transform to character (ASCII CODE) and transmit.

All appointed addresses in transmission are “RAM” address.

#### (2) Requestment sent to driver:

##### ① The read of integer variables(7byte)

“R”+Pages of variables(H)+ page layout of variables(L)+ deviation of variables

Deviation of variables(H)+ deviation of variables(L)+

inspect(H)+inspect(L)

##### ② Input of integer variables(11byte)

“W”+page of variables(H)+ page of variables(L)+ deviation of variables(H)+ deviation of variables(L)+data(HH)+data(HL)+data(LH)+  
data(LL)+inspect(H)+inspect(L)

##### ③ Input of long integer variables( 7byte)

“X”+page of variables(H)+ page of variables(L)+ deviation of variables(H)+ deviation of variables(L)+inspect(H)+inspect(L)

##### ④ Input of long integer variables(13byte)

“Y”+page of variables(H)+ page of variables(L)+ deviation of variables(H)+ deviation of variables(L)+data(HHH)+data(HHL)+data(LHH)+ data(LHL) +data(LLH)+  
+data(LLL)+inspect(H)+inspect(L)

### (3) Return of drive

① Return of integer variables read request.  
“%”+data(HH)+data(HL)+data(LH)+  
data(LL)+inspect(H)+inspect(L)

① Return of long integer variables read request(9byte).  
j°%j±+data(HH)+data(HL)+data(LH)+ data(LL)+inspect(H)+inspect(L)

③ Return of input request(1byte)  
“%”——ACK  
“!”——NACK

### (4) Inspect data

All characters’ (ASCII CODE) sum and low 8bit.


Example: page of variables=01H, deviation of variables=00H,format of reading this variables is as following:

R010013

Among the aftermost bit binary digit 13= (52H+30H+31H+30H+30H) low 8bit

## **7-3 Communication operation**


## 1、Communication software of operating A&D servo drive




2、Setup communication parameter, to setup baud rate and communication port according to different computer.



3、Click ADSD-S in the main menu of the communication software after the communication display is well, and conduct read-out and write-in of RAM and EEPROM directly. The specific address of RAM and EEPROM should be referred to detailed specification.



4、The related parameters also can be read and put in direct through parameter page, but the parameters of EEPROM just will be valid after power off.



5、Servo can be leaded in recorded parameter by “lead-in record”. All parameters also can be kept in servo-drive by “keeping record”.

## **Chapter 8 Maintenance and Inspection**

## **8-1 Basic Inspection**

Item	Content of inspection
General Inspection	Periodically inspect the screws of the servo drive, motor shaft, terminal block and the connection to mechanical system. Tighten screws as necessary as they may loosen due to vibration and varying temperatures.
	Ensure that oil, water, metallic particles or any foreign objects do not fall inside the servo drive, motor, control panel or ventilation slots and holes. As these will cause damage.
	Ensure the correct installation and the control panel. It should be free from airborne dust, harmful gases or liquids.
	Ensure that all wiring instructions and recommendations are followed; otherwise damage to the drive and/or motor may result.
Inspection before operation ( Control power is not applied)	To avoid an electric shock, be sure to connect the ground terminal of servo drive to the ground terminal of control panel.
	Before making any connection, wait 10 minutes for capacitors to discharge after the power is disconnected, alternatively, use an appropriate discharge device to discharge.
	Ensure that all wiring terminals are correctly insulated.
	Ensure that all wiring is correct or damage and/or malfunction may result.
	Visually check to ensure that there are not any unused screws, metal strips, or any conductive or inflammable materials inside the drive.
	Make sure control switch is OFF.
	Servo controller and exterior brake resistant can't be installed on combustible object.
	To avoid electromagnetic brake invalid, please check the circuit of immediately stop and cutting off power.
	When electronic equipments are being interfered around servo-controller, Please use other equipment to abate this interference.
Inspection before working	Ensure that detector cable is not over tension. When servo motor is working, Please take caution to avoid attrition between cable and machine member.
	If the servo motor has phenomenon of vibration and big noise, please contact to

( Control power is applied)	manufacturer.
	Confirming all parameters are proper set, difference of mechanical features will lead to unpredictable motion. Do not excessively adjust parameters.
	Resetting parameter should be done under controller status of ( SERVO OFF) . Otherwise which will be reason of fault.
	If there is an abnormal voice or not voice of touching when relay acts, please contact manufacturer directly.
	Whether there is abnormal phenomenon of power indicator-light and LED.

## 8-2 Maintenance

- ◇ Use and store the product in a proper and normal environment.
- ◇ Periodically clean the surface and panel of servo drive and motor.
- ◇ Do not disassemble or damage any mechanical part when performing maintenance.
- ◇ Clean off any dust and dirt with a vacuum cleaner. Place special emphasis on cleaning the ventilation ports and PCBs. Always keep these areas clean, as accumulation of dust and dirt can cause unforeseen failures.

## 8-3 Lifespan of Replacement Components

### Smooth capacitor

- ◇ The characteristics of smooth capacitor would be deteriorated by ripple current affection. The life of smooth capacitor varies according to ambient temperature and operating conditions. The common guaranteed life of smooth capacitor is ten years when it is properly used in normal air-conditioned environment.

### Relay

- ◇ The contacts will wear and result in malfunction due to switching current. The life of relay varies according to power supply capacity. Therefore, the common guaranteed life of relay is cumulative 100,000 times of power on and power off.

### Cooling fan

- ◇ The cooling fan life is limited and should be changed periodically. The cooling fan will reach the end of its life in 2~3 years when it is in continuous operation. However, it also must be replaced if the cooling fan is vibrating or there are unusual noises.

## Chapter 9 Troubleshooting

### 9-1 Fault Messages Table

Parameter No.	Fault Code	Fault Name	Fault Description
A01	0001	CPU error	CPU is in error
	0002	RAM error	RAM write-in and read-out is in error
	0004	EEP error	EEPROM write-in and read-out is in error
	0008	CW/CCW prohibited fault	The forward and reverse drive forbidden switches are in error.
	0010	Encoder error	Pulse signal is in error.
	0020	Overcurrent	Main circuit current is higher than 1.5 multiple of motor's instantaneous maximum current value.
	0040	Overload	Servo motor and drive is overload.
	0080	Undervoltage	Main circuit voltage is below its minimum specified value.
	0100	Ovvoltage	Main circuit voltage has exceeded its maximum allowable value.
	0200	Regeneration error	Regeneration control operation is in error.
	0400	IPM error	IPM hardware is in error.
	0800	Overspeed	Motor's control speed exceeds the limit of normal speed.
	1000	Emergency stop	Emergency stop switch is activated.
	2000	Excessive deviation	Position control deviation value exceeds the limit of its allowable setting value.
	4000	Motor overheat	The drive detected the motor temperature exceeded its allowable value.
	8000	Drive overheat	IGBT temperature is overheated.
A02	0001	Input power phase loss	The main circuit lacks of phase.

	0002	Dynamic braking relay error	Dynamic braking relay is in error.
	0004	CW limitation alarm	Forward limit switch is activated.
	0008	CW limitation alarm	Reverse limit switch is activated.
	0010	Communication abnormal	Communication is in error.

## 9-2 Potential Cause and Corrective Actions

Fault Name	Potential Cause	Corrective Actions
CPU error	The CPU of the driver is in error.	Please contact your distributor or manufacturer for service.
RAM/EEPROM error	The drive is error during parameter read-out and write-in.	Reset the parameter in the guidance of technicians, if the error is still unclear, please contact your distributor or manufacturer for service.
CW/CCW prohibited fault	1. The parameter setting of the forward and reverse drive forbidden error	1. Correctly set the parameter.
	2. When the forward and reverse forbidden switch is set, the switch is in error.	2. Check the location of drive and switch and if the wiring of the switch is correct, if there's broken wire for the normally closed switch.
Encoder error	1、The wiring of encoder is in error.	1、Ensure all wiring is correct.
	2、Encoder connector is loose.	2、Restall the connector.
	3、The wiring of encoder is defective.	3、Conduct the wiring again.
	4、Encoder is damage.	4、Change the motor.
Overcurrent	Short-circuit at drive output.	Check the wiring connections between drive and motor and check if the drive is short-circuited, if so, repair it.
	Motor wiring error	Follow the standard wiring steps to reconnect wiring.
	Main circuit drive power tube IGBT error	Please contact your distributor or manufacturer for service.
	Parameter setting error	Adjust the parameter setting again.
Overload	The drive has exceeded its rated load.	Reduce load or change the drive with higher capacity.

		capacity
	Control system parameter setting is incorrect	Adjust gain value, increase Accel/Decel time or decrease inner torque limit.
	The wiring of drive and encoder is in error	Adjust the wiring of U\V\W or encoder.
	The motor encoder is damaged.	Please contact your distributor or manufacturer for service.
Undervoltage	Main circuit voltage is below its minimum specified value.	Check whether the wiring of main circuit is correct and if the input voltage is low, if so, rejust.
	Power input error (incorrect power system)	Use correct power supply.
Overvoltage	The main circuit voltage has exceeded its maximum allowable value.	Use correct power supply.
	Drive hardware error	Please contact your distributor or manufacturer for service.
Regeneration error	Regenerative resistor is not connected or low.	For inner regenerative resistor, check if short circuit occurs between RB and RB2 terminator. For external regenerative resistor, check if there's resistor between RB and RB1, and if the resistance is correct.
	Regenerative switch transistor fault	Please contact your distributor or manufacturer for service.
	The control parameter setting of the drive is incorrect.	Change the parameter.
IPM error	Motor wiring error	Check if the phase-sequence of U\V\W is correct.
	Hardware damage	Please contact your distributor or manufacturer for service.
	Y13 (current coefficient) of system parameter setting error	Change the parameter.
	The maximum torque current exceeds IGBT capacity.	Change the inner torque current limit parameter.
Overspeed	Speed input command exceeds the limit of the drive	Change the speed command.

	The permissible value of the drive is too small.	Change the parameter.
	Electronic gear ratio setting is too high.	Correctly set the electronic gear ratio and change the parameter.
Emergency stop	Check if the emergency stop switch is on.	Release the emergency stop button when there's no error.
	The wiring of the emergency stop is in error.	Change the wiring, reconnect the wire if there's broken wire.
	Parameter setting is in error, and the emergency stop input port setting is incorrect.	Change the parameter.
Excessive deviation	The forward and reverse maximum deviation no. setting of the basic parameter is too small.	Change the parameter.
	The system gain value is too small.	Correctly adjust gain value.
	Encoder cable connection error	Reconnect encoder cable.
	External load is too high.	Check the external load condition or reassess the motor capacity.
	Control parameter setting of the controller is incorrect, and the motor can't work normally.	Change the parameters.
	The motor capacity is too small and can't work in overload condition for long time.	Change a appropriate motor.
Drive overheat	Ventilation of the drive is poor, and the temperature is too high.	Improve the ventilation.
	Hardware error	Please contact your distributor or manufacturer for service.
Input power phase loss	Input power supply of main circuit lacks of phase.	Check if the wiring is correct or loose, and if the power supply lack of phase, if not, the drive hardware may be in error, contact your distributor or manufacturer for service.
Dynamic braking relay error	Dynamic breaking relay is in error.	Please contact your distributor or manufacturer for service.
CW limitation	The motor mechanism reaches the	Remove the mechanism and reset, and get rid of

alarm	forward limit switch postion.	alarm.
	The wiring of the forward limit switch is incorrect or loose.	Reconnect again.
	The parameter setting of the limit switch is in error.	Change the parameter.
CCW limitation alarm	The motor mechanism reaches the forward limit switch postion.	Remove the mechanism and reset, and get rid of alarm.
	The wiring of the forward limit switch is incorrect or loose.	Reconnect again.
	The parameter setting of the limit switch is in error.	Change the parameter.
Communication error	Communication wire error	Confirm the wiring is in good condition and correct.
	Communication parameter setting error	Confirm the communication parameter setting is correct.

**Chapter 10 Specifications****10-1 Specifications of Servo Drive**

Items		Specifications	
Power supply	Voltage/frequency range	Single-phase 220V, 50/60HZ	Three-phase 220V, 50/60HZ
	Permissible fluctuation	Voltage: ±15%	Frequency: ±5%
Control System		Based on 32 byte great performance controller of vector	
Output frequency		0.00~450.00Hz, The highest frequency can be set among 10.00~450.00Hz at random.	
control mode	The highest speed of vector control	Output frequency	2 poles 18000 r/min
		4 poles	9000 r/min
		300Hz as example	6 poles 6000 r/min
	Methods of control	Mode of position-control, Mode of speed-control, Mode of torque-control	
		Position/speed compounded mode , position/torque compounded mode, torque/speed compounded mode	
		Mode of set by user.	
	Torque control	Precision of torque	±5% rated torque
		Amplitude limiting of torque	0~300% set rated torque at random
		Limit of torque	Methods of parameter set or analog input
	range of speed-control	1: 5000 above	
	Postion-control	Highest precision	±1pulse
		The highest frequency of input pulse	500KPPS
		Range of position-control	0~ $2^{31}$ given pulse

		Input mode	Double phases A/B orthogonal pulse , pulse + direction , double pulses of forward and reverse
		Electronic gear wheel	1/50~50
		Control of acceleration and deceleration	beeline, smoothing filtering, acceleration and deceleration of S curve.
		Resolution of speed set	0.1RPM
		Overload capacity	300% rated current-5 seconds.
Operation	Output signal	Methods of operation	keyboard/terminals/methods of communication
		Setup of speed	Methods of speed-setup:keyboard , simulation , communication
		Input of programmable digital quantity.	Multifunctional input,such as servo start,abnormal reset.Support source/drain electrode, Total 8 ports.
		Input of programmable digital quantity.	Output of servo start-preparation,start,etc. Total:8 ports.
			Output of A,B,Z lines drive.
	Input signal	Input of programmable analog quantity	Double input ports of analog signal, and be equally to input of speed,torque,position.
		Output of programmable analog quantity	Double output ports of analog signal with voltage or current mode.
		Input of digital quantity.	Control-logic of high-speed multifunctional digital quantity-input.
		Working status	Servo motor shows status that is stop,speed up or down,uniform-speed,program running.
		Output of fault	Touch spot output-AC 250V 5A, DC 30V 5A
Protection	Output of analog signal	Output of analog signal	Output of frequency/current/voltmeter
		output of digital quantity.	There are 6 channels for signal output, and each channel has 32 kinds of signal for choosing.
	DC current braking		External braking resistor can provide enough torque on the condition of not over current.
	Protection of controller		Over voltage , less voltage,over current,over load,over heat,over speed,less phase,outside fault,fault of communication,abnormal PID feedback signal,PG fault.

	Protection of parameters		Through set administer's password or decode to protect parameters.			
Display	LCD Chinese -english display + LED keyboard	Operatio n message	There are total 16 objections of operation: set frequency,actual frequency,motor actual current,actual current percentage,DC Bus voltage,motor actual speed,total ruuning time,IGBT temperature,torque heft set value,torque heft actual value.			
	fault message		The memory capacity is 10 fault messages, which can be checked when fault occur.			
Communication	RS485		Isolated RS485 communication mode can be chose to realize connection with upper computer.			
	CAN BUS		Optional Bus mode			
Environment	Environment temperature	-10°C - 40°C				
	Memory temperature	-20°C - 65°C				
	Environment humidity	At most 90% RH .				
	Height·vibration	Below 1, 000m, and 5.9m/S <sup>2</sup> (=0.6g)				
	Place of application	No sunlight,corrosive and explosive gas and moisture				
	Cooling mode	Fan cooling and natural circulation cooling.				

## 10-2 Specification of ADSM Servo Motor

Standard specification of 110 series motor

Motor model	110-020M30	110-020M30	110-050M30	110-060M20	110-060M30
Power (KW)	0.6	1.2	1.5	1.2	1.6
Rated torque (N.m)	2	4	5	6	6
Rated RPM (Rpm)	3000	3000	3000	2000	3000
Rated current (A)	4.0	6.0	7.0	6.0	8.5
Rotor inertia Kgm <sup>2</sup> )	0.33×10 <sup>-3</sup>	0.828×10 <sup>-3</sup>	0.915×10 <sup>-3</sup>	1.0×10 <sup>-3</sup>	1.111×10 <sup>-3</sup>
mechanical time constant (ms)	3.64	3.46	4.8	1.82	1.864
Encoder line	2500 (A、B、Z、U、V、W)				

number (C/T)						
Motor insulation class	B					
Operational environment	Environment temperature: 0~55°C Humidity: at most 90% (non condensing)					
Protection class	IP65					
Motor weight (Kg)	4.2	6	5.8	6.4	6.4	6.4

Standard specification of 130 series motor

Motor model	130-040M25	130-050M20	130-050M2	130-060M2	130-077M20	130-077M2
Power (KW)	1.0	1.0	1.3	1.5	1.6	2.0
Rated torque (N.m)	4	5	5	6	7.7	7.7
Rated RPM (Rpm)	2500	2000	2500	2500	2000	2500
Rated current(A)	5.0	5.5	6.0	7.0	6.5	8.5
Rotor inertia Kgm <sup>2</sup> )	1.101×10 <sup>-3</sup>	1.333×10 <sup>-3</sup>	1.333×10 <sup>-3</sup>	1.544×10 <sup>-3</sup>	2.017×10 <sup>-3</sup>	2.017×10 <sup>-3</sup>
mechanical time constant(Ms)	5.042	4.186	3.677	3.122	2.34	2.624
Encoder line number (C/T)	2500 (A、B、Z、U、V、W)					
Motor insulation class	B					
Operational environment	Environmental temperature: 0~55°C Humidity: at most 90% (non condensing)					
Protection class	IP65					
Motor weight (Kg)	6.1	6.9	7.0	7.6	8.8	8.8
Motor model	130-077M30	130-100M15	130-100M2	130-150M15	130-150M25	
Power (KW)	2.4	1.5	2.6	2.3	3.8	
Rated torque (N.m)	7.7	10	10	15	15	

Rated RPM (Rpm)	3000	1500	2500	1500	2500
Rated current(A)	10.5	6.5	11.5	9.5	16.5
Rotor inertia $\text{Kgm}^2$ )	$2.017 \times 10^{-3}$	$2.595 \times 10^{-3}$	$2.595 \times 10^{-3}$	$3.24 \times 10^{-3}$	$6.15 \times 10^{-3}$
mechanical time constant(Ms)	2.353	2.162	1.903	1.88	2.59
Encoder line number (C/T)	2500 (A、B、Z、U、V、W)				
Motor insulation class	B				
Operational environment	Environmental temperature: 0~55°C Humidity: at most 90% (non condensing)				
Protection class	IP65				
Motor weight (Kg)	8.8	10.6	10.6	14.3	15.35

$\text{Kgm}^2)$				
mechanical time constant(Ms)	2.43	2.27	2.04	1.932

## Standard specification of 150 series motor

Motor model	150-150M2 5	150-180M2 0	150-230M 20	150-270M 20
Power (KW)	3.8	3.6	4.7	5.5
Rated torque (N.m)	15	18	23	27
Rated RPM (Rpm)	2500	2000	2000	2000
Rated current(A)	16.5	16.5	20.5	26
Rotor inertia	$5.2 \times 10^{-3}$	$6.3 \times 10^{-3}$	$8.0 \times 10^{-3}$	$11.19 \times 10^{-3}$

## Chapter 11 Application examples

It can be widely used in manufacturing equipment of machine tool, printing, textile, plastic, paper, wind energy area that the synchro servo drive produced by Dalian A&D digital operation.

The following is the specification of its main function.

### 11-1 Internal position register control (including origin regression function)

The internal position register function of ADSD-S drive can let it be used as isolated controller, and no need control of NC system and PLC. There are 8 group position registers in drive. When the control motion is not complex and alternation is not frequent, the internal position register control mode can be used to set corresponding order of position and speed, as well as delayed time of two positions.

When using internal position register control function,because the motor encoder is incremental model, so in order to promise consistency and precision of processing,every time homing operation is needed when the drive restarts.Specific operation is as following:

#### 1、 Confirm the definition of I/O interface.


- DI1:Servo-on (SVON)
- DI2:Internal position register trigger (ATRIG)
- DI3: Selection of internal position register order (PS0)
- DI3: Selection of internal position register order (PS1)
- DI5: The prohibitive extreme limit of reverse (CWSTE)
- DI5: The prohibitive extreme limit of forward (CWSTE)
- DI7: Starting signal of activating homing function (ORG\_ST)
- DI8: Slowdown switch of homing function (ORG\_SW)
- DO1: Output signal of servo on (SON)
- DO2: Finish signal of homing function (HOME)
- DO5: Alarm output signal (ALM)

#### 2、 parameters setting

- B01=6 (Internal position register control model Pi setting)
- H14=1901 (DI2:ATRIG, DI1:SVON)
- H15=1C1B (DI4:PS1,DI3:PS0)
- H16=0B0A (DI6:CCWSTE,DI5:CWSTE)
- H17=100F (DI8:ORG\_SW,DI7:ORG\_ST)
- H18=0701(DO2:HOME ,DO1:SON)
- H19=0000

- H20=0005 (DO5:ALM)
- H21=0 (The mode of homing is I/O activating mode)
- H22=0 (The homing direction is forward)
- H23=0 (The confirming method of Z-phase pulse is to press slowdown switch -ORG\_SW and when the motor reverse runs and pulled off switch,the Z-phase will count)
- H24=1555H (The high-speed of homing is 1000rpm)
- H25=444H (The low-speed of homing is 200rpm)
- H26=1 (the No. of Z-phase pulse in homing is 1, namely after pulling off speed reducing switch ,the system find NO.1 Z-phase pulse and regards it as homing point )
- H27/H28=0 (There is no homing deviation after finding homing point )
- H41=1 (absolute positioning order)
- H42~H49 Set internal register position order
- H58~H61 Set corresponding speed of internal position order
- Other motor parameters such as gain of position,speed will be set according to mechanical running condition.

#### 3、 Timing diagram of origin regression action



#### 4、 Operation

Under the correct wiring and parameters setting

- 1) First let SVON=1 (DI1) ,
- 2) Doing origin regression operation and then choose origin regression mode ORG\_ST=1(DI7).The motor will start forward running with high speed from origin according to parameter setting. When motor meets ORG\_SW(speed reducing switch),it will decelerate and reverse running with low speed from origin until the speed reducing switch falling off, the system will check Z-phase pulse, lastly the motor will stop when checked Z-phase pulse.
- 3) According to processing demand to choose respectively corresponding 0~internal position register under PS1 and PS0 status,3, Put down order

trigger (ATRIG-DI2), motor will run according to position and speed order.

**Remark: The origin homing operation just needs to be done one time when everytime power on.**

## 11-2 Rotation table control

ADSD-S drive has inside toe index function, which can replace tool control function. As the more and more precise demand of digital control machine tool, the servo tool has gradually replaced electrical and hydraulic tool. ADSD servo drive can be conveniently matched with machine tool and without extra servo tool controller. In addition, the function can be widely used in Rotation table control and other Rotation equipments.

The following is the specification of servo tool turret control.

We assume that the turret has 8 positions, there are shortest path for turret switching and the deceleration rate is 2:1 (The motor runs 2 circles 720 degrees, the turret will run 1 circle 360 degrees)

### 1、 Confirm the definition of I/O interface.

DI1: DI1: Servo-on (SVON)

DI2: Choose turret position TB0

DI3: Choose turret position TB1

DI4: Choose turret position TB2

DI5: Trigger turret position CTRIG

DI6: empty

DI7: Starting signal of activating origin homing function (ORG\_ST)

DI8: Deceleration signal of origin homing (ORG\_SW) (origin is as NO 1 position of turret)

DO1: Output signal of ENAB (SON)

DO2: Finish signal of origin homing function (HOME)

DO3: Position coincidence signal (POSIN)

DO5: Alarm output signal (ALM)

### 2、 Parameters setting

B01=11 (Toe index function)

B25=1555 (graduated speed 1000rpm)

H14=1F01 (DI2:TB0, DI1:SVON)

H15=2120 (DI4:TB2, DI3:TB1)

H16=0024 (DI6:empty, DI5:CTRIG)


H17=100F (DI8:ORG\_SW, DI7:ORG\_ST)

H18=0701 (DO2:HOME, DO1:SON)

- H19=0008 (DO3:POSIN)
- H20=0005 (DO5:ALM)
- H21=0 (The mode of origin homing is I/O activating mode)
- H22=0 (The origin homing direction is forward)
- H23=0 (The confirming method of Z-phase pulse is to press speed reducing switch-ORG\_SW. When the motor reverse runs and pulled off switch, the Z-phase will count)
- H24=1555H (The high-speed of homing is 1000rpm)
- H25=444H (The low-speed of homing is 200rpm)
- H26=1 (the No of Z-phase pulse in homing is 1, namely after pulling off speed reducing switch, the system finds NO.1 Z-phase pulse and regards it as homing point)
- H27/H28=0 (There is no origin deviation after finding origin homing point)
- H41=4 (Turret shortest path graduation)
- H35=0 (The torque will not decrease when the turret stops, the practical application of this parameter is set according to mechanical structure)
- H36=8 (The turret has 8 positions)
- H37=1 H38=2 (Deceleration rate of Rotation table)
- Other motor parameters such as loop of position, speed and graduated control gap compensation parameters will be set according to mechanical running condition.

### 3、 Operation:


- 1) When the servo is equipped, first use SVON=1 (DI1)
- 2) Doing origin homing operation and confirming No1 position of turret.
- 3) Put in turret optional signal (TB0~TB2) according to demand, then trigger CTRIG (DI5). The rotation table will reverse run turret and reach target position in principle of shortest path from current position to target position.
- 4) Sequence chart




### 11-3 ADSD-S drive and numerical control system accessories

#### 11-3-1 The accessories schematic chart with HNC-21T (century star) /Dalian CNC

1、Using HNC-21T and matching with ADSM series motor wiring.



**Remark:** Using Dalian CNC 31T/M. The wiring of numerical control system is same as above.




2、Using Dalian CNC 31T system and matching with Wuhan Golden motor wiring.


**Remark:** The wiring of using HCNC system 21T/M is same as above.

### 11-3-2.The schematic chart of matching with Guangzhou NC GSK218M.

1、ADSD-S drive connects to GSK-218M



2、The wiring of ADSD-S drive matching with TSFA of Dalian motor factory



## Addendum

## Drive matched cable

(1) power cable:

Order model: ADSD-S-CP-\*\*\* (\*\* indicates cable length)


Aviation plug model of lateral configuration ADSM-S series motor: YD28K4TS-A



## (2) encoder feedback cable:


Order model: ADSD-S-CE-\*\*\* (\*\* indicate cable length)

Aviation plug model of lateral configuration ADSM-S series motor: YD28K15TS-A



## (2) Communication cable(optional)

**Order model:** ADSD-CRS-\*\*\* (\*\* indicates cable length)



### **Pinboard of interface (optional)**

Our company's interface pinboard is designed for customer's convenience and it has CN1

and CN2 interface of synchro servo motor for all signals.

### Order model: ADSD-B

