

• 15Q0102B200 •

# SINUS PENTA

MULTIFUNCTION AC DRIVE

## GUIDE TO THE SYNCHRONOUS MOTOR APPLICATION

*English*

Issued on 13/07/2012  
R.00  
Software Version 4.01x

- This manual is integrant and essential to the product. Carefully read the instructions contained herein as they provide important hints for use and maintenance safety.
- This device is to be used only for the purposes it has been designed to. Other uses should be considered improper and dangerous. The manufacturer is not responsible for possible damages caused by improper, erroneous and irrational uses.
- Elettronica Santerno is responsible for the device in its original setting.
- Any changes to the structure or operating cycle of the device must be performed or authorized by the Engineering Department of Elettronica Santerno.
- Elettronica Santerno assumes no responsibility for the consequences resulting by the use of non-original spare-parts.
- Elettronica Santerno reserves the right to make any technical changes to this manual and to the device without prior notice. If printing errors or similar are detected, the corrections will be included in the new releases of the manual.
- The information contained herein is the property of Elettronica Santerno and cannot be reproduced. Elettronica Santerno enforces its rights on the drawings and catalogues according to the law.



# SANTERNO

CARRARO GROUP

Elettronica Santerno S.p.A.  
Strada Statale Selice, 47 – 40026 Imola (BO) Italy  
Tel. +39 0542 489711 – Fax +39 0542 489722  
[santerno.com](http://santerno.com)    [sales@santerno.com](mailto:sales@santerno.com)

## 0. TABLE OF CONTENTS

|   |           |
|---|-----------|
| <b>0. TABLE OF CONTENTS</b> .....   | <b>2</b>  |
| 0.1. Index of Figures .....   | 3         |
| 0.2. Index of Tables .....  | 3         |
| <b>1. SCOPE OF THIS MANUAL</b> .....  | <b>4</b>  |
| <b>2. OVERVIEW</b> .....  | <b>4</b>  |
| 2.1. SYNCHRONOUS MOTOR APPLICATION .....  | 4         |
| <b>3. SOFTWARE DOWNLOAD FOR APPLICATION PROGRAMMING</b> .....                             | <b>5</b>  |
| 3.1. FIRMWARE UPGRADE .....   | 6         |
| <b>4. MENU TREE</b> .....   | <b>8</b>  |
| <b>5. START-UP MENU</b> .....   | <b>10</b> |
| 5.1. Overview .....   | 10        |
| <b>6. FIRST STARTUP PROCEDURE (SYNCHRONOUS MOTOR)</b> .....                               | <b>12</b> |
| <b>7. PARAMETERS FOR SINUS PENTA DRIVES FEATURING SYNCHRONOUS MOTOR APPLICATION</b> ..... | <b>15</b> |
| 7.1. MEASURES MENU .....  | 15        |
| 7.1.1. Overview .....   | 15        |
| 7.1.2. Encoder Measures Menu .....  | 15        |
| 7.1.3. Status List .....  | 17        |
| 7.2. SPEED LOOP, POSITION AND CURRENT BALANCING MENU .....                                | 18        |
| 7.2.1. Overview .....   | 18        |
| 7.2.2. List of Parameters P125 to P152 .....  | 19        |
| 7.3. SYN REGULATORS MENU .....  | 23        |
| 7.3.1. Overview .....   | 23        |
| 7.3.2. List of Parameters P174a1 to P174c3 and Input I027 .....                           | 23        |
| 7.4. AUTOTUNE MENU .....  | 26        |
| 7.4.1. Overview .....   | 26        |
| 7.4.2. Motor Autotune and Adjusting Loops .....   | 26        |
| 7.4.3. Checking the Encoder Operation .....   | 28        |
| 7.5. MOTOR CONTROL MENU .....   | 29        |
| 7.5.1. Overview .....   | 29        |
| 7.5.2. Torque Control (SYN only) .....  | 31        |
| 7.5.3. List of Parameters C008 to C128 .....  | 32        |
| 7.6. DIGITAL INPUTS MENU .....  | 49        |
| 7.7. ENCODER/FREQUENCY INPUTS MENU .....  | 50        |
| 7.7.1. Overview .....   | 50        |
| 7.7.2. When the Optional Board is not Used .....  | 50        |
| 7.7.3. When Using ES836 or ES913 .....  | 51        |
| 7.7.4. With Optional Boards for Absolute Position Transducers .....                       | 52        |
| 7.7.5. List of Parameters C189 to C199 .....  | 53        |
| 7.8. EXPANSION BOARD CONFIGURATION MENU .....   | 59        |
| 7.8.1. Overview .....   | 59        |
| 7.8.2. List of Parameters R021 to R024 and R092 to R097 .....                             | 61        |
| 7.9. ALARMS SPECIFIC TO SYN APPLICATION .....   | 67        |
| 7.9.1. Overview .....   | 67        |
| 7.9.2. List of the Alarm Codes .....  | 67        |

## 0.1. Index of Figures

---

|  |    |
|--|----|
| Figure 1: Menu tree of the Synchronous Motor application ..... | 9  |
| Figure 2: Dual Parameterization function (example) .....       | 18 |
| Figure 3: Torque control with speed limit.....                 | 36 |

## 0.2. Index of Tables

---

|  |    |
|--|----|
| Table 1: Coding of M125 .....  | 16 |
| Table 2: List of parameters P125 ÷ P152.....                           | 19 |
| Table 3: List of Parameters P174a to P174c3 and input I027 .....       | 23 |
| Table 4: Programmable “Motor Tune” functions.....                      | 27 |
| Table 5: Description of the parameters classified by motor .....       | 30 |
| Table 6: List of Parameters C008 to C128 .....                         | 32 |
| Table 7: Equivalence between AC mains range and DC range .....         | 34 |
| Table 8: List of Parameters C189 ÷ C199 .....                          | 53 |
| Table 9: Matching between physical encoders and logic encoder A .....  | 54 |
| Table 10: Matching between physical encoders and logic encoder B ..... | 55 |
| Table 11: Coding of C189 .....   | 55 |
| Table 12: Coding of C199 .....   | 58 |
| Table 13: Possible encoder configurations .....                        | 59 |
| Table 14: List of Parameters R021 to R024 and R092 to R097 .....       | 61 |
| Table 15: Optional boards and parameter R023 .....                     | 62 |
| Table 16: Optional boards and parameter R023a .....                    | 62 |
| Table 17: Optional boards and parameter R023b .....                    | 63 |
| Table 18: List of the Alarms specific to the SYN application .....     | 67 |

## 1. SCOPE OF THIS MANUAL

Eletronica Santerno is committed to update its User Manuals available for download from [santerno.com](http://santerno.com) with the latest software version officially released. Please contact Eletronica Santerno if you require technical documents related to previous software versions.

## 2. OVERVIEW

Special software that can be used for particular applications is supplied with the drives of the Sinus Penta series. The menu tree, the programming mode and navigation mode of the Sinus Penta are used; parameters or menus will be added/(removed) whether required/(not required) for your application.

This manual covers the wiring diagrams and the parameters relating to the Synchronous Motor application.

Accessory boards are covered in the Sinus Penta **Installation Guide**.

The parameters shared with the standard Sinus Penta are covered in the Sinus Penta **Programming Guide**.

The FIRMWARE UPGRADE section explains how to download the files for the Sinus Penta applications to the standard drive: this download procedure is to be performed only when a drive programmed with standard firmware, *not* with Synchronous Motor firmware, needs to be updated.

The procedure above is not required if the drive is factory set with the Synchronous Motor firmware.

### 2.1. SYNCHRONOUS MOTOR APPLICATION

---

The Sinus Penta drive featuring Synchronous Motor application enables torque control and speed control of permanent magnet synchronous motors (PMSMs).

Controlling a synchronous motor requires a position transducer (encoder, resolver, etc.). Also, the offset angle between the position sensor and the rotor must be known, because the power supply current fed to the stator windings must be kept in phase with the rotor magnetic field generated by permanent magnets. The “alignment procedure” permits to estimate the offset angle. Using absolute position sensors avoids repeating the alignment procedure every time the drive is powered on.

The Sinus Penta application for synchronous motors covers any issues typical of synchronous motors and features a number of procedures to pinpoint the electromechanical characteristics of the motor to be controlled and to perform autotuning of the fundamental control parameters.

### 3. SOFTWARE DOWNLOAD FOR APPLICATION PROGRAMMING

The Remote Drive software and the PXxxxF0.mot, PXxxxF1.mot files of the application are required to download the Synchronous Motor application to a Sinus Penta drive. The download procedure is detailed in the following section.

The PRxxxF0.mot and PRxxxF1.mot files are required for the regenerative application.

For different applications, please refer to the relevant manuals and to the updates available on Elettronica Santerno's website:

[santerno.com](http://santerno.com)



**NOTE** Please refer to the User Manual of the Remote Drive software for more details.


The software of the Sinus Penta drives consists of two files, one containing the firmware and one containing the MMI table for the keypad interface. Both files use hexadecimal files with the MOT format. The filenames ending with "F0" relate to the firmware; the filenames ending with "F1" relate to the MMI table.

### 3.1. FIRMWARE UPGRADE

This section covers firmware upgrade and application download.




**NOTE** In case of multidrop connection (RS485), only the equipment to be upgraded shall be connected to the network.

|   |   |
|---|---|
| 1 | Launch the Remote Drive.  |
| 2 | Select the dialog language (click a flag) and press Next.   |
| 3 | <p>In the "Connection Parameters" window, select the Local mode. In the "Serial Configuration Parameters" window, set the interface device, the COM port being used and the baud rate (38400bps); click "Connect", then click "Next".</p> <p>In the example below, USB-RS485 converter is used.</p>  |
| 4 | <p>Select "Firmware Upgrade" from the "File" drop-down menu. Enter the path for the PXxxxFO.mot and PXxxxF1 files to be downloaded.</p> <p>If only one of the firmware files or MMI tables is to be updated, go to step 7. If an application shall be downloaded to a PXxxx, select the PXxxxFO.mot file and click the "Open" button.</p>   |

Send the "Autodet." command to allow the Remote Drive to detect the type of equipment. Once the product is detected, PXxxxx will appear in the Equipment Type window.


5



Press the "Send" button; confirmation for the Flash clearing will appear. Click "Yes" to start downloading. Once download is complete, go to step 6.

Click "Browse" to select the PxxxxF1 .mot file

6




Click "SendTab". Once this file is downloaded, the application download is complete (end of the download procedure).

7

Click "Browse" to select the file to be updated, PxxxxF0.mot for the firmware and PxxxxF1.mot for the MMI table; first click "Open", then click "Send" or "SendTab". Confirm flash clearing. The Upgrade procedure is finished.

### 4. MENU TREE








Figure 1: Menu tree of the Synchronous Motor application

## 5. START-UP MENU

### 5.1. Overview

---

For easier start-up of the Sinus Penta drive, you can activate the Start-Up Menu. The Start-Up Menu is a wizard allowing programming the main parameters for the connected motor and the parameters for PID control. The parameters in this menu are the same as described in the FIRST STARTUP PROCEDURE (SYNCHRONOUS MOTOR) section.

The Start-Up Menu is displayed when the Penta drive is first started. The Start-Up Menu can be reactivated at any time. To do so, set **P265** in "Start-Up" mode (see the DISPLAY/KEYPAD MENU in the **Programming Guide**) and power on the Penta drive again.

The following is the root page of the Start-Up menu:

```
[ I D P ] S I N U S   P E N T A
S T A R T   U P - M E N U
P r e s s   E N T E R
t o   s t a r t
```

Press **ENTER** to enter the wizard.

Before entering the control parameters, you are asked to choose a dialogue language:

```
P 2 6 3   L a n g u a g e
→@@@@@@@@@@@@@@@@@
```

Then you are asked to choose the display mode of the Start-up Menu:

```
W h e n   d o e s   t h e
S t a r t - U p   M e n u
a c t i v a t e ?
→@@@@@@@@@@@@@@@@@
```

Choose one of the following:

```
1 : E V E R Y   S T A R T - U P
2 : O N L Y   N O W
3 : N E X T   S T A R T - U P
4 : N E V E R
```

If you select "EVERY START-UP", the wizard appears whenever the Sinus Penta drive is powered on;  
if you select "ONLY NOW", you can scroll through the menu and the wizard is disabled as soon as you quit the menu;  
if you select "NEXT START-UP", the menu is displayed only when the Penta drive is next started up;  
if you select "NEVER", the Start-up menu is disabled.

Parameters included in the Start-up menu:

| Parameter | Description                      | Visibility                     |
|-----------|----------------------------------|--------------------------------|
| C008      | Rated mains voltage              |                                |
| C010      | Type of control algorithm        |                                |
| C013      | Type of V/f pattern              | [only if IFD is active]        |
| C015      | Rated motor frequency            |                                |
| C016      | Rated motor rpm                  |                                |
| C017      | Rated motor power                |                                |
| C018      | Rated motor current              |                                |
| C019      | Rated motor voltage              |                                |
| C028      | Min. motor speed                 |                                |
| C029      | Max. motor speed                 |                                |
| C034      | Voltage preboost                 | [only if IFD is active]        |
| P009      | Acceleration ramp time           |                                |
| P010      | Deceleration ramp time           |                                |
| C043      | Current limit while accelerating | [only if IFD is active]        |
| C044      | Current limit at constant rpm    | [only if IFD is active]        |
| C045      | Current limit while decelerating | [only if IFD is active]        |
| C048      | Torque limit                     | [only if SYN is active]        |
| C189      | Encoder operating mode           | [only if SYN is active]        |
| C190      | Encoder A pls/rev                | [only if SYN is active]        |
| C191      | Encoder B pls/rev                | [only if SYN is active]        |
| I073      | Autotuning selection             | [only if SYN is active]        |
| I074      | Motor tuning selection           | [only if SYN is active]        |
| C265      | Motor thermal protection         |                                |
| C267      | Motor thermal time constant      | [only if protection is active] |

After setting the last parameter and moving the cursor forward, the following screen appears:

P r e s s   U P   A R R O W  
t o   q u i t  
D O W N   A R R O W  
t o   c o n t i n u e

Press ▲ to quit the Start-up menu. The default page of the system will be displayed.

## 6. FIRST STARTUP PROCEDURE (SYNCHRONOUS MOTOR)

- 1) **Wiring:** Follow the instructions stated in the “Caution Statements” and “Installation” sections (**Installation Guide**).
- 2) **Power on:** Power on the drive and do not close the link to the START input and the ENABLE input to prevent the motor from running.
- 3) **Parameter modifications:** Access parameter **P000** (Key parameter) and enter its code (default value = 00001). Set user level **P001** = Eng. Use the **ESC**, **▲**, **▼** and **SAVE/ENTER** keys to access the programming parameters. Also refer to the MENU TREE.
- 4) **Supply voltage:** Set the real supply voltage for the drive. You can set either the mains voltage range or the DC supply stabilized by a Regenerative Penta drive. To set the type of power supply for the drive, access the MOTOR CONTROL MENU and set configuration parameter **C008** to the value corresponding to the installation concerned.
- 5) **Encoder parameters:**
- Incremental encoders on optional boards ES836 or ES913 (slot A) or terminal boards (MDI6, MDI7)**  
In the EXPANSION BOARD CONFIGURATION MENU, set parameters **R023a** and **R023b** to 0. Reset the board.  
Access the ENCODER/FREQUENCY INPUTS MENU; in **C189**, set the source of the encoder signal used as the speed feedback (Encoder A in the terminal board, Encoder B in optional board **ES836** or **ES913**), enter the number of pulses per revolution (**C190** and **C191**) and the number of encoder channels (**C197** – refer to the relevant section in the **Installation Guide** for more details).
- Incremental encoders on optional boards ES861, ES950, ES966 (slot C)**  
In the EXPANSION BOARD CONFIGURATION MENU, set parameter **R023a** to 0 and **R023b** to 1 (for **ES950** or **ES966**, any value  $\neq 3$  is sufficient). Reset the board.  
Access the ENCODER/FREQUENCY INPUTS MENU; in **C189**, set the source of the encoder signal used as the speed feedback in Encoder A (e.g. 1: A Feedback B Unused), enter the number of pulses per revolution (**C190** and **C191**) and the number of encoder channels (**C197** - consult the relevant section in the **Installation Guide** for more details).
- Absolute digital encoders (EnDat, BiSS, HIPERFACE)**  
In the EXPANSION BOARD CONFIGURATION MENU, set parameter **R023a** to 2, 3, 4 (EnDat, BiSS, HIPERFACE). Set the other parameters relating to the type of encoder being used. Reset the board.
- SinCos encoder**  
**3-channel SinCos encoder:**  
In the EXPANSION BOARD CONFIGURATION MENU, set parameter **R023b** to 3 and parameter **R023a** to 0. Reset the board. Access the ENCODER/FREQUENCY INPUTS MENU; in **C189**, set the source of the encoder signal used as the speed feedback in Encoder B (e.g. 3: A Unused, B Feedback). In **C191**, set the number of pulses per revolution. For more details, refer to the relevant section in the **Installation Guide**.
- Five-channel SinCos encoder:**  
In the EXPANSION BOARD CONFIGURATION MENU, set parameter **R023b** to 0 and parameter **R023a** to 5. In **R097**, set the number of sinusoids per revolution (e.g. 3: A Unused, B Feedback). In **C191**, set the number of pulses per revolution. Reset the board.
- Resolver**  
In the EXPANSION BOARD CONFIGURATION MENU, set parameter **R023a** to 1 (Resolver). Reset the board.  
Access the ENCODER/FREQUENCY INPUTS MENU, properly set parameter **C201** (Excitation Frequency), **C202** and **C203** (Excitation Signal Amplitude Adjustment). An

indicative value for both **C202** and **C203** may be "75", but optimum values are found by connecting the drive to the Remote Drive application. Access the ENCODER/FREQUENCY INPUTS MENU and monitor the status of the two LEDs of measure **M100**-Resolver Signal Status. When the optimum value is set for **C202** and **C203**, the two LEDs turn green, otherwise they turn red.

**6) Motor parameters:**

Access the MOTOR CONTROL MENU and set **C010** (Control Algorithm) as SYN (Synchronous Motor).  
Parameter **C012** (Type of Speed Feedback from Encoder) will automatically be set to Yes.

Set the motor ratings as follows:

- **C015** (fmot1) rated motor frequency, computed as follows:  

$$fmot1 = rpmnom / 60 * p$$
, where:  
**rpmnom** is the rated motor speed in rpm  
**p** is the number of pole pairs of the motor. Example:  
 rpmnom = 3000rpm  
 p = 3 pole pairs (6 poles)  

$$fmot1 = 3000 / 60 * 3 = 150$$
- **C016** (rpmnom1) rated rpm
- **C017** (Pmot1) rated power
- **C018** (Imot1) rated current
- **C019** (Vmot1) rated voltage
- **C029** (Speedmax1) desired maximum speed

If it is known, also set the following parameter:

- **C015a** (BEMF) (it may also be obtained during autotuning).

**7) Autotune of stator resistor, phase reactor, current loop:**

Open the ENABLE input, then access the AUTOTUNE MENU and set **I073**= [1: Motor Tune] and **I074**= [8: SYN Autotune]. Press **ESC** to confirm. Close the ENABLE and START inputs and wait until tune is complete (Warning "W32 Open Enable" is displayed). The drive has computed and saved the values for: **C022**, **C022a**, **P174a**, **P174b**.

If the values of parameters **C022** and **C022a** are known, they may manually be entered. By setting **I074**= [6: SYN Update Current Loop], only parameters **P174a** and **P174b** will be defined.

If alarm "A097 Motor Wires KO" trips, check the motor wiring. If alarm "A065 Autotune KO" trips, this means that the **ENABLE** command has opened before autotune was complete. In this case, reset the drive sending a command from terminal **MDI3**, or press the **RESET** key in the display/keypad and perform the autotune procedure again.

**8) Alignment procedure:**

The alignment procedure must be performed:

- If an absolute position sensor is installed on the motor (encoder type EnDat, BiSS, 5-channel SinCoS encoder, or Resolver):
  - only once at first startup;
  - if alarm **A132** trips;
  - if a mechanical displacement between the motor shafts and the position sensor has occurred.
- If an incremental position sensor is installed on the motor (incremental encoder, 3-channel SinCos encoder):
  - as in the case above;
  - every time the drive is powered on or reset.



**CAUTION**

This procedure will make the motor run. Make sure that the motor can rotate freely (no mechanical constraints or heavy loads).

Access the SYN REGULATORS MENU. Set **I027**= 1: Encoder Align.

Close the ENABLE and START inputs.

Wait for **W32** "Open Enable", open the ENABLE and START inputs.

**9) Speed loop**

This procedure is optional. It enables calculating the speed loop gains; before performing

**autotune:** the speed loop autotune, set up parameter **C022b** (Load Inertia, MOTOR CONFIGURATION menu) – this parameter is to be expressed in  $\text{Kgm}^2$ . Parameters **P126** and **P128** may also be entered while performing a manual tune procedure.

Open the ENABLE input, then access the AUTOTUNE MENU and set **I073**= [1: Motor Tune] and **I074**= [7: SYN Update Speed Loop]. Press **ESC** to confirm. Close the ENABLE input and wait until tune is complete (Warning “**W32** Open Enable” is displayed). The drive has calculated and saved the values of **P126**, **P128**.



**NOTE** Later on, it could be necessary to manually change parameters **P126**, **P128** above to optimize the dynamic response of the motor.

**10) BEMF autotune:** If the value of the motor BEMF is known, set it in parameter **C015a** – this parameter is expressed in  $\text{V}/(\text{rad}/\text{s})$ .

If the BEMF value is not known, it may be obtained through autotune.



**CAUTION** This procedure will make the motor run. Make sure that the motor can rotate freely (no mechanical constraints or heavy loads).

Open the ENABLE input, then access the AUTOTUNE MENU and set **I073**= [1: Motor Tune] and **I074** = [9: SYN BEMF Tune]. Press **ESC** to confirm. Close the ENABLE and START inputs and wait for **W32** “Open Enable”. The drive has calculated and saved the values of **C015a**.

**11) Startup:** Activate the **ENABLE** input (terminal 15) and the **START** input (terminal 14) and send a speed reference. The RUN LED and REF LED will come on and the motor will start rotating.

Make sure that the motor is rotating in the correct direction. If not, set parameter **C014** (Phase Rotation) to [1:Yes] or open the ENABLE and START inputs, remove voltage from the drive and, after waiting at least 15 minutes, swap two of the motor phases.

**12) Speed regulator adjustment:** If overshoot occurs when the speed setpoint is attained or if system instability is detected (the motor does not run smoothly), adjust the parameters relating to the speed loop (SPEED LOOP AND CURRENT BALANCING MENU). Set parameter **P126** (integral time) as [Disabled] and set a low value for the proportional gain (**P128**). Then increase **P128** until overshoot takes place when the setpoint is achieved. Decrease **P128** by approx. 30%, then decrease the high values set for integral time in **P126** until an acceptable setpoint response is obtained. Check to see if the motor runs smoothly at constant speed.

## 7. PARAMETERS FOR SINUS PENTA DRIVES FEATURING SYNCHRONOUS MOTOR APPLICATION

### 7.1. MEASURES MENU

---

#### 7.1.1. OVERVIEW

This section covers the specific measures of the Synchronous Motor application.

#### 7.1.2. ENCODER MEASURES MENU

##### M120 Incremental Encoder A Value

|             |                 |   |  |
|-------------|-----------------|---|--|
| <b>M120</b> | <b>Range</b>    | 0 ÷ 65535   | 0 ÷ 65535<br><u>Note:</u> The actual range of this measure may depend on the type of encoder being used. |
|             | <b>Active</b>   | Always active   |  |
|             | <b>Address</b>  | 1743  |  |
|             | <b>Function</b> | This is the count value of encoder A (see ENCODER/FREQUENCY INPUTS MENU). |  |

##### M121 Incremental Encoder B Value

|             |                 |   |  |
|-------------|-----------------|---|--|
| <b>M121</b> | <b>Range</b>    | 0 ÷ 65535   | 0 ÷ 65535<br><u>Note:</u> The actual range of this measure may depend on the type of encoder being used. |
|             | <b>Active</b>   | Always active   |  |
|             | <b>Address</b>  | 1744  |  |
|             | <b>Function</b> | This is the count value of encoder B (see ENCODER/FREQUENCY INPUTS MENU). |  |

##### M122 Absolute Encoder Value

|             |                 |   |  |
|-------------|-----------------|---|--|
| <b>M122</b> | <b>Range</b>    | 0 ÷ 65535   | 0 ÷ 65535<br><u>Note:</u> The actual range of this measure may depend on the type of encoder being used. |
|             | <b>Active</b>   | Active only if the absolute encoder is enabled via parameter <b>R023a</b> .                     |  |
|             | <b>Address</b>  | 1747  |  |
|             | <b>Function</b> | This is the count value of absolute encoder (or encoder M) (see ENCODER/FREQUENCY INPUTS MENU). |  |

## M123 Absolute Encoder Value – Singleturn (ST)

|             |                 |   |  |
|-------------|-----------------|---|--|
| <b>M123</b> | <b>Range</b>    | 0 ÷ 65535   | 0 ÷ 65535<br><i>Note:</i> The actual range of this measure may depend on the type of encoder being used. |
|             | <b>Active</b>   | Active only if the absolute encoder is enabled via parameter <b>R023a</b> .   |  |
|             | <b>Address</b>  | M123a (LO - first 16 bits): 3367<br>M123b (HI - second 16 bits): 3368   |  |
|             | <b>Function</b> | Shows the values of the least significant word (LO – first 16 bits) and the most significant word (HI – second 16 bits) of the single turn measure of the absolute encoder. |  |

## M124 Absolute Encoder Value – Multiturn (ST)

|             |                 |   |  |
|-------------|-----------------|---|--|
| <b>M124</b> | <b>Range</b>    | 0 ÷ 65535   | 0 ÷ 65535<br><i>Note:</i> The actual range of this measure may depend on the type of encoder being used. |
|             | <b>Active</b>   | Active only if the absolute encoder is enabled via parameter <b>R023a</b> .   |  |
|             | <b>Address</b>  | M124a (LO - first 16 bits): 3369<br>M124b (HI - second 16 bits): 3370   |  |
|             | <b>Function</b> | Shows the values of the least significant word (LO – first 16 bits) and the most significant word (HI – second 16 bits) of the single turn measure of the absolute encoder. |  |

## M125 Resolver Signal Status

|             |                 |  |             |
|-------------|-----------------|--|-------------|
| <b>M125</b> | <b>Range</b>    | Bit-controlled measure   | See Table 1 |
|             | <b>Active</b>   | Active only if the absolute encoder is enabled via parameter <b>R023a</b> .  |             |
|             | <b>Address</b>  | 3251   |             |
|             | <b>Function</b> | Quality of the sensor signal.<br>The sensor operation is correct if both signals DOS (degradation of signal) and LOT (loss of tracking) are OK (KO if the signals are poor quality). |             |

Table 1: Coding of M125

| Bit n. | Description                 | Notes  |
|--------|-----------------------------|--------|
| 0      | Degradation of Signal (DOS) | 0 = OK |
| 1      | Loss of Tracking (LOT)      | 1 = KO |

## M126 Shaft Absolute Position

|             |                 |  |                      |
|-------------|-----------------|--|----------------------|
| <b>M126</b> | <b>Range</b>    | -3.1416 ÷ 3.1416   | -3.1416 ÷ 3.1416 rad |
|             | <b>Active</b>   | Active for the SYN control   |                      |
|             | <b>Address</b>  | 2619 (float)   |                      |
|             | <b>Function</b> | This is the absolute position of one turn of the rotor, adopted for the control of the synchronous motor. The measure is expressed in radians. |                      |



### M127 Motor Aligned

|             |                 |  |                 |
|-------------|-----------------|--|-----------------|
| <b>M127</b> | <b>Range</b>    | 0 ÷ 1  | 0: No<br>1: Yes |
|             | <b>Active</b>   | Active for the SYN control   |                 |
|             | <b>Address</b>  | 224  |                 |
|             | <b>Function</b> | Status of the "motor aligned" flag. If the value is 0, alarm <b>A132</b> (Motor not aligned) will trip when the ENABLE input closes. The system sets the flag to 1 when the alignment procedure is complete. |                 |

### M128 Phases Swapped

|             |                 |   |                 |
|-------------|-----------------|---|-----------------|
| <b>M128</b> | <b>Range</b>    | 0 ÷ 1   | 0: No<br>1: Yes |
|             | <b>Active</b>   | Active for the SYN control  |                 |
|             | <b>Address</b>  | 225   |                 |
|             | <b>Function</b> | Status of the "phases swapped" flag. When the alignment procedure is complete (see section FIRST STARTUP PROCEDURE (SYNCHRONOUS MOTOR)), the flag is set to 1:Yes if the phases are swapped so that the direction of rotation of the motor and the encoder is the same. |                 |

### M129 Alignment Value

|             |                 |  |                      |
|-------------|-----------------|--|----------------------|
| <b>M129</b> | <b>Range</b>    | -3.1416 ÷ 3.1416   | -3.1416 ÷ 3.1416 rad |
|             | <b>Active</b>   | Active for the SYN control   |                      |
|             | <b>Address</b>  | 2031 (float)   |                      |
|             | <b>Function</b> | This is the offset value between the rotor and the encoder detected during the alignment stage. The measure is expressed in radians. |                      |

## 7.1.3. STATUS LIST

The Status List is the same as the standard Sinus Penta's (see the Status List table in the Sinus Penta's **Programming Guide**), except for the following:

- 36: SYN ALIGNING: alignment in progress
- 38: DRIVE ENABLED (replaces status 18: MOTOR FLUXED)
- 39: DRIVE OK (replaces status 16: INVERTER OK)

## 7.2. SPEED LOOP, POSITION AND CURRENT BALANCING MENU

### 7.2.1. OVERVIEW

The SPEED LOOP, POSITION AND CURRENT BALANCING MENU allows setting the parameter values of the speed regulators for the three programmable connected motors (SYN control); it also enables manual balancing of the motor currents (any control algorithm – see **P152**).

The speed regulator for each motor has a dual parameter setting capability: two integral terms, two proportional terms and two speed error thresholds (expressed as a percentage of the rated motor speed).

The response of the speed regulator can be dynamically linked with the speed error; in this way, the speed regulator will be more sensitive to remarkable speed errors and less sensitive to negligible speed errors.

Factory setting: because two identical error thresholds are set, only two parameters are used: **P126** (Maximum Integral Time) and **P128** (Minimum Proportional Constant).

The setup of min. integral time and max. proportional constant is enabled provided that two different error thresholds are used.

Example:

|             |       |      |   |
|-------------|-------|------|---|
| <b>P125</b> | 100   | [ms] | Minimum integral time for maximum error |
| <b>P126</b> | 500   | [ms] | Integral time for minimum error         |
| <b>P128</b> | 10.00 |      | Proportional constant for minimum error |
| <b>P129</b> | 25.00 |      | Proportional constant for maximum error |
| <b>P130</b> | 2     | [%]  | Minimum error threshold                 |
| <b>P131</b> | 20    | [%]  | Maximum error threshold                 |

#### Error ≤ P130

For speed errors lower than or equal to 2% of the rated motor speed, the speed regulator adopts parameters **P126** and **P128**.

#### Error ≥ P131

If the speed error exceeds the second error threshold, the speed regulator adopts parameters **P125** and **P129**.

#### P130 < Error < P131

When the speed error is included between the two error thresholds, the speed regulator will use coefficients that are dynamically linked with the speed error (see figure below).

$$\begin{aligned} \text{Integral coefficient} &= (1/P126) + [(err\% - P130) * (1/P125 - 1/P126) / (P131 - P130)] \\ \text{Proportional coefficient} &= P128 + [(err\% - P130) * (P129 - P128) / (P131 - P130)] \end{aligned}$$




Figure 2: Dual Parameterization function (example)

## 7.2.2. LIST OF PARAMETERS P125 TO P152

Table 2: List of parameters P125 ÷ P152

| Parameter | FUNCTION  | User Level  | DEFAULT VALUE | MODBUS Address |
|-----------|---|-------------|---------------|----------------|
| P125      | Mot1 Integral time for maximum error                                    | BASIC       | 500 ms        | 725            |
| P126      | Mot1 Integral time for minimum error                                    | BASIC       | 500 ms        | 726            |
| P127      | Mot1 Prop. coefficient of the position regulator for synchronous motors | ENGINEERING | 300           | 727            |
| P128      | Mot1 Prop. coefficient for minimum error                                | BASIC       | 10.00         | 728            |
| P129      | Mot1 Prop. coefficient for maximum error                                | BASIC       | 10.00         | 729            |
| P130      | Mot1 Minimum error threshold  | BASIC       | 1.00%         | 730            |
| P131      | Mot1 Maximum error threshold  | BASIC       | 1.00%         | 731            |
| P135      | Mot2 Integral time for maximum error                                    | BASIC       | 500 ms        | 735            |
| P136      | Mot2 Integral time for minimum error                                    | BASIC       | 500 ms        | 736            |
| P137      | Mot2 Prop. coefficient of the position regulator for synchronous motors | ENGINEERING | 300           | 737            |
| P138      | Mot2 Prop. coefficient for minimum error                                | BASIC       | 10.00         | 738            |
| P139      | Mot2 Prop. coefficient for maximum error                                | BASIC       | 10.00         | 739            |
| P140      | Mot2 Minimum error threshold  | BASIC       | 1.00%         | 740            |
| P141      | Mot2 Maximum error threshold  | BASIC       | 1.00%         | 741            |
| P145      | Mot3 Integral time for maximum error                                    | BASIC       | 500 ms        | 745            |
| P146      | Mot3 Integral time for minimum error                                    | BASIC       | 500 ms        | 746            |
| P147      | Mot3 Prop. coefficient of the position regulator for synchronous motors | ENGINEERING | 300           | 747            |
| P148      | Mot3 Prop. coefficient for minimum error                                | BASIC       | 10.00         | 748            |
| P149      | Mot3 Prop. coefficient for maximum error                                | BASIC       | 10.00         | 749            |
| P150      | Mot3 Min. error threshold   | BASIC       | 1.00 %        | 750            |
| P151      | Mot3 Max. error threshold   | BASIC       | 1.00 %        | 751            |
| P152      | Symmetry regulation of three-phase current                              | ENGINEERING | 0 %           | 752            |

**P125 (P135, P145) Integral Time for Maximum Error**

|   |          |  |                        |
|---|----------|--|------------------------|
| P125 (Mot1)<br>P135 (Mot2)<br>P145 (Mot3) | Range    | 1 ÷ 32000  | 1 ÷ 32000 [Disable] ms |
|   | Default  | 500  | 500 ms                 |
|   | Level    | BASIC  |                        |
|   | Address  | 725, 735, 745  |                        |
|   | Control  | SYN  |                        |
|   | Function | This parameter sets the integral time for the speed regulator when the error is over the maximum threshold.<br>It may be accessed only if the minimum and maximum error thresholds are different ( <b>P130≠P131</b> for Motor1, <b>P140≠P141</b> for Motor2, <b>P150≠P151</b> for Motor3). |                        |

**P126 (P136, P146) Integral Time for Minimum Error**

|   |          |   |                        |
|---|----------|---|------------------------|
| P126 (Mot1)<br>P136 (Mot2)<br>P146 (Mot3) | Range    | 1 ÷ 32000   | 1 ÷ 32000 [Disable] ms |
|   | Default  | 500   | 500 ms                 |
|   | Level    | BASIC   |                        |
|   | Address  | 726, 736, 746   |                        |
|   | Control  | SYN   |                        |
|   | Function | This parameter sets the integral time for the speed regulator used when the error is under the maximum threshold.<br>If the minimum and maximum error thresholds are the same ( <b>P130=P131</b> for Mot1, <b>P140=P141</b> for Mot2, <b>P150=P151</b> for Mot3), this is the integral time of the speed regulator. |                        |

**P127 (P137, P147) Proportional Constant of Position Controller**

|   |          |  |               |
|---|----------|--|---------------|
| P127 (Mot1)<br>P137 (Mot2)<br>P147 (Mot3) | Range    | 0 ÷ 65000  | 0.00 ÷ 650.00 |
|   | Default  | 300  | 3.00          |
|   | Level    | ENGINEERING  |               |
|   | Address  | 727, 737, 747  |               |
|   | Control  | SYN  |               |
|   | Function | Proportional constant of the position control loop.<br>Applicable to synchronous motors only.<br>It may automatically be updated by means of the relevant adjusting command (see AUTOTUNE MENU - <b>I074 = 2</b> : SYN Update Speed Loop). |               |

**P128 (P138, P148) Proportional Coefficient for Minimum Error**

|   |          |  |               |
|---|----------|--|---------------|
| P128 (Mot1)<br>P138 (Mot2)<br>P148 (Mot3) | Range    | 0 ÷ 65000  | 0.00 ÷ 650.00 |
|   | Default  | 1000   | 10.00         |
|   | Level    | BASIC  |               |
|   | Address  | 728, 738, 748  |               |
|   | Control  | SYN  |               |
|   | Function | This parameter sets the minimum proportional coefficient for the speed regulator, used when the error is lower than the minimum threshold. If the minimum and maximum error thresholds are the same ( <b>P130</b> = <b>P131</b> for Mot1, <b>P140</b> = <b>P141</b> for Mot2, <b>P150</b> = <b>P151</b> for Mot3), this is the proportional coefficient of the speed regulator. Default value (10): if a speed error of 1% occurs, the regulator will require 10% of the rated motor torque. |               |

**P129 (P139, P149) Proportional Coefficient for Maximum Error**

|   |          |   |               |
|---|----------|---|---------------|
| P129 (Mot1)<br>P139 (Mot2)<br>P149 (Mot3) | Range    | 0 ÷ 65000   | 0.00 ÷ 650.00 |
|   | Default  | 1000  | 10.00         |
|   | Level    | BASIC   |               |
|   | Address  | 729, 739, 749   |               |
|   | Control  | SYN   |               |
|   | Function | This parameter sets the proportional coefficient for the speed regulator, used when the error is higher than the maximum threshold. Default value (10): if a speed error of 1% occurs, the regulator will require 10% of the rated motor torque. This parameter may be accessed only if the min. and max. error thresholds are different ( <b>P130</b> ≠ <b>P131</b> for Motor1, <b>P140</b> ≠ <b>P141</b> for Motor2, <b>P150</b> ≠ <b>P151</b> for Motor3). |               |

**P130 (P140, P150) Minimum Error Threshold**

|   |          |   |                 |
|---|----------|---|-----------------|
| P130 (Mot1)<br>P140 (Mot2)<br>P150 (Mot3) | Range    | 0 ÷ 32000   | 0.00 ÷ 320.00 % |
|   | Default  | 100   | 1.00%           |
|   | Level    | BASIC   |                 |
|   | Address  | 730, 740, 750   |                 |
|   | Control  | SYN   |                 |
|   | Function | This parameter sets the minimum error threshold expressed as a percentage of the rated motor speed. If <b>P130</b> = <b>P131</b> or in case of speed errors lower than or equal to the min. threshold, parameters <b>P126</b> and <b>P128</b> will be used. |                 |

**P131 (P141, P151) Maximum Error Threshold**

|  |                 |   |                 |
|--|-----------------|---|-----------------|
| <b>P131 (Mot1)<br/>P141 (Mot2)<br/>P151 (Mot3)</b> | <b>Range</b>    | 0 ÷ 32000   | 0.00 ÷ 320.00 % |
|  | <b>Default</b>  | 100   | 1.00%           |
|  | <b>Level</b>    | BASIC   |                 |
|  | <b>Address</b>  | 731, 741, 751   |                 |
|  | <b>Control</b>  | SYN   |                 |
|  | <b>Function</b> | This parameter sets the maximum error threshold expressed as a percentage of the rated motor speed. In case of speed errors greater than or equal to the maximum threshold, the regulator uses parameters <b>P125</b> and <b>P129</b> . |                 |

**P152 Symmetry Regulation of Three-phase Current**

|             |                 |   |       |
|-------------|-----------------|---|-------|
| <b>P152</b> | <b>Range</b>    | ±100  | ±100% |
|             | <b>Default</b>  | 0   | 0%    |
|             | <b>Level</b>    | ENGINEERING   |       |
|             | <b>Address</b>  | 752   |       |
|             | <b>Function</b> | This parameter affects three-phase current balancing. It must be used when dissymmetry of the motor currents occurs, especially when no-load currents are delivered and the motor rotates at low rpm. |       |

## 7.3. SYN REGULATORS MENU

### 7.3.1. OVERVIEW



**NOTE** This menu may be accessed only if one of the two motors is set up as SYN (C010=1 for motor n.1, C053=1 for motor n.2, C096=1 for motor n.3).

This menu includes the parameters for PI current regulators and the command to perform the motor alignment procedure, which is required if the motor is not provided with an absolute position transducer.

### 7.3.2. LIST OF PARAMETERS P174A1 TO P174C3 AND INPUT I027

Table 3: List of Parameters P174a to P174c3 and input I027

| Parameter/<br>input | FUNCTION   | User Level  | DEFAULT<br>VALUE | MODBUS<br>Address |
|---------------------|--|-------------|------------------|-------------------|
| I027                | SYN Controls   | BASIC       | –                | 1414              |
| P174a1              | Maximum Time for Encoder Alignment Mot.1             | ENGINEERING | 10 s             | 760               |
| P174b1              | Proportional Constant of Current Regulator for Mot.1 | ENGINEERING | 3.00             | 761               |
| P174c1              | Integral Time of Current Regulator for Mot.1         | ENGINEERING | 2.0 ms           | 762               |
| P174a2              | Maximum Time for Encoder Alignment Mot.2             | ENGINEERING | 10 s             | 771               |
| P174b2              | Proportional Constant of Current Regulator for Mot.2 | ENGINEERING | 3.00             | 772               |
| P174c2              | Integral Time of Current Regulator for Mot.2         | ENGINEERING | 2.0 ms           | 773               |
| P174a3              | Maximum Time for Encoder Alignment Mot.3             | ENGINEERING | 10 s             | 1251              |
| P174b3              | Proportional Constant of Current Regulator for Mot.3 | ENGINEERING | 3.00             | 1252              |
| P174c3              | Integral Time of Current Regulator for Mot.3         | ENGINEERING | 2.0 ms           | 1253              |

I027 SYN Controls

|             |                 |   |                                |
|-------------|-----------------|---|--------------------------------|
| <b>I027</b> | <b>Range</b>    | 0 ÷ 1   | 0: Disable<br>1: Encoder Align |
|             | <b>Default</b>  | This is not a parameter: the input is set to zero whenever the drive is powered on and whenever the command is executed.  |                                |
|             | <b>Level</b>    | BASIC   |                                |
|             | <b>Address</b>  | 1414  |                                |
|             | <b>Function</b> | <p>Selects the command for the synchronous motor:</p> <p>[1: Encoder Align] → The motor alignment procedure is required. The rotor is run in order to detect the offset angle between the encoder and the motor phases. The alignment procedure must be performed:</p> <ul style="list-style-type: none"> <li>- <u>If an absolute position sensor is installed on the motor</u> (EnDat encoder, BiSS encoder, 5-channel SinCoS encoder, or Resolver): <ul style="list-style-type: none"> <li>- only once at first startup;</li> <li>- if alarm <b>A132</b> trips;</li> <li>- if a mechanical displacement between the motor shafts and the position sensor has occurred.</li> </ul> </li> <li>- <u>If an incremental position sensor is installed on the motor</u> (incremental encoder, 3-channel SinCos encoder): <ul style="list-style-type: none"> <li>- as in the case above;</li> <li>- every time the drive is powered on or reset.</li> </ul> </li> </ul> <p>After setting <b>I027</b> to 1, close the ENABLE and START inputs to start the alignment procedure. Wait for <b>W32</b> "Open Enable", then open the ENABLE and START inputs.</p> <p>The offset angle is displayed in measure <b>M129</b>.</p> |                                |



**CAUTION** The alignment procedure will make the motor run. Make sure that the motor can rotate freely (no mechanical constraints or heavy loads).

P174a1 (P174a2, P174a3) Maximum Time for Encoder Alignment

|  |                 |   |           |
|--|-----------------|---|-----------|
| <b>P174a1 (Mot1)<br/>P174a2 (Mot2)<br/>P174a3 (Mot3)</b> | <b>Range</b>    | 1 ÷ 180   | 1 ÷ 180 s |
|  | <b>Default</b>  | 10  | 10 s      |
|  | <b>Level</b>    | ENGINEERING   |           |
|  | <b>Address</b>  | 760, 771, 1251  |           |
|  | <b>Control</b>  | SYN   |           |
|  | <b>Function</b> | <p>Duration of the alignment procedure for synchronous motors.</p> <p>The alignment algorithm will perform the procedure within the set time. If the alignment procedure time is increased, the rotor will run more slowly, thus reducing acceleration and load stress.</p> <p>The time set in this parameter shall be exceedingly longer than the mechanical motor+load time constant.</p> |           |



**P174b1 (P174b2, P174b3) Proportional Constant of Current Regulator**

|   |          |   |               |
|---|----------|---|---------------|
| P174b1 (Mot1)<br>P174b2 (Mot2)<br>P174b3 (Mot3) | Range    | 0 ÷ 65000   | 0.00 ÷ 650.00 |
|   | Default  | 300   | 3.00          |
|   | Level    | ENGINEERING   |               |
|   | Address  | 761, 772, 1252  |               |
|   | Control  | SYN   |               |
|   | Function | <p>Proportional coefficient <b>K<sub>p</sub></b> of current regulator <b>PI</b> for motor n.1 (P174b2 and P174b3 are the equivalent parameters for motor 2 and motor 3).</p> <p>The regulator has the typical structure:<br/> <math>error = set\_point - measure;</math><br/> <math>integral\_status = integral\_status + error * Ki * Ts;</math><br/> <math>output = Kp * error + integral\_status;</math><br/>                     where <b>K<sub>p</sub></b> is the proportional coefficient<br/> <b>K<sub>i</sub></b> is the integral coefficient = 1/T<sub>i</sub>, where T<sub>i</sub> is the integral time<br/> <b>T<sub>s</sub></b> is the execution time of the regulator (may range from 200 to 400 microseconds based on the carrier frequency).</p> |               |



**NOTE**

The parameter above is **automatically computed and saved** with the Autotune procedure (see AUTOTUNE MENU).

**P174c1 (P174c2, P174c3) Integral Time of Current Regulator**

|   |          |  |                            |
|---|----------|--|----------------------------|
| P174c1 (Mot1)<br>P174c2 (Mot2)<br>P174c3 (Mot3) | Range    | 1 ÷ 32000  | 1.0 ÷ 3200.0 [Disabled] ms |
|   | Default  | 20   | 2.0 ms                     |
|   | Level    | ENGINEERING  |                            |
|   | Address  | 762, 773, 1253   |                            |
|   | Control  | SYN  |                            |
|   | Function | <p>Integral time <b>T<sub>i</sub></b> of current regulator <b>PI</b> for motor n.1 (P174c2 and P174c3 are the equivalent parameters for motor 2 and motor 3).</p> <p>The regulator has the typical structure:<br/> <math>error = set\_point - measure;</math><br/> <math>integral\_status = integral\_status + error * Ki * Ts;</math><br/> <math>output = Kp * error + integral\_status;</math><br/>                     where <b>K<sub>p</sub></b> is the proportional coefficient<br/> <b>K<sub>i</sub></b> is the integral coefficient = 1/T<sub>i</sub>, where T<sub>i</sub> is the integral time<br/> <b>T<sub>s</sub></b> is the execution time of the regulator (may range from 200 to 400 microseconds based on the carrier frequency).</p> |                            |



**NOTE**

The parameter above is **automatically computed and saved** with the Autotune procedure (see AUTOTUNE MENU).

## 7.4. AUTOTUNE MENU

---

### 7.4.1. OVERVIEW

**NOTE**

See the FIRST STARTUP PROCEDURE (SYNCHRONOUS MOTOR) section for tuning based on the control algorithm to be used.

**NOTA**

At the end of the Autotune procedure, the system automatically saves the whole parameter set of the drive.

**NOTA**

Autotune must be performed only after entering the motor ratings or the ratings of the encoder used as a speed feedback. Please refer to the MOTOR CONTROL MENU and ENCODER/FREQUENCY INPUTS MENU.

The selected motor may be tuned in order to obtain the equipment ratings or the parameterization required for the correct operation of the control algorithms.

The user can also check the proper operation/wiring of the encoder used as a speed feedback.

The Autotune menu includes two programming inputs, **I073** and **I074**. Input **I073** allows enabling and selecting the type of autotune. Input **I074**—which can be programmed only if **I073** = Motor Tune—describes the type of autotune which is performed. Because the values set in **I073** or **I074** cannot be changed permanently and are automatically reset after autotuning, the **ENABLE** signal must be disabled and the **ESC** key must be used to accept the new value.

### 7.4.2. MOTOR AUTOTUNE AND ADJUSTING LOOPS

Set **I073** as Motor Tune to enable autotune functions that can be selected with **I074**.

**NOTE**

For the correct operation of the tuning algorithms, enter the motor ratings and the ratings of the encoder used as a speed feedback. Please refer to the MOTOR CONTROL MENU and ENCODER/FREQUENCY INPUTS MENU.

Table 4: Programmable “Motor Tune” functions

| I074 Setting               | Motor Rotation | Type of Tune   |
|----------------------------|----------------|--|
| 0: IFD ctrl no rotation    | No             | <p><b>Automatic estimation</b> of the stator resistance and the leakage inductance, that can be performed only on asynchronous motors controlled via IFD algorithm.</p> <p>If no-load current (C021) is zero, no-load current values are computed based on the rated power of the connected motor.</p> <p>This tuning mode is required for the correct operation of the control algorithms.</p>  |
| 1: SYN Update current loop | No             | <p><b>Automatic autotune</b> of the current loop.</p> <p>Tuning mode required for the correct operation of the SYN algorithm.</p> <p>During autotune, it is possible to monitor the reference current and the reference obtained on analog output AO2 and AO1.</p> <p>In order to perform the procedure, close the ENABLE signal after setting I074 accordingly.</p> <p>When the procedure is complete, parameters P174b1 and P174c1 (motor 2: P174b2 and P174c2; motor 3: P174b3 and P174c3) will automatically be updated.</p>   |
| 2: SYN Update speed loop   | No             | <p><b>Automatic autotune</b> of the speed loop and position loop (SYN algorithm).</p> <p>This procedure automatically calculates parameters P125, P126, P127, P128, P129 (motor 2: P135 to P139; motor 3: P145 to P149). Because the result depends on the load inertia, make sure that parameters C022b and C022c (motor 2: C065b and C065c; motor 3: C108b and C108c) are properly set. If those parameters are not known, the gains for speed loop and position loop are to be manually set up. Manual adjustment might be required anyway.</p> <p>In order to perform the procedure, close the ENABLE signal after setting I074.</p> |
| 3: SYN autotune            | No             | <p><b>Automatic estimation</b> of the stator resistance and the phase inductance of the synchronous motor (SYN algorithm) + <b>automatic tune</b> of the gains for speed loop and position loop (the position tune is the same as the one obtained with 1: SYN Update current loop).</p> <p>In order to perform the procedure, close the ENABLE signal and the START signal after setting I074 accordingly.</p> <p>When the procedure is complete, parameters P174b1, P174c1, C22, C22a (motor 2: P174b2, P174c2, C065, C065a; motor 3: P174b3, P174c3, C108, C108a) will automatically be updated.</p>                                  |
| 4: SYN BEMF tune           | Yes            | <p><b>Automatic tune</b> of the BEMF.</p> <p>This procedure causes the motor to rotate at high speed and enables estimating parameter C015a (C058a and C097a respectively for motor 2 and motor 3).</p> <p>In order to perform the procedure, close the ENABLE and the START signal after setting I074 accordingly.</p>  |

### 7.4.3. CHECKING THE ENCODER OPERATION

Set **I073** as Encoder Tune to check the correct operation of the encoder selected as a speed feedback (see the ENCODER/FREQUENCY INPUTS MENU) and to automatically set the correct direction of rotation.

**NOTE**

Before checking the correct operation of the encoder used as a speed feedback, **enter the motor ratings and the encoder ratings.**

Refer to the MOTOR CONTROL MENU and ENCODER/FREQUENCY INPUTS MENU.

Once **I073** is set as Encoder Tune and the **ENABLE** and **START** commands are enabled, the connected motor attains a speed of rotation of approx. 150 rpm; its speed of rotation is detected by the encoder, then the drive is disabled. The following messages can be displayed on the display/keypad:

**A059 Encoder Fault**

**W31 Encoder OK**

Then the following message is always displayed:

**W32 OPEN ENABLE**

If alarm **A059 Encoder Fault** trips: in the encoder input, the value measured by the drive does not match with the real speed of rotation of the motor. Check if the encoder is properly set up (see the ENCODER/FREQUENCY INPUTS MENU) and wired; if the Encoder B input is used, check the Configuration of the DIP-switches located on optional board **ES836** or **ES913** (see the Sinus Penta's **Installation Guide**).

If **W31 Encoder OK** appears: the speed feedback from encoder is correct.

In addition, the autotune sets the encoder signal as feedback with parameter **C199**.

## 7.5. MOTOR CONTROL MENU

---

### 7.5.1. OVERVIEW

The Sinus Penta allows configuring three different types of motors and two different types of control algorithms at the same time.

The two types of control algorithms are identified with the acronyms:

- ✓ **IFD** (Voltage/Frequency Control);
- ✓ **SYN** (Synchronous Motor)

The Voltage/Frequency control allows controlling **asynchronous motors** by producing voltage depending on frequency.

The Synchronous Motor control allows controlling torque, speed, position of permanent magnet synchronous motors (PMSMs).

The parameter set for the selected motor is included in the Motor Control menu:

- ✓ Motor Control 1 Menu concerns motor 1;
- ✓ Motor Control 2 Menu concerns motor 2;
- ✓ Motor Control 3 Menu concerns motor 3.

Factory setting allows configuring only one motor. To access the Configuration menus of the other connected motors, simply enter the number of the selected motor in **C009** (Number of Configured Motors) in the Motor Control 1 Menu.

To select the connected motor, use digital inputs programmed via parameters **C173** and **C174**, Digital Input for Motor 2 Activation and Digital Input for Motor 3 Activation respectively (see also the DIGITAL INPUTS MENU in the **Programming Guide**).

The parameters included in the Motor Control Menus are detailed in Table 5.



**NOTE**

Different SYN control parameter sets must refer to the same physical motor. Controlling multiple motors with the same drive is not possible.

Table 5: Description of the parameters classified by motor

| Parameter Contents  | Motor Control 1       | Motor Control 2       | Motor Control 3       |
|---|-----------------------|-----------------------|-----------------------|
| • Rated mains voltage   | C008                  | —————                 | —————                 |
| • Control algorithm being used  | C010                  | C053                  | C096                  |
| • Type of reference being used (speed / torque) (SYN algorithm only)  | C011                  | C054                  | C097                  |
| • SYN control compensations   | C011a ÷ C011b         | C054a ÷ C054b         | C097a ÷ C097b         |
| • Presence of the speed feedback from encoder   | C012                  | C055                  | C098                  |
| • Electric ratings of the connected motor   | C015 ÷ C025           | C058 ÷ C068           | C101 ÷ C111           |
| • Load characteristics (SYN algorithm only)   | C022b ÷ C022d         | C065b ÷ C065d         | C108b ÷ C108d         |
| • Minimum and maximum speed required, speed at the beginning of defluxing, overspeed alarm enable and threshold | C028 ÷ C031           | C071 ÷ C074           | C114 ÷ C117           |
| • V/f pattern parameters  | C013 /<br>C032 ÷ C038 | C056 /<br>C075 ÷ C081 | C099 /<br>C118 ÷ C124 |
| • Slip compensation activation  | C039                  | C082                  | C125                  |
| • Voltage drop at rated current   | C040                  | C083                  | C126                  |

The parameters that can be modified depend on the type of control that has been selected.

## 7.5.2. TORQUE CONTROL (SYN ONLY)

The SYN algorithm enables controlling the drive with a torque reference instead of a speed reference. To do so, set [1: Torque or 2: Torque with Speed Limit [FOC only] in the relevant parameter (**C011** for motor 1, **C054** for motor 2, **C097** for motor 3).

In this way, the main reference corresponds to the motor torque demand and may range from **C047** to **C048** (see the LIMITS MENU in the **Programming Guide**) for motor 1 (minimum and maximum torque expressed as a percentage of the rated motor torque). For motors 2 and 3, the parameters relating to the minimum and maximum torque (**C090**, **C091** and **C133**, **C134**) are included in the Limits Menu 2 and Limits Menu 3.

When using a Sinus Penta drive model "0020" connected to a 15kW motor, **C048** is factory-set to 120% of the rated motor torque. If the max. reference is applied (**C143** = REF), the torque reference will be 120%.

If a 7.5kW motor is connected, **C048** may exceed 200%; torque values exceeding 200% may be obtained based on the value set in **C048**.

The rated motor torque results from the following formula:

$$C = P / \omega$$

where P is the rated power expressed in W and  $\omega$  is the rated speed of rotation expressed in radians/sec.

Example: the rated torque of a 15kW motor at 1420rpm is equal to:

$$C = \frac{15000}{1420 \cdot 2\pi / 60} = 100.9 \text{ Nm}$$

The starting torque is:

$$\text{rated torque} * 120\% = 121.1 \text{ Nm}$$

### 7.5.3. LIST OF PARAMETERS C008 TO C128

Table 6: List of Parameters C008 to C128

| Parameter | FUNCTION                | User Level  | MODBUS Address | DEFAULT VALUES |
|-----------|-------------------------|-------------|----------------|----------------|
| C008      | Rated mains voltage     | BASIC       | 1008           | 2:[380÷480V]   |
| C009      | N. of configured motors | ENGINEERING | 1009           | 1              |

| Parameter |    | FUNCTION                            | User Level  | Modbus Address | Parameter  |
|-----------|----|-------------------------------------|-------------|----------------|--|
| C010      | M1 | Type of control algorithm           | BASIC       | 1010           | 1: SYN   |
| C053      | M2 |                                     |             | 1053           |  |
| C096      | M3 |                                     |             | 1096           |  |
| C011      | M1 | Type of reference                   | ADVANCED    | 1011           | 0: Speed (MASTER mode)                                       |
| C054      | M2 |                                     |             | 1054           |  |
| C097      | M3 |                                     |             | 1097           |  |
| C011a     | M1 | Forward Actions over Torque Control | ADVANCED    | 634            | 0: No  |
| C054a     | M2 |                                     |             | 636            |  |
| C097a     | M3 |                                     |             | 638            |  |
| C011b     | M1 | BEMF Compensation                   | ADVANCED    | 635            | 0: No  |
| C054b     | M2 |                                     |             | 637            |  |
| C097b     | M3 |                                     |             | 639            |  |
| C012      | M1 | Encoder/resolver present            | BASIC       | 1012           | 0: No  |
| C055      | M2 |                                     |             | 1055           |  |
| C098      | M3 |                                     |             | 1098           |  |
| C013      | M1 | Type of V/f pattern                 | BASIC       | 1013           | Depending on the model. See tables in the Programming Guide. |
| C056      | M2 |                                     |             | 1056           |  |
| C099      | M3 |                                     |             | 1099           |  |
| C014      | M1 | Phase rotation                      | ENGINEERING | 1014           | 0: No  |
| C057      | M2 |                                     |             | 1057           |  |
| C100      | M3 |                                     |             | 1100           |  |
| C015      | M1 | Rated motor frequency               | BASIC       | 1015           | 50.0 Hz  |
| C058      | M2 |                                     |             | 1058           |  |
| C101      | M3 |                                     |             | 1101           |  |
| C015a     | M1 | BEMF constant                       | ENGINEERING | 753            | 0.00 V/(rad/s)   |
| C058a     | M2 |                                     |             | 764            |  |
| C101a     | M3 |                                     |             | 1236           |  |
| C016      | M1 | Motor rpm                           | BASIC       | 1016           | 1500 rpm   |
| C059      | M2 |                                     |             | 1059           |  |
| C102      | M3 |                                     |             | 1102           |  |
| C017      | M1 | Rated motor power                   | BASIC       | 1017           | Depending on the model. See tables in the Programming Guide. |
| C060      | M2 |                                     |             | 1060           |  |
| C103      | M3 |                                     |             | 1103           |  |
| C018      | M1 | Rated motor current                 | BASIC       | 1018           | Depending on the model. See tables in the Programming Guide. |
| C061      | M2 |                                     |             | 1061           |  |
| C104      | M3 |                                     |             | 1104           |  |
| C019      | M1 | Rated motor voltage                 | BASIC       | 1019           | Depends on the inverter voltage class                        |
| C062      | M2 |                                     |             | 1062           |  |
| C105      | M3 |                                     |             | 1105           |  |
| C020      | M1 | No-load motor power                 | ADVANCED    | 1020           | 0.0%   |
| C063      | M2 |                                     |             | 1063           |  |
| C106      | M3 |                                     |             | 1106           |  |



|       |    |  |             |      |  |
|-------|----|--|-------------|------|--|
| C021  | M1 | No-load motor power  | ADVANCED    | 1021 | 0%   |
| C064  | M2 |  |             | 1064 |  |
| C107  | M3 |  |             | 1107 |  |
| C022  | M1 | Motor stator resistance  | ENGINEERING | 1022 | Depending on the model.<br>See tables in the<br>Programming Guide. |
| C065  | M2 |  |             | 1065 |  |
| C108  | M3 |  |             | 1108 |  |
| C022a | M1 | Phase inductance   | ENGINEERING | 754  | 0.00 mH  |
| C065a | M2 |  |             | 765  |  |
| C108a | M3 |  |             | 1237 |  |
| C022b | M1 | Load inertia   | ENGINEERING | 755  | 0.000 kgm <sup>2</sup>   |
| C065b | M2 |  |             | 766  |  |
| C108b | M3 |  |             | 1238 |  |
| C022c | M1 | Rotor inertia  | ENGINEERING | 756  | 300 kgmm <sup>2</sup>  |
| C065c | M2 |  |             | 767  |  |
| C108c | M3 |  |             | 1239 |  |
| C022d | M1 | Viscous friction coefficient   | ENGINEERING | 757  | 0.00 mNm/(rad/s)   |
| C065d | M2 |  |             | 768  |  |
| C108d | M3 |  |             | 1240 |  |
| C023  | M1 | Leakage inductance   | ENGINEERING | 1023 | Depending on the model.<br>See tables in the<br>Programming Guide. |
| C066  | M2 |  |             | 1066 |  |
| C109  | M3 |  |             | 1109 |  |
| C024  | M1 | Mutual inductance  | ADVANCED    | 1024 | 250.00mH   |
| C067  | M2 |  |             | 1067 |  |
| C110  | M3 |  |             | 1110 |  |
| C026  | M1 | Time constant of bus voltage<br>low-pass filter                            | ENGINEERING | 1026 | 0 ms   |
| C069  | M2 |  |             | 1069 |  |
| C112  | M3 |  |             | 1112 |  |
| C028  | M1 | Minimum motor speed  | BASIC       | 1028 | 0 rpm  |
| C071  | M2 |  |             | 1071 |  |
| C114  | M3 |  |             | 1114 |  |
| C029  | M1 | Maximum motor speed  | BASIC       | 1029 | 1500 rpm   |
| C072  | M2 |  |             | 1072 |  |
| C115  | M3 |  |             | 1115 |  |
| C031  | M1 | Maximum speed alarm  | ADVANCED    | 1031 | 0: Disabled  |
| C074  | M2 |  |             | 1074 |  |
| C117  | M3 |  |             | 1117 |  |
| C032  | M1 | Quadratic torque curve<br>decrease   | ADVANCED    | 1032 | 30%  |
| C075  | M2 |  |             | 1075 |  |
| C118  | M3 |  |             | 1118 |  |
| C033  | M1 | Rated revolutions referring<br>to quadratic torque curve<br>decrease       | ADVANCED    | 1033 | 20%  |
| C076  | M2 |  |             | 1076 |  |
| C119  | M3 |  |             | 1119 |  |
| C034  | M1 | Voltage preboost for IFD   | BASIC       | 1034 | Depending on the model.<br>See tables in the<br>Programming Guide. |
| C077  | M2 |  |             | 1077 |  |
| C120  | M3 |  |             | 1120 |  |
| C035  | M1 | Voltage Boost at 5% of the<br>rated motor frequency                        | ADVANCED    | 1035 | Depending on the model.<br>See tables in the<br>Programming Guide. |
| C078  | M2 |  |             | 1078 |  |
| C121  | M3 |  |             | 1121 |  |
| C036  | M1 | Voltage Boost at<br>programmable frequency                                 | ADVANCED    | 1036 | Depending on the model.<br>See tables in the<br>Programming Guide. |
| C079  | M2 |  |             | 1079 |  |
| C122  | M3 |  |             | 1122 |  |
| C037  | M1 | Frequency for application of<br>voltage Boost at<br>programmable frequency | ADVANCED    | 1037 | Depending on the model.<br>See tables in the<br>Programming Guide. |
| C080  | M2 |  |             | 1080 |  |
| C123  | M3 |  |             | 1123 |  |

|      |    |                               |             |      |   |
|------|----|-------------------------------|-------------|------|---|
| C038 | M1 | Autoboost                     | ADVANCED    | 1038 | Depending on the model.<br>See tables in the Programming Guide. |
| C081 | M2 |                               |             | 1081 |   |
| C124 | M3 |                               |             | 1124 |   |
| C039 | M1 | Slip compensation             | ADVANCED    | 1039 | 0: Disabled   |
| C082 | M2 |                               |             | 1082 |   |
| C125 | M3 |                               |             | 1125 |   |
| C040 | M1 | Voltage drop at rated current | ADVANCED    | 1040 | 0: Disabled   |
| C083 | M2 |                               |             | 1083 |   |
| C126 | M3 |                               |             | 1126 |   |
| C042 | M1 | Vout saturation percentage    | ENGINEERING | 1042 | 100%  |
| C085 | M2 |                               |             | 1085 |   |
| C128 | M3 |                               |             | 1128 |   |

**C008 Rated Mains Voltage**

|      |          |   |  |
|------|----------|---|--|
| C008 | Range    | 0 ÷ 8   | 0: [ 200 ÷ 240 ] V<br>1: 2T Regen.<br>2: [ 380 ÷ 480 ] V<br>3: [ 481 ÷ 500 ] V<br>4: 4T Regen.<br>5: [ 500 ÷ 600 ] V<br>6: 5T Regen.<br>7: [ 600 ÷ 690 ] V<br>8: 6T Regen. |
|      | Default  | 2   | 2: [ 380 ÷ 480 ] V   |
|      | Level    | BASIC   |  |
|      | Address  | 1008  |  |
|      | Function | <p>This parameter defines the rated voltage of the mains powering the drive, thus allowing obtaining voltage ranges to be used for the drive operation. The value set in this parameter depends on the <b>Drive voltage class</b>.</p> <p>To supply the drive via a non-stabilized DC source, the corresponding AC voltage range must be used (see Table 7); <b>DO NOT USE T Regen settings in this case.</b></p> |  |

Table 7: Equivalence between AC mains range and DC range

| AC MAINS    | DC range    |
|-------------|-------------|
| 200÷240 Vac | 280÷338 Vdc |
| 380÷480 Vac | 530÷678 Vdc |
| 481÷500 Vac | 680÷705 Vdc |
| 500÷600 Vac | 705÷810 Vdc |
| 600÷690 Vac | 810÷970 Vdc |



NOTE

**Select xT Regen** (where x relates to the voltage class of the drive) if the drive is DC-supplied through a regenerative Sinus Penta or a different drive used to stabilize the DC bus to a higher level than the stabilization level obtained when rectifying the 3-phase mains.

**C009 N. of Configured Motors**

|             |                 |   |     |
|-------------|-----------------|---|-----|
| <b>C009</b> | <b>Range</b>    | 1÷3   | 1÷3 |
|             | <b>Default</b>  | 1   | 1   |
|             | <b>Level</b>    | ENGINEERING   |     |
|             | <b>Address</b>  | 1009  |     |
|             | <b>Function</b> | <p>This parameter determines the number of motors to be configured. The active motor is selected through digital inputs programmed with <b>C173</b> and <b>C174</b> (see DIGITAL INPUTS MENU in the <b>Programming Guide</b>).</p> <p>The programming parameters of the Motor Control 2 Menu can be accessed only if <b>C009</b> = 2 or 3; the programming parameters of the Motor Control 3 Menu can be accessed only if <b>C009</b> =3.</p> |     |

**C010 (C053, C096) Type of Control Algorithm**


|  |                 |   |                  |
|--|-----------------|---|------------------|
| <b>C010 (mot. n.1)<br/>C053 (mot. n.2)<br/>C096 (mot. n.3)</b> | <b>Range</b>    | 0 ÷ 1   | 0: IFD<br>1: SYN |
|  | <b>Default</b>  | 0   | 1: SYN           |
|  | <b>Level</b>    | BASIC   |                  |
|  | <b>Address</b>  | 1010, 1053, 1096  |                  |
|  | <b>Function</b> | <p>This parameter sets the type of control algorithm to be used.</p> <p>Types of control:<br/>0: IFD V/f control for asynchronous motor<br/>1: SYN Synchronous motor control</p> <p><b>The V/f control</b> allows controlling the motor by producing voltage depending on frequency. It is possible to configure several types of V/f patterns (see V/f pattern parameters in the <b>Programming Guide</b>).</p> <p><b>The synchronous motor control</b> enables speed control and torque control of a permanent magnet synchronous motor (PMSM).</p> |                  |



**NOTE** The SYN control requires a position transducer, such as an encoder.

**C011 (C054, C097) Type of Reference (Master/Slave)**

|  |                 |   |   |
|--|-----------------|---|---|
| <b>C011 (mot. n.1)</b><br><b>C054 (mot. n.2)</b><br><b>C097 (mot. n.3)</b> | <b>Range</b>    | 0 ÷ 2   | 0: Speed (MASTER mode)<br>1: Torque (SLAVE mode)<br>2: Torque with speed limit (SLAVE mode) |
|  | <b>Default</b>  | 0   | 0: Speed (MASTER mode)  |
|  | <b>Level</b>    | ADVANCED  |   |
|  | <b>Address</b>  | 1011, 1054, 1097  |   |
|  | <b>Control</b>  | SYN   |   |
|  | <b>Function</b> | <p>This parameter defines the type of reference to be used. The torque control may be set up (see section Torque Control (VTC and FOC Only) as well in the <b>Programming Guide</b>).</p> <p>When the Torque control with speed limit mode is used, the drive will limit the motor rotation to the rpm set in parameter <b>C029 (C072, C115)</b>. This function can be used to automatically toggle from the torque control mode to the speed control mode: when the torque control mode is implemented, the motor speed can reach any value included in the "AB" zone (see Figure 3).</p> <p>If the limit speed is attained due to particular load conditions, the drive will automatically switch to the speed control ("BC" zone). The controlled torque is no longer maintained.</p> <p>If the torque returns to its setpoint value, the drive will automatically switch to the torque control again ("AB" zone).</p> |   |



**Figure 3: Torque control with speed limit**



**C011a (C054a, C097a) Enable Forward Actions over Torque Control**

|   |                 |   |                 |
|---|-----------------|---|-----------------|
| <b>C011a (mot. n.1)<br/>C054a (mot. n.2)<br/>C097a (mot. n.3)</b> | <b>Range</b>    | 0 ÷ 1   | 0: No<br>1: Yes |
|   | <b>Default</b>  | 0   | 0: No           |
|   | <b>Level</b>    | ADVANCED  |                 |
|   | <b>Address</b>  | 634, 636, 638   |                 |
|   | <b>Control</b>  | SYN   |                 |
|   | <b>Function</b> | If the speed control is active ( <b>C011</b> =0), this parameter enables forward actions over torque regulation during acceleration/deceleration. The forward action depends on the load set in <b>C022b</b> and <b>C022c</b> . It is advisable to set parameter <b>C011a (C054a, C097a)</b> to 1 only if parameters <b>C022b</b> and <b>C022c</b> are set to correct values. |                 |

**C011b (C054b, C097b) BEMF Compensation**

|   |                 |  |                 |
|---|-----------------|--|-----------------|
| <b>C011b (mot. n.1)<br/>C054b (mot. n.2)<br/>C097b (mot. n.3)</b> | <b>Range</b>    | 0 ÷ 1  | 0: No<br>1: Yes |
|   | <b>Default</b>  | 0  | 0: No           |
|   | <b>Level</b>    | ADVANCED   |                 |
|   | <b>Address</b>  | 635, 637 639   |                 |
|   | <b>Control</b>  | SYN  |                 |
|   | <b>Function</b> | When in speed control mode or position control mode, this parameter indicates if the back electromotive force (BEMF) is compensated in the current loop starting from the speed reference. This parameter is ignored in torque control mode. If the motor BEMF is known (parameter <b>C015a</b> ), it is advisable to keep the relevant parameter set to Yes; otherwise, BEMF compensation may be kept disabled, but this will slightly affect the system performance. |                 |

**C012 (C055, C098) Feedback from Encoder/Resolver**

|  |                 |   |                 |
|--|-----------------|---|-----------------|
| <b>C012 (mot. n.1)<br/>C055 (mot. n.2)<br/>C098 (mot. n.3)</b> | <b>Range</b>    | 0 ÷ 1   | 0: No<br>1: Yes |
|  | <b>Default</b>  | 0   | 0: No           |
|  | <b>Level</b>    | BASIC   |                 |
|  | <b>Address</b>  | 1012, 1055, 1098  |                 |
|  | <b>Control</b>  | SYN   |                 |
|  | <b>Function</b> | Enables using the position transducer.<br>See the ENCODER/FREQUENCY INPUTS MENU in order to define the characteristics of the position transducer and to define whether encoder A (terminal board MDI6 and MDI7), encoder B (optional board) or the absolute encoder/resolver is used for the speed feedback.<br>If <b>C010=1: SYN</b> , this parameter is automatically set to [1: Yes] and cannot be changed, because the SYN control requires a position transducer. |                 |

**C013 (C056, C099) Type of V/F Pattern**

|  |                 |  |   |
|--|-----------------|--|---|
| <b>C013 (mot. n.1)<br/>C056 (mot. n.2)<br/>C099 (mot. n.3)</b> | <b>Range</b>    | 0 ÷ 2  | 0: Constant Torque<br>1: Quadratic<br>2: Free Setting |
|  | <b>Default</b>  | See relevant Tables in the <b>Programming Guide</b> .  |   |
|  | <b>Level</b>    | BASIC  |   |
|  | <b>Address</b>  | 1013, 1056, 1099   |   |
|  | <b>Control</b>  | IFD  |   |
|  | <b>Function</b> | Enables selecting different types of V/f patterns:<br><br>If <b>C013 (C056, C099) = Constant torque</b> , voltage at zero frequency can be selected (Preboost <b>C034 (C077, C120)</b> ).<br><br>If <b>C013 (C056, C099) = Quadratic</b> you can select: voltage at zero frequency (preboost, <b>C034 (C077,C120)</b> ), maximum voltage drop with respect to the theoretical V/f pattern, <b>C032 (C075 C118)</b> , and the frequency allowing implementing max. voltage drop, <b>C033 (C076, C119)</b> .<br><br>If <b>C013 (C056, C099) = Free setting</b> you can select: voltage at zero frequency (preboost <b>C034 (C077, C120)</b> ); voltage increase to 20% of the rated frequency (Boost0 <b>C035 (C078, C121)</b> ); voltage increase to a programmed frequency (Boost1 <b>C036 (C079, C122)</b> ); frequency for Boost1 <b>C037 (C080, C123)</b> . |   |

**C014 (C057, C100) Phase rotation**

|  |                 |  |                   |
|--|-----------------|--|-------------------|
| <b>C014 (mot. n.1)<br/>C057 (mot. n.2)<br/>C100 (mot. n.3)</b> | <b>Range</b>    | 0÷1  | 0: [No]; 1: [Yes] |
|  | <b>Default</b>  | 0  | 0: [No]           |
|  | <b>Level</b>    | ENGINEERING  |                   |
|  | <b>Address</b>  | 1014, 1057,1100  |                   |
|  | <b>Function</b> | Allows reversing the mechanical rotation of the connected motor. |                   |



**DANGER!!!**

The activation of **C014 (C057, C100)** causes the mechanical rotation of the motor and the connected load to reverse accordingly.

**C015 (C058, C101) Rated Motor Frequency**

|   |          |  |                    |
|---|----------|--|--------------------|
| C015 (mot. n.1)<br>C058 (mot. n.2)<br>C101 (mot. n.3) | Range    | 10 ÷ 10000   | 1.0 Hz ÷ 1000.0 Hz |
|   |          | See upper limits according to the relevant Table in the <b>Programming Guide</b> .   |                    |
|   | Default  | 500  | 50.0 Hz            |
|   | Level    | BASIC  |                    |
|   | Address  | 1015, 1058, 1101   |                    |
|   | Function | <p>This parameter defines the rated motor frequency (nameplate rating). For SYN control, it is to be calculated as follows:<br/> <math>f_{mot} = rpm_{nom}/60 * p</math>, where:<br/> <math>rpm_{nom}</math> is the rated motor speed in rpm<br/> <math>p</math> is the number of pole pairs of the connected motor. Example:<br/> <math>rpm_{nom}=3000rpm</math><br/> <math>p=3</math> pole pairs (6 poles)<br/> <math>f_{mot}=3000/60*3=150</math></p> |                    |

**C015a (C058a, C101a) Back Electromotive Force (BEMF) Constant**

|  |          |   |                         |
|--|----------|---|-------------------------|
| C015a (mot. n.1)<br>C058a (mot. n.2)<br>C101a (mot. n.3) | Range    | 0 ÷ 65000   | 0.00 ÷ 650.00 V/(rad/s) |
|  |          | See upper limits according to the relevant Table in the <b>Programming Guide</b> .  |                         |
|  | Default  | 0   | 0.00 V/(rad/s)          |
|  | Level    | BASIC   |                         |
|  | Address  | 753, 764, 1236  |                         |
|  | Control  | SYN   |                         |
|  | Function | <p>BEMF of the synchronous motor.<br/>                     This parameter may automatically be updated by the relevant tuning command (<b>I074 = 4: SYN BEMF tune</b>).</p> |                         |

**C016 (C059, C102) Rated motor RPM**

|   |          |  |               |
|---|----------|--|---------------|
| C016 (mot. n.1)<br>C059 (mot. n.2)<br>C102 (mot. n.3) | Range    | 1 ÷ 32000  | 1 ÷ 32000 rpm |
|   |          | See upper limits according to the relevant Table in the <b>Programming Guide</b> . |               |
|   | Default  | 1500   | 1500 rpm      |
|   | Level    | BASIC  |               |
|   | Address  | 1016, 1059, 1102   |               |
|   | Function | This parameter defines the rated motor rpm (nameplate rating).                     |               |

**C017 (C060, C103) Rated Motor Power**

|   |          |  |                 |
|---|----------|--|-----------------|
| C017 (mot. n.1)<br>C060 (mot. n.2)<br>C103 (mot. n.3) | Range    | 1 ÷ 32000  | 0.1 ÷ 3200.0 kW |
|   |          | Upper limited to twice the default value                         |                 |
|   | Default  | See relevant tables in the <b>Programming Guide</b> .            |                 |
|   | Level    | BASIC  |                 |
|   | Address  | 1017, 1060, 1103   |                 |
|   | Function | This parameter defines the rated motor power (nameplate rating). |                 |

**C018 (C061, C104) Rated Motor Current**

|   |          |   |                |
|---|----------|---|----------------|
| C018 (mot. n.1)<br>C061 (mot. n.2)<br>C104 (mot. n.3) | Range    | 1 ÷ 32000   | 0.1 ÷ 3200.0 A |
|   |          | See twice the upper values in <b>Inom</b> column in Table 73 and Table 77 in the <b>Programming Guide R07</b> . |                |
|   | Default  | See relevant tables in the <b>Programming Guide</b> .   |                |
|   | Level    | BASIC   |                |
|   | Address  | 1018, 1061, 1104  |                |
|   | Function | This parameter defines the rated motor current (nameplate rating).  |                |

**C019 (C062, C105) Rated Motor Voltage**

|   |  |  |  |
|---|--|--|--|
| C019 (mot. n.1)<br>C062 (mot. n.2)<br>C105 (mot. n.3) | Range  | 50 ÷ 12000   | 5.0 ÷ 1200.0 V   |
|   |  | Default  |  |
|   | 2300 for class 2T drives<br>4000 for class 4T drives<br>5750 for class 5T drives<br>6900 for class 6T drives |  | 230.0V for class 2T drives<br>400.0V for class 4T drives<br>575.0V for class 5T drives<br>690.0V for class 6T drives |
|   | Level  | BASIC  |  |
|   | Address  | 1019, 1062, 1105   |  |
|   | Function   | This parameter defines the rated motor voltage (nameplate rating). |  |

**C020 (C063, C106) No-load Motor Power**

|   |   |                  |              |
|---|---|------------------|--------------|
| C020 (mot. n.1)<br>C063 (mot. n.2)<br>C106 (mot. n.3) | Range   | 0 ÷ 1000         | 0.0 ÷ 100.0% |
|   |   | Default          |              |
|   | 0   |                  | 0.0%         |
|   | Level   | ADVANCED         |              |
|   | Address   | 1020, 1063, 1106 |              |
|   | Control   | IFD              |              |
| Function  | This parameter defines the power absorbed by the motor at rated voltage and rated rpm when no load is connected to the motor. It is expressed as a percentage of the value in parameter <b>C017</b> . |                  |              |

**C021 (C064, C107) No-load Motor Current**

|   |   |                  |          |
|---|---|------------------|----------|
| C021 (mot. n.1)<br>C064 (mot. n.2)<br>C107 (mot. n.3) | Range   | 1 ÷ 100          | 1 ÷ 100% |
|   |   | Default          |          |
|   | 0   |                  | 0%       |
|   | Level   | ADVANCED         |          |
|   | Address   | 1021, 1064, 1107 |          |
|   | Control   | IFD              |          |
| Function  | This parameter defines the current absorbed by the motor at rated voltage and rated rpm when no load is connected to the motor. It is expressed as a percentage of the rated motor current <b>C018 (C061, C104)</b> . |                  |          |



**C022 (C065, C108) Motor Stator Resistance**

|   |          |  |                 |
|---|----------|--|-----------------|
| C022 (mot. n.1)<br>C065 (mot. n.2)<br>C108 (mot. n.3) | Range    | 0 ÷ 32000  | 0.000 ÷ 32.000Ω |
|   | Default  | See relevant tables in the <b>Programming Guide</b> .  |                 |
|   | Level    | ENGINEERING  |                 |
|   | Address  | 1022, 1065, 1108   |                 |
|   | Function | <p>This parameter defines stator resistance <math>R_s</math>.<br/>If a star connection is used, it matches with the value of the resistance of one phase (half the resistance measured between two terminals); if a delta connection is used, it matches with 1/3 of the resistance of one phase.</p> <p>Autotune is always recommended.</p> <p>This parameter may automatically be updated by the relevant tuning command:<br/>                     SYN Control: <b>I074 = 4: SYN BEMF tune</b><br/>                     IFD Control: <b>I074 = 0: IFD Control Auto no Rot.</b></p> |                 |

**C022a (C065a, C108a) Phase Inductance (Synchronous Motor)**

|  |          |  |                  |
|--|----------|--|------------------|
| C022a (mot. n.1)<br>C065a (mot. n.2)<br>C108a (mot. n.3) | Range    | 0 ÷ 65000  | 0.00 ÷ 65.000 mH |
|  | Default  | 0  | 0.00 mH          |
|  | Level    | ENGINEERING  |                  |
|  | Address  | 754, 765, 1237   |                  |
|  | Control  | SYN  |                  |
|  | Function | <p>Single-phase inductance of the synchronous motor.<br/>This parameter may automatically be updated by the relevant tuning command (<b>I074 = 4: SYN BEMF tune</b>)</p> |                  |

**C022b (C065b, C108b) Load Inertia (Synchronous Motor)**

|  |          |   |                                 |
|--|----------|---|---------------------------------|
| C022b (mot. n.1)<br>C065b (mot. n.2)<br>C108b (mot. n.3) | Range    | 0 ÷ 65000   | 0.000 ÷ 65.000 kgm <sup>2</sup> |
|  | Default  | 0   | 0.000 kgm <sup>2</sup>          |
|  | Level    | ENGINEERING   |                                 |
|  | Address  | 755, 766, 1238  |                                 |
|  | Control  | SYN   |                                 |
|  | Function | <p>Moment of inertia of the load. If summed to the value in parameter <b>C022c (C065c, C108c)</b>, the value in this parameter determines the total moment of inertia of the system. In order for the tuning procedure of the speed loop gains selected by <b>I074 = 2: SYN update speed loop</b> to be performed correctly, the total moment of inertia shall be as close as possible to the actual value.</p> <p>The value of this parameter determines the forward action enabled by <b>C011a</b>.</p> |                                 |

**C022c (C065c, C108c) Rotor Inertia (Synchronous Motor)**

|  |          |   |                             |
|--|----------|---|-----------------------------|
| C022c (mot. n.1)<br>C065c (mot. n.2)<br>C108c (mot. n.3) | Range    | 0 ÷ 65000   | 0 ÷ 65000 kgmm <sup>2</sup> |
|  | Default  | 300   | 300 kgmm <sup>2</sup>       |
|  | Level    | ENGINEERING   |                             |
|  | Address  | 756, 767, 1239  |                             |
|  | Control  | SYN   |                             |
|  | Function | Moment of inertia of the rotor. If summed to the value in parameter <b>C022b (C065b, C108b)</b> , the value in this parameter determines the total moment of inertia of the system. In order for the tuning procedure of the speed loop gains selected by <b>I074 = 2: SYN update speed loop</b> to be performed correctly, the total moment of inertia shall be as close as possible to the actual value.<br>The value of this parameter determines the forward action enabled by <b>C011a</b> . |                             |



CAUTION

Parameters C022b (C065b, C108b) and C022c (C065c, C108c) are expressed in two different units of measure: C022b is in kgm<sup>2</sup>, C022c is in kgmm<sup>2</sup>. The relation between the two units of measure is:  
1 kgm<sup>2</sup> = 1000000 kgmm<sup>2</sup>

**C022d (C065d, C108d) Viscous Friction Coefficient (Synchronous Motor)**

|  |          |  |                           |
|--|----------|--|---------------------------|
| C022d (mot. n.1)<br>C065d (mot. n.2)<br>C108d (mot. n.3) | Range    | 0 ÷ 65000                              | 0.00 ÷ 650.00 mNm/(rad/s) |
|  | Default  | 0                                      | 0.00 mNm/(rad/s)          |
|  | Level    | ENGINEERING                            |                           |
|  | Address  | 757, 768, 1240                         |                           |
|  | Control  | SYN                                    |                           |
|  | Function | Sets the viscous friction coefficient. |                           |

**C023 (C066, C109) Motor Leakage Inductance**

|   |          |  |                 |
|---|----------|--|-----------------|
| C023 (mot. n.1)<br>C066 (mot. n.2)<br>C109 (mot. n.3) | Range    | 0 ÷ 32000  | 0.00 ÷ 320.00mH |
|   | Default  | See relevant tables in the <b>Programming Guide</b> .  |                 |
|   | Level    | ENGINEERING  |                 |
|   | Address  | 1023, 1066, 1109   |                 |
|   | Control  | IFD  |                 |
|   | Function | Sets the total leakage inductance of the connected motor.<br>If a star connection is used, it matches with the value of the inductance of one phase; if a delta connection is used, it matches with 1/3 of the inductance of one phase.<br>Autotune is always recommended. |                 |



NOTE

By means of the Autotuning function, calculate the value of the leakage inductance (C023). From the resulting value, manually subtract the value in mH of the output inductance (if any).

**C024 (C067, C110) Mutual Inductance**

|   |          |  |                 |
|---|----------|--|-----------------|
| C024 (mot. n.1)<br>C067 (mot. n.2)<br>C110 (mot. n.3) | Range    | 0 ÷ 65000  | 0.00 ÷ 650.00mH |
|   | Default  | 25000  | 250.00mH        |
|   | Level    | ADVANCED   |                 |
|   | Address  | 1024, 1067, 1110   |                 |
|   | Control  | IFD  |                 |
|   | Function | This parameter defines the mutual inductance of the connected motor.<br>The approximate value of the mutual inductance results from no-load current according to the formula below:<br>$M \cong (V_{mot} - R_{stat} \cdot I_o) / (2\pi f_{mot} \cdot I_o)$ |                 |



**NOTE**

Parameter **C024** (mutual inductance) is **automatically calculated** based on the preset no-load current value (**C021**) whenever parameters **I073** and **I074** are set as follows:

**I073 = [1: Motor Tune]**

**I074 = [0: All no rotation]**

whether current loop tuning is performed or not.

**C026 (C069, C112) Time Constant of Bus Voltage Low-pass Filter**

|   |          |   |                 |
|---|----------|---|-----------------|
| C026 (mot. n.1)<br>C069 (mot. n.2)<br>C112 (mot. n.3) | Range    | 0 ÷ 32000   | 0.0 ÷ 3200.0 ms |
|   | Default  | 0   | 0.0 ms          |
|   | Level    | ENGINEERING   |                 |
|   | Address  | 1026, 1069, 1112  |                 |
|   | Function | This parameter defines the time constant of the low-pass filter of the bus voltage readout.<br>Changing this value can avoid motor oscillations, especially when no load is connected to the motor. |                 |

**C028 (C071, C114) Minimum Motor Speed**

|  |                 |   |                        |
|--|-----------------|---|------------------------|
| <b>C028 (mot. n.1)</b><br><b>C071 (mot. n.2)</b><br><b>C114 (mot. n.3)</b> | <b>Range</b>    | -32000 ÷ 32000 (*)  | -32000 ÷ 32000 rpm (*) |
|  | <b>Default</b>  | 0   | 0 rpm                  |
|  | <b>Level</b>    | BASIC   |                        |
|  | <b>Address</b>  | 1028, 1071, 1114  |                        |
|  | <b>Function</b> | <p>This parameter defines the minimum speed of the connected motor. When references forming the total reference are at their min. relative value, the total reference equals the min. speed of the connected motor.</p> <p><i>Example:</i></p> <p>CONTROL METHOD MENU</p> <p><b>C143</b> → [1: REF]      Selection of reference 1 source<br/> <b>C144</b> → [2: AIN1]     Selection of reference 2 source<br/> <b>C145</b> → [0: Disable]   Selection of reference 3 source<br/> <b>C146</b> → [0: Disable]   Selection of reference 4 source</p> <p>INPUTS FOR REFERENCES MENU</p> <p><b>P050</b> → [0: ±10]    Type of reference for REF input<br/> <b>P051</b> → [- 10V]    Value of the min. reference for REF input<br/> <b>P052</b> → [+10V]    Value of the max. reference for REF input<br/> <b>P055</b> → [0: ±10]    Type of reference for AIN1 input<br/> <b>P056</b> → [- 5 V]    Value of min. reference for AIN1 input<br/> <b>P057</b> → [+5 V]    Value of max. reference for AIN1 input</p> <p>The speed reference is the min. speed set in <b>C028</b> (motor 1) when both REF input and AIN1 input values are lower than or equal to the minimum values set in <b>P051</b> and <b>P056</b> respectively.</p> |                        |



(\*) NOTE

The maximum allowable value (as an absolute value) for **C028** and **C029** (minimum and maximum motor speed) also depends on the preset **maximum carrier frequency** (see Table 63 in the **Programming Guide R.07**). It can be max. 4 times the rated speed of the connected motor.



NOTE

The value set as the min. speed is used as the saturation of the total reference; the speed reference will never be lower than the value set as minimum speed.



NOTE

The minimum speed is not respected only when the REV command or the CW/CCW command is sent after setting a value for max. speed exceeding the minimum value (**C029** > **C028** for motor 1) and with the maximum reference to the drive. The motor rpm will be **-C029** < **C028**.

**C029 (C072, C115) Maximum Motor Speed**

|   |          |  |   |
|---|----------|--|---|
| C029 (mot. n.1)<br>C072 (mot. n.2)<br>C115 (mot. n.3) | Range    | 0 ÷ 32000 (*see note in parameter C028)  | 0 ÷ 32000 rpm (*see note in parameter C028) |
|   | Default  | 1500   | 1500 rpm                                    |
|   | Level    | BASIC  |   |
|   | Address  | 1029, 1072, 1115   |   |
|   | Function | <p>This parameter defines the maximum speed of the connected motor. When references forming the global reference are at their maximum relative value, the global reference equals the max. speed of the connected motor.</p> <p>If C011 (C054, C097) = 2: Torque with speed limit, this parameter is used to limit the motor rotation.</p> |   |



**NOTE**

In the CONTROL METHOD MENU, if an external speed/torque limit source (C147) is selected, the speed limit value set with this parameter is the upper limit, that can be reduced by adjusting the external source. Also, the ramp times set in the RAMPS MENU (P009–P025) are applied to this limit.

**C031 (C074, C117) Maximum Speed Alarm**

|   |          |   |                           |
|---|----------|---|---------------------------|
| C031 (mot. n.1)<br>C074 (mot. n.2)<br>C117 (mot. n.3) | Range    | 0 ÷ 32000   | 0: [Disabled] ÷ 32000 rpm |
|   | Default  | 0   | 0: Disabled               |
|   | Level    | ADVANCED  |                           |
|   | Address  | 1031, 1074, 1117  |                           |
|   | Function | If it is not set to zero, this parameter determines the speed value to be entered for the maximum speed alarm (A076). |                           |

**C032 (C075, C118) Reduction in Quadratic Torque Curve**

|   |          |  |            |
|---|----------|--|------------|
| C032 (mot. n.1)<br>C075 (mot. n.2)<br>C118 (mot. n.3) | Range    | 0 ÷ 1000   | 0 ÷ 100.0% |
|   | Default  | 300  | 30.0%      |
|   | Level    | ADVANCED   |            |
|   | Address  | 1032, 1075, 1118   |            |
|   | Control  | IFD  |            |
|   | Function | If the V/f curve pattern C013 (C056, C099) = Quadratic, this parameter defines the maximum voltage reduction in terms of theoretical V/f pattern, which is implemented at the frequency programmed in C033 (C076, C119). |            |

**C033 (C076, C119) Frequency for Maximum Reduction in Quadratic Torque Curve**

|  |                 |   |          |
|--|-----------------|---|----------|
| <b>C033 (mot. n.1)<br/>C076 (mot. n.2)<br/>C119 (mot. n.3)</b> | <b>Range</b>    | 1 ÷ 100   | 1 ÷ 100% |
|  | <b>Default</b>  | 20  | 20%      |
|  | <b>Level</b>    | ADVANCED  |          |
|  | <b>Address</b>  | 1033, 1076, 1119  |          |
|  | <b>Control</b>  | IFD   |          |
|  | <b>Function</b> | If the V/f pattern <b>C013 (C056, C099) = Quadratic</b> , this parameter defines the frequency implementing the maximum torque reduction in terms of theoretical V/f pattern set in <b>C032 (C075, C120)</b> (see section V/F Pattern Parameters in the <b>Programming Guide</b> ). |          |

**C034 (C077, C120) Torque Curve Increment Preboost**

|  |                 |   |             |
|--|-----------------|---|-------------|
| <b>C034 (mot. n.1)<br/>C077 (mot. n.2)<br/>C120 (mot. n.3)</b> | <b>Range</b>    | 0 ÷ 50  | 0.0 ÷ 5.0 % |
|  | <b>Default</b>  | See relevant tables in the <b>Programming Guide</b> .   |             |
|  | <b>Level</b>    | BASIC   |             |
|  | <b>Address</b>  | 1034, 1077, 1120  |             |
|  | <b>Control</b>  | IFD   |             |
|  | <b>Function</b> | Torque compensation at minimum frequency produced by the drive. Determines the increase of the output voltage at 0Hz. |             |

**C035 (C078, C121) Torque Curve Increment Boost 0**

|  |                 |  |               |
|--|-----------------|--|---------------|
| <b>C035 (mot. n.1)<br/>C078 (mot. n.2)<br/>C121 (mot. n.3)</b> | <b>Range</b>    | -100 ÷ +100  | -100 ÷ +100 % |
|  | <b>Default</b>  | See relevant tables in the <b>Programming Guide</b> .  |               |
|  | <b>Level</b>    | ADVANCED   |               |
|  | <b>Address</b>  | 1035, 1078, 1121   |               |
|  | <b>Control</b>  | IFD  |               |
|  | <b>Function</b> | Torque compensation at low rpm. Determines how output voltage varies at 5% of the rated motor frequency with respect to the voltage obtained with a constant V/f pattern (constant voltage frequency). |               |

**C036 (C079, C122) Torque Curve Increment Boost 1**

|   |          |   |               |
|---|----------|---|---------------|
| C036 (mot. n.1)<br>C079 (mot. n.2)<br>C122 (mot. n.3) | Range    | -100 ÷ +400   | -100 ÷ +400 % |
|   | Default  | See relevant tables in the <b>Programming Guide</b> .   |               |
|   | Level    | ADVANCED  |               |
|   | Address  | 1036, 1079, 1122  |               |
|   | Control  | IFD   |               |
|   | Function | Torque compensation at preset frequency (parameter <b>C037</b> for motor 1, <b>C080</b> for motor 2 and <b>C123</b> for motor 3). Determines how output voltage varies at preset frequency with respect to voltage obtained with a constant V/f pattern (constant voltage frequency). |               |

**C037 (C080, C123) RPM Relating to C36 (C079,C122) (Frequency for Application of Boost 1)**

|   |          |   |          |
|---|----------|---|----------|
| C037 (mot. N.1)<br>C080 (mot. n.2)<br>C123 (mot. n.3) | Range    | 6 ÷ 99  | 6 ÷ 99 % |
|   | Default  | See relevant tables in the <b>Programming Guide</b> .   |          |
|   | Level    | ADVANCED  |          |
|   | Address  | 1037, 1080, 1123  |          |
|   | Control  | IFD   |          |
|   | Function | Frequency for application of voltage Boost with parameter <b>C036</b> for motor 1, parameter <b>C079</b> for motor 2 and parameter <b>C122</b> for motor 3. This is expressed as a percentage of the rated motor frequency. |          |

**C038 (C081, C124) Torque Curve Automatic Increment**

|   |          |   |          |
|---|----------|---|----------|
| C038 (mot. n.1)<br>C081 (mot. n.2)<br>C124 (mot. n.3) | Range    | 0 ÷ 10  | 0 ÷ 10 % |
|   | Default  | See relevant tables in the <b>Programming Guide</b> .   |          |
|   | Level    | ADVANCED  |          |
|   | Address  | 1038, 1081, 1124  |          |
|   | Control  | IFD   |          |
|   | Function | Variable torque compensation expressed as a percentage of the rated motor voltage. The preset value expresses the voltage increase when the motor is running at its rated torque. |          |

**C039 (C082, C125) Slip Compensation**

|   |          |  |                       |
|---|----------|--|-----------------------|
| C039 (mot. n.1)<br>C082 (mot. n.2)<br>C125 (mot. n.3) | Range    | 0 ÷ 200  | [0: Disabled] ÷ 200 % |
|   | Default  | 0  | [0: Disabled]         |
|   | Level    | ADVANCED   |                       |
|   | Address  | 1039, 1082, 1125   |                       |
|   | Control  | IFD  |                       |
|   | Function | This parameter represents the rated motor slip expressed as a value percent. If set to 0, this function is disabled. |                       |

**C040 (C083, C126) Voltage Drop at Rated Current**

|   |          |  |             |
|---|----------|--|-------------|
| C040 (mot. n.1)<br>C083 (mot. n.2)<br>C126 (mot. n.3) | Range    | 0÷500  | 0÷50.0%     |
|   | Default  | 0  | 0: Disabled |
|   | Level    | ADVANCED   |             |
|   | Address  | 1040, 1083, 1126   |             |
|   | Control  | IFD  |             |
|   | Function | <p>Defines the increase in voltage (in terms of the corresponding produced frequency) when the current produced by the motor is greater than or equal to the rated current.</p> <p>For example:</p> <p><b>C040 = 10%</b>                      Voltage drop at rated current<br/> <b>C013 = Constant Torque</b>    Type of V/f pattern<br/> <b>C015 = 50 Hz</b>                    Rated frequency<br/> <b>C019 = 380 V</b>                    Rated voltage</p> <p>If the drive output frequency is 25 Hz, it must deliver 190V. When the output current is equal to the rated current of the motor (<b>C018</b>), the voltage actually produced is</p> <p><math>V_{out} = 190 * (1 + C040/100) = 209V.</math></p> |             |

**C042 (C085, C0128) Vout Saturation Percentage**

|   |          |  |            |
|---|----------|--|------------|
| C042 (mot. n.1)<br>C085 (mot. n.2)<br>C128 (mot. n.3) | Range    | 10 ÷ 120   | 10 ÷ 120 % |
|   | Default  | 100  | 100%       |
|   | Level    | ENGINEERING  |            |
|   | Address  | 1042, 1085, 1128   |            |
|   | Function | <p>This parameter sets the bus voltage value percent used to generate the output voltage of the drive.</p> <p>Changes made to this parameter affect the motor performance in terms of defluxing.</p> |            |



## 7.6. DIGITAL INPUTS MENU

The following parameter has been added to the Digital Inputs menu for the Synchronous Motor application:

### C188d MDI for SYN Alignment Request

|              |                 |  |   |
|--------------|-----------------|--|---|
| <b>C188d</b> | <b>Range</b>    | 0 ÷ 16<br>0 ÷ 24 if ES847 or ES870 is fitted   | 0 → Inactive<br>1 ÷ 8 → MDI1 ÷ MDI8<br>9 ÷ 12 → MPL1 ÷ MPL4<br>13 ÷ 16 → TFL1 ÷ TFL4<br>17 ÷ 24 → XMDI1 ÷ XMDI8 |
|              | <b>Default</b>  | 0  | Inactive  |
|              | <b>Level</b>    | ADVANCED   |   |
|              | <b>Address</b>  | 1149   |   |
|              | <b>Function</b> | Request for performing the synchronous motor alignment procedure.<br>Do the following: enable the input specified by the parameter, then close the <b>ENABLE</b> and <b>START</b> input. |   |



**CAUTION**

The alignment procedure will make the motor run. Make sure that the motor can rotate freely (no mechanical constraints or heavy loads).

## 7.7. ENCODER/FREQUENCY INPUTS MENU

---

### 7.7.1. OVERVIEW

Three quick acquisition digital inputs are available in the Sinus Penta control board:

- MDI6/ECHA/FINA;
- MDI7/ECHB;
- MDI8/FINB

These inputs can be used as incremental encoder reading (encoder A) or as frequency inputs. In addition, if optional board **ES836** or **ES913** is used (see the Sinus Penta's **Installation Guide**), an additional encoder reading (encoder B) is allowed.

Optional boards **ES860** (3-channel or 5-channel SinCos encoder), **ES861** (resolver), **ES950** (EnDat encoder or BiSS absolute encoders), **ES966** (HIPERFACE absolute encoder) make it possible to interface with that type of transducers for motor control purposes.



**NOTE** If **MDI6** and **MDI7** are used for encoder reading, only Push–Pull encoders can be used.



**NOTE** For the reversal of the incremental encoder speed measure, properly set up parameter **C199**.

### 7.7.2. WHEN THE OPTIONAL BOARD IS NOT USED

#### • Incremental Encoder reading:

Digital inputs **MDI6** and **MDI7** are used for reading the two channels of a 24V push–pull encoder powered directly by the Sinus Penta control board (see the Sinus Penta's **Installation Guide**).

No function can be programmed for **MDI6** and **MDI7**; when trying to program **MDI6** and **MDI7**, alarm **A082** Illegal Encoder Configuration will trip when **ENABLE** closes.

#### • Reading a Frequency Input:

Digital inputs **MDI6** or **MDI8** can be used.

If **MDI6** is programmed as a frequency input (**FINA**) with **C189**, no other function can be programmed; otherwise, alarm **A100** MDI6 Illegal Configuration trips when **ENABLE** closes.

If **MDI8** is programmed as a frequency input (**FINB**) with **C189**, no other function can be allocated to MDI8, and **ES836** or **ES913** option board must not be applied to the power drive, otherwise, alarm **A101** MDI8 Illegal Configuration trips when **ENABLE** closes.

#### • Reading a Frequency Input and an Encoder:

**MDI6** and **MDI7** are used to read the push–pull encoder, and **MDI8** is used to read the frequency input. The following alarms may trip:

- **A082** Illegal Encoder Configuration, if additional functions are allocated to **MDI6** or **MDI7**;
- **A101** MDI8 Illegal Configuration, if additional functions are allocated to **MDI8** or if the power drive detects the presence of optional board **ES836** or **ES913**.



**NOTE** If an optional board for absolute encoder/resolver is fitted into slot C, digital inputs **MDI6** and **MDI7** may not be used for encoder acquisition.

### 7.7.3. WHEN USING ES836 OR ES913

- **Reading 1 or 2 Incremental Encoders:**

To read one Encoder, use the optional board or digital inputs **MDI6** and **MDI7** (if a push-pull encoder is used).

Both the optional board and digital inputs **MDI6** and **MDI7** can be used to read two encoders at a time. Use parameter **C189** to set the readout of the speed measure of the controlled motor or to read reference values. You can use encoder **A** or encoder **B** as a speed feedback or a reference source (speed reference, torque reference or PID reference).

For example:

If you want to use encoder **A** as a speed reference source and encoder **B** as a speed feedback, set **C189** as 6:[A Ref ; B Fbk]; use **P073** and **P074** (INPUTS FOR REFERENCES MENU) to define the minimum speed and the maximum speed read for scaling and saturation of encoder **A** selected as a reference source (in one of parameters **C144** ÷ **C147**, CONTROL METHOD MENU); set parameter **C012** (motor 1) to [Yes] to enable the Speed Feedback from Encoder function.

If encoder **A** is selected, no function can be programmed for **MDI6** and **MDI7**; otherwise, alarm **A082 Illegal Encoder Configuration** will trip when **ENABLE** closes.

If encoder **B** is selected and **ES836** or **ES913** option board is not detected by the drive, alarm **A082 Illegal Encoder Configuration** will trip when **ENABLE** closes.

- **Reading a Frequency Input:**

Only **MDI6** digital input (FINA) can be used as a frequency input; if **MDI8** is programmed as a frequency input (FINB) with **C189**, if the option board is installed, alarm **A101 MDI8 Illegal Configuration** trips.

No additional function must be assigned to **MDI6**; otherwise, alarm **A100 MDI6 Illegal Configuration** will trip when **ENABLE** closes.

- **Reading a Frequency Input and an Incremental Encoder:**

**MDI6** Digital input (FINA) is used as a frequency input and Encoder **B** is used (because **ES836** or **ES913** board avoids reading frequency input FINB through **MDI8**).

If additional functions are programmed for digital input **MDI6**, alarm **A100 MDI6 Illegal Configuration** will trip when **ENABLE** closes.

If alarm **A082 Illegal Encoder Configuration** trips, this means that the drive has not detected **ES836** or **ES913** board (check the board wiring).

Parameter **C189** defines whether quick acquisition digital inputs are used to read a frequency input or an encoder, and if the encoder is a reference source or a feedback source.

In the **Encoder Menu**, you can also do the following:

- define the number of plr/rev for the encoder being used;
- enable or disable the speed alarm;
- define a time constant applied to read filtering;
- define whether encoders are read by means of squaring channels or by channel **A** only (while the direction of rotation will be defined by channel **B**: ChB low level → negative rotation; ChB high level → positive rotation).

## 7.7.4. WITH OPTIONAL BOARDS FOR ABSOLUTE POSITION TRANSDUCERS

### 7.7.4.1. BOARDS INTO SLOT C

Acquisition boards for absolute encoders may be inserted into slot C. Some of these boards enable interfacing with one incremental line-driver encoder.

| Board | Absolute Transducer                            | Incremental Transducer                                       |
|-------|--|--|
| ES861 | Resolver                                       | Incremental encoder<br>Incr. encoder simulated from resolver |
| ES950 | EnDat Encoder<br>BiSS Encoder                  | Incremental encoder  |
| ES966 | HIPERFACE Encoder<br>5-channel Sin/Cos Encoder | Incremental encoder<br>3-channel Sin/Cos encoder             |

The type of absolute transducer is selected by parameter **R023a** (see EXPANSION BOARD CONFIGURATION MENU). If **R023a** > 0, the selected absolute transducer will automatically be used for the motor feedback regardless of the value set in parameter **C189**.

On board ES861, the type of incremental transducer acquired as encoder **A** is selected by parameter **R023b**:

- **R023b**=1: Enc. incr. on Exp. Board – incremental, line-driver encoder
- **R023b**=2: Resolver to Encoder – conversion from resolver to encoder

On the other boards, regardless of **R023b**, the incremental encoder (if any) is encoder **A** and may be programmed by way of parameters **C189** and **C190**. In the event of an encoder simulated from a resolver, the number of pulses will be **1024**, regardless of the value set in **C190**.

If that encoder is set as feedback (**C189**=1, 5, 7, 14):

- If **R023a**=0, encoder A will be used as the motor feedback
- If **R023a**>0, encoder A will be used only as PID feedback (refer to the PID CONFIGURATION MENU in the **Programming Guide**), because the motor feedback is assigned to the absolute transducer selected by **R023a**.

On board ES966, the 3-channel Sin/Cos encoder is acquired as encoder **B** by setting parameter **R023b** to 3: SinCos 3 Ch.

If that encoder is set as feedback (**C189**=3, 6, 8, 13):

- If **R023a**=0, encoder B will be used as the motor feedback
- If **R023a**>0, encoder B will be used only as PID feedback (refer to the PID CONFIGURATION MENU in the **Programming Guide**) because the motor feedback is assigned to the absolute transducer selected by **R023a**.

### 7.7.4.2. ES860 OPTIONAL BOARD INTO SLOT A

An acquisition board for 3-channel or 5-channel Sin/Cos encoder board (ES860) may be fitted into slot A. The type of encoder is selected:

- by parameter **R023a**=5: SinCos 5 Ch, for 5-channel Sin/Cos encoder (absolute sensor). In that case, the sensor is used as a motor feedback for parameter **C189**
- by parameter **R023b**=3: SinCos 3 Ch, for 3-channel Sin/Cos (incremental sensor). In that case, the sensor is used as the motor feedback only if **R023a**=0 and **C189**=3, 6, 8, 13

### 7.7.5. LIST OF PARAMETERS C189 TO C199

Table 8: List of Parameters C189 ÷ C199

| Parameter | FUNCTION  | User Level  | MODBUS Address | DEFAULT VALUES        |
|-----------|---|-------------|----------------|-----------------------|
| C189      | Encoder/Frequency input operating mode                    | BASIC       | 1189           | 0 [Not used]          |
| C190      | Number of pls/rev for encoder A                           | BASIC       | 1190           | 1024                  |
| C191      | Number of pls/rev for encoder B                           | BASIC       | 1191           | 1024                  |
| C192      | Speed searching error timeout                             | ENGINEERING | 1192           | 5.00 sec              |
| C193      | Error between reference and speed                         | ENGINEERING | 1193           | 300 rpm               |
| C194      | Tracking error alarm enable                               | ENGINEERING | 1194           | 1: Active             |
| C195      | Filter time constant over value of feedback from encoder  | ENGINEERING | 1195           | 5.0 ms                |
| C196      | Filter time constant over value of reference from encoder | ENGINEERING | 1196           | 5.0 ms                |
| C197      | Number of channels of Encoder A                           | ENGINEERING | 1197           | 0:2 Squaring channels |
| C198      | Number of channels of Encoder B                           | ENGINEERING | 1198           | 0:2 Squaring channels |
| C199      | Encoder sign reversal                                     | ENGINEERING | 1199           | 0[Fdbk.NO;Ref.NO]     |
| C201      | Resolver excitation frequency                             | ENGINEERING | 1201           | 1: 10kHz              |
| C202      | EXC+ Adjustment   | ENGINEERING | 1202           | 75                    |
| C203      | EXC- Adjustment   | ENGINEERING | 1203           | 75                    |

**C189 Encoder/Frequency Input Operating Mode**

|             |                 |  |                        |
|-------------|-----------------|--|------------------------|
| <b>C189</b> | <b>Range</b>    | 0 ÷ 14   | See Table 11           |
|             | <b>Default</b>  | 0  | 0 [Not used; Not used] |
|             | <b>Level</b>    | BASIC  |                        |
|             | <b>Address</b>  | 1189   |                        |
|             | <b>Function</b> | <p>This parameter determines the operating mode of quick acquisition digital inputs or encoders connected to optional boards. If <b>MDI8</b> is used as a frequency input, the option board for encoder B is not required. <b>MDI6</b> digital input may be used as a frequency input; if used along with <b>MDI7</b>, it can be used for encoder A reading.</p> <p>Reading both encoders A and B can be programmed; parameter <b>C189</b> defines the encoder to be used as a reference source (if set as a speed/torque reference source in the MOTOR CONTROL MENU or as a reference source of the PID CONFIGURATION MENU in the <b>Programming Guide</b>) and the encoder to be used as a speed feedback. Configuration allowed for quick acquisition digital inputs is given in Table 11.</p> <p>The matching between the different physical encoders and logic encoders <b>A</b> and <b>B</b> is given in Table 9 and Table 10.</p> <p>If the encoder is used as a reference source, the detected speed value will be saturated and scaled based on the values set in <b>P073</b> and <b>P074</b> respectively (minimum and maximum value for the encoder).<br/> <i>Example:</i><br/> <b>C189</b> [A Reference; B Unused], <b>P073</b> [-1500rpm], <b>P074</b> [1500rpm] if the encoder is used as a PID reference, the reference measure is expressed as a percentage of the max. value [ <b>P073</b> ;  <b>P074</b> ].</p> <p><b><u>If a frequency input is selected, its readout is saturated and scaled based on parameters P071 and P072 respectively (minimum and maximum value for the frequency input).</u></b></p> |                        |



**NOTE**

If parameter **R023a** is >0, the transducer selected by that parameter will be used as the motor feedback, regardless of the value in **C189**.

In that case, encoder A or B selected as the feedback encoder in parameter **C189** will act as the PID feedback only (see the PID CONFIGURATION MENU in the **Programming Guide**).



**NOTE**

If a board acquiring absolute position transducer is fitted, such as **ES861**, **ES950**, **ES966**, inputs **MDI6** and **MDI7** cannot be used as push-pull encoder inputs. Consequently, encoder A will be the incremental encoder connected to the acquisition board.

**Table 9: Matching between physical encoders and logic encoder A**

| <b>R023b</b> | <b>Encoder A</b>   |
|--------------|--|
| 1            | Incremental encoder on optional board <b>ES861</b>   |
| 2            | Simulated encoder from resolver on optional board <b>ES861</b>   |
| any          | <ul style="list-style-type: none"> <li>• Incremental encoder on optional boards <b>ES950</b>, <b>ES966</b></li> <li>• Incremental encoder on optional boards <b>MDI6/MDI7</b> if no board is fitted into slot C</li> </ul> |

Table 10: Matching between physical encoders and logic encoder B

| R023b | Encoder B   |
|-------|---|
| 3     | SinCos encoder on optional board <b>ES860</b>   |
| any   | <ul style="list-style-type: none"> <li>Incremental encoder on optional board ES836/ES913</li> <li>Frequency input <b>MDI8</b> if no optional board is fitted into slot A</li> </ul> |

Table 11: Coding of C189

| Value | When using Encoder A/FINA          | When using Encoder B/FINB          |
|-------|------------------------------------|------------------------------------|
| 0     | <i>Not used</i>                    | <i>Not used</i>                    |
| 1     | <b>EncA Feedback</b>               | <i>Not used</i>                    |
| 2     | <b>EncA Reference</b>              | <i>Not used</i>                    |
| 3     | <i>Not used</i>                    | <b>EncB Feedback</b>               |
| 4     | <i>Not used</i>                    | <b>EncB Reference</b>              |
| 5     | <b>EncA Feedback</b>               | <b>EncB Reference</b>              |
| 6     | <b>EncA Reference</b>              | <b>EncB Feedback</b>               |
| 7     | <b>EncA Reference and Feedback</b> | <i>Not used</i>                    |
| 8     | <i>Not used</i>                    | <b>EncB Reference and Feedback</b> |
| 9     | <b>MDI6 Frequency Input</b>        | <i>Not used</i>                    |
| 10    | <i>Not used</i>                    | <b>MDI8 Frequency Input</b>        |
| 11    | <b>MDI6 Frequency Input</b>        | <b>EncB Reference</b>              |
| 12    | <b>EncA Reference</b>              | <b>MDI8 Frequency Input</b>        |
| 13    | <b>MDI6 Frequency Input</b>        | <b>EncB Feedback</b>               |
| 14    | <b>EncA Feedback</b>               | <b>MDI8 Frequency Input</b>        |

Values 7-8: the same encoder can be used both as a reference source and as a reference feedback. Value 7: encoder A can be used both as a speed feedback for the motor control and as a PID regulator reference.

#### C190 Number of Pls/Rev for Encoder A

| C190 | Range    | 256 ÷ 10000   | 256 ÷ 10000 pulses/rev |
|------|----------|---|------------------------|
|      | Default  | 1024  | 1024 pulses/rev        |
|      | Level    | BASIC   |                        |
|      | Address  | 1190  |                        |
|      | Function | Defines the number of pulses per revolution of encoder A (see Table 9). |                        |

#### C191 Number of Pls/Rev for Encoder B

| C191 | Range    | 256 ÷ 10000  | 256 ÷ 10000 pulses/rev |
|------|----------|--|------------------------|
|      | Default  | 1024   | 1024 pulses/rev        |
|      | Level    | BASIC  |                        |
|      | Address  | 1191   |                        |
|      | Function | Defines the number of pulses per revolution of encoder B (see Table 10). |                        |

**C192 Timeout for Speed Alarm**

|             |                 |   |                   |
|-------------|-----------------|---|-------------------|
| <b>C192</b> | <b>Range</b>    | 0 ÷ 65000   | 0.00 ÷ 650.00 sec |
|             | <b>Default</b>  | 500   | 5.00 sec          |
|             | <b>Level</b>    | ENGINEERING   |                   |
|             | <b>Address</b>  | 1192  |                   |
|             | <b>Function</b> | If the speed alarm (C194) is enabled and the speed error exceeds the speed threshold (C193), this parameter determines the speed error timeout. Even if the alarm speed is disabled, the time set in C192 and the error threshold set in C193 are used to signal a speed searching error to digital outputs set with BRAKE or LIFT mode. Digital outputs are then disabled. |                   |

**C193 Speed Error Threshold**

|             |                 |   |               |
|-------------|-----------------|---|---------------|
| <b>C193</b> | <b>Range</b>    | 0 ÷ 32000   | 0 ÷ 32000 rpm |
|             | <b>Default</b>  | 300   | 300 rpm       |
|             | <b>Level</b>    | ENGINEERING   |               |
|             | <b>Address</b>  | 1193  |               |
|             | <b>Function</b> | If the speed alarm (C194) is enabled and the speed error exceeds the speed threshold (C193), this parameter determines the error threshold for the speed error timeout. Even if the alarm speed is disabled, the time set in C192 and the error threshold set in C193 are used to signal a speed searching error to digital outputs set with BRAKE or LIFT mode. Digital outputs are then disabled. |               |

**C194 Speed Error Enable**

|             |                 |   |                           |
|-------------|-----------------|---|---------------------------|
| <b>C194</b> | <b>Range</b>    | 0 ÷ 1   | 0: Disabled<br>1: Enabled |
|             | <b>Default</b>  | 1   | 1: Enabled                |
|             | <b>Level</b>    | ENGINEERING                                   |                           |
|             | <b>Address</b>  | 1194  |                           |
|             | <b>Function</b> | This parameter enables the speed error alarm. |                           |

**C195 Filter Time Constant over Value of Feedback from Encoder**

|             |                 |  |               |
|-------------|-----------------|--|---------------|
| <b>C195</b> | <b>Range</b>    | 0 ÷ 30000  | 5 ÷ 3000.0 ms |
|             | <b>Default</b>  | 50   | 5.0 ms        |
|             | <b>Level</b>    | ENGINEERING  |               |
|             | <b>Address</b>  | 1195   |               |
|             | <b>Function</b> | This parameter defines the time constant used for filtering the reading of the encoder used as a speed feedback. |               |

**C196 Filter Time Constant over Value of Reference from Encoder**

|             |                 |   |               |
|-------------|-----------------|---|---------------|
| <b>C196</b> | <b>Range</b>    | 0 ÷ 30000   | 5 ÷ 3000.0 ms |
|             | <b>Default</b>  | 50  | 5.0 ms        |
|             | <b>Level</b>    | ENGINEERING   |               |
|             | <b>Address</b>  | 1196  |               |
|             | <b>Function</b> | This parameter defines the time constant used for filtering the reading of the encoder used as a reference. |               |



**C197 Number of Channels of Encoder A**

|             |                 |   |   |
|-------------|-----------------|---|---|
| <b>C197</b> | <b>Range</b>    | 0 ÷ 1   | 0: 2 Squaring Channels<br>1: Channel only |
|             | <b>Default</b>  | 0   | 0: 2 Squaring Channels                    |
|             | <b>Level</b>    | ENGINEERING   |   |
|             | <b>Address</b>  | 1197  |   |
|             | <b>Function</b> | This parameter defines the number of channels used for encoder A reading. Factory-setting is 2 Squaring channels. Speed can be read through one channel only (as for phonic wheel); channel 2 can define the direction of rotation (low level → negative rotation; high level → positive rotation). |   |

**C198 Number of Channels of Encoder B**

|             |                 |  |   |
|-------------|-----------------|--|---|
| <b>C198</b> | <b>Range</b>    | 0 ÷ 1  | 0: 2 Squaring channels<br>1: Channel only |
|             | <b>Default</b>  | 0  | 0: 2 Squaring channels                    |
|             | <b>Level</b>    | ENGINEERING  |   |
|             | <b>Address</b>  | 1198   |   |
|             | <b>Function</b> | This parameter defines the number of channels used for encoder B reading (see parameter <b>C197</b> ). |   |

**C199 Encoder Sign Reversal**

|             |                 |  |                       |
|-------------|-----------------|--|-----------------------|
| <b>C199</b> | <b>Range</b>    | 0 ÷ 3  | See Table 12          |
|             | <b>Default</b>  | 0  | 0 [Fdbk. NO; Ref. NO] |
|             | <b>Level</b>    | ENGINEERING  |                       |
|             | <b>Address</b>  | 1199   |                       |
|             | <b>Function</b> | This parameter permits to reverse the speed sign measured by encoder inputs. |                       |



**NOTE**

When tuning the encoder, the encoder sign used as feedback is automatically adjusted to the direction of rotation of the connected motor.



**NOTE**

If a sign reversal of the encoder feedback is selected (**C199**=1 or 3), this will only affect the encoder set as feedback through **C189**, and will not affect the absolute encoder on optional board defined by **R023a**.

Table 12: Coding of C199

| Value | Feedback Encoder Sign Reversal | Reference Encoder Sign Reversal |
|-------|--------------------------------|---------------------------------|
| 0     | Fdbk. NO                       | Ref. NO                         |
| 1     | Fdbk. YES                      | Ref. NO                         |
| 2     | Fdbk. NO                       | Ref. YES                        |
| 3     | Fdbk. YES                      | Ref. YES                        |

C201 Resolver Excitation Frequency

|             |          |  |  |
|-------------|----------|--|--|
| <b>C201</b> | Range    | 0 ÷ 4  | 1: 10kHz<br>2: 12kHz<br>3: 15kHz<br>4: 20kHz |
|             | Default  | 1  | 1: 10kHz                                     |
|             | Level    | ENGINEERING  |  |
|             | Address  | 1201   |  |
|             | Function | This parameter is active if the resolver is selected as a position sensor ( <b>R023a=1</b> ).<br>Sets the value of the excitation frequency based on the sensor ratings. |  |

C202 EXC+ Adjustment

|             |          |   |         |
|-------------|----------|---|---------|
| <b>C202</b> | Range    | 0 ÷ 255   | 0 ÷ 255 |
|             | Default  | 75  | 75      |
|             | Level    | ENGINEERING   |         |
|             | Address  | 1202  |         |
|             | Function | This parameter is active if the resolver is selected as a position sensor ( <b>R023a=1</b> ).<br>Adjustment value (+) of the potentiometer for the resolver excitation signal.<br>Adjustment is manual. Measure <b>M125</b> is a useful feedback. |         |

C203 EXC- Adjustment

|             |          |   |         |
|-------------|----------|---|---------|
| <b>C202</b> | Range    | 0 ÷ 255   | 0 ÷ 255 |
|             | Default  | 75  | 75      |
|             | Level    | ENGINEERING   |         |
|             | Address  | 1203  |         |
|             | Function | This parameter is active if the resolver is selected as a position sensor ( <b>R023a=1</b> ).<br>Adjustment value (-) of the potentiometer for the resolver excitation signal.<br>Adjustment is manual. Measure <b>M125</b> is a useful feedback. |         |

## 7.8. EXPANSION BOARD CONFIGURATION MENU

### 7.8.1. OVERVIEW

The parameters in this menu configure the expansion boards.

In particular, parameters **R023a** and **R023b**, along with **C189** (see ENCODER/FREQUENCY INPUTS MENU), define the function of the position sensors/encoders. The encoder configurations are given in the table below. Parameter **C189** is referred to logic encoders **A** and **B**. Encoder **M** is the absolute encoder used for motor control.

Table 13: Possible encoder configurations

| Board (slot) | R023a | R023b | Description   |
|--------------|-------|-------|---|
| ES860 (A)    | -     | 3     | <b>Encoder A:</b> Inputs MDI6 and MDI7<br><b>Encoder B:</b> 3-channel Sin/Cos on ES860<br><b>Motor control encoder:</b> Defined by <b>C189</b>  |
|              | 5     | 0     | <b>Encoder M:</b> 5-channel Sin/Cos encoder on ES860 (if ES966 is not fitted into slot C)<br><b>Encoder A:</b> Inputs MDI6 and MDI7<br><b>Encoder B:</b> -<br><b>Motor control encoder:</b> Encoder M (5-channel SinCos encoder)  |
| ES861 (C)    | 0     | 1     | <b>Encoder A:</b> Incremental encoder on ES861<br><b>Encoder B:</b> Frequency input MDI8 (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)<br><b>Motor control encoder:</b> Defined by <b>C189</b>  |
|              |       | 2     | <b>Encoder A:</b> Incremental encoder simulated from resolver on ES861<br><b>Encoder B:</b> Frequency input MDI8 (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)<br><b>Motor control encoder:</b> Defined by <b>C189</b>  |
|              | 1     | 0     | <b>Encoder M:</b> Resolver on ES861<br><b>Encoder A:</b> -<br><b>Encoder B:</b> Frequency input MDI8 (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)<br><b>Motor control encoder:</b> Encoder M (resolver).<br>Encoders A and B may be used as a PID feedback or reference based on the configuration of <b>C189</b> .  |
|              |       | 1     | <b>Encoder M:</b> Resolver on ES861<br><b>Encoder A:</b> Incremental encoder on ES861<br><b>Encoder B:</b> Frequency input MDI8 (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)<br><b>Motor control encoder:</b> Encoder M (resolver).<br>Encoders A and B may be used as a PID feedback or reference based on the configuration of <b>C189</b> .                         |
|              |       | 2     | <b>Encoder M:</b> Resolver on ES861<br><b>Encoder A:</b> Incremental encoder simulated from resolver on ES861<br><b>Encoder B:</b> Frequency input MDI8 (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)<br><b>Motor control encoder:</b> Encoder M (resolver).<br>Encoders A and B may be used as a PID feedback or reference based on the configuration of <b>C189</b> . |
|              |       | 2     | <b>Encoder M:</b> Resolver on ES861<br><b>Encoder A:</b> Incremental encoder simulated from resolver on ES861<br><b>Encoder B:</b> Frequency input MDI8 (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)<br><b>Motor control encoder:</b> Encoder M (resolver).<br>Encoders A and B may be used as a PID feedback or reference based on the configuration of <b>C189</b> . |

|           |     |   |  |
|-----------|-----|---|--|
| ES950 (C) | 0   | - | <p><b>Encoder A:</b> Incremental encoder on ES950</p> <p><b>Encoder B:</b> Frequency input <b>MDI8</b> (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)</p> <p><b>Motor control encoder:</b> Defined by <b>C189</b></p>   |
|           | 2/3 | - | <p><b>Encoder M:</b> EnDat/BiSS encoder on ES861</p> <p><b>Encoder A:</b> Incremental encoder on ES950</p> <p><b>Encoder B:</b> Frequency input <b>MDI8</b> (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)</p> <p><b>Motor control encoder:</b> Encoder M (EnDat/BiSS).</p> <p>Encoders A and B may be used as a PID feedback or reference based on the configuration of <b>C189</b>.</p>                       |
| ES966     | 0   | - | <p><b>Encoder A:</b> Incremental encoder on ES966</p> <p><b>Encoder B:</b> Frequency input <b>MDI8</b> (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)</p> <p><b>Motor control encoder:</b> Defined by <b>C189</b></p>   |
|           | 4   | - | <p><b>Encoder M:</b> HIPERFACE encoder on ES966</p> <p><b>Encoder A:</b> Incremental encoder on ES966</p> <p><b>Encoder B:</b> Frequency input <b>MDI8</b> (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)</p> <p><b>Motor control encoder:</b> Encoder M (HIPERFACE).</p> <p>Encoders A and B may be used as a PID feedback or reference based on the configuration of <b>C189</b>.</p>                         |
|           | 5   | - | <p><b>Encoder M:</b> 5-channel Sin/Cos encoder on ES966</p> <p><b>Encoder A:</b> Incremental encoder on ES966</p> <p><b>Encoder B:</b> Frequency input <b>MDI8</b> (if ES836 or ES913 are fitted into slot A: incremental encoders on ES836 and ES913)</p> <p><b>Motor control encoder:</b> Encoder M (5-channel Sin/Cos encoder).</p> <p>Encoders A and B may be used as a PID feedback or reference based on the configuration of <b>C189</b>.</p> |



**NOTE**

Parameters in this menu are **Rxxx** parameters. Once changed and saved, **Rxxx** parameters become active only after the drive has been switched off and switched on again, or after resetting its control board by pressing the **RESET** button for more than 5 seconds.

### 7.8.2. LIST OF PARAMETERS R021 TO R024 AND R092 TO R097

Table 14: List of Parameters R021 to R024 and R092 to R097

| Parameter | FUNCTION  | User Level  | MODBUS Address | DEFAULT VALUE |
|-----------|---|-------------|----------------|---------------|
| R021      | Data Logger setting                                     | ENGINEERING | 551            | Disable       |
| R023      | I/O board setting                                       | ENGINEERING | 553            | None          |
| R023a     | Absolute sensor for motor control                       | ENGINEERING | 594            | 0: None       |
| R023b     | Incremental sensor on expansion board                   | ENGINEERING | 605            | 0: None       |
| R024      | Incremental encoder frequency divider on resolver board | ENGINEERING | 221            | 0: None       |
| R092      | EnDat protocol frequency                                | ENGINEERING | 526            | 2: 2MHz       |
| R093      | Number of multiturn bits for absolute digital encoder   | ENGINEERING | 527            | 12            |
| R094      | Number of singleturn bits for absolute digital encoder  | ENGINEERING | 528            | 19            |
| R095      | BiSS frequency in Sensor Mode                           | ENGINEERING | 529            | 0: 10MHz      |
| R096      | BiSS frequency divider in Register Mode                 | ENGINEERING | 530            | 5: 64         |
| R097      | Sinusoids per turn of 5-Ch HIPERFACE/SinCos Encoder     | ENGINEERING | 531            | 1024          |

#### R021 Data Logger Setting

|      |          |   |                         |
|------|----------|---|-------------------------|
| R021 | Range    | 1 ÷ 2   | 1: Disable<br>2: Enable |
|      | Default  | 1   | 1: Disable              |
|      | Level    | ENGINEERING   |                         |
|      | Address  | 551   |                         |
|      | Function | This parameter enables or disables Data Logger initialization (if the Data Logger board is fitted). |                         |

#### R023 I/O Board Setting

|      |          |  |   |
|------|----------|--|---|
| R023 | Range    | 0 ÷ 5  | 0: None<br>1: 8I + 6O<br>2: 8I + 6O + XAIN<br>3: 8I + 6O + PT100<br>4: 8I + 6O + XAIN + PT100<br>5: 3I + 3O |
|      | Default  | 0  | 0: None   |
|      | Level    | ENGINEERING  |   |
|      | Address  | 553  |   |
|      | Function | Based on the settings in the relevant parameter, this parameter enables controlling digital I/Os (XMDI/Os), analog inputs (XAIN) and PT100 probes located on optional control boards. Refer to Table 15. |   |

Table 15: Optional boards and parameter R023

| Board | Description         | R023: Allowable values   |
|-------|---------------------|--|
| ES847 | I/O Expansion       | 1: 8I + 6O<br>2: 8I + 6O + XAIN<br>3: 8I + 6O + PT100<br>4: 8I + 6O + XAIN + PT100 |
| ES870 | Relay I/O Expansion | 1: 8I + 6O   |
| ES861 | Resolver            | 5: 3I + 3O   |
| ES950 | BiSS/EnDat Encoder  |  |
| ES966 | HIPERFACE Encoder   |  |

**R023a Absolute Sensor for Motor Control**

|              |                      |   |   |
|--------------|----------------------|---|---|
| <b>R023a</b> | <b>Range</b>         | 0 ÷ 5   | 0: None<br>1: Resolver<br>2: EnDat<br>3: BiSS<br>4: HIPERFACE<br>5: 5-channel Sin/Cos |
|              | <b>Default Level</b> | 0   | 0: None   |
|              | <b>Address</b>       | ENGINEERING   |   |
|              | <b>Function</b>      | 594<br>Defines the type of absolute position sensor used for motor control. Refer to Table 16.<br>The sensor set in this parameter is used for motor control regardless of the value set in <b>C189</b> . |   |

Table 16: Optional boards and parameter R023a

| Sensor                   | Board                           | R023a: allowable values     |
|--------------------------|---------------------------------|-----------------------------|
| Resolver                 | ES861                           | 1: Resolver                 |
| Encoder BiSS             | ES950 Part Number:<br>ZZ0101880 | 2: EnDat                    |
| Encoder EnDat            | ES950 Part Number:<br>ZZ0101890 | 3: BiSS                     |
| Encoder HIPERFACE        | ES966                           | 4: HIPERFACE                |
| 5-channel SinCos encoder | ES966                           | 5: 5-channel SinCos encoder |
|                          | ES860                           | 5: 5-channel SinCos encoder |



**NOTE**

Board **ES950** may be supplied as BiSS or EnDat. The two versions have different purchase codes (see table above). The desired version must be specified when ordering the product.

**R023b Incremental Sensor on Expansion Board**

|              |                 |   |  |
|--------------|-----------------|---|--|
| <b>R023b</b> | <b>Range</b>    | 0 ÷ 3   | 0: None<br>1: Incr. Enc. on Exp. Board<br>2: Resolver to Encoder<br>3: SinCos 3 Ch |
|              | <b>Default</b>  | 0   | 0: None  |
|              | <b>Level</b>    | ENGINEERING   |  |
|              | <b>Address</b>  | 605   |  |
|              | <b>Function</b> | <p>The parameter defines the type of incremental position sensor acquired by optional board fitted into slot C (ES861, ES950, ES966), or by SinCos board (ES860) fitted into slot A.</p> <p><b>0: None:</b> The incremental sensor on boards ES950, ES966 is acquired as <b>encoder A</b>.</p> <p><b>1: Enc. Incr. on Exp. Board:</b> The incremental encoder on optional board ES861 is acquired as <b>encoder A</b>.</p> <p><b>2: Resolver to Encoder:</b> The incremental encoder obtained by the resolver signal on optional board ES861 is acquired as <b>encoder A</b>.</p> <p><b>3: SinCos 3 Ch:</b> The 3-channel SinCos encoder on optional board ES860 or ES966 is acquired as <b>encoder B</b>.</p> <p>Refer to Table 17.</p> <p>The sensor set in this parameter will be used based on the setting in <b>C189</b> (see ENCODER/FREQUENCY INPUTS MENU). In order to be used as motor feedback sensor, parameter <b>R023a</b> must be set to 0.</p> |  |

Table 17: Optional boards and parameter R023b

| Sensor                   | Board | R023b: allowable values     |
|--------------------------|-------|-----------------------------|
| Line driver encoder      | ES836 | Any value ≠ 3               |
|                          | ES913 |                             |
|                          | ES950 | - (any)                     |
|                          | ES966 |                             |
| Encoder from resolver    | ES861 | 1: Enc. Incr. on Exp. Board |
|                          | ES861 | 2: Resolver to Encoder      |
| 3-channel SinCos encoder | ES860 | 3: SinCos 3 Ch              |
|                          | ES966 |                             |

**R024 Incremental Encoder Frequency Divider on Resolver Board**

|             |                 |  |                                    |
|-------------|-----------------|--|------------------------------------|
| <b>R024</b> | <b>Range</b>    | 0 ÷ 3  | 0: None<br>1: /2<br>2: /4<br>3: /8 |
|             | <b>Default</b>  | 0  | 0: None                            |
|             | <b>Level</b>    | ENGINEERING  |                                    |
|             | <b>Address</b>  | 221  |                                    |
|             | <b>Function</b> | <p>Defines the frequency division factor applied to the encoder fed back as an output on the terminals of the optional board (pins 15 to 20).</p> <p>On <b>ES861</b>: applied on the simulated encoder signal fed back on the terminal board.</p> <p>On <b>ES950</b> and <b>ES966</b>: applied to the signal of the incremental encoder wired on the terminal board and fed back on the terminal board itself.</p> |                                    |

R092 EnDat Protocol Frequency

|             |                 |  |  |
|-------------|-----------------|--|--|
| <b>R092</b> | <b>Range</b>    | 0 ÷ 4  | 0: 8 MHz<br>1: 4 MHz<br>2: 2 MHz<br>3: 1 MHz<br>4: 200 kHz |
|             | <b>Default</b>  | 2  | 2: 2 MHz   |
|             | <b>Level</b>    | ENGINEERING  |  |
|             | <b>Address</b>  | 526  |  |
|             | <b>Function</b> | Sets the clock frequency of the EnDat protocol for an EnDat encoder on optional board ES950. |  |

R093 Number of Multiturn Bits for Absolute Digital Encoder

|             |                 |  |            |
|-------------|-----------------|--|------------|
| <b>R093</b> | <b>Range</b>    | 0 ÷ 31   | 0 ÷ 31 bit |
|             | <b>Default</b>  | 12   | 12 bit     |
|             | <b>Level</b>    | ENGINEERING  |            |
|             | <b>Address</b>  | 527  |            |
|             | <b>Function</b> | Sets the number of multiturn (MT) bits of absolute digital encoders (EnDat, BiSS, HIPERFACE) on optional boards ES950 and ES966. |            |

R094 Number of Singleturn Bits for Absolute Digital Encoder

|             |                 |  |            |
|-------------|-----------------|--|------------|
| <b>R094</b> | <b>Range</b>    | 0 ÷ 31   | 0 ÷ 31 bit |
|             | <b>Default</b>  | 12   | 12 bit     |
|             | <b>Level</b>    | ENGINEERING  |            |
|             | <b>Address</b>  | 528  |            |
|             | <b>Function</b> | Sets the number of singleturn (ST) bits of absolute digital encoders (EnDat, BiSS, HIPERFACE) on optional board ES950 and ES966. |            |



**R095 BiSS Frequency in Sensor Mode**

|             |                 |  |              |
|-------------|-----------------|--|--------------|
| <b>R095</b> | <b>Range</b>    | 0 ÷ 30   | 0: 10 MHz    |
|             |                 |  | 1: 5 MHz     |
|             |                 |  | 2: 3.33 MHz  |
|             |                 |  | 3: 2.5 MHz   |
|             |                 |  | 4: 2 MHz     |
|             |                 |  | 5: 1.67 MHz  |
|             |                 |  | 6: 1.43 MHz  |
|             |                 |  | 7: 1.25 MHz  |
|             |                 |  | 8: 1.11 MHz  |
|             |                 |  | 9: 1 MHz     |
|             |                 |  | 10: 0.91 MHz |
|             |                 |  | 11: 0.83 MHz |
|             |                 |  | 12: 0.77 MHz |
|             |                 |  | 13: 0.71 MHz |
|             |                 |  | 14: 0.67 MHz |
|             |                 |  | 15: 0.63 MHz |
|             |                 |  | 16: 0.5 MHz  |
|             |                 |  | 17: 0.33 MHz |
|             |                 |  | 18: 0.25 MHz |
|             |                 |  | 19: 0.2 MHz  |
|             |                 |  | 20: 0.17 MHz |
|             |                 |  | 21: 0.14 MHz |
|             |                 |  | 22: 0.13 MHz |
|             |                 |  | 23: 0.11 MHz |
|             |                 |  | 24: 0.1 MHz  |
|             |                 |  | 25: 0.09 MHz |
|             |                 |  | 26: 0.08 MHz |
|             |                 |  | 27: 0.08 MHz |
|             |                 |  | 28: 0.07 MHz |
|             |                 |  | 29: 0.07 MHz |
|             |                 |  | 30: 0.06 MHz |
|             | <b>Default</b>  | 0  | 0: 10 MHz    |
|             | <b>Level</b>    | ENGINEERING  |              |
|             | <b>Address</b>  | 529  |              |
|             | <b>Function</b> | Sets the clock frequency of the BiSS protocol in sensor mode for a BiSS encoder on optional board ES950. |              |

**R096 BiSS Frequency Divider in Register Mode**

|             |                 |  |   |
|-------------|-----------------|--|---|
| <b>R096</b> | <b>Range</b>    | 0 ÷ 7  | 0: /2<br>1: /4<br>2: /8<br>3: /16<br>4: /32<br>5: /64<br>6: /128<br>7: /256 |
|             | <b>Default</b>  | 5  | 5: /64  |
|             | <b>Level</b>    | ENGINEERING  |   |
|             | <b>Address</b>  | 530  |   |
|             | <b>Function</b> | Divider of the selected frequency for BiSS in Sensor Mode. The result defines the working frequency for Register Mode transmissions. |   |

**R097 Sinusoids per turn of 5-Ch HIPERFACE/SinCos Encoder**

|             |                 |   |                          |
|-------------|-----------------|---|--------------------------|
| <b>R097</b> | <b>Range</b>    | 0 ÷ 16384   | 0 ÷ 16384 sinusoids/turn |
|             | <b>Default</b>  | 1024  | 1024 sinusoids/turn      |
|             | <b>Level</b>    | ENGINEERING   |                          |
|             | <b>Address</b>  | 531   |                          |
|             | <b>Function</b> | Defines the number of sinusoids/turn of the HIPERFACE encoder on optional board ES966, or of 5-channel SinCos encoder on optional board ES966 or ES861. |                          |



**NOTE**

For 3-channel SinCos encoder on optional board ES966 or ES861, the number of sinusoids per turn is defined by parameter **C191** in the ENCODER/FREQUENCY INPUTS MENU.

## 7.9. ALARMS SPECIFIC TO SYN APPLICATION

### 7.9.1. OVERVIEW

This section covers only the alarms specific to the SYN application.  
Refer to the **Programming Guide** for the whole list of the Sinus Penta alarms.

### 7.9.2. LIST OF THE ALARM CODES

Table 18: List of the Alarms specific to the SYN application

| Alarm | Name              | Description                                |
|-------|-------------------|--|
| A130  | SYN Align KO      | Motor alignment procedure failed           |
| A131  | ABS Encoder Fault | Absolute encoder malfunction               |
| A132  | Motor not Aligned | No alignment between rotor/position sensor |

#### A130 SYN Alignment KO

|      |                 |   |
|------|-----------------|---|
| A130 | Description     | The motor alignment procedure has failed before being completed   |
|      | Event           | The motor alignment procedure has failed  |
|      | Possible Causes | <ul style="list-style-type: none"> <li>• Wrong power and/or signal wiring</li> <li>• Wrong parameterization</li> <li>• Electrical failure on inverter board</li> </ul>  |
|      | Solutions       | <ol style="list-style-type: none"> <li>1. Reset the alarm and the board.</li> <li>2. Perform the alignment procedure again.</li> <li>3. If the alarm persists, contact the CUSTOMER SERVICE of ELETTRONICA SANTERNO.</li> </ol> |

#### A131 ABS Encoder Fault

|      |                 |  |
|------|-----------------|--|
| A131 | Description     | Absolute encoder malfunction   |
|      | Event           | No position information from the absolute encoder  |
|      | Possible Causes | <ul style="list-style-type: none"> <li>• Wrong wiring</li> <li>• Wrong parameterization</li> <li>• Electrical failure on optional acquisition board</li> <li>• Sensor failure</li> <li>• Communication channel disturbance</li> </ul>                                    |
|      | Solutions       | <ol style="list-style-type: none"> <li>1. Power off the equipment and check wiring.</li> <li>2. Check the board parameterization.</li> <li>3. Restart the equipment.</li> <li>4. If the alarm persists, contact the CUSTOMER SERVICE of ELETTRONICA SANTERNO.</li> </ol> |

A132 Motor not Aligned

|             |                        |   |
|-------------|------------------------|---|
| <b>A132</b> | <b>Description</b>     | No alignment between rotor/position sensor.   |
|             | <b>Event</b>           | When the ENABLE closes (except for the autotuning and alignment procedures), the system detects that the rotor is not aligned with the position sensor, so the motor cannot be properly controlled.<br>If a relative position sensor is used (incremental encoder or 3-channel Sin/Cos encoder), the alignment procedure shall be performed whenever the drive is powered on. |
|             | <b>Possible Causes</b> | The started motor has not been aligned with the position sensor, or the latest alignment procedure has failed.  |
|             | <b>Solutions</b>       | <ol style="list-style-type: none"> <li>1. Remove the Enable command and reset the alarm.</li> <li>2. Performed an alignment procedure as described in this manual.</li> <li>3. If the alarm persists, contact the CUSTOMER SERVICE of ELETTRONICA SANTERNO.</li> </ol>  |