

How to use EasyDDNS



Index

Before you start	3
EasyDDNS Mode - Basic Settings	3
EasyDDNS Mode - Client software	5
EasyDDNS Mode - DDNS Management System(optional)	6
IP Server Mode - Settings for Device	9
IP Server Mode - Settings on DDNS Management System	10
IP Server Mode - Client software	11
Mobile client software support	13
Firmware support	14



Before you start

EasyDDNS is a free DDNS service which enables you to get access to the device by simply a domain name. You can use EasyDDNS in two modes: EasyDDNS mode and IP server mode, and these 2 modes support mobile phone monitoring. In other words, you can get EasyDDNS service without upgrading the device.

EasyDDNS Mode - Basic Settings in DVR

1) Go to MENU>Settings>Network. Fill in the IP Address, Subnet Mask, Default Gateway and the DNS Server. Then click Apply.

NIC Type	10M/100	M Auto		
DHCP				
IP Address	172.6	.19	. 15	
Subnet Mask	255.255	.255	.0	
Default Galeway	172.6	. 19	.1	
Preferred DNS Server	192.0	.0	.200	
Alternate DNS Server	127.0	.0	.1	
MAC Address	00:0e:99:	02:b2	:bc	

2) Go to Advanced and choose DDNS. Choose the DDNS Type as easyDDNS. The server address is www.hik-online.com. The DVR Domain Name is a user defined alias(The device's alias must begin with an English letter, and only English letters, numbers or underscores are allowed. Characters like /, \ and * will be denied. If the name has already been used, an error message will pop up. In that case, please use another name instead.). You need this alias to login. Then click OK. It will pop up register successful.

	DDNS
DDNS	5
DDNS Type Server Address DVR Domain Name User Name Password	easyDDNS 🔫 www.hik-online.com darren
Confirm Password	ار OK Cancel

3) Login to the management interface of the router, enter the NAT settings, or called port-forwarding/port-mapping settings of the router.



						Win	eless G Broad	band Router	WRT54G
& Gaming	Setup	Wirele	SS	Securi	ity A Res	ccess trictions	Applications & Gaming	Administration	Status
	Port Range For	ward	P	ort Triggerin	e i	DMZ	1 005		
Port Range Forward	1							Port Range Fo	orwarding:
	2			Port	t Range			Certain applicat	ions may requ c ports in orde
	Application	Start		End	Protocol	IP Address	Enable	for it to function Examples of the	n correctly, ese application
	DVR1	81	to	81	Both 💌	192.168.1.6	5 🔽	include servers online games.V	and certain When a reques
	DVR1	8000	to	8000	Both -	192.168.1. 6	5 🔽	for a certain po the Internet, the	rt comes in fro e router will ro
	SERVER	5631	to	5632	Both 💌	192.168.1.6	7	the data to the specify. Due to	computer you security
	SERVER	5800	to	5800	Both 💌	192.168.1.6	7 🔽	concerns, you port forwarding	may want to li g to only those
	SERVER	5900	to	5900	Both 💌	192.168.1.6	7 🔽	uncheck the Er	ising, and lable checkbo
	DVR2	82	to	82	Both 💌	192.168.1. 6	6 17	More	
	DVR2	8001	to	8001	Both 💌	192.168.1.6	6 🔽		
		0	to	0	Both 💌	192.168.1. 0			
		0	to	0	Both -	192.168.1. 0			
		0	to	0	Both •	192.168.1.0			

Forward the http port (80) and server port (8000) of a device to its local IP address. Some devices also require RTSP port (554) to be fowarded properly.

HOS	ST/OTHERS
Alarm Host IP Alarm Host Port	 0
Server Port	8000
Multicast IP	
	OKCancel

4) Then you could access the device directly through web browser by using the URL below, as long as the device is online.

http://www.hik-online.com/AliasGivenByYou. Example: <u>http://www.hik-online.com/darren</u>

EasyDDNS Mode - Basic Settings in IPC

- 1) Enter into the IPC web interface through IE browser and click Advanced Configuration in Configuration interface.
- 2) In the DDNS interface, check the checkbox to enable DDNS, choose the DDNS type as EasyDDNS.



3) Input the Domain then you can login the device through url: <u>http://www.hik-online.com/AliasGiveByYou</u> or client software after you forwarding the ports to internet properly.

Live View	Playback	Log	Configuration	🧟 admin 🥁 Logou
 Local Configuration Local Configuration Local Configuration Basic Configuration Advanced Configuration System Network Video/Audio 		DDNS PPPoE SNMP DNS EasyDDNS ss www.hik-onlin ipc854ipc 0	802.1X QoS FTP	
© Image	User Name			
© Security	Password			
© Events	Confirm			
⊘ Storage				Save

EasyDDNS Mode - Client software

iVMS- 4200 V1.02.00.07

At the main interface of iVMS-4200, click import camera>Add Device, the Nickname is user defined, and the DNS address is <u>http://www.hik-online.com</u>.Fill in the port (8000 as default), Device ID (alias), user name and password. Tick on "Export to Group" and click Add. Then you can go to Main View page and start previewing.



	Add Device 🛛 🗙
Private Domain Mod	e
Nickname:	7216HVI-ST
DNS Address:	www.hik-online.com
Protocol Type:	IP Server EasyDDNS
Port:	8000
Device ID:	darren
User Name:	admin
Password:	•••••
Multicast Address:	
Export To Group	
Show Online Devices	Add Cancel

iVMS-4000 v2.04.02

- 1) In the Add Device interface or the Modify Device Information interface.
- 2) Choose the Register Mode as EasyDDNS.
- 3) Enter the Device Name(DVR Domain Name), DNS Address, Port, Username, Password and Channel NO..

Device Information			
Device Name	NVR	Register Mode	EasyDDNS
Device IP	172 . 6 . 21 . 160	Port	Normal IP IPServer
Usemame	admin	Password	Normal Domain
Channel No.	8	Multicast	0.0.0.0
DNS Address		Belongs to area	test area
Serial Number	DS-7208HVI-ST/SE012011	0804AAWR4043707	85WCVU
Senai ryumber	105-7206HVI-51/3E012011	00040401043707	esword

4) Click to confirm your settings.

EasyDDNS Mode - DDNS Management System(optional)

Open Internet Explorer In the address bar, type IP address of DDNS Management Server Http://www.hik-online.com If you don't have an account, please click "register new user" to create a new user. Login page shown as Figure 1:





Figure 1

Register User

Enter in user name and password and click OK to save. After creating a user, enter in User name and password. Then click "Login" to enter DDNS Management System. Note: If login failed and error message shows "Login failed, the user is locked!" Please contact Administrator for help.

	Vser Name: Password: Confirm Password: Real Name: Mobile Phone: remark:	MIKVISION Inagement System v1.0
User Pass	word: register new user?	Login Reset

Figure 2

Device Management

After login, main page shown as Figure 3:



DDN	IS Manag	ement Systen	n v1.0	HIKVISION	Current User : M	forris <u>Modify password</u> <u>Logout</u>
Menu	Device Status	Export				
Device Status	Serial No.	Device Name	Device Link URL	Device Serial	Dynamic IP	Port No. Create Time
 Device Management Log 	H H Page	1 of 1 2 24 2				No data to display

Figure 3

Click "Device Management", there is no device at first time. Click "Add" button to add device.

Menu	Device Management 🛛 🛃	Add 😡 Modify 🔀 Delete		Please	input the searching condition $ \mathbf{Q} \mathbf{x})$
Device Status	Seria	Device Alias	Device Serial No.	Http Port	Login User Name
Device Management					
→Log	4 4 Page 1 of 1 ▶ ₽	A &			No data to display
-					

Figure 4

Enter in Device aliases name and serial number. By default, http port is 80. If http port of device was changed from 80, please enter new port in Http Port area.

Note: The Device Alias here is used for previewing, if you change the Device Alias here, then the Alias in DVR will be invalid. And you must fill in the correct Device Serial No.



Figure 5

Device Status

Click "Device Status" to show all added devices information like Serial number, Dynamic IP, HTTP port, DDNS IP address. And you can just click the Device Link URL to start previewing.



Menu	Device Statu	us Export					
Device Status	Serial No.	Device Name	Device Link URL	Device Serial	Dynamic IP	Port No.	Create Time
Device Management	1	darren	http://172.6.22.250/darren	403163698	172.6.19.141	80	2012-04-17T20:18:59
→Log	14 4 Pag	ge 1 of 1 🕨 🕅 🥮					Displaying 1 - 1 of 1

Figure 6



to export device list.

Log

Log Interface allows the user to view Device IP updates.

Click "Log" to enter Log interface.

DDN	IS Mana	gemen	t System	N V1.0	IMANTSTON M		Cur	rent User : Morris <u>M</u>	odify password L	ogout
Menu	Log					_				xport
Device Status Device Management	Log Type	e: All		™ From:	2012-01-12 13:56:56		\bigcirc			
Log	User:			~ To:	2012-01-13 13:56:56					
	Search Result									
	Serial No.		Log Date		Log Type	User		Details		
	14 4 Page	1 of 1 >	NIR						No data to	display

Figure 7

Log Type includes: All, Login, Logout, Device Management and Device IP Updates.

Select Log Type first and select start time and end time. Then click is search.

Access device

If the setup has been done successfully, there are two ways to access your device:

- 1. Login in to DDNS Management System first, then click device name, it will automatically link to device login page.
- 2. Directly type in www.hik-online.com/DeviceAlias name in IE address bar to access device

IP Server Mode - Settings for Device

Register your device to the IP server, you can register it in the local configuration of the device side; or you can register the IP server remotely after you add the device to the iVMS-4000.

For the local configuration of the IP server on the device side, please refer to the user manual of the device. To register on the IP server in the iVMS-4000,

1) Select the device and click Remote Settings in the setup interface.

2) In the JP DDNS Settings interface, check the checkbox to enable DDNS, choose the protocol type as IpServer.

3) Enter the server name; and the recommended server name is 115.236.50.27.

Other fields are read only.



Remote setting	DDWS Sattings			×
Device Information Version Information DST Settings Channel Parameters Network Parameters Network Parameters PFPOE Settings NTF Settings NTF Settings E-mail Settings Serial Port Settings Alarm Parameters Exception Parameters Account Management HDD Settings Device Maintenance Zero-channel Settings	DDAS Settings Protocol Type: Server Name: Port: User Name: Password: Confirm Password: Domain:	IpServer 115.236.50.27 0		
Default Reboot			Save	Cancel

IP Server Mode - Settings on DDNS Management System

After saving the settings of the IP server, go to the EasyDDNS website: <u>www.hik-online.com</u>. To add the device on the EasyDDNS server:

1) Register an account and use the account to log in.

HIKVISION

User Name: Password: Confirm Password Real Name: Email: Remark:	d: XXX XXX XXX@gmail.com XXX QK Cancel	MIKVISION Inagement System v1.0
User Name: Password: Regi	ster new user	Login Reset

2) In the Device Management interface, click Add to add the device.

The alias of the device must be started with letters of the English alphabet.

Menu	Device Management	Add	Modify	X Delete		Please in	put the searching condition 🔍 🗙
Device Status	🖾 Seri		Device Alias		Device Serial No.	Http Port	Login User Name
Device Management							
Log	Page 1 of 1						No data to display
				Add Device	×		
				Device Alias	dvr122		
				Device Allas.	111044 00000000000000000000000000000000		
				Utto Derte	11104AAWR092200071WCVL0		
				Http Port:	80		
					OK Cancel		

IP Server Mode - Client software

iVMS- 4200 V1.02.00.07

At the main interface of iVMS-4200, click import camera>Add Device, the Nickname is user defined, and the DNS address is <u>http://www.hik-online.com</u>.Fill in the port (8000 as default), Device ID (alias), user name and password. Tick on "Export to Group" and click Add. Then you can go to Main View page and start previewing.



	Add Device 🛛 🗙				
Private Domain Mode					
Nickname:	7216HVI-ST				
DNS Address:	www.hik-online.com				
Protocol Type:	IP Server EasyDDNS				
Port:	8000				
Device ID:	darren				
User Name:	admin				
Password:	•••••				
Multicast Address:					
💌 Export To Group					
Show Online Devices	Add Cancel				

iVMS-4000 v2.04.02

Add the device with a EasyDDNS domain name in iVMS-4000. (Change the device register mode as EasyDDNS.)

- 1) In the Add Device interface or the Modify Device Information interface.
- 2) Choose the Register Mode as EasyDDNS.
- 3) Enter the Device Name, DNS Address and the Serial Number. Use the alias created when you added the device in the EasyDDNS serve, the software can get the serial number of the device automatically. Otherwise, the serial number must be exactly correct.

Davies Mamo	Luce.		5 ac 0010
Device Marrie	INVR	Register Mode	EasyDONS
Device IP	172 . 6 . 21 . 160	Port	Normal IP IPServer
Username	admin	Password	Normal Domain
	10		EasyDONS
Channel No.	8	Multicast	0.0.0.0
DNS Address		Belongs to area	test area
Serial Number	DS-7208HVI-ST/SE012011	0804AAWR4043707	85WCVU



Device Name	NVR	Register Mode	EasyDDNS -
Device IP	172 6 . 21 . 160	Port	8000
Usemame	admin	Password	
Channel No.	8	Multicast	0.0.0.0
DNS Address	www.hik-pnline.com	Belongs to area	test area
Serial Number	DS-7208HVI-ST/SE012011	0804AAWR4043707	85WCVU

4) Click _____ to confirm your settings.

 4 Note: The device once added to the EasyDDNS server can be viewed via web browser with a EasyDDNS server

address and its alias.

Example: www.hik-online.com/darren

Mobile client software support

EasyDDNS mode and IP Server mode both support mobile phone monitoring. For Apple device, you can download the mobile client software from App store: Iphone: iVMS-4500 Lite V1.6 IPAD: iVMS-4500 HD V1.6 For android device, you can download the Mobile client software from Google Play: Android: iVMS-4500 V1.6 At the main interface of 4500, click Devices and add, choose Register mode asDDNS and fill in the Device Alias and save. Then you can go to Live preview and start previewing. Notice: For android client software, you need to delete the "/" at the end of Address The right Address is http://www.hik-online.com



	(E) III 🖭 09:28
New Device	
Device Alias	darren
Register mode	DDNS ~
Address	vw.hik-online.com/
Port	80
User name	admin
Password	••••
Chan No.	16

Firmware support easyDDNS

The firmware as follows support easyDDNS, you can get DDNS service with easyDDNS mode.

Product series: 7204 &7208 HVI ST/SN

Version: V1.3

Model:DS-7204HFI-ST;DS-7204HFI-ST/RW;DS-7204HFI-ST/SE;DS-7204HFI-ST/SN;DS-7204HVI-ST;DS-7204HVI-ST/L;DS-720 4HVI-ST/RW;DS-7204HVI-ST/SE;DS-7204HVI-ST/SN;DS-7208HVI-ST;DS-7208HVI-ST/RW;DS-7208HVI-ST/SE;DS-7208HVI-ST /SN;

Product series: 7208 HFI & 7216HVI ST/SN Version: V1.3 Model: DS-7208HFI-ST; DS-7208HFI-ST/RW; DS-7208HFI-ST/SE; DS-7208HFI-ST/SN; DS-7216HVI-ST; DS-7216HVI-ST/RW; DS-7216HVI-ST/SE; DS-7216HVI-ST/SN

Product series: 7216HFI ST/SN Version: V1.3 Model: DS-7216HFI-ST; DS-7216HFI-ST/RW; DS-7216HFI-ST/SE; DS-7216HFI-ST/SN;

Product series: 7304 &7308 HFI ST Version: V 2.2 Model:DS-7304HFI-ST;DS-7304HI-ST;DS-7308HFI-ST;DS-7308HI-ST;DS-7316HI-ST;DS-8104HDI-ST;DS-8108HDI-ST;DS-8116



Product series: 7316 HFI-ST Version: V 2.2 Model: 7316HFI-ST

Product series: 8100 HCI-ST Version: V1.3 Model: DS-8104AHI-ST; DS-8104AHLI-ST; DS-8104HCI-ST;DS-8104HSI-ST;DS-8108AHI-ST;DS-8108AHLI-ST;DS-8108HCI-ST; DS-8108HSI-ST; DS-8116HCI-ST; DS-8116HSI-ST;

Product series: 81/90/91XX HFI-ST Version: V2.2 Model:DS-8004HFI-ST;DS-8008HFI-ST;DS-8016HFI-ST;DS-8104HFI-ST;DS-8108HFI-ST;DS-8116HFI-ST;DS-9004HFI-ST;DS-9 008HFI-ST;DS-9016HFI-ST;• DS-9104HFI-ST;DS-9104HFI-ST;DS-9108HFI-ST;DS-9116HFI-ST;

Product series: 81/91XX HWI-ST Version: V2.2 Model: DS-8108HWI-ST; DS-8116HWI-ST; DS-9108HWI-ST; DS-9116HWI-ST;

Product series: 365 platform IPC Version: V4.0.1

Note: You can get DDNS service with IP server mode if the device at your hand is too old and there is no firmware supporting EasyDDNS.