

OPERATING AND INSTALLATION INSTRUCTIONS

Models 122-322
Type H, WH, & P



FOR YOUR SAFETY

Do not store or use gasoline or other flammable vapors and liquids or other combustible materials in the vicinity of this or any other appliance. To do so may result in an explosion or fire.


WARNING: Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Refer to this manual. Installation and service must be performed by a qualified installer, service agency or the gas supplier.

FOR YOUR SAFETY

WHAT TO DO IF YOU SMELL GAS:

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

This manual should be maintained in legible condition and kept adjacent to the heater or in a safe place for future reference.



Raypak®
A Rheem® Company

TABLE OF CONTENTS

PAGE NO.

4	SECTION A:	BEFORE INSTALLING THE HEATER
8	SECTION B:	HEATER INSTALLATION
11	SECTION C:	COMBUSTION AND VENTILATION AIR
13	SECTION D:	WATER PIPING - GENERAL
14	SECTION E:	HYDRONIC HEATING PIPING
16	SECTION F:	DOMESTIC HOT WATER PIPING
18	SECTION G:	POOL HEATING
19	SECTION H:	GAS SUPPLY CONNECTIONS
21	SECTION I:	ELECTRICAL POWER CONNECTIONS
24	SECTION J:	VENTING CONNECTIONS
28	J-1:	Natural Draft Vertical Venting
31	J-2:	Horizontal Thru-Wall Venting
33	J-3:	Horizontal Thru-Wall Direct Venting
35	J-4:	Vertical Direct Venting/Combustion Air
37	J-5:	Outdoor Installation
38	SECTION K:	CONTROLS
41		WIRING DIAGRAM
42	SECTION L:	GENERAL SAFETY PRECAUTIONS
43	SECTION M:	PRE-START-UP
44	SECTION N:	HI DELTA INITIAL START-UP
46	SECTION O:	POST START-UP CHECK
47	SECTION P:	OPERATION
48	SECTION Q:	MAINTENANCE
49	APPENDIX A:	COMBUSTION AIR CONTAMINATION
50		ILLUSTRATED PARTS LIST
55		WARRANTY

DANGER: *Make sure the gas on which the heater will operate is the same type as that specified on the heater model and rating plate.*

WARNING: *Should overheating occur or the gas supply valve fail to shut, do not turn off or disconnect the electrical supply to the heater. Instead, shut off the gas supply at a location external to the appliance.*

WARNING: *Do not use this heater if any part has been under water. Immediately call a qualified service technician to inspect the heater and to replace any part of the control system and any gas control which has been under water.*

WARNING: *To minimize the possibility of improper operation, serious personal injury, fire, or damage to the heater, never violate the following safety rules:*

- 1. Always keep the area around the heater free of combustible materials, gasoline, and other flammable liquids and vapors.*
- 2. Heater should never be covered or have any blockage to the flow of fresh air to the heater.*

WARNING: *Risk of electrical shock. More than one (1) disconnect switch may be required to de-energize the equipment before servicing.*

CAUTION: *Operation of this heater on low temperature systems requires special piping to insure correct operation.*

CAUTION: *If this heater is to be installed above radiation level, it must be provided with a low water cut-off device at the time of heater installation.*

CAUTION: *This heater requires forced water circulation when the burner is operating. See minimum and maximum flow rates. Severe damage will occur if the heater is operated without proper water flow circulation.*

CALIFORNIA PROPOSITION 65 WARNING: This product contains chemicals known to the state of California to cause cancer, birth defects or other reproductive harm.

Pay attention to these terms:

DANGER: *indicates the presence of immediate hazards which will cause severe personal injury, death or substantial property damage if ignored.*

WARNING: *indicates the presence of hazards or unsafe practices which could cause severe personal injury, death or substantial property damage if ignored.*

CAUTION: *indicates the presence of hazards or unsafe practices which could cause minor personal injury or product or property damage if ignored.*

NOTICE: *indicates special instructions on installation, operation, or maintenance which are important but not related to personal injury hazards.*

SECTION A: BEFORE INSTALLING THE HEATER

Raypak strongly recommends that this manual be reviewed thoroughly before installing your Raypak heater. Please review the General Safety Precautions on Section L before installing the heater. Factory warranty does not apply to heaters that have been improperly installed or operated. Installation and service must be performed by a qualified installer, service agency or gas supplier. If, after reviewing this manual, you still have questions which this manual does not answer, please contact the factory or your local Raypak representative.

Thank you for purchasing a Raypak product. We hope you will be satisfied with the high quality and durability of our equipment.

PRODUCT RECEIPT

On receipt of your product it is suggested that you visually check for external damage to the shipping crate. If the crate is damaged, make a note to that effect on the Bill of Lading when signing for the shipment. Remove the heater from the shipping packaging. Report any damage to the carrier immediately.

On occasion, some items will be shipped loose. Be sure that you receive the correct number of packages as indicated on the Bill of Lading.

Claims for shortages and damages must be filed with the carrier by consignee. Permission to return goods must be received from the factory prior to shipping. Goods returned to the factory without an authorized Returned Goods Receipt number will not be accepted. All returned goods are subject to a restocking charge.

When ordering parts, you must specify the Model and Serial Number of the heater. When ordering under warranty conditions, you must also specify the date of installation.

Purchased parts are subject to replacement only under the manufacturer's warranty. Debits for defective replacement part will not be accepted and will be replaced in kind only per Raypak's standard warranties.

MODEL IDENTIFICATION

The model identification number and heater serial number are found on the heater data plate located on the left inside jacket of the heater. The model number will have the form H3 0162 or similar depending on the heater size and configuration. The first character of the model number identifies application (H = Hydronic Heating System, WH = Hot Water Supply System, P = Pool Application). The second character identifies the firing mode (3-two stage firing, 4 – On/Off firing). The next four places identify the size of the heater.

RATINGS AND CERTIFICATIONS

STANDARDS


- Gas-Fired Low Pressure Steam and Hot Water Heaters, ANSI Z21-13 • CSA 4.9 - latest edition
- Industrial and Commercial Gas-Fired Package Heaters, CAN 31 - latest edition
- Gas-Fired Pool Heaters, ANSI Z21.56 • CSA 4.7 - latest edition
- Gas Water Heaters, ANSI Z21.10.3 • CSA 4.3 - latest edition

All Raypak heaters are National Board Approved, design certified and tested by the CSA International for U.S.A. and Canada. Each heater is constructed in accordance with Section IV of the American Society of Mechanical Engineers (ASME) Heater Pressure Vessel Code and bears the ASME stamp. This heater complies with the latest edition of ASHRAE 90.1 Standard.


Altering any RAYPAK pressure vessel by installing replacement heat-exchangers, tube bundle headers, or any other ASME part not manufactured and/or approved by RAYPAK will instantly void the ASME, ratings of the vessel and any RAYPAK warranty on the vessel. This also violates national, state, and local approval codes.

Rated inputs are suitable for up to 4500 feet elevation without de-rate . Consult the Factory for installations at altitudes in excess of 4500 feet.


HI DELTA COMPONENT LOCATION



BACK



LEFT-SIDE



Fig# 9399

FRONT

General Information


BASIC DATA

MODEL NUMBER	NUMBER OF			VENT SIZES	
	BURNERS	GAS VALVES	BLOWERS	FLUE	INTAKE
122	3	2*	1	4	5
162	4	2*	1	5	5
202	5	2*	1	5	5
242	6	2*	1	5	5
322	8	2*	1	6	5


* Second valve located inside air plenum

MANIFOLD DATA

MODEL NUMBER	# BURNERS PER VALVE		STAGES		% FIRE AT STAGE	
	A	B	1	2	1	2
122	2	1	A	AB	66	100
162	3	1	A	AB	75	100
202	3	2	A	AB	60	100
242	4	2	A	AB	66	100
322	5	3	A	AB	63	100



Gas Valve Detail



Air Shutter Adjustment

SECTION B: HEATER INSTALLATION

INSTALLATION CODES

Installations must follow these codes:

- Local, state, provincial, and national codes, laws, regulations and ordinances.
- National Fuel Gas Code, ANSI Z223.1- latest edition (NFGC).
- National Electrical Code, ANSI/NFPA 70 - latest edition (NEC).
- Standard for Controls and Safety Devices for Automatically Fired Heaters, ANSI/ASME CSD-1, when required (CSD-1).
- For Canada only: CAN/CGA B149.1 and .2 Installation Code (B149.1 and .2) and C.S.A. C22. 1 C.E.C. Part 1 (C22. 1).

EQUIPMENT BASE

The heater should be mounted on a level, structurally sound surface. The heater is approved for installation on a combustible surface but must NEVER be installed on carpeting. Gas fueled equipment installed in enclosed parking garages must be located at least 18 in. above the floor.

CAUTION:

The heater should be located in an area where water leakage will not result in damage to the area adjacent to the appliance or to the structure. When such locations cannot be avoided, it is recommended that a suitable catch pan, adequately drained, be installed under the appliance. The pan must not restrict air flow.

In addition, the heater shall be installed such that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during appliance operation or service (circulator replacement, control replacement, etc.).

WARNING:


This Product Must Be Installed By A Licensed Plumber Or Gas Fitter when Installed Within The Commonwealth Of Massachusetts.

CLEARANCES


TABLE 1
INDOOR INSTALLATION
MINIMUM CLEARANCES FROM COMBUSTIBLE SURFACES

<u>Heater Side</u>	<u>Models</u> <u>122-322</u>
Floor	See Note 1
Rear	1"
Water Side	12"
Other Side	1"
Top	1"
Vent	2"

Note 1. Do not install on carpeting.



TOP VIEW



Fig# 9394

FRONT VIEW

When installed according to the listed minimum clearances from combustible construction materials, the Raypak heaters can still be serviced without removing permanent structural construction around the heater.

However, for ease of servicing, we recommend a clearance of at least 24" in front, and at least 18" on the water connection side. This will enable the heater to be serviced in its installed location, that is, without movement or removal of the heater.

Clearances less than minimum, may require removal of the heater to service either the heat exchanger or the burner tray. In either case, the heater must be installed in a manner that will enable the heater to be serviced without removing any structure around the heater.

OUTDOOR INSTALLATIONS

Raypak Hi Delta Heaters are design certified for outdoor installation. Heaters must not be installed under an overhang that is less than three (3) feet from the top of the heater. Three (3) sides must be open in the area under the overhang. Roof water drainage must be diverted away from heaters installed under overhangs.

TABLE 2
OUTDOOR INSTALLATION MINIMUM CLEARANCES

<u>Heater Side</u>	<u>Heater Model</u>
Rear	12"
Right	36"
Left	36"
Top	Unobstructed
Vent	N/A

These clearances required where the outdoor vent cap is used. If installing the heater outdoors with a vent stack, the indoor clearances may be used.




Fig # 9400

FRONT VIEW

SIDE VIEW

SECTION C: COMBUSTION AND VENTILATION AIR

COMBUSTION AND VENTILATION AIR (Indoor Units)

The heater must be supplied with sufficient quantities of non-contaminated air to support proper combustion and equipment ventilation. Combustion air can be supplied via conventional venting, where combustion air is drawn from the area immediately surrounding the heater, or via direct vent, where combustion air is drawn directly from outside. All installations must comply with the requirements of NFGC (U.S.), B 149.1 and .2 (Canada), and all local codes.

CAUTION:

Combustion air must not be contaminated by corrosive chemical fumes which can damage the heater and void the warranty. See appendix A.

DIRECT COMBUSTION AIR

If outside air is drawn through the intake pipe directly to the unit for combustion:

1. Install combustion air direct vent in accordance with Section J of this manual.

CONVENTIONAL COMBUSTION AIR SUPPLY (FOR U.S. INSTALLATION ONLY)

(a) All Air from Inside the Building. The confined space shall be provided with two permanent openings communicating directly with an additional room(s) of sufficient volume so that the combined volume of all spaces meets the criteria for an unconfined space. The total input of all gas utilization equipment installed in the combined space shall be considered in making this determination. Each opening shall have a minimum free area of 1 square inch per 1,000 Btu per hour (22 cm² per kW) of the total input rating of all gas utilization equipment in the confined space, but not less than 100 in.² (645 cm²). One opening shall commence within 12 in. (30 cm) of the top, and one opening shall commence within 12 in. (30 cm) of the bottom, of the enclosure. The minimum dimension of air openings shall be not less than 3 in. (8 cm) in any direction.

(b) All Air from Outdoors. The confined space shall communicate with the outdoors in accordance with methods 1 or 2. The minimum dimension of air openings shall not be less than 3 in. (8 cm) in any direction. Where ducts are used, they shall be of the same cross-sectional area as the free area of the openings to which they connect.

1. Two permanent openings, one commencing within 12 in. (30 cm) of the top, and one commencing within 12 in. (30 cm) of the bottom, of the enclosure shall be provided. The openings shall communicate directly, or by ducts, with the outdoors or spaces (crawl or attic) that freely communicate with the outdoors.

- a. Where directly communicating with the outdoors or where communicating to the outdoors through vertical ducts, each opening shall have a minimum free area of 1 sq in. per 4000 Btu per hr (5.5 cm² per kW) of total input rating of all equipment in the enclosure.

- b. Where communicating with the outdoors through horizontal ducts, each opening shall have a minimum free area of 1 sq in. per 2000 Btu per hr (11 cm² per kW) of total input rating of all equipment in the enclosure.

2. One permanent opening, commencing within 12 in. (30 cm) of the top of the enclosure, shall be permitted where the equipment has clearances of at least 1 in. (2.5 cm) from the sides and back and 6 in. (16 cm) from the front of the appliance. The opening shall directly communicate with the outdoors or shall communicate through a vertical or horizontal duct to the outdoors or spaces (crawl or attic) that freely communicate with the outdoors, and shall have a minimum free area of:

- a. 1 sq in. per 3000 Btu per hr (7 cm² per kW) of the total input rating of all equipment located in the enclosure, and
- b. Not less than the sum of the areas of all vent connectors in the confined space.

WARNING:

Do not use one permanent opening method if the equipment room is under negative pressure condition or the equipment is common vented with other gas-fired appliances.

COMBUSTION AND VENTILATION AIR SUPPLY (FOR CANADA INSTALLATION)

CAUTION:

All combustion air has to be drawn from the air outside the building (the mechanical equipment room directly communicates with the outdoors).

1. Ventilation of the space occupied by the heater shall be provided by an opening(s) for ventilation air at the highest practical point communicating with outdoors. The total cross-sectional area of such an opening(s) shall be at least 10% of the area required in (2) and (3), but in no case shall the cross-sectional area be less than 10 sq. in. (6500 sq. mm.).
2. For heaters using a barometric damper in the vent system, and when air supply is provided by natural air flow from the outdoors for natural draft, partial fan assisted, fan-assisted or power draft-assisted burners, there shall be a permanent air supply opening(s) having a cross section area of not less than 1 sq. in. per 7000 BTUH (310 sq. mm per kW) up to and including 1 million BTUH, plus 1 sq. in. per 14000 BTUH (155 sq. mm per kW) in excess of 1 million BTUH. This opening(s) shall be either located at or ducted to a point neither more than 18 in. (450 mm) nor less than 6 in. (150 mm) above the floor level. The duct can also "Goose Neck" through the roof. The duct is preferred straight down 18" from floor, but do not place near piping. This air supply opening requirement shall be in addition to the air opening for ventilation air required in (1).
3. For heaters not using a barometric damper in the vent system, and when air supply is provided by natural air flow from outdoors for a power burner and there is no draft regulator, drafthood or similar flue gas dilution device installed in the same space, in addition to the opening for ventilation air required in (1), there shall be a permanent air supply opening(s) having a total cross-sectional area of not less than 1 sq. in. for each 30,000 BTUH (70 sq. mm per kW) of total rated input of the burner(s), and the location of the opening(s) shall not interfere with the intended purpose of the opening(s) for ventilation air referred to (1). This opening(s) can be ducted to a point neither more than 18 in. (450 mm) nor less than 6 in. (150 mm) above the floor level. The duct can also "Goose Neck" through the roof. The duct is preferred to be straight down 18" from floor, but do not place near piping.
4. Refer to the latest version of the B149.1 and .2 for additional information.

SECTION D: WATER PIPING - GENERAL

The heater should be located so that any water leaks will not cause damage to the adjacent area or structures.

CAUTION:

This heater requires forced water circulation when the burner is operating. See Table D-1 for minimum and maximum flow rates and water pump selection. The pump must be interlocked with the heater to prevent heater operation without water circulation.

RELIEF VALVE PIPING

WARNING:

Pressure relief valve discharge piping must be piped near the floor close to a floor drain to eliminate the potential of severe burns. Do not pipe to any area where freezing could occur. Refer to local codes.

HYDROSTATIC TEST

Unlike many other types of heaters, Raypak heaters do not require hydrostatic testing prior to being placed in operation. The heat exchanger has already been factory-tested and is rated for 160 PSI maximum operating pressure. However, Raypak does recommend hydrostatically testing the piping connections to the heater and the rest of the system prior to operation. This is particularly true for hydronic systems using expensive glycol-based antifreeze. Raypak recommends conducting the hydrostatic test before connecting gas piping or electrical supply.

Leaks must be repaired at once to prevent damage to the heater. NEVER use petroleum-based stop-leak compounds.

1. Connect fill water supply. Fill heater with water (be sure bleed valve is open). When water flows from bleed valve, shut off water. Close bleed valve. Carefully fill the rest of the system, being sure to eliminate any entrapped air by using high point vents. Close feed valve. Test at standard operating pressure for at least 24 hours.
2. Make sure constant gauge pressure has been maintained throughout test.
3. Check for leaks. Repair if found.

LOW TEMPERATURE SYSTEM

Heater requires minimum inlet temperature of 105°F. Consult sections E, F for piping details.

TEMPERATURE & PRESSURE GAUGE

The temperature and pressure gauge is factory-mounted in the inlet/outlet header.

SECTION E: HYDRONIC HEATING PIPING

PUMP SELECTION

In order to ensure proper performance of your boiler system, you must install a properly sized pump. Raypak recommends using a 20°F Delta T as design Delta T. (Delta T is the temperature difference between the inlet and outlet water when the heater is firing at full rate). If a Delta T larger than 20°F is necessary, see Table D-1 for minimum flow rate requirements.

PRESSURE DROP IN FEET OF HEAD FEEDWATER REGULATOR

Raypak recommends that a feedwater regulator be installed and set at 12 PSIG minimum pressure at the highest point of system. Install a check valve or back flow device upstream of the regulator, with a manual shut off valve as required by local codes.

PIPING - HEATING BOILERS

All high points should be vented. Purge valves and a bypass valve should be installed. A boiler installed above radiation level must be provided with a low water cut-off device. The boiler, when used in connection with a refrigeration system, must be installed so the chilled medium is piped in parallel with the boiler with appropriate valves to prevent the chilled medium from entering the boiler.

The boiler piping system of a hot water heating boiler connected to heating coils located in air handling units where they may be exposed to circulating refrigerated air, must be equipped with flow control valves or other automatic means to prevent gravity circulation of the boiler water during the cooling cycle. It is highly recommended that the piping be insulated.

AIR-SEPARATION/EXPANSION TANK

All boilers should be equipped with a properly sized expansion tank and air separator fitting as shown in the following diagrams.

THREE-WAY VALVES

Valves designed to blend water temperatures or reduce water circulation through the boiler should not be used. Raypak boilers are high recovery low mass boilers not subject to thermal shock. Raypak offers a full line of electric sequencers that produce direct reset of boiler water temperature. Refer to the Controls Section in our Complete Catalog.

Table D-1


BOILER RATE OF FLOW AND PRESSURE DROP

Model	10°F ΔT		20°F ΔT		30°F ΔT		MIN FLOW			MAX FLOW		
	GPM	ΔP (ft)	GPM	ΔP (ft)	GPM	ΔP (ft)	GPM	ΔP (ft)	ΔT	GPM	ΔP (ft)	ΔT
122	20	2.5	10	<1.0	N/A	N/A	10*	<1.0	20	30	5.3	7
162	27	4.5	13	1.10	N/A	N/A	10	<1.0	27	30	5.4	9
202	34	7.2	17	1.85	11	<1.0	10	<1.0	34	30	5.5	11
242	40	10.0	20	2.65	14	1.3	10	<1.0	40	44	11.8	9
322	N/A	N/A	27	4.70	18	2.2	14	1.4	40	44	12.2	12

* Flow switch (when used) will not activate at less than 12 gpm.


NOTE: Basis for minimum flow - 10 gpm or 40° Delta T
maximum flow - 44 gpm, except for 1.25" header.

SINGLE BOILER - LOW TEMPERATURE APPLICATION (HEAT PUMP) PRIMARY/SECONDARY PIPING



Fig# 9396

DUAL BOILER PRIMARY/SECONDARY PIPING



NOTES:

1. PLUMB SWING CHECK VALVE IN GRAVITY CLOSED POSITION.
2. PIPE ALL RELIEF VALVES TO DRAIN, OR AS LOCAL CODES REQUIRE.

Fig. #M8336 rev 0

SECTION F: DOMESTIC HOT WATER PIPING

When designing the water piping system for domestic water applications, water hardness should be considered. Table F-1 indicates the suggested flow rates for soft, medium and hard water. Hardness is specified as grains per gallon.

TABLE F-1
DOMESTIC WATER HEATER
FLOW RATE REQUIREMENTS

MODEL	SOFT					MEDIUM					HARD*				
	0-4 GRAINS PER GALLON					5-15 GRAINS PER GALLON					16 + OVER GRAINS PER GAL.				
	ΔT	GPM	ΔP	MPS	SHL	ΔT	GPM	ΔP	MPS	SHL	ΔT	GPM	ΔP	MPS	SHL
122	10	20	2.5	1-1/4	4.9	8	26	4.0	1-1/4	7.8	7	30	5.3	1-1/4	10.3
162	14	20	2.5	1-1/4	4.9	11	26	4.1	1-1/4	7.9	9	30	5.4	1-1/4	10.4
202	17	20	2.6	1-1/4	5.0	13	26	4.2	1-1/4	8.0	11	30	5.5	1-1/4	10.5
242	21	20	2.6	1-1/2	3.5	16	26	4.3	1-1/2	5.9	9	44	11.8	1-1/2	16.1
322	27	20	2.7	1-1/2	3.6	20	27	4.8	1-1/2	6.6	12	44	12.2	1-1/2	16.5


* Must use optional Cupronickel tubes.

ΔT = Temperature Rise, Degree F
GPM = Gallons/Minute, Flow Rate
MPS = Minimum Pipe Size, NPT

ΔP = Pressure Drop Ft. thru heat exchanger
SHL = System Head Loss, Ft.

System head loss is based on the heater and tank placed no more than 5 feet apart and 25 feet equivalent length of pipe and fittings.

SINGLE HEATER DOMESTIC HOT WATER WITH ONE STORAGE TANK



SECTION G: POOL HEATING

CAUTION:

Power to the heater should be interlocked with the main system pump to make sure the heater does not fire without the main system pump in operation. Improper flow control can damage the heater. Uncontrolled flow (too high) or restricted flow (too low) can seriously damage the heater. Follow these instructions to make sure your heater is properly installed.

The Hi Delta pool heater is equipped with an external pump and bypass arrangement that blends outlet water with the inlet to increase the inlet water temperature, thereby reducing the likelihood of condensation forming on the heat exchanger. The pump also serves to circulate water through the heater from the main system piping.

To complete the installation of the pool heater, the pool thermostat needs to be installed in the main return water line. This will insure that the heater will be energized at the right time. If the main water line is too far away from the heater and the capillary bulb will not reach it, locate the pool thermostat adjacent to the main line and run wires back to the heater. See Figure #9225.

Adjustment of the bypass valve is critical to proper operation of the heater. The bypass valve should be adjusted to achieve a minimum inlet water temperature of 105°F and an outlet water temperature between 120°F and 140°F. When starting with a cold pool, make initial adjustments. Make final adjustments when pool water approaches desired temperature.

AUTOMATIC CHLORINATORS AND CHEMICAL FEEDERS

All chemicals must be introduced and completely diluted into the pool or spa water before being circulated through the heater. Do not place chlorine tablets or bromine sticks in the skimmer. High chemical concentrations will result when the pump is not running (i.e. overnight).

Chlorinators must feed downstream of the heater and have an anti-siphoning device to prevent chemical backup into the heater when the pump is shut off.

NOTE: *High chemical concentrates from feeders and chlorinators that are out of adjustment will cause very rapid corrosion to the heat exchanger in the heater. Such damage is not covered under the warranty.*

WINTERIZING YOUR HEATER

When heaters installed outdoors in freezing climate areas are to be shut down for the winter, please observe the following procedure:

1. Heaters installed outdoors in freezing climate areas should be shut down for the winter. To shut down heater, turn off manual main gas valve and main gas shut-off. Close isolation valves and remove water piping from the in/out header of the heater. Drain the heater and any piping of all water that may experience below freezing temperatures.

POOL AND SPA WATER CHEMISTRY

NOTE: *Chemical imbalance can cause severe damage to your heater and associated equipment. Maintain your water pH between 7.4 and 7.8 and total alkalinity between 100 and 150 p.p.m. If the mineral content and dissolved solids in the water become too high, scale forms inside the heat exchanger tubes, reducing heater efficiency and also damaging the heater. If the pH drops below 7.2, the heater will be severely damaged.*

NOTE: *Heat exchanger damage resulting from chemical imbalance and/or scaling is not covered under the warranty.*

SECTION H: GAS SUPPLY CONNECTIONS

DANGER: Make sure the gas on which the heater will operate is the same type as specified on the heater model and rating plate.

Gas piping must have a sediment trap ahead of the heater gas controls, and a manual shut-off valve located outside the heater jacket. A pounds to inches regulator must be installed to reduce to gas supply pressure to under 14" W.C. The regulator should be placed a minimum distance of 10 times the pipe diameter upstream of the heater gas controls. All gas piping must be tested after installation in accordance with local codes. The heater and its gas connection must be leak-tested before placing it in operation.




Fig. #9401.1

GAS SUPPLY CONNECTION

CAUTION: The heater and its manual shutoff valve must be disconnected from the gas supply during any pressure testing of the gas supply system at test pressures in excess of 1/2 PSIG (3.45 KPA). The heater must be isolated from the gas supply piping system by closing the manual shutoff valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 PSIG. Relieve test pressure in the gas supply line before reconnecting the heater and its manual shut off valve to the gas supply line. **FAILURE TO FOLLOW THIS PROCEDURE MAY DAMAGE THE GAS VALVES.** Over pressurized gas valves are not covered by warranty. The heater and its gas connections shall be leak tested before placing the appliance in operation. Use soapy water for leak test: **DO NOT** use open flame.

CAUTION: Do not use Teflon tape on gas line pipe thread. A pipe compound rated for use with gas systems is recommended. Apply sparingly only on male pipe ends.

CAUTION: Support gas supply piping with hangers, not by the heater or its accessories. Ensure the gas piping is protected from physical damage and freezing where required.

GAS SUPPLY PRESSURE

A minimum of 7" W.C. and a maximum of 10.5" W.C. upstream gas pressure is required under no load conditions for natural gas. A minimum of 12" W.C. and a maximum of 13" W.C. is required for propane gas. The gas pressure regulator supplied on the heater is for low pressure service. **If upstream pressure exceeds 14" W.C., an intermediate gas pressure regulator, of the lockup type, must be installed.**

When connecting additional gas utilization equipment to the gas piping system, the existing piping must be checked to determine if it has adequate capacity.

MODEL	SOFT					MEDIUM					HARD*				
	0-4 GRAINS PER GALLON					5-15 GRAINS PER GALLON					16 + OVER GRAINS PER GAL.				
	ΔT	GPM	ΔP	MPS	SHL	ΔT	GPM	ΔP	MPS	SHL	ΔT	GPM	ΔP	MPS	SHL
122	10	20	2.5	1-1/4	4.9	8	26	4.0	1-1/4	7.8	7	30	5.3	1-1/4	10.3
162	14	20	2.5	1-1/4	4.9	11	26	4.1	1-1/4	7.9	9	30	5.4	1-1/4	10.4
202	17	20	2.6	1-1/4	5.0	13	26	4.2	1-1/4	8.0	11	30	5.5	1-1/4	10.5
242	21	20	2.6	1-1/2	3.5	16	26	4.3	1-1/2	5.9	9	44	11.8	1-1/2	16.1
322	27	20	2.7	1-1/2	3.6	20	27	4.8	1-1/2	6.6	12	44	12.2	1-1/2	16.5

GAS PRESSURE REGULATOR

The gas valve pressure regulator(s) on the heater are nominally preset at 3.5" W.C. for Natural gas, and 10.5" W.C. for Propane gas manifold pressure. The pressure at the gas valve outlet tap, measured with a manometer, while in operation should be 3.5 ± 0.1 " W.C. for Natural gas and 10.5 ± 0.1 " W.C. for Propane gas. If an adjustment is needed, turn the adjustment screw clockwise to increase pressure or counter-clockwise to decrease pressure.

SECTION I: ELECTRICAL POWER CONNECTIONS

Installations must follow these codes:

- National Electrical Code and any other national, state, provincial or local codes or regulations having jurisdiction
- Safety wiring must be N.E.C. Class 1
- Heater must be electrically grounded as required by N.E.C.
- In Canada, C22. 1

The heater is wired for 120 Volts, 12 AMPS. The voltage is indicated on the tie-in leads. Consult the wiring diagram shipped with the heater in the instruction packet. The remote tank control stat, thermostat, or electronic heater control as applicable, may be connected to stage selector terminal (See wiring diagram). 24 Volts are supplied to this connection through the heater transformer. DO NOT attach line voltage to the “TH” leads. Before starting the heater check to insure proper voltage to the heater and pump.

Install a separate disconnect means for each load. Use appropriate-sized wire as defined by NEC, CSA and/or local code. All primary wiring should be 125% of minimum rating.

It is strongly recommended that all individually-powered control modules and the heater should be supplied from the same power source.

SURGE PROTECTION

Microprocessor-based and solid state controls are vulnerable to damage from voltage and amperage fluctuations in the power supply. All sensitive control components should be protected by a suitable commercial-grade surge protection device.

If any of the original wire as supplied with the heater must be replaced, it must be replaced with 105°C wire or its equivalent.

CHECK THE POWER SOURCE

Using a volt-ohm meter (VOM), check the following voltages at the circuit breaker panel prior to connecting any equipment: Make sure proper polarity is followed and house ground is proven.

FIGURE I-1
CHECK POWER SOURCE




Fig. # 9237

AC = 108 Volts AC Minimum, 132 Volts AC MAX
AB = 108 Volts AC Minimum, 132 Volts AC MAX
BC = < 1 Volt AC

MAKING THE ELECTRICAL CONNECTIONS

Refer to Fig. #9403 Wiring Connection, and Wiring Diagram #152564.

1. Verify circuit breaker is properly sized by referring to heater rating plate. A dedicated circuit breaker should be provided.
2. Turn off all power to the heater. Verify that power has been turned off by testing with a volt-ohm meter prior to working with any electrical connections or components.
3. Observe proper wire colors while making electrical connections. Many electronic controls are polarity sensitive. Components damaged by improper electrical installation are not covered by warranty.
4. Provide an external surge suppressor capable of maintaining system integrity.
5. Provide overload protection and a disconnect means for equipment serviceability as required by local and state code.
6. Install heater controls, thermostats, or building management systems in accordance with the applicable manufacturer's instructions.
7. Conduit should not be used as the ground. There must be a solidly wired ground.

NOTICE:

A grounding electrode conductor shall be used to connect the equipment grounding conductors, the equipment enclosures, and the grounded service conductor to the grounding electrode.

FIELD WIRING CONNECTION


FIELD—CONNECTED CONTROLLERS, MODELS 122–322

IF UNIT DOES NOT HAVE A FACTORY WIRED STAGE CONTROLLER, THE UNIT IS FACTORY—WIRED IN ON/OFF CONFIGURATION WITH OTHER STAGE TERMINALS JUMPERED.

TO FIELD—CONNECT STAGE CONTROLLER, REMOVE FACTORY—INSTALLED JUMPER AND WIRE STAGE CONTROL AS SHOWN:

ON/OFF

STAGE
SELECTOR



2-STG

STAGE
SELECTOR




Fig. #9446

ELECTRICAL CONNECTIONS - DOMESTIC HOT WATER

CAUTION:

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation. Verify proper operation after servicing.

DANGER

-SHOCK HAZARD

Make sure electrical power to the heater is disconnected to avoid potential serious injury or damage to components.

Installer action is required to electrically enable your Hi Delta heater to operate after making the power connections. You must make a connection on Terminal Block #3 for temperature control connections. This will be done based on the controller option selected with your heater order.

1. For Pool and Closed Loop Water Source Heat Pump applications, your heater should be configured to operate in an ON/OFF firing mode. This means that you will connect a single-pole control to stage one of stage selector (Terminals 1&2). Then jumper the remaining firing stages. For example, if your heater is a 162, you will jumper stage two. Then your heater will either be on at full fire, or it will be off.
2. For multi-stage controller connections, connect each stage of the control to the corresponding stage selector terminal block in the heater. Stage 1 of the heater to stage 1 of the control. Stage 2 of the heater to stage 2 of the control, and so on. Set the operating control at the setpoint in which you want the heater to maintain. Ensure that the sensing bulb of the control is at the point in the system that will best maintain the temperature you want. For example, when you are heating a tank of water, you want the operating control sensor bulb in the tank.

Consult the wiring diagram shipped with the heater in the instruction packet. The "TH" connections are for the remote tank control through the heaters 24 volt transformer. DO NOT attach line voltage to the "TH" connection. Before starting heater check to ensure proper voltage to heater and pump.





Fig. #9138.2

ATTACH STAGE 1 CONNECTIONS ON HEATER TO THE SINGLE - STAGE TANKSTAT AS SHOWN IN THE DIAGRAM ABOVE.



ig. #9138.1

ATTACH STAGE 1 CONNECTIONS ON HEATER TO STAGE 1 CONNECTION ON TANKSTAT. ATTACH STAGE 2 CONNECTIONS OR STAGE CONNECTIONS OF HEATER 2 TO STAGE 2 CONNECTION ON TANKSTAT AS SHOWN IN DIAGRAM.

Heater must be electrically grounded in accordance with NEC and C22.1(in Canada).

NOTES:

1. Field installed ground to inside of junction box.
2. If any of the original wire as supplied with the heater must be replaced, it must be replaced with 105°C wire or its equivalent.

SECTION J: VENTING CONNECTIONS

GENERAL

CAUTION: *Proper installation of flue exhaust venting is critical for the safe and efficient operation of the heater.*

Definition of Appliance Categories

Heaters are divided into four categories based on the pressure produced in the exhaust and the likelihood of condensate production in the vent.

- | | |
|---------------|--|
| Category I. | A heater which operates with a non-positive vent static pressure and with a vent gas temperature that avoids excessive condensate production in the vent. |
| Category II. | A heater which operates with a non-positive vent static pressure and with a vent gas temperature that may cause excessive condensate production in the vent. |
| Category III. | A heater which operates with a positive vent pressure and with a vent gas temperature that avoids excessive condensate production in the vent. |
| Category IV. | A heater which operates with a positive vent pressure and with a vent gas temperature that may cause excessive condensate production in the vent. |

See Table J-1 for appliance category requirements for the Hi Delta.

Note: *For additional information on appliance categorization, see appropriate ANSI Z21 Standard and the latest NFPA or in Canada, the B149 Installation Code or applicable provisions of local building codes.*

Determination of Appliance Category for Venting Purposes and Venting Arrangements

WARNING: *Contact the manufacturer of the vent material if there is any question about the appliance categorization and suitability of a vent material for application on a Category III or IV vent system. Using improper venting materials can result in personal injury, death or property damage.*

HI DELTA VENTING ARRANGEMENTS

COMBUSTION AIR SUPPLY	EXHAUST CONFIGURATION	VENTING CATEGORY	CERTIFIED APPLIANCE MATERIALS	COMBUSTION AIR INLET MATERIAL
From Inside Building (Non-Direct Venting)	Vertical Natural Draft Venting	I	Type B or any Category I Venting System*	
	Horizontal Thru-Wall Venting	III	Stainless Steel (Gas Tight)	
From Outside Building (Direct Venting)	Vertical Venting	I	Type B or any Category I Venting System*	Galvanized Steel PVC ABS CPVC
	Horizontal Thru-Wall Venting	III	Stainless Steel (Gas Tight)	

* As defined in the latest edition of the NFGC, or in Canada, the B149.1 and .2

TABLE J-1

Support of Vent Stack

The weight of the vent stack or chimney must not rest on the heater vent connection. Support must be provided in compliance with applicable codes. The vent should also be supported to maintain proper clearances from combustible materials.

Use insulated vent pipe spacers where the vent passes through combustible roofs and walls.

Vent Terminal Location

NOTICE:

During winter months check the vent cap and make sure no blockage occurs from build up of snow. Condensate can freeze on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition.

General

Give special attention to the location of the vent termination to avoid possibility of property damage or personal injury.

- a) Gases may form a white vapor plume in winter. The plume could obstruct a window view if the termination is installed in close proximity to windows.
- b) Prevailing winds could cause freezing of condensate and water/ice build-up on building, plants or roof.
- c) The bottom of the vent terminal and the air intake shall be located at least 12 in. above grade.
- d) Un-insulated single-wall metal vent pipe shall not be used outdoors on cold climates for venting gas utilization equipment.
- e) Through-the-wall vents for Category II and IV appliances and non-categorized condensing appliances shall not terminate over public walkways or over an area where condensate or vapor could create a nuisance or hazard or could be detrimental to the operation of regulators, relief valves, or other equipment. Where local experience indicates that condensate is a problem with Category I and III appliances, this provision shall also apply.
- f) Locate and guard vent termination to prevent accidental contact by people or pets.
- g) DO NOT terminate vent in window well, stairwell, alcove, courtyard or other recessed area, unless previously approved by local authority.
- h) DO NOT terminate above any door, window, or gravity air intake. Condensate can freeze, causing ice formations.
- i) Locate or guard vent to prevent condensate from damaging exterior finishes. Use a 2' x 2' rust resistant sheet metal backing plate against brick or masonry surfaces.
- j) DO NOT extend exposed vent pipe outside of building. Condensate could freeze and block vent pipe.

US Installations - Refer to latest edition of NFPA

Vent termination requirements are as follows:

- a) Vent must terminate at least four (4) feet below, four (4) feet horizontally, or one (1) foot above any door, window or gravity air inlet to the building.
- b) The vent must not be less than seven (7) feet above grade when located adjacent to public walkways.
- c) Terminate vent at least three (3) feet above any forced air inlet located within ten (10) feet.
- d) Vent must terminate at least four (4) feet horizontally, and in no case above or below unless four (4) feet horizontal distance is maintained, from electric meters, gas meters, regulators, and relief equipment.
- e) Terminate vent at least six (6) feet away from adjacent walls.
- f) DO NOT terminate vent closer than five (5) feet below roof overhang.
- g) The vent terminal of a direct vent appliance with an input over 50,000 Btu per hour shall require a 12-inch vent terminal clearance.
- h) Terminate vent at least one (1) foot above grade, including normal snow line.
- i) Multiple direct vent installations require a four (4) foot clearance between vent caps.

Canada Installations - Refer to latest edition of CAN/CGA-B149.1 and .2

A vent shall not terminate:

- a) Directly above a paved sidewalk or driveway which is located between two single family dwellings and serves both dwellings
- b) Less than 7 ft.(2.13m)above a paved sidewalk or paved driveway located on public property
- c) Within 6 ft(1.8m) of a mechanical air supply inlet to any building
- d) Above a meter/regulator assembly within 3 ft(900mm) horizontally of the vertical centre-line of the regulator
- e) Within 6 ft.(1.8m) of any gas service regulator vent outlet
- f) Less than 1 ft.(300mm) above grade level
- g) Within the 3 ft.(1m) of a window or door which can be opened in any building, any non-mechanical air supply inlet to any building or the combustion air inlet of any other appliance
- h) Underneath a verandah, porch or deck, unless
 - (i) the verandah, porch or deck is fully open on a minimum of two sides beneath the floor, and
 - (ii) the distance between the top of the vent termination and the underside of the verandah, porch or deck is greater than 1 ft (30 cm).

Venting Installation Tips

Support piping:

- horizontal runs- at least every five (5) feet.
- vertical runs - use braces:
- under or near elbows

Follow items listed below to avoid personal injury or property damage.

- Cut nonmetallic intake pipe with fine-toothed hacksaw.
- Do not use nonmetallic intake pipe or fittings that are cracked or damaged.
- Do not use nonmetallic intake fittings if they are cut or altered.
- Do not drill holes, or use screws or rivets, in nonmetallic intake pipe or fittings.

To make metallic vent joints:

- Do not install seams of vent pipe on bottom of runs.
- 100% Seal all joints and seams with high temperature silicone sealant.

WARNING: *Examine the venting system at least once a year. Check all joints and vent pipe connections for tightness, corrosion or deterioration.*


NOTE: The words "*Flue Exhaust*", "*Flue*" and "*Exhaust Vent*" are used interchangeably.

VENTING CONFIGURATIONS

For heaters connected to gas vents or chimneys, vent installations shall be in accordance with the section on, Venting of Equipment, of the latest edition of NFGC, or in Canada, B149.1 and .2 Installation Code for Gas Burning Appliances and Equipment, or applicable provisions of local building codes.

SECTION J-1

Natural Draft Vertical Venting (Category I)



NATURAL DRAFT VERTICAL VENT

MODEL	APPLIANCE CATEGORY	CERTIFIED VENTING MATERIAL	MINIMUM RECOMMENDED VENT SIZE (INCHES)	MINIMUM / MAXIMUM VENTING LENGTH W/O BAROMETRIC DAMPER (FEET)**
122	I	Type B or Equivalent	4	5/25
162			5	
202			5	
242			5	
322			6	

NOTE:

**Vent lengths are based on a lateral length of 2 feet. Refer to the latest edition of the NFGC for further details. (ANSI Z223.1)

• Natural Draft Vertical Venting System Installation

Natural draft venting uses the natural buoyancy of the heated flue products to create a thermal driving head that expels the exhaust gases from the flue. The negative draft must be within the range of $-.01''$ to $-.08''$ W.C. as measured 12 in. from the appliance flue outlet to ensure proper operation. Vent material must be listed by a nationally recognized test agency.

The maximum and minimum venting length for Category I appliance shall be determined per the latest edition of the NFGC (U.S.) or B149.1 and .2 Installation Code (Canada).

The diameter of vent flue pipe should be sized according to Part 11 of the latest edition of the NFGC (U.S.) and part 7 and appendix B of the B149.1 and .2 Installation Code (Canada). The minimum flue pipe diameter for conventional negative draft venting using double-wall B type vent is 4" for 122, 5" for 162, 202 and 242, 6" for 322.

NOTICE: *Vent Adapter will have to be used to connect B vent to the unit.*

The connection from the appliance vent to the stack must be as direct as possible and shall be the same diameter as, or larger than the vent outlet. The horizontal breaching of a vent must have an upward slope of not less than 1/4 inch per linear foot from the heater to the vent terminal. The horizontal portions of the vent shall also be supported for the design and weight of the material employed to maintain clearances and to prevent physical damage or separation of joints.

• Natural Draft Vertical Vent Termination

The vent terminal should be vertical and should terminate outside the building at least two (2) feet above the highest point of the roof that is within 10 feet. The vent cap should have a minimum clearance of four (4) feet horizontally from and in no case above or below (unless a four (4) foot horizontal distance is maintained) electric meters, gas meters, regulators and relief equipment. The distance of the vent terminal from adjacent public walkways, adjacent buildings, open windows and building openings must be consistent with the NFGC, or in Canada, the B149 Installation Code for Gas Burning Appliances and Equipment. Gas vents supported only by flashing and extended above the roof more than five feet should be securely guyed or braced to withstand snow and wind loads.

CAUTION: *Listed vent cap terminal must be used and sized adequately to evacuate the flue products from the heaters.*

• Natural Draft Vertical Venting With Common Venting System, Category I Appliance Only

Manifolds that connect more than one heater to a common chimney must be sized to handle the combined load. Consult available guides for proper sizing of the manifold and the chimney. At no time should the area of the vent be less than the area of the largest heater exhaust outlet.

WARNING: *Vent connectors serving appliances vented by natural draft shall not be connected into any portion of mechanical draft systems operating under a positive pressure.*

CAUTION: *Vent connectors for natural draft venting systems must be type "B" vent or better.*

Common venting systems may be too large when an existing unit is removed. At the time of removal of an existing appliance, the following steps must be followed with each appliance remaining connected to the common venting system placed in operation, while the other appliances remaining connected to the common venting system are not in operation.

- a) Seal any unused opening in the common venting system.
- b) Visually inspect the venting system for proper size and horizontal pitch and determine there is no blockage or restriction, leakage, corrosion or other unsafe condition.
- c) Insofar as is practical, close all building doors and windows and all doors between the space in which the appliances remaining connected to the common venting system are located and other spaces of the building. Turn on clothes dryers and any appliance not connected to the common vent system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate summer exhaust fan. Close fireplace dampers.
- d) Place in operation the appliances being inspected. Follow the manufacturers instructions for lighting each appliance. Adjust thermostat so appliance will operate continuously.
- e) Test for spillage at the drafthood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle, or smoke from a cigarette, cigar or pipe, toilet paper trick. For the Hi Delta, check the pressure at a pressure tap located 12 in. above the bottom joint of the first vertical vent pipe. Pressure should be anywhere between -.01 to -.08 inch W.C.
- f) After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and other gas burning appliances to their previous conditions of use.
- g) Any improper operation of the common venting system should be corrected so that the installation conforms with the latest edition of the NFGC (US) and the B 149.1 and .2 Installation Code (Canada). When re-sizing any portion of the common venting system, the common venting system should be re-sized to approach the minimum size as determined using the appropriate tables in Appendix G in the NFGC (US) and Appendix B of the B 149 Installation Code (Canada).

SECTION J-2

Horizontal Thru-Wall Venting (Category III)




Fig # 9402

HORIZONTAL THRU-WALL VENTING (CATEGORY III) TABLE

MODEL	APPLIANCE CATEGORY	CERTIFIED VENTING MATERIAL	VENT SIZE (INCHES)	MAXIMUM VENTING LENGTH (FEET)
122	III	Stainless Steel (Gas Tight)	4	70 Subtract 10 ft per elbow Maximum three elbows
162 202 242			5	
322			6	

- Horizontal Thru-wall Venting System (Category III) Installation**

These installations utilize the heater-mounted blower to vent the combustion products to the outdoors. Combustion air is taken from inside the room and the vent is installed horizontally through the wall to the outdoors. Adequate combustion and ventilation air must be supplied to the mechanical room in accordance with the NFGC or, in Canada, the B149.1 and .2 Installation Code.

The total length of the horizontal thru-wall exhaust vent system should not exceed seventy (70) feet in length. If horizontal run exceeds 70 feet, an appropriately sized extractor must be used. To maintain proper operation pressure reading must be between -.01" to -.08" W.C. as measured 12 in. from the appliance flue outlet. Each elbow used is equal to ten (10) feet of straight pipe. This will allow installation in one of the four following combinations.

- 70' of straight flue pipe.
- 60' of straight flue pipe and one elbow.
- 50' of straight flue pipe and two elbows.
- 40' of straight pipe and three elbows.

The vent cap is not considered in the overall length of the venting system.

The vent must be installed to prevent the flue gas leakage. Care must be taken during assembly to ensure that all joints are sealed properly and are airtight.

The vent must be installed to prevent the potential accumulation of condensate in the vent pipes. It is recommended that:

- a) The vent be installed with a slight downward slope of not more than 1/4" per foot of horizontal run to the vent terminal.
- b) The vent be insulated through the length of the horizontal run.

For appliances installed in extreme cold climate, it is recommended that:

- a) The vent be installed with a slight upward slope of not more than 1/4" per foot of horizontal run to the vent terminal. In this case, an approved condensate trap must be installed per applicable codes.
- b) The vent be insulated through the length of the horizontal run.

• **Horizontal Thru-wall Direct Vent Termination**

The flue exhaust direct vent cap **MUST** be mounted on the exterior of the building. The direct vent cap cannot be installed in a well or below grade. The direct vent cap must be installed at least one (1) foot above ground level and above normal snow levels. The Raypak supplied flue exhaust direct vent cap must be utilized.

WARNING:


No substitutions of flue pipe or vent cap material are allowed. Such substitutions would jeopardize the safety and health of inhabitants.

The Stainless Steel direct vent cap must be furnished by the heater manufacturer in accordance with its listing.

Use only the special gas vent pipes listed for use with category III gas burning heaters, such as the stainless steel vent by Heat Fab Inc (800-772-0739), Protech Systems, Inc. (800-766-3473) or Z-Flex (800-654-5600). Pipe joints must be positively sealed. Follow carefully the vent manufacturers installation instructions.

SECTION J-3

DIRECT VENT Horizontal Thru-wall Venting (Category III)



HORIZONTAL THRU-WALL VENTING TABLE

MODEL	APPLIANCE CATEGORY	CERTIFIED VENTING MATERIAL	VENT SIZE (INCHES)	MAXIMUM VENTING LENGTH (FEET)	COMBUSTION AIR INTAKE PIPE MATERIAL	AIR INLET SIZE (INCHES)	MAXIMUM AIR INTAKE LENGTH (FEET)
122	III	Stainless Steel (Gas Tight)	4	40 Subtract 10 ft per elbow Maximum two elbows	Galvanized Steel PVC ABS CPVC	5	40 Subtract 10 ft per elbow Maximum two elbows
162							
202							
242							
322			6				

- **Horizontal Thru-wall Direct Vent System (Category III) Installation**

These installations utilize the heater mounted blower to draw combustion air from outdoors and vent combustion products to the outdoors.

The total length of the thru-wall exhaust vent cannot exceed forty (40) feet in length for the flue outlet. Each elbow used is equal to ten (10) feet of straight pipe. This will allow installation in one of the three following combinations.

- 40' of straight flue pipe.
- 30' of straight flue pipe and one elbow.
- 20' of straight flue pipe and two elbows.

The total length air supply pipe cannot exceed forty (40) feet in length for the combustion air inlet. Each elbow used is equal to ten (10) feet of straight pipe. This will allow installation in one of the three following combinations.

- 40' of straight combustion air pipe
- 30' of straight combustion air pipe and one elbow.
- 20' of straight combustion air pipe and two elbows.

The flue exhaust direct vent cap is not considered in the overall length of the venting system.

Care must be taken during assembly that all joints are sealed properly and are airtight.

The vent must be installed to prevent the potential accumulation of condensate in the vent pipes. It is recommended that:

- a) The vent be installed with a slight downward slope of not more than 1/4" per foot of horizontal run to the vent terminal.
- b) The vent be insulated through the length of the horizontal run.

For appliances installed in extreme cold climate, it is recommended that:

- a) The vent be installed with a slight upward slope of not more than 1/4" per foot of horizontal run to the vent terminal. In this case, an approved condensate trap must be installed per applicable codes.
- b) The vent be insulated through the length of the horizontal run.

- **Horizontal Thru-wall Direct Vent Termination**

The flue exhaust direct vent cap **MUST** be mounted on the exterior of the building. The direct vent cap cannot be installed in a well or below grade. The direct vent cap must be installed at least one (1) foot above ground level and above normal snow levels.

Multiple direct vent caps **MUST NOT** be installed with one combustion air inlet directly above a direct vent cap. This vertical spacing would allow the flue products from the direct vent cap to be pulled into the combustion air intake installed above. This type of installation can cause non warrantable problems with components and poor operation of the unit due to the recirculation of flue products. Multiple direct vent caps should be installed in the same horizontal plane with a three (3) foot clearance from the side of one vent cap to the side of the adjacent vent cap(s).

Combustion air supplied from outdoors must be free of particulate and chemical contaminants. To avoid a blocked flue condition, keep the vent cap clear of snow, ice, leaves, debris, etc.


WARNING: *No substitutions of flue pipe or vent cap material are allowed. Such substitutions would jeopardize the safety and health of inhabitants.*

The Stainless Steel flue exhaust direct vent cap must be furnished by the heater manufacturer in accordance with its listing.

Use only the special gas vent pipes listed for use with category III gas burning heaters, such as the stainless steel vent by Heat Fab Inc (800-772-0739), Protech Systems, Inc. (800-766-3473) or Z-Flex (800-654-5600). Pipe joints must be positively sealed. Follow carefully the vent manufacturers installation instructions.

SECTION J-4

DIRECT VENT Vertical Venting (Category I)



VERTICAL VENTING TABLE

MODEL	APPLIANCE CATEGORY	CERTIFIED VENTING MATERIAL	MINIMUM RECOMMENDED VENT SIZE (INCHES)	MINIMUM/MAXIMUM VERTICAL VENTING HEIGHT (FEET)	COMBUSTION AIR INTAKE PIPE MATERIAL	AIR INLET SIZE (INCHES)	MAXIMUM AIR INTAKE LENGTH (FEET)
122	I	Type B Equivalent	4	5/25	Galvanized Steel PVC ABS CPVC	5	40 Subtract 10 ft per elbow Maximum two elbows
162			5				
202			5				
242			5				
322			6				

- **Vertical Direct Vent System Installation**

These installations utilize the heater mounted blower to draw combustion air from outdoors and uses the natural buoyancy of the heated flue products to create a thermal driving head that expels the exhaust gases from the flue. The negative draft must be within the range of -0.01" to -0.08" W.C. as measured 12 in. from the appliance outlet to insure proper operation. The vent material must be in accordance with the above instructions for vent materials. Vent material must be listed by a nationally recognized test agency.

The maximum and minimum venting length for Category I appliance shall be determined per the latest edition of the NFGC (U.S.) and B149.1 and .2 Installation Code (Canada).

The connection from the appliance exhaust vent to the stack must be as direct as possible and should be the same as or larger than the vent outlet. The vent must be installed to prevent accumulation of condensate and, where necessary, have means provided for drainage of condensate. The horizontal breaching of a vent must have an upward slope of not less than 1/4 inch per linear foot from the heater to the vent terminal. The horizontal portions of the vent shall also be supported for the design and weight of the material employed to maintain clearances and to prevent physical damage or separation of joints.

- **Vertical Direct Vent Termination**

The exhaust vent terminal should be vertical and should terminate outside the building at least two (2) feet above the highest point of the roof within 10 feet. The vent cap should have a minimum clearance of four (4) feet horizontally from and in no case above or below (unless a four (4) foot horizontal distance is maintained) electric meters, gas meters, regulators and relief equipment. The distance of the vent terminal from adjacent public walkways, adjacent buildings, open windows and building openings must be consistent with the NFGC, or in Canada, the B149.1 and .2. Installation Code. Gas vents supported only by flashing and extended above the roof more than five feet should be securely guyed or braced to withstand snow and wind loads.

The vertical direct vent cap is designed for roof top mounting only. The air inlet opening MUST be installed one (1) foot above the roof line or above normal snow levels that might obstruct combustion air flow. This dimension is critical to the correct operation of the heater and venting system and reduces the chance of blockage from snow. The vent cap must have a minimum 3 foot clearance from the air inlet opening.

SECTION J-5 **Outdoor Installation**

Outdoor models are self-venting when installed with the factory-supplied restricted direct vent cap and require no additional vent piping. This special vent cap is provided with the heater in accordance with CSA requirements. It must be installed directly on the heater. See Section B for correct clearances.

Care must be taken when locating the outdoor unit because the flue gases discharged from the vent hood can condense as they leave the hood. Improper location can result in damage to adjacent structures or building finish. For maximum efficiency and safety, the following precautions must be observed:

- a) Outdoor models must be installed outdoors and must use the outdoor vent hood supplied by the manufacturer.
- b) Periodically check venting system. The heater's venting areas must never be obstructed in any way and minimum clearances must be observed to prevent restriction of combustion and ventilation air. Keep area clear and free of combustible and flammable materials.
- c) Do not locate adjacent to any window, door walkway, or gravity air intake. The vent must be located a minimum of four (4) feet horizontally, or four (4) feet below, or one (1) foot above such areas.
- d) Install above grade level and above normal snow levels.
- e) Vent terminal must be at least 3 feet above any forced air inlet located within 10 feet.
- f) Adjacent brick or masonry surfaces must be protected with a rust-resistant sheet metal plate.
- g) Multiple Outdoor Vent installations require a four (4) feet clearance between vent caps.

NOTICE:

Condensate can freeze on the vent cap. Frozen condensate on the vent cap can result in a blocked flue condition.

The restricted vent cap must be furnished by the heater manufacturer in accordance with its listing.

An outdoor air filter, supplied by the manufacturer is mounted on the heater.

SECTION K: CONTROLS

WARNING: *Installation, adjustment and service of heater controls including timing of various operating functions must be performed by a qualified installer, service agency or the gas supplier. Failure to do so may result in control damage, heater malfunction, property damage, personal injury, or death.*

WARNING: *Turn off the power to the heater before installation, adjustment or service of the heater controls. Failure to do so may result in heater malfunction, property damage, personal injury, or death.*

CAUTION: *This appliance has provisions to be connected to more than one (1) supply source. To reduce the risk of electric shock, disconnect all such connections before servicing.*

CAUTION: *Risk of electric shock. More than one (1) disconnect switch may be required to de-energize the equipment before servicing.*

IGNITION CONTROL MODULE

The interrupted proved ignition device conserves energy. When additional heat is needed, the combustion air blower starts to purge all air from the combustion chamber for about 15 seconds. On proof of air flow, the air proving switch closes and the igniter is energized, eliminating the fuel costs of maintaining a constant pilot. To assure safe operation, the gas valve cannot open until the pilot igniter is verified. The 100% igniter safety is an electronic device which closes the main gas valve within 8/10 of a second whenever the flame is interrupted. Main burner is automatically lit when the device is powered and pre-purged. Unit performs its own safety check and opens the main valve only after the igniter is proven to be capable of ignition.





Fig. #9322

IGNITION MODULE

HIGH LIMIT (MANUAL RESET)

The heater is equipped with a manual reset high limit temperature device. Push the reset button and adjust the setting to 30° F or 40° F above desired operating temperature.



Drw. #8644


Fig. J-3

MANUAL RESET HIGH LIMIT

FLOW SWITCH

Dual-purpose control shuts off heater in case of pump failure or low water flow. Mounted and wired in series with the main gas valve. Check with Manufacturer for proper paddle size. Utilize correct paddle size for proper operation.

Flow switch will not operate if flow is less than 20 GPM.




Drw. #8241.1

Fig. J-4

FLOW SWITCH

OPERATING CONTROL

The heater may be equipped with different types of operating controls. Consult data sheet supplied with installation instructions. See Section L for adjustment safety precautions on domestic hot water applications.




Drw. #8643

THERMOSTAT CONTROL

LOW WATER CUT OFF (OPTIONAL)

The low water cut off automatically shuts down the burner whenever water level drops below the level of the sensing probe. A 3-second time delay prevents premature lockout due to temporary conditions such as power fluctuations or air pockets.




Drw. #8996.1

Fig.# J-5

LOW WATER CUT-OFF

WIRE DIAGRAM MODELS 122-322

Reference Drawing Number M152564C



NOTES:


1. USE GROUND CONNECTION PROVIDED. FAILURE TO PROVIDE PROPER GROUND MAY RESULT IN LOCK-OUT.

ALL GROUND ∇ TERMINATE AT \oplus
 ✓ CHECK CONTROLS PROVIDED (WIRED AS SHOWN)
 REPLACE WIRING WITH 105°C WIRE ONLY

SECTION L: GENERAL SAFETY PRECAUTIONS

To meet commercial water use needs, the temperature Hi-Limit on this hot water heater is adjustable up to 210°F. However, water temperatures over 125°F can cause severe burns instantly or death from scalds. The preferred starting point for setting the control for supplying general purpose hot water is 125°F.

Safety and energy conservation are factors to be considered when setting the water temperature on the thermostat. The most energy efficient operation will result when the temperature setting is the lowest that satisfies the needs consistent with the application.



Water temperature over 125°F can cause severe burns instantly or death from scalds.

Children, disabled and elderly are at highest risk of being scalded.

See instruction manual before setting temperature at water heater.

Feel water before bathing or showering.

Temperature limiting valves are available, see note below.

Maximum water temperatures occur just after the heater's burner has shut off. To determine the water temperature being delivered, turn on a hot water faucet and place a thermometer in the hot water stream and read the thermometer.

The following chart details the relationship of water temperature and time with regard to scald injury and may be used as a guide in determining the safest water temperature for your applications.

Temperature	Time to Produce Serious Burn	Temperature	Time to Produce Serious Burn
120°F	More than 5 minutes	140°F	Less than 5 seconds
125°F	1-1/2 to 2 minutes	145°F	Less than 3 seconds
130°F	About 30 seconds	150°F	About 1-1/2 seconds
135°F	About 10 seconds	155°F	About 1 second

Table courtesy of The Shriners Burn Institute


TIME/TEMPERATURE RELATIONSHIPS IN SCALDS

The temperature of the water in the hot water heater can be regulated by setting the temperature dial on front of the thermostat. To comply with safety regulations the thermostat was set at its lowest setting before the hot water heater was shipped from the factory. The illustration below shows the thermostat and how to adjust the water temperature.

To adjust the water temperature, insert a small straight screwdriver into slotted screw in hole in front of thermostat and turn wheel to desired setting.

CAUTION!! - Hotter water Increases the risk of SCALDING!

There is a Hot Water SCALD Potential if the thermostat is set too high.



NOTE: When this hot water heater is supplying general purpose hot water requirements for use by individuals, a thermostatically controlled mixing valve for reducing point of use water temperature is recommended to reduce the risk of scald injury. Contact a licensed plumber or the local plumbing authority for further information.

SECTION M: PRE-START-UP

FILLING SYSTEM-HEATING HEATERS

Fill system with water. Purge all air from the system using purge valve sequence. After system is purged of air, lower system pressure. Open valves for normal system operation, fill system through feed pressure. Manually open air vent on the compression tank until water appears, then close vent.

DOMESTIC HOTWATER HEATERS

Purge all air from system before lighting heater. This can be normally be accomplished by opening a downstream valve.

INSPECT VENTING SYSTEM:

1. Check all vent pipe connections and flue pipe material.
2. Ensure vent terminations are installed per code and are clear of all debris or blockage.

FOR YOUR SAFETY READ BEFORE LIGHTING

WARNING:

If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

1. This appliance does have an intermittent pilot. It is equipped with an ignition device which automatically lights the pilot. DO NOT try to light the pilot or burner by hand.
2. BEFORE OPERATING, smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.
3. WHAT TO DO IF YOU SMELL GAS
 - Do not try to light any appliance.
 - Do not touch any electrical switch; do not use any telephone in your building.
 - Immediately call your gas supplier from a neighbor's telephone. Follow the gas supplier's instructions.
 - If you cannot reach your gas supplier, call the fire department.
4. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not turn by hand, do not try to repair it, call a qualified service technician. Forced or attempted repair may result in a fire or explosion.
5. Do not use this appliance if any part has been under water, immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
6. Check around unit for debris and remove combustible products, i.e. gasoline, etc.

PRE-START-UP CHECK

1. Verify heater is filled with water.
2. Check system piping for leaks. If found, repair immediately.
3. Vent air from system. Air in system can interfere with water circulation.
4. Purge air from gas line up to heater.

SECTION N: INITIAL START-UP

1.0 TOOLS NEEDED

- One 12-0-12, 24" scale manometer
- Two 6-0-6, 12" scale manometers
- 7/16" open end wrench
- 1/2" open end wrench
- Screwdriver
- Volt meter
- 3/16" Allen wrench

2.0 PREPARATION FOR START-UP

WARNING: *DO NOT TURN ON GAS AT THIS TIME*

2.1 Check Power Supply

With volt meter at incoming power check voltage between:

Hot - Common	(~120 VAC)
Hot - Ground	(~120 VAC)
Common - Ground	(< 1 VAC)

If Common - Ground is ≥ 1 VAC - **STOP:** Contact electrician to correct ground failure. Warning: Failure to do this may burn out 120V-24V transformer, or may cause other safety control damage or failure.

2.2 Attach Manometers to Measure Pressures

- Attach 24" scale manometer to the first main gas shut-off valve pressure tapping.
- Attach one 12" scale manometer to the manifold gas pressure tapping. (See gas valve detail on page 7.)
- Attach one 12" scale manometer to — Pull rubber tube from air pressure switch off the aluminum tubing and connect the manometer using a tee.

Turn Off Main Gas Valve;

2.3 Check the Gas Supply Pressure

1. Slowly turn on main gas shut-off valve.
2. Read the gas supply pressure from the manometer; minimum supply pressure is 5" W.C., recommended supply is 7" W.C. for natural gas (minimum 12" W.C. for LP gas).
3. If pressure is > 14 " W.C., turn off the valve.
4. Check if the service regulator is installed and/or adjust the service regulator.

3.0 START-UP

3.1 Blower Adjustment

1. Disconnect fan pressure switch tubing at plenum and connect manometer using a tee.
2. Close all manual firing valves.
3. Turn power on;
4. Check manometers attached to fan pressure switch.
The readings should be :
.5 + .1" W.C. for models 102 and 122
.7 ± .1" W.C. for models 202, 242, 322
If not, adjust the air shutter on the blower to attain the correct value. (See air shutter adjustment page 7)
5. Turn power off.
6. Reconnect fan pressure switch tubing to original position.

3.2 Main Burner Adjustment

1. Turn off unit.
2. Open manual firing valve.
3. Turn on the unit, wait 15 seconds, and the igniter should glow. Sight glass to check igniter at both ends of the heater. Gas valve should be open after 45 seconds.
4. If burner does not light on first trial. It will retry, up to 3 times
5. Main burner ignition – check manifold gas pressure at gas valve manifold pressure tap. (See gas valve detail page 7)
This should read $3.5 \pm .1$ " W.C. for natural gas or $10.5 \pm .1$ " W.C. for LP gas.
6. If the pressure reading differs by more than $\pm .1$ " W.C. Remove manifold adjustment screw cover off the pressure regulator on the gas valve, adjust main burner manifold pressure. Replace the manifold adjustment screw cap on the gas valve.

Your Hi Delta is tuned in!

3.3 Safety Inspection

- Replace main gas manifold adjustment screw cap.
- Check all thermostats and high limit settings.
- During the following safety checks leave manometers hooked up, check and record.
- If other gas fired equipment are in the room and on same gas main check all pressures on the Hi Delta with all other equipment running.

Remember, incoming gas pressure could be lower than specified on page 19, provided 3.2.5 is met.

- Check thermostats for ON/OFF operation.
- Check High limits for ON/OFF operation.
- While in operation, check flow switch operation
- Check the low gas pressure switches (For proper adjustment, if available, use the attached manometers to set pressure. The scales on the switch are approximate only); Low gas pressure switch must be set at 5" W.C. for natural gas and 10" W.C. for LP gas.
- High gas pressure switch (optional) at 1" W.C. above manifold pressure.
- Insert ignition control lockout tests as safety check.

3.4 Follow-Up

- Safety checks must be recorded as performed.
- Turn unit on.

After main burner ignition:

- Check Manometer for proper reading.
- Cycle unit several times and recheck readings
- Reanalyze with unit running record or print results.
- Remove all Manometers and replace hose, remove jumper, replace all gas pressure caps.
- Check for gas leaks one more time.

SECTION O: POST START-UP CHECK

Check off steps as completed:

1. Heater and heat distribution units or storage tank filled with water?
2. Automatic air vent, if used, open two full turns during venting procedure?
3. Air purged from system?
4. Air purged from gas piping? Piping checked for leaks?
5. Followed start-up procedure for proper start-up?
6. Is burner flame visible?
7. Test safety controls: If heater is equipped with a low water cut-off or additional safety controls, test for operation as outlined by manufacturer. Burner should be operating and should go off when controls are tested. When safety devices are restored, burners should reignite after pre-purge time delay.
8. Test limit control: While burner is operating, move indicator on high limit control below actual heater water temperature. Burner should go off while blower and circulator continue to operate. Raise setting on limit control above heater water temperature and burner should reignite after pre-purge time delay..
9. Test ignition system safety device:
 - Turn on manual gas valve. Turn power on.
 - Set thermostat to call for heat.
 - When the unit is in operation. Disconnect combustion air blower pressure switch, burner should go off immediately.
 - Wait 5 minutes.
 - Reconnect combustion air pressure switch, burner should reignite after pre-purge time delay.
10. To restart system, follow lighting instructions in Section P.
11. High limit control set to design temperature requirements of system?
For multiple zones: flow adjusted as required in each zone?
12. Heater cycled with thermostat? Raise to highest setting and verify heater goes through normal start-up cycle.
Reduce to lowest setting and verify heater goes off.
13. Observed several operating cycles for proper operation?
14. Set room thermostat or tankstat to desired temperature?
15. Reviewed all instructions shipped with this heater with owner or maintenance person, returned to envelope and given to owner or placed in pocket inside front panel on heater?

SECTION P: OPERATION

OPERATING INSTRUCTIONS

Lighting Instructions

1. STOP! Read the safety information first.
2. Set the thermostat to the lowest setting.
3. Turn off all electric power to the appliance.
4. This appliance is equipped with an ignition device which automatically lights the burner. Do Not try to light the burner by hand.
5. Remove upper front panel.
6. Turn on main manual gas valve.
7. Wait five (5) minutes to clear out any gas. Then smell for gas, especially near the floor. If you then smell gas. STOP! Follow the steps in the safety information on the front cover. If you do not smell gas, go to next step.
8. Turn on all electric power to the appliance.
9. Set thermostat to desired setting. The appliance will operate. The igniter will glow after the pre-purge time delay (15 seconds). After igniter reaches temperature (45 seconds) the main valve will open. System will try for ignition three (3) times. If ignition is not sensed, lockout will commence.
10. If the appliance will not operate, follow the instruction "To Turn Off Gas To Appliance", and call your service technician or gas supplier.
11. Replace access panel.

TO TURN OFF GAS TO APPLIANCE

1. Set the thermostat to lowest setting.
2. Turn off all electric power to the appliance if service is to be performed.
3. Remove upper front panel.
4. Turn off main manual gas valve.
5. Replace access panel.

If heater fails to start, check for:

- Loose connections, blown fuse or service switch off?
- High temperature limit switch set below heater water temperature?
- Thermostat set below room temperature?
- Gas not turned on at meter or heater?
- Incoming gas pressure less than 6" W.C. for natural gas, 11" W.C. for LP gas.

SECTION Q: MAINTENANCE

SUGGESTED MINIMUM MAINTENANCE SCHEDULE:

Regular service by a qualified service agency and maintenance must be performed to ensure maximum heater operating efficiency.

Maintenance as outlined below may be performed by the owner.

Yearly (Beginning of each heating season):

1. Annual service call by qualified service agency.
2. Visually check top of vent for soot. Call service person to clean. Some sediment at bottom of vent is normal.
3. Visually inspect venting system for proper function, deterioration or leakage.
4. Check that heater area is free from combustible materials, gasoline, and other flammable vapors and liquids.
5. Check for and remove any obstruction to the flow of combustion or ventilation air to heater.
6. Follow pre-start-up check in Section N.
7. Visually inspect burner flame. Should see light blue flame. Visually inspect hot surface igniter for damage, cracking or debris build-up.
8. Check operation of safety devices. Refer to manufacturer's instructions.
9. Follow oil-lubricating instructions on circulator. Over-oiling will damage circulator. Water-lubricated circulators do not need oiling.
10. To avoid potential of severe burn, DO NOT REST HANDS ON OR GRASP PIPES. Use a light touch - return piping will heat up quickly.
11. Check blower and blower motor. Clean and oil as necessary.
12. Check for piping leaks around circulators, relief valves and other fittings. Repair, if found. DO NOT use petroleum based stop leak.

Daily:

1. Check that heater area is free from combustible materials, gasoline, and other flammable vapors and liquids.
2. Check for and remove any obstruction to the flow of combustion or ventilation air to heater.

Monthly:

1. Check for piping leaks around circulators, mixing valves, relief valves, and other fittings. If found, repair at once. DO NOT use petroleum-based stop leak compounds.
2. Visually inspect burner flame.
3. Visually inspect venting system for proper function, deterioration or leakage.
4. Check air vents for leakage.

Quarterly:

1. Check relief valve. Refer to manufacturer's instructions on valve.
2. Test low water cut-off, if used. Refer to manufacturer's instructions.
3. Clean screen and air filter in intake.

APPENDIX A

INSIDE COMBUSTION AIR CONTAMINATION:

All heaters experience some condensation during start-up.

The condensate from flue gas is slightly acidic. In most cases the pH level is not harmful to vents or drains. When combustion air is contaminated by vapors from products in areas listed below, the acidic levels in the condensate increase. Higher acidic levels attack many materials, including stainless steel commonly used in high efficiency systems.

The heater can use special corrosion-resistant nonmetallic intake vent material. You may, however, choose to use outside combustion air for one or more of these reasons:

- installation is in an area containing contaminants listed below which will induce acidic condensation.
- you want to reduce infiltration into your building through openings around windows and doors.
- you are using AL29-4C stainless steel vent pipe, which is more corrosion-resistant than standard metallic vent pipe. In extremely contaminated area, this may also experience deterioration.

Products causing contaminated combustion air:


- spray cans containing chloro/fluorocarbons
- permanent wave solutions
- chlorinated waxes/cleaners
- chlorine-based swimming pool chemicals
- calcium chloride used for thawing
- sodium chloride used for water softening
- refrigerant leaks
- paint or varnish removers
- hydrochloric acid/muriatic acid
- cements and glues
- antistatic fabric softeners used in clothes dryers
- chloride-type bleaches, detergents, and cleaning solvents found in household laundry rooms
- adhesives used to fasten building products
- ... and other similar products.

Areas causing contaminated combustion air:



- dry cleaning/laundry areas and establishments
- metal fabrication plants
- beauty shops
- refrigeration repair shops
- photo processing plants
- auto body shops
- plastic manufacturing plants
- furniture refinishing areas and establishments
- new building construction
- remodeling areas.

Check for areas and products as listed above before installing heater. If found:

- remove products permanently, OR
- provide outdoor combustion air.



HEAT EXCHANGER DETAIL



CALL OUT	DESCRIPTION	122	162	202	242	322
B	BURNER ASSEMBLY					
1-B	Burner Assy w/Burners (Includes Front Comb Panel)	008525F	008526F	008527F	008528F	008529F
2-B	Burner	008522F	008522F	008522F	008522F	008522F
3-B	Seal Gasket	007443F	007443F	007443F	007443F	007443F
4-B	Manifold On/Off	008459F	008460F	008461F	008462F	008463F
5-B	Manifold 2 Stage	008464F	008465F	008466F	008467F	008468F
6-B	Manifold Gasket	008469F	008469F	008469F	008469F	008469F
7-B	Burner Orifice Nat.#51	351541 / 3	351541 / 4	351541 / 5	351541 / 6	351541 / 8
	Burner Orifice Pro.#63	351443 / 3	351443 / 4	351443 / 5	351443 / 6	351443 / 8
C	CONTROLS					
1-C	Manual Hi Limit 240 Deg Max. H	007144F	007144F	007144F	007144F	007144F
	Manual Hi Limit 200 Deg Max. WH	008081F	008081F	008081F	008081F	008081F
2-C	Adj/Auto Hi Limit 240 Deg Max. H	007141F	007141F	007141F	007141F	007141F
	Adj/Auto Hi Limit 200 Deg Max WH	006445F	006445F	006445F	006445F	006445F
3-C	Manual Hi Limit Non-Adjustible 36T 240 Deg H	008520F	008520F	008520F	008520F	008520F
	Manual Hi Limit Non-Adjustible 36T 2 Deg WH	008093F	008093F	008093F	008093F	008093F
4-C	Electronic Fast Response Sensor w/Probe 240 Deg H	008521F	008521F	008521F	008521F	008521F
	Electronic Fast Response Sensor w/Probe 200 deg WH	005555F	005555F	005555F	005555F	005555F
5-C	Probe Fast Response	006532F	006532F	006532F	006532F	006532F
6-C	PC Control Board 240 Deg H	008540F	008540F	008540F	008540F	008540F
	PC Control Board 200 Deg WH	005197F	005197F	005197F	005197F	005197F
7-C	Remote Aquastat (Tankstat) (B-2)	007148F	007148F	007148F	007148F	007148F
	Remote Aquastat (Tankstat) 2-Stage (B-3)	007392F	007392F	007392F	007392F	007392F
	Controller 2-Stage (B-4)	007393F	007393F	007393F	007393F	007393F
	Controller 4-Stage (B-20)	006445F	006445F	006445F	006445F	006445F
8-C	Flow Switch	007142F	007142F	007142F	007142F	007142F
9-C	Switch Air Pressure N.C.	006538F	006538F	006538F	006538F	006538F
10-C	Switch Air Pressure N.O.	008827F	008827F	008756F	008756F	008756F
F	Fan					
1-F	Blower Combustion Air	008470F	008470F	008470F	008470F	008470F
2-F	Air Shutter Assembly	008471F	008471F	008471F	008471F	008471F
G	GAS VALVES					
1-G	Combination Gas Valve On/Off Nat 3/4"	007424F	007424F	007424F	007424F	007424F
	Combination Gas Valve On/Off Pro 3/4"	007425F	007425F	007425F	007425F	007425F
2-G	Solenoid Gas Valve	008407F	008407F	008407F	008407F	008407F
H	HEAT EXCHANGER					
1-H	Heat Exch Cast Iron Side Connections	008408F	008409F	008410F	008411F	008412F
	Heat Exch Brass Side Connections	008413F	008414F	008415F	008416F	008417F
	Heat Exch Cast Iron Cupro Nickel Side Connections	008418F	008419F	008420F	008421F	008422F
	Heat Exch Brass Cupro Nickel Side Connections	008423F	008424F	008425F	008426F	008427F
2-H	Heat Exch Cast Iron Top Connections ASME	008658F	008659F	008660F	N/A	N/A
	Heat Exch Cast Iron Top Connections NON-ASME				N/A	N/A
3-H	Inlet/Outlet Header Cast Iron Side Connections	008428F	008428F	008428F	008429F	008429F
	Inlet/Outlet Header Brass Side Connections	008430F	008430F	008430F	008431F	008431F
4-H	Inlet/Outlet Header Cast Iron Top ASME	004236F	004236F	004236F	N/A	N/A
	Inlet/Outlet Header Cast Iron Top NON-ASME	008670F	008670F	008670F	N/A	N/A
5-H	Return Header Cast Iron	008432F	008432F	008432F	008432F	008432F
	Return Header Brass	008433F	008433F	008433F	008433F	008433F
6-H	Tube Bundle Side Connections	008434F	008435F	008436F	008437F	008438F
	Tube Bundle Cupro Nickel Side Connections	008439F	008440F	008441F	008442F	008443F
7-H	Tube Bundle Top Connections	008672F	008673F	008674F	N/A	N/A
8-H	Heat Exchange Tube	008444F	008445F	008446F	008447F	008448F
	Heat Exchange Tube Cupro Nickel	008449F	008450F	008451F	008452F	008453F
9-H	Baffle Kit	008454F	008455F	008456F	008457F	008458F
10-H	Stud Bolt Kit	007870F	007870F	007870F	007870F	007870F
11-H	Header Gasket	800203B	800203B	800203B	800203B	800203B
12-H	Sensor Well	007211F	007211F	007211F	007211F	007211F
13-H	Well Retaining Clip	300203	300203	300203	300203	300203
J	CONTROL BOX					
1-J	Control Assy H	008524F	008524F	008524F	008524F	008524F
	Control Assy WH	009824F	009824F	009824F	009824F	009824F
2-J	Ignition Control	008472F	008472F	008472F	008472F	008472F
3-J	Transformer 100VA	007494F	007494F	007494F	007494F	007494F
4-J	Pump Relay	007925F	007925F	007925F	007925F	007925F
5-J	Pump Relay P.C. Board	004675F	004675F	004675F	004675F	004675F
6-J	Blower Capacitor	008552F	008552F	008552F	008552F	008552F
7-J	Terminal Block (3 Space)	008523F	008523F	008523F	008523F	008523F
	Terminal Block (7 Space)	007385F	007385F	007385F	007385F	007385F
8-J	On/Off Switch	008681F	008681F	008681F	008681F	008681F
*FOR ALTITUDES ABOVE 4,500 FEET, CONSULT THE FACTORY						

CALL OUT	DESCRIPTION	122	162	202	242	322
M	MISCELLANEOUS					
1-M	Flow Switch Paddle	004079F	004079F	004079F	004079F	004079F
2-M	PRV 30 PSI	007470F	007470F	007470F	007470F	007470F
	PRV 45 PSI	007220F	007220F	007220F	007220F	007220F
	PRV 60 PSI	007222F	007222F	007222F	007222F	007222F
	PRV 75 PSI	007223F	007223F	007223F	007223F	007223F
	PRV 125 PSI	008091F	007224F	007224F	007224F	007224F
	PRV 150 PSI	007225F	007225F	007225F	007225F	007225F
3-M	Deliming Kit	052871F	052871F	052871F	052871F	052871F
4-M	T & P Gauge (H)	007205F	007205F	007205F	007205F	007205F
	T & P Gauge (W)	007399F	007399F	007399F	007399F	007399F
5-M	Pump Inline Top Water CIBF	008708	008708	008708	N/A	N/A
	Pump Inline Top Water BR (Non-Ferrous Waterway)	008709	008709	008709	N/A	N/A
	Pump Inline BR Soft	008709	008709	008709	008710	008710
	Pump Inline BR Medium	008709	008709	008709	008710	008745
	Pump Inline BR Hard	008713	008713	008713	008717	008717
	Pump Inline CIBF Soft	008708	008708	008708	005593	005593
	Pump Inline CIBF Medium	008708	008708	008708	005593	008746
	Pump Inline CIBF Hard	008711	008711	008711	008716	008716
6-M	Pump Cartridge 0010	951154F	951154F	951154F	951154F	951154F
	Pump Cartridge 0012	N/A	N/A	N/A	N/A	951153F
7-M	Pump Flange Gasket 0012	008747F	008747F	008747F	008747F	008747F
12-M	RTV Sealant 10 oz	005755F	005755F	005755F	005755F	005755F
13-M	FiberFrax Strip Insulation 1" Wide	008473F	008473F	008473F	008473F	008473F
8-M	Sight Window Plug	008474F	008474F	008474F	008474F	008474F
9-M	Window Combustion Chamber	006947F	006947F	006947F	006947F	006947F
11-M	Flame Sensor	006535F	006535F	006535F	006535F	006535F
10-M	Ignitor	007400F	007400F	007400F	007400F	007400F
O	OPTIONS					
1-O	Remote Sensor for Low Water Cut-Off	008063F	008063F	008063F	008063F	008063F
2-O	Low Water Cut Off PC Board	007157F	007157F	007157F	007157F	007157F
3-O	Reset/Test Switch for Low Water Cut Off	005641F	005641F	005641F	005641F	005641F
R	REFRACTORY					
1-R	Refractory Kit (All Panels)	008475F	008476F	008477F	008478F	008479F
2-R	Refractory Front Panel	008480F	008481F	008482F	008483F	008484F
S	SHEETMETAL					
1-S	Jacket Top	008485F	008486F	008487F	008488F	008489F
2-S	Jacket Top w/ Top Water Connections	008530F	008531F	008532F	N/A	N/A
3-S	Door Assy	008490F	008491F	008492F	008493F	008494F
	Door Assy w/ Top Gas Connections	008534F	008535F	008536F	N/A	N/A
4-S	Rear Jacket Panel	N/A	008495F	008496F	008497F	008498F
5-S	Left Side Jacket Panel	008499F	008499F	008499F	008499F	008499F
6-S	Right Side Jacket Panel	008500F	008500F	008500F	008500F	008500F
7-S	Front Combustion Chamber Panel	008501F	008502F	008503F	008504F	008505F
8-S	Rear Combustion Chamber Panel	008506F	008507F	008508F	008509F	008510F
9-S	Blower Air Intake Adapter	008511F	008511F	008511F	008511F	008511F
10-S	Flue Collector Top	008512F	008513F	008514F	008515F	008516F
11-S	Access Panel Ignitor/Flame Sensor	008678F	008678F	008678F	008678F	008678F
12-S	Access Panel Left Side Water Connections	008517F	008517F	008517F	008517F	008517F
13-S	Access Panel Right Side Water Connections	008518F	008518F	008518F	008518F	008518F
14-S	Access Panel Top Water Connections	008519F	008519F	008519F	N/A	N/A
15-S	Seal Brackets	008700F	008700F	008700F	008700F	008700F
V	VENTING					
1-V	Intake Filter Box Mounted	008555F	008555F	008555F	008555F	008555F
2-V	Filter	008556F	008556F	008556F	008556F	008556F
3-V	Inline Intake Air Filter Box	008699	008699	008699	008699	008699
4-V	Filter	008557F	008557F	008557F	008557F	008557F
5-V	Outdoor Stack	008537	008538	008538	008538	008856



**LIMITED PARTS WARRANTY COMMERCIAL HEATERS
TYPE HI DELTA MODELS 122 TO 322
MODELS H AND WH**

SCOPE:

Raypak, Inc. ("Raypak") warrants to the original owner that all parts of this heater which are actually manufactured by Raypak will be free from failure under normal use and service for the specified warranty periods and subject to the conditions set forth in this Warranty. Labor charges and other costs for parts removal or reinstallation, shipping and transportation are not covered by this Warranty but are the owner's responsibility.

HEAT EXCHANGER WARRANTY:

Domestic Hot Water

Five (5) years from date of heater installation. Includes copper heat exchanger with bronze and cast iron waterways.

Ten (10) years from date of heater installation. Includes only cupro-nickel heat exchanger with bronze or cast iron waterways.

Space Heating (Closed Loop System)

Ten (10) years from date of heater installation. Includes both cupro-nickel and copper heat exchanger with bronze or cast iron waterways.

Thermal Shock Warranty

Twenty (20) years from date of heater installation against "Thermal Shock" (excluded, however, if caused by heater operation at large changes exceeding 150°F between the water temperature at intake and heater temperature, or operating at heater temperatures exceeding 230°F).

ANY OTHER PART MANUFACTURED BY RAYPAK:

One (1) Year warranty from date of heater installation, or eighteen (18) months from date of factory shipment based on Raypak's records, whichever comes first.

SATISFACTORY PROOF OF INSTALLATION DATE, SUCH AS INSTALLER INVOICE, IS REQUIRED. THIS WARRANTY WILL BE VOID IF THE HEATER RATING PLATE IS ALTERED OR REMOVED.

ADDITIONAL WARRANTY EXCLUSIONS:

This warranty does not cover failures or malfunctions resulting from:

1. Failure to properly install, operate or maintain the heater in accordance with our printed instructions provided;
2. Abuse, alteration, accident, fire, flood and the like;
3. Sediment or lime build-up, freezing, or other conditions causing inadequate water circulation;
4. High velocity flow exceeding heater design rates;
5. Failure of connected systems devices, such as pump or controller;
6. Use of non-factory authorized accessories or other components in conjunction with the heater system;
7. Failing to eliminate air from, or replenish water in, the connected water system;
8. Chemical contamination of combustion air or use of chemical additives to water.

PARTS REPLACEMENT:

Under this Warranty, Raypak will furnish a replacement for any failed part. The failed part must first be returned to Raypak if requested, with transportation charges prepaid, and all applicable warranty conditions found satisfied. The replacement part will be warranted for only the unexpired portion of the original warranty. Raypak makes no warranty whatsoever on parts not manufactured by it, but Raypak will apply any such warranty as may be provided to it by the parts manufacturer.

TO MAKE WARRANTY CLAIM:

Promptly notify the original installer, supplying the model and serial numbers of the unit, date of installation and description of the problem. The installer must then notify his Raypak distributor for instructions regarding the claim. If either is not available, contact Service Manager, Raypak, Inc., 2151 Eastman Avenue, Oxnard, CA 93030 or call (805) 278-5300. In all cases proper authorization must first be received from Raypak before replacement of any part.

EXCLUSIVE WARRANTY - LIMITATION OF LIABILITY:

This is the only warranty given by Raypak. No one is authorized to make any other warranties on Raypak's behalf. THIS WARRANTY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. RAYPAK'S SOLE LIABILITY AND THE SOLE REMEDY AGAINST RAYPAK WITH RESPECT TO DEFECTIVE PARTS SHALL BE AS PROVIDED IN THIS WARRANTY. IT IS AGREED THAT RAYPAK SHALL HAVE NO LIABILITY, WHETHER UNDER THIS WARRANTY, OR IN CONTRACT, TORT, NEGLIGENCE OR OTHERWISE, FOR ANY SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGE, INCLUDING DAMAGE FROM WATER LEAKAGE. Some states do not allow limitations on how long an implied warranty lasts, or for the exclusion of incidental or consequential damages. So the above limitation or exclusion may not apply to you.

This Limited Warranty gives you specific legal rights. You may also have other rights which may vary from state to state. We suggest that you complete the information below and retain this certificate in the event warranty service is needed. Reasonable proof of the effective date of the warranty (date of installation) must be presented, otherwise, the effective date will be based on the rate of manufacture plus thirty (30) days.

Name of Owner	Name of Dealer
Address	Address
Model No.	Serial No.
Date of Installation:	Date of Initial Operation:

CORPORATE HEADQUARTERS:

RAYPAK, INC. • 2151 Eastman Avenue • Oxnard • CA 93030 • (805) 278-5300 • Fax (800) 872-9725 • www.raypak.com



Registered Quality Management System

www.raypak.com