

By default, the notifications regarding the back-up battery status are disabled. To enable/disable a certain notification, please refer to the following configuration methods.

Enable Battery Connected Notification	SMS text message content: BATCON:ON Example: <i>BATCON:ON</i>
Disable Battery Connected Notification	SMS text message content: BATCON:OFF Example: <i>BATCON:OFF</i>
Enable Battery Disconnected Notification	SMS text message content: BATDIS:ON Example: <i>BATDIS:ON</i>
Disable Battery Disconnected Notification	SMS text message content: BATDIS:OFF Example: <i>BATDIS:OFF</i>
Enable Low Battery Notification	SMS text message content: BLOW:ON Example: <i>BLOW:ON</i>
Disable Low Battery Notification	SMS text message content: BLOW:OFF Example: <i>BLOW:OFF</i>
Enable Mains Power Supply Lost Notification	SMS text message content: PWRLOST:ON Example: <i>PWRLOST:ON</i>
Disable Mains Power Supply Lost Notification	SMS text message content: PWRLOST:OFF Example: <i>PWRLOST:OFF</i>
Enable Mains Power Supply Restore Notification	SMS text message content: PWRREST:ON Example: <i>PWRREST:ON</i>
Disable Mains Power Supply Restore Notification	SMS text message content: PWRREST:OFF Example: <i>PWRREST:OFF</i>

8. System Information: Status SMS

The system supports an informational SMS text message identified as the Status SMS, which can be delivered upon request. Once requested, the system will reply with Status SMS that may provide the following:


- System name
- System date & time
- GSM signal strength
- System's internal temperature
- Name and status (ON/OFF) of the output
- Input Z1 state / value
- Input Z2 state / value

Request System Information	SMS text message content: STATUS Example: <i>STATUS</i>
Manage Status SMS Content	SMS text message content: TESTM:1;2;4;5;6;7;8 Value: 1 - system name; 2 - system date and time; 4 - GSM signal strength; 5 - system's internal temperature; 6 - name and status of the output; 7 - input Z1 state/value; 8 - input Z2 state/value. Example: <i>TESTM:3;6;8;1;2</i>
Enable Periodic Status SMS & Set Frequency	SMS text message content: TEST:frequen Value: frequen - frequency, range - [1... 1193046] hours. Example: <i>TEST:15550</i>
Disable Periodic Status SMS	SMS text message content: TEST:OFF Example: <i>TEST:OFF</i>

1. Overview

The SmartGuard GSM Module uses the GSM network to transmit information coming from connected equipment to authorised users e.g. send alarm notification from an intruder alarm panel to a mobile phone. The SmartGuard GSM Module has two normally open digital inputs (zone1 & zone2). The SmartGuard GSM Module can also be used to send commands to electrical equipment e.g. remotely turn central heating on in a house from a mobile phone. The SmartGuard GSM Module has one open collector output.

2. Connections



**Battery must be rechargeable
NiMH 9V 250mAh
48 x 26 x 15mm**

ANT	GSM antenna
FW	Pins for firmware update
TAMPER	Tamper switch
GSM MODEM	GSM network 900/1800 MHz modem
RESET	Button for restoring default settings
SIM CARD	SIM card slot / holder
LED	Light-emitting diode indicating system status
USB	Mini USB port
MIC	Microphone connector
-/+	Backup battery slots
F1	0.5A fuse


LED Indication	Description
OFF	No power supply
Flashing every 30 ms	SIM card is not present / PIN code enabled
Flashing every 0,5 sec.	Searching for GSM network
Flashing every 1 sec.	Connected to GSM network/system operating successfully

Connectors	Description
Z1	Digital input terminal
COM	Common terminal
Z2	Digital input terminal/temperature sensor data terminal (DATA)
DC	Positive power supply terminal
C1	Open-collector output terminal/temperature sensor power supply terminal (+4V)

3. System Notes

- The GSM module should be fixed to a wall using 4 screws.
- Do not install the GSM unit onto metal as this will reduce signal strength.
- The SIM card's PIN code must be disabled.
- Any SMS messages stored on the SIM card will be deleted during the system start-up.
- Power supply cables should be connected last when wiring (see 2. Connections).
- System start-up should take less than one minute.

4. Wiring Diagrams



5. Date & Time

The system comes equipped with internal real-time clock (RTC) that keeps track of the current date and time. Once the system is up and running, the user must set the correct date and time, otherwise the system will not operate properly. After shutting down and starting up the system, the date and time must be set again.

Setting the Date & Time	<p>SMS text message content: CLK:yyyy.mm.dd_hr:mn Value: yyyy – year; mm – month, range – [01... 12]; dd – day, range – [01... 31]; hr – hours, range – [00... 23]; mn – minutes, range – [00... 59]. Example: CLK:2013.03.16_14:33</p>
------------------------------------	---

6. Operation

a. Saving a user's phone number to the SIM card using a phone call

Only one user's phone number can be saved to the SIM card in this manner. Insert the SIM card into the SmartGuard GSM Module and make a phone call to it from the phone number you wish to save as 'User1'. NB: Caller ID must not be blocked.

b. Changing users' phone numbers on the SIM card using an SMS text message

The user phone numbers can be changed by sending the SIM card an SMS text message from a phone number that is already saved in the GSM unit. To save the 'User1' phone number, send the SIM card an SMS text message in the following format: NR1:xxxxxxxx (where x = the user's phone number). This process can be repeated for the 'User2' phone number by using the following format: NR2:xxxxxxxx.

c. Reporting of triggered inputs

When a digital input (zone1 or zone2) is triggered, the users are informed by an SMS text message containing the text 'Triggered ZONE1' or 'Triggered ZONE2'. When a digital input is reset, the users are informed by an SMS text message containing the text 'Restored ZONE1' or 'Restored ZONE2'. The text in these messages can be changed as follows:

d. Inputs

By default, the inputs are set as NO (normally open). To change the state of the inputs:

Set Input Z1 as NC (normally closed)	<p>SMS text message content: ZONE1:NC Example: ZONE1:NC</p>
Set Input Z1 as NO (normally open)	<p>SMS text message content: ZONE1:NO Example: ZONE1:NO</p>
Set Input Z2 as NC (normally closed)	<p>SMS text message content: ZONE2:NC Example: ZONE2:NC</p>
Set Input Z2 as NO (normally open)	<p>SMS text message content: ZONE2:NO Example: ZONE2:NO</p>

To manage input and/or tamper alarm and restore notifications by SMS text message, please refer to the following configuration methods:

Disable Input Alarm Notification	<p>SMS text message content: SAZi:OFF Value: i - input number, range - [1...2] Example: SAZ1:OFF</p>
Enable Input Alarm Notification	<p>SMS text message content: SAZi:ON Value: i - input number, range - [1...2] Example: SAZ2:ON</p>
Set Input Alarm Text	<p>SMS text message content: TAZi:in-alarm-text Value: i - input number, range - [1...2]; in-alarm-text - up to 23 characters input alarm text Example: TAZ2:Alarm Z2</p>
Disable Input Restore Notification	<p>SMS text message content: SRZi:OFF Value: i - input number, range - [1... 2] Example: SRZ2:OFF</p>
Enable Input Restore Notification	<p>SMS text message content: SRZi:ON Value: i - input number, range - [1... 2] Example: SRZ1:ON</p>
Set Input Restore Text	<p>SMS text message content: TRZi:in-restore-text Value: i - input number, range - [1... 2]; in-restore-text - up to 23 characters input restore text Example: TRZ1:Restore Z1</p>

f. Triggering outputs

The open collector output can be triggered by sending the GSM module an SMS text message from the saved 'User1' or 'User2' phone numbers. To turn the output on, the SMS text message sent should say OUT:ON. To turn the output off, the SMS text message sent should say OUT:OFF.

g. Outputs

By default, output C1 name is output. To rename the output, send the following SMS:

Rename Output	<p>SMS text message content: TOUT:out-name Value: out-name - up to 23 characters output name Example: TOUT:Lamp</p>
----------------------	---

To turn the output on or off:

Turn ON Output	<p>SMS text message content: OUT:ON Example: OUT:ON</p>
Turn OFF Output	<p>SMS text message content: OUT:OFF Example: OUT:OFF</p>

h. Tamper

The system comes equipped with on-board tamper switch designed for sabotage detection. In the event of enclosure tampering, the system can notify the user by SMS text message or phone call.

Set Tamper Name	<p>SMS text message content: TTMP:tamp-name Value: tamp-name – up to 23 characters tamper name Example: TTMP:Tamper</p>
Disable Tamper Alarm / Restore Notification	<p>SMS text message content: TMP:OFF Example: TMP:OFF</p>
Enable Tamper Alarm / Restore Notification	<p>SMS text message content: TMP:ON Example: TMP:ON</p>

7. Back-Up Battery and Mains Power Supply Status Monitoring

The system may come equipped with a back-up battery maintaining the power supply of the system for up to 12 hours when the mains power supply is temporarily lost. The implemented feature allows to perform a self-test on the backup battery every 6 seconds and notify the user by SMS text message under the following conditions:

- Battery connected – battery is present.
- Battery disconnected – battery is dead or missing.
- Low battery – battery voltage is 8V or lower.