

IDAutomation SC4USB

Scanner Programming Manual

www.idautomation.com



IDAutomation.com provides barcode fonts, components, label printing software and barcode readers, such as scanners and wands. To obtain support for this product, please visit www.idautomation.com/support/

Plug In
Play

CONTENTS

Getting Started -----	2
Setup Procedures -----	3
Setup Menu-----	4
Setup flow Chart -----	4
Group 0 : Interface Selection -----	5
Group 1 : Device Selection for keyboard interface-----	6-7
Group 2 : Inter-character Delay -----	8
Group 3 : Language for Keyboard Interface -----	9-10
Group 4 : Terminator-----	11-12
Group 5 : Scan Mode -----	13-14
Group 6 : Preamble and Postamble -----	15
Group 7 : Reserved -----	15
Group 8 : RS-232 Parameters -----	16-18
Group 9 : Code 39 / Code 32 -----	19-20
Group 10-1: Interleaved 2 of 5 -----	21
Group 10-2: Industrial 2 of 5 / IATA-----	22
Group 10-3: Matrix 2 of 5-----	23
Group 10-4: China Postage-----	24
Group 11 : Code 128/ Code 93/ Code 11/ MSI-PLESSEY-----	25-26
Group 12 : ISBN/ISSN-----	27
Group 13 : Codabar / NW7-----	28
Group 14 : Code 4-----	29
Group 15-1 : EAN 13 / JAN 13-----	30
Group 15-2 : UPC-A-----	31
Group 15-3 : EAN-8 / JAN-8-----	32
Group 15-4 : UPC-E / UCC EAN-128-----	33
Group 16 : General Parameters-----	34
Group 17 : Code ID Settings-----	35
Group 18 : Wand Type Parameters-----	36
Group 19 : Magnetic Parameters-----	37-39
Group 20 : Function Key Emulation-----	40
Function Code for PC XT/AT-----	41-42
Table-Hex : Hexadecimal-----	43
ASCII Table-----	44
Hexadecimal-Decimal Conversion Table -----	45
Pin Assignments of Scanners-----	46-47

Getting Started

Installing Keyboard Wedge Scanner

To install a keyboard wedge scanner, follow the steps listed below:

- 1) Make sure that the scanner has the correct Y (U)- cable for the system (a PC or terminal)
- 2) Turn off the power of the system
- 3) Unplug the keyboard from the system
- 4) Connect the Y (U)- cable to the system and keyboard
- 5) Turn on the power of the system
- 6) If the indicator LED lights up and the buzzer sounds, the scanner is ready for reading

Installing a RS-232 Interface Scanner

To install a RS-232 interface scanner, the host device should have a RS-232 port to receive data from the scanner, follow the steps listed below:

- 1) Make sure that the scanner has the right connector for the RS-232 port of the host device
- 2) Make sure that there is a power supply to the scanner (if necessary)
- 3) Connect the cable to the RS-232 port of the device
- 4) If the indicator LED lights up and the buzzer sounds, the scanner is ready for reading

Setup Procedures

- 1) Locate a group that contains the parameters to be changed.
- 2) Scan the “Enter Group #” label. The scanner will sound beeps indicate that setup is in progress
- 3) Scan the label representing the parameter to be changed
- 4) Scan the “Exit” to end the group currently selected, the scanner will sound beeps.
- 5) Repeat the procedure for other groups including the parameters to be changed

Example 1:

Set the operating mode to “Continuous mode”



- 1) Scan “Enter Group 5”
- 2) Scan “Continuous/Trigger off”
- 3) Scan “Exit”

Example 2


Assign Preamble string as “#”, and postamble string as “END”

- 1) Scan “Enter Group 6”
- 2) Scan Preamble”
- 3) Scan “#” from “Full ASCII Table and Table-Hex.”
- 4) Scan “Confirm” Label in Table-Hex
- 5) Scan “Postamble”
- 6) Scan “E”, “N”, “D” from “Full ASCII Table and Table Hex” consecutively
- 7) Scan “Confirm” Label in Table-Hex.
- 8) Scan Exit

Setup Flow Chart



Set All Defaults




Show Version

Group 0: Interface Selection



ENTER GROUP



EXIT



KEYBOARD



RS-232



WAND




OCIA



RS-232



Reserved 2



DTMF



Reserved 4

Group 1: Device Selection for Keyboard Interface




ENTER GROUP



EXIT



PC/AT, PS/2 50,60,70,80(*)



PC/XT



PS/2 25, 30



(NEC 9801)



(IBM 5550)




(PS 55)



(NEC N5520)



(ACER 7300)



(KW1050D/CT-700A/WANG 5120)



(WANG 5425)



(MAC_SE)



(LC-6533)

Group 1: Device Selection for Keyboard Interface



ENTER GROUP



EXIT



(IBM3196,3197,3476,3477)



Reserved Q



Reserved R



Reserved T



IBM3197



IBM 3476



IBM3477



RESERVED 5



Reserved 6



RESERVED 7



Reserved 8



RESERVED 9


Group 2: Intercharacter Delay



ENTER GROUP



EXIT



Start Keyboard Setting

Scan Enter Group 2 Label -- >

Scan Start Keyboard (or RS-232) Setting Label -->

Scan two digits labels in "Table-Hex" -->

Scan Exit Label



Start RS-232 Setting


Keyboard Default Value: 05

RS-232 Default Value : 00

Group 3: Language for Keyboard Interface




ENTER GROUP



EXIT




U.S. (*)




ENGLAND



FRANCE



GERMANY



ITALY



BELGIUM



SWEDEN/FINLAND




SPANISH



DENMARK



PORTUGAL



SWISS




NORWAY


Group 3: Language for Keyboard Interface




ENTER GROUP




EXIT




CANADA




HOLLAND




POLAND



LATIN




JAPAN



RESERVED 1



RESERVED 2



RESERVED 3



(IBM THINK-PAD FOR JAPAN)




(PANASONIC CF-II FOR JAPAN)

Group 4: Terminator




ENTER GROUP




EXIT

KEYBOARD


NONE



CR



SPACE



TAB



ESC



CTRL-C




ESC



Group 4: Terminator



ENTER GROUP



EXIT

RS-232

NONE



CR



CR/LF



LF



SPACE



TAB



ESC



CTRL-C



STX..ETX



XON.. XOFF




EOT



Group 5: Scan Mode



ENTER GROUP



EXIT




1: Trigger On/Off



2: Trigger On/Good Read Off (*)




3: Trigger On/Good Read Off/
Delay Timeout = ?




4: Continuous/Trigger Off



5: Continuous/LED Always on



6: Continuous/No Trigger




7: Continuous/Testing




8: Continuous/Trigger Off/
Delay Timeout = ?

Group 5: Scan Mode



ENTER GROUP



EXIT



FLASH OFF(*)



FLASH ON



SHORT ZONE



LONG ZONE



LASER DELAY

For Laser Scanner Mode

Default Laser Delay Timeout = 60 sec.

Scan Enter Group 5 Label


Scan Laser Delay -->

Refer to the Table-Hex at page 41 and select a value -->

Scan Confirm in Table Hex.

Scan Exit Label

LAG-960TR - Auto Trigger mode



AUTO TRIGGER

Scan Enter Group 5 Label -->


Scan 8: Continuous/Trigger off/Delay timeout=? (Page 13) -->

Scan two digit label and "confirm" label in Page 43 -->

Scan Above "Auto Trigger Label)

Switch on the LAG-960 bottom switch

Note: Scan mode setting is only available for CCD/Laser type scanner.



Preamble



Postamble

Preamble & Postamble Setting:

Scan Enter Group 6 Label -->

Scan Preamble or Postamble Label -->

Refer to ASCII Table(page 44), scan two digits in Table-Hex (Page 43)

Representing one character, maximum 10 characters can be accepted. -->

Scan Confirm Label in Table-Hex (Page 43)

Scan Exit Label



Clear

Clear Preamble & Postamble :

Scan Enter Group 6 Label -->

Scan Preamble or Postamble Label -->


Scan "Clear" Label-->

Scan "Exit" Label

Group 8: RS-232 Parameters



ENTER GROUP



EXIT

Baud Rate




300



600




1200



2400



4800



9600(*)



19200



38400

Data Bit





BIT 7



BIT 8

Group 8: RS-232 Parameters

	
ENTER GROUP	
	
	EXIT


Parity :


NONE (*)


ODD


EVEN

Handshaking:


NONE (*)



XON/OFF


Scanner Ready



Data Ready


ACK/NAK

Group 8: RS-232 Parameters











ENTER GROUP




EXIT

**(CK/NAK Response Time
CTS Observation Time:)**

 100 ms	 300 ms
 500 ms	 1 sec.
 3 sec (*)	 5 sec.
 10 sec.	 00

Group 9: CODE 39 / (CODE 32)


ENTER GROUP


EXIT



Enable (*)



Disable


Standard (*)



Full ASCII


Transmit Start/End Character


Enable


Disable (*)

Transmit Check Character


Disable


Enable (*)

Verify Checksum


Disable (*)



Enable


Enable CODE 32

Group 9: CODE 39 / (CODE 32)




ENTER GROUP



EXIT




Verify Normal (*)




Verify Strick

Group 10-1: Interleaved 2 OF 5



ENTER GROUP



EXIT



Disable (*)



Enable

Transmit Check Character



Enable (*)



Disable


Verify Checksum



Enable




Disable



Barcode Length Setting

Length Define
Min: 4
Max: 48


Scan Enter Group 10-1 Label -->
Scan Length Define Label -->
Scan Four Digit Labels in Table Hex (Page 43) -->
Scan Confirm Label in Table-Hex -->
Scan Exit Label




User Define
3 Sets Available

User Define Length Setting:
Scan Enter Group 10-1 Label
Scan User Define Label-->
Scan Six Digit Labels in Table Hex (Only 3 sets of length can be defined)
Scan Confirm Label in Table Hex -->
Scan Exit Label

Group 10-2: Industrial 2 OF 5 / IATA



ENTER GROUP



EXIT




Disable (*)




Enable

Transmit Check Character




Enable (*)




Disable


Verify Checksum



Enable




Disable



Barcode Length Setting

Length Define
Min: 2
Max: 24

Scan Enter Group 10-2 Label -->
Scan Length Define Label -->
Scan Four Digit Labels in Table Hex (Page 43) -->
Scan Confirm Label in Table-Hex -->
Scan Exit Label



User Define Length Setting:

User Define
3 Sets Available

Scan Enter Group 10-2 Label
Scan User Define Label-->
Scan Six Digit Labels in Table Hex (Only 3 sets of length can be defined)
Scan Confirm Label in Table Hex -->
Scan Exit Label




Enable




Disable (*)

Group 10-3: Matrix 2 of 5



ENTER GROUP



EXIT




Disable (*)




Enable

Transmit Check Character



Disable



Enable (*)


Verify Checksum



Disable (*)




Enable



Barcode Length Setting
Scan Enter Group 10-3 Label -->
Scan Length Define Label -->
Scan Four Digit Labels in Table Hex (Page 43) -->
Scan Confirm Label in Table-Hex -->
Scan Exit Label

Length Define
Min: 2
Max: 40



User Define Length Setting:
Scan Enter Group 10-3 Label
Scan User Define Label-->
Scan Six Digit Labels in Table Hex (Only 3 sets of length can be defined)
Scan Confirm Label in Table Hex -->
Scan Exit Label

User Define
3 Sets Available

Group 10-4: CHINA POSTAGE




ENTER GROUP



EXIT




Disable (*)




Enable

Transmit Check Character



Disable




Enable (*)


Verify Checksum



Disable (*)




Enable



Barcode Length Setting
Scan Enter Group 10-3 Label -->
Scan Length Define Label -->
Scan Four Digit Labels in Table Hex (Page 43) -->
Scan Confirm Label in Table-Hex -->
Scan Exit Label


Length Define
Min: 2
Max: 40




User Define Length Setting:
Scan Enter Group 10-3 Label
Scan User Define Label-->
Scan Six Digit Labels in Table Hex (Only 3 sets of length can be defined)
Scan Confirm Label in Table Hex -->
Scan Exit Label

User Define
3 Sets Available

Group 11: CODE 128/(CODE 93)/(CODE 11)/(MSI-PLESSEY)




ENTER GROUP




EXIT

CODE 128



Enable (*)




Disable

CODE 93



Disable (*)



Enable

Concatenation




Disable (*)




Enable

Note: Options marked by () are only available upon request


Group 11: CODE 128/(CODE 93)/(CODE 11)/(MSI-PLESSEY)




ENTER GROUP



EXIT




Enable(*)




Disable

Number of Check Character




One




Two (*)

Transmit Check Character




Enable




Disable (*)

MSI/PLESSEY




Enable (*)




Disable

Note: Options marked by () are only available upon request


Group 12: (ISBN/ISSN)




ENTER GROUP



EXIT




Disable (*)




Enable

Note: Options marked by () are only available upon request

Group 13: CODABAR / NW7



ENTER GROUP



EXIT




Enable(*)




Disable

Transmit Start/End Character




Enable




Disable (*)


Start/End Transmit Type




ABCD/ABCD



ABCD/TN*E




abcd/abcd (*)




abcd/tn*e

Group 14: (Code 4)



ENTER GROUP



EXIT




Enable




Disable (*)

Note: Options marked by () are only available upon request


Group 15-1: EAN-13/JAN-13




ENTER GROUP



EXIT



Enable (*)



Disable

ADD-ON 2/5



Enable (*)



Disable (*)

Transmit Check Character



Enable (*)



Disable

Truncate Leading Digit




Enable




Disable (*)

Truncate Leading Zero



Enable



Disable (*)



Check-Digit On (*)



Check-Digit Off

Group 15-2: UPC-A

 ENTER GROUP	 EXIT
--	--

 Enable (*)	 Disable
---	--

ADD-ON 2/5

 Enable (*)	 Disable (*)
---	--

Transmit Check Character

 Enable (*)	 Disable
---	---



Truncate Leading Digit

 Enable	 Disable (*)
---	--

Truncate Leading Zero

 Enable	 Disable (*)
---	--

Group 15-3: EAN-8/JAN-8



 ENTER GROUP	 EXIT
--	--

 Enable (*)	 Disable
---	--

ADD-ON 2/5

 Enable (*)	 Disable (*)
---	--



Transmit Check Character

 Enable (*)	 Disable
--	---


Truncate Leading

 Enable	 Disable (*)
---	--


EAN Convert to EAN-13

 Enable	 Disable (*)
---	--


Group 15-4: UPC-E / UCC EAN/128




ENTER GROUP



EXIT



Enable (*)



Disable

ADD-ON 2/5




Enable (*)




Disable (*)

Transmit Check Character



Enable (*)



Disable

Truncate Leading Digit



Enable



Disable (*)

UCC/EAN/128




Enable




Disable (*)

UPC-E Convert to UPC-A








Enable





Disable

Group 16: General Parameters

	
ENTER GROUP	
	
	EXIT

	
Upper Case	
	
	Lower Case
	
Universal	
	
	ALT Mode

	Buzzer Pitch (Default : 16)
	Buzzer Duration (Default: 04)

Buzzer Pitch & Buzzer Duration Setting:
 Scan Enter Group 16 Label -->
 Scan Buzzer Pitch or Buzzer Duration Label -->
 Scan Two Digit Labels in Table-Hex -->
 Scan Confirm Label in Table-Hex -->
 Scan Exit Label

Power Up Beeping

	
	Disable
	
Enable (*)	

	
Turbo (*)	
	
	Normal

Group 17: Code ID Setting

 ENTER GROUP	 EXIT
--	--


 CODE 39


 INTERLEAVED 2 OF 5


 INDUSTRIAL 2 OF 5


 MATRIX 2 OF 5


 CHINA POSTAGE


 CODE 128


 CODE 93


 CODE 11


 MSI/PLESSEY


 CODABAR/NW7


 EAN-13/UPC-A



 EAN-8



 UPC-E


 UPC-A

Note: Refer to ASCII Table, scan two hexadecimal labels
in Table Hex to represent one character

Group 18: WAND Type Parameters



ENTER GROUP



EXIT


BAR=LOW



BAR=HIGH(*)

Scan Speed



Low (*)



Highest



Lowest


High


Data Format



Transmit in Normal Format (*)



Transmit in Code 128 Format



Transmit in Code 39 Format

Group 19-1: (Magnetic Parameters)



ENTER GROUP



EXIT



Disable



Enable (*)


Track Order



Track 1/3/2


Track 2/3/1


Track 3/1/2




Track 1/2/3 (*)


Track 2/1/3









Track 3/2/1

Note: Options marked by () are only available upon request

Group 19-1: (Magnetic Parameters)

 ENTER GROUP	 EXIT
--	--


Track Selection


 Track 1 only	 Track 1&2&3 any (*)
 Track 3 only	 Track 2 only
 Track 2 and 3	 Track 1 and 2
	 Track 1 and 2 and 3

 ISO (*)	 (JIS-2)
--	--


Note: Options marked by () are only available upon request


Group 19-2: (Magnetic Parameters)



ENTER GROUP


EXIT

Start Sentinel:
(SS)


Tk1 Default : %



Tk2 Default



Tk3 Default : ; ?


End Sentinel:
(ES)


Tk1&2&3 Default: ?

DLE:


Tk1 Default : Null


Tk2 Default: Null


Tk3 Default: Null


STX:


Tk1&2&3 Default: Null


Magnetic Output Data Format:
 STX - Tk1 Start Sentinel - Tk1 Data - End Sentinel - Tk1 - DLE
 STX - Tk2 Start Sentinel - Tk2 Data - End Sentinel - Tk2 - DLE
 STX - Tk3 Start Sentinel - Tk3 Data - End Sentinel - Tk3 - DLE

Note: Options marked by () are only available upon request


Group 20: (Function Key Emulation)




ENTER GROUP



EXIT



Enable



Disable (*)

Enable Function Key Emulation:
 Scan Enter Group 20 Label -->
 Scan Enable Label -->
 Scan Exit Label

1:

To concatenate a function key with input data, please refer to Function Key Table for its hexadecimal representation.
 For Example:

Preamble data with F1
 Scan Enter Group 6 Label -->
 Scan Preamble Label -->
 Scan Label 0 and 1 respectively in Table-Hex (Page 43) -->
 Scan Confrim Label in Table-Hex (page 43) -->
 Scan Exit Label

F1:01	F2:02	F3:04	F4:04
F5:05	F6:06	F7:07	F8:08
F9:09	F10:0A	F11:0B	F12:0C
Enter:0D	Tab:0E	BS:0F	Up:10
Down:11	Left:12	Home:14	End:15
PgUp:16	PgDn:17	Ins:18	Del:19
Esc:1B	Right:13	S-Tab:1C	

2:

To scan a function key barcode label, full CODE 39 must be enabled. Please refer to Full CODE 39 Table to produce the function key barcode label.



Full CODE 39 Enable

Function Code for PC XT/AT



F1 (\$A)



F2 (\$B)



F3 (\$C)



F4 (\$D)



F5 (\$E)



F6 (\$F)



F7 (\$G)



F8 (\$H)



F9 (\$I)



F10 (\$J)



F11 (\$K)



F12 (\$L)

Function Code for PC XT/AT



Enter (\$M)



Tab (\$N)



BS (\$O)



Up (\$P)



Down (\$Q)



Left (\$R)



Right (\$S)



End (\$U) (\$B)



PgUp (\$V)



PgDn (\$W)



Ins (\$X)



Del (\$Y)



Esc (%A)



Home (\$T)

Table-Hex : HEXADECIMAL



0



2



4



6



8



A



C



E



Confirm



1



3



5



7



9



B



D



F

ASCII TABLE

L / H	0	1	2	3	4	5	6	7
0	NULL	DLE	SP	0	@	P		p
1	SOH DC1	DC1	!	1	A	Q	a	q
2	STX	DC2	"	1	A	Q	a	q
3	ETX	DC3	#	3	C	S	c	s
4	EOT	DC4	\$	3	C	S	c	s
5	ENQ	NAK	%	5	E	U	e	u
6	ACK	SYN	&	6	F	V	f	v
7	BEL	ETB		7	G	W	g	w
8	BS	CAN	(8	H	X	h	x
9	HT	EM)	9	I	Y	l	y
A	LF	SUB	*	:	J	Z	j	z
B	VT	ESC	+	;	K	[k	{
C	FF	FS	,	<	L	\	l	
D	CR	GS	-	_	M]	m	}
E	SO	RS	.	>	N	^	n	~
F	SI	US	/	?	O	-	o	DEL

Hexadecimal-Decimal Conversion Table

HM	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
0	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
A	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
B	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
C	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
D	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
E	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
F	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

For Example:

Hexadecimal
56 -> H:5 L:3
D5 -> H:D L:5

Decimal
83
213

PIN ASSIGNMENTS

COLOR	Function	9 Pin DSUB/AM P (F)	25 PIN DIN(M)	6 PIN DIN (M)	6 PIN MINI DIN (M)
Yellow	Start of Scan	1	---	6	6
Orange	Signal Data	2	2	2	4
White	Led Indicator	3	---	---	---
Blue	Trigger	5	5	5	1
Green	Power Enable	6	4	4	2
Black	GND	7	3	3	5
Red	VCC+5V	9	1	1	3

Wand Emulation Signal Output

COLOR	Function	9 PIN DSUB/AM P (F)	5 PIN DIN (M)	6 PIN DIN (M)
Orange	Signal Data	2	2	2
Black	GND	7	3	3
Red	VCC+5V	9	1	1

Note : The pin numbers for the 5 or 6 pin connectors are viewed internally.

"F" stands for a female connector while "M" stands for a male connector.

PIN ASSIGNMENTS

RS-232 Signal Output

COLOR	FUNCTION	9 PIN DSUB/AMP(F)	25PIN DSUB(F)
Black	GND	5	7
Brown	CTS	7	4
Grey	RTS	8	5
Violet	RX	3	2
Green	TX	2	3
Red	VCC+5V	9	25

Note : For PC applications , a cable with DC power jack is required to accept external power input.

Keyboard Signal Output

COLOR	FUNCTION	5 PIN DIN (F)	5 PIN DIN (M)
Black	GND	4	4
White	PC_Data	---	2
Orange	PC_CLK	---	1
Red	Vcc+5V	5	5
Blue	KB_CLK	1	---
Yellow	KB_Data	2	---