

USER GUIDE

SH310

Bluetooth® Wireless Headset

First steps...

1

Charge your SH310 Headset

See **CHARGING** section

2

Pair your Headset to a Bluetooth phone.

See **PAIRING** section. PIN= ‘0000’

3

Wear it and free your hands

See **WEARING** section

Powered by SouthWing

OVERVIEW - SH310 HEADSET

1. USB charging socket

2. Push4™ Button / Indicator light

3. Turn On / Off

4. Vol+

5. Vol-

6. Speaker

7. Microphone

8. Multi-function Arm

9. Ear Hook

© Bluetooth is a registered trademark owned by Bluetooth SIG, Inc. U.S.A. and licensed to SouthWing.

* The features marked with an asterisk will only work with Bluetooth phones which support the Hands-free profile.

Today, most Bluetooth phones support this profile.

1

8. ADDITIONAL INFORMATION

Customer Service

Visit us online at:
www.south-wing.com/cingular-sh310
or call toll free in USA/Canada
1-877-715-WING OR 1877-717-9464

Battery Care

Your Headset battery will have a long life provided you follow these guide lines:

- Do not charge your Headset outdoors.
- Do not charge your Headset if the ambient temperature is above 113 degrees Fahrenheit (45 degrees Celsius) or below 50 degrees Fahrenheit (10 degrees Celsius).
- Do not leave your Headset driving may reduce your ability to react to road conditions.
- Be aware that using a wireless headset while driving is illegal in certain countries. Therefore, you should check the local laws before using the product while driving.
- As this product contains parts which may cause injury if consumed, keep it out of reach of children.
- Use only the power supply provided by SouthWing or by Cingular in Cingular packaging labeled as compatible with the SouthWing SH310 Headset.

Safe Usage Guidelines

- Only use the product according to the directions within this User Guide. Usage of this product contrary to these directions could cause injury. In addition, any usage of this product contrary to this User Guide will void any warranty.
- Do not use the product in an environment where it may come in contact with liquid be exposed to high humidity or extreme temperatures.

Caution: Prolonged use of the headset at high volumes may affect your hearing capacity.

2

INTRODUCTION

Thank you for choosing a Bluetooth® Headset SH310 from Cingular, powered by SouthWing. This user guide provides all the information you will need to use and care for your product. All relevant information regarding this product can be found on the support section of the website:
www.south-wing.com/cingular-sh310

1. CHARGING THE HEADSET

You will need to charge the battery of your SH310 Headset. To do so, follow these steps:

- Plug the power supply into a power point.
- Plug the connector of the power supply into the USB Charging Socket (1). The Indicator Light (2) will turn green to indicate the Headset battery is charging.
- Once the Indicator Light (2) turns off, the Headset is fully charged and can be removed from the power supply

Please Note:

- The Headset will not function while charging.
- If the Indicator Light (2) remains off when charging, the battery is already fully charged and does not require further charging.
- To maximize battery life, do not charge the Headset for extended periods of time.
- Full battery capacity will be achieved after two or three full charge/discharge cycles.

2. PAIRING THE HEADSET

Auto-pairing

For added convenience, your headset has an auto-pairing function so that **when you turn the headset on for the first time, it is already in pairing mode** (you will also hear a series of high tones). Then, follow these steps:

- Make sure your phone is in pairing mode (reference your phone user manual). Ensure the mobile phone is no more than 3 feet (1 meter) away from the headset.
- Turn the headset on. **The headset will already be in pairing mode.** You do not need to push any buttons on the headset.
- From your mobile phone search for the headset (reference your phone user manual).
- Select “SouthWing SH310” from the list of headsets detected.

3. WEARING AND CARRYING THE HEADSET

You can wear your Headset on either ear and carry it in different ways using the rotating Multi-function Arm(8).

Wearing the Headset Without the Ear Hook

You can wear the Headset without using the Ear Hook. To do so:

- Rotate the Multi-function Arm (8) downwards, until it stays in your ear like a wired headset cable extension.
- Gently place the Speaker (6) into your ear canal.
- Finally find the most comfortable position by rotating the Headset forward and backward.

Wearing Headset Without Earhook

Wearing the Headset with the Ear Hook
The Ear Hook may also be used for

5. Enter the PIN number (four zeros): 0000

2

Limited Warranty & Warranty Exclusions

Please Note:

For all warranty related issues; please return with the product to the shop from which you purchased it.

One Year Limited Warranty.

What is covered: Cingular warrants to the first retail purchaser of this wireless accessory that should this product or any part be proved defective in materials or workmanship, from the date of proof of purchase for a period of one (1) year, then it will be subject to the terms of this one year limited warranty. Such defects will be repaired, replaced or credit issued at Cingular’s option, without charge for parts or labor directly related to the defect. Limitations and Exclusions: This warranty does not apply to any cost incurred for removal or reinstallation, or to any product or part thereof which has suffered through normal wear and tear, alteration, improper installation, physical abuse, misuse, neglect or accident. Nor does it cover defects caused by shipment to a Cingular Wireless service center, or repair or service of the product by anyone other than a Cingular service center. Damage resulting from an act of God, including but not limited to fire, flood, earthquake and other natural disasters will be excluded. **This limited warranty is in lieu of all other warranties, express or implied either in fact or by operations of law, statutory or otherwise, including, but not limited to any implied warranty of merchantability or fitness for a particular use.** Cingular Wireless does not authorize any other person to assume any liability beyond the warranty herein described. In no event, whether based in contract or tort shall Cingular Wireless be liable for incidental, consequential, indirect, special, or punitive damages of any kind resulting from the use of this product, including interrupted or incomplete phone calls, or arising out of any breach of this warranty. In no event shall Cingular Wireless be liable for damage in excess of the purchase price. Cingular and the graphic icon are registered trademarks of Cingular Wireless LLC. ©2006 Cingular Wireless LLC. Other manufacturer warranties may apply.

9

6. If pairing is successful, you will see your phone connect to the SouthWing SH310 and the Indicator Light on the SouthWing headset will begin flashing every 3 seconds.

Normal pairing

You will need to follow the steps below if you want to pair your Headset with another mobile phone. You will be able to pair your Headset with up to 3 devices.

- Ensure the Headset is off
- Press and hold the On/Off Button (3) for about 5 seconds until the Indicator Light (2) flashes twice every second (you will hear a series of high tones.)Then complete the normal pairing process by following steps 1-6 in the Auto-pairing section above.

3. WEARING AND CARRYING THE HEADSET

You can wear your Headset on either ear and carry it in different ways using the rotating Multi-function Arm(8).

Wearing the Headset Without the Ear Hook

You can wear the Headset without using the Ear Hook. To do so:

- Rotate the Multi-function Arm (8) downwards, until it stays in your ear like a wired headset cable extension.
- Gently place the Speaker (6) into your ear canal.
- Finally find the most comfortable position by rotating the Headset forward and backward.

Wearing Headset Without Earhook

Wearing the Headset with the Ear Hook
The Ear Hook may also be used for

5. Enter the PIN number (four zeros): 0000

3

9. FCC Statement and Notice (Federal Communications Commission, USA)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.

For questions regarding your product or this FCC declaration, contact:

SouthWing

2655 LeJeune Rd.

Suite 810

Coral Gables, FL. 33134

FAX :+ 1 305 442 1676

fcc_certifications@south-wing.com

To identify this product, refer to the Part, Series, or Model number found on the product.

cingular SH310

Tested To Comply With FCC Standards

FOR HOME OR OFFICE USE

The FCC requires the user to be notified that any changes or modifications made to this device that are not expressly approved by the party responsible for compliance may void the user’s authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off

10

Changing Color Covers

To change a color cover, place your thumbnail on the cover end and pull it out gently. Now you can fit the new color cover. Gently clip in the front of the cover and then gently snap the back in place.

Changing Color Cover

4. GENERAL USAGE

Turning the Headset On and Off

To turn the Headset on, press and hold the On/Off Button (3) for about 2 seconds until a series of tones is heard. The Indicator Light (2) will flicker for 1 second and start flashing. To turn the Headset off, press and hold the On/Off Button (3) for about 2 seconds until a series of tones is heard. The Indicator Light will flash, before turning off.

Changing Volume

To increase the volume, with the Headset on, press Vol+ Button (4). To decrease the volume, press the Vol- Button (5). The Headset will remember all volume settings even when it is switched off.

Accepting/rejecting* a call

When the phone rings (ring tone can be heard in Headset), briefly press the Push4™ Button (2) once to accept the call. Press and hold the Push4™ Button (2) for 1 second to reject the call.

4

Initiating a Call from Your Mobile Phone

Dial the number as usual with your phone. If your Headset is on and the phone has been correctly paired, your phone will transfer the call to your Headset.

Initiating a Call With Voice Dialing

You may be able to initiate the voice dialing function from your Headset (your phone will need to support Voice Dialing and voice tags need to be entered into your phone – reference your phone user manual). To activate, briefly press the Push4™ Button (2). You will then be able to speak the name of the person you wish to call.

Ending a Call

Press the Push4™ Button (2) briefly during a call and the call will be ended.

Disconnecting from the phone*

You may wish to disconnect the Headset from the phone in order to reduce battery consumption. To do so, press the Push4™ Button 3 times on the Headset when it is not in an active call. If you want to pick up a call, you first need to reconnect the Headset. To do so, press the Push4™ Button once again on the Headset.

Battery Life

To conserve battery life, your Headset features an auto-sleep function. This function switches the Headset off after 12 hours of inaction. Once your Headset has entered auto-sleep, it can be switched on again normally. When the battery has only 10% charge remaining, the Headset will produce an audible warning tone sequence every time a call is ended. This headset features a battery

5. Push4™ CALL FUNCTIONS

Your Headset can be configured with a specific Push4™ call function. So by pressing one button you can call a number stored in your headset memory without touching your phone. With the Headset on, press and hold the Push4™ Button (2) for 1 second to call directly to the configured number or phone service. In some cases, you can use this function as your favorite number on the Headset. This can only be done when you have received a call (A) from this same number into your Headset (not made through a hidden call). Once this received call has ended (B), press and hold both Vol+ (4) and Vol- (5) buttons for 3 seconds, until you hear a series of tones. The number from the last received call will be stored. (C) Now you can make a direct call to this number at any time just by pressing and holding the Push4™ Button (2) for 1 second.

*8 Cingular Voicelinfo Service

Your Headset has been preconfigured to access the *8 Cingular Voicelinfo service. Simply press and hold the Push4™ button for approximately 1 second to connect Cingular’s popular *8 Voicelinfo service which gives you access to rich audio content like sports, stock quotes, horoscopes,

6. If pairing is successful, you will see your phone connect to the SouthWing SH310 and the Indicator Light on the SouthWing headset will begin flashing every 3 seconds.

Normal pairing

You will need to follow the steps below if you want to pair your Headset with another mobile phone. You will be able to pair your Headset with up to 3 devices.

- Ensure the Headset is off
- Press and hold the On/Off Button (3) for about 5 seconds until the Indicator Light (2) flashes twice every second (you will hear a series of high tones.)Then complete the normal pairing process by following steps 1-6 in the Auto-pairing section above.

3. WEARING AND CARRYING THE HEADSET

You can wear your Headset on either ear and carry it in different ways using the rotating Multi-function Arm(8).

Wearing the Headset Without the Ear Hook

You can wear the Headset without using the Ear Hook. To do so:

- Rotate the Multi-function Arm (8) downwards, until it stays in your ear like a wired headset cable extension.
- Gently place the Speaker (6) into your ear canal.
- Finally find the most comfortable position by rotating the Headset forward and backward.

Wearing Headset Without Earhook

Wearing the Headset with the Ear Hook
The Ear Hook may also be used for

5. Enter the PIN number (four zeros): 0000

3

7. Troubleshooting

1. Headset will not turn on

The Headset battery may be empty.

Try recharging the Headset

2. Pairing is unsuccessful

Try moving the phone and Headset closer together during pairing.

Make sure that the mobile phone is in the correct Bluetooth mode.

Some electrical devices such as microwave ovens create a noisy electrical environment making it difficult for the Headset to communicate with the phone. Try moving away from such devices and try again.

3. Pairing has succeeded but calls are not heard in the Headset

Make sure that your phone is switched on and ready to connect to the Headset. Check your phone user manual on how to do this.

4. Headset stops responding to button presses

Ensure that your Headset battery is charged.

Try resetting your Headset according to the directions given in “Resetting your Headset”

5. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

6. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

7. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

8. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

9. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

10. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

11. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

12. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

13. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

10. COMMANDS SUMMARY TABLE

1. Main Menu

HOW TO?	ACTION	HEADSET RESPONSE
Power On	In OFF state press and hold ON/Off Button for 2 sec	Headset turns on and light flashes green
Power Off	In ON state press and hold ON/Off Button for 2 sec	Light flashes green 3 times every second, for 2 sec and Headset turns off
Volume up	In ON state, press Vol+ Button repeatedly	Every press you hear a beep with higher volume and higher tone
Volume down	In ON state, press Vol- Button repeatedly	Every press you hear a beep with lower volume and lower tone
Pairing Mode	In OFF state press and hold ON/Off Button for 5 sec and see the pairing instructions of your phone	Headset light flashes green twice every second and a series of high tones can be heard
Accept call	During incoming call press Push4 Button once	Headset picks call up
Reject Call	During incoming call press and hold Push4 Button for 1 sec	Headset rejects call
Voice Dialling	In ON state press Push4 button once quickly (do not hold for 1 second or more)	Headset makes a series of short beeps while mobile initiates the voice dialing command
Push4 call	In ON state press and hold Push4 Button for 1 sec	Headset will initiate a call to the *8 Cingular Voicelinfo Service* or initiates a call to your favorite stored number
End Call	During a call press Push4 Button once	Headset hangs up the current call
Disconnect from phone	In ON state press Push4 Button 3 times	Headset disconnects from phone
Connect to phone	When disconnected, press Push4 Button once	Headset connects to phone
Memorize last calling number	In ON state press Vol+ and Vol- Button for 3 sec	Headset stores the last calling number to the stored Favourite number

2. Extended Menu

You must first access the Extended Menu itself before you can use any of its functionality. You may leave the headset engaged in the Extended Menu to access all Extended Menu functions as well as all basic headset usage functions.

HOW TO?	ACTION	HEADSET RESPONSE
Access/Deactivate the Extended Menu	In ON state press Vol+, Vol- and Push4 Buttons for 1 sec	Headset light flashes 3 times every second for 3 seconds and a series of 10 beeps is heard
Muting microphone	During a call press Push4 Button twice	Microphone is muted and periodic tones are heard
Reactivate microphone	During a call with muted microphone press and Push4 Button twice	Microphone is reactivated
Transfer call to mobile	During a call press Push4 Button 3 times	Call continues in mobile
Transfer call back to Headset	During a call in the mobile press Push4 Button once	Call continues in Headset
Last Number Redial	In ON state press Push4 Button twice	Mobile Redials
Check battery level	In ON state press Push4 Button 4 times	A series of beeps indicates remaining talk time in hours
Automatic call pick up activation	In ON state press Push4 and Vol+ Buttons	Select Automatic call pick up mode
Enter Ringtone selection	In ON state press and hold either Vol+ or Vol- Buttons for 5 sec	Enters ring tone list
Check different ring tones	In ring tone menu press Vol+ or Vol- Button	Up and down in the ring tone list
Select ring tone	In ring tone menu press Push4 once	Selects ring tone in Headset

1 Only with mobile phones supporting voice dialling

2 Only with mobile phones supporting Hands-free mode

13

4. When you want to call your favorite number simply press and hold the Push4™ button for approximately 1 second.

Delete Your Favorite Number and Restore *8 Cingular Voicelinfo Service

Simultaneously press and hold the Push4™(2) and Vol- (5) buttons for 5 seconds. You will hear 4 beeps and see the light flash at the beginning and end of the 5 seconds to signify that your previous favorite number has been deleted and restored back to dial *8 Cingular Voicelinfo Service.

6. EXTENDED MENU

To access the Extended Menu functions of the headset, press the Vol+ (4), Vol- (5) and Push4™ (2) buttons simultaneously until the Indicator Light flashes 3 times per second for 3 seconds (a series of 10 beeps will also be heard). To exit the Extended Menu functions follow the same steps. When exiting the Extended Menu, the settings you setup in that specific menu will be lost. You can leave the headset in “Extended Menu” to access all of the Extended Menu functions as well as all the basic usage functions (that are also available when not in Extended Menu). When in the Extended Menu you can do the following:

Muting the Microphone

During a call, briefly press the Push4™ Button (2) twice. A tone will be heard every 2 seconds during the call to remind you that the microphone is muted. Two additional presses of the Push4™ Button will reactivate the microphone.

Transferring a call to the phone*

Press the Push4™ Button 3 times during a call to transfer the call to the mobile phone. Pressing the Push4™ Button (2) once again will transfer the call back

5. Push4™ CALL FUNCTIONS

Your Headset can be configured with a specific Push4™ call function. So by pressing one button you can call a number stored in your headset memory without touching your phone. With the Headset on, press and hold the Push4™ Button (2) for 1 second to call directly to the configured number or phone service. In some cases, you can use this function as your favorite number on the Headset. This can only be done when you have received a call (A) from this same number into your Headset (not made through a hidden call). Once this received call has ended (B), press and hold both Vol+ (4) and Vol- (5) buttons for 3 seconds, until you hear a series of tones. The number from the last received call will be stored. (C) Now you can make a direct call to this number at any time just by pressing and holding the Push4™ Button (2) for 1 second.

*8 Cingular Voicelinfo Service

Your Headset has been preconfigured to access the *8 Cingular Voicelinfo service. Simply press and hold the Push4™ button for approximately 1 second to connect Cingular’s popular *8 Voicelinfo service which gives you access to rich audio content like sports, stock quotes, horoscopes,

6. If pairing is successful, you will see your phone connect to the SouthWing SH310 and the Indicator Light on the SouthWing headset will begin flashing every 3 seconds.

Normal pairing

You will need to follow the steps below if you want to pair your Headset with another mobile phone. You will be able to pair your Headset with up to 3 devices.

- Ensure the Headset is off
- Press and hold the On/Off Button (3) for about 5 seconds until the Indicator Light (2) flashes twice every second (you will hear a series of high tones.)Then complete the normal pairing process by following steps 1-6 in the Auto-pairing section above.

3. WEARING AND CARRYING THE HEADSET

You can wear your Headset on either ear and carry it in different ways using the rotating Multi-function Arm(8).

Wearing the Headset Without the Ear Hook

You can wear the Headset without using the Ear Hook. To do so:

- Rotate the Multi-function Arm (8) downwards, until it stays in your ear like a wired headset cable extension.
- Gently place the Speaker (6) into your ear canal.
- Finally find the most comfortable position by rotating the Headset forward and backward.

Wearing Headset Without Earhook

Wearing the Headset with the Ear Hook
The Ear Hook may also be used for

5. Enter the PIN number (four zeros): 0000

3

7. Troubleshooting

1. Headset will not turn on

The Headset battery may be empty.

Try recharging the Headset

2. Pairing is unsuccessful

Try moving the phone and Headset closer together during pairing.

Make sure that the mobile phone is in the correct Bluetooth mode.

Some electrical devices such as microwave ovens create a noisy electrical environment making it difficult for the Headset to communicate with the phone. Try moving away from such devices and try again.

3. Pairing has succeeded but calls are not heard in the Headset

Make sure that your phone is switched on and ready to connect to the Headset. Check your phone user manual on how to do this.

4. Headset stops responding to button presses

Ensure that your Headset battery is charged.

Try resetting your Headset according to the directions given in “Resetting your Headset”

5. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

6. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

7. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

8. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

9. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

10. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

11. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

12. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

13. Headset does not work properly

Check the battery level.

Check the ring tone selection.

Check the select ring tone.

1. Only with mobile phones supporting voice dialling

2. Only with mobile phones supporting Hands-free mode

13

weather and much more!†
(standard airline charges apply)

OR
Store Your Favorite Number
Your headset has been preconfigured to access the *8 Cingular Voicelinfo service. If you don't want to keep *8 you can change it and store your favorite, most called number instead. Your headset gives you the opportunity to instantly call one number of your choice by simply pressing and holding the Push4™ button (2) for approximately 1 second.

To remove the *8 Cingular Voicelinfo service in order to store your favorite frequently called number instead press and hold both Vol+ (4) and Vol- (5) buttons for 3 seconds until you hear a series of tones. You will automatically store the number from your last received call as your favorite number instantly. You can change the stored number at any time by following these same steps.

Storing your Favorite (last received) Number to Your Headset
1. Answer Your Call
2. End Your Call
3. Press and hold both Vol+ and Vol- buttons for 3 seconds to delete the previous number and store the number from your last received call as your favorite number.
Press 3 Sec.

***8 Cingular Voicelinfo Service**
Your Headset has been preconfigured to access the *8 Cingular Voicelinfo service. Simply press and hold the Push4™ button for approximately 1 second to connect Cingular’s popular *8 Voicelinfo service which gives you access to rich audio content like sports, stock quotes, horoscopes,

Accepting/rejecting* a call
When the phone rings (ring tone can be heard in Headset), briefly press the Push4™ Button (2) once to accept the call. Press and hold the Push4™ Button (2) for 1 second to reject the call.

Changing Volume
To increase the volume, with the Headset on, press Vol+ Button (4). To decrease the volume, press the Vol- Button (5). The Headset will remember all volume settings even when it is switched off.

Changing Color Covers
To change a color cover, place your thumbnail on the cover end and pull it out gently. Now you can fit the new color cover. Gently clip in the front of the cover and then gently snap the back in place.

Initiating a Call from Your Mobile Phone
Dial the number as usual with your phone. If your Headset is on and the phone has been correctly paired, your phone will transfer the call to your Headset.

Initiating a Call With Voice Dialing
You may be able to initiate the voice dialing function from your Headset (your phone will need to support Voice Dialing and voice tags need to be entered into your phone – reference your phone user manual). To activate, briefly press the Push4™ Button (2). You will then be able to speak the name of the person you wish to call.

Ending a Call
Press the Push4™ Button (2) briefly during a call and the call will be ended.

Disconnecting from the phone*
You may wish to disconnect the Headset from the phone in order to reduce battery consumption. To do so, press the Push4™ Button 3 times on the Headset when it is not in an active call. If you want to pick up a call, you first need to reconnect the Headset. To do so, press the Push4™ Button once again on the Headset.

Battery Life
To conserve battery life, your Headset features an auto-sleep function. This function switches the Headset off after 12 hours of inaction. Once your Headset has entered auto-sleep, it can be switched on again normally. When the battery has only 10% charge remaining, the Headset will produce an audible warning tone sequence every time a call is ended. This headset features a battery

Maximum comfort. To mount the Ear Hook, rotate the Multi-function Arm (8) upwards and slide it inside the Ear Hook (9) jack. To place it on your ear follow these steps:

- Rotate the Ear Hook (9) slightly forwards.
- Gently place the Speaker (6) into your ear canal.
- Rotate the Ear Hook (9) backwards and adjust it behind your ear.
- To switch from one ear to the other, simply rotate the Multi-function Arm (8) downwards and rotate the Ear Hook (9) to the opposite side.

Wearing Headset with the Earhook

Clipping your Headset to your Clothes
The Multi-function Arm can also be used to carry your headset in several convenient ways when the earhook is not mounted. To clip it to your clothes do the following:

- Rotate the Multi-function Arm (8) to the same direction of the microphone (7).
- Use the Multi-function Arm (8) and Headset Body as a clip to attach the Headset to your clothes.

Wearing the Headset Without the Ear Hook
You can wear the Headset without using the Ear Hook. To do so:

- Rotate the Multi-function Arm (8) downwards, until it stays in your ear like a wired headset cable extension.
- Gently place the Speaker (6) into your ear canal.
- Finally find the most comfortable position by rotating the Headset forward and backward.

Wearing Headset Without Earhook

Wearing the Headset with the Ear Hook
The Ear Hook may also be used for

5. Enter the PIN number (four zeros): 0000