


99-97-1961
(V 5.4)

Viper Climate and Production Computer Technical Manual



99

Program Version

The product described in this manual is computer based, and most functions are realised by software. This manual corresponds to:

- Software Version CPU 5.4

It was released in May, 2006.

Product and Documentation Changes

Big Dutchman reserve the right to change this document and the product herein described without further notice. In case of doubt, please contact Big Dutchman.

Latest date of change appears from the back page.

NOTE

- All rights reserved. No part of this manual may be reproduced in any manner whatsoever without the expressed written permission of Big Dutchman in each case
- Big Dutchman have made reasonable efforts to ensure the accuracy of the information contained in this manual. Should any mistakes or imprecise information occur in spite of this, Big Dutchman would appreciate being notified hereof
- Irrespective of the above, Big Dutchman shall not accept any liability with regard to loss or damage caused or alleged to be caused by reliance on any information contained herein
- Copyright 2006 by Big Dutchman

IMPORTANT

NOTES CONCERNING THE ALARM SYSTEM

Where climatic control is used in livestock buildings, breakdowns, malfunctions or faulty settings may cause substantial damage and financial losses. It is therefore most important to install a separate, independent alarm system, which monitors the house concurrently with the climate computer. According to EU-directive No. 91/629/EØF and 91/630/EØF an alarm system must be installed in any house that is mechanically ventilated.

Please note that the product liability clause of Big Dutchman's general terms and conditions of sale and delivery specify that an alarm system must be installed.



In case of misoperation or improper use, ventilation systems can result in production loss or cause loss of lives among animals.

Big Dutchman recommend that ventilation systems should be mounted, operated and serviced only by trained staff and that a separate emergency opening unit and an alarm system be installed as well as maintained and tested at regular intervals, according to Big Dutchman's terms and conditions of sale and delivery.

1	INTRODUCTION	7
2	MOUNTING GUIDE	8
2.1	Mounting of Viper together with MC 278CT and wiring box	8
2.2	Mounting of Viper	9
2.2.1	Mounting of I/O Module	10
2.2.2	Mounting of Cooling Plate and Fan Speed Controller	11
2.2.3	Mounting of AUT/MAN Change-over Switch	12
2.2.4	Mounting of Climate Sensors	12
2.3	Mounting of Wiring Box	13
3	INSTALLATION GUIDE	14
3.1	Technical Menus	14
3.2	Setup	14
3.2.1	Connection of Mains Voltage	15
3.2.2	Menu for Installation	16
3.2.3	Connection of Components: Show Installation	19
3.2.3.1	Manual I/O-allocation	20
3.2.3.2	Connection of MC 278CT Temperature Controlled Emergency Opening	22
3.2.3.3	Settings for Winch Motor	23
3.2.3.4	Setting of CAN Addresses	24
3.2.3.5	Setting of Jumpers for Water Meter, Humidity Sensor or DOL 12	26
3.2.4	Setting of CAN Termination Jumpers (max. 1 metre)	27
3.2.5	Setting of CAN Termination Jumpers (max. 200 metres)	28
3.2.5.1	Calibration of Weighing Module	29
3.2.5.2	Extra Supply to HI-power Relay Modules/Switch Modules	31
3.3	Adjustment	32
3.3.1	Menu for Adjustment	32
3.3.1.1	Configuration	34
3.3.1.2	Setting of Indication of Minimum Ventilation	38
3.3.1.3	Setting of Feed	39
3.3.1.4	Setting of Water Meter	39
3.3.1.5	Selection of Production Form	40
3.3.1.6	Setting of 1 or 2 Types of Animals	40
3.3.1.7	Selection of Operation Form	41
3.3.1.8	Select Measuring Unit	41
3.4	User Setup	42
3.4.1	Menu for User Setup	42
3.4.1.1	Selection of Language	43
3.4.1.2	Setting of Password	43

3.4.1.3	Setting of Display.....	44
3.4.1.4	CPU Module.....	45
3.4.1.5	Main I/O.....	45
3.4.1.6	General I/O.....	45
3.4.1.7	Weighing Modules.....	45
3.4.1.8	Calibrating Temperature Sensors.....	45
3.5	Testing	46
3.5.1	Testing Basis Components.....	46
3.5.1.1	Testing Inside Temperature and Air Humidity Sensors.....	46
3.5.1.2	Testing Outside Temperature Sensor.....	46
3.5.1.3	Testing Auxiliary Sensor.....	47
3.5.1.4	Testing Alarm.....	47
3.5.1.5	Testing MC 278M Emergency Opening.....	48
3.5.1.6	Testing MC 278CT Temperature Controlled Emergency Opening.....	48
3.5.2	Testing Optional Components: Manual Control.....	49
3.5.3	Menu for Manual/Auto.....	49
3.5.4	Automatic/Manual Control.....	51
3.5.5	Testing Climate Functions.....	52
3.5.5.1	Testing Air Intake and Air Outlet.....	52
3.5.5.2	Testing Stepless Fans.....	53
3.5.5.3	Testing Emergency Change-over Switch AUT/MAN.....	54
3.5.5.4	Testing MultiStep®, Tunnel MultiStep®, Side Stagefans and Tunnel Stagefans.....	55
3.5.5.5	Testing Heating.....	56
3.5.5.6	Testing Relay for Cooling, PAD-cooling, Humidification, Soaking and 24-hour Clock.....	57
3.5.6	Testing Production Functions.....	57
3.5.6.1	Testing Feed Relay, Silo Relay, Light Relay and 24-hour Clock.....	57
3.5.6.2	Testing the Bird Scales.....	58
3.5.6.3	Testing the Electronic Silo Weigher.....	58
3.5.6.4	Testing the Tip Weigher.....	59
3.5.6.5	Testing the Feed Demand Sensor and Cross Auger Sensor.....	59
3.5.6.6	Testing the Light Dimmer.....	59
3.5.7	End of Component Testing.....	60
3.6	System Setting	61
3.6.1	Menu for System Setting	61
3.6.2	Climate	63
3.6.2.1	Setting of Exhaustion (MultiStep®).....	63
3.6.2.2	Calibration of Air Intake and Air Outlet.....	65
3.6.2.3	Calibration of Tunnel Air Intake and Tunnel Air Outlet.....	65
3.6.2.4	Setting of Ventilation.....	66
3.6.2.5	Setting of Fan with Internal Fan Speed Controller.....	66
3.6.2.6	Setting of Fan with External Fan Speed Controller.....	66
3.6.2.7	Setting of Heating.....	67
3.6.2.8	Setting of Cooling.....	67
3.6.2.9	Setting of PAD Cooling.....	67

3.6.2.10	Setting of Humidification.....	67
3.6.2.11	Setting of Pressure Control	68
3.6.2.12	Adjustment of CO ₂ sensor.....	68
3.6.2.13	Adjustment of Auxiliary Sensor.....	68
3.6.2.14	Setting of Night Setback	68
3.6.3	Production.....	69
3.6.3.1	Setting of Bird Scales.....	69
3.6.3.2	Setting of Silo Calibration.....	69
3.6.3.3	Setting of Light Dimmer	69
3.6.4	Info Matic.....	70
3.7	Memory	71
3.7.1	Menu for Memory	71
3.7.1.1	Operation Log	71
3.7.1.2	Compact Flash Card.....	72
3.7.1.3	Default Deviation	73
3.8	Control Parameters	74
3.8.1	Menu for Control Parameters.....	74
3.8.1.1	Ventilation.....	75
3.8.1.2	Flex Mode	75
3.8.1.3	Air Intake	75
3.8.1.4	Winter Compensation.....	76
3.8.1.5	Cycle Time	76
3.8.1.6	Comfort	77
3.8.1.7	Heating.....	77
3.8.1.8	PAD Cooling.....	78
3.8.1.9	Humidity Control	78
3.8.1.10	Humidification	78
3.8.1.11	Pressure Control	78
3.8.1.12	CO ₂ Regulator	78
3.9	Adjustment of Negative Pressure and Stepless Units	79
3.9.1	Adjustment of Stepless 1 and 2	83
4	TROUBLE SHOOTING INSTRUCTIONS	84
4.1	Temperature Sensor Control Table	84
5	SPARE PARTS	85
6	TECHNICAL DATA	88
7	INDEX	89

1 INTRODUCTION

This technical manual deals with installation and service of the Viper climate and production computer. The first section of the manual is primarily aimed at electricians who are to mount, install and test Viper. The sections concerning adjustment and service, however, may be relevant to the electrician, the service engineer and the daily user.

The manual is built up to follow the working routine, which the setup of Viper climate and production computer requires. By following the instructions of the manual, you will go through all steps in the correct order.

Big Dutchman congratulate you on your new
Viper climate and production computer



2 MOUNTING GUIDE

2.1 Mounting of Viper together with MC 278CT and wiring box

When you want to... mount Viper together with MC 278 and wiring box they must be placed like this:




Figure 1: Mounting of Viper together with MC 278 CT and wiring box

2.2 Mounting of Viper

When you want to... mount the Viper climate and production computer, you must:

- 1) Remove the front panel with the front panel screws and the flat cable plug (A)
- 2) Prick/drill holes for the four screws (B) in the bottom of the cabinet
- 3) Hold the bottom against the wall with the display (C) at eye level for the daily user
- 4) Remember free space around the cabinet:
 - 43 cm (D) so that the front panel can be placed on top of the cabinet base during service
 - 10 cm (E) below the cabinet base for air cooling
 - 10 cm (F) at the right side for operation of the AUT/MAN (Auto/Manual) change-over switches
- 5) Mark out for the four fastening screws through the new holes (B) when mounting on a brick and concrete wall. On a wood and panel wall the computer can be fastened directly
- 6) Correct the four marks to horizontal and drill four 8 mm holes
- 7) Mount the cabinet base using the enclosed wall dowels
- 8) Place one or more washers under one of the bottom feet if the wall is not level




Figure 2: Mounting of Viper climate and production computer

2.2.1 Mounting of I/O Module

When you want to... mount the I/O module, you must:

- 1) Fasten the module (A) using the enclosed screws
- 2) Connect the plug (B) to the basis module
- 3) Set the change-over switch (C) at "1"
- 4) Set the jumpers (D) as shown in the installation menu




Figure 3: Mounting of I/O module

2.2.2 Mounting of Cooling Plate and Fan Speed Controller

One or two fan speed controllers can be mounted.

When you want to... mount a fan speed controller, you must

- make holes and mount the cooling plate:

- 1) Drill one or two holes **(A)** from the outside or the back using an approx. 38 mm spoon bit. Remove any roughness from the edge
- 2) Mount the packing line **(B)** carefully in the notch on the back so that the joint turns downwards
- 3) Fasten the cooling plate **(C)** on the back using eight (countersunk) screws **(D)**

- mount the fan speed controller:

- 1) Smear a little cooling paste on the back of the fan speed controller **(E)**
- 2) Fasten the fan speed controller with four screws **(F)** (coarse threads)
- 3) Fasten the earth wire **(G)** (fine thread). Remember the toothed disk
- 4) Connect the other end of the earth wire **(H)** to the looped terminal Q31
- 5) Fasten the fan speed controller well with the (smallest) screw **(I)**. Do not twist the pins
- 6) Connect the plug **(J)** to the basis module




Figure 4: Mounting of cooling plate and fan speed controller

2.2.3 Mounting of AUT/MAN Change-over Switch

When you want to... mount an AUT/MAN change-over switch, you must:

- 1) Knock or drill and file one or two knock-out pieces for the AUT/MAN change-over switch **(A)**
- 2) Mount the AUT/MAN change-over switch **(B)** in the hole (remember packing **(C)**)
- 3) Connect the wires **(D)** to the change-over switch. Hold the change-over switch so that it is not pressed out of the hole again. The wires cannot be mixed up




Figure 5: Mounting of AUT/MAN change-over switch

2.2.4 Mounting of Climate Sensors

Always use reinforced house wiring cable, minimum 1 mm², to avoid rodent attack.

When you want to... mount climate sensors, you must

- place the DOL 12 temperature sensors and DOL 14 humidity sensor inside the house:

- One metre above the animals, approx. in the middle of the pen (ensuring the animals cannot reach the sensors)
- In a draught-free zone. Not opposite an air inlet
- Not directly in a heating jet
- Not where sunrays can shine on the sensor through windows. Take into account that the altitude of the sun varies with the season/time of day
- Not where spraying can hit the sensor

A plug on the DOL 14 humidity sensor is preferable so it can be removed during cleaning.



Never use a plug on the DOL 12 temperature sensor as a bad connection here could have disastrous results. Never use shrink-on sleeves.

- place the DOL 12 temperature sensor outside:

- On the shady side of the house to avoid the sun. Take into account that the altitude of the sun varies with the seasons
- As much in the open as possible, but protected from rain and snow

2.3 Mounting of Wiring Box

When you want to... mount the Viper climate and production computer, you must:

- 1) Remove the front panel with the front panel screws and the flat cable plug **(A)**
- 2) Prick/drill holes for the four screws **(B)** in the bottom of the cabinet
- 3) Hold the bottom against the wall with the panel **(C)** at eye level for the daily user
- 4) Remember free space around the cabinet:
 - 43 cm **(D)** so that the front panel can be placed on top of the cabinet base during service
 - 10 cm **(E)** below the cabinet base for air cooling
 - 10 cm **(F)** at the right side for operation of the AUT/MAN (Auto/Manual) change-over switches
- 5) Mark out for the four fastening screws through the new holes **(B)** when mounting on a brick and concrete wall. On a wood and panel wall the computer can be fastened directly
- 6) Correct the four marks to horizontal and drill four 8 mm holes
- 7) Mount the cabinet base using the enclosed wall dowels
- 8) Place one or more washers under one of the bottom feet if the wall is not level




Figure 6: Mounting of wiring box

3 INSTALLATION GUIDE

3.1 Technical Menus
























Main menu	Sub-menu	
 Technical	 Setup	 Installation  Adjustment  Show installation
	 User setup	 Language  Password  Display  CPU module  Main I/O  General I/O  Weighing modules  Calibrate sensors
	 Service	 Manual/auto  Setting  Memory  Control parameters  Adjust neg. pressure  Adjust stepless A  Adjust stepless B  Diagnostics

Table 1: Survey of technical menus

3.2 Setup

This section describes the connection of mains voltage and components, setting of the climate computer and connection of other components.

When you want to... make electric installation, you must:

- 1) Connect cables according to that particular basis wiring diagram, which corresponds to the emergency opening of the system
- 2) Connect mains voltage
- 3) Set up the relevant ventilation components in the climate computer
- 4) Connect the individual components by means of the wiring diagrams
- 5) Adjust the system
- 6) Test the system

3.2.1 Connection of Mains Voltage

IMPORTANT Before you connect mains voltage, it is important to set the voltage in the computer so that it corresponds to the voltage level in the local house.

You have the following options:

- 230/240 V Leave the plug in (factory setting)
- 200 V Move the plug to 200 V
- 115 V Move the plug to 115 V

NB Fan speed controller modules can only operate at 230/240 V.




































Figure 7: Setting of mains voltage

3.2.2 Menu for Installation

Setup: Installation	Menu items	Sub-menus	Options under the individual menu items	
	 I/O modules	 General modules	 Module 1 - 6	None Type 1 10 RL Type 3 10 RL Type 4 0RL Type 6 10 HP Type 7 10 LP
		 Weighing modules	 Module 1-2	None Type 5W
	 Climate	 Number of temperature sensors	1-8	
		 Air inlet	 Side inlet 1 - 6	No With feedback – no M.O. With feedback – with M. No feedback – no M.O.sw No feedback – with M.O.
			 Tunnel inlet 1 - 2	No With feedback – no M.O. With feedback – with M. No feedback – no M.O.sw No feedback – with M.O.
			<input type="checkbox"/> Manual tunnel input	
		 Air outlet	 Stage/MultiStep	Stage MultiStep
			 Stepless 1	 Air outlet 1
			 Stepless 2	 Fan speed control 1
			 No. of side MultiStep	 Air outlet 2
			 No. of tunnel MultiStep	 Fan speed control 2
			 No. of side fans stages	0 – 8
			 No. of tunnel fans stages	0 – 8
		 Emergency opening	 Flap control side-MS	0 – 16
			<input type="checkbox"/> 278CT	0 – 16
	 Heaters	 Number of house heaters		0-6
			 Number of brooding heaters	0-4
			 Heater setup	 Heater 1 - 6
		<input type="checkbox"/> Humidity sensor	None	 Brooding heater 1 - 4
			One humidity sensor Two humidity sensors	
	 Cooling	 Pad cooling	No 1 2	
			No	







Setup: Installation	Menu items	Sub-menus	Options under the individual menu items	
			One pump Two pumps	
		<input type="checkbox"/> Pad sensor		
		<input type="checkbox"/> Humidification	No 1 2	
		<input type="checkbox"/> Humidification		
		<input type="checkbox"/> Soaking	No 1 2	
		<input type="checkbox"/> Pressure control		
		<input type="checkbox"/> Aux. sensors	<input type="checkbox"/> Aux. sensor 1 - 4	No CO2 sensor Press. sensor NH3 sensor O2 sensor
		<input type="checkbox"/> CO ₂ -sensor		
	 Production	 Feed	<input type="checkbox"/> Feed control <input type="checkbox"/> Feed weigher <input type="checkbox"/> Number of silos	None Time controlled Tip weigher Electronic silo weigher One silo Two silos
		 Water meter	<input type="checkbox"/> Water meter installed <input type="checkbox"/> Active alarm relay	
		 Bird scales	<input type="checkbox"/> Bird scale 1 - 2	None Manual 5 kg weight 10 kg weight 30 kg weight Other scale Electronic scale
		 24-hour clock	<input type="checkbox"/> 24-hour clock A - D	
		<input type="checkbox"/> Light control		
	<input checked="" type="checkbox"/> Info Matic			


Table 2: Survey of the installation menu

When you want to... set the climate and production computer,

→ press 




→ select **Technical**, and press




→ select **Setup**, and press




→ select **Installation**, and press




→ select **I/O modules**, and press




→ select **General modules**, and press




→ select a component, and press to gain access to choosing or cancelling it



→ select to change the setting, and press to choose a setting




→ select **Weighing modules**, and press




→ select a component, and press to gain access to choosing or cancelling it






→ select to change setting, and press to choose a setting



→ when **Yes** is highlighted, press to save the change



It is not possible to select more components than practically possible. Therefore, you must note whether the computer accepts your wish to connect a component.



→ during installation the computer will inform you if a component cannot be connected

3.2.3 Connection of Components: Show Installation

The climate and production computer will inform you *where* to connect the components when you have answered all questions of the installation menu (e.g. Water meter: **Yes/No**). Therefore, when it says **See Show installation** in a wiring diagram, it refers to the connections that the climate and production computer gives you during the setting of the computer.

The main part of the connection terminals is universal. Thus, it is possible to install various components for the individual terminals.

When you install a component, which requires the allocation of I/O, the following happens.


All I/Os are allocated according to a prioritized list. This means that if priority 1 I/O is free, priority 1 I/O will be selected. On the other hand, if priority 1 I/O is already being used by another component, the computer will try priority 2 I/O etc.

Many components use the same prioritized list to get the I/O. This means that if you install component 1 first and then component 2, component 1 will have priority 1 I/O and component 2 will have priority 2 I/O. On the other hand, if you install component 2 first, it will have priority 1 I/O and component 1 will have priority 2 I/O. If you want the same I/O allocation in two computers, it is therefore important to make the installation in the same order.


Another way of having the same I/O allocation is by installing all components on one of the computers first. Then save the setup on a CF-card and enter the setup in the other computers. These two computers now have the same I/O allocation.

When you want to... see **Show installation**, you must

→ press 




→ select **Technical**, and press



→ select **Setup**, and press



→ select **Show installation**, and press



→ scroll to see the other connected components and press to exit the menu

3.2.3.1 Manual I/O-allocation

If you want to decide the I/O-allocation for one or more components yourself, you can change it manually under the menu item **Manual I/O allocation**.

When you want to... change the I/O-allocation, open the **Technical / Setup / Manual I/O allocation** menu, and



→ select the component that you wish to change, and press



> Shows the current I/O-allocation


Choose between the listed terminals:


- * The terminal is currently allocated to another function
- The terminal is not in use

Select the required terminal and press Enter

If you use a terminal that is currently used by another function (indicated by *), Viper will automatically change the I/O-allocation for this function.






Press the  menu key to accept the change

or

Select **Return** at the top of the menu and press Enter.

Viper will not make the change of the I/O-allocation until you accept it.



If the change of the I/O-allocation is possible, Viper will accept it.

If the change is not possible, Viper will reject, and the I/O-allocation will continue as previously.

Viper rejects the change of the I/O-allocation if:

- you have manually used all DOL 12 inputs for other analog inputs
- you have manually used relays so that there are no free relays for the relay-controlled shutters

Instead, manually select terminal for all temperature sensors and subsequently for all relay-controlled shutters.

3.2.3.2 Connection of MC 278CT Temperature Controlled Emergency Opening

When you want to... connect MC 278CT temperature controlled emergency opening, you must

- 1) Remove the jumper plug (A) (place it at the bottom of the cabinet)
- 2) Connect the enclosed MC 278CT connection cable (B)
- 3) Fasten three conductors in the terminal strip (C) Q1-Q5 in the climate computer
- 4) Connect the 12-conductor cable in MC 278CT (D) to the T1-T12 terminal strip (this cable can be replaced by a longer cable, if required)
- 5) Set the jumpers (E) of the basis and I/O modules, which decide which relays are activated by the emergency opening. See jumper placement under **Show installation**
- 6) Set the jumpers (F) on the LO-power relay module
 - ON = the relay is overridden by the MC 278CT temperature controlled emergency opening
 - OFF = the relay is not overridden




Figure 8: Connection of MC 278CT temperature controlled emergency opening and setting of the jumpers of the basis module and the I/O module

3.2.3.3 Settings for Winch Motor

When you connect winch motors, the following must be set as shown in: **Technical/Setup/Show installation**

(A) LO-power relay module:

Winch motor YES / NO, jumpers W1 - W5:

- YES = Inverts one of the relays in the pair of relays so that it matches winch motor and emergency opening
- NO = The relay matches e.g. heating and fans

(B) Override switch modules:

WINCH-MOTOR BLOCKED: slide switch: S1 - S5

- ON = For winch motor. Prevents paired activation of relays and quick changes in direction out of consideration for the lifetime of the relay contacts
- OFF = For e.g. heating and gable fans. The relays can be activated unobstructed
- A winch motor must always be installed on one of the following pairs of relays: 1st + 2nd relay, 3rd + 4th relay, 5th + 6th relay, 7th + 8th relay or 9th + 10th relay
- The HI-power relay module with make contacts can control e.g. fan, heating and a 230 V winch motor
- The LO-power relay module with make contacts can control e.g. fan, heating, a 230 V winch motor and a 24 V DC winch motor with emergency opening
- The switch module is used together with both the HI-power relay module and the LO-power relay module

Example:

If a 24 V winch motor is installed on 9th and 10th relay, the following must be set:

- Set the W5 jumper on the LO-power relay module to YES
- Set the S5 slide switch on the override switch module to ON

There are no settings on the HI-power relay module and it cannot control 24 V winch motors either.





Figure 9: Settings for winch motor

3.2.3.4 Setting of CAN Addresses


Each individual module on the CAN bus must have a certain address so that the computer can communicate with it.

Set the addresses on a small rotary switch with a number: 0 – 9

When you want to... set module types for **General modules**, open the **Technical/Installation/I/O modules** menu, and



→ select **General modules**, and press




Make sure that the address switch is always the same as the module number.


In the example, the **General modules** must be set as follows:

Module 1	Type 3 10 RL	Address = 1
Module 2	Type 7 10 LP	Address = 2
Module 3	Type 7 10 LP	Address = 3
Module 4	Type 7 10 LP	Address = 4
Module 5	Type 7 10 LP	Address = 5

When you want to... set module types for **Weighing modules**, open the **Technical/Installation/I/O modules** menu, and



→ select **Weighing modules**, and press



In the example, the **Weighing modules** must be set as follows:

Module 1	Type 5 W	Address = 1
----------	----------	-------------

The two address rotary switches X10 and X1 must then be set as follows:

Weighing module no.	X10	X1
1 st module	0	1




Figure 10: Setting of CAN addresses

3.2.3.5 Setting of Jumpers for Water Meter, Humidity Sensor or DOL 12

When installing the water meter (DI), humidity sensor 0-10 V (AI) or the DOL 12 temperature sensor, the jumpers of the basic module and the I/O module must be set as shown in the menu:

Technical/Setup/Show installation.

I/O-module

The analog inputs on the I/O module can be set:

- DOL 12 (temp.) = Temperature sensor input for DOL 12
- ON (DI) (Pull down) = E.g. water meter (digital input) (pull down resistance = ON)
- OFF (AI) (0-10V) = E.g. humidity sensor (analog input) (pull down resistance = OFF) (remove the jumper completely or place it on one pin only)




Figure 11: The basic module and the I/O-module jumpers for water meter, humidity sensor or DOL 12 temperature sensor


Basic Module

The analog inputs of the basic module can be set to ON/OFF.

For the inputs C2, C5, C7, C9, C 15 and C 18 you must also set:

- DOL 12 (temp.) = Temperature sensor input for DOL 12
- 0-10V = E.g. humidity sensor (analog input)

When you want to... set the jumpers,
open the Technical/**Setup/Show installation** menu, and



→ scroll to display the setting of jumpers, and press to return to the menu

3.2.4 Setting of CAN Termination Jumpers (max. 1 metre)

See section 3.2.5 if the silo-weighing module is installed with a long CAN cable.

The various modules are controlled by CAN-bus communication. To obtain a safe communication between the modules, it is important that the CAN termination jumpers are set correctly.

- (1) Set the "ON/OFF CAN TERM" jumper to ON (only the last module that is placed at the end of the CAN-bus, in this case the manual override switch module)
- (2) Set the "ON/OFF TERMINATE" jumper to OFF (all other modules that are connected with the CAN-bus: I/O-modules, override switch modules and silo-weighing module)




Figure 12: Setting of CAN termination jumpers - max. 1 m cable

3.2.5 Setting of CAN Termination Jumpers (max. 200 metres)

See section 3.2.4 if the silo-weighing module is installed with a short CAN cable.

The various modules are controlled by CAN-bus communication. To obtain a safe communication between the modules, it is important that the CAN termination jumpers are set correctly.

- (1) Set the "ON/OFF CAN TERM" jumper to ON (only the last module that is placed at the end of the CAN-bus, in this case the manual override switch module)
- (2) Set the "ON/OFF CAN TERM" jumpers to OFF (all other I/O modules and override switch modules)
- (3) Set the "ON/OFF TERMINATE" jumper to ON (silo-weighing module)
- (4) Set the "ON/OFF INT-TERM CAN" jumper to OFF (data network module RS485/CAN)
- (5) Set the "ON/OFF EXT-TERM CAN" jumper to ON (data network module RS485/CAN)




Figure 13: Setting of CAN termination jumpers - max. 200 metres cable

3.2.5.1 Calibration of Weighing Module

The module has the following settings:

- (1) "ON/OFF TERMINATE" small slide switch/DIL-switch
- (2) Module address (is set on two small rotary switches/HEX-switch address)




Figure 14: Calibration of weighing module

When you want to... calibrate the weighing module, you must

- make sure that the green PWR-lamp (4) shines constantly (must not flash)
- set switch (3) (NORMAL- S) to "S" = setup (and C, A and B to NORMAL)
- press the RESET-button (5)
- wait until the red lamp (6) switches on*
- select the weight channel to be calibrated (only one at a time):

Weigher#1: Set switch (3) (NORMAL – A) to "A" or

Weigher#2: Set switch (3) (NORMAL – B) to "B"

- make sure that the load on the weigher corresponds to empty silo (TARE)
- set switch (3) (NORMAL – C) to "C" = CAL position
- wait until the yellow lamp switches on*
- load the silo with a known test load
- wait a few seconds until the weigher is calm
- return switch (3) (NORMAL – C) to "NORMAL" position

If the green lamp switches on the calibration is accomplished OK*

- return switch (3) S and A or B to NORMAL
- press the RESET-button (5)

This routine saves the TARE and TEST calibration values in the weighing module.

To finish the calibration of the weigher, the test load must be entered in the menu, see section 3.6.3.2 Setting of Silo Calibration.

*) In case of an error, the RED+YELLOW+GREEN lamp will flash. The error can be remedied by setting switch (3) S, C A and B to NORMAL and repeat the calibration.

The calibration can fail

- if switch (3) A or B is not set correctly
- if the weigher is defective or if there is no connection to the weigher
- if the value with the test load (calibration plumb) is too light. The test load must be min. 1 per mille and max. 10 per cent of full load. Full load is 2 mV/V
Example: If the load amplifier is e.g. connected to four load cells, which give 2 mV/V at 2000 kg, the calibration plumb must weigh min. 8 kg and max. 800 kg
- if errors occur when data are saved

3.2.5.2 Extra Supply to HI-power Relay Modules/Switch Modules

When installing three or more HI-power relay modules, an extra wire must be connected from the +24 V wire terminal module of the power module to the +24 V wire terminal module of the third override switch module. This is necessary because the flat cable cannot bear the 24 V power consumption to 30 or 40 HI-power relays alone.

Do not install more than two HI-power relay modules or four LO-power relay modules without installing an extra wire.

































Figure 15: Extra supply to HI-power relay modules

3.3 Adjustment

This section describes the adjustment of the system for the individual house sections. However, the temperature display (°C) is common for the houses.

3.3.1 Menu for Adjustment

Setup: Adjustment	Menu items	Options under the individual menu items	
	 Climate	 Configuration	<div>  Control mode <ul style="list-style-type: none"> Basic-step Flex-step UltiMatic </div> <div>  Flex mode init <ul style="list-style-type: none">  Maximum level  Control <input type="checkbox"/> Matrix completed </div> <div>  Sectional cross area <ul style="list-style-type: none"> 10 m² – 1000 m² </div> <div>  Grow zones <ul style="list-style-type: none"> 1 2 3 </div> <div>  Temperature sensors setup <ul style="list-style-type: none">  Grow zone sensors  Heating zone sensors </div> <div>  Zone setup <ul style="list-style-type: none"> <input type="checkbox"/> Zone inlets  Air inlet  Temp. sensors for inlets  Stepless  Stage fans  MultiStep <input type="checkbox"/> 2-zone outlet  Temp. sensors for 2-zone  Setup 2-zone </div> <div>  Heater setup <ul style="list-style-type: none"> <input type="checkbox"/> Activate inactive grow zone heating  Inactive grow zone temperature offset  Heater selection  Brooding zone selection </div> <div>  Humidity sensor setup </div> <div>  Cooling </div> <div>  Pad cooling </div> <div>  Humidification </div> <div>  Real air Percent </div>
		 Min. vent.	









Setup: Adjustment	Menu items	Options under the individual menu items		
	 Production	 Kg per impulse	0.500 – 50.000 kg	
		 Feed per second	0.100 – 100.000 kg	
		 Water meter	0.10 – 50.00 L	
		 Production form	Broiler Breeder	
	 1 or 2 types of animals	Mixed animals Sexed animals		
	 Operation form	Continuous Batch prod.		
	 Unit definition	Metric (°C) US mode (°F)		

Table 3: Survey of adjustment menu


This adjustment is typically only made once and it determines how the Viper Climate and Production Computer controls the climate.


When you want to... adjust the computer under the setup menu item **Adjustment**, you must

- 1) Connect power to the climate computer


After a few seconds, the Viper display shows the current inside temperature, and you can carry out the adjustment.

All menu items in the **Adjustment** menu can be set by

→ pressing 



→ selecting **Technical**, and pressing



→ selecting **Setup**, and pressing




→ selecting **Adjustment**, and pressing



3.3.1.1 Configuration

3.3.1.1.1 Selecting Control Mode

When you want to... select Control mode,
open the **Technical/Setup/Adjustment/Climate/Configuration** menu, and



→ select **Control mode**, and press




→ select the required setting (**Basic-step/Flex-step/Ultimatic**), and press to select it




Flex-Step cannot be selected until after setting the functions in **Flex mode init** and after having selected **Matrix completed**.

3.3.1.1.2 Setting of Flex Mode Init


When you want to ... set **Flex mode init**, open the
Technical/Setup/Adjustment/Climate/Configuration/Flex mode init menu, and



→ select **Maximum level**, and press



→ set maximum ventilation level, and when **Yes** is highlighted, press to save the change



→ select **Control**, and press


Control					
Lev.	Diff	ON	OFF	Mode	S1
0	0.0	50	250	Side	.
1	0.0	50	250	Side	.
2	0.0	50	250	Side	.
3	0.0	50	250	Side	.

- select the required field, and press
see perhaps the User's Manual section dealing with the Flex-Steps **Control** menu to get an explanation of the functions

Adjust

50

Minimum : 0 Maximum : 999

- set the function, and press
- press  to return to the menu

Flex mode init

..Return

Maximum level 10

Control

Matrix completed

- select **Matrix completed**, and press to confirm that the setting of the matrix is completed

Flex-Step can now be selected in the **Control mode** menu item of the configuration menu.



When setting the control table, note the placement of the fans in relation to the division of the house into **grow zones**. Thus, the settings of a grow zone will be a determining factor to the fans (see section 3.3.1.1.6).

For instance, a fan in a grow zone, which is not active, will not run even if it belongs to the current ventilation level in the control table.

3.3.1.1.3 Setting of Area

When you want to... set area,
open the **Technical/Setup/Adjustment/Climate/Configuration** menu, and

Configuration

..Return

Control mode

UltiMatic

Sectional cross area

60m2

- select **Sectional cross area**, and press

Sectional cross area

60m2


Minimum : 10 Maximum : 1000

- enter the required area, and when **Yes** is highlighted, press to save the change


3.3.1.1.4 Selection of Number of Grow Zones

With Viper, you can divide the house up into three grow zones. According to the age and size of the animals, Viper will activate the grow zones.

When you want to... set Grow zones,
open the **Technical/Setup/Adjustment/Climate/Configuration** menu, and



→ select **Grow zones**, and press




→ select 1, 2 or 3 zones, and press to save the change


3.3.1.1.5 Setting of Temperature Sensor

You must assign a number of temperature sensors to each individual grow zone, which register the temperature in the zone. The individual temperature sensor is only active when the zone to which it belongs, is active. Thus, the temperature display of Viper depends on which grow zone is active.


When you want to... set the temperature sensors,
open the **Technical/Setup/Adjustment/Climate/Configuration** menu, and



→ select **Temperature sensors setup**, and press



→ select **Grow zone sensors**, and press



→ select a **Grow zone/Tunnel zone** for each temperature sensor, and press to save the change


→ press  to return to the menu

Heating zone sensors are set in the same way.




3.3.1.1.6 Setting of Zone Setup

When you want to... set Zone setup,
open the **Technical/Setup/Adjustment/Climate/Configuration** menu, and




→ select **Zone setup**, and press



→ select **Air inlet**, and press



→ select **Grow zone/Tunnel zone** for each side inlet/tunnel inlet, and press to save the change


→ press  to return to the menu

If no check boxes are displayed in the column, no side inlet/tunnel inlet is installed.


Stepless, **Stagefan** and **MultiStep** are set in the same way.

3.3.1.1.7 Setting of Heater Setup


When you want to... set Heater setup,
open the **Technical/Setup/Adjustment/Configuration** menu, and




→ select **Heater setup**, and press




→ select **Activate inactive grow zone heating**, and when **Yes** is highlighted, press to save the change




→ select **Inactive grow zone temperature offset**, and press




→ change the setting, and when **Yes** is highlighted, press to save the change




→ select **Heater selection**, and press




→ select a **Grow zone** for each **Box heater**, and press to save the change


→ press  to return to the menu



→ select **Brooding zone selection**, and press




→ select a **Grow zone** for each **Brooding zone no.**, and press to save the change

→ press  to return to the menu


3.3.1.2 Setting of Indication of Minimum Ventilation

You can set **Minimum ventilation** to be indicated either as a percentage of the nominal ventilation output or real air.

When you want to... set the indication of minimum ventilation, open the **Technical/Setup/Adjustment/Climate** menu, and




→ select **Minimum ventilation**, and press



→ select the required setting (**Real air/Percent**), and press to choose it

3.3.1.3 Setting of Feed

When you want to... set kg feed per impulse,
open the **Technical/Setup/Adjustment/Production** menu, and




→ select **Tip weigher**, and press



→ set the required quantity, and press to save the change

When you want to... set kg feed per second,
open the **Technical/Setup/Adjustment/Production** menu, and



→ select **Feed per second**, and press




→ set the required quantity, and press to save the change


3.3.1.4 Setting of Water Meter

To obtain correct calculation of the water consumption, it is necessary to enter how many litres of water per pulse the installed water meter gives.

When you want to... set the water meter,
open the **Technical/Setup/Adjustment** menu, and




→ select **Water meter**, and press



→ enter a value, and press to save the change

3.3.1.5 Selection of Production Form

When you want to... select production form,
open the **Technical/Setup/Adjustment/Production** menu, and




→ select **Production form**, and press




→ select the required setting (**Broiler/Breeder**), and press to choose it

3.3.1.6 Setting of 1 or 2 Types of Animals

When you want to... select 1 or 2 types of animals,
open the **Technical/Setup/Adjustment** menu, and




→ select **1 or 2 types of animals**, and press



→ select the required setting (**Mixed animals/Sexed animals**), and press to choose it

3.3.1.7 Selection of Operation Form

When you want to... select operation form,
open the **Technical/Setup/Adjustment** menu, and



→ select **Operation form**, and press




→ select the required setting (**Continuous/Batch prod.**),
and press to choose it


3.3.1.8 Select Measuring Unit

To obtain the correct climate control, it is necessary to indicate, which measuring unit Viper is to use.

When you want to... select measuring unit,
open the **Technical/Setup/Adjustment** menu, and



→ turn until **Unit definition** is selected, and press



→ turn to select the required setting (**Metric (°C) / US-mode (°F)**), and press to select it

3.4 User Setup

3.4.1 Menu for User Setup
































User setup	Menu items	Options under the individual menu items	
	 Language	Dansk English Deutsch	
	 Password	<input type="checkbox"/> Use password 1 - 3  New password 1 -3	
	 Display	 Set brightness  Set contrast	
	 CPU module	 Type  Software version  Serial no.	
	 Main I/O	 Type  Serial no.	
	 General I/O	 Module 1 - 3  Module 4 - 6	 Type  Software version  Serial no.  Type  Software version  Serial no.
	 Weighing modules	 Module 1 - 2	 Type  Software version  Serial no.
	 Calibrate sensors	 Temperature sensor 1 - 8	


Table 4: Survey of user setup

All menu items... in the **User setup** menu can be set by

→ pressing 



→ selecting **Technical**, and pressing



→ selecting **User setup**, and pressing

3.4.1.1 Selection of Language

When you want to... select language,
open the **Technical/User setup** menu, and



→ select **Language**, and press



→ select the required language, and press

3.4.1.2 Setting of Password

The functions of the computer are on three access levels that can be activated individually. When an access level is active, you can also change the four-digit password.

When you want to... code protect an access level,
open the **Technical/User setup** menu, and



→ select **Password**, and press



→ select **Use password 1**, and press to activate it

You must activate the access levels 2 and 3 in the same way.

When you want to... change the password, the password must be active, and you must
open the **Technical/User setup/Password** menu, and



→ select **New password 1**, and press



→ enter a new password by selecting the first digit in the new password, and press

An asterisk (*) in the black box indicates that you have selected a digit

→ repeat for the last three digits

→ to correct a wrong, entered digit, select (←), and press



→ go to the end of the digit string, and when **OK** appears, press to approve



→ repeat the entry of the new code to execute the change

3.4.1.3 Setting of Display

You can set the brightness and the contrast of the Viper display for optimum reading in relation to the actual placement of the computer.


When you want to... set the display,
open the **Technical/User setup** menu, and



→ select **Display**, and press




→ select **Set brightness**, and press



→ change the setting, and press



→ select **Set contrast**, and press



→ change the setting, and press

3.4.1.4 CPU Module

Under the **Technical/User setup** menu, you can read which type of **CPU module** the computer has and the serial number and software version of the module.

3.4.1.5 Main I/O

Under the **Technical/User setup** menu, you can read which type of **Main I/O** the computer has and the serial number of the module.

3.4.1.6 General I/O

Under the **Technical/User setup** menu, you can read which type of **General I/O** the computer has and the serial number of the software version of the module.


3.4.1.7 Weighing Modules

Under the **Technical/User setup** menu, you can read which type of **Weighing modules** the computer has and the serial number and software version of the module.


3.4.1.8 Calibrating Temperature Sensors

If, in connection with manual temperature measurements, you measure the current house temperature to a level that differs from Viper's registrations from the installed temperature sensors, you can adjust the temperature in the **Calibrate sensors** menu so that it matches your observations.

When you want to ... calibrate temperature sensors, open the **Technical/User setup/Calibrate sensors** menu, and



→ select **Temperature sensor 1**, and press



→ set a value, and when **Yes** is highlighted, press to save the change

Repeat the setting for the installed number of temperature sensors.



3.5 Testing


After installing the system you **must make a thorough test** to make sure that the system works as intended.

3.5.1 Testing Basis Components

3.5.1.1 Testing Inside Temperature and Air Humidity Sensors

When you want to... test inside temperature and humidity sensors,

→ press the  survey key



→ read the current inside temperature and humidity


Check...

- 1) that the temperature indicated corresponds to the result that can be measured in the house
- 2) that the temperature rises in the display when the sensor is warmed in your hand
- 3) that the humidity indicated corresponds to the result that can be measured in the house

3.5.1.2 Testing Outside Temperature Sensor

When you want to... test the outside temperature sensor,

→ press  the survey key



→ read the current outside temperature


Check...

- 1) that the temperature shown corresponds to the current outside temperature
- 2) that the outside temperature rises in the display when the outdoor sensor is warmed in your hand

3.5.1.3 Testing Auxiliary Sensor

This section is only relevant to houses where auxiliary sensors are installed.

When you want to... check that the auxiliary sensor works,
open the **Technical/Service/Manual/Auto** menu, set the computer to **Manual**,
and in **Main menu/Climate**




→ select **Aux. sensors**, and read the current voltage

Compare the reading with what you can measure on the sensor or the connection terminals with a multimeter.


3.5.1.4 Testing Alarm

When you want to... test the alarm,

→ press 



→ select **Alarms**, and press



→ select **Alarm test**, and press to start the test



→ press to end the test

Check...

- 1) that the alarm lamp for the relevant house is flashing
- 2) that the alarm system works as intended

Make the test in all houses.

The test should then be made every week.

3.5.1.5 Testing MC 278M Emergency Opening

When you want to... test the emergency opening, you must



- 1) disconnect the mains voltage to Viper and MC 278M on the common external TEST mains switch
- 2) check that:
 - The inlets open completely
 - The green TEST lamp remains on during the entire test which indicates that battery voltage is sufficient (i.e. > 16 V)
- 3) Reconnect mains voltage.
The inlets should close again

3.5.1.6 Testing MC 278CT Temperature Controlled Emergency Opening

When you want to... test the temperature controlled emergency opening, you must

- 1) Connect the panel and the power supply. The TEST lamp must be green indicating that the 24 V on the N6-N7 terminal is OK > 16 V. See the Troubleshooting Instructions if the TEST lamp is off
- 2) Connect the battery if the TEST lamp lights up. Connect the red battery wire to the red battery connector and the black battery wire to the black battery connector. (The battery should be charged for at least ten minutes before the first test)
- 3) Turn the temperature knob on MC 278CT. The display of the climate computer should then automatically show the setting of the knob together with the setpoint of the house, i.e. the required house temperature
- 4) Check the battery voltage; see emergency opening alarms in Viper.
The voltage in a partly charged battery should be between 20.0 and 20.5 V

Side mode:

- 5) Check if the system runs side mode. The side mode icon  must be shown in the survey menu of Viper. If the system runs tunnel mode , it is possible to force the system to run side mode by increasing the **Temperature setpoint**
- 6) Turn the emergency temperature knob to TEST
- 7) Check if the red and the yellow lamps turn on
- 8) Check if the system opens in the house
- 9) Check if all fans are still operating
- 10) Turn the emergency temperature knob up slowly until the red lamp just turns off and continue approx. 1-2 degrees higher. The red and the yellow lamp should now be turned off
- 11) Warm the MC 278CT emergency temperature sensor in your hand for a couple of minutes. (Do not mistake the sensor for the inside temperature sensor of the climate computer). Check if the red lamp turns on in the same side as under item 6. The yellow lamp will also turn on for some seconds every three minutes when the house opens a little, but it may be difficult to reach seeing it
- 12) The red lamp must turn off again when the DOL 12 emergency temperature sensor has cooled off again








































Tunnel mode:

- 13) Turn the emergency temperature knob to 40 °C. The red lamp must turn off
- 14) Set the system to tunnel mode by changing the setting of the CL 75CT curtain motor from AUT (automatic) to MAN (manual) and pressing ↑ - and let the curtain open completely
- 15) Turn the emergency temperature knob slowly to 10 °C, the yellow lamp must turn on before the knob is turned to approx. 12.5 °C
- 16) **IMPORTANT** – remember to change the setting of CL 75CT to AUT (automatic) again

3.5.2 Testing Optional Components: Manual Control

During testing, and in a service situation, you can switch the climate computer from automatic to manual control. Thus, you can easily test the optional components such as winch motors, heating etc.

3.5.3 Menu for Manual/Auto


Service: Manual/auto	Components	Menu in manual control		
	 Manual/auto	Manual Auto		
	 Climate	 Temperature sensors  Air inlet	 Temperature sensor 1-8  Calibration offset 1-8  Side inlet 1-6  Tunnel inlet 1-2	 Side inlet 1-6 required  Side inlet 1-6 required  Side inlet 1-6 position  Tunnel inlet 1-2 required  Tunnel inlet 1-2 required  Tunnel inlet 1-2 position
		 Air outlet	 Stepless 1  Stepless 2  Side stage fan  Tunnel stage fan  MultiStep  Tunnel MultiStep	 Air outlet required  Air outlet required  Air outlet position  Fan speed control 1  Fan speed control 1  Air outlet required  Air outlet required  Air outlet position  Fan speed control 2  Fan speed control 2  Side stage fan 1 - 16  Side stage fan 1 - 16  Tunnel stage fan 1-16  Tunnel stage fan 1-16  MultiStep 1 - 8  MultiStep 1 - 8  MultiStep 1 - 8  MultiStep 1 - 8

Service: Manual/auto	Components	Menu in manual control		
		Heaters	House heaters	Heater 1 - 6 Heater 1 - 6
			Brooding heaters	Brooding heater 1-4 Brooding heater 1-4
		Humidity sensors	Humidity sensor 1	
			Humidity sensor 2	
		Cooling	Cooling relay 1-2	
		Pad cooling	Pad cooling 1-2	
		Pad sensor		
		Humidification	Humidification relay 1-2	
		Soaking relay		
		Pressure regulator	Sensor signal	
			Actual value	
		CO2 sensor	CO2 sensor	
		Aux. sensors	Aux. sensor 1-4	
	Production	Feed relay		
		Tip weigher impulse		
		Feed demand sensor		
		Cross auger sensor		
		Cross auger relay		
		Electronic silo weigher	Silo 1-2 current value	
			Silo 1-2 tare value	
			Silo 1-2 calibration value	
		Silo 1-2 relay		
		Bird scale 1-2 signal	Voltage	
			Grams	
		Light relay		
		Light dimmer		
		Light dimmer		
		24-hour clock	24-hour clock A-D	
	Info Matic test	Received telegrams		
		Received percentage		

Table 5: Survey of the menu Manual/auto (you can change the values highlighted in bold)

In the **Manual/auto** menu, the Viper climate and production computer shows you the components, which are selected under the **Installation** menu. You must test the components one at a time.

After testing the components, you must set the climate computer back to automatic control so that the computer continues to control as previous



→ The computer indicates when it is set to manual control by letting **MANUAL** flash in the display




When the house is set to manual control, the climate and production computer does not control according to **Temperature setpoint** and **Humidity**, but the alarm function is still active.


3.5.4 Automatic/Manual Control

Normally the computer must be set to automatic control. During start, or in a service situation, it may be convenient to control the individual functions manually.


When you want to... set the computer to manual control, open the **Technical/Service** menu, and



→ select **Manual/auto**, and press



→ select **Man./auto**, and press




→ select **Manual**, and press

3.5.5 Testing Climate Functions


3.5.5.1 Testing Air Intake and Air Outlet

The test is to show whether air intake and air outlet can open and close completely. Air intake and air outlet must be tested in the same way.


When you want to... test air inlet and outlet,
open the **Technical/Service/Manual/Auto** menu, set the computer to **Manual**, and




→ select **Climate**, and press



→ select **Air inlet**, and press



→ select **Side inlet 1**, and press



→ select **Side inlet 1 required**, and press



→ set to 100 %, and when **Yes** is highlighted, press to save the change

→ check that the correct air intakes open completely



→ set to 0 %, and when **Yes** is highlighted, press to save the change

→ check that the correct air inlets close completely

→ set the air intake to the required position

Repeat the test for the installed air inlets and outlets.


3.5.5.2 Testing Stepless Fans

3.5.5.2.1 Testing Setting and Placement of Stepless Fans


The test is to show if the connected stepless fans are set correctly, i.e. if they can run at minimum and maximum velocity, and if they are placed correctly.

With an internal fan speed controller the emergency change-over switch AUT/MAN (automatic/manual) on the side of the Viper must be set to AUT.


When you want to... test maximum revolutions,
open the **Technical/Service/Manuel/Auto/** menu, set the computer to **Manual**, and




→ select **Climate**, and press



→ select **Air outlet**, and press



→ select **Fan A**, and press



→ select **Air outlet required**, and press




→ set to 100 %, and when **Yes** is highlighted, press to save the change

→ check that the fan is placed in the correct house

→ check that the fan is running in the right direction and sucks air out of the house (possibly by means of a smoke test)

→ check that the fan runs at maximum revolutions

When you want to... test minimum revolutions, open the **Technical/Service/Manual/Auto** menu, set the computer to **Manual**, select the **Climate/Air outlet/Stepless 1** menu, and




→ select **Air outlet required**, and press

→ set to 1 %, and when Yes is highlighted, press to save the change

→ check that the fan is running in the right direction and sucks air out of the house (possibly by means of a smoke test)

→ check that the fan is running at minimum revolutions

When you want to... test whether the fan can stop, open the **Technical/Service/Manual/Auto** menu, set the computer to **Manual**, select the **Climate/Air outlet/Stepless 1** menu, and



→ select **Air outlet required**, and press

→ set to 0 %, and when Yes is highlighted, press to save the change

→ check that the fan stops completely


→ If the fans are connected as 3-wire, they should not stop completely, but instead run at minimum speed

Repeat the test for **Stepless 2**.

An external stepless fan speed controller (e.g. MC 23U or MC 37) must be tested in the same way as an internal fan speed controller.

3.5.5.3 Testing Emergency Change-over Switch AUT/MAN

When you want to... test the emergency change-over switch AUT/MAN,



→ set the change-over switch to **MAN** (manual)

→ check that the stepless fan(s) run(s) at maximum revolutions

→ set the change-over switch to **AUT** (automatic)

→ check that the stepless fan(s) reduce(s) the revolutions

Figure 16: AUT/MAN emergency change-over switch on the side of Viper

3.5.5.4 Testing MultiStep®, Tunnel MultiStep®, Side Stagefans and Tunnel Stagefans

The test is to show whether shutters and fans in the chimneys work in relation to each other.


Testing of the eight MultiStep® is to be made in the same way for each step, as you must check the exhaust units individually.

When you want to... test MultiStep®, open the

Technical/Service/Manual/Auto menu, set the computer to **Manual**, select the **Climate/Air outlet** menu, and



→ select **MultiStep**, and press



→ select **MultiStep 1**, and press




→ select **ON**, and press to activate it

→ check that the swivel shutter in the chimneys open completely

→ When the shutter is approx. 15 % open, the MultiStep 1 fan must start at full speed

→ check that the fan sucks air out of the house (possibly by means of a smoke test)



→ select **MultiStep 1**, and press



→ select **OFF**, and press to disconnect

→ check that the swivel shutter in the chimneys closes again

→ When the shutter is less than approx. 15 % open, the fan must stop

Repeat the above procedure for each MultiStep® and for each stagefan.

3.5.5.5 Testing Heating


This section is only relevant to houses where heating is installed.

The test is to show whether the heating systems can connect and disconnect.


The test of the systems takes place in the same way, as every system must be checked individually.

When you want to... test the heating system, open the


Technical/Service/Manual/Auto menu, set the computer to **Manual**, select the **Climate/Heaters** menu, and



→ select **House heaters**, and press




→ select **Heater 1**, and press




→ set to 0 %, and when **Yes** is highlighted, press to save the change

→ check that heat source 1 does not supply heating



→ select **Heater 1**, and press



→ set to 100 %, and when **Yes** is highlighted, press to save the change

→ check that heat source 1 supplies heating constantly

Repeat the procedure for each system to check that it can connect and disconnect heating.

3.5.5.6 Testing Relay for Cooling, PAD-cooling, Humidification, Soaking and 24-hour Clock


This section is only relevant to houses where the concerned systems are installed.

The test is to show whether the systems can start and stop.

The test of the systems takes place in the same way as every system must be checked individually.


When you want to... test a system, open the

Technical/Service/Manual/Auto menu, set the computer to **Manual**, select the **Climate/e.g. Cooling** menu, and



→ select **Cooling relay 1**, and press to connect it

→ check that the system (cooling) is on



→ select the system (**Cooling relay 1**) to disconnect it

→ check that the system (cooling) is off


Repeat the procedure for each system to check that it can start and stop.

3.5.6 Testing Production Functions


3.5.6.1 Testing Feed Relay, Silo Relay, Light Relay and 24-hour Clock

When you want to... test a system, open the

Technical/Service/Manual/Auto menu, set the computer to **Manual**, select the **Production/Feed relay** menu, and




→ select **Production**, and press



→ select **Feed relay**, and press to connect it

→ check that the system is on




- select the system (**Feed relay**) to disconnect it
- check that the system is off


Repeat the procedure for each system to check that it can start and stop.

3.5.6.2 Testing the Bird Scales

When you want to... test the bird scales, open the **Technical/Service/Manual/Auto** menu, set the computer to **Manual**, select the **Production/Bird scale 1 signal** menu, and



- select **Bird scale 1 signal**, and press




- read the voltage and check the value in the table

Bird scales	
5 kg	0 kg = 0.5 V 5 kg = 10.0 V
10 kg	0 kg = 0.5 V 10 kg = 10.0 V
30 kg	0 kg = 0.5 V 30 kg = 10.0 V


Repeat the test procedure for **Bird scale 2 signal**.

3.5.6.3 Testing the Electronic Silo Weigher

When you want to... test the silo weigher, open the **Technical/Service/Manual/Auto** menu, set the computer to **Manual**, select the **Production** menu, and



- select **Electronic silo weigher**, and press




- read the values to check whether the weigher is connected and calibrated
- If **Silo current value** shows a value that is higher than 0, the weigher is connected.
- If **Silo tare value** and **Silo calibration value** are both 0, the silo weigher has not been calibrated. If the silo weigher has not been calibrated, the **Silo current value** will always be 0.000 t.
- See section 3.2.5.1 Calibration of Weighing .



3.5.6.4 Testing the Tip Weigher

When you want to... test the tip weigher, open the **Technical/Service/Manual/Auto** menu, set the computer to **Manual**, select the **Production/Tip weigher impulse** menu, and



→ read the voltage and check the feedback switch on the tip weigher


The feedback switch is operated manually on the tip weigher; check the voltage at the same time.

10 kg = 0.0 V

0 kg = 10.0 V

3.5.6.5 Testing the Feed Demand Sensor and Cross Auger Sensor

When you want to... test the feed demand sensor, open the **Technical/Service/Manual/Auto** menu, set the computer to **Manual**, select the **Production/Feed demand sensor** menu, and



→ select **Feed demand sensor**, and press

→ read the voltage and check the value

Feed demand sensor: 0.0 V = feed demand


10.0 V = no feed demand

Repeat the test procedure for **Cross auger sensor**. The values are the same as for the cross auger sensor.

3.5.6.6 Testing the Light Dimmer

The test is to show whether the connected light dimmer can increase and reduce the light intensity.

When you want to... test the light dimmer, open the **Technical/Service/Manual/Auto/** menu, set the computer to **Manual**, select the **Production/Light dimmer** menu, and




→ select **Light dimmer**, and press



→ set to 10.0 V, and when **Yes** is highlighted, press to save the change

→ check for maximum light in the house



→ select **Light dimmer**, and press




→ set to 1.0 V, and when **Yes** is highlighted, press to save the change


→ check that the light is dimmed in the house

3.5.7 End of Component Testing

When you want to... set Viper back to automatic control, open the **Technical/Service** menu, and



→ select **Manual/auto**, and press


















































→ select **Manual/auto**, and press



→ select **Auto**, and when **Yes** is highlighted, press to save the change

3.6 System Setting

3.6.1 Menu for System Setting

Service: Setting		Menu items	Options under the individual menu items	
	 Climate	 Air output	 Output in m ³ /h*1000  Nominal  Stepless 1-2  MultiStep 1 - 8  MultiStep tunnel 1 - 8  Side stage 1 - 16  Tunnel stage 1 -16 <input type="checkbox"/> Rotate  Max. output	0 – 999,900 m ³ /h 0 – 999,900 m ³ /h 0 – 999,900 m ³ /h 0 – 999,900 m ³ /h 0 – 999,900 m ³ /h 0 – 999,900 m ³ /h
		 Calibration	 Calibrate side inlet 1 - 6  Calibrate tunnel inlet 1-2  Calibrate air outlet 1-2	 Side inlet 1  Calibration  Tunnel inlet 1  Calibration  Air outlet 1  Calibration
		 Ventilation	 Max. flap  Outs. temp. limit  Gradual limit	0 – 100 % 0 – 100 °C 0 – 100 °C
		 Fan speed controller	 Power supply  Wire type  Min. voltage  Max. voltage	200 210 220 230 240 2-wire 3-wire 0 – 10 V 0 - 10 V
		 Heating	 Heaters  Brooding heaters	 Pre runtime  Adjust analog heater  Pre runtime  Adjust analog heater
		 Cooling	 Cooling mode  Cooling 1/2 ratio	Sequential Parallel 2 - 98
		 Pad cooling	 Pad cooling mode with 2 pumps  Pump 1/2 ratio	Sequential Parallel 1 - 99
		 Humidification	 Humidification mode  Humidifier 1/2 ratio	Sequential Parallel 0 -100 %
		 Pressure control	 Min. voltage	0 – 10 V

Service: Setting		Menu items	Options under the individual menu items	
			Max. voltage	0 – 10 V
			Min. value	-200 – 200 Pa
			Max. value	-200 – 200 Pa
		Adjust CO2 sensor	Min. voltage	0 – 10 V
			Max. voltage	0 – 10 V
			Min. value	0 – 30000 ppm
			Max. value	0 – 30000 ppm
		Adjust aux. sensors	Aux. sensor 1-4	Min. voltage
				Max. voltage
				Min. value
				Max. value
		Night setback	<input type="checkbox"/> Night setback	
			Adaptation period	01:00
			Return period	00:30
		Bird scale 1 - 2setup	Search limit	0 – 50 %
			Min. voltage	0 – 10 V
			Max. voltage	0 – 10 V
			Min. value	0 – 30000
			Max. value	0 – 30000
		Silo	Silo 1-2 calibrate	0.1000 – 1000.000 t
			Silo 1-2 offset	-10.000 – 10.000 t
		Light dimmer	Time for dawn	00:24
			Time for dusk	00:24
			Light dimmer voltage at 0 %	0 – 10 V
			Light dimmer voltage at 20 %	0 – 10 V
			Light dimmer voltage at 40 %	0 – 10 V
			Light dimmer voltage at 60 %	0 – 10 V
			Light dimmer voltage at 80 %	0 – 10 V
			Light dimmer voltage at 100 %	0 – 10 V
		Network address	0 - 250	
		System codes	Read+write access	
			Read access	
		Baud rate	1200	
			2400	
			4800	
			9600	
			19200	
			38400	

Table 6: Survey of the setting menu (you can change the values highlighted in bold)



3.6.2 Climate

3.6.2.1 Setting of Exhaustion (MultiStep®)

MultiStep® is a method for controlling one or more exhaust units in steps, so that the exhaustion becomes stepless. The computer controls one or two exhaust units stepless from zero to 100 %, while the rest of the exhaust units are switched on in steps as required.


Every exhaust unit is equipped with a CL 74A winch motor, which can open and close the swivel shutter.

The CL 74AV is used for the stepless exhaust unit(s). The internal fan speed controller in the Viper climate and production computer or an external fan speed controller controls the fan revolutions. The fan must always be single-phase, or else an external MC 23U must be used.

CL 74A ON/OFF is used for the other exhaust units. When the shutters open, the fans start via an integrated switch. These fans will then run at their maximum. The fans can be single-phase or three-phase. If three-phase fans are used, the CL 74A ON/OFF winch motors must be equipped with contactors, which are controlled by an integrated switch.

The system can also handle an air-operated shutter (gable fan).


Example 1: MultiStep® exhaustion




In order to obtain correct adjustment of the house climate with MultiStep® you must adjust the climate computer using the ventilation system data:

- 1) Nominal air output of the system in m³/h (air requirement of the animals)
- 2) Exhaustion capacity of the stepless exhaust unit(s)
- 3) Exhaustion capacity of the various steps, MultiStep® 1-8


When you want to... adjust the exhaustion,
open the **Technical/Service** menu, and




→ select **Setting**, and press




→ select **Climate**, and press



→ select **Air output**, and press




→ select **Nominal**, and press



→ set a value, and when **Yes** is highlighted, press to save the change

Stepless, **MultiStep**, **MultiStep tunnel**, **Side stage** and **Tunnel stage** should be set in the same way.

When you want to... connect and disconnect the rotate function, open the **Technical/Service/Setting/Climate/Air output** menu, and



→ select **Rotate**, and when **Yes** is highlighted, press to save the change

The rotate function makes it possible to switch between fans with the same output.

Max. output is the max. output in percentage of the ventilation system.


3.6.2.2 Calibration of Air Intake and Air Outlet

After installation, the Viper must be adapted to the winch motor. During this automatic calibration, the shutters are opened briefly and shut completely.


When the air inlets or air outlets are analog controlled, you can adjust the output voltage via Min. voltage and Max. voltage.

With a CL 75A winch motor, the change-over switch on the winch motor must be set to AUT.


When you want to... calibrate air intake and air outlet,
open the **Technical/Service/Setting/Climate** menu, and




→ select **Calibration**, and press



→ select **Calibrate side inlet 1**, and press



→ select **Calibration**, and press



→ select **Ongoing**, and press to start calibration

→ check for proper opening and closing of the correct outlet(s)

1) Wait until the calibration is finished and the display shows **Calibration ended** again


2) Carry out the calibration in the same way for air intake B and air outlets A and B

3.6.2.3 Calibration of Tunnel Air Intake and Tunnel Air Outlet

The tunnel air intake and the tunnel air outlet are calibrated in the same way as air intake and air outlet.




3.6.2.4 Setting of Ventilation

Ventilation	Display shows		Function explanation
	Max. flap	100 %	The maximum opening of the air intake as long as the outside temperature is below outside temperature limitation (15 °C)
	Outs. temp. limit	15 °C	Below this outside temperature, the flaps will not open more than Maximum flap
	Gradual limit	5 °C	Temperature area (P-band) where the limitation is switched on


3.6.2.5 Setting of Fan with Internal Fan Speed Controller

With an internal fan speed controller, it is necessary to enter the typical voltage of the mains supply to obtain the correct control of the fan. Measure the voltage by means of a voltmeter or possibly contact an electrician.

Internal fan speed controller	Display shows		Function explanation
	Power supply	200 210 220 230 240	Enter the typical mains supply voltage to obtain correct control of the fan.
	Wire type	2-wire 3-wire	Enter the type of wire to be used.







3.6.2.6 Setting of Fan with External Fan Speed Controller

When the fan is regulated by an external fan speed controller, a minimum and a maximum voltage are set depending on which type of fan speed controller it concerns.








External fan speed controller	Display shows		Function explanation
	Min. voltage	0.0 V	Voltage at 0 % fan output.
	Max. voltage	10.0 V	Voltage at 100 % fan output.









3.6.2.7 Setting of Heating

Heat	Display shows		Function explanation
 Climate  Ventilation  Heating  Cooling  PAD cooling  Humidification	Box heaters		
	Pre runtime	0 s	Time from the heating relay is picked up till heating is physically supplied (flush time)
	Adjust analog heater		
	Min. voltage	3.0 V	At heating requirement, the analog voltage will never be lower than Min. voltage
	Max. voltage	7.5 V	The heating shunt works at maximum output at this voltage
	Brooding heaters		
	Pre runtime	0 s	Time from the heating relay is picked up till heating is physically supplied (flush time)
	Adjust analog heater		
	Min. voltage	3.0 V	At heating requirement, the analog voltage will never be lower than Min. voltage
	Max. voltage	7.5 V	The heating shunt works at maximum output at this voltage







3.6.2.8 Setting of Cooling

Cooling	Display shows		Function explanation
 Climate  Air output  Calibration  Ventilation  Heating  Cooling  Pressure control	Cooling mode	Sequential Parallel	If there are more cooling pumps, they can be set to running either sequentially or in parallel.
	Cooling 1/2 ratio	50	The distribution between two cooling pumps running sequentially.


3.6.2.9 Setting of PAD Cooling

PAD cooling	Display shows		Function explanation
 Climate  Ventilation  Heating  Cooling  PAD cooling  Humidification	PAD cooling mode with 2 pumps	Sequential Parallel	If there are more cooling pumps, they can be set to running either sequentially or in parallel.
	Pump 1/2 ratio	50	The distribution between two cooling pumps running sequentially.


3.6.2.10 Setting of Humidification

Humidification	Display shows		Function explanation
 Climate  Ventilation  Heating  Cooling  PAD cooling  Humidification	Humidification mode	Sequential Parallel	If there are more humidifiers, they can be set to running either sequentially or in parallel.
	Humidifier 1/2 ratio	50	The distribution between two humidifiers running sequentially.


3.6.2.11 Setting of Pressure Control

Pressure control	Display shows	Function explanation
	Min. voltage 1.0 V	The menu defines the pressure sensor. Enter a voltage for the min. value of the sensor.
	Max. voltage 10.0 V	Enter a value for the max. value of the sensor.
	Min. value 10 Pa	The lowest measured value.
	Max. value 100 Pa	The highest measured value.

3.6.2.12 Adjustment of CO₂ sensor


CO ₂ sensor	Display shows	Function explanation
	Min. voltage 0.0 V	When a sensor is analog controlled, you can adjust the voltage. Enter a voltage for the min. value of the sensor.
	Max. voltage 10.0 V	Enter a value for the max. value of the sensor.
	Min. value 0 ppm	The lowest measured value.
	Max. value 10000 ppm	The highest measured value.

3.6.2.13 Adjustment of Auxiliary Sensor

Auxiliary sensor	Display shows	Function explanation
	Min. voltage 1.0 V	When a sensor is analog controlled, you can adjust the output voltage via Min. voltage and Max. voltage.
	Max. voltage 9.0 V	
	Min. value 1000 ppm	When a Min. value and a Max. value are set, you should also indicate the range within which the sensor can measure
	Max. value 9000 ppm	

The units for **Min. value** and **Max. value** will depend on which auxiliary sensors have been selected. Besides ppm, the units can be Pa, °C, % and m/s.

3.6.2.14 Setting of Night Setback

Night setback	Display shows	Function explanation
	Adaption period 01:00	P-band. When the function is activated, the temperature setback will be reached after this period.
	Return period 00:30	P-band. When the function is ended, the temperature setback will be ended after this period.

3.6.3 Production

3.6.3.1 Setting of Bird Scales

Bird scales	Display shows		Function explanation
Production ..Return Bird scale 1 setup Bird scale 2 setup Silo Light dimmer	Search limit	30 %	The search limit is an accepted deviation. The search limit is used to sort out incorrect weighings, for example when two animals are standing on the scales at the same time.
	Min. voltage	0.500 V	The menu defines the scales. Two values are entered at two voltages. Voltage/signal at 0 kg. Voltage/signal at max. weight
	Max. voltage	10.000 V	
	Min. value	0 g	Lowest registration of the weigher
	Max. value	5000 g	Highest registration/load of the weigher.






3.6.3.2 Setting of Silo Calibration

Silo calibration	Display shows		Function explanation
Production 1 or 2 types of animals Mixed animals Bird scale 1 setup Bird scale 2 setup Silo	Silo 1 calibrate	10.0000 t	Indicates the number of tonnes at which the silo is calibrated.
	Silo 1 offset	0.000 t	It is possible to make an offset so that the current indication from the silo is correct (tare weight of the silo).
	Silo 2 calibrate	10.0000 t	Indicates the number of tonnes at which the silo is calibrated.
	Silo 2 offset	0.000 t	It is possible to make an offset so that the current indication from the silo is correct (tare weight of the silo).

3.6.3.3 Setting of Light Dimmer

Light dimmer	Display shows		Function explanation
Production Bird scale 1 setup Bird scale 2 setup Silo calibrate 0.001 Light dimmer	Time for dawn	00:20	The time for dawn indicates the period where the light is changed from "Day" to "Night".
	Time for dusk	00:20	
	Light dimmer voltage at 0 %	0.0 V	Defines the mode of the light dimmer in relation to the light intensity. Indicates how to activate the light dimmer
	Light dimmer voltage at 20 %	2.0 V	
	Light dimmer voltage at 40 %	4.0 V	
	Light dimmer voltage at 60 %	6.0 V	
	Light dimmer voltage at 80 %	8.0 V	
	Light dimmer voltage at 100 %	10.0 V	

3.6.4 Info Matic

Info Matic	Display shows		Function explanation
 Setting  .. Return  Climate  Production  Info Matic	Network address	0	<p>Control code on the data network. Climate computers in different houses must have alternative network addresses</p> <p>The network address can be set from 1 to 249. It is recommended to use the lowest possible addresses</p>
	System codes	Read+write access	<p>Read and write access: Full access</p> <p>When a PC is connected to the climate computer, the computer executes an access control. The PC must have "full access" or just "read access"</p> <p>If a modem is connected to the data network, the system codes for access control must always be entered. In this way, it is ensured that only authorized personnel can call the computer. If a modem is not connected, the system codes / passwords can be 0 both in the climate computer and in the PC</p> <p>Full access can be obtained when the PC has the same system code / password as the code for full access in the climate computer. The code is a four-digit number (value: 0-9999)</p>
		Read access	<p>Read access: Read access only</p> <p>Read access can be obtained when the PC has the same system code / password as the code for read access in the climate computer. The code is a four-digit number (value: 0-9999)</p>
	Baud rate	1200 2400 4800 9600 19200 38400	<p>The speed with which the computers transfer data.</p> <p>The climate computer must have the same baud rate as all the other computers on the data network</p> <p>The setting for Euro Matic and Uni Matic house computers must be 2400 baud</p>

3.7 Memory

3.7.1 Menu for Memory


Service: Memory	Menu items	Options under the individual menu items
	! Operation log	Value 74 Time 2004.09.23 09:05 Now 12.0 Previous 10.0 Editor 0
	CF-card	Program upload Copy to CF-card Copy from CF-card Delete on CF-card Save alarm log Save operation log Save present setup
	! Default deviation	

Table 7: Survey of memory menu (you can change the values highlighted in bold)


3.7.1.1 Operation Log

The operation log saves the latest 35 changes of settings and the time of the change.

When you want to... read the operation log,
open the **Technical/Service/Memory** menu, and



→ select **Operation log**, and press



→ scroll to see changes

→ press to return to the menu

When all 35 storage locations are used, the oldest change will disappear.

3.7.1.2 Compact Flash Card

When using a CF-card it is possible to copy the current setting of the computer to a CF-card. This makes it possible partly to save a backup copy of the setup, partly to copy the setup to other climate computers. It is also possible to save data from a CF-card in the computer. The **Program upload** function enables you to update the computer program while all settings are maintained.

When you want to... insert a CF-card, you must

- 1) Dismount the front panel by loosening the front panel screws
- 2) Tilt the front panel outwards and insert the CF-card at the top of the CPU on the rear of the front panel






Figure 17: Insertion of CF-card

If you want to remove the CF-card again immediately after operation, you can place the “loosened” front panel on top of the cabinet by screwing the bottom front panel screws into the top screw holes of the cabinet while operating the computer.


When you want to... save data on or retrieve data from a CF-card, open the **Technical/Service/Memory** menu, and



→ select **CF-card**, and press



→ select the required menu item (**Program upload/Copy to CF-card/Copy from CF-card/Delete on CF-card/Save alarm log/Save operation log/Save present setup**), and press




→ select the required file, and press

3.7.1.3 Default Deviation

Under **Default deviation**, you can read out the changes that have been made compared to the default values.

When you want to... read the default deviation,
open the **Technical/Service/Memory** menu, and



→ select **Default deviation**, and press
















































→ scroll to see more items

→ press to return to the menu

3.8 Control Parameters


3.8.1 Menu for Control Parameters

Service: Control parameters		Menu items	Settings	
	 Climate	 Ventilation	 Winter factor	0.1 – 1.0
		 Flex mode	<input type="checkbox"/> Cycle inlets  Open delay  Close delay	
		 Inlets without feedback	 Inlet running time  Tunnel inlet running time  Calibration count  Tunnel calibration count  Stop fans if inlet 1-6 below  Stop fans if tunnel inlet 1-2 below  Inlet 1 – 6 dead band  Tunnel inlet 1 - 2 dead band	30.0 – 1800.0 30.0 – 1800.0 5.0 – 99.0 5.0 – 99.0 0.0 – 50.0 0.0 – 50.0 1.0 – 20.0 1.0 – 20.0
		 Winter compensation	<input type="checkbox"/> Activate  Adjustment	1.00 – 2.00
		 Cycle time ventilation	 Stop modulation <input type="checkbox"/> Air inlet modulation  Cycle time  Min. ON-/OFF time  Air inlet delay	0 - 500 0 - 1000 0 - 1000  Air inlet open delay 0 s  Air inlet open delay -10 s
		 Comfort	 Start ventilation  Max. ventilation	0.0 – 0.1 0 - 200
		 Heating	 Heaters  Brooding heaters	 Cycle time  Min. run-time  Min. OFF-time  Cycle time  Min. run-time  Min. OFF-time
		 Pad cooling	<input type="checkbox"/> Cycle timer  Cycle time  Min. ON-time  Pre run-time	0 – 100 min 0 - 300 0 - 60
		 Humidity control	 Max. humidity vent.  Max. temperature reduc.	0 - 100 s -9.0 – 0.0s
		 Humidification	 Cycle time	180 s.


Service: Control parameters		Menu items	Settings	
			Min. run-time	10 s.
		Pressure control	Sample rate	10 – 1200 s
			Accept band	0 – 20 Pa
			Delta demand	0 – 20
		CO2 regulator	P-band	0 – 50000 ppm
			Int. time	0 – 99 min

Table 8: Survey of control parameters


3.8.1.1 Ventilation

Ventilation	Display shows	Function explanation
	Winter factor 0,7	The increase is gradually limited with this factor under winter conditions. Factor 1 gives no limitation. Factor 0.5 halves the increase.


3.8.1.2 Flex Mode

Flex mode	Display shows	Function explanation
	Cycle inlets Open delay Close delay	Connection and disconnection of cycle on the air inlets. Delayed opening of air inlets at Cycle time in Flex mode. Delayed closing of air inlets at Cycle time in Flex mode.

3.8.1.3 Air Intake

Air Intake	Display shows	Function explanation
	Inlet running time 60 s Tunnel inlet running time 60 s Calibration count 20 Tunnel calibration count 20 Stop fans if inlet 1 - 6 below 0 % Stop fans if tunnel inlet 1 - 2 below 0 % Inlet 1 – 6 dead band 10 % Tunnel inlet 1 – 2 dead band 10 %	The running time of the inlet. The running time of the tunnel inlet. Shows the number of changes of the flap opening that is allowed between fully open or closed position. During calibration, the flap goes to either fully open or closed position and thereafter it goes to the current position. In houses with curtain openings, it can be difficult to change the curtain position due to the negative pressure when the fans run. It is possible to stop the fans temporarily while the curtain run at smaller curtain openings that stated here. Side inlet dead band. Tunnel inlet dead band.

3.8.1.4 Winter Compensation

Winter compensation	Display shows	Function explanation
	Winter comp. OFF	The function can be connected and disconnected.
	Winter comp. 1.2 The menu is only visible when Winter comp. is ON.	The factor is multiplied by the values, which are entered under exhaustion in the adjustment of negative pressure. When the factor is set to 1.0, there is no winter compensation.


The winter compensation factor makes it possible to increase the negative pressure during cold periods and thus avoid a down draught in the house. The increase happens gradually from a warm to a cold period.

If, for example, you set the factor to 1.5, the computer increases the negative pressure by max. 50 % under winter conditions.

The increase of the negative pressure goes down gradually from zero to 35 % air output. From 35 to 100 % air output the winter compensation is inactive.


The function should be used with caution.

3.8.1.5 Cycle Time

Cycle time	Display shows	Function explanation
	Stop intake modulation 30 %	If the exhaustion requirement exceeds the value for Stop intake modulation the time modulation is stopped and the closest MultiStep-step runs constantly
	Air intake modulation ON	Decides if air intake should be modulated at the same time ON: Modulation on air intake OFF: Air intake runs stepless
	Cycle time 300 s	The total running time for steps, which modulate (ON + OFF time) or with Cycle Time
	Min. ON-/OFF time 30 s	When a step is activated, it will be ON/OFF for at least this time. ON/OFF with Cycle Time
	Air inlet delay Air intake open delay 0 s	Delay opening of air intake with Cycle Time
	Air intake close delay - 10 s	Delay closing of air intake with Cycle Time

The objective of the Cycle Time function is to enable the control of air currents in the house at a very limited ventilation requirement. The function opens and closes the air inlets alternately thus sending a more powerful air current through the house. This ensures a thorough change of the house air.

Example 2: Cycle time



When the ventilation requirement becomes higher than what the Cycle Time function can perform, the Viper controls the ventilation again in relation to inside temperature and air humidity.


3.8.1.6 Comfort

Comfort	Display shows		Function explanation
Climate ..Return Ventilation Winter comp. Cycle time Comfort	Start ventilation	50 %	Ventilation degree at which comfort is activated
	Max. ventilation	100 %	Ventilation degree at which maximum Comfort temperature is reached


3.8.1.7 Heating

Heating	Display shows		Function explanation
Climate Inlets without feedback Winter compensation Cycle time ventilation Comfort Heating	Heaters		
	Cycle time	180 s	ON + OFF time of the heating relay
	Min. run time	10 s	At heating requirement: The heating relay is ON for minimum this time.
	Min. OFF time	6 s	When the heating relay is released, it is OFF for minimum this time.
	Brooding heaters		
	Cycle time	180 s	ON + OFF time of the heating relay
	Min. run time	10 s	At heating requirement: The heating relay is ON for minimum this time.
	Min. OFF time	6 s	When the heating relay is released, it is OFF for minimum this time.


3.8.1.8 PAD Cooling

PAD cooling	Display shows		Function explanation
	Cycle time	10 min	ON- + OFF time of the cooling relay.
	Min. ON time	60 s	At cooling requirement: The cooling relay is ON for minimum this time.
	Pre runtime	0 s	Time from the cooling relay is picked up until cooling is physically added (flush time).


3.8.1.9 Humidity Control

Humidity control	Display shows		Function explanation
	Max. humidity vent.	35 %	Ventilation degree at which humidity ventilation is stopped
	Max. temperature reduc.	- 2.0 °C	Maximum reduction from Temperature setpoint when humidity ventilation is used


3.8.1.10 Humidification

Humidification	Display shows		Function explanation
	Cycle time	180 s	ON + OFF time of the humidification relay.
	Min. runtime	10 s	The humidification relay is picked up for at least this time.

3.8.1.11 Pressure Control

Pressure control	Display shows		Function explanation
	Sample rate	180 sek.	Sample rate indicates how often a new calculation is to be made.
	Acceptband	2 Pa	When the pressure is within this range, the requirement is not changed, i.e. no new calculation is made.
	Delta demand	2.5	Requirement changes if the pressure is outside the acceptband.

3.8.1.12 CO₂ Regulator

CO ₂ regulator	Display shows		Function explanation
	P-band	50000 ppm	Working range for CO ₂ regulator.
	Int. time	30 min.	Integration time for CO ₂ regulator.



3.9 Adjustment of Negative Pressure and Stepless Units










Service:	Menu items	Settings			
	 Adjust negative pressure	 Adjust LPV curve	Output	Side	Tunnel
			0.0	0.0	0.0
			1.0	5.0	0.0
			8.0	10.0	0.0
			16.0	15.0	0.0
			20.0	27.0	0.0
			28.0	33.0	0.0
			50.0	50.0	0.0
			60.0	60.0	0.0
			90.0	90.0	0.0
		100.0	100.0	0.0	
		 Adjust tunnel curve	Speed	Side	Tunnel
			0.6	0.0	20.0
			0.8	0.0	30.0
			1.0	0.0	40.0
			1.2	0.0	50.0
			1.4	0.0	60.0
			1.6	0.0	70.0
			1.8	0.0	80.0
			2.0	0.0	90.0
			2.3	0.0	100.0
		2.5	0.0	100.0	
		 Side pressure curve	Output	Press.	
			0.0	0.0	
			1.0	25.0	
			8.0	35.0	
			16.0	30.0	
			20.0	25.0	
			28.0	25.0	
			50.0	20.0	
			60.0	20.0	
			90.0	20.0	
		100.0	20.0		
		 Tunnel pressure curve	Speed	Press.	
			0.6	0.0	
			0.8	25.0	
			1.0	35.0	
			1.2	30.0	
			1.4	25.0	
			1.6	25.0	
			1.8	20.0	
			2.0	20.0	
			2.3	20.0	
		2.5	20.0		
		 Adjust point	0 - 10		
		 Minimum air inlet	0 - 100		
		 Adjust stepless 1		Fan A	Capac.
0.0	0.0			0.0	
58.0	15.0			32.0	
58.0	25.0			41.0	
54.0	45.0			58.0	
55.0	55.0			66.0	
55.0	85.0			86.0	
100.0	90.0			85.0	
100.0	100.0			100.0	
 Adjust stepless 2		Fan B	Capac.	Flap	
		0.0	0.0	0.0	
		58.0	15.0	32.0	
		58.0	25.0	41.0	
		54.0	45.0	58.0	
		55.0	55.0	66.0	
		55.0	85.0	86.0	
		100.0	90.0	85.0	
		100.0	100.0	100.0	


Table 9: Survey of menus for adjustment of negative pressure and stepless units

There are ten available curve points for adjustment of negative pressure.

To begin with you must select the curve point that you wish to set, and thereafter you must first set the flap opening of the air intake (air 1 and 2), which can be regulated from 0 to 100 %. Then you can set the required exhaustion as a percentage of the nominal output.

Thus, both exhaustion and air intake are adjustable at each curve point.


Example 3: Adjustment of negative pressure 1: Inlet 1 and 2 (flap opening)




Depending on the type of winch motor utilised this negative pressure curve will be ideal for a given system.

When the Cycle Time function is used, it is the position of air intake 1, which is entered as minimum air intake.


When you want to... adjust the negative pressure,
open the **Technical/Service** menu, and



→ select **Adjust negative pressure**, and press




→ select **Side**, and press



→ select **Adjust point**, and press



- select the required curve point, and press
- when **Yes** is highlighted, press to save the change




- select **Adjust LPV curve**, and press

Adjust LPV curve		
Output	Side	Tunnel
0.0	0.0	0.0
1.0	5.0	0.0
8.0	10.0	0.0
16.0	15.0	0.0


- three vertical number series show you the curve values for **Output**, **Side** and **Tunnel**, respectively.
- select the value that you want to change, and press




- press to change the setting, and press to return

- press  to return to the **Adjust LPV curve** menu

Change the curve values for **tunnel**, **side pressure** and **tunnel pressure** in the same way.




- select **Minimum air inlet**, and press



- set the required value

Example 4: Adjustment of negative pressure 2: Air outlet

Exhaust. %	Inlet 1	Inlet 2
0	0	0
4	5	5
8	10	10
20	27	27
28	33	33
50	50	50
60	60	60
80	80	80
90	90	90
100	100	100



To obtain this negative pressure curve the relation between exhaustion and inlet 1 and 2 (flap opening of the air intake) could be as follows.

When the Cycle Time function is used, it is the position of air intake 1, which is entered as minimum air intake.


3.9.1 Adjustment of Stepless 1 and 2

The adjustment of the stepless units is important to make the computer ascertain the correct relation, and thus the correct ventilation output between the fan voltage and flap opening of the air outlet. This is also important to maintain the pressure stability.


Example 5: Adjustment of stepless unit

Fan voltage % (*)	Stepless output %	Flap opening % (*)
0	0	0
68	10	23
52	20	34
36	30	48
36	70	83
62	80	84
100	90	84
100	100	100

(*) This information may be obtained from the fan manufacturer. You can also measure it



When you want to... adjust the exhaust output of the stepless units, open the **Technical/Service** menu, and




→ select **Adjust stepless 1**, and press

→ three vertical number series show you the curve values for **Fan A**, **Capac.**, **Flap**, respectively

→ select the curve point that you want to change, and press

→ change the setting, and press to return

→ press  to return to the **Adjust stepless 1** menu

4 TROUBLE SHOOTING INSTRUCTIONS

- 1) Is there 230 V current on terminals A1+ A3 (if not, check installation fuses and fault current relay)
- 2) Is the change-over switch of the fan speed controller MAN/AUT set on AUT?
- 3) Is the computer set to automatic control?
- 4) Are the temperature sensors OK?
- 5) Is the motor relay/switch of the fan OK?
- 6) Is the source of heating and its supply OK?
- 7) Is the winch motor and its change-over switches OK?
- 8) Is the electrical connection of the winch motors correct? See the electrical diagrams; please pay extra attention to the supply voltage via the relays
- 9) Is the potentiometer of the winch motor adjusted?
- 10) Is the computer installed correctly?

4.1 Temperature Sensor Control Table


Temp.		DOL 12	Volt
°C	°F	kOhm	V
- 10	14,0	44,02	7,12
- 9	15,8	42,80	7,06
- 8	17,6	41,61	7,00
- 7	19,4	40,43	6,94
- 6	21,2	39,28	6,88
- 5	23,0	38,15	6,82
- 4	24,8	37,05	6,75
- 3	26,6	35,96	6,69
- 2	28,4	34,91	6,62
- 1	30,2	33,87	6,56
0	32,0	32,86	6,49
1	33,8	31,88	6,42
2	35,6	30,92	6,35
3	37,4	29,99	6,28
4	39,2	29,08	6,20
5	41,0	28,20	6,13
6	42,8	27,34	6,06

Temp.		DOL 12	Volt
°C	°F	kOhm	V
7	44,6	26,51	5,98
8	46,4	25,70	5,91
9	48,2	24,91	5,83
10	50,0	24,15	5,76
11	51,8	23,42	5,68
12	53,6	22,70	5,61
13	55,4	22,01	5,53
14	57,2	21,35	5,45
15	59,0	20,70	5,38
16	60,8	20,08	5,30
17	62,6	19,47	5,22
18	64,4	18,89	5,15
19	66,2	18,33	5,07
20	68,0	17,78	5,00
21	69,8	17,26	4,92
22	71,6	16,75	4,85
23	73,4	16,26	4,77

Temp.		DOL 12	Volt
°C	°F	kOhm	V
24	75,2	15,79	4,70
25	77,0	15,34	4,63
26	78,8	14,90	4,56
27	80,6	14,48	4,49
28	82,4	14,07	4,41
29	84,2	13,68	4,35
30	86,0	13,30	4,28
31	87,8	12,94	4,21
32	89,6	12,58	4,14
33	91,4	12,25	4,08
34	93,2	11,92	4,01
35	95,0	11,61	3,95
36	96,8	11,31	3,88
37	98,6	11,01	3,82
38	100,4	10,73	3,76
39	102,2	10,46	3,70
40	104,0	10,21	3,64

5 SPARE PARTS


Viper Climate/Production Computer



134936 Viper CPU module incl. display

BD no. 61-00-0219

Spare part for alle Viper models.



134933 Basic module 10RL MK2

BD no. 60-43-4901


Spare part for:

135622 Viper 2330 EN

135623 Viper 1520 EN

135635 Viper 2330 flex EN

135636 Viper 1520 flex EN



134714 I/O module 10RL 8AI 8AO, type 3


Spare part for:

135622 Viper 2330 EN

135623 Viper 1520 EN

135635 Viper 2330 flex EN

135636 Viper 1520 flex EN



134943 Basic module 0RL MK2

BD no. 61-00-0213


Spare part for:

135629 Viper 2300 EN

135630 Viper 1500 EN

135633 Viper 2300 flex EN

135634 Viper 1500 flex EN



135701 I/O module 0RL 8AI 8AO, type 4

BD no. 61-00-0212

Spare part for:


135629 Viper 2300 EN

135630 Viper 1500 EN

135633 Viper 2300 flex EN

135634 Viper 1500 flex EN

Viper Climate/Production Computer




134701 DOL 234 power supply 24 V 1A

Spare part for:

135623 Viper 1520 EN

135636 Viper 1520 flex EN



135703 DOL 339 power supply 24 V 3A

BD no. 61-00-0210

Spare part for:

135622 Viper 2330 EN

135629 Viper 2300 EN

135630 Viper 1500 EN

135633 Viper 2300 flex EN


135634 Viper 1500 flex EN

135635 Viper 2330 flex EN




347330 Keyboard foil ViperCompu 264x330mm

Spare part for all Viper models.



134729 4 screws f. top part - front

Spare part for all Viper models.



134702 DOL 234/339 speed controller 6.8A

Spare part for:

135622 Viper 2330 EN

135623 Viper 1520 EN



280008 Fuse 5x20 mm. T8A

BD no. 60-42-0008

Spare part for all Viper models.

Viper Climate/Production Computer



132233 Euro Matic data net module

BD no. 60-40-2233

Spare part for all Viper models.



313035 Flat cable 5cm 10p Gold DOL 440 switch-sw

Spare part for:

135623 Viper 1520 EN



313037 Flat cable 49.5cm 10p Viper switch

Spare part for:

135622 Viper 2330 EN

135623 Viper 1520 EN



313038 Flat cable 69.5cm 10p DOL 440 switch

Spare part for:

135622 Viper 2330 EN

6 TECHNICAL DATA

Technical Data Viper	
Electric	
Supply voltage	115 V*, 200 V* and 230 V/240 V AC +/- 10 % (*not fan speed controller)
Supply frequency	50/60 Hz
Max. power consumption	75 VA
Inputs	4 analog in, 0-10 V DC. Input impedance 2.2 MOhm
	1 inside temperature sensor DOL 12 (-10 °C to +40 °C)
	1 outside temperature sensor DOL 12 (-10 °C to +40 °C)
Outputs	2 sensor supplies 15 V DC +/- 10 % max. 40 mA
	1 analog out, 0-10 V DC. Output impedance 1.5 KOhm
	1 supply for winch motor potentiometer 10 V DC, max. 40 mA
	1 motor supply 24 V DC +/- 20 %. Max. 0.4 A in all
	10 relays NO/NC potential free max. 250 V AC, 5 A resistive load
Output	1 alarm relay NC, max. 24 V 2 A. Min. 12 V 10 mA
Auxiliary modules/extra options	
Viper I/O module (type 3) (8In/8Out)	8 analog in, 0-10 V DC. Input impedance 2.2 MOhm
	8 analog out, 0-10 V DC. Output impedance 1.5 KOhm
	10 relays NO/NC potential free max. 250 V AC 5 A resistive load
	1 motor supply 24 V DC +/- 20 %, 0.4 A
Hi-power relay modules (output)	10 relays NO potential free max. 250 V AC 30 A resistive load
Override switch module (input)	10 ON-OFF-AUTO mechanic override switches
(output)	10 ON-lamps
Adjustment	230 V winch motor blocking ON/OFF
Lo-power relay modules 24 V/230 V motor	5 A (resistive load)
Adjustment	Emergency opening ON/OFF
Weighing module	2 and 4 input silo load cells
Fan speed controller (output)	Motor load, max. 6.8 A 230-240 V AC/min. 150 W
Mechanic	
Cable knock-out punches	30 for metric cable flange M25 x1.5 (Note: PG 16 does not fit!)
Environment	
Ambient temperature, operation	-10 to +45 °C (+14 to 140 °F)
Ambient temperature, storage	-25 to +60 °C (-13 to +140 °F)
Ambient humidity, operation	0-80 % RH
Density class	Splashproof IP 54
Shipping	
Dimensions Viper	H x W x D: 381 x 568 x 170 mm
Dimensions Viper crated	H x W x D: 421 x 608 x 230 mm
Shipment weight Viper	8.8 kg



7 INDEX

1

1 or 2 types of animals.....40

2

24-hour clock.....17

A

adjust negative pressure.....80
adjust stepless.....79;83
air inlet.....37;52;74;76
air inlet modulation.....74
air intake delay.....76
air outlet.....49;53;54;55;82
air output.....64
aux. sensor.....47;50

B

batch production.....33;41
baud rate, Info Matic.....70
bird scale 1 signal.....58
bird scales.....58;69
brooding heaters.....67;77

C

calibrate sensors.....42;45
CF-card.....19;71;72
CO2 sensor.....17;50;62;68
comfort.....77
continuous.....41
control mode.....34;35
control parameters.....74
cooling.....11;50;57;67;78
cooling relay.....50
copy from CF-card.....72
copy to CF-card.....72
CPU module.....42;45
cross auger sensor.....59
cycle time.....75;76;77;78

D

delete on CF-card.....72
display.....42;44;66;67;68;69;70;75;76;77;78

E

electronic silo weigher.....17;58

F

fan speed controller.....15
feed.....17;39;50;57;58;59
feed control.....17
feed demand sensor.....59
feed relay.....57;58

G

general I/O.....42;45
general modules.....18;24
gradual limit.....66
Grow zones.....36

H

heater setup.....37
heaters.....56;77
humidification.....17;50;57;67;78
humidity control.....78
humidity sensor.....50

I

I/O module.....10;18;22;24;26;28
Info Matic.....70

J

jumpers.....26;27;28

L

Language.....43
light control.....17
light dimmer.....50;59;60;69
light relay.....50

M

main I/O.....42;45
manual/auto.....49;50;51;60
max. flap.....66
max. output.....61;64
memory.....71;72;73
menu for adjustment.....32
menu for system setting.....61
min. ON-/OFF time.....76
minimum ventilation.....38
MultiStep.....16;37;49;55;63;64;76



N

NH3 sensor.....	17
night setback.....	68
nominal output.....	63;64;80

O

O2 sensor.....	17
operation log.....	71
outs. temp. limit.....	66

P

Pad cooling.....	50
Pad sensor.....	17;50
password.....	43
p-band.....	66;68;78
power supply, fan.....	66
press. sensor.....	17
pressure control.....	17;68;78
program upload, CF-card.....	72

R

read, Info Matic.....	70
rotate.....	61;64

S

save alarm log, CF-card.....	72
save operation log, CF-card.....	72
save present setup.....	72
sectional cross area.....	35
set brightness.....	44
set contrast.....	45

set operation form.....	41
Show installation.....	19
side inlet.....	49;52;61;75
silo.....	30;50;57;58;69
soaking.....	50;57
soaking relay.....	50
spray cooling.....	57
stepless.....	37;53;54;63;64;79;83

T

temperature setpoint.....	51;78
tip weigher impulse.....	59
tunnel inlet.....	49;75

U

user setup.....	42
-----------------	----

V

ventilation.....	38;66;75;77;78
------------------	----------------

W

water meter.....	17;19;39
weighing modules.....	18;24;42;45
winter compensation.....	76
winter factor.....	75
wire type, fan.....	66

Z

zone setup.....	37
-----------------	----



Big Dutchman