

FORMULA RENAULT 1.6 USER MANUAL

2013



USER MANUAL

CONTENTS

1. OVERVIEW OF THE CAR	4
2. CONTACTS	5
2.1. Organizers	5
2.2. Technical contacts	5
2.3. Manufacturer.....	5
2.4. Renault Sport extranet	6
3. OVERALL DESCRIPTION	7
3.1. Dimensions	7
3.2. Capacities	8
3.3. Technical Specifications	8
4. USE.....	9
4.1. Switch panel	9
4.2. Starting procedure	10
4.3. Safety procedure	10
4.5. Ballast location	11
5. CHASSIS.....	12
5.1. Basic Setup.....	12
5.2. Setup adjustment	13
5.3. Aero setup	13
5.4. Suspension geometry.....	15
5.4.1. Toe/Camber shims position	15
5.4.2. Rear bracket position.....	16
5.5. Damper setting	17
5.6. Front antiroll stiffness setting	18
5.7. Brakes.....	19
5.7.1. Discs / Pads bedding in procedure.....	19
5.7.2. Wear	19
5.8. Nosebox cap change	19
5.9. Tightening torques.....	20
6. ENGINE	21
7. TRANSMISSION / GEARBOX.....	22
7.1. Clutch bleeding procedure.....	22
7.2. Ratio charts	23
7.3. Lubrification	23
7.4. Glue components.....	24
7.5. Gears	24
7.6. Selector.....	26
7.7. Differential.....	28
7.8. Final drive.....	29
7.9. Bearings	31
7.10. Clutch shaft.....	34
7.11. Rebuilding of the gearbox	35
7.12. Gear shift setup	36
8. ELECTRONICS.....	37
8.1. Dashboard	37
8.1.1. Driver pages	37

8.1.2. Diag pages.....	38
8.1.3. Diag CAN	39
8.1.4. Display settings	40
8.1.5. Dash configuration	40
8.1.6. Synthesis operation.....	43
8.2. Details of the transponder connector.....	44
8.3. Composition of the PI Data system kit.....	44




The repair procedures prescribed by the manufacturer in this manual have been written in compliance with the technical specifications in force at publication issuing date. They are subject to modifications in case of changes made by the manufacturer to the production of the various components and accessories of his brand name vehicles".

All copyrights are reserved to RENAULT SPORT TECHNOLOGIES.

Reproducing or translating this document, even partially, and using the spare parts reference numbering system are prohibited without the previous written consent of SIGNATECH AUTOMOBILES

© RENAULT SPORT TECHNOLOGIES 2013

1. OVERVIEW OF THE CAR



2. CONTACTS

2.1. Organizer

RENAULT SPORT

Renault Sport Technologies

ZA Courtaboeuf 2
14, Avenue des Tropiques
91978 Les Ulis Courtaboeuf Cedex
FRANCE
Tel : +33-1 76 82 40 00
Sporting coordinator: Rudy Thomann
rudy.thomann@renault.com

2.2. Technical contacts

For any questions or advice, please contact:

RENAULT SPORT

Renault Sport Technologies

ZA Courtaboeuf 2
14, Avenue des Tropiques
91978 Les Ulis Courtaboeuf Cedex
FRANCE
Tel : +33-1 76 82 40 00
Fax : +33-1 76 82 12 40
<http://extranet.renault-sport.com>

Racing Technical Support:

Guillaume Argy
Tel : +33-1 76 84 18 93
Mob: +33-6 84 93 86 46
guillaume.argy-renexter@renault.com

Racing Technical Dpt Referent:

Julien Jehanne
Tel : +33-1 76 82 41 25
julien.jehanne-renexter@renault.com

2.3. Manufacturer



Signatech Automobiles

Parc Esprit 1
Rue Michael Faraday
18000 Bourges
France
Tel/Fax : +33-2 48 02 01 77

Racing Technical Support:

Lionel Chevalier
Tel : +33-2 48 02 01 77
lionel@signature-team.com

Spare Parts:

Florent Pacholak
Tel : +33-2 48 02 01 77
signatech@signature-team.com

2.4. Renault Sport extranet

The Renault Sport Extranet website is accessible for every FR1.6 owners, after asking for an access directly from the welcome page of the website:

<http://extranet-competition.renault-sport.com/>

or




All the technical documents issued are available through this website:

- Technical Regulations
- User Manual
- Technical Bulletins & Information Notes
- Spare parts catalogue
- Softwares
- HQ Loom drawings and so on.

3. OVERALL DESCRIPTION

3.1. Dimensions



Overall length	4118 mm
Overall width	1670 mm
Overall height	999 mm
Wheelbase	2651 mm
Front track	1486 mm
Rear track	1436 mm
Front overhang	935 mm
Rear overhang	531 mm

3.2. Capacities


Products	Quantity	Characteristics
Petrol	43 L	Unleaded 98
Engine oil	Around 6.5 L	Elf HTX 825 (10W60)
Gearbox oil	2.1 L	Elf HTX 735 (75W90)
Coolant	6 L	-
Brake fluid	0.4 L	Elf HTX 115
Clutch fluid	0.15 L	Elf HTX 115

3.3. Technical Specifications

Weight	470 kg without driver and fuel (with catalyser exhaust)
Front suspension	Push road, mono damper unit (non adjustable)
Rear suspension	Push road, twin damper unit (non adjustable)
Wheels	Rims : one piece Speedline aluminium alloy rim with central nut Rims size : Fr 8"x13" Rr 10"x13 Kumho tyres : Fr 180/53x13 Rr 220/54x13 Dunlop tyres : Fr 175/535x13 Rr 230/535x13
Brakes	4 piston Alcon calipers, 274x18.5mm ventilated discs Right/Left foot adjustable pedal
Engine	Renault Sport Type : K4M 854 – 1.6L Max power : 140 bhp @ 6800 rpm Max torque : 160 Nm @ 4500 rpm Max revs : 7200 rpm
Transmission	SADEV SL66 5 front gears + one reverse gear Shift cut system Free differential

4. USE

4.1. Switch panel



- 1- Unused Connector
- 2- Main switch
- 3- Rain light switch
- 4- Connector for the mechanic electronic throttle (joystick)
- 5- Dashboard reset
- 6- Neutral and reverse handgrip
- 7- Ignition switch
- 8- Starter button
- 9- Fuel pump switch for drain tank
- 10- Fire extinguisher handgrip
- 11- Brake balance handgrip (clock wise increases front brake pressure)

"ON" is the up position of the switches

4.2. Starting procedure

- Switch the master switch and the ignition on.
- No throttle.
- Push the starter button few seconds. The engine must start.
- If the engine doesn't start, switch ignition off and on and push the starter button again.
- After starting you can accelerate gently.
- Warm the engine up to 80°C before running.

4.3. Safety procedure

Switch ignition and master switch off.

For transportation it's easy to disconnect the electrical system by unscrewing the main fuse (100A).


In case of fire, the driver pulls the handgrip on the right side of the steering wheel or an external person pulls the red ring on the right side of the roll hoop.

This action triggers the extinguisher and switches the electrical system off. After this action, the electrical system can be on again only by pushing the fire switch on the extinguisher ones (Spare parts catalog page 14 Ref 12).

Fire extinguisher cables are located in two points:



Behind the roll hoop



Inside the cockpit

4.5. Ballast location

The ballast must be placed inside the cockpit, under the driver seat.
The lead ballast has to be fitted between the bottom of the chassis and the stainless steel cover.


Ballast system are described as follows:

- 3mm stainless steel cover : 2.0kg
- 1.5 mm lead ballast: 1.5kg

Maximum ballast weight possible: +/- 15kg.

You can only fit the steel cover plate.

Mounting screws: 3 FHC M5 with diam5x12 washers and nylstop nuts. Length depending of the thickness of the ballast



5. CHASSIS

5.1. Basic Setup

Gearbox	Final drive	1st	2nd	3rd	4th	5th
SADEV SL66	10/31	11/35	14/31	18/30	19/25	25/27


	Front		Rear	
SPRINGS				
Spring Stiffness [lb/in - daN/mm]	800	14	700	12.3
Motion Ratio Wheel / Damper	0.86		1.18	
DAMPERS	Nadal Tech non adjustable			
ANTIROLL				
Bellevilles Stack	11x1			
Motion Ratio Wheel / Bellevilles	1.77			
Element Stiffness [daN/mm]	81			
GEOMETRY				
Ride Height [mm]	18		33	
Castor [°]	10°			
Camber [°]	-3.5°	-3.5°	-2.5°	-2.5°
Toe per Wheel	1,5 mm OUT		1 mm IN	
Roll centre position vs ground [mm]	23		52	
Anti-Dive	38%		15%	
Anti-Squat			40%	
WINGS				
Main [°]	4°		9°	
Flap [°]			P2 = 3°	
TYRES				
Pressure [bar] @ 20° C	1.2		1.2	
Hot Pressure [bar]	1.5-1.6		1.5-1.6	
Kumho Circumference [mm]	1665		1696	

5.2. Setup adjustment


Adjustment	Front	Rear
RIDE HEIGHT change		
1 turn of damper platform (2mm)	1.7 mm	2.4 mm
CAMBER change		
1 mm shim	0.285°	0.278°
3.5mm shim	1°	0.97°
+10mm ride height	-0.3°	+0.15°
TOE change		
1 turn (1mm)	0.653° around 4 mm at the Wheel	
1.5 flat	1 mm at the wheel	
1mm shim		0.157° around 1 mm at the wheel
CASTER change		
1mm shim	0.218°	
WING change		
1mm shim	-0.6°	

Special damper spanners are available (one for each size of platform)

5.3. Aero setup



Front wing




The front wing shims must only be fitted on the rear of the front wing brackets.

Available shims thickness: 0.5mm, 1mm and 2mm.

Without shims, the wing angle is 5° (Maximum value)


Rear wing




0° parallel to the car floor or to the reference plan on the top of the bellhousing

5.4. Suspension geometry


5.4.1. Toe/Camber shims position






Rear toe and camber shims are the same.

5.4.2. Rear bracket position



Only one rear bracket position is allowed (red fixing points)

5.5. Damper setting



Speed [mm/sec]	force [kg]					
	bump min	bump	bump max	rebound min	rebound	rebound max
20	14,35	15,60	16,85	-13,16	-14,30	-15,44
100	44,34	48,20	52,06	-50,05	-54,40	-58,75
160	58,88	64,00	69,12	-71,02	-77,20	-83,38

gas force measured at middle stroke = 15kg +/- 1,5kg
 all measures are done at 30°C shock temperature

5.6. Front antiroll stiffness setting

The front antiroll stiffness is set by a Belleville washer stack.

Belleville dimensions: diam 31.4 x 16.4mm thickness 1.75mm

Only following Belleville stacks with the corresponding spacers are allowed:

Stack	Spacer	Stiffness (daN/mm)	Max Deflection (mm)
4x2 <>>><>>>	6x1 >>>>>>	444	2.4
5x2 <>>><>>><<	4x1 >>>>	355	3.0
6x2 <>>><>>><>>>	4x1 >>>>	296	3.6
7x2 <>>><>>><>>><<		254	4.2
8x2 <>>><>>><>>><>>>		222	4.8
9x2 <>>><>>><>>><>>><<		197	5.4
5x1 <><><	9x1 >>>>>>>>>>	178	3.0
6x1 <><><><	7x1 >>>>>>>>	148	3.6
7x1 <><><><<	6x1 >>>>>>>	127	4.2
8x1 <><><><><	5x1 >>>>>>>	111	4.8
9x1 <><><><><<	4x1 >>>>>	99	5.4
10x1 <><><><><><	4x1 >>>>>	89	6.0
11x1 <><><><><><<		81	6.6
12x1 <><><><><><<<		74	7.2
13x1 <><><><><><<<<		68	7.8
14x1 <><><><><><<<<<		63	8.4
15x1 <><><><><><<<<<<		59	9.0
16x1 <><><><><><<<<<<<		56	9.6

Take care to respect the mounting direction of the Belleville stack with the smaller diameter of the Belleville in contact with the preload nut.

If the Belleville stack needs a spacer, the spacer has to be mounted after the Belleville stack with the bigger diameter in contact with the preload nut.

5.7. Brakes

5.7.1. Discs / Pads bedding in procedure

- During the first 2 laps do not over heat the new brake discs and pads. Brake earlier than usually and with less brake pressure (50%)
Don't be aggressive, warm progressively the brakes by small and frequent braking: every 10 seconds.
- After 2 laps, do half slow lap to cool down the brakes
- Do again 2 laps like the first ones but with more brake pressure (75%)
- Do half lap to cool down the brakes and so after 5 laps you can brake like usually.

5.7.2. Wear

Disc nominal thickness: 18.5mm


Disc minimal thickness: 16.5mm

5.8. Nosebox cap change

In case of nosebox cap damage, it's possible to change it.

- Cut the nosebox cap at the mentioned dimensions.
Around 20mm of the nose cap is still on the nosebox.
- Unstick carefully this part of the nose cap.
Take care not to damage the main part of the nosebox.
- Use "ARALDITE 2031" to bond the new nose cap.

For safety reason it's forbidden to repair the nosebox if the honeycomb is damaged.



5.9. Tightening torques


Bolt and nut	Nm
M5	10
M6	14
M8	25
M10 Roll Hoop	35
M10	40
M18 Wheel Nut	140
M20 Wheel Stud	180
Brake Bleeder	12

6. ENGINE


- Optimum water temperature: 90°C
- Maximum water temperature: 105°C
- Maximum oil temperature: 140°C
- Revs limiter: 7200 rpm
- Engine oil and filter oil change : every 2500km
- Engine air filter cleaning: every 1000km
- Engine must be checked in case of an 8000RPM over rev

7. TRANSMISSION / GEARBOX

The SADEV SL66-14 gearbox, is a sequential 5 front gears & one reverse gear with cut off system. Its weight is approximately 36 kg. It is equipped with a bevel gear differential.



7.1. Clutch bleeding procedure



7.2. Ratio charts

Gear	Ratio	Ref.
1 st	11x35 (0,314)	D669002036J6J1
2 nd	14x31 (0,451)	
3rd	18x30 (0,6)	C66141830606J
4th	19x25 (0,76)	C66141925606J
5th	25x27 (0,925)	C66142527606J

Reverse gear	
Primary shaft	11
Reverse gear	16
Secondary shaft	36

Final drive	
Secondary shaft	10
Crown wheel	31


7.3. Lubrification

Oil capacity: 2.1 L (at drain plug level)

1st drain	Drain frequency	Viscosity
After a 50Km running-in	Each meeting	75W90

PARTICULAR PRECAUTIONS

No additives should be added to the oil. The resulting consequences are not in any circumstances covered by the SADEV supplier.
When topping up the gearbox oil, do not mix any other oil with that already in the box.



STORAGE AND USE

Be particularly careful with any bottles which are open when used:

- Close the bottle again properly after use to prevent the introduction of water or dirt.
- Store bottles horizontally, protected from severe weather.
- Do not store bottles close to a washing station.
- Do not decant the oil into larger containers.

WASHING UNDER PRESSURE

When the gearbox is removed, seal all openings correctly to prevent the ingress of water into the gearbox.

7.4. Glue components

Glue components and tightening torque are shown in the rebuild section.

WARNING:

Glue components have been chosen during tests sessions. Only 'Loctite' brand components must be used.

Consequences of false glue component choice can't be ensured by Sadev.

7.5. Gears


Removing

- Engage neutral
- Drain the gearbox through the lower plug (clean the oil level plug magnet)
- Disconnect the potentiometer
- Lock the differential using the dedicated tool.
- Remove the end cap (1) (4 M6 bolts)

Remove the secondary shaft nut (2) , its circlip and stopping washer

Caution : *It is left hand threaded.*

- Remove the back housing (3) (8 M7 nuts)




Caution : The secondary shaft, only guided with taper roller bearing and rested against the teeth, can drop a little.

- Remove the fork axle (4).
- Remove the gears 5th, 4th, 3rd, 2nd & 1st and reverse wheels, and all other parts of the primary and secondary stacks.
- Remove the reverse gear idler bolt (5).


Caution : It is glued, so use a hot air gun.

- Remove the reverse gear idler
- Remove the clutch shaft (7) (see 7.10)
- Remove the primary shaft (6).



Reinstallation

- Clean and check the conditions of the parts. Clean the mating surfaces of the housings.
- Reinstall the primary shaft (support the clutch shaft to slide the primary shaft)
- Install the reverse gear idler (tighten the reverse gear idler bolt bonded with Loctite 648 to 5.5daN.m)
- Reinstall all the parts in the reverse order as for removing. Lightly lubricate them with gearbox oil before fitting.
- Install the fork pin and make sure the fork actuating pins are in the relevant barrel slots. (Tool FOUT0085003 and check the barrel is in neutral position)



Set up the primary & secondary stacks clearance (you can do this simultaneously).


- Primary stack adjusting shim (8):
 - o If you did refit all the original parts, refit the original shim.
 - o If not : install the finest shim of the set (F90020181), and close the gearbox (without glu or seal component & tighten the nuts moderately).
 - o Remove the differential (see 7.7), and check the primary stack axial clearance.

- Choose the ideal adjusting shim (after setting, the primary line must be tight form 0 to 0.1mm) re-install the differential, re-open the gearbox and install it.
- Secondary stack preload adjusting shim (9):
 - In exclusion of wheels, wheels bearings, dogring & forks, if you did refit all the original parts, refit the original shim.
 - If not : install the thickest (2.5mm) shim of the set (F90020121), and close the gearbox (without glu or seal component & tighten the nuts moderately).
 - Tighten the secondary shaft nut to 18daN.m (left hand thread)
 - Remove the differential (see 7.7), and check the secondary stack axial clearance "X".
 - Calculate the shim thickness : $2.5\text{mm} - X$. Choose the nearest thicker shim, re-install the differential remove the secondary shaft nut, re-open the gearbox and install it.
- Coat the rear housing mating surface with Loctite 518, and install it. Thighten the M7 nuts to 2.2daN.m
- Tighten the secondary shaft nut to 18daN.m (left hand thread), and install its stopping washer & the circlip.
- Coat the end cap mating surface with Loctite 518, and install it. Thighten the M6 bolts bonded with Loctite 222 to 1.5daN.m
- Reinstall and adjust the potentiometer.

7.6. Selector

Removing the selector axle

- Engage reverse gear
- Drain the gearbox through the lower drain plug (Clean the drain plug magnet)
- Remove the external axle (1) (2 M7 bolts).
- Remove the reverse gear unlocking cable.
- Remove the control closing block with the cut off switch (2) (2 M7 bolts).
- Remove the dual pin rock pusher (3) (2 M5 bolts)
- Introduce a round magnet FACOM (4) in the pusher guide hole and raise the dual pin rock making sure it is not in contact with the barrel.
- Keeping the dual pin rock raised, make the selector axle turn $\frac{1}{4}$ of a turn and extract it from the control closing block side.




Reinstallation of the selector axle

- Clean and check the conditions of the parts
- Check the barrel is in reverse position. This position is visible when looking at the barrel through the selector axle hole : in reverse position, there is a notch on the barrel to let the selector axle go through.
- Put the dual pin rock into the selector axle.
- Insert the selector axle in the housing with the same position as when removing it.
- Drive in the selector axle until the spring is completely compressed, turn it $\frac{1}{4}$ of a turn (in the opposite way to removing) and check the double ratchet is correctly installed in the barrel.
- Install the dual pin rock pusher (3) (2 M5 bolts, Loctite 222, 0.5daN.m), control closing block with the cut off switch (2) (2 M7 bolts, Loctite 222, 2.2daN.m), Remove the external axle (1) (2 M7 bolts, Loctite 222, 2.2daN.m) and the reverse cable, being careful to clean and degrease all the screws.

Removal of barrel

- Engage neutral
- Drain the gearbox through the lower drain plug (Clean the drain plug magnet)
- Remove the reverse gear unlocking cable & the potentiometer
- Remove the indexor (1)
- Lock the differential using the dedicated tool
- Remove the end cap (4 M6 bolts)
- Remove the secondary shaft nut, its circlip and stopping washer

Caution : *It is left hand threaded.*



- Remove the back housing (2)
- Remove the fork pin (3) and disengage the forks to get out the fork actuating pins from the barrel slots
- Remove the barrel (4)


Reinstallation of the barrel

- Clean and check the condition of the parts
- Install the barrel taking care it's resting well in its main housing bearing.
- Adjust the barrel clearance:
 - o If you refit all the original parts, refit the original shim.
 - o If not : install the finest shim of the set (F90020041), and close the gearbox (without glu or seal component & tighten the nuts moderately).
 - o Remove the differential (see 7.7), and check the barrel axial clearance.
 - o Choose the ideal adjusting shim (after setting, the clearance must be as near of 0mm as possible) re-install the differential & re-open the.
- Install the chosen barrel clearance adjusting shim
- Check the barrel is in neutral position.
- Install the fork pin and make sure the fork actuating pins correctly fit the barrel slots. (Tool FOUT0085003)
- Coat the rear housing mating surface with Loctite 518, and install it. Tighten the M7 nuts to 2.2daN.m
- Tighten the secondary shaft nut to 18daN.m (left hand thread), and install its stopping washer & the circlip.
- Coat the end cap mating surface with Loctite 518, and install it. Tighten the M6 bolts bonded with Loctite 222 to 1.5daN.m
- Reinstall and adjust the potentiometer.

7.7. Differential


Removing

- Engage the neutral
- Drain the gearbox through the lower drain plug (Clean the drain plug magnet)
- Remove the differential housing (1) (11xM8 bolts)
- Remove the differential (2)



Rebuild operation

- Remove the bevel gears stops (3) (12xM6 bolts each)
- Remove the bevel gears (4) noting their mounting side.
- Remove the dowel pins (5)
- Remove the planet gears, their axles and the nut.
- Clean and check the good conditions of the parts (change them if necessary).
- Reinstall the planet gears, their axles and the nut.
- Reinstall new dowel pins.
- Reinstall the bevel gear (taking care of their mounting side).
- Reinstall the bevel gears stops. (for each one, tighten the 12xM6 bolts bonded with Loctite 243 to 1.5DaN.m)
- Before re-installing, check the condition of the final drive (crownwheel and secondary shaft) and if necessary, change it (see 7.8)



Reinstallation

- Clean the threads , bolts & mating surfaces of the differential & main housings.
- Install the differential.
- Coat the differential/main housing mating surface with Loctite 518.
- Install the differential housing (tighten the 11xM8bolts bonded with Loctite 222 to 2.2DaN.m)
- Fill up the gearbox with oil to the Oil level.

7.8. Final drive

Removal


- Engage neutral
- Drain the gearbox through the lower plug (clean the oil level plug magnet)
- Disconnect the potentiometer
- Lock the differential using the dedicated tool. (FOUT90020081)
- Remove the end cap (4 M6 bolts)
- Remove the secondary shaft nut, its circlip and stopping washer

Caution : *It is left hand threaded.*

- Remove the differential (see 7.7)
- Remove the gears (without primary shaft) (see 7.5)
- Remove the secondary shaft


Secondary shaft

- Set the secondary shaft advance :
- Note the dimensions engraved inside the main housing (about 109.5mm) and on the secondary shaft (about 90mm)
- Make the following operation :
housing dimension - shaft dimension - 18 = shim thickness
- Install the corresponding thickness shim (1), and the conical bearing on the shaft (2).
- Reinstall the secondary shaft and its gears (see 7.5).



Crownwheel


- Remove the differential bearings (see 7.9)
- Remove the crownwheel. (8xM10 bolts)
- Clean and check the parts condition.
- Install the new crownwheel (tighten the M10 bolts bonded with Loctite 648 to 9DaN.m)
- Install the differential bearings (see 7.9)



- Check the two differential bearings shim thicknesses, addition them and note the result (B).
- Set the final drive clearance :
- Install the FOUT90020401 (1) tool, and for each tooth of the tool, check the final drive clearance.

The average clearance must be of 0.1 to 0.2mm.


If the clearance is too high : make the crown wheel and pinion closer by increasing the spacer thickness at the ring gear side (2) and



decreasing the opposite spacer thickness (3) : you must keep the same total thickness

If the clearance is too low : separate the crown wheel and pinion by decreasing the spacer thickness at the ring gear side and increasing the opposite spacer thickness : you must keep the same total thickness


- Process again until getting good values.
- Reinstall the gears (see 7.5)



7.9. Bearings

Primary shaft bearings


- Remove the primary shaft (see 7.5)
- Remove the bearing (2) and spacer (3) on primary shaft using a press, taking care not to damage it
- Clean and check the condition of bearing journal
- Fit the new bearing using a press making sure it is correctly seated on its journal.
- Fit the spacer making sure it is well positioned against the bearing inner race.
- Refit a new dowel pin
- Remove the back housing lip seal
- Heat the back casing using a hot air gun to approximately 120°C
- Position an extractor FACOM (ref. U.49AD5) on the primary shaft bearing loosened in the back casing and extract it with a slide hammer



- Clean and check the conditions of the bearing journal
- Put the new bearing using a press (or heating the shaft to approx. 120°C) making sure it is correctly seated in its housing
- Install a new lip seal in the back housing.
- Install the primary shaft and set up the primary line shims (see 7.5)


Barrel bearings

- Remove the barrel (see 7.6)
- Remove the barrel bearing (4) using a press and taking care not to damage it
- Clean and check the condition of the bearing journal
- Install the new bearing using a press and making sure it is well positioned against the shoulder
- Remove the back casing lip seal
- Heat the back casing using a hot air gun to approximately 120°C
- Position an extractor FACOM (ref. U.49AD5) on the primary shaft bearing loosened in the back casing and extract it with a slide hammer
- Clean and check the conditions of the bearing journal
- Put the new bearing using a press making sure it is correctly seated in its housing
- Install the lip seal in the back housing after checking its condition
- Reinstall the barrel (see 7.6)




Secondary shaft bearings

- Remove the differential and the secondary shaft (see 7.8)
- Remove the front plate (1) (11xM6 bolts)
- Remove the back casing lip seal
- Heat the back casing using a hot air gun to approximately 120°C
- Extract the external ring from the back casing by hitting the ring through the oil way hole
- Clean and check the condition of the bearing journal
- Fit the new ring using a press and




making sure is correctly seated in its housing

- Install the lip seal in the back housing after checking its condition
- Extract the external ring from the main casing hitting the ring by the 3 dedicated holes (2)
- Clean and check the condition of the bearing journal
- Put the new ring using a press and making sure is correctly seated in its housing
- Remove the secondary shaft bearing using possibly the tool FACOM (ref. U.53T1) taking care not to damage the bearing journal
- Clean and check the condition of the bearing journal
- Install the new bearing using a press and making sure it is well positioned against the spacer adjuster
- Reinstall the differential and the gears (see 7.5)
- Reinstall the front plate. (tighten the 11xM6 bolts bonded with LOCTITE 222 to 0.5DaN.m)



Differential bearings

- Remove the differential (see 7.7)
- Remove the differential case bearings (1) using a press and taking care not to damage it
- Clean and check the parts condition.
- Fit the new bearings using a press making sure it is correctly seated on its journal.



- Set the bearings preload (only if you changed the main housing, the differential housing, the differential case or the bearings):

Caution : *You will have to set the final drive clearance too (see §6-4-3).*

- Install the differential and the thinnest shims (2) (1.5mm) between each bearing and its housing.
- Install the differential housing, tightening the bolts moderately.
- Measure the axial clearance of the differential "A".

Note : *It is tight mounted, so you will have to push hard from one side and then from the other of the differential case to check the clearance.*

- Make the following operation : $A + 3\text{mm} + 0.1\text{mm} = B$


Caution : *Note it, this is an important measure for the final drive clearance set up.*

- Remove the differential.
- Reinstall the differential (see 7.7). On each side, use shim thicknesses equal to $B/2$.

7.10. Clutch shaft

Removal

- Drain the gearbox through the lower drain plug (Clean the drain plug magnet)
- Remove the lip seal from the front side of the gearbox
- Remove the circlip which retains the clutch shaft bearing
- Remove the clutch shaft



Reinstalling

- Clean and check the conditions of the parts
- Reinstall the clutch shaft inserting it in the primary shaft (mesh a speed and lock the differential if necessary)
- Reinstall a circlip to lock the clutch shaft bearing
- Reinstall a new lip seal

7.11. Rebuilding of the gearbox

In Sadev workshop rebuilding

Notes :

- The gearboxes are delivered leaded and numbered.
- The absence of lead 'Sadev' imposes a careful attitude in the event of minor or major problem to us, and applies to complete reserve of our share if necessary.

Return gear boxes to revision :

At the time of the return of the gearboxes in our buildings, a certain procedure of delivery has to be respected, so that our intervention can be total, and practical (casing ' closed' for passage to the bench).

We must receive the complete product as described below:

- Release bearing in place
- entry and exit of lubrication closed by plugs envisaged for this purpose (Goodridge, SpeedFlow...)
- Gear box drained and cleaned
- Drain plug and drain plug seal in place
- Differential in place
- *A card specifying the kilometers of the special stage and connection since the last service, available near our sales department*

The absence of elements can be specified on the card, but in case of doubt, the material will be send back re-equipped.

Administrative procedure:

1. Send a request for service to SADEV sales department
2. Forward The material and its card (description above) in our workshops
3. Approve the estimate presented by SADEV sales department
4. APPROXIMATELY 2 TO 3 WEEKS OF DELIVERY TIME MUST BE CONSIDERED

Personal revision:

After sale parts for customers who want to proceed a revision by themselves, are delivered only by SADEV sales service.

SADEV IS NOT RESPONSIBLE FOR ANY DAMAGE FOLLOWING A REVISION NOT EXECUTED IN A SADEV AGREED TECHNICAL SERVICE (LIST ON DEMAND).


As every mechanical part which is dedicated for racing, there is not warranty at all from our side.

7.12. Gear shift setup

- Pull the gear shift level to upshift. No need to use clutch and to throttle off. The ignition cut is automatic and has to be set-up.
There is a switch cut on the left side of the gear box at the end of the barrel drive axle. It's screwed with shims to adjust its position. Each car is delivered with a set of shims. When reducing the thickness of the shims, the ignition cut is earlier in the level movement.
- As soon as the barrel drive axle starts moving (first mm), the ignition has to be cut off. It's possible to check the cut off position without running engine.
- Switch ignition on. The EDiag LED on the right of the dashboard is flashing. When pushing the barrel drive axle, the LED turns on permanently.


8. ELECTRONICS

8.1. Dashboard



8.1.1. Driver pages


Three driver pages are available.
 You can change the driver pages by pushing the red button.




8.1.2. Diag pages

To access to the different Diag pages :

- Hold the green button down until this page appears :




- Move the cursor with the blue or yellow button to access the 4 different Diag (Lap time ; Mini/Maxi ; Alarm ; Custom).
- When the cursor is located on the Diag you want, press the green button to display the page, and scroll it.
- Push the red button to exit.



Details on the 4 Diag pages:

- Lap time: displays the lap times made.

Sec: indicates the session by a letter.
 Lap: indicates which lap of the session.
 Time: indicates the lap time.



With the blue or yellow button, you can select a lap time. The date and beginning hour of this lap are displayed in the two little windows located on the right.

- Mini-Maxi: mini and maxi values of each parameter are displayed. To display all the parameters, scroll with the blue or yellow button. You can reset the values by pressing the blue and yellow buttons simultaneously until crosses (x) appear.

Parameters	Mini	Maxi
(</>) to select. (<+>) & (<->) to Reset.		

- Alarm: displays how long, in seconds, the parameter has remained in "alarm".

To display another parameter, scroll by pushing the blue or yellow buttons.

To reset the alarms completely, just press the blue and yellow buttons simultaneously, until the length figures are back to zero (all the duration of the different parameters will be reset at the same time).

<	/	S
>	/	S
(</>) to select. (<+>) & (<->) to Reset.		

- Custom: these pages allow to display other parameters in "real time".

Push the green button to scroll down.

Ped1		Gea
Ped2	Pot2	Cam
Par	Syn	Res

Mechanic page 1

Shif		Gea
Pit Lim	Sav Map	Secu Off
Tot Fuel	Tot Hrs	Tot Kms

Mechanic page 2

8.1.3. Diag CAN

You can access to the diag can page by pushing simultaneously the blue and yellow button when the dash is displaying the first mechanic page.

CAN1	CAN Diagnostics	CAN2
TEC: 0		TEC: 0
REC: 0		REC: 0
bus active		bus active

8.1.4. Display settings


To reach the display settings, press together the red and green buttons and hold them down until the page appears. To move within the different parameters, you have to use the green button. To change the value, you need to press the blue button in order to set the value down, and the yellow one to rise it up. Values go from 1 to 10.

	Day	Night
Contrast	/ 10	/ 10
Backlight	/ 10	/ 10
Led	/ 10	/ 10
(</>) to adjust Valid to select		

- Contrast: to setup the shade between the screen background and the written indications.
- Backlight: to modify the brightness of the screen background.
- Led: to set up the brightness of the LEDs.
- Day and night: Set up for night or daylight.

8.1.5. Dash configuration

To reach the configuration menu, push the green button **before** to raise the ignition switch. Once the page is displayed, move the cursor with the blue or yellow buttons. When the cursor is on the parameter to tune, use the green button to validate and the red one to exit.



Details on the configuration pages:

- **Beacon:** to set up the timing parameters.

Beacon	
Min lap time:	s
Display delay:	s
Display time:	s
(</>) to adjust Valid to select	

Press the green button to select one of the three parameters and the blue or yellow one to adjust the time in seconds.

Min lap time: to set the minimum gap time between two laps (to avoid in between beacons on the track).

Display delay: to set the delay in seconds, between the time the beacon is set off and the lap time displayed on the screen.

Display time: to set the length of time, during which the lap time remains displayed.

- **Alarms:** to set the min and the max values of warning of the different parameters.

Alarm		
	min	max
(</>) to adjust Valid to select		

You go from one value to the other by pushing the green button and you adjust the value thanks to the blue and yellow buttons (the unit value is displayed next to the given parameter).

- **Gear:** to set the minimum and maximum of each gear (in volt)

Gear		
min	max	Current input
		<input type="text"/>
(</>) to adjust Valid to select		

In the little window on the right, you have the voltage value given by the barrel potentiometer for the current gear engaged (R; N; 1).

Setting example : for the first gear

- Put the first gear
- Check the value displays in the box current input
- Move the cursor with the green button on the first row
- Adjust the min and max values to "frame" the current input value with the blue or yellow button.

NB: keep a little margin between the max value of a gear and the min value the following gear.


- **Led:** to set the revs leds and the shift led switch on (on top of the dash).



You switch from a value to the other by pushing the green button and you tune the value with the blue and yellow buttons.

- Bargraph first led: to set the first bargraph led (green) switch on.
- Bargraph last led: to set the last bargraph led (orange) switch on.
- Led shift: to set the revs (rpm) for which the shift led lights.


- **RPM+Speed:**



Allow to adjust the number of top per rotation on engine target for the calculation of the engine revs, and the number of top per rotation on the wheel target and the circumference of the wheel (in mm) for the calculation of the vehicle speed.


You switch from one value to the other by pushing the green button, and you adjust the value with the blue and yellow buttons.

- **About:**



This window contains information about the Firmware used in this Dash, the date of the firmware and the appliance specific configuration.

8.1.6. Synthesis operation



8.2. Details of the transponder connector

DTM04-2P connector

Pin1: +12V

Pin2: Ground

8.3. Composition of the PI Data system kit

- One PI compact logger Signatech spec with an integrated lateral accelerometer
- One compact flash card
 - Note: This card must not exceed 2GB memory
- One steering angle sensor with its fastening
- Two wheel speed sensors
- Two brake pressure sensors with its hoses, bleeders and support
- One beacon receiver
- The PI Toolbox and Pectel Card Management softwares