



Copyright 2014 Johnson Controls, Inc. All Rights Reserved

No part of this document may be reproduced without the prior permission of Johnson Controls, Inc.

If this document is translated from the original English version by Johnson Controls, Inc., all reasonable endeavors will be used to ensure the accuracy of translation. Johnson Controls, Inc. shall not be liable for any translation errors contained herein or for incidental or consequential damages in connection with the furnishing or use of this translated material.

Due to continuous development of our products, the information in this document is subject to change without notice. Johnson Controls, Inc. shall not be liable for errors contained herein or for incidental or consequential damages in connection with furnishing or use of this material. Contents of this publication may be preliminary and/or may be changed at any time without any obligation to notify anyone of such revision or change, and shall not be regarded as a warranty.

Other Manufacturer's Documentation

Johnson Controls does not duplicate documentation of other equipment manufacturers. When necessary, Johnson Controls provides documentation that supplements that of other manufacturers. When unpacking your equipment, keep all original manufacturer documentation for future reference.

Technical Support

Johnson Controls authorized dealer representatives can call the Field Support Center at (800) 524-1330 or (414) 524-5000 and use options 6, 1, 7. System users that need information on maintenance contracts or on-site field support can call a local Johnson Controls sales or service office.

Acknowledgment

Metasys® and Johnson Controls® are trademarks of Johnson Controls, Inc. All other company and product names are trademarks or registered trademarks of their respective owners.

CE

Declaration of Conformity

This product complies with the requirements of the EMC Directive 2004/108/EC and the Low Voltage Directive 2006/95/EEC.

This equipment must not be modified for any reason and it must be installed as stated in the Manufacturer's instruction.

If this shipment (or any part thereof) is supplied as second-hand equipment, equipment for sale outside the European Economic Area or as spare parts for either a single unit or system, it is not covered by the Directives.

Table of Contents

Chapter 1: Introduction	1
- Getting Started	1
Chapter Summaries	1
Manual Conventions.	2
Basic System Components	2
Main Menu	5
Registration Parameters	6
System Overview	6
Basic Configuration	6
Network Communication	6
Loop Communication	7
Communication Modes	7
Types of Communication	8
Access Requests	8
Time and Time Zones	8
Valid or Invalid Badges	8
Badge Privileges	8
Controlling Special Access	9
Overriding Basic Access	9
Granting Badge Privileges	9
Alarms	9
External Device Alarms	9
Door Alarms	9
Software-Only Alarms	9
P2000 Host Alarms	10
Remote Alarms	10
Non-alarm Input Points	10
Output Relays	10
Input and/Output Linking	10
Activating Outputs by Events	10
Activating Outputs Manually	10
Events	10
Database Partitioning	
Logging On to the P2000 System Software	
Changing the Default Login Values	
Logging Off from the P2000 System Software	
Navigating through the P2000 System	
Mouse Conventions	14

i

Instruction Conventions	
Menu Shortcuts	
Verification Passwords	
Context Sensitive Help	
Online Help	
P2000 Tutorial	
Viewing the Toolbar	

Chapter 2: Configuring the System

System Configuration Overview	17
Using the System Configuration Window	17
Set Up Workstations and Operators	19
Workstations	19
Workstation Field Definitions	20
Adding Operators to the System	21
Creating Permission Groups	21
Assigning Operators	22
P2000 Directory Services Password Validation	27
Changing the User Password	
Setting Up User Accounts	
Adding a Login Name and Password for the P2000 System into the	
Operating System	
Configure System Components	32
Registration Parameters	32
Site Parameters	
Site Parameters Field Definitions	34
Local Site	47
Local Configuration	48
Time Zones	49
Configuring Time Blocks	49
Holiday Types	51
Holiday	51
Using the Holiday Calendar	52
Assigning Holiday Types	52
Configure Hardware Components	53
Hardware Configuration Sequence	53
Create Panels	53
Panel Naming Conventions	53
Loop Configuration	54
Soft Input Points	56
Edit Panel Field Definitions	56
Configure Panel Components	65
Configure Panel Time Zones	66
Configure Panel Holidays	67
Enable Codes (EC) Definition	68

Configure Panel Card Formats69
Configure Additional Panel Components70
Create and Configure Terminals
Set up Terminals for each Panel70
Edit Terminal Field Definitions71
Use the Add Hardware Module83
Create Terminal Groups85
Configure PIN Codes
PIN Only
PIN + Card ID
PIN
Four-Digit PINs
PIN Duress
PIN Retry Alarm
Create Input and Output Points and Groups
Create Output Points and Groups
Create Input Points and Groups 90
Create Input Points 90
Input Point Field Definitions 90
Configuring Reader Terminal Hardwired Input Points
Using Reader Terminal Door Contact Input Points 96
Using the Terminal Down Input Point 96
Create Input Groups 97
Creating Instruction Text
Create Panel Card Events
Panel Card Event Field Definitions 99
Configure Soft Alarms
Soft Alarms Field Definitions 101
Configure P900 Panels and Components
P900 to P2000 Terminology Cross Reference
Import P900 Sequence Files
Configure P900 System Parameters104
Configure P900 Panels105
Configure P900 Terminals107
P900 Terminal Field Definitions107
Configure P900 Input/Output Points111
P900 Input Field Definitions112
P900 Soft Alarms
Configuring CLIC Components114
P900 Counters
P900 Flags115
P900 Trigger Events
P900 Trigger Event Field Definitions
P900 Trigger Links
Configure OSI Panels and Components

Unsupported OSI Features	
Unsupported P2000 Features	
System Architecture	
Hardware Detection	
Badge Access Rights	
Configuration Sequence	
Configure OSI Facility Parameters	
OSI Facility Field Definitions	123
Adding New Portals	127
Configure OSI Panels	128
Configure OSI Terminals	129
OSI Terminal Field Definitions	130
Viewing OSI Wireless Devices Status	132
Configure S321-IP Panels and Components	133
S321-IP Naming Conventions	133
Configure S321-IP Panels	133
S321-IP Panel Field Definitions	134
Configure \$321-IP Terminals	137
S321-IP Terminal Field Definitions	
Configure \$321-IP Input Points	
S321-IP Input Point Field Definitions	
Configure \$321-IP Output Points	
Configure Isonas Panels and Components	144 1/16
Configure Isonas Panels	140
Configure Isonas Terminals	140
Isonas Terminal Field Definitions	
Configure Iconae Input Pointe	
Configure Isonas nipul Points	
Configure HID Denels and Components	
Lordware Deguiremente	
Configure UID Facility Decomptore	
Configure HID Panels	
HID Panel Fleid Definitions	
HID Terminal Field Definitions	
Configure HID Output Points	
I roubleshooting Misconfigured HID Readers	
Configure Assa Abloy® IP Door Locks and Components	
Hardware Requirements	
Assa Abloy Component Naming Conventions	
Configure Assa Abloy Facility Parameters	
Using the Card ID teature with Assa Abloy Locks	
Add a Door Service Router (DSR)	

Edit Assa Abloy Panels17	1
Assa Abloy Panel Time Zones17	3
Assa Abloy Holiday Definition	4
Configure Assa Abloy Terminals174	4
Assa Abloy Terminal Field Definitions	5
Configure Assa Abloy Soft Input Points	6
Assa Abloy Status Information	7
Real Time Functions	8
Lockout Mode with Assa Abloy Locks178	8
File Maintenance on the DSR Server	8
Configure Mercury Panels and Components17	9
Configure Mercury Facility Parameters	9
Mercury Facility Field Definitions	9
Configure Mercury Panels	3
Mercury Panel Field Definitions	4
Configure Mercury Terminals	7
Mercury Terminal Field Definitions	9
Configure Mercury Inputs	6
Mercury Input Field Definitions	8
Configure Mercury Outputs	0
Configure Mercury Procedures and Triggers	2
Configuring Procedures	2
Configuring Triggers	4
Configure Mercury Elevators	6
Best Practices	0
P2000 Badge Format212	2
Configure Elevators and Cabinets	5
Elevator Access Control	5
General Overview	5
Basic Definitions	6
Low Level Interface	6
KONE HLI/KONE ELINK High Level Interface	7
KONE IP High Level Interface	7
Otis EMS - Security / BMS Protocol High Level Interface	7
Otis Compass High Level Interface	8
Defining Floor Names	0
Defining Floor Masks	0
Configuring Elevators	1
Elevator Configuration Field Definitions	1
Configuring Floors	5
Configuring Otis Unsecured Elevators	5
Configuring KONE IP Elevators	6
Defining Floor Groups	1
Creating Access Groups for Elevator Floors	1
Cabinet Access Control	1
Defining Door Names	2

Defining Door Masks	233
Configuring Cabinets	233
Cabinet Configuration Field Definitions	233
Configuring Doors	235
Defining Door Groups	
Creating Access Groups for Cabinet Doors	
Configure Message Filtering and Message Routing	236
Operators and Messages	236
Basic Principles and Definitions	236
Sequence of Steps	237
Message Filtering	237
Create Message Filter Groups	244
Message Routing	245
Configuring P2000 Remote Servers	245
P2000 Remote Server Field Definitions	245
Set up Access Groups and Cardholders	247
Create Access Groups	247
Cardholder Options	249
Define Companies and Departments	249
Create Access Templates	251
Access Template Edit Field Definitions	251
Create Badge Formats	252
Create Badge Purposes	253
Create Badge Reasons	253
Create Required Cardholder Fields	254
Create User Defined Fields	254
Define Automatic Employee IDs	256
Entering Cardholders	257
Chapter 2: Operating the System	050
chapter 3. Operating the System	
Providing Access to Cardholders and Visitors	259
Entering Cardholder Information	
Viewing Cardholder Information	
Cardholder Field Definitions	261
Adding a Cardholder Image	264
Adding a Cardholder Journal	264
User Defined Fields	265
Entering Badge Information	267
Badge Field Definitions	
Viewing Badge Data	274
Bulk Badge Change	275

Image Recall	282
Image Recall Filters	282
Image Recall FS (Full Screen)	283
To Activate Image Recall FS:	283
Monitoring Alarms	285
Alarm Configuration	285
Alarm Category	285
Alarm Handling	286
Monitoring Remote Alarms	287
Alarm Monitor Definitions	288
Configuring Alarm Colors	292
Creating Predefined Alarm Response Text	294
Monitoring Alarms Using the SIA Interface	294
Message Forwarding	296
Fire Alarm Control	297
Basic Definitions	297
Basic Fire Alarm Components	298
Fire Alarm Server Configuration	298
Fire Alarm Configuration	299
Fire Alarm Management	300
Controlling Fire Alarm Components	300
Viewing Fire Transactions Using the Real Time List	302
Monitoring Fire Components Using the Real Time Map	302
Viewing and Controlling Fire Components Using the System Status Window	302
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events	302 302
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls	302 302 303
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors	302 302 303 303
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs	302 302 303 303 304
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays	302 302 303 303 304 305
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls. Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls	302 302 303 303 304 305 305
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter:	302 302 303 303 304 305 305 305
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag:	302 303 303 303 304 305 305 305 306
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Flag:	302 303 303 303 304 305 305 306 306
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Flag: To Manually Control a P900 Trigger Event: Security Threat Level Control	302 303 303 303 304 305 305 305 306 306 307
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events	302 303 303 303 304 305 305 306 306 307 307
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls. Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Flag: To Manually Control a P900 Trigger Event: Security Threat Level Control. Defining Security Levels Applying Security Level	302 303 303 303 304 305 305 305 306 306 306 307 308
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Flag: To Manually Control a P900 Trigger Event: Security Threat Level Control Defining Security Levels Applying Security Level Input Point Suppression	302 303 303 303 304 305 305 305 306 306 307 307 308 309
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Flag: To Manually Control a P900 Trigger Event: Security Threat Level Control Defining Security Levels Applying Security Level Input Point Suppression Controlling Areas and Muster Zones	302 303 303 303 304 305 305 305 306 306 307 307 308 309 310
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls. Controlling Doors Controlling Outputs Controlling Panel Relays. P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Flag: To Manually Control a P900 Trigger Event: Security Threat Level Control. Defining Security Levels. Applying Security Level Input Point Suppression. Controlling Areas and Muster Zones. Area Control.	302 303 303 303 304 305 305 305 306 306 307 307 308 307 308 309 310 310
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events	302 303 303 303 304 305 305 305 306 306 307 307 307 308 309 310 310 310
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events	302 303 303 303 304 305 305 305 306 306 307 307 307 308 309 310 310 313
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events	302 303 303 303 304 305 305 305 305 306 307 307 307 307 308 309 310 310 313 315
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Trigger Event: Security Threat Level Control Defining Security Levels Applying Security Level Input Point Suppression Controlling Areas and Muster Zones Area Control Configuring the Area Defining Area Filters Displaying Area Details	302 303 303 303 305 305 305 305 306 306 307 307 307 307 308 309 310 310 313 315 315
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Trigger Event: Security Threat Level Control. Defining Security Levels Applying Security Levels Input Point Suppression Controlling Areas and Muster Zones Area Control Configuring the Area Controlling the Area Defining Area Filters Displaying Area Details. Area Details Field Definitions.	302 303 303 303 304 305 305 305 306 306 307 307 308 307 309 310 310 313 315 315 316
Viewing and Controlling Fire Components Using the System Status Window Fire Component Events Operator Controls Controlling Doors Controlling Outputs Controlling Panel Relays P900 CLIC Controls To Manually Control a P900 Counter: To Manually Control a P900 Flag: To Manually Control a P900 Trigger Event: Security Threat Level Control Defining Security Levels Applying Security Level s Applying Security Level Input Point Suppression Controlling Areas and Muster Zones Area Control Defining the Area Defining Area Filters Displaying Area Details Area Layout	302 303 303 303 304 305 305 305 306 306 307 308 307 307 308 307 310 310 313 315 315 317

vii

Mustering	319
Basic Definitions	319
Sequence of Steps	320
Define Risk Areas and Muster Zones	320
Muster Zone Definition Fields	321
Defining Zone Terminals	
Defining Muster Terminals	
Defining Sequester Terminals	325
Mustering Events	326
Controlling Muster Zones	327
Muster Zone Status and Control Field Definitions	327
Viewing and Printing Muster Transactions in Real Time	
Muster Reports	
Intrusion Detection	331
Basic Definitions	332
Sequence of Steps	
Intrusion Configuration	
OPC Aritech Intrusion Interface	333
Bosch Intrusion Interface	334
Mercury Intrusion Interface	337
Configuring Mercury Intrusion Zones	337
Mercury Intrusion Zone Field Definitions	337
Configuring Mercury Intrusion Areas	338
Mercury Intrusion Area Field Definitions	339
Intrusion Alarms	340
Intrusion Management	
Controlling Intrusion Items Using the Intrusion Control Window	
Viewing Intrusion Transactions Using the Real Time List	
Monitoring Intrusion Using the Real Time Map	
Viewing and Controlling Intrusion Items Using the System Status Window	
Intrusion Events	345
Hours On Site	346
Configuring Hours On Site Zones	
Hours On Site Reporting	
Hours On Site (Detail) Report	
Hours On Site - Simple Report	349
Creating Events	
Using Event Configuration Dialog Boxes	349
Creating Triggers	349
Trigger Field Definitions	351
Creating Actions	351
Event Actions Field Definitions	352
OPC Server Event Actions	353
Counting Events	354
Creating Manual Triggers	355
Monitoring the System in Real Time	356

Creating a Real Time Man	362
Handling Alarms from the Real Time Map	365
Adding Map Attachments	366
Dunlicating Mans	366
Adding Image Sets	
Chapter 4: Advanced Features	
- Partitions	
Partition Types	
Regular Partitions	
The Super User Partition	
Creating Partitions	
Video Imaging	
Video Imaging Specifications	
Defining a Video Imaging Workstation	
Printing a Badge	373
Capturing the Portrait and Signature Images	373
Viewing and Printing the Badge	374
	•••••••••••••••••••••••••••••••••••••••

Msg Rejected Errors	
Action Interlock Errors	
Metasys System Integration	
Defining MSEA Graphics	
Registering the P2000 Server with a Site Director	
Guard Tour	
Basic Principles and Definitions	
Sequence of Steps	
Defining System Hardware for Guard Tour Operation	
Assigning Tour Badges	
Configuring Guard Tours	
Using the Guard Tour Configuration Window	
Timezones, Start and Abort Times	
Additional Guard Tour Options	
Adding Stations to the Guard Tour	
Tour Station Definition Fields	
Controlling Guard Tours	
Guard Tour Handling	
Guard Tour Details	
Guard Tour Notes	
Viewing and Printing Transactions in Real Time	
Guard Tour Reports	400
Tour Configuration Report	400
Tour Transaction History Report	400
Tour Notes Report	400
CCTV	401
Using P2000 functions with the CCTV Feature	402
CCTV Configuration Overview	402
Points to Note	403
Using the CCTV/AV Configuration Window	403
Defining System Hardware for the CCTV Feature	404
Namespace and Database	404
Relationship Between the Namespace and Database	405
CCTV Naming Conventions	405
Naming Items for the CCTV Server Namespace	405
Defining the Number of Namespace Items	406
Number of Default Items Permitted	406
Changing the Number of Namespace Items	407
Switch Protocols	407
Tristate Check Boxes	407
CCTV Components	408
CCTV Server	409
Create and Configure the CCTV Server	409
Edit Server Field Definitions	410
Switches	410
Create and Configure Switches	410

	444
Edit CCTV Switch Field Definitions	
Alarms, Auxiliaries, Macros and Tours	413
Alarms	413
Auxiliaries	413
Macros	413
Tours	413
Edit CCTV Alarm, Auxiliary, Macro and Tour Field Definitions	414
Monitors	
Create and Configure Monitors	414
Edit CCTV Monitor Tabs	415
	416
Edit CCTV Sequence Field Definitions	/17
	۲۱۲. ۸17
Create and Configure Compares	
Edit COTV Compare Take	
Ealt CCTV Camera Tabs	
Camera Auxiliaries, Patterns and Presets	
Camera Auxiliaries	
Patterns	420
Presets	420
Edit CCTV Named Camera Item Field Definitions	421
CCTV Control	421
CCTV Standard Controls	422
Selecting the Item to Control	
Operating the Controls	
Using Switch Controls	
Selecting a Switch	423
Selecting a Tour, Macro or Switch Auxiliary	423
Using Tour, Macro or Switch Auxiliary Controls	423
Using the Monitor Controls	121 121
Selecting a Monitor	+224 ۸۵۸
Selecting a Normon	424
Selecting a Sequence Controls	424
Using Sequence Controls	
Selecting a Camera	
Selecting a Pattern, Preset or Camera Auxiliary	
Using Pattern, Preset or Camera Auxiliary Controls	425
CCTV Event Actions	426
CCTV Event Action Field Definitions	427
CCTV Reports	428
CCTV Switch Report	428
CCTV Monitor Report	428
CCTV Camera Report	
CCTV Summary Report	
VR	
edundancy	429
DA Part 11	429

Intercom	
Hardware Requirements	430
Intercom System Hardware Verification	431
Intercom Configuration	431
Intercom Exchange	431
Intercom Stations	434
Intercom Control	436
Controlling Intercom Stations using the Real Time Map	
Intercom Events	438
Intercom Transaction History Reports	
P2000 Enterprise	439
Enterprise Parameters	440
Assign Cardholders Enterprise Access	441
Define Global Badge Access Rights	
Web Access	
Sequence of Steps	
Creating and Assigning Web Access Menu Permissions	444
Defining Web Access Options	445
Web Access Options Field Definitions	445
Defining Request Approvers	447
Submitting Requests using Web Access	450
Web Access Functions	450
Employee Services	450
Guard Services	451
Management Services	451
Visitor Management	452
Emergency Access Disable	453
Processing Web Access Requests	453
Visitor Request Management Field Definitions	455
Customizing the Web Access Interface	457
Assigning Styles to Web Access Users	457
Web Access Smart Card Encoder Configuration	458
-	
Chantor 5: System Maintonance	400
Downloading Data to Panels	
Monitoring Downloads	
Controlling Smart Download	
Controlling P2000 Services	
Service Startup Configuration	
P2000 Services Definitions	
Starting and Stopping Service Control	
Controlling Services through the Service Monitor	
Viewing Workstation Status	
Automatic Software Updates	
Viewing System Status	

Writing Panel Database to Flash Memory	482
Updating CK7xx Panels	482
Updating S321-DIN Panels	484
Updating Mercury Panels	485
Performing Database Maintenance	486
To Perform Database Maintenance Functions	486
Database Maintenance Actions	487
Database Backup	490
Configuring a Backup Device	490
Manual Backups	491
Advanced Backups	491
Automatic Backups	492
FDA Part 11 Backups	493
Database Restore	493
System Validation	495
CK721-A and S321-IP Data Import and Export	496
Importing CK721-A and S321-IP Data	496
Evaluating Imported Data	499
Saving the Log File	501
Exporting CK721-A and S321-IP Data	501
Evaluating Exported Data	502
Viewing Request Queue	502
Searching Specific Requests	504
Viewing Request Details	505

Chapter 6: System Reports

apter 6: System Reports	507
Using P2000 Standard Reports	507
P2000 Standard Report Definitions	510
Selected Sample Reports	515
Run the Alarm History Report	515
Run the Cardholders - Preprocessed Report	517
Run the Cardholders without Badges Report	519
Run the Panel Report	520
Run the Transaction History Report	521
Creating Custom Reports	522
Creating a Custom Report Using SAP Crystal Reports	522
Database Table Definitions	522
To Import a Custom Report into the P2000 System	522
Editing a P2000 Standard Report in SAP Crystal Reports	523
To Export an Existing Standard Report from the P2000 System	523
To Edit the P2000 Report in SAP Crystal Reports	523

Appendix A: Event Triggers/Actions	
Trigger Types	525
Category Alarm	525
Category: Area	
Category: Audio-Visual	
Category: Audit	527
Category: Radae	
Category: Counter	
Category: External Trigger	
Category: Ere Detector	
Category: Fire IO Module	529
Category: Fire Panel	529
Category: Fire Zone	529
Category: Inputs	529
Category: Integration Component	
Category: Intercom	
Category: Intrusion Annunciator	
Category: Intrusion Area	
Category: Intrusion Device	
Category: Intrusion Zone	
Category: Mustering	
Category: Operator	
Category: Outputs	
Category: Panel	
Category: Terminal	533
Category: Time Zone	534
Category: Time/Date	534
Event Action Types	535
Category: Audio-Visual	535
Category: BACnet	536
Category: Badge	536
Category: CCTV	536
Category: Download	536
Category: Fire Detector	537
Category: Fire IO Module	537
Category: Fire Zone	537
Category: Host	537
Category: Inputs	540
Category: Intercom	540
Category: Intrusion Annunciator	540
Category: Intrusion Area	540
Category: Intrusion Zone	540
Category: Metasys Interlock	541
Category: Mustering	541
Category: OPC Server	541

Category: Outputs	541
Category: Panel	541
Category: Security Level	541
Category: Terminal	542
Appendix B: Message Types and Sub-Types	.543
Appendix C: Panel Comparison Matrix	547
Appendix D: CCTV Switch Protocols	553
Communications	553
Communications	
Monitor Sequences	
Conoral ASCII Protocol	
Commande Supported	
American Dynamics	
American Dynamics Protocol	555
Supported CCTV Controls	555
Supported CCTV Event Actions	555
Supported OPCWrite Event Actions	556
Auto Repeat Actions	556
Automatic Status Undate Tags	556
Maximum and Default Values	556
BetaTech	
Switch Configuration	
Keyboard 16 Commands	
BetaTech Parameters	
Supported CCTV Controls	
Supported CCTV Event Actions	
Supported OPCWrite Event Actions	
Auto Repeat Actions	
Automatic Status Update Tags	
Maximum and Default Values	
Geutebrück - GST Interface	
Geutebrück Parameters	559
Supported CCTV Controls	559
Supported CCTV Event Actions	
Supported OPCWrite Event Actions	
Macros	
Camera Auxiliaries	
Monitor Sequences	561
Auto Repeat Actions	561
Automatic Status Update Tags	561

Maximum and Default Values	561
Panasonic®	562
Switch Configuration	562
Panasonic SX850 Parameters	562
Supported CCTV Controls	562
Supported CCTV Event Actions	
Supported OPCWrite Event Actions	563
Camera Movement Commands	563
Auto Repeat Actions	563
Automatic Status Update Tags	563
Maximum and Default Values	563
Pelco®	564
Pelco 9760 Protocol	564
Supported CCTV Controls	564
Supported CCTV Event Actions	565
Supported OPCWrite Event Actions	565
Auto Repeat Actions	565
Automatic Status Update Tags	566
Macro Programming	566
Recording Patterns	566
Maximum and Default Values	566
Philips Burle (Bosch®)	567
Switch Macros	567
Philips Burle Parameters	567
Supported CCTV Controls	568
Supported CCTV Event Actions	568
Supported OPCWrite Event Actions	568
Auto Repeat Actions	568
Automatic Status Update Tags	568
Maximum and Default Values	569
Cabling Configuration	569
Ultrak®	570
Switch Configuration	570
Keyboard 64 Commands	570
Ultrak MaxPro-1000 Parameters	570
Supported CCTV Controls	570
Supported CCTV Event Actions	570
Supported OPCWrite Event Actions	571
Auxiliaries	571
Monitor Sequences	571
Auto Repeat Actions	571
Automatic Status Update Tags	571
Maximum and Default Values	571
Vicon®	572
Switch Configuration	572
Vicon Parameters	572

Supported CCTV Controls	572
Momentary and Latched Auxiliaries	573
Camera Lens Speed Control	573
Supported CCTV Event Actions	573
Supported OPCWrite Event Actions	573
Auto Repeat Actions	574
Automatic Status Update Tags	574
Maximum and Default Values	574

Appendix E: CCTV Server Namespace Definitions

Flags	
Notes	
Namespace Tags	576
Switch Namespace Tags	576
Monitor Namespace Tags	581
Camera Namespace Tags	
Macro Namespace Tags	587
Auxiliary Namespace Tags	587
Tour Namespace Tags	587
Alarm Namespace Tags	587
Sequence Namespace Tags	588
Pattern Namespace Tags	588
Preset Namespace Tags	588

Appendix F:	DCOM Configuration	589
DOOLL		

DCOM Installation	36)
-------------------	----	---

To invoke access with PIN Only:	591
To invoke access with Card ID:	591
To invoke access with PIN and Card ID:	591
To invoke access using PIN and Badge:	592
To invoke access with PIN and Badge, allowing PIN after Badge:	592
Invoking Air Crew Access Requests from a Keypad	592
To invoke Air Crew access:	592
Invoking Timed Overrides from a Keypad	592
To invoke Timed Override with Badge:	592
To invoke Timed Override with PIN Only:	
To invoke Timed Override with Card ID.	593
To invoke Timed Override with PIN and Card ID:	593
To invoke Timed Override with PIN and Badge:	594

To invoke Timed Override with PIN and Badge, allowing PIN after badge:	594
Invoking Panel Card Events from a Keypad	595
To invoke Panel Card Events with Badge:	595
To invoke Panel Card Events with PIN Only:	595
To invoke Panel Card Events with Card ID:	595
To invoke Panel Card Events with PIN and Card ID:	596
To invoke Panel Card Events with PIN and Badge:	596
To invoke Panel Card Events with PIN and Badge, allowing PIN after badge:	597
Quick Guide to Using Keypad Readers	597
Appendix H: Troubleshooting	601
Authentiantian Dragon	601
Mindawa Authontication	1 00 ۵۵1
SOL Sonver Authentication	1 00 601
D2000 Authentication	100 203
F2000 Authentication	002 602
Troubleshooting Workstation Problems	002 602
P2000 Login Troubleshooting	200
P2000 Network Troubleshooting	003 M0A
CCTV Control Troubleshooting	605
Appendix I: Secured Premises Notification Settings	607
Configuration	007 607
Conliguiation	100 ۵۵۵
Sequence of Events	000
Appendix J: Secured Premises Notification Settings for Merc	ury
Panels with Keypad DM-21 (MRDT)	609
Index	611

Chapter 1: Introduction

he Johnson Controls® P2000 security management system represents the latest technology in integrated security solutions. Using Microsoft® Windows® operating systems, operators can easily configure and use the P2000 software.

Through its intuitively laid-out menus, users can create cardholder records, define hardware components, and control access using badging, Closed Circuit Television (CCTV), Digital Video Recorder (DVR), area control, mustering, and elevator control to name a few, as well as monitor local and remote transactions and alarm activity in real time.

Note: The screen captures shown in this manual may differ slightly, depending on the software version you are using.

Getting Started

Operators familiar with Windows-based programs should easily master the P2000 software. This manual provides complete instructions on configuring and operating the system; and virtually the entire manual content is accessible from the P2000 online Help.

Take a few moments to review the information in this chapter and get familiar with the P2000 system basics.

Chapter Summaries

- Chapter 1: Introduction. Presents the conventions used throughout this manual, an overview of basic system components, and menu options available in the system. The system overview familiarizes you with P2000 system capabilities and how to log on, log off, and navigate through the system.
- Chapter 2: Configuring the System. Directs you through tasks to properly configure your system for operation. Elements featured in this chapter include: Workstations, Operators, Permissions, Site Parameters, Local Configuration, Time Zones, Holidays, Panels, Terminals, Input and Output definitions, Elevators and Cabinets, Message Filtering and Routing, Access Groups, and Cardholder Options.

 Chapter 3: Operating the System. Describes the primary features used to run the P2000 system. It shows you how to provide access to cardholders and visitors, monitor alarms, control doors, set outputs and panel relays, control areas and muster zones, control and detect intrusion in a facility, create events, and monitor the system in real time.

 Chapter 4: Advanced Features. Describes features that provide a more efficient way to operate and monitor your access control system. These include Partitioning, Video Imaging, MIS Interface, Metasys® Integration (BACnet), Metasys System, Guard Tour, CCTV, DVR, Redundancy, FDA Part 11, Intercom, P2000 Enterprise, and Web Access.

- Chapter 5: System Maintenance.
 Describes the tools available to maintain your system in optimum operating condition.
- Chapter 6: System Reports. Includes a complete list of P2000 Standard Reports, along with a brief description of each and how they might be used.
- Appendix A: Event Triggers/Actions. Lists all trigger categories, types, conditions, and event action types available for Event configuration.
- Appendix B: Message Types and Sub-Types. Lists all message types and sub-types available for Message Filtering.
- Appendix C: Panel Comparison Matrix. Lists the panel types supported by the P2000 system, including their features and capabilities.
- Appendix D: CCTV Switch Protocols. Describes the CCTV Switch Protocols that are supported by the CCTV feature.
- Appendix E: CCTV Server Namespace Definitions. Describes the CCTV Server namespace tags.
- Appendix F: DCOM Configuration. Describes changes to the DCOM settings that need to be made to assure proper CCTV configuration.
- Appendix G: Using a Keypad Reader on CK7xx Panels. Presents the sequence of actions at a keypad reader.
- Appendix H: Troubleshooting. Explains connection problems and how to solve them.
- Appendix I: Secured Premises Notification Settings. Describes the sequence of actions needed to notify operators when a panel card event is used to unsuppress alarm signals.
- Appendix J: Secured Premises Notification Settings for Mercury Panels with Keypad DM-21 (MRDT). Describes the sequence of actions needed to notify operators when a Mercury intrusion keypad terminal is used to unsuppress alarm signals.

Manual Conventions

The following terms and conventions are used throughout this manual.

Note: Notes indicate important points or exceptions to the information provided in the main text.

TIP: Tips describe time-saving or additional information.

IMPORTANT: Important messages remind you that certain actions, if not performed exactly as stated, may cause damage to equipment or make your system non-operational.



Provides essential information relevant to the program.

Basic System Components

The following terms describe the P2000 system, including hardware and software terms, computer equipment, and field equipment. Components are shown in two basic configurations: Figure 1-1 displays the P2000 system with network panels and Figure 1-2 displays the P2000 system with serial panels. For hardware installation of OSI, Isonas, HID®, Assa Abloy®, and Mercury panels, refer to the manufacturer's documentation.

P2000 Server – The main computer in the system. The system Server runs the P2000 system software, stores database information, and communicates with the field panels. The P2000 Server may also be referred to as the Database (DB) and Communications (Comms.) Server.



Figure 1-1.P2000 System with Network Panels

IMPORTANT: We recommend the system Server be used only as a Server and not as an additional day-to-day workstation. You must protect the Server from physical access by unauthorized users. Use the Server only for those tasks that must be performed from the Server.

Workstations – Workstations allow additional users to monitor and configure the P2000 system. Workstations communicate with the Server via an Ethernet TCP/IP local area network (LAN).

P2000 Enterprise – System that consists of one or more P2000 sites.

P2000 Site – Uniquely identified by its local site name. A P2000 site can have multiple locations but only one P2000 Server.

P2000 Location – A physical location or place with a P2000 workstation, panel, terminal, input, or output point.

Encryption – All real-time messages from the P2000 server to services and workstations are encrypted using Advanced Encryption Standard (AES) with a 256-bit key.



Figure 1-2.P2000 System with Serial Panels

System Printer – System printers, connected either to the Server or to workstations, provide real-time transaction printing or report printing capabilities.

Field Panels – This term refers to CK7xx, S321-IP, OSI, Isonas, HID, Assa Abloy, and Mercury network panels or S321-DIN, S320, D6xx series (D620, D620-TIU, and D600 AP), and P900 serial panels. These connect to terminals and communicate with the Server. S320 and D6xx series panels are also called *legacy panels*. See Appendix C: Panel Comparison Matrix for a detailed list of features and capabilities.

Note: Throughout this manual, the term CK7xx refers to CK705, CK720, CK721, and CK721-A panels.

Terminals – Terminals provide a point of contact with panels to facilitate a variety of functions. Depending on your panel type, some terminal boards can be used to connect readers, input points, and output points and can be mounted in the basic panel enclosure or an expansion enclosure. CK7xx terminals support the following module types: 116, IO8, SI8, SIO8, RDR2, RDR2S, RDR2S-A, and RDR8S. For D620, D620-TIU, and D600 AP panels, terminal hardware boxes, such as an STI/STI-E (Reader, I/O), AMT (Alarm Monitoring), or OCT (Output Control), provide the reader and input point or output point connection.

External Device – This general term describes any device wired to one of the terminal types, such as readers, motion sensors or other input devices, door strikes, or audible alarm devices.

Main Menu

The Main menu is the backbone of the P2000 system. From here, you select each feature and option available in the system. While logical operation of the system does not follow the Main menu from right-to-left, every menu and option is displayed.



© 2014 Johnson Controls, Inc.

Registration Parameters

Parameters associated with your system, such as maximum number of badges, terminals, and workstations are enabled via the entry of a Registration Key. Also, if your system takes advantage of advance features such as Enterprise or integrate with third-party hardware such as OSI devices, it requires the entry of Option Keys to control those features (some of these features must be selected during installation). Both the Registration and Option keys are provided by Johnson Controls and are associated with your purchase contract. Refer to the *P2000 Software Installation* manual for instructions.

System Overview

This section is designed to help P2000 users understand basic operation before configuring the system. The following topics are covered:

Basic Configuration – Describes an overview of system configuration.

Communication Modes – Describes P2000 system operating modes and communications types.

Access Requests – Shows how the system determines whether a cardholder is granted or denied access at a door.

Controlling Special Access – Describes features that can override normal system operation.

Alarms – Describes various types of alarms.

Non-alarm Input Points – Provides a basic description of input points.

Output Relays – Provides a basic description of output relays.

Events – Describes how input points and output relays can be manipulated automatically or manually in various ways to create events.

Database Partitioning – Provides an overview of how database partitioning is used within the P2000 system.

Basic Configuration

Network Communication

CK7xx panels support terminals, readers, input, and output devices, and connect to the P2000 Server via a network card. Each panel has an embedded 32-bit processor, with 16-reader capability for CK720s and CK721s, and 4-reader capability for CK705s. CK721-A Version 3.0 and later supports 32 readers.

S321-DIN panels can also connect to the P2000 Server through the network using a Digi® One® SP converter box. S321-DIN panels have 2-reader capability.

You can configure an entire system using CK7xx panels, or use them in combination with S321-DIN, S321-IP, P900, and legacy panels; or use third-party devices such as OSI, Isonas, HID, Assa Abloy, or Mercury panels.

A single workstation is shown in Figure 1-1 on page 3; however, a fully configured Server can support multiple workstations. The number of workstations (including the Server) depends on the type of system you purchased.

If Integrated Video Imaging is part of the configuration, the Video Imaging workstation is attached to the network similarly to the workstations.

Loop Communication

In a combined P2000 system configuration, the Server connects via a current loop configuration to P900 and legacy panels, using an AccelePort® connector box and a PC232 converter (legacy only). S321-DIN panels can also connect to the Server via a current loop configuration using an RS232-to-RS485 converter connected to a built-in serial port. The P2000 loop system can support up to 32 loops, with up to sixteen legacy panels per loop, up to sixty-four P900 panels per loop, or up to thirty S321-DIN panels per loop. Different panel types cannot be mixed within one loop.

Forward and Reverse – Forward and reverse are terms used to describe the direction the Server *polls*, or communicates with legacy panels in the loop configuration.

During operation, the Server contacts each panel to determine if the panel has information it needs to send to the Server. Each panel is polled in sequence. Panels may be polled in either forward or reverse direction. Once a polling sequence begins, each panel is polled until all panels in the loop are polled.

If communication is interrupted on one direction, the Server polls in the opposite direction to ensure that all panels are polled. All loops in the system are polled simultaneously.

Legacy panels should be installed in a loop configuration to allow the Server to continue communication with all panels should a break in the loop occurs. For example, if a break in communication occurs at point A (see Figure 1-2 on page 4), the P2000 Server automatically begins polling in the opposite direction to reestablish communication with panels on one side of the break or the other. Polling automatically continues in both directions until the link is repaired, as long as the loop configuration is utilized.

Communication Modes

The P2000 Server communicates with panels that provide reader interfaces, input points, or output relays. Communication is bi-directional, some messages are sent from the Server to the field panels, other messages are sent from the panels to the Server, and then can be distributed within the system (through workstations). The volume of messages across the communication link depends, in part, on the overall operating mode of the system.

While several factors affect overall system performance (performance is defined as the speed with which communication occurs between the Server, workstations, and field panels), the most significant factor is operating mode, which is defined when configuring the system. The P2000 system provides the following three operating modes:

Local – In this mode, the field panels make all access decisions. This eliminates the need for panels to communicate with the Server every time an access request is presented at a reader. Local mode provides the best overall system capability; however, access is denied to those badges not stored in the panel memory.

Central – This mode is useful when you want to assign access restrictions on a global scale (throughout the entire system). All access requests are forwarded to the Server for an access grant or deny decision. Central mode has the most impact on system performance (the slowest), and should be used only when necessary.

Shared – Access decisions are made either at the panel level or by the Server. Field panels first search for a badge in their memory, as in Local mode. If a badge's record is not found at the panel level, the access request is then forwarded to the Server, as in Central mode. Shared mode is useful when a panel's badge capacity is exceeded. Shared mode is the preferred method of operation. This mode not only gives you the high performance of Local mode for badges stored in the panel memory, but also gives proper access to all badges even if they are not stored in the panel memory.

Types of Communication

The P2000 Server communicates with system field panels via Transactions, Downloads, and Commands.

Transactions – Transactions indicate some form of system activity. They can include items such as access requests and general system messages such as when a panel loses communication with a reader. Typically, transactions represent communication initiated at field panels and sent to the P2000 Server.

Downloads – Downloads refer to the transfer of system configuration information from the P2000 Server to the memory of the field panels. This includes information such as badge records and access rights. Network panels can be downloaded in minutes using the download feature. Serial panels take a longer amount of time to download.

Commands – Commands, such as opening a door manually, are initiated at the Server and sent to the appropriate panels.

Access Requests

The basic function of the P2000 system is to grant or deny cardholders access to areas in and around your facility or facilities.

The P2000 system makes access decisions based on:

- Time and time zones
- Valid or invalid badges
- Badge privileges

Time and Time Zones

Almost every P2000 system feature can be controlled by time. This includes basic access where readers and badges can be enabled or disabled. By configuring time zones, you can determine the following:

- when any reader-controlled door in your facility can grant access to a valid badge
- at which times during a 24-hour period a cardholder can be granted access at a reader-controlled door
- reader override

Valid or Invalid Badges

The P2000 system provides many methods for you to determine what constitutes a valid badge in your system. These include the use of the following:

- Facility codes
- Encoded badge number
- Issue level
- Expiration date
- Badge time zones
- Badge access groups

Badge Privileges

Badge privileges relate to the time of day, areas, and access groups a cardholder can be granted access. A badge can be valid in all other respects, but the cardholder can be restricted as to the times and days they can enter your facility, or an area within the facility. The P2000 system also provides the means to grant cardholders special privileges, which is also described as *special access*.

Controlling Special Access

In addition to basic access, operators can control special access for overriding the normal operation of the system. The two main categories for special access are:

- Overriding basic access
- Granting badge privileges

Overriding Basic Access

In most cases, you may want to configure the P2000 system for basic access control and also provide the means for special access. In general, special access may be necessary at predetermined times or may be random occurrences as circumstances warrant. The P2000 system allows you to account for both, with features such as the following:

Timed Override – A door can be automatically unlocked between specified times.

Extended Access – A door can be manually unlocked and propped open as needed.

Auxiliary Access – An external device, such as a push button, can temporarily open a door without the use of a badge or PIN code.

Granting Badge Privileges

The other means of providing special access is through badge privileges. Privileges are configured as part of a badge's definition. Badge privileges allow the cardholder the following access:

- access to the facility outside normal operating hours.
- access using different access times, to satisfy the requirements for assisted access according to ADA (Americans with Disabilities Act).
- extended access by manually executing override features.

Alarms

Another fundamental principle of P2000 system operation is to report alarm activities. Alarms can be triggered by several methods including the following:

- External device alarms
- Door alarms
- Software-only alarms
- P2000 host alarms
- Remote alarms

External Device Alarms

External devices, such as motion or glass break sensors, can be wired to P2000 input points. When these devices become active, as in a motion sensor detecting movement, they trigger the input point, which causes an alarm. You can define how input points respond when activated, whether or not they trigger output relays, and at which times an alarm can be activated. This offers you the flexibility of automating the alarm operation.

Door Alarms

When a door is unsecured because of unauthorized activities, the door is considered to be in a forced alarm state and is reported to the system. The system can also monitor cases where the door is propped open after a valid access grant.

Software-Only Alarms

Software-only alarms are unlike external device alarms in that software alarms are triggered by system activities (such as when a panel loses AC power), rather than by external devices, which are wired to the system panels and terminals.

P2000 Host Alarms

The P2000 system also reports host alarms, such as alarms originated by P2000 event actions, mustering alarms, or FDA record retention alarms.

Remote Alarms

These are external device alarms, door alarms, software-only alarms, and host alarms that are generated at remote sites.

Non-alarm Input Points

The P2000 system allows you to use input points for activities other than alarms. For example, a motion sensor wired to an input might be used to turn on lights.

Output Relays

Where input points are triggered by external devices, output relays allow you to trigger external devices using the P2000 system. These devices might include warning indicators for alarm situations or non-alarm related functions such as lighting or environment control. In general, output relays are activated by one of the following:

- Input and output linking
- Events
- Manually

Input and/Output Linking

The P2000 system allows you to form individual output relays into groups (as a note, you can also group input points). The primary purpose of linking inputs to output relays is to trigger external devices, such as:

- in emergency situations, using room lighting or warning indicators like flashing lights or sirens,
- automatically activating a building function such as lighting or environment control.

Activating Outputs by Events

As an alternative to input and output linking, output relays can also be activated either manually or automatically by events.

Activating Outputs Manually

Operators can manually activate outputs using the P2000 Output Control application.

Events

Events are sequences of system commands or actions that may be activated at a predefined time or on an as-needed basis. You can use the P2000 system to activate and deactivate events either manually or automatically. Examples of events include the following:

Card Events – A badge is assigned event privileges and may execute an event from a reader equipped with a keypad.

Timed Events – Events are assigned specific activation dates and times, and are activated or deactivated automatically by the P2000 system.

System Events – Event triggers can be based on a variety of system activities, such as when an operator attempts to log on with an invalid user name or password.

Database Partitioning

You can divide the P2000 database into smaller sections that can be individually managed. Database partitioning structures define what data is accessible by an individual operator, or by a group of operators. You can create as many partitions as you need, depending on your system requirements. After partitions are created, they can be assigned to all major system components. See Partitions on page 369 for more information.

There are two types of partitions:

Super User – This partition is automatically created by the system and is the main partition in the database. Only one Super User partition can be defined. This partition can be assigned to multiple operators and has access to all partitions of the system.

Regular – Regular partitions are assigned to operators. These partitions allow the operator to add, modify, delete, or view records within their assigned partition.

If you are new to the P2000 system or new to security management in general, it is important you have at least a basic understanding of these principles before configuring the system. What is important to keep in mind is the relationship between the various system features.

As you work through Chapters 2 and 3, these principles are reinforced as you learn which options relate to which specific system features.

Logging On to the P2000 System Software

The P2000 system uses a user name and unique password to establish each authorized user. Passwords are used to protect access within a database or system. A password is a unique combination of alphanumeric characters, such as in a string of letters and numbers.

Logging on to the P2000 system is similar for the Server and for a workstation.

 Double-click the P2000 icon on your Windows desktop,



or, from your Windows desktop, select Start>Programs>Johnson Controls> P2000>P2000. The Login window opens.

Login	×
	P2000 SECURITY MANAGEMENT
	Johnson WC
User Name	Cardkey
Password	Cancel

- 2. Place the cursor in the User Name field and enter **Cardkey**.
- Press < Tab> to move to the Password field and enter master.
- 4. Click **OK** or press **<Enter>** to continue. The P2000 Main menu bar displays.
- The upper-right corner displays Super User as the default Partition option. Operators that belong to the Super User partition have access to all areas of the P2000 program, see Partitions on page 369.

Note: By default, the Alarm Monitor window automatically opens when logging on to the Server. For detailed information, see Monitoring Alarms on page 285.

Changing the Default Login Values

By using the default User Name and Password, whether at the Server or at a workstation, you are logging on to the system with Super User privileges. This account has, by default, full privileges for viewing and changing system parameters. After initially logging on to the system, you have the option to change the default login User Name and Password to prevent unauthorized users full access to the system.

You cannot remove the default account from the system. Instead, use the following steps to change the default user name and password, thereby restricting access to the Super User account.

To Change the Default User Name and Password:

1. From the P2000 Main menu, select **Opera**tor>**Operator Account/Profile**.



 The password verification dialog box displays. Type master and click OK or press <Enter> to continue.

Dperator Account/Profile	
Password Verification Required	
Password xxxxxx	
OK Cancel	

The Operator Account/Profile window displays.



4. For new systems, the only User Name is the default Cardkey. Select Cardkey and click **Edit**. The Edit Operator dialog box opens.

Note: You must log off from the P2000 system for the changes to take effect (see the following section for details).

5.	Information for the Cardkey user displays.
	To change the User Name and Password,
	go to each field and enter the new informa-
	tion.

6. Re-enter the password in the **Confirm Password** field.

missions Partitions Remote Partitions Concealed UDFs

User Type P2000 Accourt

ord

ord

Filter Group |<none>

sing Group

Create NT user account on server User must change password at next logon

C Password expires

count Type

Verify Password for Critical Functions

Allow Multiple Alarm Handling

OK

Cancel Apply

▼ P2000 ▼ MIS

•

IMPORTANT: Once you change the default login password, you can only use the new User Name and Password to access the Super User account.

- 7. You may also enter the **Full Name** of the operator assigned to the User Name. For more details on adding operator information into the P2000 system, see Adding Operators to the System on page 21.
- 8. Click **OK** to save your settings.
- 9. Click **Done** to close the window.

System Software

After changing the default User Name and Password, you must log off from the P2000 system. You are not required to shut down the Server or workstation.

Logging Off from the P2000

To Log Off from the P2000 System:

1. From the P2000 Main menu, select Exit>Exit.



2. The system prompts for logoff verification.

P2000		×		
Are you sure you want to logoff and exit P2000?				
Yes	No			

3. Click **Yes** or press **<Enter>**. The system returns to the Windows desktop.

Navigating through the P2000 System

The P2000 system provides an easy-to-use graphical user interface (GUI) for making selections and entering data.

Mouse Conventions

The standard pointing device for the P2000 Server and workstations is a two-button mouse. The left mouse button is the primary mouse button. The following terms are used throughout this manual to describe how you navigate through the P2000 system.

Pointer – The pointer may display differently depending on the action that you are performing. For example, the pointer is normally an arrow, but changes to an hourglass to denote the system is saving, retrieving, or compiling information. When in a text field, the pointer changes to a cursor.

Select – This term directs you to select a menu, submenu, or list item. For example, *select Control>Output Control* means to click on the Control option from the Main menu bar, then click on the Output Control submenu.

Clear – Click again on a selected radio button or check box to clear the option.

Click – Press and release the left mouse button once. Note that *click* always refers to the left mouse button, unless the right mouse button is specifically called out in the text.



Double-click – Quickly press twice and release the left mouse button.

Click and Drag – Press and hold down the left mouse button to select an item, drag and point to where you want to place the object; then release the mouse button.

Instruction Conventions

For clarity, the following convention is used throughout the manual for selecting P2000 menus, submenus, and options:

From the P2000 Main menu, select **Config>** Cardholder Options>Company.

In this example, click the **Config** option from the P2000 Main menu bar, then click the **Cardholder Options** menu, and then click the **Company** submenu item to open the *Company* dialog box.

Config Options View He	elp
Local	
<u>S</u> ystem	
Cardholder Options	⊆ompany
Integrated Badging	Department N Access Template
Map Maker Icon Editor	Required <u>F</u> ields <u>U</u> ser Defined Fields
Area Layout	Badge <u>F</u> ormat
<u>P</u> 2000 Badge Førmat	Badge <u>P</u> urpose
	Badge <u>R</u> eason
	Auto Employee ID
/	

An arrow indicates there are submenus for this menu item.

Menu Shortcuts

In the P2000 system the mouse is normally used, but you may also use key combinations to select the menus and submenus from the Main menu bar, or to open windows.

To Select Menus or Submenus Using a Menu Shortcut:

- 1. Select the P2000 Main menu bar as the active window.
- 2. Press <**Alt**> + <the underlined letter shown on the Main menu bar>.
- 3. Once a Main menu is open, simply press the underlined letter of the submenu item you wish to select.

To Tab through Open Windows on the Screen:

 When you have several windows open, you can press <Alt> + the Tab key to bring open windows forward and make them active, including the P2000 window.

To Tab through Fields on a Window:

1. Once an active window is selected, you can use the **Tab** key to tab through fields on the window.

Verification Passwords

The P2000 software offers added security by requiring operators to verify their login password when performing certain system-critical functions. If this option is selected in the Edit Operator dialog box (see page 25), when operators access some functions, a password verification dialog box displays for the operators to enter their login password.

Operator Account/Profile	
Password Verification Required	
Password ×××××	
OK Cancel	

The purpose of a verification password is to prevent unauthorized users from performing system-critical functions at unattended PCs.

Context Sensitive Help

Help is available from most P2000 windows or dialog boxes by pressing F1. Once you press F1, help text for the selected item displays in a separate window.

Online Help

The P2000 software contains virtually the entire User's Guide in online documentation accessed via the Help option on the Main menu. You can also press **F1** for context-sensitive help from most windows in the program and most individual fields.

Access information under Introduction, System Configuration, System Operation, Advanced Features, System Maintenance, or System Reports; or use the Index to search for specific topics.

P2000 Tutorial

The tutorial presents an overview of the P2000 security system's major features and options. It also covers several system configuration, installation, and troubleshooting tips. Adobe® Flash is required to run the tutorial and can be installed when you start the tutorial program from the Help option in the P2000 menu bar.

The modular design enables navigation to all or specific tutorial topics. The tutorial introduces topics and sub-topics, which are discussed through Flash presentations that provide audio narration (with matching text if desired) to guide users on how to make the most of P2000 main popular features. Software screenshots are used to walk the user through actual configuration and installation steps.

Viewing the Toolbar

The toolbar gives you easy access to the more commonly used windows in the P2000 system.

To Use the Toolbar:

 If the toolbar is not visible, from the P2000 Main menu select View>Toolbar. The toolbar displays.



Click and drag to another position

- 2. Place the mouse over an icon to display the name of the icon.
- To open a dialog box from the toolbar, click the desired icon. Choices are: Access Cardholder, Alarm Monitor, Real Time List, Real Time Map, System Configuration, System Status, Security Level Control, and Launch AV Player (if the DVR option is available in your facility).
- 4. To position the toolbar anywhere on the screen, double-click the left handle, click the title bar and drag it to the desired position.
- To close the toolbar, click the Close button, or select View>Toolbar from the P2000 Main menu.

Note: A Partition selection box is available on the right side of the toolbar and can also be positioned anywhere on the screen
Chapter 2: Configuring the System

o operate your P2000 Security Management System, you must set up and configure the software to communicate with the system hardware. After you complete all hardware installations, you are ready to configure the P2000 software. Configuration is typically performed by a System Engineer or System Administrator.

System Configuration Overview

Configuration should progress in a logical sequence. For example, you must configure the system site parameters before you can assign them to panels; you must configure panels before you can assign terminals to them; and you must configure terminals before you can create terminal groups, inputs, and outputs. This chapter guides you through a logical progression. After you configure the system, you always have the option to return to a component and make changes if necessary.

The following elements must be set up to complete system configuration:

- Set up Workstations and Operators
- Configure System Components
- Configure Hardware Components
- Configure Elevators and Cabinets
- Configure Message Filtering and Message Routing
- Set up Access Groups and Cardholders

After you configure your system components, these items are available to you as you work your way through hardware configuration. The parameters set up during hardware configuration are accessible when you begin creating your database. As soon as the system is completely configured, you are ready to begin system operation.

Note: We recommend you develop a naming convention plan to apply to panels, terminals, inputs, outputs, and other system components when you configure the P2000 software. The following characters are not allowed when defining P2000 components: @., ? * # : "/ [] <> | \$.

Using the System Configuration Window

The System Configuration window provides quick access to many component configurations. Select **Config>System** from the P2000 Main menu bar and enter your password if prompted. The System Configuration window opens, as shown in the following page. All root items in the system configuration tree display on the left side of the window (windowpane). A plus (+) sign next to an item indicates that branches exist beneath them. When you select a branch in the tree, the detailed settings and values relating to that selection are listed on the right windowpane.

You can add as many items to the configuration as you need, depending on your Registration Parameters. After you add items to the system, you can modify them as desired.

Show For Super User		•	<u>S</u> earch
Show For Super User	×	Item Partition Public Name Default Timezone Enabled Terminal Terminal Details Terminal Elevator Reader	Value Super User No Warehouse Group Ful Time Yes Elevator Reader North Entrance Shipping Area Reader Time Zone Full Time
Daily Access Warehouse Group Terminal Groups Elevator/Cabinet Parameters Panels	•	4	

To Add an Item to the System Configuration:

 From the configuration tree, select the item you wish to add, and either click Add at the bottom of the window, or right-click to access a shortcut menu and select Add. The appropriate dialog box opens.

2. After you add the information according to the field definitions, click **OK** to return to the System Configuration window. When dialog boxes offer several configuration tabs, such as in the Panel or Terminal Edit dialog boxes, continue to the next tab, as applicable. After you enter all settings, click **OK** to save your data and return to the System Configuration window. The settings for the new item are listed on the right windowpane. 3. Continue to add items in this manner until all components and their related controls are configured in the P2000 system.

To Edit System Configuration Items:

- 1. From the configuration tree, select the item you wish to modify and click **Edit** at the bottom of the window (or right-click the item and select **Edit** from the shortcut menu). The Edit dialog box opens.
- 2. After you complete your changes, click **OK** to save the settings and return to the System Configuration window. The changes are reflected on the right window-pane.

To Search for System Configuration Items:

1. If you wish to search for a specific item, enter the name of the item in the **Search** field at the top right corner of the System Configuration window.

You can enter complete or partial words; no wildcards are needed, and this field is not case sensitive.

- 2. Click **Search**. The System Configuration window displays the match entered in the search field.
- 3. Continue clicking **Search** until you find the item you are looking for.



Refreshing the System Configuration Window: The Refresh button is used to update changes made at the Server or other workstations.

To Print System Configuration Items:

- 1. From the configuration tree, select the item you wish to print. The settings associated with the selected item are listed on the right windowpane.
- 2. Click **Print** at the bottom of the window.
- Select a printer name and any other information for the printer to be used. Printers must first be set up using the Windows Printer Settings dialog box. See your system administrator if you need more information, or refer to your Microsoft Windows documentation.
- 4. Click OK to print.

Set Up Workstations and Operators

Before configuring system and hardware components, Workstations and Operators should be properly set up to communicate with the Server. While Workstations are assigned from the System Configuration window, Operators are assigned via the P2000 Main menu. The following sections describe how to:

- Set up Workstations
- Add Operators to the System
- Set up User Accounts

Workstations

Workstations communicate with the Server via the network. The Server can communicate with a maximum number of Workstations concurrently, based on your registration options. Workstations are assigned a partition, a name, a time zone, and designated as public to make the workstation visible to all partitions. A workstation must be configured as a Badge Station if it operates Video Imaging. When you click a Workstation on the System Configuration window, the current settings display on the right windowpane.

Note: To log on from a workstation to the P2000 system, you must set up user accounts in the Windows operating system. See Setting Up User Accounts on page 28.

To Add a Workstation:

- 1. In the System Configuration window, expand **Site Parameters**.
- 2. Select **Workstation** and click **Add** to access the Workstation dialog box.

C Workstation		
Partition	Super User	▼ □ Public
Name	Warehouse	
Location	West Entrance to Warehouse	
🔽 Enable		
🗖 Badge Sta	tion	
🗖 Server		
Alarm Monitor		
Normal		
C Launch Automatical	ly	
C Always Active		
T Message Filt	imezone: <always enabled=""> er Group: <none> OK Cancel</none></always>	× ×

- 3. Enter the information required. (See the following Workstation Field Definitions for detailed information.)
- 4. Click **OK** to save your entries and return to the System Configuration window. The new Workstation displays beneath the main Workstation icon.
- Click the new Workstation icon to display the current settings on the right windowpane. It may be necessary to click the plus (+) sign to display all configured Workstations on the system.

Note: Operators cannot delete their currently logged on workstation; however, an operator can delete other workstations that are currently active. A message displays to confirm the deletion.

Workstation Field Definitions

Partition – Select the partition to which the Workstation has access. Partitions are described in detail on page 369.

Public – Click this check box to make this Workstation visible to all partitions.

Note: A workstation must be made **Public** to allow users from different partitions to log on at that workstation.

Name – Enter the name of the Workstation. This must be the name of this workstation, as configured in the Windows operating system. You can also click the [...] button to find a workstation on your network (see your system administrator).

Location – Enter the location of the workstation. If you define this as a Badge Station (see page 372), this field describes the location where badges are issued. You can also enter the name of the local site (see page 47).

Enable – Click to have the system recognize this Workstation.

Badge Station – Click to define this workstation as a Video Imaging station.

Server – Identifies the workstation that operates as the system Server.

Alarm Monitor – Settings in this box define whether or not the Alarm Monitor window displays at the workstation after logging on. Select one of the following options:

- Normal Default option for workstations. Enables an authorized operator to open and close the Alarm Monitor window on this workstation.
- Launch Automatically The Alarm Monitor window automatically starts after logging on. Operators with the appropriate permissions can open and close the Alarm Monitor window, if required.
- Always Active Default option for Server stations. The Alarm Monitor automatically starts after logging on and cannot be closed by the operator. This is the required option for UL listed sites, where all alarms must always be visible at the Server to meet UL requirements.

This document contains confidential and proprietary information of Johnson Controls, Inc. © 2014 Johnson Controls, Inc.

Timezone – Assign a time zone to the workstation to define the days and hours it can be used. See <u>Time Zones</u> on page 49 for detailed information.

Message Filter Group – Assign a Message Filter Group to define which messages are transmitted to this workstation. Select **<none>** if you wish to transmit all messages to this workstation. See Configure Message Filtering and Message Routing on page 236 for detailed information.

Adding Operators to the System

Access to the system is controlled by operators that have been assigned system privileges and permissions that allow them to perform various system functions. Therefore, you must first create operator records for each person who operates the Server or a workstation in the P2000 system. The operator record consists of the operator's login name, password, menu permissions, and other features that determine how this person operates. Menu permissions are assigned by group and must be created before they can be available for assignment to the operators.

Note: You can also use Active Directory accounts (user or group accounts) to provide operator access to the P2000 system.

Creating Permission Groups

Menu permissions define the system elements to which an operator has access. For example, a guard operating a P2000 workstation at a warehouse gate may need to have access to alarm monitoring, but may not need access to the Cardholder functions. Some operators may need to view system functions, but are not allowed to edit features, and some operators may need full permissions such as a system administrator or designee. The P2000 software is delivered with a default operator that can be used to configure the system, and therefore has all menu permissions. You can completely configure the system using only the default operator, or you can create additional groups that include various combinations of permissions depending on the responsibilities and access needs of the individual operators. Once permission groups have been created, they are accessible from the Edit Operator dialog box. Menu Permission Groups are password protected.

Menu permission groups can also be created for cardholders. These are assigned via the Cardholder Edit dialog box and provide permissions to Web Access functions; see Web Access on page 443.

To Create a Permission Group:

- 1. From the P2000 Main menu, select **Opera**tor>Menu Permission Groups.
- 2. Enter your password if prompted. The Menu Permission Groups dialog box opens.

C M	lenu Permiss	ion Groups		_ 🗆 🗵
ΓP	ermission Group	ps		
	Super User Test Group Warehouse			
	Done	Add	Edit	Delete

All currently defined menu permission groups are listed here.

3. Click Add. The Menu Permission Group Edit dialog box opens.

Access Templote Image: Constraint of the second of the secon	ter	n	View	Edit	Add	Delete	
Add Valar Y Y Alarm Rospore Y Y Y Alarm Codors Y Y Y Alarm Codors Y Y Y Alarm Rospore Text I I I Aname Rospore Text Y Y I I Alarm Rospore Text Y I I I Alarm Rospore Text Y I I I Alarm Rospore Text I I I I Alarm Rospore Text I I I I Alarm Rospore Text I I I I Rospet Text Access Royfes I I I I]	Access Template					
Alam Rohor Ø Ø Ø Ø Ø Ø Ø Ø I <thi< td=""><td></td><td>Add Visitor</td><td></td><td></td><td></td><td></td><td></td></thi<>		Add Visitor					
Alara Colors		Alarm Monitor	•	•		•	
Alam Response Text	=	Alarm Colors					
Area Control Ø		Alarm Response Text					
Area layout		Area Control	•				
Operator Account/Profile		Area Layout					
Auto Badge Nunder Mitragement Image: Comparison of the compari		Operator Account/Profile					
AV Rayer AV Rayer Bodges Bodges Bodges Bodges Bodges Bodge Bodgee Bodgee Bodgee Bodgee		Auto Badge Number Management	•				
Badges - No Access Rights Image: Constraint of the second of the secon		AV Player					
Badges-No Access Rights Ø Ø Ø Ø Badge-Format 0 Coress Rights 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		Badges					
Badge FASC-N Override		Badges - No Access Rights	•	•		•	
Badge Format	Ξ	Badge FASC-N Override					
		Badge Format					
Badge Resync		Badge Resync					

4. Enter the **Permission Group Name**. The list box displays menu items preceded by the following icons:

 \equiv – Menu list icon to indicate items that are accessible from the P2000 Main menu.

 \square – Sub-menu list icon to indicate items that are accessible from the application.

⁽¹⁾ – Tool icon to indicate items that are accessible from the System Configuration or CCTV/AV Configuration window.

 $\mathbf{L}_{\mathbf{H}} \stackrel{\text{m}}{=} -$ Sub-tool icon to indicate items that are accessible from the application in the System Configuration window.

- Web icon to indicate items that are defined for cardholders who require permissions to Web Access functions; see Web Access on page 443.

■ – Web UI icon to indicate items that are accessible from P2000 Web User Interface applications. Refer to the *P2000 Web UI Manual* for details on the different permission levels and options.

 Click the check boxes for the items you wish to include in the permission group. Each column provides the following permission levels:

View – The operator can see the element in the system, but cannot edit, add, or delete items.

Edit – The operator can view and make changes to entries in these items, but cannot add or delete.

Add – The operator can view, edit, and add records, but cannot delete.

Delete – The operator can view, edit, add new, and delete existing items.

- 6. To assign all items with the same permission level, select the desired function button at the bottom of the screen.
- 7. To clear your selections, click **None** and reselect the items individually.
- 8. Click **OK**. The new permission group is added to the Menu Permission Groups list.
- 9. Click **Done**. The new permission group is now accessible from the Permissions tab in the Edit Operator dialog box. See Assigning Operators for more information.

Note: If you delete a permission group, currently logged on operators who belong to that group can continue to access items in the permission group until they log off from the system.

Assigning Operators

After initial login, the system is ready for operator configuration. Depending on the user type, an operator is assigned a name, which uniquely identifies the user, and is usually the person's first and last name. The user password and name are used to verify access to the system. Use the Edit Operator dialog box to set up user information, including menu permissions, partitions to which the user is assigned, and other system functions.

23

To Add an Operator:

- 1. From the P2000 Main menu, select **Opera**tor>**Operator Account/Profile**.
- 2. Enter your password if prompted. The Operator Account/Profile dialog box opens. All operators that have been created in the system are listed along with their user name, user type, full name, menu permissions to which the operator has access, and the partition to which they are assigned.

dkey P2000 Account Super User Super U	er
Done Add Edit Dolo	
Done Add Edit Dele	е

- 3. To add a new operator, click **Add**. The Edit Operator dialog box opens.
- Enter the information in each tab, as described in the following tab definitions. You can click **Apply** to save your entries.

Note: If FDA Part 11 Record Retention Policy is enabled in Site Parameters, you cannot delete operators for the number of years specified in the Retention Period field; see page 40 for details.

- After you enter all the information, click OK. The operator now has access to system elements as defined.
- 6. Click Done to close.

User Info Tab

User Type – Select one of the following user types to be assigned to this operator:

- P2000 Account This is the default P2000 user type. Users can log on to the P2000 system by entering their password.
- AD Account This is an Active Directory user account. Users can log on to the P2000 system if their user name and password combination can be validated by the Directory Services Password Validation (see page 42), and not by the P2000 system.

Edit Operator		×
User Info Permissions Partitions Rem	ote Partitions Concealed UDFs	
User Type	P2000 Account	Account Type
User Name	SJones	
Full Name	Scott Jones	
Password	•••••	
Confirm Password	•••••	
Message Filter Group	<none></none>	•
Alarm Processing Group	<none></none>	T
Account Disabled		
Create NT user account on server		Verify Password for Critical Functions
User must change password at ne	xt logon	Allow Multiple Alarm Handling
Password never expires		
C Password expires	8/22/2012 10:51:03 AM	
		OK Cancel Apply

AD Profile – This is an Active Directory Group. Users can log on to the P2000 system if their Active Directory account belongs to this Active Directory group and their user name and password combination can be validated by the Directory Services Password Validation (see page 42), and not by the P2000 system. The Active Directory Profile name must match the Active Directory group name. A user can only belong to one P2000 AD group; otherwise, this is considered as an invalid active directory configuration.

Note: AD Account and AD Profile user types require Windows Active Directory to be installed and configured on your network. When you select these user types, other password related fields are disabled. See P2000 Directory Services Password Validation on page 27 for more information.

User Name – Enter the name the operator must type when logging on to the system. Although not required, it is recommended that you use the same user name that the operator uses to log on to Windows (passwords can be different).

Full Name – Enter the operator's full name.

Password – Enter the password the operator must type when logging on to the P2000 system. If you wish to change the password at a later time, see Changing the User Password on page 28. In addition, see Password Policy Tab on page 41 for additional password complexity rules.

Confirm Password – Enter the password again to confirm.

Message Filter Group – Select the Message Filter Group that defines which messages the operator can see. If you select **<none>** the operator can see all messages, provided the operator has access to the Super User partition (or records are marked Public), and the Message Filter Group field defined at the workstation is also set to **<none>** (see page 21). See Configure Message Filtering and Message Routing on page 236 and to Operators and Messages on page 236.

Alarm Processing Group – Select the Message Filter Group that defines which alarms the operator can process (acknowledge, respond, or complete). If you select **<none>** the operator can process all alarms that pass the Message Filter Group selection. If an operator is allowed to receive and process all alarms, then both the Message Filter Group and Alarm Processing Group selections should be set to **<none>**.

Note: Message Filtering and Alarm Processing Groups apply on P2000 Workstations only, not on P2000 Servers. In addition, partitioning rules still apply, regardless of filter group selections.

Account Type – Select the type of account that the operator is authorized to access. If FDA Part 11 Password Policy is enabled in Site Parameters (see page 41), then only one account type can be selected.

Account Disabled – Select this option if you wish to disable this account. Once this option is selected, this account can no longer be used for logging into the P2000 system, until the account is enabled again. A message displays at the next login informing the operator that the account has been disabled.

Create NT user account on server – If selected, a user account is automatically added to the operating system on the Server. You must have administrative rights on the P2000 Server to select this option. This option is not available for selection if your Server is part of a domain. As an alternative, you can manually add the account using the Windows interface; see Setting Up User Accounts on page 28.

Note: The **Create NT user account on server** option only creates the Windows account and associated privileges on the P2000 Server and Database Server, not on the local Workstation, where you need to create the account manually.

If you create the account on the P2000 Server, the account is assigned with Users privileges on the P2000 Server but not on the Database Server, which means that account can be used to access Windows on the P2000 Server, but not on the Database Server.

If you create the from the Workstation, then the account is only associated with the Windows group Pegasys Users on P2000 Server and the Database Server.

User must change password at next logon – If a user forgets his or her password, the system administrator may grant a temporary password and force the user to change the password at the beginning of the next login. This option is only available if the Account Type selected is **P2000**; a password cannot be changed for MIS or XML RPC users.

Password never expires – Select this option to define passwords that never expire, for MIS users for example. This option is not available if FDA Part 11 Password Policy is enabled in Site Parameters (see page 41).

Password expires – If you select this option, the password expires on the displayed date. This date depends on the value defined in Site Parameters (page 41). Verify Password for Critical Functions – If selected, the operator is required to enter the login password to access certain system-critical functions.

Allow Multiple Alarm Handling – If selected, the operator can process more than one alarm at a time. This option is always enabled by default. When selected, the operator can acknowledge or complete multiple alarms in the Alarm Monitor window.

Permissions Tab

Permissions determine the functions that an operator can perform in the system. Each operator can be associated with different rights to different functions. Menu permissions must be defined, otherwise the table is empty. See Creating Permission Groups on page 21 for more information.

dit Operator			
User Info Permission	Partitions Remote P	artitions Conce	aled UDFs
Member Of			Available Groups
Super User			Engineering
		~	

- 1. Select from the **Available Groups** box, the permission group that defines the functions that the operator can view or change. You can select multiple items by holding down the **<Shift>** key.
- Click << to move the permission group to the Member Of box.

Note: An operator can perform any function if at least one menu permission group assigned to the operator allows permission to that function.

Partitions Tab

Operators can be assigned to single or multiple partitions and have unique access restrictions, such as the ability to add, modify, or view database information within their assigned partitions. See Partitions on page 369 for information on defining partitions.

Edit Operator		
User Info Permissions	Partitions Remote Partitions Cor	ncealed UDFs
Member Of Executive		Available Partitions Engineeing Human Resources Super User

- Select from the Available Partitions box, the partition to which this operator can access. You can select multiple items by holding down the <Shift> key.
- Click << to move the partition name to the Member Of box.

Note: An operator can see alarms and real time messages that are associated with the partitions selected here, unless records are marked Public or the operator is monitoring the system from the Server, where all alarms and real time messages are visible, regardless of the partitions selected here. Operators that belong to the Super User partition have access to all partitions of the system.

Remote Partitions Tab

If the operator monitors remote messages, use this tab to define the partitions to which the operator can access. If you do not enter any partition names, the operator can monitor all messages from the remote site.

Note: Remote messages are any alarm or transaction messages originated at another P2000 site. See Message Filtering on page 237.



- 1. Enter the name of the partition at the remote site and click **Add**. The remote partition name displays in the Remote Partitions box.
- 2. If you wish to modify an existing remote partition name, select the name in the Remote Partitions box, make the change, then click **Update**.
- 3. If you wish to delete a remote partition name from the list, select the name in the Remote Partitions box and click **Delete**.

Concealed UDFs Tab

Use this tab if you wish to restrict operators from viewing certain fields in the Cardholder dialog box. For example, a guard operating a P2000 workstation at a parking structure may need to have access to car and parking information, but may not need to view personal Cardholder information.

- 1. All UDFs are selected by default. Clear the check boxes next to the UDFs that you wish to restrict from viewing.
- 2. Click OK to save.

Only the selected UDFs are visible in the Cardholder dialog box. In addition, other P2000 applications that use UDFs, such as the Search tool, do not display the UDFs that are restricted from viewing.

P2000 Directory Services Password Validation

Authentication of P2000 operators can now be handled by a centralized directory service such as Microsoft Active Directory or other directory service using the Lightweight Directory Access Protocol (LDAP). This feature provides a single point of authentication - when a user enters the credentials to log on to the P2000 system, the P2000 server generates an authentication request to the LDAP server. Once the LDAP server authenticates the user, the P2000 server logs on the user and authorizes certain permissions, as defined in the user's AD account or group operator settings.



This feature eliminates operator passwords from the P2000 database and is useful when passwords are periodically changed, eliminating the need to update passwords in the P2000 system and passwords that are used to log on to Windows.

To use directory service password validation, the following elements must be set up in the P2000 system:

- The **Directory Services Path** field must be set in the Password Policy tab of Site Parameters (see page 42). The actual value to use for the Directory Services Path is unique to your specific network configuration and needs to be obtained from your network administrator.
- For each P2000 operator that you want their password verified by directory services, you need to select the AD Account or AD Profile **User Type** in the Edit Operator dialog box (see page 23).

Directory Services Path

The Directory Services Path is specific to your network layout and configuration. You must consult with your network administrator for the correct path. The path statement provides the network location for the *Users* object within the directory services hierarchy.

The P2000 software includes a utility that allows you to test the correct path statement. You can find the **ActiveDirectoryTest.exe** application in the *bin* folder of the P2000 software installation. By using this application, you can easily try different path values to help determine the correct value for your network.

C Active Directory Tes	t in the second s
Username	sjones
Password	•••••
ADS Path	LDAP://CN=Users,DC=companyname,DC=com
Processed Path	LDAP://CN=Users,DC=companyname,DC=com
Username Formatting	\$USERNAME
Processed Username	sjones
Note: The	above processed strings will replace "\$USERNAME" with entered username.
Flags:	
	Authenticate
	Exit

See the following examples:

- Directory Services Path for a Windows domain named *companyname*: WinNT://companyname/Users
- Directory Services Path for an Active Directory domain named *companyname.com*: LDAP://CN=Users,DC=companyname,DC=com

For more details on path values and typical examples, refer to **LDAP ADsPath** and to **WinNT ADsPath** on Microsoft's MSDN Library.

Changing the User Password

Use the Change Password option to change a user's password. Depending on the permissions assigned using the Menu Permission Groups, some or all users may be able to change their own password at any time.

To Change a Password:

 From the P2000 Main menu, select Operator>Change Password. The Change Password dialog box opens.

🕼 Change Password	
User Name	rlopez
Current Password	
New Password	
Confirm Password	
OK	Cancel

- 2. Enter your Current Password.
- 3. Enter your New Password.
- 4. Re-enter your new password in the **Confirm Password** field.
- 5. Click **OK** to save your new password. There is no need to log out of the system. The new password is now valid within the P2000 system.

Setting Up User Accounts

To add operators to the P2000 system, accounts must be set up in the operating system. Without proper authorizations, the system may not allow connections to the Server.

Note: If the **Create NT user account on server** option (see page 25) was selected at the time you added the user to the P2000 system, the following steps were performed automatically by the P2000 system.

Adding a Login Name and Password for the P2000 System into the Operating System

When you add operators into the Windows list of valid users on the server, you must assign this user account as a member of the *PEGASYS Users* group to give them rights to connect to the P2000 database. Use the same user name and password that the operator uses to log on to Windows at the workstation.

The user account may be assigned membership of other groups as desired. The commonly used groups are explained:

PEGASYS Users – Gives rights to log on to the P2000 database.

PEGASYS Administrators – Gives rights to administrate the P2000 database (create and drop tables, restore the database, and so on).

Users – Gives rights to log on to the server computer locally.

Administrators – Gives rights to administrate the server computer (add users, change hardware configuration, and so on).

Note: The following instructions are provided for Windows 2008 Server operating systems. For other operating systems, follow the general outline to enter your settings.

Windows 2008 Server Details

1. Run the Computer Management program; select Start>Settings>Control Panel> Administrative Tools. Double-click the Computer Management icon.

1-1-1-1

Ref Action New Help
Computer Meangement (Loca) Computer Meangement (Loca)
Compute Management Locol There Tell Sine Compute Salid Compute Sa

- 2. Click System Tools>Local Users and Groups>Users.
- From the Computer Management menu, select Action>New User. The New User dialog box opens.

New User		? ×
User name:	djones	
Full name:	David Jones	
Description:		
Password:	•••••	
Confirm password	•••••	
🔲 User must cha	ange password at next logon	
🔲 User cannot c	hange password	
Password nev	er expires	
Account is dis	abled	
Help	Create Clos	æ

4. Enter the data for the new user, then click **Create**. Click **Close** to return to the Computer Management window.

- 5. Right-click the newly added user on the center pane and select **Properties**.
- 6. In the user Properties window, click the **Member Of** tab.

djones Proper	ties			? ×
Remote o	ontrol	Terminal Servi	ces Profile	Dial-in
General	Member Of	Profile	Environment	Sessions
Member of:				
& Users				
Add	Remove	are not effi user logs o	o a users group m ective until the nex n.	empership d time the
	ОК	Cancel	Apply	Help

- 7. Click Add.
- 8. In the Select Groups window, click **Advanced**.

elect Groups	?
Select this object type:	
Groups	Object Types
From this location:	
MA2008SQL	Locations
Enter the object names to select (examples):	
inter the object names to select (<u>examples</u>):	 Check Names
enter the object names to select (<u>examples</u>):	 Check Names
inter the object names to select (<u>examples</u>):	Check Names

- 9. In the expanded Select Groups window, click **Find Now**.
- 10. From the list of groups select the PEGA-SYS Users group and click **OK**.

Select Groups			? ×
Select this object type:			
Groups			Object Types
From this location:			
CBAUERMA2008SQL			Locations
Common Queries			
Name: Starts with 🔻		 	Columns
			Find Now
Description: Starts with			
Disabled accounts			Stop
Non expiring password			
Dave sizes last lagen.	-		27
Days since last logon:	<u> </u>		71
Search results:		ОК	Cancel
Name (RDN)	In Folder		_
Certificate Service DCOM Access	MA200		
Cryptographic Operators	MA200		
Distributed COM Users	MA200		
Event Log Readers	MA200		
Guests	MA200		
IIS_IUSHS	MA200		
Network Configuration O	144200		
Network Configuration Operators	MA200		
PEGASYS Administrators	MA200 MA200		
Network Configuration Operators PEGASYS Administrators PEGASYS MIS Users PEGASYS Users	MA200 MA200 MA200		

11. In the Select Groups window, verify that the correct group is listed and click **OK**.

Select Groups		? >
Select this object type:		
Groups		Object Types
From this location:		
MA2008SQL		Locations
Enter the object names to select (<u>examples</u>):		
MA2008SQL\PEGASYS Users		Check Names
Advanced	ОК	Cancel

- 12. Repeat steps 7 11 for other groups you want to add, (see page 28 for reference), this time selecting that particular group from the list.
- Click **OK** to close the user Properties window.

Windows 2008 Server with Active Directory Details

Follow this procedure if you are using Windows 2008 Server or Windows 2008 Server Enterprise Edition and the server is a member of a domain. 1. Run the Computer Management program (select Start>Programs>Administrative Tools>Active Directory Users and Computers).

Active Directory Users and Comp	uters		_10 ×
Ele Action View Help			
(+ +) 🖄 📰 🗋 🔛 🍳 🖻	- 🛛 🖬 🔧 📚 🖆 🍸 💆 📚		
Active Directory Users and Computer	Name	Type	Description
E	& Administrator	User	Built-in account for admini
🖃 🚔 Pdomain.com	& Allowed RODC Password Replication Group	Security Group	Members in this group can
🗄 🚞 Builtin	& Cert Publishers	Security Group	Members of this group are
E Computers	& Denied RODC Password Replication Group	Security Group	Members in this group can
Domain Controllers	& DnsAdmins	Security Group	DNS Administrators Group
ForeignSecurityPrincipals	& DnsUpdateProxy	Security Group	DNS clients who are permi
Users	& Domain Admins	Security Group	Designated administrators
	& Domain Computers	Security Group	All workstations and serve
	& Domain Controllers	Security Group	All domain controllers in th
	& Domain Guests	Security Group	All domain guests
	& Domain Users	Security Group	All domain users
	& Enterprise Admins	Security Group	Designated administrators
	& Enterprise Read-only Domain Controllers	Security Group	Members of this group are
	& Group Policy Creator Owners	Security Group	Members in this group can
	9. Quest	liser	Built-in account for quest

- 2. Expand Active Directory Users and Computers, right-click Users and select New>User.
- 3. The New Object User dialog box opens. Enter the data for the new user, click **Next**.

lew Object - User				×
Create in:	PDOMAIN.C	OM/Users		
Eirst name:	David		Initials:	
Last name:	Jones			
Full name:	David Jones			
User logon name:				
djones		@PDOMAIN	N.COM	•
User logon name (pre	• <u>W</u> indows 2000	1):		
PDOMAIN\		djones		
	[< <u>B</u> ack	<u>N</u> ext >	Cancel

4. Enter the password for the user, check the password type (if you select the **Password never expires** feature, you are prompted to click **OK** to confirm it). Click **Next**.

New Object - User	×
Create in: PDOMAIN.	.COM/Users
Password: XXXXXX Confirm password: XXXXXX	
User <u>m</u> ust change password at Uger cannot change password Jer cannot change password Password never expires Account is disabled	next logon
	< Back Next > Cancel

5. Verify the parameters, then click **Finish**.

New Object - User	×
Create in: PDOMAIN.COM/Users	
When you click Finish, the following object will be created:	
Full name: David Jones	A
User logon name: djones@PDOMAIN.COM	
The password never expires.	
	_
1	
< Back Finish	Cancel

6. To add a member to a user group, from the Active Directory Users and Computers window, select the newly added user on the right pane, right-click and select **Add to a group**.

Note: The user is already a member of Domain Users.

7. In the Select Group window, click **Advanced**.

Select Group		? ×
Select this object type:		
Group or Built-in security principal	Object	Types
Erom this location:		
PDOMAIN.COM	Loca	ations
Enter the object name to select (examples):		
	Check	Names

- 8. In the expanded Select Group window, click **Find Now**.
- 9. From the list of groups select the PEGA-SYS Users group and click **OK**.

Select Group		<u>? ×</u>
Select this object type:		
Group or Built-in security pri	ncipal	Object Types
From this location:		
PDOMAIN.COM		Locations
Common Queries		
Name: Starts with		<u>C</u> olumns
Description: Starts with		Find Now
Disabled accounts		Stop
Non expiring passwor	d	
Days since last logon:	Y	
Search results:		OK Cancel
Name (RDN)	Description	In Folder
Administrators		PDOMAIN.COM
🕵 Backup Operators		PDOMAIN.COM
🕵 CCTV Operators	CCTV Operator	PDOMAIN.COM
Cert Publishers	Members of this group are permitted to	PDOMAIN.COM
5 DnsAdmins	DNS Administrators Group	PDOMAIN.COM
5 DnsUpdateProxy	DNS clients who are permitted to perfo	PDOMAIN.COM
🕂 💯 Domain Admins	Designated administrators of the domain	PDOMAIN.COM
2 Domain Computers	All workstations and servers joined to t	PDOMAIN.COM
Domain Controllers	All domain controllers in the domain	PDOMAIN.COM
🚰 Domain Guests	All domain guests	PDOMAIN.COM
		0000002

10. In the Select Group window, verify that the correct group is listed and click **OK**.

Select Group	? ×
Select this object type: Group or Built-in security principal	Object Types
Erom this location: PDOMAIN.COM	Locations
Enter the object name to select (examples):	
PEGASYS Users	Check Names
Advanced 0K	Cancel

11. Click **OK** at the confirmation message.



12. Repeat steps 6 - 11 for other groups you want to add, (see page 28 for reference), this time selecting that particular group from the list.

13. To manage the existing domain user, from the Active Directory Users and Computers window, select the newly added user on the right pane, right-click and select **Proper**ties. The Properties screen opens.

David Jones Properti	25		<u>?</u> ×
Member Of Remote control General Address	Dial-in Enviro Terminal Service Account Profile	onment :s Profile Telephones	Sessions COM+ Organization
David Jo	nes		
<u>F</u> irst name:	David	Initials:	
Last name:	Jones		
Display name:	David Jones		
Description:			
Offi <u>c</u> e:			
<u>T</u> elephone number:			Other
E- <u>m</u> ail:			
Web page:			Other
	ОК	Cancel	Apply

- 14. Complete each tab according to your needs, then click **OK**.
- 15. Close all windows.

Configure System Components

System components that operate globally throughout the P2000 system include Site Parameters, Partitions, Local Configuration, Time Zones, and Holidays. To speed the configuration process, we recommend that you set up system components in the following order:

1. **Site Parameters** – Site Parameters define general system information, real time printing, panel types, facility codes, record retention times, and other parameters that are specific for the entire facility.

- Partitions You can divide the P2000 database into smaller sections that can be individually managed. Partitions allow a system to function as multiple, separate systems. For more information on Partitions, see page 369.
- 3. Local Configuration With Local Configuration, you can enter the database server source and application path of your P2000 system, select the language in which to run your P2000 software, and define the database connection settings for your local computer.
- 4. **Time Zones** Times Zones are used throughout the system to define active and inactive time periods for various system components.
- 5. **Holidays** Holidays are defined for the entire facility. Holiday start and stop times may be different for different access rights.

Registration Parameters

You can review the maximum number of terminals and workstations, the maximum badges allowed, and other parameters specified for your system. Select **Config>System** from the P2000 Main menu bar, enter your password if prompted, and click the **Registration Parameters** icon at the top of the configuration tree in the System Configuration window. The parameters display on the right windowpane. In addition, you can expand **Registration Parameters** and select **Option Keys** to display additional P2000 features available for your system.

All these parameters are enabled via the entry of your valid Registration Key and Option Keys provided by Johnson Controls. These keys are associated with your purchase contract and cannot be modified within the program.

Site Parameters

The elements that define how your access control system operates are entered in Site Parameters. The P2000 system uses the information in Site Parameters to determine how system and hardware components can be configured. It is important to plan your access requirements by establishing elements such as visitor badge validity period, the server that handles system communications, real time printing, panel types, facility codes, record retention times, and other parameters that are specific for the entire facility. Setup information associated with the BACnet®, MIS, and Web Access features is described in Chapter 4: Advanced Features. When you click Site Parameters in the System Configuration window, the current settings display on the right windowpane. You may modify these settings as desired. The Backup Device, DB Server, and Real Time Printer in Site Parameters can only be set at the Server. On a partitioned system, only users that belong to the Super User partition can modify Site Parameters.

IMPORTANT: The Communication and Database Server settings are advanced settings and should be changed only at the direction of our Technical Support team. If these settings are changed, the system may not work properly.



Root System Components Tree Right Windowpane

To Edit Site Parameters:

1. With Site Parameters selected, click **Edit**. The Edit Site Parameters dialog box opens at the General tab.

🕻 Edit Si	te Parameters					×
Port Co General	nfiguration RM5	EMail Facilit	External Ev v Code Reten	ent Trigger MIS tion Policy Passwo	Web Acce ard Policy BACN	ss XmlRpc et Download
- Bado	es					
	Visitor Validity	/ Period	4	hours		
	Max Visitor Validity	/ Period	90	days (0= forever)	
	<u>M</u> a× Inactive	e Period	0	days (0 = foreve	r)	
	Global In-X-It Tracking					
	Global Badge Entry/Exit :	Status S	/nchronization			
	Badge Trace Alarm for G Badge Trace Alarm for D	iranted A enied Ac	ccess cess		Alarm Opti	ons
Serve	br					
	Comms Server	p2000se	erv	Browse	,	
	DB Server	P20005	ERV			
Eleva	tor/Cabinet					
		Numbe	r of Eloors 120			
		Numbe	r of Doors 128			
Badg	e Editing					
	Cross Site Access Group	Editing				
	Display asterisks instead	l of pin co	ode			
		Ma× PIN	Code Digits	•		
		Spe	cial Access A	ipecial Access A		
		Spe	cial Access B	ipecial Access B		
		Spe	cial Access C	ipecial Access C		
<u> </u>						
				OK	Cancel	Apply

- 2. Enter the information in each tab according to your system requirements. (See Site Parameters Field Definitions for detailed information.)
- 3. As you work through the tabs, you may click **Apply** to save your entries.
- After you have entered all the information, click OK to save the settings and return to the System Configuration window. The new values display on the right windowpane.

Site Parameters Field Definitions

General Tab

Visitor Validity Period – Enter the time, between 1 and 80 hours, after which a Visitor badge expires by default.

Max Visitor Validity Period – Enter the maximum number of days that a Visitor badge may be valid. If an operator tries to set the validity period for a Visitor badge longer than the configured value, an error message displays and the badge is not saved.

Max Inactive Period – Enter the number of days after which a badge is disabled because of inactivity. The operator has to manually reactivate the badge when needed.

Global In-X-It Tracking – If selected, messages are sent to the real time list to report global entry or exit violations. A global entry or exit violation occurs when access is granted after presenting a valid badge at, for example an entry reader and then that badge is presented again at another entry reader, despite the requirement to badge at entry and exit readers alternately.

Global Badge Entry/Exit Status Synchronization

- Select to allow synchronization of badge status across multiple panels. This feature is not recommended for medium and large systems, unless using panels CK7xx of Version 2.5 or later. After you enable this feature, settings may only take effect after you stop and restart the following services:

- CK720 Download Service
- CK720 Priority Service v1.0 (optional)
- CK720 Priority Service v2.1
- CK720 Upload Service
- P900 SIO Handler Service
- S321 SIO Handler Service
- SIO Handler Service

See Starting and Stopping Service Control on page 470 for details.

IMPORTANT: This feature must never be combined with the **Peer to Peer Badge Sync** option (see page 60). Selecting both features causes badge entry/exit enforcement errors across multiple panels. **Badge Trace Alarm for Granted Access** – Select to generate an alarm when a badge with the Trace flag set is granted access at any reader in the system.

Badge Trace Alarm for Denied Access – Select to generate an alarm when a badge with the Trace flag set is denied access at any reader in the system.

Alarm Options – Click to open the Alarm Categories window and assign alarm options associated with the Badge Trace Alarms. For detailed instructions, see Alarm Configuration on page 285.

Comms Server – Defaults to the server that handles communications.

DB Server – Displays the name of the server that handles the databases.

Number of Floors – Enter the maximum number of floors at your facility (up to 128) for elevator access. This is the number of floors that displays in the Floor Name Configuration list.

Number of Doors – Enter the maximum number of doors at your facility (up to 128) for cabinet access. This is the number of doors that displays in the Door Name Configuration list.

Cross Site Access Group Editing – Select to allow modifying access groups for other Enterprise sites.

Display asterisks instead of pin code – If selected, the PIN code entered in the Badge dialog box displays as asterisks.

Max PIN Code Digits – Select the maximum number of PIN code digits that can be entered in the Badge dialog box.

Note: If your facility uses Mercury panels, you must restart the P2000 Mercury Interface Service for this change to be effective. You must also download all items to all Mercury panels with the **Reset Panel Before Download** flag selected; see Downloading Data to Panels on page 463.

Special Access – The system provides three Special Access flags to satisfy the requirements for assisted access according to Americans with Disabilities Act (ADA). The Special Access fields A, B, and C can be renamed according to your facility needs, *Handicap Access* for example. The names entered in these fields become effective throughout the system. For configuring special access for your panel type, see your specific hardware configuration section for information on setting up these flags.

Printing Tab

Real Time printers can be set up only from the system Server, even if the operators have permissions to modify Site Parameters at their workstations. Printers to be used by the P2000 system must first be set up using the Windows printer set up function. If you need assistance adding printers to the system, see your system administrator or refer to your Windows documentation.

Note: While the same options are offered from Real Time Printing, this function operates independently from the Real Time List viewed on screen. It is not connected in any way to a history file. It simply prints the transaction types selected as they occur.

IMPORTANT: Real time printing is not guaranteed on foreign language systems.

🕻 Edit Site Parameters	
Port Configuration RMS EMail Extern General Printing Panel Types Facility Code F	nal Event Trigger MI5 Web Access XmlF Retention Policy Password Policy BACNet Downl
Printing \\c7ckys01\RicohExec_PS	3
Set All	Clear All
I Host	Access Deny
Panel	Access Grant
Audit	☑ Irace
I → Alarm	Guard Tour
Elevators	✓ ⊆abinets
Areas	Mustering Zones
VA V	Intrusion
	☑ Fire

Printing – If you wish to print any transaction, select this box and choose a printer. We recommend a dot matrix printer be used exclusively for printing the following transaction types as they occur.

Set All – Select if you wish to print all transactions.

Clear All – Select to clear the selections. To limit the type of transactions printed, select any of the following options:

Host – Prints triggered and system events.

Panel – Prints reader strikes and status, terminal and panel status changes, and so on.

Audit – Prints operator actions such as add an alarm instruction, edit an event, run a report, and so on.

Alarm – Prints all alarm messages.

Elevators - Prints all elevator messages.

Areas – Prints all area messages.

AV – Prints all audio-visual messages. DVR is described on page 428.

Access Deny – Prints all Access Deny messages.

Access Grant – Prints all Access Grant messages.

Trace – Prints all transactions associated with a badge. The Trace option must also be enabled on the Badge dialog box; see page 271.

Guard Tour – Prints all guard tour messages. Guard Tour is described in detail on page 386.

Cabinets – Prints all cabinet messages.

Mustering Zones – Prints all mustering zone messages.

Intrusion – Prints all intrusion messages.

Fire – Prints messages generated by the fire alarm panel.

As a reference, see Using the Real Time List on page 356.

Panel Types Tab

Use this tab to select the panel types and related parameters that define how your system can be configured.

Panel Types Box

Select the panel types to be used at your facility. Specific features for the selected panel type display when configuring the panels and their system and hardware components. For example if you only select the D620 panel type, features for a CK7xx panel such as Elevator and Cabinet in the Access Group dialog box do not display. Your system can be configured with any combination of panel types.

Edit Site Param	eters				
Port Configuration General Printing	RMS EMail External Panel Types Facility Code Re	Event Trigger tention Policy	MIS V Password Policy	Veb Access	XmlRpc Download
Panel Types					
 CK705 CK720 CK721 CK721-A D620 D620 TIU D620 TIU D600 AP \$320 P900 \$321 	S321-IP OST S321-IP S1 Sonas RC-02 HID S4 Assa Abloy PoE Assa Abloy Wi-Fi Mercury EP1501 Mercury EP2502 Mercury EP2502 S4 Mercury EP2502 S5 Ashage PIM400-112 S5 As	501			
1					
Parameters	ations				
Badge Type	Badge Terminal Access Timezor	ne			
	Max Badge Number	20 Digits (64 E	it)	-	
	Number of Access Groups	32			
	Max Issue Level	255			
	Max Security Level	99			
Options	Status to "Unknown" when Panel C	Offline			

Parameters Box

The Parameters box defines various elements for each panel type. Before entering your selections, see the table on page 37 for the maximum default values for each panel type. **Enforce Limitations** – Select to force the system to use the default values listed in the following table. If you select to Enforce Limitations, you are not required to enter any values in the Parameters box and all tabs are disabled. There is a combination of options depending on whether or not you select this check box and the type or types of panels selected. See the following rules:

- If you select one panel type and enable Enforce Limitations, you force the system to use the maximum default values for the panel selected.
- If you select one panel type and do not enable Enforce Limitations, you can enter any value up to the maximum default values for the panel selected.
- If you select more than one panel type and enable Enforce Limitations, you force the system to use the lowest values among the panel types selected. For example, if you select CK720 and D620 as the panel types, you are only able to configure up to 2 access groups and up to 7 issue levels, even though CK720 panels support 8 access groups and 255 issue levels.
- If you select more than one panel type and do not enable Enforce Limitations, you can enter any value, but the system only recognizes the maximum values for each panel type selected. For example, if you select CK720 and D620 as the panel types and you enter 8 in the Number of Access Groups, you can download up to 8 access groups for CK720 panels, and only up to 2 access groups for D620 panels.

		CK7xx	Legacy								
Parameters	Elements	CK705, CK720, CK721, CK721-A	D620, D620 TIU, D600 AP, S320	P900	S321-DIN	S321-IP	OSI	Isonas	HID	Assa Abloy	Mercury
Badge	Max Badge Number	20 Digits	65,535	20 Digits	32 bit ¹	20 Digits	47 bit ²	32 bit ³	64 bit ⁴	19 Digits 5	63 bit ⁶
	Number of Access Groups	87	2	1	2	N/A	N/A	1	8	32	32
	Max Issue Level	255	7	7	7	N/A	99	255	N/A	255	255
	Max Security Level	99 (2.2 and later)	99 (D600 AP only)	N/A	99	99 (2.6 and later)	N/A	N/A	N/A	N/A	N/A
Timezone	Number of time pairs per day	4 ⁸	4	10	4	4	20	10	6	10	10
	Number of unique time pairs per Timezone	40	40	16	40	40	N/A	80	60	32 ⁹	12

1 Max Badge Number for S321-DIN and Isonas panels is 4,294,967,295

2 Max Badge Number for OSI panels is 140,737,488,355,327

3 Max Badge Format digits is 32 bits

4 Max Badge Format digits is 64 bits

5 19 digits for Mag Stripe, 48 bits for others

6 Max Badge Number for Mercury panels is 9,223,372,036,854,775,807

7 CK721-A Version 3.0 supports 32 access groups per badge

8 CK721-A Version 3.0 supports 10 time pairs per day

9 Each Assa Abloy lock can only store a maximum of 32 different time periods

Badge Type Tab

Settings in this tab define the badge type to be used at your facility.

Parameters
Enforce Limitations
Badge Type Badge Terminal Access Timezone
Badge Edit Style Normal and FASC-N
Default Agency Code 4444
Default System Code 7777
Default Series 5

Badge Edit Style – Select one of the following options:

- Normal Only Select Normal if your facility uses any badge type other than FASC-N.
- FASC-N Only Select FASC-N (Federal Agency Smart Credential Number) if your facility supports the Federal Government smart card encoding protocol. If you select this option, the system generates a 15-digit badge number using the default values defined in this tab.
- Normal and FASC-N Use this option if your facility uses both Normal and FASC-N badges.

Default Agency Code – Enter the 4-digit default agency code to be used at your facility.

Default System Code – Enter the 4-digit default system code to be used at your facility.

Default Series – Enter a 1-digit default series number to be used at your facility.

For more information, see FASC-N Badges on page 269.

Badge Tab

Settings entered in this tab govern how badges are configured for the entire system. When you create a badge, the system uses this information to determine the maximum allowed values. For more information, see Badge Field Definitions on page 268.

F	Parameters	itations				
	Badge Type	Badge	Terminal Access	Timezor	ne	
			Max Badge	Number	20 Digits (64 Bit)]
			Number of Access	Groups	32	
			Max Issu	ie Level	255	
			Max Securit	ty Level	99	

Max Badge Number – Select the maximum number of characters allowed to be entered in the badge Number field. See the table on page 37 for the maximum default values for each panel type.

Number of Access Groups – Enter the maximum number of access groups that can be assigned to each badge. This is the number of access groups that displays in the Access Rights tab of the Badge dialog box. See the table on page 37 for the maximum default values for each panel type.

Note: By default, Mercury panels allow up to 32 Access Groups. The maximum Access Groups allowed is configured in the Mercury Facility tab, (see page 179). Contact Technical Support if you need to change that number.

Max Issue Level – Enter the highest issue level that can be assigned to a badge. The maximum value displays in the Issue drop-down list of the Badge dialog box. See the table on page 37 for the maximum default values for each panel type.

Max Security Level – Enter the highest security level that can be assigned to a badge. This is the maximum number that displays in the Security Options tab of the Badge dialog box.

Security levels are supported by D600 AP panels, S321-DIN panels, S321-IP panels (Version 2.6 and later), and CK7xx panels Version 2.2 and later. See **Security Level** on page 64 (for D600 AP only), and Security Threat Level Control on page 307.

Terminal Access Tab

This tab applies to P900 and Mercury panels only.



Terminals associated with Timezone - If you

select this option, you activate the *Details* tab in the Access Group dialog box, which enables you to assign different time zones to each P900 and Mercury terminal. For more information, see Create Access Groups on page 247.

Assume you selected the CK720 panel type. CK720 allows: 4 time pairs per day 40 unique time pairs per Timezone Assume you selected the P900 panel type. P900 allows: 10 time pairs per day 16 unique time pairs per Timezone

Timezone Tab

Parameters

Enforce Limitations

Use the Timezone tab to enter the maximum

number of time pairs per day and the maxi-

mum number of unique time pairs per time

zone that are allowed for the entire system. A

time pair is defined as a period of the day, with

a starting and ending time. See Time Zones on page 49 for configuration instructions. To have

a better understanding of how the time pairs

Number of time pairs per day

Number of unique time pairs per Timezone

Number of time pairs per day – Enter the maxi-

mum number of time pairs per day that can be

configured for the entire system. The number

of time pairs per day display in the Time Zone

dialog box (see the following illustration). See

the table on page 37 for the maximum default

work, see the following illustration.

Badge Type | Badge | Terminal Access | Timezone

values for each panel type.

Assume you enable Enforce Limitations

NOTE: According to the Enforce Limitation rules (see page 37), the system uses the lowest values among the panel types selected. In this case **4 pairs per day** and **16 unique time pairs per Timezone**.

Using the preceding values, the Time Zone dialog box displays 4 time pairs for each day...

Periods						_		-	
Monday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Tuesday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Wednesday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Thursday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Friday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Saturday	Inactive	12:00:00 AM	8:00:00 AM	12:00:00 PM	1:00:00 PM	4:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Sunday	Inactive	12:00:00 AM	8:00:00 AM	11:00:00 AM	12:00:00 PM	3:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Holiday 1	Inactive	12:00:00 AM	-7:00:00 AM	11:30:00 AM	1:30:00 PM	5:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Holiday 2	Inactive	12:00:00 AM	7:00:00 AM	11:00:00 AM	1:30:00 PM	5:00:00 PM	10:30:00 PM	11:30:00 PM	11:59:00 PM
Holiday 3	Inactive	12:00:00 AM	7:30:00 AM	1:00:00 PM	2:00:00 PM	5:00:00 PM	10:30:00 PM	11:30:00 PM	11:59:00 PM

... and allow you to configure up to 16 unique time pairs for the entire Time Zone.

Number of unique time pairs per Timezone –

Enter the maximum number of unique time pairs that can be created for each Time Zone. See the table on page 37 for the maximum default values for each panel type.

Options Box

Set Terminal Status to "Unknown" when Panel **Offline** – Select to set a terminal status to Unknown when a panel goes offline. For Assa Abloy panels, this setting becomes effective after the Assa Abloy DSR Interface Service is restarted. This option is not recommended for Mercury panels, since terminal offline alarms cannot be generated while the panel is offline.

Facility Code Tab

Some of the codes stored in every badge are known as *facility codes*. These codes allow you to identify the badges that belong to your facility. See the instructions provided on page 267 to assign facility codes to badges.

a de Tr	Finding Parlet types Toolicy code [Recender Pointy Password Pointy]	DACINEL DUV
No.	Name	Value
0	Default Facility Code	0
1		
2		
3		
4		
5		
6		
/		

You can define up to eight facility codes. The box displays the Default Facility Code with a default value of θ . Double-click these fields to enter the facility code Name and corresponding Value. If you use badges with different facility codes, enter the names and corresponding values for each group of badges. You cannot delete facility codes that have been assigned to badges.

Retention Policy Tab

Enter in the Retention Time box, the amount of time and select Days, Hours, or Minutes after which all records are deleted from the system. If you enter 1440 Minutes on any of the fields, the system automatically converts it into 1 Day. If you enter 1441 Minutes, the system leaves the value as is. The system converts even values only. The maximum retention period is 24,855 days (about 68 years).

Edit Site Parameters		
Port Configuration RMS EMail External Eve eneral Printing Panel Types Facility Code Retent	nt Trigger N on Policy Pass	IIS Web Access XmlRpc word Policy BACNet Download
Retention Time		
<u>A</u> udit Trail	30	Days 💌
Iransactions	30	Days
Alar <u>m</u> s	30	Days
Muster Data	30	Days 💌
Request Queue	30	Days
<u>⊺</u> our Note	30	Days 💌
FDA Retention Policy	and Validation I	Policy
Retention Period (years)	10	
Violation Alert Period (days)	30	
Last FDA Backup	1/23/2009	
	1	fia Deuire

Audit Trail – Enter the time after which all audit records at the Server, such as logins, logouts, and record changes are purged.

Transactions – Enter the time after which all system and badge transactions are purged.

Alarms – Enter the time after which all alarm records are purged.



Site Parameters Application: The number of days history should be stored on the Server hard drive depends on the

APPLICATION NOTE

amount of activity at your site. If you continually fill up the server hard drive, you can reduce the number of days history is stored.

Muster Data – Enter the time after which all Muster data is deleted from the system.

Request Queue – Enter the time after which all Request Queue records are deleted from the system. See Viewing Request Queue on page 502.

Tour Note – If your facility uses the Guard Tour feature, enter the time after which all notes are deleted from the system. See Guard Tour Notes on page 399.

FDA Retention Policy

Settings in this box are available if your facility uses the FDA Part 11 option. See FDA Part 11 on page 429.

Enforce FDA Title 21 CRF Part 11 Record Retention and Validation Policy – Select to enable FDA Part 11 record retention policy, which addresses the protection of records for a specified period.

Retention Period – Enter the number of years that the system keeps all records in the system.

Violation Alert Period – Enter the number of days to generate a warning message before records are deleted from the system. If the Retention Period is longer than any of the values entered in the Retention Time box, an alarm message is generated, and repeated on a daily basis, until the operator performs the FDA Backup procedure; see page 493.

Last FDA Backup – This is a displayed field only and shows the date you informed the system that a backup was archived, according to your company policies to comply with FDA Part 11 record retention requirements.

IMPORTANT: Changes to any of the FDA Record Retention Policy settings take effect only after all services have stopped and restarted using Service Control. You must also log off and on at the Server computer to see these changes. **Backup Device** – Select the name of the device to which database backups are sent. For detailed information, see Configuring a Backup Device on page 490.

Password Policy Tab

Settings in this tab provide additional security to your system by allowing the system administrator to define several parameters to set up strong passwords, passwords that are hard to break.

dit Site Parameters	
ort Configuration RMS	EMail External Event Trigger MIS Web Access Xm/Rc
eneral Printing Panel Typ	es Facility Code Retention Policy Password Policy BACNet Downlo
	Password Validation (days)
	Max, consecutive Invalid Logins 10
	Place conductor anyona cogina (11
Password Complexity	
	Minimum Length
Specify the minimum number	r of characters for each character group to establish the required
password complexity.	
	'A' to 'Z' or 'a' to 'z'
	'0' to '9' 0
	Other 0
Enforce EDA Title 21 CE	D Dark 11 December Delice
T LINGIGET DA TRE 21 CT	Crait II Password Policy
Directory Services Passwon	d Validation
Directory Serv	ices Path LDAP://CN=Users,DC=cg,DC=na,DC=jci,DC=com
Username Ho	smatting positivanic
	Principal
	Principal
F	Principal
F	Principal Password View Construction
ſ	Principal Password V Use Encryption V Secure Authenbication

Password Validation – Enter the number of days during which a changed password remains valid. Users are required to change their password within this period; otherwise, the account is automatically disabled. The user is informed of the password expiration at the next login. If you enter θ in this field, the password remains valid indefinitely. If complying with FDA Part 11, FDA recommends that the password be changed every 30 days.

Max. consecutive Invalid Logins – If users exceed the maximum number of consecutive invalid login attempts entered in this field, they immediately lose their ability to access the P2000 system and the account is automatically disabled for one hour. There are no limitations if you enter θ . FDA recommends no more than three invalid attempts.

Minimum Length – Enter the minimum number of characters in a password. FDA recommends the password to be at least 6 characters long.

'A' to 'Z' or 'a' to 'z' – Enter the number of letters (uppercase and lowercase) required in a password.

'0' to '9' – Enter the number of numerals required in a password.

Other – If you wish to use characters not defined as letters or numerals (symbols such as & or !), enter the number of symbols required in a password.

Enforce FDA Title 21 CFR Part 11 Password Pol-

icy – This feature is available for selection if your facility uses the FDA Part 11 feature. Select this box to enable FDA Part 11 password policy. For more information, see FDA Part 11 on page 429.

IMPORTANT: Changes to any of the FDA Password Policy settings take effect only after all services have stopped and restarted using Service Control. You must also log off and on at the Server computer to see these changes.

Directive Services Password Validation

Directory Services Path – This is the Lightweight Directory Access Protocol (LDAP) path for the directory server. This setting is specific to the network; contact your network administrator for assistance. See P2000 Directory Services Password Validation on page 27 for more information.

Username Formatting – This is the formatting of the username passed to Directory Services for authentication. The username is the string as entered with \$USERNAME replaced by the actual username. For Windows Active Directory the default \$USERNAME is recommended. Special formatting may be needed for LDAP systems or when requested by your Directory Services administrator.

Principal – This is a service account that is used to connect to the LDAP source for single sign-on login of an Active Directory Group account.

Password – Enter a password for the Principal service account.

Use Encryption – Forces the connection to the Directory Services to use data encryption for network communications. Not recommended for Windows Active Directory. May be requested by your Directory Services administrator.

Secure Authentication – Requests the connection to the Directory Services to be made using secure communications such as Kerberos. Recommended for Windows Active Directory. May be requested by your Directory Services administrator.

Bind Server – Requests the Directory Services to bind to the server. Not needed for Windows Active Directory. May be needed for LDAP systems if your Directory Services Path includes a server name or when requested by your Directory Services administrator.

Download Tab

Use this tab to define different downloading options.

Port Configuration	RMS	EMail E	external Event Trigg	er MIS	Web Access	XmlRpc
Download Option	o disabled pane	ls	e Recendion Polic;	/ Passworu	POICY BACNEL	Download
C Download b	adges with Uno el access group	lefined entry download d	/exit status sable			
Delayed do Smart Download	wnload for bad	ges and acce	ss groups			
5	Minutes Delay					
Shared Mode Ba	dge Downloads					
Download 4	ccess Groups o	f badge				

Download to disabled panels – Select if you wish to download items to disabled panels. If this option is not selected and the panel is offline, items that are automatically downloaded by the system are not queued for download until you select this check box again.

Note: If you do not select this option, when you enable the panel again using the Enabled function in the Edit Panel dialog box, you should queue a complete download for that panel; see Downloading Data to Panels on page 463.

Download badges with Undefined entry/exit status – Select to change the entry/exit status of downloaded badges to Undefined.

Legacy panel access group download disable -

Select to disable downloading badges to the panel when access groups are changed.

Delayed download for badges and access

groups – If you select this option, badge and access group downloads to panels are performed using Smart Download instead of performing the download immediately. This moves the burden of building the download from the workstation to the server, in addition to delaying the download by the number of minutes set in the Smart Download Rules box. This option only effects downloads caused by editing badges, access groups, or terminal groups. This option does not apply to badge and access group downloads performed using the Download application. See Controlling Smart Download on page 465.

Smart Download Rules – This option defines the time for downloading badges to panels when changes are made to access groups and terminal groups, as well as defines the time for downloading cardholder and badge changes. The download starts automatically whenever the system does not process any access groups, terminal groups, cardholder or badge changes, during the number of minutes that you enter in this field. The default value is 5 minutes. Enter **0** to download immediately.

Download Access Groups of badge – Select to enable downloading of access groups when downloading badges after a Central mode request for a terminal in Shared mode. Changes to this option only take effect after you restart the P2000 Priority Service; see Starting and Stopping Service Control on page 470.

Port Configuration Tab

Use the Port Configuration tab if you wish to change the default port values that are assigned to the P2000 system applications during software installation. To change a port number, double-click the desired value and enter a number between 1 and 65535, you are prompted to restart the Server and all workstations.

ame	Value	
IMETIS Interface Command Port	41042	
ssa Ablov DSR Interface Command Port	41039	
vigion Interface Command Port	41044	
osch Interface Command Port	41041	
K720 v 1.0 Download Port	1198	
K720 v 1.0 Priority Port	1200	
K720 v1.0 Upload Port	1199	
K720 v2.1 Priority Port	10201	
K720 v2.2 Download Port	41014	
K720 v2.2 Priority Port	41012	
K720 v2.2 Upload Port	41013	
K720Dnld Command Port	41004	
ndura Service Command Port	41037	
xternal Trigger TCPIP Listen Port	42000	
ID Communications Port	4070	
ID Interface Command Port	41034	
ntercom Interface Command Port	41017	
sonas Communications Port	10001	
sonas Interface Command Port	41029	
lercury Interface Command Port	41043	
lilestone Interface Command Port	41032	
liestone MIP Interface Command Port	41038	
luster Command Port	41010	
ice v 10.5 Interface Command Port	41033	
InSSI Interface Command Port	41035	
PC Proxy Command Port	41022	
tis Interface Command Port	41030	

The CK720 Priority Port, CK720 Upload Port, and CK720 Download Port values (firmware Version 2.2 and later) *must* match the values configured at the panel, and *must* use TCP/IP port numbers above 41000. CK720 panels Version 1.0 do not allow Priority and Download Port changes. See the following recommended port values:

	CK7xx 2.1 or earlier	CK7xx 2.2 or later
CK720 v2.1 Priority Port	10201	N/A
CK720 v.2.2 Priority Port	N/A	41012
CK720 v1.0 Upload Port	1199	N/A
CK720 v2.2 Upload Port	N/A	41013
CK720 v2.2 Download Port	N/A	41014

If the mix of panel versions in the P2000 system does not need a particular port, set the value to 0 to disable that port. If the P2000 system contains only CK7xx panels that are Version 2.1 and later, disable the CK720 Priority Service v1.0 using the Service Startup Configuration application; see page 466.

Note: We recommend not changing the P2000 XmlRpc Interface Port. If you need to do so, contact Technical Support for further instructions.

RMS Tab

Settings in the Remote Message Service (RMS) tab determine if your P2000 site receives messages from remote P2000 sites. In addition, you can define whether remote messages indicating alarm status changes for local or remote alarms are to be processed.

C Edit Site Parameters
General Printing Panel Types Facility Code Retention Policy Password Policy BACNet Port Configuration RMS EMail External Event Trigger MIS Web Access Static
✓ Process Received Remote Messages
Message Filter Group East Coast Alarm Monitoring
Alarm Processing Process Remote Operator Actions For
T Local Alarms
✓ Remote Alarms
Inactivity Period
Receiving Messages (sec)
Transmitting Messages (sec)

Process Received Remote Messages – Select if you wish to receive messages from remote P2000 sites. If you select this option, the P2000 Remote Message Service processes incoming messages and passes them on to RTLRoute for distribution within the local system and, if applicable, to other remote sites.

Message Filter Group – Select the Message Filter Group that defines which remote messages your P2000 Remote Message Service processes. If you select **<None>**, your local P2000 site can receive all remote messages. See Configure Message Filtering and Message Routing on page 236 for detailed information.

Local Alarms – Select to allow operators at a remote site to acknowledge, respond, and complete alarms originated at your P2000 site. By default, this option is not selected.

Remote Alarms – Select to allow operators at a remote site to acknowledge, respond, and complete alarms originated at other P2000 sites. By default, this option is selected.

Note: Although the Alarm Status column in the Alarm Monitor window displays a **Responded** status, the alarm response entered at a remote P2000 site is **NOT** part of the P2000 alarm history in your P2000 site.

Receiving Messages (sec) – Enter the time in seconds after which the P2000 system generates an alarm because no messages are received from a remote server. If you enter 0, an alarm is not generated.

Transmitting Messages (sec) – Enter the time in seconds after which the P2000 system generates an alarm because no messages are transmitted to a remote server. If you enter 0, an alarm is not generated.

Note: The time configured here is applicable to all remote server connections from or to this computer. Inactivity periods are checked every 30 seconds by the Remote Message Service. These periods should be configured in line with the maximum duration of session configured in the Transmit Session tab in the P2000 Remote Server dialog box of the transmitting system. See Configuring P2000 Remote Servers on page 245.

All remote message server communication alarms generated by the local system are reset to *Secure* when the P2000 Remote Message Service is restarted.

EMail Tab

Use this tab to enter a valid email account that can be used to send email messages, and also where automatic error returns could be sent. Before you enter your connection parameters, check with your Internet Service Provider (ISP) or IT department to verify the required connection settings.

C Edit Site Parameters	
General Printing Panel Types Port Configuration RMS	Facility Code Retention Policy Password Policy BACNet C EMail External Event Trigger MIS Web Access
SMTP Hello Domain	redtwo_p3
Return Address	xxxx@xxxx.com
SMTP Server	Mail.ABC
☑ Use Authorized SMTP	
Use Dial-up Connection	
	Dial-up Connection Name pacbell
	Username abcdef
	Password •••••

SMTP Hello Domain – This value is the domain name sent with the SMTP *Hello* command. Enter the domain of the computer sending the email. The computer name of the P2000 Server is normally acceptable unless your SMTP Administrator requests a specific value.

Return Address – Enter the email address at your P2000 site that is used to send messages and also is used to receive automatic error returns.

SMTP Server – Enter the name of the SMTP (Simple Mail Transfer Protocol) Server provided by your Internet Service Provider (ISP) or IT department.

Use Authorized SMTP – Select if your ISP requires authenticated email connections that need a username and password to send emails. The Dial-up Connection Username and Password is used.

Use Dial-up Connection – Select if your P2000 site uses a dial-up connection (via telephone lines).

Dial-up Connection Name – Enter the name of the dial-up connection used at your P2000 site.

Username – Enter the name to be used to establish the dial-up connection.

Password – Enter the password to be used to establish the dial-up connection.

External Event Trigger Tab

The P2000 software allows external inputs to be used as event trigger conditions. These external inputs can be in the form of an RS232 serial message or a TCP/IP message; an ASCII file or a database write. These inputs allow external software or hardware systems to send a message to the P2000 system, which triggers a Host event that in turn generates an alarm or other event action.

Settings in this tab define which of the external inputs are monitored.

Edit Site Parameters				
eneral Printing Panel Ty	pes Facility Code F	letention Policy Pas	sword Policy B	ACNet Download
Port Configuration RM5	EMail Extern	ial Event Trigger	1IS Web /	Access XmlRpc
RS232 External Trigger				
Enable				
COM Port COM	<u> </u>	Parity	None	-
Baud Rate 9600	-	Stop Bits	1	
	_	5100 510		
TCPIP External Trigger				
✓ Enable				
File External Trigger				
🔽 Enable			Scan Interval	10
	Filena	ame		
		,		
Database External Trigger				
Enable			Scan Interval	10

RS232 External Trigger – If you select **Enable**, the P2000 system opens the configured RS232 port and listens for incoming characters. When characters are received, they are placed into an input buffer. When a carriage return is received, the current contents of the input buffer is processed and checked to see if it meets a trigger condition. When the input buffer has been processed, it is cleared and P2000 starts waiting for the next message. If you select this option, you must specify the **COM Port** to use. The RS232 port is initialized with the **Baud Rate**, **Parity**, and **Stop Bits** configured for that port. **TCP/IP External Trigger** – If you select **Enable**, the P2000 system creates a TCP/IP socket on the configured IP port and listens for incoming characters. When characters are received, they are placed into an input buffer. When a carriage return is received, the current contents of the input buffer is processed and checked to see if it meets a trigger condition. When the input buffer has been processed, it is cleared and the P2000 starts waiting for the next message. The external system may connect to this TCP/IP socket and remain connected or it may disconnect after each message. If the external system remains connected, then only one external system may send messages. If the external system connects, sends the message, and then disconnects, then multiple external systems may send messages. If the P2000 detects a network error or if the external system closes its connection, the P2000 returns to the listen state waiting for new incoming connections.

File External Trigger – If you select Enable, the P2000 system periodically checks the configured location to look for the existence of the configured file name. When the specified file is found it is renamed to <original name>.BAK. After it has been renamed, the lines in the file are processed. The file must contain only ASCII text. If the file contains multiple lines, each line must be separated by a carriage return. The last line in the file may optionally include the carriage return or not. Each line in the file is processed separately and checked to see if it meets a trigger condition. After the file has been processed, it is deleted. If you select this option, you must enter the path and Filename of the ASCII file to look for, as well as the Scan Interval time (1 to 65535 seconds) between scans.

Database External Trigger – If you select Enable, the P2000 system periodically checks for any records in the external trigger database table. Each row found in this table is processed separately and checked to see if it meets a trigger condition. After a row has been processed, it is deleted. If you select this option, you must enter the Scan Interval time (1 to 65535 seconds) between scans.

Note: Since these external inputs do not authenticate the user sending the incoming message, enabling any of these inputs may cause the P2000 system to be non-compliant with FDA Title 21 CFR Part 11. When you enable any of these external inputs, Site Parameters checks the Enforce FDA Rules setting. If this setting is on, then a warning message displays to inform that the P2000 system may now be non-compliant if the events modify database records. See FDA Part 11 on page 429.

XmIRpc Tab

Use this tab to configure communications with an external device using the XmlRpc protocol.

C Edit Site Parameters			×
General Printing Panel Types Facility Port Configuration RMS EMail	Code Retention Policy External Event Trigger	Password Policy BACNet MIS Web Access	Download XmlRpc
Password Mode Base	54 💌		
∏ ali	ow Any IP Address		

Password Mode – Select one of the following encryption modes to be used for XmlRpc communication:

- **Base64** Password is Base64 encoded.
- Clear Text Password is not encoded.
- Ignore Password parameter is not validated.

Allow Any IP Address – Select to allow the P2000 system to accept XmlRpc commands from any IP address. If not selected, the P2000 system only accepts XmlRpc commands from IP addresses defined in the External IPs dialog box; see page 380 for details. Changes to this setting only take effect after you stop and restart the P2000 XmlRpc Interface service.

Local Site

The P2000 Local Site name is assigned during the initial software installation and uniquely identifies the P2000 site within the P2000 Enterprise System.

The Local Site name is a system wide setting and does not require a partition reference. The site name is part of all audit entries, alarms, and transactions originated in your system. Applications such as the Alarm Monitor and Real Time List display the site name to indicate the P2000 site where the message originated.

The system allows changes to the Local Site name, for example to change the name of the facility location, however frequent changes to this setting are not recommended. Changes to the Local Site name can only be performed from the P2000 Server.

To Edit the P2000 Local Site Name:

- 1. In the System Configuration window, expand **Site Parameters**.
- 2. Select Local Site and click Edit to open the Local Site Edit dialog box.

🕻 Local Site Edit	×
Local Site Name Atlar	ta Office
ОК	Cancel

- 3. Enter a Local Site Name (up to 32 characters) that easily identifies your P2000 site.
- 4. Click OK to save the Local Site Name.
- 5. A message displays, warning that changing the site name requires you to update existing database records that refer to the current site name. Click **Yes** if you want to proceed to change the name.
- 6. You are prompted to stop all P2000 services at the Server (see Starting and Stopping Service Control on page 470) and to log out of all workstations.
- 7. Click **OK** to proceed with the update of the database tables.
- 8. After the database tables have been updated, click **Yes** to restart the Server computer.

Local Configuration

Use the Local Configuration window to enter the database server source and application path of your P2000 system. You can also select the language in which you wish the P2000 software to run. Incorrect settings in this dialog box may cause the P2000 software not to function properly.

 From the P2000 Main menu, select Config>Local. Enter your password if prompted. The Local Configuration dialog box opens.

L	ocal Configuration 🗙
	Database Connection
	ODBC Data Source pegasys
	Cursor Type dynaset
	Lee ODBC Cursor Lib
	Optimize for LAN Optimize for WAN
	Applications Application Path C:\Program Files\Johnson Contro Browse
	Language <system setting=""></system>
	OK Cancel

- 2. The **ODBC Data Source** field displays the name of the ODBC data source that communicates with the database server.
- 3. Click one of the following buttons to change the database connection settings for the local computer:

Optimize for LAN – To set the database connection settings to values that are appropriate to a Local Area Network (LAN).

Optimize for WAN – To set the database connection settings to values that are appropriate to a Wide Area Network (WAN) or any other type of connection to the P2000 database server with reduced bandwidth or high latency times.

- 4. The **Application Path** field displays the location of the P2000 program. Click **Browse** to find another path, if the location has changed.
- If you wish to run the P2000 software in a language that is different from the Windows operating system language, select the desired Language from the drop-down list, otherwise use the default <system settings> option.

Note: Contact your Johnson Controls representative if you wish to run the P2000 software in a different language.

6. Click **OK** to save your settings. If you are switching languages, you are prompted to close all P2000 programs and restart for the changes to take effect.



Time Zones

Time zones define all the periods during which a reader, badge, alarm point, or other system component or feature is active or inactive. A time zone is a set of enable and disable times applied to days of the week and holidays. You can set up different time zones and then assign these time zones to readers, inputs, outputs, terminal groups, and other system elements.

You can define an unlimited number of time zones, but you must assign at least one time zone to each panel. This could be done at the time you create the panels or later. See Configure Panel Time Zones on page 66.

After you configure your time zones, expand the Time Zones icon to display all configured time zones. When you click on a Time Zones icon, the values for the time zone display on the right windowpane. See Appendix C: Panel Comparison Matrix for the maximum number of time zones supported by each panel type.

Configuring Time Blocks

The period between an active and inactive time may be thought of as a time block. Some panel types allow up to four time pairs (four active and four inactive times); therefore, you can configure up to eight time blocks per day for those panels. See the table on page 37 for the number of time pairs per day allowed for each panel type.

The previous example shows eight time blocks representing a *business hours* day, opened at 6:00 A.M., closed one hour for lunch, opened until 6:00 P.M., and opened for cleaning from 10:00 to 11:00 P.M.

	Name: Wh	nse Hours		_	Partition	Super User		Pu 🔽 Pu	blic
eriods									
Monday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
uesday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Vednesday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
hursday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
riday	Inactive	12:00:00 AM	6:00:00 AM	12:00:00 PM	1:00:00 PM	6:00:00 PM	10:00:00 PM	11:00:00 PM	11:59:00 PM
Saturday	Inactive	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM
unday	Inactive	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM
toliday 1	Inactive	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM
loliday 2	Inactive	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM
loliday 3	Inactive	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:00 AM
1									
·									
			E	Edit	Copy	Paste			
h (K									
iber or time p	airs per day: 4								
nber of unique	e time pairs per `	Timezone: 40							

To Create a New Time Zone:

- 1. In the System Configuration window, select **Time Zones** and click **Add**. The Time Zone dialog box opens displaying the maximum number of time pairs, as defined in Site Parameters; see Timezone Tab on page 39.
- Select the day of the week (or a holiday) you wish to define and click Edit. A time zone dialog box opens with the name of the day in the title block. The number of time periods available depends on the parameters selected in Site Parameters.

Monday				×
Period	12:00 AM	Period	12:00 AM	Start As
Inactive Active	6:00 AM		12:00 AM	C Active
Inactive	▼ 12:00 PM		12:00 AM	Set Default
Inactive	 ✓ 6:00 PM ✓ 10:00 PM 		12:00 AM	
Active Inactive	▼ 11:00 PM		12:00 AM	
Active	11:59 PM		12:00 AM	ОК
	12:00 AM		12:00 AM	Cancel

3. In the Start As box, select whether, starting at midnight, this time zone is Inactive or Active.

If you select **Inactive**, the time period between 12:00 A.M. and the hour entered in the first field in the list is labeled *Inactive*. (See the Period group box.) If you select **Active** from the Start As box, the time period between 12:00 A.M. and the hour entered in the first field in the list is labeled *Active*.

4. In the Period group box, define the time at which the period between 12:00 A.M. changes status (from Active to Inactive or vice versa).

Note: The time format displayed throughout the P2000 software is set up in the Windows Control Panel, Regional Options.

Check the box and select the hour from the spin box. For example, if the time period starting at midnight is *Inactive*, enter the hour at which the time period becomes *Active*. In the next field, select the time at which the period returns to *Inactive*. You can include minutes, if needed.

Note: The number of Active and Inactive times is limited to the **number of time pairs per day** defined in Site Parameters. Select only those time check boxes you wish to enable. For example, to create a Time Zone that is active from 6:00 A.M. to 6:00 P.M., select the first check box and set the time to 6:00 A.M.; then select the second check box and set the time to 6:00 P.M.

- 5. The **Set Default** button sets all times to 12:00, and either Active or Inactive as defined in the Start As box.
- 6. Click **OK** to save the settings and return to the Time Zone dialog box.
- 7. Continue to edit and enter time zones, until all days of the week and any applicable holidays have been defined. See the next section To Copy a Time Zone:.
- 8. Enter a descriptive **Name** for the new time zone (Day Shift, Full Time, and so on).
- 9. If this is a partitioned system, select the **Partition** in which this time zone is active.
- 10. If this is a partitioned system, select **Public** if you wish this time zone to be visible to all partitions.
- 11. Click **OK**. If you wish to add this time zone to all panels, click **Yes**. Otherwise, you must add the new time zone for each panel separately using the Panel Timezone application; see page 66.

The new time zone displays under the root Time Zones icon. These time zones are now accessible to other system features such as panels, workstations, cardholders, and so on, for the partition selected.

To Copy a Time Zone:

You can copy a time zone from one day to the next, or to all of the days.

- 1. In the Time Zone dialog box, define one time zone (a day of the week or a holiday).
- 2. Select the defined **time zone** and click **Copy**.
- 3. Select the day to which you wish to copy the time zone and click **Paste**.

Holiday Types

When the system reaches midnight prior to a day defined as a holiday it switches to Active and Inactive periods, depending on the Holiday Type specified for that time zone.

You can define three Holiday Types. For example, you may want to define a Type 1 holiday to indicate a full day, such as Christmas Day; and a Type 2 holiday as a half-day, such as Christmas Eve; and a Type 3 that is specific to your company.

You can set different Holiday Types for different Time Zones. For example, Night Shift full-day holiday hours may begin and end at different times than Day Shift full-day holiday hours.

IMPORTANT: See Assa Abloy Holiday Definition on page 174 for specific instructions associated with Assa Abloy locks.

To Create Holiday Types:

- 1. In the Time Zone window, select **Holiday** 1 and click **Edit**.
- 2. Define the Active and Inactive periods as described for the other days of the week.
- 3. Define Holiday 2 and 3, if needed.
- Click **OK** to save your settings and return to the System Configuration window.

These holiday types correspond directly to Type 1, 2, and 3 in the Edit Holiday dialog box.

Holiday

Use the Holiday window to define dates when the system uses Holiday 1, 2, or 3 active and inactive periods rather than the usual time zones set for those days of the week. When the system reaches midnight prior to a day defined as a Holiday, it switches to Active and Inactive periods, depending on the Holiday type specified for that time zone.

Each day of a Holiday period must be assigned separately. For example, you may plan to allow two days off for the Christmas holiday. You must define two separate holidays with separate names and dates, such as Christmas 1 for the first date, and Christmas 2 for the second date.

You can define an unlimited number of holidays.

To Add a Holiday:

1. In the System Configuration window, select **Holidays** and click **Add**. The Edit Holiday dialog box opens.



Select a Type as defined on the Time Zone dialog box

2. If this is a partitioned system, select the **Partition** to which the Holiday applies, and select **Public** if you wish this Holiday to be visible to all partitions.

- 3. Enter the **Name** of the Holiday.
- 4. Enter the **Date** of the Holiday. (See Using the Holiday Calendar for details.)
- 5. Select the **Type: 1, 2,** or **3** depending on the Holiday types set up in the Time Zone dialog box.
- Click OK to save the new Holiday. If you wish to add this Holiday to all panels, click Yes. Otherwise, you must add the new Holiday for each panel separately using the Panel Holiday application; see page 67.

Note: If you select to add the new Holiday to all panels, the system may display a message indicating that the number of panel holidays has exceeded (or there are duplicate dates in P900 Panel Holidays) for the panel names that display in the list box.

Using the Holiday Calendar

When you click the **Date** down arrow on the Edit Holiday dialog box, a calendar displays where you can select a specific date for the Holiday.

To Change the Calendar Month:

Do one of the following:

- 1. Use the left or right arrows in the Calendar header to move forward or backward through the months.
- 2. Press Page Up or Page Down to move through the months.

🔹 November, 2013 🕨									
Sun	Mon	Tue	Wed	Thu	Fri	Sat			
27	28	29	30	31	1	2			
3	4	5	6	7	8	9			
10	11	12	13	14	15	16			
17	18	19	20	21	22	23			
24	25	26	27	28	29	30			
1	2	3	4	5	6	7			
		Too	lay: 1	1/25	5/20	13			

To Change the Calendar Year:

Do one of the following:

- 1. Use the left or right arrows in the Calendar header to move forward or backward through the months into the next or last year.
- 2. Click the year in the Calendar header. Use the left or right arrows to move forward or backward through the years.

•	2013		Þ
Jan	Feb	Mar	Apr
May	Jun	Jul	Aug
Sep	Oct	Nov	Dec
Today: 11/25/2013			

Assigning Holiday Types

Holiday Types correspond directly to Holiday 1, 2, and 3 on the Time Zone dialog box. You can define different hours for each holiday type, depending on your facility's preferences. For example, in the Time Zone window, you may designate Holiday 1 as a full day and Holiday 2 as a half day. You can then create a holiday in the Holiday dialog box, such as New Year's Eve, as Type 2, changing the active and inactive times for that holiday to correspond with a half-day schedule. (See Time Zones on page 49 for more information on creating Holiday types.)
Configure Hardware Components

Hardware components are the physical panels, terminals, and other inputs and outputs that make up the security management system. After the physical panel and terminal hardware is set up at the various system locations, panels and terminals must be created and then configured using the P2000 software program.

Hardware Configuration Sequence

When you create panels, the new panels display under the root Panels icon in the System Configuration window, and placeholders for additional items that need to be configured are listed under each panel.



The logical configuration sequence; however, does not follow the order presented on the System Configuration window. We recommend hardware configuration begin with the following sequence:



Create Panels

Field panels are advanced intelligent controllers that interface between the Server and other hardware in the system. Some panels (CK7xx, S321-DIN, S321-IP, OSI, Isonas, HID, Assa Abloy, and Mercury), communicate with the Server via network connections.

Other panels (legacy, S321-DIN, and P900), communicate with the Server via a serial connection using loop configurations. You must set up loop configurations before creating these panels; see Loop Configuration on page 54.

Note: S321-DIN panels can be installed in a network or serial configuration.

For hardware installation and specification information, refer to the documentation that was shipped with your panel.

Panel Naming Conventions

Panels should be named logically, including information such as a panel's location and what it controls. This is helpful when configuring other system components and when troubleshooting the system. For example, the panel name *Bldg B SW Corner* is more meaningful to an operator than *Panel 1B*. Descriptive names cannot only identify the panel name and location; but also, when terminals and time zones associated with a panel use similar names, the components are listed together (alphabetically).

Loop Configuration

The P2000 Server uses loop configurations to communicate with legacy, S321-DIN, and P900 panels. The system supports up to 32 loops, with up to 16 legacy panels per loop, up to thirty S321-DIN panels per loop, and up to sixty-four P900 panels per loop. For more information, see Loop Communication on page 7. New loops can only be created at the Server.

To Set Up Loop Configurations:

- 1. In the System Configuration window, expand **Panels**.
- 2. Select **Serial Loops** and click **Add**. The Loop Configuration dialog box opens.
- 3. Select a loop Number (1 32).
- 4. Click **Enable** to establish software communication with the loop. If you wish to temporarily disable loop communication, without having to delete the loop, click again to clear the check box to disable it.
- 5. Select the **Baud** rate that was programmed at the panel. (The default is 9600.)

- 6. Select the Serial **Port**. This represents the actual port in the AccelePort Serial Adapter.
- 7. From **Panel Type**, select whether this loop is used by Cardkey Legacy, P900, or S321 panels.
- 8. If this loop is used by Cardkey Legacy panels, click **Monitor Loop Tamper** to allow panels to monitor loop tamper alarms. This is the required option for UL listed sites, where all alarms must always be visible to meet UL requirements. Click again to clear the check box if you wish to disable monitoring.
- 9. Click OK to save your settings.

After panels have been created and configured for loop communication, the bottom box in the Loop Configuration dialog box displays the panel name, model (D620, S320, P900, S321, and so on), address, timeout setting, and loop direction (forward or reverse, for legacy only). The system also allows you to enable or temporarily disable the panel from here, and this setting is reflected in the Edit Panel dialog box for the panel selected.

ļ	vumber: 2 I⊽ Enable	<u> </u>		Baud: 9600 Port: COM2		Panel <u>T</u> ype:	Cardkey Legacy
nabled	Monitor Lo	p Tamper	Direction	Model	Danel Name		P900
Habieu	Mulicos	170 113	Direction	noder	Pariorivanio		

This document contains confidential and proprietary information of Johnson Controls, Inc. © 2014 Johnson Controls, Inc.

Panel Configuration

Before configuring the panels that control your security system, you must identify the type of panel installed at your facility and follow the pertained instructions.

The following sections describe procedures to configure CK7xx, S321-DIN, and Legacy panels and related components.

The steps to configure other panel types differ from the procedures described here. If you plan to configure P900, OSI, S321-IP, Isonas, HID, Assa Abloy, or Mercury panels, you must skip the remaining sections and proceed to one of the following sections:

- **Configure P900 Panels and Components** on page 103.
- Configure OSI Panels and Components on page 120.
- Configure S321-IP Panels and Components on page 133.
- Configure Isonas Panels and Components on page 146.
- Configure HID Panels and Components on page 152.
- Configure Assa Abloy® IP Door Locks and Components on page 164.
- Configure Mercury Panels and Components on page 179.

Also, see Appendix C: Panel Comparison Matrix to see the features supported by each panel type.

To Add a New Panel:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Select one of the following panel types:

CK7xx Panels – To configure CK705, CK720, CK721, and CK721-A panels.
S321 Panels – To configure S321-DIN panels. **S321-IP Panels** – To configure S321-IP panels, go to page 133 for details.

Legacy Panels – To configure D620, D620-TIU, D600 AP, and S320 panels.

Isonas Panels – To configure Isonas panels, go to page 146 for details.

HID Network Panels – To configure HID panels, go to page 152 for details.

Mercury Panels – To configure Mercury panels, go to page 179 for details.

OSI Panels – To configure OSI panels, go to page 120 for details.

P900 Panels – To configure P900 panels, go to page 103 for details.

Assa Abloy Panels – To configure Assa Abloy panels, go to page 164 for details.

- 3. Click **Add**. The Edit Panel dialog box opens at the General tab.
- 4. Fill in the information on each tab. (See Edit Panel Field Definitions for details.)
- 5. As you work through the tabs, you may click **Apply** to save your entries.
- 6. Click **OK** to save your entries. A message box displays asking if you wish to automatically add all time zones to the new panel. If you select **No**, you can add the time zones later; see Configure Panel Time Zones on page 66.
- 7. If you select **Yes**, the time zones are automatically added. When you return to the System Configuration window, the new panel name displays under the selected panel type.

Note: For CK7xx panel software Versions 1.1 and later, the panel version number displays on the right windowpane of the System Configuration window, after that panel establishes communication with the Server.

Soft Input Points

When a panel is created in the system, a Panel Down soft input point is automatically created for input point 25 and displays under the Soft Input Point icon as *Panel Down < panel name*>. If you wish to report this type of alarm, edit the input point and make sure the **Disable Alarm** option is not selected in the General tab of Alarm Options, otherwise the alarm does not report to the Alarm Queue, but continues to report to the Real Time List (see Alarm Options Tab on page 91).

If you rename the panel, you must edit the input point to manually enter the new panel name, as in *Panel Down <panel name>*. See Create Input Points on page 90 for detailed information.

Edit Panel Field Definitions

General Tab

This dialog box defines descriptive information of the panel.

🕼 Edit Panel	
General Address History Acc	ess Alarm Elevator Encryption
<u>P</u> artition: <u>N</u> ame:	Super User Public North Tower
<u>T</u> ype:	CK721-A V3.1+
Query String:	High Speed R5485 No Badge Archive To Flash No Configuration Archive To Flash No Configuration Archive To Flash Backup DB to Flash Interval 24 hours
BACnet Interface I♥ Engble Panel I♥ Enable Ter I■ E	minals nable Tuputs nable Outputs

Partition – If you use Partitioning, select the Partition that has access to this panel information.

Public – If you use Partitioning, click Public to allow all partitions to see this panel.

Name – Enter a descriptive name for the panel.

Type – Select a panel type and corresponding firmware version from the drop-down lists.

- *If you select a CKxx panel type*, the Address and Elevator tabs are available.
- *If you select a legacy or S321 panel type*, the Loop/Unit, Misc, and Mag Format tabs are available.

Note: Certain features are enabled or disabled depending on the panel type and version selected. The version selected is validated when the panel connects. CK7xx panels (Version 2.1 and later) that do not match are put into a misconfigured state and are not allowed to fully communicate until the problem is resolved.

Enabled – The system does not recognize the panel unless you click **Enabled**. If you wish to temporarily disable the panel, without having to delete the panel or disconnect the network cable, click again to clear the check box to disable it. When you disable a panel, the readers continue to grant access, but the panel does not communicate with the Server until you enable the panel again.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

High Speed RS485 – Click to allow a fast communication rate with RS485 serial connectors to CK7xx add-on terminals. This option requires high-speed add-on terminals. Refer to the CK7xx manual for configurations that support the faster communications rate. **No Badge Archive to Flash** – Available for CK7xx panels Version 2.5 and later. If enabled, the Badge database is not saved to Flash during a Write-Flash operation.

No Access Group Archive to Flash – Available for CK7xx panels Version 2.5 and later. If enabled, the Access Group database (including elevator Access Groups) is not saved to Flash during a Write-Flash operation.

No Configuration Archive to Flash – Available for CK7xx panels Version 2.5 and later. If enabled, the Configuration databases such as Panel, Elevator, Terminal, Input, Output, Time Zones, Holidays, Soft Alarms, and Card Events are not saved to Flash during a Write-Flash operation.

Backup DB to Flash Interval – Available for CK721-A panels Version 2.10 and later. Enter the time interval (in hours) to schedule automatic backup of the panel database to flash memory. The default backup period is once every 24 hours. A backup period of 0 hours disables automatic database backups to flash memory. This feature is to be used in conjunction with the Write DB to Flash feature; see page 482 for details.

Custom Configuration Number – Available for CK7xx panels Version 2.6 and later. This option allows you to enter a number that is provided by Johnson Controls, to enable special custom features.

BACnet Interface – These settings are available after you select *Enable BACnet Interface* in Site Parameters; see page 379. Click **Enable Panel** to define the panel, and if you wish, the associated Terminals, Inputs, and Outputs, as BACnet objects. The number of BACnet objects should not exceed 7200. Keep the number of BACnet objects reasonably low; otherwise, system performance can be adversely affected. Refer to the *P2000 Metasys*® *System Integration Manual* for details.

Address Tab

Use this tab when configuring CK7xx panels. The information on this tab varies depending on the panel version selected. In general, this dialog box defines Primary and Alternate IP addresses for the panel. (You cannot complete panel configuration unless you assign an IP address.)

Note: You must first configure the panel at the Server, then proceed to configure the panel using the CK7xx panel user interface.

Address Tab for Panel Versions 1.1 to 2.0

🕼 Edit Panel				
General Address History Access Alarm				
- Drimmu				
IP Address: 200 . 0 . 0 . 2				
- ålternate				
IP_Address: 0 . 0 . 0				
Ereferred Primary Communication Path				
Network Timeout 5 🙀 seconds				
- , 2				

Primary IP Address – Enter the IP Address. This entry must match the IP address at the panel.

Alternate IP Address – Leave this field empty unless your panel has a second network connection.

Preferred Primary Communication Path – Click to indicate that this is the primary communication path between the panel and the Server.

Network Timeout – Some installations may require more time to complete communication between the Server and the panel. You can increase the time in seconds before a time out occurs between the P2000 Server and the panel. This value must match the panel local user interface; otherwise communication problems may exist.

Address Tab for Panel Versions 2.1 and Later

Seneral Addres	S History Access Ala	arm Elevator	Encryption		
Primary	Panel IP Address:	200 .	0.0	. 24]
		Days	Hours	Minutes	Seconds
	Panel Poll Interval:	0	0	0	30
	Host Poll Timeout:	0	0	1	15
Alternate					
	Panel IP Address:	0.	0.0	. 0	
		Days	Hours	Minutes	Seconds
	Panel Poll Interval:	1	0	0	0
	Host Poll Timeout:	2	1	0	0
	-	J			J

Primary Panel IP Address – Enter the IP Address. This entry must match the IP address at the panel.

Primary Panel Poll Interval – Enter the number of days, hours, minutes, and seconds to set up the maximum time that the panel should be without contact with the Server. This value is downloaded to the panel.

Primary Host Poll Timeout – Enter the number of days, hours, minutes and seconds that the Server waits without receiving a poll, until it declares the panel down.

Use the **Alternate** box to configure CK705 or CK720 panels (Version 2.6) that have a second network connection through a Dual Ethernet interface. Dual Ethernet allows the alternate connection to take over the communications if the primary connection fails.

Alternate Panel IP Address – For panels with two network connections, enter the IP address of the alternate connection. This entry should be from a different subnet address and must match the IP address at the panel. Alternate Panel Poll Interval – Enter the number of days, hours, minutes, and seconds to set up the maximum time that the panel should be without contact with the Server. This value is downloaded to the panel.

Alternate Host Poll Timeout – Enter the number of days, hours, minutes and seconds that the Server waits without receiving a poll, until it declares the panel down.

Loop/Unit Tab

Use this tab when configuring serial panels only.

🕼 Edit Panel						
General Loop / Unit Access Alarm History Misc						
Loop Number: 2 Prefetred Loop Direction Forward Unit Number: 1						
Loop Timeout: 200 💼 milliseconds						
Reestablish Delay: 60 seconds						

Loop Number – Select a loop number defined in the Loop Configuration dialog box. The P2000 system can support up to 32 loops.

Unit Number – Select a unit number to be assigned to this panel. The P2000 system supports up to sixteen legacy panels per loop and thirty S321-DIN panels per loop.

Loop Timeout – Select the time (100 to 2000 milliseconds) that the port driver waits for a response to a message, before going offline.

Reestablish Delay – Select the time (5 to 32000 seconds) after which the panel tries to reestablish communication.

Preferred Loop Direction – Select the direction (**Forward** or **Reverse**) the Server communicates with the panel in the loop configuration. Available for legacy panels only.

History Tab

History settings govern how the panel uploads data to the Server, and how long the panel retains data in the transaction database before older data is deleted.

History Tab for Serial and CK7xx (Versions 1.1 to 2.0) Panels

🖀 Edit Panel	
General Address History Access Alarm	
🔽 Upload	Delete At: 12:00:00 AM
	Delete After: 0 days

Upload – Click to constantly upload panel transactions directly to the Server in real time.

Restrict Storage – Click to limit the amount of data held at the panel. If enabled, you must also select a time at which data is deleted, and the number of days to hold data before deletion. This option is not available for TIU panels.

Delete At – Select the time when history is deleted.

Delete After – Enter the number of days you wish the panel to hold data before deletion.

History Tab for CK7xx Panels Versions 2.1 and Later

🕻 Edit Panel
General Address History Access Alarm Elevator Encryption
_ Upload
Imezone: Full Time
Upload only when greater than
50 ercent full
Always upload when greater than 80 percent full
☑ Delete history older than
2 days
at 12:00:00 AM 👘

Timezone – Select a time zone during which the panel uploads data to the Server.

Upload only when greater than – To limit the panel from always uploading data to the Server during the time zone selected, click and select a percentage from the spin box only after which data is uploaded.

Always upload when greater than – Click and select a percentage from the spin box after which the panel always uploads data to the Server.

Delete history older than – Click and enter the number of days the panel holds data before deletion. Select a time at which the history is deleted.

Access Tab

This dialog box defines Time Offsets for communicating with remote panels and other time zone-related information. Here you enable or disable Timed Override/Anti-Tailgate, Entry/Exit, and System Override parameters; and set the PIN Code type used at the panel. (See the *Tip* box on page 61 for more information on PIN types.)

_		
Ľ	🕻 Edit Panel	
	General Address History Access Alarm Elevator	Encryption
	Ime Offset C - 2	hours 0 minutes
	✓ Timezone ⊆hecking	Enforce Entry/Exit
	Timed Override/Anti-Tailgate	System Override
	Peer to Peer Badge Sync	
	Broadcast Port Number 47500	
	PIN Code	
	PIN Code Type Algorithmic	•
	PIN Code Digits 5	
	Scramble Mode 0	

Time Offset – Click if the panel is in a different geographical time zone from the Server. Enter the appropriate hours and minutes for the time offset.

Timezone Checking – Click if the panel is to check for valid reader and badge time zones, badge access requests, PIN code suppression, and upload suppression during the assigned time zones. If disabled, badge access decisions are made based on valid badge and valid access group parameters only.

Enforce Entry/Exit – Click if the panel operates Entry and Exit terminals. Entry and Exit terminals require the cardholder to badge at Entry and Exit terminals alternately. For example, badging at an Entry terminal and then badging again at another Entry terminal is invalid. If Entry and Exit terminals are installed in the panel, this option must be enabled for the Entry and Exit requirements to operate.

Timed Override/Anti-Tailgate – If enabled, a Reader-controlled door in a state of manual Timed Override is locked automatically when the door is closed. If disabled, the Reader-controlled door remains in override mode even when the door is closed. Using this feature requires the desired terminal's Anti-Tailgate check box to be enabled (see Flags Tab on page 72). **Note:** Timed Override/Anti-Tailgate and the PIN Code box are disabled if using TIU panels.

System Override – If enabled, all doors controlled by the panel are set in the unlocked position. If disabled, all doors are set to their normal position.

Note: The override state gets cancelled when communication with the panel is lost for more than 20 seconds (RDR2S-A in physical addressing mode and RDR8S) or 5 seconds (RDR2S-A in non-physical addressing mode and RDR2S). The override resumes when communication is reestablished. In addition, be aware that if you perform the **Resume Normal Operation** function from the Control All Doors application, the override state gets cancelled, but the System Override option remains enabled.

Peer to Peer Badge Sync – Available for CK721-A panels Version 2.10 and later. Click to have entry and exit privileges enforced on reader terminals connected to different CK721-A panels. This feature allows a CK721-A panel to broadcast the entry and exit status of a badge to multiple CK721-A panels, via User Datagram Protocol (UDP). This allows an entry and exit zone to span across multiple panels within the same subnet or across multiple subnets using a properly configured multicast router.

IMPORTANT: This feature must never be combined with the **Global Badge Entry/Exit Sta***tus Synchronization* option selection (see page 34). Selecting both features causes badge entry and exit enforcement errors across multiple panels. **Broadcast Port Number** – Enter the UDP port number used by the Peer to Peer Badge Sync UDP Broadcast agents. This number must match that configured at the other CK721-A panels.

PIN Code Type – Select **Algorithmic** or **Custom**. An algorithmic PIN is determined by an algorithm programmed in the terminal. A custom PIN code must be entered in the Badge window for each individual cardholder. (See the following *Tip* box for more information on PIN types, and see Configure PIN Codes on page 86 for instructions.) Algorithmic codes need to be requested from Technical Support.

PIN Code Digits – Select the number of PIN code digits that allow access at a keypad terminal. See Appendix C: Panel Comparison Matrix for the maximum number of PIN code digits supported by each panel type.

TIP:

IIT. We recommend all panels in the system that use PIN code readers be defined to use the same number of PIN code digits and to have the same PIN type, or access may be denied. Access could be denied because of mismatches in PIN code length and type between the PINs defined here and the PINs defined in the Badge window.

Scramble Mode – Eight algorithms are embedded in the terminal. If **Algorithmic** was selected in the PIN Code Type field, enter a number from 0 through 7 to choose the appropriate algorithm.

Alarm Tab

Panel relay, latch output functionality, and other parameters are set up in the Alarm tab.

Reporting Delay – If enabled, the alarm is delayed by the number of seconds (0 to 60) set in the Reporting Delay field. If the input point returns to the secure state before the delay expires, the panel does not report the alarm to the Server at all. If disabled, the alarm is reported immediately. Open and short conditions for 4-state input points are reported immediately regardless of this setting.

Latch Output – Not available for S321-DIN panels. If enabled, the alarm relay is activated whenever an alarm occurs, and remains latched (activated) until reset by a card activated event, or acknowledged at the panel. If disabled, the panel alarm relay is activated whenever an alarm occurs and deactivated when all alarms are reset (if configured to do so in the Input Point dialog box).

Enable Panel Relay Group Outputs – For use with CK7xx panels. If enabled, two output groups are created to represent the two physical output points on the panel CPU board: Relay 1 and Relay 2. These display as icons under the Output Groups icon for the panel selected. These output groups can be controlled as any other output group in the system.

Output Delay – Not available for S321-DIN panels. Enter the number of seconds before the latch in the Latch Output field is to be activated. Use this field only when the Latch Output field is enabled. You can define a time interval before the panel's alarm relay activates; for example, if an input point has been configured to activate the panel's alarm relay, this could be the selectable delay in seconds (0 to 60), before the relay activates. The delay starts after the input point has activated.

Enable Input Suppression Messages – Available for CK7xx panels Version 2.5 and later. If enabled, input points that enter suppression are reported as being suppressed. When the input is no longer suppressed, the current input point state is reported.

Elevator Tab

Use this tab to configure CK7xx panels to communicate with *High Level Interface* elevator control equipment via a protocol. Once the elevator protocol parameters are defined, use the Elevator Configuration dialog box to define the readers and associated outputs and inputs that operate with your particular elevator controller. For details, see Elevator Access Control on page 215.

🕻 Edit Panel
General Address History Access Alarm Elevator Encryption
Protocol Type KONE HLI
Darameters
T di dificici s
Baud Rate 9600 💌
Group Controller Address
Laurah Shari Gurun Cashallar 0
Lowest Hour for Group Controller

Protocol Type – Select the elevator protocol type to be used at your facility. Choices are: KONE HLI, Otis® EMS - Security/BMS, Otis Compass, and Kone IP. See Appendix C: Panel Comparison Matrix for the elevator protocols supported by each panel type. Protocols 4 to 9 are reserved for future use. If KONE HLI is selected, you must complete the next fields.

Baud Rate – Select the baud rate, options are 9600 or 1200. This setting must match the baud rate configured at the elevator group controller.

Group Controller Address – Select an address (1 to 8). This setting must match the address of the elevator group controller. An incorrect setting does not permit the integration to be operational.

Lowest Floor for Group Controller – Enter the lowest level (1 to 64) of the building served by any KONE elevator in this KONE group controller. An incorrect setting secures and unsecures floors other than those intended.

Encryption Tab

Use this tab to configure the P2000 software to secure every message to and from a CK721-A Version 3.1 panel, using Advanced Encryption Standard (AES) to protect the P2000 system from unauthorized sources. This encryption methodology is supported for all three channels: Upload, Download, and Priority.

Note: P2000 Version 3.11 Encryption is implemented using Federal Information Processing Standards (FIPS) 140-2, validated, (Certificate #1336), cryptographic module, from Microsoft <u>http://www.microsoft.com</u>.

Misc Tab

Use this tab when configuring legacy and S321-DIN panels only. Not available for TIU panels.

eneral Loop / Unit Access Alarm Hist	ory Misc Mag Format
Facility	
Facility Code 1	Facility Code 2
0	0
Facility Code 3	Facility Code 4
0	0
	,
Enable PIN Duress	Security Level 0
FIN Plus 1 Duress	
PIN Code Timed Override	No. of PIN Retries
🗖 Log Reader Strike Message	
E Log Output Status Massage	

Facility – Some of the codes stored in every badge are known as facility codes. These codes allow you to identify the badges that belong to your facility. Enter the facility code provided for your facility.

Note: CK7xx facility codes are assigned in the Edit Terminal dialog box.

Enable PIN Duress – For use with D600 AP panels only. If selected, a duress alarm is generated when a cardholder substitutes a **9** for one of the PIN code digits. If not selected, the cardholder can use the digit 9 without triggering a duress alarm. The digit 9 is usually reserved to indicate that a cardholder is seeking entry under duress (the door is opened, but an alarm is sent to local security that the user is being forced to make the entry request).

IMPORTANT: You must define the encryption key before enabling encryption.

EC85E9C7

1F71D345

B17B0E6

🕻 Edit Panel

Encryption Enabled

Encryption Key: EF658099

309F3169

Create

General Address History Access Alarm Elevator Encryption

A9494F97

Encryption Enabled – Click to allow encryption of all messaging between the CK721-A Version 3.1 panel and the P2000 Server. Encryption must be enabled at the CK721-A panel using its local user interface.

Note: While encryption is enabled, Telnet and FTP network connections are rejected by the CK721-A panel.

Create – Click to generate a random encryption key.

Encryption Key – The Encryption Key text boxes display the key to be used for encrypted communications. If you prefer you may enter your own key (not to exceed 64 digits) in the text boxes. This key must match the key configured at the CK721-A panel using its local user interface. Refer to the *CK721-A Version 3.1 Installation and Operation Manual* for details. **PIN Plus 1 Duress** – For use with D600 AP panels only. This is a protected feature and can only be used by defining Enable Codes; see page 68 for details. If selected, a duress alarm is generated when a cardholder adds 1 to the last digit of the PIN code (for example, 5 becomes 6, not 51). If the last digit of the PIN code is a 9, then the user substitutes a 0 for the 9 and this triggers the duress alarm. This feature only works if the Enable PIN Duress option is not selected.

PIN Code Timed Override – For use with D600 AP panels only. If selected, an authorized cardholder may temporarily override access control at a keypad reader by performing a badging procedure. The override establishes an extended access time period from 0 to 1440 minutes (24 hours). During this period, the door is unlocked and the green indicator light on the reader remains lit. Cardholders can activate this feature as follows:

- 1. Enter the **PIN code** on the keypad (if PIN codes are part of your system configuration).
- Press the <*> key and enter the number of minutes desired for the override period.
- 3. Press the <#> key.
- 4. Badge into the keypad reader, so that the override privilege can be checked against the badge record.
- 5. To terminate the timed override period (before the number of minutes selected have run out), repeat steps 1 through 4, entering 0 minutes in step 2.

Security Level – For use with D600 AP panels only. Enter the security level number from 0 (lowest) to 99 that is assigned to terminals connected to this panel. If there is a security breach, a system administrator can rapidly change access privileges for all cardholders at any door. For this feature to work, you also need to assign security levels to badges (page 271). To obtain access at a door, the badge security level must be equal to or higher than the security level entered here. If an event occurs, the system administrator can raise the security level of the terminals in question, and access is immediately restricted. To restrict access at all terminals at once, simply raise the security level of the panel. See Security Threat Level Control on page 307.

No. of PIN Retries – For use with D600 AP panels only. Select the number of consecutive incorrect PIN code entries that are allowed at a keypad reader before an alarm is generated.

Log Reader Strike Message – For use with S320 and S321-DIN panels only. If selected, the transaction displays in the Real Time List and on the System Status window.

Log Output Status Message – For use with S320 and S321-DIN panels only. Select to send output relay messages from the panel to the Server (whether or not access is granted). Must be selected to show as active on the System Status window.

Mag Format Tab

For D600 AP panels only. Since the encoding format may vary among card manufacturers, the system provides up to ten fields to define the magnetic stripe card format used at your facility (depending on the format, all fields may not be used). A magnetic stripe card contains card number, facility code, and issue level information required by the system. Each field format in a magnetic stripe formula is represented by the format type and the number of characters used in each format type. Select from the drop-down lists the format type and corresponding number of characters to be used for each type.

10	Edit Par	nel		
G	ieneral	Loop / Unit Access Alarm History Misc Mag Format		
	Mag S	tripe Format		
	1	Card Number	5	•
	2	Ignore Characters	3	•
	3	Facility Code	4	•
	4	Ignore up to Next Field Separator	0	7
	5	Issue Level	2	•
	6	End Character	0	Ŧ
	7	•		Ŧ
	8	·		V
	9	· · · · · · · · · · · · · · · · · · ·		7
	10	· · · · · · · · · · · · · · · · · · ·		7

Ignore Characters – Select from the associated drop-down list, the number of characters that are ignored.

Card Number – Select from the associated drop-down list, the number of characters in the card number.

Facility Code – Select from the associated drop-down list, the number of characters in the facility code.

Issue Level – Select from the associated drop-down list, the number of characters in the issue level.

Ignore up to Next Field Separator – This field is always 0. The system ignores any number of characters until it finds a field separator, a comma for example.

End Character – This is the last field in the format. This field is always 0.

Using the values entered in the Mag Format tab:

5 3 4 0 2 0

a card that uses these magnetic stripe values displays:



Configure Panel Components

When a new panel is created, the new Panel icon is listed under the root Panels icon in the System Configuration window, and placeholders for all panel components are added under the new panel.



Some components must be configured before they can be applied to other components; however, the System Configuration window does not list them in a logical configuration sequence. For example, you must configure Panel Time Zones before you can complete Terminal configuration, but you must configure Terminals before you can create Soft Alarms, Input and Output Points and Groups, and Panel Card Events. For this reason, it is important to configure Panel Time Zones and Panel Holidays (if used), and then configure Terminals before continuing with other panel components. We recommend the following configuration sequence:

- Configure Panel Time Zones
- Configure Panel Holidays
- Define Enable Codes
- Configure Air Crew PIN Numbers
- Configure Panel Card Formats
- Configure Additional Panel Components

Complete instructions are presented in the following sections.

Configure Panel Time Zones

Time Zones (created during System Configuration) can be applied to a specific panel and its associated components. See Appendix C: Panel Comparison Matrix for the number of panel time zones supported for each panel type. You must apply at least one time zone to each panel in your system. If time zones are applicable to other panel components such as readers, inputs, or outputs, these time zones must also be defined.

Note: Each Assa Abloy lock can only store a maximum of 32 different time periods. Make sure the panel time zones assigned to an Assa Abloy panel do not exceed this number; otherwise the panel is out of sync.

Note: Any changes to the panel time zones for Mercury panels requires downloading Access Groups and Card Events to the affected panel.

You can automatically operate outputs such as lights, air conditioning, and so on, by associating Output Groups with Panel Time Zones (not available for OSI, S321-IP, Isonas, HID, Assa Abloy, or Mercury panels).

Panel Time Zones must be defined before you can complete Terminal configuration. If you have not yet configured Terminals and Output Groups, you should enter Panel Time Zones now, and return to add the Output Groups and any additional time zones.

To Assign a Panel Time Zone:

- 1. In the System Configuration window, expand the Panel to which you wish to assign the Time Zone. The panel components are listed below the panel icon.
- 2. Select **Panel Timezones** and click **Edit**. The Panel Timezone Edit dialog box opens.

C Panel	Timezone Edit			×
Timezon	es 1-16 Timezones 17-32	Timezones 33-4	B Timezones 49-64	
	Time Zone		Output G	roup
1	Whse Hours	•	<none></none>	•
2	Limited Access	•	<none></none>	•
3	Always active	-	<none></none>	•
4	<none></none>	•	<none></none>	•
5	<none></none>	•	<none></none>	•
6	<none></none>	•	<none></none>	•
7	<none></none>	•	<none></none>	•
8	<none></none>	•	<none></none>	•
9	<none></none>	•	<none></none>	•
10	<none></none>	•	<none></none>	•
11	<none></none>	•	<none></none>	•
12	<none></none>	•	<none></none>	¥
13	<none></none>	•	<none></none>	•
14	<none></none>	•	<none></none>	•
15	<none></none>	•	<none></none>	•
16	<none></none>	•	<none></none>	•
			OK Cance	el <u>A</u> pply

- 3. Use the drop-down lists to select any time zones configured in the system.
- 4. If your panel type allows it and you need to assign more than 16 time zones, click the Timezones 17–32 tab and continue to add time zones as in step 3. Select additional tabs and enter additional time zones as needed, up to a total of 64.
- After all time zones (and Output Groups, if applicable) are assigned, click **OK** to save your entries and return to the System Configuration window.

To Assign an Output Group to a Panel Time Zone:

- 1. In the Panel Timezone Edit dialog box, select the **Time Zone** to which you wish to associate an Output Group.
- 2. Select the associated **Output Group**. Output Groups must be created before they can be accessible from the Panel Time Zone drop-down lists. (See Create Input and Output Points and Groups on page 88.)

Configure Panel Holidays

Panel Holidays are not required for system operation; however, they may be useful in certain applications. For example, you may want to allow facility access during a Holiday period, but limit the number of entry doors. You can assign a specific Holiday Time Zone to restrict access at a specific panel.

See Appendix C: Panel Comparison Matrix for the number of panel holidays supported for each panel type.

To Assign a Panel Holiday:

- 1. In the System Configuration window, expand the Panel to which you wish to assign a Panel Holiday.
- 2. Select **Panel Holidays** and click **Edit**. The Panel Holiday Edit dialog box opens.

: Pan	el Holiday Edit				_ 🗆 ×
1	Thanksgiving	•	21	<none></none>	
2	Christmas	-	22	<none></none>	•
3	Holiday C	•	23	<none></none>	•
4	<none></none>	-	24	<none></none>	•
5	<none></none>	•	25	<none></none>	-
6	<none></none>	•	26	<none></none>	•
7	<none></none>	•	27	<none></none>	•
8	<none></none>	•	28	<none></none>	•
9	<none></none>	•	29	<none></none>	•
10	<none></none>	-	30	<none></none>	•
11	<none></none>	-	31	<none></none>	▼
12	<none></none>	-	32	<none></none>	•
13	<none></none>	-	33	<none></none>	•
14	<none></none>	•	34	<none></none>	•
15	<none></none>	•	35	<none></none>	•
16	<none></none>	•	36	<none></none>	v
17	<none></none>	•	37	<none></none>	•
18	<none></none>	•	38	<none></none>	•
19	<none></none>	•	39	<none></none>	▼
20	<none></none>	•	40	<none></none>	•
		ЭК	Ca	ancel	

3. Use the drop-down lists to select the system Holidays that apply to this panel.

4. When all Holidays are defined, click **OK** to save the settings and return to the System Configuration window.

Enable Codes (EC) Definition

The following D600 AP panel options are protected features and can only be used by entering an appropriate Enable Code:

- **PIN Plus 1 Duress**, set up at the panel Misc tab (see page 64).
- Air Crew PIN Code, set up at the terminal Air Crew Pin tab (page 83). You must first configure the numbers (see next section Configure Air Crew PIN Numbers).
- Extended Shunt Time, set up at the terminal Access tab (page 78).
- **Timed Override**, set up at the terminal Access tab (page 78).

Enable Codes are provided by Johnson Controls and then entered into the system using the Enable Code dialog box. These codes are programmed from the customer's facility codes to allow each customer to have unique Enable Codes. To obtain Enable Codes, you should contact our Technical Support team and provide your facility code together with a list of the panel options you wish to enable.

IMPORTANT: If you change any of the four facility codes set up at the D600 AP panel, the Enable Codes provided by Johnson Controls are automatically turned off. You may have to obtain new codes and re-enter them into the system.

To Define Enable Codes:

1. In the System Configuration window, expand the D600 AP panel where you wish to set up the Enable Codes. 2. Select **Enable Code** and click **Edit**. The Enable Code dialog box opens. The Panel field displays the name of the D600 AP panel selected.

C Enable Code	
Panel:	Local AP Panel
Timed Override	0
Extended Shunt Time	0
Air Crew PIN Code	0
PIN Plus 1 Duress	0
ОК	Cancel

- 3. Select any of the options you wish to enable and enter the corresponding code provided by Johnson Controls.
- 4. Click **OK** to save the codes and return to the System Configuration window. Once the desired options have been turned on, you are ready to configure the enabled features.

Configure Air Crew PIN Numbers

The P2000 system allows you to define air crew personal identification numbers (PIN) to be used at PIN readers connected to D600 AP panels and CK7xx panels Version 2.3 and later. Once the Air Crew PIN numbers are defined, a system administrator can enable or disable the Air Crew PIN feature from the Edit Terminal dialog box; see page 83 for details. When this feature is enabled, entering the assigned Air Crew PIN number allows access at the door. You can create an Air Crew PIN number to be assigned to a group of people, or create a PIN number to be assigned individually to an Air Crew member with different access needs. Presenting a badge is not required when using the Air Crew PIN Number feature

As an alternative, you can also see the instructions in Appendix G: Using a Keypad Reader on CK7xx Panels.

To Define Air Crew PIN Numbers:

- 1. In the System Configuration window, expand **Panels**.
- Select Air Crew PIN Code and click Edit. The Edit Air Crew PIN Number dialog box opens.

Name	Code	
United Travel	3124	
ABC Airlines	2946	
Add	Delete	

- 3. Double-click to enter the **Name** and corresponding **Code** to define each Air Crew PIN Number. The Code number can have up to 16 digits.
- 4. When you finish defining all Air Crew PIN numbers, click **OK** to return to the System Configuration window. These names display in the Air Crew Pin tab of the Edit Terminal dialog box.

Configure Panel Card Formats

P2000 supports up to eight custom card formats that can be downloaded to S321-DIN, S321-IP, and CK7xx panels of Version 2.2 or later. Upon selection, custom card files are stored in a separate database table. Once the selected card formats have been compiled, they are available for selection using the Card Type tab in the Terminal dialog box. **Note:** Contact Johnson Controls for instructions in generating Custom Card Format files.

To Add Custom Card Formats:

- 1. In the System Configuration window, expand **Panels**.
- 2. Select **Panel Card Formats** and click **Edit**. The Panel Card Formats dialog box opens.

No.	Name	Description	
1			
2			
3			
4			
5			
6			
7			
8			

- 3. To add a custom card format, click the line item you wish to define and click **Add**.
- 4. Navigate to the directory where your card format files are stored and double-click the <name>.txt file you wish to use. Click Yes if you wish to enable the format for all CK7xx and S321-DIN terminals and also want to add it to S321-IP terminals with no custom card assignment. The name and description of the selected card format file displays in the line item selected. You can add up to eight custom card format files.
- 5. If you wish to update or replace an existing file, select the file name from the list and click **Update**. A verification message displays, click **Yes** then proceed to select the replacement file.
- 6. To delete a file format, select the file name from the list and click **Delete**. You are prompted for verification.

- 7. To view the contents of a file format, select the file from the list and click **View**. A text file displays the format code string of the selected format. When you finish viewing the file, close the window.
- Click Done to close the Panel Card Formats dialog box. The new card formats are available from the Card Type tab in the Terminal dialog box.

Configure Additional Panel Components

Soft Alarms, Input and Output Points and Groups, and Panel Card Events all use Terminal information in their configuration; therefore, you must create and configure terminals before you can configure these components. See Create and Configure Terminals for more information.

Create and Configure Terminals

Terminals are add-in boards such as reader boards and input and output boards. These are installed into the panels to communicate with devices such as card readers; input groups such as alarm monitoring devices; and output devices that control other devices such as lights, air conditioning, alarm annunciators, and so forth.

Each terminal installed in your system must be set up and configured in the P2000 software to establish communication and control. Once terminals are configured, they may be included in Terminal Groups and associated with Input Points and Groups to report alarms and trigger events. We recommend the following setup and configuration sequence:

- Set up Terminals for each Panel
- Create Terminal Groups
- Create Input and Output Points and Groups

The following sections present instructions to configure terminals installed on CK7xx, S321-DIN, and Legacy panels. If you have not already developed naming conventions for these program elements, we recommend you do so before beginning this procedure. See Panel Naming Conventions on page 53 for more information.

Set up Terminals for each Panel

Terminals can control card readers, input points, output points, or a combination of the three, depending on the type of board installed in the panel. You must set up terminals for each panel configured in the P2000 software. As with all configuration operations, the Edit Terminal dialog box is accessed from the System Configuration window.

Note: Not all terminal options are available to all panel types. Certain features are enabled or disabled depending on the panel type and version where the terminals are installed.

To Create a New Terminal:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand the panel type configured for your system, for example **CK7xx Panels**. The panel names created under this type display.
- 3. Expand the panel in which the terminal is installed. All the items that can be configured for the panel are listed under it.
- 4. Select Terminals and click Add. The Edit Terminal dialog box opens at the General tab. Enter the information in each tab according to your system requirements and naming conventions. (See Edit Terminal Field Definitions for detailed information.) As you work through the tabs, click Apply to save your settings.

🖸 Edit Termir

Type **E**nable

🔽 Input

🗹 Qutput

Reader

General Flags Access Timezone Facility Codes Card Type Calibrate Air Crew Pin

•

▼ 5

•

•

5. When all entries are complete, click **OK** to

is listed under the Terminal icon. In the

Whse Entry Reader, Whse Exit Reader, and Whse I/O8 were created for the Ware-

following example, Terminals named

🗄 🚮 Whse Entry Reader

🗄 🚮 Whse Exit Reader

6. Continue to create terminals for every

Note: You must perform the Write DB to Flash function (see page 482) when adding or deleting

RDR2S-A or RDR8S terminals, or when modify-

ing general parameters of existing RDR2S-A or

RDR8S terminals (except Name, Public, or Query

panel in which they are installed.

🗄 🚮 Whse I/08

save your settings and return to the System

Configuration window. Your new terminal

✓ Public

Address

1

Inde

•

•

• 8

• 2

Name Whse Entry Reader

Panel Warehouse

Туре

RDR85

RDR25A

Ouery String

house panel.

String fields).

T۲ © 🖻 🔩 Terminals

Number 1

The Edit Terminal dialog box opens at the General tab. You must enter information in all Edit Terminal tabs to complete configuration. Tabs are dependent on the type of panel. For example, when configuring terminals for CK7xx panels, the Facility Codes tab is available. When configuring terminals for legacy panels, the Legacy tab is available.

General Tab

Name – Enter the name of the new terminal. Use descriptive names according to your Naming Conventions Plan.

Panel – This field displays the name of the panel you selected from the System Configuration window.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Number – Enter a terminal address number. This terminal address number corresponds to the physical address as installed at the panel. (Refer to your specific hardware configuration documentation if you need more information on terminal address assignment.)

Public – If this is a partitioned system, select **Public** if you wish this terminal to be visible to all partitions.

Enable – Click **Enable** for the system to recognize the new terminal, then select the terminal types you have installed in this panel:

 Input – Indicates an alarm monitor terminal or another terminal that provides input points.

- **Output** Indicates an output control terminal or another terminal that provides output points.
- Reader Indicates a card reader terminal. If selected as the terminal type, additional tabs are added. Choose one of the following reader types from the drop-down list:
 - Access Normal access reader.
 - Entry Entry defined access reader.
 - **Exit** Exit defined access reader.

Note: For Entry and Exit to work, all Entry and all Exit terminals must run in Central mode or they must all be defined on the same panel and run in Local mode.

In addition, when configuring terminals connected to CK721-A panels Version 3.0 and later, you must select the module type installed at the panel, including the address and index of each module.

Type – Select from the drop-down list whether this is a Legacy, RDR2S-A or RDR8S module.

Note: A legacy module is any RDR2, SI08, SI8, IO8, or I16 device installed at the panel.

Address – Select the address (0 to 31) of the RDR2S-A or RDR8S module. Not available for legacy modules.

Index – Select the index number of the RDR2S-A (1 to 2) or of the RDR8S (1 to 8) module. Not available for legacy modules.

Flags Tab

The only available options when configuring TIU terminals are Reader Override Timezone Enable and Soft-In-X-It.



Reader Box

Alarm Shunt Only for Auxiliary Access – If enabled, the Aux-Access Input Point on the terminal suppresses only the Door Open Alarm. If disabled, the Aux-Access Input Point on the terminal performs an access grant.

Facility Code Only when Offline – If enabled, the terminal accepts any badge with the correct facility code when the terminal is offline from the panel. Not available for S321-DIN panels and does not apply to custom card formats. See Facility Codes Tab on page 81 for more details.

PIN Required when Offline – If enabled, an algorithmic PIN number is required for badge acceptance if the terminal goes offline. Not available for S321-DIN panels.

Allow PIN after Badge – If enabled, the cardholder can enter the PIN number after presenting the badge instead of before presenting the badge. Press the <#> key after entering the PIN number (see Configure PIN Codes on page 86). If disabled, the conditions under Trigger Type in the Options box of the Panel Card Event apply; see page 100.

Reverse Reading – Not available for legacy panels. If enabled, when you turn a badge facing away from you and swipe in the normal direction, the badge still reads. This does not apply to mag stripe, proximity, or barcode cards.

Log Reader Strike Message – Not available for legacy or S321-DIN panels. If enabled, the transaction displays in the Real Time List and on the System Status window. This option must be disabled if the reader is to be assigned to an elevator or cabinet.

Access Grant Message on Door Open Only – For this feature to work, the terminal must be configured to run in Local mode. If enabled, access grant messages are generated when the cardholder swipes the badge and opens the door. This option is only available for S321-DIN and CK7xx panels Version 2.0 and later.

When enabled on CK721-A panels Version 3.0 and later, the Keyless Override timer starts after swiping a badge (with override privileges) and immediately opening the door. When disabled, the Keyless Override timer starts after swiping a badge (with override privileges). Also, in the case of elevator readers when this flag is enabled, elevator access grant messages are generated only when the cardholder presents a badge at an elevator reader and a valid floor is selected.

Re-lock on Door Open – This option is only available for S321-DIN and CK7xx panels Version 2.2 and later with modules RDR2 (PS201-E or later), RDR2S, RDR2S-A or RDR8S. Normally the Anti-Tailgate and Timed Override/Anti Tailgate options cancel both access time and shunt time when the door closes. Enabling the Re-lock on Door Open option modifies the anti-tailgate feature to lock the strike when the door opens, for example to avoid excessive wear of the electrical equipment. The shunt time is still cancelled when the door closes. **Note:** The Re-Lock on Door Open mode is only available with modules RDR2 (PS201-E or later), RDR2S, RDR2S-A or RDR8S. If not, the Re-Lock on Door Open mode works identically to the existing Anti-Tailgate mode. For specific instructions, refer to the CK7xx Release 2.2 and later documentation.

No Green Light on Aux Access – Available for CK7xx panels Version 2.5 and later. If enabled, no green light displays on auxiliary access. Requires the RDR2S (firmware Revision Q or later), the RDR2S-A or RDR8S module.

Deny If Door Open – Available for CK7xx panels Version 2.5 and later. If enabled, an access denied message is generated when the cardholder swipes the badge at an opened door.

Anti Tailgate – If enabled, the access timer resets and the door immediately locks when the door closes. This prevents reopening the door using one badge access.

Momentary Auxiliary Access – If enabled, the Access Time begins timing when a switch shorts the terminal's Aux-Access input point contact. If disabled, the terminal's Aux-Access input point contact energizes the door relay as long as the contact is shorted.

Reader Override Timezone Enable – If enabled, the reader does not require a badge to open the door during the reader override time zone. (A time zone must be selected in the Override field of the Timezone tab to enable this function.)

Soft In-X-It – If enabled, cardholders have access even though the In-X-It status is incorrect. (A soft alarm can be triggered if configured through the Soft Alarms dialog box; see page 101.)

Valid & Unauthorized – Not available for legacy panels. If enabled, a green light indicates that badging has taken place; however, the system does not grant access to the cardholder. A security guard must manually unlock the door with a key or push a button to open the door and allow access.

Reverse Swipe Duress – Not available for legacy panels. If enabled, you can turn the badge away from you and swipe in the normal direction to report a duress alarm. (Soft alarm must be configured for this reader; see Soft Alarms Field Definitions on page 101.) This does not apply to mag stripe, proximity, or barcode cards. When you enable Reverse Swipe Duress, the Reverse Reading option is automatically enabled.

PIN Plus 1 Duress – This option is only available for S321-DIN and CK7xx panels Version 2.2 and later. If enabled, a duress alarm is generated when a cardholder adds 1 to the last digit of the PIN code (for example, 6 becomes 7, not 61). When this option is enabled, the 9 does not create a duress alarm. If the last digit of the PIN code is a 9, then the user substitutes a 0 for the 9 and this triggers the duress alarm. This feature only works if the Duress soft alarm is enabled.

Star Feature – This option is only available for S321-DIN and CK7xx panels Version 2.2 and later. If enabled, the cardholder can press the star (*) key at the keypad plus a feature number, to activate some of the panel's functions that are normally invoked from keypads that contain the A, B, C, or D keys. The (#) key acts as the *Enter* key, it wraps-up the previously entered keys and starts the processing of the key sequence. It also clears the keypad buffer for the next command to be entered. The (*) key starts the feature selection process. Once pressed, the cardholder can activate one of the following features:

- 0 = Local Override, followed by number of minutes
- 1 = Enable event, followed by event number
- 2 = Air Crew PIN
- 4 = Disable event, followed by event number
- * = Clear the keypad buffer. This works independently of the Star Feature setting

The cardholder must enter all PIN and Card ID information before selecting a feature. As an alternative, instead of pressing the (#) key, the cardholder can swipe the badge to wrap-up the previously entered keys and start the processing of the key sequence, unless the **Allow PIN after badge** option is selected.

For details, see Appendix G: Using a Keypad Reader on CK7xx Panels.

BQT Reader with LCD – Available for CK7xx panels Version 2.5 and later. CK721-A Version 3.0 does not support this feature. If selected, the system enables the LCD display of the following messages (arranged from highest to lowest initial priority):

- Reader Offline A reader offline message displays on the LCD when a terminal cannot communicate with a panel for more than 5 seconds. As soon as a poll message is received, this message does no longer display.
- Access Granted An access granted message displays on the LCD when a reader is not offline. When the granted access timer expires, this message does no longer display. The LCD displays the access granted message when it is in override, it has received an assisted activate message, or it has received a normal access grant.

- Access Denied An access denied message displays on the LCD when a reader is not offline and does not have an active access granted message. When the denied access timer expires, this message does no longer display. The denied access time is either 1.5 seconds, or the defined assisted access time (see page 79). The LCD displays the access denied message when it has received an invalid assisted activate message, or it has received an invalid access grant.
- Enter PIN Code An enter PIN code message displays on the LCD when a reader is not offline, it does not have an active access granted message, and it does not have an active access denied message. The LCD displays the enter PIN code message when a PIN code is required after a regular badge swipe; the PIN Only flag is set and the user pressed a key at the reader; the Card ID flag is set and the user pressed a key at the reader; or the PIN + Card ID flag is set at the terminal and the user pressed a key at the reader.
- Enter Shunt Time An enter shunt time message displays on the LCD when a reader is not offline, it does not have an active access granted message, it does not have an active access denied message, or it does not have an active PIN code message. The LCD displays the enter shunt time message after a regular badge with override privilege has been swiped. The shunt timer range is from 0 to 9999 minutes.
- Shunt Time Warning A shunt time warning message displays on the LCD when a reader is not offline, it does not have an active access granted message, it does not have an active access denied message, it does not have an active PIN code message, or it does not have an active shunt time message. The LCD displays the shunt time warning when the shunt timer value reaches the value defined for the shunt warning time.

Present Card – A present card message displays on the LCD by default. Since it has the lowest priority (unless changed by the customer), this message does not display as long as any of the other messages are active.

Input/Output Box

Alarm Debounce Time – (Inputs only) Not available for legacy panels. Enter a delay time in milliseconds that the system waits to sample this terminal's Supervised Input Point Circuits. The default is 20 msec. This improves system performance by ignoring a circuit disturbance, such as a door jiggle as it closes, rather than reporting an alarm.

Log Output Status Message – (Outputs only) Not available for legacy or S321-DIN panels. Click to send output relay messages from the panel to the P2000 Server (whether or not access is granted). Must be selected to show as active on the System Status window. This option must be disabled if the output point is to be assigned to an elevator or cabinet.

To Create an Input/Output Terminal:

- 1. From the System Configuration window, select the panel to which the Input/Output terminal is added.
- Select the terminal to which you wish to add input points and click Add. The Edit Terminal dialog box opens.

C Edit Terminal				
General Flags				
Name	Whse IO8			
Panel	Warehouse			
Query String				
Number	2 💌	🗖 Public		
Type <u>Enable</u>				
✓ Input	Туре	Address	Index	
V Qutput	Legacy 💌	0 🔻	Ţ	
E Reader	Legacy 💌	0 🔻	<u> </u>	
	Access			

- 3. Enter a descriptive name for the terminal. In the example, we created Whse I/O8 and under Type, selected both **Input** and **Output** to indicate an I/O-8 board.
- 4. Enter the physical address for this terminal.
- 5. Click the Flags tab.

Alarm Shunt Only for Auxiliary Access	Anti Tailgate
Facility Code Only when Offline	Momentary Auxiliary Access
PIN Required when Offline	🗖 Reader Override Timezone Enable
Allow PIN after Badge	🗖 Soft In-X-It
Reverse Reading	Valid & Unauthorized
🖉 Log Reader Strike Message	🗖 Reverse Swipe Duress
Access Grant Message on Door Open Only	PIN Plus 1 Duress
Re-lock on Door Open	🗖 Star Feature
No Green Light on Aux Access	BQT Reader with LCD
Deny If Door Open	
Input/Output	
Alarm Debounce Time: 20	10 ms
🔽 Log Output Status Message	

- 6. Enter an Alarm Debounce time.
- 7. Select **Log Output Status Message** if you want the status of the outputs to display in the Real Time List and the System Status window.

Override Reset Threat Level Box

Each reader terminal defined for a CK7xx (Version 2.4 or later) or S321-DIN panel can be configured with an Override Reset Threat Level ranging between 0 and 99. A value of 0 disables the *Override Reset* feature; a value between 1 and 99 invokes the following behavior:

Whenever a terminal's Security Level reaches or exceeds the terminal's Override Reset Threat Level, all time zone based overrides, host initiated overrides and cardholder overrides are immediately disabled. Subsequent attempts to invoke host initiated overrides or cardholder overrides are denied. Once a terminal's Security Level drops below the terminal's Override Reset Threat Level, the time zone based override is restored immediately. Host initiated overrides and cardholder overrides are not automatically restored, but subsequent attempts to invoke host initiated overrides or cardholder overrides are granted, provided the configuration allows these overrides.

The System Override feature is not affected by the Override Reset Threat Level, and remains in effect as long as the panel's System Override flag is set.

Legacy Tab

The Legacy tab gives you access to STI-E and AMT options associated exclusively with legacy panels.

📽 Edit Terminal	
General Flags Legacy Access Timezone Car	rd Type Air Crew Pin
STI-E	☐ 1/0 Linking Point 2 ☐ 1/0 Linking Point <u>4</u> ☐ giffine Card Search IØ Host Fails Deny
AMT Annunciation Mode Enabled Eelay Enabled Eyey Switch Enabled	

STI-E Box

I/O Linking Points 1 through 4 – If enabled, the specific alarm point to activate the associated output point is enabled.

I/O Latching – If enabled, the output relay is activated whenever its associated input goes into the alarm state and remains latched (activated) until reset by a card-activated event or by a reset output command from the Server. If disabled, output point N tracks input point N if I/O linking point N is enabled, where N=1 through 4. The output relay is activated only as long as its associated input is in the alarm state.

Offline Card Search – If enabled, the STI-E searches its own database when a badge is presented in the offline mode.

Note: If you enable the Offline Card Search function, you must also ensure that Download to STI-E has been enabled in the Badge dialog box.

Host Fails Deny – This options allows you to program the terminal to deny or accept access if the system is in Central mode and goes offline. If enabled, the terminal denies all access attempts. If this option is disabled, the terminal accepts all access requests and the panel makes an access decision in Local mode by checking the badge data against the data stored in the system database.

AMT Box

Annunciation Mode Enabled – If enabled, the annunciation mode is activated when an input point goes into an alarm state; to sound a siren, for example.

Relay Enabled – If enabled, a local relay on AMT activates when any input point on this AMT goes into alarm state.

Key Switch Enabled – If enabled, the annunciation device can be deactivated by using a keyswitch.

Access Tab

The Access tab defines the terminal's operating mode, and the access parameters and overrides allowed at the terminal. The only available options when configuring TIU terminals are Process mode and Anti-Passback option.

A				
ALLESS	Process	Central 💌		Access Time 5 sec.
🔽 Anti-	Passback	1 min.		Shunt Time 10 sec.
Door Open W	arning			
	Warning Output Group	Audible Alarm	•	Warning Time 5 sec
		Shunt Warning Auto Off		
Timed Overric	le / Timed Shunt			
C Time	d Override			Cardholder Override / Shunt M
Time	d Shunt			Keyless Override / Shunt Time 2 min.
	Warning Output Group	Audible Alarm	•	Warning Time 1 min.
		Warning Auto Off		
Assisted Acce	55			
	Assisted Access	Handicap Access 💌		ADA Relay Connector Green
	Assisted Access Time	15 sec.		ADA Relay Time 25 sec.
				ADA Relay Delay 15 100 m

Access Box

Process – Select one of three operating modes:

- Local Access decisions for this terminal are made at the panel level. Must be selected for readers assigned to elevators or cabinets.
- **Central** Access decisions for this terminal are made at the Server.
- Shared Access decisions are first requested at the panel; if the badge record is not stored at the panel, the access request is passed on to the Server.

For more information on system performance and operating process modes, see Communication Modes on page 7.

Anti-Passback – Click if this reader is an anti-passback reader. Enter a time in minutes that a badge used at the reader is invalid before it can be used at the same or any other anti-passback reader.

Access Time – Enter a time in seconds that the door strike is energized after each valid badge access request. The maximum value is 25 seconds.

Shunt Time – Enter a time in seconds (minutes if defining TIU panels) that the door open alarm is suppressed after a valid badge access request. The shunt time should be longer than the access time. The maximum value is 255 seconds (255 minutes for TIU panels).

Note: After an access grant, the shunt time is cancelled once the door status changes to locked and closed, even if the shunt time has not yet expired.

Timed Shunt – Available for S321-DIN and CK7xx panels Version 2.2 and later with modules RDR2 (PS201-E or later), RDR2S, RDR2S-A or RDR8S. If you select this option, only the shunt time is extended by the number of minutes entered at a keypad reader. The access time remains at the configured value. Use the Timed Shunt mode if you want the door to be held open for an extended period of time, but do not want the door to be unlocked for that time.

Door Open Warning Box

This option is available for S321-DIN and CK7xx panels Version 2.0 and later.

Warning Output Group – Select the output group that is to be activated when the Warning Time is reached.

Warning Time – Enter the time in seconds (0 to 255) before the Shunt Time expires for the Warning Output Group to be activated if the door remains open.

Shunt Warning Auto Off – Not available for S321-DIN panels. If enabled, the Warning Output Group is reset when the door is closed, access is granted, or the door is overridden. Therefore, the Door Open Warning is deactivated when there is no Propped Door alarm in the immediate future.

Timed Override/Timed Shunt Box

With S321-DIN and CK7xx panels Version 2.2 and later, the Local Override feature of previous releases can be configured to work in two different modes:

Timed Override – If selected, the access time and the shunt time are extended by the number of minutes entered at a keypad reader. Use the Timed Override mode if you want the door to be unlocked for an extended period of time. **Note:** The Timed Shunt mode is only available with modules RDR2 (PS201-E or later), RDR2S, RDR2S-A or RDR8S. If not, the Timed Shunt mode works identically to the existing Timed Override mode. For specific instructions, refer to the CK7xx Release 2.2 or later documentation.

Timed Overrides/Shunts only work if the following two conditions are met: the presented badge has the Override option enabled in the Badge dialog box, and the Cardholder Override/Shunt option is enabled in this tab.

The Timed Override/Anti-Tailgate option in the Edit Panel dialog box applies equally to Timed Overrides and Timed Shunts.

Cardholder Override/Shunt – If enabled, an authorized cardholder may temporarily override the shunt time and access time by performing a badging procedure at a keypad reader. The timed override/shunt establishes an extended shunt time and access time period from 0 to 1440 minutes (24 hours). The cardholder must have the Override option enabled in the Badge dialog box. Follow these instructions to perform a timed override/shunt access at a keypad:

1. Enter your **PIN code** on the keypad (if PIN codes are part of your system configuration).

- Press the <*> key (or <*> 0 if the Star Feature is selected in the Flags tab).
- 3. Enter the number of minutes desired for the override/shunt period.
- 4. Press the $\langle \# \rangle$ key.
- 5. Badge into the keypad reader, so that the override/shunt privilege can be checked against the badge record.
- 6. If you wish to terminate the timed override/shunt period (before the number of minutes selected have run out), repeat steps 1 through 5, entering 0 minutes in step 3.

For details, see Appendix G: Using a Keypad Reader on CK7xx Panels.

Keyless Override/Shunt Time – Available for S321-DIN and CK7xx panels Version 2.2 and later. Instead of having to enter the number of minutes for the timed override/shunt at a keypad reader, you can have the system do it for you. Entering a time from 1 to 1440 minutes into this field treats a qualifying badging procedure as if the number of minutes had been entered at the keypad. You can still choose to enter a different number of minutes at the keypad reader, which takes priority over the configured override/shunt time. Entering a 0 into the Kevless Override/Shunt Time field turns this feature off. The rules as to who can invoke a keyless timed override/shunt are identical to those governing the keypad invoked override. When the Access Grant Message on Door Open Only flag is selected (see page 73), the keyless override timer starts after the cardholder swipes the badge with override privileges and then opens the door.

Warning Output Group – Select the output group to be activated when the timed override/shunt expiration for this terminal falls within the time set in the Warning Time field. **Warning Time** – Enter the time (0 to 10 minutes) to activate the Warning Output Group to warn operators that the override/shunt is about to expire. For example, if you have created a temporary door override/shunt for 8 hours, you can create an audible output group that activates 10 minutes before the override/shunt expires to let operators know the door shortly begins operating in normal mode.

Warning Auto Off – Not available for S321-DIN panels. If enabled, the Warning Output Group is reset when the door closes or when override is extended past the point when the warning should be triggered. Just an access grant alone does not deactivate the Override Warning. This feature is most useful in connection with the Timed Override/Anti-Tailgate option enabled. If Timed Override/Anti-Tailgate is not enabled, it is possible that the Override Warning is deactivated before the override actually expires. If you want to avoid this scenario, disable this option.

Assisted Access Box

Note: The Assisted Access feature is only available with modules RDR2 (PS201-E or later), RDR2S, RDR2S-A or RDR8S. If not, the Assisted Access works identically to the regular Access mode. In addition, this feature only works on terminals that operate in Local mode.

Enter the information in this box if you are configuring S321-DIN or CK7xx panels Version 2.2 and later with modules RDR2 (PS201-E or later), RDR2S, RDR2S-A, or RDR8S. This option allows you to set up a door's access time to be different, to satisfy the requirements for assisted access according to ADA (Americans with Disabilities Act). The system provides three Special Access flags, A, B, and C, which can be renamed in the Site Parameters dialog box according to your facility needs, and then assigned to a cardholder that requires special access at a door. Additionally, you may activate an ADA relay in conjunction with granting assisted access.

Assisted Access – Select one of the following options:

- Never Assisted Access is not available at the door, even if the cardholder's badge has the Special Access A flag enabled.
- Always The door is always opened for the Assisted Access Time, regardless if the cardholder's badge has the Special Access A flag enabled.
- Special Access A The door is opened for the Assisted Access Time, only if the cardholder's badge has the Special Access A flag enabled. If the Special Access A flag has been renamed using the Site Parameters dialog box, that name displays here.

Assisted Access Time – Enter the time in seconds (1 to 120) that the door remains unlocked to provide access time to cardholders with special needs. The assisted shunt time exceeds the assisted access time by the same amount that the regular shunt time exceeds the regular access time.

ADA Relay Connector – In case an output on an S300 I/O terminal is not available to drive an ADA relay, you may use either one of the two outputs that are available on the RDR2, RDR2S, RDR2S-A, or RDR8S module. Select the module's connector that is activated for the ADA Relay time when assisted access is granted. Choices are:

- **Green** if the ADA relay is connected to the supported module connector that normally drives the green light
- Shunt if the ADA relay is connected to the supported module connector that normally indicates the shunt condition
- None if the ADA relay is not connected to any supported module connector.

Note that when connecting the ADA relay to either one of these outputs, its regular function, such as activating the green light or indicating the shunt condition, is no longer available. Also, refer to the S321-DIN or CK7xx documentation about wiring procedures.

ADA Relay Time – Enter the amount of time in seconds (1 to 120) that needs to elapse after an assisted access grant before the ADA Relay Connector is deactivated. The ADA Relay time therefore specifies the time the ADA relay is activated minus any ADA Relay Delay.

ADA Relay Delay – Enter the amount of time (0 to 30 units of 100 milliseconds) that needs to elapse after an assisted access grant before the ADA Relay Connector is activated. This may be necessary to avoid operating the door-opening device before the door is fully unlocked.

N-Man Rule Box

Available for CK7xx and S321-DIN panels. This option provides additional security measures for specific access-controlled readers at your facility. The N-Man Rule is based on a team of cardholders who must present their badge as a group within a defined period of time to gain access at an N-Man Rule defined reader. For this option to work, the terminals are required to operate in Central mode.

Cardholders – Enter the number of cardholders who must badge as a unit when entering an N-Man Rule controlled-reader.

Time – Enter the time in seconds during which the number of cardholders in the team are required to present their badge.

Visitor Escort Mode – If enabled, a visitor can gain access after badging at an N-Man Rule defined reader, as long as the visitor's sponsor presents the badge after the visitor. If this option is selected, the default number in the Cardholders field is 2.

Timezone Tab

The Timezone tab defines the time zones in which this terminal operates. Panel Time Zones must be set up before they display in drop-down lists.

🕼 Edit Terminal
General Flags Access Timezone Facility Codes Card Type Calibrate Air Crew Pin
Enabled Whse Hours
Qverride Time Zone 3
PIN Suppression www.englishippide.com

Enabled – Select a time zone that is in effect for this terminal.

Override – Select a time zone that can be set as an override for this terminal. This field is available if Reader Override Timezone Enable is selected in the Flags tab.

PIN Suppression – Select a time zone during which cardholders do not have to enter a PIN number.

Facility Codes Tab

Available for CK7xx panels. Enter a Facility Code and corresponding card type for each group of cards that uses this terminal. You may enter up to 12 different facility codes. Facility codes must be entered consecutively. When a facility code is 0, the following codes are ignored. See Misc Tab on page 63 to assign facility codes to legacy and S321-DIN panels.

Note: Only cards that have the first facility code selected here are granted access if the terminal loses connection to the panel, as long as the Facility Code Only when Offline option is selected, see page 72.

🖸 Edit Te	erminal						
General	Flags Access	s Timezone	Facility Code	es Caro	d Type Cali	brate Air	Crew Pin
1	468	Wiegand	–	7 0	_		•
2	468	N-Crypt	•	8 0			-
3	0		-	9 0			•
4	0		-	10 0			•
5	0		-	11 0			-
6	0		•	12 0			•

Card Type Tab

Select the type of card to use at this reader. If the reader is disabled, the Card Type should be set to No Card Allowed. The Invert Data, HID Corporate 1000, 26-bit Wiegand® Inverted, 32 bit Motorola®, and Custom type cards are not available with legacy panels. TIU Panels do not use card types. HID Corporate 1000 is only available for S321-DIN and CK7xx panels Version 2.2 and later.

HID Corporate 1000 and Custom Card Format cards work offline (using the Facility Code Only when Offline option), as long as the Binary BaFe card type is also selected. In addition, the first Facility Code entered in the Facility Code tab must be 4.

Note: HID Corporate 1000 card type do not work offline with RDR2 devices.

🕻 Edit Terminal	
General Flags Access Timezone Facility Co	odes Card Type Calibrate Air Crew Pin
No Card Allowed	🗖 BCD BaFe
Standard Wiegand	26-bit Wiegand Inverted
Encrypted Wiegand	🔲 Eyecam, Prox, Indala
🗖 Binary BaFe	PIN + Card ID
Mag Stripe	26 bit Sensor Forward
Invert Data	26 bit Sensor Reverse
FIN Only	32 bit Motorola
🗖 Card ID	Custom
HID Corporate 1000	
Custom Card Formats	
🔲 64 bit Wiegand	🗖 Not Present
🔲 64bit Wiegand Reverse	🗖 Not Present
Not Present	Not Present
Not Present	Not Present

If you use S321-DIN or CK7xx panels Version 2.2 and later, the Custom Card Formats box displays the card formats that were downloaded into the panel, using the Panel Card Formats dialog box; see page 69 for detailed instructions.

Only one type of card should be selected, with two exceptions:

- In addition to a non-PIN based card type, you may click **PIN + Card ID**. This gives people who have forgotten their badge the opportunity to get access by keying-in their badge number and their PIN. See the description of PIN Codes on page 86.
- If you use a two-wire reader with a keypad, you must wire the Data 0 and Data 1 wires so that the keypad produces the correct input to the panel. If this configuration causes the badge data to be reported inversely, you can click Invert Data to inverse just the badge data, so that the panel can correctly interpret both the keypad data and the badge data.

Calibrate Tab

Use this tab to calibrate auxiliary access input point contacts on the terminal, as well as door contact input points. Available only on inputs of the RDR2S, RDR2S-A, or RDR8S module connected to CK7xx panels, Version 2.2 and later.

C Edit Terminal General Flags Access Timezone Facility Codes Card Type Calibrate Air Crew Pin Auxiliary Access Calibrate Uncalibrate Door Alarm Calibrate Uncalibrate

To calibrate or uncalibrate the auxiliary access, you must enable the Propped Door (24) soft alarm. After the calibration command has been successfully issued, input point 24 can be deleted if it is not being used.

IMPORTANT: During the entire input calibration procedure, the input's contact must be physically closed. Otherwise, the input's status is unreliable.

If you click either of the Calibrate buttons, the Server sends a calibration command to the panel, the panel then forwards the command to the RDR2S. RDR2S-A. or RDR8S module to initiate the input's calibration. When the module completes its calibration, typically within a few seconds, the panel sends a transaction message to the Real Time List indicating the calibration result. After a successful calibration, four-state input statuses are available for the input point.

If you click either of the Uncalibrate buttons, the Server sends a command to the panel to uncalibrate the module's input. The panel then sends a transaction message to the Real Time List indicating the uncalibration result. After the uncalibration, four-state input statuses are no longer available for the input, only two-state statuses

IP: Once an input is calibrated, you do not need to use this feature again, unless you change the controller hardware or the input point's wiring.

Note: RDR2S-A and RDR8S modules with optional calibration resistors attached automatically use this reference for calibration. Inputs calibrated in this way do not need to be secured at the time of calibration.

Air Crew Pin Tab

To be used only with D600 AP panels and CK7xx panels Version 2.3 and later.



To enable the use of PIN codes at this terminal, select from the list any or all previously defined **Air Crew PIN Codes** that were set up in the Edit Air Crew PIN Number dialog box (see page 68 for details).

When this feature is enabled, entering an assigned Air Crew PIN code allows access at the door. If using D600 AP panels, the terminal must be running in Central mode. If selected, other terminal access options are still available (Card ID, PIN Only or PIN + Card ID). Follow these instructions to use the Air Crew PIN:

- 1. If you use the Star Feature, press the ***2** keys to initiate the sequence. If you do not use the Star Feature, press the **B** key.
- 2. Enter the unique Air Crew PIN code. If an error is made, press the ** keys (with Star Feature) to clear the keypad buffer and start with step 1. To clear the keypad without the Star Feature, press the C key.
- 3. Press the # key to terminate the sequence.

Use the Add Hardware Module

The Add Hardware Module command starts a wizard style interface that simplifies the process of adding a new module to a CK7xx panel. It supports module types of 116, IO8, SI8, SIO8, RDR2S, RDR2S-A, and RDR8S. The wizard asks the operator some basic configuration information specific to the module being added and automatically adds the necessary configuration items (terminals, input points, and output points) to the P2000 system.

To Add a Hardware Module:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **CK7xx Panels** and select the panel name where you want to add the new hardware module.
- Right-click the panel name and select Add Hardware Module from the shortcut menu. The Module Type dialog box opens.

C Module Type		×
	Module Type	RDR25
		<back next=""> Cancel</back>

4. Select from the **Module Type** drop-down list one of the following options:

116 – The wizard creates one input terminal with sixteen unsupervised 2-state input points.

108 – The wizard creates one input/output terminal with eight outputs and eight unsupervised 2-state input points.

RDR2 – The wizard creates two RDR2 reader terminals

RDR2S – The wizard creates two RDR2S reader terminals

RDR2SA – The wizard creates two RDR2S-A reader terminals.

RDR8S – The wizard creates eight RDR8S reader terminals. Available only for CK721-A panels Version 3.0 and later.

SI8 – The wizard creates one input terminal with eight supervised 4-state input points.

SIO8 – The wizard creates one input/output terminal with eight outputs and eight supervised 4-state input points.

5. Make your selection and click **Next**. The Terminal Number dialog box opens.

Base Number 10	
✓ Use Extended Addressing	
Module Address	
< Bark Next > Cancel	1

6. Select from the **Base Number** drop-down list the terminal address that corresponds to the physical address as installed at the panel.

- For RDR2S-A modules, you have the option of using extended addressing. Click Use Extended Addressing and select the Module Address. If you do not select this option, the terminal operates in Legacy mode.
- For RDR8S modules, you <u>must</u> select the **Module Address**.
- 7. Click **Next**. The Module Name dialog box opens.

C Module Name		×
Base Name	Warehouse	
Stule	Page Name First Underscore	
Style	Lase Name Hirst, Understore	1
Item Names	Warehouse_IO83	<u> </u>
	Warehouse_IO83_I1	
	Warehouse 1083 13	
	Warehouse IO83 I4	
	Warehouse_IO83_I5	
	Warehouse_IO83_I6	
	Warehouse_IO83_I7	
	Warehouse_IO83_I8	
	Warehouse_IO83_01	
	Warehouse_IO83_O2	
	Warehouse_1083_03	
	Warehouse_1083_04	-
	Warehouse_1083_06	
	Warehouse IO83 07	-
		-
	< Back Next > C	ancel

- 8. The **Base Name** displays the name of the selected CK7xx panel. You can however, change the name if you wish.
- 9. Select from the **Style** drop-down list one of the following name styles:
 - Base Name First, Space
 - Base Name First, Underscore
 - Base Name Last, Space
 - Base Name Last, Underscore

The Item Names box displays the items created with the name style selected.

10. Click **Next**. If you selected an input/output module, continue to step 12.

If you selected a reader type module (RDR2S, RDR2S-A, or RDR8S), the Template dialog box opens.



- 11. Select from the **Template Terminal** drop-down list, an existing reader terminal from which the access configuration parameters are copied. Click **Next**.
- 12. The Summary dialog box opens.

G Summary	×
Add terminal Lobby IO83 at addr Add input point 'Lobby IO83 II' Add input point 'Lobby IO83 I2' Add input point 'Lobby IO83 I2' Add input point 'Lobby IO83 I6' Add input point 'Lobby IO83 I6' Add input point 'Lobby IO83 I6' Add input point 'Lobby IO83 I7' Add output point 'Lobby IO83 I7' Add output point 'Lobby IO83 I7' Add output point 'Lobby IO83 03' Add output point 'Lobby IO83 03'	ess 3
Add output point 'Lobby IO83 O5' Add output point 'Lobby IO83 O6' Add output point 'Lobby IO83 O7' Add output point 'Lobby IO83 O8'	
	< Back Finish Cancel

- 13. Click **Finish**. The Create Items progress bar displays.
- 14. A message displays indicating that all items were successfully created. Click **OK** to finish. The System Configuration window displays the created items. You can edit any of the items to change configuration parameters.

Create Terminal Groups

You can group terminals that have common access throughout your facility and then apply them as a group rather than individually to the various functions. For example, you may have ten terminals (readers) with access to a warehouse area. When grouped together, you can assign cardholders that should have access to that area to the *Warehouse Doors* terminal group, rather than assigning all ten terminals to the cardholders individually.

Terminal Groups may also be used to define events. Using the warehouse example, the *Warehouse Doors* group can be associated with a cardholder and an event to trigger the lights to come on no matter which door the cardholder uses.

To Create a Terminal Group:

1. In the System Configuration window, select **Terminal Groups** and click **Add**. The Edit Terminal Group dialog box opens.



2. If you use Partitioning, select the **Partition** that has access to this Terminal Group. All available terminals (for the partition selected) are listed on the right side of the dialog box.

- 3. If you use Partitioning, click **Public** to allow all partitions to see this Terminal Group.
- 4. Enter a descriptive **Name** for this Terminal Group.
- From the Available Terminals list, click the terminal you wish to include in your group.
- Click << to include the terminal in the Terminals in Group box.
- 7. To remove a terminal from the Terminals in Group box, select the terminal and click >>.
- 8. When all terminals you wish to include in the group have been moved to the Terminals in Group box, click **OK**. A Terminal Group icon for the new group is added under the Terminal Groups icon in the System Configuration window.

In the example, *Warehouse Group* has been added as a new terminal group.



Configure PIN Codes

There are three different ways of using PINs to get access at a reader: PIN Only, PIN + Card ID, and PIN. In configurations that require presenting a badge to request access, it is possible to add the mode PIN + Card ID as an alternative for people who have forgotten their badge. See Appendix G: Using a Keypad Reader on CK7xx Panels for further instructions. Also, see Appendix C: Panel Comparison Matrix for the number of PIN codes supported by each panel type.

PIN Only

In PIN Only mode all it takes for the system to identify a person is entering a PIN at a reader. Given a fixed scramble mode, an algorithm produces a unique PIN for every badge number between 1 and 32767. When a PIN is entered at the keypad, the algorithm calculates the corresponding badge number and the access decision is made based on that badge's access rights. This feature works with 5-digit algorithmic PINs only.

For PIN Only to work, you need to configure the following parameters:

- 1. The panel's PIN Code Type must be set to **Algorithmic** (see page 61).
- 2. The panel's **PIN Code Digits** must be set to 5 (see page 61).
- 3. The panel's **Scramble Mode** must be set to the value used to create the PINs from the badge numbers (see page 61).
- 4. The terminal's **PIN Only** card type must be selected in the Card Type tab. All other card types must not be selected (see page 81).
- 5. The terminal's **Allow PIN after Badge** in the Flags tab has no effect (see page 72).
- 6. The terminal's **PIN Suppression** in the Timezone tab has no effect. For obvious reasons you cannot waive the requirement to enter a PIN in PIN Only mode.

To use PIN Only mode, simply enter your 5-digit algorithmic PIN at the keypad followed by the # key, and the access decision is made.

PIN + Card ID

In this mode the badge does not have to be presented at the reader. The numeric keypad is used to enter the PIN and the badge number. This feature works with 4 or 5-digit algorithmic and with 4 up to 9-digit custom PINs.

For PIN + Card ID to work, you need to configure the following parameters:

- The terminal's **PIN + Card ID** must be selected in the Card Type tab. All other card types should not be selected, unless you want to use the PIN + Card ID mode only as an alternative for people who have forgotten their badge (see page 81).
- 2. The terminal's **Allow PIN after Badge** in the Flags tab has no effect (see page 72).
- 3. The terminal's **PIN Suppression** in the Timezone tab has no effect, that is, you cannot use time zones to waive the requirement to enter a PIN in PIN + Card ID mode.

To use PIN + Card ID mode, you must enter your PIN followed by your 5-digit badge number, followed by the # key. You must enter leading zeros if your badge number has fewer than 5 digits.

PIN

In this mode, the PIN needs to be entered in conjunction with a valid badge presented at the reader. This feature works with 4 or 5-digit algorithmic and with 4 up to 9-digit custom PINs.

For PIN to work, you need to configure the following parameters:

- 1. Select a card type in the terminal's Card Type tab that matches the reader's technology (see page 81).
- 2. All other card types should not be selected.

- 3. The terminal's **PIN Only** card type in the Card Type tab must not be selected.
- 4. The terminal's **PIN + Card ID** card type in the Card Type tab should not be selected, unless you want to use the PIN + Card ID mode as an alternative for people who have forgotten their badge.
- 5. The terminal's **PIN Suppression** in the Timezone tab must be set to a defined time zone. PINs are only required to be entered when the time zone is inactive.

To use PIN mode when the terminal's **Allow PIN after Badge** option in the Flags tab is not set, you must key in the entire PIN before presenting the badge. The PIN does not need to be terminated with a # key.

To use PIN mode when the terminal's **Allow PIN after Badge** option in the Flags tab is set, the PIN must be terminated with a # key. You can enter the PIN and the # key before, during, or after the badge is presented.

To use PIN mode when you also have the **PIN** + **Card ID** card type selected, as an alternative for people who have forgotten their badge, the *#* key must not be entered before the badge is presented.

Four-Digit PINs

A four-digit custom PIN is defined by the first four digits entered in the **PIN Code** field in the Badge dialog box (see page 268). Algorithmic codes need to be requested from Technical Support.

PIN Duress

The PIN Duress feature in the Soft Alarm dialog box, creates an access grant and a duress alarm only if all of the following conditions apply:

- 1. The duress soft alarm is defined at the panel (see page 101).
- 2. The cardholder is required to enter a PIN at the terminal.
- 3. Exactly one digit of the PIN is replaced by the digit 9.
- 4. All other digits match the badge's PIN.
- 5. The card type selected in the terminal's Card Type tab is not PIN Only.

PIN Retry Alarm

A PIN Code Retry alarm is generated when the respective soft alarm is defined at the panel, and three consecutive unsuccessful attempts to enter a PIN were made for the same badge (see page 102). In Local mode, the three consecutive attempts can be made at any terminal of a single panel. In Central mode, the three consecutive attempts can be made at any terminal at any panel.

Create Input and Output Points and Groups

Input and output points and groups work together to control devices connected to the system terminals. For example, an input can be configured for a broken window contact and this can generate an output to an alarm annunciator. A group of inputs can generate the same output, no matter which input point in the group is activated.

Create Output Points and Groups

Output Points are dry contact relays located on the Terminal boards. These are opened or closed by the system to control devices connected to them such as lights, air conditioning, alarm annunciators, parking barriers, and so on. After output points are created, they can be grouped with other output points that have a common purpose in the system and then used in conjunction with specific inputs.

To Create Output Points:

- 1. In the System Configuration window, select a Terminal that has been configured for outputs.
- 2. Select **Output Points** and click **Add**. The Output Point dialog box opens.

C Output Point			_ 🗆 X
Output Point			
Partition Super Use	r 💌	🔽 Public	
Name Whse Aud	ible Alarm	N <u>u</u> mber	2 💌
Query Strin	ə [l		
State Option			
Status Enable	7		
Active State Timed	▼ D	uration 60 Second	
Output Group			
Group 1			
Group 2			
Group 3			
	OK Car	icel	

- 3. If this is a partitioned system, select in the Output Point box the active **Partition** and click **Public** if you wish the output point to be visible to all partitions.
- 4. Enter a descriptive **Name** for the output point.
- 5. Select an output point **Number**. This number represents the physical connection to the I/O terminal.
- 6. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- If this is an S321-DIN output point, select Disable from the Status drop-down list if you wish to use the default S321-DIN output point functionalities. Select Enable to define this output point as any general output point.
- 8. In the State Option box, select the Active State from the drop-down list. See the following definitions:
Reset – Reserved for diagnostic purposes.

Set – Turns on the output point. This option must be selected for output points assigned to elevators or cabinets.

Fast Flash – Toggles the output point on and off quickly (once per second).

Slow Flash – Toggles the output point on and off slowly (once per two seconds).

Timed – Turns on the output point for a specified time in seconds.

- 9. If the Active State is **Timed**, you must enter a **Duration** in seconds.
- 10. The Output Group box is view-only. Each output point can belong to three output groups.
- 11. Click **OK** to save your settings. The new output point is listed under the Output Points icon.

Note: You must perform the Write DB to Flash function (see page 482) when adding or deleting RDR2S-A or RDR8S output points.

To Create Output Groups:

Output Points can be grouped together to perform common functions. For example, an input such as an air-sampling device can be configured to activate a group of exhaust fans connected to output points on a terminal.

- 1. In the System Configuration window, expand the panel that contains the output points you wish to group.
- 2. Select **Output Groups** and click **Add**. The Output Group dialog box opens.

🖆 Output Group					×
Group					
<u>N</u> ame	Fan Group			🗖 Pu <u>b</u> lic	
Panel	Warehouse				
Group Number	1				
Output Point Names	•				
Output Points in G	roup		<u>A</u> vailable	e Output Points	
Exhaust 1 Exhaust 2 Exhaust 3		<u><u> </u></u>	Whse 4	àudible Alarm	
	ОК		Car	ncel	

- 3. Enter a Name for the Output Group.
- 4. The **Panel** field displays the name of the Panel selected.
- 5. The **Group Number** field displays the number that is automatically assigned when you create an output group.
- 6. If your system is partitioned, click **Public** if you wish this group to be visible to all partitions.
- In the Output Point Names box, select an Output Point from the list of Available Output Points.
- Click << to move the Output Point to the list of Output Points in Group.
- 9. Continue to move available output points from the **Available** list to the **Group** list until all output points you wish to include are in the Output Points in Group box.
- To remove an output point from the Output Points in Group box, select the output point and click >>.
- Click OK to save your settings. A new Output Group icon is listed under the root Output Groups icon for the panel.

Create Input Points and Groups

Input points can be physical connections to monitored devices such as a window or door contact, or a motion detector. They can be software alarms that are reported to the system, and can be connected to alarm pop-ups and instruction text. They can also trigger an event or an output device.

Create Input Points

After the terminal is created, the Input Points icon is added under the terminal. From here, you create the input points for the terminal. (If you need more information, see Create and Configure Terminals on page 70.)

To Create Input Points:

- 1. In the System Configuration window, select a Terminal that has been configured for inputs.
- 2. Select **Input Points** (under the Terminal icon) and click **Add**. The Input Point dialog box opens at the General tab.
- 3. Enter the information in each tab, as described in the following Input Point Field Definitions.
- 4. Click **OK** to save your settings and return to the System Configuration window. A new Input Point icon is listed under the root Input Points icon. When you click on the new input point, the settings display on the right windowpane.

Note: You must perform the Write DB to Flash function (see page 482) when adding or deleting RDR2S-A or RDR8S input points.

Input Point Field Definitions

General Tab

G Input Point				
General Alarm Options	I/O Linking Misc			
Partition	Super User	•	Public	7
Name	Rollup Door		Nymber 2]
	Query String			
Options				
Status Enable	•	Disabled During Time Zone	Full Time	•
Iype Two State	•	Entry Exit Dela	y 0	
Report Delay		🔽 Set Panel Relay	When Active	
			aw	Analy
			Cancel	Robbly

Partition – If you use partitions, select the appropriate Partition that has access to this input point.

Public – If you use partitions, click Public if you want this input point to be visible to all partitions.

Name – Enter a descriptive Name for the input point.

Number – Select an input point number.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Status – If you select Enable, all input point changes of state are reported. Select Disable if you do not want these changes reported.

Disabled During Time Zone – Select a Time Zone during which the input point is disabled. For example, it is impractical to report a door contact alarm during business hours when the door is in constant use.

Type – Choose either Two State or Four State.

Entry Exit Delay – Enter a time (0 to 600 seconds) that the alarm is suppressed until an event disables the alarm. If a delayed entry/exit value is defined for an input point, the system delays reporting activation of this input point for the time value specified. If the input point is suppressed within this delay period (that is, by a card event), the alarm is not reported. For example, a cardholder can badge at a reader, open the door, and then badge at a second reader to suppress the door alarm before it reports. If the cardholder does not badge and suppress the alarm (by card event) at the second reader within the specified time, the alarm is reported.

Report Delay – If enabled, the alarm is delayed by the number of seconds set in the Reporting Delay field in the Alarm tab of the Edit Panel dialog box. If the input point returns to the secure state before the delay expires, the panel does not report the alarm to the Server at all. If disabled, the alarm is reported immediately. Open and short conditions for 4-state input points are reported immediately.

Set Panel Relay When Active – If enabled, the relay on the panel activates when the input point is activated. If disabled, the relay on the panel does not activate. Not available for S321-DIN panels.

Alarm Options Tab

Use this tab to configure alarm options for P2000 devices that generate alarms, such as input points, cameras, switches, and so on. Each alarm must belong to at least one Alarm Category (see Alarm Configuration on page 285 for details), but can also be assigned to multiple alarm categories, each with its own set of alarm options. For example, if an input point connected to a glass breakage sensor generates an alarm, the P2000 system may create two separate alarms for two configured alarm categories: P2000\Maintenance\Building 1 and P2000\Security\Building 1. Typically, a single operator is configured to receive only a single category of alarms, and therefore could only receive a single alarm. However, higher level operators such as supervisors, or an operator at a central alarm monitoring location, may be configured to receive both of these alarms.

1. Click the Alarm Options tab. The P2000 Alarm Category displays by default.

C Input Point					×
General Alarm Options I/O Li	nking Misc				
Select Alarm Categories					
82000				_	(Edit
2000					<u>. Ear</u>
		1			
_	8dd	Delete			
·			or 1	Cancel	0 noly
				Calicei	

 If you wish to assign this alarm to other alarm categories, click Add. The Add Alarm Categories dialog box opens displaying all previously created alarm categories (see page 285 for details).



Note: If you use the Enterprise option, the Alarm Categories defined for all P2000 sites within an Enterprise system are listed.

- 3. Select one or more categories and click **Add**. The list displays all the selected alarm categories.
- If you wish to remove a category from the list, select the alarm category and click Delete.
- 5. Once you have all the alarm categories you want to assign to this alarm, select an alarm category from the list and click Edit to modify the alarm options. You can select and edit more than one category at a time. The Alarm Options dialog box opens displaying the General tab. See the following definitions.

General Tab

Alarm Options - Input Point [P2000]			×
General Events Escalation MSEA			
Disable Alarmi	Alarm Priority	0 *	
🔽 Aļarm Popup	Alarm Timezone	Full Time	•
Normal Popup	Alarm Instruction	Call Security	•
Cother Popup	Normal Instruction	<none></none>	•
Acknowledgement Required before Completion	Other Instruction	<none></none>	•
Operation Completion	Associated AV Channel	<none></none>	•
Respuise Requires before Competion	Associated Real Time Map	<none></none>	•
L			
	OK	Cancel Ap	ply

Disable Alarm – Do not select if you wish this alarm to be added to the alarm queue and displayed in the alarm monitoring window to notify the operator of its activation. Enabling or disabling the alarm is specific to a particular Alarm Category. For example, you can enable an alarm for a *Security* alarm category and disable the same alarm for a *Maintenance* alarm category.

Alarm Priority – Enter a value from 0 to 255. Zero equals the highest priority. This is the order in which the alarm message is placed in the alarm queue. If alarm messages have the same alarm priority, the date and time determine which alarm is positioned higher in the queue. Alarm Timezone – Select the time zone during which new alarm state changes are to be added to the alarm queue and displayed in the Alarm Monitor window. If you select **<None>**, the alarm state is reported any time it changes.

Alarm Popup – When you enable Alarm Popup for an alarm, the Alarm Monitor window automatically displays in front of all other windows on the screen whenever the alarm is in the alarm state. If disabled, the alarm is simply entered in the alarm queue.

Alarm Instruction – Select the Instruction Text that displays in the Alarm Response window when the alarm is in the alarm state. The Alarm Response window displays a set of instructions related to that particular alarm.

Note: Before you can assign instruction text to the various pop-ups, you must first create instruction text. See Creating Instruction Text on page 97 for more information.

Normal Popup – When you enable Normal Popup for an alarm, the Alarm Monitor window automatically displays in front of all other windows on the screen whenever the alarm enters its normal state.

Normal Instruction – Select the Instruction Text that displays in the Alarm Response window when the alarm enters its normal state. The Alarm Response window displays a set of instructions related to that particular alarm.

Other Popup – When you enable Other Popup for an alarm, the Alarm Monitor window automatically displays in front of all other windows on the screen whenever the alarm is in a state other than alarm or normal.

Other Instruction – Select the Instruction Text that displays in the Alarm Response window when the alarm enters a state other than alarm or normal.

Acknowledgement Required before Completion

- Select to require acknowledgement of this alarm before its completion.

Response Required before Completion – Select to require response to this alarm before its completion.

Associated AV Channel – If your facility uses the DVR feature, select the camera to be associated with this alarm. If applicable, this selection overrides the selection made in the Input to camera mapping window.

Associated Real Time Map – Select the Real Time Map to be associated with this alarm. If applicable, this selection overrides the default behavior of the Real Time Map containing the alarm. That is, when you click the Map button in the Alarm Monitor, the associated Real Time Map displays, even if it is different from the Real Time Map containing the alarm.

Events Tab

Alarm Ontions - Input Point [P2000) Se	acurity\Building 11		
General Events Escalation MSEA			
Event 1 Event 2 Event 3	Switch CCTV Camera	Activate Camera North	-
Event 4		<none></none>	•
		OK	

Event 1-4 – You can define up to four events that can be triggered from the Alarm Monitor window whenever the alarm goes into an alarm condition and is entered into the alarm queue. Enter a descriptive Event name and select a previously configured Event from the associated drop-down list; see To Activate an Event from the Alarm Monitor: on page 292.

Escalation Tab

The alarm escalation function constantly monitors all generated alarms that have their escalation options enabled. Escalation level value range is from 0 to 10, where 0 indicates a non-escalated alarm.

The alarm escalation feature provides for two different conditions when an alarm may be escalated:

- If an alarm is generated for a specific alarm category and there are currently no operators logged on to the P2000 system that have privileges to receive alarms for that category.
- If an alarm is generated and remains pending for the configured escalation timeout period.

If either of these conditions occurs, that alarm is regenerated with an elevated escalation level. The escalation level is incremented by the configured escalation increment value. This process may be repeated multiple times until a high enough escalation level is reached that matches the privileges of a currently logged on operator. If no operators are logged on to the P2000 system, the alarm is regenerated until the maximum escalation level is reached, and then no further action is taken.

After an escalated alarm has been completed, the next occurrence of that alarm is created with no escalation level.

Alarm Options - Input Point [P2000\Security\Building :	1]
General Events Escalation MSEA	
Escalation Repeat Escalation based upon visibility	Escalation Timeout (1 to 1440 minutes) 10 and 20 an
	OK Ca

Enable – Select to enable alarm escalation.

Escalation Repeat – Select to allow escalation to occur more than once for the alarm. For example, if the Escalation Timeout is set to 30 minutes, and the Escalation Increment is set to 2, every half an hour the escalation value for alarms remaining in pending state goes up by 2 until it reaches the maximum value. If this check box is not selected, escalation can occur only once for this alarm. To avoid the delay when the alarm cannot be seen and actioned by an active operator, click the *Escalation based upon visibility* check box.

Escalation based upon visibility – If selected, the alarm is immediately escalated by a defined increment if, at the time of occurrence, no operator able to receive alarms from this Alarm Category is logged on. This includes operators that are logged on to the Web UI Alarm Manager interface via a browser.

Escalation Timeout (1 to 1440 minutes) – Enter the time period (in minutes) after which an alarm remaining in pending state is escalated by the Escalation Increment.

Escalation Increment (1 to 10) – Enter the value by which to escalate an alarm each time the escalation takes place.

MSEA Tab

In facilities that use the Metasys system, this feature allows an alarm that is forwarded to the Metasys system to contain an embedded reference to a Metasys graphic. For more information, see Defining MSEA Graphics on page 383.

Alarm Options - Input Point [P2000\Security\Building 1]	
General Events Escalation MSEA	
MSEA Graphic Facility Map	
ОК	C

Select from the drop-down list the **MSEA Graphic** to reference in this alarm. When an alarm is received and displayed by the Metasys system, the Metasys operator can simply click the alarm to display the graphic item associated with the alarm and the item that caused the alarm.

I/O Linking Tab

Use the I/O Linking tab to link I/O Types to specific output groups. You must define output groups in the Output Group dialog box before you can use this function. See Create Output Points and Groups on page 88 for detailed information.

Input Point					
General Alarm Options	1/0 Linking Misc				
	1/O Link Type	Track		•	
	Output Group	Belau 1 Main Lobhu			
		I rost realized by			
			OK	Cancel	Apply

I/O Link Type – Select one of the following link types:

- None Default selection, indicating that there is no linkage between the input point and output group.
- Active-on When the input point is activated, the output group activates.
- Secure-on When the input point is secure, the output group activates.
- **Track** When the input point is activated, the output group activates. When the input point is secure, open, or short, the output group deactivates.
- **Mimic** When the input point is activated, open, or short, the output group activates. When the input point is secure, the output group deactivates.

- Active-off When the input point is activated, the output group deactivates.
- Secure-off When the input point is secure, the output group deactivates.
- **Reverse Track** When the input point is activated, open, or short, the output group deactivates. When the input point is secure, the output group activates.

Output Group – Select from the drop-down list the Output Group to which you wish to link.

- - -**T** - 1

Input Groups Group Group 2 Group 3

Calibra

MIS	c Tab			
C Input I	Point			
General	Alarm Options	1/0 Linking	Misc	

Calibrate

Un-calibrate

Input Groups – If this input point is included in
an Input Group, the associated Input Group
displays in this box. An input point cannot be
included in more than three Input Groups.

DK

Cancel

Apply

Calibration – Available only on inputs of the S321-DIN, RDR2S, RDR2S-A, or RDR8S module connected to CK7xx panels Version 2.2 and later

IMPORTANT: During the entire input calibration procedure, the input's contact must be physically closed. Otherwise, the input's status is unreliable.

If you click Calibrate, the Server sends a calibration command to the panel, the panel then forwards the command to the S321-DIN, RDR2S, RDR2S-A, or RDR8S module to initiate the input's calibration.

When the S321-DIN, RDR2S, RDR2S-A, or RDR8S module completes its calibration, typically within a few seconds, the panel sends a transaction message to the Real Time List indicating the calibration result. After a successful calibration, four-state input statuses are available for the input point.

If you click Un-calibrate, the Server sends a command to the panel to un-calibrate the S321-DIN, RDR2S, RDR2S-A, or RDR8S input. The panel then sends a transaction message to the Real Time List indicating the un-calibration result. After the un-calibration, four-state input statuses are no longer available for the input, only two-state statuses.

TIP: Once an input is calibrated, you do not need to use this feature again, unless you change the controller hardware or the input point's wiring.

Note: RDR2S-A and RDR8S modules with optional calibration resistors attached automatically uses this reference for calibration. Inputs calibrated in this way do not need to be secured at the time of calibration.

Configuring Reader Terminal Hardwired Input Points

When a reader terminal is created, three input points are reserved for specific inputs: input points for reader terminal door contact points (these have to be configured in the Soft Alarm window; see Configure Soft Alarms on page 101), and an input point for a terminal down input point. In the following example, Input Points Forced Door Office Entry Reader, Propped Door Office Entry Reader, and Term Down Office Entry Reader were created for the Office Entry Reader terminal in the Warehouse panel.



Using Reader Terminal Door Contact Input Points

Using the previous example, when the Office Entry Reader was created and Forced Door, **Propped Door** was enabled in the Edit Soft Alarm window, the system created the Input Points icon with two entries beneath it. The first input point, named Forced Door Office Entry Reader in the example, was created for input point 18 (varies, depending on the panel type). The second input point, named Propped Door Office Entry Reader was created for input point 24 (varies, depending on the panel type). You can use these input points as a door contact alarm. If enabled in the Input Point dialog box, these input points report to the Alarm Queue and Real Time List if the door contact is broken, or if left open longer than the configured alarm suppression for the reader.

To Edit a Reader Terminal Door Contact Input Point:

 Select the Forced Door or Propped Door <terminal name> icon under the reader terminal you wish to configure and click Edit to open the Input Point dialog box. If Forced Door was selected, input point 18 displays in the Number field. If Propped Door was selected, input point 24 displays in the Number field. These are hardwired to points 18 or 24 on the reader terminal.

- 2. Enter the information on each tab as you do for any other input point.
- 3. Click **OK** to save your settings and return to the System Configuration window.

Note: If you rename a terminal that has a Forced Door or Propped Door input point, you must edit the input points to manually enter the new terminal name, as in Forced Door <terminal name> or Propped Door <terminal name>. As an alternative, you could also disable the Forced Door, Propped Door in the Soft Alarm window and then enable it again to automatically create the input points under the new terminal name.

Using the Terminal Down Input Point

When a reader terminal is created in the system, a Terminal Down Input Point is automatically created for input point 25 on the terminal and displays under its input point icon as Term Down <terminal name>. If you wish to report this type of alarm, edit the input point and make sure the **Disable Alarm** option is not selected in the General tab of Alarm Options, otherwise the alarm does not report to the Alarm Queue, but continues to report to the Real Time List (see Alarm Options Tab on page 91).

To Edit a Reader Terminal Down Input Point:

- Select the Term Down <terminal name> icon under the reader terminal you wish to configure and click Edit to open the Input Point dialog box. Input point 25 displays in the Number field. (This is hardwired to point 25 on the reader terminal.)
- 2. Enter the information on each tab as you do for any other input point.
- 3. Click **OK** to save your settings and return to the System Configuration window.

Note: If you rename a terminal that has a Terminal Down Input Point, you must edit the Terminal Down Input Point to manually enter the new terminal name, as in Term Down <terminal name>.

Create Input Groups

Input Points from the same panel can be grouped to perform related functions. For example, motion detectors within a specific area can be grouped together to trigger an alarm or other output when activated. You can create as many input groups as you need; however, an individual input point can be included in no more than three input groups.

To Create an Input Group:

- 1. In the System Configuration window, expand the panel that contains the input points you wish to group.
- 2. Select **Input Groups** and click **Add**. The Input Point Group dialog box opens.

roup		
Name	Whse Break	Public
Panel	Warehouse	
Group Number	1	
put Point Names		
Reader Door Whse Rollup Door 1		Term Down Front Entrance Term Down Whse Exit Reader Term Down Whse 1/08
		× · · · · · · · · · · · · · · · · · · ·

3. Enter a descriptive **Name** for the Input Group.

- 4. If your system is partitioned, click **Public** if you wish this group to be visible to all partitions.
- 5. The **Panel** name displays in the Panel field.
- 6. The **Group Number** field displays the number that is automatically assigned when you create an input group.
- Select an input point from the Available Input Points list and click << to move it to the Input Points in Group list.
- 8. Select all the input points you wish to include in the group and move them into the group list until all have been added.
- To remove an input point from the Input Points in Group box, select the input point and click >>.
- 10. Click **OK** to save your settings and return to the System Configuration window. A new Input Group icon is listed under the root Input Groups icon for the panel.

Creating Instruction Text

Instruction text can be assigned to input points and other P2000 applications. When any of these elements changes state, an alarm is sent to the Alarm queue and displayed in the Alarm Monitor window. When an operator selects the message for response, the instruction text displays in the Alarm Response dialog box.

You can configure Alarm Instructions with an embedded URL and assign that instruction to an alarm. When the alarm instruction displays in the Alarm Monitor, the user can click the URL and it starts the Web Browser with the URL. The alarm instruction detects URLs that begin with the following prefixes:

http:	file:	mailto:
ftp:	https:	gopher:
nntp:	prospero:	telnet:
news:	wais:	

When one of the previous URLs are found in the instruction text, Windows performs its configured default action for the URL. For URLs of *http:* or *https:*, the Web Browser is started with that URL. If the URL begins with *mailto:*, Windows starts your email program. If the URL begins with *file:*, Windows starts the associated application to view the file.

To Create Instruction Text:

 From the P2000 Main menu, select Alarm>Instruction Text. The Instruction Text dialog box opens.

C Instruction Text		_ 🗆 ×
Partition: Supe	r User 💌	
Name	Partition	Public
Whse Motion	Super User	No
Whee Rollup Door 1	Super User	No
Whse Rollup Door 1 Secure	Super User	No
Instruction		
Whee Motion - Alert Security		
Done Add	Edit De	lete

2. Click **Add**. An instruction entry dialog box opens.

Instruction Text			×
<u>P</u> artitic <u>N</u> am	on: SuperUser e: Whse Rollup Do	or 1	lic
Instruction:			
Alarm Rollup door 1 - S This message was ger	Summon Security nerated at \$TIME on	\$DATE	
Insert Mac	ro \$DATE	•	
	OK	Cancel	

- 3. If this is a partitioned system, select the appropriate **Partition**, and click **Public** if you want this instruction to be visible to all partitions.
- 4. Enter the **Name** of the Instruction. This is the name that displays in drop-down lists for selection in P2000 applications that use Instruction Text.
- 5. Enter the actual instruction text you want to display.
- If you wish to insert a macro to be part of the instruction text, select a macro from the Insert Macro drop-down list. See the following table.

Use Macro	To Insert
\$ASCII(xxx)	ASCII Character
\$BADGE_DESCRIPTION	Badge Description
\$BADGE_NUMBER	Badge Number
\$BS	Backspace
\$CARDHOLDER_FIRSTNAME	Cardholder's First Name
\$CARDHOLDER_LASTNAME	Cardholder's Last Name
\$CARDHOLDER_NAME	Cardholder's First <space> Last Name</space>
\$CR	Carriage Return
\$DATE	Today's Date
\$FF	Form Feed
\$INPUT_NAME	Input Name
\$INPUT_NUMBER	Input Number
\$LF	Line Feed
\$OPERATOR	Operator Name
\$PANEL_NAME	Panel Name
\$TAB	ТАВ
\$TERMINAL_NAME	Terminal Name
\$TIME	Current Time
\$UDF_x*	User Defined Field

* The x must be replaced with the UDF order number. This macro is used with Host events, where the triggering message is directly associated with a Cardholder, such as an Access Grant message.

Note: Do not include macros in Instruction Text that is used in delayed event actions. The information needed for the macros is not available when the action is delayed. See Creating Actions on page 351.

 Click OK to save the Instruction Text entry and return to the Instruction Text dialog box. Click Done.

Create Panel Card Events

Panel Card Events operate independently from the Server and therefore affect only the Panel for which they are configured. Panel Card Events are particularly useful for panels that operate offline, such as in areas that must remain operable if the network goes down.

Note: Panel Card Events are configured for each panel while System Events are configured for the Server. For more information on System Events, see Creating Events on page 349.

A Panel Card Event is based on badge (trigger) activity and used to suppress or unsuppress an input group, activate or deactivate an output group, operate a door strike, and reset a panel alarm relay.

The following section presents steps to create Panel Card Events. To invoke panel card events using a keypad, see Appendix G: Using a Keypad Reader on CK7xx Panels.

To Create a Panel Card Event:

- 1. From the System Configuration window, select the panel to which you wish to assign a Panel Card Event.
- 2. Select **Panel Card Event** and click **Add**. The Panel Card Event dialog box opens.

Panel Card Event			_ []
Panel Card Event			
Name: Turn Lights (In	Panet: Warehouse	
Number: 1			
Option			
Privilege Level	0 💌	Irigger Type: Card Only	•
Keypad Code:		Event Duration: minutes	
Input Group			
Enable	Suppress	Input Group: Whee Break	•
Output Group			
🔽 Ena <u>b</u> le	✓ Activate	Output Group: Rollup Door 1	-
Misc			
🗖 Operate Door Strike	E Res	et Panel Alarm Relay (Acknowledge Alarm)	
Valid Readers for Current Even			
Terminal 1 · Whse Entry F	eader		
Terminal 3 - Office Exit Re	ader		
I erminal 4 - Whee Exit Re Terminal 5 - Office Entry F	ader eader		
	ouddi		
1			
	OK	Cancel	

- 3. Enter the information according to the Panel Card Event Field Definitions.
- 4. When all information is added, click **OK** to save your settings and return to the System Configuration window.

Panel Card Event Field Definitions

Panel Card Event

Name – Enter a descriptive event name.

Panel – Displays the selected panel name.

Number – Enter an event number from 1 to 20.

Option

Privilege Level – This entry corresponds to the Cardholder's privilege level (from 0 to 7, with 0 being the lowest). The Cardholder's privilege level must be equal to or greater than the Privilege Level defined here to initiate the event; see Entering Badge Information on page 267 for more information.

Trigger Type – Indicates the condition that triggers this card event. Select one of the following:

- Card Only Present badge. This trigger type does not generate *Invalid Event Privilege Level* messages.
- Card/PIN Code Enter PIN code, then present badge.
- Card/Keypad Code Enter activation or deactivation code, followed by the code specified in the Keypad Code field, then present badge.
- Card/PIN/Keypad Code Enter PIN and activation or deactivation code, followed by the keypad code, then present badge.
- Any Void Card Present any void badge. In this case the card event's privilege level should be set to 0, as void badges do not have any privilege level. For this condition to trigger a card event with a consistent behavior, the terminal should run in local mode. The card event may also be triggered on terminals running on shared or central mode, depending on the generated card message.
- Special Access Flags Select one of the three Special Access flags A, B, or C that can trigger this card event. The list displays the special access flag names as configured in Site Parameters. Special access conditions are set up in the Access tab of the terminal dialog box; see page 79.

Note: If **Allow PIN after Badge** is enabled in the Terminal dialog box, the cardholder can enter the PIN number after presenting the badge; see page 72 for more information.

Keypad Code – Enter a four-digit keypad code that must be entered to activate or deactivate the event. Deactivating an event can only accomplished by using a keypad code.

Event Duration – Enter the duration, in minutes that the event is active (up to 1440 minutes). If the event activates an output group, the output group is deactivated after this time period. If the event suppresses an input group, the input group is unsuppressed after this time period. Event duration applies only to event activation, and not to event deactivation. Furthermore, only output group activation and input group suppression may be assigned a duration, but not output group deactivation and input group unsuppression.

Input Group

Enable – Click to enable the Input Group Suppression function.

Suppress – Click to suppress the specific Input Group when this event is activated. Do not select Suppress to unsuppress the specific Input Group when this event is activated. When this event is deactivated, the selected action is inverted; that is, an event that suppresses an input group on activation, unsuppresses that input group on deactivation, and an event that unsuppresses an input group on activation, suppresses that input group on deactivation.

Input Group – Select the name of the Input Group that can be suppressed or unsuppressed.

Output Group

Enable – Click to enable the Output Group Activate function.

Activate – Click to activate the specific Output Group when this event is activated. Do not select Activate to deactivate the specific Output Group when this event is activated. When this event is deactivated, the selected action is inverted; that is, an event that activates an output group on activation, deactivates that output group on deactivation, and an event that deactivates an output group on activation, activates that output group on deactivation. **Output Group** – Select the name of the Output Group that can be activated or deactivated.

Misc.

Operate Door Strike – If not selected, a valid event invokes the event action only, but does not unlock the door. This setting does not apply to legacy panels and badges with executive privilege. Also, events with trigger type *Any Void Card* never unlock the door.

Reset Panel Alarm Relay (Acknowledge Alarm)

- If selected, the panel alarm relay is reset. Not available for S321-DIN panels.

Note: If a panel card event is created for CK7xx panels and none of the boxes to suppress output points or strike readers are enabled, the panel card event still shows in the Real Time List, as an activated event. For legacy panels, if none of the boxes are enabled, no panel card event activation messages are generated.

Valid Readers for Current Event

The terminals connected to this panel display in the list. Select those readers that are used to initiate this card event. If not selected, the terminal is not affected by the event.

Configure Soft Alarms

Soft alarm points and their addresses are created by the system during installation rather than hardwired to an actual input point. You can enable these soft alarms for Readers, Terminals, or Panels.

The alarm point numbers may be different, depending on the type of panel selected.

To Enable Soft Alarms:

- 1. From the System Configuration window, select the Panel for which you wish to enable soft alarms.
- 2. Select **Soft Alarm** and click **Edit**. The Edit Soft Alarm dialog box opens.
- 3. Select the **Reader**, **Terminal**, or **Panel Soft Alarms** you wish to enable, and click the corresponding **Relay** box to activate the panel relay. See Soft Alarms Field Definitions for detailed information.

🕻 Edit Soft Alarm	
Reader Soft Alarms	
✓ Duress (17)	🗖 Relay
Pin Code Retry (19)	🗖 Relay
Forced Door (18), Propped Door (24)	🗖 Relay
Card Parity	🗖 Relay
Soft In-X-It (23)	
Terminal Soft Alarms	
Ierminal Lost AC	🗖 Relay
Terminal Low Batterg	🗖 Relay
Terminal Tamper	🗖 Relay
Panel Soft Alarms	
Panel Lost AC (21)	🗖 Relay
Panel Low Battery (20)	🗖 Relay
Panel Tamper (22)	🗖 Relay
<u>R</u> eport On Terminal Office	Entry Reader
OK	Cancel

4. Click **OK** to save your settings and return to the System Configuration window.

Soft Alarms Field Definitions

Duress – If enabled, an alarm is generated when an authorized cardholder reverse-swipes the badge, provided that the terminals' Reverse Swipe Duress feature is enabled, or substitutes a 9 for one of their PIN code digits. The PIN is used with the badge and grants access to avoid compromising the personal safety of the cardholder. The panel relay for a duress alarm is only activated when the reader is either in Local mode, or in Shared mode and the panel knows the badge. **PIN Code Retry** – When enabled, an alarm is generated when three consecutive invalid PIN codes are entered at a keypad reader.

Note: If you enable the **Relay** box associated with a Duress or PIN Code Retry alarm to activate the panel relay, you must also enable the **Latch Output** option on the Alarm tab of the Edit Panel dialog box; see page 61.

Forced Door/Propped Door – If enabled, a Forced Door alarm message is printed whenever there is a door open condition without a valid badge read detected first; and a Propped Door alarm message is printed whenever there is a door open condition with a valid badge, but the door is left open past the entry time.

Card Parity – The binary card number includes a bit which confirms that the number of ones in that binary number is odd or even. This is compared to the card number by the STI, to confirm that the reader and the card are functioning properly. If an error is detected, a Card Parity Error message is sent and logged to Transaction History. This soft alarm type is not used with CK7xx, S321-DIN, S320 or TIU panels.

Soft In-X-It – If enabled, the Soft In-X-It overrides the system In-X-It control function for a specified reader and allows cardholders to gain access at that reader even though they have the wrong In-X-It status. An alarm is generated when a violation occurs. **Terminal Lost AC** – On a UPS-equipped STI-E, an alarm is sent when power is lost. This soft alarm is equivalent to the *STI NO AC* alarm message that is printed in real time. This soft alarm type is not used with CK7xx, S321-DIN, S320 or TIU panels.

Terminal Low Battery – An alarm is sent when the battery in the terminal is low. This soft alarm type is not used with CK7xx, S321-DIN, S320 or TIU panels.

Terminal Tamper – A message is generated whenever the terminal enclosure is opened or closed. This soft alarm type is not used with CK7xx, S321-DIN, S320 or TIU panels.

Panel Lost AC – Used with the UPS option, this soft alarm sends an alarm if the panel loses power. Not available for S321-DIN panels.

Panel Low Battery – With UPS equipped panels, an alarm is sent when the battery in the panel is low. Not available for S321-DIN panels.

Panel Tamper – The panel has an internal hardware connection for its own enclosure tamper switch that generates a special message whenever the enclosure is opened or closed. Not available for S321-DIN panels.

Report on Terminal – Select a terminal from the drop-down list. This is the actual terminal connection associated with the Soft Alarm and is used for panel soft alarms only. Not available for S321-DIN panels.

Configure P900 Panels and Components

Use this section to configure your P2000 system to communicate with P900 panels. P900 panels communicate with the Server via a loop configuration. It is assumed that the P900 hardware is already connected to the Server before you can configure and use the essential functions described in the following procedures. The following instructions describe how to:

- Import P900 Sequence Files
- Configure P900 System Parameters
- Configure P900 Panels
- Configure P900 Terminals
- Configure P900 Input and Output Points
- Configure CLIC Components
- Configure P900 Trigger Links

P900 to P2000 Terminology Cross Reference

The following table has been designed to assist P900 panel users become familiar with the terms used across the P2000 software.

P900	P2000
Controller	Panel
Access Point	Terminal
Site Code	Facility Code
Access Level	Access Group
Time Frame	Time Zone
Disable During Time Frame	Timezone Exception
Card	Badge
Reconfigure System	Download
Valid Entry	Access Granted
Local Anti-Passback Violation	Invalid In-X-It Status

Import P900 Sequence Files

The P900 Sequence Files feature allows existing P900 users without full software support, to download commands for special usage, such as the card bit swapping command.

Sequence files are simple string files created using *Notepad* (or similar), with each line being one communication command. When the P2000 software downloads all badges, it checks if the files *Config1.Seq* or *Config2.Seq* exist, if they do, these commands are inserted into the download sequence as required. *Config1.Seq* is downloaded before the badges, while *Config2.Seq* is downloaded after the badges.

To Import P900 Sequence Files:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand **P900 Panels** to open the P900 components.
- Select Sequence Files and click Edit. The Select P900 Sequence Files dialog box opens.



 In the Config 1 box, click Import and navigate to the directory where your command files are stored.

- Double-click the <name>.seq file you wish to import. The name and commands of the selected file displays.
- 7. If you wish to modify the existing commands, click **Edit** and make your changes, then click **Save**.
- 8. To export the command file under a different name, click **Export**.
- 9. If you wish to delete the command file, click **Delete**.
- 10. If you wish to import a second commands file, go to the **Config 2** box and repeat the previous steps.
- 11. Click **Done** to close the dialog box.

Configure P900 System Parameters

Before configuring P900 hardware components, you must define whether the P900 panels configured in the system can send messages to the Server to report certain types of access denied transactions. These messages display in the Real Time List and are saved in the database. You must also define Anti-Passback settings and the card format type used with P900 readers.

To Configure P900 System Parameters:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand **P900 Panels** to open the P900 components.
- 4. Select **P900 System Parameters** and click **Edit**. The P900 System Parameters dialog box opens.

	Facility Code Report	
	Access Group Report	
	Issue Level Report	
	Badge Not Found Report	
	Time Zone Report	
	PIN Violation Report	
	Local Anti-Passback Report	
Anti-Passback		
	Reader Holdoff Time 0 Seconds	
	Repeat Transaction Delay 0 Seconds	
	Local Anti-Passback Forgiveness Enable	
	Time 12:00:00 AM	
Card Mode		
	Card Mode 16 bit	

- In the Access Violation Messages box, select **Report** from the message type drop-down list that is sent to the Real Time List on access denied transactions. Select <none> if you do not wish to send messages of this type.
- 6. Enter the **Reader Holdoff Time** in seconds (0 to 255) after which a reader is polled again.
- 7. Enter the **Repeat Transaction Delay** time in seconds (0 to 255) after which cardholders can use their badge at a different reader connected to the same panel. This allows a delay time for the badge not to be read immediately at for example, an Exit reader at the other side of the door.
- 8. In the Local Anti-Passback Forgiveness drop-down list select Enable to change the status of all badges to *undefined* and that way forgive anti-passback access violations at all P900 readers every day at the time selected in the Time field. Select **Reset** if you wish to immediately change the status of all badges to undefined.
- 9. Select the **Card Mode** to be used at all P900 readers. The range of values within a card number depends on the card mode selected. See the following table:

Card Mode	Card Number Range
16 bit	1 - 65535
24 bit	1 - 16777215
30 bit	1 - 1073741823
P900 Cards 31 bit / Swipe Cards 32 bit	1 - 2147483647 / 1 - 4294967295
48 bit	1 - 281474976710655
64 bit	1 - 18446744073709551615

10. Click **OK** to save your settings and return to the System Configuration window.

Configure P900 Panels

P900 panels communicate with the Server via a serial connection using a loop configuration. With the serial connection, the system supports up to 32 loops, with up to sixty-four P900 panels per loop. You must set up loop configurations before configuring P900 panels. Complete instructions are presented in Loop Configuration on page 54.

To Create P900 Panels:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Select **P900 Panels** and click **Add**. The Edit P900 Panel dialog box opens.



3. If you use Partitioning, select the **Partition** that has access to this panel information, and click **Public** if you wish to allow all partitions to see this panel.

- 4. Enter a descriptive **Name** for the panel, according to your Naming Conventions Plan; see page 53.
- 5. Click **Enabled** so the system recognizes the panel. If you wish to temporarily disable the panel, without having to delete the panel, click the check box again to disable it. When you disable a panel, the readers continue to grant access, but the panel does not communicate with the Server until you enable the panel again.
- 6. Select any of the P900 **Loop** numbers defined in the Loop Configuration dialog box. The P2000 system can support up to 32 loops.
- Enter the Address assigned to this panel (see the following section P900 Panel Addressing Principles). The P2000 system supports up to sixty-four P900 panels per loop.
- 8. Click **Time Offset** if the panel is in a different geographical time zone from the Server. Enter the appropriate hours and minutes for the time offset.
- 9. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see page 381).
- 10. Click **Enabled for BACnet Interface** if you wish to define this panel as a BACnet panel object.
- 11. Click **OK** to save your entries. A message displays asking if you wish to automatically add all time zones to the new panel. If you select **No**, you can add the time zones later; see Configure Panel Time Zones on page 66. If you select **Yes**, the time zones are automatically added.

Note: In addition to applying time zones to the panels (described in Configure Panel Time Zones on page 66), you may also define panel holidays if you wish to restrict access in your facility during a holiday period; see Configure Panel Holidays on page 67.

When a P900 panel is created, the system automatically creates a *Panel Down* soft input point for input point 25 and displays under the **Soft Input Point** icon as *Panel Down <panel name*>. If you wish to report this type of alarm, edit the input point and make sure the *Disable Alarm* option is not selected in the General tab of Alarm Options, otherwise the alarm does not report to the Alarm Queue, but continues to report to the Real Time List. Also, if you rename the panel, you must edit the input point to manually enter the new panel name, as in *Panel Down <panel name*>.

P900 Panel Addressing Principles

Panel address assignment depends on how the P900 panels are connected to the Server, which is done using one of the following three basic configurations:

Server to One or Two Panels Only – This configuration uses an RS232 link. Addresses can be 00 and 01.



Server to up to 32 Panels – This configuration is done through a COM module. Addresses can be 00 through 31.



Server to Several Panels in a Branch Configuration – This configuration is done through COM modules in a branch configuration. There can be up to 10 branches (0 to 9), and each branch can have up to 32 panels. Addresses can be 000 to 931, and the last two digits must match the panel's physical address.



Configure P900 Terminals

Terminals are installed into the P900 panels to control devices such as card readers; inputs such as alarm monitoring devices; and output devices that control other devices such as lights, air conditioning, alarm annunciators, and so forth. Each terminal installed in your system must be set up and configured in the P2000 software to establish communication and control. Once terminals are configured. they may be included in terminal groups and associated with input and output points and groups. You must set up terminals for each P900 panel configured in the system. As with all configuration operations, the P900 Terminal Edit dialog box is accessed from the System Configuration window.

To Create a New Terminal:

- 1. Expand **P900 Panels**. All P900 panels currently configured in the system are listed.
- 2. Expand the panel in which the terminal is installed. All the items that can be configured for the panel are listed under it.
- 3. Select **Terminals** and click **Add**. The P900 Terminal Edit dialog box opens at the General tab. Enter the information in each tab according to your system requirements and naming conventions. See P900 Terminal Field Definitions for detailed information. As you work through the tabs, click **Apply** to save your settings.

C P900 Terminal Edit		
, . Terminal Name	West Entrance	
Panel	P900 on Lobby West	Public
Hardware Type	Dual Reader	▼ IV Enable
Query String		
- Hardware Inform	nation Input Output Reader Access	Number 2 💌
System will add ne	w dual terminals automatically	
	OK	Cancel Apply

- 4. When all entries are complete, click **OK** to save your settings and return to the System Configuration window. Your new terminal is listed under the Terminal icon.
- Continue to create terminals for every P900 panel in which they are installed. If you wish to group P900 terminals that provide common access, see Create Terminal Groups on page 85 for detailed instructions.

P900 Terminal Field Definitions

The P900 Terminal Edit dialog box opens at the General tab. You must enter information in all tabs to complete configuration. Terminal options available in the P900 Terminal Edit dialog box are dependent on the type of hardware selected. For example, if you select any of the four Inputs/Outputs, only the General tab is available. If you select any of the eight Readers, the Readers tab is available. The Options tab is available if you select any of the Readers, except the Dual Reader and the Dual Cotag Reader.

General Tab

Terminal Name – Enter the name of the new Terminal. Remember to use descriptive names according to your Naming Conventions Plan.

Panel – This field displays the name of the P900 panel you selected from the System Configuration window.

Public – If you use Partitioning, click **Public** if you wish this terminal to be visible to all partitions.

Hardware Type – Select the board type installed into the P900 panel. Choices are:

- Dual Reader
- Single Reader
- Dual Cotag Reader
- Single Cotag Reader
- MK2 Dual Reader
- MK2 Dual Reader & PINpad I/F
- MK2 Dual Cotag Reader
- MK2 Dual Cotag Reader & PINpad I/F
- 16 Inputs/0 Outputs
- 8 Inputs/8 Outputs
- 8 Inputs/4 Outputs
- 16 Inputs/8 Outputs

Once you save this configuration, changes in this field can only be done within the same hardware type; for example, you cannot change a reader type to an input/output point type or vice versa.

Enable – Click if you wish the system to recognize this terminal.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381). **Number** – Enter a terminal address number, 0 through 8. This terminal address number corresponds to the physical address as installed at the panel. (See your specific hardware configuration if you need more information on terminal address assignment.) Reader terminals are numbered 0, 2, 4, or 6. Input/Output boards are numbered 0, 2, 4, 6, or 8.

If you select any of the **Dual** readers, the system automatically adds a new dual terminal to the panel, using an odd address number. For example, if you create a Dual Cotag Reader named *Warehouse Reader* with an address number of 2, the system adds a new dual terminal using the same hardware type, named *Warehouse Reader_1*. Note that if you wish to edit the new added terminal, the hardware type and address number cannot be changed, unless you modify the first dual reader.

Hardware Information – This box displays one of the following terminal types, depending on your selection on the Hardware Type field:

- Input Indicates a terminal that provides input points.
- **Output** Indicates a terminal that provides output points.
- Reader Indicates a card reader terminal. If a reader is selected as the hardware type, choose one of the following reader types:
 - Access Normal access reader.
 - Entry Entry defined access reader.
 - **Exit** Exit defined access reader.

Readers Tab

🕻 P900 Terminal Edit	×
General Readers Options	
Unlocked Time Zone	Relay Time Time 5 - Second(s) •
Monitoring Action ↓ Enable Monitoring Action ↓ Door Forced ↓ Alarm ↓ Warning	Door Open Delay 30 Sec Alarm Delay 30 Sec Warning Delay 20 Sec
Egress Actions C Disabled C Enable Report	Shurt Terminal (Anti-Pasaback)
	OK Cancel Apply

Interface Type – Select the interface setting used to decode the data from a swipe card reader. This field is not available for any Cotag readers. Choices are: 26 Bit, 34 Bit Cardkey, 34 Bit Cardkey Enc, 16 Char Cardkey Mag, and Other. If you select Other, you must enter an interface number, associated with the make and model of card reader installed.

Note: If you select **Other**, do not use the following interface numbers: 0, 4, 7, or 54. These numbers correspond to the interface types displayed in the drop-down list, such as 26 Bit is 0, 34 Bit Cardkey is 4, and so on.

Unlocked Time Zone – Select the Time Zone during which the reader does not require a card to open the door, and therefore allow unrestricted access. Select **<none>** if you do not wish to enable this function.

Relay Time – Select the amount of time and select Seconds (1-180), or Minutes (1-60), or 100, 200 or 500 ms that the door relay is energized after each valid card access request.

Fixed Period – Click if the door relay is always energized within the Relay Time selected.

Auto Relock – Click to lock the door immediately when the door closes. This prevents reopening the door on one card access. If you select this option, you must click Enable Monitoring Action.

Enable Monitoring Action – Click if you wish to monitor Door Forced and Door Open alarms and warnings. This feature is required if you select the **Auto Relock** option.

Door Forced - Alarm – If enabled, an alarm message is generated whenever there is a door forced condition; the door was opened without a valid card read detected first.

Door Forced - Warning – If enabled, a warning output is activated whenever there is a door forced condition; the door was opened without a valid card read detected first.

Door Open - Alarm – If enabled, an alarm message is generated whenever there is a door open condition; the door was opened with a valid card, but was left opened past the **Delay Time** (1 to 255 seconds).

Door Open - Warning – If enabled, a warning output is activated whenever there is a door open condition; the door was opened with a valid card, but was left opened past the **Delay Time** (1 to 255 seconds).

Egress Actions – If you select **Enable**, the door relay is energized within the Relay Time selected, whenever the door exit control input is activated. If you select **Disabled**, the system does not respond to the door exit control input. If you select **Report**, the door relay is energized within the Relay Time selected, and a message is sent to the Real Time List to monitor the event. Shunt Terminal (Anti-Passback) – Available for Entry and Exit readers only. Select the reader that is shunted whenever the door relay is energized simultaneously at an Entry and Exit reader. When you define an Entry reader, the Shunt Terminal you select here is the Exit reader, which is usually installed at the other side of the door. The Shunt Terminal suppresses the door forced alarm after the cardholder swipes the card. When you define the Exit reader, the Shunt Terminal is the Entry reader. We recommend you select the Shunt Terminal in both Entry and Exit readers to avoid reporting false alarms.

Manually Selected – Click if you want to allow an operator to manually control this door using the Door Control function; see Controlling Doors on page 303.

Options Tab



Pin Pad Box

Enabled – The system does not recognize the PINpad matrix connected to the reader, unless this check box is selected. The PINpad feature is available for the Single Reader, the Single Cotag Reader, and the MK2 Dual Cotag Reader & PINpad I/F. It could also be used by the MK2 Dual Reader & PINpad I/F, as long as the Swipe PIN option is disabled. **Type 1, 2, or 3** – Select the type of layout of the PINpad model connected to the reader. See the following PINpad layouts:



Disabled Time Zone – Select the Time Zone during which a PIN code is not required to open the door, access is granted by presenting the card only. Select **<none>** if you require entering the PIN code at all times.

Aux Input Box

Options in this box are only available for the Single Reader and the Single Cotag Reader.

Tamper Monitoring – If enabled, a tamper alarm is generated if the input reports an Open or Short condition.

Aux Input Monitoring – If enabled, an auxiliary input alarm is generated if the input reports an Alarm or Secure condition.

Aux Input Description – Enter a name (up to 32 characters) for the auxiliary input. This name describes the function of the input. This is the name of an unconfigurable input point created automatically by the Single Reader terminal.

Disabled Time Zone – Select the Time Zone during which the auxiliary input monitoring is disabled. Select **<none>** if you do not want to disable the auxiliary input monitoring.

Aux Output Control Box

Options in this box are only available for the Single Reader and the Single Cotag Reader.

Aux Output Control – If enabled, the auxiliary output is activated. An auxiliary output can be activated by entering a PIN at the reader or during the Time Zone selected.

Under PIN Control – If enabled, the auxiliary output is activated when a valid card is read and the cardholder enters the correct PIN number at the reader. If you select this option, use the box at the right of this field to enter the PIN number (4 digits) that is used to activate and deactivate the auxiliary output.

Aux Output Description – Enter a name (up to 32 characters) for the auxiliary output. This name describes the function of the output. This is the name of an unconfigurable output point created automatically by the Single Reader terminal.

On During Time Zone – Select the Time Zone during which you can activate the auxiliary output. Select **<none>** if you wish to activate the auxiliary output at any time.

MK II Box

Options in this box apply to the MK2 readers only.

Swipe PIN – If enabled, a PIN is required after swiping a card. This option is available for the MK2 Dual Reader. It could also be available for the MK2 Dual Reader & PINpad I/F, as long as the Pin Pad option is disabled. If you enable the Swipe PIN option, you can select a time zone from the **Disabled Time Zone** drop-down list in the Pin Pad box, during which the Swipe PIN option is not active. **CLIC PIN** – Enter a four-digit PIN code that is used to activate any device connected to a Configurable Logical I/O Control (CLIC) component. See Configuring CLIC Components on page 114. This option is available for the following MK2 readers, in the following situations:

- MK2 Dual Cotag Reader & PINpad I/F if Pin Pad is enabled
- MK2 Dual Reader if Swipe PIN is enabled
- *MK2 Dual Reader & PINpad I/F* if Pin Pad or Swipe PIN is enabled

Tamper Monitoring of Door Contact - If enabled, a tamper alarm is generated whenever the door detects a forced door or propped door condition.

Tamper Monitoring of Egress Contact – If enabled, a tamper alarm is generated whenever the door exit control input is activated.

Configure P900 Input/Output Points

Input points are used to monitor external equipment connected to the P900 terminal; they are used to generate alarms, either when the input is activated, or if the connections to the input are tampered with, or if the tamper switch in the equipment is activated. Output points control external devices connected to the P900 terminal using relay contacts located on the terminal board. Outputs can be switched on during a time zone, or can be activated in response to an access transaction or activated input point.

To Create an Input Point:

1. In the System Configuration window, expand the P900 terminal that provides the input point.

- Select Input Points and click Add. The P900 Inputs dialog box opens at the General tab. Enter the information in each tab. See P900 Input Field Definitions for detailed information. As you work through the tabs, click Apply to save your settings.
- 3. Click **OK** to save your entries and return to the System Configuration window. After the input points are created, input points from the same panel can be grouped to perform related functions; see Create Input Groups on page 97 for detailed instructions.

P900 Input Field Definitions

General Tab

C P900 Inputs				×
General Alarm Options				
Partition	Super User	•	Public	
Hardware Type	Supervised NC/NO			
Input Name			🔽 Enable	
Input Number	1 💌			
Disable Timezone	<none></none>	•		
Query String				
	Enable Reporting			
Dis	able While Terminal Unsecure	<none></none>	-]
Monitoring	Tamper]
		ОК	Cancel	Apply

Partition – If you use Partitioning, select the **Partition** that has access to this input point.

Public – Click **Public** if you wish to allow all partitions to see this input point.

Hardware Type – This field displays the supervised input connection type. Supervised inputs monitor tamper conditions and input state changes. Input numbers 1 to 4 are configured as NC/NO (Normally Closed/Normally Open); input numbers 5 to 8 are configured as NC (Normally Closed).

Input Name – Enter a descriptive name for this input point.

Enable – Click to report all input point changes of state.

Input Number - Select an input point number.

Disable Timezone – Select a Time Zone during which the input point is disabled. For example, it is impractical to report a door contact alarm during business hours when the door is in constant use.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Enable Reporting – If this input point is not related to alarm monitoring, select this option to report input point changes of state to the Real Time List.

Disable While Terminal Unsecure – This option disables this input point whenever the relay at the selected terminal is energized. If you do not wish to disable the input point, select **<none>**.

Input Monitoring – Click if you wish to monitor input points that report Alarm or Secure conditions.

Tamper Monitoring – Click if you wish to monitor input points that report Open or Short conditions. Conditions are reported as Short only.

Alarm Options Tab

Alarm options are described in detail on page 91.

To Create an Output Point:

- 1. In the System Configuration window, expand the P900 terminal that provides the output point.
- 2. Select **Output Points** and click **Add**. The P900 Outputs dialog box opens.

- 11. From the **On During Timezone** field, select a time zone during which the output point is always active. Select **<none>** if this output point is controlled with a trigger event.
- 12. To activate the output point whenever the access condition selected in the Action/ Condition field occurs, select the terminal name from the **Output Action on Event at** drop-down list where this access condition should occur.
- 13. The choices in the Action/Condition drop-down list determine how the output is activated, and the type of access that causes it to be activated. See the following definitions:

Actions	Definitions
Toggle State	If the output is off, then turn it on. If the output is on, then turn if off.
Pulse	Turn the output on for the period defined in the next field, then turn it off again.
Energize	Turn the output on.
De-Energize	Turn the output off.
Conditions	Definitions
Valid Card	Access granted.
Invalid (Report Only) Card	Access denied: transaction message sent to Real Time List
ANY Invalid Card	Access denied: any or no message sent to computer.

Select **<none>** if this output point is controlled with a trigger event.

- 14. If you select any of the Pulse actions, you must enter the **Defined Pulse Period**.
- 15. Click OK to save your entries and return to the System Configuration window. After the output points are created, they can be grouped to perform common functions; see To Create Output Groups: on page 89 for detailed instructions.

On During Timezone (chone>
Uutput Action / Condition (chone>
Action / Condition (chone>
Defined Putse Period I Seconds
OK Cancel

-

•

Duration [

Partition Super User

Hardware Type Single Pole Relay

Output Name

Output Number

Query String

Active State Set

💌 🗆 Public

Enable

Report

C P900 Output

State Opti

- 3. If you use Partitioning, select the **Partition** that has access to this output point and click **Public** if you wish the output point to be visible to all partitions.
- 4. The **Hardware Type** field displays the *pole relay* output type. The number 1 output on a 4250 I/O module is the only Double Pole Relay output type; all others are Single Pole Relay type.
- 5. Enter a descriptive **Name** for the output point.
- 6. Click **Enable** if you wish to report all output point changes of state.
- 7. Select an **Output Number**. This number represents the physical connection to the I/O terminal.
- 8. Click **Report** if you wish to report output point changes of state to the Real Time List.
- From the Active State drop-down list, select Set to turn on the output point, or Timed to turn on the output point for the specified time entered in the Duration field.
- 10. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

P900 Soft Alarms

Soft alarm points and their addresses are created by the system during installation rather than hardwired to an actual input point. To open the Edit Soft Alarm dialog box, double-click the Soft Alarm icon that displays under the P900 panel name. The system automatically configures certain soft alarms for P900 panels and readers; for detailed descriptions, see Soft Alarms Field Definitions on page 101. The only item you are allowed to configure is the selection of the terminal associated with the soft alarm.

Configuring CLIC Components

Configurable Logical I/O Control (CLIC) components can be set up to program inputs and outputs of I/O modules to control and act in response to external equipment such as intruder alarms or lights, detectors connected to the system. Input/Output operations can be integrated with the access control so actions can be taken based on access transactions, system alarms, and time zones to make the external equipment behave in any way you want, according to what is happening in the rest of the system.

The execution of CLIC relies on the definition of one or more Trigger Events, which link *Sources* with *Conditions* and *Actions*. The Sources that can initiate a **Trigger Event** are the change of state of a time zone, an access transaction, a system alarm, the change of state of an input or input group, a **Counter** reaching a specified value, and a change of state of a **Flag**.

Once a Trigger Event is initiated, it tests the *Condition* of a time zone, the value of a Counter, and the state of up to two Flags. If the *Sources* of a Trigger Event become active and its *Conditions* are met, then it initiates an *Action* to change the state of any or all inputs, outputs, counters or flags, and optionally send a message to the system.

To use programmable I/O (CLIC), you must configure the following components:

- Counters
- Flags
- Trigger Events

P900 Counters

You can create up to 64 counters for each P900 panel. A counter reaching a specified value can be the source used to initiate a Trigger Event, and can increment or decrement each time a trigger occurs. A counter might be used, for instance, to count certain access transactions such as entries to a parking structure. The value of a counter can also be changed as part of the action of a trigger event. Counter values can be reset using the P900 Counter Control dialog box; see page 305.

To Create a P900 Counter:

- 1. Expand **P900 Panels**. All P900 panels currently configured in the system are listed.
- 2. Expand the panel where you wish to configure the CLIC components. All the items that can be configured for the panel are listed under it.
- 3. Expand CLIC. Select **P900 Counters** and click **Add**. The P900 Counters dialog box opens.

C P900 Counters		×
Partition	Super User	V Public
Panel Name	P900 on Lobby West	
Counter Name		🔽 Enable
Counter Number	3 💌	
Default Value	0 Report Cha	ange
Query String		
	IK Cancel	

24-10685-157 Rev. D

- If you use Partitioning, select the Partition that has access to this counter and click Public if you wish the counter to be visible to all partitions.
- 5. The **Panel Name** field displays the name of the panel selected.
- 6. Enter a **Counter Name** to describe the function of the counter.
- 7. Click **Enable** to allow the counter to change values.
- 8. Select a Counter Number.
- 9. Enter a **Default Value** for this counter. This is the value that the counter is set to when you reset the counter using the P900 Counter Control dialog box. Each counter can have any integer value from 0 to 65535.
- 10. Click **Report Change** if you wish to report counter changes to the Real Time List.
- The Query String value only applies if you have the P2000-Metasys integration feature. See Configuring Hardware Components for BACnet Interface on page 381.
- 12. Click **OK** to save your entries and return to the System Configuration window.

P900 Flags

You can create up to 64 flags for each P900 panel. Flags provide a means for passing conditions from one Trigger Event to another. A flag changing to a specified state can be the source used to initiate a Trigger Event. The state of a flag can be defined as **Set** (when the flag is active) or **Clear** (when the flag is inactive). You can also use the P900 Flag Control dialog box to manually change the current state of the selected flag.

To Create a P900 Flag:

1. Expand **P900 Panels**. All P900 panels currently configured in the system are listed.

- 2. Expand the panel where you wish to configure the CLIC components. All the items that can be configured for the panel are listed under it.
- Expand CLIC. Select P900 Flags and click Add. The P900 Flags dialog box opens.

C P900 Flags			×
Partition	Super User	•	Public
Panel Name	P900 on Lobby West		
Flag Name			🔽 Enable
Flag Number	3 💌	🔽 Report Chang	je
Default State	Clear	⊂ Set	
Query String			
	OK	Cancel	

- 4. If you use Partitioning, select the **Partition** that has access to this flag and click **Public** if you wish the flag to be visible to all partitions.
- 5. The **Panel Name** field displays the name of the panel selected.
- 6. Enter a **Flag Name** to describe the function of the flag.
- 7. Click **Enable** to allow the flag to change states.
- 8. Select a Flag Number.
- 9. Click **Report Change** if you wish to report flag state changes to the Real Time List.
- 10. Select the **Default State** for this flag. Click **Clear** if the flag's default state is always inactive, or **Set** if the flag's default state is always active.
- The Query String value only applies if you have the P2000-Metasys integration feature. See Configuring Hardware Components for BACnet Interface on page 381.
- 12. Click **OK** to save your entries and return to the System Configuration window.

P900 Trigger Events

You can create up to 128 trigger events for each P900 panel. Trigger events define actions that are performed when specified conditions are met. Each trigger event is made of the following elements: the Source, the Conditions, and the Actions. When the Source changes state and the Conditions are met, the Actions are performed. Trigger events can also be forced to immediately perform one of its actions by manually activating it using the P900 Event Control dialog box; see page 306.

To Create a P900 Trigger Event:

- 1. Expand **P900 Panels**. All P900 panels currently configured in the system are listed.
- 2. Expand the panel where you wish to configure the CLIC components. All the items that can be configured for the panel are listed under it.
- 3. Expand CLIC. Select **P900 Trigger Events** and click **Add**. The P900 Trigger Event dialog box opens.
- Enter the information in each field, as described in the P900 Trigger Event Field Definitions.
- 5. When all information is completed, click **OK** to save the trigger event and return to the System Configuration window.

P900 Trigger Event Field Definitions

General Tab

C P900 Trigger Event		
General Others		
Partition	Super User 💌	
Event Name		I✓ Enable
Query String		
Number	3 💌	Manual Control
Source Source Type	ANY Valid Access	 AND
Terminal	<ai> /</ai>	AND
Facility Code	Default Facility Code 💽 🗸	AND Badge Number
Access Group	<al></al>	AND <all></all>
Conditions Flag No. 1	<none></none>	State Clear
Flag No. 2	<none></none>	State Clear 💌
Counter	<none></none>	Value 📼 🔽 🛛
Timezone	<none></none>	State Inactive
Actions Type (room Flag No 1 (none) State Clear	Flag No 2 Flag No 2 State Clear Y	Type (none) V Counter (none) V Value V
		OK Cancel Apply

Partition – If you use Partitioning, select the **Partition** in which this trigger event is active.

Public – Click **Public** if you wish to allow all partitions to see this trigger event.

Event Name – Enter a descriptive name for the event.

Enable – Click to have the system process this trigger event. If you wish to temporarily disable the trigger event, click the check box again to disable it.

Query String – This value only applies if you have the P2000-Metasys integration feature. See Configuring Hardware Components for BACnet Interface on page 381.

Number – Select an event number. This number determines the order in which the trigger event is performed.

Manual Control – Select this check box if you wish to allow this trigger event to be manually initiated by an operator using the P900 Event Control dialog box; see page 306.

Source Box

Select the **Source Type** whose change of state starts the trigger event. Specific parameters must be defined for each Source Type selected. The following table describes all the possible sources types and corresponding parameters.

Source Type	Parameters			
ANY Valid Access Trigger event is initi- ated by a badge that is granted access.	Terminal – The trigger event is initiated by a badge read at the termi- nal selected here.	Facility Code – The trig- ger event is initiated by a badge whose facility code is selected here.	Access Group – The trigger event is initi- ated by any badge that belongs to the access group selected here.	Badge Number – The trigger event is initiated only by the badge number entered here.
ANY Invalid Access Trigger event is initi- ated by a badge whose code is read but no access is granted.	Terminal – The trigger event is initiated by a badge read at the termi- nal selected here.	Invalid Type – The trig- ger event is initiated by a badge that is denied access for the reason selected here.		
Input Point Trigger event is initi- ated by the change of state of a single input.	Input – The trigger event is initiated by the change of state of the input name selected here.	State – The trigger event is initiated when the input goes into the Alarm, Normal or Tam- per state.		
Input Group Trigger event is initi- ated by the change of state of an input group.	Name – The trigger event is initiated by the change of state of the input group name selected here.	Logic – Select OR if the input group becomes active when one or more inputs are in the State selected, or select AND if the input group becomes active when all the inputs are in the State selected.	State – The trigger event is initiated when the input group goes into the <i>Clear</i> or <i>Set</i> state.	
Time Zone Trigger event is initi- ated by the change of state of a Time Zone.	Name – The trigger event is initiated by the change of state of the time zone selected here.	State – The trigger event is initiated when the time zone becomes <i>Active</i> or <i>Inactive</i> .		
Flag Trigger event is initi- ated by the change of state of a Flag.	Name – The trigger event is initiated by the change of state of the flag selected here.	State – The trigger event is initiated when the flag goes into the Set or Clear state.		
Counter Trigger event is initi- ated by the change of value of a Counter.	Name – The trigger event is initiated by the change of value of the counter selected here.	Value – Select whether the trigger event is initi- ated when the counter becomes equal to (=), greater than (>), or less than (<) the value (0 and 65535) entered here.		
System Alarms Trigger event is initi- ated by an alarm condition.	Sub Type – Select the type of alarm: Controller Power, Controller Tam- per, Terminal Open or Forced, Duress Entry or Polling Detected.	State – The trigger event is initiated when the alarm becomes active (<i>Alarm</i>) or when it becomes inactive (<i>Nor-</i> <i>mal</i>).	Terminal – The trig- ger event is initiated by an alarm gener- ated at the terminal selected here.	

Conditions Box

The trigger event can test the conditions of two flags, one counter, and one time zone. If you leave all the conditions set to **<none>**, then none is tested and the trigger event automatically proceeds to the Actions state.

Flag No. 1 – To test the condition of a flag, select the flag name that the trigger event uses.

State – Select whether the flag should be **Clear** or **Set** for the condition to be true.

Flag No. 2 – To test the condition of a second flag, select the flag name that the trigger event uses.

State – Select whether the second flag should be **Clear** or **Set** for the condition to be true.

Counter – To test the value of a counter, select the counter name that the trigger event uses.

Value – Select whether the value of the counter is equal to (=), greater than (>), or less than (<) the value entered in the next field, for the condition to be true.

Timezone – To test the state of a Time Zone, select the time zone that the trigger event uses.

State – Select whether the Time Zone should be **Active** or **Inactive** for the condition to be true.

Actions Box

Define the actions that are performed by the trigger event based on the sources and conditions selected.

Input Type – A trigger event can disable, enable, or shunt an input or an input group. When an input or input group is enabled, its state is being monitored. When an input or input group is disabled or shunted, its state is ignored. Select one of the following input action types: Enable Input, Disable Input, Shunt Input, Enable Input Group, Disable Input Group, or Shunt Input Group. **Name** – Select the input or input group name that can be enabled, disabled, or shunted.

Input Period – If you select the Shunt Input or Shunt Input Group, select a shunt time in the Input Period field, enter the number, then on the next field select minutes, seconds or milliseconds.

Output Type – A trigger event can turn on, turn off, or pulse (temporarily turn on) an output or an output group. Select one of the following output action types: Output On, Output Off, Output Pulse, Output Group On, Output Group Off, or Output Group Pulse.

Name – Select the output or output group name that can be turned on, turned off, or pulsed.

Output Period – If you select to pulse the output or output group, select a pulse time in the Output Period field, enter the number, then on the next field select minutes, seconds or milliseconds.

Flag No 1 – If you wish the trigger event to set, clear or pulse a flag, select the flag name and select whether the trigger event can **Clear**, **Set** or **Pulse** the flag. If you select to Pulse the flag, you must also enter a pulse time.

Flag No 2 – If you wish the trigger event to set, clear or pulse a second flag, select the flag name and select whether the trigger event can **Clear, Set** or **Pulse** the second flag. If you select to Pulse the flag, you must also enter a pulse time.

Counter – If you wish the trigger event to increment, decrement or set the value of a counter, select the counter name and select whether the counter adds 1 (+), subtracts 1 (-), or sets the counter (=), to the value (0 to 65535) entered in the next field.

Others Tab

C P9	000 Trigger Event				X
Ger	neral Others				
	Message				
	Me	essage Priority	<none></none>]
	F	Report card at	<none></none>	<u>•</u>]

Message Priority – Select **Report** from the drop-down to send a trigger event activation message to the Real Time List. Select **<none>** if you do not wish to send messages of this type.

Report card at – If you select to Report trigger event activation messages to the Real Time List and wish to include a card number as part of the message, select the terminal name where the valid card is read. If you select **<none>** the card number in the message is always 0.

P900 Trigger Links

The P900 Trigger Links function enables you to program a trigger event in one panel to initiate a trigger event in another panel, as along as the **Message Priority** of the first trigger event is set to **Report**. When the *Source* of the originating trigger event changes state and the *Conditions* are met, the destination trigger event's Conditions are tested and, if met, its *Actions* are performed.

To Configure P900 Trigger Links:

- 1. Expand **P900 Panels** to open the P900 components.
- Select Trigger Link and click Add. The P900 Trigger Links dialog box opens.

C P900 Trigger Links		×
Partition	Super User 💌 🗖 Public	
Name	Enable	
Query String		
Source		
Panel		
Trigger Event		
Destination		
Panel	_	
Trigger Event		
OK	Cancel	

- If you use Partitioning, select the Partition that has access to this trigger link and click Public if you wish the trigger link to be visible to all partitions.
- 4. Enter a **Name** to describe the function of the link.
- 5. Click **Enable** to allow the system to perform the trigger link between the selected panels.
- The Query String value only applies if you have the P2000-Metasys integration feature. See Configuring Hardware Components for BACnet Interface on page 381.
- 7. Select the source Panel.
- 8. Select the source **Trigger Event**. The list displays all trigger events configured for the panel selected.
- 9. Select the destination Panel.
- 10. Select the destination **Trigger Event**. The list displays all trigger events configured for the panel selected.
- 11. Click **OK** to save your entries and return to the System Configuration window.

Note: If the trigger link does not work, make sure the **Message Priority** of the source trigger event is set to **Report**.

Configure OSI Panels and Components

IMPORTANT: This release of the P2000 software is compatible with Stanley® Wi-Q[™] Version 3.00.38, Portal Firmware Version 3.0.17.155, and Reader Version 3.00.039. Older versions of the OSI software are not compatible with this P2000 release.

Use this section to configure your P2000 system to communicate with OSI Wireless Access Management Solutions (WAMS) hardware. It is assumed that the OSI hardware is already installed before you can configure and use the essential functions described in this section. Refer to the OSI documentation for hardware installation instructions and to the *P2000 Software Installation Manual* for instructions associated with the installation of the OSI Interface software.

IMPORTANT: The installation of the Stanley Wi-Q software must follow some specific instructions. Contact Technical Support for detailed instructions.

The OSI Interface that resides on the P2000 Server is called P2000 OSI Interface Service, and provides an interface between the P2000 system and Stanley OSI OMNILOCK® 2000 Series readers. This integration allows P2000 operators to configure and control OSI readers to provide badge access. Transactions and alarm messages associated with these readers are sent to the Alarm Monitor and the Real Time List.

The OSI hardware consists of a Portal Gateway that provides wireless communications to the individual readers.

The portal gateway communicates with the P2000 Server via standard 10/100Base-T Ethernet connectors. The transmit range from portal gateway to reader is typically 150 to 300 feet. Each portal gateway supports up to 128 readers. The wireless reader performs the actual access validation and can support up to 65,000 badges. The OSI interface has no hard limit on the number of portal gateways but enforces the existing P2000 limits on the number of readers.

The portal gateway includes a built-in Web server that provides a simple easy-to-use user interface for configuring the portal, monitoring the status of the portal, and updating the firmware loaded into the portal and the readers.

Unsupported OSI Features

The following OSI system features are not compatible with the P2000 system architecture:

- Access and Shunt Time per Badge
- PIN Expiration Dates
- Unlock with ID access mode
- OSI I/O modules

Unsupported P2000 Features

The following P2000 system features are not supported by the OSI system:

- Extensive badge specific time-controlled access rights (see Badge Access Rights on page 122 for more information)
- Quick detection of hardware offline

System Architecture

The communication to the OSI portal gateway is performed by the OSI Web Service, which is installed with the OSI Interface. The portal gateway in turn provides the wireless communication path to the individual OSI readers. The OSI Web Service runs in the context of the Microsoft Internet Information Services (IIS) Web server, sends data and commands to the readers, and receives transaction data from the readers. The OSI Web Service reads and writes data to the OSI WAMS database that is hosted in the same SQL Server as the P2000 system. The P2000 OSI Interface Service provides the interface between the P2000 system and the OSI system. The OSI Interface Service performs all of its functions by calling functions in the Stanley Wi-Q Version 3.x SDK. All other major principles of the P2000 architecture remain the same.

Hardware Detection

The OSI system provides automatic hardware detection. When new portal gateways or readers are added to the system, they are detected by the OSI Web Service and the appropriate record is created in the WAMS database. The P2000 OSI Interface Service periodically scans for these new items. When a new item is found, the appropriate record is created in the P2000 database.

This automatic hardware detection also affects long term operation. If an OSI reader is unable to communicate with its portal gateway for a period of about 30 minutes or more, it attempts to connect to any other portal gateway within wireless range. This provides communication redundancy if a reader is within communication range of multiple portal gateways. Since the P2000 software maintains a relationship between panels and terminals (and displays this relationship in several different locations), it must update the database when a reader switches to a new portal gateway. The P2000 OSI Interface Service detects this condition and updates the database as required.

Since the terminal record is only updated and not recreated, any links between terminals and other items remain unchanged. The only impact is for partitioned P2000 systems. Since by definition the terminal belongs to the same partition as its panel, moving a terminal to a different panel may require the partition of the terminal to change. In practice, this is usually not a problem since P2000 partitions usually correspond to some physical barrier or separation such as different buildings or different areas of the same building.



In most cases the physical separation between these areas prevents readers from communicating with portals in other partitions.

Badge Access Rights

The P2000 software defines access rights for individual badges through multiple pairs of Access Groups and Timezones. OSI readers do not support this model of badge access rights. The OSI model consists of a list of readers that a badge has rights to use at any time in combination with membership in up to 32 User Groups. Since the P2000 system operates with a set of badge access rights across multiple types of controllers and readers, the P2000 OSI Facility Edit application is provided to configure these settings.

Using the OSI Facility Edit application, a P2000 operator can configure up to 32 pairs of Access Groups and Timezones as Facility Access Groups. These Facility Access Group pairs correspond to OSI User Groups. When Access Groups and Timezone pairs are assigned to an individual badge (using the Badge application), the Timezone values are ignored unless the Access Group has been configured as an OSI Facility Access Group. If the Access Group corresponds to an existing OSI Facility Access Group, then the Timezone configured for the Facility Access Group defines the time when access is allowed. If the Access Group is not defined as a Facility Access Group, then the badge is granted access on a 24/7 basis.

Configuration Sequence

Once the hardware is installed, we recommend the following configuration sequence:

- Configure OSI Facility parameters.
- Establish network connections between OSI hardware devices and the P2000 Server

- Configure the portal gateways
- Configure readers

Configure OSI Facility Parameters

Before bringing any OSI hardware online, the OSI Facility record must be added to the P2000 database. The OSI Facility record defines settings that control all OSI portal gateways and wireless readers connected to a single P2000 server.

To Configure OSI Facility Parameters:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand **OSI Panels** to open the OSI components.

Note: If the **OSI Panels** branch does not display, you need to enable the **OSI** panel type in the Panel Types tab of Site Parameters. This should only be necessary if you have upgraded from a previous version of the P2000 software.

- 4. Select **OSI Facility** and click **Add**. The OSI Facility Edit dialog box opens at the General tab.
- Fill in the information on each tab according to the following OSI Facility Field Definitions.
- 6. As you work through the tabs, you may click **Apply** at any time to save your entries.
- 7. After you have entered all the information, click **OK** to save the settings and return to the System Configuration window.

123

Once the OSI Facility record is saved, it is written in the OSI system. At that point, the system automatically recognizes the new hardware when it is activated, as well as automatically adds it to the P2000 database.

OSI Facility Field Definitions

General Tab

Use this tab to define general descriptive information of the OSI Facility record and the access parameters associated with the readers.

🖸 OSI Facility Edit 🛛 🗙
General Badges Magnetic Stripe Time Access Groups
Name P2000
Sign On Key 203061
Database Name WAMS
Keypad Credential Length 4
PIN Length 4
Manager Flag <none></none>
Programmer Flag <none></none>
Extended Access Flag <none></none>
Extended Access Time reader default
Extended Shunt Time reader default
OK Cancel Apply

Name – Enter the name of the OSI Facility record. This field displays **P2000** by default, but you can change the name according to your facility needs.

Sign On Key – This is a six-digit number that is automatically assigned to each OSI Facility record. If your facility uses OSI readers with keypads, you need to enter this number at each wireless reader to establish connection between the readers and the portal gateways, and ultimately to establish the communication with the WAMS software. **Database Name** – This field displays the name of the OSI database.

Keypad Credential Length – Enter the number of digits that cardholders need to enter at wireless keypad readers in your facility.

PIN Length – For facilities that require additional security, enter the number of PIN code digits that cardholders need to enter at wireless keypad readers in your facility. OSI supports PIN codes ranging from 3 to 6 digits.

Manager Flag – Select one of the three special access flags to be assigned to users with Manager privileges who require special access at a reader.

Note: Special access allows a door's access time to be different. The list displays the special access flag names as configured in Site Parameters; see page 35.

Programmer Flag – Select one of the three special access flags to be assigned to users with Programmer privileges who require special access at a reader.

Extended Access Flag – Select one of the three special access flags to be assigned to users with Extended Access privileges who require special access at a reader.

Note: Manager, Programmer, and Extended Access privileges are assigned using the OSI software.

Extended Access Time – Select the amount of time that the door remains unlocked to provide extended access time to cardholders with special needs.

Extended Shunt Time – Select the amount of time that the door alarm is suppressed to allow access to cardholders with special needs. The Extended Shunt Time must exceed the Extended Access Time.

Note: The **reader default** option in the Extended Access Time and the Extended Shunt Time is the time defined at the Access tab of the OSI Terminal Edit dialog box; see page 131 for details.

Badges Tab

Use this tab to define the badge formats and type that can be used at all OSI readers. In addition, if the OSI readers do not have keypads, you need to enter the Reader Sign On Badge information to be used at your facility.

C OSI Facility Edit
General Badges Magnetic Stripe Time Access Groups
Primary Badge Format Cardkey 34 bit
Vise Secondary Badge Format
Secondary Badge Format Corporate 1000
Badge Type Prox Badge
Create Keypad Credential
Reader Sign On Badge
Number 3737
Issue 0
Fadity Code 0
OK Cancel Apply

Primary Badge Format – Click the [...] button and select the primary badge format to be used at your facility. The P2000 software provides badge formats that are located in the \Program Files\Johnson Controls\P2000\BadgeFormats folder. If a different format is needed, create a new badge format file by using the P2000 Badge Format tool; see page 212 for details. **Note:** On upgraded systems, badge formats are located in \Program Files\Johnson Controls\ CARDKEY P2000\BadgeFormats. On 64-bit Windows operating systems use \Program Files (x86)\Johnson Controls\P2000\BadgeFormats.

Use Secondary Badge Format – Click if your facility uses a secondary badge format.

Secondary Badge Format – Click the [...] button and select the secondary badge format to be used at your facility.

Badge Type – Select the badge type to be used at your facility. Options are: **Prox Badge**, **Mag Stripe Badge**, and **Smart Card Badge**.

Create Keypad Credential – Keypad Credential numbers are codes stored in every badge and allow you to identify the badges that belong to your facility. Click if you wish to automatically assign these codes to all badges in your facility that can be used with OSI wireless readers.

Reader Sign On Badge

If your facility uses OSI readers with no keypads, you can create a master badge that can be assigned with a facility number. This badge can be used to establish communication between the readers and the software.

Number – Enter a badge number that can be used for the facility number. This badge number does not need to be a valid P2000 badge assigned to a cardholder.

Issue – Select the issue level from 0 to 255 to use for the facility number.

Facility Code – Enter the facility code number to use for the facility.
Magnetic Stripe Tab

If your facility uses Magnetic Stripe cards, use this tab to configure the software to accept the card types and settings. Default settings are sufficient for most systems.

C OSI Facility Edit		X
General Badges Ma	agnetic Stripe Time Ac	cess Groups
	Card Tra	ack Track 2 💌
	Card Track Li	mit 26
	Expiration Date Form	nat DDMMYY
	Expiration Date Posit	ion 1
	Expiration Date Position Ty	pe Unused 💌
	Expiration Date Va	alid Thru Expiration Date
	Facility Co	de
	Facility Code Posit	ion 1
	Facility Code Position Ty	pe Unused 🔽
	Issue Number Posit	ion 1
	Issue Number Position Ty	pe Unused 💌
	ID Posit	ion 1
	ID Position Ty	pe Character 💌
	Г	OK Cancel Apply

Card Track – Select **Track 2** or **Track 3** magnetic cards. The system can be used with either Track 2 or 3 cards; however, you cannot use both types within the same facility. Most users use Track 2 cards and do not need to set up any type of advanced card parameters.

Card Track Limit – There is a limitation on the number of characters for each track. These characters include any digits and field separators; however, they exclude the starting and ending sentinels. The maximum number of characters that the system can read on Track 2 is **26** characters; Track 3 can read up to **70** characters. The P2000 software does not enforce these limits.

Expiration Date Format – Select the card expiration date format.

Expiration Date Position – Enter the position in the card of the expiration date field.

Expiration Date Position Type – Select if the position type is a **Character**, a **Field**, or **Unused**.

Expiration Date Valid – Select if the expiration date is valid **Thru Expiration Date** (includes the day of expiration), or **To Expiration Date** (expires at midnight the previous day).

Facility Code – Enter the facility code number to assign to your cards.

Facility Code Position – Enter the position in the card of the facility code field.

Facility Code Position Type – Select if the position type is a Character, a Field, or Unused.

Issue Number Position – Enter the position in the card of the issue number field.

Issue Number Position Type – Select if the position type is a **Character**, a **Field**, or **Unused**.

ID Position – Enter the position in the card of the ID field.

ID Position Type – Select if the position type is a **Character**, a **Field**, or **Unused**.

Time Tab

Use this tab to adjust Daylight Savings Time (DST) settings according to your region. DST varies from country to country. Some countries may not observe DST, while in many other countries the start dates and end dates for DST change from year to year.

C OSI Facility Edit			×
General Badges Magnetic Stripe Time	Access Groups		
Daylight Savings Type	North America		•
Fall Back Month	November		~
Fall Back Sunday	First Sunday		~
Spring Forward Month	March		7
Spring Forward Sunday	Second Sunda	lγ	7
	ОК	Cancel	Apply

Daylight Savings Type – Select the daylight savings type that applies to your region. Choices are Custom, Europe, North America, and Southern Hemisphere. When you select Europe, North America or Southern Hemisphere, the system uses the standard Daylight Savings Time settings for the selected region.

If you wish to change the default settings, select **Custom** from the Daylight Savings Type drop-down list and select:

- the Fall Back Month
- the Fall Back Sunday
- the Spring Forward Month
- the Spring Forward Sunday

Access Groups Tab

Use this tab to define up to 32 Access Groups and corresponding Timezones that can be assigned to all badges that are used at OSI readers. You must create Access Groups (page 247) and Time Zones (page 49) before the selections display in the drop-down lists.

Number	Access Group	Timezone	<u>▲</u>	
1	Daily Access	Full Time		
2	<none></none>	<none></none>		
3	<none></none>	<none></none>		
4	<none></none>	<none></none>		Edit
5	<none></none>	<none></none>		
5	<none></none>	<none></none>		Delete
7	<none></none>	<none></none>		
3	<none></none>	<none></none>		
9	<none></none>	<none></none>		
10	<none></none>	<none></none>		
11	<none></none>	<none></none>		
12	<none></none>	<none></none>		
13	<none></none>	<none></none>		
14	<none></none>	<none></none>		
15	<none></none>	<none></none>		
16	ZhoneN	Zoonell	<u> </u>	

To Define OSI Facility Access Groups:

1. In the Access Groups tab, double-click the line item you wish to define. The Group Edit dialog box opens.

Group Edit		×
	Number	1
	Access Group	Daily Access
	Timezone	Full Time
	ОК	Cancel

The **Number** field displays a number that indicates the order in which the access group will be downloaded to the panels.

- 2. Select the Access Group you wish to assign to the badges that are used at OSI readers.
- 3. Select the **Timezone** to assign to the selected Access Group.
- 4. Click **OK** to save your settings.
- 5. If you wish to remove a group from the list, select the line item and click **Delete**.

Adding New Portals

To add OSI hardware devices into the P2000 database, you must first establish the communication between the OSI portals and the software. Each portal gateway must be configured with its assigned IP address, the name of the P2000 Server, and the name and description of the OSI portal. The portal gateways use the Stanley Wi-Q Access Management Software (AMS) Configurator that allows you to configure these settings.

Note: Make sure you have followed the specific instructions from Technical Support to install the Stanley Wi-Q software.

To Set Up the Portal Gateway:

- From you Windows desktop, double-click Stanley Wi-Q Access Management Software. The Configurator window opens.
- 2. Click the **Portals** tab.

A SECOND REPORT OF LODIER AND A SECOND	Charge C. R. Heart		4.1
As segment portais as readers	Interesties Er Osers Orennare		
E- C P2000	24 🖴		
See Portal 117	🗄 (Address)		
COLECTED Both	MAC Address	Waiting for Sync	
	Workstation	SVSWL8-52052	
	E (Name)		
	Portal Name	OSI P2000 Portal	
	Description	West Facility	
	🗄 (Portal Connection)		
	IP Address	192.168.5.168	
	Port	8000	
	E Configuration		
	Statistics Update Interval	1 Days	
	Assigned to Channels	ALL CHANNELS	
	Uploaded Transactions		
	Transaction Settings	Transaction Masks	

3. Click **Add**. The Configure New Portal Gateway dialog box opens.

onfigure New Pa	rtal Gateway
MAC Address:	Waiting for Sync
Facility:	P2000
Workstation	*** Not Assigned ***
Name:	
Description:	
IP Address:	192.168. 1 .168
Port:	8000
Channels:	ALL CHANNELS
Update Interval:	1 Days
Transactions:	Transaction Masks
SSL Certificate:	
	Cancel Finish

- 4. From the **Workstation** drop-down list, select the name of the P2000 server.
- 5. Enter the portal **Name** and **Description** of the OSI portal.
- 6. Enter the portal's **IP Address**.

- 7. Keep the values of the remaining fields at their default setting.
- 8. Click **Finish**. The new portal appears in the tree.

Shortly after, the portal is added to the P2000 system as a new OSI panel. Edit the panel record in the P2000 software as desired.

To Set Up OSI Readers

- 1. Power up the new OSI reader.
- 2. Press and hold the reset button on the back of the reader (next to the batteries). The green LED flashes followed by the red LED.
- When the green LED flashes again, enter 5678 followed by the Sign On Key from the P2000 OSI Facility record, see the General Tab on page 123.
- 4. Shortly after, the reader appears in the AMS Configurator and then in the P2000 system as a new OSI terminal. Edit the terminal record in the P2000 software as desired.

Configure OSI Panels

Once the portal gateway is set up and configured through the OSI Web Interface to establish the connection to the P2000 Server, the portal displays in the System Configuration window under the OSI Panels root icon. By default, portal names include their MAC address. You must now complete the configuration of the portal.

To Configure OSI Panels:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand **OSI Panels** to open the OSI components.
- 4. Select the portal you wish to configure and click **Edit**. The OSI Panel Edit dialog box opens.

C OSI Panel Edit				_ 🗆 🗙
Partition	Super User		Public	
Name	Software Lab Port	al	🔽 Enabled	
Query String				
Mac Address	0014f5000bf6			
Channels				
11	L 15	L 19	23	
□ 12	☐ 16	□ 20	24	
L 13	17	21	25	
14	18	22	26	
	Reboot			
	ОК	Cancel		

- If you use Partitioning, select the Partition that has access to this panel, and Click Public if you wish to allow all partitions to see the panel.
- 6. Enter a descriptive **Name** for the panel. By default the Name field displays the MAC address of the portal but you can change the name according to your facility needs.
- 7. Click Enabled so the panel can be recognized by the system. If you wish to temporarily disable the panel, without having to delete the panel, click the check box again to disable it. When you disable a panel, the readers continue to grant access, but the panel does not communicate with the Server until you enable the panel again.

- 8. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see page 381).
- 9. The **Mac Address** field displays the Media Access Control address automatically assigned to the portal.
- 10. Select from the **Channels** box, the Radio Frequency (RF) channels or frequency bands that this panel uses to communicate with the readers.
- 11. The **Reboot** button is provided to restart the portal; for example, if the portal is not responding or to recover from an error.
- 12. Click OK to save your entries.

After you create the OSI panel, the system automatically creates a *Panel Down* soft input point for input point 25 and displays it under the **Soft Input Points** icon. If you wish to report this type of alarm, edit the input point and make sure the **Disable Alarm** option is not selected in the General tab of Alarm Options, otherwise the alarm does not report to the Alarm Queue, but continues to report to the Real Time List (see Alarm Options Tab on page 91).

Configure OSI Terminals

After a portal is up and functional, you can add new readers to the system. A new reader needs to be *enrolled* into the OSI system to become functional. The enrollment process is different for readers that have keypads and readers that do not. **Readers with Keypads** – For a reader with a keypad, you must enter the Sign On Key from the P2000 OSI Facility record into the keypad; see page 123. To place the reader into enrollment mode, enter **5678** on the keypad. A green light on the reader flashes three times. Within five to six seconds, enter the six-digit Sign On Key from the OSI Facility record. The reader goes through a sequence of alternating red and green lights and should finish with three green flashes. That means the reader successfully communicated with the portal.

Readers without Keypads – For a reader without a keypad, the reader is placed into enrollment mode by presenting the default badge that was included in your package from OSI. Within five to six seconds, present the badge that was defined in the Reader Sign On Badge box of the OSI Facility record; see page 124. The reader goes through a sequence of alternating red and green lights and should finish with three green flashes. That means the reader successfully communicated with the portal.

After a successful sign on, the reader should be detected and automatically added to the P2000 database as a new terminal. Note that the Real Time List displays messages associated with the new OSI components.

Each reader installed in your system must be set up and configured in the P2000 software to establish communication and control. Once Terminals are configured, they may be included in Terminal Groups to provide common access throughout your facility.

To Create OSI Terminals:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **OSI Panels**. All OSI portals currently configured in the system are listed.

- 3. Expand the portal that contains the readers you wish to configure.
- 4. Expand **Terminals** to display the readers that were successfully enrolled. By default, the reader names include their MAC address.
- 5. Select the reader you wish to configure and click Edit. The OSI Terminal Edit dialog box opens at the General tab. Enter the information in each tab according to your system requirements. See the following OSI Terminal Field Definitions for detailed information.
- 6. As you work through the tabs, you may click **Apply** to save your settings.
- 7. When all entries are complete, click **OK** to save your settings and return to the System Configuration window.
- If you wish to group OSI terminals that provide common access, see Create Terminal Groups on page 85 for detailed instructions.

After you create the OSI reader terminal, the system automatically creates three soft input points: Low Battery, Tamper, and Term Down. These input points display under the Input **Points** icon as *Low Battery* <*reader name*>. Tamper <reader name>, and Term Down <reader name>. If you wish to report the associated alarms, edit the input point and make sure the Disable Alarm option is not selected in the General tab of Alarm Options, otherwise the alarm does not report to the Alarm Queue, but continues to report to the Real Time List (see Alarm Options Tab on page 91). Also, if you rename the reader, you must edit the input point to manually enter the new reader name, as in Term Down <reader name>.

Note: The Tamper alarm for OSI soft input points is generated after five consecutive invalid credential attempts.

OSI Terminal Field Definitions

General Tab

Use this tab to enter general descriptive information of the OSI reader.

C OSI Terminal Edit				×
General Access Time	zone Reboot			
Name	Back Door	Back Door		
Pane	Software Lat	o Portal		
Query String	ə 📃			
Mac Address	; 0014f50001:	2c		
🔽 Enable		Pu	ı <u>b</u> lic	
Door Ser	nsors			
Channels				1
□ 11	15	L 19	23	
1 2	1 6	2 0	24	
1 3	17	21	25	
14	1 8	22	26	
		ОК	Cancel	Apply

Name – Enter a descriptive Name for the terminal. By default the Name field displays the MAC address of the reader but you can change the name according to your facility needs.

Panel – This field displays the name of the portal you selected from the System Configuration window, which provides the wireless communication to the reader.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Mac Address – This field displays the Media Access Control address automatically assigned to the reader.

Enable – Click if you wish the system to recognize this terminal.

Public – If you use Partitioning, click if you wish this terminal to be visible to all partitions.

Door Sensors – Click if your reader has the optional Door Sense Module for monitoring of the actual strike status.

Channels – Click the Radio Frequency (RF) channels or frequency bands that this terminal uses to communicate with the readers.

Access Tab

This tab defines the OSI reader's time parameters.

C OSI Term	inal Edit				×
General A	cess Timezone	Reboot			
	Acces: Shunt	Time <mark>3 se</mark> Time 10 s	conds 💽		
Sta	atistics Update In	terval Rea	der Default 💌		
			ОК	Cancel	Apply

Access Time – Select the amount of time that the door remains unlocked to provide access.

Shunt Time – Select the amount of time that the door alarm is suppressed to allow access at the door. The Shunt Time should be longer than the Access Time.

Statistics Update Interval – Select the frequency at which the reader sends messages to the portal gateway with signal strength, battery voltage, external supply voltage and packet transfer ratio information.

Note: The smaller the interval, the greater the battery use. For a high volume area, you may want to keep the interval time at 1 minute to ensure adequate coverage. (You need to monitor battery use to ensure adequate power supply.) However, for little used areas, you can set the update interval up to 24 hours to preserve battery life.

Timezone Tab

The Timezone tab defines the time zones in which the OSI reader operates. Time Zones must be set up before they display in drop-down lists.

C OSI Terminal Edit			
General Access Timezone Reb	oot		
Badge Required	<none -="" 24="" enable="" hour=""></none>		
Override	<none></none>	•	
PIN Required	<none></none>	-	
	ОК	Cancel	Apply

Badge Required – Select the time zone during which the reader requires a badge to allow access. If you do not wish to enable this function, select **<none - 24 hour enable>** to allow access at all times.

Override – Select a time zone during which the reader does not require a badge to open the door.

PIN Required – Select a time zone during which cardholders are required to enter a PIN number.

Note: If the **Badge Required** time zone selected for the OSI terminal is inactive, but the **PIN Required** time zone is active, then the OSI terminal grants access to a valid cardholder.

Reboot Tab

At times it may be necessary to use this tab to reset the reader. This could typically happen only if you were to take the reader offline, for example to change batteries.

🖸 OSI Termir	nal Edit				×
General Acc	ess Timezone	Reboot			
	Reboot				
Re	boot and Clear E)B			
			ОК	Cancel	Apply

Reboot – Click to reset the reader.

Reboot and Clear DB – Click to reset the reader and temporarily clear current reader data. After you perform this command, you must reset the OSI terminal using the instructions provided on To Set Up OSI Readers on page 128.

Note: After you click one of the previous buttons, a Reader Cleared message displays in the Real Time List. The total time for these operations to complete and the time it takes for the corresponding message to display in the Real Time List varies due to the wireless nature of the system.

Viewing OSI Wireless Devices Status

The System Status window displays the current status of all OSI devices that have been configured in the system. It also allows you to view portal and reader values related to the wireless signal they receive.

See Viewing System Status on page 473 for instructions on how to display the status of OSI devices.

Configure S321-IP Panels and Components

Use this section to configure your P2000 system to communicate with S321-IP panels. S321-IP panels communicate with the P2000 Server using a standard TCP/IP network protocol to provide badge access, alarm monitoring, history reporting, input/output linking, and card and system activated events.

The S321-IP is an advanced, intelligent, network panel capable of monitoring and controlling one or two fully configured doors. The S321-IP panel provides the ability to configure supervised 4-state inputs and unsupervised 2-state inputs. When interfacing to a single door, you can configure the unused points as general purpose input/output points.

It is assumed that the S321-IP hardware is already connected to the P2000 Server before you can configure and use the functions described in this section. Refer to the S321-IP *Network Controller Hardware Installation Manual* for hardware installation instructions.

S321-IP Naming Conventions

S321-IP panel components are named using a consistent naming scheme. Terminals, input, and output point are automatically allocated an identifying name. This name consists of a fixed description of the item (such as Term 1 for terminals or Panel Battery for inputs), plus the panel name. In the case of terminal input and output points, the name of the terminal is also appended to the input and output names, so that an input point for example, is recognized by its panel and terminal name.

You should logically name S321-IP panels, including information such as a panel's location or what it controls, but bear in mind that the maximum number of characters allowed in an S321-IP component name is 32. When you use long panel names, you need to remember that a terminal input point name is <input name> <terminal name> <panel name> and therefore, that combination should not exceed 32 characters. If the combination does exceed 32 characters the resulting name is truncated to 32 characters.

IMPORTANT: Although the P2000 system allows S321-IP component names to have up to 32 characters, the S321-IP panel user interface only supports names of up to 16 bytes long.

Configure S321-IP Panels

To enable communication between the S321-IP panel and the P2000 Server, you have to configure the connection at both sides. First, you need to define the P2000 Server at the S321-IP panel, and then you need to enter the S321-IP information in the P2000 S321-IP Panel Edit dialog box.

Note: You must generate a Certificate using the S321-IP user interface to enable encrypted communications between the P2000 Server and the S321-IP panel.

Refer to the *S321-IP Configuration and Operation Manual* to prepare the S321-IP panel for integration with the P2000 system.

Note: Because of S321-IP requirements, there must be at least one time zone available before creating or editing an S321-IP panel.

To Configure S321-IP Panels:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Select **S321-IP Panels** and click **Add**. The S321-IP Panel Edit dialog box opens.
- Fill in the information on each tab. (See S321-IP Panel Field Definitions for details.)
- 5. As you work through the tabs, you may click **Apply** to save your entries.
- Click OK to save the panel information. A message box displays asking if you wish to automatically add all time zones to the new panel. If you select No, you can add the time zones later; see Configure Panel Time Zones on page 66.
- If you select Yes, the time zones are automatically added. When you return to the System Configuration window, a new S321-IP Panel icon bearing the name assigned displays under the root S321-IP Panels.

Note: In addition to applying time zones to the panels (described in Configure Panel Time Zones on page 66), you may also define panel holidays if you wish to restrict access in your facility during a holiday period; see Configure Panel Holidays on page 67.

S321-IP Panel Field Definitions

General Tab

C 5321-IP Panel Edit	×
General Address Other	
Partition	Super User
Name	Main Lobby
Version	v2.9+
	Enabled
Query String	
	Enable Panel Inputs
	Enable Encryption
	Reboot
	OK Cancel Apply

Partition – If you use Partitioning, select the Partition that has access to this panel.

Public – If you use Partitioning, click Public to allow all partitions to see this panel.

Name – Enter a descriptive Name for the panel. See S321-IP Naming Conventions on page 133 for more information.

Version – Select the firmware version of the S321-IP panel. Certain features are enabled or disabled depending on the panel version selected.

Note: If you upgrade the panel firmware, you must edit the version field to match the updated panel's firmware. If the versions do not match, the panel is put into a misconfigured state and is not allowed to fully communicate until the problem is resolved.

Enabled – The system does not recognize the panel unless you click Enabled. If you wish to temporarily disable the panel, without having to delete the panel, click the check box again to disable it. When you disable a panel, the readers continue to grant access, but the panel does not communicate with the Server until you enable the panel again.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Enable Panel Inputs – Click to create two panel soft input points: Panel Tamper and Power Failure.

Enable Encryption – Click to allow encryption of all messaging between S321-IP panels and the P2000 Server.

Note: To use encrypted communications, you must also configure the SSL settings at the S321-IP panel.

Note: You must disable the **Enable Encryp**tion option when performing the S321-IP firmware upgrade process. After the panel is updated, you can enable the encryption option again.

Reboot – Click to reboot the S321-IP panel. The Reboot button is provided to force the panel to restart, for example in cases when the panel is not functioning properly. This feature is available after you save the panel information.

Address Tab

				-	
Fived IP Address					
200 . 0 .	0.)			
MAC Address					
123456668976					
anel Communications Paramet	ers				
Heartbeat Transmit Interval	Hours	; Min	utes	Seconds	
		0	1	0	
Host No Reception Timeout					
Host No Reception Timeout		0	2	30	
Host No Reception Timeout		•	2	30	
Host No Reception Timeout		0	2	30	
Host No Reception Timeout		0	2	30	
Host No Reception Timeout		0	2	30	

Name for DNS Address Resolution – Click and enter the name assigned to the S321-IP panel. This name is used to communicate with the panel instead of the IP address if the Domain Name Server (DNS) is present on the network. This field must exactly match the S321-IP name defined using the S321-IP panel user interface.

Fixed IP Address – If your facility uses fixed IP addresses, click and enter the IP address assigned to the S321-IP panel.

MAC Address – Enter the Media Access Control (MAC) address assigned to the S321-IP panel.

Note: Changes to any of the following Panel Communication Parameters may cause the panel to go down and then up again.

Heartbeat Transmit Interval – Enter the number of hours, minutes, and seconds that determines how often the S321-IP panel sends *keepalive* messages to the P2000 system. Host No Reception Timeout – Enter the number of hours, minutes, and seconds that must pass without receiving any notification, before the P2000 system assumes the S321-IP panel is no longer available. If this value is set below 60 seconds, the P2000 system may report the S321-IP offline when a large number of badges are downloaded, because of S321-IP internal processing.

Resend Attempt Interval – Enter the number of hours, minutes, and seconds to define how long the S321-IP panel waits before resending a message after the previous attempt failed.

HTTP Disconnect Delay – Determines how long the S321-IP panel holds on to a connection if there is no activity. Select one of the following:

- Time Delay Click to tell the S321-IP panel to keep the underlying HTTP connection for the time specified in the Hours, Minutes and Seconds fields.
- Never Click to tell the S321-IP panel to never drop the underlying HTTP connection.
- Immediate Click to tell the S321-IP panel to drop the underlying HTTP connection immediately after each transmission.

Restore Defaults – Click to restore default values of all related communication timed values.

Other Tab

listory Retention Period	Enable Secondary Interfaces
Delete history older than	☐ SNMP
21 days	Veb UI
Vorld Timezone Information	
Import World Time Zone Information	
Panel UTC Offset	00 00
Daylight Savings Time	
✓ Daylight Savings Used	Hours Minutes
Added During Daylight Savings	01 00
Daylight Savings Begin	Daylight Savings End
Month March	Month November
Week Of Month 2	Week Of Month 1
Day of Week Sunday	Day of Week Sunday
Hours Min Sec	Hours Min Sec
Time of Day 02 00 01	Time of Day 02 00 01

History Retention Period – This setting defines how long the panel retains data in the transaction database before older data is deleted. Click **Delete history older than** and enter the number of days the panel holds data before deletion.

Enable Secondary Interfaces – Use this setting if you wish to use an external device to configure, monitor, and control the S321-IP panel.

- SNMP The Simple Network Management Protocol (SNMP) option is used mostly by network connected devices to report conditions such as a high temperature alarm. You would have to provide a third party device for doing this monitoring.
- Web UI The Web UI option is the interface method necessary for using a Web Browser to communicate with the S321-IP panel.

IMPORTANT: It would be virtually impossible for the P2000 system to control and monitor the S321-IP panel correctly if you use either of these options to control or configure the S321-IP panel. If you only use SNMP or Web UI to monitor the S321-IP panel, while the P2000 system is in operation, then the risk of problems is greatly reduced, but not eliminated. Do not enable these secondary interfaces unless you need to obtain diagnostic information from the S321-IP panel during system startup, or you wish to monitor certain S321-IP items using SNMP and understand the risks.

World Timezone Information Box

The information in this box defines time zone-related information and Daylight Savings Time (DST) settings.

Import World Time Zone Information – Click to select the time zone information that applies to the panel location.

Panel UTC Offset – Defines time offsets for remote panels, relative to Universal Time. Click the + or - radio button and enter the appropriate hours and minutes for the time offset.

Daylight Savings Used – When you select a time zone, the system defaults to the standard daylight savings time settings for the selected region, the S321-IP's clock is automatically adjusted for daylight savings time. If you wish to change the default settings, click the Daylight Savings Used check box and select:

- the Begin and End Month
- the Begin and End Week of Month
- the Begin and End Day of Week
- the Begin and End Time of Day

Added During Daylight Savings - A value of 1 hour is currently the world standard. You cannot change this value.

Configure S321-IP Terminals

The S321-IP panel can control two door terminals, which are automatically created after you configure and save the S321-IP panel. Either or both terminals can be configured as a reader terminal or with all input and output points designated as general purpose input/outputs.

When the terminals are created in the system, they display under the Terminals icon as Term 1 <panel name > and Term 2 <panel name>.

Note: The Entry/Exit concept is not supported by S321-IP panels. In addition, the S321-IP terminal only supports Local access operation. See Appendix C: Panel Comparison Matrix for detailed information on the features supported.

To Configure S321-IP Terminals:

1. In the System Configuration window, expand **Panels** to display the panel types.

- Expand S321-IP Panels to display all S321-IP panels configured in the system.
- 3. Expand the panel that contains the terminals you wish to configure. All the items that can be configured for the panel are listed under it.
- 4. Expand **Terminals**. Select the terminal you wish to configure and click **Edit**. The S321-IP Terminal Edit dialog box opens at the General tab.
- Enter the information in each tab according to your system requirements. (See S321-IP Terminal Field Definitions for detailed information.) As you work through the tabs, click Apply to save your settings.
- When you finish with all the entries, click OK to save your settings and return to the System Configuration window. If you wish to include S321-IP terminals in groups that provide common access, see Create Terminal Groups on page 85.

S321-IP Terminal Field Definitions

General Tab

	Tarm 1 Main Lobby
	Name Term Trian cobby
	Panel Main Lobby
	Query String
	Number 1
	Public
	Enable
Terminal Oper	ational Mode
Reader N	lode
C Input / C	utput Mode

Name – This field displays the name automatically assigned to the terminal. You can however enter a different name for the terminal.

Panel – This field displays the name of the S321-IP panel you selected from the System Configuration window.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Number – This field displays the terminal index number (1 or 2). This number corresponds to the terminal index as assigned at the panel.

Public – If you use Partitioning, click Public if you wish this terminal to be visible to all partitions.

Enable – Click so the new terminal is recognized by the system.

Reader Mode – Indicates a card reader terminal. If selected as the Terminal Operational Mode, additional tabs are added. If the Terminal is a reader terminal, only two input points can be utilized.

Input/Output Mode – Indicates a terminal that provides input and output points. In this mode, four input points and four output points can be utilized.

Flags Tab

C 5321-IP Terminal Edit	×
General Flags Access Timezone Card Ty	ypes Calibrate
Flags	Badge ID Allowed
Momentary Auxiliary Access	PIN Required
Report Strike Status	
🔲 Badge Override	
Override Reset Threat Level	Override is reset when the threat level reaches 1
	OK Cancel Apply

Shunt Alarm on Request to Exit – If enabled, the system shunts the Request to Exit door alarm when the system grants access through an auxiliary access point. If the Request to Exit alarm is shunted, the door can be opened and closed for a specific period of time (shunt time defined in the Access tab) after access has been granted. If a door is opened without access being granted, or if the door is held open beyond the alarm shunt time and the alarm signal is not suppressed, the alarm is detected immediately.

Momentary Auxiliary Access – Determines the total access time when a cardholder is entering or exiting a secured area via an auxiliary access point. When enabled, the access time (defined in the Access tab) begins timing when a switch shorts the door's auxiliary access input point contact (the door strike unlocks for the number of seconds defined in the Access Time field when the system first detects an entry or exit request through an auxiliary access point). If not enabled, the door's auxiliary access input point contact energizes the door relay as long as the contact is shorted (the door strike remains unlocked for the entire auxiliary access time, including the number of seconds defined in the Access Time field).

Report Strike Status – Click to report the status of the door strike associated with the reader.

Badge Override – If enabled, cardholders with their badge's Override option enabled can unlock the door controlled by the selected reader for a specified time period.

Badge ID Allowed – If enabled, a cardholder may enter the badge number at a keypad to access a secured area. This feature enables cardholders who have forgotten their badge the opportunity to gain entry by keying in their badge number.

PIN Required – If enabled, all cardholders must enter a custom PIN on the selected reader when attempting to access a secured area.

Override Reset Threat Level Box

Each reader terminal defined for an S321-IP panel can be configured with an Override Reset Threat Level ranging between 0 and 99.

Whenever a terminal's Security Level reaches or exceeds the terminal's Override Reset Threat Level, all overrides are immediately disabled. Subsequent attempts to invoke overrides are denied.

All overrides are restored once a terminal's Security Level drops below the terminal's Override Reset Threat Level. For more information, see Security Threat Level Control on page 307.

Access Tab

C 5321-IP Term	nal Edit	×
General Flags	Access Timezone Card Types Calibrate	
Reader Opera	tion	
	Access Time 5 Seconds	
	Shunt Time 10 Seconds	
Anti Passback		
🗹 Enable	30 Minutes	
	OK Cancel	Apply

Access Time – Enter the time (in seconds) that the door strike remains energized after a cardholder presents a valid badge at the selected reader. The cardholder has up to 60 seconds to open the unlocked door before it re-locks when the access time elapses.

Shunt Time – Enter a time in seconds that the door open alarm is suppressed after a valid badge access request. The Shunt Time should be longer than the Access Time.

Anti Passback – This feature prevents unauthorized persons from using the badge of an authorized cardholder to gain access to a controlled area. Once an authorized cardholder presents a valid badge to access the facility, the cardholder cannot access the facility again until the anti-passback time entered expires.

Timezone Tab

This tab defines the time zones in which this terminal operates. Time Zones must be set up before they display in drop-down lists.

6 5321-IP Terminal Edit	×
General Flags Access Timezone Card Types Calibrate	
Enabled Full Time	
Override Overtime Hours	
PIN Suppression Full Time	
OK Cancel	Apply

Enabled – Select a time zone during which the terminal is active. For example, you may not want the reader to be used between midnight and 5:00 AM, so assign a time zone with the desired inactive time period. If you select **<none>**, the terminal is always active and allows unrestricted access.

Override – Select a time zone that can be set as an override for this terminal. If you select **<none>**, this terminal is never in override.

PIN Suppression – Select a time zone during which cardholders do not have to enter a PIN number. If you select **<none**>, cardholders are never required to enter their PIN number.

Card Types Tab

This tab determines which card type can be used at the selected reader. If a presented badge does not match the selected card type, the system denies access to the cardholder.

🕻 5321-IP Terminal Edit 🛛 🗙
General Flags Access Timezone Card Types Calibrate
Bull-in Card Formats © No Card Types C HID Concorts 1000
C Cardkey Standard
C Cardkey Magstripe
C Sensor 26 Bit
Raw 128 Bt
Custom Card Format
JCI Standard
OK Cancel Apply

- The S321-IP panel supports one built-in card type at a time, therefore select only one card type.
- Select No Card Types if this reader is disabled.
- The **Sensor 26 Bit** card format is compatible with the 26-bit Wiegand Inverted card format.
- If you select **Raw 128 Bit**, enter the Number of bits to use (12 64).
- If your facility uses Custom Card Formats, select one of the formats previously downloaded into the panel using the Panel Card Formats application; see page 69 for detailed instructions.

Calibrate Tab

Use this tab to calibrate door contact input points as well as auxiliary access input point contacts on the terminal.

6 5321-IP Terminal Edit				×
General Flags Access Timezone	Card Types Calibrate	1		
Door Contact Calbrate	Uncalibrate		Calibrate with R	esistor
Request To Exit				
Calibrate	Uncalibrate		Calibrate with R	esistor
	[ОК	Cancel	Apply

IMPORTANT: During the entire input calibration procedure, the input's contact must be physically closed. Otherwise, the input's status is unreliable.

Calibrate – This command calibrates the S321-IP's selected input point contacts without using the panel's CAL RESISTOR points. Issuing this command determines the door's secure state and sets the selected input point as supervised (4-state).

Note: A Reader Status Input Fault message displays in the Real Time List when Door Contact or Exit Request 4-state inputs are opened or shorted.

Uncalibrate – This command uncalibrates the selected input point and sets it as unsupervised (2-state). After you uncalibrate the input point, four-state input statuses are no longer available for the input, only two-state statuses.

Calibrate with Resistor – This command calibrates the S321-IP's selected input point contacts using the panel's CAL RESISTOR points. Issuing this command determines the door's secure state and sets the selected input point as supervised (4-state). Calibrating the input point based on the CAL RESISTOR points does not require the door to be in the secure state during the calibration process.

Note: Once you perform a calibration procedure on an input point, you should not use this feature again, unless you change the input point's wiring.

Configure S321-IP Input Points

S321-IP Panel and Terminal applications automatically generate input points and their addresses. These input points can be enabled to indicate the current state of a device and can be used for alarm or non-alarm purposes.

Some S321-IP input points have a predefined and unchanging purpose – indicating panel power failure and low battery power. When terminals are enabled, some input points are dedicated to access control functions, such as receiving input from door contacts and REX devices. Other input points can be used for a variety of purposes and devices (motion sensors, tamper switches, and so on) - these input points are referred to as general purpose inputs. The number of terminals enabled determines the available number of general purpose inputs.

Panel input points are automatically created under the selected S321-IP panel and are named using the input name and <panel name>, as in Power Failure <panel name>. Terminal input points are created under the selected S321-IP terminal and are named using the input name and <terminal name> <panel name>, as in Forced Door <terminal name> <panel name>. If you rename the panel or terminal, you can edit the input point to manually enter the new panel or terminal name.

The following possible input points are available:

Input Type	Input Name	Generated for	Description	
Panel Inputs	Panel Tamper	S321-IP panels with the Enable Panel Inputs option selected.	General purpose input. Typically wired to a tamper switch on an enclosure to indi- cate tampering.	
	Power Failure		With battery backup employed, this input point indicates power failure.	
Panel Soft Inputs	Panel Battery	All S321-IP panels.	With battery backup employed, this input point provides a low battery indication during power failure.	
	Clock Battery		Indicates when the panel's lithium battery, which is used to back up the real-time clock, is low.	
	Panel Down		Internal to the P2000 system to indicate that the panel is not active.	
Terminal Inputs	Forced Door	S321-IP terminals with the Reader Mode option selected.	Indicates when there is a door open con- dition without a valid badge read detected first.	
	Propped Door		Indicates when there is a door open con- dition with a valid badge, but the door is left open past the entry time.	
	Door Contact	S321-IP terminals with the Input/Output Mode option selected.	In Reader Mode, this input point receives input from the door contact associated with the terminal. In Input/Output Mode, this input point can be used as a general purpose input.	
	Exit Request		In Reader Mode, this input point receives input from the REX device associated with the terminal. In Input/Output Mode, this input point can be used as a general purpose input.	
	Spare	All S321-IP terminals.	General purpose input.	
	Tamper]	General purpose input.	
	Term Down		Internal to the P2000 system to indicate that panel communications have ceased.	

© 2014 Johnson Controls, Inc.

To Configure S321-IP Inputs:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **S321-IP Panels** to display all S321-IP panels configured in the system.
- 3. Expand the panel that contains the input points you wish to configure.
 - To configure panel inputs, expand **Input Points**, select the input point you wish to configure and click **Edit**.
 - To configure terminal inputs, expand the terminal that contains the input point you wish to configure, then expand **Input Points**, select the input point you wish to configure and click **Edit**.

The S321-IP Input Point dialog box opens at the General tab.

- 4. Enter the information in each tab according to your system requirements. The fields available for configuration depend on the type of input point selected. (See S321-IP Input Point Field Definitions for detailed information.) As you work through the tabs, click **Apply** to save your settings.
- 5. When you finish with all the entries, click **OK** to save your settings and return to the System Configuration window.

S321-IP Input Point Field Definitions

General Tab

C 5321-IP Input Point		×
General Alarm Options Misc		
Partition	Super User 💌	🗆 Public
Name	Panel Tamper Main Lobby	
Query String		
Poin <u>t</u> Name	Panel Tamper	
Point Number	1	
	✓ Enable	
Suppress During Timezone	Full Time	
	ОК	Cancel Apply

Partition – If you use partitions, select the appropriate Partition that has access to this input point.

Public – If you use partitions, click Public if you want this input point to be visible to all partitions.

Name – This field displays the name automatically assigned to the input point, which consists of the <point name> <panel name>; the <terminal name> displays for terminal inputs. If you wish to change it, enter a descriptive name for the input point.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Point Name – Displays the point name defined by the S321-IP panel.

Point Number – Displays the number associated with the input point. This number represents the physical connection to the I/O terminal.

Enable – Click to report all input point changes of state.

Suppress During Timezone – Select a Time Zone during which the input point is disabled. For example, it is impractical to report a door contact alarm during business hours when the door is in constant use. This option is not available for Panel Down, Forced Door, Propped Door, and Term Down input points.

Alarm Options Tab

6 S321-IP Input Point	x
General Wall Options Inter-	1
Select Marin Categories	
2200	Edit
Add Delete	
OK Cancel	Apply

Alarm options are described in detail on page 91.

Misc Tab

Settings in this tab are not available for Panel Down, Forced Door, Propped Door, and Term Down input points.

5321-IP Input Point			x
General Alarm Options	Misc		
Miscellaneous	Debounce Time 20 1 Output Link <none></none>) ms	
Calibration Calibrate	Unca	ibrate	Calibrate with Resistor
		ОК	Cancel Apply

Debounce Time – Enter the time in tens of milliseconds that the input must remain in a transition state to establish the detected state. Without a debounce time, the panel may detect that the input is in an incorrect state because of the *bouncing* of the input device's contacts. **Output Link** – This option links the input point to an output point, so that the output point can be triggered by a change in the input point's state. For example, when an input point, such as a motion sensor, is tripped (the input point state changes from secure to alarm), an output point triggers an external device (a light is turned on). Select the number of the output point that can be triggered by the selected input point. The list display the output point number preceded by the terminal number, as in <terminal number>-<output number>.

Calibrate – This command calibrates the S321-IP's selected input point contacts without using the panel's CAL RESISTOR points. Issuing this command determines the door's secure state and sets the selected input point as supervised (4-state).

IMPORTANT: During the entire input calibration procedure, the input's contact must be physically closed. Otherwise, the input's status is unreliable.

Uncalibrate – This command uncalibrates the selected input point and sets it as unsupervised (2-state). After you uncalibrate the input point, four-state input statuses are no longer available for the input, only two-state statuses.

Calibrate with Resistor – This command calibrates the S321-IP's selected input point contacts using the panel's CAL RESISTOR points. Issuing this command determines the door's secure state and sets the selected input point as supervised (4-state). Calibrating the input point based on the CAL RESISTOR points does not require the door to be in the secure state during the calibration process.

Note: Once you perform a calibration procedure on an input point, you should not use this feature again, unless you change the input point's wiring.

Configure S321-IP Output Points

S321-IP output points are automatically created under terminals that operate with the Input/Output Mode enabled. These output points are used to trigger external devices using the S321-IP panel. These devices might include warning indicators for alarm situations or non-alarm related functions, such as lighting or environmental control.

When the terminal operates in Reader Mode, the output points are dedicated to access control functions, such as controlling the door strike, shunting an alarm, and turning green and red LEDs on and off to indicate access granted or denied.

If the terminal operates in Input/Output Mode, the output points that were used by the reader can be used to trigger external devices, such as lights and sirens – these output points are referred to as general purpose outputs.

Output points are created under the selected S321-IP terminal and are named using the output name and <terminal name> <panel name>, as in *Shunt <terminal name> <panel name>*. If you rename the panel or terminal, you can edit the output point to manually enter the new panel or terminal name.

The following possible output points are available:

Output Name	Description
Green	If the terminal is enabled, this out- put point controls a green LED associated with the terminal. When access is granted, this output is activated. If the terminal is disabled, this output point can be used as a general purpose output.
Red	If the terminal operates in Reader Mode, this output point controls a red LED associated with the termi- nal. When access is denied, this output is activated. If the terminal operates in Input/Output Mode, this output point can be used as a gen- eral purpose output.
Shunt	If the terminal operates in Reader Mode, the alarm shunt prevents the external alarm system from sound- ing an alarm when a valid access occurs. When a valid access occurs, the shunt relay is energized for the number of seconds entered in the Shunt Time field on the Access tab of the S321-IP Terminal Edit application. If the terminal operates in Input/Output Mode, this output point can be used as a gen- eral purpose output.
Strike	If the terminal operates in Reader Mode, the door strike controlled by the terminal unlocks for the number of seconds entered in the Access Time field on the Access tab of the S321-IP Terminal Edit application. If the terminal operates in Input/Out- put Mode, this output point can be used as a general purpose output.

To Configure S321-IP Outputs:

- 1. In the System Configuration window, locate the S321-IP terminal that contains output points.
- 2. Expand **Output Points**, select the output point you wish to configure and click **Edit**. The S321-IP Output Point dialog box opens.

6 5321-IP Output Point		_ 🗆 ×
Output Point		
Partition	Super User Public	
Name	Shunt Term 2 Main Lobby	
Point Name	Shunt	
Point Number	3	
Query String		
	I Enable	
	🔽 Log Output Staus Message	
Output Operational Mode		
Operational Mode	Timed Duration (on until duration expires)	•
Timed Duration	0 Seconds	
	OK Cancel	

- 3. If you use partitions, select the appropriate **Partition** that has access to this output point.
- 4. If you use partitions, click **Public** if you want this output point to be visible to all partitions.
- 5. The **Name** field displays the name automatically assigned to the output point, which consists of the <point name> <terminal name> <panel name>. If you wish to change it, enter a descriptive name for the output point.
- 6. The **Point Name** field displays the point name defined by the S321-IP panel.
- 7. The **Point Number** field displays the number associated with the output point. This number represents the physical connection to the I/O terminal.

© 2014 Johnson Controls, Inc.

- 8. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- 9. Click **Enable** to allow the output point to be activated or deactivated.
- 10. Click **Log Output Status Message** if you want the status of the output point to display in the Real Time List and the System Status window.
- 11. Select one of the following **Operational Mode** options:

Latched (on until turned off, off until turned on) – to command the output point to be set and remain active, until commanded to be reset.

Latched with Fast Flash (flashes until turned off) – to toggle the output point on and off quickly (once per second).

Latched with Slow Flash (flashes until turned off) – to toggle the output point on and off slowly (once per two seconds).

Timed Duration (on until duration expires) – to turn on the output point for the time specified in the Timed Duration field.

Timed Duration with Fast Flash (flashes until duration expires) – to toggle the output point on and off quickly for the time specified in the Timed Duration field.

Timed Duration with Slow Flash (flashes until duration expires) – to toggle the output point on and off slowly for the time specified in the Timed Duration field.

- 12. If you selected any of the Timed Duration operational modes, enter a **Duration** in seconds.
- When you finish with all the entries, click OK to save your settings and return to the System Configuration window.

Configure Isonas Panels and Components

This section describes the P2000 integration with Isonas RC-02 single door controllers. The Isonas panel has been designed using IP standards and technology with direct connectivity to the network and Power over Ethernet (PoE) built-in. Once installed, the readers use TCP/IP to communicate with the network and respond to specific commands and parameters. This allows access to be changed and maintained from anywhere at any time via the network.

It is assumed that the Isonas hardware has been properly installed and configured to communicate with the P2000 Server before you can use the functions described in this section. Refer to the *PowerNet IP Reader Hardware Installation Manual* for instructions.

IMPORTANT: This release of the P2000 software works with Isonas readers that use Freescale 9.20 and PIC 3.08 firmware. Other versions may not be compatible with this release of the P2000 software.

Configure Isonas Panels

After you install the Isonas hardware and assign a static IP address, you are ready to configure the P2000 Server to communicate with the Isonas panel. You should logically name the Isonas panel, including information such as the panel's location or what it controls. Optionally, you can configure the P2000 system to secure each and every message to and from the Isonas panel using Advanced Encryption Standard (AES) to protect the P2000 system from unauthorized sources.

To Configure Isonas Panels:

 From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.

- 2. Expand **Panels** to display the panel types.
- 3. Select **Isonas Panels** and click **Add**. The Isonas Panel Edit dialog box opens.

C Isonas Panel Edit				_ 🗆 🗙
Partition	Super User	Public		
Name	Shipping Area	F Enabled		
Query String				
IP Address	200 . 0 . 0 . 11			
Heartbeat Interval	60 seconds			
	Encryption Enabled			
	Create			
Encryption Key	1EB94100164030CF4887485835C92	99859364DF62F48D08	25761C567EE368CF2	64
	ОК	Cancel		

- 4. If you use Partitioning, select the **Partition** that has access to this panel.
- 5. If you use Partitioning, click **Public** to allow all partitions to see this panel.
- 6. Enter a descriptive Name for the panel.
- 7. The **Enabled** check box is automatically selected for the system to recognize this panel. If you wish to temporarily disable the panel, without having to delete the panel, click the check box to disable it. When you disable a panel, the reader continues to grant access, but the panel does not communicate with the Server until you enable the panel again.
- 8. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- Enter the IP Address assigned to the Isonas panel.
- 10. From the **Heartbeat Interval** spin box, select the number of seconds that determines how often the P2000 system sends heart beat messages that flash the LEDs on the reader to confirm continuous successful communication.

- 11. Click **Encryption Enabled** to allow encryption of all messaging between the Isonas panel and the P2000 Server.
- 12. If you choose to enable encryption, you must click **Create** to generate a random Isonas encryption key.
- 13. The **Encryption Key** box displays the hexadecimal characters generated. The box on the right side displays the number of characters in the encryption key. There should always be exactly 64 characters
- 14. Click **OK** to save the panel information. A message box displays asking if you wish to automatically add all time zones to the new panel. If you select **No**, you can add the time zones later; see Configure Panel Time Zones on page 66.
- 15. If you select **Yes**, the time zones are automatically added. When you return to the System Configuration window, a new panel icon bearing the name assigned displays under the root Isonas Panels.

Note: In addition to applying time zones to the panels (described in Configure Panel Time Zones on page 66), you may also define panel holidays if you wish to restrict access in your facility during a holiday period; see Configure Panel Holidays on page 67.

Configure Isonas Terminals

The Isonas RC-02 panel controls a single door terminal, which is automatically created after you configure and save the Isonas panel information. The Isonas terminal is a reader terminal which consists of four input points and two TTL output points. These components are named using a consistent naming scheme. The terminal name consists of the panel name plus the word *Reader* and may be included in Terminal Groups that provide common access. **Note:** The Entry/Exit concept is not supported by Isonas panels. In addition, the Isonas terminal only supports Local access operation. See the Appendix C: Panel Comparison Matrix for detailed information on the features supported.

To Configure Isonas Terminals:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **Isonas Panels** to display all Isonas panels configured in the system.
- 3. Expand the panel that contains the terminal you wish to configure. All the items that can be configured for the panel are listed under it.
- 4. Expand **Terminals**, select the terminal and click **Edit**. The Isonas Terminal Edit dialog box opens at the General tab.
- Enter the information in each tab according to your system requirements. (See Isonas Terminal Field Definitions for detailed information.) As you work through the tabs, click Apply to save your settings.
- When you finish with all the entries, click OK to save your settings and return to the System Configuration window. If you wish to include Isonas terminals in groups that provide common access, see Create Terminal Groups on page 85.

Isonas Terminal Field Definitions

General Tab

🕻 Isonas Terminal Edit		×
General Access Timezone	I/O Configuration Card Type	
Name	Shipping Area Reader	
Panel	Shipping Area	1
Query String		
	□ Pu <u>b</u> lic	
	OK Cancel	Apply

Name – This field displays the name automatically assigned to the terminal. You can however enter a different name for the terminal.

Panel – This field displays the name of the Isonas panel you selected from the System Configuration window.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Public – If you use Partitioning, click Public if you wish this terminal to be visible to all partitions.

Access Tab

Door access is allowed based on the parameters selected here.

🕻 Isonas	Termin	al Edit							
General	Access	Timezone	I/O Confi	iguration	Card [•]	ype			
r:: Allow F	Intry Base	ed On Card	Number At						
🔽 Pr	oximity Re	eader							
	imeric Keş	/ Pad							
				-l-					
		Access I im	el	⊡ Secor	ids				
						ок	Can	cel	Apply

Proximity Reader – Click to enable this reader as a proximity reader.

Numeric Key Pad – Click to enable this reader as a keypad reader. If enabled, a cardholder must enter the badge number followed by the <#> key.

Access Time – Select the time (in seconds) that the door remains unlocked after a cardholder presents a valid badge at this reader.

Timezone Tab

This tab defines the time zone during which this reader door is not locked.

🕻 Isonas Termin	al Edit				×
General Access	Timezone	I/O Configural	tion Card Type		
	<u>O</u> verride	<none></none>			
				Cancel	Annly

Override – Select a time zone that can be set as an override for this terminal.

I/O Configuration Tab

Settings in this tab define how the reader's inputs and outputs behave when activated.

🕻 Isonas Terminal Edit 🛛 🗙
General Access Timezone I/O Configuration Card Type
Forced Door Image: Activate TTL-2 and Continuously Beep
REX Input (Request to Exit)
• Unlock Door (activate relay)
2 Short Beeps when REX Unlocks Door
C Activate TTL-2 (Do not activate door relay)
AUX Input (Auxiliary)
C Take No Action
C Activate TTL-1 and Continuously Beep
C Activate TTL-2, 3 Short Beeps and LED-1 Red
Unlock Door (activate relay), 1 Beep and LED-1 Green
Tamper
Eeep Continuously on Tamper
Activate TTL-1 on Tamper
OK Cancel Apply

Forced Door

A Forced Door condition occurs when a door is opened without a valid badge read detected first.

Activate TTL-2 and Continuously Beep – Click to activate the TTL-2 defined output when the forced door condition is reported, and to force the reader to beep continuously.

REX Input (Request to Exit)

A Request to Exit (REX) Input is a signal received from a REX device associated with the reader, which prompts the reader to unlock the door without setting off the alarm.

Unlock Door (activate relay) – Click to unlock the door upon receiving a REX Input signal. The relay is activated to unlatch the door. If you select this option, you can enable the **2 Short Beeps when REX Unlocks Door** option is you wish the reader to beep upon activation. Activate TTL-2 (Do not activate door relay) – Click to activate the TTL-2 defined output upon receiving a REX Input signal. This option does not activate the relay to unlatch the door.

AUX Input (Auxiliary)

An Auxiliary (AUX) Input is a signal received from an auxiliary device associated with the reader, such as a device controlled by a relay on an intercom at the door, a push button switch or a motion sensor.

Take No Action – Click if you do not want the reader to perform any special action.

Activate TTL-1 and Continuously Beep – Click to activate the TTL-1 defined output upon receiving the AUX Input signal, and to force the reader to beep continuously.

Activate TTL-2, 3 Short Beeps and LED-1 Red – Click to activate the TTL-2 defined output upon receiving the AUX Input signal. The reader emits 3 short beeps and the red LED is lit.

Unlock Door (activate relay), 1 Beep and LED-1 Green – Click to unlock the door upon receiving the AUX Input signal. The relay is activated to unlatch the door. The reader emits 1 beep and the green LED is lit.

Tamper

A tamper signal is received from a tamper switch on the reader to indicate a tamper condition if for example, the reader has been disturbed or removed from the wall.

Beep Continuously on Tamper – Click to send a continuous beep upon receiving a tamper signal.

Activate TTL-1 on Tamper – Click to activate the TTL-1 defined output upon receiving a tamper signal.

Card Type Tab

This tab determines which card type can be used at the selected reader. If a presented badge does not match the selected card type, the system denies access to the cardholder.

🖸 Isonas Terminal Edit	X
General Access Timezone I/O Configuration Card Type	
Badge Format Cardkey 34 bit - Ignore Fixed Bits	
Card Bits to Use 2-33 (Can use 1 - 32 bits out of 96)	
OK Cancel	Apply

Badge Format – Click the [...] button and select the badge format to be used by this reader. The P2000 software provides badge formats that are located in the \Program Files\Johnson Controls\P2000\BadgeFormats folder. If a different format is needed, create a new badge format file by using the P2000 Badge Format tool; see page 212 for details.

Note: On upgraded systems, badge formats are located in \Program Files\Johnson Controls\ CARDKEY P2000\BadgeFormats. On 64-bit Windows operating systems use \Program Files (x86)\Johnson Controls\P2000\BadgeFormats.

Card Bits to Use – Enter the range of card bits to be used at this reader. Isonas readers limit the card formats to a maximum of 32 bits of the card data.

Configure Isonas Input Points

Isonas input points are automatically generated after you create and save the Isonas panel information. These input points are used to monitor external devices connected to the Isonas reader and can be used to generate alarms, either when the input is activated or if the tamper switch in the equipment is activated. Isonas input points are named using the input name plus the panel name, if you rename the panel, you can edit the input point to manually enter the new panel name. See I/O Configuration Tab on page 149 for details on how the reader's inputs behave when activated.

The following input points are available:

Input Type	Input Name	Description
Panel Soft Input Point	Panel Down	Internal to the P2000 system to indicate that the panel is not active.
Terminal Input Points	Aux Input	This input point receives input from the auxiliary device associ- ated with the reader.
	Forced Door	Indicates when there is a door open condition without a valid badge read detected first.
	Request Exit	This input point receives signal from the REX device associated with the reader.
	Tamper	General purpose input. Typically wired to a tam- per switch to indicate tampering.
	Terminal Down	Internal to the P2000 system to indicate that panel communications have ceased.

To Configure Isonas Inputs:

1. In the System Configuration window, expand **Panels** to display the panel types.

- 2. Expand **Isonas Panels** to display all Isonas panels configured in the system.
- 3. Expand the panel that contains the input points you wish to configure.
 - To configure the panel input, expand **Soft Input Points**, select the input point you wish to configure and click **Edit**.
 - To configure terminal inputs, expand the terminal that contains the input point you wish to configure, then expand **Input Points**, select the input point you wish to configure and click **Edit**.

The Isonas Input Point Edit dialog box opens at the General tab.

C Isonas Input Point Edit			
General Alarm Options			
Partition	Super User	💌 🗌 Public	
Name	Request Exit Shipping Area		
Query String			
Point Description	REX [Request to Exit]	_	
Point Nymber	2		
	,		
·	OK	Capcel An	nhr
			μų

- If you use partitions, select the appropriate Partition that has access to this input point.
- 5. If you use partitions, click **Public** if you want this input point to be visible to all partitions.
- 6. The **Name** field displays the name automatically assigned to the input point, which consists of the <point name> plus the <panel name>. If you wish to change it, enter a descriptive name for the input point.

- 7. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- 8. The **Point Description** field displays the point name defined by the Isonas panel.
- 9. The **Point Number** field displays the number associated with the input point. This number represents the physical connection to the terminal.
- 10. As you work through the tabs, click **Apply** to save your settings.
- 11. To configure alarm options for Isonas input points, click the **Alarm Options** tab and follow the instructions provided on page 91.
- 12. When you finish with all the entries, click **OK** to save your settings and return to the System Configuration window.

Configure Isonas Output Points

Two Isonas output points are automatically generated after you create and save the Isonas panel information. These output points can be activated in response to an activated input point, and are used to trigger external devices, such as alarm warning indicators or emergency lights. Isonas output points are named TTL-1 Output <panel name> and TTL-2 Output <panel name. If you rename the panel, you can edit the output point to manually enter the new panel name. See I/O Configuration Tab on page 149 for details on how the reader's outputs behave when activated.

To Configure Isonas Outputs:

1. In the System Configuration window, locate the Isonas terminal that contains output points.

2. Expand **Output Points**, select the output point you wish to configure and click **Edit**. The Isonas Output Point Edit dialog box opens.

C Isonas Output Point Edit		_ 🗆 ×
Output Point		
Partition	Super User 💌	Public
<u>N</u> ame	TTL-1 Output Shipping Area	
Point Description	TTL-1	
Point Number	1	
Query String		
	OK Cancel	

- 3. If you use partitions, select the appropriate **Partition** that has access to this output point.
- 4. If you use partitions, click **Public** if you want this output point to be visible to all partitions.
- 5. The **Name** field displays the name automatically assigned to the output point. If you wish to change it, enter a descriptive name for the output point.
- 6. The **Point Description** field displays the point name defined by the Isonas panel.
- 7. The **Point Number** field displays the number associated with the output point.
- 8. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- When you finish with all the entries, click OK to save your settings and return to the System Configuration window.

Configure HID Panels and Components

HID Edge readers interface with the P2000 Server using a TCP/IP connection to provide a single-door access control solution. The HID Edge readers are IP-based readers with Power over Ethernet (POE) capabilities and can be initially configured remotely over the network via standard Web browser.

IMPORTANT: This release of the P2000 software works with HID Edge readers that use firmware Version 2.2.7.39. Other versions may not be compatible with this release of the P2000 software.

Hardware Requirements

Before you can use the functions described in this section, the HID hardware must be properly installed and configured to communicate with the P2000 Server. Refer to the HID documentation for hardware installation instructions.

The connection settings are determined by HID guidelines; however, to ensure proper operation with the P2000 system, the following is required:

- If your HID model requires an external reader, we recommend using the following connections:
 - Pwr
 - Gnd
 - Data0
 - Data1
 - GrnLED
 - RedLED (optional)
 - Beeper
 - Hold
- When configuring the HID device via its built-in Web page, you must enter a value (no less than 20 seconds), in the *Here I Am Interval (sec)*: field; otherwise, the reader does not attempt to communicate with the P2000 Server.

HID Panel Naming Conventions

HID panel components are named using a consistent naming scheme. The system automatically allocates an identifying name to the terminal and associated input and output points. This name consists of a fixed description of the item (such as Term 1 for the terminal or Request Exit for an input), plus the panel name. In addition, the name of the terminal is also appended to the input and output names, that way, you can for example recognize an input point by its panel and terminal name.

You should logically name HID panels, including information such as the panel's location or what it controls. The maximum number of characters allowed for an HID component name is 32. If you use long panel names, you need to remember that a terminal input point name is <input name> <terminal name> <panel name> and therefore, that combination should not exceed 32 characters.

Configure HID Facility Parameters

Before configuring your HID components, use the following instructions to define facility parameters associated with HID readers.

To Configure HID Facility Parameters:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand **HID Network Panels** to open the HID components.
- 4. Select **HID Facility** and click **Add**. The HID Facility Edit dialog box opens.

G HID Facility Edit	
Name	P2000
Extended Access Flag	Badge Handicap Support
Badge Format	Cardkey 34 bit
ОК	Cancel

- 5. Enter the **Name** of the HID Facility record. This field displays P2000 by default, but you can change the name according to your facility needs.
- 6. Select from the **Extended Access Flag** drop-down list, one of the three special access flags that are used by cardholders with extended access privileges who require special access at a reader. Special access allows a door's access time to be different. The list displays the special access flag names as configured in Site Parameters; see page 35.
- In the Badge Format field, click the [...] button and select the format to be used at your facility. The P2000 software provides badge formats that are located in the \Program Files\Johnson Controls\P2000\ BadgeFormats folder. If a different format is needed, create a new badge format file by using the P2000 Badge Format tool; see page 212 for details. This field selection is required.

Note: On upgraded systems, badge formats are located in \Program Files\Johnson Controls\ CARDKEY P2000\BadgeFormats. On 64-bit Windows operating systems use \Program Files (x86)\Johnson Controls\P2000\BadgeFormats.

Note: The system may generate "Facility code too large" Event Log error messages when the facility code is too large for the selected format.

 After you enter all the information, click OK to save the settings and return to the System Configuration window.

Configure HID Panels

After you install the hardware and use the HID tools to locate and connect to the HID reader, you are ready to configure the P2000 Server to communicate with the HID device by defining communication and time parameters. In addition, if you wish to protect the P2000 system from unauthorized sources, you can implement encryption using Advanced Encryption Standard (AES) to secure each and every message to and from the HID panel.

To Configure HID Panels:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- Select HID Network Panels and click Add. The HID Panel Edit dialog box opens.
- 4. Fill in the information on each tab. (See HID Panel Field Definitions for details.)
- 5. As you work through the tabs, you may click **Apply** to save your entries.
- 6. Click OK to save the panel information. A message box displays asking if you wish to automatically add all time zones to the new panel. If you select No, you can add the time zones later; see Configure Panel Time Zones on page 66.
- If you select Yes, the time zones are automatically added. When you return to the System Configuration window, a new panel icon bearing the name assigned displays under the root HID Network Panels.

Note: In addition to applying time zones to the panels (described in Configure Panel Time Zones on page 66), you may also define panel holidays if you wish to restrict access in your facility during a holiday period; see Configure Panel Holidays on page 67.

HID Panel Field Definitions

Note: Changes to any of the following HID Panel parameters causes the panel to go offline momentarily.

General Tab

CHID Panel Edit	
General Communi	tations Time Information
	Partition: Super User 🔽 🔽 Public
	Name: Main Entrance
	Enabled
	Query String:
Encryption Cont	rol 🔽 Encryption Enabled
	Create
	Encryption Key: 90575945628583605462285622218095030443160232
	,
	OK Cancel Apply

Partition – If you use Partitioning, select the Partition that has access to this panel.

Public – If you use Partitioning, click Public to allow all partitions to see this panel.

Name – Enter a descriptive Name for the panel.

Enabled – The Enabled check box is automatically selected for the system to recognize this panel. If you wish to temporarily disable the panel, without having to delete the panel, click the check box to disable it. When you disable a panel, the reader continues to grant access, but the panel does not communicate with the Server until you enable the panel again.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

IMPORTANT: The Encryption Control parameters described next, are not available until the panel information is saved. Communications with the panel must be established in a non-encrypted way before encrypted communications can be established.

Encryption Enabled – Click to allow encryption of all messaging between the HID panel and the P2000 Server. If you choose to enable encryption, you may click **Create** to generate a random HID encryption key, or if you prefer you may enter your own key (not to exceed 200 digits).

The **Encryption Key** box displays the key to be used for encrypted communications.

Important Notes

- When any encryption setting is changed, a warning message displays notifying the user that communications must exist and must not be interrupted while encrypted communications are established or ended.
- Only one encryption setting change can be made using the HID Panel Edit application per session (before the panel information is saved after clicking OK). The user must restart the HID Panel Edit application to make another change.
- If the user chooses to delete an HID panel from the System Configuration window, and that panel has encryption enabled, a warning message displays indicating the risk involved.

Communications Tab

ieneral Communications Time Information Panel Identification MAC Address [222333444555 Panel Communications Parameters Heartbeak Transmit Interval Hours Minutes Seconds Heartbeak Transmit Interval 0 1 0 Resend Attempt Interval 0 0 10 Restore Defaults	HID Panel Edit				
Panel Identification MC Address [222333444555 Panel Communications Parameters Heartbeat Transmit Interval 0 1 0 Host No Reception Timeout 0 2 30 Resend Attempt Interval 0 0 10 Restore Defaults	eneral Communications Time I	Information			
MAC Address 222333444555 Panel Communications Parameters Heartbeat Transmit Interval 0 1 Host No Reception Timeout 0 2 30 Resend Attempt Interval 0 0 0 10	Panel Identification				
222333444555 Panel Communications Parameters Heartbeat Transmit Interval 0 1 Host No Reception Timeout 0 2 Resend Attempt Interval 0 0 0 10	MAC Address				
Panel Communications Parameters Heartbeat Transmit Interval Host No Reception Timeout 0 2 30 Resend Attempt Interval 0 0 0 1 Restore Defaults Restore Defaults	222333444555				
Panel Communications Parameters Hours Minutes Seconds Heartbeat Transmit Interval 0 1 0 Host No Reception Timeout 0 2 30 Resend Attempt Interval 0 0 10 Restore Defaults					
Heartbeat Transmit Interval Hours Minutes Seconds Host No Reception Timeout O C C C C C C C C C C C C C C C C C C	Panel Communications Paramete	rs			
Host No Reception Timeout 0 1 0 Host No Reception Timeout 0 2 30 Resend Attempt Interval 0 0 10	-Heartheat Transmit Interval-	Hours	Minutes	Seconds	
Host No Reception Timeout 0 2 30 Resend Attempt Interval 0 0 10 10 Restore Defaults	ricarcosac manamic fricoryar	0	1	0	
Resend Attempt Interval 0 2 30 Resend Attempt Interval 0 0 10 Restore Defaults	Host No Desception Timeout				
Resend Attempt Interval 0 0 10 Restore Defaults	Host No Reception himeout	0	2	30	
Reserve Autempt, Intervar 0 0 10 Restore Defaults	Descend Although Tabaural	,			
	Resend Attempt Interval	0	0	10	Restore Defaults
				1	
				ок (ancel Apply
				ок	Cancel Apply

MAC Address – Enter the Media Access Control (MAC) address assigned to the HID panel.

Heartbeat Transmit Interval – Enter the number of hours, minutes, and seconds that determines how often the HID panel sends heart beat messages that confirm successful communication. If you change the heartbeat interval, the panel is rebooted after the update. You must confirm if you wish to continue.

Host No Reception Timeout – Enter the number of hours, minutes, and seconds that must pass without receiving a heartbeat notification, before the P2000 system assumes the HID panel is no longer available.

Resend Attempt Interval – Enter the number of hours, minutes, and seconds to define how long the HID panel waits before resending a message after the previous attempt failed.

Restore Defaults – Click if you wish to restore default values of all related communication timed values.

Time Information Tab

The information in this box defines time zone-related information and Daylight Savings Time (DST) settings.

HID Panel Edit	
eneral Communications Time Information	
World Timezone Information	
Import World Time Zone Information	Hours Minutes
Panel UTC Offset	
Daylight Savings Time	
Daylight Savings Used	Hours Minutes
Added During Daylight Savings	01 00
Daylight Savings Begin	Daylight Savings End
Month March 💌	Month November
Week Of Month 2	Week Of Month 1
Day of Week Sunday	Day of Week Sunday
Hours Min Sec Time of Day 02 00 00	Hours Min Sec Time of Day 02 00 00
	OK Cancel Annly

Import World Time Zone Information – Click to select the time zone information that applies to the panel location.

Panel UTC Offset – Defines time offsets for remote panels, relative to Universal Time. Click the + or - radio button and enter the appropriate hours and minutes for the time offset.

Daylight Savings Used – When you select a time zone, the system uses the standard daylight savings time settings for the selected region, the HID's clock is automatically adjusted for daylight savings time. If you wish to change the default settings, click Daylight Savings Used and select:

- the Begin and End Month
- the Begin and End Week of Month
- the Begin and End Day of Week
- the Begin and End Time of Day

Note: Because of HID limitations, all minutes and seconds values must always be zero.

Added During Daylight Savings – A value of 1 hour is currently the world standard. You cannot change this value.

Configure HID Terminals

The HID panel controls a single door terminal, which is automatically created after you configure and save the HID panel information. The HID terminal is a reader terminal which consists of six input points and one output point. When the terminal is created, it displays under the Terminals icon as Term 1 <panel name >.

Note: The Entry/Exit concept is not supported by HID panels. In addition, the HID terminal only supports Local access operation. See Appendix C: Panel Comparison Matrix for detailed information on the features supported.

To Configure HID Terminals:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **HID Network Panels** to display all HID panels configured in the system.
- 3. Expand the panel that contains the terminal you wish to configure. All the items that can be configured for the panel are listed under it.
- 4. Expand **Terminals**, select the terminal and click **Edit**. The HID Terminal Edit dialog box opens at the General tab.
- 5. Enter the information in each tab according to your system requirements. (See HID Terminal Field Definitions for detailed information.) As you work through the tabs, click **Apply** to save your settings.
- 6. When you finish with all the entries, click **OK** to save your settings and return to the System Configuration window. If you wish to include HID terminals in groups that provide common access, see Create Terminal Groups on page 85.

Query String – This value is used with message

figuration window.

filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Name – This field displays the name automati-

cally assigned to the terminal. You can however enter a different name for the terminal.

Panel – This field displays the name of the

HID panel you selected from the System Con-

OK

Cancel

Apply

IMPORTANT: Whenever an HID terminal configuration is downloaded, there is a 7 to 8 second window when a cardholder may gain access even if the enabled time zone does not allow it.

HID Terminal Field Definitions

Name Term 1 Main Entrance
Panel Main Entrance

General Tab

General Flags Access Timezone Card Types

Query String Number 1
Public

G HID Terminal Edit

Number – This field displays the terminal index number. This number corresponds to the terminal index as assigned at the panel.

Public – If you use Partitioning, click Public if you wish this terminal to be visible to all partitions.

Flags Tab

HID Te	erminal Edit	×
Seneral	Flags Access Timezone Card Types	
Read	der Flags	
•	REX Contact Energizes Door Strike Relay	
	(REX always shunts door contact for access time)	
	Propped Door is Annunciated at Door	
v	Tamper Alarm Epergize Al IX Relay	
	Tanpar Harm Energies Herricoly	
	OK Cancel Apply	
		-

REX Contact Energizes Door Strike Relay (REX always shunts door contact for access time) – If enabled, the Request to Exit (REX) input point automatically energizes the door strike relay (unlock the door) without setting off the alarm. When pressed, the REX input always shunts the door contact for the access time defined. If not enabled, the REX contact only shunts the door contact.

Propped Door is Annunciated at Door – If enabled, the reader beeps when the propped door condition is reported. A Propped Door condition occurs when a door is opened with a valid badge, but the door is left open past the entry time.

Tamper Alarm Energize AUX Relay – Click to activate the auxiliary relay upon receiving a tamper signal. A tamper signal is received from a tamper switch on the reader to indicate a tamper condition if for example, the reader has been disturbed or removed from the wall.

Access Tab

Door access is allowed based on the parameters selected here.

C HID Terminal	Edit	×
General Flags	Access Timezone Card Types	
	Access Method	Card and PIN
Cardhold	der Override	
Anti Passback		
🔽 Enable	Time Active	60 Seconds
	Action on Anti Passback Violation	No action
Reader Parame	eters	
	Access Time	5 Seconds
	Extended Access Time	40 Seconds
	Time Before Propped Door Reported	10 Seconds
Keypad Entry I	Parameters	
	Maximum Entry Time	30 Seconds
	Maximum Attempts	4
	Failed Attempts Lockout	20 Seconds
		OK Cancel Apply

Access Method – This option defines the type of credentials that must be presented to unlock the door. Select one of the following:

- Card only The cardholder must swipe the badge to gain access.
- Card and PIN The cardholder must swipe the badge and is also required to enter a PIN code. If this option is selected, you must complete the Keypad Entry Parameters settings.
- Card ID only The cardholder must enter the badge number at the keypad. If this option is selected, you must complete the Keypad Entry Parameters settings.
- Card or Card ID The cardholder could either swipe the badge or enter the badge number at the keypad. If this option is selected, you must complete the Keypad Entry Parameters settings.

Cardholder Override – This feature is not available if the Access Method is *Card only*. If Cardholder Override is enabled, an authorized cardholder may place the reader in an override condition by performing a badging procedure at the reader's keypad. The override remains in effect until:

- An authorized cardholder takes it out of override by performing a badging procedure at the reader's keypad.
- The reader's override timezone enables or disables the door.
- A command is received from the Door Control application to change the door's condition.

The following describes the keypad sequence necessary to unlock the door and return the door to normal operation.

- Depending on the Access Method used (*Card and PIN*, *Card ID only*, or *Card or Card ID*) gain access and enter 9 9 # to unlock the door.
- Depending on the Access Method used (*Card and PIN*, *Card ID only*, or *Card or Card ID*) gain access and enter 0 0 # to return the door to normal operation.

Note: HID panels do not report transactions associated with Cardholder Override.

Anti Passback

Enable – Click to enable the anti-passback feature at this reader for the number of seconds entered in the **Time Active** field. The anti-passback function prevents cardholders from using their badge at the same reader until the timer has expired.

Note: If cardholders swipe their badge while the anti-passback timer is active, the anti-passback period is reset to its initial value. Also, badges with Executive privilege enabled, do not override the timed anti-passback feature.

Time Active – Enter the time in seconds that a badge used at the reader is invalid before it can be used at the same reader.

Action on Anti Passback Violation – Select the action that occurs if the cardholder violates the anti-passback rule. Choices are:

- No action Select if you do not want the reader to perform any special action.
- Grant Access and Report Violation Select to allow access at the door and to report the anti-passback violation.
- Deny Access and Report Violation Select to deny access at the door and to report the anti-passback violation.

Reader Parameters

Access Time – Enter the time (in seconds) that the door remains unlocked after a cardholder presents a valid badge at this reader. The cardholder has up to 60 seconds to open the unlocked door before it re-locks when the access time elapses.

Extended Access Time – Enter the time (up to 1620 seconds) that the door remains unlocked to provide extended access time to cardholders with special needs.

Time Before Propped Door Reported – Enter the number of seconds (up to 60) that the door can remain opened before the propped door alarm is reported.

Keypad Entry Parameters

Maximum Entry Time – Enter the number of seconds (up to 60) the user has to enter the PIN code or badge number at the keypad.

Maximum Attempts – Enter the number of attempts (up to 10) the user has to enter a correct PIN code or badge number at the keypad.

Failed Attempts Lockout – Enter the number of seconds (up to 99) the reader is locked after the user exceeded the maximum attempts to enter a PIN code or badge number at the keypad.

Timezone Tab

This tab defines the time zone during which the terminal operates. Time zones must be set up before they display in drop-down lists.

C HID Terminal Edit		×
General Flags Access Timez	one Card Types	
Enabled	Full Time	
Qverride	Night Shift	
PIN Suppression	Full Time	
		Cancel Annly
	OK	Bppiy

Enabled – Select a time zone during which the terminal is active. For example, you may not want the reader to be used between midnight and 5:00 AM, so assign a time zone with the desired inactive time period. If you select **<always enabled>**, the terminal is always active.

Override – Select a time zone that can be set as an override for this terminal.

PIN Suppression – Select a time zone during which cardholders are not required to enter a PIN code.

Card Types Tab

This tab determines which card type can be used at the selected reader. If a presented badge does not match the selected card type, the system denies access to the cardholder. The Badge Format field displays the default HID facility badge format as defined in the HID Facility application (see page 153). If this reader uses a different format, select the format here.



Badge Format – Click the [...] button and select the badge format to be used by this reader. The P2000 software provides badge formats that are located in the \Program Files\Johnson Controls\P2000\BadgeFormats folder. If a different format is needed, create a new badge format file by using the P2000 Badge Format tool; see page 212 for details.

Note: On upgraded systems, badge formats are located in \Program Files\Johnson Controls\ CARDKEY P2000\BadgeFormats. On 64-bit Windows operating systems use \Program Files (x86)\Johnson Controls\P2000\BadgeFormats.

Configure HID Input Points

HID panel and terminal applications automatically generate input points and their addresses. These input points can be enabled to indicate the current state of a device and can be used for alarm or non-alarm purposes.

Some HID input points have a predefined and unchanging purpose, such as to indicate panel tamper. Other input points are dedicated to access control functions, such as receiving input from door contacts and REX devices; and other input points can be used for a variety of purposes and devices, such as power failure - these input points are referred to as general purpose inputs.

Panel input points are automatically created under the selected HID panel and are named using the input name and <panel name>, as in *Power Failure <panel name>*. Terminal input points are created under the selected HID terminal and are named using the input name and <terminal name> <panel name>, as in Forced *Door* <*terminal name*> <*panel name*>. If you rename the panel or terminal, you can edit the input point to manually enter the new panel or terminal name.

The following input points are available:

Input Type	Input Name	Description	
Panel Input	Power Failure	Indicates the reader has a power failure.	
Point	Panel Battery	Provides low battery indication.	
	Panel Down	Internal to the P2000 system to indicate that the panel is not active.	
Terminal Input Points	Door Monitor	This input point receives signal from the door con tact device associated with the reader.	
	Forced Door	Indicates when there is a door open condition without a valid badge read detected first.	
	Propped Door	Indicates when there is a door open condition with a valid badge, but the door is left open past the entry time	
	Request Exit	This input point receives signal from the REX device associated with the reader.	
	Tamper Switch	General purpose input. Typically wired to a tam- per switch to indicate tampering.	
	Terminal Down	Internal to the P2000 system to indicate that panel communications have ceased.	
161

To Configure HID Inputs:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **HID Network Panels** to display all HID panels configured in the system.
- 3. Expand the panel that contains the input points you wish to configure.
 - To configure panel inputs, expand Input Points, select the input point you wish to configure and click Edit.
 - To configure terminal inputs, expand the terminal that contains the input point you wish to configure, then expand **Input Points**, select the input point you wish to configure and click **Edit**.

The HID Input Point Edit dialog box opens at the General tab.

- 4. Enter the information in each tab according to your system requirements. The fields available for configuration depend on the type of input point selected. (See HID Input Point Field Definitions for detailed information.) As you work through the tabs, click **Apply** to save your settings.
- When you finish with all the entries, click OK to save your settings and return to the System Configuration window.

IMPORTANT: Whenever an HID input configuration is downloaded, there is a 7 to 8 second window when a cardholder may gain access even if the enabled time zone does not allow it.

HID Input Point Field Definitions

General Tab

C HID Input Point Edit		×
General Alarm Options Misc		
Partition	Super User	Public
Name	Door Monitor Term 1 North Lobby	
Query String		
Point Description	Door Contact	
Point Number	1	
	🔽 Enable	
	Report Status Change	
	ОК	Cancel Apply

Partition – If you use partitions, select the appropriate Partition that has access to this input point.

Public – If you use partitions, click Public if you want this input point to be visible to all partitions.

Name – This field displays the name automatically assigned to the input point, which consists of the <point name> <panel name>. For terminal inputs, the input name consists of the <point name> <terminal name> <panel name>. If you wish to change it, enter a descriptive name for the input point.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Point Description – Displays the point name defined by the HID panel.

Point Number – Displays the number associated with the input point. This number represents the physical connection to the terminal and cannot be changed.

Enable – Click to allow the input point to operate as a predefined input, such as REX, Door Monitor or Tamper Switch.

Report Status Change – Click to report all input point changes of state.

Note: HID input points do not differentiate between short or open changes of state, they are both considered fault conditions; however, they are reported in the system as short alarms.

Alarm Options Tab

C HID Input Point Edit	×
General Alarm Options Misc	
Select Alarm Categories	
22000	Edit
<u>A</u> dd Delete	
OK Cancel	Apply

Alarm options are described in detail on page 91.

Misc Tab

Settings in this tab are not available for Panel Down, Forced Door, Propped Door, and Term Down input points.

G HID Input Point Edit	×
General Alarm Options Misc	
Debounce	
Debounce Time 96 Milliseconds	
Coperational Mode	
Import Standard Values	
HRUL HRUL LRUL LRU	<u>. </u>
A/D values 192 0 255 193	
A/D Values Define: 2-State Normally Closed	
OK Cano	el <u>Apply</u>

Debounce Time – Enter the time in milliseconds that the input must remain in a transition state to establish the detected state. Without a debounce time, the panel may detect that the input is in an incorrect state because of the *bouncing* of the input device's contacts.

Import Standard Values – Click to select a predefined mode of operation of the input. Inputs can be used as either 2-state or 4-state inputs and can be Normally Open or Normally Closed. Once you make your selection, click **OK**.

Standard A/D Value Selection	×
2-State Normally Closed (no resistor) 2-State Normally Open (no resistor) 4-State Normally Closed using 1200 Ohm resistor 4-State Normally Open using 1200 Ohm resistor	
<u>(ОК</u>	Cancel

A/D values – The Analog to Digital (A/D) default values displayed here represent the High Range Upper Limit (HRUL), High Range Lower Limit (HRLL), Low Range Upper Limit (LRUL), and Low Range Lower Limit (LRLL) values assigned for each operational mode and that match the end of line (EOL) resistors. You can however, change any of the four A/D values at any time.

Note: The A/D Values Define field displays how HID uses the four values. It also shows errors when an illegal combination of values is entered. This field is updated every time you make changes to the A/D values

Configure HID Output Points

HID outputs consist of a single auxiliary output that is automatically generated after you create and save the HID panel information. The auxiliary output point can be activated in response to an activated input point, and can be used to trigger external devices, such as alarm warning indicators or emergency lights. It can also be commanded from the P2000 Output Control application.

To Configure HID Outputs:

- 1. In the System Configuration window, locate the HID terminal that contains output point.
- 2. Expand **Output Points**, select the output point and click **Edit**. The HID Output Point Edit dialog box opens.

6	HID Output Point Edit		_ 🗆 X
	Output Point		
	Partition	Super User 🔽 Dublic	
	Name	Auxiliary Term 1 North Lobby	
	Query String		
	Point Description	Auxiliary Output	
	Point Number	1	
		🔽 Enable	
	Output Operational Mode		
	Operational Mode	Set	
		OK Cancel	

- 3. If you use partitions, select the appropriate **Partition** that has access to this output point.
- 4. If you use partitions, click **Public** if you want this output point to be visible to all partitions.
- 5. The **Name** field displays the name automatically assigned to the output point. If you wish to change it, enter a descriptive name for the output point.
- 6. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- 7. The **Point Description** field displays the point name defined by the HID panel.
- 8. The **Point Number** field displays the number associated with the output point and cannot be changed.
- 9. Click **Enable** to allow the output point to be activated or deactivated.

- 10. Select from the **Operational Mode** drop-down list, the state in which the output point operates. If you select *Set*, the output point remain actives, until commanded to be *Reset*.
- When you finish with all the entries, click OK to save your settings and return to the System Configuration window.

Troubleshooting Misconfigured HID Readers

The HID ERW400, ER40, and ERP40 Edge devices have integrated R40 type HID readers. The integrated readers may ship from HID configured to either hold one card swipe or ignore all card swipes when disabled. If configured to hold a card swipe, when the device is re-enabled, card data is presented to the Edge device for an access decision, possibly granting access. The ability to disable the reader is used within the P2000 software by Reader Enable Timezone, Reader Override Timezone, and Control All Doors.

To Determine if an HID Reader is Storing Card Information:

- 1. From the P2000 Main menu select Control>Control All Doors.
- 2. Enter your password if prompted. The Control All Doors dialog box opens.

Control All Doors	
Partition Super U	ser 💌
All Panels	
C Selected Panel	
	•
Resume Normal Operation	
C Unlock All Doors	
Perfor	m
Done	

- 3. If this is a partitioned system, select the **Partition** in which the HID doors are active.
- 4. Click Selected Panel.
- 5. Select the HID panel you wish to test.
- 6. Click **Unlock All Doors** to unlock all doors connected to the selected panel.
- 7. Click **Perform**. The system informs you that the doors remain unlocked until you lock the doors again, and prompt you to continue.
- 8. Click **Yes**. This puts the device into override.
- 9. With the device in override swipe a card at the reader.
- 10. If the reader is configured incorrectly the reader beeps.
- 11. To return the doors to their previous state, click **Resume Normal Operation**.
- 12. Click **Perform**. The system prompts for verification.
- 13. Click **Yes**. The Door Control override is reversed. The Real Time List shows the results of the card swipe if the reader is not properly configured.

Note: Contact HID if you encounter this type of problem.

Configure Assa Abloy® IP Door Locks and Components

Assa Abloy Intelligent Locks provide a wired (PoE) and wireless (Wi-Fi) door locking security solution that can be integrated with the P2000 system. Integration between these two systems is possible via the Assa Abloy Door Service Router (DSR), which is installed on the DSR server, and the P2000 Assa Abloy DSR Interface Service, which runs on the P2000 server.

IMPORTANT: This release of the P2000 software works with Assa Abloy locks that use firmware Version N05 or later. Other versions may not be compatible with this release of the P2000 software.

This P2000 software version requires DSR Version 5.0, other previous versions are not supported. The P2000 system can only connect to a single DSR, with up to 1024 locks per DSR. If more than 1024 locks are required, you may have to install additional P2000 servers. This is typically a case for P2000 Enterprise systems.

The DSR can be on a separate server or on a virtual computer on the P2000 server, and must have network access to the P2000 server.

The following figure illustrates DSR running on physical computers.



The following figure illustrates a DSR running in a virtual environment.



Hardware Requirements

Before you use the functions described in this section, the Assa Abloy hardware and DSR servers must be properly installed. Refer to the Assa Abloy documentation for hardware installation assistance.

Also, refer to the Assa Abloy Network & Lock Configuration Tool (LCT) documentation for alarm configuration instructions. The following LCT settings provide a good compromise for both response time and battery life. We highly recommend configuring these settings during the initial installation phase to view relevant messages during testing.

Sconfigure Alarms				2
Alarm Message	Enabled When Secured	Enabled When In Passage	Enabled When REX Held	
Alarm on Rx Held Event	Π	Π		
Alarm on Access Granted		Π.	Γ	
Alarm on Access Denied			Γ	
Alarm On Door Secured			7	
Alarm on Door Forced			7	
Alarm on Key Override			Γ	
Alarm on Door Ajar			₩	
Alarm on Low Battery		1	₩	
Rea	id Apj	oly Clos	e	

For DSR installation information, refer to the *P2000 Software Installation Manual*.

Assa Abloy Component Naming Conventions

Each Assa Abloy Intelligent Lock is represented by a panel and a single reader terminal in the P2000 software. The P2000 system automatically adds Assa Abloy panels, terminals, and associated soft input points to the P2000 system configuration tree after the DSR detects the corresponding locks, which occurs after the DSR Interface Service restarts or when a change occurs to the fields on the Assa Abloy DSR Edit dialog box (see page 169). Each component has a predefined name, including a 16-character string identifying the panel serial number as defined in the DSR.

Panel names have the following predefined structure:

[PoE or Wi-Fi] [Lock Serial Number]

Example: PoE IT107E2577PA0BCE

Terminal names have the following predefined structure:

[PoE or Wi-Fi] [Lock Serial Number] Term

Example: PoE IT107E2577PA0BCE Term

Note: Predefined panel and terminal names enable you to determine whether the panel (or associated panel in the case of a terminal) is wired (PoE) or wireless (Wi-Fi).

Soft input points have the following predefined structure:

[Soft input point alarm name] [Lock Serial Number]

Example: Forced PoE IT107E2577PA0BCE

When renaming Assa Abloy panels, terminals, and soft input points, use a consistent naming scheme to avoid panel and component identification confusion. Use logical names for Assa Abloy panels. For example, consider a name that identifies the panel's location. The maximum number of characters allowed for an Assa Abloy component name is 32.

Configure Assa Abloy Facility Parameters

Before configuring your Assa Abloy components, use the following instructions to define facility parameters associated with Assa Abloy panels.

Note: Facility parameter modifications affect **all** Assa Abloy panels and associated components defined in the P2000 System Configuration.

Configuring Assa Abloy facility parameters consists of the following:

- Assigning special access requirements for Assa Abloy panels (see Special Access for Assa Abloy Panels on page 166)
- Setting up badge formats for use with Assa Abloy panels (see Set Up Badge Formats for Assa Abloy Panels on page 167)

Special Access for Assa Abloy Panels

In addition to basic access, operators can control special access for overriding the normal operation of Assa Abloy panels. Special access options include:

- Extended Access Extends the time a cardholder is permitted to hold a door open, which can be used to comply with Americans with Disabilities Act (ADA) requirements.
- Deadbolt Override Enables a cardholder to unlock an Assa Abloy lock when the deadbolt is engaged. On PersonaTM or PassportTM locks, the Deadbolt Override privilege grants access 24/7, including holidays, eliminating the time zone check in the access decision process.

 Wakeup Communication (Wi-Fi only) – Forces the Assa Abloy lock to connect to the DSR so that the P2000 system can retrieve panel event data since the last panel-DSR connection.

Note: Assa Abloy wireless locks connect to a DSR at specified time intervals, because of an alarm, or upon presentation of a badge with the Wakeup Communication capability. P2000 operators can only view panel event data that has occurred since the last lock-DSR connection.

Note: If a badge has both Deadbolt Override and Wakeup Communication capabilities, the Wakeup Communication function takes priority when the cardholder presents the badge (Deadbolt Override does not take effect).

Note: Badges with Wakeup Communication capability do not unlock any doors.

To Modify the Assa Abloy Facility Parameters for Special Access:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Select **Assa Abloy Panels** and click **Edit**. The Assa Abloy Facility Edit dialog box opens.

	Calc						
						_	
	Extended Acces	s Flag Specia	Access A			-	
	Dandholt Ouerride	a Flag	1.4			7	
	Debubort Orento	erray [specia	Access b			-	
w	akeup Communication	n Flag Specia	Access C			-	
		. —					
	Primary Badge H	ormat Corpo	rate 1000 wi	th Sentinel			
ditional Barlos	Formate						
dditional Badge	Formats						_
dditional Badge	e Formats	Technolog	yy Bits	Qualifier			_
dditional Badge Name Cardkey 34 b	e Formats	Technolog	y Bits 0	Qualifier			=
dditional Badge Name Cardkey 34 b	t with Sentinel	Technolog IClass	y Bits 0	Qualifier			=
dditional Badge Name Cardkey 34 b	t with Sentinel	Technolog IClass	W Bits 0	Qualifier	1		-
dditional Badge Name Cardkey 34 b	e Formats	Technolog [Class	W Bits 0	Qualifier 1	1		-
dditional Badge Name Cardkey 34 b	e Formats	Technolog IClass	iy Bits O	Qualifier 1	1		-
dditional Badge Name Cardkey 34 b	e Formats	Technolog IClass	iy Bits O	Qualifier 1			
dditional Badge Name Cardkey 34 b	e Formats	Technolog IClass	y Bits 0	Qualifier 1			
dditional Badge Name Cardkey 34 b	: Formats	Technolog IClass Edit	y Bits 0 Delete	Qualifier 1			
dditional Badge Name Cardkey 34 b	Formats It with Sentinel Add	Technolog IClass Edit	0 0 Delete	Qualifier 1			

- 4. Assign the desired special access flags. The drop-down lists display the special access flag names as configured in Site Parameters; see page 35.
- 5. Click **Yes** when informed about the down-load requirement.
- 6. Click OK.

Set Up Badge Formats for Assa Abloy Panels

Assa Abloy intelligent locks support multiple badge formats. The integration with these locks requires P2000 operators to configure the P2000 system to support the badge formats that are employed at the site. The P2000 system offers the flexibility of defining a primary badge format for the majority of badges used at Assa Abloy locks, and allows supplemental formats to be added for the rest.

The P2000 software provides the following formats to be used with Assa Abloy locks:

- Cardkey 34 bit with Sentinel
- Corporate 1000 with Sentinel
- H10301 with Sentinel (this is the 26 Bit Wiegand format)
- H10302 with Sentinel (this is the HID Proprietary 37 Bit Wiegand format. As this format does not have a facility code, use facility code 0 for all badges of this format.)

Note: If any other binary card formats are to be used for Assa Abloy locks, a Sentinel version of the card format must be created. In addition, a card format for Magnetic stripe cards must be created to match the encoding on the magnetic stripe cards. Contact Technical Support for assistance in creating card formats. **Note:** The system may generate "Badge number encode failed" Event Log error messages when the badge number or facility code is too large for the selected format.

To start, add any badge formats (*.bft files) not already defined that are required by Assa Abloy locks. See P2000 Badge Format on page 212 for more information. All badge formats (*.bft files) are located in \Program Files\Johnson Controls\P2000\BadgeFormats.

Note: On upgraded systems, badge formats are located in \Program Files\Johnson Controls\ CARDKEY P2000\BadgeFormats. On 64-bit Windows operating systems, the path is \Program Files (x86)\Johnson Controls\ P2000\BadgeFormats.

In addition to creating *.bft files, you must perform additional badge format configuration steps specific to Assa Abloy panels, as described in this section. These steps consist of the following:

- Creating badge formats to be assigned to cardholder badges (see Create Badge Formats on page 252). These settings must match the settings defined for Assa Abloy supplemental badge formats.
- Selecting the primary badge format for Assa Abloy locks (see To Select a Primary Badge Format for Assa Abloy Locks: on page 167).
- Adding supplemental badge formats, as needed (see To Add Supplemental Badge Formats: on page 168).

To Select a Primary Badge Format for Assa Abloy Locks:

 From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.

- 2. Expand **Panels** to display the panel types.
- Select Assa Abloy Panels and click Edit. The Assa Abloy Facility Edit dialog box opens.
- 4. In the **Primary Badge Format** field, click the [...] button and select the badge format that is the primary format used at the site for Assa Abloy locks.

Note: If a P2000 operator does not assign a badge format to a cardholder badge, the Primary Badge Format is used.

5. Click Apply.

To Add Supplemental Badge Formats:

1. On the Assa Abloy Facility Edit dialog box, click **Add**. The Badge Format Edit dialog box opens.

Badge Format Edit		×
Name	Cardkey 34 bit with Sentinel	
Technology	Wiegand	
Bits	34	
Qualifier	2	
	OK Cancel	

- 2. Click the [...] button, select a *.bft file from the list, and click **Open**. The name of the selected *.bft file displays in the **Name** field. You cannot edit this name.
- 3. Select the **Technology** type.
- 4. Enter the total number of **Bits** expected to be returned from the reader when the badge is read.
- 5. Select a **Qualifier** number. The number selected represents a 32-bit numerical value that allows differentiating formats with the same technology and the same number of bits. The default value is 1.

IMPORTANT: The Assa Abloy Technology, Bits, and Qualifier badge format settings must match the badge format settings defined for a cardholder badge (see Create Badge Formats on page 252).

- 6. Click OK.
- 7. Verify that the badge format is listed under Additional Badge Formats.
- 8. Repeat these steps for each badge format to be used with Assa Abloy locks.

Using the Card ID feature with Assa Abloy Locks

The following instructions allow you to use the Card ID feature with Assa Abloy Locks:

- First you need to use the instructions provided in Create Badge Formats on page 252 to define a badge format of Technology PIN Only, set Bits to 0, and Qualifier to 1. Name this format Card ID.
- Use the Badge application (see page 267), to select from the Format field, the **Card ID** format previously defined. Also, enter in the Number field, the Card ID number that the cardholder must enter at an Assa Abloy keypad lock.
- We recommend defining a Facility Code of 0 to be assigned to this type of badge format.
- On magstripe locks, the Card ID must contain exactly 6 digits, no leading zeros allowed. The cardholder must enter the # key followed by the 6 digit number.
- On non magstripe locks, the Card ID may contain from 1 to 6 digits, no leading zeros allowed. The cardholder must enter the number followed by the * key.

Add a Door Service Router (DSR)

The Assa Abloy DSR is the communication link between the P2000 server and Assa Abloy panels. Once you add a DSR on the P2000 System Configuration window, the P2000 system automatically adds all of the Assa Abloy panels and sub-components associated with the DSR.

Note: If a lock is added to a DSR after you add the DSR to the P2000 system configuration, the lock is added to the P2000 system only after the DSR Interface Service restarts or when a change occurs to the fields on the Assa Abloy DSR Edit dialog box.

To Add an Assa Abloy DSR:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand Assa Abloy Panels.
- 4. Right-click over **Integration Components** and click **Add**. The Assa Abloy DSR Edit dialog box opens.

Assa Abloy DSR Edit	
<u>P</u> artition:	Super User
	T Public
<u>N</u> ame:	DSR West Lobby
Query String:	
<u>I</u> P Address:	255 . 141 . 226 . 115
TCP Port:	8080
	Encryption Enabled
Panel Status When DSR is Down:	Down
	Clear DSR
	OK Cancel

- 5. If this is a partitioned system, select the **Partition** in which the Assa Abloy DSR is active.
- 6. Click **Public** if you wish the Assa Abloy DSR to be visible to all partitions.
- 7. Enter a descriptive Name for this DSR.
- The Query String value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- 9. Enter the IP Address of the DSR.
- 10. Enter the TCP Port address of the DSR.
- 11. The **Encryption** feature is currently not supported in this release.
- 12. When a DSR status changes to Down, the P2000 system receives notifications about the panel status, according to the following selections in the **Panel Status When DSR is Down** drop-down list:

Down – The P2000 system receives a panel down notification for **each** panel associated with the DSR.

No Change – The P2000 system receives only a single notification that the DSR is currently down. The P2000 system does **not** receive panel down notifications for each panel associated with the DSR. This option is recommended for large installations.

13. Click OK.

IMPORTANT: The **Clear DSR** button is provided to delete all P2000 data (for example, badge data or access groups) from the DSR. This function should only be performed with the aid of a Johnson Controls Technical Support specialist. After clearing the DSR of P2000 data, once the DSR downloads these changes to the Assa Abloy locks, P2000 cardholders are unable to gain access. To repopulate the DSR with P2000 data, perform a P2000 download function to all Assa Abloy panels. See the next section for additional information.

Download Strategy After Clearing the DSR

IMPORTANT: Clear the DSR only if you believe that the P2000 data in the DSR is corrupted.

After clearing a DSR, all locks that connect before the DSR is fully repopulated with its P2000 data, receive only a partial database.

If the items that are not yet downloaded contain the terminal's *Connect Interval* (see page 175), the Wi-Fi locks no longer wake up on their intended schedule. You need to wake up the locks manually by either presenting a badge with the *Wakeup Communication Flag* enabled (see page 166), or by pressing the *Comm* button (Wake-up button) on the lock after removing the back cover.

To minimize the phase in which the DSR does not have the Terminal configuration data, we recommend the following download strategy after clearing a DSR.

- 1. Using the Download application (see Downloading Data to Panels on page 463), download Terminals to all Assa Abloy panels under the DSR. This restores the critical *Connect Interval* settings for all locks.
- 2. Download Time Zones, Panel, and Badges to the Assa Abloy panel that is used by most cardholders.

Some data is shared among panels, so by downloading the most populated panel first increases the chances that other locks can have their data already available in the DSR before the P2000 system gets to download to those panels.

3. Download Panel and Badges to all other Assa Abloy panels. You do not need to download other items. Access Groups are part of the Badge data for Assa Abloy panels. 4. When downloading badges to multiple locks on a DSR, it is advised to leave the *Delete Badges From Panel Before Download* flag unchecked. Otherwise, the DSR may be tied up in a large amount of internal data processing and may not respond in time to requests made by the P2000 system.

Additional DSR Downloading Notes

To ensure that the DSR remains in synch with the P2000 database, the DSR is expected to be online all the time.

In case the DSR is offline, downloading of certain configuration data, including badges and access groups, is suspended for the DSR.

The suspension of downloads is automatically lifted as soon as the DSR is online to the P2000 Server, and any suspended downloads resume automatically. No user action is required.

However, if a DSR goes offline frequently, or goes offline for unknown reasons, an investigation must be initiated as soon as possible.

Download Recommendations

The following general download recommendations must be followed when integrating with Assa Abloy locks, specially in facilities where the number of locks is higher than 128 locks.

1. Open the **Download** tab in Site Parameters.

C Edit Site Parameters
Port Configuration RMS EMail External Event Trigger MIS Web Access XmlRpc
General Printing Panel Types Facility Code Retention Policy Password Policy BACNet Download
Download Options
Download to disabled panels
Download badges with Undefined entry/exit status
Legacy panel access group download disable
Delayed download for badges and access groups
Smart Download Rules 0 Minutes Delay 5hared Mode Badge Downloads
Download Access Groups of badge

- Select the Delayed download for badges and access groups check box.
- Unless some other condition requires the Minutes Delay value to be set to a specific value, enter 0 minutes in this field.

In addition, you must consider the following operational recommendations:

 Avoid unnecessary downloads using the Download application or through Download event actions.

The DSR queues all download records received from the P2000 system.

Any unnecessary download records increase the load on the DSR, and more importantly, the time it takes to synchronize the locks.

Therefore, observe the following instructions to reduce the amount of messages the DSR has to process.

- In general, all modifications in the P2000 system are automatically queued for download. Unless the download queues are emptied, or a lock or the DSR were cleared, or the Panel Time Zone table of an Assa Abloy locks is changed, there is no need to manually download to an Assa Abloy lock.
- Downloading a Time Zone to a specific Assa Abloy panel results in an automatic forwarding to all locks under the same DSR that have that Time Zone in their Panel Time Zone table.

Therefore, we recommend that all Assa Abloy panels have identical Panel Time Zone tables.

This way, downloading Time Zones to a single Assa Abloy lock updates all Assa Abloy locks under that DSR with respect to Time Zone configuration. Downloading Holidays to a specific Assa Abloy panel results in an automatic forwarding to all locks under the same DSR.

Therefore, downloading Holidays to a single Assa Abloy lock updates all Assa Abloy locks under that DSR with respect to Holiday configuration.

 Downloading Access Groups to a specific Assa Abloy panel has ultimately the same results as downloading all Badges to that Assa Abloy panel.

As downloading badges is less disruptive, we do not recommend downloading Access Groups to Assa Abloy panels, but instead download Badges.

 Downloading Input Points, Output Points, Soft Alarms, Card Events, and Elevator/Cabinets has no effect, and may therefore be omitted.

Edit Assa Abloy Panels

After you add a DSR, a panel list displays under the DSR in the System Configuration tree.



New panels cannot be added manually. However, you can edit or delete the panels, as necessary.

To Edit an Assa Abloy Panel:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.

- 3. Expand Assa Abloy Panels.
- 4. Expand Integration Components.
- 5. Expand the **DSR** that has the panel you wish to edit.
- 6. Right-click over the panel you wish to edit and select **Edit**. The Assa Abloy Panel Edit dialog box opens.

C Assa Abloy Panel Edit			_ = ×
Partition	Super User	Public	
Name	PoE IT 107E2500PA0BCB	Finabled	
Query String			
	Clear Lock		
			OK Cancel

- 7. If this is a partitioned system, select the **Partition** in which the Assa Abloy panel is active.
- 8. Click **Public** if you wish the Assa Abloy panel to be visible to all partitions.
- 9. The **Name** field displays the name automatically assigned to the panel. You can however enter a different name.
- 10. Click **Enabled** to enable the Assa Abloy panel.
- 11. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- 12. Click **OK** to save the panel information.

IMPORTANT: The **Clear Lock** button is provided to delete all P2000 data (for example, badge data or access groups) from the Assa Abloy panel. After clearing a lock, once the DSR downloads these changes to the panel, P2000 cardholders are unable to gain access via the Assa Abloy door locks. To repopulate the lock with P2000 data, perform a P2000 download function to the Assa Abloy panel.

To Move a Panel to a Different DSR:

Use the following instructions to properly relocate an Assa Abloy panel to a different DSR. In this example a lock is moved from DSR1 to DSR2:

- 1. Ensure that DSR1 is online to the P2000 system.
- Use the LCT configuration tool to configure the lock to <u>not</u> talk to any existing DSR; that is, neither DSR1 nor DSR2.
- 3. Delete the panel from the P2000 system, under the DSR1 integration component.
- 4. Use the LCT to configure the lock to talk to the new DSR; that is, DSR2.
- 5. Ensure that DSR2 is online to the P2000 system.
- 6. The panel shows up under the DSR2 integration component.
- 7. Clear the lock and download from the P2000 system.

To Delete an Assa Abloy Panel:

IMPORTANT: Deleting the panel from the P2000 system does not delete the panel from the DSR. Therefore, the next time the DSR Interface Service restarts, the panel reappears, along with the associated components, on the System Configuration window. You can only delete an Assa Abloy panel from the P2000 system if the lock is no longer connected to the DSR.

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand Assa Abloy Panels.
- 4. Expand Integration Components.

- 5. Expand the **DSR** that has the panel you wish to delete.
- 6. Right-click over the panel you wish to delete and select **Delete**.
- 7. On the Confirm Delete dialog box, click **Yes**.

Assa Abloy Panel Time Zones

By default, P2000 time zones are <u>not</u> automatically assigned to Assa Abloy panels. See the instructions described in Configure Panel Time Zones on page 66 to assign up to 32 time zones to an Assa Abloy panel.

Note: Each Assa Abloy lock can only store up to 32 different time blocks. A time zone may have multiple time blocks.

- If a panel is deleted and then re-added, any time zones previously assigned to the panel are cleared. Reassign the time zones, if necessary.
- Changing a panel time zone affects all panels that use this time zone; therefore, downloading time zones to a single Assa Abloy panel may affect all Assa Abloy panels.
- The access rights of a badge are determined by the combination of Access Groups and Time Zones.
- Ensure that Access Groups containing Assa Abloy panels are only paired with Time Zones that are eligible for those Assa Abloy panels.
- To be eligible, a Time Zone must be included in the Assa Abloy Panel Time Zone table.
- To keep the number of time blocks inside each lock to a minimum, we recommend using a very basic Time Zone strategy for Assa Abloy locks.

Changes to the Panel Time Zone Table of an Assa Abloy panel

- If a Time Zone is used to define access rights to an Assa Abloy panel, but the panel does not have that Time Zone listed in its Panel Time Zone table, no access is granted. In case such Time Zone is later added to the Panel Time Zone table, all badges shall be downloaded to that panel to ensure that access is granted.
- In case a Time Zone was previously contained in the Panel Time Zone table, but is now removed, access rights of badges that solely rely on this time zone are only revoked after all badges are downloaded to that panel.
- The exclusion of a Time Zone from the Panel Time Zone table shall not be used to curtail the access rights of defined badges. Instead, the Access Groups shall be chosen to only include the applicable Assa Abloy panels.
- In general, removing or rearranging Time Zones in a Panel Time Zone table is not advisable. If such actions are necessary, we recommend downloading all Time Zones and badges to the affected panel after the changes were made.

Important Points

- Only use a Time Zone for granting access to an Assa Abloy lock after it was added to its Panel Time Zone table.
- Only remove a Time Zone from an Assa Abloy Panel Time Zone table after ensuring that it is no longer used in granting access to the lock.
- Keep the Time Zone strategy for Assa Abloy locks as simple as possible.

Assa Abloy Holiday Definition

Holiday periods behave differently for Assa Abloy locks. See the following notes:

- If a day is defined as a Holiday in an Assa Abloy Time Zone, that Time Zone does <u>not</u> grant access to anyone during the entire day, regardless of the Holiday's defined time periods.
- If a day is defined as a Holiday in an Assa Abloy Time Zone, and that Time Zone is used to drive the Unlock or First Person Through feature, those features do <u>not</u> work during the entire day, regardless of the Time Zone's defined time periods.
- Define a specific day to be an Assa Abloy Holiday by doing two things:
 - declare the specific day as a Holiday (of Type 1, 2, or 3) in the Edit Holiday application (see page 51), and
 - define the time blocks in a Time Zone for the Holiday's Type as always *Inac-tive*.

This configuration matches the intent to have <u>**no**</u> access and <u>**no**</u> overrides during the entire holiday.

If in a Time Zone there is any Active period defined for a Holiday of Type 1, 2, or 3, then this configuration is <u>not supported</u> by Assa Abloy locks, and the Assa Abloy integration ignores the particular holiday type for that Time Zone and treat the day as a regular day.

Configure Assa Abloy Terminals

Each Assa Abloy panel controls a single door terminal, which is automatically created with each panel added to the System Configuration window via the DSR. The Assa Abloy terminal consists of seven soft input points.

To Configure Assa Abloy Terminals:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand Assa Abloy Panels.
- 4. Expand Integration Components.
- 5. Expand the **DSR** that has the panel or terminal you wish to configure.
- 6. Expand the panel that has the terminal you wish to configure.
- 7. Right-click over the terminal and select **Edit**. The Assa Abloy Terminal Edit dialog box opens at the General tab.
- 8. Enter the information in each tab according to your system requirements. (See Assa Abloy Terminal Field Definitions for detailed information.) As you work through the tabs, click **Apply** to save your settings.
- When you finish with all the entries, click OK to save your settings and return to the System Configuration window. If you wish to include Assa Abloy terminals in groups that provide common access, see Create Terminal Groups on page 85.

Assa Abloy Terminal Field Definitions

General Tab

C Assa Abloy Terminal Edit			×
General Access			
N <u>a</u> me	PoE IT 107E2500PA0BCB Term		
Panel	PoE IT 107E2500PA0BCB		
Query String			
Number	1 🗸		
	F Public		
Lock Type	SxPx External Powered	☐ Wireless	
Connect Interval	0 Minutes		
		. 1	
	OK C	Cancel A	pply

Name – This field displays the name automatically assigned to the terminal. You can however enter a different name for the terminal.

Panel – Displays the name of the Assa Abloy panel you selected from the System Configuration window.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Number – Displays the terminal number automatically assigned and cannot be edited.

Public – If you use Partitioning, click Public if you wish the Assa Abloy terminal to be visible to all partitions.

Lock Type – Displays the name indicating the terminal lock type, as defined by the DSR. This field cannot be edited.

Wireless – By default, this check box is selected for Assa Abloy wireless locks (indicated as Wi-Fi in the default name) and not selected for wired locks (indicated as PoE in the default name). Do **not** change the default setting unless special circumstances require it. This field enables you to define the time interval when the lock connect to the DSR. Since wireless Assa Abloy locks typically run on battery power, configuring the lock to connect to the DSR too often significantly drains the lock's battery power.

Connect Interval – For wireless locks only; use this field to set the time interval (up to 65535 minutes) to have the lock connect to the DSR for updates and event information. The **Wireless** check box must be selected to modify the time interval.

Note: We recommend setting a badge start to a date early enough to give the Wi-Fi locks time to connect and learn about the badge before it is used. The P2000 system downloads the badge to the DSR when its start date and time is reached. With a connect interval of 1440 minutes, the badge start date should be set to at least one day before it is actually used. If there are other timing issues, we recommend setting the badge start date even earlier, or not set it at all.

Access Tab

🕻 Assa Abloy Terminal Edit			×
General Access			
Access Time	5 Seconds		
Shunt Time	10 Seconds		
Extended Access Time	15 Seconds		
PIN Type	No PIN Required	•	
Override Type	First Person Through	•	
Override Timezone	<never overridden=""></never>	•	
		OK	Cancel Apply

Access Time – Enter a time in seconds that the door strike is energized after each valid badge access request. The default value is 5 seconds.

Shunt Time – Enter a time in seconds that the door open alarm is suppressed after a valid badge access request. The shunt time should be longer than the access time. The default value is 10 seconds.

Extended Access Time – Select the amount of time that the door remains unlocked to provide extended access time to cardholders with special needs.

PIN Type – Determines the use of PIN codes. Select one of the following options:

- No PIN Required In this mode, cardholders do not enter a PIN to gain access through a door.
- PIN Required In this mode, cardholders that have a PIN must enter their PIN in conjunction with presenting a valid badge. PIN codes can be entered before or after presenting a badge. This feature is not supported on all locks (for example, Persona or Passport locks). Check with your local Assa Abloy dealer for information on PIN support with other locks. Cardholders that do not have a PIN, do not have to enter a PIN in conjunction with presenting a valid badge.
- PIN After Badge In this mode, cardholders that have a PIN must enter their PIN in conjunction with presenting a valid badge. PIN codes must be entered after presenting a badge. Cardholders that do not have a PIN, do not have to enter a PIN in conjunction with presenting a valid badge.

Note: For information on the number of supported PIN digits on Assa Abloy locks, check with your local Assa Abloy dealer.

Override Type – If a time zone is selected in the **Override Timezone** drop-down list, the Override feature functions according to one of the following options:

- Unlock The door automatically unlocks and remains unlocked during the active period of the selected time zone.
- First Person Through The door remains locked during the active period of the selected time zone until a cardholder presents a valid badge at the reader, at which time the door remains unlocked for the remainder of the time zone's active period.

Override Timezone – To disable the Override feature, select **<never overridden>**. To use the Override feature in accordance with the **Override Type** selected, select a time zone during which the override period is active.

Configure Assa Abloy Soft Input Points

The P2000 system monitors the following soft input points for Assa Abloy panels and terminals:

Low Battery (Low Batt) – Indicates that the wireless lock's battery is failing. Does not apply to wired locks.

Forced Door (Forced) – Indicates when the door has been opened without a valid badge having been presented to the reader first.

Out of Sync (OutOfSync) – Indicates when the DSR and lock are out of sync, which can be caused by numerous events (for example, downloading a badge with an invalid badge format for the lock or exceeding the number of time periods for the lock).

Propped Door (Propped) – Indicates when a door has been opened with a valid badge but has been held open longer than the shunt time.

177

Tamper – Indicates when someone has tampered with the lock or firmware.

Terminal Down (Term Down) – Since an Assa Abloy panel and terminal are essentially the same in the P2000 system, watch for panel down indications.

Panel Down (PanelDown) – Listed under **Soft Input Points** in the System Configuration tree; this soft input point indicates when panel communications have ceased.

To Configure Assa Abloy Soft Input Points:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand Assa Abloy Panels.
- 4. Expand Integration Components.
- 5. Expand the **DSR** that has the panel or terminal and the soft input point you wish to configure.
- 6. Expand the panel that has the terminal and soft input point you wish to configure.
- 7. Expand the terminal to view the available soft input points.
- 8. Right-click over the soft input point you wish to edit and select **Edit**. The Input Point dialog box opens. This dialog box consists of four tabs: **General**, **Alarm Options**, **I/O Linking**, and **Misc**.

Note: All of the fields on the **I/O Linking** and **Misc** tabs, including many fields on the **General** tab, cannot be modified.

 Modify the fields on the desired tabs accordingly. For information on the General and Alarm Options tabs, see Input Point Field Definitions on page 90.

10. Click OK.

Assa Abloy Status Information

The status of Assa Abloy components can be monitored on the P2000 System Status window.

DSR Status Information

The DSR is represented as an **Integration Component** in System Status with the following states:

- **Unknown** The status has not yet been determined.
- Up The P2000 system is communicating with the DSR.
- **Down** The P2000 system is not communicating with the DSR.

Panel and Terminal Status Information

Each **door lock** is represented in the P2000 system as a **panel** in System Status with the following states:

Unknown – The status has not yet been determined.

Up – The panel is currently online with the DSR.

Down – The panel is currently offline with the DSR. This is the normal state for wireless locks.

Disabled – The P2000 system has been instructed not to communicate with the panel.

Real Time Functions

When access is denied, the Real Time List shows one of three different reasons why access is denied.

- Invalid Card may be shown when a badge has recently expired. This situation is rare though, as the P2000 system deletes expired badges from the Assa Abloy system.
- Invalid Card Timezone is shown when a badge has access rights to the door, but not at the current time. This message is not generated for Assa Abloy PoE locks, but only the Assa Abloy Wi-Fi locks.
- Invalid Reader is shown for all other reasons, including:
 - the deadbolt is thrown
 - the lock is currently in Lockout mode
 - the Wi-Fi lock is currently communicating with the DSR
 - the badge is presented outside of a valid time zone
 - the presented badge is not known to the lock
 - the wrong card format was selected

Even though the last two cases traditionally would be mapped to an *Invalid Card* message, the information received from the DSR does not distinguish this case from some other cases that would traditionally be mapped to the *Invalid Reader* message. Therefore, the *Invalid Reader* message needs to be understood as the generic message for access being denied by an Assa Abloy lock.

For information, see Using the Real Time List on page 356.

Assa Abloy Wi-Fi locks are not permanently connected to the DSR. For this reason, real-time functions, such as operating a door, and real time database modification and event reporting are not supported. Communication between the DSR and the locks may be as frequent as once per day, but can be less frequent.

Assa Abloy PoE locks are permanently connected to the DSR, and real-time operations as well as real-time database modification and event reporting are supported.

Lockout Mode with Assa Abloy Locks

The P2000 Door Control application supports the ability to set an Assa Abloy door into **Lockout** mode. In this mode, the lock denies access to all users, except those that have the Assa Abloy Emergency privilege. P2000 operators cannot assign this privilege because of restrictions with the DSR.

For information see, Controlling Doors on page 303.

File Maintenance on the DSR Server

The DSR produces *.zip and *.log files that contain archived logs; and which are stored on the computer hosting the DSR. These files are normally located in the \Program Files\DSR\ logs and the \Program Files\DSR\logarchives folders.

However, the DSR does not purge them automatically or regularly.

To avoid running out of disk space on the computer that hosts the DSR, we recommend periodically deleting these files manually.

Configure Mercury Panels and Components

The P2000 system can communicate with a variety of Mercury Security Corporation's access control hardware products to provide access control, alarm monitoring, and other security operations.

Mercury panels offer different solutions to fit your access control needs, such as IP and Power over Ethernet (PoE) capabilities, up to 64 doors per panel, support for installations that use RS-485 communications, and other configuration options for small-to-large security applications, whether you are installing a new security system or retrofitting an existing one. The following panel types are supported:

Panel Type	Max. Number of Terminals
EP1501	17
EP1502	64
EP2500	64
Schlage PIM400-1501*	16
* Does not offer many o other Mercury panel typ	f the features provided with the es.

Before you use the functions described in this section, the Mercury hardware must be properly installed and configured to communicate with the P2000 system. Refer to the hardware installation instructions that were shipped with your Mercury equipment.

Once you define your Mercury panels, terminals, inputs, and outputs, see Configure Mercury Elevators on page 206 for specific instructions to implement elevator access control using Mercury panels, and also see Mercury Intrusion Interface on page 337 for specific instructions to implement intrusion detection using Mercury panels.

IMPORTANT: This P2000 software release is compatible with Mercury panels that use firmware Versions 1.17.3 and 1.18.7. Other versions may not be compatible with this release of the P2000 software.

Configure Mercury Facility Parameters

Before configuring Mercury hardware components, you must define facility wide settings associated with your Mercury devices.

To Configure Mercury Facility Settings:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Select **Mercury Panels** and click **Edit**. The Mercury Facility dialog box opens.
- 4. Fill in the information on each tab according to the following Mercury Facility Field Definitions.
- 5. As you work through the tabs, click **Apply** at any time to save your entries.
- 6. After you have entered all the information, click **OK** to save your settings.

Mercury Facility Field Definitions

Facility Tab

Use this tab to define access parameters associated with Mercury readers.

Mercury Fa	cility	
Facility Input	Point Calibration Card Format	
	Access Levels 32	
	Multi-Card Access Time Out (sec) 5	
PIN Duress		
	Mode Mercury Legacy Mode	•
	Offset / Append Value	¥
Cardholder	Privileges	
	ADA Indicator <pre></pre>	•
	VIP Indicator <pre></pre>	•
	OK Cancel	Apply

Access Levels – Displays the maximum number of access groups (up to 32), that can be assigned to a badge. **Multi-Card Access Time Out (sec)** – Enter the time in seconds (0 to 60) that the system waits for a subsequent card to be presented at readers that require more than one card.

Note: Changes to Multi-Card Access Time Out require performing a Panel Download procedure to all Mercury panels.

PIN Duress Mode – Select one of the following PIN code modes used for detecting duress:

- Mercury Legacy Mode Uses the normal duress PIN codes, where a value of 1 is added to the last PIN digit. For example, PIN 1234 would become 1235. If the last PIN digit is a 9, the last digit in the PIN code becomes 0, for example PIN 1239 would become 1230.
- PIN Append Appends a duress value (0 to 9) to the PIN code. For example, PIN 1234 with a duress value of 8 would become 12348.
- PIN Code Offset Adds a duress value (1 to 9) to the last PIN digit. For example, PIN 1234 with a duress value of 2 would become 1236, PIN 1239 would become 1231.

Offset / Append Value – Select the value that identifies the PIN append or PIN code offset value.

Note: Changes to the PIN Duress Mode and to the Offset / Append Value require restarting the P2000 Mercury Interface Service for the change to be effective. You must also download panel information to all Mercury panels.

Note: The following special access indicators allow a door's access time to be different. The ADA Indicator and VIP Indicator lists display the special access flag names as configured in Site Parameters; see page 35 for details. **ADA Indicator** – Select one of the three special access flags used by cardholders with ADA privileges and that require special access at a reader. Select **<none>** if special access is not required.

VIP Indicator – Select one of the three special access flags used by cardholders with VIP privileges and that require special access at a reader. Select **<none>** if special access is not required. A cardholder with VIP privileges is exempt from anti-passback checking, or exempt from entering a PIN code.

IMPORTANT: VIP privileges are not implemented in this release.

Note: Changes to the ADA or VIP indicators require restarting the P2000 Mercury Interface Service for the change to be effective. You must also download all badges to all Mercury panels.

Input Point Calibration Tab

Supervised inputs are calibrated by assigning the correct calibration table to the input point. The calibration tables defined in this tab specify the predefined mode of operation of Mercury inputs.

Mercury Facility	
acility Input Point Calibration Card Format	
Calibration Tables	
Liphan Normally Closed	
2kOhm Normally Open	
Special 1234 Ohm Normally Closed Special 1234 Ohm Normally Open	
Special 125 Form Hornory Open	
	Edit Add Delete

Mercury provides two standard tables for inputs with 1kOhm and 2kOhm as their normal state. If the input points need to use other resistances, click **Add** to create additional custom calibration tables.

	Table Name				
No.	Status Name	Priority	Status Code	Low Resistance	High Resistance
1	Supervisory fault, shorted circuit	1	3	-2	50
2	Supervisory fault, foreign voltage	1	5	50	850
3	Inactive, normal state of circuit	2	0	850	1150
4	Supervisory fault, foreign voltage	1	5	1150	1800
5	Active	0	1	1800	2200
6	Supervisory fault, foreign voltage	1	5	2200	25000
7	Supervisory fault, open circuit	1	4	25000	-1
8	Supervisory fault, ground fault	1	2	-4	-3

Enter the **Table Name** and double-click to edit any of the eight displayed set of values to define the possible states of the input circuit. The reporting **Priority** value must be between 0 (the highest) and 2.

The following tables show input calibration values for 1200 Ohm resistances:

Norma	Ily Closed	F	Normal	ly Opened
Status Code	Resistance Range		Status Code	Resistance Range
3 - short	-2 to 51	Ē	3 - short	-2 to 51
5 - fault	52 to 1053	Ē	5 - fault	52 to 516
0 - inactive	1055 to 1354	F	0 - inactive	517 to 688
5 - fault	1356 to 2122	Ē	5 - fault	689 to 1053
1 - active	2124 to 2671	Ē	1 - active	1055 to 1355
5 - fault	2674 to 23600	F	5 - fault	1356 to 23500
4 - open	23700 to -1	F	4 - open	23600 to -1
2 - short	-4 to -3		2 - short	-4 to -3

Note: The calibration values are based on the actual resistances of the input's states and the specific type of hardware device. Contact Mercury Technical Support for specific values.

Click **Save**. You can assign up to four of these calibration tables to each Mercury panel; see the General Tab on page 184 for more information.

Note: Mercury provides two standard settings for non-supervised inputs, Normally Open and Normally Closed. Those inputs do not require an Input Calibration table.

Card Format Tab

This tab determines the card formats to be used at Mercury readers. You can define up to 16 card formats to allow your facility to use badges with different facility codes, different data lengths, and so on. Once the selected card formats are defined, they are available for selection using the Card Type tab in the Mercury Terminal dialog box.

Order	Name	Facility Code	Offset	Function	Details
0	HID Corp 1000 FC 1646	1646	3344	Wiegand	0,35,0,0,0,0,12,2,20,14,0,0
1	Mag Stripe	3212	4156	Magnetic stripe	0,12,12,5,0,6,5,1,11
2	Not configured 2	0	0	No formatting	
3	Not configured 3	0	0	No formatting	
4	Not configured 4	0	0	No formatting	
5	Not configured 5	0	0	No formatting	
6	Not configured 6	0	0	No formatting	
7	Not configured 7	0	0	No formatting	
8	Not configured 8	0	0	No formatting	
9	Not configured 9	0	0	No formatting	
10	Not configured 10	0	0	No formatting	
11	Not configured 11	0	0	No formatting	
12	Not configured 12	0	0	No formatting	
13	Not configured 13	0	0	No formatting	
14	Not configured 14	0	0	No formatting	
15	Not configured 15	0	0	No formatting	
					Clear

With the exception of the **Order** field, you can select a row and click on any of the following fields to define your formats:

Note: The Order column displays the order in which the card formats are created. The first eight card formats are defined to work in offline mode. Verify that your reader terminals display the correct card formats; see Card Type Tab on page 194 for details.

Name – Enter the name you wish to give to the card format.

Facility Code – Enter the facility code of the card format. For *Card ID Without Facility Code* formats, you must enter -1.

Offset – Enter an offset number to add to the card number (based on the card format type) to create a unique card number.

Function – Select one of the following card types to use with the card format:

- No formatting
- Wiegand
- Magnetic stripe

Details – Click to open the Details dialog box to enter the details of the card format. Configuration of these fields depends on the card type selected, Wiegand, Magnetic stripe, and so on.



Flags – This field is not currently used. You may enter 0 under the corresponding bit number.

Total Length – Enter the total number of digits on a Wiegand card format.

Minimum and Maximum Number of Digits – Enter the minimum and the maximum number of digits required in a card format.

Even Parity Number of Bits – Enter the number of bits that are used to calculate even parity.

Even Parity Start Bit – Enter the starting bit position of the even parity.

Odd Parity Number of Bits – Enter the number of bits that are used to calculate odd parity.

Odd Parity Start Bit – Enter the starting bit position of the odd parity.

Facility Code Length and Position – Enter the number of bits or digits in the facility code and the position of the first bit or digit of the facility code in the card format.

Card Number Length and Position – Enter the number of bits or digits in the card number and the position of the first bit or digit of the card number in the card format.

Issue Level Length and Position – Enter the number of bits or digits in the issue level and the position of the first bit or digit of the issue level in the card format.

Click **OK** to return to the Card Format tab. If you wish to remove a card format, select the format and click **Clear**.

Commonly Used Card Formats

The following table displays values associated with the most popular card formats used at Mercury readers.

	Flag To Be Set to 1	Total Length	Minimum Number of Digits	Maximum Number of Digits	Even Parity Number of Bits	Even Parity Start Bit	Odd Parity Number of Bits	Odd Parity Start Bit	Facility Code Length	Facility Code Position	Card Number Length	Card Number Position	Issue Level Length	Issue Level Position
Magnetic Stripe (example)	-	-	12	12	-	-	-	-	5	0	6	5	1	11
26-bit Wiegand Standard	-	26	-	-	13	0	13	13	8	1	16	9	0	0
34-bit Wiegand Standard	1	34	-	-	0	0	0	0	-13	32	-16	16	-3	19
35-bit HID Corporate 1000	I	35	-	-	0	0	0	0	12	2	20	14	0	0
37-bit HID H10302	-	37	-	-	19	0	19	18	0	0	32	4	0	0
37-bit HID H10304	-	37	-	-	19	0	19	18	16	1	19	17	0	0
Card ID with Facility Code*	-	-	F + C	F + C	-	-	-	-	F	0	С	F	0	0
Card ID without Facility Code *	-	-	С	С	-	-	-	-	0	0	С	0	0	0

* F = number of digits in a facility code

C = number of digits in a card number.

Configure Mercury Panels

After you install the Mercury hardware and define facility parameters, you must configure the P2000 Server to communicate with Mercury panels by defining connection settings, time information, and other parameters.

Note: Encryption of all messaging between Mercury panels and the P2000 Server is done through the Transport Layer Security (TLS) protocol. The encrypted communication uses the **TLS If Available** setting, which is configured using Mercury's web browser interface.

To Configure Mercury Panels:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand Panels to display the panel types.
- 3. Select **Mercury Panels** and click **Add**. The Mercury Panel Edit dialog box opens.
- Fill in the information on each tab. (See Mercury Panel Field Definitions for details.)
- 5. As you work through the tabs, you may click **Apply** to save your entries.

IMPORTANT: You cannot modify certain panel parameters after you save the panel information in the database.

- Click OK to save the panel information. A message box displays asking if you wish to automatically add time zones to the new panel. If you select No, you can add the time zones later; see Configure Panel Time Zones on page 66.
- 7. If you select **Yes**, the time zones are automatically added. When you return to the System Configuration window, a new panel icon bearing the name assigned displays under the root Mercury Panels.

Note: In addition to applying time zones to the panels (described in Configure Panel Time Zones on page 66), you may also define panel holidays if you wish to restrict access in your facility during a holiday period; see Configure Panel Holidays on page 67.

IMPORTANT: After you create the panel and verify that it is online, you must download the panel information with the **Reset Panel Before Download** flag selected.

Mercury Panel Field Definitions

General Tab

eneral	Communicat	tions Downstre	am Connections Time Information	1	
				1	
		Partition:	Super User 💌	Public	
		Name:	Main Lobby 2500		
		i	Enabled		
		Query String:			
	Merci	ury Panel Type:	Mercury EP2500	•	
				_	
_					
Panel	I Inputs	Tamper	✓ Low Battery	Power Failure	
	t Calibration –				
Input	0000100011	Table 1	Special 1234 Ohm Normally Closed		•
Input		Table 1 Table 2	Special 1234 Ohm Normally Closed 2kOhm Normally Open		- -
Input	Comproduction	Table 1 Table 2 Table 3	Special 1234 Ohm Normally Closed 2kOhm Normally Open 1kOhm Normally Closed		। । ।
-Input		Table 1 Table 2 Table 3 Table 4	Special 1234 Ohm Normally Closed 2kOhm Normally Open 1kOhm Normally Closed		
Input		Table 1 Table 2 Table 3 Table 4	Special 1234 Ohm Normally Closed 2kOhm Normally Open 1kOhm Normally Closed <none></none>		•
Input		Table 1 Table 2 Table 3 Table 4	Special 1234 Ohm Normally Closed 2kOhm Normally Open 1kOhm Normally Closed <none></none>	. 1	

Partition – Select the partition that has access to this panel.

Public – Click Public to allow all partitions to see this panel.

Name – Enter a descriptive name for the panel.

Enabled – The system does not recognize the panel unless you click Enabled. To temporarily disable the panel, without having to delete or disconnect the panel, click again to clear the check box. When you disable a panel, the readers continue to grant access, but the panel does not communicate with the Server until you enable the panel again.

Query String – This value is used with message filtering; see Define Query String Filters on page 240.

Mercury Panel Type – Select a panel type. Certain features are enabled or disabled depending on the panel type selected here. Refer to the documentation that was shipped with your Mercury equipment for details specific to your panel type.

Note: You cannot change the **Mercury Panel Type** once you add the panel to the system.

Panel Inputs – Panel input points are automatically created for specific purposes. Enable:

- **Tamper** to indicate tampering if the panel is wired to a tamper switch on an enclosure.
- Low Battery to indicate that the battery is low.
- **Power Failure** to indicate a power failure if the panel uses a battery backup.

Input Calibration – Select the calibration tables that provide the predefined mode of operation of the input points defined for this panel. Calibration tables are defined in the Input Point Calibration tab in Mercury Facility, see page 180 for details.

This document contains confidential and proprietary information of Johnson Controls, Inc. © 2014 Johnson Controls, Inc.

Communications Tab

You cannot complete panel configuration unless you define these communication parameters.

Note: Changes in this tab do not take effect until you restart P2000 Mercury Interface Service.

C Mercu	ry Panel Edit			×
General	Communications	Downstream C	nnections Time Information	
Prima	ry Channel Cor	nection String: ximum Retries:	200.0.0.5	
Altern	ate Channel nable Cor	nection String:	200.0.23.28	
	Ма	kimum Retries:	8	
			OK Can	cel Apply

Primary Channel

Connection String – Enter the IP address that is used to connect to the panel. If you use a Dynamic Host Configuration Protocol (DHCP), enter the controller name in this field.

Maximum Retries – Enter the number of times that the Server tries to connect with the panel, after which the panel is considered offline.

Alternate Channel

Use the Alternate Channel box to configure Mercury EP2500 panels that have a second network connection through a Dual Ethernet interface. Dual Ethernet allows the alternate connection to take over the communications if the primary connection fails. Refer to the *EP2500 Hardware Installation* manual for configuration instructions.

Enabled – Click to enable the alternate connection.

Note: When you select or clear the **Enable** check box, Primary Channel and Alternate Channel soft input points are added or removed. Removing these points may result in unexpected consequences in some areas, such as Events and Actions. This change does not take effect until the Mercury Interface Service is restarted.

Connection String – Enter the IP address of the alternate connection. This entry should be from a different subnet address and must match the IP address at the panel. If you use a Dynamic Host Configuration Protocol (DHCP), enter the name of the alternate connection device.

Maximum Retries – Enter the number of times that the Server tries to connect with the panel, after which the panel is considered offline.

Downstream Connections Tab

IMPORTANT: You cannot modify certain parameters in this tab after you save the panel information in the database.

Mercury panels connect to their terminals using downstream ports. These ports contain parameters that define the port's behavior, including the type of devices that can be connected. The availability of the ports varies by panel type. Also, the options in the Mercury Terminal configuration depend on the choices made in the port definition.

imary 10/100 Ethernet ort 2 (RS-485) ort 3 (RS-485)	0 115200 115200	900 90 90	MSP1 MSP1 MSP1	Default Default
ort 2 (RS-485) ort 3 (RS-485)	115200 115200	90 90	MSP1 MSP1	Default
ort 3 (RS-485)	115200	90	MSP1	Default

Port – Displays the available ports for the selected panel type. See the following table for details.

Panel Type	Port	Protocol
Mercury	Primary 10/100 Ethernet	MSP1
EP1501	TB2 (RS-485)	MSP1 Direct Reader *
Mercury	Primary 10/100 Ethernet	MSP1
EP 1502	TB3 (RS-485)	MSP1
Mercury	Primary 10/100 Ethernet	MSP1
EP2000	Port 2 (RS-485)	MSP1 MSP1 MSP1 Schlage PIM MSP1
	Port 3 (RS-485)	MSP1 Schlage PIM
Schlage PIM400- 1501	TB2 (RS-485)	Schlage PIM (uses a fixed 9600 baud rate)
* Select Dir to use a rea bus.	ect Reader for the EP1501 ader on connector TB2 inst	panel if you want ead of an MSP1

Baud Rate – Select the specific baud rate for the selected port. Confirm that all terminals associated with the panel are set to the same baud rate. Mismatching of the baud rate between the panel and terminals causes the Real Time List to display a download failure message for the terminal. **Reply Timeout (ms)** – Select the time in milliseconds that the panel waits for a response.

Protocol – Select the type of protocol specific to the selected port; see the table on page 186 for details.

Dialect – Always use the Default setting.

Time Information Tab

The information in this tab defines time zone-related information and Daylight Savings Time (DST) settings.

	Time Information
Seneral Communications Downstream Connection	IS TIME INFORMATION
World Timezone Information	
(UTC-08:00) Pacific Time (US Cana	ida)
	Panel UTC Offset
Daylight Savings Time	
Daylight Savings Used	Hours Minutes
Added During Daylight Savings	01 00
Daylight Savings Begin	Daylight Savings End
Month March 💌	Month November
Week Of Month 2	Week Of Month 1
Day of Week Sunday	Day of Week Sunday
Hours Min Sec Time of Day 02 00 00	Hours Min Sec Time of Day 02 00 00
	OK Cancel Apply

Import World Time Zone Information – Click to select the time zone information that applies to the panel location.

Panel UTC Offset – Defines time offsets for remote panels, relative to Universal Time. Click the + or - radio button and enter the appropriate hours and minutes for the time offset.

Daylight Savings Used – When you select a time zone, the system uses the standard daylight savings time settings for the selected region, the panel's clock is automatically adjusted for daylight savings time. If you wish to change the default settings, click Daylight Savings Used and select:

- the Begin and End Month
- the Begin and End Week of Month
- the Begin and End Day of Week
- the Begin and End Time of Day

Added During Daylight Savings - A value of 1 hour is currently the world standard. You cannot change this value.

Configure Mercury Terminals

A variety of terminal types can be installed into Mercury panels to control devices such as card readers, inputs that control alarm monitoring devices, outputs that control other devices such lights or alarm annunciators, or they can be configured to control soft input points.

Each terminal installed in your system must be set up and configured in the P2000 software to establish communication and control. Once terminals are configured, they may be included in Terminal Groups to provide common access throughout your facility.

Understanding Terminal Siblings

The P2000 system considers each Mercury reader as its own terminal. Some Mercury Serial Input/Output (SIO) devices, such as the MR52, MR51e, and the on-board SIO devices on the EP1501 and EP1502 panels can have two reader terminals. The Aperio 1 to 8 Hub can have eight reader terminals, and the Schlage PIM400-485 can have 16 reader terminals on the same device.

Note: SIO devices are not necessarily serial devices or pure input/output devices.

The term *sibling*, refers to all terminals that are on the same SIO device; for example, a terminal on an MR52 may have up to one sibling, a terminal on a Schlage PIM400-485 may have up to 15 siblings. The following rules apply to terminal siblings:

- A terminal can only have siblings that are in the same panel.
- Terminals that are siblings to each other have the same SIO number.
- Terminals that are siblings to each other have the same address configuration (such as Port, Address, IP Address, or MAC Address), but a different Index.
- If you change the address configuration (such as Port, Address, IP Address, or MAC Address) of a terminal, the following warning message displays:

Mercury 1	Ferminal Edit	×
?	You are about to change the addressing information of an SIO device. This change affects all terminals residing on the same SIO device. Continue?	
	Yes No Cancel	

If you click **Yes**, the same change is also made to all siblings of the terminal.

 If you change the Enabled flag of a terminal, the following warning message displays:



If you click **Yes**, the same change is also made to all siblings of the terminal.

 Updating the firmware of a terminal applies automatically to all of its siblings. For Mercury terminals MR52, MR51e, and the on-board SIO devices on the EP1501 and EP1502 panels, the following additional rules apply:

Note: These rules do not apply to the Aperio 1 to 8 Hub or the Schlage PIM400-485 device.

- Siblings share their P2000 inputs and P2000 outputs on a first come first serve basis. This allows a more flexible assignment of inputs and outputs, in case one terminal needs more inputs/outputs than the other. For example:
 - Out of the 8 inputs of an MR52 there may be 6 assigned to terminal 1 and the remaining 2 to terminal 2.
 - Out of the 8 inputs of an MR52 there may be 8 assigned to terminal 1 and none left for terminal 2.
 - Out of the 8 inputs of an MR52 there may be 8 assigned to terminal 2 and none left for terminal 1.
 - Out of the 8 inputs of an MR52 there may be 4 assigned to terminal 1 and the remaining 4 to terminal 2.
- All inputs of an SIO device are equally visible in the System Configuration tree under the *Mercury Input Points* branch for all of the siblings on that SIO device.
- The System Configuration tree under the *P2000 Input Points* branch shows only P2000 inputs assigned to that specific terminal, and not to a sibling.
- All outputs of an SIO device are equally visible in the System Configuration tree under the *Mercury Output Points* branch for all of the siblings on that SIO device.
- The System Configuration tree under the *P2000 Output Points* branch shows only P2000 outputs assigned to that specific terminal, and not to a sibling.

To Configure Mercury Terminals:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **Mercury Panels** to display all Mercury panels configured in the system.
- 3. Expand the panel for which you wish to configure the terminal. All the items that can be configured for the panel are listed under it.
- 4. Select **Terminals** and click **Add**. The Mercury Terminal Edit dialog box opens at the General tab. Enter the information in each tab according to your system requirements. See the following Mercury Terminal Field Definitions for detailed information.
- 5. As you work through the tabs, click **Apply** to save your settings.
- 6. When all entries are complete, click **OK** to save the terminal information.
- 7. Continue to create terminals for every Mercury panel in which they are installed. If you wish to group Mercury terminals that provide common access, see Create Terminal Groups on page 85.

Note: If you delete a Mercury terminal from the system, you must download at a convenient time, all items to the affected panel with the **Reset Panel Before Download** flag selected. Failure to do so may prevent you from adding another terminal to the same address as the deleted terminal.

Mercury Terminal Field Definitions

General Tab

	vame prore	in onlygeing Area			_	
1	Panel Main	Lobby 2500				
Query S	String					
Nu	mber 7	•	Public			
Type and Address	Type MR5	2	V		SIO Number	1
	Port Port	2 (RS-485)		•		
👿 Reader		Add	Iress 1	•	Index	1
Entry		C IP Addre	ss •			
		C MAC Add	ress			
Soft Input Points			F - 1-	(12)		
Terminal Power P	-ar (21) (22)		Propped Doo	r (18) vor (24)		
PIN Code Retry	(19)		Duress (17))		
🗌 Soft In-X-It (23)						

Name – Enter a descriptive name for the terminal.

Panel – This field displays the name of the Mercury panel you selected from the System Configuration window.

Query String – This value is used with message filtering; see Define Query String Filters on page 240.

Number – Select a terminal number. Refer to your specific hardware configuration documentation if you need more information on terminal address assignment.

Public – If you use Partitioning, click Public if you wish the Mercury terminal to be visible to all partitions.

Enable – Click if you wish the system to recognize this terminal.

Type – Select the terminal module type installed. The specific number of readers, input points, output points, and the terminal features supported depend on the type of module selected here. You cannot change the terminal type after the terminal information is saved. The following table displays the options provided with each terminal type:

Terminal Type	Specification
EP1501 On-Board	up to 2 reader terminals * 2 input points 2 output points
EP1502 On-Board	2 reader terminals 8 input points 4 output points
MR50	1 reader terminal 2 input points 2 output points
MR51e	2 reader terminals 4 input points 2 output points
MR52	2 reader terminals 8 input points 6 output points
MR16in	16 input points 2 output points
MR16out	16 output points
MRDT (DM-21)	1 keypad display terminal
Schlage PIM400-485**	16 reader terminals ***
Aperio 1 to 8 Hub	8 reader terminals
 Available if the select you select the MSP1 terminal is available, 	ted protocol is Direct Reader. If protocol, then only one reader located on connector TB3.
** The Schlage PIM400 Schlage PIM400-150 the Schlage PIM prof	-485 reader is only available with 1 panels, or EP2500 panels with cocol selected.
***For performance rease exceed 8 reader term	sons, we recommend not to ninals for Schlage PIM400-485.

SIO Number – This field is available after the terminal is saved. It displays the Mercury Serial Input/Output (SIO) number assigned to SIO devices (the terminal types listed in the previous table), and is used for diagnostic purposes only. See Understanding Terminal Siblings on page 187 for additional information.

Port – Select the port that is specific to the terminal type. The availability of the ports varies by panel type and by selected terminal type. See Downstream Connections Tab on page 185 for more information. **Reader** – Click to define this terminal as a reader terminal. You must enter information on the Access, Card Type, and Input/Output tabs to complete the configuration. You cannot change this setting after the terminal is saved. Not available for MR16in or MR16out terminal modules. Select one of the following reader types from the drop-down list:

- Access Normal access reader.
- Entry Entry defined access reader.
- **Exit** Exit defined access reader.

Note: Entry and Exit terminals require cardholders to badge at Entry and Exit terminals alternately. For example, badging at an Entry terminal and then badging again at another Entry terminal is invalid. If Entry and Exit terminals are installed on the panel (must be installed on the same panel), this option must be enabled for the Entry and Exit requirements to operate.

Address – Select the address of the selected terminal module. Not available for MR51e modules. The address selection varies according to the terminal type selected.

Index – Select the index number of the selected terminal. The index selection varies according to the terminal type selected. The index specifies which reader terminal is defined, if there is more than one terminal available.

IP Address – Available for MR51e modules. Enter the IP address when using static IP addressing. See What to Do When Changing an MR51e IP Address on page 211 for additional information.

MAC Address – Available for MR51e modules. Enter the Media Access Control (MAC) address of the module when using DHCP. **Soft Input Points** –The P2000 system can monitor the following soft input points for Mercury terminals (the availability of these soft input points varies according to the terminal type selected):

- Terminal Power Fail (21) When enabled, an alarm is generated when the terminal device has a power failure.
- Terminal Tamper (22) When enabled, an alarm is generated to indicate a tamper condition if for example, the terminal device has been disturbed or removed from the wall.

The following soft input points are only available for Reader type terminals.

- PIN Code Retry (19) When enabled, an alarm is generated when three consecutive invalid PIN codes are entered at a keypad reader.
- Soft-In-X-It (23) This soft input point is only available for Entry or Exit readers. When enabled, an alarm is generated when the system detects an entry/exit violation.
- Forced Door (18) When enabled, an alarm is generated when a door has been opened without the door being unlocked.
- Propped Door (24) When enabled, an alarm is generated when a door has been held open longer than allowed.
- Duress (17) When enabled, an alarm is generated if the system detects a duress condition. See page 180 for the different duress mode definitions.

Reader Tab

I	C Mercury Terminal Edit		
	General Reader Access Card	Type Input / Output	
	ACR Number	4	
	Reader Configuration	Paired, Master]
	Paired Reader Terminal	Marketing Conference Room]
	Keypad Mode	Motorola / Indala 8-bit]
	LED Mode	Separate red and green, no buzzer]
	Offline Reader Mode	No Change]
	Default Reader Mode	Card Only]

ACR Number – This field is available after the terminal is saved. It displays the Access Control Reader (ACR) number assigned to the reader, and is used for diagnostic purposes only.

Reader Configuration – This field defines the hardware operation of the reader. Select one of the following:

- Single The reader operates as a single reader.
- Paired, Master The reader operates as the master reader in a paired reader configuration.
- Paired, Slave The reader operates as the slave reader in a paired reader configuration.

Note: In paired reader mode, the master reader controls the access, and the slave reader makes access requests to the master reader.

- Turnstile The reader provides turnstile access. Security personnel can provide access through turnstile devices using a single badge to control and count the flow of pedestrian traffic in and out of a facility.
- Elevator without feedback This option is not available for selection. It displays in this field after the reader is assigned to an elevator without the *Floor Tracking* option selected; see page 207 for details.

 Elevator with feedback – This option is not available for selection. It displays in this field after the reader is assigned to an elevator with the *Floor Tracking* option selected; see page 207 for details.

Paired Reader Terminal – If your reader operates as a master reader, select the slave reader that defines the paired reader configuration. If your reader operates as a slave reader, then select the master reader that defines the paired reader configuration. You can only select reader terminals that are installed on the same panel.

Keypad Mode – If this is a keypad reader, select one of the following keypad modes to be used with your reader.

- <none>
- Motorola / Indala 8-bit
- HID 4-bit
- MR20 8-bit with tamper
- MR20 8-bit without tamper

Note: Some Schlage Magstripe keypad readers are not compatible with Motorola/Indala 8-bit. For those Schlage devices, select MR20 8-bit without tamper.

LED Mode – Select one of the following LED modes associated with the reader:

- none>
- Separate red and green, no buzzer
- Generic 1-wire, tri-state, bi-color
- Dorado 780
- LCD

Offline Reader Mode – This option is not available for Schlage or Aperio readers. Select one of the following behavior modes of the reader if the terminal loses communication with the panel:

- No Change
- Disable Reader, no REX
- Unlocked
- Locked (No Access, REX Active)
- Facility Code Only

Default Reader Mode – Select one of the following reader default mode of operation (make your selection after the panels starts up):

- Disable Reader, no REX
- Unlocked
- Locked (No Access, REX Active)
- Card Only
- Card and PIN Required

Note: Changes to the Default Reader Mode become effective after you download all items to the affected panel, with the **Reset Panel Before Download** flag selected. Otherwise, changes become effective the next time the panel is restarted.

Access Tab

C Mercury Terminal Edit	and Turpe [Torout / Output]		×
Access Access Time Access Time Shunt Time Door Open Warning Time	5 seconds 10 seconds 5 seconds 1 minutee	Minimum Access Time 1 Anti-Tailgating Re-lock on Shunt Only on REX Allow PIN before Badge	Seconds
Assisted Access Assisted Access Time Assisted Shunt Time	15 seconds 20 seconds	ADA Relay Mode <pre></pre>	1 00 ms
		OK	Cancel Apply

Access Time – Enter the time in seconds that the door remains unlock to provide access.

Minimum Access Time – Enter the minimum access time in seconds. This access time is used in combination with the Re-lock on Open option selected in the Anti-Tailgating field.

Shunt Time – Enter the time in seconds that the door alarm is suppressed to allow access at the door. The shunt time should be longer than the access time.

Anti-Tailgating – Select one of the following anti-tailgating modes that occur to prevent more than one person accessing a controlled area with a single card transaction:

- <none> This option is only available for Aperio 1 to 8 Hub terminal type.
- Re-lock on Open Select to lock the door immediately when the door opens to prevent reopening the door on one card access. The door does not relock until the Minimum Access Time has elapsed.
- Re-lock on Close Select to lock the door immediately when the door closes to prevent reopening the door on one card access.

Door Open Warning Time – Enter the time in seconds before the Shunt Time expires, to warn operators that the door is still open. The maximum time must be 2 seconds less than what is configured for the Shunt Time. For example, if the Shunt Time is set for 10 seconds, then the maximum Door Open Warning time must be 8 seconds. This option only works in conjunction with Mercury Triggers of category *Door Status* and type *Open Pre-Alarm Only*, otherwise the seconds entered here are ignored; see Configuring Triggers on page 204 for more information.

Anti-Passback – Select to enable the anti-passback feature to prevent cardholders from using their badge again at this reader until the anti-passback time entered expires. **Note:** If cardholders use their badge at a different reader on the same panel and are granted access, the system resets the anti-passback period to its initial value.

Shunt Only on REX – If enabled, the door alarm is suppressed when a Request to Exit (REX) input signal is received from a REX device associated with the reader, which prompts the door contact to be shunted without setting off the alarm.

Allow PIN before Badge – If enabled, the cardholder can enter the PIN number before presenting the badge. The cardholder must press the <#> key after entering the PIN number.

Two Badge Access – If enabled, the system requires presenting two badges to grant access.

Cardholder Override – If enabled, an authorized cardholder may place the reader in a shunt time override condition by performing a badging procedure at the reader's keypad. The cardholder must have the Override option enabled in the Badge dialog box. Follow these instructions to perform a cardholder override at a keypad:

- 1. Present a valid badge.
- Enter the following key sequence at the keypad: *, 0, nnn, # (nnn is the desired shunt time in minutes, with leading zeros if necessary).

Note: You must enter the key sequence within 30 seconds after badging at the reader.

Soft-In-X-It – Available for entry or exit readers. If enabled, this function overrides the system entry and exit control function and allows cardholders to gain access at that reader even though they have the wrong entry and exit status. An alarm is generated when a violation occurs.

Assisted Access Box

The Assisted Access option allows you to set up a different access time, to satisfy the requirements for assisted access according to ADA (Americans with Disabilities Act).

Note: Schlage readers support the Assisted Access feature if connected to Mercury EP2500 panels that use firmware version 1.18.5.

Assisted Access Time – Enter the time in seconds that the door remains unlocked to provide additional access time to cardholders with special needs.

Assisted Shunt Time – Enter the time in seconds that the door alarm is suppressed to allow additional access time to cardholders with special needs. The assisted shunt time should exceed the assisted access time by the same amount that the regular shunt time exceeds the regular access time.

ADA Relay Mode – Select one of the following relay modes that specifies the time the ADA relay is activated minus any ADA Relay Delay.

- <none> if there is no ADA Relay support.
- Same as Access Time if an ADA Relay is used, make sure you select the ADA Relay button in the Input/Output tab.

Note: Activation of the ADA Relay is independent of the special ADA access flag assigned to a cardholder. Also, you must define a Door Contact to make the ADA Relay work, and you must also define the reader on the same terminal as the Door Strike.

ADA Relay Delay – Enter the amount of time (in 100 milliseconds) that needs to elapse after the door is unlocked before the ADA Relay is activated. This may be necessary to avoid operating the door-opening device before the door is fully unlocked.

Card Type Tab

G Mercury Terminal Edit	
General Reader Access Card Type Input / Output	
Card Data Formatting	
Data1 / Data0, Wiegand Pulses	Card ID
Trim Zero Bits	
Format To Nibble Array	
Allow Bi-Directional Mag Decode	
Cond France Transmith Office Connect	Conference Transmitter to Constant
Card Pormat Types with Omine Support	Card Format Types without Omine Support
FID Corp 1000 FC 1646	Not Present
Mag Stripe	Not Present
🗖 Not Present	Not Present
Not Present	Not Present
Not Present	Not Present
Not Present	Not Present
Not Present	Not Present
Not Present	Not Present

Card Data Formatting – Select the type of card format to be used with this reader.

- For magnetic stripe cards, select the *Trim* Zero Bits and Format To Nibble Array formats. Make sure the Data1 / Data0, Wiegand Pulses format is not selected.
- For magnetic stripe cards, you can select the *Allow Bi-Directional Mag Decode* format to also read cards that are reverse swiped.
- For readers that send their input as a Wiegand signal, select the *Data1 / Data0*, *Wiegand Pulses* format and make sure the *Trim Zero Bits*, *Format To Nibble Array*, and *Allow Bi-Directional Mag Decode* formats are not selected.

Card Format Types with Offline Support – Select the card types to be used with this reader. These card types are configured using the Card Format tab in Mercury Facility; see page 181 for details. These formats are defined to work in offline mode.

Card Format Types without Offline Support – Select the card types to be used with this reader. These card types are configured using the Card Format tab in Mercury Facility; see page 181 for details. These formats do not work in offline mode.

Input/Output Tab

Settings in this tab define how inputs and outputs behave when activated. Not available for MR16in or MR16out terminals. You must save the terminal information before you access this tab.

Door Contact		
Enable	Terminal Main Entrance 52 (Local) Input	1 💌
Debounce Scan Count 3	Hold Time 5 sec. Calibration Normally Closed	•
Primary REX		
Enable	Terminal Main Entrance 52 (Local) Input	2 🔻
Debounce Scan Count 4	Hold Time 6 💌 sec. Calibration IK OHM Normal	¥
Secondary REX		
Enable	Terminal Main Entrance 52 (Local)	5 💌
Debounce Scan Count 4	Hold Time 7 sec. Calibration Normally Closed	¥
Strike		
Enable	Terminal Main Entrance 52 (Local) Output	1 💌
	Drive Mode Normal Offline Mode Active	-
Shunt / ADA Relay		
C Not used	Terminal Main Entrance 52 (Local) Output	2
C Shunt Relay	Drive Made Normal	-
ADA Relay	onnie Hode Inacive	-

Door Contact

Enable – Click to enable the Door Contact input point. If enabled, an alarm is generated when the door detects a forced door or propped door condition.

Terminal – Select the terminal associated with the door contact input point. The terminal list includes only terminals that are configured in the same panel.

Input – Select the Door Contact input point number that receives signal from the door contact associated with the terminal.

Debounce Scan Count – Select the number of consecutive input scans that must agree, before a change of state is reported. Each scan period is 16.7 milliseconds.

Hold Time – Select the number of seconds (2 to 15) to hold a higher priority status before a lower priority status is reported. Select 0 to prevent any hold time.

Calibration – Select the calibration table that provides the predefined mode of operation of the Door Contact input point. You can define additional calibration tables by using the Input Point Calibration tab in Mercury Facility; see page 180 for details.

Primary REX

Enable – Click to enable the primary Request to Exit (REX) input point. If enabled, the door is unlocked, or only shunted when the Shunt Only on REX flag is selected.

Terminal – Select the terminal associated with the REX input point. The terminal list includes only terminals that are configured in the same panel.

Input – Select the REX input point number that receives signal from the primary REX associated with the terminal.

Debounce Scan Count – Select the number of consecutive input scans that must agree, before a change of state is reported. Each scan period is 16.7 milliseconds.

Hold Time – Select the number of seconds (2 to 15) to hold a higher priority status before a lower priority status is reported. Select 0 to prevent any hold time.

Calibration – Select the calibration table that provides the predefined mode of operation of the primary REX input point. You can define additional calibration tables by using the Input Point Calibration tab in Mercury Facility; see page 180 for details.

Secondary REX

Enable – Click to enable the secondary Request to Exit (REX) input point. If enabled, the door is unlocked, or only shunted when the Shunt Only on REX flag is selected. **Terminal** – Select the terminal associated with the REX input point. The terminal list includes only terminals that are configured in the same panel.

Input – Select the REX input point number that receives signal from the secondary REX associated with the terminal.

Debounce Scan Count – Select the number of consecutive input scans that must agree, before a change of state is reported. Each scan period is 16.7 milliseconds.

Hold Time – Select the number of seconds (2 to 15) to hold a higher priority status before a lower priority status is reported. Select 0 to prevent any hold time.

Calibration – Select the calibration table that provides the predefined mode of operation of the secondary REX input point. You can define additional calibration tables by using the Input Point Calibration tab in Mercury Facility; see page 180 for details.

Strike

Enable – Click to enable the Strike output point.

Terminal – Select the terminal associated with the door strike output point. The terminal list includes only terminals that are configured in the same panel.

Output – Select the door strike output point number that is activated after each valid badge access request.

Drive Mode – Select one of the following modes that define the door strike output point behavior upon activation:

 Normal – This mode locks the door when the strike output state is Inactive, and unlocks the door when the strike output state is Active. Inverted – This mode unlocks the door when the strike output state is Inactive, and locks the door when the strike output state is Active.

Offline Mode – Select one of the following modes that define the door strike state when the terminal goes offline:

- No Change The strike output state does not change.
- Inactive This mode locks the door when the strike output drive mode is Normal, and unlocks the door when the strike output drive mode is Inverted.
- Active This mode unlocks the door when the strike output drive mode is Normal, and locks the door when the strike output drive mode is Inverted.

Shunt/ADA Relay

Note: The Shunt Relay or ADA Relay output point is always defined as the next output point of the selected Strike output point. If the Shunt Relay or ADA Relay output point is not available, the **Not used** option is automatically selected. Also, you must define a Door Contact to make the Shunt Relay or ADA Relay work, and you must also define the reader on the same terminal as the Door Strike.

Not used – Select if there is no output relay connected to the reader.

Shunt Relay – Select if the relay is connected to an output point that indicates a shunt condition.

ADA Relay – Select if the relay is connected to an output point that controls a door opening device.

Terminal – Displays the name of the terminal associated with the shunt/ADA relay output point.

Output – Displays the shunt/ADA relay output point number that is activated after each valid badge access request.

Drive Mode – Select one of the following modes that define the output point behavior upon activation:

- Normal This mode sets the output point if the output state is Active, and resets the output point if the output state is Inactive.
- Inverted This mode resets the output point if the output state is Active, and sets the output point if the output state is Inactive.

Offline Mode – Select one of the following modes that define the output point state when the terminal goes offline:

- No Change The output state does not change.
- Inactive This mode resets the output point when the output drive mode is Normal, and sets the output point when the output drive mode is Inverted.
- Active This mode sets the output point when the output drive mode is Normal, and resets the output point when the output drive mode is Inverted.

Configure Mercury Inputs

The Mercury configuration provides several types of input points. Some of these input points have a predefined and unchanging purpose, such as to indicate panel tamper. Other input points are dedicated to access control functions, such as receiving input from door contacts and REX devices; and other input points can be used for a variety of purposes and devices, such as power failure.

The system automatically creates panel input points under the selected Mercury panel and can be enabled for alarm and non-alarm purposes.
The system also automatically creates two sets of terminal input points under the selected terminal: P2000 Input Points and Mercury Input Points. The terminal hardware type determines the available number of input points on both sets. See the table on page 189 for the number of inputs provided with each terminal type.

Before you configure your input points, you should note that:

 You cannot add or delete Mercury Input Points; those input points are associated with other Mercury components, such as P2000 general inputs or Door Contact inputs. You can configure P2000 Input Points to indicate the current state of a device, and also for alarm or non-alarm purposes.

The System Configuration window displays the following icons associated with Mercury input points:

- → Not Used
- P2000 General Purpose Input
- Door Contact
- REX (primary or secondary)
- Elevator Floor

The following possible input points are available:

Input Type	Input Name	Generated for	Description
Panel Soft Inputs	Panel Down	All Mercury panels.	Internal to the P2000 system to indicate that the panel is not active.
Panel Inputs	Panel Tamper	Mercury panels with Panel Inputs enabled (availability of	Typically wired to a tamper switch on an enclosure to indicate tampering.
	Panel Battery pa	these inputs depends on the panel type selected).	Indicates when the battery in the panel is low.
	Power Failure		With battery employed, this input point indicates power failure.
	Primary Ch	EP2500 Mercury Panels with Dual Ethernet communication	Indicates the panel primary communica- tion channel status.
	Alternate Ch	enabled.	Indicates the panel alternate communica- tion channel status.
Terminal Soft Inputs	Term Down	All Mercury terminals.	Indicates that panel communications have ceased.
Terminal Inputs	rminal Inputs Terminal Power Mercury terminals v Fail Input Points enable		Indicates power failure.
	Terminal Tamper	ability of these inputs depends on the panel type	Typically wired to a tamper switch to indi- cate tampering.
	Terminal Lost AC		Indicates when the reader has lost power.
	Forced Door	Mercury terminals with Soft Input Points enabled. The Reader option must be selected (availability of these inputs depends on the panel type selected).	Indicates when a door has been opened without the door being unlocked.
	Propped Door		Indicates when a door has been held open longer than allowed.
	Duress		Indicates when the system detects a duress condition. See page 180 for duress mode definitions.
	PIN Code Retry		Indicates when three consecutive invalid PIN codes are entered at a keypad reader.
	Soft-In-X-It		Indicates when there is an entry/exit viola- tion.

To Configure Mercury Inputs:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **Mercury Panels** to display all Mercury panels configured in the system.
- 3. Expand the panel for which you wish to configure the input point.
 - To configure panel inputs, expand **Panel Input Points**, select the input point you wish to configure and click **Edit**.
 - To configure terminal inputs, expand the terminal that contains the input point you wish to configure, expand **Input Points**, then expand **P2000 Input Points**, either click **Add** or select the input point you wish to configure and click **Edit**.

The Edit P2000 Input Point dialog box opens at the General tab.

- 4. Enter the information in each tab according to your system requirements. The fields available for configuration depend on the type of input point selected. (See Mercury Input Field Definitions for detailed information.) As you work through the tabs, click Apply to save your settings.
- 5. When you finish with all the entries, click **OK** to save the input information.

Mercury Input Field Definitions

General Tab

C Edit P2000 Input Point	
General Alarm Options 1	Mercury
Partition	Super User 🔽 🔽 Public
Name	Motion Sensor Number 1
	Query String
Status	Enable
	OK Cancel Apply

Partition – Select the partition that has access to this input point.

Public – Click Public to allow all partitions to see this input point.

Name – Enter a descriptive name for the input point.

Number – Select an input point number. This number is always associated with the input point number automatically created under the Mercury Input Points.

Query String – This value is used with message filtering; see Define Query String Filters on page 240.

Status – Select **Enable** to report all input point changes of state. Select **Disable** if you do not want these changes reported.

Alarm Options Tab

C Edit P2000 Input Point	ξ
Select Alarm Categories	
P2000	Edt
Add Delete	
	OK Cancel Apply

Alarm options are described in detail on page 91.

Mercury Tab

Since Mercury Input Points (automatically created for Mercury terminals) are not configurable, use this tab to define parameters associated with those input points.

🛱 Edit P2000 Input Point	×
General Alarm Options Mercury	
	Calibration Normally Closed
	Debounce Scan Count 5
	Hold Time 2 Seconds
Monitor	
Monitor Point Number	
Log Type All	Entry Delay 5 Seconds
Mode Latching	Exit Delay 5 Seconds
	OK Cancel Apply

Calibration – Select the calibration table that provides the predefined mode of operation of this input point. You can define additional calibration by using the Input Point Calibration tab in Mercury Facility; see page 180 for details. **Debounce Scan Count** – Select the number of consecutive input scans that must agree, before a change of state is reported. Each scan period is 16.7 milliseconds.

Hold Time – Select the number of seconds (2 to 15) to hold a higher priority status before a lower priority status is reported. Select 0 to prevent any hold time.

Monitor Point Number – Displays the internal Mercury monitor point number associated with this input point. Used for diagnostic purposes only.

Log Type – Select one of the following log types that are used for status notifications:

- All logs all status change.
- No Change-of-State does not log any contact changes of state when the input point is in suppression mode.
- No Fault-to-Fault in addition to the *No Change-of-State* log type, this log type does not log any contact changes of state if the contact's fault to fault status changes, when the input point is in suppression mode.

Mode – Select one of the following entry and exit delay modes:

- Normal if there is no entry or exit delay.
- Non-latching if the input point goes into alarm state and then immediately returns to the secure state (within the entry delay), then the alarm would not go off. This transaction is not reported to the Alarm Monitor.
- Latching if the input point goes into alarm, regardless if the input point is secure, the alarm goes off, (unless the input point is suppressed). This transaction is reported to the Alarm Monitor and the Real Time List.

Entry Delay – Enter the time in seconds (from 0 to 65,535) that the system delays reporting an entry. This value must be 0 if the entry/exit Mode selected before is *Normal*.

Exit Delay – Enter the time in seconds (from 0 to 65,535) that the system delays reporting an alarm after the input point is unsuppressed. This value must be 0 if the entry/exit Mode selected before is *Normal*.

Configure Mercury Outputs

Mercury outputs are provided to trigger external devices, such as lights and sirens, or can be activated in response to access transactions, such as controlling a door strike or shunting an alarm.

The system automatically creates two sets of terminal output points under the selected terminal: P2000 Output Points and Mercury Output Points. The terminal hardware type determines the available number of output points on both sets.

As in the input point configuration, you cannot add or delete Mercury Output Points; those output points are associated with other Mercury components, such as P2000 general outputs or Elevator Floor outputs.

The System Configuration window displays the following icons associated with Mercury output points:

- /> Not Used
 - P2000 General Purpose Output
- 📁 🗧 Strike
- Shunt / ADA Relay
- Elevator Floor

To Configure Mercury Outputs:

- 1. In the System Configuration window, expand the terminal that contains the output you wish to configure.
- 2. Expand **Output Points**, then expand **P2000 Output Points** and click **Add**. The Edit Mercury Output Point dialog box opens.

Paruuon	Super User	•	Public
Name	Lobby Siren		Number 1
Query String			
Status	Enable	•	
Control Point Number Drive Mode Nor Active State Flac Duration 15	mal 💌	Offline Mor Flash Option On Time 35 Off Time 35 Repeat Count 5	ie Active

- 3. If you use partitions, select the appropriate **Partition** that has access to this output point.
- 4. If you use partitions, click **Public** if you want this output point to be visible to all partitions.
- 5. Enter a descriptive **Name** for the output point.
- 6. Select the output point **Number**. This number is always associated with the output point number automatically created under the Mercury Output Points.
- 7. The Query String value is used with message filtering; see Define Query String Filters on page 240.

- From the Status drop-down list, select Enable if you wish to allow the output point to be activated or deactivated.
- 9. The **Control Point Number** displays the internal Mercury control point number associated with this output point. Used for diagnostic purposes only.
- 10. Select one of the following **Drive Modes** that define the output point behavior upon activation:
 - Normal This mode sets the output point if the output state is Active, and resets the output point if the output state is Inactive.
 - Inverted This mode resets the output point if the output state is Active, and sets the output point if the output state is Inactive.
- 11. Select one of the following **Offline Modes** that define the output point state when the terminal goes offline:
 - No Change The output state does not change.
 - **Inactive** Resets the output point when the output drive mode is Normal, and sets the output point when the output drive mode is Inverted.
 - Active Sets the output point when the output drive mode is Normal, and resets the output point when output drive mode is Inverted.

- 12. Select one of the following **Active States** that are used with the *Preset* command in the Output Control application:
 - **Reset** to reset the output point.
 - Set to set the output point.
 - **Flash** to toggle the output point on and off with the specified On Time and Off Time pattern.
 - **Timed** to turn on the output point for the specified time entered in the **Duration** field.
- 13. If the Active State is Timed, enter the **Duration** in seconds that the output point is turned on.
- 14. If the Active State is Flash, enter the following parameters:
 - On Time to toggle the output point on for the time specified here.
 - **Off Time** to toggle the output point off for the time specified here.
 - **Repeat Count** the number of times to repeat the flash cycle.
- When you finish with all the entries, click OK to save your settings.

Configure Mercury Procedures and Triggers

You can set up terminals, inputs, or output points to initiate specific actions based on input points or time zones changes of state.

Mercury Procedures and Triggers affect only the panel for which they are configured. Triggers define the actions (procedures) that must be performed when the specified Trigger Category selected changes state.

For example, you can define triggers that suppress an input point, activate or deactivate an output point, or temporarily change the reader mode of operation whenever a specified time zone becomes active or inactive.

Configuring Procedures

Procedures allow you to define a sequence of actions that can be executed based on the selected trigger category. For example, a procedure could unlock a door, suppress an alarm, and then turn on the lights. You can create several actions within a procedure that can occur in the order they are defined.

To Configure a Procedure:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand Mercury Panels to display all Mercury panels configured in the system.
- 3. Expand the panel for which you wish to define a procedure.
- 4. Select **Procedure** and click **Add**. The Mercury Procedure Edit dialog box opens.

	Proced	ure Name: Clea	rring Crew Access	I⊽ Put	blic	
	Qu	ery String:				
No.	Group	Category	Type	Item	Value	Details
1	1	Input	Suppress	Motion Sensor	On	
2	1	Terminal	Set Reader Mode	Marketing Conference Room	Unlock	
3	1	Output	Activate	Emergency Lights		
4	2	Output	Deactivate	Emergency Lights		
5	2	Terminal	Set Reader Mode	Marketing Conference Room	Card Only	
6	2	Input	Suppress	Motion Sensor	Off	

- 5. Enter a descriptive Procedure Name.
- 6. Click **Public** to allow all partitions to see this procedure.
- 7. The Query String value is used with message filtering; see Define Query String Filters on page 240.
- 8. Click **Add**. The action number automatically displays in the **No.** column.
- 9. Select the row, click the corresponding **Group** field, and select a group number from 1 to 4. Only actions that belong to the group selected in the Mercury Trigger definition will be activated.
- 10. Click the corresponding **Category** field and select Terminal, Input, Output, or Timezone. The choices in the **Type**, **Value**, and **Details** columns determine how the terminal, input, output, or timezone behaves upon activation. The following table describes all possible action types.

Category	Туре	Value	Details
Terminal	Open for Access Time – unlocks the door for the amount of time set in the Access Time field defined for the Terminal.		
	Set Reader Mode – sets the reader mode of operation to the option selected in the Value field.	Card Only – a card is required for access. Card with PIN – a card and a PIN are required for access. Disable, REX Off – the reader is disabled; request to exit is not allowed. Lock, REX On – the reader is locked; request to exit is allowed. Unlock – the reader is unlocked.	
	Suppress Forced Door – activates or deactivates the forced door suppression, according to the option selected in the Value field.	On Off	
	Suppress Propped Door – activates or deactivates the propped door suppression, according to the option selected in the Value field.	On Off	
	Temporary Set Reader Mode – tempo- rarily sets the reader mode of operation to the option selected in the Value field.	Card Only – a card is required for access. Card with PIN – a card and a PIN are required for access. Disable, REX Off – the reader is disabled; request to exit is not allowed. Lock, REX On – the reader is locked; request to exit is allowed. Unlock – the reader is unlocked.	Enter the temporary duration in minutes to set the reader mode.
Input	Suppress – activates or deactivates the input point suppression, according to the option selected in the Value field.	On Off	
Output	Activate – activates the output point.		
	Deactivate – deactivates the output point.		
	Flash – toggles the output point on and off during the specified On Time and Off Time selected in the Value field. You must also enter the number of times to repeat the flash cycle.	On Time Off Time Repeat Count	
	Timed Pulse – turns on the output point for the specified number of seconds entered in the Value field.	Enter the number of seconds the output point shall be on.	
Timezone	Active – activates the selected time zone.		
	Deactive – deactivates the selected time zone.		
	Release – returns the selected time zone to its scheduled setting.		

Note: The **Timezone** procedure category allows a reader terminal behavior to be controlled by a predicted time schedule, such as a coming snow storm.

- 11. Click the corresponding **Item** field and select the name of the terminal, input, or output.
- 12. If you wish to add additional actions to the procedure, click **Add** and repeat the previous steps.
- 13. The actions within a procedure are executed in the order they are added. If you wish to change the sequence of the actions, select the action line and click **Up** or **Down**.
- 14. Once you define your actions, click **Apply** or **OK** to save the Procedure.

Configuring Triggers

Triggers are defined to detect a specific transaction, such as a time zone or input point change of state, and to invoke a procedure that in turn executes a list of actions.

To Configure a Trigger:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **Mercury Panels** to display all Mercury panels configured in the system.
- 3. Expand the panel that contains the trigger you wish to configure.
- 4. Select **Trigger** and click **Add**. The Mercury Trigger Edit dialog box opens.

C Mercury Trigg	per Edit X
Name:	Special Access
	Public
Query String:	✓ Enabled
Group:	1
Category:	Timezone
Type:	Active
Item:	After Office Schedule
Procedure:	Cleaning Crew Access
	Ok Cancel

- 5. Enter a **Name** to describe the function of the trigger.
- 6. Click **Public** to allow all partitions to see this trigger.
- 7. The Query String value is used with message filtering; see Define Query String Filters on page 240.
- 8. Click **Enabled** to allow the system to perform the trigger.
- 9. Select a **Group** number from 1 to 4. Only actions that belong to this group can be triggered.
- 10. Select from the **Category** drop-down list if the trigger is to be activated by **Door Status**, **Input Point** changes, or **Timezone** transitions.
- 11. If you selected **Door Status**, select from the **Type** drop-down list if the trigger is initiated when the door status is Door Closed, Door Opened, Forced Open Cancelled, Held Open Cancelled, Held or Forced Open Cancelled, or Open Pre-Alarm Only.

If you selected **Input Point**, select from the **Type** drop-down list if the trigger is initiated when the input goes into Alarm, Fault, or Secure state. If you selected **Timezone**, select from the **Type** drop-down list if the trigger is initiated when the time zone becomes Active or Inactive.

- 12. Select from the **Item** drop-down list, the name of the door, input point, or time zone that activates the trigger upon change of state.
- 13. Select the **Procedure** that contains the actions that can be activated when the selected item changes state.
- 14. Click **Apply** to save the Trigger information.

In the following example, the procedure provides access to the cleaning crew. First, the door alarm is suppressed, the door is unlocked, and the lights turn on. These three actions belong to Group 1.

The defined trigger specifies that all three actions in Group 1 will be triggered when the selected time zones becomes active.

You can create another trigger that includes the defined Group 2 actions, and that will be triggered when the selected time zone becomes inactive.

	Procedu	re Name: Clea	ning Crew Access	IV ₽	ublic		
	Que	ery String:					
	Group	Category	Туре	Item	Value	Details	
	1	Input	Suppress	Motion Sensor	On		
	1	Terminal	Set Reader Mode	Marketing Conference Room	Unlock		
	1	Output	Activate	Emergency Lights			
	2	Output	Deactivate	Emergency Lights			
	2	Terminal	Set Reader Mode	Marketing Conference Room	Card Only		
	2	Input	Suppress	Motion Sensor	Off		
		_					
• N	Iorcum Tria	non Edit		T			
					Triggor Edit		
	rereary ringe	jer talt	E	X G Mercury	Trigger Edit		
	rereary ring <u>e</u>	Jer tuit		X C Mercury	Trigger Edit		
	Name:	Special Acces	s	Na C Mercury	Trigger Edit	al Access	
	Name:	Special Acces	is		me: End Specie	al Access	
	Name:	Special Acces	15 	× C Mercury	Trigger Edit me: End Speci	al Access	
(Name: Query String:	Special Acces	is	Na Query St	Trigger Edit me: End Specia Public ing:	al Access	
(Name: Query String:	Special Acces Public Fnabled	IS	Query St	Trigger Edit me: End Speci Public ing: Enabled	al Access	
¢	Name: Query String:	Special Acces Public Enabled	s	Query St	Trigger Edit me: End Speci Public ing: Enabled	al Access	
(Name: Query String:	Special Acces	5 	Query St	Trigger Edit me: End Speci Public ing: Enabled	al Access	
(Name: Query String: Group:	Special Acces	8	Query St	Trigger Edit me: End Specia Public ing: Finabled pup: 2	al Access	
(Name: Query String: Group: Category:	Special Acces Public Function Fun	5 	C Hercury	Trigger Edit me: End Specia I♥ Public ing: I♥ I♥ Enabler pup: 2 ory: Timezone	al Access	
¢	Name: Query String: Group: Category:	Special Acces Public Enabled I Timezone Activo	s s	X CHERCURY Na Query St Gr Categ	Trigger Edit me: End Speci ✓ Public ing: ✓ Enabler pup: 2 pry: Timezone Tarether	al Access	Y
(Name: Query String: Group: Category: Type:	Special Acces V Public F Enabled 1 Timezone Active	s 	X CHERCURY	Trigger Edit me: End Speciar IV Public ing: IV IV Enabler pup: 2 ory: Timezone ype: Inactive	al Access	Y
(Name: Query String: Group: Category: Type: Item:	Special Acces	is is is is is is is is is is	X CHERCURY	Trigger Edit me: End Speci IV Public ing: IV IV Enabled pup: 2 ory: Timezone ype: Inactive em: After Offic	al Access	r r
C	Name: Query String: Group: Category: Type: Item:	Special Acces Public Public I Timezone Active After Office S	s s chedule	X CHERCURY	Trigger Edit me: End Speci Image: Image: Image: Image: Image: Image: oup: 2 ory: Timezone ype: Inactive em: After Official	al Access d e Schedule	V V V
C	Name: Query String: Group: Category: Type: Item: Procedure:	Special Acces Public Public I Finabled Active Active After Office S Cleaning Creat	s	X CHERCURY	Trigger Edit me: End Speci Iv Public ing: Iv Iv Enabled oup: 2 ory: Timezone upe: Inactive em: After Offic re: Classing	al Access a s e Schedule	

Configure Mercury Elevators

The Mercury elevator integration is a low level interface that allows you to configure one output for each floor. If you select floor tracking, you must also configure one input for each floor.

Input and output points are selected by picking terminal boards. The start point can be selected on the first board only. Each subsequent board must start on point one.

The Mercury elevator integration supports up to 128 floors, and each elevator must be defined with a minimum of two floors.

User experience varies depending on floor tracking selection:

- Without floor tracking, elevator users can select more than one floor per access grant. The system does not keep any records of what floors were selected.
- With floor tracking, elevator users can only select one floor at a time. The system keeps records of which floor was selected.

When defining access groups for Mercury elevators, the readers in the access group are automatically assigned the default timezone of the access group. Floor masks are also assigned to the default timezone.

The Mercury elevator integration allows you to configure and control one or more Mercury elevators at a facility.

Before you can configure Mercury elevators, you must configure the Mercury panels and terminals that are to be part of the elevator system.

Output and Input Point Chain Rules

The Mercury elevator control requires that you configure one physical output for each elevator floor. If floor tracking is enabled, you must also configure one physical input for each elevator floor.

All input and output points used for an elevator must be continuous. That means that if floor 1 uses output point 1, floor 2 must use output point 2. Output point 2 cannot be used for any other purpose.

To support the desired number of elevator floors, you may need to chain the points from one terminal board to the next. You must follow specific rules when chaining points, which is done on the Output Board and Input Board tabs. Note that the same rules apply to chaining both output and input points.

If you need more output or input points to support the number of elevator floors that are on the terminal you started with, those extra terminals are called *additional* terminals.

Starting the Output Point/Input Point Chain

- Any terminal on the panel that has spare points can be used to start the chain.
- Before you define the number of the starting point for the chain, make sure that either enough consecutive points are available to support the number of defined floors or that all of the points to the end of the board are available.

ury Elevator Configuratio

Using Additional Terminals

- Additional terminals *cannot* be associated with the terminal whose SIO number is 0.
- The first output/input point *must* be available.
- The number of consecutive, available points, starting from the first point, must match at least the lower of:
 - the number of floors that need to be associated with a point
 - the number of physical points on the board.

Note: A point is considered available if it is currently unused or is currently used for the elevator you are configuring.

To Configure Mercury Elevators:

- 1. In the System Configuration window, expand **Panels** to display the panel types.
- 2. Expand **Mercury Panels** to display all Mercury panels configured in the system.
- 3. Expand the panel for which you wish to configure the elevator.
- Select Elevators and click Add. The Mercury Elevator Configuration dialog box opens.

5. Enter a descriptive **Name** for the Mercury elevator.

- 6. Click **Public** to allow all partitions to see the elevator.
- 7. The **Panel** field displays the name of the Mercury panel for which you are configuring the elevator.
- 8. The **Number of Floors** field displays two floors by default. You can change the number of floors by entering the desired number and clicking **Update**. The list on the Floor tab displays the defined number of floors.

Note: The list box displays the floor names as configured in the Floor Name Configuration dialog box; see Defining Floor Names on page 220.

- 9. The **Query String** value is used with message filtering; see Define Query String Filters on page 240.
- 10. Click **Floor Tracking** to keep track of floor selection.

Note: You must select **Floor Tracking** to complete the Input Point settings in the Mercury Elevator Floor Configuration dialog box and to access the Mercury Elevator Input Board Selection.

11. Select the **Reader** that provides the elevator access. You can only select Mercury readers that are defined as *Single*. See Reader Tab on page 191 for details.

Note: After you select the reader and save the elevator configuration, the Reader Configuration in the Reader tab of the Mercury Terminal displays **Elevator with feedback** or **Elevator with out feedback**, depending on whether you selected the Floor Tracking option.

Name Vers Sde Benotors Pane Vers Sde Benotors Pane Vers Sde Vers Strag Werd Elevator Reader Floors Output Band | Input Band | Werder Vers Benotor Reader Nors Output Band | Input Band | Norse Output Band | **Note:** Deleting an elevator or modifying the associated reader requires a download to the affected panel of all access groups associated with that reader.

Configuring Mercury Elevator Floors

- 1. In the Mercury Elevator Configuration dialog box, select the **Floors** tab. The list box displays the defined number of floors.
- 2. Select a floor from the list and click **Edit**. The Mercury Elevator Floor Configuration dialog box opens.

cury Elevator Floor Configura	tion	
Number	1	
Floor Name	First Floor Lobby	
Public Access Timezone	Daily Normal Access	
Output Point		
Mercury Output	Main Terminal Outputs Point Number 1	
Drive Mode	Normal	
Offline Mode	No Change	
Input Point		
Mecury Input	Main Inputs on Elevator Terminal Point Number 1	
Calibration	Normally Closed	
Debounce	4	
Hold Time	0 Seconds	
	OK Cancel	

- 3. The **Number** field displays the number of the floor being configured.
- 4. The **Floor Name** field displays the name of the selected floor. You can select a different floor from the drop-down list.
- Select the Public Access Timezone that was defined to allow cardholders to access the floor without presenting their badge at the reader. If you select <None>, then a badge is always required to access the floor.

Note: This is any time zone that was assigned to the Mercury panel.

- 6. The **Mercury Output** field displays the terminal name and output point number assigned to the floor. This is based on the information in the Output Board tab; see page 209 for details.
- 7. Select one of the following **Drive Modes** that define the output point behavior upon activation:

Normal – Sets the output point if the output state is Active, and resets the output point if the output state is Inactive.

Inverted – Resets the output point if the output state is Active, and sets the output point if the output state is Inactive.

8. Select one of the following **Offline Modes** that define the output point state when the terminal goes offline:

No Change – The output state does not change.

Inactive – Resets the output point when the output drive mode is Normal, and sets the output point when the output drive mode is Inverted.

Active – Sets the output point when the output drive mode is Normal, and resets the output point when output drive mode is Inverted.

- 9. The Mercury Input field displays the terminal name and input point number assigned to the floor. This is based on the information in the Input Board tab; see page 209 for details. This field may display <*Floor Tracking Disabled>* if Floor Tracking is not enabled for the elevator.
- 10. Select the **Calibration** that provides the predefined mode of operation of the input point.
- 11. Enter in the **Debounce** field the number of consecutive input scans (0 to 15) that must agree before a change of state is reported. Each scan period is 16.7 milliseconds. The default is 4. Use a higher setting if you are seeing noise induced reports.

12. In the **Hold Time** field enter a hold time in seconds (2 to 15) to hold a higher priority status before a lower priority status is reported. Enter 0 to prevent any hold time.

Configuring Mercury Elevator Outputs

Use the Output Board tab to define the chain of terminals that identify the output points used for the elevator floor. See Output and Input Point Chain Rules on page 206 for more information.

- 1. In the Mercury Elevator Configuration dialog box, select the **Output Board** tab.
- 2. Click **Add** to add an output board. The Mercury Elevator Output Board Configuration dialog box opens.

Mercury Elevator Output Board Configuration	n 🗵	1
Select output ten	minal from list to see available points	
Output Terminal Name Terr	n Outputs	
First Board Start Point		
Output Points Available 16		
OK	Cancel	

- 3. Select an Output Terminal Name.
- 4. Select the **First Board Start Point** number. This number is always assigned to the lowest floor number.
- 5. The **Output Points Available** field displays the number of available output points on the selected terminal. This number is determined automatically and must be sufficient to support the number of defined floors.
- 6. Click **OK** to return to the Mercury Elevator Configuration dialog box.
- 7. You can use the **Up** or **Down** buttons to change the order of the output terminals, if necessary.

Note: The list box displays all defined output boards, including the total number of points on each board, and the total point count.

Configuring Mercury Elevator Inputs

Use the Input Board tab to define the chain of terminals that identify the input points used for the elevator floor. See Output and Input Point Chain Rules on page 206 for more information.

- 1. In the Mercury Elevator Configuration dialog box, select the **Input Board** tab.
- Click Add to add an input board. The Mercury Elevator Input Board Configuration dialog box opens.

Mercury Elevator Input Board Configu	ration	X
Select in	put terminal from list to see available points	
Input Terminal Name	Term Inputs	
First Board Start Point	1	
Input Points Available	16	
	OK Cancel	

- 3. Select an Input Terminal Name.
- 4. Select the **First Board Start Point** number. This number is always assigned to the lowest floor number.
- 5. The **Input Points Available** field displays the number of available input points on the selected terminal. This number is determined automatically and must be sufficient to support the number of defined floors.
- 6. Click **OK** to return to the Mercury Elevator Configuration dialog box.
- 7. You can use the **Up** or **Down** buttons to change the order of the input terminals, if necessary.

Note: The list box displays all defined input boards, including the total number of points on each board, and the total point count.

Best Practices

This section provides a description of how to accomplish common tasks associated with Mercury components.

How to Override a Reader Based on a Time Zone

Follow the instructions provided in Configure Mercury Procedures and Triggers on page 202. Also, see How to Change Reader Mode Based on Time Zone Change of State on page 211.

How to Use Card ID using a Keypad Reader

To authenticate a user via an entered Card ID at a Mercury keypad reader, the following conditions must be met.

1. You must define a card format with a **Function** value of *Magnetic Stripe* (even if you are using a Wiegand reader).

This card format defines how many digits need to be entered for the facility code, and how many digits need to be entered for the Card ID. If no facility code is entered, the card format uses a Facility Code value of -1. See Card Format Tab on page 181 for details.

You must select the *Card ID* format in the Card Type tab of the terminal configuration; and must also select the correct Card Data Formatting (select *Data1 / Data0*, *Wiegand Pulses* for Wiegand readers; or select *Trim Zero Bits* and *Format To Nibble Array* for Magnetic Stripe readers). See Card Type Tab on page 194 for details.

It is possible to combine the *Card ID* format with other badge based formats at the same reader; however, some combinations may not be operational. Contact Technical Support for instructions if you need to use a specific combination. 3. If you select *Card Only* as the Default Reader Mode in the **Reader** tab of the terminal configuration (see Reader Tab on page 191 for details), you must enter your credentials at the keypad reader by pressing the * key, enter the Facility Code, enter the Card ID, and press the # key.

The Facility Code and the Card ID must be filled up with leading zeros to match the number of digits specified in the format defined in step 1.

Note: A Facility Code may be absent if the card format was defined without it.

4. If you select *Card and PIN Required* as the Default Reader Mode in the **Reader** tab of the terminal configuration (see Reader Tab on page 191 for details), you must enter your credentials at the keypad reader by pressing the * key, enter the Facility Code, enter the Card ID, press the # key, and enter the PIN number.

The Facility Code and the Card ID must be filled up with leading zeros to match the number of digits specified in the format defined in step 1.

If the PIN has fewer digits than specified in the Site Parameters (see page 35 for details), the # key must be pressed after the PIN is entered (you cannot enter PIN numbers with leading zeros).

Note: A Facility Code may be absent if the card format was defined without it.

5. The *Allow PIN before Badge* option in the Access tab has no effect in the operation of Card ID and PIN. The required sequence is always as specified in step 4.

How to Save Data to the Mercury Panel in the Event of Power Loss

Ensure that all three of the following requirements are met for all Mercury panels:

- 1. The on-board coin cell is electrically connected and the isolation strip is removed.
- 2. The firmware version is 1.18.5 or 1.17.3, as displayed in the Panel Details of the System Status window.
- 3. The following Auto-Save settings in the Mercury Configuration Manager are enabled:
 - Restore from the last saved settings
 - Auto Save is enabled
 - Delay before save is 30 seconds

How to Change Reader Mode Based on Time Zone Change of State

- 1. Create a Procedure (see page 202 for details), that includes the following parameters:
 - **Group:** make appropriate selection. This number must match the Group number selected in the Trigger defined in Step 2.
 - Category: select *Terminal*.
 - Type: select Set Reader Mode.
 - Item: make appropriate selection.
 - Value: make appropriate selection (for example, Unlock).
- 2. Create a Trigger (see page 204 for details), that includes the following parameters:
 - **Group:** make appropriate selection. This number must match the Group number defined in the Procedure.
 - Category: select *Timezone*.
 - **Type:** select if the trigger is initiated when the time zone becomes *Active* or *Inactive*.

- Item: select the *name of the time zone* that activates the trigger upon change of state.
- **Procedure:** select the *name of the procedure* defined in Step. 1.

In the previous example, the selected terminal unlocks every time the selected time zones becomes active or inactive, depending on your selection.

What to Do When Relocating a Mercury Panel

If you install a Mercury panel that was previously configured for a different site or location, you must use the panel's *Bulk Erase Configuration Memory* function to reset the panel to factory conditions. This prevents the P2000 system from processing transaction messages that are not applicable to the panel's current use. Refer to your panel's hardware installation manual for details on the *Bulk Erase Configuration Memory* function.

What to Do When Changing an MR51e IP Address

- If you change the IP address using the P2000 Mercury Terminal Edit application, the MR51e goes offline. If you change this field again back to the correct IP address, you must download all items to the panel with the **Reset Panel Before Download** flag selected to return the MR51e to normal operation.
- If you change the IP address using the MSC MR51e Address Configuration Tool before changing the IP address using the P2000 Mercury Terminal Edit application, when the MR51e is reset to begin the IP address change (using its S2 push button), the MR51e goes offline. You must download all items to the panel with the **Reset Panel Before Download** flag selected to return the MR51e to normal operation.

P2000 Badge Format

The P2000 software offers the flexibility of defining badge formats to be used at readers that support different formats. You can create a new badge format, load an existing format, or load and modify an existing format to create a new one.

To Create P2000 Badge Formats:

 From the P2000 Main menu, select Config>P2000 Badge Format. The P2000 Badge Format dialog box opens.

C P2000 Badge Form	at		>
Format Name:		Total Bits:	
Format Layout		-	
1234567890123	3456789012345678901234567890	123456789012345	678901234
"P" - parity bit; "N" - ca "I" - issue level bit; "1"	ard number bit; "F" - facility code bit - fixed bit of 1; "0" - fixed bit of 0	🕅 Invert Bits	Details
Parity Definition			
Position	Parity Bits	Parity Type	Edit
			Defete
			Delete
			Up Dn
P			
Rules			
			Add
			Edit
			Delete
Encode			
			Add
			Edit
			Delete
	Clear Save Lo	oad Test	⊆lose

- 2. Enter the **Format Name** of the badge.
- 3. The **Total Bits** displays the total number of bits in the format.
- 4. In the **Format Layout** box specify the layout of the bits on the badge:
 - P: Bits allocated to parity
 - N: Bits allocated to card number
 - I: Bits allocated to issue level
 - 1: Fixed bit of 1
 - 0: Fixed bit of 0

For example, starting the format with *PP* indicates that the first two bits are allocated to parity.

Every parity bit position entered in the **Format Layout** box is automatically added to the **Parity Definition** list where it needs to be defined. See the following instructions for details.

- 5. Click **Invert Bits** if the bits are to be inverted when the raw badge format is processed by the P2000 system.
- 6. Click **Details** to see bit locations for card number, facility code, and issue level. Edit the text in the box only if you need to reverse the order of the bits when they are processed by the P2000 system.

For example, if the raw card number bits are 15-34, and they must be reversed, enter *34-15*.

Note: You cannot use this window to change bits allocation as defined in Format Layout.

Format Details		×
Enter custom bits	s order, like 1,3,7,5 o	r 6-10 for range.
Card Number:	15-34	
Facility Code:	3-14	
Issue Level:		
	ОК	Cancel

7. Click OK to close Format Details.

To Define Parity Bits:

1. Select an item from the Parity Definition box and click **Edit**. The Edit Parity dialog box opens.

Edit Parity	×
Position: 1	
Parity Mask (1, 2,, n or 1-n for ranges):	
Parity Type	
⊙ Even C Odd	
OK Cance	;I

- 2. In the **Parity Mask** field enter the bits that are used to calculate parity.
- 3. Click Even or Odd to specify parity type.
- 4. Click **OK** to save the changes and to close Edit Parity.
- 5. To delete parity definitions, select an entry from the list and click **Delete**.

Note: Delete a parity definition only if you have removed the corresponding parity bit from the **Format Layout** box.

 Once all parity positions are defined, click Up or Dn to change the order in which the parity is calculated.

For example, if parity in position 1 uses in its calculation the value of parity in position 35, then it must be listed below position 35.

To Add Decoding Rules:

Decoding rules are used to convert a raw number received from a badge reader into the P2000 badge number, facility code, and issue level.

Note: For each decoding rule, you must also add an encoding rule that matches it in reverse form.

1. In the P2000 Badge Format dialog box click **Add** in the Decode box. The Add Decode Rule dialog box opens.

Add Decode Rule	X
If If	Then
• =(•	
Legend BN - badge pumber	PN - P2000 pumber
BF - badge facility code	PF - P2000 facility code
BI - badge issue level	PI - P2000 issue level
	OK Cancel

2. Specify the rule to be used by the P2000 software for decoding raw card format. To enable condition fields click **If**.

The *Bs* indicate the values returned from the badge reader, while the *Ps* indicate the values as displayed in the P2000 user interface.

3. Click **OK** to close Add Decode Rules.

To Add Encoding Rules:

Encoding rules are used to convert the P2000 badge number, facility code, and issue level into a single number for a badge reader.

Each encoding rule must match a decoding rule in reverse form. See the following example of a pair of matching decoding and encoding rules.

Decoding rule: If BI = 500 Then PN = (BN+10000)



Encoding rule: If PI = 500 Then BN = (PN-10000)

🔽 If 🏼 PI	-	500	Then
BN - =(PN 💌 -	▼ 10000	

Follow the next steps to create an encoding rule.

1. In the P2000 Badge Format dialog box click Add in the Encode box. The Add Encode Rule dialog box opens.

Add Encode Rule	×
If 🔽	Then
Legend	
BN - badge number	PN - P2000 number
BF - badge facility code	PF - P2000 facility code
BI - badge issue level	PI - P2000 issue level
	OK Cancel

2. Specify the rule to be used by the P2000 software for encoding card format. To enable condition fields click **If**.

The *Ps* indicate the values as displayed in the P2000 user interface, while the *Bs* indicate the values for the badge reader.

3. Click **OK** to close Add Encode Rules.

To Test the Badge Format:

1. To test the format, click **Test** at the bottom of the P2000 Badge Format dialog box. The Test Format dialog box opens.

Test Format		×	
Card Number:	Facility Code:	Issue Level:	
To Raw Data To P2000 Raw data (binary):			
Close			

- 2. In the upper boxes enter the card number, facility code, and issue level as would be displayed in the P2000 interface.
- 3. Click **To Raw Data**. The bit string displayed in the lower box should be a valid raw data card number.
- 4. Click to clear the **Raw data** box and enter in it the single number as would be received from a badge reader. The number has to be provided in the data type selected.
- 5. Click **To 2000**. The card number, facility code, and issue level as would be displayed in the P2000 interface should appear in the upper boxes.
- 6. Click **Close** to return to the P2000 Badge Format dialog box.
- 7. Click Save to save the badge format.
- 8. The Save As window opens. Enter the file name and click **Save**.
- 9. In the P2000 Badge Format window click **Close**.

To Load/Edit Badge Format:

- From the P2000 Main menu, select Config>P2000 Badge Format. The P2000 Badge Format dialog box opens.
- 2. Click Load.
- 3. Browse for the badge format to load and select the appropriate *.bft file.



4. Click **Open**.

C P2000 Badg	e Format	×
Format Name:	Corporate 1000 Total Bits: 35	
Format Layout	23455789012285788000000000000000000000000000000000	6 5678901234
"P" - parity bit "I" - issue leve	; "N" - card number bit; "F" - facility code bit bit; "1"- fixed bit of 1; "0" - fixed bit of 0	Details
Parity Definitio	n	-
Position	Parity Bits Parity Type	Edit
2	3,4,6,7,9,10,12,13,15,16,18,19,21,22,24,25,27, Even	Delete
1	2-35 Odd	
		Up Dn
1		
Rules		
Decode		
		Add
		Edit
		Delete
Encode		
		Add
		Edit
		Delete
	Clear Save Load Tert	Clore
	Load Test	

5. Edit the badge format if desired.

Note: Each modified format should be tested before saving.

- 6. Click Save.
- 7. The Save As window opens. Enter the file name and click **Save**.
- 8. To define additional badge formats, click **Clear** and enter the new data.
- 9. In the P2000 Badge Format window click Close.

Configure Elevators and Cabinets

The P2000 system supports the elevator and cabinet access control using CK7xx panels, Version 2.0 and later.

The following sections describe how to configure:

- Elevator Access Control
- Cabinet Access Control

Note: To configure elevators that use Mercury panels, see page 206.

Elevator Access Control

General Overview

The elevator access control gives you the ability to assign cardholders access to various elevators and floors in your facility, through their access groups.

Elevator readers cannot be overridden by a Local Cardholder Override or a Timed Override, and do not allow the Auxiliary Access input to grant access to any floors.

Also, panel card events cannot be used on elevator readers.

Elevators are assigned floors and floor groups, then these floors and floor groups are included in access groups which are assigned to cardholders.

The basic procedures for defining and implementing the elevator access control are:

- Define Floor Names
- Define Floor Masks
- Configure Elevators
- Configure Floors
- Define Floor Groups
- Create Access Groups for Elevator Floors

215

Steps to perform each procedure are presented in the following sections. To successfully implement the elevator access control, configure these steps in the order presented.

Basic Definitions

Valid Badge – A valid badge in this context is defined as a badge that is accepted by the elevator's reader with a green light. The specific rights of this badge are dependent on the badge's access groups' floor masks, so it may be possible that a valid badge gives no access to any of the elevator's floors.

Elevator Access Grant – The valid badge's access groups' floor masks determine which of the elevator cab's floors are enabled by an elevator access grant. Relinquishing an elevator access grant does not disable an elevator floor that is enabled by public access or by direct output control.

Direct Output Control – Each elevator cab's floor buttons may be enabled by direct output control from the Server's or the panel's user interface. Relinquishing direct output control does not disable an elevator button that is enabled by an elevator access grant or by public access.

Access Grant Message – When a valid badge is presented, the panel sends an elevator access grant message to the Server, which includes the badge's number and cardholder name.

Override – When the reader terminal in the elevator cab is overridden, the public access feature energizes all of the associated output relays. This means, that there are no floor tracking messages generated. Except for local cardholder override, all modes of reader override are applicable to elevator terminals; that is, override per timezone, per panel system override, and per the *Unlock All Doors* command from the Server. Override has no effect on Otis Compass elevators.

Executive Privilege – Badges with executive privilege enable all floors of the elevator per elevator access grant. Executive privilege does not modify the floor's granted access when using PIN codes in Otis Compass elevators.

Low Level Interface

Low level interface elevators have readers associated with a set of output points and an optional set of input points. The field panel works with the elevator manufacturer's control system using output points to enable car-call buttons, and input points to monitor car-call buttons.

The panel may grant access to a floor by enabling the corresponding car-call button when a badge is presented at a reader installed in the elevator cab.

An elevator cab must be equipped with one reader, and one output needs to be assigned to every floor button in the cab that needs to be enabled by the security system. If floor tracking is desired, one input needs to be assigned to every floor button in the cab that is supposed to create a floor tracking message.

There is no prescribed scheme to associate outputs and inputs by their address to the elevator's floor buttons, but the reader and all outputs and inputs for an elevator must be defined on the same panel. The association of elevators, floors, readers, outputs, and inputs is done by defining an Elevator (see page 221), and then downloading it into the panel.

When presenting a badge at the elevator cab's reader, the panel searches the badge record for floor access information. This information is then applied to energize the output relays of those floors that the person should have access. It is the elevator control system's responsibility to ensure the elevator does not go to disabled floors.

217

The enabled floors are disabled after the elevator access time has expired, unless they are still enabled by public access or by direct output control. All buttons, that are exclusively enabled by the elevator access grant produce floor tracking messages.

D620-ECG Elevator Mode

The P2000 system provides a low level D620 elevator mode that if selected, causes a modification in the badging sequence and in the elevator input and output point's behavior; see page 223 for more information.

KONE HLI/KONE ELINK High Level Interface

The KONE interface is a master slave protocol over RS232 or RS485, according to KONE Elevator EPL HLI Security Protocol specification V=2.3 SO-13.20.10-KAM, with the CK7xx being the master.

Each panel connects to a KONE group controller with up to 8 elevators, with each elevator serving up to 64 floors. To connect a KONE group controller to a CK721 or CK721-A panel, use the RS232C B (J2) connector. To connect a KONE group controller to a CK705 or CK720 panel, you have to remove all modems from the panel and install a serial PCMCIA card.

To define a KONE elevator, the High Level Interface flag has to be checked, and the Protocol and Address fields have to be defined. To define the floors of a KONE elevator, the public access timezone must be defined, but there should be no output or input points associated with the floor. A floor is on public access when the specified timezone is active. A floor is not on public access when the specified timezone is inactive.

The rest of this integration is identical to the low level elevator interface.

KONE IP High Level Interface

CK721-A panels Version 3.1 and later provide the communication necessary for KONE IP elevators. In this high-level elevator integration, the CK721-A panel interfaces with the elevator control system through a communications protocol. Granting access to floors is achieved by sending messages to the elevator controller; reporting destination floors is achieved by receiving messages from the elevator controller (you must select the Floor Tracking function).

Each CK721-A panel can connect to multiple KONE IP group controllers, each controller with up to 8 elevators, each elevator serving up to 128 floors. To define a KONE IP elevator, you must first select the *Kone IP* protocol type in the Panel Elevator tab.

The KONE IP elevator interface provides two types of group controllers, the KONE KIC and the Primary/Backup KGC. There are different rules when interfacing to a KONE KIC as opposed to a Primary/Backup KGC controller. KONE KIC controllers only support Car Operation Panels (COPs), and not Destination Operation Panels (DOPs). You can define up to 33 elevator groups for each KONE KIC controller. KONE IP controllers, configured in primary/backup pairs, only support elevator group address number 1 (all other elevator groups are ignored).

For detailed instructions, see Configuring KONE IP Elevators on page 226.

Otis EMS - Security / BMS Protocol High Level Interface

The Otis Elevator Management System (EMS) controls up to 8 groups of elevators, each group consisting of up to 8 elevators. It communicates with the Building Management System (BMS) through an RS422 interface. This elevator protocol is available with CK721-A panels Version 2.10 and later.

The number of elevators, and their assignment to elevator groups determines the number of CK721-A panels required. All elevators of each single group must be handled by the same CK721-A panel. Each CK721-A can support multiple groups, as long as the total number of elevators in these groups does not exceed 16.

To define an Otis EMS - Security / BMS elevator, you must select the High Level Interface flag. When you configure the Otis EMS elevator floors (1 to 99 floors allowed), you must define the public access timezone, but there should be no output or input points associated with the floor. A floor is on public access only when the specified timezone is active.

The rest of this integration is identical to the low level elevator interface.

Note: When downloading elevators to a panel running the Otis EMS integration, make sure the **Delete Elevators From Panel Before Download** option is not selected, as otherwise, the temporary deletion of the elevators would temporarily disrupt communication with the Otis EMS; see page 463 for details.

Otis Compass High Level Interface

The Otis Compass interface is a high level interface that uses a TCP/IP network to send elevator commands to the Otis system, and also receives historical information from the Otis system.

The P2000 system provides the communication between the Otis Compass elevator system and CK721-A panels Version 3.0 and later. When a cardholder swipes a badge, a message from the CK721-a panel is routed to the Otis Compass elevator system to identify the authorized floors for this cardholder. The Otis Compass interface requires the P2000 Server to have a dedicated network interface card (NIC) connected to the Otis Compass network with an assigned static IP address of 192.168.50.250 and a mask of 255.255.255.0 with no default gateway. To configure a permanent static network route for the Otis system, a static route must also be configured at the P2000 Server by issuing once the following command (CMD) during commissioning: route add -p 192.168.0.0 mask 255.255.0.0 192.168.50.254.

Note: The P2000 Otis Interface Service must be running at all times if Otis Compass elevators are being used, even during maintenance operations if possible, so it has the correct information to send to the Otis Compass system when it is reactivated. To disable P2000 control of the Otis Compass system for testing or maintenance operations, the network connection between the systems can be disconnected, but the Otis Interface Service must be left operational on the P2000 system.

The Otis system differs from typical elevator systems because the floor selection is done outside of the elevator cab. Access to the floor entry keypad, called a Destination Entry Computer (DEC), can be controlled by a reader connected to a CK721-A panel, if configured to do so. The Otis system allows operation of the DECs in four different *modes* that define the availability of floors and the order in which floors and badges are presented to the system.

Once a P2000 system is connected to an Otis Compass system, the P2000 system is in full control of what each DEC is able to do. This means that until an elevator is defined in the P2000 system and its access parameters are configured, no use of the elevator is permitted.

Important Notes

- Each CK721-A panel can control as many DECs as it has readers configured, using a one to one mapping.
- The P2000 system allows for the configuration of public use of a DEC through the configuration of unsecured elevator entry points.
- The P2000 system also allows for configuration of secured entry points and the association of access rights on a badge to those secured entry points.
- The P2000 system supports the Otis concepts of *Allowed Floors* and *Authorized Floors* through its configuration screens.
- The P2000 system supports the ability to enter a PIN code on the DEC which is associated with a badge in the P2000 system and granted appropriate access if allowed.
- The P2000 system also allows configuration of the ADA access and VIP access features, as well as the Default Floor feature in the Otis system.
- The PIN Access and Default Floor settings are defined using the Badge application.

Otis Compass Elevator Modes

The Otis Compass system provides the following elevator mode types:

Mode 1 – Initially allows entry of a requested floor or the presentation of a badge. If a cardholder enters a floor request, and is an allowed floor, an elevator is dispatched. If a cardholder presents a badge first, that badge's default floor is used to dispatch an elevator, assuming the default floor is an authorized or an allowed floor. To configure Mode 1 elevators, use the Elevator Configuration application (see page 221) and the Otis Unsecured Elevator Configuration application (see page 225). **Mode 2** – These elevators must have a reader associated with the elevator and operate when the cardholder presents a valid badge at the reader/DEC combination. The cardholder must present the badge before selecting a floor, if the floor is authorized or allowed, an elevator is dispatched. This is the common mode of operation for secured elevator entry points. To configure these elevators use the Elevator Configuration application (see page 221).

Mode 3 – Initially allows entry of a requested floor. If the floor is allowed, an elevator is dispatched. If the floor is not allowed, a request is made for the user to provide a badge, if the badge presented authorizes the floor requested, an elevator is dispatched. This is the most common mode of operation for unsecured elevator entry points. To configure Mode 3 elevators use the Elevator Configuration application (see page 221) and the Otis Unsecured Elevator Configuration application (see page 225).

Mode 4 – The cardholder must present a badge before selecting a floor; the system preselects the badge's default floor for the user, but the user has a short time to select a different floor. If the floor selected after the time-out is authorized or allowed, an elevator is dispatched. To configure these elevators use the Elevator Configuration application (see page 221).

In all modes, if the cardholder presents an invalid badge or enters an illegal floor, the system informs the cardholder using the DECs display. If the cardholder makes a valid combination of badge and floor selection, the system informs the cardholder what elevator to board using the DECs display. All transactions occurring at secured elevator entry points are logged in the P2000 system.

Defining Floor Names

Use the Floor Name Configuration dialog box to define floor names and associated index number. Floors should be named by physical characteristics such as Lobby or Roof Access, to help identify the floor name and location when configuring the actual elevators. The system supports up to 128 floors (127 floors with Otis Compass elevators). If your facility uses Otis EMS elevators, you can only configure floors 1 to 99.

- 1. In the System Configuration window, expand **Elevator/Cabinet Parameters** to display the elevator parameters.
- Select Elevator Floor Names and click Edit. The Floor Name Configuration dialog box opens.

Number	Floor Name	A
1	First Floor Lobby	_
2	Second Floor Corporate	
3	Third Floor Accounting	
4	Floor 4 Sales	_
5	Floor 5	
6	Floor 6	
7	Floor 7	
8	Floor 8	
9	Floor 9	
10	Floor 10	
11	Floor 11	
12	Floor 12	
13	Floor 13	
14	Floor 14	
15	Floor 15	
16	Floor 16	
17	Floor 17	
18	Floor 18	
19	Floor 19	
20	Floor 20	
21	Floor 21	
22	Floor 22	
23	Eloor 23	<u> </u>
	Floor Name: Floor 4 Sales	
Defaults	Update Insert	Delete

The number of floors entered in the Site Parameters dialog box displays. (See Site Parameters Field Definitions on page 34).

 Select the floor you wish to rename. The floor name displays in the Floor Name field at the bottom of the window.

- 4. Rename the floor accordingly and click **Insert**. The new name displays and the list of floor names moves down one position. For example, if you rename floor 1 and floor 2, Number 3 on the list becomes Floor 1.
- 5. If you wish to edit a floor name, select the floor name, rename it, then click **Update**.
- 6. If you delete a floor name, using the **Delete** button, the next floor on the list moves up one position.
- 7. To restore the default floor names, click **Defaults**.
- 8. When you finish configuring floor names, click **OK** to return to the System Configuration window.

Defining Floor Masks

You can group floors that have common access throughout your facility and then apply them as a group to associate them with physical elevators when configuring Floor Groups. For example, your facility may have three floors that access the Operations department. When floors are grouped, you can assign cardholders that should have access to the three floors to the Operations group, rather than assigning all three floors to the cardholders individually.

- In the System Configuration window, expand Elevator/Cabinet Parameters to display the elevator parameters.
- 2. Select Elevator Floor Masks and click Add. The Floor Mask dialog box opens.

Floor Plask				
Pi	artition: Super Use	r	Public	
	Name: Operation	ns Group		
Floors				
Selected Floors:		Available	Floors:	
First Floor Lobby Second Floor Corporate Third Floor Accounting		Floor 4 Floor 5 Floor 6 Floor 7 Floor 1 Floor 1 Floor 1 Floor 1 Floor 1 Floor 1 Floor 2 Floor 2	0 1 1 2 3 4 4 5 6 9 9 9 9 1 1 2 3 4 5 6 6 7	_

- 3. If you use Partitioning, select the **Partition** that has access to this Floor Mask. All available floors (for the partition selected) are listed on the right side of the dialog box.
- 4. If you use Partitioning, click **Public** to allow all partitions to see this Floor Mask.
- 5. Enter a descriptive **Name** for this Floor Mask.
- 6. From the **Available Floors** list, select the floor you wish to include in your group.
- Click <<. The floor moves to the left side of the dialog box, to be included in the Selected Floors box.
- 8. To remove a floor from the Selected Floors box, select the floor and click >>.
- 9. When all floors you wish to include in the group have been moved to the Selected Floors box, click **OK**. A Floor Mask icon for the new group is added under the Elevator Floor Masks root icon in the System Configuration window.

Configuring Elevators

Use the Elevator Configuration dialog box to define the reader and, if applicable, the associated output and optional input points that operate with your particular elevator controller type.

Note: See specific instructions when configuring Mercury elevators (page 206), Unsecured Otis Compass elevators (page 225), or KONE IP elevators (page 226).

- 1. In the System Configuration window, expand the CK7xx Panel to which you wish to assign an elevator.
- 2. Select **Elevators** and click **Add**. The Elevator Configuration dialog box opens.
- 3. Enter the required information according to the following Elevator Configuration Field Definitions.
- 4. After you have entered all the information, click **OK** to save your settings and return to the System Configuration window.

Elevator Configuration Field Definitions

Name – Enter a descriptive **Name** for this elevator.

Public – Click **Public** if you wish the elevator to be visible to all partitions.

Panel – This field displays the name of the panel you selected from the System Configuration window.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

C Elevator Configuration		
<u>N</u> ame:	North West Elevator	Public
Panel:	Warehouse	
Query String:		
<u>R</u> eader:	OC Elevator Reader	Timed Button
Fireman Override:	<none></none>	Agcess Time: 5 seconds
≦ervice Override:	<none></none>	
C Low Level Interface	🗖 D620 Mode	Floor Tracking
High Level Interface		Track On Input Open
Pr <u>o</u> tocol:	Otis Compass	Track On Transition Only
Address:	0	ADA Compliance
Machine Room Enclosure:	MRE 1	Special Access Flag: Handicap Access
Destination Entry Computer:	DEC 2	VIP Access
Operational Mode:	Mode 2 💌 🔽 Enable Otis PIN	Special Access Flag: Special Access B
Floor Information		
Number Floor Name	Output Point	Input Point Public Access Timezone
2 Second Floor Corp	orate Push Button	Normal Business Hours
Add	Delete	
	ОК	Cancel

Reader – Select an available reader that has not yet been assigned to an elevator or cabinet, and that has an address number no higher than 16.

Fireman Override – If the elevator has a fireman override switch, select an available input point that has not yet been assigned to an elevator or cabinet. The only purpose of this input point is to send messages to the Real Time List; it does not control Fireman Override. Not available for Otis Compass elevators.

Service Override – If the elevator has a service override switch, select an available input point that has not yet been assigned to an elevator or cabinet. The only purpose of this input point is to send messages to the Real Time List; it does not control Service Override. Not available for Otis Compass elevators.

Timed Button – If enabled, the access grant at an elevator remains active for the specified elevator access time, independent of any elevator buttons being pressed. If this option is not enabled, the access grant is cancelled as soon as an enabled elevator button is pressed. It does not matter whether or not that enabled point is on public access. If no button is pressed, the access grant is cancelled at the end of the specified elevator access time. Not available for Otis Compass elevators.

Otis EMS elevators may report with a significant delay, landing numbers that were selected after a badge was used to de-secure floors. Therefore, the P2000 system does not take any actions to re-secure those floors, as this may interfere with subsequent access requests. This implies that the Timed Button flag should always be selected.

223

The P2000 system then re-secures the floors after the configured elevator access time has elapsed, or when a new access request is processed that de-secures different floors. If the Timed Button flag is not selected, the P2000 system re-secures the elevator as soon as it receives a reported landing number.

Access Time – Enter the amount of time in seconds (2 to 600) that cardholders have to press a car-call button after badging at the elevator.

At the time a valid badge is presented to the elevator reader, the elevator access time starts. The elevator access time starts over with every subsequent presentation of a valid badge. At the beginning of the elevator access time certain floor buttons are enabled by the panel outputs per elevator access grant. Subsequent presentation of other badges therefore may enable more outputs. Only outputs exclusively enabled by elevator access grants are disabled at the end of the elevator access time. Not available for Otis Compass elevators.

Low Level Interface - This is the default connection to the elevator control system. The idea behind tying a security system to an elevator control system is to allow people access only to certain floors and to control public access to floors by time zone control. The way this is done through the Low Level Interface is by tying the security system's electrical outputs to the elevator control equipment, letting it know which of the cab's floor buttons a person is allowed to press. Obviously, a person in the cab could press any button, but only those that are enabled by the security system actually register and take the elevator to those floors. Each pressed button can also be fed back to an electrical input of the security system, so it can track which buttons were pressed at any time.

D620 Mode – This option enables the low level D620 Elevator Mode. If enabled, when a badge is presented at the elevator cab's reader, the panel searches the badge record for floor access information. The floor access information is compared with the floor button selection input point. If the floor button selection, then the output (timed) point for the floor the person should have access to is enabled. It is the elevator control system's responsibility to ensure the elevator does not go to disabled floors.

Note: If you configure a low level elevator with **D620 Mode** enabled, you must create new panel and terminal definitions. You cannot convert existing panels and terminals into an elevator application with D620 mode enabled.

The cab's floor button selection must be made before the elevator access time has expired, unless the floor call-button is enabled by public access or by direct output control. The floor car-call button that is exclusively enabled by the elevator access grant produces floor tracking message.

High Level Interface – Click to have the system communicate with the elevator control equipment via a serial protocol, exchanging all necessary information in both directions.

Protocol – If using a high level interface, select the protocol used to communicate to the elevator control equipment. To select this option, you must define the protocol parameters in the Elevator tab; see page 62.

Note: After you create or edit Otis Compass elevator settings, you are required to restart the P2000 Otis Interface Service to make effective the changes.

Address – When configuring KONE HLI elevators, you must enter the KONE elevator address (from 1 to 8) inside the KONE group controller. This value must match the address of the elevator group controller.

Machine Room Enclosure – Available for Otis Compass elevators only. A Machine Room Enclosure (MRE) defines a group of elevators that serve a set of floors. Select the MRE (1 to 8) that is associated with the elevator reader. As an option, you can select a Destination Entry Redirector (DER) that connects to all elevator groups for building-wide dispatching. Select the DER (1 or 2) that is associated with the elevator reader.

Destination Entry Computer – Available for Otis Compass elevators only. A Destination Entry Computer (DEC) is a user interface device into which the desired floor is entered. Select the DEC that is associated with the MRE or DER selected, and is also associated with the elevator reader.

Note: The MRE and DEC combination settings must be unique throughout the system.

Operational Mode – Select one of the four elevator modes provided with the Otis Compass system. See Otis Compass Elevator Modes on page 219 for more information.

Enable Otis PIN – Available for Otis Compass elevators only. Click if you allow cardholders to enter a PIN code on the DEC to gain access to a floor.

Floor Tracking – Floor tracking is permanently enabled for Otis Compass elevators. If enabled, the panel generates a history message identifying the badge number, cardholder's name, elevator, and floor selected when the car-call button is pressed. Floor tracking messages are generated only for floors whose associated output is exclusively enabled by the elevator access grant, and not enabled by public access or by direct output control.

A floor tracking message is generated for each elevator input that experiences a transition from the normal into the off-normal state during the elevator access time; or that is in the off-normal state at the time a valid badge is presented.

Track On Input Open – Defines the normal and off-normal states. If enabled, a floor tracking message is generated when the floor's input is open. If disabled, a floor tracking message is generated when the floor's input is closed.

Track On Transition Only – If enabled, a floor tracking message is generated only when the input transitions from a normal to off-normal state. If disabled, a floor tracking message is generated when the input transitions from a normal to off-normal state and during the presentation of a valid badge while the input is in the off-normal state.

Note: The **Track On Input Open** and **Track On Transition Only** options apply only to elevators that use input points for floor tracking, and only when the **Floor Tracking** option is enabled for Low Level Interface connections.

Otis EMS elevators report landing numbers that were selected after a badge was used to de-secure floors. When the floor tracking option is enabled, the P2000 system creates a floor tracking message for each landing number that is reported by the Otis EMS. The P2000 system associates the reported landing number with the last person that was granted access at the elevator.

225

ADA Compliance – Select one of the three special access flags that was also assigned to cardholders with ADA privileges and that informs the Otis Compass system that the person requires special access at a reader.

VIP Access – Select one of the three special access flags that was also assigned to cardholders with VIP privileges and that informs the Otis Compass system that the person requires special access at a reader.

Note: The ADA Compliance and VIP Access lists display the special access flag names as configured in Site Parameters; see page 34. These are global settings and are effective for all Otis Compass configured elevators in the system.

Configuring Floors

The Floor Information box at the bottom of the Elevator Configuration dialog box displays the associated floors active for access. Follow the next steps to add the individual floors that this particular elevator can service.

 In the Elevator Configuration dialog box, click Add at the bottom of the window. The Floor Configuration dialog box opens.

C Floor Configuration	×
Floor Name:	First Floor Lobby
Number:	1
Output Point:	Elevator Lights
Input Point:	Carl Button
Public Access Timezone:	Full Time
ОК	Cancel

- 2. Select a **Floor Name** that has not yet been assigned to this elevator. The list displays the floors names as configured in the Floor Name Configuration dialog box.
- 3. The floor **Number** index automatically displays in the Number field. You could select the Number first, and the associated floor name displays in the Floor Name field.

- 4. Select an available **Output Point** that has not yet been assigned to an elevator or cabinet. Not available for Otis Compass elevators.
- 5. Select an available **Input Point** that has not yet been assigned to an elevator or cabinet. Not available for Otis Compass elevators.
- 6. Select the **Public Access Timezone** defined to allow cardholders to use the elevator without presenting their badge at the reader. If no time zone is selected, then this floor is not active for public access.
- 7. Click **OK** to save your settings and return to the Elevator Configuration dialog box.

Configuring Otis Unsecured Elevators

Use this section to configure unsecured Otis Compass elevators. Unsecured elevators are not associated with readers, input, or output points and include floors that users are allowed to access without any specific access right.

- 1. From the System Configuration window, expand **Elevator/Cabinet Parameters** to display the elevator parameters.
- 2. Select **Otis Unsecured Elevators** and click **Add**. The Otis Unsecured Elevator Configuration dialog box opens.

🕻 Otis Unsecu	ed Elevator Configuration	_ _ _
	Name: Western Ba	nk Elevators
Machine Destination	Room Enclosure: MRE 2 Entry Computer: DEC 9 Uperational Mode: Mode 3	Enable Otis PIN: 🗹 Report on Terminal 🛛 Admin Entrance 💽
Floor Informat Number 1 2	ion Floor Name First Floor Lobby Second Floor Corporate	
Add	Edit Dek	te Cancel

- 3. Enter a descriptive Name for this elevator.
- 4. Click **Public** if you wish the elevator to be visible to all partitions.
- 5. The **Query String** value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).
- 6. Select the Machine Room Enclosure MRE (1 to 8) that defines a group of elevators that can serve a set of floors. As an option, you can select the Destination Entry Redirector (DER 1 or 2) that connects to all elevator groups for building-wide dispatching.
- 7. Select from the **Destination Entry Computer** drop-down list the user interface device number into which the desired floor is entered. This DEC number is associated with the MRE or DER selected.

Note: The MRE and DEC combination settings must be unique throughout the system.

- Select from Operational Mode drop-down list whether this is a Mode 1 or Mode 3 elevator. See Otis Compass Elevator Modes on page 219 for more information.
- Click Enable Otis PIN to allow unsecured elevators to accept a PIN code to gain access to a floor.
- 10. Select from the **Report on Terminal** drop-down list, the terminal that is used to report access grant decisions.

11. Click **Add** at the bottom of the window. The Floor Configuration dialog box opens.



- 12. Select a **Floor Name**. The list displays the floors names as configured in the Floor Name Configuration dialog box; see page 220.
- 13. The floor **Number** index automatically displays in the Number field. You could select the Number first, and the associated floor name displays in the Floor Name field.
- 14. Click **OK** to return to the Otis Unsecured Elevator Configuration dialog box.
- 15. After you enter all the information, click OK to save your settings and return to the System Configuration window. You are required to restart the P2000 Otis Interface Service to make effective the changes.

Configuring KONE IP Elevators

Before configuring a KONE IP elevator, you must define the KONE IP controller that serve as the interface to set the configuration parameters related to the elevator controller, as well as the interface to monitor the status of the elevator controller and its communication with the CK721-A panel.

KONE IP Controller Configuration

- 1. In the System Configuration window, expand the panel (CK721-A Version 3.1) that communicates with the KONE IP Controller.
- Select Kone IP Controller and click Add. The Kone IP Controller Configuration Edit dialog box opens.

🕻 Kone IP Controller Configurat	ion Edit 📃 🗌 ݢ
Panel Name	North Tower
Panel Id	19
Kone IP Controller Id	
Kone IP Type	KIC
Controller Name	KONE North Tower
IP Address	200 . 0 . 0 . 55
Backup Controller Name	
Backup IP Address	0.0.0.0
Send COP	N
Send DOP	
Heartbeat Interval	15
TCP Port	1
Group And Floor Configuration	
Group Address Define	d 🔺
0 Define	d Defined 🔽
1 Not De	fined
2 Not De	fined
4 Not De	finedFloors
Le une	
	OK Cancel

- 3. The **Panel Name** field displays the name of the selected panel, which is used to communicate with the KONE IP controller.
- 4. The **Panel Id** field displays the identification number assigned to the panel.
- 5. The **Kone IP Controller Id** displays the identification number of the KONE IP controller. This number only displays after you save the record.

- 6. Select from the **Kone IP Type** drop-down list, whether this is a KIC or a Primary/ Backup KGC controller.
- 7. Enter the **Controller Name** of the KONE IP controller.
- 8. Enter the **IP Address** of KONE IP controller.
- If you selected a Primary/Backup KGC controller type, enter the Backup Controller Name and Backup IP Address of the primary/backup controller.
- 10. Click **Send COP** if you wish the system to send COP global default masks messages to the KONE IP elevator controller.
- 11. Click **Send DOP** if you wish the system to send DOP global default masks messages to the KONE IP elevator controller.
- 12. In the **Heartbeat Interval** field, enter the time interval at which heartbeat messages are sent to the KONE IP elevator controller.
- 13. Enter the **TCP Port** number of the KONE IP elevator controller.

Kone IP Group and Floor Configuration

The Group and Floor Configuration box at the bottom of the Kone IP Controller Configuration dialog box displays the Group Number of the KONE IP controller and whether the group was defined. You can define up to 33 elevator groups for each KONE KIC controller. Primary/Backup KGC controllers only support elevator group address number 1 (all other elevator groups are ignored).

Floor Number	Floor Name	Level Number	Elevator Side	COP Destination When Connected	COP Destination When Disconnected	DOP Destination When Connected	DOP Destination When Disconnected	DOP Source When Connected	DOP Source When Disconnected	-
1	First Floor Lobby	1	Any 💌			П				
2	Second Floor Corporate	2	Front 💌							
3	Third Floor Accounting	3	Rear 💌							
4	Floor 4 Sales		<unused></unused>							
5	Floor 5		<unused></unused>							
6	Floor 6		<unused></unused>							
7	Floor 7		<unused></unused>							
8	Floor 8		<unused></unused>							
9	Floor 9		<unused></unused>							
10	Floor 10		<unused></unused>							
11	Floor 11		<unused></unused>							
12	Floor 12		<unused></unused>							
17	Eloor 12		<unused></unused>	<	Car	ncel				

- 1. In the Group and Floor Configuration box, select the group number you wish to define and click **Floors**. The Kone IP Floor Configuration dialog box opens.
- 2. The **Floor Number** column displays the number of floors configured in Site Parameters.
- The Floor Name column displays the floor name assigned to each floor number. See Defining Floor Names on page 220.
- 4. Enter the floor **Level Number** as defined by the KONE equipment.
- 5. Select the **Elevator Side** through which the selected floor is accessible.
- 6. Click **COP Destination When Connected** to specify whether the selected floor is publicly accessible as a COP destination when the KONE IP controller is online. This value is ignored when communicating to KONE KIC controllers.
- Click COP Destination When Disconnected to specify whether the selected floor is publicly accessible as a COP destination when the KONE IP controller is offline. This value is ignored when communicating to KONE KIC controllers.

- 8. Click **DOP Destination When Connected** to specify whether the selected floor is publicly accessible as a DOP destination when the KONE IP controller is online. This value is ignored when communicating to KONE KIC controllers.
- 9. Click **DOP Destination When Disconnected** to specify whether the selected floor is publicly accessible as a DOP destination when the KONE IP controller is offline. This value is ignored when communicating to KONE KIC controllers.
- 10. Click **DOP Source When Connected** to specify whether the selected floor is publicly accessible as a DOP source when the KONE IP controller is online. This value is ignored when communicating to KONE KIC controllers.
- 11. Click **DOP Source When Disconnected** to specify whether the selected floor is publicly accessible as a DOP source when the KONE IP controller is offline. This value is ignored when communicating to KONE KIC controllers.
- 12. Click **OK** to save the KONE IP group and floor configuration.

- 13. Select the KONE IP group number just defined and click **Defined**.
- 14. Click **OK** to save the KONE IP controller.

Kone IP Elevator Configuration

Use the Kone IP Elevator Configuration dialog box to define the reader, group and elevator address, and the floor parameters associated with your KONE IP elevator.

To Configure KONE IP Elevators:

1. In the System Configuration window, expand the panel (CK721-A Version 3.1) that communicates with the KONE IP elevator.

- 2. Select **Kone IP Elevator** and click **Add**. The Kone IP Elevator Configuration dialog box opens.
- 3. Enter a descriptive **Name** for the KONE IP elevator.
- 4. The **Panel Name** field displays the panel you selected from the System Configuration window.
- 5. The **Panel Id** field displays the identification number assigned to the panel.
- 6. Select the **Reader** terminal that provides the access in the elevator cab.
- 7. In the **Access Time** field, enter the time (0 to 30 seconds) that cardholders have to press a car-call button after badging at the elevator.

C Kone IP Elevator Configuration	1			
Name	Tower Elevator		🔲 Public	
Panel Name	North Tower			
Papel Id	19			
1 0.101 10	,			
Reader	Main Lobby Reader	•		
Access Time	5 seconds			
	Floor Tracking			
Туре	COP			
COP Group Address	1			
COP Elevator Address	1			
Elevator Floor Management				
Floor Number Floor Name	Public Acces	s Timezone Public	When Disconnected	
1 First Floor Lobby	Full Time	No		
2 Second Floor Cor	porate Full Time	Yes		
3 Third Floor Accou	nting <none></none>	Yes		
Select Floors	Ρι	Public Access Timezor blic When Disconnect	ne <none></none>	
	ОК	Can	cel	

- Click Floor Tracking to allow the panel to generate a history message identifying the badge number, cardholder's name, elevator, and floor selected when the car-call button is pressed.
- 9. Select from the **Type** drop-down list, whether this is a COP or DOP KONE IP elevator.
- 10. Enter the COP Group Address or DOP Address of the elevator group. This value must match the address of the elevator group controller. If you selected a Primary/ Backup KGC controller type, the COP Group Address must be set to 1.
- 11. Enter the **COP Elevator Address** or **DOP Level Number** of the elevator cab.
- In the Elevator Floor Management box, click Select Floors. The Select Floors dialog box open.

elect Floors					
Selected Floors			Available Floors		
Floor Number	Floor Name		Floor Number	Floor Name	
1	First Floor Lobby		4	Floor 4 Sales	
2	Second Floor Corporate		5	Floor 5	
3	Third Floor Accounting		6	Floor 6	
			7	Floor 7	
		<<	8	Floor 8	
			9	Floor 9	
			10	Floor 10	
			11	Floor 11	
			12	Floor 12	
			13	Floor 13	
			14	Floor 14	
			15	Floor 15	
			16	Floor 16	
			17	Floor 17	
			18	Floor 18	
			19	Floor 19	
			20	Floor 20	
			21	Floor 21	
			22	Floor 22	
			23	Floor 23	
▲	<u>></u>		74	Floor 24	•
				-1	
	OK		Cancel		

- 13. From the **Available Floors** list, select the floors you wish to include in your elevator configuration.
- 14. Click <<. The floors are included in the Selected Floors box.
- 15. Click OK.

- 16. In the Elevator Floor Management list box, select a floor number. Select the Public Access Timezone defined for public access. If no time zone is selected, this floor is not active for public access.
- 17. Click **Public When Disconnected** to specify whether the floor should be in public access when the KONE IP controller is offline.
- 18. Repeat this steps for each floor.
- 19. Click **OK** to save your KONE IP elevator configuration.

Controlling the KONE IP Portal

Operators with the appropriate permissions can manually change a specific KONE IP elevator's mode of operation from a workstation.

To Change Mode of Operation of a KONE IP Elevator:

1. From the P2000 Main menu select **Control>Kone IP Portal Command**. The Kone IP Portal Command dialog box opens.

C Kone IP Portal Co	mmand			_ 🗆 🗙
Partition Sup	er User	•		
Kone IP Portal M	ode Command			
Corp	oorate Elevator h Tower Elevator			
<u>N</u> orma	l	Override	Lockdown	J
		Done		

- 2. If this is a partitioned system, select the **Partition** in which the elevators are active.
- 3. Select from the Kone IP Portal Mode Command list box, the elevator you wish to control
- 4. Click one of the following actions:

Normal – to return the elevator to its previous state.

Override – to override access at the elevator. All floors defined for the selected elevator are in public access.

Lockdown – to prevent access to all destination floors.

5. Click Done to exit the window.

Defining Floor Groups

Use the Edit Floor Group dialog box to associate specific groups of floors with physical elevators.

- From the System Configuration window, expand Elevator/Cabinet Parameters to display the elevator parameters.
- Select Elevator Floor Groups and click Add. The Edit Floor Group dialog box opens.

🖸 Edit Floor Group 📃 🗖	х
Name: Main Building	
Partition: Super User	
Detatils	
Elevator Floor Mask	
Add Edit Delete	
OK Cancel	

3. Enter a descriptive **Name** for the Floor Group.

- 4. If you use Partitioning, select the **Partition** that has access to this Floor Group.
- 5. Click **Public** to allow all partitions to see this Floor Group.
- 6. Click **Add** at the bottom of the dialog box. The Group Detail dialog box opens.

🕼 Group Detail		_ 🗆 ×
	Elevator: North West Elevator	
	Eloor Mask: juperations taroup	

- 7. Select an **Elevator** name, previously configured in the Elevator Configuration dialog box.
- 8. Select the **Floor Mask** name, previously configured in the Floor Mask dialog box.
- 9. Click **OK** to save your entries and return to the Edit Floor Group dialog box.
- Click **OK** to save the Floor Group and return to the System Configuration window.

Creating Access Groups for Elevator Floors

Access groups are described under Create Access Groups on page 247. See this section for detailed information.

Cabinet Access Control

The Cabinet Access Control feature protects sensitive information by monitoring and controlling access to files and equipment contained in a cabinet. The P2000 system allows a single reader to provide access to up to 32 cabinets. Cabinet readers are associated with a set of output points to unlock cabinet doors and an optional set of input points to monitor the status of cabinet doors. The panel may grant access to a cabinet by unlocking the corresponding door when a badge is presented at a reader installed at the cabinet.

The cabinet access control gives you the ability to assign cardholders access to various cabinets and doors in your facility, through their access groups.

Cabinets are assigned doors and door groups, then these doors and door groups are included in access groups which are assigned to cardholders.

The basic procedures for defining and implementing the cabinet access control are:

- Define Door Names
- Define Door Masks
- Configure Cabinets
- Configure Doors
- Define Door Groups
- Create Access Groups for Cabinet Doors

Steps to perform each procedure are presented in the following sections. To successfully implement the cabinet access control, configure these steps in the order presented.

Defining Door Names

Use the Door Name Configuration dialog box to define door names and associated index number. Doors should be named by physical characteristics such as Supply Cabinet 1 or Electronics Bay 1, to help identify the door name and location when configuring the actual cabinets. The system supports up to 128 doors.

- 1. In the System Configuration window, expand **Elevator/Cabinet Parameters** to display the cabinet parameters.
- Select Cabinet Door Names and click Edit. The Door Name Configuration dialog box opens.

Door Name C	Configuration	
Number	Door Name	▲
1	Supply Cabinet 1	
2	Supply Cabinet 2	
3	Electronics Bay 1	
4	Electronics Bay 2	
5	Electronics Bay 3	
6	Door 6	
6	Door /	
8	Door 8	
3	Door 9 Deer 10	
11	Door 11	
12	Door 12	
13	Door 13	
14	Door 14	
15	Door 15	
16	Door 16	
17	Door 17	
18	Door 18	
19	Door 19	
20	Door 20	
21	Door 21	
22	Door 22	
23	Door 23	
24	Door 24	
25	Door 25	
26	Door 26	
27	Door 27	•
ĺ	Door Name: Tool Crib 1	
De <u>f</u> aults	<u>U</u> pdate	Insert Delete
Γ	<u>o</u> k	Cancel

The number of doors entered in the Site Parameters dialog box displays. (See Site Parameters Field Definitions on page 34.)

- Click on the door you wish to rename. The door name displays in the **Door Name** field at the bottom of the window.
- 4. Rename the door accordingly and click **Insert**. The new name displays and the list of door names moves down one position. For example, if you rename door 1 and door 2, Number 3 on the list becomes Door 1.
- If you wish to edit a door name, click on the door name, rename it, then click Update.
- 6. If you delete a door name, using the **Delete** button, the next door on the list moves up one position.
- 7. To restore the default door names, click **Defaults**.
8. When you finish configuring door names, click **OK** to return to the System Configuration window.

Defining Door Masks

You can group doors that have common access throughout your facility and then apply them as a group to associate them with physical cabinets when configuring Door Groups.

- 1. In the System Configuration window, expand **Elevator/Cabinet Parameters** to display the cabinet parameters.
- 2. Select Cabinet Door Masks and click Add. The Door Mask dialog box opens.

Partition: Super User

Selected Doors

Supply Cabinet 1 Electronics Bay 1

actronics Bai

Name: Aircraft Maintenance

3. If you use Partitioning, select the **Partition** that has access to this Door Mask. All available doors (for the partition selected) are listed on the right side of the dialog box.

OK

- 4. Click **Public** to allow all partitions to see this Door Mask.
- Enter a descriptive Name for the Door Mask. In the example, Aircraft Maintenance Group includes Supply Cabinet 1, Electronics Bay 1, and Electronics Bay 2 doors.

- 6. From the **Available Doors** list, click the door you wish to include in your group.
- Click <<. The door moves to the left side of the dialog box, to be included in the Selected Doors box.
- To remove a door from the Selected Doors box, select the door and click >>.
- When all doors you wish to include in the group have been moved to the Selected Doors box, click OK. A Door Mask icon for the new group is added under the Cabinet Door Masks root icon in the System Configuration window.

Configuring Cabinets

- 🗆 X

Public

•

Available Doors

Door 6

oor 24 oor 25 oor 26 oor 26 oor 27

Cancel

Supply Cabinet 2 Electronics Bav 3 Use the Cabinet Configuration dialog box to define the reader and associated output and optional input points that operate with your particular cabinet controller type.

- 1. In the System Configuration window, expand the CK7xx Panel to which you wish to assign a cabinet.
- 2. Select **Cabinets** and click **Add**. The Cabinet Configuration dialog box opens.
- 3. Enter the required information according to the following Cabinet Configuration Field Definitions.
- 4. After you have entered all the information, click **OK** to save your settings and return to the System Configuration window.

Cabinet Configuration Field Definitions

Name – Enter a descriptive **Name** for this cabinet.

Public – Click **Public** if you wish the cabinet to be visible to all partitions.

Panel – This field displays the name of the panel you selected from the System Configuration window.

Query String – This value is used with message filtering (see Define Query String Filters on page 240), and is also used with the P2000-Metasys integration feature (see Configuring Hardware Components for BACnet Interface on page 381).

Reader – Select an available reader that has not yet been assigned to an elevator or cabinet, and that has an address number no higher than 16.

Emergency Override – If the cabinet has an emergency override switch, select an available input point that has not yet been assigned to an elevator or cabinet. The only purpose of this input point is to send messages to the Real Time List; it does not control Emergency Override. **Service Override** – If the cabinet has a service override switch, select an available input point that has not yet been assigned to an elevator or cabinet. The only purpose of this input point is to send messages to the Real Time List; it does not control Service Override.

Door Tracking – If enabled, the panel generates a history message identifying the badge number, cabinet, and door selected when an enabled door is opened.

Report Alarm – If enabled, an alarm is reported when a door, that has not been enabled, is opened; or when an enabled door remains opened for longer than the time set in the Alarm Suppression Time.

Access Time – Enter the amount of time in seconds (2 to 600) that cardholders have to open a door after badging at the cabinet.

Alarm Suppression Time – Enter the amount of time in minutes (2 to 1440) for a door to remain open.

Cabinet Con	figuration					
	Name:	Main Hangar		🔽 Public	c	
	Panel:	Simulator				
	Query String:			Repo	ort Alarm	
	Reader:	, Cabinet Reader	•		_	
	Emergency Override:	Emergencu Switch		Access Time:	5	seconds
	Service Override:	Service Switch	-	Alarm Suppression Time:	60	minutes
- Door Informatio	on			- internet internet internet	1	
Number	Door Name	Output Point	Input Poin	Public Act	cess Timezone	
1	Supply Cabinet 1 Supply Cabinet 2	Dr 01	Dr Inp1 Dr Inp2	Always A	clive	
2	Supply Cabinet 2	DI UZ	Di inp2			
1						
Add	<u>E</u> dit	Delete				
		ОК	(Cancel		

Configuring Doors

The Door Information box at the bottom of the Cabinet Configuration dialog box displays the associated doors active for access. Follow the next steps to add individual doors to this cabinet.

 In the Cabinet Configuration dialog box, click Add at the bottom of the window. The Door Configuration dialog box opens.

C Door Configuration	<
Door Name:	Supply Cabinet 1
Number:	1 🚊
<u>O</u> utput Point:	Dr 01
Input Point:	Dr Inp1
Public Access <u>T</u> imezone:	Always Active
ОК	[Cancel]

- 2. Select a **Door Name** that has not yet been assigned to this cabinet. The list displays the doors names as configured in the Door Name Configuration dialog box.
- 3. The door **Number** index automatically displays in the Number field. You could select the Number first, and the associated door name displays in the Door Name field.
- Select an available **Output Point** that has not yet been assigned to an elevator or cabinet.
- Select an available Input Point that has not yet been assigned to an elevator or cabinet.
- 6. Select the **Public Access Timezone** defined to allow cardholders to access the cabinet without presenting their badge at the reader. If no time zone is selected, then this door is not active for public access.
- 7. Click **OK** to save your settings and return to the Cabinet Configuration dialog box.

Defining Door Groups

Use the Edit Door Group dialog box to associated specific groups of doors with physical cabinets.

- 1. In the System Configuration window, expand **Elevator/Cabinet Parameters** to display the cabinet parameters.
- Select Cabinet Door Groups and click Add. The Edit Door Group dialog box opens.

Edit Door Grou	P			
	<u>N</u> ame:	Har	ngar Group	
	Partition:	Sup	per User	T
	l i		Public	
Detatils				
Cabinet			Door Mask	
Main Hangar			Aircraft Maintenance	
Add	Edit		Delete	

- 3. Enter a descriptive **Name** for the Door Group.
- 4. If you use Partitioning, select the **Partition** that has access to this Door Group.
- 5. Click **Public** to allow all partitions to see this Door Group.
- 6. Click **Add** at the bottom of the dialog box. The Group Detail dialog box opens.



- Select a Cabinet name, previously configured in the Cabinet Configuration dialog box.
- 8. Select a **Door Mask** name, previously configured in the Door Mask dialog box.
- 9. Click **OK** to save your entries and return to the Edit Door Group dialog box.
- 10. Click **OK** to save the Door Group and return to the System Configuration window.

Creating Access Groups for Cabinet Doors

Access groups are described under Create Access Groups on page 247. See this section for detailed information.

Configure Message Filtering and Message Routing

Message Filtering and Routing configuration allows you to transmit and receive specific messages to and from specific local or remote P2000 systems, thereby reducing network traffic by transmitting and receiving only messages that pass filter criteria. The Remote Message Server (RMS) maintains central control over all message routing and transmits messages only to P2000 servers or workstations that the RMS assumes are able and willing to receive the message.

Operators and Messages

The following illustrates the authorization process to allow operators to see messages.



Basic Principles and Definitions

P2000 Site – Uniquely identified by its Local Site name. A P2000 site can have multiple locations but only one P2000 server.

P2000 Location – A physical location or place with a P2000 workstation or panel.

P2000 Server – A single server that communicates with the panels for that site. Typically, it is also the database server for that site, but it is possible for another computer to act as the database server for performance reasons.

P2000 Workstation – A single computer that is connected to one P2000 server and is used to run the P2000 software.

P2000 System – A P2000 system is defined by what is controlled by the P2000 server. A P2000 system has no relationship to geography, so a single P2000 system can and often contains multiple facilities in multiple locations.

Local P2000 Server/Workstations – A P2000 server or P2000 workstations are local to each other, if they are part of the same P2000 system.

P2000 Remote Server – A P2000 server that controls a different P2000 system to the one where the transaction was originated. The P2000 Remote Server is the recipient of a forwarded transaction and has no knowledge of the access control hardware and system information related to the originating P2000 system.

Remote Transactions – Remote Transactions are messages received from another P2000 system.

Message Forwarding – Message Forwarding is the ability to temporarily forward messages from one P2000 operator logged on at a local P2000 workstation "A" to another local P2000 workstation "B." The forwarded messages are only visible at the P2000 workstation "B," if the operator at workstation "B" has sufficient rights to view these messages.

Message Filtering – Reduces network traffic by only transmitting a sub-set of P2000 messages that pass a filter criteria.

Message Routing – Allows the system to route a sub-set of messages to a remote P2000 system.

Remote Message Service (RMS) – P2000 service that receives messages from the local RTL Route Service and transmits these messages to the remote P2000 Remote Message Service. When receiving a remote message, the local Remote Message Service processes the message and passes it on to the local RTL Route Service for distribution to the local workstations.

Sequence of Steps

The basic procedures for defining and implementing message filtering and routing are:

- Define message filters
- Create message filter groups
- Configure P2000 Remote Servers
- Assign message filter groups to workstations (page 21), operators (page 24), and remote servers (page 246).
- Define Remote Message Service settings in Site Parameters; see RMS Tab on page 44.

Message Filtering

Message filtering allows you to control the types of messages transmitted to local workstations or remote servers, thereby reducing network traffic by only transmitting a sub-set of P2000 messages that pass filter criteria.

Messages are sent to all workstations by default, provided the message is marked **Public** or the logged on operator has the proper access. Depending on the parameters selected in the Message Filter Configuration dialog box, you can filter which messages are to be transmitted when alarm and transaction messages are generated. The system only transmits messages that pass the filter criteria defined. You can, for instance, filter messages to send a specific group to one workstation and a different group to another. By using message filters you may for example, limit the alarm messages sent to workstations located in Building A to only those alarms originating in Building A, and do the same for Building B. For a complete list of all available message types and associated sub-types, see Appendix B: Message Types and Sub-Types.

Note: All messages are sent by default to the local Server at all times, therefore this feature cannot be used at the Server.

To Create a Message Filter:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- Select Message Filter and click Add. The Message Filter Configuration dialog box opens.

- 3. If you use Partitioning, select the **Partition** that has access to this Message Filter.
- 4. If you use Partitioning, click **Public** to allow all partitions to see this Message Filter.
- 5. Enter a descriptive **Name** for this Message Filter.
- 6. See the following sections to define message types, filters, and ranges.

Note: The length of all filter strings entered in each Selected List is limited to approximately 1000 characters.

- 7. As you work through the tabs, you may click **Apply** at any time to save your entries.
- 8. After you have entered all the information, click **OK** to save the settings and return to the System Configuration window.

6 Message Filter Configuration	
Partition	Super User
Name	Weekend Alarm Monitoring
Message Type Site Name Partition Name	Query String Item Name Priority Range Alarm Escalation Range Operator Name Alarm Category Name
Exclude Tackuda	AvailableType Available Subtype
	Code Message Name Code Message Name 1 Notify 1 Generic 3 Alarm 2 Generic 2 System Action 3 Area 259 Muster Status 4 Guard Tour 259 Muster Event Trigger 5 Muster Xuning 290 P900 CLIC Command 6 Muster Zone Status 290 P900 CLIC Status 7 Muster Disabled 305 Roucing Session 8 Muster Aborted 403 Intrusion Status 9 Loop Tamper Alarm 28673 RTL Data 12 AV Motion Alarm 28675 Audit 13 AV Behavior Alarm
	Manual Edit Box Add Update Delete
	OK Cancel Apply

Define Message Types

- 1. Click the Message Type tab.
- 2. In the **Available Type** box, click the message type you wish to define.
- 3. In the **Available Subtype** box, click the message subtype you wish to define. The selections in this box are dependent on the type selected in the Available Type box.
- 4. Click **Add**. The message type and subtype code are automatically entered in the Selected List box.
- 5. To enter messages from third-party software or any currently unknown message, enter the text in the **Manual Edit Box**, then click **Add**.
- 6. To edit your selection, select the message code from the Selected List box, make the change, then click **Update**.
- 7. To delete a message type from the Selected List, select the message code and click **Delete**.
- 8. Once the message types are selected, click **Include** in the Selected List box to accept these types of messages.
- 9. To reject all messages of the type selected, click **Exclude**.

Define Site Name Filters

Messages associated with the Site Name selected in this tab are either accepted or rejected. For example, you can select to see *Area Alarm* messages originated only at the *Chicago Office*, or you can select to see all *Area Alarm* messages, except the ones originated at the *Chicago Office*, if the Exclude option is selected.

C Exclude	:	5ite Name		
Include		Chicago Office		
Chicago Office		Add	Update	Delete
		Available List		
		Simi Valley		
	<<			
	22			

- 1. Click the Site Name tab.
- Select from the Available List the Site Name and click << to move it to the Selected List. To remove it from the Selected List, click >>.

Note: The Available List displays the Local Site Name only. All other site names need to be entered in the Site Name field. Site Name entries are case sensitive.

3. To add a remote site name to the Selected List, enter the name in the **Site Name** field and click **Add**.

If the Site Name changes either at the local site or at the remote site, you must re-select the name from the Available List or re-enter the new name in the Site Name field.

Entries may contain a filter string to specify more than one Site Name, for example enter New* to add Site Names such as New York, New Jersey, or New Security.

Note: The wildcard character * (asterisk) in a filter string means that all possible selections are listed. The wildcard character is supported at the end of the filter value only.

4. To edit a remote site name or filter string, select the name, make the change, then click **Update**.

- 5. To delete a remote site name or filter string from the list, select the name and click **Delete**.
- Once the Site Names are selected, click Include in the Selected List box to accept messages associated with the Site Names.
- 7. To reject all messages associated with the Site Names selected, click **Exclude**.

Define Partition Name Filters

The system either accepts or rejects messages associated with the Partition Names selected in this tab. The Available List displays all partition names within the local system, including any Remote Partitions entered in the Edit Operator dialog box.

Message Type Site Name Selected List C Exclude C Include Marehouse	Partition Name	Query String	Item Name Partition Main* Availal Execu Huma Main (Super	Priority Range Name Add U U ble List the Electron Resources - Alarka Office - New York User	Alarm Escalation Ran	
Message passes filter	riteria, if messag	has no filter va	lue			

- 1. Click the Partition Name tab.
- Select from the Available List the Partition Name and click << to move it to the Selected List. To remove it from the Selected List, click >>.
- 3. To add a remote partition name to the Selected List, enter the name in the **Partition Name** field and click **Add**.

If the Partition Name changes either at the local site or at the remote site, you must re-select the name from the Available List or re-enter the new name in the Partition Name field. You may enter a filter string to specify more than one Partition Name, for example enter Main* to add Partition Names such as Main Office - Atlanta and Main Office -New York.

- 4. To edit a remote partition name or filter string, select the name, make the change, then click **Update**.
- 5. To delete a remote partition name or filter string from the list, select the name and click **Delete**.
- 6. Once the Partition Names are selected, click **Include** in the Selected List box to accept messages associated with the Partition Names.
- 7. To reject all messages associated with the Partition Names selected, click **Exclude**.
- 8. If the **Message passes filter criteria, if message has no filter value** check box is enabled, the message meets the filter criteria even if there is no filter value. Do not select the check box to stop the message from passing the filter criteria if there is no filter value.

Define Query String Filters

Use this tab to filter messages by Query Strings. Query Strings are filled by querying Panels, Terminals, Input Points, and Output Points. The Available List displays all query strings defined within the local system.

<	Add Update Delete
<<	1
	1

- 1. Click the Query String tab.
- Select from the Available List the Query String and click << to move it to the Selected List. To remove it from the Selected List, click >>.
- 3. To add a remote query string to the Selected List, enter the query string in the **Query String** field and click **Add**.

If the Query String Name changes either at the local site or at the remote site, you must re-select the name from the Available List or re-enter the new name in the Query String field.

You may enter a filter string to specify more than one Query String, then click **Add**.

- 4. To edit a remote query string name or filter string, select the name, make the change, then click **Update**.
- 5. To delete a remote query string name or filter string from the list, select the name and click **Delete**.
- Once the Query Strings are selected, click Include in the Selected List box to accept messages associated with the Query Strings.
- 7. To reject all messages associated with the Query String selected, click **Exclude**.
- 8. If the **Message passes filter criteria, if message has no filter value** check box is enabled, the message meets the filter criteria even if there is no filter value. Do not select the check box to stop the message from passing the filter criteria if there is no filter value.

Define Item Name Filters

Use this tab to filter messages by Item Names. The Available List displays all Panels, Terminals, Input and Output Points defined within the local system.

Exclude	Item Name	
C Include	Area*	
Area*	Add Update Delete	
	Available List	
	Area Eight	_
	Area Eleven Area Fifteen	
	Area Five	
	>>> Area Fourteen	
	Area Nine Area Seven	
	Area Six	
	Area Ten Area Thirteen	
	Area Twelve	

- 1. Click the Item Name tab.
- Select from the Available List the Item Name and click << to move it to the Selected List. To remove it from the Selected List, click >>.
- 3. To add an item from a remote site to the Selected List, enter the name in the Item Name field and click Add.

If the Item Name changes either at the local site or at the remote site, you must re-select the name from the Available List or re-enter the new name in the Item Name field.

You may enter a filter string to specify more than one Item Name.

- 4. To edit a remote item name or filter string, select the name, make the change, then click **Update**.
- 5. To delete a remote item name or filter string from the list, select the name and click **Delete**.
- Once the Item Names are selected, click Include in the Selected List box to accept messages associated with the Item Names.
- 7. To reject all messages associated with the Item Name selected, click **Exclude**.
- 8. If the **Message passes filter criteria, if message has no filter value** check box is enabled, the message meets the filter criteria even if there is no filter value. Do not select the check box to stop the message from passing the filter criteria if there is no filter value.

Define Priority Ranges

Priorities define the order an alarm message is placed in the alarm queue. You can configure message filtering to accept or reject messages within a priority range. For example, you can assign a security supervisor to monitor high priority alarms only (zero being the highest).

Message Type	Site Name	Partition Name	Query String	Item Name	Priority Range	Alarm Escalation Range	0
Priority Rang	9e						
From 0		9 9			From: 0 To: 9 Add Up	date Delete	
🔽 Message p	asses filter i	riteria, if messag	e has no filter v	alue			

- 1. Click the Priority Range tab.
- 2. Enter in the **From** field the start of the priority range.
- 3. Enter in the **To** field the end of the priority range.
- Click Add. The selected values display in the Priority Range box.
- If you wish to edit the priority range, select the value, make the change, then click Update.
- 6. To delete an entry, select the value and click **Delete**.
- 7. Once the Priority Ranges are selected, click **Include** in the Priority Range list box to accept messages that have a priority value within the range selected.
- 8. To reject all messages that have a priority value within the range selected, click **Exclude**.

9. If the **Message passes filter criteria, if message has no filter value** check box is enabled, the message meets the filter criteria even if there is no filter value. Do not select the check box to stop the message from passing the filter criteria if there is no filter value.

Define Alarm Escalation Ranges

You can configure message filtering to accept or reject messages based on the alarm escalation value. For example, you can assign a security supervisor to monitor only the alarms escalated above level 5 (0 meaning that an alarm has not been escalated, and 10 meaning an alarm has been escalated to the highest possible value).

lessage Type	Site Name	Partition Name	Query String	Item Name	Priority Range	Alarm Escalation Range
 Alarm Escala Exclude Include 	tion Range -					
From		To 8				
					From: 5	
					To: 8	
					Add Up	odate Delete
I						
Message o	asses filter o	riteria, if messag	e has no filter v	/alue		

- 1. Click the Alarm Escalation Range tab.
- 2. Enter in the **From** field the start of the alarm escalation range.
- 3. Enter in the **To** field the end of the alarm escalation range.
- 4. Click Add. The selected values display in the Alarm Escalation Range box.
- 5. If you wish to edit the alarm escalation range, select the value, make the change, then click **Update**.
- 6. To delete an entry, select the value and click **Delete**.

- 7. Once the Alarm Escalation Ranges are selected, click **Include** in the Alarm Escalation Range list box to accept messages that have an alarm escalation value within the range selected.
- 8. To reject all messages that have an alarm escalation value within the range selected, click **Exclude**.
- 9. If the Message passes filter criteria, if message has no filter value check box is enabled, the message meets the filter criteria even if there is no filter value. Do not select the check box to stop the message from passing the filter criteria if there is no filter value.

Define Operator Name Filters

Use this tab to accept or reject messages associated with the operator names selected here. For example, you can limit the number of operators who respond to alarm messages generated at your local site. The Available List displays the names of all the operators within the local system.

- 1. Click the **Operator Name** tab.
- Select from the Available List the Operator Name and click << to move it to the Selected List. To remove it from the Selected List, click >>.

 To add remote operator names to the Selected List, enter the name in the Operator Name field and click Add.

If the Operator Name changes either at the local site or at the remote site, you must re-select the name from the Available List or re-enter the new name in the Operator Name field.

You may enter a filter string to specify more than one Operator Name.

- 4. To edit a remote operator name or filter string, select the name, make the change, then click **Update**.
- 5. To delete a remote operator name or filter string from the list, select the name and click **Delete**.
- 6. Once the Operator Names are selected, click **Include** in the Selected List box to accept messages associated with the Operator Names.
- 7. To reject all messages associated with the Operator Names selected, click **Exclude**.
- 8. If the **Message passes filter criteria, if message has no filter value** check box is enabled, the message meets the filter criteria even if there is no filter value. Do not select the check box to stop the message from passing the filter criteria if there is no filter value.

Define Alarm Category Filters

The system either accepts or rejects messages associated with the Alarm Category Names selected in this tab. The Available List displays the default *P2000* category and all user-defined categories. If you use the Enterprise option, the Alarm Categories defined for all P2000 sites within an Enterprise system are listed.

Exclude		Narm Category Name	
C Include		P2000\Security\Building 1	
P2000(Maintenance)Building 1 P2000(Security)Building 1		Add Update Delete	
		Available List	
	~~	P2000 P2000/Maintenance P2000/Maintenance/Building 2 P2000/Security P2000/Security/Building 2	
	>>		

- 1. Click the Alarm Category Name tab.
- Select from the Available List the Alarm Category Name and click << to move it to the Selected List. To remove it from the Selected List, click >>.
- 3. To add an alarm category name, enter the name in the Alarm Category Name field and click Add.

You may enter a filter string to specify more than one Alarm Category Name.

- 4. To edit a remote alarm category name or filter string, select the name, make the change, then click **Update**.
- 5. To delete an alarm category name or filter string from the list, select the name and click **Delete**.
- 6. Once the Alarm Category Names are selected, click **Include** in the Selected List box to accept messages associated with the Alarm Category Names.
- To reject all messages associated with the Alarm Category Name selected, click Exclude.
- 8. If the Message passes filter criteria, if message has no filter value check box is enabled, the message meets the filter criteria even if there is no filter value. Do not select the check box to stop the message from passing the filter criteria if there is no filter value.

Create Message Filter Groups

Message filters are assigned by groups; therefore, you must create Message Filter Groups before they are available to be assigned to workstations, operators, and remote servers.

A Message Filter Group can contain multiple message filters, but if at least one message filter within the group passes the filter criteria, the message is transmitted.

To Create a Message Filter Group:

 From the System Configuration window, select Message Filter Group and click Add. The Edit Message Filter Group dialog box opens.



- 2. If you use Partitioning, select the **Partition** that has access to this Message Filter Group. All available message filters (for the partition selected) are listed on the right side of the dialog box.
- 3. If you use Partitioning, click **Public** to allow all partitions to see this Message Filter Group.
- 4. Enter a descriptive **Name** for this Message Filter Group.
- 5. From the **Available** list, click the message filter you wish to include in your group.

 Click <<. The message filter moves to the left side of the dialog box, to be included in the Selected box.

Note: The Selected box displays **auto-added** next to a Message Filter that was automatically added using a Host Event.

- To remove a message filter from the Selected box, select the message filter and click >>.
- When all message filters you wish to include in the group have been moved to the Selected box, click OK. A Message Filter Group icon for the new group is added under the Message Filter Groups icon in the System Configuration window.

Message Routing

Message routing allows the transfer of alarm and transaction messages between P2000 Servers located at different P2000 Sites. Message routing is processed by the Alarm Monitor (see Monitoring Remote Alarms on page 287) and the Real Time List application (see Monitoring Remote Messages in Real Time on page 356).

Note: Before you configure any P2000 Remote Servers, verify your settings in the RMS tab of Site Parameters (page 44), to make sure your system is ready to process remote messages.

Configuring P2000 Remote Servers

The P2000 Remote Server application must be properly configured at each remote site that wishes to transmit and receive alarm and transaction messages. The setup must include the name, IP address and Remote Message Service Listener Port number of the remote site; the type of messages to be forwarded and at what times; and other related parameters.

To Create a P2000 Remote Server:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Select **Remote Server** and click **Add**. The P2000 Remote Server dialog box opens at the General tab.
- 3. Fill in the information on each tab according to the following P2000 Remote Server Field Definitions.
- 4. As you work through the tabs, you may click **Apply** at any time to save your entries.
- 5. After you have entered all the information, click **OK** to save the settings and return to the System Configuration window.

Note: Any change made to the P2000 Remote Server settings only takes effect after you restart the P2000 Remote Message Service; see Starting and Stopping Service Control on page 470.

P2000 Remote Server Field Definitions

General Tab

Use this tab to define general descriptive information of the P2000 remote servers that are allowed to receive or transmit messages to other servers.

C P2000 Remote Server	
General Transmit Filter Transmit	Queue Transmit Session
Partition	Super User Public
Name	Atlanta Server
IP Address 📀	200 . 0 . 0 . 0
Computer Name	
Remote site name	
E Receive	a mossanes from this server
✓ Transmi	it messages to this server
	Port 41016 Binary Protocol
	OK Cancel Apply

Partition – If you use Partitioning, select the Partition that has access to this P2000 Remote Server.

Public – Click to allow all partitions to see this P2000 Remote Server.

Name – Enter a descriptive Name of the P2000 Remote Server. This name must match exactly the name of the server at the remote site, including the case.

IP Address – If you select the IP Address option, enter the IP Address of the P2000 Remote Server that is used to receive or transmit messages.

Computer Name – If you select the Computer Name option, enter the Windows computer name that is used to receive or transmit messages, or click the [...] button to find a computer by name on your network.

Remote Site Name – Enter the name of the remote site that can send messages to your local site. You must enter a name in this field if you select the *Receive messages from this server* option.

Receive messages from this server – Click if you wish to receive messages from this remote server.

Transmit messages to this server – Click if you wish to transmit messages to this remote server.

Port – Enter the Remote Message Service Listener Port number of the remote site, and select the protocol to be used for transmitting messages to the remote server. Options are: Binary Protocol, HTTP Post XML Protocol, and XML Protocol.

Transmit Filter Tab

This tab defines what type of messages and during which times you want to send messages to a remote server.

P2000	Remote Serv	er			
General	Transmit Filter	Transmit Queue Transmit Session	1		
		Timezone Messane Filter Group	NGHI SHII East Coast Alarm Monitoring	•	
		message riker urdup	1		
			OK	Cancel	Apply

Timezone – Select the time zone during which messages, that pass the Message Filter Group criteria, are transmitted to the P2000 remote server. Select **<Always Enabled>** if you wish to send messages at all times.

IMPORTANT: If the P2000 Remote Server is down during an active time zone, messages are not transmitted and they are not available for later transmission.

Message Filter Group – Select the Message Filter Group that defines which messages are transmitted to this P2000 remote server. Select **<None>** if you wish to transmit all messages to this remote server.

Transmit Queue Tab

Use this tab to define message queue parameters for the remote server.

C P2000 Remote Serve	er	×
General Transmit Filter	Transmit Queue Transmit Session	
	Maximun Queue Length (in records)	
	'Message Void' Period (in seconds) 60	
	OK Cancel Apply	

Maximum Queue Length – Enter the maximum number of messages to place in the transmission queue. Messages are transmitted based on the First-In-First-Out (FIFO) principle.

Message Void Period – Enter the time in seconds after which the system declares messages in the buffer as obsolete.

Transmit Session Tab

Parameters specific to individual transmission sessions are set up in the Transmit Session tab. You must select the *Binary Protocol* in the General tab to complete the settings in this tab.

C P2000 Remote Server	×
General Transmit Filter Transmit Queue Transmit Session	
Maximum Number of Records	0
Maximum Duration (in seconds)	60
Timeout Period for Session End Message (in seconds)	60
OK	Cancel Apply

Maximum Number of Records – Enter the maximum number of messages than can be transmitted within one session.

Maximum Duration – Enter the maximum duration in seconds that a session is kept open.

Timeout Period for Session End Message -

Enter the number of seconds that the session waits without receiving a message, until it declares the session closed.

Set up Access Groups and Cardholders

After you have configured your panels, terminals, terminal groups and various input and outputs, you are ready to complete system configuration by adding Access Groups and Cardholder Options. While Access Groups are assigned from the System Configuration window, Cardholder Options are assigned via the P2000 Main menu. We recommend these elements be assigned in the following sequence:



After these final elements are added, you are ready to move on to operating the system.

Create Access Groups

After terminals and terminal groups have been configured, you can group them together to create common access groups. For example, you can assign two terminals that control the doors into a common area, such as a warehouse, to an access group. When you assign a cardholder badge to that access group, the cardholder is granted access to both doors in the group. This is a quick way to assign badges access to a large number of doors and areas.

If your system is configured to operate elevators and cabinets, elevators floors and cabinet doors can also be assigned to control which floors and doors a cardholder can access. Once access groups are created, they are available for assignment in the applications that use access groups. You can assign up to 32 access groups to a badge (depending on the parameters selected in Site Parameters; see **Number of Access Groups** on page 38). In addition, you can also define personalized access groups for each individual cardholder. (See Personalized Access Groups on page 273).

To Create an Access Group:

- 1. In the System Configuration window, select Access Groups.
- 2. Click **Add**. The Access Group Edit dialog box opens at the General tab.
- 3. Enter a descriptive **Name** for the Access Group.
- 4. Click **Enable** for the system to recognize this access group. If at any time you wish to temporarily disable access to any of the items in this group, without having to delete the access group, click to clear this box.

5. Select the **Default Timezone** during which all terminals (P900 and Mercury only) included in this access group are active. To assign different time zones to the P900 or Mercury terminals in this access group, click the **Details** tab and follow the instructions provided in step 14.

Note: The Details tab is only available if you select the **Terminals associated with Timezone** option in the Edit Site Parameters dialog box.

- 6. If this is a partitioned system, select the **Partition** name in which the items for this access group reside.
- 7. Click **Public** if you wish this Access Group to be visible to other partitions.
- 8. From the list of **Available Terminals** list at the far right of the dialog box, select the terminal to include in the Access Group.
- Click << to move the terminal into the Terminals box.
- 10. From the **Available Terminal Groups** list, select the Terminal Group to include in the Access Group.
- Click << to move it into the Terminals Groups box.

C Access Group Edit			
Name	Warehouse	🔽 Enable	
Default Timezone	Full Time	•	
Partition	Super User	💌 🔽 Public	
General Elevator Cabinet D	etails		
Terminal Groups	Available Terminal Groups	Terminals	Available Terminals
Warehouse Group	Operations Group Security Group >>>	Whee Entry Reader Whee Exit Reader	Office Entry Reader Office Exit Reader >>>
	ОК	Cancel	

- 12. To add elevator floors to the Access Group, click the Elevator tab and select from the Available Floor Groups list, the Floor Group to include in the Access Group.
- 13. To add cabinet doors to the Access Group, click the Cabinet tab and select from the Available Door Groups list, the Door Group to include in the Access Group.
- 14. If you wish to assign a different time zone to the any of the P900 or Mercury terminals selected in this access group, click the **Details** tab, double click the time zone name you wish to change, and select a new time zone from the drop-down list.

Note: The Details tab displays Mercury terminals that are defined in the General tab, and also Mercury terminals that are assigned to elevators included in the Floor Groups defined in the Elevator tab.

15. Click OK. The new access group displays under the root Access Groups icon. When you click on the new Access Group icon, the parameters display on the right windowpane of the System Configuration window.

Cardholder Options

At a minimum, a first and last name must be entered into the Cardholder database for each person who needs access to your facility. Cardholder data entry is typically performed as part of system operation, which is described in detail in Chapter 3: Operating the System.

However, if your facility takes advantage of additional cardholder information, such as company and department definition, and any other information specific to each facility (defined in User Defined fields), these must be configured before adding cardholders, to make this information accessible from the Cardholder Edit dialog box. You can also create access templates to speed cardholder and badge data entry, as well as create badge purposes to specify the badge's intention. Complete instructions are presented in the following sections:

- Define Companies and Departments
- Create Access Templates
- Create Badge Formats
- Create Badge Purposes
- Create Badge Reasons
- Create Required Cardholder Fields
- Create User Defined Fields
- Define Automatic Employee IDs
- Entering Cardholders

Define Companies and Departments

If your facility includes Company and Department as part of Cardholder definition, you must first configure Companies and Departments from the **Config>Cardholder Options** menu. The company and department names are then available for assignment to cardholders in the Cardholder Edit dialog box.

To Define a Company:

 From the P2000 Main menu, select Config>Cardholder Options>Company. The Company dialog box opens.

C Company						_ 🗆 X
	Partition	Super L	Jser		•	
Name			Auto Added	Partition		Public
-			1			
Done		Add	Edit		Delete	

 Click Add. The Edit Company dialog box opens.

Edit Company		×
Partition Super User	•	Public
<u>N</u> ame KD Distributors		
OK	Cancel	

- 3. If this is a partitioned system, select the **Partition** to which this company belongs and click **Public** if you wish this company to be visible to all partitions.
- 4. Enter the Name of the company.
- 5. Click **OK**. The new company name displays in the Company dialog box.

ľ	Company					_ 🗆 ×
		Partition	Super L	Jser	•	
	Name			Auto Added	Partition	Public
	KD Distributors The XYZ Company			No Yes	Super User Super User	No Yes
	Done		Add	Edit	Delete	

The **Auto Added** column displays company names that were added using other P2000 applications.

 Click Done. Company names are accessible from the Cardholder Edit dialog box. (See Entering Cardholder Information on page 260.)

To Define a Department:

 From the P2000 Main menu, select Config>Cardholder Options>Department. The Department dialog box opens.



2. Click Add. The Edit Department dialog box opens.

Edit Department	×
Partition Super User	
<u>N</u> ame Engineering	
OK	Cancel

- 3. If this is a partitioned system, select the **Partition** to which this department belongs and click **Public** if you wish this department to be visible to all partitions.
- 4. Enter the Name of the department.
- 5. Click **OK**. The new department name displays in the Department dialog box.

🕼 Department					_ 🗆 ×
	Partition [Super User	_	•	
Name			Partition		Public
Engineering			Super User		No
Davia	1	. 1	5 .0	Delete	-
Done	Ad		Eak	Delete	

6. Click **Done**. This department name is now accessible from the Cardholder Edit dialog box.

Create Access Templates

Access Templates are an excellent tool for speeding the entry of cardholders and badges into your system. You may have a large group of cardholders that need badges with the same access privileges. For example, your entire Day Shift Shipping Department may need access to the same group of doors, time zones, and associated input and output groups. An Access Template can be created to apply up to 32 Access Groups and time zones to a badge, simply by selecting the template from the Badge dialog box. You can create several Access Templates to speed cardholder data entry.

To Create an Access Template:

 Select Config>Cardholder Options> Access Template. The Access Template window opens.

C Access Template						_ = >
	Partition Su	ber User		•		
Name	Disabled	Options	Access Group 1	Access Group 2	Timezone 1	Timezone 2 F
Shipping	No	т	Warehouse		Whee Hours	5
						<u> </u>
ſ	Dono	Ade	- E-60	1 Dolot	. 1	
L L	Done				·	

 Click Add. The Access Template Edit dialog box opens.

ss Template Edit				
emplate Partition [<u>N</u> ame [Super User Shipping	×	Public	
adge				
	Facility Code	Default Facility	Code	×
otions				
Disabled	Verride Qverride			
Exegutive Privilege	Irace		Event Priv	0
1-4 5-8 9-12 1	3 - 16 17 - 20 21 - 2	1 25 - 28 29 - 32	Action Interlocks	Additional Options
Court Land				
Group 1 Inone		21]		
Group 2 none		z 2	<u>v</u>	
Group 3 none	•	z 3	7	
Group 4 none	•	z 4	~	
	_			
			-	

- 3. Enter the information as described in the Access Template Edit Field Definitions.
- After you have entered all the information, click OK. The new Access Template is listed in the Access Template window. These Access Templates are now available to assign to badges from the Badge dialog box.

Access Template Edit Field Definitions

Note: The definitions in this section are described in detail in Badge Field Definitions on page 268.

Template Box

Partition – If this is a partitioned system, select the Partition in which this access template is used.

Public – If this is a partitioned system, click Public if you wish this Access Template to be visible to all partitions.

Name – Enter a descriptive Name for the Access Template.

Badge Box

Facility Code – Select the type of facility code to be assigned to this Access Template. Facility codes identify the cards that belong to your particular site.

Options Box

Disabled – Click if you wish to disable the badges that use this Access Template.

Override – Click if you wish to give override privileges to the badges that use this Access Template.

Executive Privilege – Click if you wish to give executive privileges to the badges that use this Access Template.

Trace – Click if you wish the badges that use this Access Template to be traced throughout the facility.

Event Privilege – Select a privilege level you wish to assign to the badges that use this Access Template.

1-4 through 29-32 Tabs

Use these tabs to select the Access Groups and associated Time Zones to be assigned to the badges that use this Access Template.

Action Interlocks Tab

Use this tab if you wish to allow badges that use this Access Template to activate up to two action interlocks that can be triggered when the badge is granted access. For more information, see To Set Up BACnet Action Interlocks: on page 381.

Additional Options Tab

Security Level – Select a security level number from 0 (lowest) to 99 that defines the access privilege to be assigned to badges that use this Access Template.

Guard Tour Priority – Select a priority number from 1 (lowest) to 99 that determines which tours the badges that use this Access Template can perform.

Special Access – Select the special access flags that are assigned to badges that use this Access Template.

Create Badge Formats

This feature allows you to configure badge format categories to assign to badges. This allows facilities that use multiple badge technologies or formats to differentiate their badges.

To Create Badge Formats:

 From the P2000 Main menu, select Config>Cardholder Options>Badge Format. The Badge Format dialog box opens.

C Badge Format					_ 🗆 ×
Partition Supe	r User		•		
Name	Partition	Public	Technology	Bits	Qualifier
Cardkey Standard 34 Bit Sentinel	Super User	No	Wiegand	34	1
HID Corporate 1000 Sentinel	Super User	No	Wiegand	35	1
Magstripe 04 Digit Assa Abloy	Super User	Yes	Magstripe	4	1
Smartcard 34 Bit	Super User	No	SmartCard	34	1
Wiegand 34	Super User	No	Wiegand	34	1
Done	Add	Edit	Delete		

2. Click Add. The Edit Badge Format dialog box opens.

Edit Badge Format	×
<u>P</u> artition	Super User 🔽 🔽 Public
Name	Smartcard 34 Bit
Technology	SmartCard 💌
Bits	34
Qualifier	1 💌
[OK Cancel

- 3. If this is a partitioned system, select the **Partition** in which the badge format is active.
- 4. Click **Public** if you wish the badge format to be visible to all partitions.
- 5. Enter a descriptive **Name** for this badge format.

- 6. Select the Technology type.
- 7. Enter the total number of **Bits** expected to be returned from the reader when the badge is read.
- 8. Select a **Qualifier** number. The number selected represents a 32-bit numerical value that allows differentiating formats with the same technology and the same number of bits. The default value is 1.
- 9. Click OK.
- 10. Click Done.

Create Badge Purposes

Users can assign a purpose to a badge for example, to specify the badge's intention. The Purpose field can be used for different applications. For example, an airport employee may have multiple badges, one for each airline terminal the employee is allowed to access. The Purpose field for each badge could be used to identify the airline where the badge is valid. Use the Badge Purpose tool to create the different Purpose field values that can be available for assignment in the Badge dialog box.

To Create Badge Purpose Fields:

 From the P2000 Main menu, select Config>Cardholder Options>Badge Purpose. The Badge Purpose dialog box opens.

🕻 Bad	lge Purpose							_ 🗆 ×
		Partition	Super U	lser			-	
Nam	e			Partition	ı	Public		
	Done		Add		Edit		Delete	

2. Click Add. The Edit Badge Purpose dialog box opens.

Edit Badge Purpose				×
Partition	Super User	•	Public	
Name	ABC Airlines			
[ОК	Cancel		

- 3. If this is a partitioned system, select the **Partition** to which this badge purpose field belongs and click **Public** if you wish this purpose field to be visible to all partitions.
- 4. Enter the Name of the badge purpose.
- Click OK. The new badge purpose field displays in the Badge Purpose dialog box.

🔀 Badge Purpose				
	Partition Super L	lser	•	
Name		Partition	Public	
ABC Airlines Warehouse Building		Super User Super User	No No	
Done	Add	Edit	De	lete

6. Click **Done**. This purpose field is now available from the Badge dialog box.

Create Badge Reasons

The P2000 system provides a list of predefined badges reasons that are used to indicate why a badge is being issued. This application allows you to define new badge reasons or modify existing ones according to your facility needs, and then assign these reasons to badge records for filtering and reporting purposes.

To Create Badge Reasons:

 From the P2000 Main menu, select Config>Cardholder Options>Badge Reason. The Badge Reason dialog box opens.

🕻 Badge Reason	
Name Damaged Lost New Not Returned Reissue Returned Stolen Temporary Visitor	
Done Add	Edit Delete

2. Click **Add**. The Edit Badge Reason dialog box opens.

Edit Badge Reason		×
<u>N</u> ame	Emergency Void	
0	K Cancel	

- 3. Enter the Name of the badge reason.
- 4. Click **OK**. The new item is added to the list of badge reasons.
- 5. Click **Done**. The badge reason is now available from the Badge dialog box.

Create Required Cardholder Fields

The P2000 system requires that at a minimum, a first and last name must be entered into the Cardholder database for each person that needs access to your facility. However, you can define additional cardholder fields as required fields, which must be completed before a cardholder record is saved.

The Cardholder dialog box displays an asterisk (*) next to a field to indicate a required field. If a required field is left empty, the system displays a warning message to indicate that a required field has not been completed.

To Create Required Cardholder Fields:

 From the P2000 Main menu, select Config>Cardholder Options>Required Fields. The Cardholder Required Fields dialog box opens.

ielected	Available	
First Name Last Name	City Conservy Department End Date Extension ID Middle Name Pessword Permission Group Phone Statt Date State State State Zipcode	

- 2. From the list of **Available** cardholder fields at the right side of the window, select the field you wish to define as a required field.
- Click the << button to move the required field to the Selected box. You can add as many fields as you wish.
- 4. To remove a required field from the **Selected** box, select the field and click >>.
- 5. When all the required fields are defined, click **OK**.

Create User Defined Fields

Use the User Defined Fields (UDF) tool to define your own data fields, which you can access from the Cardholder dialog box to store additional cardholder information.

If you wish to restrict operators from viewing certain user defined fields in the Cardholder dialog box, see the instructions provided in Concealed UDFs Tab on page 26.

To Create User Defined Fields:

 From the P2000 Main menu, select Config>Cardholder Options>User Defined Fields. The User Defined Fields dialog box opens.

User Defined Fields						_ 🗆
			Partiti	on Super Use	r	3
Name	Туре	Width	Order	Required	Hide from MIS	Partition
Hire Date	Date	15	1	No	No	Super Us
Car Color	Text	10	2	No	No	Super Us
Car Model	Text	10	3	No	No	Super Us
Car Year	Numeric	4	4	No	No	Super Us
Parking Access	Boolean	1	5	No	No	Super Us
Parking Area	Selection	15	6	No	No	Super Us
(]						
Done A	ы	<u>E</u> dit		Delete	Choices	Migrate

 Click Add. The Add User Defined Field dialog box opens.

Edit User Defined Field		×
Partition	Super User	
Name	License Plate	
Туре	Text Required	
Width	9 <u>O</u> rder 7	
Field Order		
Hire Date Car Color Car Model Car Year Parking Access Parking Area License Plate		
	OK Cancel	

- 3. If this is a partitioned system, the partition name displays in the **Partition** field.
- 4. If this is a partitioned system, click **Public** if you wish to make this field visible to all partitions.
- 5. Enter the **Name** you wish to display as the field title. Names can contain alphanumeric characters, symbols, spaces or underlines.
- 6. Click **Hide from MIS** if you do not wish to display this field in the MIS Interface tables.

 Select from the Type drop-down list, the format in which the data is to be displayed. Select either Text, Numeric, Boolean (toggle field), Date or Selection. The Selection type allows you to define set values to choose from a drop-down list.

Note: The maximum number that you can enter in a Numeric UDF field is 21474836478. For higher numbers, change the UDF type to Text.

- 8. Click **Required** if this field must always be completed. The system displays a warning message if the field is left empty.
- 9. In the **Width** field, enter the maximum number of characters allowed in this field.
- 10. The **Order** box displays the order in which the fields appear in the UDF tab of the Cardholder dialog box. As you add user defined fields, they display in the order they are created. You can however, change the order in which the fields display by selecting the field from the Field Order box and clicking **Up** or **Down** to move the field up or down on the list.
- After you enter all the information, click OK to return to the User Defined Fields dialog box.
- 12. To delete a user defined field, select the field from the list and click **Delete**. A message displays if there are cardholders with values entered in this field. Click **Yes** to continue. When the Delete User Defined field dialog box opens, click **Yes** to delete the field.
- 13. To add choices to Selection type fields, select the field from the list and click Choices. The Choices dialog box opens displaying the name of the UDF and the current number of choices.



14. Click Add. The Choice dialog box opens.

Choice		×
Lobby Entrance		
ОК	Cancel	

- 15. Enter the set value for this field and click **OK**.
- 16. The choice displays in the list. Click **Done** to return to the User Defined Fields dialog box.
- 17. If you wish to convert a Text type field into a Selection type field, select the Text field from the list and click **Migrate**. In the New Type dialog box click **Next**.
- 18. A Summary window displays a description of the change. All previously values defined for the Text field are converted to Choices for the new Selection field. Click Finish.
- 19. A message indicates that the UDF was successfully migrated. Click **OK**.
- 20. Click **Done** to close the User Defined Fields dialog box.

Define Automatic Employee IDs

Use the Auto Employee Id Configuration tool to define a pool of consecutive ID numbers that can be automatically assigned to each cardholder record created in the system. This means that every time you create a cardholder record you no longer have to keep track of the last number assigned or the minimum number of characters used for each ID number.

To Configure Automatic Employee ID Numbers:

 From the P2000 Main menu, select Config>Cardholder Options>Auto Employee ID. The Auto Employee Id Configuration dialog box opens.

C Auto Employee Id Configurat	ion 📕 🗌 🗙
	🔽 Enable
	✓ Prevent Editing Employee ID
Minimum Length	3
Starting Number	801
Next Available	801
OK	Cancel

- 2. Click **Enable** to enable the automatic generation of employee IDs. If you wish to use a different number scheme for a particular cardholder, click to clear this check box and manually assign the ID number.
- 3. Click **Prevent Editing Employee ID** if you wish to make the ID field a display field, no editing allowed.
- 4. In the **Minimum Length** field, enter the minimum number of characters allowed in the ID field. A cardholder ID can have up to 25 characters.
- 5. Define the pool of numbers by entering the first number in the **Starting Number** field.

6. The **Next Available** field displays the next number that can be assigned to the cardholder record.

Note: Automatic Employee IDs are only assign when you create a new cardholder record. If you wish to edit an existing cardholder record and assign a number from the pool, click to clear the **Prevent Editing Employee ID** check box and manually enter the next available number from the pool.

7. Click **OK** to save your settings.

Next time you create a cardholder record, the ID field will display the number that was automatically assigned from the pool, and whether the field allows editing.

Entering Cardholders

After all configuration elements have been defined; along with companies, departments, and user defined fields, if applicable; you are ready to enter cardholders into the database. See Entering Cardholder Information on page 260 for more detailed information.



Commissioning the System: When commissioning the system, we recommend you create at least one or two cardholder records and badges,

then swipe these badges to ensure door controls are working properly.

258 CHAPTER 2 Configuring the System

Chapter 3: Operating the System

his chapter describes procedures typically performed by operators of the *P2000 Security Management System*, assuming all system configuration has been completed. If you have not completed Chapter 2: Configuring the System, some of the functions described in this chapter may not be ready to operate.

Operations typically performed as part of system maintenance, such as downloading data, updating software and panels, starting and stopping service control, and reviewing system and workstation status; are typically performed by a system administrator and are described in Chapter 5: System Maintenance.

The following sections describe how to:

- Provide access to cardholders and visitors
- Monitor alarms
- Manually control doors, outputs, panel relays, P900 CLIC components, security threat levels, and suppress inputs
- Control areas and muster zones
- Detect and control intrusion in a facility
- Track cardholder's hours on site
- Create events
- Monitor the system in Real Time

IMPORTANT: All configuration steps outlined in Chapter 2: Configuring the System, must be completed before you can program and use the essential functions described in this chapter and some system features require specific configuration settings before others can be enabled. These are described in the appropriate sections that follow.

Providing Access to Cardholders and Visitors

Access privileges define which cardholder or visitor may enter a specific area of the facility, and at what time they may enter. Access privileges are assigned to individual reader terminals or group of reader terminals; these devices are assigned to specific access groups, and then when cardholder records are added to the database, the cardholders are assigned to the access groups.

The Access feature provides flexible tools to create cardholder records and assign badges with which to grant or deny facility access. At a minimum, a first and last name must be entered into the Cardholder database for each person who needs to have access to your facility. Additional cardholder information can include personal information such as address and phone; company information such as a company name and department; a Photo ID; and any additional information such as eye color, height, weight, or other information you can define in User Defined Fields.



MIS Interface: Cardholder information can be added, deleted, or updated from a database outside the P2000 software using the MIS Inter-

face; see page 375 for more information. MIS is a low-level interface that requires programming to implement.

Cardholder and Visitor information is entered via the Access feature on the P2000 Main menu. The procedures are presented in the following sections:

- Entering Cardholder Information
- Entering Badge Information
- Entering Visitor Information

Entering Cardholder Information

Every person who needs access to the facility must have a Cardholder and Badge record entered into the P2000 system. Cardholders can be entered all at once at system startup, and then added, edited, or removed as necessary thereafter. Permanent cardholders and visitor cardholders are viewed and added in the same Cardholder window.

If you use database partitioning, the cardholder can belong to one partition, and could have multiple badges, each in a different partition with different access parameters. A cardholder may have several different badges; however, each access badge must have a unique number.

Viewing Cardholder Information

- Select Access>Cardholder from the P2000 Main menu to open the Cardholder window.
- 2. To view current cardholder information, select a **Type** from the drop-down list at the right side of the window (All, Regular, or Visitor).

Note: The system displays up to 20,000 cardholders at a time, for the partition selected in the **Partition** field. If the number of cardholders in your system exceeds 20,000, you must use the Search feature, described in To Search for Specific Cardholders: on page 266.

Cardholo	ler											_
		Site: S	imi Valley		•							
		Partition: S	uper User		•	All						
First	Mid	Last	Туре	Guard	Partition	Pu	Edited By	Edit Ti	me		Type	
Loretta	W.	Adams	Visitor	No	Super User	No	Cardkey	4/1/20	11 10:57		All	•
Fred	R.	Albertson	Visitor	No	Super User	No	Cardkey	4/1/20	11 10:57			
Joe	Μ.	Brown	Regular	No	Super User	No	Cardkey	7/28/2	011 12:5			
Brenda	Τ.	Covington	Regular	No	Super User	Yes	Cardkey	3/31/2	011 2:39		26	arch
Anna	S.	Flint	Visitor	No	Super User	No	Cardkey	7/28/2	011 1:00			
James	Α.	Jasper	Regular	Yes	Super User	No	Cardkey	7/28/2	011 12:5			AļI
Jeanette	Α.	Jasper	Regular	No	Super User	No	Cardkey	3/29/2	011 3:22	_		
Tom	R.	lones	Visitor	No	Super User	No	Cardkey	7/28/2	011 1:00	_		
Michaol	т	Smith	Dogular	No	Supor Lloor	Voc	Cardkou	A11100	11 10.55	-	1	٨dd
			Journal		Badging Take		Display				D	one
/1/1900 :	12:00:00	AM UNDER	INED								10 Cardhold	ers
Badge Inf	ormation	Туре:	All		•	[Partitic	n: Super U	ser		•
Number	Alpha	a Issue ⊆	itatus	Options	Type	Partitio Super I	n P Iser N	ublic A	cess Group	Ti	ne Zone	Reason
•					Heedso							
	Add		Edit		Delete		Pre <u>v</u> iew		Print		Print	Queue

Cardholder Types

Regular – These are the permanent cardholders in the system. Their access begins with a start date, but unless terminated or temporarily reassigned, no end date is specified. Select Regular from the Cardholder window Type drop-down list to view only the regular cardholders.

Visitor – A visitor is given temporary access to the system on a limited basis. Their access is limited by start and end dates and times, and they are assigned a company Sponsor to take responsibility for them while visiting the facility. Select Visitor from the Cardholder window Type drop-down list to view only visitor cardholders in the system.

All – When you select All from the Cardholder window Type drop-down list, all cardholders currently in the system display, regardless of cardholder type.

Additional Cardholder Data

When you select a cardholder from the list, additional cardholder data such as Image, Address, Start/End Badges, UDFs, and other information display in the tabs in the middle of the Cardholder window. If the cardholder selected is a Visitor, a Sponsor tab is added to the window and displays limited Sponsor information. Regular cardholders display the Sponsored Visitors tab, which displays the visitors sponsored by the selected cardholder. If your facility uses P2000 Enterprise, a Site field is added at the top of the window, which allows you to view only cardholders that belong to the selected Site name. In addition, the Enterprise Sites tab is also added to the window to display the site names assigned to the cardholder. See P2000 Enterprise on page 439 for details.

To Enter New Cardholder Information:

1. From the Cardholder window, click **Add**. The Cardholder dialog box opens at the Cardholder Edit tab.

Cardbolder		Other	
Partition	Super User 💌	Email BCovi	ngton@xxx.com
P <u>u</u> blic I		Company KD Dis	tributors 💌
Туре	Regular 💌	Department Aug	-
*Eirst	Brenda	Debaumeur Accon	nong 💆
Middle	т.		guard (
*Last	Covington	Al Badges	8:00:00 AM
īp	763	End 10/ 8/2021	 11:59:00 PM
Address Suite	200 4100 Guardian Street	Web Access Menu Permission Group Secu Pessyord	rity Operations
Street Sty	x Simi Valley	Enterprise Chicago Regional Office Milwar kee Office	
State CA	Zip 93063 5555 Ext 224	Simi Valley	None
		Middle:	
Last:			
Phone:		Select	
			Create Badge

- 2. Enter the information as described in the Cardholder Field Definitions. Required fields are indicated by an asterisk and must be completed before a record is saved.
- 3. You may click **Apply** at any time to save your settings. When you finish click **OK** to return to the Cardholder window, the name of the newly added cardholder displays selected in the list box.

Cardholder Field Definitions

Cardholder Tab

Partition – If this is a partitioned system, select from the drop-down list the Partition to which this cardholder is assigned.

Public – If this is a partitioned system, click Public if you wish this cardholder record to be visible to all partitions. **Type** – Select Regular or Visitor. If you select Visitor, the Sponsor box at the bottom of the window is activated. (See Sponsor on page 263 for more information.)

First – Enter the first name of the cardholder.

Middle – Enter the middle name of the card-holder.

Last – Enter the last name of the cardholder.

ID – This field displays the ID number that was automatically assigned from the Automatic Employee ID pool numbers. Depending on your settings, this field may allow editing. See Define Automatic Employee IDs on page 256.

Address

Address fields are optional, unless they are defined as required fields in your facility. Enter the suite, street, city, state, zip, phone number, and extension, if required.

Other

Email – If available in your facility, enter the email address assigned to this cardholder.

Company and **Department** – To include this information in your Cardholder database, select a Company and Department from the drop-down lists. You must create Companies and Departments before the selections display in the drop-down lists. See Define Companies and Departments on page 249 for detailed information.

Guard – This field is used with the Guard Tour feature and allows you to assign Tour Badges to cardholders who participate in guard tour operations; see Guard Tour on page 386.

All Badges

Start – This is the date and time that badges become active. Select the check box and click the down arrow to select a start date from the system calendar. This date applies to all badges assigned to this cardholder. If you selected a start date, the time field is enabled. Click the spin box buttons to select the time that badges are activated.

End – This is the date and time that badges are voided. Select the check box and click the down arrow to select an end date from the system calendar. This date applies to all badges assigned to this cardholder. This box is typically used for Visitor badges, but can also be edited as needed to void badges for a terminated employee or similar application. The system automatically voids the badge on the date specified. If you selected an end date, the time field is enabled. Use the spin box arrows to select the time that badges are voided.

Note: If you create a Visitor badge and do not enter an end date and time, the date and time default to the Visitor Validity Period value specified in your Site Parameters setting.

Web Access

Menu Permission Group – If your facility uses the Web Access feature, select from the drop-down list the permission group that is assigned to this cardholder. The cardholder is allowed to perform any Web Access function defined in this permission group. See Web Access on page 443 for detailed information.

Password – Enter the password that the cardholder uses to log on to the P2000 Web Access site.

Enterprise

If your facility uses P2000 Enterprise, the Enterprise box displays all the sites defined in the system. Select the check box next to the site that this cardholder may access. See P2000 Enterprise on page 439.

Sponsor

If you selected Visitor as the Cardholder Type, the Sponsor box is activated. A sponsor is the name of the cardholder responsible for the visitor.

To Enter a Visitor Sponsor:

 Once the Sponsor box is activated at the bottom of the Cardholder Edit dialog box, after you select Visitor as the Cardholder Type, click Select. The Cardholder – Find Sponsor dialog box opens.

Cardholder - F	ind Sponsor				×
Caronouer - r	F Mid L	irst J Idle ast ID		-	~
	Compa	any <all></all>		<u> </u>	3
First	Middle	Last	ID	Company	
Jeff	R.	Evans	124		
James	Α.	Jasper	12346		
Jane	т.	Smith	123		
	[ОК	Cancel		

2. Enter a value in any of the fields. The list box displays the cardholder records that match the entered values.

3. Select a cardholder name and click **OK** to save the setting and return to the Cardholder Edit dialog box. Basic Cardholder information displays in the Sponsor box.

Address Sui <u>t</u> e	5300 State Stre	et _		Web Access Menu Permission Group Password	<none></none>
∑treet ⊆ity	Sacramento			Enterprise	,
St <u>a</u> te CA Phone 555	-5555	Zip 94444 Ext 123]		
Sponsor First	: James			Middle: A.	
Last	: Jasper			ID: 12346	
Phone: 555	-3333	Ext:	123	Select	

This information also displays in the Sponsor tab of the Cardholder window.

Image Address O	ther Start/End Badges UDF	Enterprise Sites Sponsor	
	-	-	
First	pames	Middle (A.	
Last	Jasper		
ID	12346		
Phone	555-3333	Ext 123	

In addition, when you select a sponsor name from the Cardholder window and click the Sponsored Visitors tab, the list displays all visitors sponsored by the selected cardholder. If you double-click a visitor name in the list, the visitor becomes the selected cardholder.

Image Address Other Start/End Badges UDF Enterprise Sit	ses Sponsored Visitors
Anna S. Flint	
Tom R. Jones	
1	

Adding a Cardholder Image

You can import an existing image to display in the Cardholder Image tab. The P2000 system supports a large number of image formats; however, if your image format is not supported, you may need to use an image-editing program to convert to a supported format. See To Import an Image: on page 374.

Note: If your imported image displays cropped on the screen, you may need to contact Technical Support if you wish to change the image aspect ratio.

If the workstation is configured as a badging workstation, you can use the Badging buttons to capture an image. See Video Imaging on page 371 for details.

Adding a Cardholder Journal

Journal entries supplement cardholder information by storing notes associated with each cardholder. For example, you may want to keep track of cardholders with parking violations, or keep a record of cardholders that attended specific company training, or track cardholders with suspicious behavior.

To Enter Journal Entries:

- 1. Select a cardholder from the Cardholder list.
- 2. Click **Journal** in the Image tab located in the middle of the Cardholder window. The Journal dialog box opens displaying the journal entries associated with the cardholder, together with the date and time when the journal was entered, the name of the operator who last edited the journal, the date and time the journal was last edited, and whether there is an attachment file associated with the journal entry.



 Click Add. The Journal Edit dialog box opens.

Journal Edit	
Title Vacation Schedule	
Jeanette Jasper will be out of the office from 4/25/2011 to 5/	1/2011.
	Þ
Import Export	
Vacation List.cot	
Attach Detach Save Ope	n Email
OK Cancel	

- 4. Enter a descriptive **Title** to identify the subject of this note.
- 5. Click in the text area and enter the details of the note.
- 6. If you want to add additional information to the note, click **Import** and navigate to the directory that contains the text file you want to include. Select the file and click **Open**. The text file displays in the text area.

- If you wish to save the note as a text file, click Export and navigate to the directory where the exported notes are stored. Enter a file name and click Save.
- 8. If you wish to attach a file to the journal entry, click **Attach** and navigate to the directory that contains the file you wish to attach. Select the file and click **Open**.
- 9. If you do not wish to use the attachment file, select the file and click **Detach**. The attachment file is removed from the list.
- 10. If you wish to save the attachment file, click **Save** and navigate to the directory where the attachment file is stored.
- 11. If you wish to view the contents of the attachment file, click **Open**.
- 12. To email the attachment file, click **Email**. The program starts your default email client with the file attached. Check with your Internet Service Provider (ISP) or IT department to verify the required email client settings.
- 13. When you finish with the note details, click **OK** to save the entry and return to the Journal dialog box.
- 14. To view the contents of a note, select the note from the list and click **View**. When you finish viewing the note, click **Cancel**.
- 15. If you wish to modify an existing note, select the note from the list and click **Edit**; make your changes, then click **OK**.
- 16. To delete a note, select the note from the list and click **Delete**. You are prompted for verification.
- 17. When you finish with the Journal entries, click **Exit**. The Journal button displays the number of notes associated with the cardholder.

User Defined Fields

After you create User Defined Fields (see page 254), use the UDF tab in the Cardholder dialog box to enter additional cardholder information. The number of UDF tabs displayed depends on the number of UDF fields created. Select additional UDF tabs and enter the data as needed.

Note: The UDF tab displays only the user defined fields that were assigned to the operator. See Concealed UDFs Tab on page 26 for details.

To Enter User Defined Field Information:

- 1. Select a cardholder from the Cardholder list.
- 2. Click **Edit** on the right side of the window. The Cardholder dialog box opens.
- 3. Click the **UDF 1** tab to display the user defined fields. Required fields are indicated by an asterisk and must be completed before a record is saved.

Cardholder	
Cardholder Edit UDF 1]
Hire Date	☑ 2/12/2009 ▼
Car Color	Red
Car Model	Toyota
Car Year	2004
Parking Access	v
Parking Area	West Entrance
*License Plate	27896133
Parking Usage	Monthly

4. After you enter the information, click **OK** to return to the Cardholder window.

 Click the UDF tab located in the middle of the Cardholder window. The User Defined Fields and entries display for the cardholder selected.

Ir	nage Address Other	Start/End Badges UDF Enterp	rise Sites 🛛 Sponso
	Field	Value	
	Hire Date	2/12/2009	
	Car Color	Red	
	Car Model	Toyota	
	Car Year	2004	
	Parking Access	Yes	
	•		

To Edit Cardholder Information:

- 1. From the Cardholder window, select a cardholder from the Cardholder list.
- 2. Click **Edit**. The Cardholder dialog box opens.
- 3. Enter the necessary changes.
- 4. Click **OK** to save your changes and return to the Cardholder window. Changes are reflected in the Cardholder list and in the appropriate tabs in the center of the window.

To Search for Specific Cardholders:

1. In the Cardholder window, click **Search** on the right side of the cardholder list. The Database Search dialog box opens.



- 2. Enter or select from the associated drop-down lists, the information for any or all of the fields to search for specific cardholders.
- 3. If you wish to search by **Company** and **Department**, select a previously defined name from the drop-down list.
- 4. You can also search by UDF (up to two UDF fields). Select any of the previously defined UDFs from the drop-down lists (Date type UDFs cannot be included in the search). Then enter the UDF search criteria in the associated fields. (Fields associated with Selection type UDFs are selected from drop-down lists.)

Note: The UDF list only displays the UDF fields associated with the operator record; see Concealed UDFs Tab on page 26 for details.

- 5. If you wish to clear the existing search criteria, click **Clear**.
- 6. After you define the search criteria, click one of the following:

Exact Match – to display an exact match to your search criteria.

Partial Match – to display all possible selections that match the initial characters of the search criteria; for example, if you enter *Carl* in the First Name field, the list box displays names such as Carla, Carlos, Carlton, and so on.

7. The Cardholder window opens showing the number of cardholders and the match specified in the search criteria.

rdholder							
	She	Simi Valley	•				
				1	Description Manager		
	Partition	1: Super User	<u>•</u>	iname =	Jasper dur = Toyota		
at	Middle	Last	Type	Guard	Partition	Public	Type
rol	R.	Jasper	Regular	No	Super User	No	All
nes	Α.	Jasper	Regular	No	Super User	No	
							Care
							2017/08
							2ear
							2ear
							A
							Aj
							Al
						Þ	Al
]	Ľ	
	1	1	un la			<u>.</u>	All
nage Addres	ss Other	Start/End Bade	ges UDF Ent	erprise Site	s Sponsored Visitors)	All
nage Addres	ss Other	Start/End Bad	ges UDF Ent	erprise Site	s Sponsored Visitors) 	All All Edi
nage Addres	ss Other	Start/End Bad	ges UDF Ent	erprise Site	s Sponsored Visitors	• 	All All Edi
nage Addres Field Hire Date	ss Other	Start/End Bad;	ges UDF Ent	erprise Site	s Sponsored Visikors	▶ 	All All Edi
Field Hire Date Car Color	is Other	Start/End Bad; Value 2/12/2009 Red	ges UDF Ent	erprise Site	s Sporsored Visikors) 	All All Edi Dele
Field Hire Date Car Color Car Model	is Other	Start/End Bads Value 2/12/2009 Red Toyota	ges LIDF Ent	erprise Site	s Sponsored Visitors		All All Edi
Field Hire Date Car Color Car Model Car Year	ss Other	Start/End Bady 2/12/2009 Red Toyota 2004	ges UDF Ent	erprise Site	s Sponsored Visitors	1	All All Edi Dele
Field Hire Date Car Color Car Model Car Year Parking Acce	ss Other	Start/End Bads 2/12/2009 Red Toyota 2004 Yes	ges UDF Ent	erprise Site	s Sponsored Visitors	1	All All Edi Defe
Held Hire Date Car Color Car Model Car Year Parking Acce	ss Other	Start/End Badg Value 2/12/2009 Red Toyota 2004 Yes	ges UDF Ent	erprise Site	s Sponsored Visikors		All All All Add Edd Dele
Field Hire Date Car Color Car Model Car Year Parking Acce 4	ss Other	Start/End Bad; Value 2/12/2009 Red Toyota 2004 Yes	ges UDF Ent	erprise Site	s Spansored Visitors	1	Ad
Field Hire Date Car Color Car Model Car Year Parking Acce	ss Other	Start/End Bad; Value 2/12/2009 Red Toyota 2004 Yes	ges UDF Ent	erprise Site	s Sponsored Visitors		All Add Edd Dgele
Field Hire Date Car Color Car Model Car Year Parking Acce	ss Other	Start/End Bady 2/12/2009 Red Toyota 2004 Yes	ges UDF Ent	erprise Site	ss Sponsored Mistors		Ad
nage Addres Field Hire Date Car Color Car Model Car Year Parking Acce 4	ss Other	Start/End Bad; Value 2/12/2009 Red Toyota 2004 Yes	ges UDF Ent	erprise Site	s Sponsored Visitors		Al Ad Ed Dele Dgr Cardholden
nage Addres Field Hire Date Car Color Car Yoar Parking Acce 4	ss Other	Start/End Bady 2/12/2009 Red Toyota 2004 Yes	ges UDF Ent	erprise Site	s Sponsored Vistors	• 	All Add Edd Edd Don 2 Cardholders
nage Addres Field Hire Date Car Color Car Model Car Year Parking Acce	ss Other	Start/End Bady Value 2/12/2009 Red Toyota 2004 Yes	ges UDF Ent	erprise Site	s Sponsored Vistors		All Add Edd Defe Defe Cardholders

8. Click **All** on the right side of the Cardholder window to restore it to display all cardholders.

Entering Badge Information

The Badge Information box in the Cardholder window displays all badge information for the cardholder selected from the Cardholder list. A badge can be created strictly for identification, or it can be assigned access privileges.

To Enter Badge Information:

- 1. In the Cardholder window, select a cardholder from the Cardholder list.
- 2. In the **Badge Information** box at the bottom of the Cardholder window, click **Add**. The Badge dialog box opens.

Badge					_ 0
Badge					
Partition	Super User	– [Public		
Number	302			Auto	
Facility Code	Default Facility Code	·	Iype	Access	-
<u>A</u> lpha	AA1 Issue 0		Eormat	Wiegand 34	•
Description		_	Purpose	ABC Airlines	-
Pin	12345		<u>R</u> eason	New	-
Start	▼ 10/ 7/2011 ▼ 8:00:	00 AM 📥	Design	<none></none>	-
End	▼ 10/ 4/2021 ▼ 11:59:	00 PM		,	
Disabled Disabled Executive Trace Override Download Special Acc Special Acc	ty Options 'Enterprise' STIE ess A ess B ess C	Security Level Levent Privilege Privileg Guard Tour	e 0		
		Priorit	y <none< th=""><th>> •</th><th></th></none<>	> •	
	Apply Access Righ	Priorit ts Shipping Access	y	> <u> </u>	·
Du	Apply Access Righ	Priorit ts Shipping Access Print	y <none< td=""><td>></td><td>-</td></none<>	>	-
	Apply Access Righ	Priorit Priorit Shipping Access Print Cancel		>	

TIP:

IIF. You can also access the Badge dialog box from the Cardholder Edit tab by selecting **Create Badge** at the bottom of the window.

- 3. Enter the information as described in the Badge Field Definitions.
- 4. When all information is entered, click **OK** to return to the Cardholder window. The new badge is listed in the Badge Information box at the bottom of the window.

Note: Click **Duplicate** at the bottom of the Badge dialog box to create any number of badges for a cardholder. All current badge information is copied; however, each badge must have a unique number.

Badge Field Definitions

Badge

Partition – If this is a partitioned system, select the Partition in which this badge is active.

Public – Click Public if you wish this badge record to be visible to all partitions.

Number – Enter a badge number (the number of allowed characters depends on the parameters selected in the Site Parameters dialog box; see **Max Badge Number** on page 38). Access and Identification badges can have the same number. If your system is configured to use FASC-N badges, see FASC-N Badges on page 269 for instructions on generating this number.

Auto – If your facility is set up to use the Auto-Badge Management feature (see page 279), click Auto to insert the next available badge number in the Number field. Not available for FASC-N badges.

Facility Code – Select the facility code to be assigned to this badge. Facility codes are defined in Site Parameters (see page 40), and identify the badges that belong to your particular site. Not available for FASC-N badges.

Note: It is imperative that you select the correct facility code for badges that are used at Assa Abloy locks, since these locks verify both badge number and its facility code when making access decisions. In addition, if you have an existing system in which facility codes are only defined on a terminal basis, but not on a per badge basis, you must ensure that all badges have the correct facility code assigned before adding them to access groups that include Assa Abloy locks.

Alpha – Some custom badges may provide space for additional characters. If so, you may enter up to four characters here. Not available for FASC-N badges. **Issue** – Select an issue level. If cardholders lose their badge, you would give them the next available issue level and retain the same badge number. The number of badge issue levels supported depends on the panel type you use; see **Max Issue Level** on page 38.

Note: When using Assa Abloy locks, be aware that when you modify a badge issue level, that badge may be unavailable for access for up to one minute after the change is made.

Description – If desired, enter a description (up to 32 characters) of this badge.

Pin – Enter the cardholder or visitor personal identification number (PIN) to be used with PIN readers. If an algorithmic PIN is used, leave this field blank.

Start – Select the date and time this badge becomes active. Click the down arrow to select a date from the system calendar and click the spin box buttons to select a time.

End – Select the date and time this badge is automatically voided. Click the down arrow to select a date from the system calendar and click the spin box buttons to select a time.

Note: Some Assa Abloy locks only support expiration dates, but no specific times. The badges are automatically voided at midnight on the expiration date.

If this is a Visitor badge and no end date and time is entered, the badge is automatically voided as configured in Site Parameters; see page 34 for more information.

Note: The time used to void a badge is based on the P2000 Server time and not the time defined for a panel. The panel time may be different if a Time Offset was defined; see page 60 for details.
Type – Select a badge type, choices are: Access or Identification.

Format – Select the badge format to be assigned to this badge. See Create Badge Formats on page 252.

Purpose – If you wish to include this badge information, select a purpose to indicate the badge's intention. You must create Purpose fields before the selections display in the drop-down list. See Create Badge Purposes on page 253.

Reason – Select a reason to indicate why the badge is being issued. You can add or edit badge reasons using the Edit Badge Reason application. See Create Badge Reasons on page 253.

Design – If you have created several badge designs using your Video Imaging software, you can select a design from the drop-down list. (Badge design instructions are provided in the *P2000 Integrated Video Imaging Installation and Operation Manual.*)

FASC-N Badges

The P2000 software supports the programming of smart cards that are compliant with the Government Smart Card Interoperability Specification (NIST IR 6887 - 2003 Edition, GSC-IS Version 2.1). These smart cards are programmed using a smart card encoder, physically located in the badge printer.

Note: Smart card encoding is only available if the Video Imaging software option used at your facility is EPI Builder.

To support the Federal Government smart card encoding protocol, an encoded badge must include FASC-N (Federal Agency Smart Credential Number) data fields. A FASC-N badge number is a unique number assigned to one individual. This type of badge is typically issued to government employees; however, it could also be used by any industry. Data elements in this number determine whether a cardholder should be granted access to specific buildings and controlled places.

To create FASC-N badges, the Badge Edit Style selected for your facility (see page 38), must be defined as FASC-N Only or Normal and FASC-N.

- If FASC-N Only was selected, click Add in the Badge Information box at the bottom of the Cardholder window, or click Create Badge in the Cardholder Edit tab.
- If Normal and FASC-N was selected, click the Add down arrow in the Badge Information box at the bottom of the Cardholder window and select Add FASCN. The Create Badge button in the Cardholder Edit tab only allows you to create FASC-N badges.
- To create Normal badges if Normal and FASC-N is selected, click the Add down arrow in the Badge Information box at the bottom of the Cardholder window and select Add Normal.

When the badge dialog box opens, the fields display the default values defined in Site Parameters (see page 38) to generate a 15-digit badge number described as follows.

🕻 Badge		_ 🗆 X
Badge		
Partition	Super User 🔽 🗖 Public	Change Style
Number	System 7777	Issue 0 🔺
Agency	4444 Series 5 Iype	Access
Generated	444477775307676 Eormat	Cardkey Standard
Description	Purpose	ABC Airlines
Pin	Reason	New
Start	V 10/12/2011 V 8:00:00 AM + Design	<none></none>
End	11:59:00 PM	

Number – This is a six-digit unique badge number assigned to the cardholder.

System – This is a four-digit number identifying the specific government site or facility issuing the badge, so that each site within a government agency can have a system number which is unique to that agency.

Agency – This is a four-digit unique number identifying the government agency issuing the badge.

Series – This is a one-digit number that can be left to the discretion of the site administrator as to how this number can be used.

Generated – This box displays the generated number containing the 15 digits as follows:

AAAASSSSRNNNNNN

where *A* is the Agency code, *S* is System code, *R* is Series, and *N* is the Credential Number.

The Agency, System, and Series default values are used for all badges created in the system, however, an authorized operator can enter specific values for a specific badge. The [...] button on the right side of the Series field opens the FASC-N Fields dialog box.

FASC-N Fields	
Agency Code	4444
System Code	7777
Credential Series	5
Defaults	
OK	Cancel

You can change any of the default values, which are used instead of the configured default values for the badge currently being edited. If you want to go back to the default values, click **Defaults**. Once the badge record is saved, and if the Badge Edit Style used at your facility is **Normal and FASC-N**, you can edit the badge and click **Change Style** at the top right corner of the window to change the badge style, if necessary.

Security Options Tab

These options allow you to define access privileges for a cardholder. Access decisions are made based on the privileges assigned to the badge.

Note: Some security options are panel specific. See Appendix C: Panel Comparison Matrix for a detailed list of features and capabilities supported by your panel type.

In Enterprise systems, the Badge dialog box displays the site name tabs of the sites assigned to the cardholder. The first tab is always the local site tab and is used to assign local access privileges. The second tab is the Enterprise tab and is used to assign global access privileges. Additional tabs show other site names assigned to the cardholder.

Assigning access privileges is determined by the following conditions:

- When you define access to the local site and click Apply Security Options Enterprise, the security options defined in the Enterprise tab are applied.
- When you define access at a different site and click Apply Security Options Enterprise, the security options defined in the Enterprise tab are applied to that site.

For more information, see P2000 Enterprise on page 439.

Disabled – When a badge is created, it is automatically enabled. Click this check box to disable this badge. This function is useful when you wish to disable a badge, but do not wish to re-issue or redefine a badge for this cardholder.

Executive – If enabled, the cardholder has unlimited access to all operational doors controlled by the access control system, regardless of any other privileges programmed for this badge. (If a specific terminal requires the use of a PIN code with a badge, the PIN code is still required.)

Note: For badges that are used with Mercury panels, the badge must be in the same partition as the panel, or the panel must be set as Public.

Trace – Enable to trace cardholder movement throughout the facility. Badge transactions are printed, as they occur, on any printer configured to print trace transactions, as long as the Badge Trace and Printing options are selected in the Real Time List window.

Override – If enabled, the cardholder can unlock any door controlled by a keypad reader that has the Override option enabled. See your specific hardware configuration section for information on setting up this option.

Download to STI-E – This option applies only to legacy panels using STI-E terminal interfaces. If selected, the badge is downloaded to the STI-E terminal. The STI-E terminal can save up to 1,000 badges in a resident database for use if the panel becomes inactive.

Special Access – Special Access flags are defined in the Site Parameters dialog box; see page 35. Click any of the three special access flags if the cardholder requires special access at a reader. Special access allows a door's access time to be different. See your specific hardware configuration section for information on setting up this option.

Security Level

Select a security level number from 0 (lowest) to 99 or the maximum security level set up at the Site Parameters dialog box. To obtain access at a door, this number must be equal to or greater than the security level set up at the terminal. If the security level at the terminal is raised, cardholders are denied access, unless the badge has the Executive privilege enabled.

Event Privilege

Every badge has an event privilege level, ranging from 0 to 7, with zero as the lowest level. If a cardholder's badge is to initiate a card event, this event privilege level must be equal to or greater than the privilege level defined in the Panel Card Event dialog box.

Guard Tour

The Priority field is used with the Guard Tour feature. Select a priority number from 1 (lowest) to 99. This number determines which tours the selected cardholder can perform. Only tour badges with equal to or greater than this priority can perform a tour.

Access Rights Tab

Use this tab to define the Access Groups and corresponding Time Zones that can be assigned to this badge. The number of groups displayed here depends on the parameters selected in the Site Parameters dialog box (see **Number of Access Groups** on page 38). See Badge Access Rights on page 122 for details associated with OSI panels.

To Define Access Rights:

1. In the Access Rights tab, double-click the line item you wish to define.

Secur	ity Optio	ns Access Rights	Otis Compass Elevator Options	Action Interlocks
	Index	Access Group	Timezone	Valid From 🔺
	1	Night Shift	Full Time	
	2	Warehouse	Whse Hours	
-	3	<none></none>	<none></none>	
	4	<none></none>	<none></none>	
_	5	<none></none>	<none></none>	
•	6	<none></none>	<none></none>	
_	7	<none></none>	<none></none>	
	8	<none></none>	<none></none>	-1
	21	<pre>/none></pre>	<000e>	النے .
	<u> </u>			<u></u>
	Ec	diti	Remove	

The Access Rights Definition dialog box opens.

Access Rights Definition						×
	Index Access Group Time Zone	1 Wa	rehouse Group I Time			- -
Temporary Access Period	St	art Ioid	11/17/2009	•	8:00:00 AM 5:00:00 PM	•
Personalized Access Group						
	ОК		Cancel		Apply	

- 2. The **Index** number automatically displays. Select from the drop-down list, the **Access Group** you wish to assign to this badge.
- If you wish to modify the settings in the selected Access Group, click the [...] button to open the Access Group Edit dialog box. Make your changes and click OK to return to the Access Rights Definition dialog box.
- 4. In the **Time Zone** field, select a time zone to be assigned to the selected Access Group. If the Access Group selected includes P900 or Mercury terminals, the system uses the default time zone defined for each P900 or Mercury terminal, regardless of the time zone selected here. See page 248 for details on creating access groups.

5. If you wish to define a **Temporary Access Period** for the selected Access Group, select the check box and use the drop-down lists to select the **Start** date and time when permission for access is granted. If the check box is not selected, access is allowed immediately.

Note: For example, if the reader doors included in the Access Group normally grant access from 8:00 A.M. to 5:00 P.M., you can set up temporary access on a selected date and time period that can grant the cardholder permission for limited access within the normal time zone. This feature is performed by the Smart Download service and therefore, you can use it only when Smart Download is running; see P2000 Services Definitions on page 467. This feature only works on terminals running in Local mode.

- 6. Select the **Void** check box and use the drop-down lists to select the stopping date and time when permission for access expires.
- 7. Click **Apply** to save your settings. To assign another access group to this badge or see other definitions, click the spin box next to the Index field.
- 8. To define personalized settings, click **Personalized Access Group** and enter your settings. See Personalized Access Groups at the end of this section.
- 9. Click **OK** to return to the Access Rights tab.
- 10. To remove a definition, select the line item and click **Remove**.
- 11. The list displays the access groups assigned to the badge. To edit an access group, select the line item and click the [...] button.

This document contains confidential and proprietary information of Johnson Controls, Inc. © 2014 Johnson Controls, Inc.

Personalized Access Groups

When assigning access groups to a badge, you can use personalized access group for each cardholder. The Personalized Access Group button provides a shortcut to set up access groups without the need of scanning through all existing access groups.

By default, the Name of the access group is always the name of the cardholder. However, be aware that the name of the access group is <u>not</u> automatically modified if you change the name of the cardholder.

Once you have all the access group elements defined, such as terminals, terminal groups, elevators, or cabinets, click **OK**. The new personalized access group displays automatically in the Access Group field. Assign a time zone to the new access group as you would for any other access group.

Note: Although initially created for a particular cardholder, a personalized access group becomes a standard access group within the P2000 system and <u>can</u> also be assigned to other cardholders.

Otis Compass Elevator Options Tab

Use this tab to define parameters for cardholders that need access to Otis Compass elevators.

Security Options Access Rights Otis Compass Elevator Options Action Interlocks
PIN Access Floor Mask Maintenance Group
Default Floor Floor First Floor Lobby

Floor Mask – For Otis Compass elevators that are configured for PIN entry, select the floor mask that contains the floors that this badge is able to gain access to when they enter a PIN code at the elevator.

Floor – Select the default floor for the user. When the badge is swiped, depending on the operational mode of the elevator that is being used, that badge's default floor is used to dispatch an elevator, assuming the default floor is an authorized or an allowed floor.

Action Interlocks Tab

Action Interlocks allow the P2000 system to initiate actions in BACnet devices. Use this tab if you wish a badge to activate up to two action interlocks that can be triggered when the badge is granted access. For more information, see Setting Up BACnet Action Interlocks on page 381.

Security Options Access Rights	Otis Compass Ele	evator Options	Action Interlocks
Name Lights	•	Value 1	
Name Air Conditioning	-	Value 5	

Access Template

If a large number of cardholders uses badges having the same options, you can set all badge options at once by applying an Access Template. The Access Template contains preset badge options, access groups, and time zones, and overrides any settings already defined in the Badge dialog box, before the template was applied. You can edit badge options individually after the template is applied; if you re-select the template, the settings mirror the template settings. In addition, if you make changes to an Access Template, you have to re-select the template to apply the new settings. **Note:** Access Templates must first be created before they are available in the Badge dialog box. For more information, see Create Access Templates on page 251.

Note: In addition to selecting Access Templates from the **Apply Access Rights** drop-down list, you can also select another badge owned by the same cardholder and apply the same access rights from the selected badge.

To Apply Access Rights to a Badge:

1. From the **Apply Access Rights** drop-down list, at the bottom of the Badge dialog box, select the Access Template or badge number you wish to apply to the badge. All access options defined for the Access Template or selected badge number are applied to the badge.

Simi Valley Enterprise Security Options Access Rights Otis Compas Poisabled Creacuity Options Enterprise Disabled Creacuitye Trace Override Download STI E Handridap Access B Special Access B	s Elevator Options Action Interfolds Security Level 0 Level 0 Event Privlege Privlege 0 Guard Tour Priority crone>
Apply Access Right	s <none></none>
Duplicate	Cancel Apply

2. If you wish to change specific badge options, access groups, or time zones for this badge, you may do so. All other settings remain in effect.

Viewing Badge Data

Badge information such as Number, Status, Options, Type, Partition, and Access Group displays in the list box at the bottom of the Cardholder window. When you select a cardholder from the Cardholder list, all badges assigned to that cardholder display in the Badge Information box. You can also display the badge's transaction history.

To Display Badge Transaction History:

- 1. In the Cardholder window, select a cardholder from the list.
- 2. In the **Badge Information** box, right-click the badge number you wish to view.
- 3. From the shortcut menu select **Transaction History**. The Badge Transaction History dialog box opens displaying the selected Cardholder name and Badge number.

Badge Transaction Hist	ory		
Cardholder	Jeff Evans		
Badge	3076		
Date	Type	Location	
7/20/2005 8:57:05 AM	Access Granted Local	North Entrance, Security	
7/20/2005 8:55:26 AM	Invalid Card Timezone	North Entrance, Security	
7/20/2005 8:54:43 AM	Invalid Card Timezone	North Entrance, Security	
7/20/2005 8:53:26 AM	Invalid Reader	North Entrance, Security	
7/20/2005 8:53:13 AM	Invalid Reader	North Entrance, Security	
T			
Num Re	ecords 20 Refresh	Done	

The list box displays the date, transaction type, and location where the badge was presented.

- 4. To change the number of transactions displayed, enter the desired number in the **Num Records** field.
- 5. To update the list box with new data, click **Refresh**.
- 6. Click **Done** to close the dialog box.

Bulk Badge Change

The Bulk Badge Change tool is used to change badge parameters across multiple records, in a single operation. This feature not only allows you to save time by modifying multiple records at once, but also improves the accuracy from single record editing, and avoids the hassle of updating badge records one entry at a time. In addition, you can also delete multiple badges and associated cardholder records at the same time.

To Bulk Change Badge Records:

 From the P2000 Main menu, select Access>Bulk Badge Change. The Bulk Badge Change dialog box opens.

C Bulk Badg	e Change							
	Cardholder Typ	e <al></al>		*		Partition	Super User	•
	First Nar	ne		_		Middle Name		
	Last Nar	ne		_				
	Compar	w sale		-	snone>	-		
	Decation	nt Annualia	-	-				_
	Ceparone	A paccountin	à		James	-		
	Badge Reas	on <al></al>		-				
	Badge Purpo	se <al></al>		•				
	Badge Unused F	or 0	(days)					
			Exact Match	1	Partial Mi	atch		
Badge	First Name	Middle Name	Last Name	Type	Company	Department	Reason	Purpose
301	Charles	1	Anderson	Reality		Arrounting	New	
303	larges	n.	Carter	Recular	1077 Security	Accounting	New	ABC Airlines
305	Pohert	1	Smith	Receilar	the second	Accounting	Masu	
206	Ann.	E	Europe	Damidar		Assessmenting	Alexan	
2075	2000		Cashar	Deeder	WAT Francisco	Associations	Alan	ADC Abless
312	Brenda	т.	Covington	Regular	ABC Industries	Accounting	New	A.C. 601.67
1								
6 Badge(s)								Print
	A		· · · · · · · · · · · · · · · · · · ·	-		Assess Template	Dent fate d terrer	
	ALL	ит Тиррку мее	ess remplate	-		wccess reliipiace	[Restricted Access	-
					u 1			
				App	ey			
				Don				

2. Enter or select from the associated drop-down lists, the information for any or all of the fields.

Note: The list box displays cardholders that match <u>all</u> fields in the search criteria. Make sure you use the AND logic to define your search.

3. If you wish to search by **Company** and **Department**, select a previously defined name from the drop-down list.

- You can also search by UDF (up to two fields). Select any of the previously defined UDFs from the drop-down lists (Date type UDFs cannot be included in the search), then enter or select the UDF search criteria in the associated fields.
- If you wish to search for badges that have not been used for a while, enter in the Badge Unused For field the number of days that the badges have not been used.
- 6. After you define the search criteria, click one of the following buttons:

Exact Match – to display an exact match to your search criteria.

Partial Match – to display all possible selections that match the initial characters of the search criteria; for example, if you enter *Carl* in the First Name field, the list box displays names such as Carla, Carlos, Carlton, and so on.

7. Once the list box displays the cardholders specified in the search criteria, select from the **Action** drop-down list one of the following options:

Add Access Group – to assign all badges in the list box with access to all terminals defined in the access group. Select the Access Group and Timezone to be assigned to the selected badges. The access group is added to the first available slot on the badges.

Apply Access Template – to apply all preset access privileges, badge options, access groups, and time zones that were defined in the access template. Select from the Access Template drop-down list, the Access Template to be applied to the selected badges.

Note: You cannot apply Facility Code settings using the Bulk Badge Change function.

Delete Access Group – to remove from the selected badges access to all terminals defined in the access group. Select the **Access Group** to remove.

Delete Badge – to delete all badges in the list box.

Delete Badge and Cardholder – to delete all badges and associated cardholders in the list box.

Note: If a cardholder owns more than one badge, and that badge is not included in the list box, the cardholder record is not deleted.

Disable Badge – to disable all badges in the list box.

Replace Access Group – to replace the existing access group. Select from the **New Access Group** drop-down list the access group you wish to assign. Select from the **Old Access Group**, the access group you wish to replace. The original timezone for the access group does not change.

8. If you wish to print the data in the list box, click **Print**.

- 9. Click **Apply** to change the selected badge records.
- 10. Click Done to close Bulk Badge Change.

Entering Visitor Information

The Add Visitor function introduces an easier and faster way to enter visitor and badge information, by allowing authorized operators to enter visitor and badge data using a single user interface. Before a visitor's arrival, the operator enters the appropriate visitor data into the system, assigns a visitor sponsor, enters the date and time period of the scheduled visit, and assigns access privileges using Access Templates. Subsequently and from the same screen, the visitor badge is printed.

To Enter Visitor Information:

- From the P2000 Main menu, select Access>Add Visitor. The Add Visitor dialog box opens.
- 2. See the following Add Visitor Field Definitions for detailed information.

C Add Visitor	
Visitor	Sponsor
First	First
Middle	Middle
Last	Last
ID	ID
Company <none></none>	Company
Partition Super User	<u>I</u> ake Partition
Found in DB Approved Visits	
Search	Search
Badge	Save
Number Auto	Start Date 🗹 3/26/2009 🔻
Issue 0	Start Time 4:04:30 PM - Save and Print
Template Restricted Access	Void Date Void Date Clear
Design <none></none>	Void Time 4:04:30 PM * Exit

Save to save the visitor and badge information. The new visitor data is also reflected in the Cardholder window.4. If you wish to save and print the badge,

3. After you enter all the information, click

- If you wish to save and print the badge, click Save and Print (requires the Video Imaging application).
- If you wish to enter additional visitors, click Clear, then enter the information according to the Add Visitor Field Definitions.
- 6. Click **Exit** to close the Add Visitor dialog box.

Add Visitor Field Definitions

Visitor Box

First – Enter the first name of the visitor.

Middle – Enter the middle name of the visitor.

Last – Enter the last name of the visitor.

ID – Enter a unique ID for this visitor (up to 25 characters).

Company – Select the visitor's Company name. If the company name does not already exist in the database for the visitor's assigned partition, click the browse button [...] to open the Company window. See Define Companies and Departments on page 249 for information on adding a company name to the P2000 database.

Partition – Select the partition to be assigned to the visitor.

Found in DB – Indicates whether or not the P2000 system has identified a matching Visitor record in the cardholder database after you click Search. If Found in DB shows Yes, then the existing visitor record in the P2000 database is updated. If it shows No, the new visitor is added when you click Save. **Approved Visits** – Displays the number of approved visits. This field is only valid if the **Found in DB** field displays **Yes**.

Note: The Add Visitor application creates four UDFs: **Approved Visits**, **Most Recent Visit**, **Second Most Recent Visit**, and **Third Most Recent Visit**. These UDFs are automatically updated and allow you to monitor the visits associated with the selected visitor.

Search – If the visitor information already exists in the database, you may search the database by entering a value in any of the Visitor fields and then clicking **Search**. The Find Visitor dialog box opens displaying the visitor records that match the entered values. You may also click **Search** without entering any values to display all visitors in the database.

Find Visitor					×
First Middle Last ID Company	Paulson ABC Marks	sting 💌			1
First N John	Aiddle	Last Paulson	ID 1221	Company ABC Marketing	
		OK	Cancel		

Select the visitor's name and click **OK**.

Take – If your facility uses the Video Imaging application, click **Take** to capture the visitor's portrait. See the instructions on page 374 (step 4.) for details on capturing portrait images.

Sponsor Box

First – Displays the first name of the person who sponsors this visitor.

Middle – Displays the middle name of the person who sponsors this visitor.

Last – Displays the last name of the person who sponsors this visitor.

ID – Displays the unique ID assigned to the sponsor (up to 25 characters).

Company – Displays the sponsor's Company name.

Partition – Displays the partition assigned to the sponsor.

Search – Click this button to find a Sponsor in the database. The Find Sponsor dialog box opens. When you enter a value in any of the fields, the list box displays the sponsor records that match the entered values. If no value was entered, all cardholders in the database display.

- ID	Company	14
	Company	14
- ID	Company	14
ID	Company	14
- ID	Company	14
ID	Company	
12265	Johnson Controls	
	Johnson Controls	
5676	Johnson Controls	
	1	, Č
	5676 Cancel	5676 Johnson Controls

Select the sponsor's name and click OK.

Badge Box

Number – Enter a badge number (the number of allowed characters depends on the parameters selected in the Site Parameters dialog box; see **Max Badge Number** on page 38).

Note: The Add Visitor application does not support FASC-N badge numbers.

Auto – If your facility is set up to use the Auto-Badge Management feature (see page 279), click **Auto** to insert the next available badge number in the Number field.

Issue – Enter an issue level per badge number. If a visitor loses a badge, give the next available issue level and retain the same badge number. The number of badge issue levels supported depends on the panel type you use; see **Max Issue Level** on page 38.

Template – Select the access template to be applied to this badge. See Access Template on page 273.

Design – Select the badge design that was created using the Video Imaging application.

Start Date – Enter the date this badge becomes active. Click the down arrow to select a date from the system calendar.

Start Time – Enter the time this badge becomes active. Click the spin box buttons to select a time.

Void Date – Enter the date this badge is automatically voided. Click the down arrow to select a date from the system calendar.

Void Time – Enter the time this badge is automatically voided by the system. Click the spin box buttons to select a time.

Auto Badge Management

The Auto Badge Management feature allows you to control and manage badge numbers within a defined pool. Once the pool of numbers is defined and you are issuing a badge, you can click **Auto** to insert the next available badge number in the Number field.

To Create a Pool of Badge Numbers:

- 1. From the P2000 Main menu, select System>AutoBadge Management.
- 2. Enter your password if prompted. The AutoBadge Number Management dialog box opens.
- 3. If this is a partitioned system, select the **Partition** for which you want to display the badge numbers.
- 4. Click **Add Numbers**. The Add badge numbers dialog box opens.

Add badge numbers		_ 🗆 🗙
	🔽 Public	
First badge	1001	
Last badge	1010	
Туре	Regular 💌	OK
Issue	0 -	Cancel

- 5. If this is a partitioned system, click **Public** to make these badge numbers visible to all partitions.
- 6. Define the pool of numbers by entering the **First badge** and **Last badge** numbers.
- 7. From the **Type** drop-down list, select whether this pool of numbers is assigned to Regular or Visitor badges.
- 8. From the **Issue** drop-down list, select the issue level for a badge with this number.

	Parl	ition Sup	er User		•		
Badge Number	Туре	Issue	Status	Modification Date	Partition	Public	Τ
.001	Regular	0	In Use	4/28/2004 11:27:53 AM	Super User	Yes	
002	Regular	0	In Use	4/28/2004 11:28:04 AM	Super User	Yes	
003	Regular	0	In Use	4/28/2004 11:28:15 AM	Super User	Yes	
004	Regular	0	Available	4/28/2004 11:26:55 AM	Super User	Yes	
005	Regular	0	Available	4/28/2004 11:26:55 AM	Super User	Yes	
006	Regular	0	Available	4/28/2004 11:26:55 AM	Super User	Yes	
007	Regular	0	Available	4/28/2004 11:26:55 AM	Super User	Yes	
008	Regular	0	Available	4/28/2004 11:26:55 AM	Super User	Yes	
009	Regular	0	Available	4/28/2004 11:26:55 AM	Super User	Yes	
010	Regular	0	Available	4/28/2004 11:26:55 AM	Super User	Yes	
011	Visitor	0	In Use	4/28/2004 11:28:27 AM	Super User	Yes	
012	Visitor	0	Available	4/28/2004 11:27:13 AM	Super User	Yes	
013	Visitor	0	Available	4/28/2004 11:27:13 AM	Super User	Yes	
014	Visitor	0	Available	4/28/2004 11:27:13 AM	Super User	Yes	
015	Visitor	0	Available	4/28/2004 11:27:13 AM	Super User	Yes	
016	Regular	0	Available	4/28/2004 11:27:24 AM	Super User	Yes	
017	Regular	0	Available	4/28/2004 11:27:24 AM	Super User	Yes	
018	Regular	0	Available	4/28/2004 11:27:24 AM	Super User	Yes	
019	Regular	0	Available	4/28/2004 11:27:24 AM	Super User	Yes	
020	Regular	0	Available	4/28/2004 11:27:24 AM	Super User	Yes	
021	Regular	0	Available	4/28/2004 11:27:24 AM	Super User	Yes	
022	Regular	0	Available	4/28/2004 11:27:24 AM	Super User	Yes	
	Set Available	;		Set In-use			
Advanced							

 Click OK to return to the AutoBadge Number Management dialog box. The list box displays the pool of numbers defined for the selected partition, together with the Status of each number and the Modification Date when the entry was created or last modified.

When you assign numbers from this pool, the Status column displays one of the following:

Available – this number can be assigned to a badge.

Reserved – this number has already been assigned, but a badge has not yet been issued.

In Use – this number is currently in use and cannot be assigned to another badge.

- 10. To change the status of a badge number from *Available* to *In Use*, click **Set In-use**.
- 11. To change the status of a badge number from *In Use* to *Available*, click **Set Available**.

Note: The status of a badge number can be changed from **In Use** to **Available** only if the number has not yet been issued (it was in the **In Use** state because if was changed using the **Set In-use** button).

- 12. To delete badge numbers from the pool, select the numbers and click **Delete Selected**.
- 13. Click **Done** to close AutoBadge Number Management.

Badge Resync

Entry and Exit terminals require cardholders to enter and exit an area in sequence. That is, when cardholders badge *in* at an entry terminal, they must badge *out* at the next badging. If, for example, they follow another cardholder *out* without swiping their badge, their badge remains in the *In* state (out-of-sync). When they attempt to badge back into the area, they are denied access. You can manually adjust the state of a badge to return it to the correct state. You can also reconfigure this badge as Undefined to clear the Entry/Exit status until the next badging.

Note: For Entry/Exit to work, all Entry and all Exit terminals must either run in Central mode, or they must all be defined on the same panel and run in Local mode.

To Resync Badges:

 From the P2000 Main menu, select Access>Badge Resync. The Badge Resync dialog box opens.

C Badge Resync					
Partition Su	iper User	•	Show	Cardholders Cardholders	<u>•</u>
<all></all>				Last Badging T	erminal
First	Middle	Last		Last Badging 1	erminal Group
Peter Fred Karen Charles Grace Jeff Anna James Tom ◀	S. R. N. L. R. S. A. R	Adams Albertson Banks Bentley Brice Evans Flint Jasper Jones		• •	Type <al> ⊻ Search <u>A</u>I</al>
Badges Badge 2004	Statu Out	15			1 Badges
In	Qut	Done		efined	

- 2. If this is a partitioned system, select the **Partition** in which the badges are active.
- 3. From the **Show** drop-down list, select one of the following options:

Cardholders – to resync the status of badges that belong to all or specific cardholders.

Last Badging Terminal – to resync the status of all badges last presented at the selected terminal.

Last Badging Terminal Group – to resync the status of all badges last presented at all terminals in the selected terminal group.

Note: The Last Badging Terminal and Last Badging Terminal Group options are used, for example, to quickly reset the status of all badges after a mustering event or reset the status of badges in situations when cardholders badged in at an entry terminal and they were unable to badge out at an exit terminal because the exit terminal was down.

- 4. If you selected **Last Badging Terminal** or **Last Badging Terminal Group**, select a terminal or terminal group from the list and continue with step 16.
- If you selected Cardholders, select the Type of cardholder (Regular, Visitor, or <all>) that you wish to display in the list box.
- If you wish to display specific cardholders (within the type selected), click Search. The Database Search dialog box opens.

Database Search	X
First Name	
Middle Name	
Last Name	
ID	
Badge Number	
Company	ABC Industries
Department	<all></all>
<none></none>	
	Clear
Partial Match	Exact Match Cancel

- 7. Enter the information on any or all of the fields to search for specific cardholders.
- 8. If you wish to search by **Company** and **Department**, select a previously defined name from the drop-down list.
- 9. You can also search by UDF. Select any of the previously defined UDFs from the drop-down list (Date type UDFs cannot be included in the search). Then enter or select the UDF search criteria in the associated field.
- 10. If you wish to clear the existing search criteria, click **Clear**.
- 11. After you define the search criteria, click one of the following buttons:

Exact Match – to display an exact match to your search criteria.

Partial Match – to display all possible selections that match the initial characters of the search criteria; for example, if you enter *Carl* in the First Name field, the list box displays names such as Carla, Carlos, Carlton, and so on.

- 12. The list box in the Badge Resync dialog box opens displaying the cardholders specified in the search criteria.
- 13. If you wish to display all cardholders again (within the type selected), click **All**.
- 14. After you define the cardholders you wish to display in the list box, select a cardholder name from the list.
- 15. The badge number and status of all badges assigned to this cardholder display in the Badges list. Select the badge or badges to be resync.

Note: To resync the status of all badges of all cardholders currently in the list, click **Select All**.

- Click the appropriate button, In, Out, or Undefined to change the status of the badges.
- 17. Click **Done**. The badge status is now changed.

Image Recall

If the Image Recall window is open on the workstation, any badging (for the partition selected in Image Recall Filters) displays the cardholder's image and information. An operator with proper menu permissions can define access conditions and other filter criteria (transactions set up in the Image Recall Filter Edit dialog box, such as an Access Grant or any invalid transaction), to determine if an image displays in the Image Recall window.

Image Recall Filters

 From the P2000 Main menu, select Access>Image Recall Filters. The Image Recall Filters dialog box opens.

🕻 Im	age Recall	Filters					_ 🗆 ×
			Partition	Super	User	•	
Nar	ne				Partition		Public
-							
	Done		Add		Edit	Delete	

2. Click **Add**. The Image Recall Filter Edit dialog box opens.

Image Recall Filter Edit
Partition Super User Public
Name Display on Invalid Card
Type To Display
Access Grant Duress
🗖 Any Deny 🔽 Anti-Passback On
🔽 Invalid Card 🔲 Invalid Card Timezone
🔽 Invalid Issue Level 📃 Invalid Reader
🗖 Invalid Pin
Terminals To Display
Terminal North Entrance
Terminal Group <none></none>
OK Cancel

- 3. If this is a partitioned system, select the **Partition** in which this image recall filter is active.
- 4. Click **Public** if you wish this image recall filter to be visible to all partitions.
- 5. Enter a descriptive **Name** for the image recall filter.
- 6. From the **Type to Display** box, select the transactions that you wish to monitor. You do not need to select all conditions. If you select *Any Deny*, all other filtering conditions are dimmed, except *Access Grant* and *Duress*.

Note: Cardholder image and information always display in the Image Recall window if the associated badge has the Trace option enabled, regardless of the filter conditions selected here.

- 7. Select a **Terminal** name to specify the terminal to be monitored.
- 8. Select a **Terminal Group** name if you wish to monitor a Terminal Group.
- 9. Click **OK**. The new image recall filter displays in the Image Recall Filters list.
- 10. Click Done.

To Activate Image Recall:

 From the P2000 Main menu, select Access>Image Recall. The Image Recall window opens.

G Image Recall		_ 🗆 🗙
P2000 Securi	ty Management System	Johnson Controls
Partition Super	User 💌 🔽 Popup	Show UDF Fields
	First John	Badge 372
	Last Rar	Terminal North Entrance
10 10	Date/Time 5/14/2007 11:40:08 AM	Action Invalid Card
	UCF Field Value	Ľ
Qeer	Blanking Time 10 (In mins)	Elter Display on Invalid Card

- 2. If this is a partitioned system, select the **Partition** in which the image recall is active.
- 3. Select **Popup** if the Image Recall window is to move to the front of all windows on the P2000 screen whenever an access attempt that matches the current filter occurs.

Note: Some computers may not allow the Image Recall window to automatically pop up in front of other windows on the screen; instead, the Image Recall button begins flashing in the Windows taskbar.

- 4. Click **Show UDF Fields**, if you wish to display the user defined fields associated with the cardholder.
- 5. In the **Blanking Time** field, enter the time in minutes after which the image and the data are cleared. If you enter a value of zero, the display is not blanked.
- 6. Select a Filter from the drop-down list.
- 7. When a cardholder presents a badge at a terminal or group of terminals that meets the filtering conditions, the cardholder's image displays, along with the current cardholder information.

- 8. This image and information remain in the window until another cardholder badges within the partition, or until the **Blanking Time** defined elapses, or until you click **Clear** to clear the information in the Image Recall window.
- 9. Leave the Image Recall window open on the workstation to view images displayed as a result of subsequent badgings.

Image Recall FS (Full Screen)

The Image Recall FS feature offers a simplified display and works in both default and full screen modes.

When the Image Recall FS window is open and a cardholder presents a badge at a terminal or group of terminals that meets the filtering conditions, the cardholder's image displays along with the cardholder name. Optionally, one or two of the following can also display: Company, Department, ID, and any text or numeric user defined field (UDF).

To Activate Image Recall FS:

 From the P2000 Main menu, select Access>Image Recall FS. The Image Recall FS window opens.



2. Select Edit>Options to open the Image Recall Options dialog box and define the elements you wish to display.

Image Recall Options	×
Partition	Super User
Filter	Display on Invalid Card 🗨
	Popup
Line 1	Cardholder Full Name
Line 2	Company
Line 3	Department
Text Font	Arial
Text Color	(255,255,255)
Background Color	(0,0,0)
Background Image	
Blanking Time	10 (in mins)
c	K Cancel

- 3. If this is a partitioned system, select the **Partition** in which the image recall is active.
- Select a Filter that contains the access conditions that determine which images to display. See Image Recall Filters on page 282.
- 5. Select **Popup** if the Image Recall FS window is to move to the front of all windows on the P2000 screen whenever an access attempt that matches the current filter occurs.

Note: Some computers may not allow the Image Recall window to automatically pop up in front of other windows on the screen; instead, the Image Recall button begins flashing in the Windows taskbar.

 From Line 1, Line 2, or Line 3, select the data to be displayed in the first, second, or third line under the cardholder's image. You can select Badge Expiration Date, Cardholder Expiration Date, Cardholder First Name, Cardholder Full Name, Cardholder Last Name, Company, Department, ID, or any text or numeric user defined field.

- 7. Click the **Text Font** browse button [...] to open the Font window and select the font type you wish to display. The font style and size are not configurable.
- 8. Click the **Text Color** browse button [...] to open the standard Color window and select the text color you wish to display.
- 9. Click the **Background Color** browse button [...] to open the standard Color window and select the background color you wish to display.
- 10. Click the **Background Image** browse button [...] to select a background image.
- 11. In the **Blanking Time** field, enter the time in minutes after which the image and the data are erased and the background is displayed. If you enter a value of zero, the display is not blanked.
- 12. Click **OK** to save your options and return to the Image Recall FS window.
- Select View>Full Screen to change the display mode to full screen. Click <Esc> to return to previous view.
- 14. The image and information remain in the window until another cardholder badges within the partition, or until the **Blanking Time** defined in Image Recall Options elapses, or until you select **View>Clear** to clear the information.
- 15. Leave the Image Recall FS window open on the workstation to view images displayed as a result of badgings, or select File>Exit to close.

Monitoring Alarms

Alarm monitoring is at the heart of the *P2000* Security Management system. According to system devices configuration, alarms display in the Alarm Monitor queue as they occur.

Operators assigned to monitor alarms respond according to individual company policy, and the alarm instruction and response text configured for the various alarm types. The Alarm Response text can be pre-configured for operator selection or set to enter manually for a more appropriate response.

The Alarm Monitor window opens immediately after logging on to the Server, so that ongoing alarms are always visible. The Alarm Monitor window cannot be closed at the Server, to ensure that alarm conditions do not go unnoticed. However, it can be minimized using the minimize button on the title bar.

If the Alarm Monitor window is minimized, an alarm message pop-up can alert the operator that a new alarm has been reported. When an alarm is reported, the operator acknowledges the alarm, makes the appropriate response, and then completes the response.

Note: Some computers may not allow the Alarm Monitor window to automatically pop up in front of other windows on the screen; instead, the Alarm Monitor button begins flashing in the Windows taskbar.

Pending alarm messages remain in the Alarm Queue until acknowledged and removed by an operator. Alarm History is stored in the system as configured in Site Parameters. **Note:** Elements that report alarms, such as input points, must NOT have the **Disable Alarm** option selected to have the alarm displayed in the Alarm Monitor window; see page 92.

Alarm Configuration

Alarm Category

Every alarm in the system must belong to at least one Alarm Category, but can also be assigned to multiple alarm categories, each with its own set of alarm options. The system creates a **P2000** base alarm category, which cannot be deleted or renamed.

An operator can define an unlimited hierarchal tree of Alarm Categories under the P2000 base alarm category. When an alarm category displays in various P2000 screens, it typically displays in the form of a URL, for example: P2000\Maintenance\Building 1.

You can for example, define an input point to generate upon activation, two separate alarms for two configured alarm categories: P2000\Maintenance\Building 1 and P2000\Security\Building 1. Typically, a single operator is configured to receive only a single category of alarms, and therefore would only receive a single alarm. However, higher level operators such as supervisors, or an operator at a central alarm monitoring location, may be configured to receive both of these alarms.

When deleting an existing Alarm Category, the P2000 searches the database and issues a warning if the category is referenced by any alarm configurations. If the operator chooses to continue, all existing references to the category being deleted are changed to its parent category.

Alarm Categories are an Enterprise-wide configuration and therefore, if you are using the Enterprise feature, a single set of categories is shared by all P2000 sites within an Enterprise system.

To Create Alarm Categories:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- In the left pane, expand Alarm Categories to display the default P2000 alarm category.
- Select the P2000 alarm category and click Add. The Alarm Category dialog box opens.

C Alarm Category			_ 🗆 ×
P2000			
News	Security		
Name;	Jocency		
	ОК	Cancel	

- 4. Enter a Name for the alarm category.
- 5. Click **OK** to save the new alarm category.

The new alarm category is listed under the default P2000 category. You can create unlimited trees of alarm categories.



Alarm Handling

As an operator, you may be required to handle alarm conditions, depending on the Message Filter Group and Alarm Processing Group assigned; see User Info Tab on page 23. The Alarm Monitor verifies that alarms pass the Alarm Processing Group filter (if any) for the operator before allowing the operator to acknowledge, respond or complete alarms.

Note: Message Filtering and Alarm Processing Groups apply on P2000 Workstations only, not on P2000 Servers.

The alarm response typically includes steps similar to the following:

- 1. Acknowledge that an alarm condition has been reported by the system.
- 2. **Respond** by entering the appropriate response.
- 3. Complete the alarm.
- 4. **Remove** the completed alarm condition from the Alarm Monitor window.

Acknowledging an alarm – An operator may be required to acknowledge a new alarm as soon as it is received (see To Acknowledge an Alarm: on page 290). They may do so and then return later to actually respond to the alarm, depending on company policy and the priorities assigned to that alarm. The time and date of the acknowledgment is recorded in the alarm history. Acknowledging an alarm silences the audible beep (unacknowledged alarms continue to beep until recognized). Alarm acknowledgment is optional and does not need to occur before a response; its use is typically dictated by company policy.

287

Responding to an alarm – When an operator responds to an alarm, the operator name is entered in the User Name column of the Alarm Monitor window. The Response time is date and time stamped for the alarm history record. The operator would typically review the Alarm State and Description to note any known conditions. Specific instructions created for the particular alarm display in the Instruction box during the response to help the operator perform the appropriate action. (See To Respond to an Alarm: on page 290.)

Completing an alarm – Several actions may take place during the handling of an alarm. When all actions needed to process the alarm have been completed, the operator *completes* the alarm. This action is date and time stamped for the alarm history record. (See To Complete an Alarm: on page 291.) An alarm can only be completed if the alarm state is *secure*.

Note: Responding to an alarm that has not been acknowledged automatically causes an acknowledgment to occur. Similarly, completing an alarm causes an automatic acknowledge, if needed.

Removing the Alarm from the queue – According to company policy, operators may remove completed alarms from the alarm queue. The alarm response sequence remains in the alarm history record. (See To Remove an Alarm Message from the Queue: on page 291.)

Refreshing the Alarm Monitor window – The Refresh button on the Alarm Monitor window is used to read again all current alarms from the database (this should not be needed unless there was a loss of communication with the Server). Access the Alarm Monitor from the P2000 Main menu. Select **Alarm>Alarm Monitor**, or if minimized just click the Alarm Monitor button to restore it.

The Alarm Monitor queue displays alarms in a scrolling list, as they occur. The alarm response changes as the operator performs the response steps (see the Alarm Status column header in the Alarm Monitor window); and the date and time of each step is recorded in the alarm history record.

When a new alarm displays in the Alarm Monitor window, an audible beep sounds, and a red color bell icon in the line item entry message begins flashing. The entry continues in this *Pending* state until an operator acknowledges the alarm, after which the beep stops and the bell icon changes to yellow.

Monitoring Remote Alarms

You can configure your system to receive alarm messages from remote P2000 sites, allowing operators to simultaneously monitor alarms locally and at multiple remote sites. This feature is useful to monitor alarms at unattended sites that are closed for the weekend or a holiday, and ensures that all alarm conditions, even at far away locations, are watched closely at all times.

To be able to monitor remote alarms, both your local and the remote site have to be properly configured. The following conditions must be met:

The Remote Message Service must be up and running at both the remote site (to send the alarm message) and at your local site (to receive the alarm message). The Remote Message Service can be started and stopped using the P2000 Service Control feature, just like the other P2000 services. See Starting and Stopping Service Control on page 470.

- The Message Filter Configuration application (page 238), must be properly configured at your local site and each remote site, to control the type of messages transmitted between Servers, thereby reducing network traffic by transmitting only messages that pass the filter criteria.
- The **P2000 Remote Server** application (page 245), must be properly configured at each remote site to be able to send their alarm messages to your local site. The setup must include the name, IP address and Remote Message Service Listener Port number of your local site; the type of messages that is forwarded to your site and at what times; and other related parameters.
- The Process Received Remote Messages option in the RMS tab of Site Parameters (page 44), must be selected at your local site to be able to receive messages from remote P2000 sites. If you select this option, the Remote Message Service processes incoming messages and pass them on to RTL-Route for distribution within the local system and, if applicable, to other remote sites.
- The Message Filter Group selected in the RMS tab of Site Parameters (page 44), defines which remote messages your Remote Message Service processes. If you select <None>, your local P2000 site receives all remote messages.
- The Local Alarms option in the RMS tab of Site Parameters (page 44), must be selected at the remote site to allow remote operators to acknowledge, respond, and complete alarms originated at your local site.
- The **Remote Alarms** option in the RMS tab of Site Parameters (page 44), must be selected at the remote site to allow remote operators to acknowledge, respond, and complete alarms originated at other P2000 sites.

If these conditions are met, your local Alarm Monitor window displays alarm messages that are generated at remote sites when their alarm status or state changes.

The procedures for handling remote alarms are similar as for local alarms; however, the following points should be noted:

Responding to remote alarms – Alarm instructions are sent to remote sites; however, the alarm responses remain local. While the Alarm Status column in the Alarm Monitor displays a *Responded* status, the alarm response entered at a remote site is not part of the alarm history in your local site.

Completing remote alarms – Remote alarms can be completed, regardless of the current alarm state.

Removing remote alarms – Remote alarms can be removed from the queue, regardless of the current alarm state. Removed alarm are automatically completed.

Alarm Monitor Definitions

Date/Time – Displays the date and time the alarm was reported to the system. Alarms that are originated at remote sites with different geographical time zones display the actual time at the remote site.

Note: Click any of the column headings to sort the alarms by the selected column heading.

Escalation – Displays the escalation level of the alarm (the highest is 10).

Priority – Displays the Alarm Priority set for each alarm type (the highest is 0).

Alarm Monitor								
Date/Time	Escalation	Priority	Alarm Status	Alarm State	Description	Alarm Category	User Site	User Name
🛕 3/30/2009 8:43:10 AM	0	4	Acknowledged	Alarm	Night Patrol Late At Station Lo	P2000	Simi Valley	Cardkey
🌲 3/30/2009 8:48:27 AM	0	10	Pending	Alarm	Test Lab Min Required Alarmed	P2000	Simi Valley	Cardkey
🛆 3/27/2009 3:26:55 PM	0	10	Acknowledged	Alarm	Bank Vault Min Required Alarmed	P2000	Simi Valley	Cardkey
•								F
🔨 💽 Msg Routi	ng Status		Total: 3	F	Pending: 1			
Done Ack	Respo	nd	<u>C</u> omplete F	lemove	Refresh A⊻ ▼ Prin	nt 🔻		

You can assign sounds to Alarm Priorities 0 to 255 in groups of 10. The sound files can be set up from **Control Panel** in your Windows desktop, clicking the **Sounds** icon. In the **Sounds** tab, select any of the Pegasys Alarm Priorities from the Program events box, then select the corresponding sound file from the Sounds drop-down list.

Note: To access the P2000 alarm priority sounds, you must open the Alarm Monitor window at least once at the workstation.

Volume	Sounds	Audio	1 Voice	Hardware
volume	0000100	Audio	I voice	
A sound sc and program nave modifi	heme is a set ms. You can s ied.	of sounds elect an e:	applied to eve kisting scheme	nts in Windows or save one you
Sound s <u>c</u> h	eme:			
				•
			Sav <u>e</u> As	<u>D</u> elete
hen select :ound sche Program ev	a sound to ap me. vents:	oplý. You c	an save the cł	nanges as a new
then select sound sche Program ev S	a sound to ap me. rents: tart Navigation	pplý. You c	an save the cł	hanges as a new
then select sound sche Program ev S The Pega:	a sound to ap eme. rents: tart Navigation sys	pplý. You c n	an save the cł	hanges as a new
ihen select sound sche Program ev S S Pega: A	a sound to ap eme. rents: tart Navigation sys larm Priority 00	oplý. You c n 00-009	an save the ch	hanges as a new
ihen select sound sche Program ev S S Pega: A A	a sound to ap erne. tart Navigation sys Iarm Priority 00 Iarm Priority 07	pplý. You c n 00-009 10-019	an save the cł	hanges as a new
hen select sound sche Program ev S Pega A A Ø	a sound to ap me. tart Navigation sys Iarm Priority 00 Iarm Priority 00 Iarm Priority 00	pplý. You c n 00-009 10-019 2 0-029	an save the c	nanges as a new
ihen select sound sche Program ev S Pega: A Ø A A	a sound to ap me. vents: tart Navigation sys larm Priority 00 larm Priority 00 larm Priority 00 larm Priority 00	pplý. You c n 00-009 10-019 20-029 30-039	an save the cl	nanges as a new
then select sound sche Program ev Pega: A © A Sounds:	a sound to ap me. vents: tart Navigation sys larm Priority 00 larm Priority 00 larm Priority 00 larm Priority 00	oplý. You c n 10-009 10-019 20-029 30-039	an save the c	nanges as a new
then select sound sche Program ev Pega A Pega A Sounds:	a sound to ap me. vents: tart Navigation sys larm Priority 00 larm Priority 00 larm Priority 00	oplý. You c n 00-009 10-019 20-029 30-039	an save the c	nanges as a new
then select sound sche Program ev S Pega A A Sounds: chord.wav	a sound to ap me. vents: tart Navigation sys larm Priority 00 larm Priority 00 larm Priority 00	n 00-009 10-019 20-029 30-039	an save the ch	nanges as a new
then select sound sche Program ev S Pega A A Q A Sounds: chord.wav	a sound to ap me. vents: tart Navigation sys larm Priority 00 larm Priority 00 larm Priority 00	n 00-009 10-019 20-029 30-039	an save the ch	nanges as a new

Alarm Status – Displays one of the following:

- **Pending** Not yet acknowledged.
- Acknowledged Acknowledged but no action taken.
- Responding Acknowledged and response action in progress.
- **Complete** Action taken.

Alarm State – Indicates the state of the alarm, such as Secure, Alarm, Open, Short, Suppressed, Tamper, Bypassed, and so on.

Description – Displays a description of the element that activated the alarm.

Alarm Category – Displays the Alarm Category to which the alarm belongs. The default category is P2000. When an alarm is assigned to multiple Alarm Categories, and the operator is configured to view alarms from these multiple categories, the alarm displays separately for each category.

User Site – Displays the site name from where the operator is handling the alarm.

User Name – Displays the name of the operator who handles the alarm.

Action Date/Time – Displays the date and time the action (respond, complete, and so on) takes place. This is always the local time, regardless if a remote site is in a different geographical time zone. Query String – Displays the query string value (if it was defined) of the item associated with the alarm.

Alarm Site – Displays the name of the P2000 site where the alarm was originated.

Partition – Displays the name of the partition containing the item (input point, terminal, panel, and so on) that originated the alarm.

Public – Displays whether the alarm message is visible to other partitions.



Audible Alarm Button – Click the Audible Alarm button to temporarily disable the audible alarm beep. All alarms are affected. Unless you acknowledge, respond, or complete the alarm, the beep becomes audible again in 40 seconds. If you wish to turn off the audible alarm beep, select from the Sounds dialog box in Control Panel, any of the Pegasys Alarm Priorities, then browse for the None.wav file located in the bin folder of the P2000 software installation

Msg Routing Status – The Message \odot Routing Status indicator displays in green to indicate that all communications between the workstation and the Server are up. If communications go down, the Mes-

sage Routing Status indicator turns red.

Total – Displays the total alarm count in the Alarm Monitor window.

Pending – Displays the number of pending alarms in the Alarm Monitor window



Map Button – You can see the location of an alarm on a Real Time Map from the Alarm Monitor window. Select an alarm and click the Map button. The map displays and the icon blinks indicating the location of the alarm. For more information, see Using the Real Time Map on page 360. This feature is available for local alarms only.

AV – This button is enabled if your facility uses the DVR feature. If the alarm message displayed is associated with a camera, you can select the message line from the list and click the AV arrow, then select whether you want to display live or stored video. For more information, refer to your DVR documentation.

Print – Click the Print arrow and select whether you want to Print All alarms in the queue or select **Print Displayed** to print the alarms that are visible in the Alarm Monitor list box.

To Acknowledge an Alarm:

- 1. Click the line item you wish to respond to and click Ack. The Alarm Status changes to Acknowledged. This informs the system and anyone else monitoring the system that the alarm has been recognized.
- 2. If several alarms come in at once, you can acknowledge them in any order you wish; however, company policy may dictate that you respond by priority. If desired, select the highest priority by number, or click the **Priority** column title to sort by priority, moving the highest priority to the top of the list

To Respond to an Alarm:

- 1. With the line item to which you wish to respond selected, click Respond. The Alarm Response dialog box opens.
- 2. The **Description** box displays the description for the line item selected in the Alarm Monitor window
- 3. The Condition box displays the alarm condition.
- 4. The Instruction box displays any instruction text associated with the alarm.
- 5. The **History** box displays all stored history for the line item selected from the Alarm Monitor

Description: Pane	l Down Main Lobby	2500, Main Lobby 2500	Condition	: Alarm	
struction					
Action Date /Time	Alarm Status	Despense Tout	Liner Name	Alarm Ctate	Date /Tie
3/26/2013 11:00:46 AM	Responding	Call maintenance	Cardkey	Completed	3/25/20
3/26/2013 10:33:31 AM	Responding	Call Security Immediately	Cardkey	Completed	3/25/20
3/25/2013 1:19:41 PM		confoccarrey ininicalatery	Cardkey	Completed	3/25/20
3/25/2013 1:19:34 PM	Pendina		curate,	Completed	3/25/20
-,,					-,,
•					•
esponse					
	Predefined	Alarm Response Text:		•	
				Add	1
lext:					
lext:					

6. If you wish to add a predefined response, click the **Predefined Alarm Response Text** drop-down list and select the desired response. The response text displays in the Text box. Click **Add** to add the selected response to the History box. The Alarm Status changes to *Responding*. This stores a record of the response in the transaction history.

Note: See Creating Predefined Alarm Response Text on page 294 for information on adding different responses for specific alarms.

- 7. If you wish, you can also enter a specific response in the **Text** box and click **Add** to add your response to the History box.
- 8. Click **Done** to return to the Alarm Monitor window.

Note: You can have multiple Alarm Response windows open and respond to multiple alarms simultaneously. You can also acknowledge or complete alarms in the Alarm Monitor window while the Alarm Response window is open, but you cannot acknowledge or complete those alarms that are currently open in the Alarm Response windows.

To Complete an Alarm:

1. Click **Complete** to end the alarm processing sequence. The Alarm Status changes to Complete. Alarms can only be completed if the alarm state is *secure*.

To Remove an Alarm Message from the Queue:

The Complete and Remove buttons do not become active until the alarm is in the secure state.

- 1. Select a line item from the scrolling list.
- 2. Click **Remove**.

TIP:

As an alternative, right-click a line item in the Alarm Monitor window to perform from the shortcut menu any of the previous functions (acknowledge, respond, complete, and remove alarms).

To Display Alarm Details:

- 1. In the Alarm Monitor window, select an alarm from the list.
- 2. Right-click to open the shortcut menu and select **Details**.

Alarm Details								×
Site	Simi Va	lley						
Partition	Super I	Jser						
Public	Yes				Catego	pry P2000		
Source	Paint S	hop Min Require	ed Alarr	ned				
Query/Filter								
Alarm Status	Respor	nding		1		Escalation	0	
Alarm State	Alarm			1		Priority	10	
Instructions								
	J							
Action Date/Time		Alarm Status	Res	ponse Text		User Name	Alarm State	Date/Time
12/21/2012 11:06:0	I6 AM	Responding	Call	Security		Cardkey	Alarm	12/21/2012 11:0
12/21/2012 11:05:5	AM P	Acknowledge	1			Cardkey	Alarm	12/21/2012 11:0
12/21/2012 11:04-		restung				causey	Adm	12/21/2012 114
•								F
			[Done]			

The window displays the alarm details for the line item selected, together with the associated alarm instruction, alarm history, and any response entered for the alarm.

3 Click **Done** to close

To View Alarm Instructions:

Instruction text associated with an alarm can be viewed from the Alarm Response window, the Alarm Details window, or by right-clicking an alarm in the Alarm Monitor window and selecting Instructions.

TIP:

The shortcut menu in the Alarm Monitor window also allows you to see the location of the alarm on a Real Time Map, display live or stored AV video (if available), or view all items when you click **Display All**. In addition, if the element that generated the alarm was configured to allow operators to manually activate events, the event name also displays in the shortcut menu. Also, you can select from the shortcut menu to Print All alarms in the queue or select Print Displayed to print only the alarms that display in the list box.

To Activate an Event from the Alarm Monitor:

- 1. In the Alarm Monitor window, select the line item you are responding to and right-click to open the shortcut menu.
- 2. Click the event name you wish to activate. The event is triggered.

Configuring Alarm Colors

The P2000 system provides color configuration capability for each alarm priority (0 to 255) and its corresponding alarm status. Each alarm status can have a unique color assigned to help operators recognize specific alarms. When a new alarm displays in the Alarm Monitor window, the line for the affected alarm displays in the color that was assigned using the Default Alarm Colors dialog box.

To Define Color-Coded Alarms:

- 1. From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand Site Parameters.
- 3. Select **Default Alarm Colors** and click Edit. The Default Alarm Colors dialog box opens.

Priority	Pending	Acked	Respond	Complete
Priority 0	255,255,255	255,255,255	255,255,255	255,255,255
Priority 1	255,255,255	255,255,255	255,255,255	255,255,255
Priority 2	255,255,255	255,255,255	255,255,255	255,255,255
Priority 3	255,255,255	255,255,255	255,255,255	255,255,255
Priority 4	255,255,255	255,255,255	255,255,255	255,255,255
Priority 5	255,255,255	255,255,255	255,255,255	255,255,255
Priority 6	255,255,255	255,255,255	255,255,255	255,255,255
Priority 7	255,255,255	255,255,255	255,255,255	255,255,255
Priority 8	255,255,255	255,255,255	255,255,255	255,255,255
Priority 9	255,255,255	255,255,255	255,255,255	255,255,255
Priority 10	255,255,255	255,255,255	255,255,255	255,255,255
Priority 11	255,255,255	255,255,255	255,255,255	255,255,255
Priority 12	255,255,255	255,255,255	255,255,255	255,255,255
Priority 13	255,255,255	255,255,255	255,255,255	255,255,255
Priority 14	255,255,255	255,255,255	255,255,255	255,255,255
Priority 15	255,255,255	255,255,255	255,255,255	255,255,255
Priority 16	255,255,255	255,255,255	255,255,255	255,255,255
Priority 17	255,255,255	255,255,255	255,255,255	255,255,255
1	000 000 000		000 000 000	
Pending	Color A	tked Color	Respond Color	Complete Color
	All Colour		C-1 T- 1	
_	All Colors		Set To L	berault
	Г	ОК	Cancel	

- 4. Click the **Priority** line you wish to define.
- 5. Click one of the following buttons:
 - Pending Color to assign a specific color to alarms that have not yet been acknowledged.
 - Acked Color to assign a specific color to alarms that have been acknowledged.
 - Respond Color to assign a specific color to alarms that have been responded.
 - Complete Color to assign a specific color to alarms that have been completed.
 - All Colors to assign the same color to all alarm status for the priority selected.

Regardless of the option selected, the Edit Color dialog box opens.

Edit Color	×
Sample Text Text (0,0,0), Background (255,2	255,255)
, Text Color	Background Color
OK	Cancel

 Click Text Color and select the desired text color from the color palette. Click OK.

- 7. Click **Background Color** and select the desired background color from the color palette. Click **OK**.
- The Sample Text box displays the selected colors. Click OK to return to the Default Alarm Colors dialog box. You cannot see the new color until you select other priority number or click anywhere on the screen.
- 9. Repeat the same steps if you wish to assign colors to other alarm priorities.
- If you wish to reset to the default system colors, select the Priority line and click Set To Default.
- 11. When you finish setting all alarm colors, click **OK**.

The assigned colors for each priority and corresponding alarm status are the default colors for all operators; however, operators who are required to handle certain alarm conditions may want to use different colors for the alarms they need to see. In that case, the default alarm colors can be changed from the Alarm Monitor window.

Note: The ability to change alarm colors from the Alarm Monitor window is controlled by menu permissions. Therefore, if you do not want operators to override the default alarm colors, remove the Alarm Colors permission from their Menu Permission Group.

12. Open the Alarm Monitor window, and click the system menu button.

▼	System	n Mer	u Button		
C Alarm Monitor					
Bestore Move Size Migimize Magimize X Close Alt+F4 Alarm Colors	Escalation 0 0 0	Priority 0 5 10	Alarm Status Acknowledged Responding Responding	Alarm State N/A Alarm Alarm	Description P2000 RTL Main Vault Bank Vault

- 13. From the control menu select Alarm Colors. The Alarm Colors dialog box opens displaying the default colors that were defined from the System Configuration window.
- 14. Assign the desired colors as described before, then click **OK** to save your settings.

Note: Alarm colors that are assigned from the Alarm Monitor window are associated with the operator who made the changes. In addition, the **Set To Default** button resets to the default colors assigned from the System Configuration window.

Creating Predefined Alarm Response Text

You can create Response text to speed alarm response to specific types of alarms. For example, when panels go down for regular maintenance, a *Panel Down* soft alarm is sent to the Alarm Queue. The operator can quickly respond by selecting a predefined response from the drop-down list.

To Create Predefined Alarm Response Text:

 From the P2000 Main menu, select Alarm>Alarm Response Text. The Alarm Response Text list opens.

Alarm Response Te	ĸt		_ []
E	Partition: Warehouse		
Name	Text	Partition	Public
Alarm Set	Check with maintenance to see if point is in servi	Warehouse	Yes
Hold-Up	Call Police · Dispatch armed guard	Warehouse	Yes
Panel Maintenance	Normal Maintenance	Warehouse	No
•			•
	Done Add Edit	Delete	

2. If this is a partitioned system, select the **Partition** in which this alarm response text applies.

- 3. The Name, Text, Partition, and whether or not the text is Public display in the list.
- 4. Click Add. The Alarm Response Text dialog box opens.

Alarm Respo	nse Text	×
	Partition Super User 💌 🏳 Public Name Panel Maintenance	
Text	Normal Maintenance	
	OK Cancel	

- 5. Select a **Partition**, if applicable, and click **Public** if you wish the text to be seen by all partitions.
- 6. Enter a descriptive Name for the text.
- 7. Enter the actual **Text** you wish to enter into the Alarm Response record.
- 8. Click **OK**. The Response text name is now available in the drop-down list of the Alarm Response dialog box.

Monitoring Alarms Using the SIA Interface

Note: The P2000 system only supports the Radionics system SIA mode using ADEMCO Contact ID protocol.

The Radionics D6600 Security Receiver/Controller is capable of receiving alarm and supervisory messages from the Radionics digital dialers over analog telephone lines. It can process up to eight individual telephone lines simultaneously. The Radionics Receiver/Controller is connected to the P2000 system via a standard RS232 serial interface.

The Radionics Receiver/Controller can also be programmed to send alarm messages through the COM RS232 port. The communications parameters must be programmed using a hand-held Radionics programmer. (Refer to the Radionics manual for programming instructions.)

295

The communication takes place only in one direction; from the Radionics system to the P2000 Server. The P2000 Server does not transmit commands to the Radionics Receiver/Controller and cannot suppress any Radionics capabilities such as print or display audible indications. The P2000 Server acknowledges messages as they are received.

This section describes the configuration of the Radionics interface to the P2000 system. You must program the Radionics system before connecting it to the P2000 Server. All information must be supplied by the Radionics installer.

To Configure the SIA Interface:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Select **SIA Device** and click **Add**. The SIA Device Edit dialog box opens.

🕻 SIA Device Edit		
Partition	Super User	Public
Name	I	
	🔲 Enable	
	P2000 Alarms	
Comm. Port	COM 1	
Baud Rate	1200	
Data Bits	7	
Parity	None	
Stop Bits	1	
C	Cancel	

- 3. If this is a partitioned system, select the **Partition** to which the SIA device has access.
- 4. Click **Public** to make this SIA device visible to all partitions.

- 5. Enter the **Name** that identifies the SIA device.
- 6. Click **Enable** to enable the SIA device.
- 7. Click **P2000 Alarms** to display messages from the SIA device in the Alarm Monitor (in addition to the SIA Message Viewer window, where they display by default).
- Select the Comm. Port to which the SIA device is physically connected. Choices include serial input and output ports COM1 to COM32.
- 9. Select the **Baud Rate** for the SIA device communications. The recommended value is 9600.
- 10. Select the number of **Data Bits** for the SIA device communications. The recommended value is 8.
- 11. Select the appropriate **Parity** for the SIA device communications. The recommended value is **None**.
- 12. Select the number of **Stop Bits** for the SIA device communications. The recommended value is 1.
- 13. Click **OK** to save your settings.

To View Messages from the SIA Device:

 From the P2000 Main menu, select Alarm>SIA Message View. The SIA Message View dialog box opens.

C SIA Message View	1			_ 🗆 ×
Date/Time	Message		Partition	Public
				1
A March and March Cha	h		1 2	
 Msg Routing Sta 	lus	Clear List	Dor	ne

The **Date/Time** column displays the date and time the message originated.

The **Message** column displays the text of the message.

The **Partition** column displays the name of the partition containing the SIA device that originated the alarm.

The **Public** column indicates whether the message is visible to other partitions.

Note: The Message Routing Status indicator displayed in green indicates that all communications between the workstation and the Server are up. If communications go down, the Message Routing Status indicator turns red.

- 2. Click **Clear List** to remove all messages from the list.
- 3. Click **Done** to close the window.

Message Forwarding

Message Forwarding is useful when using message filters. At times, it may be necessary to temporarily forward messages from one workstation to another; for example, if an operator must leave the workstation for a short period of time, or during a vacation or sick leave. When the operator is ready to receive messages at the workstation again, message forwarding for the workstation can be deleted.

Note: When forwarding messages from one workstation to another, the system must decide which messages are to be forwarded depending on the operator that is logged on at the receiving workstation. The system only transmits messages that pass the filter criteria associated with the operator. See Operators and Messages on page 236.

To Forward Messages from One Workstation to Another:

 From the P2000 Main menu, select Alarm>Message Forwarding. The Message Forwarding dialog box opens listing the workstations from where and to where all current messages are forwarded.

⊐ ×

- 2. If this is a partitioned system, select the **Partition** in which the workstations are active.
- 3. Click Add. The Message Forwarding Edit dialog box opens.

Message Forwarding Edit	X
From Station:	warehouse 💌
To Station:	security station
Ōĸ	Cancel

- 4. From the **From Station** drop-down list, select the workstation from which to forward the messages.
- 5. From the **To Station** drop-down list, select the workstation to which you wish to forward the messages.
- 6. Click **OK**. The new entry displays in the Message Forwarding list.
- 7. Click Done.

Fire Alarm Control

The P2000 fire alarm control application has been designed to operate with Notifier® fire alarm panels using Johnson Controls Fire OPC Server. This integration allows the P2000 system to control alarms generated by fire devices connected to the Notifier panel. The fire system consists of sensors, connected to the Notifier fire panel, capable of detecting fire events. These detectors are grouped into zones that use audible signals (input/output modules) to indicate that a zone is in alarm condition. Use the instructions provided in the Notifier® AMx000 unit OPC Server Application to define your fire system, such as fire detectors, input/output modules, and how these input and output devices can be associated with fire zones.

IMPORTANT: The Notifier panel is not available in North America. Contact Johnson Controls Systems Integration Services Europe for information.

The Notifier fire system benefits from the P2000 system powerful alarm capability by providing the tools that define how these alarms respond when activated, whether or not they trigger output relays, and at which times an alarm can be activated.

An authorized operator at a P2000 workstation can enable or disable a fire detector alarm or fire zone alarm, and activate or deactivate a fire signal. When properly configured, the P2000 system should:

• receive notification from the fire panel that a fire has been detected in the building

- identify the location of the fire
- inform building personnel that a fire has been detected
- warn the occupants of the building that a fire has been detected to ensure that all are able to exit the building before escape routes become impassable.

Basic Definitions

Activated – The state of a device connected to a fire input/output module, such as evacuation signals or a sprinkler system. The output of an input/output module can be activated manually or by system events.

Deactivated – The state of a device connected to a fire input/output module after the fire alarm is reset. The output of an input/output module can be deactivated manually or by system events.

Detector – Device connected to the fire panel and that reports physical changes associated with fire such as a heat detector, a smoke detector, or a carbon monoxide detector.

Disabled – The state of a fire detector, zone or input/output module that is disabled from reporting fire alarms. This state is typically used with devices that report false alarms or can be used to turn off fire devices after an alarm condition. Fire devices can be disabled manually or by system events.

Enabled – The state of a fire detector, zone or input/output module that is enabled for reporting fire alarms. Fire devices can be enabled manually or by system events.

Fire Panel – Device that is the controlling component of a fire alarm system. The panel receives information from sensors designed to detect changes associated with fire (detectors), monitors the operation of these detectors, and activates equipment (input/output modules) designed to alert building personnel of potential danger.

Input/Output Modules – Device connected to a fire panel that can detect input from switched devices, such as sprinkler systems; and activate notification signals, such as alarm bells or telephone dialers. Traditionally, when an input device is activated, a certain output device (or relay) is also activated.

Zone – An area in a facility that is associated with fire detectors and input/output modules.

Basic Fire Alarm Components

This section describes the basic components of a fire alarm control system. The fire alarm control system consists of the P2000 software, the panel (Notifier) firmware, and the panel components (fire detector, zone, and input/output modules).

The P2000 software is used to:

- Create and assign menu permissions to perform fire alarm control functions; see page 21.
- Provide the communication between P2000 applications and the Fire OPC Server using the P2000 OPC Proxy Service; see page 466.
- Enable the fire server; see page 298.
- Configure alarm options for fire alarm panels, detectors, zones, and input/output modules; see page 299.
- Control, monitor, and display the status of fire detectors, zones, and input/output modules; see page 300.

 Define event triggers and actions associated with fire detectors, zones, and input/output modules; see page 302.

The following sections describe fire alarm configuration and control procedures using the P2000 software.

Fire Alarm Server Configuration

Once you configure your fire panel and associated items using the instructions provided with your Notifier unit, you must enable the fire server in the P2000 System Configuration window to populate the associated data into the P2000 database.

IMPORTANT: We recommend using the Fire OPC Server Configurator to remove fire detector loops that are not physically configured in the Notifier panel, to avoid reporting unknown states to the P2000 system. Do this before enabling fire components in the P2000 system. Otherwise, you must remove any unused fire component using the **Empty Fire Data** task in Database Maintenance.

To Enable the Fire Server:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand **Fire Server**. The name of the fire server displays.
- 3. Select the fire server name and click **Edit**. The Fire Server Config dialog box opens.

C Fire Server Config				×
Name	montreal76		Enable	
	ок	Cancel		

- 4. Verify that the fire server name displays in the **Name** field.
- 5. Select the Enable check box.
- 6. Click OK.

E Fire Server

🗄 🔐 montreal 76

🖃 🛄 Fire Panel

÷٦.

🖻 🔚 Fire Panel 1

🗄 祝 Fire Zone

Once you enable the fire server, the System Configuration window is automatically populated with the fire panel and associated fire zones, detectors, and input/output modules.



💂 Fire Detector

💂 Fire IO Module

Fire Alarm Configuration

Every alarm that is generated in the P2000 system, must belong to at least one Alarm Category (see Alarm Configuration on page 285 for details), but can also be assigned to multiple alarm categories, each with its own set of alarm options. For example, if a fire input/output module connected to a push-button switch generates an alarm, you can define this push-button switch to generate upon activation two separate alarms for two configured alarms categories, for example one for P2000\Maintenance\Building 1 and one for P2000\Fire\ Building 1. The P2000\Fire alarm can be configured with a higher priority, enabled escalation settings, and to be monitored by security personnel. The P2000/Maintenance alarm can be configured with a lower priority, no escalation settings, and to be monitored by maintenance personnel.

Use the following instructions to assign fire related alarms to one or more Alarm Categories.

To Configure Fire Alarms:

- 1. In the System Configuration window, expand **Fire Server** to display all the fire panel components.
- 2. Select a Fire Panel or component (Zone, Detector, or IO Module). Click Edit.



3. The Fire Devices Configuration dialog box opens for the selected item.

C Fire Devices Configuratio	n	×
Partition:	Super User 🔽 🔽 Public	
Alarm Options	·	
Select Alarm Categories		
	Add	
	Edit	
	Delete	
	OK Cancel	

4. If you are configuring alarm options for a Fire Panel, select from the **Partition** drop-down list, the appropriate Partition that has access to the Fire Panel. Partition selection is only available at the Fire Panel level.

- 5. Click **Public** if you wish the fire device to be visible to all partitions.
- 6. Specify the **Query String** value to be used with message filtering and with the P2000-Metasys integration feature.
- Click Add to assign this alarm to one or more Alarm Categories. The Add Alarm Categories dialog box opens displaying all previously created alarm categories (see page 285 for details).

Add Alarm Categories - Fire Devices Configuration	×
Select Alarm Categories	
P2000/Fire	Add
P2000/Fire(Building 2 P2000/Fire(Building 2	<u>C</u> ancel
P2000(Maintenance\Building 1 P2000(Maintenance\Building 2	



- Select one or more categories and click Add. The list displays all the selected alarm categories.
- If you wish to remove a category from the list, select the alarm category and click Delete.
- 10. Once you have all the alarm categories you want to assign to this alarm, select an alarm category from the list and click Edit to edit the alarm options. You can select and edit more than one category at a time. The Alarm Options dialog box opens displaying the General tab. See the definitions provided on page 91.

Fire Alarm Management

Management of fire alarms includes displaying the current state of fire alarm items as well as issuing commands for such activities (disable, enable, activate, and so on). The following sections describe how to monitor and control fire alarm components.

Controlling Fire Alarm Components

Use the Fire Alarm Control window to perform alarm commands for fire detectors, zones, and input/output modules. It allows operators to enable or disable alarms for these fire components. In addition, operators can also activate or deactivate the output of an input/output module from this window.

To Control Fire Alarm Components:

 From the P2000 Main menu select Control>Fire. The Fire Alarm Control dialog box opens.



- 2. From the **Device** drop-down list, select the device (Notifier panel) name you wish to control.
- 3. If you wish to control a fire Detector, click the **Detectors** tab. From the list of Available Detectors at the left side of the window, select the fire detector you wish to control.

This document contains confidential and proprietary information of Johnson Controls, Inc. © 2014 Johnson Controls, Inc.

4. Click the >> button to move the selected fire detector to the Selected Detectors box. You can add as many Detectors as you wish. Once you have the selected Detectors, click the function button on the right side of the window to perform the associated operation. The choices are:

Enable – Enables the selected fire detectors.

Disable – Disables the selected fire detectors.

If you wish to control a fire Zone, click the Zones tab. From the list of Available Zones at the left side of the window, select the fire zone you wish to control.

- 🗆 ×

Available Zones	Selected Zones	
holder J.Fre Pand I.Zone0000 Nooffer J.Fre Pand J.Zone0002	Dasher 1 Fer Parel 3-2cec001 >>> <	Enable Disable

6. Click the >> button to move the selected fire zone to the Selected Zones box. You can add as many Zones as you wish. Once you have the selected Zones, click the function button on the right side of the window to perform the associated operation. The choices are:

Enable – Enables the selected fire zones.

Disable – Disables the selected fire zones.

7. If you wish to control a fire input/output module, click the **IO Modules** tab. From the list of Available IO Modules at the left side of the window, select the fire input/output module you wish to control.

	Device <all></all>		
etectors Zones IO Modules	1		
Available IO Modules Notifier 1.Fire Panel 1.Zone00	01.IO Module0001_Loop00	Selected IO Modules Notifier 1-Fire Panel 1.Zone0001.IO Module0003 Loop	500
Notifier 1.Fire Panel 1.Zone00 Notifier 1.Fire Panel 1.Zone00	101.IO Module0004_Loop00 01.Pull Station0001_Loop00		Enable
		<u>>></u>	Disable
	-	<<	Activati
			Deactiva
1)	•	•

8. Click the >> button to move the selected fire input/output module to the Selected IO Modules box. You can add as many IO Modules as you wish. Once you have the selected IO Modules, click the function button on the right side of the window to perform the associated operation. The choices are:

Enable – Enables the selected input/output modules.

Disable – Disables the selected input/output modules.

Activate – Activates the selected output of an input/output module.

Note: Although the Activate and Deactivate commands are available for inputs, only outputs can be successfully activated or deactivated.

Deactivate – Deactivates the selected output of an input/output module.

9. When you finish controlling the fire items, close the Fire Alarm Control dialog box.

Viewing Fire Transactions Using the Real Time List

All fire transactions are sent through real time messages to the Real Time List. As the status of defined fire detectors, zones, and input/output modules changes, corresponding related messages are generated and displayed. You must select the **Fire** check box in the Real Time List window to display all fire transactions as they occur. See Using the Real Time List on page 356 for more information.

Note: If you wish to print fire transactions as they occur, you can either print them from the Real Time List window, or select the **Fire** check box in the Site Parameters dialog box, Printing tab; see page 35.

Monitoring Fire Components Using the Real Time Map

The Real Time Map displays the status of fire panels, detectors, zones, and input/output modules on a map layout of your facility. Upon fire alarm activity, the map shows the state change and the exact location of the activity. See Using the Real Time Map on page 360.

When a status changes, the associated fire icon starts flashing. You can right-click the icon to open a shortcut menu and choose to, for example, enable or disable a fire panel or activate a fire input/output module. If the fire component was configured to allow the operator to activate events, the event name also displays in the shortcut menu.

To add fire icons to the Real Time Map, follow the instructions provided in Creating a Real Time Map on page 362. Map Maker provides a default fire component image set to display various fire states. However, you can use your own icons to create custom image sets. See Adding Image Sets on page 366 for details.

Viewing and Controlling Fire Components Using the System Status Window

The System Status window displays the current status of fire zones, detectors, and input/output modules that have been configured for fire alarm control. It also allows you to issue commands for the fire zones, detectors, and input/output modules displayed.

See Viewing System Status on page 473 for instructions on how to display fire components status and issue commands.

Fire Component Events

The fire alarm system connected to the P2000 system can trigger events and respond to event actions using the P2000 Event application. For specific instructions, see Creating Events on page 349. Typical fire commands to be included and linked to specific actions are as follows:

- An alarmed fire zone (trigger) forces a door to be locked to control the spread of smoke fumes and fire (action).
- An access grant command (trigger) activates the output of a fire input/output module, such as an emergency notification signal (action).
- A fire panel that enters the trouble state (trigger) sets the badge security level at a specified value (action).

For a complete list of event triggers and actions associated with fire panels, detectors, zones, and input/output modules, see Appendix A: Event Triggers/Actions.

Operator Controls

Most system functions operate automatically; however, some functions may be operated manually from a workstation. Operators with the appropriate permissions can manually control doors, output devices, and panel relays. For example, an operator can unlock all doors at once, manually trigger a certain event, or allow a guard to manually control access to a specific door during off business hours. Operator controls are panel specific. See Appendix C: Panel Comparison Matrix for a detailed list of features and capabilities supported by your panel type.

Note: When you manually control doors or output devices associated with serial panels, there might be an operation delay of 5 to 10 seconds if data is being currently downloaded to the panel.

Controlling Doors

An operator can manually control a door, a group of doors, or all doors (override system controls) for a specific time period. (The operator must first have menu permissions for Door Control to use this feature.) If this is a partitioned system, the doors or door groups available from the drop-down list are those active in the operator's partition.

Note: Isonas panels do not report transactions associated with manual door control changes.

To Manually Control Doors:

- From the P2000 Main menu select Control>Door Control.
- 2. Enter your password if prompted. The Door Control dialog box opens.

Door Co	ntrol			
	P <u>a</u> rtition Su	per User	•	
Control			C Group	
	<u>N</u> ame B3	2 Basement Book :	Storage	•
Action				
C <u>R</u> etur	n To Normal			
O Open	for Access Time			
⊙ <u>U</u> nloc	k		Duration 1	Minutes
O <u>L</u> ocko	ut			
		Perform		
		Done		

- 3. If this is a partitioned system, select the **Partition** in which this door is active.
- In the Control box, select either **Door** or Group to populate the Name drop-down list with selections.
- 5. Select a Name from the drop-down list.
- 6. In the Action box, select one the following:

Return to Normal – to return the door to its normal state.

Open for Access Time – to unlock the door for the amount of time set in the Access Time field defined in the Terminal dialog box.

Unlock – to unlock the door for the number of minutes entered (up to 1440 minutes) in the **Duration** field, after which the doors reverts back to their original system-controlled condition.

Lockout – to prevent access by all badges at the door. Only supported by OSI and Assa Abloy panels. The Lockout door command is not available in the Web Access interface.

- 7. Click **Perform**. The Action selection goes into effect.
- 8. Click **Done** to exit the window.

To Control all Doors at once:

- 1. From the P2000 Main menu select Control>Control All Doors.
- 2. Enter your password if prompted. The Control All Doors dialog box opens.

C Control All Doors	_ 🗆 🗙
Partition Super User	•
• All Panels	
C Selected Panel	
	•
Resume Normal Operation	
C Unlock All Doors	
Perform	
Done	

- 3. If this is a partitioned system, select the **Partition** in which the doors are active.
- Click All Panels if you wish to control all doors in the system, or click Selected Panel and select a panel to control all doors connected to the selected panel.
- 5. Click **Unlock All Doors** if you wish to unlock all doors.
- 6. Click **Perform**. The system informs you that the doors will remain unlocked until you lock the doors again, and prompt you to continue.
- 7. Click **Yes**. This overrides the system control until you reverse the command.
- 8. To return the doors to their previous state, click **Resume Normal Operation**.
- 9. Click **Perform**. The system prompts for verification.
- 10. Click **Yes**. The Door Control override is reversed.

Controlling Outputs

An operator can manually control an output (override system controls) for a specific output point or group. (The operator must first have menu permissions for Output Control to use this feature.) If it is a partitioned system, the outputs available from the drop-down list are those active in the operator's partition.

Note: Isonas and HID panels do not report transactions associated with output point status changes.

To Manually Control an Output Point:

 From the P2000 Main menu, select Control>Output Control. The Output Control dialog box opens.

G Output C	ontrol			_ 🗆 ×
_		Partitio	ion Super User	·
Output (Point		C Group	
		Name	Activate Audible Alarm	-
Action				
 Activ 	ate		Preset	•
			Duration 0 sec	
O Dead	ctivate		Perform	
C Disal	ole			
			Exit	

- 2. If this is a partitioned system, select the **Partition** in which this output is active.
- 3. In the Output box, click either **Point** or **Group** to populate the Name drop-down list with selections.
- 4. Select an output point or output group Name from the drop-down list.
- 5. Click Activate to activate the output point (or group) and select from the drop-down list one of the following choices (the actions available in the list depend on the panel type):
- **Preset** to turn the output point to a predefined state.
- Set On to turn on the output point.
- Slow Flash to toggle the output point on and off slowly.
- Fast Flash to toggle the output point on and off quickly.
- Timed/Pulse to turn the output point for a specified time in seconds. If you select this option, you must enter the time in seconds in the Duration field.

Note: If you manually turn a P900 output point for a timed duration, you must click **Refresh** in the System Status window to update the P900 output point status information after the timed duration has expired.

- 6. Click **Perform** to manually activate the output point.
- If you wish to return the output point to a Normal state, click **Deactivate**, then click **Perform**.
- 8. If you wish to temporary disable a P900 output point, click **Disable**, then click **Perform**.
- 9. Click Exit to close the dialog box.

Controlling Panel Relays

An operator with permissions can manually override system control of specific panel relays. For example, a panel relay may automatically operate lights in a specific area. An operator can manually set the panel relay to override system control and turn on the lights when they would normally be off.

To Manually Control a Panel Relay:

 From the P2000 Main menu, select Control>Panel Relay. The Panel Relay dialog box opens.



- 2. If this is a partitioned system, select the **Partition** in which this panel is active.
- 3. Select the Panel **Name** from the drop-down list.
- 4. Click Set to activate the relay.
- 5. Click **Reset** to deactivate the relay.
- 6. Click **Done** to exit the dialog box.

Note: For D6xx series panels, the Latch Output option must be enabled on the Alarm tab of the Edit Panel dialog box to manually control a panel relay.

P900 CLIC Controls

The P2000 system also provides manual control of P900 counters, flags, and trigger events. An operator with menu permissions for P900 Control can set counters to any value, set or clear flags, or force a trigger event to perform its actions. If this is a partitioned system, the options available from the drop-down lists are those active in the operator's partition. See Configuring CLIC Components on page 114.

To Manually Control a P900 Counter:

- 1. From the P2000 Main menu, select Control>P900 CLIC>Counter.
- 2. Enter your password if prompted. The P900 Counter Control dialog box opens.

C P900 Counter Control	
Partition Super User	•
Current Value 0	Request
Force Value 0	Action
Done	

- 3. If this is a partitioned system, select the **Partition** in which this P900 Counter is active.
- Select a counter Name from the drop-down list. The dialog box displays the Current Value of the selected P900 Counter.
- 5. If you wish to update the Current Value, click **Request**.
- To force the counter to a different value, click the Force Value spin box and select a new number.
- 7. Click **Action** to force the new counter value.
- 8. Click **Done** to close the dialog box.

To Manually Control a P900 Flag:

- From the P2000 Main menu, select Control>P900 CLIC>Flag.
- 2. Enter your password if prompted. The P900 Flag Control dialog box opens.

C P900 Flag Control	
Partition	Super User
Name	
Current State	Clear Request
Clear	Set
[Done

- 3. If this is a partitioned system, select the **Partition** in which this P900 Flag is active.
- Select a flag Name from the drop-down list. The dialog box displays the Current State of the selected P900 Flag.
- 5. If you wish to update the Current State, click **Request**.
- 6. Click **Set** if you wish to force the flag to be set. The flag still acts as normal afterwards.
- 7. Click **Clear** if you wish to force the flag to be clear. The flag still acts as normal afterwards.
- 8. Click **Done** to close the dialog box.

To Manually Control a P900 Trigger Event:

- 1. From the P2000 Main menu, select Control>P900 CLIC>Trigger Event.
- 2. Enter your password if prompted. The P900 Event Control dialog box opens.

C P900 Event Control				_ 🗆 🗙
	P <u>a</u> rtition	Super User	 •	
Name			•	
Enable		Disable	 Force	
		Done		

- 3. If this is a partitioned system, select the **Partition** in which this P900 Trigger Event is active.
- 4. Select a trigger event **Name** from the drop-down list.
- 5. Click **Enable** to have the P900 panel process the trigger event.
- 6. Click **Disable** if you do not wish to have the P900 panel process the trigger event.

- 7. Click **Force** to immediately perform the trigger event action.
- 8. Click **Done** to close the dialog box.

Security Threat Level Control

Security threat level control provides a rapid method of restricting access in case of an emergency. If there is a security breach, an authorized operator is able to quickly change access privileges for all cardholders at any reader terminal connected to a panel that supports security threat level control. The default security level for these terminals is 0 (the lowest) and could be raised up to 99 (the maximum security level).

For this feature to work, you must assign security levels to badges (see page 271). To obtain access at a door, the badge security level must be equal to or higher than the terminal security level. When an event occurs, the operator raises the security level of the terminals in question, and access is immediately restricted, unless the badge has the Executive privilege option enabled.

To obtain access at a terminal connected to a D600 AP panel, the terminal security level must be equal to or higher than the panel security level, but never higher than the security level set up at the badge. To raise the security level at a D600 AP panel, see page 64.

Defining Security Levels

The Security Level Range Editor allows you to modify the default values of the security level. Security levels are represented by five colored alert codes (Red, Orange, Yellow, Blue, and Green). For each color there is a range defined by Minimum, Maximum, and Set numeric values between 1 and 99. Once the ranges are defined, they can be assigned to selected terminals using the Security Level Control dialog box.

To Define Security Levels:

- From the P2000 Main menu select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand **Panels** to display panel components.
- 3. Select **Security Level** and click **Edit**. The Security Level Range Editor dialog box opens.



- Enter for each of the five colors, the Minimum, Maximum, and Set To values. Keep in mind that the Minimum has to be below the Maximum value, and that the Set To value must be in between the Minimum and Maximum values. The system does not allow overlapping of ranges.
- Once the security level color codes have been defined with acceptable ranges, click Apply to save the values while leaving the dialog box opened.
- 6. Click **OK** if you wish to close the Security Level Range Editor dialog box.

Applying Security Level

Once the Security Level is defined, you can rapidly apply a Security Level value to terminals using the Security Level Control dialog box.

To Apply Security Levels:

 From the P2000 Main menu, select Control>Security Level. The Security Level Control dialog box opens.

TIP:

III. As an alternative, you can click the Security Level Control icon in the P2000 toolbar to rapidly open the Security Level Control dialog box.

Security Level Control				
	Pa	rtition Super L	lser	•
5elect Terminals By				
Terminal	Name	Current	Requested	
C Panel	Lobby Entrance	0	50	
C Terminal Group	Warehouse Entry Warehouse Exit	0	70 10	
iecurity Level By Color				
C Red				
Orange				
C Yellow				
C Blue				
C Green				
C Clear Security Level				
C Other >> 1				
Perform	Select All			

- 2. If this is a partitioned system, select the **Partition** in which the terminals reside.
- 3. In the **Select Terminals By** box, select one of the following options:

Terminal – All terminals (for the partition selected) are listed on the right side of the dialog box. Use this option to restrict access to the selected terminals.

Panel – All panels (for the partition selected) are listed on the right side of the dialog box. Use this option to restrict at once access to all terminals connected to the selected panels.

Terminal Group – All terminal groups (for the partition selected) are listed on the right side of the dialog box. Use this option to restrict at once access to all terminals that belong to the selected terminal groups.

- 4. Depending on your selection in the Select Terminals By box, select from the list box the desired terminal, terminal group, or panel name. You can select multiple names by holding down the <Ctrl> key, or click Select All to select all items in the list.
- 5. In the **Security Level By Color** box, select one of the colored security levels you wish to apply, then click **Perform**.

The selected terminals in the list box display in the **Requested** column the default value for that colored security level. The **Current** column display the current security level at the terminal.

Note: If you raise the security level at terminals that use the **Override Reset Threat Level** option, all time zone based overrides, host initiated overrides, and cardholder overrides are immediately disabled. For more information, see Override Reset Threat Level Box on page 76 and page 139.

- 6. If you wish to assign a particular value, click **Other** in the Security Level By Color box, enter the desired security level value, then click **Perform**. The selected terminals in the list box are set to this value as well as display the color of that value.
- 7. Once management determines that the emergency is over, you can either put the terminals in their previous level or remove the security level by selecting the item (terminal, terminal group or panel) from the list box then clicking **Clear Security Level** from the Security Level By Color box. The color is removed from the terminal and the Requested and Current columns display 0.

8. Click **Done** to close the Security Level Control dialog box.

Input Point Suppression

This feature allows an operator to rapidly suppress input points permanently or for a specific time period, during which the input point stops reporting any changes of state and consequently prevents alarms from displaying in the Alarm Monitor. For example, if an input point is constantly sending messages, the operator may want to suppress the input point until it can be determined what is causing the problem, and keep the input suppressed until the problem is resolved. This applies to forced door and propped door soft alarm inputs, as well as hardware input points. See Appendix C: Panel Comparison Matrix to verify if your panel type supports this feature. The operator must have Suppress Inputs menu permissions to use this feature.

To Suppress Input Points:

- 1. From the P2000 Main menu select Control>Suppress Inputs.
- 2. Enter your password if prompted. The Suppress Inputs dialog box opens.

C Suppress	Inputs			
	Partition Super I	Jser	•	
Suppress	Input Point			
	C Input Group			
	C Door			
	Name Rollup D	oor		•
Action				
Stop S	uppression			
C Timed	Suppression		Duration 30	Seconds
C Begin S	Suppression	Perform		
		Done		

3. If this is a partitioned system, select the **Partition** in which the inputs are active.

4. In the Suppress box, select one of the following options:

Input Point – to suppress the selected input point.

Input Group – to suppress all input points in the selected group.

Door – to suppress forced and propped soft alarm input points associated with the selected door. This feature works if the Forced Door/Propped Door soft alarm is enabled.

- 5. Select an input point, input group, or door **Name** from the drop-down list.
- 6. In the Action box, select one the following (only the actions available for your panel type are enabled):

Stop Suppression – to cancel the Input Suppression condition. This returns the input point to fully functional status. (The input point starts reporting changes of state alarms).

Timed Suppression – to suppress CK7xx or legacy input points for the number of seconds entered in the **Duration** field. (The input point does not report alarms within this period). A value of zero keeps this input point suppressed until commanded to stop suppression.

Begin Suppression – to suppress Mercury or S321-IP input points. The input point remains suppressed until you click Stop Suppression.

- 7. Click **Perform**. The Action selection goes into effect.
- 8. Click Done to exit the window.

Controlling Areas and Muster Zones

The Area Control and Mustering features provide additional security measures in specific areas of your facility, such as highly sensitive areas, dangerous areas, or areas that contain high-value materials. Using Area Control for example, an operator can define a minimum number of cardholders allowed in a *controlled area*, such as a bank vault. Alternatively, if using Mustering, the operator can define *muster terminals* as places of assembly, for tracking the location and movement of personnel in the event of an emergency.

Area Control

An Area is a designated section of a facility with one or more readers or input points assigned. The Area can be monitored at any time to determine the current count and the entry, or entry and exit of personnel or vehicles to, for example, a paint shop or parking structure within a plant or facility.

You can group readers and input points that are related to a particular section of your facility, for the purpose of reporting on the current whereabouts of cardholders. Areas do not have any access control or transaction processing functions; they are set up for reporting purposes only. This feature is useful on large sites with many card-controlled access points.

Configuring the Area

Use the Area Configuration dialog box to define the readers and input points that monitor the entry and exit of cardholders or vehicles. Here you name and describe the specific Area, define the maximum and minimum cardholders allowed in the Area at any given time, and the count mode for the specific Area.

To Configure the Area:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Select **Areas** and click **Add**. The Area Configuration dialog box opens.
- 3. If this is a partitioned system, select the **Partition** that has access to this Area, and click **Public** if you wish the Area to be visible to other partitions.
- 4. Enter a descriptive Name for the Area.
- 5. Enter an Area **Description** that is meaningful to the operator.
- 6. Select the Area **Type** from the drop-down list. The options are:

Access – Select to monitor cardholder count on a specific Area, for example a *Main Vault*.

Facility – Select to monitor cardholder count on the entire facility, for example *Bank ABC*.

Parking – Select to monitor cardholder count in a parking structure, for example *Parking One*.

Note: It is possible for a cardholder to be counted on all three Area types at the same time; for example, when the cardholder badges at the parking structure reader (Parking One), then badges at the facility reader (Bank ABC), and then proceeds to badge at a specific access Area (Main Vault).

 Click Alarm to define any or all of the following alarm fields:

Max Allowed – An alarm is generated when the maximum number of cardholders entered in this field has been exceeded. The status column in the Area Control dialog box displays *Max Allowed Alarmed*.

Min Required – An alarm is generated when the minimum number of cardholders entered in this field is not present at the same time in the specific Area. The status column in the Area Control dialog box displays *Min Required Alarmed*. **Pre Max Allowed** – An alarm is generated when the pre-maximum number of cardholders entered in this field is reached. This field is available only if the Area Type selected is *Parking*. For example, if the Max Allowed is 100 and the Pre-Max Allowed is 95, an alarm is generated when 95 vehicles have entered the parking structure, that way the operator may advise other cardholders that the lot is full.

Note: In the **Adjustment** field, select the + or – sign, and enter a number to adjust any of the previous counts by this number. For example if the Max Allowed is 100 and you entered a +2 in this field, an alarm is not generated if the Max Allowed count is 102.

C Area Configuration			
Partition	Super User	🔽 Public	Alarm Max Allowed - 4
Name	Main Vault	🔽 Alarm	Min Perguined : 2
Description	Building North West		Bas Man Allamada
Type	Access		He Max Allowed :
	,		Adjustment : 🗧 📜
			Area Alarms Setting
Entry Let 2			
Entry Exit			
	Mode C Count All	 Count Terminals 	C Count Inputs
(<u>*) (</u>			
Terminal Input			
Terminal		Terminal Group	
Selected	Available Main Exit Beader	Selected	Available D(sult Readore
Vaukenkance	Parking North West		West Building Readers
	West Entrance		
	>>		>>
		L.	,
	OK	Cancel]

Area Alarms Setting

Area Alarms Setting enables the Alarm Monitor window to automatically pop up in front of other windows on the screen whenever any of the three Area Alarm types occur. The pop up displays a set of instructions related to that particular alarm. Before you assign instruction text to the various pop ups, you must first create instruction text. See To Create Instruction Text: on page 98.

 In the Area Configuration dialog box, click Area Alarms Setting. The Area Alarm Settings dialog box opens.

lax Allowed Alarm	
	Instruction Text Name On Alarm Set
Popup when set	Number Exceeded
	Instruction Text Name On Alarm Secure
Popup when secure	<none></none>
lin Required Alarm	
	Instruction Text Name On Alarm Set
Popup when set	Increase Number
	Instruction Text Name On Alarm Secure
Popup when secure	<none></none>
re Max Allowed Alarm	
	Instruction Text Name On Alarm Set
Popup when set	<none></none>
	Instruction Text Name On Alarm Secure
Popup when secure	<none></none>

- 2. In the Max Allowed Alarm box, click **Popup when set** or **Popup when secure**, and select the **Instruction Text Name** from the associated drop-down list that displays in the Alarm Response window whenever the *Max Allowed Alarm* is in the alarm or secure state.
- 3. In the Min Required Alarm box, click **Popup when set** or **Popup when secure**, and select the **Instruction Text Name** from the associated drop-down list that displays in the Alarm Response window whenever the *Min Required Alarm* is in the alarm or secure state.

- 4. In the Pre Max Allowed Alarm box, click **Popup when set** or **Popup when secure**, and select the **Instruction Text Name** from the associated drop-down list that displays in the Alarm Response window whenever the Pre Max Allowed Alarm is in the alarm or secure state.
- 5. Click **OK** to return to the Area Configuration dialog box.

Note: The default Alarm Priority setting for Area alarms is 10.

Define Area Terminals and Inputs Points

- 1. In the Area Configuration dialog box, click the **Entry** tab to monitor Entry type reader terminals and input points.
- 2. Select one of the following count modes:

Count All – Select if you wish to count the number of cardholders that are granted access through both reader terminals and input points.

Count Terminals – Select if you wish to count the number of cardholders that are granted access through reader terminals only.

Count Inputs – Select if you wish to count the number of cardholders that are granted access through input points only.

- 3. Click the **Terminal** tab to select the terminals that to be monitored for Area count.
- In the Terminal box, select the terminal from the Available list and click << to move it to the Selected list.
- In the Terminal Group box, select the terminal group from the Available list and click << to move it to the Selected list.
- 6. Click the **Input** tab to select the input points that to be monitored for Area count.

- In the Input box, select the input point from the Available list and click << to move it to the Selected list.
- In the Input Group box, select the input group from the Available list and click << to move to the Selected list.

Note: The terminal or input selected here cannot be assigned to another Area.

- 9. Click the **Exit** tab if you wish to monitor Exit type reader terminals and input points, and repeat the same steps.
- 10. Click **OK**. A new icon displays under the root Area icon. When you click the new Area icon, the parameters display on the right windowpane of the System Configuration window.

Controlling the Area

The Area Control dialog box is a real time control window that displays all the Areas defined in the Area Configuration dialog box. The default sort in the list box is by Area Name.

To Control each Defined Area:

- 1. From the P2000 Main menu, select Control>Area Control.
- 2. Enter your password if prompted. The Area Control dialog box opens.
- 3. Select the **Partition** that contains the Areas you wish to control.
- 4. If you wish to control a specific Area, use the **Filter** box to enter a filter criteria, such as *M** then click **Filter**. The list box displays all Area Names that start with the letter *M*.

Note: You can also select a previously typed filter from the drop-down list. The list box refreshes when you select * from the Filter box or when you close the Area Control dialog box.

The list box displays the following information for each defined Area:

Area Name – The Area name, as configured in the Area Configuration dialog box.

Type – The Area type, as configured in the Area Configuration dialog box.

Count – Displays the number of cardholders currently in the specific Area.

🕻 Area Control						
	Partition	iuper User	•	*	•	Eilter
Area Name	Туре	Count	Status	Partition	Description	
Bank ABC	Facility	1	Min Required Alarmed	Super User	Facility Access	
Main Vault	Access	2	Normal	Super User	Building North West	<u>S</u> earch
Operations Area	Access	4	Normal	Super User	Building North West	
Parking One	Parking	6	Pre Max Allowed Alarmed	Super User	North West Parking	
						Show <u>A</u> ll
						Show <u>O</u> nly
						<u>R</u> efresh
						⊆lose

Status – Displays one of the following:

- Normal No alarm was generated.
- Max Allowed Alarmed An alarm was generated because the maximum number of cardholders had exceeded.
- Min Required Alarmed An alarm was generated because the minimum number of cardholders was not present at the same time in the specific Area.
- Pre Max Allowed Alarmed An alarm was generated because the pre-maximum number of cardholders had been reached.

Partition – The Partition, as configured in the Area Configuration dialog box.

Description – The Description, as configured in the Area Configuration dialog box.

- 5. If you wish to change the current sort order, click the specific column header in the list box.
- 6. To display specific details of each Area, right-click the specific Area name, and select whether to Show Only the cardholders passing the filter criteria entered in the Area Filter dialog box (see the next section Defining Area Filters), or to Show All cardholders in the Area Details dialog box (see Displaying Area Details on page 315). You can have any number of Area Details windows opened at the same time.

Note: You can also access the Area Filter and each Area Details dialog box by clicking **Show Only** and **Show All** on the right side of the Area Control dialog box.

 To search the whereabouts of a specific cardholder, click Search. The Search Badge dialog box opens.

earch Badge			
Cardholder	First		
	Middle		
	Last	В	
First	Middle	Last	
Karen	F.	Banks	
Charles	N.	Bentley	
Badge		2004	•
Results			_
	Access	Test Lab	
	Facility		
	Parking		

- 8. Enter a value in any of the Cardholder fields. The list box displays the cardholder records that match the entered values.
- 9. Select a cardholder from the list box. If only one badge was assigned to this cardholder, that number automatically displays on the Badge field, and the respective Area Type field displays the Area name where the cardholder is located.
- 10. If the cardholder has more than one badge assigned, select a **Badge** number from the drop-down. The respective Area Type field displays the Area name where the cardholder can be found.
- 11. Click **OK** to close the Search Badge dialog box and return to Area Control.
- 12. To manually update the current Count and Status displayed in the Area Control list box, click **Refresh**. This list is automatically updated every 10 seconds.
- 13. Click Close to exit Area Control.

Defining Area Filters

Each Area Details dialog box displays the total count of all cardholders that have been granted access to the specified Area. You can, however, define filter criteria to help you locate specific cardholders quickly and easily.

 From the Area Control dialog box, right-click the Area Name that you wish to monitor and click Show Only, or select the Area Name and click Show Only on the right side of the screen. The Area Filter dialog box opens.

Area Filter		×
	First Name	
	Middle Name	
	Last Name	
	Company	ABC Industries
	Department	<all></all>
	Terminal	Lobby Entrance
UDF		
<none></none>		
Date/Time		
From	3/31/2009	▼ 8:30:00 AM -
То	3/31/2009	▼ 11:30:00 AM +
Partia	al Match	Exact Match Cancel

- 2. Enter the information on any or all of the fields to display specific cardholder count.
- 3. If you wish to search all cardholders that belong to the same **Company** or **Department**, select any of the previously defined Companies or Departments.
- To search by location, select the Terminal where cardholders last presented their badge.
- 5. If you wish to search by **UDF**, select any of the previously defined UDFs (Date type UDFs cannot be included in the search). Enter or select the UDF search criteria in the next field.

- If you wish to search by specific date and time, enter the information on the Date/Time box.
- 7. After you define the search criteria, click one of the following buttons:

Exact Match – to display an exact match to your search criteria.

Partial Match – to display all possible selections that match the initial characters of the search criteria; for example, if you enter *Carl* in the First Name field, the list box displays names such as Carla, Carlos, Carlton, and so on.

8. The Area Details dialog box opens, displaying all the cardholders passing the filters defined in the Area Filter dialog box.

Displaying Area Details

The Area Details dialog box displays current count details and status information for the Area selected. Here you can monitor and manually change current cardholder count.

The Area Details can be accessed from the Area Control dialog box in one of the following ways:

- When you select an Area Name from the Area Control list box and click **Show All**, or right-click the Area Name and click **Show All**; or
- When you select an Area Name from the Area Control list box and click **Show Only**, or right-click the Area Name and click **Show Only**, and enter the criteria in the Area Filter dialog box.

In either case, the Area Details dialog box opens, showing the Area Name and Area Type in the window title. See Area Details Field Definitions for details.

Area Details Field Definitions

Area Name – Displays the Area Name selected in the Area Control dialog box.

Current Status – Displays the current status of the Area. See the Status definitions on page 314.

Current Count – Shows the total number of cardholders currently in the Area, which were granted access through either reader terminals or input points.

Terminal Count – Shows the total number of cardholders currently in the Area, which were granted access through a reader terminal.

Input Count – Shows the total number of cardholders currently in the Area, which were granted access through an input point.

Set – This button is activated when the Current Count is manually changed, for example to add cardholders that you know are currently in the Area, but you do not know who they are. After entering the new count, click Set, then click Yes to confirm. The Input Count increases or decreases by the number you manually enter in the Current Count field. If you enter a new count in the Current Count field that is less than the total number of cardholders showing in the list box, you are asked to remove some cardholders from the list, or set the count to a larger value.

Refresh – To manually update the Area Details list box, click **Refresh**. If a change in the Area count occurs, only the Count fields are updated automatically and the Refresh button changes color displaying a message to refresh the list to see the changes.

Add – If a cardholder is currently in the Area, but does not display in the Area Details list box, click **Add** and select the cardholder name and badge number, click **OK**, then click **Yes** to confirm. The cardholder is added to the list and the Current Count and Terminal Count values are updated.

Remove – This button is activated if one or more cardholders are selected in the list box. Click **Remove** if you wish to manually remove a selected cardholder, then click **Yes** to confirm. The Current Count and Terminal Count values are updated.



Layout – This field relates to how the cardholder list displays in the list box. The drop-down list displays all Layout names that were previously defined in the Area Layout dialog box. (See Area Layout for more information, and the next section Viewing the Details List for instructions on changing the list box display.)

Default – Click **Default** to restore the eight default fields; see Viewing the Details List.

Done – Click **Done** to return to the Area Control dialog box.

Print – Click Print to print the details list.

Viewing the Details List

The details list box displays all cardholders currently present in the Area. Individual operators can define how the information in the Area Details list box displays on their system. You may choose to display only specific data.

Note: The previous sort order displays the next time you open the Area Details dialog box, but if the field you used to sort by is removed from the list, then the default sort is by the first column.

- 1. If you wish to change the sort order, click the desired column header. The list is sorted by the selected column.
- 2. To add or remove columns from the list box, right-click anywhere in the header to open a pop-up menu where you select the fields you wish to add or remove.

🕻 Bank Vault (ACCESS) - Area Details

	Area Name	Bank Vau	lt	
Current Count	3		Set	Refre
Terminal Count	3			
Input Count	0		Add	Remo
First Name Last Name Charles Bentley Fred Albertson Jeff Evans		 Radae First N Middle Last N Badge Depart Compa Termin Date/J Car Mc Color Approv 	Denarty ame Name ame y ment any al jine del ved Visits	nent Cor AB(AB(AB(

The pop-up menu displays eight default fields, plus any previously defined User Defined Fields. The check mark to the left of the field name shows which fields are currently displayed.

- 3. If you wish to change the position of the columns, drag and drop the column head-ing to desired position.
- 4. To select a previously defined **Layout**, select one from the drop-down list. See Area Layout for detailed instructions.
- You can make modifications to previously defined layouts. Any changes made are saved for future use and are applied if you select <none> from the Layout drop-down list.
- 6. Click **Done** to return to the Area Control dialog box. If you apply a different layout or change the existing one, you are asked if you wish to save the current view for future use.

Area Layout

The Area Details dialog box displays a default view consisting of eight pre-stored fields. You can, however, create different layouts to display only certain information, according to your particular needs. For example, a system administrator may want to monitor how many cardholders from a specific department are currently in the Area. In that case an Area Layout is created to display only the fields selected on the Area Layout Edit dialog box.

To Define Area Layout:

 From the P2000 Main menu, select Config>Area Layout. The Area Layout dialog box opens.

🕻 Area Layout				_ 🗆 ×
	Partition Supe	er User	•	
Name		Partition	F	Public
Human Resources Security		Super User Super User		40 40
Done	Add	Edit	Delete	

2. Click **Add**. The Area Layout Edit dialog box opens.

Area Layout Edit		×
	Partition Super User	•
	Name Human Resources	
Items	,	
Item	Width	
✓ First Name	35	
Middle Name	0	Un 1
🖌 Last Name	35	P
✓ Badge	10	Down
Department	25	<u></u> 0wiii
Company	0	
Terminal	0	Change Width
Date/Time	0	
✓ Title	35	
Shift	0	
	<u>O</u> K <u>C</u> ancel	

3. If you use partitioning, select the **Partition** that has access to this Area Layout.

- 4. Click **Public** if you wish this Area Layout to be visible to all partitions.
- 5. Enter the **Name** of the Area Layout. This name displays in the Layout field of the Area Details dialog box.
- 6. The Items box displays eight default fields, plus any User Defined Fields, previously defined. Click the check box to select the fields you wish to display on the Area Details list box. The default width (in characters) of the selected field displays.
- 7. To change the width, either double-click the width field, or click **Change Width** and enter the new width.
- 8. If you wish to change the order in which the fields display, click **Up** or **Down** to move the field up or down on the list.
- 9. When all information is entered, click **OK**. The new Area Layout displays in the Area Layout dialog box.
- 10. Click **Done**. This Area Layout is now accessible from the Area Details dialog box.

Area Reports

Five Area reports are provided as part of the standard P2000 reports:

All Areas to Cardholder - Preprocessed – Lists by cardholder name, all areas the cardholder can access and the terminal doors defined for the area.

All Cardholders to Area - Preprocessed - Lists by area name, the cardholders and badges that have access to the area.

Note: Preprocessed reports display current data. Any changes made to database items are not reflected until the following day, unless you manually update the report table using the Update Preprocessed Reports table task in Database Maintenance; see page 486.

Area Configuration – Lists by area name, all configuration information entered in the Area Configuration dialog box.

Area Control – Lists the cardholders currently in the area, including the total number of cardholders for each count mode.

Area Transaction – Lists all transactions performed in the system for the specific area. You can select to run the report on transactions at your local site or you can enter the name of the remote site that you want to report on.

See Chapter 6: System Reports for detailed instructions on running P2000 Standard Reports.

Mustering

The Mustering feature provides the capability of tracking personnel movement in the event of an emergency.

During the emergency, all personnel within a risk area are expected to evacuate and are required to badge at a reader outside the risk area, thereby providing real time printed reports and online display information as to who may still be in a hazard area. The report and online display can be used to direct search and rescue operations. The list of personnel still in the risk area is derived from the last known access data, and then refined by tracking badge activity as personnel move out of the risk area.

Mustering is initiated by a P2000 event, which triggers a *Muster*; or by manual action using the Muster Zone Status and Control dialog box. Once management or emergency personnel determine that the emergency is over, the *Muster* is terminated by an event that stops the *Muster*, or by manual action using the Muster Zone Status and Control dialog box.

Basic Definitions

Muster Zone – A Muster Zone is defined as any area within a facility that presents some risk to personnel; for example, a paint shop, an oil refinery, or a building's electrical control center. In the P2000 Mustering feature, a Muster Zone is represented by one or more badge reader terminals.

Zone Terminal – Zone terminals are badge reader terminals that define a Muster Zone. These reader terminals can control entry to a zone, a paint shop for example, where the zone terminals would control the access. Zone terminals could also be readers at various locations where personnel are required to badge as they move around, but which do not control access, as in an oil refinery for example. The general requirement is that when someone has badged at a zone reader terminal, it means that person is in the zone.

Muster Terminal – In an emergency, personnel are expected to move from the Muster Zone to a safe area, where muster terminals for the zone are located. As personnel arrive, they badge at the muster terminal, allowing the system to know that they are no longer *at risk*. There can be any number of safe areas and muster terminals for a zone.

Sequester Terminal – Any terminal installed in a sequester zone. A sequester zone is defined as a secondary Muster Zone when the initial mustering may not provide permanent safety. In some cases a muster safe area may only provide temporary safety. If so, it is desirable to move people to a safer (sequestered) area, where sequester terminals are set up and where arrival of personnel is recorded in the same way as muster terminals. Sequester Terminals are optional. **Muster** – A Muster occurs when an event representing an emergency within the Muster Zone is triggered. Personnel in the Muster Zone are then expected to move to safety and badge at a muster terminal to indicate that they are out of danger.

At Risk – When a Muster begins, all personnel within a Muster Zone are considered to be *at risk* until they badge at a muster terminal so that their status can be upgraded according to the last used terminal.

Trapped – Personnel are considered trapped if they badge at one or more zone terminal after the Muster begins, indicating that they are moving but possibly unable to escape the Muster Zone, for example because of a blocked exit.

Wandering – Personnel are considered to be *wandering* if they badge at a terminal outside the Muster Zone, but not at a designated muster terminal. Wanderers are assumed to be on their way to a muster terminal, but because of circumstances, may be having difficulty finding a safe path. For example, a hazard may be spreading to other parts of the facility, causing difficulty escaping from the original event.

Mustered – Mustered personnel are those who have badged at a designated muster terminal since the start of a Muster.

Sequestered – Sequestered personnel are those who have badged at a designated *sequester terminal* since the start of the Muster.

Rescuer – Rescuers are personnel who badge into the Muster Zone during the Muster. Rescuers are assumed to be carrying out search, rescue, or emergency control activities, and are tracked until they badge at a muster or sequester terminal. **Note:** Trapped, Wandering, and Rescuer groups are only tracked if **Track Movement** is selected in the Muster Terminals tab; see page 325.

Sequence of Steps

The basic procedures for defining and implementing Mustering are:

- Define Muster Zones and the terminals that are associated with it.
- Define the Events that start and end the Muster (alarms, card events, inputs), or any Events that are to be triggered when a Muster starts or stops (set outputs to turn lights on, open doors, activate alarms, and so on.)
- Control Muster Zones before, during, and after a Muster.
- Generate reports and analysis reports.

Define Risk Areas and Muster Zones

Careful examination of a facility can disclose any potential risks and allow you to physically define the necessary Muster Zones. Following this process, use the Muster Zone Definition dialog box to define the Muster Zone, associate the necessary zone, muster, and sequester reader terminals with the Muster Zone, and select the appropriate options to control it.

To Define Muster Zones:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Select **Muster Zones** and click **Add**. The Muster Zone Definition dialog box opens at the General tab.

- 3. Enter the required information in each tab according to your system requirements. See the following Muster Zone Definition Fields for details. As you work through the tabs, click **Apply** to save your settings.
- 4. When all entries are complete click OK to return to the System Configuration window. A new icon displays under the root Muster Zones icon. When you click the new Muster Zone icon, the parameters display on the right windowpane.

Muster Zone Definition Fields

Zone Name – Enter a meaningful zone name. All zone names must be unique. Zones should be named logically, including information such as the zone location and what it contains, to be easily identified by rescue personnel in the event of an emergency.

Partition – Select the partition in which this Zone Name is active.

Public – Click Public if you wish this Zone Name to be visible to all partitions.

Enabled – Click Enabled for the system to recognize this Zone Name. If you wish to temporarily disable the Zone, click to clear the check box.

Automatically start the Muster Control Dialog – Click if you wish to automatically open the Muster Zone Status and Control dialog box as soon as a Muster begins. If you enable this option, select from the drop-down list the workstation that automatically displays the Muster Zone Status and Control dialog box when a Muster begins.

Note: To take advantage of this option, the P2000 software must be running at the designated workstation when the Muster begins.

Muster Zone Definition		
General Zone Terminals Muster Tern	ninals Sequester Terminals	
Zone Name: Paint Sho	qu	Partition: Super User
V Public	Automatically start the Muster Control E	Dialog on
Enabled	security station	•
Automatic Reports		
 One line abbreviated content 		No automatic reports
C Two line full content		Select Printers
	Report Interval: 10 📑 🛛	minutes
Muster Startup Rule		
If the badge status shows that the h regardless of last badge time only if last badge is today unless last badge is older than	older is in the zone, assume holder is in the z	1 🚟 Days 💌
unless last badge is for a prior sh	ift	
Shift Setup Number of shifts Shift 1 Timezone Shift 2 Timezone Shift 3 Timezone	2 ↔ Paint Shop Shift One ♥ Paint Shop Shift Two ♥	Options Options Image: Allow expansion Use only valid badging at startup Image: Enable de-muster Muster Zone Alarm Settings
		OK Cancel Apply

One line abbreviated content – If enabled, a one-line report is automatically printed when a Muster begins. This report is printed at the Report Interval selected and includes first and last name, badge number, and last badging date and time.

Two line full content – Select this option if you wish to automatically print more detailed cardholder information when a Muster begins. This report is printed at the Report Interval selected and includes first and last name, badge number, last badging date and time, terminal name, company, and department name.

Report Interval – Select from the spin box the report interval (in minutes) at which mustering reports is printed during an emergency. When a Muster starts, the first report is printed immediately.

IMPORTANT: Printing muster reports is not guaranteed on foreign language systems.

No automatic reports – Click if you do not wish to generate any of the previous automatic reports.

Select Printers – Click to select a printer where Muster reports are printed as soon as a Muster begins. When the Select Report Printers dialog box opens, select a printer name from the list and click OK. You can select one or more printers, as long as the *PegasysServices* Windows user account that runs the P2000 Muster Service has the appropriate access rights to those printers. Automatic muster reports can only be printed from a printer connected to the P2000 Server.

Note: We recommend setting up a printer to be used exclusively for printing Muster reports.

Muster Startup Rules

Several rules are provided to guide you in determining whether a cardholder's last badge location means that the cardholder is inside or outside the Zone when a Muster is started.

For mustering purposes, either the last valid or last invalid badging is used, depending on which has the latest date and time. You can prevent invalid badging from being used to determine the initial *At Risk* group; see **Use only valid badging at startup** on page 323 for details. Thereafter, a muster in progress always uses the last known badge activity, valid or invalid. Even invalid badging shows the cardholder's current location.

If the badge status shows that the holder is in the zone, assume holder is in the zone (select one of the following options):

- regardless of last badge time Select this option to include all cardholders regardless of the last badge time.
- only if last badge is today Select this option if you wish to monitor who badged today.
- unless last badge is older than Select this option to assume the cardholder is in the zone only if the last access grant was within the number of days, hours, or minutes selected.
- unless last badge is for prior shift Select this option if your facility does shift work and the cardholder's last access grant was during a previous shift, to assume that the cardholder is no longer in the area. If enabled, the Shift Setup box is activated.

A basic rule for applying this option is to set up your time zones to start one after the other in the correct correlative order, for example Shift 2 should always start after Shift 1, and Shift 3 should always start after Shift 2. See the following example:

	323

Enable de-muster – If selected, and a Muster has been stopped, and before returning the Zone to the *Ready* status again, you can click **De-Muster** in the Muster Zone Status and Control dialog box to put all personnel who were in the *At Risk* group back at their initial location when the Muster began. De-Muster can also be activated by a P2000 Event if desired.

Note: To end an emergency by a specific event, you must specify any number of different events as Muster terminating events. See Mustering Events on page 326.

Muster Zone Alarm Settings

Muster Zone Alarm Settings enable the Alarm Monitor window to automatically pop up in front of all other windows on the screen whenever a Muster alarm condition occurs.

You can also specify instruction text that displays when an operator responds to a Muster alarm going into a Set or Secure state. Enabling the Popup feature and selecting Instruction Text are independent tasks, and can be used in any combination.

Before you assign instruction text to the various pop ups, you must first create instruction text. See To Create Instruction Text: on page 98.

1. In the Muster Zone Definition dialog box, click **Muster Zone Alarm Settings**. The Muster Zone Alarm Settings dialog box opens.

24-10685-157 Rev. D

Shift	Work Schedule	Week Days	Time Zone
Shift 1	8:00am - 5:00pm	Mon-Fri	7:30am - 5:30pm
Shift 2	5:00pm - 2:00am	Mon-Sat	4:30pm - 2:30am
Shift 3	2:00am - 8:00am	Tue-Sat	1:30am - 8:30am

Shift Setup

Number of shifts – If you enable **unless last badge is for prior shift**, select from the spin box the number (1 to 3) of shifts in your facility.

Shift 1 - 3 Timezone – Select from the drop-down list the time zone assigned to each shift in your facility.

Muster Zone Definition Options

Allow expansion – If selected, the Zone can be dynamically expanded during a Muster. This is useful in cases where the Zones are overlapped or not very rigidly defined. For example, an emergency event in one part of the facility might spread to adjacent areas and the Zone could be expanded to include terminals in those areas as the need arises. As expansion takes place, the badging activity at the newly incorporated terminals is examined to determine which personnel need to be added to the *At Risk* group.

Use only valid badging at startup – If selected, only valid badging determines if the cardholder is inside a risk area. If this option is not selected, any invalid badging inside a risk area is included in determining if the cardholder is inside the risk area.

	Instruction Text Name On Alarm Set
🔽 Popup when set	Muster Zone Activated
	Instruction Text Name On Alarm Secure
Popup when secure	<none></none>
larm On Zone Status Degraded Or Inoperable	
F	Instruction Text Name Un Alarm Set
Popup when set	<none></none>
	Instruction Text Name On Alarm Secure
Popup when secure	<none></none>
larm On Muster Aborted	Jackweiter Test Marris Die Alexe Cet
Popup when set	Muster Zone Aborted
	Instruction Text Name On Alarm Secure
Popup when secure	<pre>(none)</pre>
larm On Muster Triggered When Zone Is Disa	bled
Popup when set	<none></none>
	- Charley

2. Click any of the following **Popup when** set or **Popup when secure** check boxes, and select the **Instruction Text Name** from the associated drop-down lists that displays in the Alarm Response window whenever any of the following alarm conditions occur:

Alarm On Start of A Muster – An alarm message is generated at the start of a Muster.

Alarm On Zone Status Degraded or Inoperable – An alarm message is generated if one or more panels or terminals that belong to a Muster Zone are disabled or go down.

Alarm On Muster Aborted – An alarm message is generated if system operation is affected during the emergency. For example, if database problems are encountered during the Muster, the Muster cannot continue and aborts.

Alarm On Muster Triggered When Zone is Disabled – An alarm message is generated when a disabled Muster Zone is triggered to be started by an event. This option does not have a specific event or action of any kind that makes it Secure, and does not have a corresponding pop-up option and related instruction text. 3. Click **OK** to return to the Muster Zone Definition dialog box.

Note: The default Alarm Priority setting for Muster alarms is 5.

Defining Zone Terminals

Use the Zone Terminals tab to select the terminals or terminal groups that provide access to the zone defined for mustering purposes. These terminals may be of any type, Access, Entry, or Exit.

IMPORTANT: Do not use Assa Abloy Wi-Fi readers to define Zone terminals, as those readers do not report transactions in real time.

- 1. From the Muster Zone Definition dialog box, click the **Zone Terminals** tab.
- 2. From the **Available Terminals** list, select the terminal that provides access to the Muster Zone.
- Click <<. The terminal is included in the Selected Terminals box.
- 4. From the **Available Terminal Groups** list, select the terminal group that provides access to the Muster Zone.
- 5. Click **<<**. The terminal group is included in the **Selected Terminal Groups** box.

Note: The Available Terminals and Available Terminal Groups boxes display only terminals that have not yet been defined as Muster or Sequester Terminals.

Defining Muster Terminals

Use the Muster Terminals tab to select the terminals or terminal groups that are designated as mustering terminals, and to associate these mustering terminals with each risk area. Muster terminals should be dedicated to the mustering function; they should not control access. From an operational viewpoint, it does not matter if badges are valid at muster terminals. As long as they are recognized by the P2000 system, its use at muster terminals is recognized during the Muster, regardless if a red or green light displays at the terminal.

During an emergency, all personnel within the risk zone are required to badge at any defined muster terminal to provide real time information as to their location.

IMPORTANT: Do not use Assa Abloy Wi-Fi readers to define Muster terminals, as those readers do not report transactions in real time.

- 1. From the Muster Zone Definition dialog box, click the **Muster Terminals** tab.
- 2. From the **Available Terminals** list, select the terminal where cardholders can badge in an emergency.
- Click <<. The terminal is included in the Selected Terminals box.
- 4. From the **Available Terminal Groups** list, select the terminal group where cardholders can badge in an emergency.
- 5. Click **<<**. The terminal group is included in the **Selected Terminal Groups** box.
- 6. Click **Muster At Any Non Zone Terminal** if in an emergency you wish to allow cardholders the option of badging at any terminal that has not been defined as a Zone Terminal.

If this option is selected, terminals not assigned to the zone are treated as muster terminals, and Movement Tracking is limited to *Trapped* and *Rescuers* only.

- 7. Click **Muster Only At Terminals Selected Here** to have cardholders, in an emergency, badge only at the muster terminals selected in this tab. This is the default option, and allows you to select specific muster terminals for the zone.
- 8. Click **Track Movement** if you wish to trace cardholder movement within the defined Muster Zone. Cardholders may be considered *Trapped*, *Wandering*, or *Rescuers*, depending on where and when they badge. See Basic Definitions on page 319 for details. To get the best use of this feature, do not click **Muster At Any Non Zone Terminal**.
- 9. When you finish defining the zone and muster terminals, you may click **Apply** to save your entries and continue with defining the optional sequester terminals; or click **OK** to save your entries and close the Muster Zone Definition dialog box.

Note: The Available Terminals and Available Terminal Groups boxes display only terminals that have not yet been defined as Zone or Sequester Terminals.

Defining Sequester Terminals

In an emergency, personnel who initially badged at a muster terminal can be moved in groups to a safer offsite location, a sequester zone, where they are required to badge at a sequester terminal, and therefore, provide real time information that they have been moved outside the risk area to a safer location.

Use the Sequester Terminals tab to define the terminals or terminal groups that are designated as sequester terminals. Sequester terminals are optional.

IMPORTANT: Do not use Assa Abloy Wi-Fi readers to define Sequester terminals, as those readers do not report transactions in real time.

- 1. From the Muster Zone Definition dialog box, click the **Sequester Terminals** tab.
- 2. From the **Available Terminals** list, select the terminal where cardholders can badge once they are moved to a safer location.
- Click <<. The terminal is included in the Selected Terminals box.
- 4. From the **Available Terminal Groups** list, select the terminal group where cardholders can badge once they are moved to a safer location.
- 5. Click **<<**. The terminal group is included in the **Selected Terminal Groups** box.
- When you finish defining the zone, muster, and optional sequester terminals, you may click **Apply** to save your entries, or click **OK** to close the Muster Zone Definition dialog box.

Note: The Available Terminals and Available Terminal Groups boxes display only terminals that have not yet been defined as Zone or Muster Terminals.

Mustering Events

After Muster Zones are defined, they can be associated with one or more events, each of which can trigger a Muster for that zone as one of its actions.

Event Actions allow an event to start and stop a Muster, while Event Triggers allow the starting and stopping of a Muster to trigger additional P2000 events, such as unlocking doors or turning on audible or visual alarms to alert personnel of danger in the area. The events used can include one or more inputs going to an alarm state in response to a variety of possible signaling devices, alarms, or manual actions. You can also specify one or more output points that can be set upon triggering of a Muster.

In the following example, the *Paint Shop Emergency Event* has been programmed to start the mustering, turn emergency lights on, and activate an audible alarm (actions) when input point *Manual Alarm* goes into alarm after the operator presents the badge at the *Emergency Terminal* (triggers).

0	nfigure Eve	ents - Edit							×
		Dartition	SuperLiser		-		ublic		
		Faruton	Duper Oser		<u> </u>				
		Name	Paint Shop Em	ergency Event		I ∨ A	llow Manual Ti	igger	
		Active	<always></always>		-	Trigg	er Logic 🛛 🔿	OR	
			🔽 Enable				۲	AND	
	Triggers								
	Category	Туре		Condition	Logic		Value		I
	Badge	Local Grant Input Is Set	(steady state)	Terminal Name Input Point Name	IS EQUA IS EQUA	LTO I	Paint Shop Em Manual Alarm	ergency Terminal	
			,						
	1	-							
	I								
			Add	Edit	(Delete			
	Actions		-						_
	Delay 00:00:00	Category Mustering	Type Mustering S	Value 1 Start Paint S	hop		Value 2	Value 3	- 11
	00:00:00	Outputs	Set Output	Activat	e Emerger	ncy Lights			
	00:00:00	Outputs	Set Output	Activat	e Audible	Alarm			
									
							_		-
	•								<u> </u>
		Add	Edi	t Delete		Up	Down		
							·		
				ОК	Cance	al			
niç	jger					×			11
	Categ	lory inputs				·			
	т	ver line t is Set (steady state)			-			
						-			
	Conai	000 Input Point N	ame			<u> </u>			
	U	ogic IS EQUAL TO				-			
	Ve	slue Manual Alarm				×			
			~	current of					
			- OK	Carta					
				Action					
						Order			
					Dela	y (H:M:S)	0:00:00		
				Cat	enera lonto	05			
					Type Set C	Dutput			
				0	Activ	rate Audible Al	am		

You can end the emergency (de-mustering) by a specified event or events, and specify any number of different events as muster terminating events.

327

The following event actions are required to start a Muster, stop it, save data, or de-muster, and then make the zone *Ready* for another Muster: Mustering Start, Mustering Stop, Make Zone Ready, De-Muster, and Save Muster Data (last two are optional).

To allow a Muster to be triggered by an event and to trigger other P2000 events, use the information on Creating Events on page 349 to create new event triggers and actions.

Controlling Muster Zones

Use the Muster Zone Status and Control dialog box to monitor the status of a Muster Zone; and when a Muster is initiated, to control all the activities of the Muster in progress.

Mustering can be manually started and terminated by operator action using the Muster Zone Status and Control dialog box. When mustering is triggered by a P2000 event, the Muster Zone Status and Control dialog box automatically opens at the designated workstation selected in the Muster Zone Definition dialog box, if this option is selected for the zone.

When an initiating event occurs, the Muster Zone enters a *Running* state. Any events scheduled to occur on starting the Muster are triggered, and the zone determines the initial situation from last badge information and any time-based rules defined for the zone. Once the initial situation is known, the report of cardholders still inside the zone is output repeatedly at the interval set up when the zone was defined. As cardholders badge at the designated muster terminals the situation is updated to show the new list of cardholders still in the zone.

Operators must first have Muster Control menu permissions to use this feature. Depending on the permissions assigned using the Menu Permission Groups, some or all operators may be able to control muster zones at any time. For detailed information, see Creating Permission Groups on page 21.

To Manually Control a Muster:

 From the P2000 Main menu, select Control>Muster Status/Control. Enter your password if prompted. The Muster Zone Status and Control dialog box opens.

Muster Zone Status a	and Control	X
	Select a Muster Zone to monitor and control.	
Manufacturing Paint Shop		
a cint of top		
	OK Cancel	

2. Select the Muster Zone you wish to control and click **OK**. The Muster Zone Status and Control dialog box opens, showing the Muster Zone name in the window title.

The list box displays the name, badge number, and last known location and time of all cardholders currently in the defined Muster Zone. See the following Muster Zone Status and Control Field Definitions for details.

Muster Zone Status and Control Field Definitions

Zone – Displays the name of the Muster Zone to be monitored.

Zone Status – Displays the status of the Muster Zone. A Muster Zone can be *Ready*, *Running*, *Stopped*, *Aborted*, or *Disabled*. As personnel, who were initially in the zone, badge at other readers during a *Running* Muster, their location is tracked and they are put in the appropriate group as their location changes.

		C Paint Shop - Muster	Zone Status and Con	trol		
		Zone Paint Shop Zone Hardware Status OK Show Group Ok Point		Zone Status Start Time	RUNNING Enabled 3:38:44 PM	
			Personnel In Group	: 2	Elapsed Time	00:01:00
	Name Badge Number Last Location Taylor, James 352 Back Entrance Smith, John 357 Main Exit		Time 2:13:30 PM 2:13:30 PM	Start Stop		
						Ready
						Drill
						De-Muster Reset
			NO PRINTER FOR MUS	FER REPORTS		
		Suspend Printing	Refresh List		Remove Selected I	ndividuals
· ·		Number Mus	tered 0		Print Grou	P
A warning Printer For	message No Muster Reports	Number Seques	tered 0		Expand Zor	ne
displays he	ere if no printer	Msg Routing S	tatus	_	View Inoperable H	lardware
was selected	ed in the Muster ition dialog box.	Muster Service	e Status	Sar	ve Data Repo	Done Done

Zone Hardware Status – Displays one of the following:

- **Inoperable** If all muster terminals or panels are disabled or down.
- Degraded If one or more muster terminal or panel is disabled or down.
- **OK** If all muster terminals or panels are enabled.

Show Group – Select the group you wish to display. This allows switching the display to any of the available groups. Choices are: At Risk, Trapped, Wandering, Mustered, Sequestered, and Rescuer. See Basic Definitions on page 319 for details. The At Risk group is the default display.

Personnel In Group – Displays the current number of cardholders in the group selected in the Show Group drop-down list.

Enabled - Click Enabled for the system to control this Zone. If you wish to temporarily disable the Zone, click to clear the check box. You can disable a Zone only when it is in the *Ready* status.

Start Time – Displays the time the Muster was triggered or manually started.

Elapsed Time – Displays the time that has gone by since the Muster started.

Start – Click Start to manually start a Muster. To manually start a Muster, the Zone must be in the *Ready* status. Once started, the Muster Service determines the initial state of the Zone and the At Risk group displays by default.

Stop – Mustering is stopped by triggering an event designated to automatically stop a Muster. If you wish to manually terminate a Muster, click Stop. The Zone Status displays the Stopped state and analysis reports become available by clicking first Save Data and then Reports.

© 2014 Johnson Controls, Inc.

This document contains confidential and proprietary information of Johnson Controls, Inc. $\ensuremath{\textcircled{i}}$ 2014 Johnson Controls, Inc.

Once the Muster is stopped the Zone Control quits updating the list of cardholders.

Ready – When a Muster is manually stopped, it may be necessary to ensure that all triggering devices, such as alarms, manual switches, or push buttons are reset so that another Muster cannot be inadvertently started. Once it is determined that the Zone can be made ready for another Muster, click Ready to enter the *Ready* state.

Drill – To participate in a disaster preparedness exercise, a Muster can also be run as a drill by clicking Drill. A drill differs from the real thing by the fact that during a drill, events that would otherwise send external alarms to outside emergency response agencies can be suppressed.

This feature applies only to events triggered by the starting or stopping of a Muster; it cannot be applied to the events that normally start a muster. When you define the trigger, and click **Do not trigger for muster drill** it prevents any event action from being carried out when a drill is in progress. A drill can only be initiated through the Muster Zone Status and Control dialog box.

Trigger			х
Category	Mustering	•	
Туре	Mustering Start	•	
Condition	Zone Name	•	
Logic	IS EQUAL TO	•	
Value	Paint Shop	•	
	Do not trigger for muster drill		
	OK Cancel		

De-Muster – Click to put all personnel who were initially in the zone back to their location when the muster began. This option is used when muster terminals are located within the Zone, in that case cardholders are not required to badge back into the Zone. All mustered cardholders can be automatically restored to their last badge location through the De-Muster capability, as long as the **Enable de-muster** option is selected in the Muster Zone Definition dialog box. This function is password protected.

Reset – Click to stop a Muster in progress and reset the Zone Status back to *Ready*. The Reset function is not normally used, but under unusual circumstances, such as database problems during a Muster causing the Muster to abort, the Reset button must then be used to reset the Zone.

Note: A Muster in progress resets itself after the P2000 system recovers from a database failure.

Suspend Printing – Enable this option to momentarily suspend the automatic printing of the selected group, to add paper or take care of some other printer problem.

IMPORTANT: Printing muster reports is not guaranteed on foreign language systems.

Refresh List – Click to update the list box.

Number Mustered – Displays the total number of cardholders who have badged at a designated muster terminal.

Number Sequestered – Displays the total number of cardholders who have badged at a designated sequester terminal.

Remove Selected Individuals – This button can be used to manually move one or more cardholders from any group to any other group while a Muster is *Running*. You can use it to make the final group content reflect a situation where, for example, some personnel left the Muster Zone but did not badge at a muster terminal, yet their current location is known. **Print Group** – Click to print the group currently being displayed. Printing is done at the designated printers selected in the Muster Zone Definition dialog box.

Expand Zone – Use this option if you wish to expand a Muster Zone during an emergency. For instance, a hazard may spread requiring zones that initially were not involved, to be added to the active Muster Zone. You can only use this option if **Allow expansion** was enabled in the Muster Zone Definition dialog box. When you click this button, a list of available terminals displays, where you can select the terminals you wish to add. All personnel who last badged at any of the new terminals are added to the *At Risk* group.

View Inoperable Hardware – Click this button to view muster terminals or panels that are not enabled or are down.

Note: The Message Routing Status indicator at the bottom of the window displays in green to indicate that all communications between the workstation and the Server are up. If communications go down, the Message Routing Status indicator turns red.

The Muster Service Status indicator displays in green to indicate that Muster Service is up and running. If Muster Service goes down, the indicator turns red.

Save Data – After the Muster is terminated, you may click this button to store the Muster data in the database for later evaluation.

Reports – Once the Muster is stopped and data has been saved, analysis reports can be run by clicking this button. These reports are run using the P2000 Standard Report feature. Reports can be run during the *Stopped* state, or at a later time when the Muster data has been saved. For more information, see Muster Reports.

Viewing and Printing Muster Transactions in Real Time

Once a Muster is started, an alarm is generated and displayed in the Alarm Monitor window, and all mustering transactions are sent through real time messages to the Real Time List. As the Muster Zone status changes, corresponding Muster-related messages are generated and displayed. You must select the Mustering check box in the Real Time List window to display all mustering transactions as they occur. See Using the Real Time List on page 356 for more information.

If you wish to print mustering transactions as they occur, you can either print them from the Real Time List window, or select the Mustering Zones check box in the Site Parameters dialog box, Printing tab. See Printing Tab on page 35 for more information.

Note: The Muster Zone hardware status also displays in the System Status window, see Viewing System Status on page 473 for details.

Muster Reports

Muster reports are available while the Muster is in the *Stopped* state, or afterward if the Muster state is saved before returning the zone to the *Ready* state. These reports allow management to assess preparedness for emergencies and improvement of procedures for handling future events.

When you click **Reports** in the Muster Zone Status and Control dialog box, the Muster Analysis dialog box opens.

luster Analysis		×
Muster Zone Name	*	
Available Date/Time	, *	
Group Type	At Risk	
Started By	Operator 💌	
Reason	Real Only	
OK	Cancel	

The **Muster Zone Name** and **Available Date/Time** fields only display selections if the Muster Zone was started at least once.

In the **Group Type** drop-down list select one of the following reports:

- At Risk Displays the list of personnel who are within the Muster Zone and have not yet checked-in at a muster terminal.
- Trapped Displays the list of all personnel who may be trapped in the Muster Zone.
- Wandering Displays the list of all personnel who are not believed to be in the Muster Zone, but who have not yet checked-in at a muster terminal.
- Mustered Displays the list of all personnel who have badged at a muster terminal.
- Sequester Displays the list of all personnel who have badged at a sequester terminal.
- **Rescuer** This report tracks all rescue personnel throughout the site.

In the **Started By** drop-down list select whether this Muster Zone was started by an *Operator* or by an *Event*.

In the **Reason** drop-down list select the reason why this Muster was started, whether it was a real Muster, a drill, or both.

After you have entered your selections, the Muster Analysis Report displays in the Crystal preview window showing the criteria selected and the total number of cardholders in the Muster Zone. This report lists all Mustering activity within a specified time frame by zone name, start and stop times and whether it was a drill or real emergency.

This report can also be generated using the **Report>Run Report** option and selecting the Muster Analysis report.

In addition to the Muster Analysis report, the P2000 Standard Reports set includes the Mustering Configuration report, which lists by Muster Zone name, all the zone definition configuration, as set up in the Muster Zone Definition dialog box. This report lists each Muster Zone and shows its defining and mustering terminals, and all associated events.

Intrusion Detection

The Intrusion Detection function has been designed to sense an intrusion into a protected building (detection) and report it to responsible parties (annunciation). This is accomplished with a combination of detection, control, and reporting devices such as a control panel, input devices (sensors), and output devices (bells, sirens).

The Intrusion Detection system consists of sensors, connected to the intrusion panel, capable of detecting various intrusion or burglary events. These intrusion detection sensors are associated with physical zones/points and grouped into areas; also intrusion events use audible annunciators to signal that a zone or area is in alarm condition.

The P2000 Intrusion Service resides on the P2000 Server and provides the communication between the P2000 system and intrusion panels. This service allows the P2000 system to obtain status information whenever an intrusion component changes and issues commands to control the intrusion zones/points, areas, and annunciators that are part of the intrusion system.

The P2000 system supports three intrusion detection integrations: OPC Aritech, Bosch® (GV3 and GV4 series), and Mercury. Complete hardware installation and operation instructions are provided with the intrusion system that is shipped with your option.

Note: Mercury intrusion panels require both the P2000 Intrusion Interface Service and the P2000 Mercury Interface Service to communicate with the server.

IMPORTANT: The Aritech panel is not available in North America. Contact Johnson Controls Systems Integration Services Europe for information.

Areas are used to control zones and can be commanded to be armed or disarmed. An authorized user at a P2000 workstation can arm or disarm an area, bypass a zone, and silence or activate an annunciator, assuming that the user has the appropriate authorization.

When an Aritech area is armed or disarmed, it causes all associated zones to become armed or disarmed (or if armed, possibly alarmed). Aritech Areas are objects that are used to control zones. Zones maintain state and can be in states such as bypassed or alarmed.

A properly configured intrusion detection system should:

- Detect an unlawful intrusion
- Identify the location of the intrusion
- Signal an alarm to inform local security forces that an intrusion has been detected
- Signal intruders that they have been detected

Basic Definitions

Annunciator – (Not supported by Mercury) An annunciator is any electrical device connected to an Aritech or Bosch output point, which is activated when an intrusion is detected (for example, a siren). An annunciator can be silenced or activated manually. **Area** – A group of zones/points within a facility (for example, the perimeter, the main entrance, the entire facility).

Armed – (Aritech and Mercury) The state of a zone that reports intrusions unless it is bypassed. When an area is armed or disarmed, it arms or disarms all associated zones.

Armed – (Bosch) The state of an area that reports intrusions.

Bypassed – The state of a zone/point that does not report intrusions. This state is intended for maintenance use. If a zone is bypassed an intrusion is not detected nor sent to the P2000 Server.

Disarmed – The state of a zone/point that is disabled from reporting intrusion alarms. This state is typically used during hours when zones are occupied.

Intrusion – An unauthorized entry to an area or zone that results in an alarm state for the area or zone.

Intrusion Input Point – A device used to detect a change in a facility. A point senses an event that could represent intrusion such as a glass break, motion or door contact.

Intrusion Interface – TCP/IP, RS232C, or OPC that is used to communicate with one or more intrusion servers.

Intrusion Server – A physical device or software component that controls one or more intrusion zones or areas.

Zone – A collection of one or more input points (or Mercury readers) that are used to monitor a particular zone within the facility.

Sequence of Steps

The following sequence of steps are involved in the process of configuring, controlling, and monitoring intrusion components:

- Create and assign menu permissions to perform Intrusion Configuration and Control functions; see page 21.
- Enable the intrusion server (Aritech only); see page 333.
- Configure the Bosch intrusion panel; see page 334.
- Configure Mercury intrusion components and alarms; see page 337.
- Configure alarm options for Aritech and Bosch intrusion devices. This allows you to view intrusion-related alarms on the P2000 Alarm Monitor and act accordingly, such as acknowledging the alarm; see page 340.
- Issue commands to control intrusion components; see page 342.
- View and monitor intrusion activity from the Real Time List and Real Time Map as they occur; see page 344.
- Control, monitor, and display the status of intrusion devices, areas, zones, and annunciators; see page 344.
- Define event triggers and actions associated with intrusion devices, areas, zones, and annunciators; see page 345.

Intrusion Configuration

The intrusion detection system consists of the P2000 software, the panel firmware (OPC Aritech, Bosch, or Mercury), and I/O modules (attached to sensors and annunciators). Use the instructions provided with your intrusion hardware to define your intrusion system, such as the number and type of sensors, number of annunciators required, how these input and output devices are associated with zones/points, and how zones/points are included within areas.

The following sections describe intrusion configuration and operation procedures using the P2000 software.

OPC Aritech Intrusion Interface

This interface controls the Intrusion OPC Server, which connects to Aritech devices to control intrusion zones, areas, and annunciators. The P2000 Intrusion Service connects to a single Intrusion OPC Server to support multiple intrusion devices.

Once you use the instructions provided with your Aritech panel to configure your intrusion panel and associated items, you must enable the intrusion server in the P2000 System Configuration window to populate the associated data into the P2000 database.

Note: Requires OPC Server Version 2.7.

To Enable the Aritech Intrusion Server:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand Intrusion.
- 3. Select **Intrusion Server** and click **Add**. The Intrusion Server Config dialog box opens.

C Intrusion Server (Config			×
Name	jcidemo1		🔽 Enable	
	OK	Cancel		

- 4. Verify that the Aritech intrusion server name displays in the **Name** field.
- 5. Click Enable.
- 6. Click OK.

Once you enable the Aritech intrusion server, the System Configuration window is automatically populated with the intrusion device and associated intrusion areas, zones, and annunciators.



The P2000 system is now ready to operate with the Aritech intrusion panel, continue with Intrusion Alarms on page 340.

OPC Tags

The P2000 Intrusion Service obtains status information by monitoring the OPC tags defined within the Intrusion OPC Server and issue commands by writing values to the appropriate OPC tags.

The following table displays nine tags that are associated with the OPC Aritech panel, including the corresponding value for each of the tags. You must set up the panel correctly to communicate with the P2000 system to achieve these values.

Tag Number	Description	Value
1	Connected	True
2	InvalidVendorAddress	False
3	PortOpened	True
4	MainsFailure	False
5	BatteryLow	False
6	BatteryTest	False
7	BatteryTestFail	False
8	BatteryMissing	False
9	Tamper	False

Be aware that under certain conditions, the P2000 system may indicate that the Aritech panel is in fault status, but the overall operation of the Aritech interface is normal. For example: If tags 2, 4, and 5 are set with a value of True, it indicates that:

2 = vendor address format is incorrect

- 4 = Aritech panel is working in battery mode
- 5 = battery charge is low

Under these conditions, the Aritech panel is still operational because:

Tag 2: Vendor Address is invalid – Even if the address format is invalid, maybe that default values are already correct. If the panel address is equal to 1 and the password is set to the default value 0000000000, the Aritech panel still communicates with OPC Server; therefore, the invalid address fault is displayed but ignored. Also, note that each field (Address, Password, and System) is independent from others. For example, if the Password field is correct and the Address field is incorrect, the driver successfully parses the password value and returns the *InvalidVendorAddress* condition because the Address is wrong (but it sets the Address to the default value 1).

Tag 4: Mains failure – This means that the Aritech panel is working in battery mode, but it stays online while the battery works.

Tag 5: Battery charge is Low – In this case the Aritech panel is working with a battery in low condition, but not yet exhausted. So, it communicates until power is present.

Bosch Intrusion Interface

This integration allows P2000 operators to configure and control Bosch intrusion devices. The intrusion system may have multiple, independent Bosch intrusion panels, and each Bosch intrusion panel can support multiple intrusion areas/zones. Before you configure your Bosch intrusion panels, ensure that the following settings are in place to establish the communication between the P2000 Server and the Bosch intrusion panel:

- You should modify some parameters using Bosch Remote Programming Software (RPS) to program the panel.
 - 1. Verify that under the AUXPARM settings, the SDI RPS Automation is enabled. This enables the third-party communication for the panel.
 - 2. If you use GV4 panels, set the Automation device under AUXPARM to the appropriate address based on the network interface connection.
 - 3. To be fully compatible with the P2000 system, you should verify that under the **POINTS** section, the point indexes have the parameters listed as follows:

a. Bypassable (enables bypassing from the Third party automation) : -	Yes
b. Defer Bypass Report : -	No
c. Alarm Abort :-	No

• The Bosch intrusion integration uses the TCP/IP protocol to communicate between the Bosch panel and the P2000 Server; therefore, you must establish the availability of Conettix DX4020 or B420 network interface. This is provided by Bosch to connect with the Bosch panel via a TCP/IP protocol.

DX4020 Configuration Rules (GV3 and GV4 Panels)

 After setting up the DX4020 module based on the instructions provided by Bosch, change the dip switch address on the network interface module to reflect address 80 to connect to the P2000 system.

- 2. Telnet into the network module via the command *Telnet <ip address> 9999* and change the channel 1 settings.
 - a. Set Connectmode to c0 for P2000/third party automation.
 - b. Do not change any other settings and press <**Return**> to leave the default settings.

	Send '+++' in Modem Mode (Y) ?
	Auto increment source port (N) ?
ĺ	Remote IP Address : (000) .(000) .(000) .(000)
ĺ	Remote Port (0) ?
ĺ	DisConnMode (02) ?
ĺ	FlushMode (00) ?
ľ	DisConnTime (00:00) ?:

B420 Configuration Rules (GV3 Panels)

For RPS:

- 1. Set the physical switch address on the B420 to **4**.
- 2. Set Automation TCP Enable to No.

For Automation (P2000 Integration):

- 1. Set the physical switch address on the B420 to **3**.
- 2. Set Automation TCP Enable to Yes.

B420 Configuration Rules (GV4 Panels)

For RPS:

- 1. Set the physical switch address on the B420 to 4, or 2 or 1. Use this value to set the panel address using the AUXPARM settings.
- 2. Set Automation TCP Enable to No.

For Automation (P2000 Integration):

- 1. Set the physical switch address on the B420 to **3**, or **2**, or **1**.
- 2. Set Automation TCP Enable to Yes.

After you define the previous settings and configure your intrusion devices using the instructions provided with your Bosch panel, you must define the Bosch panel using the P2000 software.

To Configure the Bosch Intrusion Panel:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand Intrusion.
- 3. Select **Bosch Intrusion** and click **Add**. The Bosch Intrusion Panel Edit dialog box opens.

C Bosch Intrusion Panel Edit	x
Partition	Super User Vellic
Name:	Lobby Detection
IP Address:	200 . 0 . 0 . 5
Port Number:	7700 Panel Type GV4
Query String:	
	Read Configuration
	Resend All Events
	OK Cancel Apply

- 4. If you use Partitioning, select the **Partition** that has access to this panel, and click **Public** if you wish to allow all partitions to see the panel.
- 5. Enter a descriptive Name for the panel.
- 6. Enter the **IP** Address of the intrusion panel.

- 7. Enter the **Port Number** of the intrusion panel. This value must be 7700.
- 8. Select the Panel Type.
- 9. Enter the **Query String** value to be used with message filtering (see Define Query String Filters on page 240).
- 10. The **Read Configuration** button is provided to refresh the configuration in this panel with information from the Bosch panel. This button is only available after the panel has come online. You must use this function to read the panel configuration after changes are downloaded to the Bosch panel using the hardware configuration tool (RPS for example), provided by Bosch.
- 11. Click Resend All Events if you wish to re-download all event data stored at the Bosch panel. Use this function <u>only</u> if the Bosch panel was not functioning properly and you replaced your hardware or upgraded your firmware.
- 12. Click **OK** to save your settings.

After you save the Bosch intrusion panel, within a few minutes the System Configuration window is automatically populated with the associated intrusion areas, zones, and annunciators that were configured using the Bosch user interface.



Mercury Intrusion Interface

The Mercury Intrusion integration allows P2000 operators to configure and control Mercury intrusion devices. A Mercury intrusion system may have multiple, independent Mercury intrusion panels, and each Mercury intrusion panel supports multiple intrusion areas, zones, and keypads.

To configure Mercury Intrusion, first create the zones, then configure the areas, adding the appropriate zones to the appropriate areas.

Before you can configure Mercury Intrusion areas and zones, ensure that your Mercury hardware (panels, terminals, and input points), are properly configured using the P2000 system; see Configure Mercury Panels and Components on page 179 for details.

Configuring Mercury Intrusion Zones

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand **Mercury Panels** to display all Mercury panels configured in the system.
- 4. Expand the panel for which you wish to configure an intrusion zone.
- Select Intrusion Zone and click Add. The Mercury Intrusion Zone Edit dialog box opens at the General tab. Enter the information in each tab according to your system requirements. See the following Mercury Intrusion Zone Field Definitions for detailed information.
- 6. As you work through the tabs, click **Apply** to save your settings.
- 7. When all entries are complete, click **OK** to save the intrusion zone information.

Note: If you delete an intrusion zone that was the only zone associated with an intrusion area, then you need to associate the intrusion area with a new intrusion zone or you may have to delete the intrusion area. If you do not perform these steps, then you must perform at a convenient time, a full download to the affected panel with the **Reset Panel Before Download** flag selected.

Mercury Intrusion Zone Field Definitions

General Tab

G Mercury Intrusion Zone Edit			×
General Mercury Alarm Options	1		
Partition:	Super User		
Zone Name:	Warehouse Lobby		
' I	Enabled		
Query String:			
Zone Number:	1		
	ОК	Cancel	Apply

Partition – Select the partition that has access to this intrusion zone.

Public – Click Public to allow all partitions to see this intrusion zone.

Zone Name – Enter a descriptive name for the zone.

Enabled – This check box controls whether or not the zone is enabled. The default is enabled.

Query String – This value is used with message filtering; see Define Query String Filters on page 240.

Zone Number – Select a number for the zone. Each zone must have a unique zone number.

Mercury Tab

Mercur	ry Intrusion Zon	: Edit	
Seneral	Mercury Alarm (ptions	
	Intrusion Area:	<none></none>	
	Point Type:	Input Point	
	Input Point	Motion Sensor	
	Reader Terminal	<none></none>	
	Processor Rule	24 Hour Zone	
	Delay Trigger	No delay	
		□ Bypassed	
		Chime Flag	
		OK Cancel	Apply

Intrusion Area – Displays the intrusion area name to which the zone is assigned. This field displays **<none>** until you assign the zone to an intrusion area.

Point Type – Select **Input Point** if you are configuring the zone with an input point or **Reader Terminal** if you are configuring the zone with a reader terminal.

Input Point – If the Point Type is Input Point, select the input point that has been designed to detect a change in your facility, this could be a glass break sensor or door contact.

Reader Terminal – If the Point Type is Reader Terminal, select the reader terminal that has been designed to monitor a particular zone.

Processor Rule – This field defines the zone type. Select:

- 24 Hour Zone if the zone alarms are triggered at any time (the zone is always monitored).
- Interior Zone if the zone is only monitored when the associated intrusion area is armed.

Delay Trigger – This field defines the entry delay trigger type. Select:

• No delay – if the zone is not affected by an entry delay.

- **Trigger** if activating the zone triggers an entry delay.
- Follow if the zone follows a trigger during an entry delay. This zone may be active during an entry delay.

Bypassed – Click to set the zone to be bypassed. The zone stays bypassed until the intrusion area's status changes to disarmed.

Chime Flag – Click if you want to allow the keyboard chime to be activated, when appropriate, on an MRDT keypad.

Alarm Options

G Mercury Intrusion Zone Edit	×
General Mercury Alarm Options	
Select Alarm Categories	
P2000	Edit
Add Dalata	
OK Calca	Appiy

Alarm options are described in detail on page 91.

Configuring Mercury Intrusion Areas

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Expand **Panels** to display the panel types.
- 3. Expand **Mercury Panels** to display all Mercury panels configured in the system.
- 4. Expand the panel for which you wish to configure an intrusion area.

- 5. Select Intrusion Area and click Add. The Mercury Intrusion Area Edit dialog box opens at the General tab. Enter the information in each tab according to your system requirements. See the following Mercury Intrusion Area Field Definitions for detailed information.
- 6. As you work through the tabs, click **Apply** to save your settings.
- 7. When all entries are complete, click **OK** to save the intrusion area information.

Note: If you wish to delete an intrusion area, you must first delete it from the System Configuration window, then you must perform at a convenient time, a full download to the affected panel with the **Reset Panel Before Download** flag selected; see page 464 for details.

Mercury Intrusion Area Field Definitions

Public

General Tab

eral Mercury Zones Alarm Options

umber: 1

Partition: Super User

Partition – Select the partition that has	access
to this intrusion area.	

Cancel Apply

Public – Click Public to allow all partitions to see this intrusion area.

Name – Enter a descriptive name for the area.

Query String – This value is used with message filtering; see Define Query String Filters on page 240.

Number – Select a number for the area. Each area must have a unique area number.

Mercury Tab

Monitor					
Defau	ilt Status Disar	med	•		
Entry Del	av 60		Auto Disarr	n 🔽	
Exit Del	ay 60	seconds	Skip Alarm Cance d Not Ready to Arr	н Г п Г	

Default Status – Select Disarmed or Armed as the default status for the intrusion area.

Entry Delay – Enter the number of seconds from 0 to 32767 (default is 60) that alarms are suppressed after someone enters the intrusion area.

Exit Delay – Enter the number of seconds from 0 to 32767 (default is 60) that alarms are suppressed after the intrusion area is armed.

Auto Disarm – When selected, the intrusion area is automatically disarmed when access to the area is granted via an access control reader. This applies only to the default intrusion area, the intrusion area defined as number 1.

Skip Alarm Cancel – This option is selected by default and cannot be modified. It allows an area to go directly from Disarmed to Armed or from Armed to Disarmed, as appropriate.

Report Disarmed Not Ready to Arm – This option is not selected by default and cannot be modified. The intrusion area does not report when it is not ready to be armed.

Zones Tab

Mercury Intrusion Area Edit		l l
General Mercury Zones Alarm Options		
Selected Zones	Available Zones	
Paric Zone Warehouse Lobby	<cc >>></cc 	
	,	
	ОК	Cancel Apply

To make an intrusion zone part of an intrusion area, select it in the **Available Zones** section and click << to move it to the **Selected Zones** section.

Alarm Options Tab

C Mercury Intrusion Area Edit General Mercury Zones Alarm Options	×
Alarm Options Select Alarm Categories	
P2000	Edit
Add Delete	
	OK Cancel Apply

Alarm options are described in detail on page 91.

Intrusion Alarms

Intrusion components that generate alarms must belong to at least one alarm category, and must provide their own set of alarm options and parameters to define how the alarms behave when activated, whether or not they need to be acknowledged, at what time an alarm can be activated, and other alarm settings that provide the flexibility of automating the alarm operation. **Note:** To configure Mercury intrusion zone alarms, see Configuring Mercury Intrusion Zones on page 337. To configure Mercury intrusion area alarms, see Configuring Mercury Intrusion Areas on page 338.

To Configure Aritech Intrusion Alarms:

- 1. In the System Configuration window, expand **Intrusion**.
- 2. Expand **Intrusion Server** to display all Aritech intrusion components.
- 3. Select an Intrusion component (Device, Area, Zone, or Annunciator). Click Edit.



4. The Intrusion Config dialog box opens for the selected item (Device, Area, Zone or Annunciator).

C Intrusion Area Config				×
Partition: Query String:	Super User	*	I⊽ Public	
Alarm Options				
Select Alarm Categories				_
				Add
				Edit
				Delete
	OK.		Cancel	
- If you are configuring alarm options for an Intrusion Device, select from the **Partition** drop-down list, the appropriate Partition that has access to the Intrusion Device. Partition selection is only available at the Intrusion Device level.
- 6. Click **Public** if you wish the Device, Area, Zone, or Annunciator to be visible to all partitions.
- 7. Specify the **Query String** value to be used with message filtering.
- Click Add to assign this alarm to one or more Alarm Categories. The Add Alarm Categories dialog box opens displaying all previously created alarm categories (see page 285 for details).

Add Alarm Categories - Intrusion Area Config	×
Select Alarm Categories P2000 P2000Maintenance P2000Maintenance P2000MaintenanceBuilding 2 P2000Security P200Security P200S	Add <u>C</u> ancel

Note: If you use the Enterprise feature, the Alarm Categories defined for all P2000 sites within an Enterprise system are listed.

- Select one or more categories and click Add. The list displays all the selected alarm categories.
- If you wish to remove a category from the list, select the alarm category and click Delete.
- 11. Once you have all the alarm categories you want to assign to this alarm, select an alarm category from the list and click Edit to edit the alarm options. You can select and edit more than one category at a time. The Alarm Options dialog box opens displaying the General tab. See the definitions provided on page 91.

To Configure Bosch Intrusion Alarms:

- 1. In the System Configuration window, expand **Intrusion**.
- 2. Expand **Bosch Intrusion** to display all Bosch intrusion panels.
- 3. Select the intrusion area you wish to configure and click **Edit**. The Bosch Intrusion Area Edit dialog box opens.

Bosch Intrusion A	rea Edit				
	Partition Super L Name: Area 1	Jser	•	I⊄ Publi <u>c</u>	
	Query String:				
Select Alarm Categ	ories				
					dt
	Add	Delete			
		ОК	Cancel	Apply	

Note: You can only configure alarms that are associated with Bosch Intrusion Areas.

- 4. Select from the **Partition** drop-down list, the appropriate Partition that has access to the Bosch Intrusion Area.
- 5. Click **Public** if you wish the area to be visible to all partitions.
- 6. If you wish, edit the **Name** of the Bosch Intrusion Area alarm.
- 7. Specify the **Query String** value to be used with message filtering.
- Click Add to assign this alarm to one or more Alarm Categories. The Add Alarm Categories dialog box opens displaying all previously created alarm categories (see page 285 for details).



Note: If you use the Enterprise feature, the Alarm Categories defined for all P2000 sites within an Enterprise system are listed.

- Select one or more categories and click Add. The list displays all the selected alarm categories.
- If you wish to remove a category from the list, select the alarm category and click Delete.
- 11. Once you have all the alarm categories you want to assign to this alarm, select an alarm category from the list and click Edit to edit the alarm options. You can select and edit more than one category at a time. The Alarm Options dialog box opens displaying the General tab. See the definitions provided on page 91.

Intrusion Management

Management of intrusion includes displaying the current state of intrusion items as well as issuing commands for such activities (arm, disarm, bypass, and so on). The following sections describe how to monitor and control intrusion items.

Controlling Intrusion Items Using the Intrusion Control Window

Use the Intrusion Control window to perform commands for areas, zones/points, and annunciators. It allows operators to arm and disarm areas; reset, bypass, and make any zones/points operational; and silence or activate any annunciator.

To Control Intrusion Items:

 From the P2000 Main menu select Control>Intrusion. The Intrusion Control dialog box opens.

	Device <all></all>		
eas Zones/Points Annunciato	x]		
Available Areas Area 2		Selected Areas Area 1	
Area 3 Area 4 Area 5 Area 6			Arm
Area 7		>>	Earond Am
		<<	Disam

- 2. Select the **Device** (Aritech, Bosch, or Mercury panel) name you wish to control.
- 3. If you wish to control an intrusion area, click the **Areas** tab. From the list of **Available Areas** at the left side of the window, select the area you wish to control.
- 4. Click the >> button to move the selected area to the Selected Areas box. You can add as many areas as you wish. Once you have the selected areas, click the function button on the right side of the window to perform the associated operation. The choices are:

Arm - (Aritech) Arms the selected Aritech areas if at the time that you issue the command the area's state permits it.

Arm – (Bosch and Mercury) Arms the selected areas with a pre-configured delay. For Bosch panels, this function is executed by the Bosch panel whether or not points are secured.

Forced Arm – (Aritech) Arms the selected Aritech areas regardless of the area's state at the time when you issue the command.

Forced Arm – (Bosch) Arms the selected Bosch areas immediately. This function is executed by the Bosch panel whether or not points are secured.

Note: Forced Armed is not supported by Mercury panels.

Disarm – (Aritech, Bosch, and Mercury) Disarms the selected areas.

Note: When a Mercury intrusion area is disarmed, and some zones were faulted but are now normal, the area still remains in the alarmed state. To get the area back to the normal state, you must disarm the area from the MRDT keypad terminal or from the Intrusion Control window.

5. If you wish to control an intrusion zone, click the **Zones/Points** tab. From the list of **Available Zones/Points** at the left side of the window, select the zone/point you wish to control.

C Intrusion Control			
Intrusion Control Areas: Zones/Ponts Arrundator Available Zones/Ponts Verdable Zones/Ponts Par FOLLOW PontsTwit PontsTwit PontsTwit PontsTwit PontsTwit PontsTwit PontsTwit	Device <all></all>	Selected Zones/Points P2 PAUC 20 Control Contr	Bypass On
		<u>e</u>	Bypass Off Reset ResetAck

6. Click the >> button to move the selected zone to the Selected Zones/Points box. You can add as many zones as you wish. Once you have the selected zones, click the function button on the right side of the window to perform the associated operation. The choices are:

Bypass On – Commands the selected zones/points to be bypassed.

Bypass Off – Turns off bypassing of the selected zones/points.

Reset – (Not supported by Bosch or Mercury). Resets the state of the selected zones. If you issue this command while the input point is still in alarm because of still being unsealed, you must seal the input and send this command again to reset it.

ResetAck – (Not supported by Bosch or Mercury). Resets the state of the selected zones. If you issue this command while the input point is still in alarm because of still being unsealed, there is no need to re-send the command after the input is sealed. The command remains valid and reset the zones as soon as the input seals.

7. If you wish to control an intrusion annunciator, click the **Annunciator** tab. From the list of **Available Annunciators** at the left side of the window, select the annunciator you wish to control. Not supported by Mercury.



8. Click the >> button to move the selected annunciator to the Selected Annunciators box. You can add as many annunciators as you wish. Once you have the selected annunciators, click the function button on the right side of the window to perform the associated operation. The choices are:

Silence – Silences the selected annunciators.

Activate – Activates the selected annunciators.

9. When you finish controlling the intrusion items, close the Intrusion Control dialog box.

Viewing Intrusion Transactions Using the Real Time List

All intrusion detection transactions are sent through real time messages to the Real Time List. As the status of defined areas, zones, and annunciators changes, corresponding related messages are generated and displayed. You must select the **Intrusion** check box in the Real Time List window to display all intrusion transactions as they occur. See Using the Real Time List on page 356 for more information.

Note: If you wish to print intrusion transactions as they occur, you can either print them from the Real Time List window, or select the Intrusion check box in the Site Parameters dialog box, Printing tab; see page 35.

Monitoring Intrusion Using the Real Time Map

Use the Real Time Map to display the status of intrusion areas, zones/points, annunciators, and intrusion devices on a map layout of your facility. Upon intrusion activity, the map shows the state change and the exact location of the activity. See Using the Real Time Map on page 360.

When a status changes, the associated intrusion icon may start flashing. You can right-click the icon to open a shortcut menu and choose to, for example, arm or disarm an intrusion area or bypass an intrusion zone/point. If the intrusion component was configured to allow the operator to activate events, the event name also displays in the shortcut menu.

To add intrusion icons to the Real Time Map, follow the instructions provided in Creating a Real Time Map on page 362.

Map Maker provides a default intrusion image set to display various intrusion states. However, you can use your own icons to create custom image sets. See Adding Image Sets on page 366 for details.

Viewing and Controlling Intrusion Items Using the System Status Window

The System Status window displays the status of intrusion components that are configured to monitor intrusion detection. It also allows you to issue the commands, depending on the state of the following intrusion component:

Intrusion Areas – The system displays the status of all intrusion areas associated with the selected intrusion panel. You can issue commands for the area by right-clicking the associated status icon. The following commands may be available, depending on the current state of the area:

- Arm (Aritech) Arms the selected Aritech area if at the time that you issue the command the area's state permits it.
- Arm (Bosch and Mercury) Arms the selected area with a pre-configured delay. For Bosch panels, this function is executed by the Bosch panel whether or not points are secured.

- Forced Arm (Aritech) Arms the selected Aritech area regardless of the area's state at the time when you issue the command.
- Forced Arm (Bosch) Arms the selected Bosch area immediately. This function is executed by the Bosch panel whether or not points are secured.

Note: Forced Armed is not supported by Mercury panels.

• **Disarm** – (Aritech, Bosch, and Mercury) Disarms the selected area.

Intrusion Zones – The system displays the status of all intrusion zones associated with the selected intrusion panel. You can issue commands for the zone by right-clicking the associated status icon. The following commands may be available, depending on the current state of the zone:

- **Bypass On** Commands the selected zone to be bypassed.
- **Bypass Off** Turns off bypassing of the selected zone.
- **Reset** (Not supported by Bosch or Mercury) Resets the state of the selected zone. If you issue this command while the input point is still in alarm because of still being unsealed, you must seal the input and send this command again to reset it.
- ResetAck (Not supported by Bosch or Mercury) Resets the state of the selected zone. If you issue this command while the input point is still in alarm because of still being unsealed, there is no need to re-send the command after the input is sealed. The command remains valid and reset the zone as soon as the input seals.

Intrusion Annunciators – (Not supported by Mercury) The system displays the status of all intrusion annunciators associated with the selected intrusion panel. You can issue commands for the annunciator by right- clicking the associated status icon. The following commands may be available, depending on the current state of the annunciator:

- Activate Activates the selected annunciator.
- **Deactivate** Deactivates the selected annunciator.

See Viewing System Status on page 473 for instructions on how to display intrusion status and issue commands.

Intrusion Events

The intrusion detection system hardware connected to the P2000 system can trigger events and respond to event actions using the P2000 Event application. For specific instructions, see Creating Events on page 349. Typical intrusion commands to be included and linked to specific actions are as follows:

- An armed intrusion zone (trigger) forces the door override to be cancelled (action).
- An access grant command (trigger) disables intrusion for a fixed time (action).
- An access denied message generated by the panel (trigger) bypasses or arms an intrusion zone or area (action).
- A particular badge that is granted access (trigger) silences an intrusion annunciator (action).

For a complete list of event triggers and actions associated with intrusion devices, areas, zones, and annunciators, see Appendix A: Event Triggers/Actions.

Hours On Site

This feature allows you to record a cardholder's accumulated number of hours present at a site. The Hours On Site application is used exclusively for tracking and reporting purposes and works by recording the cardholder's time interval between an <u>in</u> badging and <u>out</u> badging at reader terminals that are defined to monitor Hours on Site.

Time is accrued only from the latest in and out badging. For example, when a cardholder badges at a reader defined as an *Entry Terminal*, the cardholder's time is accrued. If the same cardholder badges at the same or other Entry Terminal, the first badging is ignored and the time is accrued from the latest badging. The reverse is true for an *Exit Terminal*. Hours On Site accurately reports hours present between matched pairs of in and out badgings (that is, an in badging followed by an out badging, with no other badgings in between).

Configuring Hours On Site Zones

Before you initiate data collection, you must define the readers that provide real time information to track a cardholder's time spent at a particular area. Use readers that are related to a particular section of your facility. For example, you may want to select readers located at the entrance of a production facility that provide for the <u>in</u> hours, and select readers located at the exit of the facility that can be used for the purpose of reporting the <u>out</u> hours.

The Hours On Site feature does not determine where and when cardholders have access in and around a facility – there is no access control or transaction processing associated with this function, the terminals that are selected for this feature are defined for time tracking purposes only.

To Define Hours On Site Zones:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- Select Hours On Site Zones and click Add. The Hours On Site Zone dialog box opens.
- 3. If this is a partitioned system, select the **Partition** that has access to this Hours On Site zone, and click **Public** if you wish the Hours on Site zone to be visible to other partitions.

C Hours On Site Zone Partition Name	Super User		K
- Entry Terrinals Selected Lobby North Entrance	Avalable De20 Term Isonasi Reader South Enkrance Term I HD Test Term I HD Test Term I HD Test Term I ND Test Test Term I ND Test Term I ND Test Tes	Citx Terminals Selected South Enhance Term 1 Man Enhance	Available Doc20 Term Lobby Worth Enfrance Term : HID Security Term : HID Security Term 2 5321 IP Security
	OK	Cancel	

- 4. Enter a descriptive **Name** for the Hours On Site zone.
- 5. In the **Entry Terminals** box, select the terminals from the **Available** list that are used for Hours on Site *in* transactions. Cardholders should use any of these terminals when entering a facility or area within a facility, to start the accumulation of hours present.
- 6. In the **Exit Terminals** box, select the terminals from the **Available** list that are used for Hours on Site *out* transactions. Cardholders should only use any of these terminals when leaving a facility or area within a facility, to stop the accumulation of hours present.
- 7. Click **OK**. A new icon displays under the root Hours On Site Zones icon in the System Configuration window.

Hours On Site Reporting

You can run Hours On Site reports at any time to determine cardholders' current number of hours present at a specified area in a facility.

These reports display calculated attendance and are ready for evaluation and printing. You can also export these reports into a payroll or human resources system for further calculation.

Hours On Site reports are provided as a subset of the standard P2000 report set. This section describes details specific to Hours On Site reports. For detailed information on running reports, see Chapter 6: System Reports.

To Run Hours On Site Reports:

 From the P2000 Main menu, select Report>Run Report. The Run Report dialog box opens. Scroll down to the two Hours On Site reports provided and select one of the following:

Hours on Site – Lists a detailed report of a cardholder's accumulated number of hours present at a site.

Hours on Site - Simple – Lists a summary report of a cardholder's accumulated number of hours present at a site.

Regardless of your selection, the Hours On Site dialog box opens displaying filtering options.

lours On Site 🛛 🔀
Eirst Name
*
Last Name
*
T <u>e</u> rminal Zone:
*
C <u>a</u> rdholder Type:
All
Date
<u>B</u> egin: 8/23/2009 ▼
<u>E</u> nd: 8/24/2009 ▼
OK Cancel

- 3. The default (*) reports all cardholders. Enter a **First Name** or **Last Name** to limit the report to a specific cardholder.
- 4. Select the **Terminal Zone** that contains the readers that were defined to track hours on site; or select the (*) to report on all defined terminal zones.

- 5. From the **Cardholder Type** drop-down list, select whether you want to report on Regular cardholders, Visitors, or All.
- 6. Select a **Begin** and **End** date for the transactions you wish to see. Only records within these dates are listed in the report.
- Click OK. Select a printer name and any other information for the printer to be used. See your system administrator if you need more information, or refer to your Microsoft Windows documentation.
- 8. Click **OK**. The Hours On Site report displays in the Crystal preview window. The top section of the report displays information according to the filtering options that you selected in the Hours On Site dialog box. You can use the arrows at the top of the window to scroll forward and back through the pages; resize the window for the best display, and export or print all or single pages of the report.

Hours On Site (Detail) Report

This report provides detail cardholder activity based on your selected search criteria. The report displays the cardholder name, badge number used, specific terminal name where the badge was presented, the terminal zone that contains the specified terminal, and the in and out date and time when the cardholder badged at the terminal. In addition, this report also displays the total number of hours on site per day, per badge, and for the entire report.

This information is updated each time the cardholder badges at the terminals included in Hours On Site zones.

Hours On Site Report Last Nam Kina. Cardholder Name: King, Jenny Hours on Site Details: 8/25/2009 Badge Number Terminal Name Terminal Zone In / Out Time In / Out 721A A225 T 8/25/2009 8:24:41AM CK721A_A225 T2 In - Out 00.00.1 8/25/2009 4/23/37Ph CK721A A225 T2 In - Out Hours: Total time for 8/25/2009: 07:59:13 Hours on Site Details: 8/26/2009 Badge Number Terminal Name Terminal Zone In / Out Time CK721A_A225 T1 8/28/2009 8:11:12AM CK721A_A225 T2 8/25/2009 4:07:58PM Total time for 8/26/2009: 07:56:46 Total Time for Badge 369 for 8/25/2009 to 8/26/2009: 15:55:59 Total Time for Entire Report: 15:55:59 * End of Report Page 1 of Hours On Site Report Iter: First Name = Jenny; Last Name = Kvon; Term Date Rance = #25/2009 through #26/2009

Note that records marked with an asterisk (*) indicate out of sequence in or out times. This occurs when:

- a cardholder badged more than once at designated <u>in</u> readers without badging at an <u>out</u> reader
- a cardholder badged more than once at designated <u>out</u> readers without badging at an <u>in</u> reader
- a cardholder badged <u>in</u> and no subsequent <u>out</u> badging occurred on that calendar day
- the first badging of the first day of the report is an <u>out</u>
- the last badging of the last day of the report is an <u>in</u>.

The asterisk could also indicate that the report might be displaying incomplete badging information, depending on what time of day and date the report is run.

Hours On Site - Simple Report

This summary report is run using the same Run Report criteria as the detailed report. The difference between this report and the detailed report is that the Simple report only shows total times for each cardholder, not badging time details.

	riours on one report - omple	
Report Filter: First Name: Last Name: Terminal Zone: Date Range: Cardholder Type:	Form 8/25/2009 tracyn 8/25/2009 Al	
Cardholder Name:	DAM, TIEN Badge Number: 6	
Total time for 8/	25/2009: 16:23:29 *	
Total time for 8/	26/2009: 07:56:30	
Total Time for B	adge 6 for 8/25/2009 to 8/26/2009: 24:19:59 *	
Cardholder Name:	Kwon, Jenny Badge Number: 369	
Total time for 8/	25/2009: 07:59:13 *	
Total time for 8/	26/2009: 07:56:46	
Total time for 8/	26/2009: 07:56:46 adge 369 for 8/25/2009 to 8/26/2009: 15:55:59 *	
Total time for 8/	28/2009: 07:56:46 adge 389 for 8/25/2009 to 8/26/2009: 16:56:59 * Entire Report: 40:15:58 * End of Report	
Total time for 8/	28/2009: 07:56:46 adge 359 for 8/28/2009 to 8/28/2009: 15:56:59 * Entire Report: 40:15:58 * End of Report	
Total time for 8/	28/2009: 07:56:46 adge 389 for 8/28/2009 to 8/28/2009: 15:55:59 * Entire Report: 40:15:58 * End of Report	
Total time for 8/	28/2009: 07:56:46 adge 369 for 8/28/2009 to 8/26/2009: 15:55:59 * Entire Report: 40:15:58 * End of Report	
Total time for 8/	28/2009: 07:56:46 adge 369 for 8/28/2009 to 8/26/2009: 15:55:59 * Entire Report: 40:15:58 * End of Report	

Creating Events

Events are system actions that you can program to occur automatically. Events can be triggered by the system or card activated. An event consists of a trigger and an action. For example, you can program an event that increments a counter (the action) when a cardholder badges at a specific reader (the trigger).

Using Event Configuration Dialog Boxes

Event configuration dialog boxes change appearance, depending on the category selected; some category selections present more fields on a dialog box than others. The following sections present general instructions and examples for creating triggers and actions; however, not every dialog box and field is illustrated. For a complete list of all available categories and associated types and conditions, see Appendix A: Event Triggers/Actions.



System Events vs. Panel Card Events: System and card-activated events, as created via the P2000 Main menu Events feature, create system-wide events initiated from

APPLICATION NOTE

the Server. These events can be triggered from several sources including badges, panels, terminals, inputs, outputs, operators, and so on. Panel card events are created via the System Configuration window for a specific panel and operate independently from the system. If the system network goes down for any reason, the panel card events continue to operate, even while the panel is offline. For more information on Panel Card Events, see Create Panel Card Events on page 99.

Creating Triggers

Triggers determine what conditions must be met to initiate a specific action. The type, condition, logic, and value that can be assigned to the trigger are specific to the category selected. For example, when you select *Badge* as the category, specific event action types are available; when you select *Panel* as the category, a different set of event action types are available.

To Create Trigger Conditions:

 From the P2000 Main menu, select Events>Configure Events. The Configure Events list displays. All events currently configured for the system are listed.

1	Configure Events		_ 🗆 ×
	Partition Super L	lser 💌	
	Event	Partition	Public
	Event 1	Super User	No
	Badge 14321 Event	Super User	Yes
	Activate Lights	Warehouse	No
	Done Add	<u>Edit</u>	lete

 Click Add. The Configure Events – Add dialog box opens.

igure Event	s - Add						
	Partition	Super User		•	Public		
	Name	Badge Event			Allow Mar	nual Trigger	
	Active	Night Shift		-	Trigger Logic	• OR	
		Enable		_		C AND	
riggers							
Category	Туре		Condition	Logic			Value
Sadge	Host Gra	int	Badge	IS EQUI	al to		301
•1							
				1	. 1		
		Add	Eat		ete		
rtions							
Delay	Category	Type		Value 1		Value 2	
oolaj	corogor)	1,1,00		1990.1		10,00 6	
•1							
•1			0			J .	
•1	Add	E E	iit. Dele	ie		Down	
۱	Add	E .	ii: Dele	ic I	10 I	Down	

- 3. If this is a partitioned system, select the **Partition** in which this event is active and click **Public** if you wish this event to be visible to all partitions.
- 4. Enter a descriptive **Name** for the event. When the event is configured, this name displays in the Configure Events list, so make it meaningful to those who must work with it.
- 5. In the **Active** field, select from the drop-down list the **Time Zone** during which this event is active.
- Click Allow Manual Trigger to allow an operator to manually initiate this trigger. See Creating Manual Triggers on page 355 for detailed information.

7. In **Trigger Logic**, click either **AND** or **OR**. If more than one group of conditions have been created for this trigger and you wish all groups of conditions to be met to activate the trigger, click **AND**. If you wish any of the groups of conditions to trigger the action, click **OR**.

IIP: Event triggers with multiple **OR** conditions can be made more efficient by defining the most specific and most likely triggers first (that is, listed first in the trigger list). For example, Access Grant triggers should be defined before Counter triggers because Counters change less frequently than the system grants access. Triggers that check if certain items are members of groups (such as the granting terminal being in a specific access group) are very costly to process and should be last on the list, and therefore checked only when all other conditions are exhausted.

Note: It is possible to define a trigger (or set of triggers) that would always be true. When using a steady-state trigger, be sure to use the **AND** logic with another trigger that is not a steady-state trigger. Steady-state triggers are the status triggers for panels, terminals, input points, and output points.

8. Click Enable to enable the event.

Trie

9. In the **Triggers** box, click **Add**. The Trigger dialog box opens.

ger		×
Category	Badge	
Туре	Host Grant	
Condition	Badge 💌	
Logic	IS EQUAL TO	
Value	30	Select
	OK Cancel	

10. Enter the information in each field as described in the Trigger Field Definitions.

 When all information is completed, click OK to save the trigger conditions and return to the Configure Events dialog box. The new conditions are listed in the Triggers list.

Note: Event triggers that use steady-state conditions, which can be modified by other event actions such as Output Status and Host Counters, may not be triggered reliably when **AND** is used with other conditions. For example, creating two triggers that activate when a badge is presented at a door <u>and</u> a counter is set at a certain value, may fail if one of the actions changes the value of the counter.

Trigger Field Definitions

Category – Select a category from the drop-down list.

Type – Select a type from the drop-down list. The types available for selection are limited to those appropriate to the category selected.

Condition – Select a condition from the drop-down list. The conditions available are limited to those appropriate for the category and type selected.

Logic – Select the logic that applies to the condition from the drop-down list. The choices are: is equal to, is not equal to, is less than or equal to, is greater than or equal to, is less than, and is greater than.

Trigger		×
Category	Badge 💌	
Туре	Host Grant	
Condition	Badge 💌	
Logic	IS EQUAL TO	
Value	IS EQUAL TO IS NOT EQUAL TO IS LESS THAN OR EQUAL TO IS GREATER THAN OR EQUAL TO	Select
	IS LESS THAN IS GREATER THAN	
	OK. Cancel	

Value – Click **Select** to select a value that applies from the Select list. For example, if the category is *Badge* you could select *is less than or equal to* and select a badge number from the list to create the condition all badges less than or equal to a specific badge number.

In the previous example, we have created a trigger using the *Badge* category, with a type *Host Grant* that triggers an event action if the value (in this case, the badge number) is equal to 30.

To Edit a Trigger Condition:

- 1. From the Configure Events list, select an event and click **Edit**. The Configure Events dialog box opens, displaying the current settings for that event.
- 2. In the Triggers box, select the trigger you wish to change and click **Edit**. The Trigger dialog box opens.
- 3. Change the selections as appropriate and click **OK** to return to the Configure Events dialog box. The Triggers list reflects the changes.

Creating Actions

An Action, as defined in the Actions list at the bottom of the Configure Events dialog box, is performed by the system when the related trigger occurs. You can program a wide variety of event actions using the Category and Type fields provided in the Action dialog box. As with Triggers, the Action types available depend on the Category type selected.

An event can trigger more than one action. You can create several actions and specify in what order the actions occur.

To Create an Action:

1. In the Configure Events dialog box, go the Actions box at the bottom of the dialog box and click Add. The Action dialog box opens.

Action		
	Order 1 Delay (H:M:S) 00:02:30 *	
Category	Host	
Туре	Increment Counter	
Counter	Counter 3	
	[OK

- 2. Enter the information according to Event Actions Field Definitions.
- When all conditions are defined, click OK to return to the Configure Events dialog box. The new Action displays in the Actions list.

	Partition	Super User			-	✓ Public		
	Name	Badge Even	1		_	Allow Mar	ual Trigger	
	100mc						-	
	Active	Night Shift			-	Trigger Logic	© OR	
		🔽 Enable					C AND	
riggers								
Category	Туре			Condition	Logic			Value
Badge	Host Gra	nt		Badge	IS EQUA	IL TO		301
•[]	Add] [Edit	Dele	ste		
• [ļ	Add] [Edit	Dele	ete		
<	Category	Add Type] [Edit	Value 1	ste	Value 2	
<pre>ctions Delay [01:00:00</pre>	Category Host	Add Type Incremen] [Edit	Value 1 Lab Entranc	ste	Value 2	
ctions Delay 01:00:00	Category Host	Add Type Incremen] [Edit	Value 1 Lab Entranc	e Counter	Value 2	
<	Category Host	Add Type Increme] [Edit	Value 1 Lab Entranc	e Counter	Value 2	
<pre>ctions Delay Oi:00:00 </pre>	Category Host	Add Type Increment	l [Edit ter	Value 1 Lab Entranc	e Counter	Value 2	
ctions Delay O1:00:00	Category Host	Add Type Increment	l [Edit For	Value 1 Lab Entranc	e Counter	Value 2	
<pre>ctions Delay ol:00:00 </pre>	Category Host	Add Type Incremen	l [nt Court	Edit ter	Value 1 Lab Entranc	e Counter	Value 2	

4. Continue to add actions as required.

To Change Event Action Order of Occurrence:

1. From the Actions box at the bottom of the Configure Events dialog box, select an action line.

2. Click **Up** or **Down** at the bottom of the dialog box to move the line item as desired. The action displayed at the top of the list occurs first.

Event Actions Field Definitions

The available fields to define any Action are dependent on which category is selected. Because there are so many combinations of categories, types, and related selections, the following list of field definitions contains only a sampling of available fields. For a complete list of categories and related selections, see Appendix A: Event Triggers/Actions.

Order – If more than one action has been defined for this trigger, the order of the action displays in this field. For example, if the action selected is first in the Action list, this field displays 1.

Delay (H:M:S) – Select hour, minutes, and seconds from the spin box to enter a delay time after which the action occurs. This would be useful with an anti-passback action, for example.

Note: Delayed event actions should not contain macros. The information needed for the macros is not available when the action is delayed. Also, event actions that need information from a trigger cannot be delayed.

Category – Select a category from the drop-down list. The category selected determines what Action types are available.

Type – Select a type from the drop-down list. The type selected may add, remove, or change any additional fields available for definition. For example, when *Increment Counter* is selected as the Type for the Host Category, an additional field is created that lists the counters available. If *Display Message* is selected as the Type for the Host Category, additional fields are added from which to select the Instruction Text to be used and the workstation on which to display the message.

OPC Server Event Actions

IMPORTANT: Do not configure OPC Server Event actions before reading and understanding OPC Server. If OPC Server Event actions are not configured correctly, the equipment may not work properly.

The following applies to OPC (OLE for Process Control) Server events:

- If the computer on which the selected Server resides is switched OFF, then the event would have no effect.
- However, if the computer is ON and the OPC Server has been switched OFF, then the event would only be acted upon if the appropriate launch and access rights are granted.
- Similarly, if the computer and the OPC Server are running, then the event would only be acted upon if it has the correct access rights (that is, the sending user and password must be correctly set up at the receiving computer together with the correct DCOM rights). Note that the set up is correct when the software is installed. For more information, see Appendix F: DCOM Configuration.

To select an OPC Server and view the available tags, a tag browser is provided in the event Action dialog box. Note that to select an OPC Server, the OPC Server must be running and you must have the appropriate rights.

Action							×
	Order Delay (H:M:S)	1 00:00:00	÷				
Coloren	lang g	,					
Category	JOPC Server					•	
Туре	OPC Write					-	
OPC Tag							
Data Type	Integer					¥	_
Value	0						
				OK	Cancel		

- In the Action dialog box, click the Category drop-down list and select OPC Server.
- 2. From the **Type** drop-down list select OPC-Write.
- 3. To select an **OPC Tag** from those available for the selected OPC Server, click the [...] button. The Items dialog box opens.

ltems		×
ltem Name OPC Servers Browse items:	Filter.	
Data Type © Use native type © Bool	C Long C Double	
C String	C Short	

- Click the [...] button to locate the OPC Server, or select the Server from the OPC Servers drop-down list.
- 5. Select the **Data Type** (the default option is *Use native type*, which displays all tags).
- 6. In the Browse Items box, select the item and the tag for the event action.

The selected item displays in the **Item Name** field.

ems		
ltem Name	S0001.C0060.PatternBackward	
OPC Servers	\\C-794S301\JC.CCTV	
Browse items:	Filter: *	
C0055 C0055 C0055 C0055 C0055 C0060 C0061 C0062 C0063 C0063 C0064 A0001	GeneralString Ins Ins Ins InsAutomatic IsAvmed LensSpeed Upht Pan PatemParse	- - -
Data Type C Use native type C Bool C String	C Long C Double C Short	

 Click **OK** to enter the Item Name into the OPC Tag field in the Action dialog box. The computer name and Prog ID are prefixed to the item name.

Note: The Tag Browser can access the OPC Server only if the log on operator has the appropriate rights to the OPC Server (see Appendix F: DCOM Configuration).

- 8. Select the appropriate **Data Type** from the drop-down list for the event action value.
- 9. Enter the Value that is to apply to the OPC Tag.
- 10. Click **OK** to return to the Configure Events dialog box. The new event action displays in the Actions list.

Counting Events

You can create an unlimited number of counters for event programming, which increment or decrement each time a trigger occurs, depending on the category and type selected for the event. For example, you can create a badge swipe trigger for a specific badge and then create an action that increments Counter 1 each time the Server grants access to that badge. Then you can view the event counters list to monitor the action. Event counters accumulate value until they are reset.

To View Event Counters:

 From the P2000 Main menu, select Events>Event Counters. The Event Counters list displays.

1	Event Cou	nters		_ 🗆 ×
		Partition Sup	er User	•
	Counter	N	/alue	▲
	Counter 1)	
	Counter 2	()	
	Counter 3	()	
	Counter 4	()	
	Counter 5	()	
	Counter 6	1)	
	Counter 7	1)	
	Counter 8	()	
	Counter 9	()	
	Counter 10	()	
	Counter 11	()	
	Counter 12	()	
	Counter 13	l)	
	Counter 14	l)	
	Counter 15	l]	-1
ļ	Lounter 16	(J	
		(<u>D</u> on	e	

Event counters are listed under the Counter column. The Value column lists the accumulated number of events attached to each counter. You can add as many counters as you wish, or change the event counter name to give the counter a meaningful name; see the following section for detailed information.

2. Click **Done** to close the Event Counters dialog box.

To Add Event Counters:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Select **Counters** and click **Add**. The Counter Name Edit dialog box opens.

Counter Name E	dit	×
Partition	Super User 🔽 🗖 Public	
Name	New Event Counter	
[OK Cancel	

- If this is a partitioned system, select a Partition where the counter applies and click Public if you wish this counter to be visible to all partitions.
- 4. Enter a descriptive Name for the counter.
- 5. Click **OK**. The new counter displays beneath the main Counters icon.

To Reset Event Counters:

- From the P2000 Main menu, select System>Database Maintenance. Enter your password if prompted. The Database Maintenance dialog box opens.
- 2. Under Maintenance Action, select **Reset** Counters to Zero.
- 3. Click **Perform**. Since this action cannot be undone, a verification message displays to confirm your action.
- 4. Click **Yes** if you wish to reset counters to zero. The Reset Counters dialog box opens.

Reset Counters		×
	Partition Super User	
	Reset To Zero	
	Done	

- 5. If this is a partitioned system, select the **Partition** in which the counters are active.
- 6. Click **Reset to Zero**. All values in the Event Counters list are reset to zero.
- 7. Click **Done** to return to the Database Maintenance dialog box.
- 8. Click Exit.

Creating Manual Triggers

Triggers can be programmed to be activated manually by an operator. In this case, the Configure Events window is set to **Allow Manual Trigger** and linked to an action. The event is then initiated by the operator from the **Events>Trigger Manually** menu, rather than by trigger conditions set up in the Configure Events window.

Note: Events can also be manually initiated by an operator from the Alarm Monitor window (see page 292), as long as the item that generated the alarm was configured to activate events; or can also be manually initiated from the Real Time Map (see page 362), regardless if the **Allow Manual Trigger** option was enabled in the Configure Events dialog box.

To Manually Trigger an Event:

 From the P2000 Main menu, select Events>Trigger Manually. The Trigger Manually dialog box opens.

1	Trigger Manually				_ 🗆 X
		Partition	Super User	•	
	Event		Partition	Public	
	Event 1		Super User	No	
	Badge Event		Super User	Yes	Perform
					Done

- 2. All the events that have the *Allow Manual Trigger* option selected in the Configure Events window display in the list.
- 3. Select an event from the list, and click **Perform**. The trigger is activated.
- 4. Click **Done** to close the window.

Monitoring the System in Real Time

The Real Time List and Real Time Map are dynamic displays of system transactions and operations. The Real Time List is a time-stamped display of all (or specified) local or remote transactions as they occur. The Real Time Map displays the current status of local terminals, inputs, outputs, and other defined elements on a map layout of your site. The Real Time List and Real Time Maps are typically used by operators and system administrators not only to view current status, but as troubleshooting tools.

Using the Real Time List

The Real Time List is a time-stamped display of all system transactions as they occur. If desired, an operator can monitor only specific transaction types. For example, an operator concerned with learning when a cardholder is denied access can select only Access Deny to filter the information displayed. The Real Time List then displays only who, what, when, where, and why the access was denied.

You can open multiple windows of the Real Time List. For example, you could have one window open with all the types enabled. You could open a second window with only the Badge Trace option selected that would display only those transactions.

Note: A description of each transaction type is presented in the Printing tab of Site Parameters on page 35. The Printing function of Site Parameters operates independently from the Real Time List function.

A system administrator may want to look at the Real Time List as a *health check*; for example, to ensure all transaction types are being processed, or trace why a specific cardholder is being denied access.

Monitoring Remote Messages in Real Time

As with remote alarm monitoring (page 287), you can monitor transactions from multiple facilities at multiple geographical locations. Although each remote site administrator has total control over their access control hardware and system information related to their site, operators can control system and event information from different sites. This means that remote operators might, for example, monitor their transactions locally during normal working hours, while your local operators might monitor transactions messages generated at their remote sites after hours, as long as both the local and remote P2000 sites are set up and configured to receive and send transaction messages across P2000 sites during such periods.

With the proper configuration, an unlimited number of sites can be monitored simultaneously, allowing operators to administer multiple regions from a single site. To monitor remote messages, both your local and the remote sites have to be properly configured. The following conditions must be met:

- The Remote Message Service must be up and running at both the remote site (to send the transaction messages) and at your local site (to receive the transaction messages). See Starting and Stopping Service Control on page 470.
- The Message Filter Configuration application (page 238), must be properly configured at your local site and each remote site, to control the type of messages transmitted between Servers, thereby reducing network traffic by transmitting only messages that pass the filter criteria.

- The **P2000 Remote Server** application (page 245), must be properly configured at each remote site to send their transactions messages to your local site. The setup must include the name, IP address and Remote Message Service Listener Port number of your local site; the type of messages that can be forwarded to your site and at what times; and other related parameters.
- The **Process Received Remote Messages** option in the RMS tab of Site Parameters (page 44), must be selected at your local site to be able to receive messages from remote P2000 sites. If you select this option, the Remote Message Service processes incoming messages and passes them on to RTLRoute for distribution within the local system and, if applicable, to other remote sites.
- The Message Filter Group selected in the RMS tab of Site Parameters (page 44), defines which remote messages your Remote Message Service processes. If you select <None>, your local P2000 site receives all remote messages.

Viewing Real Time List Transactions

To access the Real Time List, select **System> Real Time List**. Transaction types displayed in the list area of the Real Time List can be color coded to help operators recognize a specific type of transaction. You can use the default system colors, or customize a transaction type with a different color. You can also set up a printer to print transactions as they occur, or print all transactions in the list.

Note: Operators with **View** menu permissions can access all Real Time List functions.

The Real Time List displays transaction messages in the order they are received. When a message is received, it displays in the row above the scrolling list and in the first line of the list. As new transactions occur, they move to the top of the list.

🕻 Real Time	List				_ 🗆 ×
I AII	 ☑ Panel ☑ Host ☑ Eleyator ☑ Intrusion 	 ✓ Audit ✓ Alarm ✓ Cabinet ✓ Eire 	 ✓ Access Deny ✓ Access Grant ✓ Arga ✓ Intercom 	 ✓ Badge Trace ✓ Guard Tour ✓ Mustering 	
□ <u>C</u> olor It	:ems	Set Colors	Printing		
Date/Time	Type Message	e Details	Site Partition	Public Query Item	Operator Alarm Category
, Msg Ro	outing Status	Done	Clear List	Details	•

When you open the Real Time List for the first time in the session, the scrolling list is empty. Depending on the transaction types selected at the top of the window, transactions begin to display in date and time order at the top of the list. As transactions occur, the older ones scroll down in the list as the newer ones are added at the top.

The following information is shown for each transaction in the list.

Date/Time – Displays the date and time of the message. Transaction messages that are originated at remote sites with different geographical time zones display the actual time at the remote site. However, remote alarms display the time at which they were received at your local site.

Type – Displays the transaction types that were selected for monitoring (Audit, Access Deny, Badge Trace, and so on).

Message – Displays a message related to the transaction type, for example, Invalid Card for an Access Deny transaction type.

Details – Displays details related to the message, such as Badge number, Terminal and Cardholder name.

Site – Displays the name of the local or remote P2000 site where the message was originated.

Partition – Normally displays the name of the partition containing the item (input point, terminal, panel, and so on) associated with the message.

Public – If the item associated with the message is marked as Public, this column normally displays whether the message is visible to other partitions.

Query – Displays the query string value (if it was defined) of the item associated with the message.

Item – Displays the name of the item (panel, terminal, input point, and so on) that is associated with the message.

Operator – Displays the name of the operator who handled the message (alarms in non pending state or audit messages only).

Alarm Category – Displays the Alarm Category to which the associated alarm belongs.

Note: The Message Routing Status indicator at the bottom of the Real Time List window displays in green to indicate that all communications between the workstation and the Server are up. If communications go down, the Message Routing Status indicator turns red.

Note: If your facility uses the DVR feature and the selected transaction message displayed is associated with a camera, click **Details** located at the bottom of the window to start the AV Player in live mode. As an alternative, you can click the **Details** drop-down arrow and select **AV Player** (Live) to start AV Player in live mode or select **AV Player (Stored)** to start AV Player in video retrieval mode. For more information, refer to your DVR documentation.

To View all Options in the Real Time List:

1. In the Real Time List window, click **All** from the options at the top of the window. All transactions begin to accumulate in the scrolling list.

To View Specific Options in the Real Time List:

1. Click to clear the **All** option and select only those options you wish to view. Only those options begin to accumulate in the scrolling list.

To Display Color-Coded Transactions:

- 1. Click **Color Items**. All transactions display in a different color, using the default system colors.
- 2. To display a transaction type with a different color, click **Set Colors**. The Set Colors dialog box opens.

Set Colors	×
Type	
Linknown	
Panel	
Audit	
Access Deny	
Badge Trace	
Host	
Alarm	
Access Grant	
Guard Tour	
Elevator	
Cabinet	
Area	
Mustering	
Intrusion	
Fire	
Intecom	
Select	Defaults
ОК	Cancel

- 3. Select a transaction type, then click **Select**. A Color dialog box opens.
- 4. Select the desired color and click **OK** to return to the Set Colors dialog box.
- 5. Click **Defaults** if you wish to reset the colors to the default system colors.
- 6. Click **OK** to return to the Real Time List window.

To Display Cardholder Details:

- Select from the scrolling list, the transaction line item associated with a cardholder (Access Deny, Access Grant or Badge Trace transactions).
- Click the Details drop-down arrow located at the bottom of the window, and select Cardholder Info. The Cardholder Info dialog box opens.

ardholder Info					
Cardholder	Jeff Evans				
Туре	Regular				
Company	Simi Valley			2	Con 1
Department				C.C	3
Badge	85				Am
Purpose			ID	2014	
Status	Active			1	
In-X-It Status	In	Set Undefine	d		
Date	Туре	Location			J
7/21/2005 8:22:10 AM	Access Granted Local	North Ent	rance, Security		
7/20/2005 9:35:59 AM	Panel Card Event De-act	ivated North Ent	rance, Security		
7/20/2005 9:35:58 AM	Access Granted Local	North Enb	rance, Security		
7/20/2005 9:35:30 AM	Panel Card Event Actival	ted North Enb	rance, Security		
7/20/2005 9:35:30 AM	Access Granted Local	North Ent	rance, Security		
7/20/2005 9:30:02 AM	Access Granted Local	North Ent	rance, Security		
7/20/2005 9:30:02 AM	Panel Card Event De-act	wated North End	rance, Security		
7/20/2005 9:29:45 AM	Panel Card Event Actival	ted North Enc	rance, security		- N
<u> </u>					
		1		1	

The top portion of the window shows the cardholder details including image, if available.

The bottom portion includes a chronological list of badge transactions associated with the cardholder.

- 3. If you wish to manually adjust the In or Out state of a badge until next badging, click **Set Undefined**.
- To change the number of transactions displayed, enter the desired number in the Num Records field.
- 5. To update the list box with new data, click **Refresh**.
- 6. Click **Done** to return to the Real Time List.

Printing the Real Time List

An operator can print from the workstation, all (or all displayed) transactions in the Real Time List, or print individual transactions as they occur.

IMPORTANT: Real time printing is not guaranteed on foreign language systems.

Printers must first be set up using the Windows Printer Settings dialog box. See your system administrator if you need more information, or refer to your Microsoft Windows documentation.

To Print the Real Time List:

1. In the Real Time List window, click **Printing** in the top portion of the window. The Printing dialog box opens.

Printing	×
Print Now Print Displayed	Print All
Real Time Printing	
\\c7ckys01\RicohExec_PS3	Setup
ОК	ancel

- 2. Click **Print Displayed** to print the transactions that are visible in the Real Time List box, or click **Print All** to print all transactions in the list.
- 3. Select a printer name and any other information for the printer to be used.
- 4. Click OK to start printing.

To Print Real Time List Line Items:

- In the Real Time List window, click Printing in the top portion of the window. The Printing dialog box opens.
- 2. Click **Enable Printing**. Line items continuously print as long as the Real Time List window is open or minimized on the workstation. Line items stop printing when the Real Time List window is closed.
- 3. Click **Setup** to select a printer name and any other information for the printer to be used.

Note: We recommend a dot matrix printer be used exclusively for printing line items from the Real Time List, and independently from the transactions printed from the Site Parameters window.

- 4. Click **OK**. The printer name displays.
- 5. Click **OK** to enable printing.

Note: Printing transactions from the Real Time List (performed from a workstation) is different from Real Time Printing (performed at the System Server). For information on Real Time Printing, see Site Parameters Printing Tab on page 35.

Using the Real Time Map

The Real Time Map displays the current status of terminals, inputs, outputs, and other defined elements on a map layout of your facility and can be used similarly to the System Status window. Maps are created using the Map Maker feature to drag-and-drop dynamic icons to their actual locations on imported layout images. All you need are simple layout maps that can be scanned or drawn in any draw application, then saved in an importable format.

Once the maps are created, they are accessed from the P2000 System menu. If a terminal goes down or an alarm sets, the Real Time Map shows you the state change and exactly where the device is located.

Sub Maps and Attachments

You can create facility-level maps and attach sub maps (Normal and Popup maps) that detail specific areas in the facility. Sub maps may also contain sub maps to add further detail; you can create as many levels as you need.

If an alarm sets in an area detailed in a sub map, the sub map icon blinks, indicating the location of the alarm. You can double-click the blinking sub map icon to jump to the associated detail map. (See Adding Map Attachments on page 366 for more information about creating multi-level maps.) Map Maker provides image sets to display various device states such as *panel up*, *panel down*, *input set*, and so on. However, you can create your own icons and include them in image sets in Map Maker. See Adding Image Sets on page 366 for details.

Note: The Message Routing Status indicator at the bottom of the Real Time Map window displays in green to indicate that all communications between the workstation and the Server are up. If communications go down, the Message Routing Status indicator turns red.

To View the Real Time Map:

 From the P2000 Main menu, select System>Real Time Map. The Real Time Map window opens.



 The current status of Panels, I/O Terminals, Readers, Input and Output points, and other defined elements display as designed in Map Maker. The Main Map displays as assigned on Map Maker; however, you can select any map created in the system. **Note:** Icons that are crossed out with a yellow bar indicate that the items' parent devices are not functioning. For example, an input point is marked as unreliable if its parent terminal or panel is down.

Note: If your facility uses the DVR feature, when you right-click a map icon that is associated with a camera, a pop-up menu displays the **AV Player (Live)** option. If there are stored videos (associated with alarms), the pop-up menu displays the **Show Alarm Video** and **Start Record***ing* options. For more information, refer to your DVR documentation.

- 3. From the drop-down list at the bottom of the window, select the name of the map you wish to view. The list only displays Normal maps.
- 4. If your facility uses Map Attachments, click **Prev** to return to the previous map, or click **Home** to return to the main facility-level map. Clicking **Up level** takes you to the previous facility-level map.

Note: The **Prev**, **Home**, and **Up level** navigation tools are not used with Popup Map Attachments.

- 5. Use the slider control to enlarge or reduce the view of the active map. The zooming of the map can also be controlled with the mouse wheel. You can also use keyboard commands to enlarge or reduce the view of the active map. Use the **Up** or **Left** arrow keys to reduce the view and the **Down** or **Right** arrow keys to enlarge the view.
- 6. Click Done to exit the window.

Opening a Door

You can open a door from a Real Time Map. The door remains open for the time configured in the door terminal's access settings, and then close. When a door is opened in this manner, the map icon image for the terminal changes from a closed door to an opened door, as long as the door is opened, then reverts back to a closed door image when the door closes. Use the instructions in To Place Device Icons on a Real Time Map: on page 364 to insert a door icon.

Note: The Open Door command does not unlock Assa Abloy Wi-Fi readers, since those readers are normally not connected to the P2000 system.

To Open a Door from a Real Time Map:

- 1. Locate the door terminal icon for the door you wish to open.
- 2. Right-click the icon and select **Open Door** from the shortcut menu. The door opens for the configured time period, then closes.

Note: If you need to open the door for a period other than that configured, you must do so using the Door Control function.

Activating Events from the Real Time Map

Events can be manually activated by an operator from the Real Time Map, rather than by the trigger conditions set up in the Configure Events dialog box. Icons on the Real Time Map, such as Panels, Terminals or Input Points, can be configured to initiate events; or you can just place Event icons on the Map.

To Activate an Event from a Real Time Map:

- 1. In the Real Time Map, locate the icon that contains the event you wish to activate.
- 2. Right-click the icon and select the Event name from the shortcut menu. The event is triggered.

Creating a Real Time Map

The following steps allow you to create a Real Time Map using Map Maker's drag-and-drop feature:

- Set up the Map Maker window
- Create an importable image
- Import the image to Map Maker
- Drag-and-drop map icons onto the map
- Add Map Attachments
- Duplicate a Map

To Set up the Map Maker Window:

 From the P2000 Main menu, select Config>Map Maker. The Map Maker dialog box opens.

G Map Maker					_ 🗆 ×
	Partition	Super User			•
Map Name		Type	Partition	Public	
Main Facility Map		System	Super User	Yes	
Computer Center		Normal	Super User	No	
Warehouse		Normal	Super User	No	
Done	-	dd	Edit	Delete	Duplicate

2. Click Add. The Map Editor window opens.



Partition: Super Use

OK Cancel Apply

ing options:

ible in all partitions.

(Normal or Popup).

4. Enter a descriptive Map Name.

Import Export

Partition in which the map is active and

5. From the drop-down list, on the right side of the Map Name, select one of the follow-

click Public if you wish the map to be vis-

System – A system map automatically dis-

plays when you open the Real Time Map.

You can only create one system map. The

system map displays any defined sub maps

Normal – A normal map is a sub map that

Map Attachment on another map. It can

can be used as a Map Attachment or Popup

also be selected from the drop-down list at

the bottom of the Real Time Map window.

can be used as a Map Attachment or Popup

Map Attachment on another map. It is not

selectable from the Real Time Map

Popup – A pop-up map is a sub map that

3. If this is a partitioned system, select the

This document contains confidential and proprietary information of Johnson Controls, Inc. © 2014 Johnson Controls, Inc.

To Create an Importable Image:

Map Maker can import most popular image formats: *.bmp*, *.tif*, *.wmf*, *.jpg*, *.pcx*, and *.eps*, to name a few. (To see all available formats, see the **Files of type** drop-down list when you click the **Import** button.)

- 1. If floor plans or maps exist in a compatible electronic format, you can import them directly.
- 2. If floor plans or maps exist in hard copy, have them scanned and saved in a compatible format.
- 3. If floor plans or maps do not exist, you can create them using a draw program such as Microsoft Paint, CorelDRAW®, or other drawing utility, then save or export the image in a compatible format.
- 4. Copy the image file to a directory that is accessible to the P2000 system.

To Import an Image to Map Maker:

- From the P2000 Main menu, select Config>Map Maker. The Map Maker dialog box opens.
- 2. Click Add. The Map Editor window opens.
- 3. In the Map Image box at the bottom of the window, click **Import** and navigate to the directory in which your layout image is stored.
- 4. Select an image to import.
- 5. Click **Open**. The image displays in the background of the image area of the Map Editor window. You can use the mouse pointer to pull the corners and sides of the window to increase the size as necessary, or click the maximize/minimize button in the top right of the window.

Note: If you wish to export the map image, click **Export**. Navigate to the directory where the exported map is stored, give it a name, and select the file type and other related parameters.

To Place Device Icons on a Real Time Map:

When you open Map Maker, map icons representing Panels, Terminals, Inputs, Outputs, and other system elements are listed on the right windowpane.



Note: If your facility uses advanced features, such as Intercom or DVR, the associated map icons display in the list. See the respective section in Chapter 4: Advanced Features, for more information.

 Expand the element you wish to add. To add an input point for example, click the plus (+) sign next to the Input Point icon. An Input icon is added under it.

Note: Placing an Assa Abloy Wi-Fi reader on a Real Time Map has little value, as those readers do not provide real time information to the P2000 system.

2. Use the left mouse button to drag the new icon to the desired position on the map. For example, an input point could be dragged near the door representing where the input point is actually installed. When you release the mouse button, a Properties dialog box opens.

TIP:

III. The top left corner of the icon is anchored exactly where the tip of the mouse pointer is released.

operties		×
Label	Entrance	
Font	<default></default>	
Font Size	10	Choose Font
Font Style	Normal	•
Text Color	0,0,0	
Background Color	255,255,255	
	Transparent Background	
Text Position	Bottom	
Input Point		•
Event 1 Label		
Event 1	<none></none>	•
Event 2 Label		
Event 2	<none></none>	•
Event 3 Label		
Event 3	<none></none>	•
Event 4 Label		
Event 4	<none></none>	•
(OK Cancel	

- 3. In the **Label** field, enter a descriptive name that can easily identify the icon in the Real Time Map. This name displays under the icon on your layout.
- 4. The **Font** box displays the default font or the font selected for the icon name.
- 5. In the **Font Size** box enter the font size for the name appearing under the icon.
- 6. To make all font changes at once, click **Choose Font** and select a font type, style, and size for the name appearing under the icon.
- 7. If you wish to change the **Font Style**, select from the drop-down list whether the text should be Bold, Bold Italic, Italic, or Normal.
- 8. To display the text in a different color, click the **Text Color** browse button [...] and select a color from the Color dialog box.
- Click the Background Color browse button [...] to open the Color dialog box and select the background color for the icon name.
- 10. Click **Transparent Background** if you wish the background of the text to be transparent.
- 11. From the **Text Position** drop-down list, select whether you want to place the text at the Bottom, Left, Right, or Top of the icon.
- 12. Select from the drop-down list the name of the item you wish to place in the map. If you are placing an input point, all available input points (or all input points in the partition selected) display in the drop-down list. If you are placing a panel, the drop-down list includes all panels (or all panels in the partition).

Note: You can also place static text objects in the map to indicate for example, the name of an entire area, or a number to dial in case of emergency.

- 13. To assign events to the item, enter a descriptive event name and select a previously configured event from the associated drop-down list. You can define up to four events for each map icon.
- 14. Click **OK** to close the Properties dialog box. The icon is inserted in the map.
- 15. Repeat the same steps for each device or event you wish to add to the map.
- 16. When all elements have been added, click OK to close the Map Editor window. The map is now available to choose from the Real Time Map drop-down list.
- 17. Click **Done** to close the Map Maker dialog box.

Handling Alarms from the Real Time Map

You can place an **Alarm Category** icon on a Real Time Map and issue commands for all P2000 items that generate alarms, (such as input points or cameras) and that use the Alarm Category selected.

When an alarm is reported in the system, the Alarm Category icon flashes on the map. You can right-click the icon to issue from a shortcut menu one of the alarm commands (acknowledge, respond, or complete). If you select *Acknowledge* or *Complete*, all alarms that use the Alarm Category selected are acknowledged or completed at once. However, if you select *Respond*, the Alarm Monitor window displays so you can respond to each alarm by entering specific instructions for each particular alarm.

In addition, the shortcut menu allows you to open the Alarm Monitor window or display the alarm details associated with the Alarm Category selected.

Adding Map Attachments

You can add map attachments to Real Time Maps that, when right-clicked, can open another map. For example, you can place a map attachment on the *Office* map that can open the *Warehouse* map. Or you can place several area map attachments on the System Map.

To Add a Map Attachment:

- From the P2000 Main menu, select Config>Map Maker. The Map Maker list box opens.
- 2. Select the map to which you wish to add a map attachment.
- 3. Click **Edit**. The Map Editor window opens with the selected map in the image area.
- 4. Drag a **Map Attachment** icon to the image area. When you release the mouse button, select from the drop-down list the map you wish to attach.
- 5. Click **OK**. Now when you open the map in Real Time Map, you can right-click the Attachment icon and select **Open** to open the attached map.

Duplicating Maps

The Duplicate Map feature allows the duplication of existing maps. This feature is useful in buildings where the layout is the same throughout all floors. You can create a master map with default information, and then use that map as a template to create additional maps. All current map information is copied; however, each map must have a unique name.

To Duplicate a Map:

 From the P2000 Main menu, select Config>Map Maker. The Map Maker list box opens. 2. Select the map you wish to duplicate and click the **Duplicate** button. The Duplicate Map dialog box opens.

Duplicate Map			×
	New Map Name	West Campus	
	🔽 Keep Items		
	🔽 Kee	p Item Labels	
	V Kee	p Item References	
	ОК	Cancel	

- 3. Enter the New Map Name.
- 4. Click **Keep Items** if you wish to keep all items from the master map.
- 5. Click **Keep Item Labels** if you wish to keep the labels from the master map.
- 6. Click **Keep Item References** if you wish to keep all references from the master map.
- 7. Click **OK** to create the new map. The Map Editor window opens displaying the selected items. Make any additional changes if necessary.

Adding Image Sets

Map Maker provides image sets to display various device states such as *panel up*, *panel down*, *input set*, and so on. However, you can use your own icons to create custom image sets.

To Create a Custom Image Set for Map Maker:

 From the P2000 Main menu, select Config>Icon Editor. The Icon Editor dialog box lists the default image set names.

	Partition:	Super User	•	
Image Set Name		Set Type	Partition	Publi 4
Мар		Map Attachment	Super User	Yes
Popup Map		Popup Map Attachment	Super User	Yes
Panel		Panel	Super User	Yes
Terminal		I/O Terminal	Super User	Yes -
Reader		Reader	Super User	Yes
Input		Input	Super User	Yes
Output		Output	Super User	Yes
Event		Event	Super User	Yes
Intercom		Intercom	Super User	Yes
I gon Tamper		Loop Tamper	Super Liser	Vec
		Loop Lamper	Superlicer	\°°° [

2. Click Add. The Image Set Bitmap Editor opens.

Image Set I	Bitmap Edito	or		×
	Partition:	Super User	•	P <u>u</u> blic:
		Image Set <u>T</u> ype:	Panel	
		Image Set <u>N</u> ame:		
Icon				
Image	State			
	panel up			Edit
	panel down			
	panel unkno	WD		Import
				Export
		ОК	Cancel	

- 3. Select the **Image Set Type** you wish to create. The default image for each state displays in the Icon list.
- 4. Enter an **Image Set Name** for the new image set.

5. Select an icon from the list, and click one of the following function buttons:

Edit – The Edit Button Image dialog box opens. Use the editing tools and colors to edit the existing icon. Click **OK** to save.

Edit Button Image	×
Picture:	Colors:
Preview:	Tools:

Import – Select if you wish to replace the existing icon. Navigate to the directory where your new images are stored, select the image and click **Open**. The default icon in your new image set is replaced with the new icon.

Export – Select if you wish to export the existing icon.

6. Click **OK**. Your new image set displays in the Icon Editor list, and is now accessible from the right windowpane in the Map Editor window.

Chapter 4: Advanced Features

his chapter describes several advanced features that, when properly configured and utilized, allow for a more secure and efficient way to operate and monitor your access control system. Some of these features are bundled separately from the P2000 software, and some of them are shipped with their own manuals. Refer to your purchase contract to see what is available in your system. This chapter presents the information you need to set up and configure each of the following features:

- Partitions Divide your P2000 system databases into sections that can be managed individually.
- Video Imaging Improve your security by creating badges to provide a visual identification of every cardholder.
- MIS Interface Add, update, delete, or query the P2000 cardholder database from an external database system.
- Metasys Integration (BACnet) Allow P2000 security tasks to be handled by Metasys Workstations.
- Metasys System Integration Allow several P2000 security tasks to be handled via the Metasys system user interface.
- Guard Tour Define a sequence of transactions that must occur at specific intervals to ensure security personnel properly monitors your facility.
- CCTV Provides controls to operate cameras, monitors, and other CCTV elements.
- DVR Provide controls to search, retrieve, and download real-time or archived audio and video recording from surveillance cameras.

- Redundancy Run the P2000 software in a recovery configuration to ensure uninterrupted operations.
- **FDA** Define parameters to assure FDA Title 21, Code of Federal Regulation (CFR) Part 11 compliance.
- Intercom Define and control intercom calls from P2000 Workstations.
- P2000 Enterprise Allow multiple P2000 sites to communicate with each other to share cardholder and badge data.
- Web Access Perform various P2000 tasks from any Web-ready computer or compatible PDA device.

Partitions

You can divide the P2000 database into smaller sections that can be individually managed. Partitions structure what data is accessible by an individual operator, or by a group of operators. You can create as many partitions as you need, depending on your system requirements. For example, if you manage a building with several tenants, you could use partitions to segregate the databases and system functions, so that Tenant A cannot see, access, or change Tenant B's records.

Operators select the partition to which they are assigned, from the Partition selection box on the right side of the P2000 toolbar.

Partition	Super User	lot
	Super User	C
	Warehouse	
	Human Resources	
	Security	
	B 2000	
	P2000	
	. = 0 0 0	

The first partition assigned to the logged on user automatically displays in the Partition field. For multiple partition users, click the drop-down button to the right of the Partition field to display all partitions assigned to the user. The partition selected is the active partition for the user.

When a Partition field displays on a window, the items displayed in the window are only for the partition selected from the drop-down list.

After partitions are set up, they are available for assignment to all major system components, such as operators, system devices, cardholders, access groups, and terminal groups. For detailed information about using Partitions with these components, see the component sections in Chapter 2: Configuring the System.

Partition Types

Operators are assigned to single or multiple partitions and have unique access restrictions. Examples of access restrictions include the ability to add, modify, or view database information within their assigned partitions. Access restrictions for individual operators are defined in the Menu Permission Groups window. When an operator logs on to the P2000 system, the partition chosen from the Partition selection box on the right side of the toolbar is the active partition for the operator. However, an operator can select other partitions, assuming they have been given access to other partitions in the Edit Operator dialog box. See Adding Operators to the System on page 21. Any database items created by an operator in a partition are owned by that partition. That is, the information resides in that partition and it could be accessible for use by other partition operators if the database item has the Public check box enabled or the operators have been assigned to the same partition. Operators that belong to the Super User partition may access all database items.

There are two types of database partitions: Regular and Super User.

Regular Partitions

Regular partition operators may belong to multiple partitions or just a single partition. Access restrictions include the ability to add, modify, or delete items that belong only to their assigned partitions. Items that have been marked as **Public** in other than their assigned partitions can be selected for viewing; however, the information is not accessible for modification.

The Super User Partition

The Super User partition is the main partition in the database. Only one Super User partition can be defined. Operators that belong to the Super User partition have access to all other partitions; are responsible for assigning partitions to database operators; and have the ability to add, modify, and delete any items in the database. Super User members are also responsible for performing system maintenance and system configuration functions.

The Super User member can access all system data regardless of partition ownership. Regular partition operators cannot change parameters defined in the Super User partition.

Creating Partitions

Create partitions to divide the P2000 database into smaller sections. The newly created partitions are added under the root partition icon, and display in drop-down list boxes throughout the system. Once partitions have been defined, operators can be assigned to a specific partition or to multiple partitions by using the Edit Operator dialog box.

Note: If the MIS Interface feature is available in your system, you need database administrative rights to add, edit, or delete partitions. (See Setting Up User Accounts on page 28).

To Create a New Partition:

1. In the left pane of the System Configuration window, select **Partitions**

Note: In Enterprise systems, you can only create partitions at central or alternate sites.

 Click Add to access the Partition Edit dialog box.

📶 Parti	tion Edit	
<u>N</u> ame:	Warehouse	
	ОК	Cancel

- 3. Enter a Name for the new partition.
- Click **OK** to save the partition name and return to the System Configuration window.

To Delete a Partition:

- 1. In the left pane of the System Configuration window, expand **Partitions**. All the partitions currently configured in the system are listed.
- 2. Select the partition you wish to delete, and click **Delete**.
- 3. The Partition Selection dialog box opens. Select the **New Partition** to which all items from the deleted partition will be moved.

Partition Selection			×
Please select the partition that a be moved to.	all items currently de	fined in the partition 'Sale	s' should
New Partition	Super User		•
		OK	Cancel

- 4. Click OK.
- 5. At the Confirm Delete dialog box, click **Yes**. All items under the deleted partition are moved to the new partition.
- 6. Operators cannot delete a partition that is associated with their currently logged on workstation; however, an operator can delete a partition that is associated with other active workstations. A message displays to confirm the deletion and all active workstations are forcefully logged off.

Note: Deleting a partition may take a considerable amount of time, if records are still associated with the deleted partition.

Video Imaging

Video Imaging is a full-featured video imaging and badging system that is fully integrated with your P2000 Security Management System. Video Imaging improves security by providing a visual identification of every cardholder. Through the imaging software's graphical user interface, you can create custom badge layouts easily and quickly. You can include several elements on a badge, such as company logos or other important identifying images, cardholder photographs, custom text, barcodes, and signatures. You can also add User-Defined Fields (UDFs) to give you the flexibility to produce sophisticated designs with a minimum of time and effort.

The P2000 system supports two Video Imaging software options: ID Server and EPI Builder. Complete software and hardware installation and operation instructions are provided in the *P2000 Integrated Video Imaging Installation and Operation Manual* that was shipped with your Video Imaging option.

The following sections describe basic video imaging configuration and use, including:

- Video Imaging specifications
- Defining a Video Imaging workstation
- Printing a badge

Video Imaging Specifications

Video Imaging provides a full-featured badge design and imaging solution, providing the following:

- Integration with the P2000 Security Management System. The P2000 server centrally stores all cardholder records, images, and so on.
- A fully-capable P2000 workstation that you can also use as a badging station
- Easy-to-use WYSIWYG (what you see is what you get) badge design
- Badge design storage limited only by available hard disk space
- Digital camera and signature pad video capture support options
- Simple to capture photos and signatures

- Magnetic stripe or G&D smart card encoding
- Support with partitioned or non-partitioned P2000 systems

Defining a Video Imaging Workstation

Like any P2000 workstation, you must define the Video Imaging workstation at the P2000 server before the station can properly connect to the server.

To Configure a Workstation for Badging:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand Site Parameters.
- 3. Select **Workstation**, and click **Add**. The Workstation dialog box opens.

C Workstation			K
Partition	Super User	▼ V Public	
Name	warehouse		
Location	West Union Building		
🔽 Enable			
🔽 Badge Sta	tion		
🗖 Server			
Alarm Monitor			
Normal			
C Launch Automatica	ly		
C Always Active			
1	imezone: Full Time	_	
Message Filt	er Group: <a>(<	•	
	OK Cancel]	

- 4. Enter the information required; see Workstations on page 19.
- 5. Click **Badge Station** to define this workstation as a Video Imaging station.

Note: If you edit an existing workstation and define it as a Video Imaging station, you must exit the P2000 software and restart the application for the change to take effect.

6. Click OK.

Note: Configuring a workstation as a Badge Station only authorizes that workstation to perform badging operation. You must still correctly install the badging software at that workstation.

Printing a Badge

Printing a badge requires the following steps:

 Creating a cardholder record. (See Entering Cardholder Information on page 260.)

- Assigning the badge to the cardholder. (See Entering Badge Information on page 267.)
- Capturing the portrait and signature images.
- Viewing and printing the badge.

Capturing the Portrait and Signature Images

- From the P2000 Main menu, select Access>Cardholder. The Cardholder window opens.
- 2. Select a cardholder from the list.
- 3. Click **Take** to begin the process of capturing the portrait and signature images.

Cardhold	ler									
		Site:	Simi Valley		•					
		Partition:	Super User		•	All				
First	Mid	Last	Туре	Guard	Partition	Pu	Edited By	Edit Time		Type
Loretta	Ψ.	Adams	Visitor	No	Super User	No	Cardkey	4/1/2011 10:57		All 🔻
Fred	R.	Albertson	i Visitor	No	Super User	No	Cardkey	4/1/2011 10:57		
Joe	м.	Brown	Regular	No	Super User	No	Cardkey	7/28/2011 12:5	- III	Search
Brenda	Τ.	Covingtor	n Regular	No	Super User	Yes	Cardkey	3/31/2011 2:39		_
Anna Iomor	5.	HINC	Visitor	NO	Super User	No	Cardkey	7/28/2011 1:00	•	All
James	A. A	Jasper	Regular Regular	No	Super User	No	Cardkey	7/20/2011 12:5 3/20/2011 3:22	• =	
Tom	R.	lones	Visitor	No	Super User	No	Cardkey	7/28/2011 1:00		
Aidbaol	T	Cmith	Dogular	No	Supor Lloor	Ver	Cardicou	A/1/2011 10/EE		Add
Image	Address	Other	Start/End Ba	adges l	JDF Enter	prise Sit	tes Sponsor	ed Visitors		Edit
		ID		1	Portrait					Delete
		763			Import	1	Export			Delete
		1703					Export			
1 1	- 12				Dadaiaa					
	4		2	- 1	bauyiny					Done
		<u> </u>	Journal		Take		Display			- 2
		-		l						
					_/					10 Canalhalalana
/1/1900 :	12:00:00	AM UND	EFINED		/					Cardillolders
Badge Inf	ormatior	۱ <u> </u>		/	/					
		Тур	e: All		-]		Partition: Super	User	•
Number	Alph	ia Issue	Status /	options	Туре	Partiti	ion Pu	blic Access Group) Ti	me Zone Reason
306		0	Active		Access	Super	User No	Daily Access	Fu	ull Time New
•										•
		1 7	/	1		1	-	-	- 1	
	Add		Edit		Delete		Pre <u>v</u> iew	Print		Print Queue
		/								
		/								
		/							A ! I	
	_							/	Avail	able if using the
Tak	ke Bu	utton						۱ ۱	Video	o Imaging softw
										0 0 0

Note: The following sequence of steps assumes you are using all available capture devices for Video Imaging (camera and signature pad). Any devices not used, and therefore not configured, are automatically skipped by the Video Imaging application.

4. The first capture window displayed is the portrait window. If you do not see an image when the portrait capture window opens, check your camera cable connections and ensure the camera was properly configured.

For information on hardware installation, refer to the *P2000 Integrated Video Imag-ing Installation and Operation Manual* that was shipped with your system. Elements on each capture window display according to the type of devices you are using. Follow the respective instructions in your Video Imaging manual.

- 5. Capture the portrait image and make adjustments with the tools provided. Experiment with the various image controls. After you capture the portrait image, it is automatically linked to the current cardholder record.
- 6. After capturing the portrait image, the signature capture window automatically opens (if previously configured). Use the special plastic-tipped pen, shipped with the pad, to sign your name.
- 7. Make the necessary adjustments and accept the signature to assign it to the current cardholder.

Viewing and Printing the Badge

After capturing all the images, you can now view and print your badge design. Since the captured images are usually large files, it takes a few seconds to save them into the database. Always wait a few seconds after capturing images before printing a badge.

To View a Badge Before Printing:

- 1. Click **Preview** at the bottom of the Cardholder dialog box.
- 2. Your design displays in its own window with all the images you have captured.

To Print a Badge:

- 1. Before printing the badge, load the ribbon and cards according to the printer's manual.
- 2. Select the cardholder record whose badge you wish to print.
- 3. Select the badge you wish to print.
- 4. Click **Print** at the bottom of the Cardholder dialog box.

To Import an Image:

- 1. From the Cardholder window, select a cardholder from the list.
- 2. Click the Image tab.
- 3. Under the Portrait box, click Import.



4. Navigate to the directory where your images are stored. Select the image and click **Open**. The image displays in the Image tab.

Note: Once an image has been placed in the cardholder record, you cannot delete it; you must import a new image to replace it. Also, if the imported image displays cropped on the screen, you may need to contact Technical Support if you wish to change the image aspect ratio.

MIS Interface

The MIS Interface provides a means for the P2000 system to receive cardholder information and respond to queries from an external database source, such as a Human Resources database. Therefore, the cardholder records that already exist in the external database do not need to be manually re-entered into the P2000 database.

The MIS Interface allows an authorized Open DataBase Connectivity (ODBC)-compliant application to manage (add, modify, or delete) cardholders and their badges in the P2000 database and query cardholder information using wildcards. The P2000 MIS Interface communicates with the external application over an ODBC connection.

MIS Prerequisites

The following elements are external to the P2000 software and they must be in place or the MIS Interface is unable to receive data or respond to queries:

- Network connection to link the external database system with the P2000 Server.
- MIS Interface (no separate installation media is required).
- ODBC 2.6 or later (installed on the external database system).
- Microsoft SQL Server[™] ODBC driver (already installed on the P2000 system).
- An ODBC-based program that communicates between the external data source and MIS Interface input and output tables.

Note: The external database system can be any ODBC-capable application. This database system is supplied by the user and is not included in the P2000 software. Once the previous components are in place, you must set up the following elements at the P2000 Server:

- Enable the MIS account type for the operator assigned to use the MIS Interface. To do this, simply click **MIS** in the Edit Operator dialog box; see page 24 for details. We strongly recommend using a separate Operator account for the MIS interface.
- Enable Password never expires in the Edit Operator dialog box, since passwords cannot be changed for MIS users; see page 24.
- Make sure the P2000 operator is a member of the PEGASYS Administrators group. This is necessary to add or modify UDFs for use in the MIS interface. This is done by setting up the Windows account of those P2000 operators accordingly; see page 28.
- Make sure the P2000 MIS Interface Service is running using the Service Control application; see page 470.
- If you use the **Export Image** command, select in the **MIS** tab of Site Parameters, the location for storing exported badge images.

To Select a Location to Store Badge Images:

- From the System Configuration window, select Site Parameters and click Edit. The Edit Site Parameters dialog box opens at the General tab.
- 2. Click the MIS tab.

C Edit Site Paramete	ers				×
General Printing F Port Configuration	Panel Types Facility Co RMS EMail	ode Retention Policy External Event Trigger	Password Policy MIS We	BACNet	Download XmlRpc
- Image Folder					
То	[]	

- 3. Enter the name of the **Image Folder** or click [...] to find the folder for storing the badge images.
- 4. Click **OK** to save the settings and return to the System Configuration window.

Understanding the Input and Output Tables

The MIS Interface communicates with the external application via an ODBC connection to receive data and return command and query results through two database tables: an Input table and an Output table. These tables are created automatically. The Input table receives data and commands from the external system. The results of the commands issued to the P2000 system from the Input table are returned to the Output table.

When the external program writes a record into the Input table, the P2000 system reads that record and performs the requested action (Add, Delete, Update, Query, Query Multiple, Export Images, or Delete Badge). The results of that operation are written to the Output table and the record in the Input table is deleted. The external software should enter a unique Request ID for each record. Results are reported by Record ID and can be reviewed via the external program.

Results can be either *successful* or report an error on a specific Request ID. If multiple records are sent to the Input table, they are processed in the same manner: as a group of records is processed and clears the Input table, the next group is read and processed. (Request IDs remain intact, though records may not necessarily be processed in any particular order.) Records are removed from the Output table by the external system. All successful operations that modify a P2000 record generate a message in the normal P2000 Audit log.

Partitioned Systems

On P2000 systems that use the Partitioning feature, a set of input and output tables is created for each partition. The table names are prefixed by the partition name. These tables are in addition to the normal input and output tables, which are used for the Super User partition.

Using the MIS Interface

Running the MIS Interface continuously or at prescribed intervals is up to your management procedures.

For example, you may want to run the MIS Interface to populate the P2000 cardholder database for the first time, entering all cardholder information for all personnel at one time. After that is done, you may want to only run the MIS Interface once a day or once a week.



MIS Interface Application:

The MIS Interface is intended only as a tool to allow an external database source to export images and add, update, delete, or guery the

APPLICATION NOTE

P2000 cardholder database. It is **not** intended to keep the P2000 database and the external data in perfect "sync." Records deleted from the P2000 database are not automatically deleted from the external database. You should establish specific procedures to manage your use of the MIS Interface.

For detailed information, refer to the *MIS Interface Configuration* documentation.
Metasys Integration (BACnet)

Overview

The BACnet Interface allows the P2000 system to be integrated into the Johnson Controls Metasys building automation system. The P2000 system can be monitored and controlled from a Metasys M3 or M5 workstation. This interface provides a BACnet gateway through which P2000 hardware configuration and status information can be accessed. It allows an M3 or M5 workstation to receive and acknowledge P2000 alarms and events. In addition, the P2000 software can be configured to cause actions to occur within the Metasys system when access is granted.

Refer to the *P2000 Metasys*® *Integration Manual* for complete instructions.

Theory of Operation

BACnet (Building Automation and Control network) is a standard protocol from the American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE). This protocol provides a standard for allowing computers and equipment controllers to transfer data between the devices in an object-oriented fashion. The BACnet standard defines the types of information and attributes that any device must maintain, and defines how BACnet messages are communicated between the various devices.

The attributes associated with a particular device are grouped together into *Objects*. BACnet defines a standard set of objects, and a device may be represented by, or contain several of these objects. A device **must** contain at least one BACnet object, called a Device Object.

Objects have attributes and provide standardized functions to read and write those attributes. BACnet also provides defined methods to send event and alarms between equipment. The BACnet objects associated with the P2000 system represent the P2000 hardware. There are objects for the P2000 host, counters, panels, terminals, readers, input points, and output points. Each of these objects has attributes that contain the configuration parameters and status for that object. For instance, commands to open doors and set output points are sent to the P2000 system by writing specific attributes. The P2000 BACnet Interface also contains Notification Class objects that hold the names of recipients for P2000 alarms and events.

The P2000 BACnet Interface that resides on the P2000 Host computer is called BACnet Service. BACnet Service is a Windows NT service, like the other P2000 communication services. BACnet Service creates the BACnet objects that represent the P2000 hardware, and updates the hardware attributes and status in real time as changes occur in the P2000 system. BACnet Service sends data to and receives data from the Metasys system over the network using the BACnet protocol.

BACnet Service reads from the P2000 database any status information it needs, and uses the standard P2000 message routing service (RTLRoute Service) to receive real-time status and alarm changes.

To prevent unauthorized BACnet devices from accessing the P2000 system, the P2000 system only communicates with those devices that have been configured as allowed BACnet devices in the P2000 database. Communication attempts by other devices over the BACnet interface causes the P2000 system to log a system error and deny communication. A device can also be configured in the P2000 software as a disallowed BACnet device. In this case the P2000 system does not log any error messages but denies the communication. Typical BACnet devices are M3 or M5 workstations and N30 controllers. The following figure shows a logical view of this architecture.

The BACnet Interface also provides a way for the P2000 system to initiate actions in other BACnet devices. This capability is called Action Interlock. Action Interlock is an action caused by a write of the specified value to a specific attribute of a specific BACnet object. This allows the P2000 software to initiate actions in an N30 controller or other BACnet device if the proper attribute is known. The P2000 system allows a badge to be assigned up to two actions (Action Interlocks) that are triggered when that badge is granted access, and also allows Action Interlocks to be assigned as a Host Event Action. A typical use of an Action Interlock would be to cause the lights in a person's office to turn on when they are granted access at the door.

The P2000 software sends out its messages and alarms as BACnet event and alarm messages. To receive these BACnet event and alarm messages, a BACnet device must have been added to the recipient list contained in the appropriate Notification Class object. The P2000 BACnet Interface provides for the following event categories:

- Host Events
- Host Log
- Host Logic (not used in this version)
- Audit Log
- Panel Events
- Panel Hardware Status
- Input Status
- Output Status
- Access Grant
- Access Deny
- Access Trace
- Time and Attendance (not used in this version)



System Setup

The P2000 software requires the following configuration steps to get its BACnet Interface functional:

- Set up BACnet site options to define the parameters of the BACnet Interface, see next section.
- Enable the P2000 BACnet Service to automatically start by configuring the Service Startup Configuration; see page 466.
- Add entries to the External IPs application to define the BACnet devices that communicate with the P2000 system; see page 380.
- Configure the hardware components for BACnet Interface; see page 381.
- Set up BACnet Action Interlocks to initiate actions in BACnet devices; see page 381.

Setting Up BACnet Site Options

BACnet Site options allow you to configure many system wide settings, defining various parameters of the BACnet Interface.

To Edit BACnet Site Parameters:

 From the System Configuration window, select Site Parameters and click Edit. The Edit Site Parameters dialog box opens at the General tab.

6 Edit Site Parameters	د
Port Configuration RMS EMail External Event T General Printing Panel Types Facility Code Retention F	Image MIS Web Access XmIRpc Policy Password Policy BACNet Download
🔽 Enable BAG	inet Interface
Query String	
Host Event Priority	200
Host Log Priority	0
Audit Priority	200
Panel Hardware Priority	100
Panel Event Priority	200
Output Point Priority	200
Access Grant Priority	160
Access Deny Priority	150
Card Trace Priority	140
IP Address	0.0.0.0
IP Port	47808
Network Address	1001
Internal Address	1

- 2. Click the **BACNet** tab.
- 3. Enter the information on each field according to your system requirements. (See BACnet Site Field Definitions for detailed information.)
- 4. After you enter all the information, click **OK** to save the settings and return to the System Configuration window. You must stop and restart the BACnet Service.

BACnet Site Field Definitions

Enable BACnet Interface – BACnet settings are only available after you select this check box.

Query String – This is a 64-character string that is used to set the Query String attribute for the Host Device object, Counter objects, and Notification Class objects. This value is used in the Metasys M3 or M5 Workstation software.

Priority Values – This is the BACnet priority level used when sending the corresponding event or alarm.

IP Address – If the P2000 Server has a single network interface card (NIC), you do not need to enter an IP Address in this field (you may leave the default value of 0.0.0.0). If the P2000 server has more than one NIC, enter the IP Address the P2000 Server uses to receive BACnet broadcast messages over the network.

IP Port – This is a BACnet protocol addressing parameter. The default value is 47808. You may need to change this value if your existing BACnet devices use different values.

Network Address – This is also a BACnet protocol addressing parameter. The default value is 1001. You may need to change this value if your existing BACnet devices use different values. **Internal Address** – You should only change this value if there is another P2000 Server on the same network. If needed, set this value to be unique to every P2000 Server on the network.

Setting Up External IPs

Here you define a computer or device to accept messages from external devices. You can also define a computer or device from which the P2000 system does not accept external messages (using the Allow option). If the P2000 system receives an external message from a source that is not configured, the P2000 software logs an error message and does not process the message.

To Set Up External IPs:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand **Site Parameters** to display default system parameters.
- 3. Select **External IPs** and click **Add**. The External IP Edit dialog box opens.

🕻 External IP Edit									-	. 🗆 🗙
Name	M	5 Worl	stati	on					-	
	e 0	IP Ad Comp	dress uter I	Vame						
IP Address	Γ	200	•	0	•	0	•	0		
<u>C</u> omputer Name	Γ									
	☑	Allow								
	☑	Use fo	or BA	Cnet						
			BACn	et Ro	uted					
	Г	Use fo	or Xm	IRpc						
OK				Canc	el					

- 4. Enter a descriptive **Name** of the external device.
- 5. Click either IP Address or Computer Name.

- If you click IP Address, enter the IP Address of the computer or device from which to accept messages. Use this option for a device that is not a Windows computer.
- If you click Computer Name, enter the Windows Computer Name from which to accept messages, or click the browse [...] button to find a computer by name on your network.
- 8. If you click **Allow**, the P2000 software allows communication with this device. If you do not click Allow, the P2000 system denies communication with this device but does not log any error messages for this device.

Note: When configuring BACnet devices, note that since the BACnet protocol includes broad-cast messages that are sent to all BACnet devices on the network, the P2000 software may generate a lot of error messages about rejecting messages from unknown BACnet devices. Since these error messages can cause a significant slowdown in the processing of other messages, add these devices as a BACnet Source but do <u>not</u> click Allow.

- 9. Click Use for BACnet if this is a BACnet device.
- 10. If this is a BACnet device, click BACnet Routed to send certain messages directly to the device instead of broadcasting them. If you do not click BACnet Routed, certain messages are broadcasted between this device and the P2000 Server. If this device is connected on the other side of a network router, but you do not click BACnet Routed, the device does not see broadcasted messages.
- 11. Click **Use for XmlRpc** if this device uses the XmlRpc protocol. See XmlRpc Tab on page 47 for details.

12. Click **OK** to save the settings and return to the System Configuration window.

Note: The External IP settings take effect after you stop and restart the P2000 XmIRpc Interface service; see Starting and Stopping Service Control on page 470.

Configuring Hardware Components for BACnet Interface

When configuring panels, terminals, input points, and output points, described in Chapter 2: Configuring the System, you may enter a Query String value. This is a 64-character text field that is used in the QueryFilterString property of Event Notification messages.

Note: To define panels, terminals, input points, and output points as BACnet objects, see the General Tab on page 56.

Setting Up BACnet Action Interlocks

You must define Action Interlocks for the P2000 system to initiate actions in BACnet devices. Here you define the BACnet object and properties that are written to by an Action Interlock. A typical use of an Action Interlock includes turning on lights and air conditioning at a cardholder's office when they are granted access at a door.

To Set Up BACnet Action Interlocks:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Select **BACnet Action Interlocks** and click **Add**. The BACnet Action Interlock Edit dialog box opens.

C BACnet Action Interlock Edi	it 📃 🖂 🗙
Partition Super l	User 🔽 🗖 Public
Name	Lights
Object Name	First Floor Lights Control
Property Number	95
Property Type	Long
Priority	0
OK	Cancel

- 3. If this is a partitioned system, select the **Partition** that has access to this action interlock information, and click **Public** if you wish the action interlock to be visible to all partitions.
- 4. Enter a descriptive **Name** of the BACnet Action Interlock.
- 5. Enter the **Object Name** of the BACnet object to which to write.
- 6. Enter the **Property Number** of the BACnet property to which to write.
- 7. From the **Property Type** drop-down list, select the data type of the property.
- 8. Enter the BACnet **Priority** used when writing the property. If you enter 0, a non-prioritized write is used.
- 9. Click **OK** to save the settings and return to the System Configuration window.

Action Interlock Operation

Once the Action Interlocks are configured, they are available for assignment to cardholders in the Badge dialog box. The object property defined in the Action Interlock is written with the value associated with the badge. Each badge can be configured to activate up to two Action Interlocks that can be triggered when that badge is granted access.

To Assign Action Interlocks to a Badge:

- From the P2000 Main menu, select Access>Cardholder to open the Cardholder window.
- 2. Select a cardholder from the Cardholder list.
- 3. In the Badge Information box at the bottom of the window, select the badge to which you wish to assign Action Interlocks and click **Edit**.
- Click the Action Interlocks tab. If this is an Enterprise system, see Define Global Badge Access Rights on page 442 for additional information when assigning access privileges to Enterprise badges.

Security Options Access Righ	nts 🛛 Otis Compass Ele	evator Options Action Interlocks	;
Name Lights	•	Value 1	
Name Air Conditioni	ing 💌	Value 5	

- 5. From the **Name** drop-down list, select the first Action Interlock that can be written when this badge is granted access.
- 6. Enter the **Value** to write to the first Action Interlock when this badge is granted access. This value is converted into the correct data type to match the Action Interlock configuration.
- 7. Select the **Name** of the second Action Interlock that can be written when this badge is granted access.
- 8. Enter the Value to write to the second Action Interlock when this badge is granted access. This value is converted into the correct data type to match the Action Interlock configuration.
- 9. When all information is entered, click **OK** to return to the Cardholder window.

M3/M5 Setup

Refer to the *P2000 Metasys*® *Integration Manual* for instructions on setting up M3/M5 Workstations.

Troubleshooting

Duplicate Object Name Errors

The P2000 system may report errors about *Duplicate Object Names* when the BACnet Service is started. The error message gives the name of the object that caused the error. This is caused when the name of one object is the same as another object. All terminals, input points, and output points must be unique from each other. An example is when an input point and an output point have the same name.

To correct the error, rename the object specified in the error message.

Msg Rejected Errors

The P2000 system reports a *Msg Rejected* error when BACnet receives a message from an IP Address that does not correspond to a configured BACnet device. The error message contains the IP Address of the device that sent the message.

To correct the error, add a BACnet device for the IP Address specified in the error message. If this device has no reason to communicate with the P2000 BACnet Interface, click to clear the **Allow** check box.

Action Interlock Errors

When you use Action Interlocks, you may see one of the following error messages:

- ActionInterlock OpenConnection error
- WriteAttributeWait error
- Error writing object

All these errors indicate a failure to write to the object defined in the Action Interlock dialog box. Most likely, the problem is because of incorrect values in the Action Interlock definition. Verify the Object Name, Property Number, and Property Type in the Action Interlock dialog box in the P2000 system. Note that the Object Name must match exactly the name of the object, including the case.

If the Action Interlock is defined correctly, then there is a BACnet communication problem between the P2000 Server and the device containing the object. Verify basic network connectivity using the *ping* command on the P2000 Server to ping the IP address of the device. If you cannot ping the device, then most likely there is a routing problem that is blocking the BACnet broadcast messages between the device and the P2000 Server. Refer to the BACnet Communication Troubleshooting section of your M3/M5 documentation.

Metasys System Integration

This feature allows the P2000 system to be integrated with building management components designed for Metasys system using Web Services technology. The integration provides the ability for objects in the P2000 security system to be viewed from a single user interface, along with all other building systems controlled by the Metasys system. Through this integration, the P2000 system can expose *HostEngine* and *Panel* objects to the Metasys system user interface, allowing clients to browse through the P2000 object tree with the purpose to read object attributes, change those object attributes which are writable, and send commands to objects for readers and output points.

For detailed instructions refer to the *Metasys System Integration* documentation.

Defining MSEA Graphics

The MSEA Graphic feature allows you to assign a graphic reference to P2000 alarms. When the P2000 alarm is received and displayed by the Metasys system, the operator can click the alarm to display the graphic item associated with the alarm and the item that caused the alarm.

Before assigning the MSEA graphic to the alarm (see page 94), you must configure the Fully Qualified Reference Name (FQRN) of the graphic item, as defined by the Metasys system.

To Define MSEA Graphics:

- From the P2000 Main menu, select Config>System. Enter your password if prompted.
- 2. In the System Configuration window, select **MSEA Graphics** and click **Add**. The MSEA Graphic dialog box opens.

C MSEA Graphic	
Name	Door Alarm
Fully Qualified Name	securityMSEA:securityMSEA/Door Alarm
	OK Cancel

3. Enter an alias **Name** for the Fully Qualified graphic reference name.

- 4. Enter the **Fully Qualified Name** of the graphic item, as defined by Metasys system. Fully Qualified Name entries are case sensitive.
- 5. Click **OK** to save the MSEA graphic name.

Registering the P2000 Server with a Site Director

To expose P2000 objects to the Metasys system, you must register the P2000 Server with a Metasys Site Director (ADS/ADX server or NAE controller) by adding a MSEA Registration definition in the P2000 Server. The P2000 system enables you to create multiple MSEA Registration definitions, so you can register the P2000 Server with multiple Site Directors.

Note: If using an NAE controller as the Site Director, contact Johnson Controls Technical Support for assistance.



IMPORTANT: If a NAE controller is used as the Site Director, the controller can only receive four events per second from the P2000 Server. If more than four events are received per second, the NAE may erroneously indicate that the P2000 Server is offline. In addition, you may register certain partitions with a particular Site Director, so that only those P2000 objects associated with the selected partitions are visible from the Metasys system (see the following illustration).



In the previous illustration, the P2000 objects associated with Partition A are only visible from ADS/ADX 1 and NAE 1; the P2000 objects associated with Partition B are only visible from ADS/ADX 2; and the P2000 objects associated with Partition C are only visible from ADS/ADX 2 and NAE 2.

Note: The partition rule previously described has the following exceptions: 1) If you register the **Super User** partition to a particular Site Director, P2000 objects are visible from **all** partitions, even from those that were not registered with the Site Director. 2) Any P2000 device, such as a panel or terminal, set to **Public** is visible from all partitions, regardless of the ones registered to a particular Site Director.

To Register a P2000 Server with one or more Site Directors:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- Select MSEA Registrations and click Add. The MSEA Registration dialog box opens.

C MSEA Registration	
Site Director <u>N</u> ame	securityMSEA
Site Director IP Address	200 . 222 . 135 . 124
Device ID	377
ADS <u>R</u> epository Name	securityMSEA
P2000 Server IP Address	158 . 235 . 255 . 255
Security Warehouse	Available Partitions North Building Super User >>
<u>K</u>	Cancel

- 3. Enter the **Site Director Name** where the Site Director is installed (the server name of the ADS/ADX or the name of the NAE).
- Enter the Site Director IP Address of the server where the Site Director is installed (the IP address of the ADS/ADX or the NAE).
- Enter the Device ID. If the P2000 system communicates with Metasys system Release 2.1 or earlier, contact Johnson Controls Technical Support for assistance. For later releases of the Metasys system, enter 377 or contact Johnson Controls Technical Support for the Device ID used on the version of Metasys you are currently running.

 Enter the ADS Repository Name (computer name) of the Metasys ADS Repository.

Note: The ADS Repository stores messages forwarded by the P2000 system; however, an NAE device used as a Site Director cannot store these messages. If you have an NAE defined as a Site Director, to view messages forwarded from the P2000 system, you must define a valid ADS Repository name for the NAE device. Refer to the Metasys System Integration manual for more information.

- 7. Enter the P2000 Server IP Address.
- 8. In the **Available Partitions** box, select the partition you wish to register with the Metasys Site Director. To assign partitions, simply select one or more partitions and click the left arrow button to move them to the **Selected Partitions** box.
- 9. Click OK to save the MSEA Registration.
- 10. Repeat the previous steps for each Site Director with which you wish to register the P2000 Server.
- To complete the P2000 MSEA Registration, you must stop and restart the P2000 XmIRpc Interface Service. For details, see Starting and Stopping Service Control on page 470.

The P2000 Server should now appear as a device in the Metasys system user interface for the associated Site Director. Refer to the *Metasys System Integration* manual for information on starting and logging into the Metasys system user interface.

Guard Tour

Guard Tour is a sequence of transactions that must be performed within a specified time frame, to ensure your facility is properly monitored by security personnel. The main purpose of a tour is to ensure and record that an area has been physically visited. It provides real-time monitoring of guard activities, reporting if a guard arrives early or late at designated tour stations. Guard Tour stations can be either readers or input points.

Tours may run to occur at regular time intervals or they can be started manually. They can also be run in forward or reverse order.

The P2000 system allows 256 Guard Tour definitions. Each tour may contain up to 16,000 stations, which consists of the individual readers or input points where transactions occur.

If your facility uses the Guard Tour feature, the Guard Tour Service communication starts automatically when the host starts up. Note that GTService can be started and stopped using the P2000 Service Control feature, just like the other P2000 communication services. See Starting and Stopping Service Control on page 470.

Basic Principles and Definitions

Guard Tour – A defined set of check-in stations and minimum and maximum times for checking in at each station.

Check-in Station – Also called simply station. A reader or input point defined as part of a Guard Tour. **Forward** – The expected sequence the tour takes place. Beginning with the starting check-in station, the tour progresses sequentially through all stations in a forward direction. The starting tour station can be selected automatically or manually.

Forward Tour Example





Reverse – The expected sequence the tour takes place. Beginning with the starting check-in station, the tour progresses sequentially through all stations in reverse order. The tour still begins at the starting station, regardless of Forward or Reverse direction. The starting tour station can be selected automatically or manually.

Reverse Tour Example



Tour Stations



Define Tour Stations

Tour Badge – A badge used during an actual

Tour Guard – The name of the person that was

Tour Activation – Guard Tours may be acti-

vated automatically by time zones or start

Tour Abort – The P2000 system discontinues tracking a Guard Tour if 1) the tour Abort Time defined in the tour has exceeded, or 2) an

The basic procedure for defining and imple-

Define cardholders and assign Tour Badges

times, or manually by a system operator.

operator manually aborts a tour.

Sequence of Steps

menting Guard Tours are:

Define system hardware

Configure Guard Tours

guard tour to check-in at readers.

assigned a Tour Badge.

- Control and manipulate Guard Tour activities
- Generate Guard Tour Reports

to the appropriate personnel

Steps to perform each procedure are presented in the following sections.

Defining System Hardware for Guard Tour Operation

Before defining Guard Tours you must properly configure the system hardware and its components; specifically, the readers and inputs points you intend to use in defining tours. If this has not been completed, some of the functions described in this section will not be ready to operate. See Chapter 2: Configuring the System for details.

Assigning Tour Badges

The main purpose of a tour is to ensure and record that an area has been physically visited. While a guard may check-in at a reader defined in a Guard Tour as a station, access through that reader-controlled door may or may not be desired. Use the following instructions to assign badges to cardholders who can participate in guard tour operations.

To Assign a Tour Badge to a Cardholder:

- From the P2000 Main menu, select Access>Cardholder. The Cardholder window opens.
- 2. Create a new record or edit an existing cardholder as desired. For details, see Entering Cardholder Information on page 260.

n ier
Email
Canada W T Canada
Company IXY2 Secondy
Department Security
Guard 🔽
Badges
Start 7/28/2011 Store 8:00:00 AM
End 7/25/2021 V 11:59:00 PM
eh Arress
Menu Permission Group
Passmord
kerprise
Chicago Regional Office Al
Simi Valley
Middles
Select

- 3. In the Other box, click **Guard** to assign a Tour Badge to the selected cardholder. This will be reflected in the Guard column of the Cardholder window.
- 4. Click **Create Badge** at the bottom of the window. The Badge dialog box opens.

C Badge				
Badge				
Partition	Super User		Public	
Number	5587			Auto
Facility Code	Default Facility Code	•	Туре	Access
Alpha	[ssu	e 0 😐	Eormat	<none></none>
Description	Tour Badge		Purpose	<none></none>
Pin			<u>R</u> eason	New
Start	7/ 1/2011 -	8:00:00 AM	Design	<none></none>
End	▼ 10/ 3/2012 ▼ 1	1:59:00 PM		
Sim Valley Entern Security Options Apply Security Disabled Executive Override Special Ac Special Ac	rrise Access Rights Otis C ty Options 'Enterprise' STI E cess A cess B cess C	Security Event F Guard 1	Dptions Action Interle Level 0 rivilege 0 Privilege 0 Our Priority 99	ods
	Apply Access	Rights <pre><none< pre=""></none<></pre>	>	
Du	plicate	Print		Preview
	ОК	Cancel		Apply

- Enter the badge number and optional description. For detailed information, see Entering Badge Information on page 267.
- Click the Security Options tab. If this is an Enterprise system, see Define Global Badge Access Rights on page 442 for additional information when assigning access privileges to Enterprise badges.
- 7. In the Guard Tour box, assign a **Priority** to the Tour Badge.



Guard Tour Priority: When you define a Guard Tour, it is assigned a priority number from 1 to 99. In the cardholder badge record, the Tour Priority

APPLICATION NOTE

determines which tours the selected cardholder can perform. These can be all defined tours with a priority less than or equal to the badge's assigned Tour Priority. For example, a cardholder badge with Tour Priority 45 is authorized to complete tours with a priority of 1 through 45. If the cardholder badge is used to attempt to check-in at stations of a tour defined as priority 46, their badgings is ignored by the Guard Tour. 8. After adding the Tour Badge, click **OK** to return to the Cardholder window.

Configuring Guard Tours

The following steps are used to define Guard Tours. Before proceeding, you must define input points and terminals (readers) to be used in tours. In addition, tour badges should have been assigned to the appropriate cardholders.

Using the Guard Tour Configuration Window

The Guard Tour Configuration window provides quick access to all guard tour component configurations. When you select **Options> Guard Tour>Tour Configuration** from the P2000 Main menu bar, the Guard Tour Configuration window opens, displaying the actual Partition, Workstation, and User Name on the right windowpane. All defined Guard Tours display on the left side of the window. A plus (+) sign next to a defined Guard Tour indicates that Tour Stations exist beneath it. When you select a Guard Tour or Tour Station, the detailed settings and values relating to that selection are listed on the right windowpane.

Note: You cannot edit Tour Definitions or Stations from the Guard Tour Configuration window while a tour is running.

To search for specific items, enter the name of the item in the search field at the top right corner of the window. You can enter complete or partial words; no wildcards are needed, and this field is not case sensitive.

Click **Search**. The window displays the match entered in the search field. Continue clicking **Search** until you find the item you are looking for.

Show For Super I	er 🔹		Search
		,	
C Guard Tours	Item	Value	
🖻 🔁 First Floor, Night Shift	Partition	Super User	
Entrance	Public	Yes	
	Station Name	Entrance	
	Sequence No.	1	
	Description	Lobby and Elevators	
	Station Type	Reader	
	Device Name	Shipping Area Reader	
	Server Type	P2000	
	Server ID		
	Forward TravTime		
	Minimum	2 minute(s)	
	Maximum	4 minute(s)	
	Reverse TravTime		
	Minimum	2 minute(s)	
	Maximum	4 minute(s)	
	Shunt Device Type	Input Point	
	Shunt Device Name	Rolloup Door	
	Shunt Device Attr		
	Activated Device Type 1	Output Point	
	Activated Device Name 1	Alarm Bell	
	Activated Device Attr 1		

To Define a Guard Tour:

- From the P2000 Main menu, select Options>Guard Tour>Tour Configuration. The Guard Tour Configuration window opens.
- 2. Select **Guard Tours** then click **Add** to access the Guard Tour Definition dialog box.
- 3. If this is a partitioned system, select the **Partition** that has access to this Tour, and click **Public** if you wish to make this Tour visible to all partitions.
- 4. Enter the **Tour Name** and optional **Description**.
- 5. From the **Priority** drop-down list, select the tour's priority from 1 (lowest) to 99.

	Partition:	Super User		▼ ▼ Public	:			
	Tour <u>N</u> ame:	First Floor, Night Shift			Priority:	1	•	
	Description:	Finance Building						
	Timezone:		7	т	our Type:	Manual	•	
	Start Time:	L 10:02:09 AM	<u>*</u>	4	Abort Time	5	mins	
	Tour Guard 1:	Evans, Jeff	•	Ba	adge ID 1:	5587		-
	Tour Guard 2:	<none></none>	-	Ba	adge ID 2:			7
	Tour Guard 3:	<none></none>	•	Ba	adge ID 3:			7
	Alarm Priority:	4	•	Set De <u>f</u> au	ult		<u>R</u> eset	
Any Guard		🔽 Alarm Late		🔽 Log j	[our Operal	tion		
Manual Reset		🦳 Alarm Skip		🔽 Log 🤅	Derator A	tion		
🗸 Auto Duress Alarm		🗌 Grant Only				Tour A	larms Setting	
our Stations Information								
Name	Sequence No.	Туре	Device		Descriptio	n		_
Entrance	1	Reader	Shipping Area	a Reader	Lobby an	d Elevators		
•								F
Add Er	dit De	lete						

Only tour badges with equal to or greater than this priority can perform the tour.

6. Select one of the following **Tour Types** from the drop-down list:

Manual – The tour must be initiated manually from the Guard Tour Control window, described on page 395.

Auto Forward – The tour is initiated at a time specified by the Timezone or Start Time fields. The guard is expected to begin at the first defined station and proceed through all stations in a forward direction.

Auto Reverse – The tour is initiated at a time specified by the Timezone or Start Time fields. The guard is expected to begin at the first defined station, and proceed through all stations in a reverse direction.

Random Watch – There is no sequencing in this mode. All defined stations are monitored at all times, until the time entered in the Run Time expires. This is to assure that no station goes unchecked for greater than a specific stated time.

Timezones, Start and Abort Times

If you select Manual as the tour type, the Timezone and Start Time fields are disabled; these are only enabled when you select Auto Forward, Auto Reverse, or Random Watch.

Timezones – The purpose of selecting a Timezone is to provide an automatic starting time for the Guard Tour. You need to define Time Zones before defining Guard Tours. See Time Zones on page 49 for detailed instructions. In the following example, a Time Zone was defined to be assigned to a tour, the start (active) time for the tour is 8:00 p.m. Monday through Friday.

📧 Time Zone					
- Poriodo	<u>N</u> ame: To	ur Schedule			<u>P</u> ar
Fellous					
Monday	Inactive	12:00:00 AM	8:00:00 PM	12:00:00 AM	12:00:0
Tuesday	Inactive	12:00:00 AM	8:00:00 PM	12:00:00 AM	12:00:0
Wednesday	Inactive	12:00:00 AM	8:00:00 PM	12:00:00 AM	12:00:0
Thursday	Inactive	12:00:00 AM	8:00:00 PM	12:00:00 AM	12:00:0
Friday	Inactive	12:00:00 AM	8:00:00 PM	12:00:00 AM	12:00:0
Saturday	Inactive	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:0
Sundau	Inactive	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:0
Holiday 1	Inactive	12:00:00 AM	12:00:00 AM	12:00:00 AM	12:00:0

Note: Stop (inactive) times are not necessary in a Time Zone, unless a Guard Tour is to be run more than once per day. In this case, you would enter a stop time to disable the time zone so it can become active again that day, at another time.

If you define several time blocks, ensure that enough time is allotted between the active and inactive times to realistically complete the tour.

Start Time – When you click the Start Time check box, the Timezone field is automatically disabled. Enter the time (hours and minutes only) the tour is scheduled to start.

Abort Time – Enter the time in minutes (from 2 to 1440). This is the maximum time allowed to expire, before a tour is automatically aborted. This field changes to **Run Time** if Random Watch is selected as the Tour Type.

Note: A tour is automatically aborted only if there are no tour alarms or the Manual Reset option is not enabled.

Once these times are assigned, you can assign the tour to a specific guard, or allow any guard with the appropriate priority to perform the tour.

To Assign the Tour to a Specific Guard:

- In the Guard Tour Definition dialog box, click the **Tour Guard 1** drop-down list and select a name. Only cardholders with the Guard option enabled in the Cardholder Edit dialog box display in the list.
- 2. Once a Tour Guard is selected, the corresponding **Badge ID** field is enabled. Select a badge from the drop-down list. Only badge numbers with priority greater than or equal to the Tour Priority display in the list.
- 3. If you wish to select additional guards, select **Tour Guard 2** and **Tour Guard 3**, and their corresponding **Badge ID** numbers.
- 4. To allow any guard with the proper priority to perform the tour, click the **Any Guard** box. See Additional Guard Tour Options for more information.

Note: One guard can run only one tour at the same time. In addition, one tour can be run only by one guard, even if two guards were to walk the same tour; it is the guard that badged at the initial station who must complete the tour using the same badge at the remaining stations.

Additional Guard Tour Options

The remaining options in the Guard Tour Definition dialog box are described in the following paragraphs.

Alarm Priority – Select from the drop-down list an alarm priority from 0 to 255, in which the Guard Tour alarm message is placed in the queue.

Set Default – Click the **Set Default** button to store the default preference values, which include Tour Priority, Tour Type, Alarm Priority, and all check boxes. **Reset** – Click the **Reset** button to restore the pre-stored preference values.

Any Guard – Click to allow any guard with the proper priority to perform the tour. When you click this box, the Tour Guard 1 to 3 and corresponding Badge ID fields become disabled.

Manual Reset – If selected, the user has to click the **Complete** button in the Guard Tour Control dialog box to remove the tour from the tour list. This is to indicate that the tour has completed.

Auto Duress Alarm – If selected, an auto duress alarm is generated when a guard registers three consecutive times at a station within one minute, for example by swiping the badge three times, or by activating a tour input three times. If Manual Reset is not selected and Auto Duress Alarm is enabled, the tour status changes to Idle after one minute when it completes.

Alarm Late – If selected, an alarm is generated when a guard checks in later than expected at a station. If the check box is not selected and a guard is late, this is simply considered as a tour operation event.

Note: Operation events include, for example, Tour Alarmed, Tour Started, Station Checked in On Time, Station Checked in Early, Station Checked in Late, Station Checked in Out of Order, Tour Stopped, Tour Restarted, Tour Aborted, Tour Completed, Tour Terminated, Station Late Timer Reached.

Alarm Skip – If selected, an alarm is generated when a guard skips a tour station. If the check box is not selected and a guard skips a station, this is simply considered as a tour operation event.

Grant Only – If selected, the system registers only access grant transaction messages when the guard swipes the badge at the station. If not selected, either access grant or deny messages are registered. **Log Tour Operation** – If selected, all tour operation events are logged to the system as events, and therefore are available for history, event processing, and so forth.

Log Operator Action – If selected, all operator actions, such as starting or aborting a tour are logged as events.

Tour Alarms Setting

Tour Alarms Settings enable the Alarm Monitor window to automatically pop up in front of all other windows on the screen whenever a Guard Tour alarm condition occurs.

You can also specify instruction text that displays when an operator responds to a Guard Tour alarm going into a Set or Secure state. Enabling the Popup feature and selecting Instruction Text are independent tasks, and can be used in any combination.

Before you assign instruction text to the various pop ups, you must first create instruction text. See To Create Instruction Text: on page 98.

1. In the Guard Tour Definition dialog box, click **Tour Alarms Setting**. The Guard Tour Alarm Settings dialog box opens.

	Instruction Text Name On Alarm Set
Popup when set	Notify Security
	Instruction Text Name On Alarm Secure
Popup when secure	<none></none>
ut Of Order Alarm	
	Instruction Text Name On Alarm Set
Popup when set	<none></none>
	Instruction Text Name On Alarm Secure
Popup when secure	<none></none>
uress Alarm	
	Instruction Text Name On Alarm Set
Popup when set	<none></none>
	Instruction Text Name On Alarm Secure
Popup when secure	<none></none>

2. Enable any of the following **Popup when** set or **Popup when secure** check boxes, and select the **Instruction Text Name** from the associated drop-down lists that displays in the Alarm Response window whenever any of the following alarm conditions occur:

Late Alarm – An alarm message is generated when a guard checks in later than expected at a station. This option is available if you select Alarm Late in the Guard Tour Definition dialog box.

Out Of Order Alarm – An alarm message is generated if a guard skips a tour station. This option is available if you select Alarm Skip in the Guard Tour Definition dialog box.

Duress Alarm – An alarm message is generated if a guard registers three consecutive times at a station within one minute or by activating a tour input three times. This option is available if you select Auto Duress Alarm in the Guard Tour Definition dialog box.

3. Click **OK** to return to the Guard Tour Definition dialog box.

Adding Stations to the Guard Tour

Tour Station information, such as Station Name, Sequence Number, Type, Device, and Description displays in the list box at the bottom of the Guard Tour Definition dialog box, for all the stations assigned to that Guard Tour.

Guard Tour Stations can be either readers or input points.

To Add Stations to the Guard Tour:

 Click Add at the bottom of the Guard Tour Definition dialog box. The Tour Station Definition dialog box opens showing the Guard Tour Definition name on the title bar. Enter the required information. See Tour Station Definition Fields for detailed information.

Tour Station Definition Fields

Tour Stations Information Box

Station Name – Enter a descriptive name for the station.

Sequence Number – This field displays the number that is automatically assigned when you define a new station. The Tour Stations Information list at the bottom of the Guard Tour Definition dialog box shows the stations assigned to this tour in sequence. You can change the sequence of the stations by clicking the **Up** or **Down** arrows in the Tour Stations Information list box, to change the sequence of the selected station.

Description – Enter a description of this station, if desired.

Station Type – Select either **Input** or **Reader** as the station type.

Server Type – This field is not currently used in this version of the P2000 software.

Device Name – Select a previously defined input point or reader (terminal) that has not been assigned to another station. The list only displays the devices associated with the Station Type. If the input point selected is already assigned to a cabinet door, the Report Alarm option in the Cabinet Configuration dialog box should be selected to be able to report guard tour messages.

IMPORTANT: Do not use Assa Abloy Wi-Fi readers to monitor Guard Tour activities, since those readers do not report transactions in real time and the system cannot verify if a guard checks in at a station on time.

Server ID – This field is not currently used in this version of the P2000 software.

Tour Station Definition - First Fl	oor, Night Shift
Tour Station Information	
Station Name:	Entrance
Sequence Number:	1
Description:	Lobby and Elevators
Station Type:	Reader
Server Type:	P2000
Device Name:	Shipping Area Reader
Server ID:	Y
Traversal Time	
Forwa	rd Traverse Time: MIN 2 minutes MAX 4 minutes
Rever	se Traverse Time: MIN 2 minutes MAX 4 minutes
Shunt Device	
Type:	Input Point Attribute:
Name:	Rolloup Door
Activated Devices 1 & 2 Activated	Device: 3 % 4
Decisión de la construcción de l	
Type: (Dutput Point Type: <none></none>
Name:	Alarm Bell Name:
Attr:	Attr:
Value:	Value:

Traversal Time Box

Traverse Time (**Forward** or **Reverse**) sets the amount of time in minutes a guard has to reach the defined station. The maximum value is 1440 minutes. Traverse Times work in relation to a tour's Start and Abort Times. One of six possible values is assigned when a guard reaches a station:

- Early
- Running
- Late
- Out of Order
- Completed
- Idle

Traverse Times are started at station check-in. For example, suppose the guard reaches station one at the two-minute mark (see illustration). The check-in would be reported as Early and the Traverse Timer for the next station would start. If the minimum and maximum values were set at 2 for station two, the on time check-in for station 2 would be between the 4 and 6-minute marks. These same timing principles apply to all stations defined in the tour as well as Guard Tours designed to run in reverse order.

Note: If the Tour Type selected is Random Watch, the Forward Traverse Time defines how often the guard checks a defined station. Reverse Traverse Time is not available if Random Watch is selected.



Shunt Device Box

During the course of the Guard Tour, you may need to suppress alarms (shunt input points) as part of the tour.

This operation is similar to suppressing an input point or input group as part of an Event, except that an input point or input group remain suppressed until the next station in the tour is reached, a tour alarm is set, or the tour is aborted.

Type – Select either Input Point or Input Group as the Shunt Device Type.

Name – Select a previously defined input point or input group. The list only displays the devices associated with the Shunt Device Type.

Attribute – This field is not currently used in this version of the P2000 software.

Activated Devices Box

During the course of the Guard Tour, you may need to activate devices (set or reset output points) as part of the tour.

This operation is similar to setting or resetting an output point or output group in the main Control menu, except that an output point or output group remain set until the next station in the tour is reached, a tour alarm is set, or the tour is aborted.

Type – Select either Output Point or Output Group as the Activated Device Type.

Name – Select a previously defined output point or output group. The list only displays the devices associated with the Activated Device Type.

Attribute – This field is not currently used in this version of the P2000 software.

Value – This field is not currently used in this version of the P2000 software.

If you wish to activate more than one device, you can define them in the **Device 2** box, then click the **Activated Devices 3 & 4** tab and follow the same steps.

Note: The system does not shunt input points or activate output points assigned to the last station defined in the tour.

Saving the Station as Part of the Tour

After defining a station, click **OK** to return to the Guard Tour Definition dialog box, the station displays in the Tour Stations Information box.

Continue to add stations as necessary. When finished, click **OK** to return to the Guard Tour Configuration window. The Guard Tour is written to the database.

Controlling Guard Tours

Use the Guard Tour Control window to start and stop tours and monitor their progress.

To Control Guard Tours:

- From the P2000 Main menu, select Options>Guard Tour>Tour Control. Enter your password if prompted. The Guard Tour Control dialog box opens.
- 2. Select the **Partition** that contains the Guard Tours you wish to control.
- 3. Select **Active Tours** if you wish to display all tours currently in the status database, for the partition selected, and that are in non-idle state.
- 4. Select **All Tours** if you wish to display all tours currently in the database, for the partition selected, regardless of their state.

🕼 Guard Tour Control									_ 🗆 ×
		Show F	or Super Use	r	•	-			
C Active Tours			,		F	ilter: <a>l	ne>		▼ Sho <u>w</u>
All Tours		Set Alarm <u>⊂</u> olor			S <u>e</u> t Cu	rrent Sort O	rder Default		
Name	Start Time	Guard (Badge)	Last Station	Station Time	Remain Time	Status	Partition	Public	Description
West Wing East Wing	3:10:00 PM 3:45:21 PM	Richard, Bradley(5560)				Idle Stopped	Super User Super User	No Yes	
First Floor, Night Shift Second Floor, Night Shift	3:45:33 PM Tour Schedule	Jeff, Evans(5587) Any Guard			0:03:30	Started Idle	Super User Super User	Yes	Finance Building
4									>
Done	Detail	Start	Stop	Abort		omplete	Note		Refresh
Msg Routing Status		💽 Guard Tour	Service Status						

- Click Set Alarm Color if you wish to display all Alarmed records in a different color. A Color dialog box opens where you select the desired color, then click OK to return to the Guard Tour Control dialog box.
- 6. If you wish to display a specific Guard Tour, use the **Filter** box to enter a filter criteria, such as w*, then click the **Show** button. The list displays all Guard Tours that start with the letter W.

Note: You can also select a previously typed filter from the drop-down list. This list is cleared when your close the Guard Tour Control dialog box.

- To display all Guard Tours again (Active or All), select <none> from the Filter drop-down list.
- If you wish to sort the list of tours shown on the list box, click the specific column header. The current sort order can be set as default by clicking Set Current Sort Order Default. The default sort before clicking this button is by Start Time.

Viewing the Tour Control List Box

The following information is shown for each tour in the list.

Name – The tour name, as configured in the Guard Tour Definition dialog box.

Start Time – This column displays either a defined start time, a Timezone name, or if it was defined as a Manual tour type.

Guard(Badge) – If a tour is assigned to a specific guard, the name displays here with the corresponding Badge ID.

Last Station – Displays the name of the last station that the guard registered at.

Station Time – Displays the time that the guard registered at the last station.

Remain Time – Displays the time remaining for the guard to reach the next station, without being late. The time displayed decreases by 30-second increments if more than one minute remains. If less than one minute remains, the time displayed decreases every one second.

Status – Displays one of the following:

 Alarm – An alarm has occurred within the guard tour, such as guard late or duress.

- **Started** The tour has been started, either manually or automatically, but the first station has not been reached.
- **Running** Status given to an active tour after the first station has been reached.
- **Early** When a tour station check-in is sooner than expected.
- Late When a tour station check-in is later than expected.
- Out of Order When a tour station check-in occurs out of sequence.
- **Stopped** The tour has been manually stopped.
- Aborted The tour has been cancelled either manually or because of an expired Abort Time (stations not reached in time).
- **Completed** The tour has completed successfully without any alarms.
- Idle The tour is not running.

Partition – Displays the partition as configured in the Guard Tour Definition dialog box.

Public – Displays whether or not this guard tour is made public, as configured in the Guard Tour Definition dialog box.

Description – Displays the description of the tour, as configured in the Guard Tour Definition dialog box.

Note: The Message Routing Status indicator at the bottom of the window displays in green to indicate that all communications between the workstation and the Server are up. If communications go down, the Message Routing Status indicator turns red.

The Guard Tour Service Status indicator displays in green to indicate that the Guard Tour Service is up and running. If Guard Tour Service goes down, the indicator turns red.

To Start a Manual Tour:

- 1. Select a tour from the Guard Tour Control list that has a **Manual** tour type in the Start Time column.
- 2. Click **Start** at the bottom of the Guard Tour Control dialog box. The Start Tour dialog box opens.

Start Tour	×
Guard:	Jeff, Evans
Badge:	5587
Starting Station:	Entrance
C Eorward	C <u>R</u> everse
OK	Cancel

- 3. Select the **Guard** assigned to run the selected tour. If only one guard was defined to run this tour, the name of the guard automatically displays on this field.
- 4. Select the guard's **Badge** number. If only one badge was assigned to this guard, that number automatically displays on this field.

Note: If **Any Guard** was selected in the Guard Tour Definition dialog box, the previous fields are disabled.

- 5. From the **Starting Station** drop-down list, select any station in the tour to be station 1.
- 6. Select whether this tour starts in **Forward** or **Reverse** order.
- 7. Click **OK** to start the tour.

Guard Tour Handling

The Guard Tour Service communication checks the Start Time or Timezone definitions every one minute to determine whether to start automatic tours. As an operator or guard, you may be required to handle tour conditions. The tour control typically includes steps similar to the following:

Stopping a Tour – You can temporarily stop a tour by clicking **Stop**. The status of the tour changes to *Stopped*, and the Stop button changes to *Restart*. At this point the tour can be either restarted or aborted.

Restarting a Tour – If the tour has been temporarily stopped or alarmed, you can click **Restart** to update the status of the tour to its previous status, before it was stopped or alarmed.

Aborting a Tour – If you wish to manually end a tour, click Abort. The status changes to *Aborted*, or to *Idle* if Manual Reset was not enabled.

Completing the Tour – When all actions needed to complete a tour have been completed, and Manual Reset was selected in the Guard Tour Definition dialog box, the status of the tour displays as *Completed*, click **Complete** to terminate the tour. The status changes to *Idle*. If Manual Reset was not selected and Auto Duress Alarm is enabled, the status of the tour displays as *Completed* and after one minute changes to *Idle*.

Refreshing the Tour Control window – The Guard Tour Control list is updated every one minute, or when **Refresh** is selected.

Guard Tour Details

You can monitor the activity occurring within Guard Tours. The Detail button on the Guard Tour Control dialog box displays current Guard Tour status information for the selected tour.

To Display Guard Tour Details:

- 1. Select a tour in the list.
- 2. Click **Detail**. The guard tour Details dialog box opens. The top portion of the window shows the tour details.

The scroll list includes a chronological list of all activities for the specific tour, such as events, audits, and operator notes. If Set Alarm Color was selected in the Guard Tour Control dialog box, the alarms display in the color selected.

3. Click **Audit** to display all audit transactions.

	Partition:	Super User	Public:	Yes
	Tour Name:	First Floor, Night Shift	Current Status:	Started
La	ast Station Name:		Last Station Time:	
	Start Time/Date:	5/7/01 3:54:38 PM	Remaining Time:	4 minutes
	Tour Guard:	Evans, Jeff		
	Badge:	5587		
✓ Audit	🔽 Event	Vote	Show Last 3	days Refresh
Date/Time	Туре	Message	Detail	
5/4/01 1:48:44 F 5/4/01 1:30:30 F 5/4/01 1:30:30 F 5/4/01 1:29:54 F 5/4/01 1:29:40 F 5/4/01 1:29:40 F 5/4/01 1:28:18 F	M Event M Event M Audit M Event M Event M Event M Note	Tour Stopped Tour Stated Station Edited Tour Terminated Tour Abotted Tour Stopped Do not stop this tour	By Cardkey By Cardkey North Offices By Cardkey By Cardkey By Cardkey By Cardkey By Cardkey	

- 4. Click **Event** to display all event transactions.
- Click Note to display all Notes related to this tour. See the following section Guard Tour Notes for more information.
- 6. In the **Show Last** box, enter the number of days of tour activity you wish to display.
- 7. Click **Refresh** to update the list.
- 8. Click **Close** to return to the Guard Tour Control dialog box.

Guard Tour Notes

The tour Note dialog box provides a place to enter instructions for a particular tour. The amount of time after which all notes are purged is set up in Site Parameters.

- From the System Configuration window select Site Parameters and click Edit. The Edit Site Parameters dialog box opens at the General tab.
- 2. Click the **Retention Policy** tab and enter the amount of time and select Minutes, Hours, or Days from the **Tour Note** drop-down list, after which all notes are deleted from the system.

Port Configuration RMS EMail Extern	nal Event Trigger MIS We	eb Access
General Printing Panel Types Facility Code F	Retention Policy Password Policy	BACNet D
Retention Time		
Audit	t Trail 30 Days	•
Iransac	ctions 30 Days	•
Al	lar <u>m</u> s 30 Days	•
Muster	Data 30 Days	•
<u>R</u> equest Qu	Queue 30 Days	•
<u>T</u> our I	Note 30 Days	•

3. Click **OK** to save the settings and return to the System Configuration window.

To Add Tour Notes:

- 1. From the Guard Tour Control dialog box, select a non-Idle tour from the list.
- 2. Click Note. The Note dialog box opens.

Note			×
Date/Time	User Name	Note	
5/4/01 1:28:18 PM	Cardkey	Do not stop this tour	
x]			Þ
	[Done	

- 3. Enter the note you want to display in the Detail dialog box.
- 4. Click **Add**. The list box displays the Date and Time the note was added, with the User Name, and the actual note text.
- 5. Click **Done** to return to the Guard Tour Control dialog box.

Viewing and Printing Transactions in Real Time

Tour transactions are sent through real time messages to the Real Time List. You can monitor real time messages, such as tour alarm messages and see the status of a tour. Once the status changes or the tour proceeds, corresponding real time messages are generated. Select the Guard Tour box in the Real Time List window, to display all guard tour transactions as they occur. See Using the Real Time List on page 356 for more information. If you wish to print tour transactions as they occur, you can either print them from the Real Time List window, or select Guard Tour in the Printing tab of Site Parameters. See Printing Tab on page 35 for more information.

Guard Tour Reports

Guard Tour reports are provided as a subset of the standard P2000 report set. For detailed information on running reports, see Chapter 6: System Reports.

Three types of Guard Tour reports are provided: Tour Configuration, Tour Transaction History, and Tour Notes. The following sections describe each of these reports.

Tour Configuration Report

The Tour Configuration report lists by tour name, all tour definition configuration, and associated stations, as set up in the Guard Tour Definition window. When you select **Tour Configuration** from the Run Report window, the Tour Configuration dialog box opens. You can select a **Tour Name** from the drop-down list to limit the report to a specific tour or leave the default (*) to report on all tours configured in the system.

Tour Transaction History Report

This report lists every guard tour transaction in the system, or can be filtered to list by specific Partition, Tour Name, Transaction Type, specific Dates and Times, and any combination of these. In addition, you can select to run the report on transactions at your local site or you can enter the name of the remote site that you want to report on.

When you select **Tour Transaction History** from the Run Report window, the Tour Transaction History dialog box opens. Select either your local Site or enter the name of the remote site that you want to report on. The default (*) reports all tours in the system, or you can select a specific Partition, Tour Name, and Transaction Type from the drop-down lists. After you select a Begin and End Date and Time for the transactions you wish to see, the Tour Transaction History report displays in the Crystal preview window. The top of the report shows the Tour Name, Transaction Type and Site, and the date and time settings selected. Each transaction is listed as a separate date and time stamped record.

Tour Notes Report

This report lists all the tour notes assigned to a specific tour name, as set up in the Guard Tour Control window, or can be filtered to list by specific Tour Name, specific Dates and Times, and any combination of these. When you select Tour Notes from the Run Report window, the Tour Notes dialog box opens. The default (*) reports all tours in the system, or you can select a specific Tour Name from the drop-down list. After you select a Begin and End Date and Time for the notes you wish to see, the Tour Notes report displays in the Crystal preview window. The top of the report shows the date and time settings for the report and the Tour Name selected. Each note is listed as a separate date and time stamped record.

ССТУ

The P2000 system communicates with approved closed circuit television (CCTV) systems via a Host computer connected through an RS-232 serial communications line.

System actions can be sent by CCTV control to the CCTV Switch or run by event actions. The commands can:

- Place a Camera on a Monitor
- Run a Sequence on a Monitor
- Pan, tilt, zoom; focus and control iris functions; and switch on wipers, washers, and lights for a given Camera
- Run Tours and Macros
- Run Patterns and Presets, and use Auxiliaries

Settings and options vary, depending on the type of CCTV Switch selected. Installation of the CCTV equipment is done in accordance with the manufacturers' instructions. For a complete list of the protocols supported by the CCTV feature, see Appendix D: CCTV Switch Protocols.

The following diagram illustrates the possible configurations of the CCTV system equipment. The software provided by the CCTV feature has two main components; the CCTV Server and the CCTV Client. The CCTV Server consists of the OPC Server, drivers, and port controllers, and the CCTV Client consists of the CCTV Configuration and CCTV Control software. For instructions about installing CCTV, refer to the *P2000 Software Installation Manual*.

If your facility uses the CCTV feature, the CCTV communication service (CCTV Server) starts automatically when you start the computer.



Using P2000 functions with the CCTV Feature

The CCTV feature benefits from the following standard P2000 features:

Partitioning – If you are using Partitioning, then the Switch and all the items associated with the Switch should be in the same partition. However, there is no check in the software to prevent a user from setting up partitions that are not practicable. For example, if a Switch is assigned to Partition A, Camera for the Car Park to Partition B and a Preset for the Camera is assigned to Partition A, then users logged on to Partition A would not see the Car Park Camera nor would they be able to run the Preset. You should also take care when assigning partitions as Public. You may prevent logged on users from accessing items, since a user can log on with one partition only.

Menu Permissions – Create and assign menu permissions to perform CCTV Configuration and Control functions.

Event Actions – The equipment connected to the system is capable of responding to event actions started from the P2000 software. For full details, see the appropriate sections later in this chapter and also Creating Actions on page 351.

Audit Trail – Changes to the database are listed in the audit trail. You can use the standard P2000 Audit report for details.

Reports – The CCTV feature provides several standard reports. Details are given at the end of the section. For full details about the standard P2000 reports, see Chapter 6: System Reports.

CCTV Configuration Overview

To operate your Johnson Controls CCTV System, the CCTV feature must be set up and configured to communicate with system hardware. Configuration is typically performed by a System Engineer or System Administrator. Although it is simple to use the CCTV feature on a daily basis, the System Engineer needs some specific knowledge of the CCTV equipment to configure the hardware. The hardware is set up from the CCTV/AV Configuration window.

The CCTV system hardware includes the CCTV Server and Switches, Monitors, and Cameras.

The CCTV Server is OPC (OLE for Process Control) compliant. For further information relating to the OPC Interface Standard, refer to the OPC Foundation Interface Specification.

The CCTV Server and at least one Switch and the CCTV Protocol that it uses must be defined using the CCTV/AV Configuration window. The configuration of the Cameras and Monitors may be automatically generated or customized to your particular requirements. Other items that can be automatically set up or may need to be specifically configured are Alarms, Tours, Macros and System Auxiliaries, Sequences, Patterns, Presets, and Camera Auxiliaries.

Configuration should progress in a logical sequence. For example, you must configure the CCTV Server before you can configure any Switches. If you wish to customize the configuration of the Monitors and Cameras, you must first define the Switch to which they are attached. After the system is configured, you always have the option to return to a component and make changes if necessary.

TIP:

III': We recommend you develop a Naming Plan to apply to Switches, Monitors, and Cameras before you begin programming the software. A fully developed plan can speed the configuration process by creating a quick reference to system component names.

Points to Note

- Changes to the configuration settings do not take effect until you restart the CCTV service. This means that if it is currently running, you need to stop it and then start it.
- As long as you have the CCTV Server and one Switch configured, you can use the equipment using the default settings.
- For better operation, you should define your equipment and give it meaningful names so that operators can quickly understand the system.
- You should be familiar with the individual manufacturer's equipment and how it operates.

Using the CCTV/AV Configuration Window

The CCTV/AV Configuration window provides quick access to all the component configurations. All root items in the CCTV/AV Configuration tree display on the left side of the window (windowpane). A + sign next to an item indicates that branches exist beneath them. When you select a branch in the tree, the detailed settings and values relating to that selection are listed on the right windowpane.

You can add as many items to the CCTV/AV Configuration window as you need. After items have been added, you can edit them as desired. The CCTV/AV Configuration window is accessed from the P2000 Main menu. Select **Options>CCTV/AV>Configuration** from the P2000 Main menu bar and enter your password if prompted. The CCTV/AV Configuration window opens.

To Add an Item to the CCTV/AV Configuration Window:

- 1. On the left pane, select the root icon for the item you wish to add.
- 2. To access configuration dialog boxes, either click **Add** at the bottom of the window or right-click to access a shortcut menu and select **Add**. The appropriate dialog box opens.



- 3. Add the information according to the field definitions and click **OK** to return to the CCTV/AV Configuration window. When dialog boxes offer several configuration tabs, such as in the Edit CCTV Switch dialog box, configure each tab in turn, as applicable. You may be unable to access some tabs until a minimum of information has been entered into the active tab.
- 4. When all settings have been entered, click **OK** to save your settings and return to the CCTV/AV Configuration window. The settings for the new item are listed in the right windowpane.
- 5. Continue to add items in this manner until all items and their related controls have been configured.

To Edit CCTV/AV Configuration Items:

- From the configuration tree, select the item you wish to edit and click Edit at the bottom of the window (or right-click the item and select Edit from the shortcut menu). The Edit dialog box opens.
- 2. After you have completed your changes, click **OK** to save the settings and return to the CCTV/AV Configuration window. The changes are reflected in the right window-pane.

Note: Any changes take effect only after the CCTV Server has been stopped and restarted using Service Control; see Starting and Stopping Service Control on page 470.

Defining System Hardware for the CCTV Feature

Provided you have configured the CCTV Server and at least one Switch, and the Cameras and Monitors are connected to the configured addresses, you do not need to specifically configure any other equipment. The Switch configuration contains the necessary global configuration information for all the Cameras and Monitors connected to it.

However, you may want to define specifically the operation of a piece of equipment. For example you may have one Camera that is fixed, and do not want to enable the move functions when running CCTV Control. In this case you would specifically set up and configure a named Camera. Any functions expressly defined for the named Camera override the global Camera information in the Switch configuration. Similarly, the Camera configuration defines global information about the Auxiliaries, Presets, and Patterns for the Camera, including the number of these items that are to be generated in the namespace. If the Camera definition generates 20 Patterns for example, then the 20 Patterns exist in the namespace tagged with the namespace name. However, the user may wish to give a specific name to the Patterns, in which case each Pattern would need to be specifically set up and defined in the CCTV/AV Configuration window.

Namespace and Database

The software creates a database table and a valid entry for the Switch in the Server namespace. If the system then uses the default settings for the CCTV Switch Protocol, as many entries are added to the namespace as there are default items, but no database tables are created for these items until one of the items has been specifically created, configured, and saved. For example, if you specifically create a Tour, a record is created and it contains information about the named Tour. When you create the Tour, you allocate the Tour a number, which the software uses to create the namespace name (OPC name) for the Tour. The namespace entry is updated from any information in the database when the Server is next started.

Relationship Between the Namespace and Database

The following illustration summarizes how the various system activities relate to the namespace and database.



CCTV Naming Conventions

Where there is a large number of Cameras and Monitors in a CCTV system, we recommend you name the components with a consistent naming scheme. For example, a Camera may be assigned a name that also includes the switch name (OfficeCam1), or it may be named with the location of the Camera (Floor 4), or the area of its view (West Car Park). These names are added to the CCTV database. Using sensible names helps new users of the system.

The CCTV Server namespace names are assigned automatically using the number assigned to the item when it is explicitly or automatically configured.

Naming Items for the CCTV Server Namespace

Each of the items that you define specifically in the CCTV/AV Configuration window is automatically allocated an identifying name that is recognized by the CCTV Server. The name consists of the number of the item and a fixed description. In the case of Cameras and Monitors the number is the physical address that the equipment is wired to at the Switch; in the case of the other Switch elements, the address is a logical address that can be recognized by the Server. The CCTV software assigns the fixed description automatically when the item number is added to the CCTV/AV Configuration window.

The item name is tagged automatically with the inherent names, so that a Pattern for example is recognized by its Switch, Camera, and Pattern name. This means that for example Patterns that are created for different Cameras can have the same number but have a different namespace name.

When you create records in the CCTV/AV Configuration window, you need to enter a number for the address of the item that you are adding. Each number is prefixed by one or two letters. The following table shows the prefix letters and the range of numbers permitted for each item.

Name space Item	Parent Item	Prefix	Range
Switch	Server	S	1 to 9999
Alarm	Switch	AI	1 to 9999
Switch Auxiliary	Switch	Au	1 to 20000
Macro	Switch	Ма	1 to 9999
Tour	Switch	Т	1 to 9999
Monitor	Switch	М	1 to 9999
Monitor Sequence	SwitchMonitor	Se	1 to 9999
Camera	Switch	С	1 to 9999
Camera Auxiliary	SwitchCamera	Au	1 to 8
Camera Presets	SwitchCamera	Pr	1 to 9999
Camera Patterns	SwitchCamera	Pa	1 to 9999

Note that the number of Monitors and Cameras is determined by the capacity of the Switch. The capacity of other items is determined by the hardware and the CCTV Switch Protocol.

Switches must be numbered consecutively starting from S0001.

The CCTV/AV Configuration window automatically inserts the prefix letters for the item. The user selects the number. For Cameras and Monitors this must be the hardware address at the Switch. There is no checking that the number is correct for the Camera or Monitor. Where a large number of Monitors and Cameras is installed it is recommended that the installing engineer develops a plan for the addressing process so that the correct numbers can be entered into the CCTV/AV Configuration window.

It is always a good idea to connect Cameras and Monitors to the low numbered addresses at the Switch, to keep the number of CCTV Server namespace entries as small as possible.

Note that because the CCTV Server system uses intrinsic addressing, it is recommended that you do not change the address of the items once they have been configured. If you do, you may find that actions that use intrinsic addressing (for example, OPCWrite event actions) refer to a different item.

Also, to make it easier for the operator, when configuring the system, Switches numbered S0001 to S0006, Monitors numbered M0001 to M0020 and Cameras numbered C0001 to C0040 should be those that are used most frequently so that the names (or numbers) display on the lists in the CCTV Control dialog box.

Defining the Number of Namespace Items

When you create and configure items for the CCTV Server, you need to give each item in the namespace a number. The range of numbers permitted is dependent on the number of items configured for the namespace.

A powerful feature of the CCTV Server software allows the namespace items to be configured automatically. You can decide whether the total number of items in the namespace is based on the default number of names defined by CCTV Switch Protocol or whether it is based on a specific user defined number.

This feature is extremely valuable for setting up and commissioning the software initially, since you would need only to configure a Server and Switch with the CCTV Switch Protocol defaults, and provided the Cameras and Monitors are physically connected to a valid address at the Switch, you would have a working system.

Number of Default Items Permitted

When a CCTV Server and a Switch are configured, database entries are created for each item. It is not necessary to create named records for the items that belong to a Switch. If you create and configure a CCTV Server and Switch and no other item, the system uses the system default number of namespace items as the maximum number of items that can be addressed by the CCTV Server. The default values are protocol specific; see Appendix D: CCTV Switch Protocols.

You may wish to keep the maximum number of items as the default values; however, if you use fewer or more items of equipment you may wish to change the number of items that are allowed. Note that if you use the system default values for the number of Switch items, no records or database entries are created; the system works from the namespace entries that are automatically created.

Changing the Number of Namespace Items

The default number of Cameras is 64 but your system may use only 25; then there are 39 redundant entries in the namespace. In such a case, it would be advisable to specifically define the number of entries that you want to generate in the namespace. You would change the number of items from the Edit CCTV Switch window by entering the number of items that you want to generate. In this example you would enter 25. This would generate 25 entries numbered from 1 to 25. You would then need to ensure that each Camera is connected to a physical address between 1 and 25.

The number of namespace items generated may be changed at any time but the CCTV Server needs to be stopped and restarted for the changes to be effective.

You should note that the system defaults are not necessarily the maximum capacity for the particular CCTV Switch Protocol. If the number of Cameras to be used is 150, you would configure the Switch to cope with 150 Cameras.

If you select the number of Cameras to be 150, for example, and you specifically define a Camera as number 135, it implies that it is physically connected to address 135 at the Switch. If later you attempt to reduce the number of namespace entries to fewer than 135 you will not be allowed to make the change provided a Camera number 135 is still defined. In this case, the number of namespace entries would be the number of the highest defined Camera.

Switch Protocols

The CCTV Switch Protocol is the protocol that is defined by the manufacturer of the Switch. Each Switch can be associated with one Protocol only, but the system can support Switches using different protocols.

It is also possible to define a Switch that uses a General ASCII protocol. This means in effect that the Switch is a message-handling device. To define a Switch as General ASCII you would enter the item number and then enter the protocol as General ASCII.

Tristate Check Boxes

Ticked	This option is available at the control application
Not ticked	This option is not be available at the control application
Gray ticked	The control options default to the manufacturer's controls

Tristate check boxes allow the following choices:

It would be normal to set the functions to manufacturer's defaults (gray tick).

Any selection made for specific Cameras and Monitors, that is those that have been created in the CCTV/AV Configuration window, override the selections of controls at Switch level.

You should note that the software does not check to see if the equipment can handle the selected functions. When CCTV Control is running the control dialog box may display capabilities that the equipment is unable to perform. For example, if the Camera is a fixed Camera and the configuration setup requested all functions (all check boxes ticked), then the operator would in theory be able the operate the pan, tilt, zoom, and so on options. However, of course in reality there would be no Camera movement.

CCTV Components

Components that operate within the CCTV feature include Servers, Switches, Monitors and Cameras. To speed the configuration process, we recommend that you set up system components in the following order:

CCTV Server – CCTV Server defines information about the CCTV Server. The CCTV Server namespace is initialized from the P2000 database each time that the CCTV Server is started. If the CCTV Server cannot find the P2000 database, then the namespace is initialized from a local copy. However, the local copy will have been made when the P2000 database was last read, so may not be up-to-date.

Switches – Switches define general system information about the Switch and about the global information for Alarms, Auxiliaries, Macros, Tours, Monitors, and Cameras that are connected to the Switch. The Switch also determines how the CCTV Server namespace for this Switch is to be generated. You must define at least one Switch for each configured CCTV Server, but you can install more than one Switch for each CCTV Server.

Monitors – You may specifically define the Monitors that you use on your system and the Sequences that can be played for each Monitor.

Cameras –You may specifically define the Cameras that you use on your system and the controls that are available for this Camera, the Presets, Patterns, and Auxiliaries that can be played for each Camera.

The following sections give details about how to configure and control the CCTV equipment.

To Configure the CCTV Feature:

 From the P2000 Main menu, select Options>CCTV/AV>Configuration. The CCTV/AV Configuration window opens.



IMPORTANT: For any CCTV configuration changes to take effect, the CCTV Server must be stopped and restarted. This should be done on the completion of your configuration session.

When you configure the system for the first time (only), the CCTV/AV Configuration window displays the Server icon. To add a Server, select the displayed icon and click **Add**. Define and save the Server information. The new Server icon displays.

The following setup and configuration sequence is recommended:

- Add a Server
- Create and Configure Switches
- Create and Configure Monitors
- Create and Configure Cameras

If you have not already developed naming conventions for these program elements, we recommend you do so before beginning this procedure. See CCTV Naming Conventions on page 405 for more information.

Item Value □ □ CCTV Switches □ □ □ CCTV Office Partition □ □ CCTV Office No □ □ CCTV Office Public □ □ CCTV Office Public □ □ CCTV Office Public □ □ CTV Office Public □ □ CTV Switch Auxiliaries Posciption □ □ CTV Switch Auxiliaries Foursature □ □ CTV Switch Auxiliaries Foursature □ □ CTV Switch Auxiliaries If Supported □ □ CTV Careara If Supported □ □ CTV Switch Auxiliaries If Supported □ □ CTV Switch Aux If Supported <th>CCTV/AV Configuration Show For Super User</th> <th></th> <th>_ [] ×</th>	CCTV/AV Configuration Show For Super User		_ [] ×
Camera Auxiliary Play If Supported	CTV Switches CTV Switches CTV Office Aarns Macros Tours Monitors Monitors Cameras Care Park Floors 1 2 AV Switches	Item Partition Public Description OPC Name General String Tilt Pan Zoom Focus Iris Iris Automatic Wiper Washer Light Status Lens Speed Lens Speed Max Camera Auxiliaries Camera Auxiliaries Camera Auxiliaries Wardian Play	Value Super User No Floors 1 2 C0002 If Supported If Supp

A fully configured system displays the configured items in the left pane and information about the item in focus in the right pane.

CCTV Server

Create and Configure the CCTV Server

The CCTV Server creates and maintains (in RAM) a namespace, which is made available to all CCTV Controls and other OPC Clients. The namespace contains abstract descriptions of the equipment controlled by the Server. CCTV Controls query the namespace to find out what and how much equipment is available. To send commands to specific items of equipment, values are written to specific namespace positions and the Server interprets and activates these commands accordingly based on the information it has about the various manufacturers' equipment. The CCTV Server installed in your system must be set up and configured in the CCTV/AV Configuration window to establish communication and control. The CCTV/AV Configuration window displays the Server at the highest level.

To Add a Server:

 From the CCTV/AV Configuration window, select Server and click Add. The Edit Server dialog box opens.

Edit Server	X
Partition	Super User
	F Public
Description	
PC Name	
Prog ID	JC.CCTV
	0K. Cancel

- 2. Fill in the information for each field according to the following Edit Server Field Definitions.
- 3. Click **OK** to save the new Server information.

Edit Server Field Definitions

Partition – If partitioning is available, select the Partition that has access to this Server information.

Public – If partitioning is available, click Public to allow all partitions to see this Server.

Note: The CCTV Server must be set to Public if you wish to assign a CCTV Switch or AV Switch in a different partition.

Description – This is a user defined description of up to 64 characters to describe the Server.

PC Name – Enter the name of the computer on which the Server resides. This is the name of the P2000 Server on which you are operating.

Prog ID – An installed Server is associated with a Program ID. Select the Program ID for the Server. The default Program ID for the Server is JC.CCTV. Sub versions may be released from time to time (numbered consecutively starting with JC.CCTV1), but using JC.CCTV ensures that you use the latest version.

Switches

A Switch is a piece of equipment that receives video inputs from Cameras and outputs the data to video outputs such as Monitors. Each Switch operates using the manufacturer's CCTV Switch Protocol; the functionality of the Switch is largely determined by the Protocol provided and the capacity of the equipment connected to the Switch.

Some manufacturers refer to a Matrix, which is sometimes combined with a CPU. This is considered to be a Switch.

Optionally it is possible to define a general purpose Switch that uses a General ASCII Protocol.

Create and Configure Switches

A Switch is connected to a computer and the computer must have the CCTV Server running on it. The Switch has a variety of equipment connected to it, including Cameras, Monitors, and Auxiliaries. Equipment connected to a Switch is presumed to be compatible with the Switch. A Server system may include several separately connected Switches and each may use a different Protocol.

Each Switch installed in your system must be set up and configured in the CCTV/AV Configuration window to establish communication and control. CCTV configuration displays the Server at the highest level. Click the Server icon to display the CCTV Switches icon.

To Add CCTV Switch Definitions:

 From the CCTV/AV Configuration window, select CCTV Switches and click Add. The Edit CCTV Switch dialog box opens at the General tab.

Monitor Sec	uences	Camer	ros 🛛	Comero Pre	rsets	Camera Patte	ms	Comero	Auxiliaries
General	Commun	ications	Alarms	Swit	ch Auxiliaries	Macros	т	ours	Monitor
			Parti	tion Super	User				•
				E Pub	lic				_
			Descrip	bon [
			CCTV Se	ver CCTV	Office				Ψ.
			OPCNa	me				0	
			Proto	col					•
						01	1 0		A

- 2. Fill in the information for each field in each of the tabs. (See Edit CCTV Switch Field Definitions for details.)
- 3. As you work through the tabs, you may click **Apply** to save your entries.
- 4. Click **OK** to save your entries.

When a new Switch is created, the new Switch icon is listed under the root CCTV Switches icon in the CCTV/AV Configuration window, and icons for all Switch components are listed under the new Switch.

Edit CCTV Switch Field Definitions

The Edit CCTV Switch dialog box opens at the General tab. You must enter information in all Edit CCTV Switch tabs to complete your configuration of the Switch.

The General and Communications tabs give information about how the Switch is defined. The other tabs give information about the other elements of the CCTV system that are available to the operator.

However, you should note that even if you enable a function, if that function is not available for the particular protocol then the operator's action would have no effect. The system does not check whether the functions selected at the Switch are compatible with the functionality of the equipment.

You should also note that if you set up global items under the Switch and then create a specific CCTV item (for example a Camera) then the settings defined for the individual item override the global Switch settings.

You need to configure global information about the following components:

- General Tab
- Communications Tab
- Alarms Tab
- Switch Auxiliaries Tab
- Macros Tab
- Tours Tab
- Monitors Tab
- Monitor Sequences Tab
- Cameras Tab

- Camera Presets Tab
- Camera Patterns Tab
- Camera Auxiliaries Tab

Switch General Tab

Monitor Ser	quences	Carner	os 🛛	Co	mera Presets	Ce	mera Patterns	Can	nera Auxiliaries
General	Commu	nications	Ala	rms	Switch Auxilia	ies	Macros	Tours	Monitor
			F	Partition	Super User				<u> </u>
					Public				
			Des	cription	CCTV Office				
			CCTV	Server	OCTV Office				Ψ.
			OPC	Name	S0001			1	
			F	rotocol	JC.CCTVPelcos	760		_	×
									1

Partition – If partitioning is available, select the Partition that has access to this Switch information.

Public – If partitioning is available, click Public to allow all partitions to see this Switch.

Description – This is the user defined name of the Switch. The name displays in the CCTV Control window.

CCTV Server – This is the name of the Server that resides on the computer to which the Switch is physically connected. The software automatically enters this name.

OPC Name – Enter the number of the item. The number is automatically appended to the prefix letter and added to the OPC Name field. For further information about namespace names and item numbers, see Naming Items for the CCTV Server Namespace on page 405.

Protocol – This is the CCTV Switch Protocol for this make and model of Switch. For information about the Protocol, see Switch Protocols on page 407 and Appendix D: CCTV Switch Protocols.

CCTV Switch Communications Tab

Monitor Sequence	s Carner	as Car	mera Presets	Camera Patterns	Camer	a Auxiliaries
General Co	mmunications	Alarms	Switch Auxiliarie	s Macros	Tours	Monitor
	Port COM1		-			
Ba	udrate 9600		•			
D	atabits 8		•			
	Parity ODD		•			
St	op Bits 1		•			
Timeo	ut (ms) 2000					

The manufacturer of the Switch specifies the information entered into the Communications tab. You should refer to the manufacturer's documentation.

Port – This is the COM port to which the Switch is physically connected. Note that the software checks with the Server to establish whether there is a clash in port usage but does not check with any other equipment that may be running.

Baud – This is the Baud for the Switch communications.

Databits – This is the number of Databits for the Switch communications.

Parity – This is the Parity for the Switch communications.

Stop Bits – This is the number of Stop Bits for the Switch communications.

Timeout (ms) – This is the period (in milliseconds) by which the CCTV matrix should have responded. Default for all switches is 2000 ms.

All Other CCTV Switch Tabs

Monitor Sequences		Cameras		mera Presets	Camera Patterns	Camera Auxiliarie	
General	Commun	lications	Alarms	Switch Auxiliaries	s Macros	Tours	Monito
Generate I	Namespace t	on prot	ocol defaults				
C Namespa	e entries to b	e generated				0	_
IZ Play			<u> </u>	Forward			
E Record			코	Backward			
F Stop			키	Step Forward			
I7 Pause			ㅋ	Step Backward			
IZ Restart			R	Camera Forward			
			7	Camera Backward			

Generate namespace based on protocol

defaults – The CCTV Server software provides default values for the maximum number of items that are generated in the namespace. To generate the default value for an item, click this radio button from the appropriate tab. For example, where the default number of Monitors is to be generated, open the Monitors tab and click this radio button. See also Number of Default Items Permitted on page 406.

Namespace entries to be generated – The user can select the number of entries that are to be generated in the namespace. Click this radio button and enter the number of items to be generated in the namespace. See also Defining the Number of Namespace Items on page 406.

Each tab displays the functions appropriate for the item. The associated check boxes are tristate boxes and would normally be gray ticked which is the default setting (see page 407 for further information). The functions available are from the following:

Play – If available, tick the check box to enable Play for the items controlled by this Switch.

Record – If available, tick the check box to enable Record for the items controlled by this Switch.
Stop – If available, tick the check box to enable Stop for the items controlled by this Switch.

Pause – If available, tick the check box to enable Pause for the items controlled by this Switch.

Restart – If available, tick the check box to enable Restart for the items controlled by this Switch.

Forward – If available, tick the check box to enable Forward for the items controlled by this Switch.

Backward – If available, tick the check box to enable Backward for the items controlled by this Switch.

Step Forward – If available, tick the check box to enable Step Forward for the items controlled by this Switch.

Step Backward – If available, tick the check box to enable Step Backward for the items controlled by this Switch.

Camera Forward – If available, tick the check box to enable Camera Forward for the items controlled by this Switch.

Camera Backward – If available, tick the check box to enable Camera Backward for the items controlled by this Switch.

Alarms, Auxiliaries, Macros and Tours

Numbered Alarms, Auxiliaries, Macros, and Tours are automatically defined as part of the Switch definition; specifically named Alarms, Auxiliaries, Macros, or Tours can be defined in the CCTV/AV Configuration window. If the item is a named item, the name displays in the CCTV Control window. Named and numbered items can be used from the CCTV Control window provided the equipment is available and is able to perform the required functions. If the item is an Alarm, when it is played from the CCTV Control window the Alarm is set or reset.

Alarms

A Switch may provide alarms that can be set and reset. In such cases, an Alarm can be used to start a Macro or Tour associated with the same Switch.

Auxiliaries

Switches may provide relays that can be addressed to provide output control functions.

Macros

Macros are programmed sets of steps that are to be performed. The program steps can include any function provided by the associated Switch.

Tours

A Tour is a programmed set of Camera, Monitor, and Preset movements. The functionality of the Tour depends on the capability of the equipment connected to the Switch.

To Add an Alarm, Auxiliary, Macro or Tour:

- 1. In the left pane of the CCTV/AV Configuration window, expand the **Server** name.
- 2. Expand CCTV Switches.

CCTV/AV Configuration	
Show For Super User	Y
Image: Second Second Image: Second Second Second Image: Second Second Second Image: Second Second Second Second Second Second Image: Second Secon	Ben Vake
Done Add	Edit. Dejete Befresh

 Click the appropriate icon (Alarms, Auxiliaries, Macros or Tours) and click Add. The appropriate Edit CCTV dialog box opens.

Edit CCT¥ Alarm					_ 🗆 X
	Partition	Super User			•
		Public			
	Description				
	CCTV Switch	CCTV Office			v
	OPC Name			0	
			OK		Cancel

- 4. Fill in the information for each field according to the Edit CCTV Alarm, Auxiliary, Macro and Tour Field Definitions.
- 5. Click **OK** to save the new information.

Edit CCTV Alarm, Auxiliary, Macro and Tour Field Definitions

Partition – If partitioning is available, select the Partition that has access to this information.

Public – If partitioning is available, click Public to allow all partitions to see this item.

Description – This is the user defined name of the Switch item. The name displays in the CCTV Control window.

CCTV Switch – This is the name of the Switch to which the item is connected. The Switch name is automatically entered into this field.

OPC Name – Enter the number of the item. The number is automatically appended to the prefix letter and added to the OPC Name field. For further information about namespace names and item numbers, see Naming Items for the CCTV Server Namespace on page 405.

Monitors

Create and Configure Monitors

A Switch has a variety of equipment physically connected to it, including Cameras, Monitors, and Auxiliaries.

The Monitors connected to the Switch need not be expressly defined. The Switch can implicitly define several Monitors that are added to the CCTV Server namespace automatically. Any Monitor connected to the Switch are recognized by its physical address. The global functions selected in the Monitor tab in the Switch definition apply to each Monitor connected to the Switch, although the Monitor may not be capable of responding.

For commissioning and testing, there would be no need to explicitly define individual Monitors, in practice there are good reasons for doing so; in particular it simplifies the day to day operation of the system for new users. Therefore, it is recommended that when the system is proven to perform correctly, then the Monitors to be used are defined as named Monitors. See CCTV Naming Conventions on page 405 for more information.

To Add a Named Monitor:

- From the CCTV/AV Configuration window, expand the CCTV Switch that contains the Monitor.
- 2. Select **Monitor** and click **Add**. The Edit CCTV Monitor dialog box opens.

Edit CCTV Monitor	
General Sequences Partition	Super User
Burditio	Public
Description OCTV Switch	CCTV Office
OPC Name	0
General String	
	OK Cancel Apply

- 3. Fill in the information for each field in each of the tabs according to the following field definitions.
- 4. As you work through the tabs, you may click **Apply** to save your entries.
- 5. Click **OK** to save your entries.

Edit CCTV Monitor Tabs

The Edit CCTV Monitor dialog box opens at the General tab. You must enter information in all Edit CCTV Monitor tabs to complete configuration.

- General Tab
- Sequences Tab

The General tab gives information about how the Monitor is defined. The Sequences tab gives information about the Sequence functions that are to be available to the operator from CCTV Control. These definitions override the global settings in the Switch dialog box.

Monitor General Tab

E Edit CCTV Monitor	
General Sequences	
Partition	Super User
	□ Public
Description	Office
OCTV Switch	CCTV Office
OPC Name	M0001
General String	
	OK Cancel Apply

Partition – If partitioning is available, select the Partition that has access to this Monitor information.

Public – If partitioning is available, click Public to allow all partitions to see this Monitor.

Description – This is the user defined name of the Monitor. The name displays in the CCTV Control window.

CCTV Switch – This is the name of the Switch to which the Monitor is physically connected. The Switch name is automatically entered into this field.

OPC Name – Enter the number of the Monitor. The number is automatically appended to the prefix letter and added to the OPC Name field. For further information about namespace names and item numbers, see Naming Items for the CCTV Server Namespace on page 405.

General String – This is any user string that displays when CCTV Control is running.

Monitor Sequences Tab

C Edit CCTV Monitor		×
 Generate Namespace based on pr Namespace entries to be generate 	otocol defaults d	0
다 Play 다 Record 다 Stop 다 Pause 다 Restart	17 Forward 17 Backward 17 Step Forward 17 Step Backward 17 Camera Forward 17 Camera Backward	
	0	K Cancel Apply

Generate namespace based on protocol

defaults – The CCTV Server software provides default values for the maximum number of items that are generated in the namespace. To generate the default value for an item, click this radio button from the appropriate tab. For example, where the default number of Sequences is to be generated, open the Sequences tab and click this radio button. See also Number of Default Items Permitted on page 406.

Namespace entries to be generated – The user can select the number of entries that are to be generated in the namespace. Click this radio button and enter the number of items to be generated in the namespace. See also Defining the Number of Namespace Items on page 406.

Select the functions that are available for Sequences that are controlled by this Monitor. The associated check boxes are tristate boxes and would normally be gray ticked. The functions available are from the following:

Play – If available, tick the check box to enable Play for Sequences controlled by this Monitor.

Record – If available, tick the check box to enable Record for Sequences controlled by this Monitor.

Stop – If available, tick the check box to enable Stop for Sequences controlled by this Monitor.

Pause – If available, tick the check box to enable Pause for Sequences controlled by this Monitor.

Restart – If available, tick the check box to enable Restart for Sequences controlled by this Monitor.

Forward – If available, tick the check box to enable Forward for Sequences controlled by this Monitor.

Backward – If available, tick the check box to enable Backward for Sequences controlled by this Monitor.

Step Forward – If available, tick the check box to enable Step Forward for Sequences controlled by this Monitor.

Step Backward – If available, tick the check box to enable Step Backward for Sequences controlled by this Monitor.

Camera Forward – If available, tick the check box to enable Camera Forward for Sequences controlled by this Monitor.

Camera Backward – If available, tick the check box to enable Camera Backward for Sequences controlled by this Monitor.

Sequences

A Sequence is similar to a Tour except that it applies to a single Monitor. A Sequence is a set of programmed Camera, Monitor, and Preset movements.

A Sequence is defined in the CCTV/AV Configuration window, either by default from the Switch or Monitor or by being specifically named. The Sequence is played from the CCTV Control window. A numbered Sequence is defined as part of the Switch or Monitor definition; a specifically named Sequence can be defined in the CCTV/AV Configuration window. If the Sequence is a named item, the name displays in the CCTV Control window. Named and numbered Sequences can be used from the CCTV Control window provided the equipment is available and is able to perform the required functions.

To Add a Named Monitor Sequence:

- From the CCTV/AV Configuration window, expand the CCTV Switch that contains the Monitor.
- 2. Expand the **Monitor** that contains the Sequence.
- 3. Select **Sequence** and click **Add**. The Edit CCTV Sequence dialog box opens.

Edit CCTV Sequence	_ 🗆 🗵
Partitic	Super User
	Public
Descriptio	n 📃
CCTV Monito	or Office
OPC Nam	e 0
	OK Cancel

- 4. Fill in the information for each field according to the Edit CCTV Sequence Field Definitions.
- 5. Click **OK** to save your entries.

Edit CCTV Sequence Field Definitions

Partition – If partitioning is available, select the Partition that has access to this Sequence information.

Public – If partitioning is available, click Public to allow all partitions to see this Sequence.

Description – This is the user defined name of the Monitor Sequence. The name displays in the CCTV Control window.

CCTV Monitor – This is the name of the Monitor to which the Sequence is connected. The Monitor name is automatically entered into this field.

OPC Name – Enter the number of the Sequence. The number is automatically appended to the prefix letter and added to the OPC Name field. For further information about namespace names and item numbers, see Naming Items for the CCTV Server Namespace on page 405.

Cameras

Create and Configure Cameras

A Switch has a variety of equipment physically connected to it, including Cameras, Monitors, and Auxiliaries. The Cameras connected to the Switch need not be expressly defined. The Switch can implicitly define several Cameras that are added to the CCTV Server namespace automatically. Any Camera connected to the Switch is recognized by its physical address. The global functions selected in the Camera tab in the Switch definition apply to each Camera connected to the Switch, although the Camera may not be capable of responding.

Although for commissioning and testing, there would be no need to explicitly define individual Cameras, in practice there are good reasons for doing so. Therefore, it is recommended that when the system is proven to perform correctly, then the Cameras to be used are defined as named Cameras. See CCTV Naming Conventions on page 405 for more information.

To Add a Named Camera:

- From the CCTV/AV Configuration window, expand the CCTV Switch that contains the Camera.
- 2. Select **Camera** and click **Add**. The Edit CCTV Camera dialog box opens.

C Edit CCTV Camera	×
General Controls Presets Auxiliaries Patterns	
Patition	Super User
	E Public
Description	
CCTV Switch	CCTV Office
OPC Name	0
	OK Cancel Apply

- 3. Fill in the information for each field according to the following field definitions.
- 4. As you work through the tabs, you may click **Apply** to save your entries.
- 5. Click OK to save your entries.

Edit CCTV Camera Tabs

The Edit CCTV Camera dialog box opens at the General tab. You must enter information in all Edit CCTV Camera tabs to complete configuration.

- General Tab
- Controls Tab
- Presets Tab
- Auxiliaries Tab
- Patterns Tab

The General and Controls tabs give information about how the Camera is defined. The other tabs give information about the elements of this particular Camera that are to be available to the operator. These definitions override the global settings in the CCTV Switch dialog box.

Camera General Tab

5 Edit CCT¥ Camera	
General Controls Presets Auxiliaries Patterns	
.	
Parttion	Super User
Description	Fubic
Description	
UCIV Switch	
OPC Name	2 2
	OK Cancel Apply

Partition – If partitioning is available, select the Partition that has access to this Camera information.

Public – If partitioning is available, click Public to allow all partitions to see this Camera.

Description – This is the user defined name of the Camera. The name displays in the CCTV Control window.

CCTV Switch – This is the name of the Switch to which the Camera is physically connected. The Switch name is automatically entered into this field.

OPC Name – Enter the number of the Camera. The number is automatically appended to the prefix letter and added to the OPC Name field. For further information about namespace names and item numbers, see Naming Items for the CCTV Server Namespace on page 405.

Camera Controls Tab

If the majority of your Cameras are of one type (fixed for example), it would be advisable to select the Camera functions that apply to the majority (for example leave the moving functions, Pan, Tilt, and so on, unselected). You would then be able to specifically configure those Cameras that have different capabilities.

IV Washer IV Light IV Status	
	OK Cancel Apply
General String - T	This is up to 64 characters th
may display at the	e Monitor when the Camer
is operating from	the CCTV Control window
provided the prot	ocol allows it. It could be the
name of the Cam	era or a description of the

Lens Speed 1

ns Speed Max 👖

C Edit CCTV Ca

General Controls Presets Auxiliaries Patterns

General String

provided the protocol allows it. It could be the name of the Camera or a description of the location of the Camera. This is an optional field.

Note that the following check boxes are tristate boxes.

Tilt – If available, tick the check box to enable Tilt for this Camera.

Pan – If available, tick the check box to enable Pan for this Camera.

Zoom – If available, tick the check box to enable Zoom for this Camera.

Focus – If available, tick the check box to enable Focus for this Camera.

The following check boxes are two state check boxes:

Iris – If available, tick the check box to enable Iris for this Camera.

Iris Automatic – If available, tick the check box to enable Iris Automatic for this Camera.

Wiper – If available, tick the check box to enable Wiper for this Camera.

Washer – If available, tick the check box to enable Washer for this Camera.

Light – If available, tick the check box to enable Light for this Camera.

Status – If available, tick the check box to enable Status for this Camera.

Camera Presets, Auxiliaries, and Patterns Tabs

G Edit CETV Camera	×
General Controls Presets Auxiliaries Patterns	
Generate Namespace based on protocol defaults	
C Namespace entries to be generated	0
2	,
I Play I Forward	
I Record I Backward	
I Stop I Step Forward	
✓ Pause ✓ Step Backward	
I Restart	
OK	Cancel Apply

Generate namespace based on protocol

defaults – The CCTV Server software provides default values for the maximum number of items that are generated in the namespace. To generate the default value for an item, click this radio button from the appropriate tab. For example, where the default number of Patterns is to be generated, open the Patterns tab and click this radio button. See also Number of Default Items Permitted on page 406.

Namespace entries to be generated – The user can select the number of entries that are to be generated in the namespace. Click this radio button and enter the number of items to be generated in the namespace. See also Defining the Number of Namespace Items on page 406.

Select the functions that are available for Presets, Auxiliaries, and Patterns that are controlled by this Camera. Note that the check boxes are tristate boxes.

Play – If available, tick the check box to enable Play for the items controlled by this Camera.

Record – If available, tick the check box to enable Record for the items controlled by this Camera.

Stop – If available, tick the check box to enable Stop for the item controlled by this Camera.

Pause – If available, tick the check box to enable Pause for the item controlled by this Camera.

Restart – If available, tick the check box to enable Restart for the item controlled by this Camera.

Forward – If available, tick the check box to enable Forward for the items controlled by this Camera.

Backward – If available, tick the check box to enable Backward for the items controlled by this Camera.

Step Forward – If available, tick the check box to enable Step Forward for the items controlled by this Camera.

Step Backward – If available, tick the check box to enable Step Backward for the items controlled by this Camera.

Camera Auxiliaries, Patterns and Presets

Numbered Camera Auxiliaries, Patterns, and Presets are defined as part of the Switch or Camera definition; specifically named Camera Auxiliaries, Patterns and Presets can be defined in the CCTV/AV Configuration window. If the item is a named item, the name displays in the CCTV Control window. Named and numbered Camera Auxiliaries, Patterns and Presets can be used from the CCTV Control window provided the equipment is available and is able to perform the required functions.

Camera Auxiliaries

Cameras may provide relays that can be addressed to provide output control functions. Camera Auxiliaries perform according to the capability of the hardware and the Switch CCTV Protocol.

Patterns

A Pattern is user defined viewable Camera path with a beginning and an end. According to the capability of the hardware and the Switch CCTV Protocol, a Pattern may be required to complete within a specified time.

Presets

A preset camera position is a user defined position which may include pan, tilt, zoom and focus adjustments.

To Add a Named Camera Item:

- From the CCTV/AV Configuration window, expand the CCTV Switch that contains the Camera.
- 2. Expand the Camera that contains the item.
- 3. Select the appropriate icon (Auxiliary, Pattern or Preset) and click **Add**. The appropriate **Edit CCTV** dialog box opens.

Super User
Public
Floors 1 2
0
OK. Cancel

- 4. Fill in the information for each field according to the following field definitions.
- 5. Click OK to save your entries.

Edit CCTV Named Camera Item Field Definitions

Partition – If partitioning is available, select the Partition that has access to this Camera item information.

Public – If partitioning is available, click Public to allow all partitions to see this item.

Description – This is the user defined name of the Camera item. The name displays in the CCTV Control window.

CCTV Camera – This is the name of the Camera to which the item is connected. The Camera name is automatically entered into this field.

OPC Name – Enter the number of the item. The number is automatically appended to the prefix letter and added to the OPC Name field. For further information about namespace names and item numbers, see Naming Items for the CCTV Server Namespace on page 405.

CCTV Control

The CCTV Control software is part of the CCTV Server system. It provides controls to operate the Cameras and Monitors that are part of the CCTV system. In addition, it also provides the controls to select and use Alarms, Macros, Auxiliaries, and Tours from the Switches, Sequences from the Monitors and Patterns, Presets, and Auxiliaries from the Cameras.

To Run CCTV Control:

- From the P2000 Main menu, select Options>CCTV/AV>Control. The CCTV Control dialog box opens.
- 2. If you have multiple servers, select a **Server** from the drop-down list. The Server to select depends on the configuration of your system and the number of Servers that are installed.

	Server P2000	CCTV	ierver	T	
	Letter Letter				5.8.4
'lonitor —					Switch
No.	Description				GST Master Switch 💌 🦉
0001	GST Mon Ext 1				
0002	GST Mon Ext 2		Commenter Const	01 -	G Terra
0003	GST Mon Ext 3		sequence seco	01 <u> </u>	Wordt Doors
0004	GST Mon Ext 4				C Martin Dath Marthautan
0005	M0005		>> 44		Daily Monicoring
0006	M0006				C Aux GST Aux 1
0007	M0007				
0008	M0008				
0009	M0009	-			
amera -					
No.	Description		C Dattorn	D-0001	카이아 부모 것이
0001	North Terminal Station		Pattern	F80001	
0002	North Satellite Station		Preset	Pr0001	지 도 그는 것 ㅋ
0003	South Shuttle		10000	110001	■ _ l _ `++r´ _ l
0004	Concourse Left		CAUX	au0001	7
0005	South Terminal Station		- MUX	M00001	
0006	C0006				
0007	C0007				
8000	C0008				
0009	C0009		Winer	Washer	
1 0010	C0010				Nudge factor[1100] 10
0011	C0011				
0011	C0012				
0011 0012 0013	C0012				
0011 0012 0013 0014	C0012 C0013 C0014			Eccus	īris Light
0011 0012 0013 0014 0015	C0012 C0013 C0014 C0015		Zoom	Focus	Iris Light
0011 0012 0013 0014 0015 0016	C0012 C0013 C0014 C0015 C0016		Zoom	Focus	Iris Light

CCTV Standard Controls

Selecting the Item to Control

The Switch is selected from a drop-down list or by directly entering the switch number. Monitors and Cameras are selected by clicking the item from their respective list boxes.

The items displayed in the CCTV Control window depend on the configuration of your system. If the equipment is configured and named, the name displays on the lists; otherwise, the namespace name displays.

Other items (such as Camera Patterns or Switch Tours) are selected from drop-down lists or by directly entering the item number.

Operating the Controls

You can perform CCTV functions from the P2000 computer or a workstation using the CCTV Control window. Switch Tours, Macros and Auxiliaries; Monitor Sequences; and Camera Patterns, Presets, and Auxiliaries that have been configured can be activated and controlled from this window.

You should note that if the CCTV equipment is capable of operating from its own control device (a keyboard for example), then that control device would need to release control to operate the equipment from the P2000 CCTV Control. Similarly, CCTV Control would need to release control for the device to function correctly.

The following control buttons may be available depending on the availability of the functions for the selected equipment:



Step Backward



In addition, the following Camera controls may be available:



Using Switch Controls

The Switch box provides the controls that allow you to select a Switch and select and use Tours, Macros, and Switch Auxiliary functions for the selected Switch if they are available. A Tour is a programmed set of Camera, Monitor and Preset selections. Macros are programmed sets of steps that are to be performed. The program steps can include any function provided by the associated Switch. Switch Auxiliaries can be activated using the control buttons in the Switch box.

Switch					
GST Master Sv	GST Master Switch 🛛 🔽 📀				
C Tour	North Doors	~			
C Macro	Ma0002	-			
• Aux	GST Aux 1				

Selecting a Switch

Only switches that are configured for the selected CCTV Server are displayed in the Switch drop-down list. A switch is selected either from the drop-down list or by entering the switch number in the Switch field.

If a switch button is red the switch has communication problems. The associated error message displays below the Camera list box.

Selecting a Tour, Macro or Switch Auxiliary

A Tour, Macro, or Switch Auxiliary is selected either from the associated drop-down list or by entering the item number in the respective field.

Using Tour, Macro or Switch Auxiliary Controls

The precise functions of the Tour, Macro, and Switch Auxiliary controls depend on the Protocol for the associated Switch and their application by the CCTV Server system. The controls that may be available are as follows:

Step Backward – The Tour moves back to the previous Camera, or if the Tour is playing forward, reverses the sequence of operation.

Step Forward – The Tour moves forward to the next Camera, or if the Tour is playing backward, reverses the sequence of operation.

Restart – If the function has been stopped, the restart button starts the selected Tour or Macro from the beginning.

Pause – This stops the selected Tour or Macro running but allows you to continue playing from the point at which the Tour or Macro stopped.

Play – This activates the selected Tour, Macro, or Switch Auxiliary.

Stop – This stops the selected Tour, Macro, or Switch Auxiliary. With some equipment the stop button may also stop recording a Tour or Macro. **Record** – You record Tours and Macros by clicking the record button and then playing the required sequence of activities. The sequence of activities is dependent on the functions available for the protocol and the equipment installed. Stopping recording also depends on the protocol but recording probably stops if you click either the record button again or the stop button. You should consult the manuals supplied with the CCTV equipment for your site for full details.

Note that Tours, Macros and Sequences for some manufacturers can only be recorded using their proprietary setup methods. However, they can still be played using the play control described here.

Using the Monitor Controls

The Monitor list box allows you to select a Monitor and select and use Sequence functions for the selected Monitor if they are available.

Ľ.	1onitor —			
	No.	Description	•	
	0001	GST Mon Ext 1		
	0002	GST Mon Ext 2		Sequence Se0001
	0003	GST Mon Ext 3	_	Seddence Secont
	0004	GST Mon Ext 4		
	0005	M0005		▶ ▶ ◀◀ ▶ Ⅱ ▶ ■ ●
	0006	M0006		
	0007	M0007		
	0008	M0008		
	0009	M0009	•	
	·		 _	

Selecting a Monitor

The number of monitors displayed in the Monitor list box depends on the configuration of your system. If the monitor is configured and named, the name displays on the list, otherwise the namespace name displays. Click the monitor name to select the monitor you wish to control.

Selecting a Sequence

A sequence is selected either from the Sequence drop-down list or by entering the number in the Sequence field.

Using Sequence Controls

The precise functions of the Sequence controls depend on the Protocol for the associated Switch and their application by the CCTV Server system. The controls that may be available, depending on the selected Switch, are as follows:

Step Backward – The Sequence moves back to the previous Camera, or if the Sequence is playing forward, reverses the sequence of operation.

Step Forward – The Sequence moves forward to the next Camera, or if the Sequence is playing backward, reverses the sequence of operation.

Restart – If the function has been stopped, the restart button starts the selected Sequence from the beginning.

Pause – Stops the selected Sequence running but allows you to continue playing from the point at which the Sequence stopped.

Play – Activates the selected Sequence.

Stop – Stops the selected Sequence. With some equipment the stop button may also stop recording a Sequence.

Record – You record a Sequence by clicking the record button and then playing the required sequence of activities. The sequence of activities is dependent on the functions available for the protocol and the equipment installed. Stopping recording also depends on the protocol but recording probably stops if you click either the record button again or the stop button. You should consult the manuals supplied with the CCTV equipment for your site for full details.

Using the Camera Controls

The Camera list box allows you to select a Camera and select and use Patterns, Presets and Camera Auxiliary functions for the selected Camera if they are available.



Selecting a Camera

The number of cameras displayed in the Camera list box depends on the configuration of your system. If the camera is configured and named, the name displays on the list, otherwise the namespace name displays. Click the camera name to select the camera you wish to control.

Selecting a Pattern, Preset or Camera Auxiliary

A Pattern, Preset or Camera Auxiliary is selected either from the associated drop-down list or by entering the item number in the respective field.

Using Pattern, Preset or Camera Auxiliary Controls

The precise functions of the controls depend on the Protocol for the associated Switch and their application by the CCTV Server system. The controls that may be available, depending on the selected Switch, are as follows:

Step Backward – The Pattern moves back to the last Camera, or if the Pattern is playing forward, reverses the sequence of operation.

Step Forward – The Pattern moves forward to the next Camera, or if the Pattern is playing backward, reverses the sequence of operation.

Play – This activates the selected Pattern, Preset, or Camera Auxiliary.

Stop – This stops the selected Pattern or Camera Auxiliary. With some equipment the stop button may also stop recording a Pattern.

Record – You record a Pattern or Preset by clicking the record button and then playing the required sequence of activities. The sequence of activities is dependent on the functions available for the protocol and the equipment installed. Stopping recording also depends on the protocol but recording probably stops if you click either the record button again or the stop button. You should consult the manuals supplied with the CCTV equipment for your site for full details.

Pan/Tilt – Click and hold down the mouse on the movement control square in the Pan/Tilt area to move the selected Camera. The movement control returns to the center of the Pan/Tilt area when at rest. The position of the Camera is as is and not centered. To Pan the Camera you move the movement control along the horizontal; to tilt the Camera you move the Camera along the vertical. Movements between the horizontal and vertical are proportional. The further from the center, the faster the movement. The selected Camera can also be moved using the nudge arrows on each side of the Pan/Tilt area. The Camera moves at a speed defined by the nudge factor. The nudge factor is a value in the range 1 to 100 which determines the speed of the Camera movements. The larger the number, the faster the Camera movements.

Wiper – There are two wiper buttons. The left button switches off the Camera wiper; the right button switches on the Camera wiper.

Washer – There are two washer buttons. The left button switches off the Camera washer; the right button switches on the Camera washer.

Zoom – There are two Zoom buttons. The left button zooms out from the object; the right button zooms in on the object.

Focus – There are two Focus buttons. The left button focuses on far objects; the right button focused on near objects.

lris – There are two Iris buttons. The left button closes the iris; the right button opens the iris.

Light – There are two light buttons. The left button switches off the Camera light; the right button switches on the Camera light.

To Set Up a Preset:

This example is to illustrate how to use the CCTV controls to set up a Preset. Other functions would be set up in a similar way. It should be noted that the Preset runs only if the equipment supports these functions.

- 1. Select the Switch.
- 2. Select the Monitor.
- 3. Select the Camera.
- 4. Using the controls available (Pan/Tilt, Zoom, and so on), move the Camera to the position that is to be recorded as the Preset position.

- 5. Select the Preset number either from the Preset drop-down list or by entering the number in the Preset field.
- 6. Click the Record button.

If the Preset is not already named, you may want to name it. To do this, you would need to run CCTV Configuration. The associated camera would also need to be named before the Preset can be named. For details about naming Cameras and Presets, see Create and Configure Cameras on page 417. You would need to stop the CCTV service and start it again for the named item to be available in CCTV Control.

CCTV Event Actions

CCTV Event Actions are a category of the standard P2000 event action dialog box. If your facility uses the CCTV feature, you can add event actions for Switches, Monitors and Cameras. Note that event actions that are created for the category CCTV are sent via the CCTV Server, which is an OPC Server. CCTV events can therefore be created either by selecting the category CCTV from the Action dialog box or if the action that you wish to define is not available from the category CCTV or you have not fully configured the CCTV equipment from the CCTV/AV Configuration window, you can select OPC Server as the category and write an OPCWrite action.

If you chose CCTV as the category in effect, you are building an OPC Server namespace tag from your field selections. However, when you select the equipment, if you are building a CCTV action you can select it by the name that you gave it when the item was configured and the namespace tag is selected from a drop down list of action types. If you are building an OPC Server tag you are going to select an intrinsic name (that is, the default namespace name, s0001 for example). The value for an OPC Server tag is the value of the action type associated with the namespace. Full details of the namespace tags and their values are given in Appendix E: CCTV Server Namespace Definitions.

IMPORTANT: Do not configure OPC Server Event actions before reading and understanding OPC Server. If OPC Server Event actions are not configured correctly, the equipment may not work properly.

The following notes apply to CCTV actions as well as to OPC Server events:

- If the computer on which the selected Server resides is switched off, then the event would have no effect.
- However, if the computer is on and the OPC Server has been switched off, then the event would only be acted upon if the appropriate launch and access rights are granted.
- Similarly, if the computer and the OPC Server are running then the event would only be acted upon if it has the correct access rights (that is, the sending user and password must be correctly set up at the receiving computer together with the correct DCOM rights). Note that the set up is correct when the software is installed. For more information, see Appendix F: DCOM Configuration.
- Some CCTV equipment may need to gain control from other control devices (a keyboard for example) before event actions such as pan, tilt and focus can function correctly. You would need to be familiar with the operating requirements of the particular equipment.

To create a CCTV event action:

You would create a CCTV action in the same way as any other event action (see Creating Actions on page 351 for further details). You would normally select the CCTV category to add your CCTV event action but you may choose the Category OPC Server and Type OPCWrite.

CCTV Event Action Field Definitions

If CCTV is selected as the Category then the following fields display:

Type – Select from the drop-down list of available action types; see Appendix A: Event Triggers/Actions for details.

Items – Select the equipment that is to be acted upon. The selection is dependent on the type. For example, if you select a Switch Alarm action type, then you need to select the Switch and the Alarm from those configured that are to be associated with the action.

If OPCWrite is selected as the Type for the Category OPC Server then the following fields display:

OPC Tag – Select an OPC Tag from those available for the selected OPC Server. The field is associated with a Browse button, which allows you to display a list of those available for the selected server. For a complete list of the CCTV Server namespace tags and their values, see Appendix E: CCTV Server Namespace Definitions.

Value – Enter the value that is to apply to the OPC Tag.

Data Type – Select the data type appropriate for the event action value from the drop-down list.

Note that if you are defining a CCTV Server tag, you should select the Program ID JC.CCTV to ensure that all versions of the interface are supported.

CCTV Reports

CCTV reports are provided as a subset of the standard P2000 report set. For detailed information on running reports, see Chapter 6: System Reports.

Four types of CCTV reports are available: CCTV Switch, CCTV Monitor, CCTV Camera, and CCTV Summary. The following sections describe each of these reports.

CCTV Switch Report

The CCTV Switch report lists by name all Switches specifically configured in the CCTV/AV Configuration window. When you select **CCTV Switch** from the Run Report window, the CCTV Switch dialog box opens. You can select a **Server Name** and a **Switch Name** from the drop-down lists to limit the report to specific Switches or leave the default (*) to report on all switches defined for all servers.

CCTV Monitor Report

The CCTV Monitor report lists by name all Monitors specifically configured in the CCTV/ AV Configuration window. When you select **CCTV Monitor** from the Run Report window, the CCTV Monitor dialog box opens. You can select a **Server Name** and a **Switch Name** from the drop-down lists to limit the report to Monitors associated with a specific Switch or Server, or leave the default (*) to report on all Monitors defined for all switches and servers.

CCTV Camera Report

The CCTV Camera report lists by name all Cameras specifically configured in the CCTV/ AV Configuration window. When you select **CCTV Camera** from the Run Report window, the CCTV Camera dialog box opens. You can select a **Server Name** and a **Switch Name** from the drop-down lists to limit the report to Cameras associated with a specific Switch or Server, or leave the default (*) to report on all Cameras defined for all switches and servers.

CCTV Summary Report

The CCTV Summary report lists by name all items defined in the CCTV/AV Configuration window. When you select **CCTV Summary** from the Run Report window, the CCTV Summary dialog box opens. You can select a **Server Name** and a **Switch Name** from the drop-down lists to limit the report to items associated with a specific Switch or Server, or leave the default (*) to report on all items defined for all switches and servers.

DVR

The P2000 system provides seamless integration with approved Digital Video Recording (DVR) systems. The integration allows authorized users to manage camera functions from a single P2000 workstation, and to tie an event generated on the P2000 system to a live audio-visual (AV) recording. Depending on the DVR equipment used at the site, the P2000 system also enables users to search, retrieve, and download real-time or archived AV recordings from any transaction or surveillance camera, from any place and at any time. You can recall audio-visual files by a variety of query options, including date and time, alarm events, camera ID, or DVR ID. Live video and audio playback options are available from the Alarm Monitor, Real Time List, and Real Time Map.

The DVR system communicates with the P2000 Server via a TCP/IP connection. The P2000 CCTV Server, a software component installed automatically with the DVR option, provides communication.

Additionally, you can configure the DVR feature with a CCTV Switch for added control of the CCTV cameras and monitors. For detailed configuration instructions, refer to the *DVR Integration* documentation.

Redundancy

Johnson Controls provides a Fault Tolerance solution (with Marathon everRun FTTM) to their P2000 Security Management System.

Marathon Technologies everRun software runs on standard Windows servers and provides a high availability solution for the P2000 Security Management System.

The Marathon everRun FT software is layered on to standard Microsoft server software. It creates the Marathon FTvirtual Server[™], ensures *lockstep* process, and maintains full data integrity between two redundant physical servers.

IMPORTANT: The installation and configuration of a P2000 redundancy system with Marathon everRun should be performed by qualified professionals who posses a reasonable level of experience with advanced configurations. You must contact Technical Support to complete appropriate training before installing and configuring this software. Contact your sales representative for more detailed information.

FDA Part 11

The P2000 software provides change tracking parameters designed to assist facilities that may be subject to Food and Drug Administration (FDA) Title 21, Code of Federal Regulation (CFR) Part 11 for electronic records and electronic signatures. The Title 21 CRF Part 11 provides the criteria under which the FDA accepts electronic records and electronic signatures as equivalent to paper-based records and traditional handwritten signatures, and regulates how these electronic records should be created, modified, maintained, archived, and transmitted.

Note: An electronic record is a combination of text, graphics, or data that is created, modified, maintained, archived, retrieved, or distributed by a computer system. An electronic signature is a computer data compilation of any symbol or series of symbols (ID and password combination), and is the electronic equivalent of a handwritten pen on paper signature.

The P2000 system allows customers to define parameters to assure Part 11 compliance. The following are general Part 11 requirements applicable to the P2000 system.

Audit Trail – The P2000 system provides valuable time-stamped reports to monitor day-to-day operator activity, such as how the hardware is controlled, when alarms are acknowledged, when cardholder records are changed, and more. A complete list of P2000 Standard Reports is presented in P2000 Standard Report Definitions on page 510, along with a brief description of each and how they can be used. Authorized Users – The P2000 software limits system access only to authorized individuals. Authorized users are identified by their unique combination of user name and password. The passwords for these individuals can be configured to change periodically and have a minimum password length. Additionally, the software disables user access on multiple invalid log on attempts and provides for automatic log off because of user inactivity. See Assigning Operators on page 22 for detail instructions on adding operators to the system. In addition, the Password Policy Tab on page 41 presents several parameters to define passwords that comply with FDA regulations.

Record Validation – The P2000 software provides a tampering tool to detect unauthorized record modifications. See System Validation on page 495 for instructions on how the system validates digital signatures, points out discrepancies, and corrects discrepancies to ensure that records now have a valid digital signature.

Record Persistence – All original records are saved in the P2000 database, even if records are modified. The P2000 software generates detailed, time-stamped audit trails reports, assuring that all record changes maintain the original recorded information and thereby protecting all previous data. See P2000 Standard Report Definitions on page 510 for a complete list of P2000 Standard Reports.

Record Retention – Through software configuration, a system administrator can define parameters to back up and retrieve records to ensure the availability of all records for a specified period of time. See Retention Policy Tab on page 40 to enforce FDA Part 11 record retention policy. Also, FDA Part 11 Backups on page 493 provide instructions to perform periodic backups to comply with FDA Part 11 record retention requirements.

Intercom

The P2000 Intercom interface allows the P2000 server to retrieve messages coming from approved intercom equipment and use them for event processing and distribution to P2000 workstations for the processing of intercom history messages and alarms. The P2000 Intercom Interface Service that resides on the P2000 server provides the communication between the P2000 system and the intercom equipment. This interface enables audio communication links between any two or more defined intercom stations.

The P2000 system provides applications to control and display all intercom call requests coming from defined intercom stations. The operator can select a call request from the list and connect to any single intercom station, or to a group of stations.

The P2000 system supports two intercom integrations: *Zenitel AlphaCom M* (AMC 07.60) and *Commend*TM (GE300, GE800, and any Commend intercom model compatible with the ICX Protocol Version 1.1/0910) systems. Complete intercom hardware installation and operation instructions are provided with the intercom system that was shipped with your option.

Hardware Requirements

Before configuring the P2000 software components to control the intercom equipment, you must ensure that at least basic intercom hardware components are up and running. Installation of the intercom equipment must be made in accordance with the manufacturer's instructions.

For Zenitel AlphaCom systems ensure that:

 The AlphaCom intercom system is operational. Refer to the manufacturer's documentation for assistance.

431

- The MPC data output port in the AlphaCom intercom system is enabled.
- The Intercom Exchange box is connected to the P2000 Server. Use an RS232 DB9 cable to connect the specific COM port on the Exchange box to an available COM port on the P2000 Server.

Note: The COM port to be used at the Exchange box depends on the AlphaCom model used at your facility.

- At least one Master Station is configured in the intercom system.
- At least one Sub-Station is configured to link to the Master Station. The Sub-Station should be configured to send call requests to its Master Station.

For Commend systems ensure that:

- The Intercom Server is defined using the Commend system software, including connection settings and other system parameters. Refer to the manufacturer's documentation for assistance.
- If your intercom system supports output setting, use the Commend system software to configure these outputs, and then add them to the intercom exchange and station definition.
- The Commend Intercom Server is licensed and configured to use a TCP/IP channel.
- You have configured at least two stations that can communicate with each other.

Intercom System Hardware Verification

- 1. From the Master Station, dial a Sub-Station.
- 2. Verify that the call is received and that the Sub-Station name displays on the Master Station control screen.
- 3. Repeat steps 1 and 2 for each Sub-Station.

- 4. Send a call request from the configured Sub-Station.
- 5. Verify that the Master Station rings from the call request and that the Sub-Station name displays on the Master Station control screen.
- 6. Receive the call request from the Sub-Station.
- 7. Verify communication from the Sub-Station and that its name displays on the Master Station control screen.
- 8. Repeat steps 4-7 for each Sub-Station configured to send call requests to the Master Station.

Intercom Configuration

The following sections describe the procedures to define the parameters used by the P2000 system to communicate with the intercom system.

If you use Partitions, you can assign the intercom stations to a partition. The operator can only handle call requests and connect or disconnect with other stations that belong to partitions that the operator can access.

IMPORTANT: For any intercom configuration changes to take effect, you must stop and restart the P2000 Intercom Interface Service using Service Control; see Starting and Stopping Service Control on page 470.

Intercom Exchange

Each P2000 workstation acting as an intercom Master Station must be associated with a specific Intercom Exchange. You can link each intercom exchange to extend the number of intercom stations controlled by a single master intercom station.

To Define a Zenitel Intercom Exchange:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Select **Intercom Interface** and click **Add**. The Intercom Exchange dialog box opens.

🕻 Intercom Exchange		_ 🗆 ×
Partition Interface Name	Super User	♥ Public ♥ Enable Alarms
Query String		
Message Filter	<none></none>	Save XAction
Туре	Zenitel MPC protocol - AMC 07.60	•
Comm. Port	COM 1	
Baud Rate	9600	
Data Bits	7	
Parity	Even	
Stop Bits	1	
c	K Cancel]

- 3. If this is a partitioned system, select the **Partition** in which this intercom exchange is active.
- 4. Select **Public** if you wish this intercom exchange to be visible to all partitions.
- 5. Enter a descriptive **Interface Name** to identify the intercom exchange to which the stations are connected.

Note: Configuration settings defined for Intercom Exchanges and Intercom Stations must match the settings defined at the intercom equipment. If the programming at the intercom equipment changes, you have to make the corresponding changes in the P2000 intercom configuration (Exchanges and Stations).

- 6. Click **Enable Alarms**, if you wish to report all alarms generated by the intercom equipment. The P2000 Alarm Monitor displays alarms associated with the Zenitel Exchange, such as *Connect* and *Disconnect*.
- 7. Enter the **Query String** value that is used with message filtering (see Define Query String Filters on page 240).
- Select the Message Filter Group that contains the intercom history messages to save in the P2000 Transaction History database. Select <none> if you wish to save all intercom history messages.
- 9. To save the intercom history messages in the P2000 Transaction History database, you must click **SaveXAction**. For more information, see Intercom Transaction History Reports on page 438.
- 10. Select from the **Type** drop-down list, the Zenitel intercom protocol to be used at your facility.
- 11. Select from the **Comm. Port** drop-down list, the P2000 Server port to which the Intercom Exchange box is connected.
- 12. The values for the **Baud Rate**, **Data Bits**, **Parity**, and **Stop Bits** should be set to match the settings in the Zenitel intercom hardware settings. Edit the settings if necessary.
- Click OK to save your settings. The Intercom Exchange name displays under the Intercom Interface icon in the System Configuration window.

To Define a Commend Intercom Exchange:

 From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens. 2. Select **Intercom Interface** and click **Add**. The Intercom Exchange dialog box opens.

🕻 Intercom Exchange		_ 🗆 🗡
Partition	Super User	V Public
Interface Name	Lobby	🔽 Enable Alarms
Query String		
Message Filter	Intercom History	Save XAction
Туре	Commend ICX Version1.1/0910	-
Dial Number Length	4	Support Regions
IP Address	200.155.155.155	
IP Port	808	
Password	master	
Region Number	414	
	Outputs	
0	K Cancel	
		_

- 3. If this is a partitioned system, select the **Partition** in which this intercom exchange is active.
- 4. Click **Public** if you wish this intercom exchange to be visible to all partitions.
- 5. Enter a descriptive **Exchange Name** to identify the intercom exchange box to which the stations are connected.

Note: Configuration settings defined for Intercom Exchanges and Intercom Stations must match the settings defined at the intercom equipment. If the programming at the intercom equipment changes, you have to make the corresponding changes in the P2000 intercom configuration (Exchanges and Stations).

6. Click **Enable Alarms**, if you wish to report all alarms generated by the intercom equipment. The P2000 Alarm Monitor displays alarms associated with the Commend Exchange, such as Connect and Disconnect; and alarms associated with Commend stations, such as Station Alarm Set and Station Alarm Reset.

- 7. Enter the **Query String** value that is used with message filtering (see Define Query String Filters on page 240).
- Select the Message Filter Group that contains the intercom history messages to save in the P2000 Transaction History database. Select <none> if you wish to save all intercom history messages.
- 9. To save the intercom history messages in the P2000 Transaction History database, you must click **SaveXAction**. For more information, see Intercom Transaction History Reports on page 438.
- 10. Select from the **Type** drop-down list, the Commend intercom protocol to be used at your facility.
- 11. In the **Dial Number Length** field, enter the number of digits to assign to each station call number.
- 12. Click **Support Regions** if your facility supports logical grouping of one or more intercom servers.
- 13. Enter the **IP Address** of the Commend Intercom Server.
- 14. Enter the **IP Port** number for communicating with the Commend Intercom Server.
- 15. Enter the **Password** that to use for connecting to the Commend Intercom Server.
- If your facility supports regions, enter Region Number assigned to the group of intercom servers.
- 17. If your intercom system supports output setting, click **Outputs**. The Commend Outputs dialog box opens.

Commend Outputs		X
Туре	Address	
Output	8993	
Output	8994	
Output	8995	
1		
Type Add	ress	
Output 💌 8994	Add Delete	
Γ	Close	
L		

Note: The Commend interface allows you to set or reset outputs that for example, open doors, turn on lights, or activate alarm sirens. You must first configure these outputs using the Commend software and then add them to the intercom exchange definition. Intercom exchange outputs are only used for event processing and reporting purposes. If you wish to control these outputs, you must add them to the intercom station definition.

- 18. The default Type is Output. In the Address field enter the Output address and click Add. You may add as many outputs as needed. If you wish to remove an output from the list, select the output item and click Delete.
- 19. Click **Close** to save your settings and return to the Intercom Interface configuration.
- 20. Click OK to save your settings. The Intercom Exchange name displays under the Intercom Interface icon in the System Configuration window.

Intercom Stations

Once you create an Intercom Exchange in the System Configuration window, an Intercom Station icon is automatically added under the Intercom Exchange name. Now you should define the intercom call stations to use for audio channel communication. The P2000 system establishes a connection between the selected stations and the workstation where the operator is logged on. The P2000 workstation associated with the exchange can control the calls from the stations assigned to that exchange, as well as process intercom history messages and alarms.

To Add an Intercom Station:

- 1. In the left pane of the System Configuration window, expand the Intercom Exchange name where you want to define the stations.
- 2. Select **Intercom Station** and click **Add**. The Intercom Station dialog box opens.

C Intercom Stati	on	<
Name	Security	
Partition	Super User 💌 🔽 Public	
Query String		
Address	102	
Priority	0	
Туре	Master Station	
Workstation	front lobby	
	Outputs	
	OK Cancel	

- 3. Enter a descriptive **Name** that identifies the location of the station.
- 4. If this is a partitioned system, select the **Partition** in which this intercom station is active.

- 5. Click **Public** if you wish this intercom station to be visible to all partitions.
- 6. Enter the **Query String** value that is used with message filtering (see Define Query String Filters on page 240).
- 7. Enter the **Address** assigned to this station. The P2000 system connects to the station based upon the address entered here. This address has to match the address assigned at the station equipment.

Note: For a Commend station group, you can enter a 1-digit number. This number must match the 1-digit Direct Dialing number configured for a Master station (using the Commend interface), and that can be used to activate a group number.

- 8. From the **Priority** drop-down list, select a priority value from 0 (highest) to 255 that determines the order the call request is placed in the Intercom Control queue.
- 9. From the **Type** drop-down list, select one of the following:

Sub-Station – You should configure at least one Sub-Station to send call requests to its Master Station.

Global Sub-Station – Select to allow Sub-Stations to connect to other Master Stations.

Station Group – Select to connect to multiple stations at the same time. The P2000 system establishes a connection between the stations that are part of the group selected and the workstation where the operator is logged on.

Master Station – The Intercom Exchange must have at least one Master Station to link to other stations.

10. If you are defining a Master Station, select from the **Workstation** drop-down list, the workstation name that controls the Master Station.

Note: You can only associate a P2000 workstation with <u>one</u> Master Station within an intercom switch.

 If this is a Commend intercom station, and your intercom system supports output setting, click **Outputs**. The Commend Outputs dialog box opens.

ommend Outputs	×
Туре	Address
Output	8993
Output	8994
Output	8995
Type Addr	ess
Output 💌 8994	Add Delete
	Close

Note: The Commend interface allows you to set or reset outputs that for example, open doors, turn on lights, or activate alarm sirens. You must first configure these outputs using the Commend software and then add them to the intercom station definition.

- 12. The default **Type** is Output. In the **Address** field enter the Output address and click **Add**. You may add as many outputs as needed. If you wish to remove an output from the list, select the output item and click **Delete**.
- 13. Click **Close** to save your settings and return to the Intercom Station configuration.
- 14. Click **OK**. The station name displays under the Intercom Station root icon.

Intercom Control

The P2000 Intercom Control window allows operators to monitor incoming call requests and to connect with stations or station groups that are part of the workstation's exchange. In facilities that use Commend Intercom systems, operators can control outputs associated with the Commend intercom equipment. The Intercom Control dialog box allows operators to sort the list of call requests by request time, priority, status, or name.

When the call comes, the operator can select any call in the queue and connect the master intercom station to the calling intercom station. Once connected, the operator can place the call on Hold or Disconnect the call.

Note: Stations can also be connected or disconnected using the Real Time Map; see Controlling Intercom Stations using the Real Time Map on page 438.

To Control Intercom Stations:

 From the P2000 Main menu, select Control>Intercom. The Intercom Exchange Selection dialog box opens.

Please Select a Interco	om Exchange	х				
2nd comm AlphaCom Entrance Area Lobby						
ОК	Cancel					

2. Select the intercom exchange you wish to control and click **OK**. This selection list only displays in facilities that have more than one Intercom Exchange defined. The Intercom Control dialog box opens at the Call Queue tab.



The top right section of the dialog box displays general information related to the Master Station. The list box displays the calls currently in the queue, either from Sub-Stations or Station Groups. The following information is shown for each call in the list:

Time/Date – The date and time when the call was placed.

Priority – The priority that was set in the Intercom Station dialog box.

Status – The status of the selected station, such as Call Request, On Hold, Idle, Busy, and so on.

Name – The name of the Sub-Station or Station Group that is placing the call.

Address – The address assigned to the Sub-Station or Station that is placing the call.

- 3. Select any call in the queue and click **Connect**. This connects your master intercom station to the calling intercom station selected.
- 4. Once connected, you may communicate (talk and listen) with the person at the Sub-Station. You can also perform the following actions:

Push to Talk – Click and hold to talk (not listen) to the person at the selected calling station. Release the button to only listen (not talk) to the person at the Sub-Station. To return to duplex communication (the ability to talk and listen without holding and releasing the button), click the Push to Talk button without holding it down.

Hold – Disconnects from the calling station and leaves the call in the queue.

Disconnect – Disconnects from the calling station and removes the entry from the queue.

Connect – Selecting another entry in the queue and clicking Connect performs a Hold on the currently connected call.

5. Click **Exit** to close the Intercom Control dialog box.

To Control Sub-Stations Only:

1. In the Intercom Control dialog box, click the **Station** tab.

						Master Station
Name		Address	Priority	Status	Time/Date	Status Idle
Lobby Fron	Door	109	0	On Hold	9/19/2011 11:26:43	
Parking Ea	t	104	0	Idle	9/19/2011 11:26:35	
						Connect
						Push To Talk
						Hold
•						Disconnect
						Set Output
utput						
utput Name	Addre	955				

The list box displays the Name, Address, and Priority of the Sub-Station, as well as the current status of the call request and the time and date when the change of status took place.

- 2. In the list box, select a station to which you wish to connect.
- 3. Click Connect.

- 4. You may now communicate with the person at the selected station. You may also perform the actions described earlier (Push to Talk, Hold, and so on).
- If the selected intercom station is associated with outputs (Commend systems only), select the output from the Output list box and click Set Output to activate the output, or Reset Output to reset the output.
- 6. Click **Exit** to close the Intercom Control dialog box.

To Control Station Groups:

1. In the Intercom Control dialog box, click the **Station Group** tab.



The list box displays the Name, Address, and Priority of the Station Group.

- 2. In the list box, select a station group to which you wish to connect.
- 3. Click Connect.
- 4. You may now communicate with the person at the stations of the Station Group selected. You may also perform the actions described earlier (Push to Talk, Hold, and so on).
- 5. Click **Exit** to close the Intercom Control dialog box.

Controlling Intercom Stations using the Real Time Map

The Real Time Map displays the status of intercom stations on a map layout of your facility. If an intercom status changes, the Real Time Map shows the state change and the location of the intercom device. See Using the Real Time Map on page 360.

Note: Intercom station groups are stateless; therefore, the Real Time Map does not display status changes associated with intercom station groups.

When you receive a call request for a station, the intercom icon starts flashing. You can right-click the icon to open a shortcut menu and choose to connect or disconnect the call. If you configured the intercom to allow the operator to activate events, the event name also displays in the shortcut menu. In addition, if the intercom station is associated with outputs (Commend systems only), you can choose from the shortcut menu to set or reset all outputs associated with the station.

To add intercom icons to the Real Time Map, follow the instructions provided in To Place Device Icons on a Real Time Map: on page 364 and select from the drop-down list the Intercom stations you wish to display in the Real Time Map.

Note: Map Maker provides a default intercom image set to display various intercom states such as Station Idle, Station Busy, Station Call Request, and so on. However, you can use your own icons to create custom image sets. See Adding Image Sets on page 366 for details.

Intercom Events

The intercom equipment connected to the system can respond to event actions using the P2000 Event application. You can define Event Actions that *Connect* or *Disconnect* stations, or events that are to be triggered upon a *Station Busy, Station Call Request, Station Connected,* or *Station Idle.* See Creating Events on page 349 to create new event triggers and actions.

Note: The **Station Connected** trigger type is not supported by Commend Intercom station groups.

Intercom Transaction History Reports

The **SaveXAction** option in the intercom exchange definition allows you to save all intercom transactions in the P2000 Transaction History database.

Once the transaction history messages are saved, you can use the P2000 Transaction History report to list all intercom transactions in the system. The Transaction History report can be filtered to list by specific Site, Partition, Date and Time, and any combination of these. You can also select to run the report to list all intercom history types, or select a specific type such as *Intercom - Station Busy* or *Intercom -Call Station OK*. The options available for selection in the History Type field depend on the equipment used at your facility.

For detailed information on running reports, see Chapter 6: System Reports.

P2000 Enterprise

The P2000 Enterprise feature allows customers with multiple sites to communicate with each other to share cardholder and badge information. Cardholders can be granted access to doors at all assigned sites within the Enterprise system.

In the P2000 Enterprise Configuration, one P2000 site becomes the P2000 Central Site and all other P2000 systems within the enterprise become P2000 Regional Sites.

Each regional site synchronizes its data with the central site. Database replication is implemented using Microsoft SQL Server database technologies.

Before defining Enterprise parameters using the P2000 software, you must refer to the *Enterprise Configuration* manual for instructions on:

- Configuring the P2000 Central Site
- Moving data from existing P2000 Regional Sites to the P2000 Central Site
- Configuring a P2000 Regional Site



Once you complete Enterprise Configuration, you are ready to set up Enterprise parameters within the P2000 software. Follow these basic procedures:

- Define Enterprise parameters
- Assign cardholders with the sites they are allowed to access
- Define the badge access rights and security privileges at the assigned sites

Enterprise Parameters

Before assigning cardholders access to multiple sites, you should define global Enterprise Sites, Time Zones, and Access Groups.

To Define Enterprise Sites:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand Enterprise **Parameters** to display the enterprise parameters.
- 3. Select Enterprise Sites and click Add. The Enterprise Site Edit dialog box opens. The list box displays the name of your local site.



- 4. Enter the **Name** of the regional Site exactly as defined at the P2000 site that provides access.
- 5. Enter the **Database Server** name of the regional site.
- 6. In the Subscription Sites box, select the site names that can be associated with this site. Any changes in this Site are reflected on the site names selected in this box.
- 7. If you wish to select all sites, click **All**. This option allows you to unselect site names individually.
- 8. If you wish to clear your selections, click None.
- 9. If you wish to select all sites, click All sites. This option does not allow editing.
- 10. Click **OK** to save your settings.

To Define Enterprise Parameters:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. Select Enterprise Parameters and click Edit. The Enterprise Parameters Edit dialog box opens.



- 3. Select from the **Enterprise Site** drop-down list, the site name to be defined as the central Enterprise site.
- 4. Select from the Alternate Enterprise Site drop-down list, the site name that can be defined as the alternate Enterprise site.
- 5. Click OK to save your settings.

To Define Enterprise Time Zones:

- 1. Expand Enterprise Parameters to display the enterprise parameters.
- 2. Select **Time Zones** and click **Add**. The Enterprise Time Zone Edit dialog box opens.

🕻 Enterprise Time Zone Edit					
<u>N</u> ame	Business Hours				
	,				
ОК	c	ancel			

- 3. Enter the **Name** of the Time Zone exactly as defined at the P2000 site that provides access.
- 4. Click **OK** to save your settings.

To Define Enterprise Access Groups:

- 1. Expand **Enterprise Parameters** to display the enterprise parameters.
- 2. Select Access Groups and click Add. The Enterprise Access Group Edit dialog box opens.

🕻 Enterprise Access Group Edit	
Name Front Doors	
ОК	Cancel

- 3. Enter the **Name** of the Access Group exactly as defined at the P2000 site that provides access.
- 4. Click OK to save your settings.

Assign Cardholders Enterprise Access

Use the Cardholder application to assign the sites a cardholder can access. Once the sites are assigned, the cardholder information is sent to the selected sites for download.

To Assign Enterprise Access to a Cardholder:

- From the P2000 Main menu, select Access>Cardholder. The Cardholder window opens.
- 2. Create a new record or edit an existing cardholder as desired. For details, see Entering Cardholder Information on page 260. The Cardholder Edit dialog box opens.

C Cardholder									
Cardholder Edit	UDF 1								
Cardholder E	2artition Pyblic Type *Eirst Middle *Last	Super User Regular Brenda T. Covington	×	Other All Badges	Sat	Email Company Department	KD Distribu Accounting	tors guar 8:00:00 AM	
	ĪD	763			End	7/26/20	21 -	11:59:00 PM	÷
Address	Suite		A	- Web Acces	s anu Perm	ission Group Pass <u>w</u> ord	<none></none>		•
Sta	 		Zip	Enterprise	jo Regior Jkee Offi alley	ial Office ce		All	
Pho	ne		Ext						
	First: Last:								
Phon	ie;		Ext:			Select	1		

The Enterprise box displays all the sites defined in the System Configuration window. See To Define Enterprise Sites: on page 440.

- 3. In the Enterprise box, select the check box next to the site that this cardholder may access. You may select as many sites as needed.
- 4. To select all sites, click All.
- 5. To clear your selections, click None.

 Once the sites are assigned, click OK to return to the Cardholder window. The information also displays in the Enterprise Sites tab located in the center of the window.

Image Address Other Start/End Badges UDF	Enterprise Sites	Sponsored Visitors
Chicago Regional Office Simi Valley		

Define Global Badge Access Rights

Once the cardholder has been assigned to the selected sites, you may define the security privileges and access rights using the Badge application.

To Define Badge Access Rights:

- 1. In the Cardholder window, select a cardholder from the Cardholder list that has Enterprise access.
- In the Badge Information box at the bottom of the Cardholder window, click Add. The Badge dialog box opens.

C Badge					_ 🗆 🗙
Badge					
Partition	Super User		Public		
Number	303			Auto	
Facility Code	Default Facility Code		Type	Access	•
Alpha	Issue 0		Eormat	<none></none>	•
Description	Enterprise Access		Purpose	<none></none>	•
Bin	50733		<u>R</u> eason	New	•
Start	▼ 10/ 6/2011 ▼ 8:00:0	AM ·	Design	<none></none>	•
End	▼ 10/ 3/2012 ▼ 11:59:0	PM +			
Security Options Apply Security Disabled Executive Download Special Ac Special Ac	Access Rights Otis Compass http:/Options'Enterprise'	Elevator Options A Security Level — Levent Privilege Privilege Guard Tour Priority	ction Interl	ocks	
	Apply Access Rights	<none></none>		2]
Du	uplicate	Print		Preview	
	ок	Cancel		Apply	

3. Enter the badge number and optional description. For detailed information, see Entering Badge Information on page 267.

The Badge dialog box displays the site name tabs of the sites assigned to this cardholder. The first tab is always the local site tab and is used to assign local access privileges. The second tab is the Enterprise tab and is used to assign global access privileges. Additional tabs show other site names assigned to the cardholder.

Assigning access privileges is determined by the following conditions:

- When you define access to the local site, and click Apply Security Options 'Enterprise', the security options defined in the Enterprise tab are applied.
- When you define access at a different site, and click Apply Security Options 'Enterprise', the security options defined in the Enterprise tab are applied to that site.
- Access Groups and Time Zones can be accessed for your own site, the Enterprise site or for any site within the Enterprise system.
- On each site, a maximum of 64 Access Groups and Time Zones are applicable (32 local and 32 Enterprise).
- The P2000 system only downloads the maximum number of Access Groups and Time Zones for each panel type, giving priority to the local settings.
- 4. Once the badge access parameters are defined, click **OK** to return to the Cardholder window. This initiates all required downloads.

Note: The Status column in the Badge Information box at the bottom of the Cardholder window, displays the status of badges for the local site only.

Web Access

Web Access is a suite of applications that enables users to perform various P2000 tasks from any web-ready computer or compatible Personal Digital Assistant (PDA) device. Web Access offers many features such as employee, visitor, and contractor management applications; badge activity tracking and synchronization; alarm monitoring; emergency access disable; web badging capabilities; and a customizable user interface.

Web Access can support different hardware configurations, the most common (shown on the illustration), uses a single server. In this configuration, the P2000 server runs the Web Access front-end and back-end services. Essentially, the P2000 server is also the web server. The Web Access front-end services handle the web browser HTTP requests, while the Web Access back-end services handle the application's XML requests from the front end.

In another configuration, the P2000 server runs the Web Access back-end services, and a separate server runs the front-end services.

Before you define Web Access parameters using the P2000 software, you must refer to the *Web Access Manual* for the software components required to operate the P2000 Web Access application.



Sequence of Steps

Once Web Access is installed at the server and front-end computers, follow these basic procedures for defining, implementing, and using Web Access:

- Create and assign menu permissions to perform Web Access functions
- Define Web Access options
- Define request approvers
- Submit requests using Web Access
- View the status of a request
- Approve the request
- Process the request

Creating and Assigning Web Access Menu Permissions

To prevent unauthorized users from performing high-level actions, such as deleting cardholder records or rejecting requests, the system administrator must create menu permission groups, which are assigned to users who perform Web Access functions.

Each individual Web Access function is controlled by menu permissions and one menu permission group can include various combinations of permissions.

Here Edit Add F Wick Access						
Web Alam Mutator	tem	View	Edit	Add	Delete	
Web Adam Monitor	Web Access					
Web Bodge Prit V V V Web Bodge Attriby Fass Status V V Web Bodge Attriby Fass Attribut V V Web Bodge Attribut V V	🔮 Web Alarm Monitor					
Web Bodge Anthry Ares Status Ø Web Bodge Anthry Ares Status Ø Web Bodge Anthry Ares Status Ø Web Bodge Anthry Cardiodic Pictula's Ø Web Bodge Anthry Cardiodic Pictula's Ø Web Bodge Anthry Status Ø Web Bod	🔮 Web Badge	•	•	•	₹	
Web Bodge Activity Ares Status ✓ ✓ Web Bodge Activity Isolga Dotals ✓ ✓ Web Bodge Activity Isolga Dotals ✓ ✓ Web Bodge Activity Search ✓ ✓ Web	🔮 Web Badge Print				✓	
Web Bolge Andry Bolge Details V V Web Bolge Andry, Cardidate Details V V Web Bolge Andry, Cardidate Details V V Web Bolge Andry, Scarth V V Web Bolge Renyrc V V Web Cardholfer Web Cardholfer	🔮 Web Badge Activity Area Status	•			₹	
♥ who begin Anthry Cardination Details ♥ ♥ ♥ who begin Anthry Search ♥ ♥	🔮 Web Badge Activity Badge Details	•	•		✓	
Web Bidge Achtry's Search Image: Constraint of the search of	🔮 Web Badge Activity Cardholder Details	•			✓	
Web Badge Resync Ø Web Badge Resync Ø Web Cardholder - Add Only Image: Cardholder - Add Only	🔮 Web Badge Activity Search		•		₹	
Web Badge Resync ✓ Web Cardholder □ □ Web Cardholder □ □ Web Cardholder □ □	🔮 Web Badge Activity Status				✓	
Web Cardhelder Web Cardhelder Add Only Web Cardhelder Add Only Web Cardhelder	🔮 Web Badge Resync	•			✓	
Veb Cardholder - Add Only	🔮 Web Cardholder					
Control Control Control	🔮 Web Cardholder - Add Only					
👻 web Cardholder Journal	🔮 Web Cardholder Journal					
🔮 Web Contractor Request	🔮 Web Contractor Request					
🔮 Web Door Control	🔮 Web Door Control					

Some Web Access items, such as *Web Badge*, *Web Cardholder* or *Web Cardholder Journal*, provide up to four permission levels that allow the following functionalities:

View – View records.
Edit – Submit requests to edit records.
Add – Submit requests to add records.
Delete – Submit requests to delete records.

The *Web Request Queue Status* item allows users to view Web Access requests according to the following selections:

View – View requests from own department Edit – View requests from own company Delete – View all requests

Other Web Access items provide only one permission level, which is selected by clicking on any of the permission levels (View, Edit, Add, or Delete), and allow users to perform the associated function. For example selecting any of the *Web Alarm Monitor* permission levels, allows the user to perform alarm monitoring functions. For detailed instructions, see Creating Permission Groups on page 21. Once the menu permissions are defined, they are available for assignment from the Cardholder Edit dialog box.

To Assign Web Access Permissions:

- From the P2000 Main menu, select Access>Cardholder. The Cardholder window opens.
- 2. Create a new cardholder record or edit an existing cardholder record. For detailed instructions, see Entering Cardholder Information on page 260. The Cardholder Edit dialog box opens.



- In the Web Access box, select from the Menu Permission Group drop-down list the group that can be assigned to this cardholder. The cardholder may be allowed to perform any function defined in this permission group.
- 4. In the **Password** box, enter the password that the cardholder can use to log on to the P2000 Web Access site.
- 5. Click **OK** to save your settings.

Defining Web Access Options

The P2000 system allows you to set up system wide settings to define how web access requests are managed. Use the Web Access tab in Site Parameters to define the default Web Access options, approval levels, and processing method for Web Access requests. You can also configure User Authentication parameters to set up directory services for Web Access.

To Edit Web Access Parameters:

 From the System Configuration window, select Site Parameters and click Edit. The Edit Site Parameters dialog box opens at the General tab.

1	Send Email to Request Approvers Super User rules override partition rules Expiration Period for Requests 14	days	
Sender	Application	Level	Process
P2KWebAccess	BResvoc Status	0	Auto
P2KWebAccess	CardbolderRequest.Badge	0	Manual
P2KWebAccess	CardbolderRequest.Cardbolder	0	Manual
P2KWebAccess	CardholderRequest. Journal	0	Manual
P2KWebAccess	ContractorRequest.Cardholder	0	Manual
P2KWebAccess	EmergencyDisable,Cardholder	0	Auto
P2KWebAccess	Visitor Management, Visitor	0	Manual
Iser Authentication	Edit		
Use Operati	or Account / Profile Authentication tyle JCI		

- 2. Click the **Web Access** tab and see the following section for detailed information.
- 3. Click **OK** to save the settings and return to the System Configuration window.

Web Access Options Field Definitions

Send Email to Request Approvers – If you select this option, when a cardholder submits a Web Access request that requires approval, an email notification is sent to the approvers defined in the Request Approvers dialog box; see Defining Request Approvers on page 447. The email message contains a hyperlink to the request, which takes the approver directly to the Request Approval application, assuming the approver has been assigned with the proper Web Access menu permissions. The approver's email address is defined in the cardholder record.

Super User rules override partition rules – If this option is selected, any approvers defined in the Super User partition override any approvers defined in specific partitions. If this option is not selected, approvers from the specific partition are used.

Expiration Period for Requests – Enter the number of days after which all Web Access requests expire. The expiration date is calculated by adding the number of days entered here to the initial date when the request is submitted.

Required Approval Levels – This box displays default approval levels for each of the P2000 Web Access applications. To change the default values, double-click the application name you wish to modify. The Edit Request Application dialog box opens. The *EmergencyDisable.Cardholder* application does not allow editing.

Edit Request Application	×
Sender	P2KWebAccess
Application	CardholderRequest.Badge
Approval Levels	1
Processing Mode	Manual
OK	Cancel

Sender – This field displays the Sender that originated the Web Access request.

Application – This field displays the name of the P2000 Web Access application you are currently modifying.

Approval Levels – Select a number from the drop-down list to define how many approvers are required to approve this type of Web Access request. If you select **0**, the Web Access request is sent directly for processing.

Processing Mode – This field defines how the request is processed after the Web Access request has been approved. Select from the drop-down list one of the following options:

- Auto Select this option if the request is processed automatically (without intervention). Not available for the *VisitorManagement.Visitor* application.
- Manual Select this option if this application requires an authorized user to manually process the request; see Processing Web Access Requests on page 453.

User Authentication Box

P2000 Web Access operator passwords can be authenticated against a directory service such as Microsoft Active Directory or Lightweight Directory Access Protocol (LDAP). This eliminates operator passwords from the P2000 database. This feature is useful in situations where passwords are periodically changed and therefore, eliminates the need to update passwords in the P2000 system and also passwords that are used to log on to Windows.

To use directory service password validation, set up the following elements:

- Configure the Directory Services Password Validation fields on the Password Policy tab of Site Parameters (see page 42). The actual value to use for the Directory Services Path is unique to your specific network configuration and needs to be obtained from the network administrator.
- Create an AD Account or AD Profile operator account on the Edit Operator dialog box (see page 23) for each P2000 Web Access operator whose password is to be verified by directory services.

Once the previous elements are configured, define the following parameters in the User Authentication box:

Use Operator Account / Profile Authentication – Click if you wish to use the AD Account or AD Profile accounts for Web Access login.

UI Style – Enter the Web Access user interface style that users are assigned when logging on using directory services authentication.

Note: The UI Style assigned affects all P2000 operators whose accounts are enabled for directory services authentication. This parameter cannot be assigned individually (you cannot assign styles to specific users).

Defining Request Approvers

Depending on settings previously defined in Site Parameters, each Web Access request may require up to three active approvers. The approver is a cardholder who has been assigned *Web Request Approval* menu permissions. Approvers are ordered in a sequence and approve requests in the same order.

For example, an application requires three approvers: John (Level 1), Mary (Level 2), and Bob (Level 3). When a request is submitted, an email notification is sent to John, who approves the request first. After John approves the request, an email notification is sent to Mary; then after Mary approves the request, an email notification is sent to Bob. After Bob approves the request, the approval process is complete. Bob never sees requests that are not approved by Mary, and Mary never sees requests that are not approved by John.

Approvers only see requests that are waiting for their approval and each request waits for a single approver at any time. When a request becomes ready for the next approver an email notification is sent to the approver.

If an application requires a single approver, after the approver approves the request, the approval process is complete.

The P2000 system ignores all requests that do not have all required approvals completed.

The approver's email address for sending notifications is entered in the cardholder record.

To Enter the Cardholder Email Address:

- From the P2000 Main menu, select Access>Cardholder. The Cardholder window opens.
- 2. Create a new cardholder record or edit an existing cardholder record. For detailed instructions, see Entering Cardholder Information on page 260. The Cardholder Edit dialog box opens.

er	
Edit UDF 1	
ler .	Other
Partition Super User	Email JBrown@xxx.com
Public 🗐	*Company ABC Industries
Type Regular	Zoubai) Les massion
*Erst	*Department Sales
Middle M.	Guard I⊄
to a Desug	All Badges
Agast Brown	Start 🗹 3/17/2009 💌 8:00:00 AM
ID	End 🗹 3/15/2019 💌 11:59:00 PM 🕂

3. Enter the **Email** address that has been assigned to this cardholder and where notifications are sent to approve Web Access requests.

Note: To configure your Email Server, see EMail Tab on page 45, and also check with your IT department for the required email settings in your facility.

4. Click **OK** to save your settings.

To Define Request Approvers:

- 1. In the left pane of the System Configuration window, expand **Site Parameters**.
- 2. Select **Request Approvers** and click **Edit**. The Request Approvers dialog box opens.

C Re	quest Appro	vers							_ 🗆 ×
		Partition Sup	er User		•				
Ord	er Sender	Application	Operation	Company	Department	Level 1	Level 2	Level 3	
									Up
									Down
•								Þ	
	Done	Add		Edt	Delete				

- 3. Select the **Partition** from the drop-down list that contains the cardholders that are assigned as approvers. Requesters and approvers need to be in the same partition, unless the approver is in the Super User partition.
- 4. Click **Add**. The Edit Approval Rule dialog box opens. If you leave an asterisk (*) in a field, the Approval Rule includes all records for that field.

Edit Approval Rule	×
Sender	*
Application	*
Operation	*
Company	*
Department	*
Level 1 Level 2 Level 3	1
Active Name	
Yes Adams, Peter S.	
No Land, Adam R.	Active
	Add
	Delete
ОК	Cancel

5. Select from the drop-down list, the **Sender** that originated the request. The selected cardholder can only approve requests coming from this sender.

- 6. From the **Application** drop-down list, select the name of the Web Access function that the selected cardholder is allowed to approve.
- 7. Select the type of **Operation** (Add, Delete, or Update) that the selected cardholder is allowed to approve.
- 8. Select a **Company** name if you wish to have the selected cardholder approve only requests coming from the company selected here.
- 9. Select a **Department** name if you wish to have the selected cardholder approve only requests coming from the department selected here.
- 10. Select the Level 1 tab and click Add. The Select Cardholder dialog box opens.

Select Cardholder
First Name *
Last Name
Search
OK

11. Enter the **First Name** and/or **Last Name** (or leave the default *), and click **Search**.
This document contains confidential and proprietary information of Johnson Controls, Inc. © 2014 Johnson Controls, Inc.

- 12. Select a cardholder from the list and click OK. The name is added to the Level 1 list box. You can add as many Level 1 approvers as needed, but only one can be the active Level 1 approver.
- 13. From the Level 1 list box, select the cardholder who is the active Level 1 approver of the type of application and operation selected (for the company and department selected, if applicable). Click Active. You can change the Active approver as needed.
- 14. To remove a cardholder from the list, select the name and click **Delete**.
- 15. Repeat the procedure, starting with step 4, for the Web Access requests that require **Level 2** and **Level 3** approvers.

Note: The system generates an error message if a request is submitted and the number of required approvers has not been defined.

16. Once you define the rules for the requests that require approvals, click OK. The Request Approvers dialog box displays a list of approval filters. To move an approval filter up or down on the list, select the line item and click Up or Down.

The order in which approval filters display in the Request Approvers list box is significant. When a request is submitted, the approval filters in the list are scanned from the top down until the first request and filter match is found. When a match is found the attached approver list is used. If two approval filters include the same rules, the filter above has precedence over the one below.

Rule 1 requires three approvers for adding cardholders (from any company and department).

Rule 2 requires only one approver for adding visitors (from any company and department).

Rule 4 requires one approver for any request submitted, except that new cardholders (rule 1), new visitors (rule 2), and DEFG company (rule 3) requests will be approved by the approval filters above.

Reque	est Approver	'S							_ 🗆
	P	artition Super User	•	·					
Order	Sender	Application	Operation	Company	Department	Level 1	Level 2	Level 3	
1 2	WebAccess WebAccess	CardholderRequest.Cardholder VisitorManagement.Visitor	Add Add	*	*	Temple, John A. Banks, Karen	Kerns, Mary B.	Young, Bob	Up
3 4	WebAccess	*	*	DEFG Inc. *	*	King, Joe W. Brice, Grace L.			
									Down
	Done	Add Edit	Пр	elete					
-	2.0110								

Rule 3 requires one approver for any type of request submitted for the DEFG company (any department), except that new cardholders (rule 1) and new visitors (rule 2) will be approved by the approval filters above.

Submitting Requests using Web Access

The Web Access interface can be accessed via an Internet-connected computer or PDA device. This section provides a description of the features available from Web Access. For detailed information on how use this web-friendly interface, refer to the *Web Access Manual*.

To Log on to Web Access:

 From a web browser, enter the following in the Address bar, replacing ServerName or IP Address of the Web Access server:

http://ServerName or IP Address/P2000

or enter the following if the P2000 Server is configured as a secure server:

https://ServerName or IP Address/P2000

Contact your system administrator for the correct settings. The P2000 Web Access Log In page displays.



2. Enter the User Name (firstname.lastname). This is the name of any cardholder who has Web Access menu permission.

For systems that use multiple interface styles, the **User Name** may include the style name (firstname.lastname@stylename). Refer to the *Web Access Manual* for details.

- 3. Enter a valid **Password**. This is the password entered in the Cardholder Edit dialog box.
- 4. Click Log In. The Welcome page displays.

View Figurations Tools Help		
🔾 - 💽 🕱 🖉 🔎 Search 👷 Pavontes 🕐 🖉 + 🍃 🔀 +		
http://locahost/p2ldc/we/app/user/my-aspx		💌 🎦 Go Lin
2000 Security Management Syste	m	Johnson Controls
		Logged in an jackrown Log Cut Hile Change Passeon
come to the P2000 Web Access	Employee Services	
00 Web Access system provides system users and operators with the ty to perform key security operations from any fixed or mobile viewing	Guard Services	
a capable of displaying web based content.	Management Services	
	Visitor Management	

5. To log out and return to the Log In screen, click the **Log Out** link at the upper-right corner of any Web Access page.

Note: To access Web Access from the P2000 Server, you can also select **Start>Programs> Johnson Controls>P2000>P2000 Web Access Home Page**.

Web Access Functions

While each of the following procedures is described in detail in the *Web Access Manual*, a basic description is given here for your convenience.

Employee Services

Allow users to track the badge activities of cardholders, request a Badge Resync, which returns a badge to its correct state if it is out-of-sync, or print and encode a badge.

Cardholder Search

Allows searching for cardholder records in the P2000 database. Users may search by cardholder name, badge number, ID number, department, and company.

Area Search

Allows users to view which cardholders currently occupy a specific controlled area in a facility. A controlled area is a designated section of a facility, with one or more readers or input points assigned, with the purpose of reporting on the current whereabouts of cardholders.

In Out Displays

Allows users to see which cardholders are **In** or **Out** of the facility, or specific areas of the facility, based on their badge activity. If a cardholder has badged to enter the facility the status is *In*. If a cardholder has not badged to enter the facility, the status is *Out*.

Badge Resync

Allows users to manually adjust the status of their badge if it has been placed in an out-of-sync state. A badge is out-of sync when cardholders (that are required to enter and exit an area in sequence using entry and exit terminals), badge *In* at an entry terminal and don't badge *Out* at the next badging if, for example, they follow another cardholder out without swiping their badge. In that case, the badge remains in the *In* state (out-of-sync) and is denied access the next time they attempt to badge back into the area.

Badge Print

Allows users to locate cardholder records using various search filters. After performing a search, Web Access lists the badge ID number, cardholder name, personal identification number, company, and department of each cardholder record located in the search; then users can preview, print, and encode a cardholder's badge by clicking the badge ID number.

Guard Services

These services allow authorized users to perform several guard-related actions, such as view, acknowledge, and remove alarms; and manually control doors and output devices.

Alarm Monitor

P2000 alarms can be monitored, acknowledged, and removed using the Web Access interface. This feature is useful to monitor alarms at unattended sites, allowing authorized users to acknowledge alarm conditions as soon as they are reported. Once an alarm is in a secure state, the user can remove the alarm from the queue.

Command Outputs

Output devices can be manually activated or deactivated by authorized users to control devices connected to them such as lights, warning indicators or sirens.

Door Command

This feature allows an authorized user to manually lock or unlock a door (override system controls) for a specific time. The user is able to unlock all doors at once or return all doors to their previous state.

Management Services

Through Management Services, an authorized user can add or edit cardholder records, including badge and associated cardholder information. In addition, the user can also view, approve, and process Web Access requests.

Request Status

The Request Status page allows authorized users to view the status of their requests, and depending on their menu permissions, the status of all requests or the status of requests submitted by other users that belong to the same department or company. The top portion of the screen displays the *Request Parameters* box where users can search for specific requests. The bottom portion displays the *Request List*, which displays requests in the order they are received. The links under the *Request* column allows you to view the details of the requests.

Request Approval

The approval process provides additional security measures by confirming the validity of a request before the request is presented for processing. Depending on the settings previously defined in Site Parameters (see Defining Web Access Options on page 445), up to three authorized users may be required to approve Web Access requests.

Add Cardholder

This feature allows authorized users to submit requests to enter cardholder information into the system. Depending on the permissions assigned, users can enter cardholder related information such as user-defined fields, journals, badge information, sponsor information (if the cardholder is a visitor), or attach a portrait to the cardholder record.

Edit Cardholder

In addition to submitting requests for new cardholders, authorized users can also request to change existing cardholder records, including deleting records from the system.

Validate

This function is used to process Web Access requests that require manual processing. See Processing Web Access Requests on page 453.

Audit

This feature allows authorized users to track changes to the software based on who performed the action, the data affected by the action, the date and time the action occurred, and the action itself, such as Add Badge, Edit Cardholder, Execute Application, and so on.

WebBadging Setup

Allows you to download and run the Web-BadgingSetup.exe file, which installs the WebUSB application to enable the use of USB-compatible badging devices via the P2000 Web Access interface. This service must be running on the client computer running Web Access or the badging devices cannot be controlled.

Visitor Management

Allows authorized users to request a visitor badge or request to extend the validation period of a cardholder badge. In addition, users can also view the status of their requests.

Visitor Request

Web Access provides a faster way for users to make visitor badge requests, so badges are ready when a visitor arrives at a building. Users can simply enter the appropriate visitor data into the system, assign a visitor sponsor, enter the date and time period of the scheduled visit, and enter notes for visitors with special needs. Visitor requests are processed using the P2000 Visitor Request Management application; see To Process Visitor Requests: on page 453.

Contractor Request

Enables authorized users to extend the badge validity period for selected cardholders. This feature is typically used for visitor badges that are about to expire, but can also be used as needed to extend the badge validity period for regular cardholders. Users can only extend the badge validity period for cardholders who belong to the same company as the user.

Request Status

This function is also accessed from Management Services; see Request Status on page 452.

Emergency Access Disable

This feature provides a rapid method of disabling access in case of an emergency. An authorized user can quickly disable all badges associated with selected cardholders and access is immediately denied at all doors. In addition, the selected cardholders are unable to perform any Web Access functions. Once it is determined that the emergency is over, the badges can be enabled again using the Badge application.

Note: Badges cannot be enabled using the Web Access interface.

Processing Web Access Requests

Web Access requests are processed either automatically or manually, depending on the configuration defined in Site Parameters (see Defining Web Access Options on page 445). With the exception of Visitor Requests, all Web Access requests can be processed automatically. Once a request is submitted and the approval is completed (if approval is part of the process), the request is added to the P2000 database. If an error occurs during this process, the request displays in the Request Queue table (see Viewing Request Queue on page 502) as *Error* or *Rejected* and the requester is subsequently notified of the problem.

Web Access requests that are set to Manual process, require an authorized user to manually process the request. After the request is submitted and the approval is completed (if approval is part of the process), the request is sent out for validation. With the exception of Visitor Requests, all Web Access requests are processed from the Validation page. See the following section for instructions on manually processing Visitor Requests.

To Process Visitor Requests:

 From the P2000 Main menu, select Access>Visitor Request Management. The Visitor Request Management dialog box opens. The list box (top portion of the screen) displays a queue of requests submitted using Web Access.

Note: The Visitor Request Management dialog box should be kept opened at all times for the person to manually process and act upon incoming visitor requests.

- 2. Select from the **Partition** drop-down list, the partition that contains the visitor requests.
- 3. To display today's requests only, click **Today Only**.

- 4. To display requests to be processed at the workstation location, click **This Location Only**. The list displays requests that have the location name entered in the Location field of the Workstation dialog box (see page 20).
- 5. To search the request queue for a specific record, click **Search** located above the list box, enter the visitor data into the fields on the Request Search dialog box, and click **OK**.

Request Search	×
First	
Middle	
Last	Paulson
ID	
Company	<any></any>
	All
ОК	Cancel

6. You may click **All** to display all visitors currently in the queue.

Note: You can also display all visitors in the queue by clicking **All** above the list box in the Visitor Request Management dialog box.

7. Select an entry from the queue to pre-fill the Visitor and Sponsor fields. Other information related to the selected Visitor, such as Request Notes, also display.

Note: The **Found in DB** fields indicate whether or not the P2000 system has identified a matching Visitor or Sponsor record in the cardholder database. A picture also displays, if there is one previously saved for the selected visitor.

8. See the following Visitor Request Management Field Definitions for more detailed information.

ral Time /2008 8: /2008 8: /2008 9: /2009 10 /2009 10 /2009 10	Visitor Anderson, Will Gray, Abert Humphrey, Rill Reulson, John	ID 5883 5443 2543 1221 Only	Company XYZ Consulting XYZ Consulting XYZ Consulting XYZ Consulting United Networking	Req Smit Smit Smit	uestor h, Robert J. h, Robert J. h, Robert J. h, Robert J. 4 Re	Requestor C Johnson Cor Johnson Cor Johnson Cor Johnson Cor Johnson Cor First First Midde	o Sta trols 7/2 trols 7/2 trols 7/2 trols 7/2 Steven	art Date 22/2008 8: 22/2008 8: 22/2008 8: 22/2008 10	End Da 7/22/20 7/22/20 7/22/20
/2008 8: /2008 8: /2008 9: /2008 10 /2008 10 /2008 10	Anderson, Wi Gray, Albert Humphrey, Ri Paulson, John	5883 5443 2543 1221 Only	VYZ Consulting XYZ Consulting XYZ Consulting XYZ Consulting United Networking	Smit Smit Smit	h, Robert J. h, Robert J. h, Robert J. h, Robert J. 4 Re Sponsor	Johnson Cor Johnson Cor Johnson Cor Johnson Cor Johnson Cor First Middle	itrols 7/2 itrols 7/4 itrols 7/4 itrols 7/2 Steven	22/2008 8: 22/2008 8: 22/2008 8: 22/2008 8: 22/2008 10	7/22/20 7/22/20 7/22/20 7/22/20
/2008 8: /2008 9: /2008 10 st John le st Paulson	Gray, Abert Humphrey, Ri Paulson, John	5443 2543 1221 Only	XYZ consulting XYZ consulting United Networking	Smit	th, Robert J. th, Robert J. th, Robert J. 4 Re Sponsor	Johnson Cor Johnson Cor Johnson Cor Johnson Cor Pirst First Middle	trols 7/2 trols 7/2 trols 7/2 Steven	22/2008 8: 22/2008 8: 22/2008 10	7/22/20 7/22/20 7/22/20
/2008 91 /2003 10 st John le st Paulson n 1221	Humphrey, Ri Paulson, John	2543 1221 Only	VYZ Consulting United Networking	Smit	th, Robert J. h, Robert J. 4 Re Sponsor -	Johnson Cor Johnson Cor aquests First Middle	steven	22/2008 8:	7/22/20
st John le Paulson	Paulson, John	0nly	United Networking		4 Re	opuests First Middle	Steven		
st John le Paulson n 1221	This Location (Only		_	4 Re	equests First Middle	Steven		
st John le Paulson	This Location (Only		-	4 Re	equests First Middle	Steven		
st John le st Paulson				_	Sponsor -	First Middle	Steven		
e Paulson						Middle			
st Paulson		-				Middle			
st Paulson									
p 1221						Last	Johnson		
0						ID			
V United Ne	tworking	•	J			Company	Johnson	Controls	
n Super Use	er 🔤	•	Take			Partition	Super Us	er	
May arriv	ve 30 minutes befor	re schedule	ed.	-		Found in DB	Yes		
B Yes		proved Vis	its 1				Searc	h	
Search	h							5	iave
								Save	and Print
		Auto	0	Start I	Date 🔽 7	/22/2008 💌			
0	-			Start	Time 10:07	:28 AM 📫			ven ly
	-			Void I	Date 🔽 7,	/22/2008 💌			lear
	n Super Usi s May arri B Yes Seard 0 Layout	n Super User May arrive 30 minutes before Search 0	Super User May arrive 30 minutes before schedul May arrive 30 minutes before schedul Search Aut O Layout V	A Super User Iake May arrive 30 minutes before scheduled. B Yes Approved Visits Search Auto Layout	A Super User	A Super User ▼ Iake g May arrive 30 minutes before scheduled. a Yes Approved Visits Search Start Date ✓ 0 ÷ Start Time 10:07 Start Time 10:07 Layout ▼ Void Date ✓	n Super User ▼ Iake Partition g May arrive 30 minutes before scheduled. Found in DB a Yes Approved Vists 1 Search Start Date ♥ 0	A Super User ▼ Take Partition Super User g May arrive 30 minutes before scheduled. Found in DB Yes g Yes Approved Visits 1 Search Start Date ♥ 7/22/2008 0	A Super User ▼ Isle Parktion Super User g May arrive 30 minutes before scheduled. Found in DB Yes B Yes Auto Start Date Yes Search Search Search Sove 0

- 9. When all the information is entered, click **Save** to complete the request and save the visitor and badge information. The new visitor data is also reflected in the Cardholder window.
- 10. If you wish to save and print the badge, click **Save and Print** (requires the Video Imaging application).
- 11. To process additional visitor requests, click Clear to clear the information on the screen, then select another visitor name from the queue or enter the information according to the Visitor Request Management Field Definitions.
- 12. If a visitor request is to be rejected, select the name from the queue and click **Deny**.
- 13. Click **Exit** to close the Visitor Request Management dialog box.

Visitor Request Management Field Definitions

Visitor Box

First – Displays the first name of the visitor selected in the queue. You may also enter a value to search the cardholder database by first name.

Middle – Displays the middle name of the visitor. You may also enter a value to search the cardholder database by middle name.

Last – Displays the last name of the visitor. You may also enter a value to search the cardholder database by last name.

ID – Displays the ID of the visitor. You may also enter a value to search the cardholder database by this field. **Company** – Displays the visitor's Company name. You may also enter a value to search the cardholder database by company name.

If the company name does not already exist in the database for the visitor's assigned partition, you are notified upon selecting the visitor request in the queue. To add the company name to the P2000 database, click the browse button to open the Company window. See Define Companies and Departments on page 249 for information on adding a company name to the P2000 database.

Partition – Displays the partition assigned to the visitor. To change the assigned partition, select a new one from the drop-down list. If you change the partition, you may also have to reassign the visitor's company to a company that belongs to the same partition.

Notes – Displays the visitor request notes entered by the requestor.

Found in DB – Indicates whether or not the P2000 system has identified a matching Visitor record in the cardholder database. If no match is identified, click **Search** to manually search for a matching record.

If **Found in DB** shows **Yes**, then the existing visitor record in the P2000 database is updated. If it shows **No**, the new visitor is added when you click **Save**.

Approved Visits – Displays the number of approved visits. This field is only valid if the **Found in DB** field displays **Yes**.

Note: The Visitor Request Management application creates four UDFs: **Approved Visits**, **Most Recent Visit**, **Second Most Recent Visit**, and **Third Most Recent Visit**. These UDFs are automatically updated and allow you to monitor the visits associated with the selected visitor. Search – If the P2000 system did not identify a matching Visitor record in the database, you may search the database by entering a value in any of the Visitor fields and then clicking Search. The Find Visitor dialog box opens displaying the visitor records that match the entered values. You may also click Search without entering any values to display all visitors in the database.

Find Visitor					×
First	John				
Middle			-		
Last	Paulson				
ID			-		
Company	ABC Mark	eting 💌]		1
First	Middle	Last	ID	Company	- -
John		Paulson	1221	ABC Marketing	_
1	_		. 1		
		OK	Cancel		

Select the visitor's name and click OK.

Take – If your facility uses the Video Imaging application, click **Take** to capture the visitor's portrait. See the instructions on page 374 (Step 4.) for details on capturing portrait images.

Sponsor Box

First – Displays the first name of the person who sponsors this visitor.

Middle – Displays the middle name of the person who sponsors this visitor.

Last – Displays the last name of the person who sponsors this visitor.

ID – Displays the unique ID assigned to the sponsor.

Company – Displays the sponsor's Company name.

Partition – Displays the partition assigned to the sponsor.

Found in DB – Indicates whether or not the P2000 system has identified a matching Sponsor record in the cardholder database. If no match is identified, click **Search** to manually search for a matching record.

Search – If the P2000 system did not identify a matching Sponsor record in the database, you may search the database by clicking **Search**. The Find Sponsor dialog box opens displaying the sponsor records that match the entered values. If no value was entered, all cardholders in the database are displayed.

ind Spor	isor					×
				_		
	First	<u> </u>				
	Middle					
	Last					
	ID			_		
	Company	<any></any>	•	•		14
First	1	1iddle	Last	ID	Company	-
Jane			Doe			
Aron			Humphrey			
Rick			Jaschob			
Steven			Johnson	12265	Johnson Controls	
Steve			Jones			
David	F	lerbert	Lawrence			
Roy	9	5	May		Johnson Controls	
Keith			Paulson			
Mary			Robertson			
James			Smith			
Robert	I	l	Smith	5676	Johnson Controls	
Susan			Thompson			-
Varan			Tomlincon			
			ОК	Cancel		

Select the sponsor's name and click OK.

457

Badge Box

Number – Enter a badge number (the number of allowed characters depends on the parameters selected in the Site Parameters dialog box; see **Max Badge Number** on page 38).

Auto – If your facility is set up to use the Auto-Badge Management feature (see page 279), click **Auto** to insert the next available badge number in the Number field.

Issue – Enter an issue level per badge number. If a visitor loses a badge, you would give the next available issue level and retain the same badge number. The number of badge issue levels supported depends on the panel type you use; see **Max Issue Level** on page 38.

Template – Select from the drop-down list the access template to be applied to this badge. See Access Template on page 273.

Design – Select from the drop-down list the badge design that was created using the Video Imaging application.

Start Date – Enter the date this badge becomes active. Click the down arrow to select a date from the system calendar.

Start Time – Enter the time this badge becomes active. Click the spin box buttons to select a time.

Void Date – Enter the date this badge is automatically voided. Click the down arrow to select a date from the system calendar.

Void Time – Enter the time this badge is automatically voided by the system. Click the spin box buttons to select a time.

Customizing the Web Access Interface

Web Access graphical user interface is controlled by styles, which can be fully customized according to individual needs. The interface is built with XML (Extensible Markup Language) technology and can be customized using the Altova® StyleVision® designer software tool to modify the following Web Access interface components:

- Caption font size, type, and color
- Images (for example, a company logo)
- Field type (combo box, text box, and so on), location, and size
- Button types
- Background colors

Note: The customization feature also allows Web Access pages to be displayed in different languages.

Web Access provides a default style (*jci*), which is assigned to all Web Access users. You can however, modify the default style and assign it to all users, or create multiple styles to be assigned to specific users via UDFs (see Assigning Styles to Web Access Users for details).

For detailed instructions on creating customized styles, refer to the *Web Access Manual*.

Assigning Styles to Web Access Users

Once the Web Access interface styles have been created using the instructions provided in the Web Access Manual, they are available for assignment via the *UIstyle* user-defined field (UDF).

To Create the User Interface Style UDF:

- From the P2000 Main menu, select Config>Cardholder Options>User Defined Fields. The User Defined Fields dialog box opens.
- Click Add. The Add User Defined Field dialog box opens.
- 3. In the **Name** field, enter *UIstyle*. Enter the name exactly as shown. The letter case must match: *UI* should be uppercase letters and *style* should be lowercase letters. Do not add spaces.
- 4. From the Type drop-down list, select Text.
- 5. In the Width field enter 32.
- Click OK to save the *Ulstyle* UDF, then click Done to close the User Defined Fields dialog box.

The *UIstyle* UDF is available in the Cardholder window to assign one or more of the new styles to the desired Web Access users.

To Assign Styles to Web Access Users:

- From the P2000 Main menu, select Access>Cardholder. The Cardholder window opens.
- Select a cardholder that is allowed to perform Web Access functions. See To Assign Web Access Permissions: on page 444.
- 3. Click **Edit** on the right side of the window. The Cardholder dialog box opens.
- 4. Click the **UDF 1** tab to display the user defined fields. Required fields are indicated by an asterisk and must be completed before a record is saved.

Cardholder Edit UDF 1 Hire Date 🗹 2/ 1/2008 💌 Car Color Blue Car Model Ford Car Year 1997 Parking Access 🗸 Parking Area East Entrance 💌 *License Plate 3AB3213P Parking Usage Monthly 💌 UIstyle green,basic

The dialog box displays all UDFs defined for your facility.

- 5. To assign a style to the cardholder, enter the style name into the **UIstyle** field. The name must match the directory style name; for example, *green*. Refer to the *Web Access Manual* for details in creating customized styles.
- 6. If you wish to assign multiple styles to the cardholder, enter the names of the styles separated with a comma; for example, *green,basic*.
- 7. Click **OK** to return to the Cardholder window.

Web Access Smart Card Encoder Configuration

Web Access offers web badging capabilities, which allow among other things, encoding cardholder badges from a Web Access computer.

To support the programming of smart cards using the ACS® Model ACR120 MIFARE smart card encoder, the Web Access computer must be configured as a web badging station. The encoder requires a simple USB cable connection from the device to the Web Access computer.

Note: The encoder must be connected to the USB port on the Web Access computer. <u>Do not</u> <u>connect to a USB hub</u>. Refer to the Web Access manual to install and configure the proper hardware and software components.

MIFARE is a contactless smart card technology that has 16 sectors; each sector with 64 bytes (512 bits) of memory. Each sector can contain up to 4 blocks, each block containing 16 bytes (128 bits).

After you configure the web badging station, use the WebAccess Config function to configure the parameters for encoding badges from web badging stations.

IMPORTANT: Before configuring the smart card encoder, the user must have a reasonable level of experience with encoding configuration and a thorough understanding of the MIFARE functional specification, including sector and block organization. Refer to your card manufacturer documentation for specific settings.

To Configure the Web Access Smart Card Encoder:

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand Site Parameters.
- Select Web Access and click Edit. The WebAccess Config dialog box opens.

		our la				
End	oding List					
	Sector	Block	Data Type	Date Field	Data Value	Use Value

4. Click **Add** to open the Mifare Encode Details dialog box.

lifare Encode Det	ails	×
<u>K</u> ey		
Кеу <u>Т</u> уре	•	1
<u>S</u> ector	·	
Data T <u>y</u> pe		1
		ſ
Block		
Data Field		1
		1
Data <u>V</u> alue		
Г	OK Cancel	
	Calical	

- 5. Enter the **Key** that was assigned to the card. A Key is basically a password. The Mifare card uses 48-bit keys, made of up to 12 Hex characters: "0" to "9" and "a" to "f" (uppercase or lowercase). This key is usually provided by the manufacturer.
- 6. Select from the **Key Type** drop-down list, whether this is a Key A or Key B. These keys perform different functions. For example, Key A could be required to read data in a sector, while Key B could be required to write data to a sector.

- Select from the Sector drop-down list, a sector number from 0 to 15 for the card. Each sector can store its own pair of keys (A and B).
- Select from the Data Type drop-down list, whether the type is Data or Keys. See page 461 for more details.
- 9. Select from the **Block** drop-down list, the block that is assigned to the sector. Depending on the Data Type selected, each sector can contain up to 4 blocks. By default, block 3 is assigned to any sector whose Data Type is Keys. See the following table for memory organization details.
- 10. If you wish to include a P2000 database field as part of the encoding information, select from the **Data Field** drop-down list the desired field.

- 11. If you wish to customize the encoding details, click **Use Data Value**, and enter the desired data in the **Data Value** field. If the Data Type is Data, the Data Value must be a decimal number string. If the Data Type is Keys, the Data Value must be a Hex string.
- 12. Click **OK** to save the encoding details and return to the WebAccess Config dialog box.
- 13. The P2000 system does not allow encoding badges from a Web Access computer unless you click Enable Mifare Encoding. If you wish to disable badge encoding from a Web Access computer, click the check box again to disable it.
- 14. Click **OK** to save the encoding parameters.

							Byte	Num	ber	withi	n a E	Block	ζ.					
Sector	Block	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	Description
15	3			Ke	yА			ŀ	Acces	s Bit	s			Ke	y B			Sector Trailer 15
	2																	Data
	1																	Data
	0																	Data
14	3			Ke	yА			ŀ	Acces	s Bit	s			Ke	yВ			Sector Trailer 14
	2																	Data
	1																	Data
	0																	Data
:	:																	
:	:																	
:	:																	
1	3		1	Ke	yА	1	1	A	Acces	s Bit	S		1	Ke	yВ	1		Sector Trailer 1
	2																	Data
	1																	Data
	0																	Data
0	3			Ke	yА			A	Acces	s Bit	S			Ke	yВ			Sector Trailer 0
	2																	Data
	1																	Data
	0																	Manufacturer Block

Mifare Encoding Scheme

Data Type: Data / User Data Value: false

 If the value of the selected Data Field is a number, it is encoded in binary with an ending semi-byte '0x0'; example:

for data field *Cardholder ID* with a value of *123*.

123 in binary is *0000007B* and with the ending semi-byte '0x0' it is encoded as *000007B0*.

 If the value of the selected Data Field is not a number, it is treated as ASCII string and attached with a leading semi-byte '0x0'; example:

for data field *first name* with a value of *John*.

John in ASCII is *6A6F686E* and with a leading semi-byte '0x0' it is encoded as *06A6F686E0*.

Data Type: Key / User Data Value: false

- The selected Data Field is treated as Hex string with an ending semi-byte '0x0'
- If the Data Field cannot be translate into Hex string, it is converted as '0x00'; example:

if the selected datafield's value is *E324FD* it is encoded as *0E324FD0*

462 CHAPTER 4 Advanced Features

Chapter 5: System Maintenance

he P2000 software provides several functions to help you maintain your security management system once it is up and running. These functions are considered non-routine and are typically performed by a system administrator. Some of these functions can be performed only from the Server.

This section includes the following topics:

- **Downloading Data to Panels**
- Monitoring Downloads
- **Controlling Smart Download**
- **Controlling P2000 Services**
- Viewing Workstation Status -
- Viewing System Status .
- Writing Panel Database to Flash Memory -
- Updating CK7xx Panels -
- Updating S321-DIN Panels
- Updating Mercury Panels
- Performing Database Maintenance
- Viewing Request Queue

Downloading Data to Panels

Under normal operating conditions, data such as additions to the cardholder database and other changes to the system are downloaded automatically to the panels and no specific downloading procedures are required. With the Download function, you can manually download data to panels if there has been an interruption in communication.

For example, if a panel or group of panels has been offline for maintenance, you can use Download to update panels with system changes that occurred while they were down. Or, you may need to download data to all panels after a complete power failure or system upgrade.

You can download individual items such as a change in holiday schedule or added card events, or you can download all items at once.

TIP:

Open the Download Status dialog box to monitor the records in the download queue as the download takes place.

To Download Data to Panels

- 1. From the P2000 Main menu, select System>Download.
- 2. Enter your password if prompted. The Download dialog box opens.



- From the Download To Panels box, click Serial Panel (legacy and P900) and Network Panel (all other panels). The list of panels displayed is limited to the type of panel selected here.
- 4. Select the panel or panels to which you wish to download data, or click **Select All** to select all panels in the list. Click **None** to clear your selections and reselect the panels individually.
- 5. From the Items To Download box, select the items you wish to download to the panel or panels, or click Select All to select all items in the list. Click None to clear your selections and reselect the items individually.

Note: HID panels go temporarily offline when a panel download is initiated. Also, when an HID terminal or input configuration is downloaded, there is a 7 to 8 second window when a cardholder may gain access, even if the enabled time zone does not allow it.

Note: OSI readers are temporarily disabled during the download operation and deny access until the download is completed.

 If you wish to download all badges to a panel and still allow access through a door of the panel while being updated, select **Badges** from the Items To Download box, and click to clear **Delete Badges From Panel Before Download**.

Note: If the panel being updated contains badges that should not be there, the system does not remove them from the panel, unless you delete those badges before the download.

 To download elevator data without deleting all elevators from the panel, select Elevators/Cabinets from the Item To Download box, and click to clear Delete Elevators From Panel Before Download. If you wish to reset a Mercury panel before download, select **Panel** from the Item To Download box (make sure a Mercury panel type is selected in the Download To Panels box), then click **Reset Panel Before Download** option.

Note: Since the **Reset Panel Before Download** option is provided to delete all data from the selected panel, you are required to perform a full download to restore the panel's database. Click **Select All** in the Items To Download box to restore the selected panel's database.

9. After you make your selections, click Download. The records queued during the download display in the Download Status message box. In large downloads, the number of items queued may fluctuate if data is transferred faster than the panels can receive it. This is normal. The download is complete when the Records Queued returns to 0.

Monitoring Downloads

Download Status displays the status of any items that the system automatically downloads. Use this application in conjunction with the Download function.

To Monitor Download Status

 From the P2000 Main menu, select System>Download Status. The Download Status message box opens.



2. Drag the Download Status message box to where it is visible during the download process. The number of records queued during the download displays as the download progresses. 3. To see the number of records queued at each panel, click **Details**. The Download Status By Panel dialog box opens.

anel	Normal Priority	High Priority	
Security	41	2322	
Software Lab	2	131	
Tech Sunnort	- 0	66	
Warehouse	37	800	
Refre	sh Done	1	

The list displays all panels configured in the system. All items are downloaded at a **High Priority**, with the exception of Badges, which are downloaded at a **Normal Priority**.

- 4. Click **Refresh** to update the screen with new data as the download progresses.
- 5. Click **Done** to close the Download Status By Panel dialog box.
- 6. Close the Download Status message box.

Controlling Smart Download

The Smart Download Control application allows you to closely monitor Smart Download queue activities, such as downloading badges to panels when changes are made to access groups and terminal groups, as well as downloading cardholder and badge changes.

Use the Download tab in Site Parameters (see page 43) to set up rules that determine the time when these downloads take place.

To Monitor Smart Downloads

 From the P2000 Main menu, select System>Queued Download Actions. The Smart Download Control dialog box opens.

The Information box displays the Smart Download **Rule** defined in the Site Parameters dialog box. The **Count** box displays the number of records queued for download. The **In Progress** box displays the number of records currently being downloaded.

C Smart Download Control					
Information Rule : 5 Min	ute(s) after record added				
Count : 3		In Progress :	0		<u>R</u> efresh
ID	Entry Time	Scheduled Time	Status	Description	Site
R-9983A61E-C11A-6GC3-B R-07080325-027-4GC7-&C- R-8998369D-69D8-4E06-84	7/20/2009 2:27:58 PM 7/20/2009 2:25:02 PM 7/20/2009 2:26:13 PM	7/20/2009 2:27:58 PM 7/20/2009 2:26:13 PM 7/20/2009 2:26:13 PM	Ide Ide Ide	Delete Badge '306' Download Badge '308' Download Badge '308'	Enterprise Simi Valley Simi Valley
Done					Summary

The following information displays for each download in the queue:

ID – Shows a number that the system automatically assigns to each download.

Entry Time – Displays the time of each download request entry.

Scheduled Time – Displays the scheduled download time of each timed download request entry.

Status – Displays the status of each down-load request entry.

Description – Displays the text description of each download request entry.

Site – Displays the site name where the download request entry originated.

- 2. Click **Refresh** to update the screen with new data as the download progresses.
- 3. Click **Summary** to display a summary of record counts and time information associated with the records currently displayed. Click **Cancel** to return to the Smart Download Control screen.
- 4. Click Done to close.

Controlling P2000 Services

A service is a process that performs specific system functions and operates in the background without user intervention.

This section describes the procedures for controlling and monitoring P2000 services, as well as outlines the steps to customize which of these services automatically initiate at system startup.

Service Startup Configuration

Service Startup Configuration allows you to enable or disable any of the P2000 services at the start of communications, as well as set up recovery actions to take place if a service fails. If you enable the **Auto Start** flag for a particular service, that service starts automatically and you can stop it or restart it using the Service Control or the Service Monitor application. If you disable the Auto Start flag, the service does not start automatically and does not display in Service Control.

By managing P2000 services, you can reduce system load by running only the required services. Before disabling a service, you must ensure that this service is not required to support a particular system function. If your facility uses advanced features, such as Guard Tour or BACnet, you could also enable or disable those services to start automatically when the Server starts up.

Access this function through the System Configuration window from the Server or a workstation. We recommend defining Menu Permissions to restrict access to this feature only to system administrators to prevent unauthorized personnel from stopping critical services.

To Edit Service Startup Configuration

- From the P2000 Main menu, select Config>System. Enter your password if prompted. The System Configuration window opens.
- 2. In the left pane, expand **Site Parameters** to display default system parameters.
- 3. Select Service Startup Configuration, and click Edit. The Edit Service Startup Configuration dialog box opens.

E O	CTV Server	CLOPEZROVPC1			_
E P			•	Restart on 1st failure then reboot	
	2000 Ametis Interface Service	CLOPEZR0VPC1		Restart on failure	
= P;	2000 Assa Abloy DSR Interface Service	CLOPEZR0VPC1	4	Take no action	
+ P	2000 AV Service	CLOPEZR0VPC1	•	Restart on failure	
E P	2000 Avigilon Interface Service	CLOPEZR0VPC1		Restart on failure	
÷ P.	2000 BACnet Service	CLOPEZR0VPC1		Reboot on any failure	
E P	2000 Bosch Interface Service	CLOPEZR0VPC1		Restart on failure	
: P.	2000 CK720 Download Service	CLOPEZR0VPC1	•	Restart on failure	
P	2000 CK720 Priority Service v1.0	CLOPEZR0VPC1		Restart on failure	
: P.	2000 CK720 Priority Service v2.1	CLOPEZR0VPC1	v	Reboot on any failure	
E P	2000 CK720 Upload Service	CLOPEZR0VPC1	•	Restart on failure	
= P.	2000 Endura Interface Service	CLOPEZR0VPC1		Restart on failure	
÷ P	2000 Escalation Service	CLOPEZR0VPC1	•	Restart on 2 failures then reboot	
E P	2000 External Trigger Service	CLOPEZR0VPC1	v	Restart on failure	
+ P.	2000 Guard Tour Service	CLOPEZR0VPC1	•	Restart on failure	

The list displays all services installed in the system, along with the **Server** name and a check mark in the **Auto Start** column to indicate whether the service automatically initiates at system startup. See P2000 Services Definitions for a brief description of these services.

- 4. Select the service that you wish to auto start and click the associated check box in the **Auto Start** column.
- 5. To auto start all services, click **All**, or click **None** to clear the selections and reselect the services individually.
- 6. To restrict a service from starting automatically at system startup, select the service and click the associated check box to remove the check mark.
- To set up recovery actions to take place if a service fails, select the service, and under the **Recovery** column select from the dropdown list one of the following options:

Take no action – No action takes place after a service fails.

Restart on failure – Default option. Restarts the service after failure.

Restart on 1st failure then reboot – Restarts the service after first failure, then reboots the computer.

Restart on 2 failures then reboot – Restarts the service after two failures, then reboots the computer.

Reboot on any failure – Reboots the computer on any service failure.

8. Click **OK** to return to the System Configuration window. The Service Control dialog box displays only the enabled services.

P2000 Services Definitions

CCTV Server – Communicates with the CCTV and the DVR hardware. See the CCTV and the DVR features, described in Chapter 4: Advanced Features.

P2000 Aimetis Interface Service – Performs communications between the P2000 Server and Aimetis Symphony[™] DVRs. It handles host event actions and processes alarms from the Aimetis DVR. This service is not involved in video playback.

P2000 Assa Abloy DSR Interface Service – Provides the communication between the P2000 Server and the Assa Abloy Door Service Router (DSR).

P2000 AV Service – Provides communication with audio visual components. See the DVR feature on page 428.

P2000 Avigilon Interface Service – Performs communications between the P2000 Server and Avigilon DVRs. It handles host event actions and processes alarms from the Avigilon DVR. This service is not involved in video playback.

P2000 BACnet Service – Starts the BACnet Interface communication. See the Metasys Integration (BACnet) feature on page 377.

P2000 Bosch Interface Service – Performs communications between the P2000 Server and Bosch Cameo DVRs. It handles host event actions and processes alarms from the Bosch DVR. This service is not involved in video playback.

P2000 CK720 Download Service – Performs Server downloads going to all CK705, CK720, CK721, and CK721-A panels in the system. **P2000 CK720 Priority Service v1.0** – Performs CK705 and CK720 panel online and offline notifications (for panel versions earlier than 2.1).

P2000 CK720 Priority Service v2.1 – Performs CK705, CK720, CK721, and CK721-A panel online and offline notifications (for panel Version 2.1 and later).

P2000 CK720 Upload Service – Performs CK705, CK720, CK721, CK721-A panel uploads to the Server.

P2000 Endura Interface Service – Performs communications between the P2000 Server and Pelco® Endura[™] DVRs. It handles host event actions and processes alarms from the Pelco Endura DVR. This interface service uses Pelco API that supports H.264 cameras. This service is not involved in video playback.

P2000 Escalation Service – Performs the alarm escalation function to monitor alarms that have the escalation option enabled.

P2000 External Trigger Service – Receives messages from external systems to be used as P2000 host event triggers.

P2000 Guard Tour Service – Starts Guard Tour Service and receives real-time event messages from RTLRoute services. See the Guard Tour feature on page 386.

P2000 HID Interface Service – Provides the communication between the P2000 Server and HID readers.

P2000 Intercom Interface Service – Provides the communication with the Intercom hardware. See the Intercom feature on page 430.

P2000 Intrusion Interface Service – Provides the communication between the P2000 system and intrusion panels. This service allows the P2000 system to obtain status information whenever an intrusion component changes and issues commands to control the intrusion zones, areas, and annunciators that are part of the intrusion system.

P2000 Isonas Interface Service – Provides the interface between the P2000 Server and Isonas readers.

P2000 Mercury Interface Service – Provides the interface between the P2000 Server and Mercury panels.

P2000 Milestone MIP Interface Service – Performs communications between the P2000 Server and Milestone Interface Protocol (MIP) XProtect[™] Corporate and XProtect Enterprise DVRs. It handles host event actions and processes alarms from the Milestone DVR. This service is not involved in video playback.

P2000 MIS Interface Service – Imports and exports data for the MIS Interface. See the MIS Interface feature on page 375.

P2000 Muster Control Service – Monitors the status of all muster zones, and when a muster is initiated, controls all the activities of the muster.

P2000 Nice Interface Service – Performs communications between the P2000 Server and Nice[™] DVRs. It handles host event actions and processes alarms from the Nice DVR. This service is not involved in video playback.

P2000 OnSSI Interface Service – Performs communications between the P2000 Server and OnSSI DVRs. It handles host event actions and processes alarms from the OnSSI DVR. This service is not involved in video playback. P2000 OPC Proxy Service – Provides the communication between P2000 applications and certain servers, such as the CCTV Server or the OPC Server.

P2000 OSI Interface Service – Provides the interface between the P2000 system and the OSI system.

P2000 Otis Interface Service – Provides the interface between the P2000 system and the Otis Compass Destination Entry elevator system. The P2000 Server acts as a message router for the messages going between the Otis system and CK721-A panels.

P2000 P900 SIO Handler Service – Performs communications between the P2000 Server and P900 panels.

P2000 Periodic Service – Performs periodic tasks such as deleting old history, synchronizing time of panels with server, and enabling or disabling badges based upon badge start and void dates

P2000 Rapid Eye Interface Service – Performs communications between the P2000 Server and Honeywell® Rapid Eye® DVRs. It handles host event actions and processes alarms from the Rapid Eye DVR. This service is not involved in video playback.

P2000 Remote Message Service – Receives messages from the local RTL Route Service and transmits these messages to the remote P2000 Remote Message Service. When receiving a remote message, the local Remote Message Service processes the message and passes it on to the local RTL Route Service for distribution to the local workstations.

P2000 Request Queue Service – Processes request queue entries into the P2000 database.

P2000 RTL Route Service – Routes all real-time messages to workstations and services. Also processes host events.

© 2014 Johnson Controls, Inc.

P2000 S321 SIO Handler Service – Performs communications between the P2000 Server and S321-DIN panels.

P2000 S321-IP Interface Service – Provides the communication between the P2000 Server and S321-IP panels.

P2000 SIA Interface Service – Provides the communication with configured SIA devices.

P2000 SIO Handler Service - Performs communications between the P2000 Server and legacy panels.

P2000 Smart Download Service – Downloads badges to panels when changes are made to access groups and terminal groups. It also downloads cardholder and badge changes. In addition, controls badges with temporary access

P2000 SMTE Service – Provides front end translation and mapping of external request queue interfaces.

P2000 Watchdog Service – Monitors other P2000 services to verify that they are operating and generates an alarm when a P2000 service fails.

P2000 XmlRpc Interface Service – Provides communication over the network, using the XML-RPC interface to communicate with remote devices such as building management components designed for Metasys system integration, or with Web Access servers.

P2000 XPortal Interface Service – Performs communications between the P2000 Server and Pelco® DVRs (Endura). It handles host event actions and processes alarms from the Pelco DVR. This interface service uses Pelco API that does not support H.264 cameras. This service is not involved in video playback.

Starting and Stopping Service Control

Service controls are provided specifically to stop and restart communications between panels and the Server to perform system maintenance functions, or during network troubleshooting operations. For example, the system administrator would be required to stop all communication services between panels and the Server when performing a P2000 version upgrade; or could stop uploads only between panels and the Server as part of system troubleshooting.

Service Control should be used only as directed by our Technical Support personnel, and should be performed only by a system administrator at the Server or workstation.

Note: The procedure to control services at redundancy systems might be different from the steps described here. Refer to your redundancy documentation for details.

To Stop or Start All Services

 From the P2000 Main menu, select System>Service Control. Enter your password if prompted. The Service Control dialog box opens.

Name	Server	Status
P2000 RTL Route Service	TECHPUBS	Running
CCTV Server	TECHPUBS	Running
P2000 AV Service	TECHPUBS	Running
P2000 BACnet Service	TECHPUBS	Running
P2000 CK720 Download Service	TECHPUBS	Running
P2000 CK720 Priority Service v1.0	TECHPUBS	Stopped
P2000 CK720 Priority Service v2.1	TECHPUBS	Running
P2000 CK720 Upload Service	TECHPUBS	Running
P2000 Escalation Service	TECHPUBS	Running
P2000 External Trigger Service	TECHPUBS	Running
P2000 Guard Tour Service	TECHPUBS	Running
P2000 HID Interface Service	TECHPUBS	Running
P2000 Intercom Interface Service	TECHPUBS	Running
P2000 Isonas Interface Service	TECHPUBS	Running
P2000 MIS Interface Service	TECHPUBS	Running
P2000 Muster Control Service	TECHPUBS	Runnina
	All	
Done	Start	Stop

The Service Control dialog box displays all services installed in the system, along with the Server name and its current status (Stopped or Running).

- 2. Click **All**, then click **Stop** or **Start**. If you click **Stop**, all services stop and no communication occurs between the Server and the panels. If you click **Start**, all services start running again.
- 3. Click Done.

To Stop or Start a Specific Service

- Select the service to be stopped (or started) from the scrolling list and click Stop (or Start). Only the services selected stop (or start) and the Stopped (or Running) status displays.
- 2. Click Done.

Controlling Services through the Service Monitor

The **P2000 Service Monitor** application is automatically installed at the Server during initial software installation. This application is represented by a traffic signal icon located in the system tray (right side of the Windows taskbar).

Each color in the traffic signal represents the status of P2000 services:

Red – Indicates that all services are Stopped.

Green – Indicates that all services are Running.

Yellow – Indicates that at least one service is *Running* or one service is *Stopped*.

When you right-click the traffic signal icon, a dialog box opens where you can start, stop, and refresh P2000 services; or open the Service Control dialog box.



Note: The procedure to control services at redundancy systems might be different from the steps described here. Refer to your redundancy documentation for details.

Viewing Workstation Status

An operator can see workstation status information, including the workstation's P2000 software version installed. This is a display-only feature, and is helpful to determine who is in the system, at what workstation, at what time they logged on, and other parameters associated with the workstation.

To View Workstation Status

 From the P2000 Main menu, select System>Workstation Status. The Workstation Status window opens.

Workstation	Status						_ 0
		Partition	Super User	•			Refresh
Workstation	Logged In	User Name	Login Date Time	Session Type	Badging	Server	Version
clopezr0vpc1 reception area security station warehouse	Yes Yes Yes No	Cardkey SJones KRoberts	8/7/2012 7:35:00 AM 8/7/2012 9:13:34 AM 8/7/2012 9:43:38 AM	P2000 Thick Client	Yes No No	Yes No No No	3.12.2 3.12.2 3.12.2 3.12.2 3.12.2
Force Logo	off		Dor	ie -			

2. If this is a partitioned system, select the **Partition** that contains the workstations you wish to view. All workstations active in the partition are displayed.

3. The list box displays the following information for each workstation:

Workstation – Indicates the name given to the workstation (and the Server).

Logged In – Indicates whether or not the workstation is currently logged on.

User Name – Displays the name of the user logged on at the workstation, if the workstation is logged on.

Login Date Time – Displays the date and time when the user logged on at the work-station.

Session Type – Indicates whether this is a P2000 Thick Client (workstations running P2000 applications), a P2000 Thin Client (workstations running Web Access applications), a P2000 Web UI (workstations running P2000 applications using a Web user interface), or Integration (this option is not used in this release).

Badging – Indicates if the workstation is configured as a badging workstation.

Server – Indicates the workstation that operates as the system Server.

Version – Displays the P2000 version installed at the workstation.

4. If you wish to log off a workstation that is currently logged on, select the workstation name and click **Force Logoff**.

Note: The Force Logoff feature is not supported for P2000 Web IU and P2000 Web Access sessions.

- 5. To update the list box with current workstations status, click **Refresh**.
- 6. Click **Done** to exit the window.

Automatic Software Updates

P2000 supports the automatic distribution of software updates to workstations in a P2000 Security Management System. P2000 administrators can configure the P2000 Server to force update all P2000 workstations in the system or allow workstation operators to accept or deny the update when logging into the system. The Automatic Update feature eliminates the need to manually update each workstation when a new P2000 software version or service pack is released. This feature is available for workstations running P2000 Version 3.10 and later.

The P2000 Server software tracks each software update installed on the Server, providing detailed information such as the version number, service pack number, installation date, the location of installation files, and the actual status of the update.

This function should be performed by a system administrator at the Server.

To View or Modify Software Updates

- From the P2000 Main menu, select Config>System. Enter your password, if prompted. The System Configuration window opens.
- 2. In the left pane, expand **Site Parameters** to display default system parameters.
- 3. Expand **Software Updates**. All updates currently installed on the P2000 Server are listed under this option.
- 4. To view detailed update information, select an update in the list and click **Edit**. The Software Update dialog box opens.

C Software Update	
Name	P2000 V3.11
Version	3.11.26
Service Pack	0
Installed	11/8/2011 10:08:22 AM
Server Path	C:\Program Files\Johnson Controls\CARDKEY P20(
Shared Path	\CLOPEZR0VPC1\SoftwareUpdates\P2000 V3.11
Command	setup.exe
Status	Required
<u>O</u> K	

The following information displays:

Name – Name of the update. Change the name, if necessary.

Version – Software version number of the selected update.

Service Pack – Number of the service pack provided in the selected update.

Installed – Date and time the selected update was installed on the P2000 Server.

Server Path – P2000 Server directory location that houses the files installed from the update.

Shared Path – The shared network directory accessible from workstations that houses the installation files used to update the P2000 workstations.

Command – Executable file that is started to update the P2000 workstations.

Status – Update control setting that is used to configure the P2000 Server to update its workstations according to one of the following options:

- Not Available Prevents the P2000 Server from updating its workstations. Select this option if you wish to wait before updating the client computers.
- **Optional** Allows workstation operators to accept or deny a P2000 software update when prompted during login.

IMPORTANT: The P2000 Server and its workstations must run the same software version and service pack. If operators deny an update to their workstation, the P2000 software may not function correctly.

 Required – Force updates all P2000 workstations in the system. When selected, workstations are unable to log on if they deny a software update.

Note: After you update the P2000 Server software, the system does not automatically update P2000 workstations (or prompt the operator to install the update) if the workstation operator is currently logged into the P2000 software. The operator must log out and log back into the P2000 system before the software can be automatically updated (some platforms may require users to use the Run as Administrator option when logging on to the P2000 system for the automatic software update to work). To help avoid mismatched software versions between the P2000 Server and its workstations, you may perform a Force Logoff command, if needed, to force the user to log off of a selected workstation; see page 471 for details.

Note: After you update the P2000 Server software, the default **Status** setting may vary according to the type of update (for example, new version or service pack). Always verify and change, if necessary, the current Status setting after each server update.

- 5. In the **Status** drop-down list, change the update control setting, if necessary.
- 6. Click OK.

Viewing System Status

The System Status window is a dynamic display of the status of panels, associated devices, and other integration components configured in the system. This useful troubleshooting tool allows you to quickly determine if panels and connected devices are communicating. If communications go down between the Server and the panels, the System Status window reports the last known status of the devices.

The System Status window is view only. You can manually change the status of a component using features accessed from the Control menu. See Operator Controls on page 303.

To Access the System Status Window

 From the P2000 Main menu, select System>System Status. The System Status window opens.

G System Status		_ 🗆 ×
Reader Terminals	Partition Super User	-
✓ Network Panels	Serial Panels	Refresh
Panels Administration DS20, Real Entry Security Warehouse TIU	0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 A A A A A A A	1 15 16
Done O	Msg Routing Status Legend Panel	Details

- 2. Select a component from the drop-down list at the top left of the window. Information for each component is presented at the end of this section, starting on page 476.
- 3. If this is a partitioned system, select the **Partition** to which the component belongs.

- 4. Click **Network Panels** or **Serial Panels**. The list of displayed devices is limited according to the type of panel selected here.
- Click **Refresh** to update the system status display.
- 6. To see icon definitions for the different condition indicators, click **Legend** at the bottom of the window.



Note: Unreliable icons (crossed out with a yellow bar) indicate that the items' parent devices are not functioning. For example, an input point is marked as unreliable if its parent terminal or panel is down.

7. Click **Done** to close the System Status Legend dialog box.

Note: When the Message Routing Status indicator at the bottom of the System Status window displays in green, it indicates that all communications between the workstation and the Server are up. If communications go down, the Message Routing Status indicator turns red.

 To display Serial or Network panel information, select the panel and click Panel Details. A Panel Details dialog box opens displaying current panel information.



Changes to Polling Direction for Serial Panels

Name – Displays the name given to the panel.

Configured type – Displays the panel type.

Firmware version – Displays the firmware version of the panel.

IPL version – Displays the IPL (Initial Program Load) version of the panel.

Version description – Displays the version description of the panel.

Last poll communication – Displays the last time the Server received information from the panel.

Serial Number – Displays the serial number assigned to the panel. Available only for S321-DIN panels.

Primary or Alternate – Displays whether the Primary or Alternate connection is in use for a network panel.

Polling Direction – Displays the polling direction (forward or reverse) in which the Server communicates with a legacy panel in a loop configuration.

of failed download connections – Displays the number of times the Server has failed to connect to this panel.

of failed download transfers – Displays the number of times an in-progress transfer was aborted.

Delay Downloads Until – Displays the time the Server attempts the next download connection to this panel.

Reset Time – Click to immediately try a new download connection to this panel.

Counters last cleared – Displays the last time you clicked Reset Counters.

Panel avg. clock drift (seconds) – Displays the average time difference between the Server and the panel.

Panel max clock drift (seconds) – Displays the largest time difference between the Server and the panel.

Reset Counters – Click to reset the values to 0.

- Click **Done** to close the Panel Details dialog box and return to the System Status window.
- 10. Click **Done** to close the System Status window.

To Display the Status of Aritech Intrusion Panels

- In the System Status window, select one of the intrusion components (Intrusion Areas, Intrusion Zones, or Intrusion Annunciators) from the drop-down list at the top left of the window, the associated intrusion panel displays.
- Select the intrusion panel from the list box, then click Panel Details. The Intrusion Panel Status dialog box opens.

Intrusion Panel Status	×
Name	Panel_Intrusion
Connected	No
Invalid Vendor Address	No
Port Opened	No
MainsFailure	No
Battery Low	No
Battery Test	No
Battery Test Fail	No
Battery Missing	No
Tamper	No
Done	

Name – Displays the name of the intrusion panel.

Connected – Displays whether the panel is connected.

Invalid Vendor Address – Displays whether the vendor address of the intrusion panel is invalid.

Port Opened – Displays whether the intrusion panel port is open.

MainsFailure – Displays whether the maintenance of the intrusion panel has failed.

Battery Low – Displays whether the battery of the intrusion panel is low.

Battery Test – Displays whether the battery of the intrusion panel is in test.

Battery Test Fail – Displays whether the battery of the intrusion panel has failed its test.

Battery Missing – Displays whether the battery of the intrusion panel is missing.

Tamper – Displays whether the intrusion panel has been tampered.

3. Click **Done** to close the Intrusion Panel Status dialog box.

To Display the Status of Fire Alarm Panels

- 1. In the System Status window, select one of the fire alarm components (Fire Zone, Fire Detector, or Fire IO Module) from the drop-down list at the top left of the window, the associated fire alarm panel displays.
- 2. Select the fire alarm panel from the list box, then click **Panel Details**. The Fire Panel Status dialog box opens.

Fire Panel Status		×
Name	[Fire Densel 1	
Connected	Yes	
Invalid Vendor Address	No	
Port Opened	Yes	
General Failure	No	
[Done	

Name – Displays the name of the fire alarm panel.

Connected – Displays whether the fire alarm panel is connected.

Invalid Vendor Address – Displays whether the vendor address of the fire alarm panel is invalid.

Port Opened – Displays whether the fire alarm panel port is open.

General Failure – Displays whether the fire alarm panel has failed.

3. Click **Done** to close the Fire Panel Status dialog box.

System Status – Reader Terminals

When you select **Reader Terminals**, all panels in the system for the type of panel selected (Network or Serial), are listed by name in the Panels column. An icon next to the panel name indicates the status of the panel.

The reader terminals connected to the panels are displayed in the same row as their panel, and are listed under the corresponding terminal number assigned during configuration. The displayed icon indicates the status of the terminal. When you place the cursor over the terminal icon, a pop-up box displays showing the terminal name assigned.

System Status – Input Terminals

When you select **Input Terminals**, all panels in the system for the type of panel selected (Network or Serial), are listed by name in the Panels column. An icon next to the panel name indicates the status of the panel.

The input terminals connected to the panels are displayed in the same row as their panel, and are listed under the corresponding terminal number assigned during configuration. The displayed icon indicates the status of the terminal. When you place the cursor over the terminal icon, a pop-up box displays showing the terminal name assigned.

System Status – Output Terminals

When you select **Output Terminals**, all panels in the system for the type of panel selected (Network or Serial), are listed by name in the Panels column. An icon next to the panel name indicates the status of the panel. The output terminals connected to the panels are displayed in the same row as their panel, and are listed under the corresponding terminal number assigned during configuration. The displayed icon indicates the status of the terminal. When you place the cursor over the terminal icon, a pop-up box displays showing the terminal name assigned.

System Status – Inputs

When you select **Inputs**, all terminals and panels in the system for the type of panel selected (Network or Serial), are listed by name in the Terminals/Panels column. An icon next to the terminal or panel indicates the corresponding status.

The input points connected to the terminals or panels are displayed in the same row as their terminal or panel, and are listed under the corresponding input point number assigned during configuration. The displayed icon indicates the status of the input point. When you place the cursor over the input point icon, a pop-up box displays showing the input point name assigned.

All input points above 16 are reserved for Soft inputs. You can expand the size of the window to view these inputs (up to 25). A status icon is represented for each possible input state. If no icons are present, no input points are associated with the terminal or panel.

Note: You can display the status of Mercury Input Points and Mercury Output Points only if they are associated with P2000 inputs or outputs.

System Status – Outputs

When you select **Outputs**, all terminals in the system for the type of panel selected (Network or Serial), are listed by name in the Terminals column. An icon next to the terminal indicates the status of the terminal.

The output points connected to the terminals are displayed in the same row as their terminal, and are listed under the corresponding output point number assigned during configuration. The displayed icon indicates the status of the output point. When you place the cursor over the output point icon, a pop-up box displays showing the output point name assigned.

Note: Some panel types require that you select the **Log Output Status Message** option to display outputs in the System Status list.

System Status - OTIS Elevator Status

When you select **OTIS Elevator Status**, all Otis elevator servers in the system are listed by name. The individual status icon indicates if the associated Otis Destination Entry Computer is Up or Down.

System Status – Mustering Zones

When you select **Mustering Zones**, the system displays the zone status of each Muster Zone; see Muster Zone Status and Control Field Definitions on page 327.

System Status – Security Level Terminals

When you select **Security Level Terminals**, all panels that have security level terminals in the system, for the type of panel selected (Network or Serial), are listed by name in the Panels column. An icon next to the panel name indicates the status of the panel.

All security level terminals are displayed in the same row as their panel and are listed under the corresponding terminal number assigned during configuration. The display shows the security level setting for each terminal. A number 0 indicates the security level is not used or is not assigned.

System Status – Intrusion Areas

When you select **Intrusion Areas**, all intrusion panels in the system are listed by name under the Intrusion Panel column. An icon next to the intrusion panel name indicates the status of the panel.

All intrusion areas associated with the intrusion panel are displayed in the same row as their panel, and are listed under the corresponding intrusion area number assigned during configuration. The displayed icon indicates the status of the intrusion area. When you place the cursor over the intrusion area icon, a pop-up box displays showing the intrusion area name assigned. You can issue commands for the areas by right-clicking the associated status icon. The following commands may be available, depending on the current state of the area:

 Arm – (Aritech) Arms the selected Aritech area if at the time that you issue the command the area's state permits it.

Arm – (Bosch and Mercury) Arms the selected Bosch or Mercury area with a pre-configured delay.

Forced Arm – (Aritech) Arms the selected Aritech area regardless of the area's state at the time when you issue the command.

Forced Arm – (Bosch) Arms the selected Bosch area immediately.

Disarm – Disarms the selected area.

Note: When a Mercury intrusion area is disarmed, and some zones were faulted but are now normal, the area still remains in the alarmed state. To get the area back to the normal state, you must disarm the area from the MRDT keypad terminal or from the Intrusion Control window, see Controlling Intrusion Items Using the Intrusion Control Window on page 342.

System Status – Intrusion Zones

When you select **Intrusion Zones**, all intrusion panels in the system are listed by name under the Intrusion Panel column. An icon next to the intrusion panel name indicates the status of the panel.

All intrusion zones associated with the intrusion panel are displayed in the same row as their panel, and are listed under the corresponding intrusion zone number assigned during configuration. The displayed icon indicates the status of the intrusion zone. When you place the cursor over the intrusion zone icon, a pop-up box displays showing the intrusion zone name assigned. You can issue commands for the zones by right-clicking the associated status icon. The following commands may be available, depending on the current state of the zone:

Bypass On – Commands the selected zone to be bypassed.

Bypass Off – Turns off bypassing of the selected zone.

Reset – (Not supported by Bosch or Mercury) Resets the state of the selected zone. If you issue this command while the input point is still in alarm because it is still being unsealed, you must seal the input and send this command again to reset it.

ResetAck – (Not supported by Bosch or Mercury) Resets the state of the selected zone. If you issue this command while the input point is still in alarm because it is still being unsealed, there is no need to re-send the command after the input is sealed. The command remains valid and resets the zone as soon as the input seals.

System Status – Intrusion Annunciators

When you select **Intrusion Annunciators**, all intrusion panels in the system are listed by name under the Intrusion Panel column.

An icon next to the intrusion panel name indicates the status of the panel. (Annunciators are not supported with Mercury panels.)

All intrusion annunciators associated with the intrusion panel are displayed in the same row as their panel, and are listed under the corresponding intrusion annunciator number assigned during configuration. The displayed icon indicates the status of the intrusion annunciator. When you place the cursor over the intrusion annunciator icon, a pop-up box displays showing the intrusion annunciator name assigned. You can issue commands for the annunciators by right-clicking the associated status icon. The following commands may be available, depending on the current state of the annunciator:

Activate – Activates the selected annunciator.

Deactivate – Deactivates the selected annunciator.

System Status – Fire Zone

When you select **Fire Zone**, all fire panels in the system are listed by name under the Fire Panel column. An icon next to the fire panel name indicates the status of the panel.

All fire zones associated with the fire panel are displayed in the same row as their panel, and are listed under the corresponding fire zone number assigned during configuration. You can display the status of up to 20 fire zones per row. If more than 20 fire zones are defined, they display in the following rows. The displayed icon indicates the status of the fire zone. When you place the cursor over the fire zone icon, a pop-up box displays showing the fire zone name assigned. You can issue commands for the fire zones by right-clicking the associated status icon. The following commands may be available, depending on the current state of the zone: **Disable Zone** – Disables the selected fire zones.

Enable Zone – Enables the selected fire zones.

System Status – Fire Detector

When you select **Fire Detector**, all fire panels in the system are listed by name under the Fire Panel column. An icon next to the fire panel name indicates the status of the panel.

All fire detectors associated with the fire panel are displayed in the same row as their panel, and are listed under the corresponding fire detector number assigned during configuration. You can display the status of up to 20 fire detectors per row. If more than 20 fire detectors are defined, they display in the following rows. The displayed icon indicates the status of the fire detector. When you place the cursor over the fire detector icon, a pop-up box displays showing the fire detector name assigned. You can issue commands for the fire detectors by right-clicking the associated status icon. The following commands may be available, depending on the current state of the detector:

Disable Detector – Disables the selected fire detectors.

Enable Detector – Enables the selected fire detectors.

System Status – Fire IO Module

When you select **Fire IO Module**, all fire panels in the system are listed by name under the Fire Panel column. An icon next to the fire panel name indicates the status of the panel.

All fire input/output modules associated with the fire panel are displayed in the same row as their panel, and are listed under the corresponding fire input/output module number assigned during configuration. You can display the status of up to 20 fire input/output modules per row. If more than 20 fire input/output modules are defined, they display in the following rows. The displayed icon indicates the status of the fire input/output module.

When you place the cursor over the fire input/output module icon, a pop-up box displays showing the fire input/output module name assigned. You can issue commands for the fire input/output modules by right-clicking the associated status icon. The following commands may be available, depending on the current state of the input/output module:

Disable Module – Disables the selected fire input/output modules.

Enable Module – Enables the selected fire input/output modules.

Activate Module – Activates the selected output of a fire input/output module.

Note: Although the Activate and Deactivate commands are available for inputs, only outputs can be successfully activated or deactivated.

Deactivate Module – Deactivates the selected output of a fire input/output module.

System Status – Wireless Parameters

In addition to the normal Up, Down, or Override status of OSI devices, you can also verify status values of OSI devices that are related to the wireless signal they receive. When you select **Wireless Parameters**, the list box displays the signal strength, packet ratio, and battery voltage values that are reported by the OSI devices.

These parameters are only updated by the reader about every 30 minutes (to conserve battery power). The System Status window automatically refreshes itself approximately every 30 seconds.

	_			_			
Network Panels	I⊄ ≦erial Pa	nels		Refresh	J		
Terminals	Time	Portal Signal	Portal Ratio	Reader Signal	Reader Ratio	Batt Voltage	Ext Voltage
Bren Hall 2nd Floor Stair 3	4/24/2007 9:00:41 AM	-38	99.5	-43	100.0	6.066	0.009
Bren Hall 5th Floor Stair 2	4/24/2007 9:45:42 AM	-38	99.3	-47	99.6	6.213	0.007
Bren Hall 5th Floor Stair 3	4/24/2007 9:34:43 AM	-41	99.4	-48	99.4	6.039	0.009
Bren Hall 2nd Floor Stair 1	4/24/2007 9:31:16 AM	-40	99.7	-51	97.5	6.176	0.009
Bren Hall 2nd Floor Stair 2	4/24/2007 9:44:25 AM	-42	97.8	-53	98.9	5.368	0.007
OSI TEST READER	4/24/2007 9:01:36 AM	-39	100.0	-57	86.4	5.890	0.009
Bren Hall 4th Floor Stair 2	4/24/2007 9:46:55 AM	-46	99.2	-58	99.6	6.034	0.004
Bren Hall 1st Floor Stair 2	4/24/2007 9:52:04 AM	-56	99.0	-65	97.9	5,860	0.007
Bren Hall 3rd Floor Stair 2	4/24/2007 9:49:12 AM	-63	98.2	-66	97.3	6.142	0.009
Bren Hall 6th Floor Stair 3	4/24/2007 9:35:18 AM	-61	98.1	-67	97.5	6.022	0.004
Bren Hall 4th Floor Stair 3	4/24/2007 9:30:36 AM	-67	94.1	-74	95.5	5.877	0.009
Bren Hall 3rd Floor Stair 1	4/19/2007 5:49:49 PM	-62	51.5	-75	91.3	5.858	0.007
Bren Hall 3rd Floor Stair 3	4/24/2007 9:53:47 AM	-79	14.3	-65	55.9	5.748	0.004
Bren Hall 5th Floor Stair 1	4/24/2007 9:53:53 AM	-85	99.8	-85	100.0	5.439	0.009
Bren Hall East Exit	4/12/2007 6:34:00 PM	-81	44.2	-85	61.8	5.233	0.002

The Wireless Parameters display can be sorted by any column by clicking the desired column header.

Green bars indicate that the OSI devices are operating within acceptable parameters. Yellow bars indicate a weakness in the devices (you may want to investigate further to determine the cause and if corrective action is required). Red bars indicate a fatal breakdown in the OSI devices.

The display indicates the following status values for each OSI reader:

Portal Signal Strength and Reader Signal

Strength – These values indicate the Radio Frequency (RF) signal level being received by the portal and reader respectively as measured in decibel milliwatts (dBm). The signal level is affected by the distance between the portal and reader and the type number of obstructions between the portal and reader. Walls and doors between the portal and reader reduce the signal level especially if they contain metal. A signal level of -50 dBm or higher is considered good. A signal level of -70 to -50 dBm is considered marginal. A signal level of below -70 dBm is considered unacceptable and needs to be corrected to ensure proper operation. Improving signal strength is a physical installation issue and is different for every installation. Techniques for improving signal strength include reducing the distance from portal to reader, moving the portal to a location with fewer obstructions between it and the reader, installing additional portals, and changing the portal antenna to a high-gain directional antenna.

Note: The OSI portal has the capability to communicate with the reader over 16 different RF channels or frequency bands. These channels can be configured through the Web UI of the portal. By default, all 16 channels are enabled in the portal. The portal uses the first configured channel that it finds available. The reader scans through all 16 channels until it is able to establish communication with the portal over that channel. By enabling only one or two channels on the portal, you can control the frequency bands used for communication. Using a different channel may isolate the portal and reader from the interfering frequency. In particular, channels 25 and 26 are outside the frequency bands used by Wi-Fi networks and therefore good choices if a Wi-Fi network is suspected to be causing your

System Status - Integration Components

interference.

Select **Integration Components** from the drop-down list to display the status of certain third-party components configured in the system. The status column indicates one of the following possible states:

Unknown – The status of the component has not yet been determined.

Up – The P2000 system is able to communicate with the component.

Down – The P2000 system is unable to communicate with the component.

Disabled – The P2000 system has been instructed not to communicate with the component.

Unavailable – The status of the component is not available.

Portal Packet Ratio and Reader Packet Ratio –

These values indicate the ratio of good to invalid data packets received from the wireless signal as measured in percentage. The packet ratio is affected by signal strength and external interference. A packet ratio of 50 to 100% is considered good. A packet ratio of 30 to 50% is marginal and should be improved for optimum operation. A packet ratio of less than 30% is considered unacceptable and may prevent proper operation. If both the portal and reader are reporting good signal strength levels but either the portal or reader is reporting a poor packet ratio, it usually indicates some type of interference. Typical causes of interference are electrical noise from other electrical equipment (large electrical motors or microwave ovens), nearby strong RF transmissions (radio or TV station transmitting antennas), or other wireless equipment or networks (Wi-Fi wireless networks or cordless phones). Moving the portal to a different position further away from interfering sources may help. Another solution may be to change the RF channels used by the portal for communicating with the readers.

Battery Voltage – This value indicates the current voltage from the reader's batteries. As the batteries are depleted, the reported voltage drops. Weak batteries can affect the wireless communication if the reader is seeing low signal strength or if there is large amounts of interference. If the voltage drops too low, the reader shuts down. A voltage of 5.0 volts or higher is considered good. A voltage of 4.5 to 5.0 volts is considered marginal and the batteries should be replaced soon. A voltage of below 4.5 volts is considered unacceptable and the batteries must be replaced as soon as possible or the reader may shutdown.

External Voltage – Displays the voltage of the external power supply.

Writing Panel Database to Flash Memory

With the Write DB To Flash function, you can manually archive the panel's RAM data more frequently as major changes are made to the system database. For example, if you delete several badges from the system, it would be appropriate to write the panel's RAM data to flash memory. That way, if the RAM data is lost, (before the system performs the scheduled automatic backup), the most recent saved flash memory contains the latest badge information.

This function is available for CK705, CK720, CK721, CK721-A and Mercury panels.

Note: The system automatically backs up and stores CK721-A panels' RAM based database at the panel level flash memory, according to their automatic backup schedule; see Backup DB to Flash Interval on the General Tab on page 56.

For CK7xx panels, you **<u>must</u>** always perform this function after:

- Adding or deleting RDR2S-A or RDR8S terminals.
- Modifying general parameters of existing RDR2S-A or RDR8S terminals (except Name, Public, or Query String fields).
- Adding or deleting RDR2S-A or RDR8S input or output points.

Since the data stored at each panel is different, you must perform this procedure for each panel in the system.

To Manually Write Panel Database to Flash Memory

 From the P2000 Main menu, select System>Write DB To Flash. Enter your password if prompted. The Write DB to Flash dialog box opens.

C Write DB To Flash	_ 🗆 🗙
Panel To Write	: Security
	Write
	Done

- 2. Select the **Panel To Write** from the drop-down list.
- 3. Click **Write**. All data stored in the panel's RAM is backed up to its flash memory.
- 4. Click Done.

Updating CK7xx Panels

This function updates CK705, CK720, CK721, or CK721-A panel firmware. You can also update terminal firmware, as long as the terminals connect to panels of Version 2.3 or later. Johnson Controls provides the update file, along with documented instructions. This function should be performed only by a system administrator at the Server.

This function requires the login names and passwords of all panels in the system. You can find the default panel name and password in the panel's Installation and Operation manual. If you changed your panel's login name, you must enter the new name and password to perform this function.

Note: Johnson Controls delivers each version upgrade with separate documented instructions (Software Release Notes). Be sure to read and follow all specific upgrade documentation instructions before performing an update.

483

IMPORTANT: While updating firmware on an encrypted CK721-A panel (Version 3.1+), you may need to promptly answer queries generated by the WinSCP application. Selecting the **Y** (Yes) option allows the operation to proceed. Failing to provide a prompt answer may result in no firmware update. You may have to close and reopen the Update CK705/CK720 Panels application to proceed. This message no longer displays once approval has been given using the **Y** option.

To Update CK7xx Panels and Terminals

 From the P2000 Main menu, select System>Update CK705/CK720 Panels. Enter your password if prompted. The Update CK705/CK720 Panels dialog box opens.

🛱 Update CK705/CK720 Panels	>
Panel To Update Security	
Terminal To Update None	
Terminal Type	
Update File	
Browse	
Panel Login Name	
Panel Password	
Select a CK705/CK720 Updater Script File	
Lipdate	
Done	

- 2. Select the **Panel To Update** from the drop-down list.
- If the system detects that this is a panel Version 2.3 or later, the **Terminal to** Update drop-down list displays all the terminals connected to the panel selected. Select the terminal name you wish to update. If you do not wish to update terminal firmware, select None.
- 4. If you select to update a specific terminal, you must select the **Terminal Type** that you wish to update.
- Click Browse to navigate to the directory in which the update file resides. Johnson Controls provides this file.

- 6. Select the file. The file name displays in the **Update File** field.
- 7. Enter the **Panel Login Name** as programmed at the panel.
- 8. Enter the **Panel Password** as programmed at the panel.
- 9. Click **Update**. The information contained in the update file is downloaded to the panel or terminal selected. This process may take several minutes.

Note: The firmware update process requires waiting for the current terminal firmware update to complete before proceeding to update the next terminal. Do not attempt to update multiple terminals at the same time.

10. After the update process is complete, select another terminal name and type, and then click **Update**.

Note: During the terminal firmware update process, all terminals connected to a CK721-A panel go offline. The offline terminals may allow access if you enabled the **Facility Code Only when Offline** flag.

11. After the update process is complete, click **Done** to close the dialog box.

Note: After a panel version upgrade, open the System Status window to check the status of the panel. If the panel shows a **panel version mismatch** condition indicator, you must open the Edit Panel dialog box to change the panel's type to the updated panel's firmware version. Then wait until the panel indicator shows **up** in the System Status window.

12. Follow the procedure on page 463 to download data items to the recently updated panel.

Updating S321-DIN Panels

This function updates S321-DIN panel firmware. Johnson Controls provides the update file, along with documented instructions. This function should be performed only by a system administrator.

Note: Each version upgrade is delivered with separate documented instructions (Software Release Notes). Be sure to read and follow all specific upgrade documentation instructions before performing an update.

To Update S321-DIN Panels

 From the P2000 Main menu, select System>Update S321 Panels. Enter your password if prompted. The Update S321 Panels dialog box opens.

Update 5321 Panels		
Panel Name	Version	Update
5321 Panel	0.0.0	
		Verify
		Apply
		Reboot Panel
		Erase
		Refresh
		Done

 Select from the list box the panel name you wish to update. You can select multiple names by holding down the

Note: Open the Real Time List to monitor panel update transactions as they occur.

- 3. Click **Update** to navigate to the directory in which the update file resides. Johnson Controls provides this file.
- Select the <name>.bz2 file and click
 Open. The information contained in the update file is queued. You can monitor the download progress via the Download Status dialog box. This process may take several minutes. After this process is completed, the Real Time List displays a *Code Image download success* message.
- 5. If the *Code Image download success message* is not reported after several minutes, click **Reboot Panel**. After the panel reboots and reports back online (approximately 30 seconds), repeat step 4.
- 6. Click **Verify** to send a verification command to the panel. The Real Time List displays a *Code Image download success message* to indicate that the verification was successfully completed.
- 7. Click **Apply**. The panel reboots, it takes about 2 minutes to download the code into the flash. The Real Time List indicates that the panel and associated devices are down. After the code is downloaded, the panel reboots again.
- When the panel is back online, click Refresh. The Version column in the list box displays the updated version number.

Note: The **Reboot Panel** option is provided to force the panel to restart, for example in cases when the panel is not functioning properly. The **Erase** option is provided to delete the configuration data at the panel. After you click **Erase**, the panel reboots; when it comes back online, you should proceed to download data items to the panel, using the procedure on page 463.

9. After the update process is complete, click **Done** to close the dialog box.
Updating Mercury Panels

Use this function to update Mercury panel and terminal firmware. Johnson Controls provides the update files. This function should be performed only by a system administrator at the Server.

Note: Some version upgrades may be delivered with separate documented instructions. In that case, be sure to read and follow all specific upgrade documentation instructions before performing an update.

To Update Mercury Panels and Terminals

IMPORTANT: The panel must be online during the update process. Also, the Message Routing Status indicator at the bottom of the Update Mercury Panels window must display in green to indicate that all communications are up and that the RTL Route service is running. If the Message Routing Status indicator turns red, the list box on the right side cannot display any of the actions or responses associated with the update.

 From the P2000 Main menu, select System>Update Mercury Panels. Enter your password if prompted. The Update Mercury Panels dialog box opens.

C Update Mercury Panels		_ [] X
Panel To Update	EP 2500 IP 181 Build 55	Sent download command for TP2500 IP181.N Terminal 'EP2500 IP181 MR50 Reader' has fm
Terminal To Update	EP2500 IP181 MR50 Reader	
Terminal Type	MR50	
Qurrent Firmware Version	1. 1. 3	1
Update File	C:\Users\Administrator\Desktop\Firmware\mr50_appl_1_52_4.aax	
	Browse	
New Firmware Version	1.52.4	1
Sent down	oad command for 'EP2500 IP181 MR50 Reader'	
Msg Routing Status	Undate Reset	

2. Select the **Panel To Update** from the drop-down list.

3. The **Terminal to Update** drop-down list displays the terminals that are connected to the selected panel. If you wish to update terminal firmware, select the terminal from the list. If you wish to update the panel firmware, select **None**.

IMPORTANT: You can only update terminal firmware if encryption is disabled at the panel.

4. If you select to update a specific terminal, the **Terminal Type** displays the type of the selected terminal.

Note: We do not provide terminal firmware upgrades for Schlage PIM400-485 or Aperio 1 to 8 Hub terminals.

- 5. The **Current Firmware Version** displays the version of the selected panel, or of the selected terminal, if you are updating terminal firmware.
- 6. Click **Browse** to navigate to the directory in which the update file resides. Johnson Controls provides this file.
- 7. Select the file. The file name displays in the **Update File** field.
- 8. The **New Firmware Version** field displays the expected firmware version number after analyzing the file name provided in step 7.
- 9. Click Update. The information contained in the update file is downloaded to the panel or terminal selected. The list box on the right side displays actions and responses associated with the update. The update process may take several minutes.
- After the update process is complete and if you wish to update another terminal, click **Reset** to clear the information, select another terminal, and then click **Update**.

11. After the update process is complete, click **Done** to close the dialog box.

Note: After a panel version upgrade, open the Panel Details dialog box in the System Status window to verify the correct panel firmware version.

12. Follow the procedure on page 463 to download data items to the recently updated panel.

Note: Make sure you select the **Reset Panel Before Download** flag when performing the first full download after a firmware update.

Performing Database Maintenance

You can perform a database backup, empty various data histories, load an archived database from backup, or reset event counters from the Database Maintenance dialog box. This function is password protected and should be accessible only by a system administrator or a designee.

Note: Some Database Maintenance tasks, such as **Shrink Database**, can only be performed by operators that are members of the Windows or PEGASYS Administrators group; see <u>Setting Up</u> User Accounts on page 28.

If you scheduled functions such as Database Backup or Empty Audit History to occur automatically, you can use the tasks in Database Maintenance to override the system and perform manual maintenance.

To Perform Database Maintenance Functions

 From the P2000 Main menu, select System>Database Maintenance. Enter your password if prompted. The Database Maintenance dialog box opens.

🕻 Database Maintenance 📃 🗌 🗙					
Maintenance Action					
Backup Data (Append) Backup Data (Overwrite) Backup Images (Append) Backup Images (Overwrite) Calculate Digital Signature CK721A/S321IP Data Import and Export Delete all badges from OSI database Delete all hardware from OSI database Delete all hardware from OSI database Delete Expired Visitor Badges Delete Expired Visitor Badges Delete Unused Access Groups Delete Visitors Without Badges Empty Alarms Empty Alarms History Empty Alarms History	•				
Perform					
Exit					

- 2. Under **Maintenance Action**, select the function you wish to perform. See Database Maintenance Actions for a description of each function.
- 3. Click **Perform**. A confirming message box displays. Depending on your selection, click the appropriate action.
- 4. Click Exit.

Database Maintenance Actions

Backup Data (Append) – Creates a backup of P2000 data without overwriting existing back-ups.

Backup Data (Overwrite) – Creates a backup of P2000 data by overwriting existing backups.

Backup Images (Append) – Creates a backup of P2000 images without overwriting existing backups.

Backup Images (Overwrite) – Creates a backup of P2000 images by overwriting existing back-ups.

Note: For more information on the previous Backup functions, see Database Backup on page 490.

Calculate Digital Signature – Validates the digital signatures, points out discrepancies, and corrects the discrepancies to ensure that records have a valid digital signature. This function is available if your facility uses the FDA Part 11 feature. See FDA Part 11 on page 429 and System Validation on page 495.

CK721A/S321IP Data Import and Export – Imports and exports CK721-A and S321-IP hardware configuration data in Comma Separated Values (CSV) file format. See CK721-A and S321-IP Data Import and Export on page 496 for details.

Delete all badges from OSI database – Deletes all badges from the OSI database.

Delete all hardware from OSI database – Deletes all hardware from the OSI database.

Delete Expired Visitor Badges – Deletes all visitor badges that have expired from the database. Each visitor badge has a *Visitor Validity Period* (defined in Site Parameters), during which the badge is valid.

Delete Selected Alarm – Deletes the selected alarm from the database.

Delete Unused Access Groups – Deletes all unused access groups (access groups not assigned to any badge) from the database.

Delete Visitors Without Badges – Deletes all visitors who have no assigned badges from the database.

Empty Alarms – Removes all alarms from the alarm queue. This action is typically performed when the queue displays alarms that cannot be secured, and thus cannot be discarded.

IMPORTANT: The Empty Alarms action does not remove selected alarms. The system deletes <u>all</u> alarms, so proceed with caution.

Empty Alarms History – Deletes all alarms in the Alarms History database table.

IMPORTANT: The Empty Alarms History and Empty Audit History actions should only be performed with the aid of a Johnson Controls Technical Support specialist.

Empty Archive Database – Removes the data from the Archive Database. This database is used for running P2000 reports.

Empty Audit History – Purges all audit history data from the database. The audit history data contains time and date stamped records of user actions.

Empty Download Queue – Purges the actions from the Download Queue. This queue downloads P2000 data to selected panels. This function is typically performed when a panel is no longer in use, but the queue still lists downloads for that panel.

Empty Fire Data – Purges all fire alarm panel data from the database.

Empty Guard Tour Note – Purges all guard tour notes from the P2000 database. You can configure the P2000 system to remove these notes after a predetermined amount of time; see Guard Tour Notes on page 399.

Empty Saved Muster Data – Purges all muster data from the database. This data is normally saved to the database for evaluation once a muster is terminated.

Empty Smart Download Queue – Purges the actions from the Smart Download Queue. For more information, see Controlling Smart Download on page 465.

Empty Transaction History – Purges the Transaction History data from the database. Transactions indicate some form of system activity. They can include items like access requests and general system messages, such as when a panel loses communication with a reader. Typically, transactions represent communication initiated at field panels and sent to the P2000 Server.

IMPORTANT: This action should only be performed with the aid of a Johnson Controls Technical Support specialist. **FDA Backup Performed** – Informs the P2000 system that the FDA backup is archived, in accordance with company policies to meet FDA Part 11 record retention policy. For more information, see FDA Part 11 Backups on page 493.

Kill All Reports – Attempts to stop all database queries issued by a P2000 report. This is helpful if an operator accidentally tries to run an extreme report, such as all transaction history for the last two years. This action is not guaranteed to work in all cases.

Load Archive Database from Backup – Loads the data from the Archive Database. This database is used for running P2000 reports.

Mark Secondary Tables – Marks the starting point of FDA data for later analysis.

Migrate Panel – Allows you to change the panel type from D6xx or S320 to a specified CK705, CK720, CK721, CK721-A panel or STI-MUX to match the new hardware installed in the field. The former panel's settings, such as associated terminals, output points, and input points, are applied to the new panel.

Remove Access Groups from Disabled Badges

 Removes access groups from disabled badges. This in turn allows the Delete Unused Access Groups command to be used more efficiently.

Remove Expired Access Groups from Badges – Removes from badges any access group

assignment that is past its Temporary Access Period Void date.

Reset Counters to Zero – Resets all values in the Event Counters list to zero. For information, see Counting Events on page 354.

Reset Reserved Autobadge Numbers – Resets these numbers, making them available for assignment. A reserved autobadge number is a number that has already been assigned, but a badge has not yet been issued.

Set all Input Status to Unknown – Used if a panel is down (for example, for maintenance) and alarms are being generated.

Set all Output Status to Unknown – Used if a panel is down (for example, for maintenance) and alarms are being generated.

Set all Panel Status to Unknown – Used if a panel is down (for example, for maintenance) and alarms are being generated.

Set all Terminal Status to Unknown – Used if a panel is down (for example, for maintenance) and alarms are being generated.

Set Computer Default Language – Allows you to change the P2000 default language for all users using this computer. This also sets the language in which the P2000 services operate. This task is to be used on P2000 systems operating in a foreign language.

Shrink Database – Commands SQL Server to free up space in the database. This process is normally performed automatically at various intervals.

Sync cardholder/badge active flags – Synchronizes the cardholder/badge active flags, in case this uncommon problem occurs.

Synchronize OSI Transaction Counter – Sets the P2000 transaction counter to the last transaction currently in the OSI WAMS database. It would typically be used only if the OSI WAMS database was destroyed and recreated. You must stop the P2000 OSI Interface Service before performing this task. After you run the task, restart the P2000 OSI Interface Service. **IMPORTANT:** This action should only be performed with the aid of a Johnson Controls Technical Support specialist because it can cause transactions to be processed multiple times.

Update Database Default Strings – Causes all default data in the database (such as Super User partition, Super User menu permission group, default icon image set names, and so on) to be rewritten to the database in the current P2000 language. This task is to be used on P2000 systems operating in a foreign language.

Update Preprocessed Report Archive tables – Runs a preprocessed report against an archived database.

Update Preprocessed Report tables – Updates preprocessed report tables manually. Normally, this process occurs automatically each night. However, if the data has changed and you wish to run a preprocessed report with current data, you may manually start this process.

Validate Digital Signature – Ensures the integrity of all records and provides evidence when records have been altered. A digital signature verifies that unauthorized users have not modified the values in the columns of a record. This function is available if your facility uses the FDA Part 11 feature. See FDA Part 11 on page 429 and System Validation on page 495.

Database Backup

The P2000 system should be backed up on a regular basis. Backups can be performed using several supplied methods, and can be made to any backup device supported by Microsoft SQL Server. Tape backup systems are usually the most cost-effective while also being fast and reliable, and are the only type that allows backups larger than a single media.

The P2000 Data database should be backed up frequently, while the P2000 Images database should only be backed up when cardholder images are modified. Backups can be performed without stopping the P2000 communication services; therefore, the system remains operational during the backup process. This function should be performed by a system administrator.

Note: Badge layouts that are created using the ID Server software option, cannot be backed up using any of the Database Maintenance backup options. To maintain up-to-date backups of your Video Imaging layout files, refer to the Video Imaging manual that was shipped with your option.

Configuring a Backup Device

- 1. From the System Configuration window, select **Site Parameters** and click **Edit**. The Edit Site Parameters dialog box opens.
- 2. Click the Retention Policy tab.

Note: You must use the P2000 server to configure a backup device. If your P2000 system is deployed on a distributed environment (the P2000 server is hosted on two separate computers), you must use Microsoft SQL Server tools to define the backup device to use for P2000 backup and restore functions.

Edit Site Parameters					
Port Configuration RMS EMail External Eve Seneral Printing Panel Types Facility Code Retent	nt Trigger MIS Web Access XmRpc ion Policy Password Policy BACNet Download				
Retention Time					
<u>A</u> udit Trail	30 Days 💌				
Iransactions 30 Days					
Alar <u>m</u> s	30 Days 💌				
Muster Data	30 Days 💌				
Request Queue	30 Days 💌				
<u>T</u> our Note	30 Days 💌				
FDA Retention Policy	and Validation Policy				
Retention Period (years)	10				
Violation Alert Period (days) 30					
Last FDA Backup	1/23/2009				
Bachup Device					

3. At the bottom of the window, select a **Backup Device** from the drop-down list. If there are no devices on the list, or you want to add a new one, click **Config Device**. The Backup Devices dialog box opens.

Mana	 Turne	Davies
Name	туре	Device
ſape 389	Disk	C:\Program Files\Microsoft SQL Server\M
Images	Disk	C:\Program Files\Microsoft SQL Server\M
Daily	Disk	C:\Program Files\Microsoft SOL Server\M

 Click Add. The Config Backup Device dialog box opens.

Config Backup	Device	х
pid rite	Name Images	
	Elle Name C:\Program Files\Microsoft SQL Serv Browse	
Tape Drive -	N <u>a</u> me 🗾	
Named Pipe -	Name III.1	
	OK Cancel	

- 5. Enter a descriptive Name for the device.
- Select the Type of backup device from the drop-down list. Options include: Disk, Tape, and Pipe.
- 7. If you select **Disk**, enter in the Disk File box, a valid path and file name for the backup file. The specified path must exist on the SQL server computer. The backup file is created in that path on the DB server, not on the P2000 server.
- 8. If you select **Tape**, select from the drop-down list in the Tape Drive box, the name of the tape device.
- 9. If you select **Pipe**, enter in the Named Pipe box, a valid system pipe name. This option allows you to communicate with third-party backup software.
- 10. Click OK to save your settings. The new device is listed in the Backup Devices dialog box and also displays in the Backup Device drop-down list of the Edit Site Parameters dialog box.
- 11. To remove a device, select it and click **Delete**.
- 12. Click **Done** to close the Backup Devices dialog box.

Manual Backups

 From the P2000 Main menu, select System>Database Maintenance. Enter your password if prompted. The Database Maintenance dialog box opens.

🕻 Database Mainten	ance	_ 🗆 ×
Maintenance Action		
Backup Data (Append) Backup Data (Overwrii Backup Images (Apper Backup Images (Overw Calculate Digital Signat CK721A/S321IP Data 1 Delete all badges from Delete all badges from Delete Expired Visitor 1 Delete Selected Alarm Delete Unused Access Delete Visitors Without Empty Alarms History Empty Alarms History	e) d) write) import and Export OSI database om OSI database adges Groups : Badges	
	Perform	
	Exit	

- 2. Select **Backup Data** or **Backup Images** (Append or Overwrite) from the Maintenance Action list to backup the P2000 Data or the P2000 Images database.
- 3. Click **Perform**. At the verification message, click **Yes** if you wish to perform the backup operation. You cannot reverse this action.
- 4. The P2000 Backup utility opens and immediately begins the backup. The P2000 Backup utility exits when the backup is complete.
- 5. Click **Exit** to close the Database Maintenance dialog box.

Advanced Backups

You can also perform backups using the stand-alone P2000 Backup utility located in the **Bin** directory of the P2000 software installation.

Note: Use the Server to perform advanced backups.

 From your Windows desktop, select Start>Programs>Johnson Controls> P2000>Database Backup. The P2000 Backup dialog box opens.

Select Database	* P2000 Data		-
Restore options			
<u>Restore to archive</u>			
Convert to Current Ve	ersion After Restore		
Restore from foreign backup			
Media			
Backup Devic	e Tape 389		•
🗌 Initialize media on backup			
		Config Douise	1

- 2. From the Select Database drop-down list, select either P2000 Data or P2000 Badge Images.
- 3. In the Media box, select a **Backup Device** from the drop-down list. If you wish to add a new device, click **Config Device** and follow the instructions provided in Configuring a Backup Device on page 490.

Note: The **Initialize media on backup** and **Format media on backup** options are provided to allow old backup media to be reused. For more information on these options, refer to the Microsoft SQL Server documentation.

- 4. Click **Backup** to start the backup process.
- 5. Click **Done** when the backup operation finishes.

Automatic Backups

You can configure backups as P2000 event actions to allow automatic backups, based on a time setting or any other P2000 event trigger. See Creating Events on page 349 for more information. For example, you can program an event to back up the database (the action) every Friday at 5:00 P.M. (the trigger).

figure Even	ts - Edit								
	Partition	Super User				-	Public		
	Name	Automatic	Backup				Allow Ma	anual Trigge	r
	Active	<always></always>			8	-	Trigger Loak	OOR	
		Enable				-		AND	
iggers									
Category	Туре		Conditi	ion		Logic		Valu	e
Time/Date	Time/Dat	e e	Day of	the Week		IS EQUAL T	0	5:00 Frida	NUU PM
	-								
		Add	1	Edit	1	Delete	1		
						·	_		
tions									
Delay	Category	Туре			Value 1		Value 2		Value 3
00:00:00	Host	Backup	Databas	e	Data		Append		
	- IOOK	backup	- acauds	~	2010985		Overw	~~	-
er	Add		Edit	De	elete	Up		Down	
Categor	y Time/Date								
Тур	• Time/Date					•			
Condition	n Day of the W	/eek (steady sta	ke)			•			
Logi	IS EQUAL TO		_	_	_	•			
Yalu	e Friday								1
		OK		Cancel					
			Action						
					c	rder 1			
					Delay (H:	M:S) 00:00:	00	-	
				Category	Host				
				Type	Backup D	stabase			
				Database	Data				
				Hode	papend				
									ок

Program this event trigger, as you would any other event triggers in the system, giving it a descriptive name, and selecting a partition and time zone. Make sure you select **AND** in the Trigger Logic field to create more than one condition to be met to activate this trigger.

493

Define two conditions in the Triggers box: first, select the Day of the Week condition to be equal to Friday, and then select a Time condition to be equal to 5:00 P.M.

In the Actions box, define two actions: one to back up the Data database, and the second to back up the Images database. Make sure you select Category *Host* and Type *Backup Database* in the Action dialog box.

FDA Part 11 Backups

Depending on the parameters defined in the Retention Policy tab of Site Parameters (page 40), you must perform periodic backups to comply with FDA Part 11 record retention requirements. Backups must be done using the standard backup procedures described in Database Backup on page 490.

Once the backup process has been completed, use the following steps to inform the P2000 system that the backup is archived, in accordance with your company policies to meet FDA Part 11 record retention policy.

 From the P2000 Main menu, select System>Database Maintenance. Enter your password if prompted. The Database Maintenance dialog box opens.

C Database Maintenance	_ 🗆 🗙
Maintenance Action	
Empty Download Queue Empty Fire Data Empty Guard Tour Note Empty Saved Muster Data Empty Smart Download Queue Empty Transaction History FDA Backup Performed Kill All Reports Load Archive Database from Backup	
Mark Secondary Tables Migrate Panel Remove Access Groups from Disabled Badges Remove Expired Access Groups from Badges Reset Counters to Zero Reset Reserved Autobadoe Numbers	_
Perform Exit	

- 2. Select **FDA Backup Performed** from the Maintenance Action list.
- 3. Click **Perform**. At the verification message, click **Yes** to inform the P2000 system that an FDA backup was performed. You cannot reverse this action.
- 4. A message displays to confirm that you have just completed a backup, which will be archived according to your company policies to meet FDA Part 11 record retention requirements. Click **OK** to confirm. The system updates the *Last FDA Backup* field in the Retention Policy tab of Site Parameters (see page 40), to match the current system date. Any FDA Retention Policy alarms will change their alarm status to *Secure*.
- 5. Click **Exit** to close the Database Maintenance dialog box.

Database Restore

Under normal operating conditions, you do not need to restore the P2000 database, but if the database is lost, you can restore it from a recent backup, using the P2000 Backup utility. You can also restore an older P2000 database to an archive database for the purpose of printing reports or examining old settings, without affecting the currently active P2000 system.

IMPORTANT: Use the Server to restore the database. If you restore the database to a different Server other than where it was originally backed up, you need to contact Technical Support for a new Registration Key, and you also need to reconfigure your Server (DB and COMM); see Site Parameters on page 33.

You can only perform a non-archive restore after closing all P2000 applications on all workstations and the Server, and after stopping the P2000 communication services; see Starting and Stopping Service Control on page 470. You must also shut down the **P2000 Service Monitor** application at the Server. Do this by right clicking the **traffic signal** icon located in the system tray (right side of the Windows taskbar), if it exists, and selecting **Quit** from the menu. You can restart all P2000 communication services and applications after the restore process finishes. We recommend that all panels in the system be downloaded immediately after a database restore; see Downloading Data to Panels on page 463.

To Restore the Database

 From your Windows desktop, select Start>Programs>Johnson Controls> P2000>Database Backup. The P2000 Backup dialog box opens.

C P2000 Backup		
Database		
Select Database:	P2000 Data	•
Restore options		
<u>Restore to archive</u>		
Convert to Current Versi	ion After Restore	
Restore from foreign backup		
Media		
Backup Device	Tape 389	•
🔲 Initialize media on backup		
Eormat media on backup		Config De <u>v</u> ice
Backup	Restore	Do <u>n</u> e

- 2. From the Select Database drop-down list, select either P2000 Data or P2000 Badge Images.
- 3. In the Media box, select a **Backup Device** from the drop-down list. If you wish to add a new device, click **Config Device** and follow the steps provided in Configuring a Backup Device on page 490.
- 4. Select **Restore to archive** to place the database in an offline location, that way reports can be generated using its data without affecting the currently operating system.

5. If you wish to convert the restored database to the current version, click **Convert to Current Version After Restore**.

Note: The **Restore from foreign backup** option forces the SQL Server to load a database, regardless of where it was created, normally only backups created on the current computer can be restored. Use this option only when instructed to do so.

6. Click **Restore** to start the restore process. The Select Backup To Restore dialog box opens.

Select Backup To Restore		×
Backup Number	View Contents	
ОК	Cancel	

7. Click **View Contents**. The Backup Contents dialog box opens.

ackup Co	ntents	x
Number	Date	Name
1	4/30/2007 4:11:33 PM	P2000 Images Backup 4/30/2007 4:11:3.
2	7/26/2007 11:34:01 AM	P2000 Images Backup 7/26/2007 11:34:
3	12/10/2007 3:37:29 PM	P2000 Data Backup 12/10/2007 3:37:29.
4	3/12/2009 1:11:53 PM	P2000 Images Backup 3/12/2009 1:11:5
5	3/12/2009 1:58:34 PM	P2000 Data Backup 3/12/2009 1:58:33 PM
4		Þ
	OK	Cancel

- 8. Select the backup you wish to restore, and click **OK**.
- 9. A message notifies you that the restore was successfully processed, click **OK** to return to the P2000 Backup dialog box.
- 10. Click **Done** to close the P2000 Backup dialog box.

_____Eerform_____

2. Select Validate Digital Signature from the Maintenance Action list.

define the related recovery actions that were set up before the database restore; see page 466.

As a system administrator, you should schedule validation of your system on a regular basis to minimize the possibility of record tampering. The Validate Digital Signature feature ensures the integrity of all records and provides evidence when records have been altered. This function is available if your facility uses the FDA Part 11 feature. See FDA Part

Note: A digital signature verifies that unauthorized users have not modified the values in the

 From the P2000 Main menu, select System>Database Maintenance. Enter your password when prompted. The Database

_ 🗆 ×

.

Maintenance dialog box opens.

System Validation

11 on page 429.

columns of a record.

🕻 Database Maintenance

Reset Reserved Autobadge Numbers

Set all Input Status to Unknown Set all Output Status to Unknown

Set all Panel Status to Unknown Set all Terminal Status to Unknown

Set Computer Default Language

Sync cardholder/badge active flags Synchronize OSI Transaction Counter

Update Database Default Strings Update Preprocessed Report Archive tables Update Preprocessed Report tables Walidate Digital Signature

Maintenance Action Reset Counters to Zero

Shrink Database

 Note: After you restore the database, use the Service Startup Configuration application to enable or disable P2000 services as well as
 3. Click Perform. The Validate Digital Signature dialog box opens.

 Yalidate Digital Signature
 Yalidate Digital Signature

access group details	
access group details save	_
access_group_number	
accgroup	
accgroup_save	
accgrpelevator	
accgrpelevator_save	
accgrpterm	
accgrpterm_save	
accgrptermgrp	
accgrpcermgrp_save	
accupi acctol, cave	
accupi_save actioninterlock	
actioninterlock save	
alarmcategory	
alarmcategory save	
alarmcolors	
alarmcolors_save	
alarmfw	
alarmfw_save	
alarmoptions	<u> </u>
1	1
Select All	Unselect All
validate secondary table(s)	
Perform	
Cancel	

- 4. Select the database table you wish to verify. You can select to verify multiple tables, or click **Select All** to verify all tables at once.
- 5. To clear your selections, click Unselect All.
- To verify secondary database tables, click Validate secondary table(s) to add the secondary tables to the selection list.
- 7. Click **Perform** to start the validation.

ate Digital Signature						
	Table:					
	Current Table					
Records	in current Table	•				_
Table	Invalid	Name	GUID	Date/Time	Mode	-
access_group_details	0					-
access_group_details_save	0					
access_group_number	0					
accgroup	0					
accgroup_save	0					
accgrpelevator	0					
accgrpelevator_save	0					
accgrpterm	0					
accgrpterm_save	0					
accgrptermgrp	0					
accgrptermgrp_save	0					
acctpl	0					-
	т	otal Number of invalid Signa	itures			0
		Export				
					Ca	ncel

The list box displays the following information:

Table – The name of the table being validated.

Invalid – The number of invalid signatures found in the table.

Name – The name of the record, for example cardholder or panel name, as defined in the applicable P2000 application.

GUID – The Global unique identifier of the record.

Date/Time – The date and time when modification took place. Only applicable for secondary tables, that is tables with the suffix *_save*.

Mode – The type of modification performed, such as delete (0), edit (1), or insert (2).

Total Number of Invalid Signatures – The number of records that have been tampered with.

- 8. Click **Export** to save the results in a file. This result file can be easily imported into, for example a Microsoft Excel file, and formatted according to your requirements.
- 9. Click Cancel to close the dialog box.
- 10. Click **Cancel** to return to the Database Maintenance dialog box.

11. Click **Exit** to close the Database Maintenance dialog box.

Note: In addition to using the **Validate Digital Signature** function, you can also use the **Calculate Digital Signature** function, which not only validates the digital signatures and points out discrepancies, but also corrects the discrepancies to ensure that records have a valid digital signature.

CK721-A and S321-IP Data Import and Export

This feature allows you to import and export CK721-A and S321-IP hardware configuration data, which reduces the commissioning time required to enter this information during configuration. You can preconfigure panels, terminals, time schedules, access groups, and other configuration settings using a standard Microsoft Excel® spreadsheet.

Operators must have the appropriate menu permissions to use this feature and must also belong to the Super User partition.

Note: This feature does not eliminate the configuration process; it eliminates the need for entering some data during the configuration.

Importing CK721-A and S321-IP Data

To import data into the P2000 database, you must obtain the XLS file provided by a Johnson Controls representative (via the AIM tools). The column names in the XLS file must be exactly the same as the ones listed under the Name column in the following table.

Item	Name	Value Type	To be used during import to P2000
1	DOOR LOCATION per Plans & Specs (Read Only Column) Make changes in Sales View	Text	No
2	READER LOCATION per Plans & Specs (Read Only Column) Make changes in Sales View	Text	No
3	Entry Method	Selection from a list of: Card In Free Entry NA	No
4	Exit Method	Selection from a list of: NA Free Egress Free Egress-Local Alarm Card Out REX Motion REX Motion with Backup Egress Button REX Motion with Backup Panic Bar Delayed Egress Panic Bar	No
5	Reader Entry_Exit Designation	Selection from a list of: Access Entry Exit	Yes
6	Logical Terminal #	Numeric value between 1 - 64 or Unused (for CK721A) Numeric value between 1 - 2 or Unused (for S321IP) Note: When "Unused" is entered as a value for the Logical Terminal #, the data on that row is <u>not</u> be imported.	Yes
7	Hardware Module # (Physical Address)	Numeric value between 0 - 31	Yes
8	Reader Terminal Index	Numeric value between 1 - 8	Yes
9	Supervisory Controller Part #	Selection: CK721A S321IP	Yes
10	Supervisory Controller RS485 Trunk # (CK722 Only)	Selection: A B NA	No
11	Supervisory Controller Program Tag (Panel Name)	Text – Up to 32 characters taken from text pro- vided on the import file and must be within the P2000 system.	Yes
12	Supervisory Controller Physical Location	Text	Yes
13	Supervisory Controller IP Address (Also for S321_IP)	IP Address format (###.###.####.####)	Yes
14	Supervisory Controller MAC Address	MAC Address format (hh.hh.hh.hh.hh.hh)	Yes
15	Door Controller Physical Location	Text – Up to 64 characters taken from text pro- vided on the import file.	Yes

ltem	Name	Value Type	To be used during import to P2000
16	Door Controller Program Tag	Text – Up to 32 characters taken from text pro- vided on the import file and must be within the P2000 system.	Yes
17	Door Controller Part #	Selection: Generic S300DINRDR2SA S300DINRDR8S S321IP	Yes
18	Access Group	Text – List of access group names separated by semicolon (;). Each name can be up to 32 characters.	Yes
19	Time Schedule	Text – Up to 32 characters taken from text pro- vided on the import file. A valid active time zone name is preferred.	Yes
20	Card Type	Text – Selection of the following card types, sepa- rated by semicolons (;), S321-IP supports one card type and CK721-A supports multiple card types. CK721-A: Standard Wiegand, Encrypted Wie- gand, Binary BaFe, Mag Stripe, Invert Data, PIN Only, Card ID, HID Corporate 1000, BCD BaFe, 26-bit Wiegand Inverted, Eyecam-Prox-Indala, PIN + Card ID, 26 bit Sensor Forward, 26 bit Sen- sor Reverse, 32 bit Motorola, <custom> name of the first 8 CK720 card formats defined in the database. S321-IP: HID Corporate 1000, Cardkey Stan- dard, Cardkey Magstripe, Sensor 26 Bit, Raw 128 Bit (requires number of bits to use), <custom> card formats defined in the database.</custom></custom>	Yes
21	Metasys Interlock	Text	No
22	P2000 Map Reference	Text	No
23	Door Template Packages	Text	No
24	Comments	Text	No
25	Facility Code 1	Numeric Text for CK721-A. Ignored for S321IP.	Yes
26	Facility Code Type 1	Selection for CK721-A: Wiegand, N-Crypt, Mag Stripe, Custom. Ignored for S321IP.	Yes

Note: Item 10 to be used in future release.

After you enter the information in the XLS file, save the file as a Comma Separated Values (CSV) file, and then copy the CSV file to a location that is accessible to the P2000 system.

IMPORTANT: P2000 names in the imported data file must not contain any of the following characters: @ (at sign), . (period), ? (question mark), * (asterisk), \$ (dollar), # (pound), : (colon), ; (semicolon), ' (apostrophe), [(open bracket),] (close bracket), or , (comma).

To Import CK721-A and S321-IP Data

 From the P2000 Main menu, select System>Database Maintenance. Enter your password if prompted. The Database Maintenance dialog box opens.

🕻 Database Maintenance	_ 🗆 X
Maintenance Action	
Backup Data (Append) Backup Data (Overwrite) Backup Images (Append) Backup Images (Overwrite) Calculate Digital Signature CK721A/S321IP Data Import and Export Delete all badges from OSI database Delete all hardware from OSI database Delete Expired Visitor Badges Delete Selected Alarm Delete Unused Access Groups Delete Visitors Without Badges Empty Alarms Empty Alarms Empty Alarms History Empty Archive Database	•
Perform	
Exit	

2. Select CK721A/S321IP Data Import and Export from the Maintenance Action list.

Note: Make sure that all P2000 services are running.

3. Click **Perform**. The CK721A/S321IP Import and Export dialog box opens.

CK721A/5321IP Import and Export		X
File Name		Browse
Import Data		
C Export Data		
Run	Exit	

- 4. Click Import Data.
- 5. Click **Browse** to navigate to the location of the CSV file. Select the desired file.
- 6. The **File Name** displays the name of the CSV file.
- 7. Click **Run**. The Results window opens. See the following section for details.

Evaluating Imported Data

The Results window provides additional security, allowing you to evaluate all imported data before it is added to the P2000 database. You can review identified problems and decide whether to proceed with the operation or address any of the identified issues.

- After you click **Run** in the CK721A/ S321IP Import and Export dialog box, the Results window opens.
- 2. Click **Evaluate** to evaluate the data in the import file.

The import process starts by validating the data before the records are saved in the database. Once the evaluation is completed, the Results window opens displaying information associated with the imported data.

The screen is divided into two main frames. The left frame displays the evaluated data in a hierarchy tree format, showing panel to terminal relations. You need to select and expand each item in the tree to view the details. Each item is associated with one of the following icons to indicate the validity of the imported data.



The right frame displays error or warning messages associated with a selected item.

The Status box displays the following information:

Record Count – Indicates the number of records read from the import file or P2000 database.

Error Count – Indicates the number of errors found in the import file.

Warning Count – Indicates the number of warnings found in the import file.

Note: These counts display the total number of errors and warnings associated with the evaluated data displayed in the in the left frame. You may have to expand each parent item to identify each error or warning.

- 3. Click **Commit** to save the evaluated data into the P2000 database. At the verification message, click **Yes** if you wish to perform the import operation. You cannot reverse this action. Only the records without errors or warnings are saved. Verify that:
 - the Real Time List displays audit messages associated with this operation
 - the System Configuration displays the new panels and terminal names
 - the System Status shows the status of the panels and terminals

Note: When importing S321-IP panels, the P2000 S321-IP Interface Service automatically restarts after you click Commit.

- 4. Click **Save** if you wish to save all messages into a log file. See Saving the Log File on page 501 for details.
- 5. The **Cancel** button stops the processing of the specific task. For example, if you click Cancel while evaluating, this action causes all evaluated data to be lost. Cancelling the Save Log operation simply stops writing to the log file. Cancelling the Commit operation stops saving the records, but does not roll back any of the saved data and requires re-evaluation of the import file.

Results	
Penels Cr21-A Cr21-A Cr21-A Tropot Cr21-A Tropot Cr21-A Tropot Cr21-Rader 1 Tropot Reader 3 Tropot Reader 4 Dinot Reader 4 Dinot Reader 5 Dinot Reader 4 Dinot Reader 5 Dinot Reader 5	Row # = 2, Column = Hardware Module # (Physical Address), Input Data = -1, Log Type = Error, Error Number = 11, Message = Invalid value
Status	4
Record Count: 7	Eiror Count: 3 Warning Count: 0
Commit Evaluate	Save Log Gancel Exit

Saving the Log File

During the evaluation process, the system may generate error and warning messages that can be saved to further analyze the problems, correct mistakes, and improve the import process.

To Save the Log File

- After you click Evaluate in the Results window, the screen displays the evaluated data together with any error or warning messages associated with a selected item.
- To save the error or warning messages, click Save Log. The Log File dialog box opens.

Log File					×
	File Name			Browse	
		1			
		Save	Exit		

- 3. Click **Browse** to navigate to the location where you want to save the log file; enter the name of the log file.
- 4. The **File Name** displays the name of the log file.
- 5. Click **Save** to save the error information displayed in the Results window.
- 6. Click Exit to close.

Exporting CK721-A and S321-IP Data

Use this feature to export existing CK721-A and S321-IP data to an external system.

To Export CK721-A and S321-IP Data

 From the P2000 Main menu, select System>Database Maintenance. Enter your password if prompted. The Database Maintenance dialog box opens.

C	Database Maintenance	_ 🗆 🗙
M	laintenance Action	
	Backup Data (Append) Backup Data (Overwrite) Backup Images (Append) Backup Images (Overwrite) Calculate Digital Signature CK721A/S321IP Data Import and Export Delete all badges from OSI database Delete all badges from OSI database Delete Expired Visitor Badges Delete Expired Visitor Badges Delete Selected Alarm Delete Unised Access Groups Delete Visitors Without Badges Empty Alarms Empty Alarms History Empty Alarms History	
	Perform	
	Exit	

 Select CK721A/S321IP Data Import and Export from the Maintenance Action list.

Note: Make sure that all P2000 services are running.

3. Click **Perform**. The CK721A/S321IP Import and Export dialog box opens.

CK721A/S321IP Import and Export	X
File Name	Browse
🔿 Import Data	
Export Data	
Run Exit	

- 4. Click Export Data.
- 5. Click **Browse** to navigate to the location of the CSV file and select the desired file, or enter the location and file name.
- 6. The **File Name** displays the name of the CSV file.
- 7. Click **Run**. The Results window opens. See the following section for details.

Evaluating Exported Data

The Results window provides additional security by letting you verify all records before they can be exported to an external system. You can review identified problems and decide whether you wish to proceed with the operation or address any of the identified issues.

- After you click **Run** in the CK721A/ S321IP Import and Export dialog box, the Results window opens.
- 2. Click **Evaluate** to retrieve CK721-A or S321-IP panel related records from the P2000 database.

The export process starts by validating the data before it is exported to an external system. Once the evaluation is completed, the Results window opens displaying information associated with the exported data.

- 3. Click **Commit** to save the evaluated data into the selected export file (if the export file name exists, it is overwritten). At the verification message, click **Yes** if you wish to perform the export operation. You cannot reverse this action.
- 4. Click **Exit** to close the window.

Viewing Request Queue

The P2000 system provides a Request Queue database table that contains requests originated from external sources, such as Web Access requests (see Web Access on page 443).

Since external requests involve adding, deleting, or modifying data in the P2000 database, the Request Queue has been designed to provide additional security measures in the request processing by checking all records before they are allowed to enter the P2000 system. The Request Queue allows P2000 operators to intercept requests for the purpose of reviewing, editing, and finally letting request data enter the P2000 database system. The requests are packaged as XML documents and saved into the P2000 Request Queue table.

Once these requests enter the P2000 database, a system administrator can use the Request Queue View application to resolve Request Queue-related problems. The Request Queue View window displays current requests or requests that were archived in the Request Queue database table. This tool is useful to, for example, verify which requests are pending for an approval, which requests have been completed, or have been rejected.

Note: The amount of time that request records are kept in the Request Queue history table is defined in Site Parameters; see Retention Policy Tab on page 40.

To View Request Queue Items

 From the P2000 Main menu, select System>Request Queue View. The Request Queue View dialog box opens.

The list box displays the following information for each of the requests:

Create Time – Displays the date and time the request was submitted.

Expire Time – Displays the date and time the request expires. This date is defined by the number of days entered in *Expiration Period for Requests*, see Defining Web Access Options on page 445.

Sender – Displays the source that originated the request.

Details – Displays the Sender application requested for processing.

🕼 Request Queue View	,						_ 🗆 ×
Queue,							
Create Time	Expire Time	Sender	Details	Operation	Status	Last Name	First Name
6/2/2005 3:02:28 PM 6/2/2005 3:07:20 PM 6/2/2005 3:07:38 PM 6/2/2005 3:30:23 PM 6/6/2005 3:32:25 PM 6/6/2005 3:36:32 PM 6/6/2005 3:37:26 PM	6/16/2005 3:02:28 PM 6/16/2005 3:07:20 PM 6/16/2005 3:27:38 PM 6/16/2005 3:30:23 PM 6/20/2005 3:30:23 PM 6/20/2005 3:36:32 PM 6/20/2005 3:37:26 PM	P2KWebAccess P2KWebAccess P2KWebAccess P2KWebAccess P2KWebAccess P2KWebAccess P2KWebAccess P2KWebAccess	VisitorManagement.Visitor BResync.Status CardholderRequest.Cardh ContractorRequest.Cardh OntractorRequest.Cardh BResync.Status VisitorManagement.Visitor	Add Update Add Update Update Add	Ready for Manual Proc Committed Ready for Manual Proc Ready for Manual Proc Error Committed Ready for Manual Proc	Bolton Lopez Collins Jasper Adams Lopez Flint	David Ruth Michael Jeanette Peter Ruth Anna
7 of 7 Requests				View	Cancel Refre	esh	Filter

Operation – Displays the action (Add, Delete, Update) requested and that is associated with the Sender application.

Status – Displays one of the following:

- **Cancelled** The request was cancelled before being processed.
- **Committed** The request has been completed.
- **Error** There is an error in the request.
- Pending Approval 1 The request is waiting to be approved by the required approver.
- Pending Approval 2 The request was approved by Approver 1, and requires approval of a second approver.
- Pending Approval 3 The request was approved by Approvers 1 and 2, and requires approval of a third approver.
- **Processing** The request is currently being processed.
- Ready for Auto Processing The request has been approved and is ready for automatic processing; without operator intervention.

- Ready for Manual Processing The request has been approved and is ready for manual processing.
- **Rejected** The request was rejected.

Last Name – Displays the last name of the cardholder specified in the request.

First Name – Displays the first name of the cardholder specified in the request.

- To display the details of a specific request, select the line item in the list box and click View. See Viewing Request Details on page 505.
- 3. To cancel a specific request, select the line item in the list box and click **Cancel**; then click **Yes** to confirm.
- 4. To update the Request Queue View list box with new data, click **Refresh**.
- 5. To search for specific requests, click **Filter** and follow the instructions provided at the end of this section.
- 6. Click **Done** to close the Request Queue View dialog box.

Searching Specific Requests

The Request Queue View application allows you to define filters to help you locate specific requests quickly and easily, and in that way reduce the number of requests displayed on screen. You can define, for instance, a filter to show only requests that were submitted on a specific date and that are waiting for manual processing.

 In the Request Queue View dialog box, click Filter. The Filter dialog box opens. If you leave an asterisk (*) in a field, the filter criteria includes all records for that field.

Filter	×
Sender	P2KWebAccess
Status	Ready for Manual I 💌
First Name	*
Last Name	*
Begin Date	▼ 5/ 4/2005 ▼ 11:59:00 AM 🔹
End Date	▼ 5/ 6/2005 ▼ 11:59:00 AM ×
Туре	Queue
Max Count	2000
OK	Cancel

2. Enter a **Sender** name to view only requests that were originated from that source.

- 3. Select from the **Status** drop-down list the specific request status you wish to view. For example, you may want to review only requests that have been rejected or requests that require manual processing.
- 4. To view requests submitted for a specific cardholder, enter the **First Name** or **Last Name** of that cardholder.
- 5. To view requests that were submitted during a specific period, select a **Begin Date** and **End Date**. You may also enter a specific time if needed.
- 6. In the **Type** drop-down list, select whether you wish to view requests that are currently on **Queue** or requests that are archived in the **History** table.
- 7. In the **Max Count** field, enter the number of records you wish to display in the list.
- 8. Click **OK** to begin the search. The Request Queue View dialog box opens showing the requests that meet the filter criteria and the number of requests found.
- To display the details of a specific request, select the line item in the list box and click View. See the next section Viewing Request Details.

Create Time	Expire Time	Sender	Details	Operation	Status	Last Name	First Name	
5/5/2005 3:02:28 PM 5/5/2005 3:27:38 PM 5/5/2005 3:30:23 PM 5/5/2005 3:37:26 PM	5/19/2005 3:02:28 PM 5/19/2005 3:27:38 PM 5/19/2005 3:30:23 PM 5/19/2005 3:37:26 PM	P2KWebAccess P2KWebAccess P2KWebAccess P2KWebAccess	VisitorManagement.Visitor CardholderRequest.Cardh ContractorRequest.Cardh VisitorManagement.Visitor	Add Add Update Add	Ready for Manual Proc Ready for Manual Proc Ready for Manual Proc Ready for Manual Proc	Bolton Collins Jasper Flint	David Michael Jeanette Anna	Filter Criteria
•							<u> </u>	Requests
of 4 Requests				View	Cancel Refr	esh 🤅	Filter	matching th
				[one			Filler Chilen

Number of Requests found

10. To restore the list to display all requests,
you can either close and then open the
Request Queue View dialog box, or click
Filter and select to display all requests.The
about the provide the provided the pr

Viewing Request Details

1. In the Request Queue View dialog box, select the individual request you wish to display and click **View**. The Request View window opens displaying information in XML format.

Request View	_ 🗆 ×
Poriginal Modified	
<txml ?="" version="1.0">-</txml>	
Done	

The XML document contains information about the originator of the request and information about the actual request.

The top left side of the window offers two viewing options:

- **Original** Displays request information, as it was originally submitted.
- Modified Displays modified request information. For example, if a request is rejected, the requester can edit the request to correct errors and then resubmit the request for processing.
- 2. After reviewing the request details, click **Done** to close the window.

506 CHAPTER 5 System Maintenance

507

Chapter 6: System Reports

he P2000 Report feature gives you access to system data. Whether you want a printout of cardholder information or a list of specific system transactions, there is most likely a P2000 standard report that can meet your needs. P2000 standard reports are created using SAP® Crystal Reports® and can be sorted to produce the data you need. See page 510 for a complete list of these reports, a brief description of each, and how to use them. Also, later in this chapter you can find some commonly used reports, including samples of each.

If you do not find a report that meets your needs, you can create custom reports using SAP Crystal Reports and then import them into the P2000 system. You can also export a P2000 standard report into SAP Crystal Reports for editing, and then import it back into the P2000 system.

Note: While P2000 standard reports are very easy to understand and run, custom reports should be created by someone experienced with report design and operation. You must have your own copy of SAP Crystal Reports to create a custom report. See Creating Custom Reports on page 522 for more information.

This section includes the following topics:

- Using P2000 Standard Reports
- P2000 Standard Report Definitions
- Selected Sample Reports
- Creating Custom Reports

Using P2000 Standard Reports

P2000 standard reports provide the fields you need to generate reports on system databases and activities. When you run a report, the report displays on a SAP Crystal Reports preview window. You can use the options in the toolbar at the top of the window to scroll through pages of the report, resize the window, or search for a specific record.

Note: The Load Language Reports feature in the Report menu allows you to load reports in different languages. Use this feature if you have installed the P2000 Foreign Language Pack in your system. When you select Report>Load Language Reports from the P2000 Main menu. a dialog box opens where you select the desired language (previously installed from the foreign language CD), then click Load to load the SAP Crystal Reports template into the database. Once the selected language reports are loaded you do not need to perform this procedure again. You may have to modify some translated reports using SAP Crystal Reports to fix truncated text issues. In addition, because of a parameter value limitation in SAP Crystal Reports, some reports have been hard-coded and have not been translated, these reports also need to be modified using SAP Crystal Reports.

To Run a Standard Report

 From the P2000 Main menu, select **Report>Run Report**. The Run Report dialog box opens.

🖸 Run Report	_ 🗆 ×
Partition: Super User	
Access Group Access Template Alarm Activity - Simple Alarm Activity Log Alarm History Alarm History - Input Point Alarm Instruction Alarm Response Text All Access Groups to Door All Access Groups to Door All Access Groups to Elev/Cab All Access Groups to Floor/Door All Access Groups to Floor/Door All Access Groups to Terminal Group All Access Groups to Terminal Group All Access Groups to Terminal Group All Cardholders to Area - Preprocessed All Cardholders to Area - Preprocessed All Cardholders to Floor/Door Group - Preprocessed All Cardholders to Terminal Group - Preprocessed	
Database: Normal	•
<u>R</u> un E <u>x</u> it	

- 2. If your system is partitioned, select the **Partition** that contains the data you want to report on. Also, the list box only displays the report names that belong to the partition selected.
- 3. Select the name of the report you wish to run.
- 4. Select the **Database** source. Select **Normal** to generate the report from the current system database; or select **Archive** if you wish to run the report from an archived database.

Note: Before you run any **Preprocessed** report against an archived database, you must perform the **Update Preprocessed Report Archive tables** task from the Database Maintenance application; see page 486. 5. Click Run. Some reports have no specific options and display directly in the preview window after you click Run and enter the printer options. Most reports, however, have several filtering options and present a dialog box in which to select your choices.

Loop Configuration		×
Loop Number		
*	•	1
		-
OK		

- 6. To run the default report, which lists all records, leave the asterisk in the field box.
- 7. To run a report on a specific option, choose the option from the drop-down list. (See Selected Sample Reports on page 515 for detailed instructions.)
- 8. Click **OK**. Select a printer name and any other printer setup information.

Note: You must configure a default printer to retain the fonts displayed on a report. It is not required to have a printer physically connected to the workstation; you only need to set up the default printer. Do not use Generic Text printers. The **No Printer** option in the Print Setup dialog box displays P2000 reports correctly and is selected by default if you have not installed any printer drivers. Alternatively, you can manually select the **No Printer** option if you have installed one or more drivers, but you want to use a generic printer driver.

- 9. Click **OK**. After a moment, the report displays in the preview window, as shown on the following page.
- 10. Click the Printer icon to print the report. (To use this option, you must set up your system to communicate with a printer. If you need more information, see your system administrator.)



P2000 Standard Report Definitions

Following is a list of all P2000 standard reports along with a brief description of each default configuration. Any time you select an asterisk (*) in a field, the report includes all records for that field. Some reports provide options to filter and limit the search, and some present check boxes listing all available values for a field, allowing you to select multiple items.

If you use the Partition feature, report data is restricted to the partition selected from the Run Report window. However, some reports ignore the partition selected and may report data across all partitions, unless you select a specific partition name within the specific report to limit the data.

In addition, when running any of the audit, alarm, or transaction history reports, you have the option of selecting to report transactions at your local site or you can enter the name of the remote site that you want to report on.

Preprocessed reports display current data. Any changes made to database items in a Preprocessed report are not reflected until the following day, unless you manually update the report table using the **Update Preprocessed Report tables** task in Database Maintenance; see page 486.

Also, report names that start with **RAW** are duplicates of existing reports, with the difference that these RAW reports have been formatted to be exported into an Excel spreadsheet. The preview window for these reports may not display correctly, but the resulting Excel spreadsheet contains valid data. To get the fullest benefit of this powerful feature, we recommend you read through the entire list to get a complete understanding of what is available.

Access Group – Lists all terminals, terminal groups, floor groups, and door groups by access group.

Access Template – Lists the details of all access templates created in the system.

Alarm Activity - Simple – Lists alarm activities in a simpler format than the Alarm Activity Log report. You can list all alarm activities or select specific alarm category, type, description, associated alarm item; as well as date and time beginning and ending periods.

Alarm Activity Log – Lists all alarm activities, or you can select specific alarm category, type, description, associated alarm item; as well as date and time beginning and ending periods.

Alarm History – Lists all alarm history in the system or you can select specific alarm category, type, description, associated alarm item; as well as date and time beginning and ending periods. See an example of this report in the Selected Sample Reports section.

Alarm History - Input Point – Similar to the Alarm History report, except that it only displays panel input point alarms, and groups them together by their associated terminal, followed by input point. The alarms are listed for each input point chronologically. This report allows users to see a list of alarms and state changes for the input points that are configured in the system.

Alarm Instruction – Lists all alarm instructions and associated text created in the system.

Alarm Response Text – Lists all response text created in the system.

each.
All Access Groups to Elevator/Cabinet – Lists

All Access Groups to Door – Lists all access

groups and the door terminals assigned to

all access groups and the elevators or cabinets assigned to each.

All Access Groups to Floor/Door – Lists all access groups and the floors or doors assigned to each.

All Access Groups to Floor/Door Group – Lists all access groups and the floor or door groups assigned to each.

All Access Groups to Terminal Group – Lists all access groups and the terminal groups assigned.

All Areas to Cardholder - Preprocessed – Lists by cardholder name, all areas the cardholder can access, and the terminal doors defined for the area.

All Cardholders to Access Group - Preprocessed – Lists by access group the cardholders assigned to that access group.

All Cardholders to Area - Preprocessed – Lists by area name, the cardholders and badges that have access to the area.

All Cardholders to Door - Preprocessed – Lists by door terminal all cardholders that have access to that terminal.

All Cardholders to Elevator/Cabinet - Preprocessed – Lists all cardholders and the elevators or cabinets assigned to each.

All Cardholders to Floor/Door - Preprocessed – Lists all cardholders and the floors or doors assigned to each.

All Cardholders to Floor/Door Group - Preprocessed – Lists all cardholders and the floor or door groups assigned to each. All Cardholders to Terminal Group - Preprocessed – Lists by terminal group all cardholders that have access to that terminal group.

All Cardholders to Timezone – Lists by time zone all cardholders assigned to that time zone.

All Cardholders with Executive – Lists the names of all cardholders with executive privileges.

All Doors to Cardholder - Preprocessed – Lists by cardholder name all doors and access groups assigned to the cardholder.

All Elevator/Cabinet to Cardholder - Preprocessed – Lists by cardholder name the elevators or cabinets assigned to the cardholder.

All Floor/Door Groups to Elevator/Cabinet – Lists by elevator or cabinet name all floor or door groups assigned to the elevator or cabinet.

All Floor/Door Groups to Floor/Door – Lists by elevator floor or cabinet door all floor or door groups assigned to the elevator floor or cabinet door.

All Floors/Doors to Cardholder - Preprocessed – Lists by cardholder name all elevator floors or cabinet doors assigned to the cardholder.

All Terminal Groups to Door – Lists by terminal group the terminals (doors) assigned to each group.

Area Configuration – Lists by area name, all configuration information entered in the Area Configuration dialog box.

Area Control – Lists the cardholders currently in the area, including the total number of cardholders for each count mode.

Area Transaction – Lists all transactions performed in the system for the specific area. **Audit** – Lists by operator name the menu items selected by that operator during the date and time period selected.

Auto-badge Number – Lists the number and status of the badges that were created using the AutoBadge Management feature.

AV Camera – Lists all audio visual cameras and their associated configuration.

AV Dry Contact – Lists all audio visual dry contact relays and their configuration.

AV Input Point to Camera – Lists all audio visual input to camera mappings and their configuration.

AV Monitor – Lists all audio visual monitors and their associated configuration.

AV Summary – Lists by name all audio visual items defined in the CCTV/AV Configuration window.

AV Switch – Lists all audio visual switches and their associated configuration.

Cardholder Entry–Exit Status – Lists cardholder information, the entry/exit times, and status of the badge. This is useful to review cardholder movement throughout the facility.

Cardholder Last Badge – Locates a cardholder by last badging at a terminal (door).

Cardholder Transaction History – Lists transaction history by cardholder, including issue level and timed override parameters. You can select specific cardholder, badge number, terminal, history type, elevator or cabinet transactions, begin and end dates and times.

Cardholder Transaction History - Simple – This report is similar to the Cardholder Transaction History report, except that it is presented in a simpler format.

Cardholders - Preprocessed – Lists by cardholder all personal and system information, including badge numbers, access groups, card options, time zones, and so on. See an example of this report in the Selected Sample Reports section.

Cardholders - Preprocessed - with UDF – This report is similar to the Cardholders - Preprocessed report, except that it lists any User Defined Fields (UDFs) entered for that cardholder.

Cardholders - Simple - Preprocessed – This is a simplified version of the Cardholders - Preprocessed report that displays basic cardholder information.

Cardholders - Simple - Preprocessed - with UDF – This report is similar to the Cardholders - Simple report plus any UDFs entered for the cardholder.

Cardholders with Web Access - Preprocessed – Lists the cardholders that have been assigned with menu permissions to perform Web Access functions.

Cardholders without Badges – Finds all cardholders in the system without badges assigned. See an example of this report in the Selected Sample Reports section.

CCTV Camera – Lists all CCTV cameras and their associated configuration.

CCTV Monitor – Lists all CCTV monitors and their associated configuration.

CCTV Summary – Lists by name all CCTV items defined in the CCTV/AV Configuration window.

CCTV Switch – Lists all CCTV switches and their associated configuration.

Disabled Cardholders and Badges – Lists all cardholders that have been disabled or have disabled/inactive badges.

This document contains confidential and proprietary information of Johnson Controls, Inc. © 2014 Johnson Controls, Inc.

Elevator/Cabinet Configuration – Lists by elevator or cabinet name all configuration information entered in the Elevator or Cabinet Configuration dialog box for all elevators or cabinets.

Elevator/Cabinet Transaction – Lists all transactions performed in the system for the specified elevator or cabinet name.

Enable Code – Lists by panel name (for D600 AP panels only), the Enable Codes used at your facility.

Events – Lists by event name all configuration information entered in the Configure Events dialog box, including event trigger and action information.

Floor/Door Group – Lists all elevator floor or cabinet door groups and the floor or door masks assigned to each group.

Floor/Door Mask – Lists all elevator floor or cabinet door masks and the floors or doors assigned to each.

Floor/Door Name – Lists all elevator floors or cabinet doors and the floor or door numbers and names assigned to each.

Hardware Up/Down Status – Lists the name and status of all operating hardware.

Holiday – List all holidays configured in the system.

Hours on Site – Lists a detailed report of a cardholder's accumulated number of hours present at a site.

Hours on Site - Simple – Lists a summary report of a cardholder's accumulated number of hours present at a site.

Input Group – Lists by input group the associated input points and panels.

Input Point – Lists by input point all configuration information entered in the Input Point dialog box for all input points.

Input Point Disable/Suppressible – Lists all input points in the system that are disabled or suppressed.

Loop Configuration – Lists by loop number all loop configuration information entered for all loops.

Message Filter – Lists by message filter name all the filtering information entered in the Message Filter Configuration dialog box for all message filters.

Message Filter Group – Lists by message filter group the message filters associated with the message filter group.

Message Forwarding – Lists the workstation names from where and to where all current messages are forwarded.

Muster Analysis – Displays by group type the list of personnel who are within a muster zone in the specified time frame, and whether it was a drill or real emergency.

Mustering Configuration – Lists by muster zone name, all the zone definition configuration, as set up in the Muster Zone Definition dialog box.

Operator – Lists all operator information entered in the Edit Operator dialog box.

Operator Permissions – Lists the permissions assigned to each operator.

Output Group – Lists by output group the associated output points and panels.

Output Point – Lists by output point all configuration information entered in the Output Point dialog box for all output points.

P900 Counter – Lists all counter information, as set up in the P900 Counters dialog box.

P900 Flag – Lists all flag information, as set up in the P900 Flags dialog box.

P900 System Parameters – Lists the details of the P900 parameters, as set up in the P900 System Parameters dialog box.

P900 Trigger Event – Lists all trigger event information, as set up in the P900 Trigger Event dialog box.

P900 Trigger Link – Lists all trigger link information, as set up in the P900 Trigger Links dialog box.

Panel – Lists all panels in the system with their associated configuration as set up in the Panel dialog box. See an example of this report in the Selected Sample Reports section.

Panel Card Event – Lists by panel card event name all panel card event details configured for the system.

Remote Server – Lists all remote servers in the system with their associated configuration, as set up in the P2000 Remote Server dialog box.

Security Level Ranges – Lists the security levels defined in the Security Level Range Editor dialog box.

Site Parameters – Lists the details of the current site parameters as set up in System Configuration.

Station – Lists by workstation all workstation configuration.

Terminal – Lists by terminal name all terminal configuration as set up in the Terminal dialog box.

Terminal Groups – Lists by terminal group the terminals associated with the terminal group.

Terminal Unshunted – Lists all terminals with a shunt time of zero.

Time Zone – Lists all time zones configured for the system.

Tour Configuration – Lists by tour name, all tour definition configuration, as set up in the Guard Tour Definition window.

Tour Notes – Lists all the tour notes assigned to a specific tour name, as set up in the Guard Tour Control window.

Tour Transaction History – Lists all tour transactions performed in the system.

Transaction History – Lists all transactions performed in the system. See an example of this report in the Selected Sample Reports section.

Unused Active Badges – Displays a list of active badges that have not been used during the specified period of time.

Verification – Allows for a verification of the commissioning process by providing a list of all hardware to be checked off by the contractor. This list includes a list of all panels in the system and their associated terminals, inputs, and outputs.

Selected Sample Reports

Following are detailed instructions on how to run reports. Once you have experimented with these, you should have a good understanding of how to select options to get the results you need.

Each example shows a reporting criteria window and the associated report generated from the configuration selected.

Run the Alarm History Report

The Alarm History report gives you an overview of alarm activity throughout the system. You can run it for all alarm types in the system (the default), or select a specific alarm type. You can also specify a particular date and time, and review only those alarms that occurred during that time. If your system is partitioned, select the partition you want to report on. In addition, you can select to run the report for alarms generated at your local or at a remote site.

1. In the Run Report list, select **Alarm History** and click **Run**, or double-click Alarm History. The Alarm History dialog box opens.

Alarm History		
Site		Type ID
	Simi Valley	
Partition		<mark>⊯</mark> Bank Vault
	·	
Alarmiype	Area Alarm	
Description		
["Min Req"	
Alarm Categor	/	
L	2000	
Date	Time	
B	egin: 9/ 1/2013 V Begin: 12:00:00 AM	
	End: 11/15/2013 End: 11:59:59 PM	
	Created 1	
	Cancel	1

- 2. By default, the system displays the local **Site** name. If you wish to run the report on alarms generated at a remote site, select from the drop-down list the name of the remote site.
- 3. If your system is partitioned, select a specific **Partition** name, or select (*) to gather data from all partitions.
- Select a specific Alarm Type to report on only one alarm type in the system, or select (*) to report on all alarm types.
- 5. The **Type ID** list box displays items that are associated with the selected Alarm Type. Select a specific or multiple type IDs to report only on those entries selected, or select (*) to report on all type IDs.
- 6. Enter a **Description** of the alarm. You can use wildcards. For example, you can enter **Min Req** to report only on alarms generated when the minimum number of cardholders is not present at the same time in the specific Area.
- 7. The default **Alarm Category** is **P2000**. Select a specific alarm category to report only on the alarm category selected.
- 8. Select a **Begin** and **End** date for the alarms you wish to see.
- 9. Select a **Begin** and **End** time for the alarms you wish to see.
- 10. Click OK. Select a printer name and any other information for the printer to be used. See your system administrator if you need more information, or refer to your Microsoft Windows documentation.
- 11. Click **OK**. The Alarm History report displays in the preview window. You can use the arrows at the top of the window to scroll forward and back through the pages; resize the window for the best display, and print all or single pages of the report.

The report displays the information according to the options that you selected in the Alarm History dialog box. The report filter options selected for reporting display just under the report title. The results of the report query begin in the next section. In the example, the first record shows an alarm that came in on *11/13/2013* at *3:04:25 P.M.*

Report Filter

The alarm is in the *Alarm* state and is *Pending*, that is, it has not yet been acknowledged. When the alarm is acknowledged, the report shows that as another date and time-stamped record, with the alarm status as *Acknowledged*, and the *Operator Name* of the person who acknowledged the alarm. The *Operator Site* displays the site name from where the operator handled the alarm.

Alarm Type	Area	Alarm			
Alarm Device Name	Bank	Bank Vault			
Date (>=)	9/1/2013 12:00:00AM				
Date (<=)	11/15/2013 11:59:59PM				
Description	*Min Req*				
Site	Simi Valley				
Alarm Category	P200	0			
Description	Bank Vault Min Required Alarme	ed			
Partition	Super User	Public	Yes		
Alarm State	Alarm	Alarm Date	11/13/2013 3:04:25PM		
Alarm Status	Pending	Ack Date	11/13/2013 3:04:25PM		
Alarm Priority	10	Operator Site	Simi Valley		
Escalation	0	Alarm Category	P2000		
Operator Name	Cardkey				
Alarm State	Alarm	Alarm Date	11/13/2013 3:04:25PM		
Alarm Status	Acked	Ack Date	11/13/2013 3:04:38PM		
Alarm Priority	10	Operator Site	Simi Valley		
Escalation	0	Alarm Category	P2000		
Operator Name	Cardkey				
Alarm State	Alarm	Alarm Date	11/13/2013 3:04:25PM		
Alarm Status	Responding	Ack Date	11/13/2013 3:06:40PM		
Alarm Priority	10	Operator Site	Simi Valley		
Escalation	0	Alarm Category	P2000		
Operator Name	Cardkey				
Response Text	Responded from Security Sta	tion			

Alarm History Report

Run the Cardholders - Preprocessed Report

The Cardholders report gives you information about all the cardholders in the system. This report contains personal, badge, and access information as configured in the Cardholders window.

Note: Preprocessed reports display current data. Any changes made to database items in a Preprocessed report are not reflected until the following day, unless you manually update the report table using the **Update Preprocessed Report tables** task in Database Maintenance; see page 486.

 In the Run Report list, double-click Cardholders - Preprocessed. The Cardholders

 Preprocessed dialog box opens.

Cardholders - Preprocessed	
<u>F</u> irst	Company
*	-*
Last	ABCD Industries
Albertson	
Туре	
All	
Partition	Department
∀ *	▼ *
Super User	Corporate
	Human Resources
	1
OK Cancel	

2. Select a **First** or **Last** name to limit the report to a specific cardholder, or select (*) to show all cardholder records.

- 3. Select a Cardholder Type.
- 4. If your system is partitioned, select a specific **Partition** name, or select (*) to gather data from all partitions.
- Select a specific or multiple Company names, or select (*) to report on all company names.
- Select a specific or multiple **Department** names, or select (*) to report on all department names.
- 7. Click **OK**. Select a printer name and any other information for the printer to be used. See your system administrator if you need more information, or refer to your Microsoft Windows documentation.
- 8. Click **OK**. The Cardholders report displays in the preview window. You can use the arrows at the top of the window to scroll forward and back through the pages; resize the window for the best display, and print all or single pages of the report.

The top part of the record lists the cardholder's name and personal information, along with Company, Department, Cardholder type, and badge start and void dates. Sponsor information is included if the cardholder is a visitor. The bottom section of the record lists the badge information associated with the cardholder.

Cardholders F	Report
----------------------	--------

First Name Last Name Card Type (A=All, R=F Partition Company Department	Regular, V=Visitor)	* Albertson All * ABCD Industries *	3			
Partition	Super User		Public		Yes	
First Name	Fred		Middle Nan	1e	R.	
Last Name	Albertson		ID		4899	
Company Address	ABCD Industries		Departmer All Badres	nt	Sales	
Auu 233	1440 E. Chanala Street		Start		4/1/2005 8:00:00AM	
	Santa Barbara		Void		3/30/2015 11:59:00AM	
	CA 93103		Card Type	(A=All, R=	=Regular, V=Visitor)	Visitor
Phone	555-3322		E-Mail		FAlbert@xxx.com	
Ext	312		Web Acces	s	<none></none>	
Guard	No					
Sponsor						
First Name	James		ID 		12346	
Last Name	Jasper		Phone		555-3333	
Middle Name	Α.		EX		123	
Identification Badge Badge Number	44561	lssue		n		
Badge Alpha	ENG	Descript	tion	Labide	ntification Only	
Start					,	
Void 						
Access Badge						
Badge Number	44562		Badge Rea	son	New	
Badge Alpha	VIS		Design			
Start Date	4/1/2005 8:57:00AM	l	Void Date		4/1/2005 12:57:00	PM
Issue	0		PIN Code		123	
Description	North Building Acces	s				
Facility Code	Default Facility Code					

Run the Cardholders without Badges Report

The Cardholders without Badges report is useful to locate cardholders who have no access badges. A popular use is to locate cardholder records that were not deleted when badges were removed.

 In the Run Report list, double-click Cardholders without Badges. The Cardholders without Badges dialog box opens.

Cardholders without Badges	×
<u>F</u> irst	
×	•
Last	
×	•
<u>Т</u> уре	
All	•
OK Cancel]

- 2. Select a **First** or **Last** name to limit the report to a specific cardholder, or select (*) to show all cardholder records.
- 3. Select a Cardholder Type.
- 4. Click **OK**. Select a printer name and any other information for the printer to be used. See your system administrator if you need more information, or refer to your Microsoft Windows documentation.
- 5. Click **OK**. The Cardholder without Badges report displays in the preview window. You can use the arrows at the top of the window to scroll forward and back through the pages; resize the window for the best display, and print all or single pages of the report.

This report lists the cardholder by first and last name, personal information, along with Company, Department, Cardholder Type, and Start and Void dates. Sponsor information is included if the cardholder is a visitor.

First	*	Last	*
Card Type (A=Al	l, R=Regular, V=Visitor)	A	
Public First Last Company	Yes Loretta Adams YXY Manufacturing	Partition Middle ID Department	Super User W. 125 Sales
Address		Start Void Card Type	12/5/2004 8:00:00AM 2/5/2005 11:59:00AM Visitor
Phone Ext Site	222-3333 123 Simi Valley	E-Mail Web Access	<none></none>
Guard	No		
<u>Sponsor</u> First Name Last Name Middle Name	James Jasper A.	ID Phone Ext	12345 555-3333 123

Cardholders without Badges Report

Run the Panel Report

The Panel Report lists by panel name the complete panel configuration for each panel in the system. Or you can select a specific panel to report only that panel's configuration.

1. In the Run Report list, double-click **Panel**. The Panel dialog box opens.

Panel	×
Panel Name	
ji -	_
OK	Cancel

2. Select a **Panel Name** to limit the report to a specific panel, or select (*) to show all panel records.

- 3. Click **OK**. Select a printer name and any other information for the printer to be used. See your system administrator if you need more information, or refer to your Microsoft Windows documentation.
- 4. Click **OK**. The Panel report displays in the preview window. You can use the arrows at the top of the window to scroll forward and back through the pages, resize the window for the best display, and print all or single pages of the report.

This report lists the panels with their associated configuration. The information presented in this report varies according to the panel type.

Partition	Super User	Public	No
Panel	CK Security		
Туре	CK721-A	Enabled	Yes
Query String			
Encryption Enabled	No		
Enabled for BACnet	No	High speed RS485	No
Enable Terminals	Yes		
Enable Inputs	Yes		
Enable Outputs	Yes		
Primary IP Address	200.0.0.68	Alternate IP Address	0.0.0.0
Primary Poll Interval	30 seconds	Alternate Poll Interval	86400 seconds
Primary Poll Timeout	75 seconds	Alternate Poll Timeout	176400 seconds
History			
Upload Timezone	<always></always>	Delete History	Yes
Upload Only	Yes	Cap. Threshold for Upload-only	50
Upload Always	Yes	Cap. Threshold for Upload-always	80
Delete At	12:00:00AM	Delete After	1 day(s)
Access			
Time Offset Enable	Yes	Time Offset	2 hour(s)
Timezone Checking	Yes	Entry/Exit	No
Timed Over/Tailgate	Yes	System Override	Yes
PIN Code Digits	4	Pin Code Type	Algorithmic
Scramble Mode	0		
Peer to Peer Badge Sync	No	Broadcast Port Number	47500
<u>Alarm</u>			
Report Delay	0 seconds	Latch Output	No
Output Delay	0 seconds	Enable Panel Relay Output Groups	No
Enable Input Suppression Messages	Yes		

Panel Report
Run the Transaction History Report

One of the most commonly used reports in the system is the Transaction History report. This report can list every transaction in the system, or be filtered to list by specific Site, Partition, Terminal, Transaction Type, History Type, specific Dates and Times, and any combination of these. The options available for selection depend on the transaction type selected.

1. In the Run Report list, double-click **Trans**action History. The Transaction History dialog box opens.

Transaction History	×
<u>S</u> ite:	Simi Valley
Partition:	*
Transaction Type:	Panel
History Type:	Input Terminal Unknown
T <u>e</u> rminal:	*
Date Begin: 2/ 8/2004 End: 2/ 8/2005	Time Begin: 12:00:00 AM 12:00
OK	Cancel

- 2. By default, the system displays the local **Site** name. If you wish to run the report on transactions that were originated at a remote site, select from the drop-down list the name of the remote site.
- 3. If your system is partitioned, select a specific **Partition** name, or select (*) to gather data from all partitions.
- Select a specific Transaction Type to report on only one transaction type in the system, or select <all> to report on all transaction types.
- 5. Select a **History Type**. History types available from the drop-down list depend on the selection in the Transaction Type field.
- 6. If available for selection, select a specific **Terminal** to limit your search.
- 7. Select a **Begin** and **End** date for the transactions you wish to see.
- 8. Select a **Begin** and **End** time for the transactions you wish to see.
- 9. Click **OK**. Select a printer name and any other information for the printer to be used. See your system administrator if you need more information, or refer to your Microsoft Windows documentation.

Date (>=)	2/8/2004 12:00	D:00AM		
Date (<=)	2/8/2005 11:59	3:59PM		
Transaction Type	Panel			
Terminal	*			
History Type	Input Terminal	Unknown		
Site	Simi Valley			
Partition	Super User		Public	No
Date	2/7/2005 9:53:05AM	Terminal	Security Office	
Panel	North Entrance			
History Message	Input Terminal Unknown			
Input Point				
Partition	Super User		Public	No
Date	2/7/2005 9:53:05AM	Terminal	Main Door	
Panel	North Entrance			
History Message	Input Terminal Unknown			
Input Point				

Transaction History Report

10. Click **OK**. The Transaction History report displays in the preview window. You can use the arrows at the top of the window to scroll forward and back through the pages; resize the window for the best display, and print all or single pages of the report.

The top of the report shows the date and time settings for the report and the Transaction Type selected. Each transaction is listed as a separate date and time stamped record of the options selected in the Transaction History dialog box.

Creating Custom Reports

If you have an independent copy of SAP Crystal Reports, you can create custom reports using the SAP Crystal Reports software and import them into the P2000 system. You can also export a P2000 report into SAP Crystal Reports for editing, and then import it back into the P2000 system. The following sections describe each method:

- Creating a Custom Report Using SAP Crystal Reports
- Editing a P2000 Standard Report in SAP Crystal Reports

Creating a Custom Report Using SAP Crystal Reports

The P2000 system uses SAP Crystal Reports as its report engine, which allows you to create custom reports that are compatible with the P2000 system. You must have your own copy of SAP Crystal Reports, and must have access to the field and table relationships used within the P2000 software (see the following section Database Table Definitions). Once you complete the report, export it as an *.rpt* file, and then import it into the P2000 system. **Note:** Advanced SAP Crystal Reports users who plan to include customized queries (manually-edited queries) in their reports, should note that to run a manually-edited query against the archived database, the database name must be dynamically assigned in the customized query object using the parameter **DBName**. The P2000 software then passes the correct database name to the report table in SAP Crystal Reports.

Database Table Definitions

To create a custom report that is compatible with the P2000 system, refer to the *P2000 Database Table Definitions* Supplement. Once you have the field/table relationship information, create your report according to the methods presented in your SAP Crystal Reports documentation.

To Import a Custom Report into the P2000 System

- 1. Using your SAP Crystal Reports software, save your custom report in <name>.rpt format and copy it to a directory that is accessible to the P2000 Server.
- From the P2000 Main menu, select Report>Report Configuration. The Report Configuration dialog box opens.

1	Report Configuration					X
	Partition Sup	er User	_			•
	Name	User	Hide	Partition	Public	-
	Access Group	No	No	Super User	Yes .	
	Access Template	No	No	Super User	Yes	
	Alarm Activity - Simple	No	No	Super User	Yes	
	Alarm Activity Log	No	No	Super User	Yes	
	Alarm History	No	No	Super User	Yes	
	Alarm History - Input Point	No	No	Super User	Yes	
	Alarm Instruction	No	No	Super User	Yes	
	Alarm Response Text	No	No	Super User	Yes	
	All Access Groups to Door	No	No	Super User	Yes	
	All Access Groups to Elev/Cab	No	No	Super User	Yes	
	All Access Groups to Floor/Door	No	No	Super User	Yes	•
	Done Ad	d		Edit	Delete	

- 3. If your system is partitioned, select the **Partition** that contains the imported report.
- 4. Click **Add**. The Edit Report dialog box opens.

To Export an Existing Standard Report from the P2000 System

- From the P2000 Main menu, select Report>Report Configuration. The Report Configuration dialog box opens.
- 2. Select from the scrolling list the report you wish to edit in SAP Crystal Reports.
- 3. Click **Edit**. The Edit Report dialog box opens. The Name and Size of the selected report display.
- 4. Click **Export**. In the Save As dialog box, navigate to a directory that can be accessible from your SAP Crystal Reports program.

To Edit the P2000 Report in SAP Crystal Reports

As with full custom reports, you must know the field/table relationships for the information you need before you can create new fields for the report, see Database Table Definitions on page 522. After you edit and save the report in <name>.rpt format, you are ready to import it back into the P2000 system. Save or copy the new report file to a directory that is accessible to the P2000 Server.

- From the P2000 Main menu, select Report>Report Configuration. The Report Configuration dialog box opens.
- 2. If your system is partitioned, select the **Partition** that contains the imported report.
- 3. Click Add. The Edit Report dialog box opens.

5. Enter a **Name** for your custom report. This name displays in your Run Report list once the report is imported.

Import

Cancel

X

-

Public

Export

- 6. Select **Public** to make this report visible to all partitions.
- 7. Click Import.

Edit Report

Partition Super User

Size 0

Name Sample Report

E Hide

OK

- 8. In the Open dialog box, navigate to the directory in which the report resides and select the report.
- 9. Click **Open**, the **Size** of the selected report displays.
- 10. Select the Hide check box if you do not wish to display this report in the Run Report dialog box. Clear the Hide check box if for example, you wish to run this report often and therefore you want to select it from the Run Report dialog box.
- 11. Click **OK**. The new report displays in the Report Configuration dialog box and is also added to the Run Reports list for the partition selected.

You can now select the report and run it as you would any other standard report.

Editing a P2000 Standard Report in SAP Crystal Reports

A P2000 standard report may have exactly what you need with the exception of a couple of fields. You can export a standard report and then import it into SAP Crystal Reports for revision; save it in *.rpt* format and import it back into the P2000 system.

Edit Report		×
Partition	Super User	•
Name	Edited Sample Report 🔽 Public	
Size	0 Import Export	
	T Hide	
	OK Cancel	

- 4. Enter a **Name** for your edited report. You may want to rename it something other than the original. This name displays in your Run Report list once the report is imported.
- 5. Select **Public** to make this report visible to all partitions.
- 6. Click Import.

- 7. In the Open dialog box, navigate to the directory in which the report resides and select the report.
- 8. Click **Open**, the **Size** of the selected report displays.
- 9. Select the Hide check box if you do not wish to display this report in the Run Report dialog box. Clear the Hide check box if for example, you wish to run this report often and therefore you want to select it from the Run Report dialog box.
- 10. Click **OK**. The new report displays in the Report Configuration dialog box and is also added to the Run Reports list for the partition selected.

You can now select the report and run it as you would any other standard report.

Appendix A: Event Triggers/Actions

his section lists all Trigger Categories, Trigger Types, Trigger Conditions, and Event Action Types available for Event configuration. For more information, see Creating Events on page 349.

To ensure that your events work properly, we strongly recommend that you verify if the events you define work as you expected. Some event triggers and actions that use hardware values such as panels, terminals, inputs, or outputs, may not be available if your hardware does not support the associated functions. For example, the **Badge** trigger type *Deny Open Door* is only available for CK7xx panels of Version 2.5 and later, whereas a Security Level action category is only available with panels that support the Security Level feature, such as CK7xx, S321-DIN, S321-IP, and D600 AP. Before programming your system events, see Appendix C: Panel Comparison Matrix for the features supported by each panel type, and also refer to the instructions provided with your hardware type to ensure that the triggers and actions are available to you.

Trigger Types

Category: Alarm

Any Alarm – Triggers when the system creates or acts upon any alarm.

Area – Triggers when the system creates or acts upon an Area alarm.

AV Behavior Alarm – Triggers when the system creates or acts upon an Audio Visual Behavior alarm.

AV Dry Contact Alarm – Triggers when the system creates or acts upon an Audio Visual Dry Contact alarm.

AV Motion Alarm – Triggers when the system creates or acts upon an Audio Visual Motion alarm.

AV System Alarm – Triggers when the system creates or acts upon an Audio Visual System alarm.

AV Video Loss Alarm – Triggers when the system creates or acts upon an Audio Visual Video Loss alarm.

Event Alarm – Triggers when the system creates or acts upon an Event alarm.

FDA – Triggers when the system creates or acts upon an FDA alarm.

Fire Detector – Triggers when the system creates or acts upon a fire detector alarm.

Fire I/O Module – Triggers when the system creates or acts upon a fire Input/Output module alarm.

Fire Zone – Triggers when the system creates or acts upon a fire zone alarm.

Guard Tour – Triggers when the system creates or acts upon a Guard Tour alarm.

Inputs – Triggers when the system creates or acts upon an Input alarm.

Integration Component – Triggers when the system creates or acts upon an Integration Component alarm.

Intercom Station – Triggers when the system creates or acts upon an Intercom Station alarm.

Intrusion Area – Triggers when the system creates or acts upon an Intrusion Area alarm.

Intrusion Zone – Triggers when the system creates or acts upon an Intrusion Zone alarm.

Loop Tamper – Triggers when the system creates or acts upon a hardware Loop Tamper switch alarm.

Muster Aborted – Triggers when the system creates or acts upon a Muster Aborted alarm.

Muster Running – Triggers when the system creates or acts upon a Muster Running alarm.

Muster When Disabled – Triggers when the system creates or acts upon a Muster When Disabled alarm.

Muster Zone Status – Triggers when the system creates or acts upon a Muster Zone Status alarm.

Remote Messaging Receive – Triggers when the system generates an alarm when a remote message is received.

Remote Messaging Transmit – Triggers when the system generates an alarm when a remote message is transmitted.

Timesync – Triggers when the system creates or acts upon a time synchronization alarm.

Conditions

- Alarm Category
- Alarm State
- Date (steady state)
- Day of the Month
- Day of the Week
- Escalation Level
- Month
- Time

Category: Area

Area Maximum allowed alarm – Triggers when the system sets o resets an alarm when the maximum number of cardholders allowed in the selected Area has exceeded.

Area Minimum required alarm – Triggers when the system sets or resets an alarm when the minimum number of cardholders is not present at the same time in the selected Area.

Area Pre-Maximum allowed alarm – Triggers when the system sets or resets an alarm when the pre-maximum number of cardholders allowed in the selected Area is reached.

Conditions

- Reset
- Set

Category: Audio-Visual

AV Behavior Alarm – Triggers when the system creates or acts upon an AV Behavior alarm.

AV Dry Contact Alarm – Triggers when the system creates or acts upon an AV Dry Contact alarm.

AV Motion Alarm – Triggers when the system creates or acts upon an AV Motion alarm.

AV System Alarm – Triggers when the system creates or acts upon an AV System alarm.

AV Video Loss Alarm – Triggers when the system creates or acts upon an AV Video Loss alarm.

Conditions

- AV Camera Name
- AV Dry Contact Name
- AV Switch Name
- Date (steady state)
- Day of the Month

- Day of the Week
- Month
- Time

Category: Audit

Add Badge Audit – Triggers when the system generates an audit message because an operator has added a badge to the system.

Delete Badge Audit – Triggers when the system generates an audit message because an operator has deleted a badge from the system.

Edit Badge Audit – Triggers when the system generates an audit message because an operator has changed a badge in the system.

Conditions

- Badge
- Badge Configuration
- Badge Purpose
- Badge Reason
- Cardholder
- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Time

Category: Badge

Anti-Passback Timer On – Triggers when a cardholder presents a badge at an anti-pass-back reader where the timer is on.

Deny Open Door – Triggers when a panel receives a Deny Door Open message. This message is available from CK7xx panels Version 2.5 and later that have the reader flag **Deny If Door Open** enabled.

Executive Privilege – Triggers when the badge presented has executive privileges; that is, it has unlimited access and bypasses all time zones and access groups.

Host Grant – Triggers when the cardholder presents a badge and the host grants access.

Host Grant Entry – Triggers when the cardholder presents a badge and the host grants access at an entry reader.

Host Grant Exit – Triggers when the cardholder presents a badge and the host grants access at an exit reader.

Invalid Badge – Triggers when the badge presented at the reader is not valid.

Invalid Badge Time Zone – Triggers when the badge presented at the reader has a disabled time zone.

Invalid Biometric – Triggers when the badge presented at the reader does not match the information at the biometric device.

Invalid Event Privilege Level – Triggers when the badge presented at the reader has an invalid privilege level.

Invalid In-X-It Status – Triggers when the cardholder presents the badge at the reader in an out-of-sequence manner; that is, two times sequentially at an exit reader or two times sequentially at an entry reader.

Invalid Issue Level – Triggers when the badge presented at the reader has an invalid issue level.

Invalid Keypad Event – Triggers when the cardholder enters an invalid keypad code.

Invalid Pin Code – Triggers when the cardholder enters an invalid PIN code.

Invalid Reader – Triggers when the badge presented has no access rights assigned to the reader.

Invalid Reader Time Zone – Triggers when a cardholder presents a badge at a reader that has a disabled time zone.

Invalid Security Level – Triggers when the system denies access to a badge at a reader because of an invalid security level.

Local Grant – Triggers when the cardholder presents a badge and the panel grants access.

Panel Card Event Activated – Triggers when the cardholder presents a badge at a reader and activates a panel card event.

Panel Card Event Deactivated – Triggers when the cardholder presents a badge at a reader and deactivates a panel card event.

Soft In-X-It Violation – Triggers when the badge presented generates an entry/exit violation; that is, the system grants access but creates an error message.

Valid & Unauthorized Access – Triggers when the badge presented at the reader is valid, but the door remains locked because further authorization (for example, by the guard) is required.

Conditions

- Access Group of Badge
- Access Group of Terminal
- Badge
- Badge Configuration
- Badge Purpose
- Badge Reason
- Cardholder
- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Panel Name
- Terminal Index
- Terminal Name
- Time
- Timezone Active

Note: You can also use numeric UDFs as badge conditions to activate a trigger.

Category: Counter

Triggers when the selected counter reaches the specified value.

Condition

Value

Category: External Trigger

Database – Triggers when an external input in the form of a database write has been sent to the P2000 system to trigger a host event.

File – Triggers when an external input in the form of an ASCII file has been sent to the P2000 system to trigger a host event.

RS232 – Triggers when an external input in the form of an RS232 serial message has been sent to the P2000 system to trigger a host event.

TCPIP – Triggers when an external input in the form of a TCP/IP message has been sent to the P2000 system to trigger a host event.

Conditions

• Substring (the string sent to the host from the external input).

Category: Fire Detector

Fire Detector Alarmed – Triggers when the fire detector enters the alarmed state.

Fire Detector Disabled – Triggers when the fire detector enters the disabled state.

Fire Detector Enabled – Triggers when the fire detector enters the enabled state.

Fire Detector Troubled – Triggers when the fire detector enters the trouble state.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Fire Detector Name
- Month
- Time

Category: Fire IO Module

Fire IO Module Activated – Triggers when the fire Input/Output module is activated.

Fire IO Module Disabled – Triggers when the fire Input/Output module enters the disabled state.

Fire IO Module Enabled – Triggers when the fire Input/Output module enters the enabled state.

Fire IO Module Troubled – Triggers when the fire Input/Output module enters the trouble state.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Fire IO Module Name
- Month
- Time

Category: Fire Panel

Fire Panel Down – Triggers when the fire panel is down.

Fire Panel Troubled – Triggers when the fire panel is in trouble state.

Fire Panel Up – Triggers when the fire panel is up.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Fire Panel Name
- Month
- Time

Category: Fire Zone

Fire Zone Alarmed – Triggers when the fire zone enters the alarmed state.

Fire Zone Disabled – Triggers when the fire zone enters the disabled state.

Fire Zone Enabled – Triggers when the fire zone enters the enabled state.

Fire Zone Troubled – Triggers when the fire zone enters the trouble state.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Fire Zone Name
- Month
- Time

Category: Inputs

Input Goes Open (transition) – Triggers when the state of an input point has changed to open.

Input Goes Reset (transition) – Triggers when the state of an input point has changed to reset.

Input Goes Set (transition) – Triggers when the state of an input point has changed to set.

Input Goes Short (transition) – Triggers when the state of an input point has changed to short.

Input Goes Suppressed (transition) – Triggers when the state of an input point has changed to suppressed.

Input Is Open (steady state) – Triggers when an input is in open state. Use this trigger in combination with other triggers.

Input Is Secure (steady state) – Triggers when an input is in secure state. Use this trigger in combination with other triggers.

Input Is Set (steady state) – Triggers when an input is in set state. Use this trigger in combination with other triggers.

Input Is Short (steady state) – Triggers when an input is in short state. Use this trigger in combination with other triggers.

Input Is Suppressed (steady state) – Triggers when an input is in suppressed state. Use this trigger in combination with other triggers.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Input Point Name
- Input Point Number
- Month
- Panel Name
- Terminal Index
- Terminal Name
- Time
- Timezone Active

Category: Integration Component

Down – Triggers when the selected integration component is down.

Misconfigured – Triggers when the selected integration component is not properly configured.

Unavailable – Triggers when the selected integration component is not available.

Up – Triggers when the selected integration component is up.

Conditions

Integration Component Name

Category: Intercom

Station Busy (transition) – Triggers when the intercom station is busy.

Station Call Request (transition) – Triggers when a call request has been placed to the intercom station.

Station Connected (transition) – Triggers when the intercom station has been connected.

Station Idle (transition) – Triggers when the intercom station shows no activity.

Station Output Active (transition) – Triggers when the intercom station output is active

Station Output Inactive (transition) – Triggers when the intercom station output shows no activity.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Intercom Station
- Intercom Station Output
- Month
- Time

Category: Intrusion Annunciator

Activated – Triggers when the intrusion annunciator has been activated.

Deactivated – Trigger when the intrusion annunciator has been deactivated.

Conditions

- Annunciator Name
- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Time

Category: Intrusion Area

Alarmed/Armed/Bypassed/Sealed (transition) – Triggers when the intrusion area enters the alarmed, armed, bypassed, or sealed state.

Alarmed/Armed/Bypassed/Unsealed (transition) – Triggers when the intrusion area enters the alarmed, armed, bypassed, or unsealed state.

Alarmed/Armed/No-Bypass/Sealed (transition) – Triggers when the intrusion area enters the alarmed, armed, not bypassed, or sealed state.

Alarmed/Armed/No-Bypass/Unsealed (transition) – Triggers when the intrusion area enters the alarmed, armed, not bypassed, or unsealed state.

Alarmed/Disarmed/Bypassed/Sealed (transition) – Triggers when the intrusion area enters the alarmed, disarmed, bypassed, or sealed state.

Alarmed/Disarmed/Bypassed/Unsealed (transition) – Triggers when the intrusion area enters the alarmed, disarmed, bypassed, or unsealed state.

Alarmed/Disarmed/No-Bypass/Sealed (transition) – Triggers when the intrusion area enters the alarmed, disarmed, not bypassed, or sealed state.

Alarmed/Disarmed/No-Bypass/Unsealed (transition) – Triggers when the intrusion area enters the alarmed, disarmed, not bypassed, or unsealed state. **Armed (steady state)** – Triggers when the intrusion area enters the armed state. Use this trigger in combination with other triggers.

Armed (transition) – Triggers when the intrusion area enters the armed state.

Armed/Bypassed/Sealed (transition) – Triggers when the intrusion area enters the armed, bypassed, or sealed state.

Armed/Bypassed/Unsealed (transition) – Triggers when the intrusion area enters the armed, bypassed, or unsealed state.

Armed/No-Bypass/Sealed (transition) – Triggers when the intrusion area enters the armed, not bypassed, or sealed state.

Armed/No-Bypass/Unsealed (transition) – Triggers when the intrusion area enters the armed, not bypassed, or unsealed state.

Disarmed (steady state) – Triggers when the intrusion area enters the disarmed state. Use this trigger in combination with other triggers.

Disarmed (transition) – Triggers when the intrusion area enters the disarmed state.

Disarmed/Bypassed/Sealed (transition) – Triggers when the intrusion area enters the disarmed, bypassed, or sealed state.

Disarmed/Bypassed/Unsealed (transition) – Triggers when the intrusion area enters the disarmed, bypassed, or unsealed state.

Disarmed/No-Bypass/Sealed (transition) – Triggers when the intrusion area enters the disarmed, not bypassed, or sealed state.

Disarmed/No-Bypass/Unsealed (transition) – Triggers when the intrusion area enters the disarmed, not bypassed, or unsealed state.

Conditions

Area Name

- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Time

Category: Intrusion Device

Intrusion Device Goes Down (transition) – Triggers when an intrusion device state has changed to down.

Intrusion Device Goes Fault (transition) – Triggers when an intrusion device state has changed to fault.

Intrusion Device Goes Normal (transition) – Triggers when an intrusion device state has

changed to normal.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Device Name
- Month
- Time

Category: Intrusion Zone

Alarmed (steady state) – Triggers when the intrusion zone enters the alarmed state. Use this trigger in combination with other triggers.

Alarmed (transition) – Triggers when the intrusion zone enters the alarmed state.

Bypassed (steady state) – Triggers when the intrusion zone enters the bypassed state. Use this trigger in combination with other triggers.

Bypassed (transition) – Triggers when the intrusion zone enters the bypassed state.

Normal (steady state) – Triggers when the intrusion zone enters the normal state. Use this trigger in combination with other triggers.

Normal (transition) – Triggers when the intrusion zone enters the normal state.

Open (steady state) – Triggers when the intrusion zone enters the open state. Use this trigger in combination with other triggers.

Open (transition) – Triggers when the intrusion zone enters the open state.

Tampered (steady state) – Triggers when the intrusion zone enters the tampered state. Use this trigger in combination with other triggers.

Tampered (transition) – Triggers when the intrusion zone enters the tampered state.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Time
- Zone Name

Category: Mustering

Mustering Start – Triggers when the Mustering starts at a specified zone.

Mustering Stop – Triggers when Mustering stops at a specified zone.

Conditions

Zone Name

Category: Operator

Invalid Logon – Triggers when there has been an attempt to log on with an invalid user name or password. **Logon Disabled** – Triggers when an operator has been inactive at the workstation for a specified period of time and has been automatically logged off.

Operator Logoff – Triggers when an operator has logged off from the workstation.

Operator Logon – Triggers when an operator has logged on to the workstation.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Operator
- Time

Category: Outputs

Output Goes Reset (transition) – Triggers when the state of an output point has changed to reset.

Output Goes Set (transition) – Triggers when the state of an output point has changed to set.

Output Is Reset (steady state) – Triggers when an output is in reset state. Use this trigger in combination with other triggers.

Output Is Set (steady state) – Triggers when an output is in set state. Use this trigger in combination with other triggers.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Output Point Name
- Output Point Number
- Panel Name
- Terminal Index

- Terminal Name
- Time
- Timezone Active

Category: Panel

Panel Goes Offline (transition) – Triggers when the panel state has changed to offline.

Panel Goes Online (transition) – Triggers when the panel state has changed to online.

Panel Is Down (steady state) – Triggers when the panel is down. Use this trigger in combination with other triggers.

Panel Is Up (steady state) – Triggers when the panel is up. Use this trigger in combination with other triggers.

Panel Load Database From Flash (transition) – Triggers when the panel has loaded the database from flash memory.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Panel Name
- Time
- Timezone Active

Category: Terminal

Input Terminal Goes Down (transition) – Triggers when an input terminal state has changed to down.

Input Terminal Goes Up (transition) – Triggers when an input terminal state has changed to up.

Input Terminal Is Down (steady state) – Triggers when an input terminal is down. Use this trigger in combination with other triggers.

Input Terminal Is Up (steady state) – Triggers when an input terminal is up. Use this trigger in combination with other triggers.

Output Terminal Goes Down (transition) – Triggers when an output terminal state has changed to down.

Output Terminal Goes Up (transition) – Triggers when an output terminal state has changed to up.

Output Terminal Is Down (steady state) – Triggers when an output terminal is down. Use this trigger in combination with other triggers.

Output Terminal Is Up (steady state) – Triggers when an output terminal is up. Use this trigger in combination with other triggers.

Reader Terminal Goes Down (transition) – Triggers when a reader terminal state has changed to down.

Reader Terminal Goes Up (transition) – Triggers when a reader terminal state has changed to up.

Reader Terminal Is Down (steady state) – Triggers when a reader terminal is down. Use this trigger in combination with other triggers.

Reader Terminal Is Up (steady state) – Triggers when a reader terminal is up. Use this trigger in combination with other triggers.

System Facility Code Error – Triggers when a badge presented at the reader has an invalid facility code.

Timed Override Disabled – Triggers when a timed override has been manually disabled.

Timed Override Disabled Host – Triggers when a timed override has been manually disabled from the host.

Timed Override Enabled – Triggers when a timed override has been manually enabled.

Timed Override Enabled Host – Triggers when a timed override has been manually enabled from the host.

Timed Override Expired – Triggers when a timed override has expired.

Conditions

- Date (steady state)
- Day of the Month
- Day of the Week
- Month
- Panel Name
- Terminal Index
- Terminal Name
- Time
- Timezone Active

Category: Time Zone

Beginning Of Period – Triggers when the time zone period has started.

End Of Period – Triggers when the time zone period has ended.

Conditions

Time Zone

Category: Time/Date

Time/Date – The system activates the trigger on the specified time and date.

Conditions

- Date (steady state)
- Date (transition)
- Day of the Month (steady state)
- Day of the Week (steady state)
- Month (steady state)
- Time (transition)

Event Action Types

Category: Audio-Visual

Note: The following event actions may function depending on the features provided by the manufacturer of the DVR integration software. Refer to the P2000 DVR Integration manual for details.

Camera Complete Alarm – Completes an alarm generated by the selected camera.

Camera Complete Alarm Associated Input – Completes an alarm generated by any configured camera that is associated with an input created in Input to Camera mapping. You cannot manually trigger this event action.

Camera Complete Alarm Associated Terminal -

Completes an alarm generated by any configured camera that is associated with a terminal mapped in Input to Camera. You cannot manually trigger this event action.

Camera Preset – Activates the camera's preset action.

Camera Recording Quality – Changes the camera's recording quality. Enter a value from 1 to 255 (255 provides the highest quality). Not all DVR brands accept this command and some may have a limited quality range. Refer to the *P2000 DVR Integration* manual for details on recording quality settings.

Camera Send Alarm – Sends an alarm message generated by the selected camera.

Camera Send Alarm Associated Input – Sends an alarm message generated by any configured camera that is associated with an input created in Input to Camera mapping. You cannot manually trigger this event action.

Camera Send Alarm Associated Terminal -

Sends an alarm message generated by any configured camera that is associated with a terminal mapped in Input to Camera. You cannot manually trigger this event.

Camera Start Recording – Starts the recording of the selected camera.

Camera Start Recording and Archiving – Starts the recording and archiving of the selected camera.

Camera Start Recording Associated Input -

Starts the recording of any configured camera that is associated with an input created in Input to Camera mapping. You cannot manually trigger this event.

Camera Start Recording Associated Terminal – Starts the recording of any configured camera that is associated with a reader reporting access grant or access deny transactions. You cannot manually trigger this event.

Camera Stop Recording – Stops the recording of the selected camera.

Camera Stop Recording Associated Input –

Stops the recording of any configured camera that is associated with an input created in Input to Camera mapping. You cannot manually trigger this event.

Camera Stop Recording Associated Terminal – Stops the recording of any configured camera that is associated with a terminal mapped in Input to Camera. You cannot manually trigger this event.

Launch AV Player – Starts the AV Player application at the selected workstation.

Monitor Camera – Displays the image from a particular camera on the monitor.

Category: BACnet

Action Interlock – Activates an action interlock to initiate an action in a BACnet device.

Category: Badge

Add Access Group and Timezone – Adds the specified access group and time zone to the badge associated with the message that triggered the event. The access group and time zone are added in the first available position of the badge.

Add Access Group and Timezone to Cardholder

– Adds the specified access group and time zone to all badges associated with the Cardholder displayed in the message that triggered the event. The access group and time zone are added in the first available position of all badges.

Delete Access Group – Deletes the specified access group from the badge associated with the message that triggered the event.

Delete Access Group to Cardholder – Deletes the specified access group from all badges associated with the Cardholder displayed in the message that triggered the event.

Increment Start Date of Access Group – Increments the start date of the selected access group by the number of days entered for the associated badge.

Set Badge Security Level – Sets the badge security level at the specified value.

Set Badge Security Level to Reader Security Level – Sets the badge security level to match the security level at the terminal.

Category: CCTV

Camera Auxiliary Play – Activates the camera's auxiliary relay.

Camera Auxiliary Stop – Deactivates the camera's auxiliary relay.

Camera Pattern Play – Activates the camera's pattern.

Camera Pattern Stop – Deactivates the camera's pattern.

Camera Preset – Activates the camera's preset action.

Monitor Camera – Displays the image from a particular camera on the monitor.

Monitor Sequence Play – Displays a sequence of camera images on the monitor.

Monitor Sequence Stop – Stops the display of a sequence of camera images on the monitor.

Switch Alarm Play – Activates the alarm switch.

Switch Alarm Stop – Deactivates the alarm switch.

Switch Auxiliary Play – Activates the auxiliary switch.

Switch Auxiliary Stop – Deactivates the auxiliary switch.

Switch Macro Play – Activates a set of programmed steps that the switch can perform.

Switch Macro Stop – Deactivates a set of programmed steps that the switch can perform.

Switch Tour Play – Activates a combination of camera patterns and monitor sequences.

Switch Tour Stop – Deactivates a combination of camera patterns and monitor sequences.

Category: Download

Download Access Groups – Downloads all defined access groups to the selected panel.

Download All Badges – Downloads all defined badges to the selected panel.

Download All Input Points – Downloads all defined input points to the selected panel.

Download All Output Points – Downloads all defined output points to the selected panel.

Download All Terminals – Downloads all defined terminals to the selected panel.

Download All Time Zones – Downloads all defined time zones to the selected panel.

Download All to All Panels – Downloads all defined access groups, badges, input and output points, terminals, time zones, card events, holidays, and soft alarms to all panels.

Download All to Panel – Downloads all defined access groups, badges, input and output points, terminals, time zones, card events, holidays, and soft alarms to the selected panel.

Download Card Events – Downloads all defined card events to the selected panel.

Download Holidays – Downloads all defined holidays to the selected panel.

Download Panel – Downloads panel information to the selected panel.

Download Soft Alarms – Downloads all defined soft alarms to the selected panel.

Category: Fire Detector

Detector Disable – Disables the selected fire detector.

Detector Enable – Enables the selected fire detector.

Category: Fire IO Module

IO Module Activate – Activates the output of the selected fire Input/Output module.

IO Module Deactivate – Deactivates the output of the selected fire Input/Output module.

IO Module Disable – Disables the selected fire Input/Output module.

IO Module Enable – Enables the selected fire Input/Output module.

Category: Fire Zone

Zone Disable – Disables the selected fire zone.

Zone Enable – Enables the selected fire zone.

Category: Host

Access Group Enable – Enables or disables the selected access group.

Backup Database – Performs database backup of data and images according to schedule.

Cancel Event – Cancels any scheduled event actions for the selected event. There can only be scheduled actions if you use a delay between the actions.

Create Alarm – Creates an alarm and sends it to the Alarm Monitor using an alarm instruction text as the description and a specified alarm category. Click the shortcut button to edit Alarm Options for the selected Alarm Category.

Create Alarm Unique – Creates a unique alarm and sends it to the Alarm Monitor using an alarm instruction text as the description and a specified alarm category. Click the shortcut button to edit Alarm Options for the selected Alarm Category.

Decrement Counter – Decrements the value of the selected counter.

Delete All Visitor Badges – Deletes all visitor badges in the system.

Delete All Visitors – Deletes all visitors and their badges in the system.

Delete Associated Badge – Deletes the badge associated with the message that triggered the event.

Delete Associated Cardholder – Deletes the cardholder and the badges associated with the message that triggered the event.

Delete Associated Visitor – Deletes the visitor and the badges associated with the message that triggered the event.

Delete Associated Visitor Badge – Deletes the visitor badge associated with the message that triggered the event.

Delete Expired Visitor Badges – Deletes visitor badges that have been expired for the selected number of days.

Delete Unused Access Groups – Deletes all unused access groups in the system.

Delete Visitors Without Badges – Deletes visitors without badges.

Disable Badge – Disables the selected badge number.

Display Map – Displays a specified map at the selected workstation.

Display Message – Displays a predefined instruction text message at the selected work-station.

Execute Application – Starts an application at the workstation selected.

Execute Server Process – Starts a configured process. The process is started on the server and runs in the security context of the RTL Route service. The process does not have access to the Windows desktop.

Increment Counter – Increments the value of the selected counter.

Message Filter – Adds or removes a specified Message Filter to (or from) the selected Message Filter Group. This action only deletes filters that have been *Auto Added* by another event. It never deletes the original filters configured for this group.

Message Filter Group – Adds or removes a specified Message Filter Group to (or from) the selected Message Filter Group. This action only deletes filters that have been *Auto Added* by another event. It never deletes the original filters configured for this group.

Message Forwarding – Enables or disables message forwarding from/to the selected work-station.

Net Send Message – Sends a message to the specified computer, using Windows *net send* command. The *net send* command only works on computers running Windows NT, Windows 2000, Windows XP®, or Windows 2003. For this command to work, you must start the Windows Messenger Service at both the sending and receiving computers.

Open Document – Opens a document at the workstation selected.

Print Message – Sends a predefined instruction text message to a selected printer.

Real Time Printing – Enables or disables real-time printing.

Real Time Printing Access Deny – Enables or disables real-time printing of Access Deny transactions.

Real Time Printing Access Grant – Enables or disables real-time printing of Access Grant transactions.

Real Time Printing Alarm – Enables or disables real-time printing of Alarm transactions.

Real Time Printing Area – Enables or disables real-time printing of Area transactions.

Real Time Printing Audit – Enables or disables real-time printing of Audit transactions.

Real Time Printing AV – Enables or disables real-time printing of Audio-Visual transactions.

Real Time Printing Cabinet – Enables or disables real-time printing of Cabinet transactions.

Real Time Printing Elevator – Enables or disables real-time printing of Elevator transactions.

Real Time Printing Fire – Enables or disables real-time printing of Fire transactions.

Real Time Printing Guard Tour – Enables or disables real-time printing of Guard Tour transactions.

Real Time Printing Host – Enables or disables real-time printing of Host transactions.

Real Time Printing Intrusion – Enables or disables real-time printing of Intrusion transactions.

Real Time Printing Mustering – Enables or disables real-time printing of Mustering transactions.

Real Time Printing Panel – Enables or disables real-time printing of Panel transactions.

Real Time Printing Trace – Enables or disables real-time printing of Trace transactions.

Remote Server Receive – Enables or disables receiving remote messages at the selected remote server.

Remote Server Transmit – Enables or disables transmitting remote messages at the selected remote server.

Resync Badges – Adjusts the state of the selected badges to In, Out, or Undefined and gives you the option to download the change.

Resync Badges - Last Terminal – Adjusts the state of all badges presented at the selected terminal to In, Out, or Undefined and gives you the option to download the change.

Resync Badges - Last Terminal Group – Adjusts the state of all badges presented at the terminals in the selected terminal group to In, Out, or Undefined and gives you the option to download the change.

Send Email – Sends a predefined instruction text message as email to the specified address.

Serial Port Message – Sends a predefined instruction text message as a serial port message using the COM port selected.

Set Counter – Sets the counter to a selected value.

TCP/IP Port Message – Sends the configured instruction text to the specified TCP/IP port on the specified computer. The port closes after the text is sent.

Text to Speech – Sends the selected instruction text to a workstation using the Windows Text to Speech feature. If the computer has a sound card, the text can be spoken using a synthesized voice. The voice characteristics can be adjusted from the Speech icon in Windows Control Panel.

Trigger Event – Triggers the selected event.

UDF Decrement – Decrements the specified numeric UDF field by one for the Cardholder displayed in the message that triggered the event.

UDF Increment – Increments the specified numeric UDF field by one for the Cardholder displayed in the message that triggered the event.

UDF Set – Sets the specified numeric UDF field to the specified value for the Cardholder displayed in the message that triggered the event.

UDF Set to UDF – Sets the first specified numeric UDF field to the value of the second specified numeric UDF field for the Cardholder displayed in the message that triggered the event.

Category: Inputs

Acknowledge Alarm – Acknowledges an alarm.

Complete Alarm – Completes an alarm.

Input Group Disable – Disables an input group.

Input Group Enable – Enables an input group.

Input Group Suppress – Suppresses the selected Input Group for the specified time (0 seconds means forever).

Input Group Suppression Time Zone – Suppresses the selected Input Group during the specified Time Zone.

Input Group Unsuppress – Unsuppresses the selected Input Group.

Input Point Disable – Disables a selected input point.

Input Point Enable – Enables a selected input point.

Input Point Enable Alarm – Enables or disables the alarm of the selected input point.

Input Point Suppress – Suppresses the selected Input Point for the specified time (0 seconds means forever).

Input Point Suppression Time Zone – Suppresses the selected Input Point during the specified Time Zone.

Input Point Unsuppress – Unsuppresses the selected Input Point.

Category: Intercom

Connect – Connects the selected intercom station.

Disconnect – Disconnects the selected intercom station.

Intercom Station Reset Output – Resets the output associated with the master station and intercom station selected.

Intercom Station Set Output – Sets the output associated with the master station and intercom station selected.

Category: Intrusion Annunciator

Activate – Activates the selected intrusion annunciator.

Deactivate – Deactivates the selected intrusion annunciator.

Category: Intrusion Area

Arm – Arms the selected intrusion area.

Disarm – Disarms the selected intrusion area.

Category: Intrusion Zone

Bypass Off – The system does not detect intrusion activities at the selected intrusion zone.

Bypass On – The system detects intrusion activities at the selected intrusion zone.

Reset – Resets the selected intrusion zone.

Reset Ack – Resets and acknowledges the selected intrusion zone.

541

Category: Metasys Interlock

Metasys Interlock – Activates the selected Metasys system object.

Note: You can only configure Metasys Interlocks from a P2000 Server. For details, refer to the P2000 Metasys System Integration manual.

Category: Mustering

De-Muster – Resets personnel to their last badge location after the muster is terminated for the selected Zone.

Make Zone Ready – Resets zone status after a muster is stopped so that the zone is ready for another muster.

Mustering Start – Starts the muster in the selected Zone.

Mustering Stop – Ends the muster at the selected Zone.

Save Muster Data – Saves the muster data in the database.

Category: OPC Server

OPC Write – Writes an OPC Tag value in the data type selected.

Category: Outputs

Reset Output – Resets the selected output.

Reset Output Group – Resets the selected output group.

Set Output – Sets the selected output.

Set Output - Timed – Sets the selected output for the specified duration.

Set Output Group – Sets the selected output group for the specified duration.

Category: Panel

Doors - Lock All Doors - Locks all doors.

Doors - Lock All Doors On Panel – Locks all doors associated with the selected panel.

Doors - Unlock All Doors – Unlocks all doors.

Doors - Unlock All Doors On Panel – Unlocks all doors associated with the selected panel.

History Upload Disable – Disables history upload at the selected panel.

History Upload Enable – Enables history upload at the selected panel.

In-X-It Disable – Disables the entry/exit feature at the selected panel.

In-X-It Enable – Enables the entry/exit feature at the selected panel.

Set Time Offset – Sets the time offset of the selected panel by the specified number of minutes.

Time Zone Check No – Disables time zone checking.

Time Zone Check Yes – Enables time zone checking.

Category: Security Level

Clear – Removes the security level at the selected Panel, Terminal, or Terminal Group.

Set to Blue – Applies a Blue code security level at the selected Panel, Terminal, or Terminal Group.

Set to Green – Applies a Green code security level at the selected Panel, Terminal, or Terminal Group.

Set to Orange – Applies an Orange code security level at the selected Panel, Terminal, or Terminal Group.

Set to Other – Applies a specific security level code at the selected Panel, Terminal, or Terminal Group.

Set to Red – Applies a Red code security level at the selected Panel, Terminal, or Terminal Group.

Set to Yellow – Applies a Yellow code security level at the selected Panel, Terminal, or Terminal Group.

Category: Terminal

Anti-Passback Disable – Disables the anti-passback feature at the selected reader, that is, a person can re-badge at the same door without delay.

Anti-Passback Enable – Enables the anti-passback feature at the specified reader for the period of time selected.

Door Access – Unlocks the door (it is not monitored whether the door is actually accessed or not).

Door Relock – Locks the door.

Door Timed Override – Enables from the host, the door timed override feature at the specified reader for the period of time selected.

Local Timed Override Disable – Disables timed override at the specified reader for the period of time entered at the keypad.

Local Timed Override Enable – Enables timed override at the specified reader for the period of time entered at the keypad.

Pin Suppression - set Time Zone – Enables PIN Suppression at the specified reader during the Time Zone selected.

Reader - set Time Zone – Enables the specified reader during the Time Zone selected.

Reader Override - Disable – Disables reader override at the specified reader.

Reader Override - Enable – Enables reader override at the specified reader.

Reader Override - set Time Zone – Unlocks the specified reader door during the Time Zone selected.

Reader Valid & Unauthorized - Disable – Disables the valid and unauthorized feature at the specified reader.

Reader Valid & Unauthorized - Enable – Enables the valid and unauthorized feature at the specified reader.

Soft In-X-It Processing Disable – Disables the soft entry/exit processing feature at the specified reader.

Soft In-X-It Processing Enable – Enables the soft entry/exit processing feature at the specified reader.

Suppress Forced/Propped Inputs – Suppresses forced/propped inputs at the selected reader for the specified time (0 seconds means forever).

Terminal Enable – Enables or disables the terminal selected.

Unsuppress Forced/Propped Inputs – Unsuppresses forced/propped inputs at the selected reader.

Appendix B: Message Types and Sub-Types

his appendix lists all message types and sub-types available for configuring Message Filters. For more information, see Message Filtering on page 237.

Me	essad	e Tv	pes

- 1- Notify
- 3 Alarm
- 5 System Action
- 258 Muster Status
- 259 Muster Event Trigger 289 – P900 CLIC Command
- 289 P900 CLIC Comma 290 – P900 CLIC Status
- 305 Routing Session
- 403 Intrusion Status
- 403 Intrusion St 404 – Fire Status
- 28673 RTL Data
- 28673 RTL Da 28675 – Audit
- ----

Message Sub-Types

1 - Notify

- 204 Alarm Filter
- 207 Comms Up
- 208 Comms Down
- 210 Guard Tour Up

3 – Alarm

- 1 Generic
- 2 Panel Input Point
- 3- Area
- 4 Guard Tour
- 5 Muster Running
- 6 Muster Zone Status
- 7 Muster Disabled
- 8 Muster Aborted
- 9 Loop Tamper Alarm
- 10 Event Alarm
- 12 AV Motion Alarm
- 13 AV Behavior Alarm

Message Sub-Types (Continued)

3 - Alarm (continued)

- 14 AV Video Loss Alarm
- 15 AV Dry Contact Alarm
- 17 Intrusion Alarm
- 18 Fire Alarm
- 19 Integration Component
- 20 Intercom Station
- 21 Intrusion Area Alarm
- 22 Fire Detector Alarm
- 23 Fire IO Module Alarm
- 24 Fire Device Alarm

5 - System Action

- 2 Error or Log
- 4 Counter Changed
- 5 Muster Control Started

258 – Muster Status

259 - Muster Event Trigger

289 - P900 CLIC Command

290 - P900 CLIC Status

- 1 Unknown
- 2 Counter
- 3 Flag

305 - Routing Session

403 – Intrusion Status

404 – Fire Status

28673 - RTL Data

- 1 Panel: Reader Up/Normal
- 3 Panel: System Restart
- 5 Panel: Reader Down
- 10 Panel: System Facility Code Error
- 11 Panel: System Event Activated
- 12 Panel: System Event De-activated
- 15 Panel: Unlock All Doors
- 16 Panel: Lock All Doors
- 17 Panel: Output Set

28673 - RTL Data (continued)218 - Panel: Output Reset19 - Panel: Terminal Reader Strike Locked20 - Panel: Terminal Reader Strike Unlocked21 - Panel: Terminal Reader Strike Unlocked22 - Panel: Terminal Door Held Open23 - Panel: Terminal Door Forced Open23 - Panel: Terminal Valid and Unauthr Access33 - Access Deny: Invalid Card34 - Access Deny: Anti-passback Timer On35 - Access Deny: Invalid Reader36 - Access Deny: Invalid In-X-It Status37 - Access Deny: Invalid Card Timezone38 - Access Deny: Invalid PIN Code39 - Access Deny: Invalid Issue Level40404040414142434444444444454546464646464646464646464647464646464646464646464646464746464646464646464646474646464746464647
 18 - Panel: Output Reset 19 - Panel: Terminal Reader Strike Locked 20 - Panel: Terminal Reader Strike Unlocked 21 - Panel: Terminal Door Held Open 22 - Panel: Terminal Door Forced Open 23 - Panel: Terminal Valid and Unauthr Access 33 - Access Deny: Invalid Card 34 - Access Deny: Anti-passback Timer On 35 - Access Deny: Invalid Reader 36 - Access Deny: Invalid In-X-It Status 37 - Access Deny: Invalid Card Timezone 38 - Access Deny: Invalid PIN Code 39 - Access Deny: Invalid Issue Level 4 - Access Deny: Invalid Issue Level
 19 – Panel: Terminal Reader Strike Locked 20 – Panel: Terminal Reader Strike Unlocked 21 – Panel: Terminal Door Held Open 22 – Panel: Terminal Door Forced Open 23 – Panel: Terminal Valid and Unauthr Access 33 – Access Deny: Invalid Card 34 – Access Deny: Anti-passback Timer On 35 – Access Deny: Invalid Reader 36 – Access Deny: Invalid In-X-It Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 4 – Access Deny: Invalid Issue Level
 20 – Panel: Terminal Reader Strike Unlocked 21 – Panel: Terminal Door Held Open 22 – Panel: Terminal Door Forced Open 23 – Panel: Terminal Valid and Unauthr Access 33 – Access Deny: Invalid Card 34 – Access Deny: Anti-passback Timer On 35 – Access Deny: Invalid Reader 36 – Access Deny: Invalid In-X-It Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 4 – Access Deny: Invalid Issue Level
 21 – Panel: Terminal Door Held Open 22 – Panel: Terminal Door Forced Open 23 – Panel: Terminal Valid and Unauthr Access 33 – Access Deny: Invalid Card 34 – Access Deny: Anti-passback Timer On 35 – Access Deny: Invalid Reader 36 – Access Deny: Invalid In-X-It Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 4 Access Deny: Invalid Issue Level
 22 – Panel: Terminal Door Forced Open 23 – Panel: Terminal Valid and Unauthr Access 33 – Access Deny: Invalid Card 34 – Access Deny: Anti-passback Timer On 35 – Access Deny: Invalid Reader 36 – Access Deny: Invalid In-X-It Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 4 Access Deny: Invalid Issue Level 4 Access Deny: Invalid Issue Level
 23 – Panel: Terminal Valid and Onauthr Access 33 – Access Deny: Invalid Card 34 – Access Deny: Anti-passback Timer On 35 – Access Deny: Invalid Reader 36 – Access Deny: Invalid In-X-It Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 4 Access Deny: Invalid Issue Level 4 Access Deny: Invalid Issue Level
 33 – Access Deny: Invalid Card 34 – Access Deny: Anti-passback Timer On 35 – Access Deny: Invalid Reader 36 – Access Deny: Invalid In-X-It Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 40
 34 – Access Deny: Anti-passback Timer On 35 – Access Deny: Invalid Reader 36 – Access Deny: Invalid In-X-It Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 40
 36 – Access Deny: Invalid Reader 36 – Access Deny: Invalid In-X-It Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 40 Access Deny: Invalid Issue Level
 36 – Access Deny: Invalid III-X-II Status 37 – Access Deny: Invalid Card Timezone 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 40 – Access Deny: Invalid Issue Level
 37 – Access Deny: Invalid Card Time2one 38 – Access Deny: Invalid PIN Code 39 – Access Deny: Invalid Issue Level 40
39 – Access Deny: Invalid Fin Code 39 – Access Deny: Invalid Issue Level
39 – Access Deny, Invalid Issue Level
41 – Access Deny: Invalid Security Level
42 – Panel: Invalid Reader Timezone
43 – Panel: Timed Override Expiration
44 – Access Denv: Invalid Event
45 – Access Deny: Invalid Event Privilege Level
46 – Access Deny: Invalid Biometric
47 – Access Deny: Open Door
48 – Elevator: Elevator Invalid Floor
49 – Elevator: Elevator Invalid Timezone
50 – Elevator: Elevator Invalid Card
65 – Access Grant: Access Granted Central 1
67 – Access Grant: Executive Privilege 1
68 – Access Grant: Access Granted Local 1
69 – Access Grant: Timed Override Enabled 1
70 – Access Grant: Timed Override Disabled 1
71 – Access Grant: Timed Override Enabl Host 1
72 – Access Grant: Timed Override Disabl Host 1
73 – Panel: Panel Card Event Activated 1
74 – Panel: Panel Card Event De-activated 1
75 – Access Grant: Soft In-X-It Violation 2
76 – Assisted Access: Assisted Access 2
78 – Access Grant: Manual Valid&Unauth Accss 2
79 – Elevator: Access Granted 2
80 – Access Grant: Reader Egress 22
96 – Input Point History: Alarm
97 – Input Point History: Secure
90 – Panel: Alami Acknowledged Locally
100 – Panel: D620 Tamper Alarm Reset
101 – Panel: Door Open Alarm
102 – Panel: Duress Alarm
103 – Panel: PIN Code Retry Alarm
104 – Panel: Forced Door Alarm
105 – Panel: Card Parity Alarm 2
106 – Panel: Prox Card Low Battery Alarm 2
107 – Panel: D620 AC Power Set Alarm 2
108 – Panel: D620 AC Power Reset Alarm 2
109 – Panel: D620 Low Battery Set Alarm 2
110 – Panel: D620 Low Battery Reset Alarm 2

М	essage Sub-Types (Continued)
28673 –	RTL Data (continued)
111 –	Panel: Reader Low Battery Set Alarm
112 –	Panel: Reader Low Battery Reset Alarm
113 –	Panel: Reader AC Set Alarm
114 –	Panel: Reader AC Reset Alarm
115 –	Panel: Reader Tamper Set Alarm
116 –	Panel: Reader Tamper Reset Alarm
117 –	Input Point History: Open
118 –	Input Point History: Short
123 –	Panel: Calibration results
125 –	Input Point History: Input Suppressed
129 -	Kone IP Elevator: Kone IP Status Response
130 –	Kone IP Elevator: Kone IP Disconnect Msg
224 –	Panel: Node Went Up
225 -	Panel: Fallback
226 -	Panel: Converter Tamper Set Alarm
227 -	Panel: Converter Tamper Reset Alarm
228 -	Panel: Node Went Down
266 -	Access Grant: Entry Granted Central
207 -	Access Grant: Exit Granted Central
292 -	Panel: Input Module Up
293 -	Panel: Output Module Op
294 -	Panel: Input Module Down
295 -	Panel: Output Module Down
529 -	Intercom: Busy
10752 -	Intercom: Intercom Server Op
10753 -	Intercom: Intercom Server Down
10754 -	Intercomi, Intercom Server Disconnected
10756	Intercom. Intercom Server Disconnected
10750 -	Intercom: Call Poquest
10759	Intercom: Unknown
10750 -	Intercom: Station Output Sat
10760 -	Intercom: Station Output Set
20/81 -	Panel: Node Went Lin Dunlicate
20401 -	Panel: Reader status unknown
20402 -	Panel: Input status unknown
20484	Panel: Output status unknown
20486 -	Panel: Node is Misconfigured
20503 -	Panel: Panel Badge Database Full
20504 -	Panel: Panel Message Buffer Overflow
20505 -	Panel: Panel Message Buffer Cleared
20506 -	Panel: Panel Fault
20507 -	Panel: Panel Firmware Update Initiated
20508 -	Panel: Panel Firmware Update Failed
20509 -	Access Deny: No Override Privilege
20510 -	Access Deny:Timed Override Value Invalid
20511 -	Panel: Reader Status Input Fault
20576 -	Input Point State Change: Alarm
20577 -	Input Point State Change: Secure
20597 -	Input Point State Change: Open
20598 -	Input Point State Change: Short
20599 -	Input Point State Change: Input Suppressed
24577 –	Host: Event Triggered

M	lessage Sub-Types (Continued)
28673 -	RTL Data (continued)
24578 -	Host: Event Triggered Manual
28673 -	Tour Tour Alarmed
28674 -	Tour: Tour Started
28675 -	Tour: Station Checked in On Time
28676 -	Tour: Station Checked in Farly
28677 -	Tour: Station Checked in Late
28678 -	Tour: Station Checked in Out of Order
28679 -	Tour: Tour Stopped
28680 -	Tour: Tour Restarted
28681	Tour: Tour Aborted
28682 -	Tour: Tour Completed
28683 -	Tour: Station Late Timer Reached
28684	Tour: Tour Terminated
32769 -	Area: Reader Exit
32703 -	Area: Reader Entry
32771	
32772	Area: Input Entry
32773	Area: Manual Exit
32774	Area: Manual Entry
36865	Aida Visual: Motion
36866	Audio Visual: Notion
26967	Audio-Visual: Denavior
26060	Audio Visual: Video Loss
30000 -	Fire Alarm: Fire Server Connection Un
41290 -	File Alarmi, File Server Connection Op
41297 -	Otio System: Component Want Un
41472 -	Otis System: Component Went Op
41473 -	Integration Component Un
41720 -	Integration Component: Down
41729 -	Integration Component: Unknown
41730 -	Integration Component: Unavailable
41731 -	Integration Component: Missonfigured
41732 -	Integration Component. Misconligured
28675 -	Audit
1 –	User
2 –	Badge
3 –	Badge Layout
4 –	Badge Fields
5 –	Badge Encoding
6 –	ID Badge
7 –	Cardholder
8 –	Panel
9 –	Terminal
10 –	Partition
11 –	Terminal Group
12 –	Access Group
13 –	Holiday
14 –	Timezone
15 –	Input Point
16 –	Input Group
17 –	Panel Holiday
18 –	Access Template
19 –	Alarm Response Text

м	essage Sub-Types (Continued)
28675 -	Audit (continued)
20 –	Alarm Instruction
21 –	Company
22 –	Output Point
23 –	Output Group
24 –	Department
25 –	Panel Timezone
26 –	Soft Alarm
27 –	Site Parameters
28 –	Workstation
29 –	Мар
30 –	Map Icon Set
31 –	User Defined Fields
32 –	Event
33 –	Panel Card Event
34 –	Alarm Filter
35 –	Message Forwarding
37 –	Permission Group
38 –	Panel Relay
39 –	Report
40 –	MIS Interface
41 –	Image Recall Filter
42 –	Counter
43 –	Action Interlock
44 –	External IP
45 –	Guard Tour Definition
46 –	Tour Station Definition
47 –	Loop
48 –	Elevator
49 –	Floor Mask
50 –	Floor Group
51 –	Floor Name Configuration
52 –	Cabinet
53 –	Door Group
54 –	Door Mask
55 –	Door Name Configuration
56 –	Area
57 –	Muster Zone
58 –	Area Control Layout
60 –	CCTV Server
61 –	CCTV Switch
62 –	CCTV Tour
63 –	CCTV Alarm
64 –	CCTV Macro
65 –	CCTV System Auxiliary
66 –	CCTV Monitor
67 –	CCTV Sequence
68 –	CCTV Camera
69 –	CCTV Preset
70 –	CCTV Pattern
71 –	CCTV Camera Auxiliary
72 –	Enable Code
73 –	P900 Flag

М	essage Sub-Types (Continued)	
28675 –	Audit (continued)	
74 –	P900 Counter	
75 –	P900 Trigger Event	
76 –	P900 Trigger Link	
77 –	P900 System Parameters	
78 –	Auto-badge Number	
79 –	Air Crew PIN Number	
80 –	P900 Sequence Files	
81 –	Remote Server	
82 –	Message Filter	
83 –	Message Filter Group	
84 –	Local Site	
85 –	Service Startup Configuration	
86 –	Application	
87 –	Panel Card Format	
88 –	Reason	
89 –	Security Level Range	
94 –	Audit	
95 –	Alarm History	
96 –	Alarm	
97 –	Generic Text	
98 –	Muster History	
99 –	Guard Tour History	
100 -	Transaction History	
101 -	Redundancy	
102 -	Mapping Configuration	
103 -	Mapping Data Fields Configuration	
104 -	Intercom Exchange	
105 -	Intercom Station	
106 -	AV Sile	
107 -	AV Gamera	
108 -		
109 -	AV PIESEL	
110 -		

Message Sub-Types (Continued) 28675 – Audit (continued) 112 - Enterprise Site 113 - Enterprise Parameters 114 – AV Dry Contact 115 - Alarm Colors 116 - Badging Setup 117 - Request Approvers 118 - FASC-N CCC 119 - Badge Purpose 120 - Alarm Options 121 – Intrusion Entity 122 - SIA Device 123 – Alarm Category 124 - MSEA Graphic 125 – OSI Facility 173 – MSEA Registration 174 - MSEA Partition 176 - Web Access Configuration 177 - Fire Alarm 178 - Software Update 179 - Badge Reason 180 - Required Fields 182 - HID Facility 183 - Kone IP Elevator 184 – Intercom Interface 185 – Integration Component 186 - Assa Abloy Facility 187 - Badge Format 188 - Assa Abloy Badge Format 192 - Mercury Input Point Calibration Table 193 - Mercury Card Format 194 - Mercury Facility 195 - Mercury Procedure 196 - Mercury Trigger

Appendix C: Panel Comparison Matrix

Feature	CK720 (2.6)	CK705 (2.6)	CK721 (2.8)	CK721-A (2.10)	CK721-A (3.0 / 3.1)	S321-DIN	S321-IP	ISO	Isonas	QIН	Assa Abloy	Mercury
Access Grant on Door Open	✓	1	1	1	~	1	-	-	-	-	-	-
Access Groups Per Badge	8	8	8	8	32	2	-	-	1	8	32	32
Add Hardware Module Wizard	✓	1	1	1	✓	-	-	-	-	-	-	-
Air Crew PIN	✓	1	1	1	✓	-	-	-	-	-	-	-
Alarm Debounce	1	1	1	1	~	1	1	-	1	1	-	1
Americans with Disabilities Act (ADA)	1	1	1	1	~	1	-	1	-	1	1	1
Anti-Passback	1	1	1	1	~	1	1	-	-	1	-	1
Anti-Tailgate	1	1	1	1	✓	1	-	-	-	-	-	~
Backup DB to Flash Interval	-	-	-	1	✓	-	-	-	-	-	-	~
Badge Capacity		15K ¹	100K	120K	200K ²	30K	5K	65K	64K	44K	2K	111K ³
Badge Event Privilege Support	✓	~	1	1	~	1	-	-	-	-	-	-
Badge Override Support		~	1	1	~	1	1	-	-	1	-	-
Badge Time Shunt	✓	~	1	1	✓	-	-	-	-	-	-	1
BQT LCD Reader Support	✓	~	1	1	-	-	-	-	-	-	-	-
Calibration/Uncalibration	1	~	1	~	~	~	1	-	-	-	-	1
Card Formats (simultaneously supported)	21	21	21	21	21	21	1	2	1	1	U 4	16
Card ID Support	✓	~	1	1	1	1	-	1	1	1	1	~
Central Mode (Card Processing)	✓	~	1	1	✓	~	-	-	-	-	-	-
Custom Card Formats	✓	~	1	1	✓	~	1	1	1	1	~	1
Custom PIN Code	1	~	1	~	~	~	1	~	-	~	~	1
D620-ECG Elevator Mode	1	~	1	~	~	-	-	-	-	-	-	-
Door Control - Access Time (manual)	1	~	1	~	~	~	-	~	1	~	✓ ⁵	1
Door Control - Timed (manual)	1	1	1	~	~	1	~	-	1	-	-	~
Door Open Warning	1	1	1	~	~	1	-	-	-	-	-	1
Door Shunt Expiration Warning	✓	~	1	1	1	1	-	-	-	-	-	-
Dual Ethernet Support	1	1	-	-	-	-	-	-	-	-	-	✓ ⁶
Elevator Readers (max. per panel)		4	16	16	16	-	-	-	-	-	-	16
Elevator Support	1	1	1	1	1	-	-	-	-	-	-	1
Encrypted Communications	-	-	-	-	✓7	-	1	-	1	1	-	1
Encryption (FIPS 140-2 Compliant)	-	-	-	_	✓7	-	-	_	_	-	-	-

Feature	CK720 (2.6)	CK705 (2.6)	CK721 (2.8)	CK721-A (2.10)	CK721-A (3.0 / 3.1)	S321-DIN	S321-IP	ISO	lsonas	ПH	Assa Abloy	Mercury
Entry/Exit Enforce	1	~	1	1	~	-	-	-	-	-	-	~
Executive Privilege	~	~	1	~	1	~	-	1	-	1	~	1
Exempt from Archive to Flash	>	>	~	>	~	I	-	-	-	-	I	-
Extended Shunt Time	~	~	~	~	~	~	-	-	-	-	-	-
Extended Time Override	~	~	~	~	~	1	-	-	-	-	-	-
Facility Codes	12	12	12	12	12	4	U ⁴	16				
HID Corp. 1000 Card Format	~	~	1	~	✓	~	1	1	✓ ⁸	1	~	1
High Level Elevator	~	~	1	1	✓	-	-	-	-	-	-	-
High Performance Entry/Exit Status Syn- chronization	~	~	1	~	~	-	-	-	-	-	Ι	-
High Speed RS485	1	1	1	1	~	√ ⁹	-	-	-	-	-	1
History Upload With Seconds	1	1	1	1	1	1	1	1	1	1	1	1
Holidays	40	40	40	40	40	40	40	-	16	64	32	40
Input Groups		1	1	1	1	1	-	-	-	-	-	-
Input Suppression		1	1	1	1	-	1	-	-	-	-	1
Inputs (max. per panel)	256	64	256	256	256 ¹⁰ 326 ¹¹	6	12	-	4	5	-	512 ¹²
Intrusion *	-	-	-	-	-	-	-	-	-	-	-	1
Issue Level per Badge	1	1	~	~	~	1	-	~	1	~	~	1
Keyless Override Feature	1	~	~	~	~	1	1	I		I	-	-
KONE HLI Elevator Support	~	1	-	1	✓	-	-	-	-	-	-	-
KONE IP Elevator Support	-	-	-	-	✓7	-	-	-	-	-	-	-
Multi Card Types	~	1	1	1	✓	1	1	-	-	1	1	✓
Multiple Facility Codes per Badge Type	~	1	1	1	✓	1	-	1	1	1	1	✓
N-Man Rule	~	~	1	1	✓	~	-	-	-	-	-	-
Network	~	~	1	1	✓	✓ ⁹	1	1	1	1	~	✓
Otis Compass Elevator Support	-	-	-	-	~	-	-	-	-	-	-	-
Otis EMS - Security / BMS	_	-	-	~	~	-	-	-	-	-	-	-
Output Control (manual)	~	~	~	~	~	1	~	-	~	~	-	✓
Output Groups	>	>	~	>	~	>	-	-	-	-	I	-
Output Groups associated with Time Zones	~	~	1	~	<	~	-	-	-	-	-	-
Output Status Reporting	1	1	1	1	~	1	1	-	-	-	-	 Image: A start of the start of
Outputs (max. per panel)	128	32	128	128	128 ¹⁰ 208 ¹¹	10	8	-	2	2	I	512 ¹²
Override Expiration Warning	1	1	1	1	~	1	-	-	-	-	-	-
Override Reset Threat Level	1	1	1	1	1	1	1	-	-	-	-	-
Panel Card Events	20	20	20	20	20	20	_	-	-	-	-	-
Panel Relay Set/Reset	1	1	1	1	~	-	-	-	-	-	-	-

Feature	CK720 (2.6)	CK705 (2.6)	CK721 (2.8)	CK721-A (2.10)	CK721-A (3.0 / 3.1)	S321-DIN	S321-IP	ISO	Isonas	ПH	Assa Abloy	Mercury
Panel Relays	2	2	1	1	1	-	-	-	-	-	-	-
Peer to Peer Badge Sync	-	-	-	~	~	-	-	-	-	-	-	-
PIN + 1 Duress	~	~	1	~	~	~	-	-	-	-	-	1
PIN Code Digits Supported (Custom)	6	6	6	6	9	5	4	3-6	10 ¹³	9	-	9
Power over Ethernet (PoE) Connection	-	-	-	-	-	-	-	-	~	~	✓ ¹⁴	✓ ¹⁵
Raw 128 Bit Card Format	-	-	-	-	-	_	~	-	-	-	-	-
Reader Override	1	1	1	1	1	1	1	1	1	~	-	1
Reverse Card Reading	1	1	1	1	~	1	-	-	-	-	-	1
Reverse Swipe Duress	1	1	1	1	1	1	-	-	-	-	-	-
Security Level	1	1	1	1	1	1	1	-	-	-	-	-
Special Flags (A, B, C)	1	1	1	1	1	1	-	1	-	~	1	1
Star Feature	1	1	1	1	1	1	-	-	-	-	-	-
Strike Status	1	1	1	1	~	1	1	1	-	-	-	-
Terminal Override Status	1	1	1	1	~	-	-	1	1	~	✓ ¹⁴	1
Terminal Readers	16	4	16	16	64	2	2	128	1	1	1	64 ¹⁶
Terminal Time Zone Enabled	1	1	1	1	1	1	1	1	-	1	-	✓ ¹⁷
Terminal Time Zone Override	1	1	1	1	1	1	1	1	1	1	1	✓ ¹⁷
Terminal Time Zone PIN Suppression	1	1	1	1	1	1	1	1	-	1	-	✓ ¹⁷
Time Zones per Badge	8	8	8	8	32	2	2	-	1	8	8	- ¹⁸
Time Zones per Panel	64	64	64	64	64	64	64	32	32	64	32	64
Valid and Unauthorized	1	1	1	1	1	1	-	-	-	-	-	-

* Intrusion is also supported with Aritech and Bosch panels.

- 1 Without memory expansion.
- 2 When the number of badges exceeds 120,000, the number of access groups should be limited to 50,000.
- 3 Using the standard feature set EP2500 supports 111,000 badges. EP1501, EP1502, and Schlage PIM400-1501 support 31,000. With a reduced feature set, EP2500 supports 500,000. EP1501, EP1502, and Schlage PIM400-1501 support 250,000. To exceed the lower numbers, contact Technical Support for details on changing the badge configuration.
- 4 Unlimited.
- 5 Supported by hard-wired version only.
- 6 Supported by Mercury EP2500 only, using Lantronix® Micro 125 Embedded Serial to Ethernet Module.
- 7 Supported by CK721-A Version 3.1.
- 8 No formats are built-in, all are custom with a maximum of 32-bits.
- 9 S321-DIN panels can communicate with the P2000 Server through network connection using a Digi One™ SP converter box.
- 10 Maximum number supported by RDR2, SI08, SI8, IO8, I16.
- 11 Maximum number supported by RDR2S-A and RDR8S.
- 12 For panels with no reader modules.
- 13 This is the maximum number; however, the number of digits supported depends on the card format assigned to the reader.
- 14 PoE version only.
- 15 Supported by Mercury EP1501 only.
- 16 Up to 64 readers, depending on the panel type.
- 17 Provided via Mercury Triggers and Procedures.
- 18 Uses Access Group Details to associate Readers with Time Zones, on an access group basis, not on a badge basis.

Legacy ar	1d P900) Panels
-----------	---------	----------

Feature	D620 (143G)	D620-TIU (173E)	D600 AP (PS 155B)	S320	P900
Access Grant on Door Open	-	-	_	-	1
Access Groups Per Badge	2	2	2	2	1
Add Hardware Module Wizard	-	-	-	-	-
Air Crew PIN	-	-	1	-	-
Alarm Debounce	-	-	-	-	-
Americans with Disabilities Act (ADA)	-	-	-	-	-
Anti-Passback	1	1	1	1	1
Anti-Tailgate	1	-	1	1	-
Backup DB to Flash Interval	-	-	-	-	-
Badge Capacity	5K ¹	5K ¹	5K ¹	5K ¹	10K ²
Badge Event Privilege Support	1	1	1	1	-
Badge Override Support	1	-	-	1	-
BQT LCD Reader Support	-	-	-	-	-
Calibration/Uncalibration	-	-	-	-	-
Card Formats (simultaneously supported)	1	-	1	1	1
Card ID Support	1	-	1	1	-
Central Mode (Card Processing)	1	1	1	1	-
Custom Card Formats	-	-	-	-	-
Custom PIN Code	1	-	1	1	1
D620-ECG Elevator Mode	-	-	-	-	-
Door Control - Access Time (manual)	1	1	1	1	-
Door Control - Timed (manual)	1	1	1	1	-
Door Open Warning	-	-	-	1	1
Door Shunt Expiration Warning	-	-	-	-	1
Dual Ethernet Support	-	-	-	-	-
Elevator Readers (max. per panel)	-	-	-	-	-
Elevator Support	-	-	-	-	-
Encrypted Communications	-	-	-	-	-
Encryption (FIPS 140-2 Compliant)	-	-	-	-	-
Entry/Exit Enforce	1	1	1	1	1
Executive Privilege	1	1	1	1	-
Exempt from Archive to Flash	_	_	_	_	-
Extended Shunt Time	-	-	1	-	-

Feature	D620 (143G)	D620-TIU (173E)	D600 AP (PS 155B)	S320	006d
Extended Time Override	-	-	1	-	-
Facility Codes	3	-	4	3	8
HID Corp. 1000 Card Format	I	-	1	_	-
High Level Elevator	-	-	-	-	-
High Performance Entry/Exit Status Synchronization	-	-	-	-	-
High Speed 485	_	-	-	-	-
History Upload With Seconds	_	-	-	-	1
Holidays	21	21	21	21	40
Input Groups	1	1	1	1	1
Input Suppression	-	-	-	_	-
Inputs (max. per panel)	128	384	128	128	80
Intrusion	-	_	I	_	-
Issue Level per Badge	1	1	1	1	1
Keyless Override Feature	-	-	-	_	-
KONE HLI Elevator Support	-	-	-	_	-
KONE IP Elevator Support	-	-	-	-	-
Multi Card Types	-	-	-	-	-
Multiple Facility Codes per Badge Type	-	-	-	-	-
N-Man Rule	-	-	-	-	-
Network	-	-	-	_	-
Otis Compass Elevator Support	-	_	I	_	-
Otis EMS - Security / BMS	-	-	-	-	-
Output Control (manual)	1	1	1	1	1
Output Groups	1	1	1	1	1
Output Groups associated with Time Zones	1	1	1	1	1
Output Status Reporting	-	-	-	1	-
Outputs (max. per panel)	512	512	512	128	40
Override Expiration Warning	_	-	-	-	-
Override Reset Threat Level	_	-	-	-	-
Panel Card Events	20	20	20	20	-
Panel Relay Set/Reset	1	1	1	1	-
Panel Relays	1	1	1	2	-
Peer to Peer Badge Sync	-	-	-	-	-
PIN + 1 Duress	_	-	1	-	-

Legacy and P900 Panels

Legacy and P900 Panels

Feature	D620 (143G)	D620-TIU (173E)	D600 AP (PS 155B)	S320	006d
PIN Code Digits Supported (Custom)	5	-	5	5	4
Power over Ethernet (PoE) Connection	-	-	-	-	-
Raw 128 Bit Card Format	-	-	-	-	_
Reader Override	1	1	1	1	1
Reverse Card Reading	-	-	-	-	-
Reverse Swipe Duress	-	-	-	-	-
Security Level	-	-	1	-	-
Special Flags (A, B, C)	-	-	-	-	-
Star Feature	-	-	-	-	-
Strike Status	-	-	-	1	-
Terminal Override Status	-	-	-	-	-
Terminal Readers	16	16	16	16	8
Terminal Time Zone Enabled	1	1	~	1	-
Terminal Time Zone Override	1	1	~	1	✓ ³
Terminal Time Zone PIN Suppression	✓	1	~	1	✓
Time Zones per Badge	2	2	2	2	-
Time Zones per Panel	16	16	16	16	64
Valid and Unauthorized	-	-	-	-	-

1 Without MX2.

2 Without memory expansion.

3 Use the Unlocked Time Zone function to configure P900 terminal time zone override.

Appendix D: CCTV Switch Protocols

his appendix describes the CCTV Switch Protocols that the CCTV feature supports. The protocols supported vary according to the current manufacturers' products. Those listed here are for a specific version of the driver.

For each of the supported switches, this appendix gives information about the controls that are available in CCTV Control, and the actions that are available when defining CCTV event actions and OPCWrite actions.

You can define CCTV event actions using the standard P2000 event action functions. For details, see Creating Actions on page 351. However, you may also wish to use the standard P2000 OPCWrite function if what you want to do is not available with the CCTV event actions, or you have not fully configured the CCTV equipment from the CCTV/AV Configuration window.

Note that when OPCWrite is used, any changes to the namespace may not be automatically reflected.

The actions that are available in the OPC Server namespace are listed in Appendix E: CCTV Server Namespace Definitions. The switch protocols that the CCTV feature supports use a subset of the namespace tags.

The CCTV feature does not include support for multiplexers, VCRs, and video on screen.

Communications

The communication settings for each switch are determined by the manufacturer. Ensure that the protocol and COM port settings at the switch matches that configured in the Edit CCTV Switch dialog box. Refer to the manufacturer's specification for details of what the settings should be.

In addition, the CCTV driver only applies the Timeout setting in the Communications tab of the Edit CCTV Switch dialog box if the matrix transmits results, or the configured timeout is longer than the hard-coded timeout.

Camera Movement Actions

Most protocols specify that camera movements be sent once to initiate the movement in a given direction. Once movement has started, a separate stop action must be sent to stop the movement. Some protocols include a timeout function, so that camera movement stops automatically after a specified time. Refer to the manufacturer's specification for details.

For diagonal movement both the pan and tilt commands are sent.

A Monitor Selection action is sent before each action. This means that simultaneously several operators at different workstations can independently move the individual cameras they each have selected.

Monitor Sequences

Monitor sequences are normally associated with a particular monitor. However, some CCTV manufacturers use monitor sequences that are independent of the monitor. This means that all monitors use the same sequence. Therefore, sequence 1 would be the same sequence when used by any monitor on the system.

General ASCII Protocol

The General ASCII protocol uses the CCTV Server as a general OPC Server that can send ASCII control strings to devices to control them. Typically, the devices exist in the building management and process control industry, as well as the access control industry.

This protocol uses the GeneralString Tag in the switch to send a string of ASCII characters out of the COM port. Once the string has been sent, the data is cleared. Any ASCII string can be sent. A sequence of strings could be sent for applications that are more complex. The assumption is that there is no protocol control required and that no responses are processed. The standard control/client does not have a switch - General String field. The event action processing in the P2000 software or a specially written OPC Client interface drives this feature.

Commands Supported

The General ASCII Switch protocol supports up to 50 characters (from the General String field) to be stored and sent. Both printable and non-printable ASCII characters are supported; however, nulls are not supported.

Note that if the switch protocol selected in the Edit CCTV Switch window is General ASCII, then the system does not save a record in the configuration database. Since the data for reports is that in the database, it is not possible to run reports for General ASCII Switches.

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVGeneralASCII**.

American Dynamics

This section describes the American Dynamics Switch protocol for the switch model AD1024. The American Dynamics protocol enables an operator at a suitably configured P2000 workstation to control CCTV equipment connected to an American Dynamics AD1024 switch.

The CCTV feature should work with other American Dynamics switches, if they comply with the communications protocol specified in the American Dynamics manual AN001 for general commands and AN005 for the date/time command only. The only issue that may arise when operating with switches other than the AD1024 is that they may support numbers of cameras and monitors in excess of the maximum values set for the AD1024.

All basic camera and monitor selection and camera movement commands including latched auxiliaries are supported.

The American Dynamics features supported are:

- Monitor and camera selection
- Camera pan and tilt with variable speed
- Camera zoom, focus, and iris control (fixed speed only)
- Camera auxiliary on and off for latched auxiliaries only
- Camera call and set shot (preset)
- New Alarm, Clear Alarm and Acknowledge Alarm. The Clear and Acknowledge Alarm are sent simultaneously in response to a P2000 Alarm Stop event action.

American Dynamics Protocol

The protocol is assumed to be in one direction only, that is the CCTV Server sends commands to the switch and does not expect any replies. The CCTV Server ignores any responses that may be received.

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVAmericanDynamics**.

Supported CCTV Controls

The following dialog box displays some of the controls that are available for an American Dynamics AD1024 switch.

^			Switch	un Machar Switch
			AmerD	un Mactor Switch
Se				ynniaster smeet
Se				
	queore		- От	North Doors
	querre J		3 ° *	in instances
			CM	Dalu Manharina
				add Joany Homooning
			CA	switch Aux 1
-				
Station 4 t 1 Station	• Preset	Pr0001 Au0001	• •	
				Nudge factor[1100] 10
				10
	Zoom	Focus	Ŀ	is ,
		8	8	
	Saton (Saton (USaton (ISaton Staton JiSaton ISaton Zoon Zoon	ISaton Staton Staton Staton Staton Distaton Zoom Four Four	ISaton Sector ISaton ISaton Cate Account of Cate Account of Ca

Supported CCTV Event Actions

The CCTV event actions that the CCTV feature supports for American Dynamics 1024 switch are:

Supported Actions	
Switch Alarm Play	
Switch Alarm Stop	

Monitor Camera

Camera Preset

Camera Auxiliary Play Camera Auxiliary Stop

Supported OPCWrite Event Actions

Appendix E: CCTV Server Namespace Definitions displays a full list of the namespace tags that an OPC Client can interrogate. If you are using OPCWrite to create an event action, the following namespace tags are supported for an American Dynamics 1024 switch:

Supported Tags	
S%.AlarmPlay S%.AlarmStop	
S%.DateTime	
M#.Camera	
C#.PresetRecord C#.PresetPlay	
C#.AuxiliaryPlay C#.AuxiliaryStop	
C#.Tilt C#.Pan	
C#.Zoom C#.Focus C#.Iris	

Auto Repeat Actions

The following actions repeat until specifically reset to zero:

C#.Tilt C#.Pan C#.Zoom C#.Focus C#.Iris

For these commands, the client would need to issue a stop command; otherwise, the command repeats indefinitely.

See also Note 1 in Appendix E: CCTV Server Namespace Definitions.

Automatic Status Update Tags

American Dynamics does not support periodic status updates. These tags display a U flag in Appendix E: CCTV Server Namespace Definitions.

Maximum and Default Values

Some items in the CCTV Server namespace have maximum and default values associated with them. The following table lists those applicable to American Dynamics.

The maximum values define the number of items that the protocol allows. The values were derived from the American Dynamics manual *AD1024 CPU System Programming and Operating Instructions*.

The default value is the number of items generated in the namespace if the operator does not explicitly define the number from within the CCTV/AV Configuration window.

	Maximum Value	Default Value
SwitchAlarmMax	8192	64
SwitchMonitorMax	128	32
SwitchCameraMax	1024	64
CameraAuxiliaryMax	32 (per camera)	8 (per camera)
CameraPresetMax	72 (per camera)	8 (per camera)
BetaTech

This section describes the BetaTech Switch protocol. The BetaTech protocol enables an operator at a suitably configured P2000 workstation to control CCTV equipment connected to the Ademco® VideoBlox Switch.

The CCTV feature should work with any of the Surveillance Mate Master Series (Revision III) at firmware Version 4.69g.

All basic camera and monitor selection and camera movement commands are supported.

The BetaTech features supported are:

- Monitor and camera selection
- Camera pan and tilt with variable speed
- Camera zoom, focus, and iris control
- Camera auxiliaries
- Record and play camera presets
- Play/stop a sequence on a monitor
- System and switch auxiliaries
- System date and time

A BetaTech sequence is a monitor independent sequence and can be set up to behave as if it is running macros, tours, or sequences.

The following command in the BetaTech protocol is not supported:

Status inquiries

In addition, note that the BetaTech protocol does not allow alarms.

Switch Configuration

Keyboard 16 Commands

It is possible to disable functions when you set up the switch. The serial port is associated with keyboard 16; and any functions that are blocked for keyboard 16 are automatically disabled for the serial port. This means that some functions, for example, presets, sequences, may be disabled.

BetaTech Parameters

The communication parameters are:

Baudrate	9600
Data bits	8
Stop bits	1
Parity	None
Timeout (ms)	500
Handshake	Hardware

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVBetaTech**.

Supported CCTV Controls

The following dialog box displays some of the controls that are available for a supported BetaTech switch.

otor -				- Suitch
- 14.04				Debetech Medau Cuthk
No.	Description	-		Becareor Master Switch
0001	Mon Ext 1			
2000	Mon Ext 2		Sequence Se0001	C Tour North Doors
0003	Mon Ext 3	1000		-
0004	Mon Ext 4			C Macro Daily Monitoring
0005	M0005			
0006	M0005			Aux Switch Aux 1
0007	M0007			
0008	MUUUS			▶ ■
0009	MUUU9	-		
mera -				
	[1.1		
NO.	Description	_ _	C Pattern	코티아, 클릭 //
0001	North Terminal Station		1	– 비미지 김 기가
0002	North Satelike Station		Preset Pr0001	
0003	South Shuttle			
0004	Concourse Left		C Aux Au0001	
00005	COORE			물다면 가슴지 물
00007	00007			
0007	0008			- I I I I I I I I I I I I I I I I I I I
0000	00009			
0010	C0010			Nurlae Eactor [1 100]
0011	C0011			Nonfe Laccol Tr. 1001 10
0012	C0012			
0013	C0013			
0014	C0014		Zoom Focus	Iris
0015	C0015			
0017	C0016		J J 1 1 1	

Supported CCTV Event Actions

The CCTV event actions that the CCTV feature supports for BetaTech are:

Supported Actions

Switch Auxiliary Play Switch Auxiliary Stop

Monitor Sequence Play Monitor Sequence Stop

Monitor Camera

Camera Preset

Camera Auxiliary Play

Camera Auxiliary Stop

Supported OPCWrite Event Actions

Appendix E: CCTV Server Namespace Definitions displays a full list of the namespace tags that an OPC Client can interrogate. If you are using OPCWrite to create an event action, the following namespace tags are supported for a BetaTech switch:

Supported Tags
S%.AuxiliaryPlay S%.AuxiliaryStop
S%.DateTime
M#.SequencePlay M#.SequenceStop
M#.Camera
M#.GeneralString
C#.PresetRecord C#.PresetPlay
C#.AuxiliaryPlay C#.AuxiliaryStop
C#.Tilt C#.Pan
C#.Zoom C#.Focus C#.Iris

Auto Repeat Actions

Auto repeat functions are not required.

Automatic Status Update Tags

Status inquiries are not supported. These tags display a U flag in Appendix E: CCTV Server Namespace Definitions.

Maximum and Default Values

Some items in the CCTV Server namespace have maximum and default values associated with them. The following table lists those applicable to BetaTech.

The maximum values define the number of items that the protocol allows. The default value is the number of items generated in the namespace if the operator does not explicitly define the number from within the CCTV/AV Configuration window.

	Maximum Value	Default Value
SwitchMonitorMax	256	32
SwitchCameraMax	4096	64
SwitchAuxiliaryMax	256	64
MonitorSequenceMax	1024	8
CameraAuxiliaryMax	64	8 (per camera)
CameraPresetMax	128	8 (per camera)

Geutebrück - GST Interface

This section describes the Geutebrück GST Interface Switch protocol. The Geutebrück protocol enables an operator at a suitably configured P2000 workstation to control CCTV equipment connected to one of the following Geutebrück switches:

- CPX 24/8
- CPX 48/8
- VX 3 (Vicros III)
- KS 48 (Vicros II)
- KS 40

The CCTV feature should work with other Geutebrück switches, if they adhere to the communications protocol specified by the GST interface if the MicroLink controller with VicroSoft version is 5.27 or later. Note that currently the MultiScope hardware and GeVi software interface is not supported.

All basic camera and monitor selection and camera movement commands are supported.

The Geutebrück GST interface features supported are:

- Monitor and camera Selection
- Camera pan and tilt with variable speed
- Camera zoom, focus, and iris control
- Camera wiper, washer, and light
- Camera auxiliaries on and off
- Camera call and set pre-position (preset)
- Alarm activation
- Sequence play and stop
- Date and time setting
- Camera Home
- Autopanning

Note that the Camera Home function is played using pattern 1 and Autopanning is played using pattern 2; however, you cannot use the protocol to define the Camera Home position or Autopanning.

The following commands in the Geutebrück GST protocol are not supported.

- Activate or deactivate input activities (macros); although you can trigger a macro provided it has been deactivated
- Switch cameras on and off
- User program restarts or changes
- Programming sequences
- Monitor status inquiries
- Date and time inquires
- Remote controllable camera
- Sequence dwell time
- Acknowledge and reset alarms
- Toggle switch auxiliaries

Geutebrück Parameters

The default communications parameters for the GST interface are:

Baudrate	1200
Data bits	8
Stop bits	1
Parity	None
Timeout (ms)	500
Handshake	Hardware

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVGeutebrueck**.

Supported CCTV Controls

The following dialog box displays some of the controls that are available for a Geutebrück switch.



Supported CCTV Event Actions

The CCTV event actions that the CCTV feature supports for a Geutebrück switch are:

Supported Actions

Switch Macro Play Switch Alarm Play Switch Auxiliary Play Switch Auxiliary Stop

Monitor Sequence Play Monitor Sequence Stop

Monitor Camera

Camera Pattern Play

Camera Preset

Camera Auxiliary Play Camera Auxiliary Stop

Supported OPCWrite Event Actions

Appendix E: CCTV Server Namespace Defini-

tions displays a full list of the namespace tags that an OPC Client can interrogate. If you are using OPCWrite to create an event action, the following namespace tags are supported for a Geutebrück switch:

Supporte	d Tags
S%.MacroPlay S%.MacroStop S%.AlarmPlay S%.AuxiliaryPlay S%.AuxiliaryStop	
S%.DateTime	
M#.SequencePla M#.SequenceSto	y p
M#.Camera	
C#.PatternPlay	
C#.PresetRecord C#.PresetPlay	
C#.AuxiliaryPlay C#.AuxiliaryStop	
C#.Tilt C#.Pan	
C#.Zoom C#.Focus C#.Iris C#.Wiper C#.Washer C#.Light	

Macros

Macros are the same as input activities. Macros can be deactivated, but once deactivated the macro cannot be started using the CCTV driver.

Camera Auxiliaries

Camera auxiliaries 1 to 4 are used to implement the following functions:

Camera Auxiliary	Function	
1	Х	
2	Y	
3	U	
4	V	

Monitor Sequences

Geutebrück GST sequences are monitor independent. The monitor can only play sequences that are higher than or equal to the monitor number.

Sequences contain no positional commands for a camera (including presets).

Note that the dwell time is associated only with the monitor on which the sequence was set up. It does not apply when running a sequence on a different monitor.

Auto Repeat Actions

The Geutebrück protocol does not require auto repeat functions.

Automatic Status Update Tags

The Geutebrück driver does not support status updates. These tags display a U flag in Appendix E: CCTV Server Namespace Definitions.

Maximum and Default Values

Some items in the CCTV Server namespace have maximum and default values associated with them. The following table lists those applicable to the supported Geutebrück Switch. The maximum values define the number of items that the protocol allows. The default value is the number of items generated in the namespace if the operator does not explicitly define the number from within the CCTV/AV Configuration window.

	Maximum Value	Default Value
SwitchMacroMax	9999	8
SwitchAlarmMax	9999	64
SwitchAuxiliaryMax	384	8
SwitchMonitorMax	99	32
SwitchCameraMax	255	64
MonitorSequenceMax	99	8
CameraAuxiliaryMax	2 (per camera)	2 (per camera)
CameraPatternMax	2(per camera)	2 (per camera)
CameraPresetMax	200 (per camera)	8 (per camera)

Panasonic®

This section describes the Panasonic Switch protocol. The Panasonic SX850 protocol enables an operator at a suitably configured P2000 workstation to control CCTV equipment connected to the SX850 Panasonic switch.

The CCTV feature should work with other Panasonic switches, if they adhere to the same communications protocol as described in the manual *SX850 Protocol Information RS-232 Version 1.4 01.24/00*. However, other Panasonic switches may support more cameras and monitors than the maximum allowed for the *SX850* switch.

All basic camera and monitor selection and camera movement commands are supported.

The Panasonic SX850 features supported are:

- Monitor and camera selection
- Camera pan and tilt with variable speed
- Camera zoom, focus, and iris control (fixed speed only)
- Camera preset
- Alarm point set and reset sent in response to P2000 event actions
- Run Stop Pause Resume Step Forward Step Backward Monitor Tour Sequences

The following commands in the Panasonic SX850 protocol are not supported:

- Status Inquiry Commands
- Priority Lock On and Off
- Pan, Tilt Fast/Slow
- Alarm Processing (except Alarm Point Set and Reset)
- Reverse Sequence

Panasonic equipment does not support simultaneous movement of more than one camera connected to a switch. However, if you configure up to three switches in the CCTV/AV Configuration window, then you could control up to three cameras simultaneously (one per switch) by using up to three separate COM lines between the computer and the switch.

Note that Panasonic supports one client only. If you attempt to use more than one client, the commands may have unexpected results.

Switch Configuration

You must disable Auto Log-Off. Refer to your Panasonic manual for details.

Panasonic SX850 Parameters

The communications parameters are:

Baudrate	9600
Data bits	8
Stop bits	1
Parity	None
Timeout (ms)	500
Handshake	None

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVPanasonic**.

Supported CCTV Controls

The following dialog box displays some of the controls that are available for a supported Panasonic switch.



Supported CCTV Event Actions

The CCTV event actions that the CCTV feature supports for a Panasonic Switch are:

Supported Actions

Switch Alarm Play Switch Alarm Stop

Monitor Sequence Play Monitor Sequence Stop

Monitor Camera

Camera Preset

Supported OPCWrite Event Actions

Appendix E: CCTV Server Namespace Definitions displays a full list of the namespace tags that an OPC Client can interrogate. If you are using OPCWrite to create an event action, the following namespace tags are supported for a Panasonic SX850 switch:

_	
	Supported Tags
S	%.AlarmPlay
S	%.AlarmStop
N	1#.SequencePlay
Ν	1#.SequenceStop
N	1#.SequencePause
N	1#.SequenceRestart
N	1#.SequenceStepForward
N	1#.SequenceStepBackward
N	1#.Camera
С	#.PresetPlay
C	# Tilt
c	# Pan
1	
C	#.Zoom
C	#.Focus
C	C#.Iris
L	

Camera Movement Commands

Panasonic does not support movement of more than one camera (at one switch) at a time. This means that if a camera movement is being performed and a second camera is selected, the first camera stops.

Auto Repeat Actions

The Panasonic SX850 protocol does not support the auto repeat functions.

Automatic Status Update Tags

Panasonic does not support periodic status updates. These tags display a U flag in Appendix E: CCTV Server Namespace Definitions.

Maximum and Default Values

Some items in the CCTV Server namespace have maximum and default values associated with them. The following table lists those applicable to Panasonic SX850.

The maximum values define the number of items that the protocol allows. The default value is the number of items generated in the namespace if the operator does not explicitly define the number from within the CCTV/AV Configuration window.

	Maximum Value	Default Value
SwitchAlarmMax	128	64
SwitchMonitorMax	65534	32
SwitchCameraMax	99999	64
MonitorSequenceMax	65534	8

Pelco®

This section describes the Pelco Switch protocol. The Pelco 9760 protocol enables an operator at a suitably configured P2000 workstation to control CCTV equipment connected to one of the following Pelco switches:

- Pelco 9760
- CM 6700
- CM 6800

The CCTV feature should work with other Pelco switches, if they adhere to the communications protocol specified in Chapter 4 of the Pelco document C542M-B (8/00). In some of the newer Pelco switches, the functionality of the data translator is built into the switch; for these a data translator may not be required.

A Pelco 9760 switch assumes a Pelco CM9760-DT or CM9760-DT4 data translator is connected in the RS232 line between the computer running the CCTV Server and the CC1 CPU of the CM9760 Switch. The CM 6700 and CM 6800 do not require a data translator.

All basic camera and monitor selection and camera movement commands are supported.

The Pelco 9760 features supported are:

- Monitor and camera selection
- Camera pan and tilt with variable speed
- Camera zoom, focus, and iris control (fixed speed only)
- Switch camera auxiliaries and system auxiliaries on and off
- Set and go to camera presets
- Record and play camera patterns

The stop a camera pattern, select Aux, then click Stop.

- Trigger and clear/reset Alarms
- Play and stop macros. Play and stop tours and monitor sequences also appear in the window and have the same effect as play and stop macros.

The following commands in the Pelco 9760 protocol are not supported:

- Set Preset with a Label
- Query Device
- Video Loss Detect
- Report Revision
- Select Next/Previous Camera

Pelco 9760 Protocol

The protocol used is bidirectional. If the matrix recognizes a command, an acknowledgement is sent back to the CCTV Server. If a command is not recognized, a negative acknowledge is returned.

The predefined timeout for the Pelco switch is 500 ms.

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVPelco9760**.

Supported CCTV Controls

The following dialog box displays some of the controls that are available for a Pelco 9760 switch.

			Switch
Description	1		Pelco Master Switch
Mon Ext 1			
Mon Ext 2		Servere 5-0001	G Taura Nambh Danna
Mon Ext 3		sequence secont	is four prototoors
Mon Ext 4			C Name Daily Manifester
M0005		▶ ■	Toaly Honcoring
M0006			C Aux Switch Aux 1
M0007			The second secon
M0008			b
M0009	-		
South Shuttle Concourse Left South Terminal Station		C Preset Pr0001 C Aux Au0001	
C0007			
C0008			
C0009			
C0010			Nudge factor[1.,100] 10
C0011			10
C0012			
C0013			
C0014		200m Focus	ins
	Description Mon Ex1 5 Mon Ex1 5 Mon Ex1 5 Mon Ex1 4 Mon Ex1 6 Mon	Description A Mon 2-1 B Mo	Description Arr. C. 1 Arr.

Supported CCTV Event Actions

The CCTV event actions that the CCTV feature supports for a Pelco 9760 are:

Supported Actions

Switch Tour Play Switch Tour Stop Switch Macro Play Switch Macro Stop Switch Alarm Play Switch Alarm Stop Switch Auxiliary Play Switch Auxiliary Stop

Monitor Sequence Play Monitor Sequence Stop

Monitor Camera

Camera Pattern Play

Camera Preset

Camera Auxiliary Play Camera Auxiliary Stop

Supported OPCWrite Event Actions

Appendix E: CCTV Server Namespace Defi-

nitions displays a full list of the namespace tags that an OPC Client can interrogate. If you are using OPCWrite to create an event action, the following namespace tags are supported for a Pelco 9760 switch:

	Supported Tags
S%. S%. S%. S%. S%. S%. S%.	TourPlay TourStop MacroPlay MacroStop AlarmPlay AlarmStop AuxiliaryPlay AuxiliaryStop
S%.	DateTime
M#.9	SequencePlay
M#.9	SequenceStop
M#.(Camera
C#.F	PatternPlay
C#.F	PatternRecord
C#.F	PresetRecord
C#.F	PresetPlay
C#./	AuxiliaryPlay
C#./	AuxiliaryStop
C#.1	Filt
C#.F	Pan
C#.2	Zoom
C#.F	Focus
C#.I	ris

Auto Repeat Actions

The Pelco 9760 protocol does not support the auto repeat function for the following commands:

C#.Tilt C#.Pan C#.Zoom C#.Focus C#.Iris

See also Note 1 in Appendix E: CCTV Server Namespace Definitions.

Automatic Status Update Tags

Pelco 9760 does not support periodic status updates. These tags display a U flag in Appendix E: CCTV Server Namespace Definitions.

Macro Programming

Macros are programmed into the system using the 9760-MGR software shipped with each switch. They cannot be programmed from the CCTV client at a P2000 workstation.

Tour and monitor sequence commands from a P2000 workstation are executed as play or stop macro commands with the same number. Tours and sequences do not exist as separately programmable functions – there are only macros.

Recording Patterns

If you are recording patterns, ensure that no other OPC Client is using the switch. In addition, if you wish to stop recording a pattern, you must click **Record** again.

Maximum and Default Values

Some items in the CCTV Server namespace have maximum and default values associated with them. The following table lists those applicable to Pelco 9760.

The maximum values define the number of items that the protocol allows. The values were derived from Section 4 of the Pelco manual *C54M-B* (8/00) *CM9760-DT/DT4 Data Translator Installation/Operation*.

The default value is the number of items generated in the namespace if the operator does not explicitly define the number from within the CCTV/AV Configuration window.

	Maximum Value	Default Value
SwitchAlarmMax	9999	64
SwitchMonitorMax	9999	32
SwitchCameraMax	9999	64
SwitchAuxiliaryMax	20000	64
SwitchMacroMax	999	8
SwitchTourMax	99	8
MonitorSequenceMax	99 (per monitor)	8 (per monitor)
CameraAuxiliaryMax	8 (per camera)	8 (per camera)
CameraPatternMax	99 (per camera)	2 (per camera)
CameraPresetMax	9999 (per camera)	8 (per camera)

Philips Burle (Bosch®)

This section describes the Philips Burle Switch protocol. The Philips Burle protocol enables an operator at a suitably configured P2000 workstation to control CCTV equipment connected to one of the following Philips Burle switches:

- LTC 8100 Series
- LTC 8200 Series
- LTC 8300 Series
- LTC 8500 Series
- LTC 8600 Series
- LTC 8800 Series
- LTC 8900 Series

Each switch requires CPU Revision Level 8.1.

All basic camera and monitor selection and camera movement commands are supported. Commands relating to <u>logical</u> camera and monitor numbers are supported.

The LTC 8x00 Series switch features supported are:

- Monitor and camera selection
- Camera pan and tilt with variable speed
- Camera zoom, focus, and iris control (fixed speed only)
- Switch camera auxiliary on and off
- Camera call and set pre-position (preset)
- Alarm activate and deactivate
- Sequence run or hold
- Step forward and step backward in a Sequence
- Set time and set date
- Run system macros

The following commands in the protocol are not supported:

- Lockouts
- Commands using a keyboard number
- Latch Auxiliary On, Latch Auxiliary Off, and Cancel Auxiliary Latch commands
- Auxiliary Toggle
- System Status Commands
- Video Detection Commands
- Allegiant Coaxial Transmission System (ACTS) Commands
- On Screen Display Commands (except Send Monitor/Camera Title)
- System Commands (except Set Date & Set Time)
- Allegiant Diagnostic Commands

Switch Macros

Philips switches support system macros that are input using the Philips Master Control Software. These macros can be run (but not stopped) from the CCTV Server as long as they follow the correct naming convention.

The macro name must be in the form:

MACRO_nnnnn

For example, Macro 1 would start with the statement:

Begin MACRO_000001

Philips Burle Parameters

The communications parameters are:

Baudrate	19200
Data bits	8
Stop bits	1
Parity	None
Timeout (ms)	500
Handshake	Hardware, but can be disabled by connecting pins 4 and 5 at the Switch's COM port

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVPhilips**.

Supported CCTV Controls

The following dialog box displays some of the controls that are available for supported Philips Burle switches.



Supported CCTV Event Actions

The CCTV event actions that the CCTV feature supports for a Philips Burle switch:

Supported Actions Switch Alarm Play Switch Alarm Stop Switch Macro Play Monitor Sequence Play Monitor Sequence Stop Monitor Camera Camera Preset

Camera Auxiliary Play Camera Auxiliary Stop

Supported OPCWrite Event Actions

Appendix E: CCTV Server Namespace Definitions displays a full list of the namespace tags that an OPC Client can interrogate. If you are using OPCWrite to create an event action, the following namespace tags are supported for a Philips Burle switch:

Supported Tags
S%.AlarmPlay S%.AlarmStop S%.MacroPlay
S%.DateTime
M#.SequencePlay M#.SequenceStop M#.SequenceStepForward M#.SequenceStepBackward
M#.Camera
C#.PresetRecord C#.PresetPlay
C#.AuxiliaryPlay C#.AuxiliaryStop
C#.Tilt C#.Pan
C#.Zoom C#.Focus C#.Iris

Auto Repeat Actions

The Philips Burle switch protocol does not require the auto repeat function.

Automatic Status Update Tags

The Philips Burle switches do not support periodic status updates. These tags display a U flag in Appendix E: CCTV Server Namespace Definitions.

Maximum and Default Values

Some items in the CCTV Server namespace have maximum and default values associated with them. The following table lists those applicable to a Philips Burle switch.

The maximum values define the number of items that the protocol allows. The default value is the number of items generated in the namespace if the operator does not explicitly define the number from within the CCTV/AV Configuration window.

	Maximum Value	Default Value
SwitchAlarmMax	9999	64
SwitchMacroMax	10000	8
SwitchMonitorMax	9999	32
SwitchCameraMax	9999	64
MonitorSequenceMax	9999	8 (per monitor)
CameraAuxiliaryMax	9999 (per camera)	8 (per camera)
CameraPresetMax	9999 (per camera)	8 (per camera)

Note: This protocol applies to several switches that have differing maximum values. The maximum value allowed by the software is the biggest maximum for the supported Philips Burle switches. System operators should reset these maximum values from the CCTV/AV Configuration window for smaller configurations.

Cabling Configuration

Use an RS232 cable to establish the communication between the Philips Burle switch and the P2000 Server computer.

To allow the communication, the Philips Burle switch requires PIN 4 (CTS) to be held high. To accomplish this, PIN 4 (CTS) must be jumped to PIN 5 (RTS) at the Philips Burle switch.

The following procedure presents the recommended cable configuration.

- 1. Attach one end of the RS232 cable to the serial port (example: COM1) of the P2000 Server.
- 2. Attach the other end of the RS232 cable to the TCX01 main CPU bay connector marked **CONSOLE**.
- 3. Place a jumper across PINs 4 and 5 of the CONSOLE port.



Ultrak®

This section describes the Ultrak Switch protocol. The Ultrak MaxPro-1000 protocol enables an operator at a suitably configured P2000 workstation to control CCTV equipment connected to the MaxPro-1000 Ultrak switch:

All basic camera/monitor selection and camera movement commands are supported.

The Ultrak MaxPro-1000 features supported are:

- Monitor and camera selection
- Camera pan and tilt with variable speed
- Camera zoom, focus, and iris control (fixed speed only)
- Camera call and set views (presets)
- Camera washer and wiper
- Trigger and clear Alarms

The following commands in the Ultrak Max-Pro-1000 protocol are not supported:

- Selecting alternate cameras
- Video recorder features
- Selecting next/previous source for video signals
- Standard / Smart device operations
- Recording /changing scans (sequences)
- User and system macros are not supported (but they can be triggered indirectly via alarms).

Switch Configuration

Keyboard 64 Commands

The CCTV driver transmits all its commands as in Keyboard 64; therefore, you need to configure Keyboard 64 in the Ultrak switch. Normally each keyboard is associated with an operator. The CCTV access rights for this operator need to be configured correctly (ideally access to all equipment) and this operator should have the highest priority; otherwise, commands issued from the CCTV driver may be rejected.

Ultrak MaxPro-1000 Parameters

The communications parameters are:

Baudrate	19200 or 9600
Data bits	7
Stop bits	1
Parity	Even
Timeout (ms)	500

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVUltrak**.

Supported CCTV Controls

The following dialog box displays some of the controls that are available for a Ultrak switch.



Supported CCTV Event Actions

The CCTV event actions that the CCTV feature supports for an Ultrak switch are:

Supported Actions

Switch Alarm Play Switch Alarm Stop Switch Auxiliary Play Switch Auxiliary Stop

Monitor Sequence Play Monitor Sequence Stop

Monitor Camera

Camera Preset

Supported OPCWrite Event Actions

Appendix E: CCTV Server Namespace Defi-

nitions displays a full list of the namespace tags that an OPC Client can interrogate. If you are using OPCWrite to create an event action, the following namespace tags are supported for the Ultrak switch:

Supported Tags
S%.AlarmPlay
S%.DateTime
M#.SequencePlay M#.SequenceStop
M#.Camera
C#.PresetRecord C#.PresetPlay
C#.Tilt C#.Pan
C#.Zoom C#.Focus C#.Iris
C#.Wiper C#.Washer

Auxiliaries

Ultrak switch and camera auxiliaries are mapped to system auxiliaries. The system auxiliaries are numbered and can be activated and deactivated using the CCTV driver.

Monitor Sequences

An Ultrak scan is a sequence of CCTV commands defined at the switch and activated for a particular monitor. Therefore, sequence 1 for example is the same set of commands for all monitors.

Auto Repeat Actions

The Ultrak protocol does not require the auto repeat functions.

See also Note 1 in Appendix E: CCTV Server Namespace Definitions.

Automatic Status Update Tags

The Ultrak protocol does not support periodic status updates. These tags display a U flag in Appendix E: CCTV Server Namespace Definitions.

Maximum and Default Values

Some items in the CCTV Server namespace have maximum and default values associated with them. The following table lists those applicable to Ultrak MaxPro-100.

The maximum values define the number of items that the protocol allows. The default value is the number of items generated in the namespace if the operator does not explicitly define the number from within the CCTV/AV Configuration window.

	Maximum Value	Default Value
SwitchAlarmMax	8192	64
SwitchMonitorMax	2048	32
SwitchCameraMax	9999	64
MonitorSequenceMax	1999 (per monitor)	8 (per monitor)
CameraPresetMax	99 (per camera)	8 (per camera)

Vicon®

This section describes the Vicon Switch protocol. The Vicon protocol enables an operator at a suitably configured P2000 workstation to control CCTV equipment connected to one of the following Vicon switches:

- VPS1300
- VPS1344
- V1422
- VPS1466

The CCTV feature should work with other Vicon switches, if they adhere to the same communications protocol. The only disparity with switches other than the supported Vicon switches is that they may support several cameras or monitors greater than the maximum permitted.

All basic camera and monitor selection and camera movement commands are supported.

The Vicon features supported are:

- Monitor and camera selection
- Camera pan and tilt with variable speed
- Camera zoom, focus, and iris control (up to three speeds dependent on the lens control setting)
- Camera lens speed control using auxiliary 7
- Camera auto iris on and off
- Camera auxiliaries on and off
- Camera preset recall and preset store
- Alarm point set and reset sent in response to P2000 event actions

Note: Alarm resets can be sent to the switch at a maximum rate of 10 per second.

 Run tour (no stop tour in protocol). Also indirectly supports Salvos via Salvo Tours.

The following commands in the Vicon protocol are not supported:

- Sequence programming commands
- Status reports (with the exception of Receiver Status used for Auto Iris On/Off)
- System Data Upload/Download
- Keypad commands
- Alarm processing commands (except Alarm Point Set/Reset)

Switch Configuration

The tour dialup numbers must be set at 800 plus the number. For example, tour 1 would have the tour number 801. Refer to the appropriate switch programming manual for details.

Vicon Parameters

The communications parameters are:

Baudrate	9600
Data bits	8
Stop bits	1
Parity	None
Timeout (ms)	500
Handshake	Hardware

The protocol name to select in the Edit CCTV Switch window is **JC.CCTVVicon13xx** for Vicon 1300 and 1344 switches or **JC.CCTVVicon14xx** for Vicon 1422 and 1466 series switches.

Supported CCTV Controls

The following dialog box displays some of the controls that are available for a Vicon switch.



Momentary and Latched Auxiliaries

The Vicon protocol supports up to six auxiliaries per camera. The auxiliaries can be either momentary or latched. The CCTV feature cannot differentiate between latched and momentary auxiliaries and they require different protocol messages to be sent to the switch. The following auxiliary numbers have been assigned:

- 1 to 6 for latched auxiliaries
- 8 to 13 for momentary auxiliaries

Camera Lens Speed Control

The Vicon protocol supports up to three camera speeds to operate zoom, focus, and iris controls. Speed control is activated by playing auxiliary 7. It operates as a toggle so that each time it is played the lens speed changes.

Supported CCTV Event Actions

The CCTV event actions that the CCTV feature supports for a Vicon switch are:

Supported Actions
Switch Alarm Play Switch Alarm Stop
Monitor Sequence Play Monitor Sequence Stop
Monitor Camera
Camera Preset
Camera Auxiliary Play Camera Auxiliary Stop

Supported OPCWrite Event Actions

Appendix E: CCTV Server Namespace Definitions displays a full list of the namespace tags that an OPC Client can interrogate. If you are using OPCWrite to create an event action, the following namespace tags are supported for a Vicon switch:

Supported Tags
S%.AlarmPlay S%.AlarmStop
S%.DateTime
M#.SequencePlay M#.SequenceStop
M#.Camera
C#.PresetRecord C#.PresetPlay
C#.AuxiliaryPlay C#.AuxiliaryStop
C#.Tilt C#.Pan
C#.Zoom C#.Focus C#.Iris

Auto Repeat Actions

The Vicon protocol does not support the auto repeat functions

Automatic Status Update Tags

The Vicon protocol does not support periodic status updates. These tags display a U flag in Appendix E: CCTV Server Namespace Definitions.

Maximum and Default Values

Some items in the CCTV Server namespace have maximum and default values associated with them. The following table lists those applicable to Vicon.

The maximum values define the number of items that the protocol allows. The default value is the number of items generated in the namespace if the operator does not explicitly define the number from within the CCTV/AV Configuration window.

	Maximum Value	Default Value
SwitchAlarmMax	9999	64
SwitchMonitorMax	999	32
SwitchCameraMax	9999	64
MonitorSequenceMax	9999 (per monitor)	8 (per monitor)
CameraAuxiliaryMax	13 (per camera)	13 (per camera)
CameraPresetMax	99 (per camera)	8 (per camera)

Appendix E: CCTV Server Namespace Definitions

his appendix describes the CCTV Server namespace tags. Note that the appendix lists all the possible tags; however, only a subset of namespace tags is available for each supported Switch Protocol. See Appendix D: CCTV Switch Protocols for information about the supported set of tags.

Flags

The following flags are used in the namespace tag tables.

Flags	Meaning
С	Configured Value (persistence required)
D	Decrements/Increments towards 0 until value becomes 0
R	Readable
U	The value is periodically scanned from the device and updated to reflect the value in the device. If the CCTV Switch protocol does not allow the scanning of this information, then the CCTV module updates the value after transmitting the command to the CCTV switch. If updated by the module the OPC status information for the data item should return UNCERTAIN rather than GOOD.
W	Writable
Z	Server immediately resets this value to '0,' after it processes the value written to it by a client.

Notes

1. If the command auto-repeats and the associated Flags are WZ, then Z is ignored. This note refers to all Exists tags except S%.Exists, M%.Exists, and C%.Exists. If a command has an associated Exists tag, then the changes to the value of the command tag are allowed or acted upon if the Exists flag shows that the command is supported by the protocol.

During CCTV Server run up all Exists tags are checked against the current CCTV Switch Protocol.

Configured Value	Value in Namespace
0	0
1	0 = if not supported by protocol
	1 = if supported by protocol
2	0 = if not supported
	1 = if supported by switch or protocol
	Exists tags are checked in the hierarchical order of the equipment, that is, Switch then protocol. Therefore, if a switch item is unsupported at switch level, then the associated Exists tag is not supported.

3. Except for S%.Description, if the description has been defined in the CCTV/AV Configuration window, this tag has the same value. Otherwise, it uses the namespace name (prefix followed by its number, for example M0002, Pa0005).

Namespace Tags

Switch Namespace Tags

Tag Name	Data Type	Flags	Description
S%.Exists	Integer	CR	Only present if a configuration database exists. The parameter is set in the database to establish that this switch exists. 0 = does not exist 1 = exists
S%.Description	String	CR	Name as defined in CCTV/AV Configuration or S%
S%.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
S%.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)
S%.Туре	Integer	CR	1 = SERIAL 2 = TCP/IP (not supported)
S%.Port	String	CR	Name of serial port that this is connected to Needs to contain the text COM Changes are only allowed if the port type is serial. See the following tag S%.baudrate
S%.Baudrate	Integer	CR	Baud is one of the following values: 115200 57600 38400 19200 14400 9600 4800 2400 1200
S%.DataBits	Integer	CR	Word size is one of the following values: 7 8
S%.Parity	Integer	CR	Parity is one of the following values: 0 = None 1 = ODD 2 = EVEN
S%.StopBits	Integer	CR	Stop Bits are one of the following values: 0 1 2
S%.IPAddress	String	CR	IP address of network connected interfaces; this field might either hold a TCP/IP address or a computer name.
S%.Error	Integer	R	Error indicator used by the CCTV Server to indicate communication problems
S%.CCTVProtocolType	String	CR	Switch Protocol is one of the following: JC.CCTVPelco9760 JC.CCTVAmericanDynamics JC.CCTVGeneralASCII Other protocols may be added to this list.

Tag Name	Data Type	Flags	Description
S%.MonitorCount	Integer	CR	Number of monitors configured
S%.MonitorMax	Integer	CR	Number of monitors to be created in the namespace for this switch -1 = use protocol default during run up
S%.CameraCount	Integer	CR	Number of cameras configured
S%.CameraMax	Integer	CR	Number of cameras to be created in the namespace for this switch -1 = use protocol default during run up
S%.TourExists	Integer	CR	Identifies whether the switch supports tours See Note 2.
S%.TourCount	Integer	CR	Number of tours configured
S%.TourMax	Integer	CR	Number of tours to be created in the namespace for this switch -1 = use protocol default during run up
S%.TourPlayExists	Integer	CR	Identifies whether tours can be played
			See Note 2.
S%.TourPlay	Integer	WZ	Number of the tour to start. System starts to play all recorded actions for this tour 0 = new tour start pending >0 = start of tour # pending
S%.TourRecordExists	Integer	CR	Identifies whether tours can be recorded
			See Note 2.
S%.TourRecord	Integer	WZ	Number of the tour to be recorded. It must be non -negative and within range for protocol 0 = new tour record pending >0 = record tour # pending
S%.TourStopExists	Integer	CR	Identifies whether tours can be stopped
			See Note 2.
S%.TourStop	Integer	WZ	Number of the tour to be stopped. It must be non -negative and within range for protocol 0 = new tour stop pending >0 = stop tour # pending
S%.TourPauseExists	Integer	CR	Identifies whether tours can be paused
			See Note 2.
S%.TourPause	Integer	WZ	A non-zero value pauses the tour It must be non-negative and within range for protocol
S%.TourCameraSwitchForwardExis ts	Integer	CR	See Note 2.
S%.TourCameraSwitchForward	Integer	WZ	
S%.TourCameraSwitchBackwardExi sts	Integer	CR	See Note 2.
S%.TourCameraSwitchBackward	Integer	WZ	
S%.TourForwardExists	Integer	CR	See Note 2.
S%.TourForward	Integer	WZ	

Tag Name	Data Type	Flags	Description
S%.TourBackwardExists	Integer	CR	See Note 2.
S%.TourBackward	Integer	WZ	
S%.TourRestartExists	Integer	CR	See Note 2.
S%.TourRestart	Integer	WZ	Use protocol default during run up 0 = no action >0 = restart tour #
S%.TourStepForwardExists	Integer	CR	See Note 2.
S%.TourStepForward	Integer	WZ	
S%.TourStepBackwardExists	Integer	CR	See Note 2.
S%.TourStepBackward	Integer	WZ	
S%.MacroExists	Integer	CR	See Note 2.
S%.MacroCount	Integer	CR	
S%.MacroMax	Integer	CR	0 = not supported -1 = use protocol default during run up
S%.MacroPlayExists	Integer	CR	See Note 2.
S%.MacroPlay	Integer	WZ	
S%.MacroRecordExists	Integer	CR	See Note 2.
S%.MacroRecord	Integer	WZ	
S%.MacroRestartExists	Integer	CR	See Note 2.
S%.MacroRestart	Integer	WZ	
S%.MacroStopExists	Integer	CR	See Note 2.
S%.MacroStop	Integer	WZ	
S%.MacroPauseExists	Integer	CR	See Note 2.
S%.MacroPause	Integer	WZ	
S%.AlarmExists	Integer	CR	See Note 2.
S%.AlarmCount	Integer	CR	
S%.AlarmMax	Integer	CR	0 = not supported -1 = check with protocol during run up
S%.AlarmPlayExists	Integer	CR	See Note 2.
S%.AlarmPlay	Integer	WZ	Sets the alarm 0 = new alarm start pending >0 = start alarm # pending <integer></integer>
S%.AlarmStopExists	Integer	CR	See Note 2.
S%.AlarmStop	Integer	WZ	Clears the alarm 0 = new alarm stop pending >0 = stop alarm # pending
S%.AuxiliaryExists	Integer	CR	See Note 2.
S%.AuxiliaryCount	Integer	CR	
S%.AuxiliaryMax	Integer	CR	0 = not supported -1 = use protocol default during run up

Tag Name	Data Type	Flags	Description
S%.AuxiliaryPlayExists	Integer	CR	See Note 2.
S%.AuxiliaryPlay	Integer	WZ	Sets the auxiliary 0 = new auxiliary start pending >0 = start auxiliary # pending
S%.AuxiliaryStopExists	Integer	CR	See Note 2.
S%.AuxiliaryStop	Integer	WZ	Clears the auxiliary 0 = new auxiliary stop pending >0 = stop auxiliary # pending <integer></integer>
S%.DateTime	Integer	WZ	Sends date and time to the switch if applicable 0 = no action 1 = download time to switch
S%.AlarmClearAll	Integer	WZ	0 = no action 1 = clear all alarms
S%.Login	Integer	RWZ	0 = no action 1 = log on
S%.Logoff	Integer	RWZ	0 = no action 1 = log off
S%.LoginState	Integer	RW	0 = no action 1 = check whether logged onto the system
S%.MimicSwitch	Integer	WZ	Mimic a video switch
S%.TestPort	Integer	WZ	0 = no action 1 = test the validity of the port connected to the switch Watchdogs not implemented.
S%.CheckPIN	Integer	WZ	0 = no action 1 = check PIN for equipment or operator
S%.ErrorSend	Integer	WZ	Send error message
S%.FatalErrorSend	Integer	WZ	Send fatal error message
S%.Special	Integer	WZ	Request a special feature
S%.Priority	Integer	CR	Priority number of the device on the CCTV bus used to control a specific camera
S%.GeneralString	String	WZ	This sends the string from the port without any protocol adjustments. No reply is expected. When sent, the string is cleared from the namespace.
S%.CameraInfoUpdate S%.MonitorInfoUpdate S%.AlarmInfoUpdate S%.CameraNumberInfoUpdate S%.TimeDateInfoUpdate S%.SpecialMessageInfoUpdate	Integer	WZ	These commands receive an information update for the equipment associated with the switch. 0 = no action 1 = request info for all items in the group
S%.CameraAttributeUpdate S%.MonitorAttributeUpdate S%.AlarmAttributeUpdate S%.CameraNumberAttributeUpdate S%.TimeDateAttributeUpdate S%.SpecialMessageAttributeUpdate	Integer	WZ	These commands request an attribute update for the equipment associated with the switch. 0 = no action 1 = request info for all attributes for items in the group

Tag Name	Data Type	Flags	Description
S%.SequenceExists S%.SequencePlayExists S%.SequenceRecordExists S%.SequenceStopExists S%.SequencePauseExists S%.SequenceCameraSwitchForwar dExists S%.SequenceCameraSwitchBackw ardExists S%.SequenceCameraSwitchBackw ardExists S%.SequenceStepForwardExists S%.SequenceStepBackwardExists S%.PresetExists S%.PresetExists S%.PresetPlayExists S%.PresetPlayExists S%.CameraAuxiliaryExists S%.CameraAuxiliaryExists S%.CameraAuxiliaryExists S%.CameraAuxiliaryExists S%.PatternPlayExists S%.PatternPlayExists S%.PatternPlayExists S%.PatternStopExists S%.PatternRecordExists S%.PatternRestartExists S%.PatternRestartExists S%.PatternStepForwardExists S%.PatternStepForwardExists S%.PatternStepBackwardExists	Integer	CR	See Note 2.
S%.SequenceMax S%.PresetMax S%.CameraAuxiliaryMax S%.PatternMax	Integer	CR	0 = not supported -1 = use protocol default during run up

Monitor Namespace Tags

Tag Name	Data Type	Flags	Description
M#.Exists	Integer	CR	Only present if a configuration database exists. 0 = no action 1 = check that this monitor exists.
M#.Description	String	CR	See Note 3.
M#.ClientLockID	String	WR	This is a 32 character string
M#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
M#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)
M#.GeneralString	String	CWR	Up to 50 characters that are forwarded to display at the monitor.
M#.MonStatus	Integer	WRU	Bit flagged field to define the equipment status. The status field is only to be used for those status identifications that are NOT part of the original item list.
M#.GetSelected	Integer	WZ	Gets information on current assignment. Receives the current macro, auxiliary, camera and whether the macro has stopped, camera is locked or controllable, an alarm is armed or tripped and video loss is detected. Use protocol default during run up 0 = no action 1 = perform command
M#.VideoLossMask	Integer	WR	Activate/deactivate the video fail circuit. Use protocol default during run up 0 = unknown 1 = deactivated 2 = activated
M#.Salvo	Integer	WZ	Calls up a group of cameras 0 = no action 1 >= Calls up the numbered group of cameras
M#.SequenceExists	Integer	CR	Defines whether the monitor supports sequences See Note 2.
M#.SequenceCount	Integer	CR	Defines the number of sequences in the configuration database
M#.SequenceMax	Integer	CR	Defines the maximum number of sequences 0 = not supported -1 = use protocol default during run up
M#.SequencePlayExists	Integer	CR	See Note 2.
M#.SequencePlay	Integer	WR	Forces monitor to execute camera tour sequence
M#.SequenceRecordExists	Integer	CR	See Note 2.
M#.SequenceRecord	Integer	WZ	Forces monitor to record camera tour sequence
M#.SequenceStopExists	Integer	CR	See Note 2.
M#.SequenceStop	Integer	WZ	0 = no action 1 = stop the defined tour
M#.SequencePauseExists	Integer	CR	See Note 2.
M#.SequencePause	Integer	WZ	

Tag Name	Data Type	Flags	Description
M#.SequenceCameraSwitchForwar dExists	Integer	CR	See Note 2.
M#.SequenceCameraSwitchForwar d	Integer	WRD	
M#.SequenceCameraSwitchBackwa rdExists	Integer	CR	See Note 2.
M#.SequenceCameraSwitchBackwa rd	Integer	WZ	
M#.SequenceForwardExits	Integer	CR	See Note 2.
M#.SequenceForward	Integer	WZ	
M#.SequenceBackwardExists	Integer	CR	See Note 2.
M#.SequenceBackward	Integer	WZ	
M#.SequenceRestartExists	Integer	CR	See Note 2.
M#.SequenceRestart	Integer	WZ	Check that protocol supports this command 0 = no action 1 = restart
M#.SequenceStepForwardExists	Integer	CR	See Note 2.
M#.SequenceStepForward	Integer	WZ	
M#.SequenceStepBackwardExists	Integer	CR	See Note 2.
M#.SequenceStepBackward	Integer	WZ	
M#.Camera	Integer	WR	The number of the camera that is to be assigned to this monitor
M#.CameraSwitch	Integer	WRZ	Switch to a next/previous logical camera accessible < 0 previous logical camera > 0 next logical camera

Camera Namespace Tags

Tag Name	Data Type	Flags	Description
C#.Exists	Integer	CR	Only present if a configuration database exists. The parameter is set in the database by the CCTV configuration to show that this camera exists. 0 = no action 1 = check that this camera exists
C#.Description	String	CR	See Note 3.
C#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
C#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)
C#.ClientLockId	String	WR	32 character string. Can be used by a client to lock access to this camera
C#.GeneralString	String	CWR	A string of characters (50 characters maximum) that is written to the specific camera to display all that is being recorded or monitored from it
C#.CamStatus	Integer	WRU	Bit flagged field to define the equipment status. The status flags are to be defined at a later stage. The status field is only to be used for those status identifications that are <u>not</u> part of the original item list
C#.PresetExists	Integer	CR	If configuration database exists, this defines if this camera has this ability See Note 2.
C#.PresestCount	Integer	CR	
C#.PresetMax	Integer	CR	If the camera supports presets, this is the value of the maximum number of presets. Presets are numbered from 1 to (PresetMax)
C#.PresetStopExists	Integer	CR	See Note 2.
C#.PresetStop	Integer	WZ	Clears the preset <integer> 0 = no action 1 >= number of the preset to clear</integer>
C#.PresetRecordExists	Integer	CR	See Note 2.
C#.PresetRecord	Integer	WZ	Defines the current camera position as preset <integer></integer>
C#.PresetPlayExists	Integer	CR	See Note 2.
C#.PresetPlay	Integer	WR	Forces camera to pre-specified position
C#.TiltExists	Integer	CR	See Note 2.
C#.Tilt	Signed Integer	WR	Moves camera vertically with given speed 0 = stop -100 to +100 = % of protocol's maximum capability
C# PanExists	Integer	CR	See Note 2
	integer	5.	

Tag Name	Data Type	Flags	Description
C#.Pan	Signed Integer	WR	Moves camera with this speed 0 = stop -100 to +100 = % of protocol's maximum capability See Note 1.
C#.StopAllPT	Integer	WZ	Stops all Pan and Tilt commands that have not yet been issued 0 = no action 1 = stop all pan and tilt commands
C#.ZoomExists	Integer	CR	See Note 2.
C#.Zoom	Integer	WR	Controls the camera zoom 0 = stop zoom 1 = zoom wide -1 = zoom narrow See Note 1.
C#.FocusExists	Integer	CR	If configuration database exists, this defines if this camera has this ability See Note 2.
C#.Focus	Integer	WR	Controls the camera focus 0 = stop focus 1 = focus near -1 = focus far See Note 1
C#.IrisExists	Integer	CR	See Note 2.
C#.IrisAutomatic	Integer	CWR	Controls the camera iris 0 = iris not automatic 1 = iris automatic
C#.Iris	Integer	WR	Controls the camera iris 0 = stops iris 1 = drives iris open -1 = drives iris closed See Note 1.
C#.StopAllZFI	Integer	WZ	Write 1 to this property to stop all Zoom, Iris and Focus commands 0 = no action 1 = stops all Zoom, Iris and Focus commands
C#.LensSpeedMax	Integer	CR	The maximum speed of the lens 1 = fixed speed lens 1 > maximum speed of the lens
C#.LensSpeed	Integer	CWR	Number which is the lens speed See Lens speed max
C#.Arm	Integer	WZ	Arms the camera 0 = no action 1 = arms the camera
C#.Disarm	Integer	WZ	Disarms the camera 0 = no action 1 = disarms the camera

Tag Name	Data Type	Flags	Description
C#.lsArmed	Integer	RWU	Checks whether the camera is armed 0 = no action 1 = check whether the camera is armed
C#.StatusExists	Integer	CR	See Note 2.
C#.WiperExists	Integer	CR	See Note 2.
C#.Wiper	Integer	WR	Turns wipers on or off 0 = turns the wipers off 1 = turns the wipers on
C#.WasherExists	Integer	CR	See Note 2.
C#.Washer	Integer	WR	Activate washers 0 = turns the washers off 1 = turns the washers on
C#.LightExists	Integer	CR	See Note 2.
C#.Light	Integer	WR	Turns lights on or off 0 = turns the lights off 1 = turns the lights on
C#.AuxiliaryExists	Integer	CR	See Note 2.
C#.AuxiliaryCount	Integer	CR	
C#.AuxiliaryMax	Integer	CR	-1 = use protocol default during run up
C#.AuxiliaryPlayExists	Integer	CR	See Note 2.
C#.AuxiliaryPlay	Integer	WZ	Sets the auxiliary <integer></integer>
C#.AuxiliaryStopExists	Integer	CR	See Note 2.
C#.AuxiliaryStop	Integer	WZ	Clears the auxiliary <integer></integer>
C#.PatternExists	Integer	CR	Defines whether the camera supports patterns
			See Note 2.
C#.PatternCount	Integer	CR	Defines the number of Patterns in the configuration database
C#.PatternMax	Integer	CR	Defines the maximum number of patterns -1 = check with switch 0 = not supported
C#.PatternPlayExists	Integer	CR	See Note 2.
C#.PatternPlay	Integer	WR	Executes a pattern for a camera
C#.PatternRecordExists	Integer	CR	See Note 2.
C#.PatternRecord	Integer	WZ	Records a pattern for a camera
C#.PatternStopExists	Integer	CR	See Note 2.
C#.PatternStop	Integer	WZ	Stops the defined tour 0 = no action 1 = stop tour
C#.PatternPauseExists	Integer	CR	See Note 2.
C#.PatternPause	Integer	WZ	
C#.PatternForwardExists	Integer	CR	See Note 2.
C#.PatternForward	Integer	WZ	Check that protocol supports this command

Tag Name	Data Type	Flags	Description
C#.PatternBackwardExists	Integer	CR	See Note 2.
C#.PatternBackward	Integer	WZ	
C#.PatternRestartExists	Integer	CR	See Note 2.
C#.PatternRestart	Integer	WZ	0 = done 1 = restart Zero
C#.PatternStepForwardExists	Integer	CR	See Note 2.
C#.SequenceStepForward	Integer	WZ	Check that protocol supports this command
C#.PatternStepBackwardExists	Integer	CR	See Note 2.
C#.PatternStepBackward	Integer	WZ	

Macro Namespace Tags

Tag Name	Data Type	Flags	Description
Ma#.Description	String	CR	See Note 3.
Ma#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
Ma#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)

Auxiliary Namespace Tags

Tag Name	Data Type	Flags	Description
Au#.Description	String	CR	See Note 3.
Au#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
Au#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)
Au#.Closed	Integer	WRU	Shows whether a relay is closed 1 = closed 0 = open

Tour Namespace Tags

Tag Name	Data Type	Flags	Description
T#.Description	String	CR	See Note 3.
T#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
T#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)

Alarm Namespace Tags

Tag Name	Data Type	Flags	Description
Al#.Description	String	CR	See Note 3.
Al#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
Al#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)

Sequence Namespace Tags

Tag Name	Data Type	Flags	Description
Se#.Description	String	CR	See Note 3.
Se#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
Se#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)

Pattern Namespace Tags

Tag Name	Data Type	Flags	Description
Pa#.Description	String	CR	See Note 3.
Pa#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
Pa#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)

Preset Namespace Tags

Tag Name	Data Type	Flags	Description
Pr#.Description	String	CR	See Note 3.
Pr#.Partition	Integer	CR	Reserved for database partitioning > 0 Partition ID (default = 1)
Pr#.Public	Integer	CR	Reserved for database partitioning 0 = not public 1 = public (default)

Appendix F: DCOM Configuration

hen you install the P2000 software and the CCTV application on a computer, the installation process makes changes to the Distributed Component Object Model (DCOM) settings to allow communication between P2000 event actions and the CCTV Server, and between the CCTV Client and the CCTV Server; and possibly other installed options on the network.

Before you install the software, be aware of the changes that the process makes to avoid conflicts of interest with other software installed on the computer. Note that the P2000 software and the CCTV application do not operate correctly if the changes made during installation are subsequently changed.

DCOM Installation

The changes made to the computer are dependent on whether the installation is a P2000 Server, a CCTV Server, or a CCTV Client installation, and the Windows operating system.

The following table shows the changes that the process makes. Note that when you install more than one option, you should combine the appropriate columns to indicate the overall changes.

Change Made to		P2000 Server	P2000 Client
Operating System	Create PegasysServices user account as Administrator	~	
DCOM	Activate DCOM	>	
	Grant DCOM access rights to PegasysServices user account	>	
Registry	Add Program ID for JC.CCTV, JC.CCTV.2 and subsections	>	
	Add Registry settings for CCTV Selection	~	•

590 APPENDIX F DCOM Configuration

Appendix G: Using a Keypad Reader on CK7xx Panels

he following sections describe how to invoke access requests, Air Crew access requests, Timed Overrides, and Panel Card Events using a keypad reader on CK721-A, CK721, CK720, and CK705 panels.

Note: For information on using keypad readers that connect to other panel types, refer to the instructions provided with those panels.

There is a 15 second time-out on all keypads. Whenever the keypad is idle for more than 15 seconds, all keys entered so far are ignored, and the entire key sequence needs to be re-entered.

Note: Card ID (the badge number) can have up to 19 digits. However, the total number of keys pressed for PIN and Card ID combined must not exceed 21.

Invoking Access Requests from a Keypad

To invoke access with a Badge:

- To invoke access using a badge at any time, set the terminal **PIN Suppression** in the Timezone tab to **<none>**. Otherwise, access is granted only during active time zones.
- 2. At the keypad reader, present the badge.

To invoke access with PIN Only:

- 1. Select the terminal **PIN Only** option in the Card Type tab. **PIN Only** works exclusively with 5-digit algorithmic PINs.
- 2. Set the panel **PIN Code Type** to **Algorithmic**.
- 3. Set the panel PIN Code Digits to 5.
- 4. At the keypad reader, enter the PIN, and press the # key.

To invoke access with Card ID:

- To invoke access with Card ID at any time, set the terminal **PIN Suppression** in the Timezone tab to <none>. Otherwise, access is granted only during active time zones.
- 2. Select the terminal **Card ID** option in the Card Type tab.
- 3. Verify that the terminal **PIN Only** option in the Card Type tab is <u>not</u> selected.
- 4. Verify that the terminal **PIN + Card ID** option in the Card Type tab is <u>not</u> selected.
- 5. At the keypad reader, enter the Card ID number and press the # key.

To invoke access with PIN and Card ID:

- 1. Select the terminal **PIN** + **Card ID** option in the Card Type tab.
- 2. Verify that the terminal **PIN Only** option in the Card Type tab is <u>not</u> selected.
- 3. At the keypad reader, enter the PIN, then enter the Card ID number, and press the # key.

To invoke access using PIN and Badge:

- 1. Set the terminal **PIN Suppression** in the Timezone tab to an inactive time zone.
- 2. Verify that the terminal **Allow PIN After Badge** option in the Flags tab is <u>not</u> selected.
- 3. At the keypad reader, enter the PIN and then present the badge.

To invoke access with PIN and Badge, allowing PIN after Badge:

- 1. Set the terminal **PIN Suppression** in the Timezone tab to an inactive time zone.
- 2. Select the terminal Allow PIN After **Badge** option in the Flags tab.
- 3. At the keypad reader, present the badge, enter the PIN, and press the # key. You may present the badge at any time before pressing the # key.

Invoking Air Crew Access Requests from a Keypad

To invoke Air Crew access:

- 1. The Server must be online.
- 2. Enable the respective **Air Crew PIN** for the terminal.
- 3. To request Air Crew access:

Without the Star Feature, press the B key followed by the Air Crew PIN number and the # key.

With the Star Feature, press the star (*) key, then press number 2, followed by the Air Crew PIN number and the # key.

Invoking Timed Overrides from a Keypad

To invoke Timed Override with Badge:

- 1. Select the terminal Cardholder Override/Shunt option in the Access tab.
- 2. Set the badge **Override** option in the Security Options tab.
- To invoke Timed Override using badge at any time, set the terminal PIN Suppression in the Timezone tab to <none>. Otherwise, Timed Override is invoked only during active time zones.
- 4. To start Timed Override:

Without the Star Feature, press the star (*) key, enter the number of minutes, and present the badge.

With the Star Feature, press the star (*) key followed by number 0, enter the number of minutes, and present the badge.

5. To stop Timed Override:

Without the Star Feature, press the star (*) key, enter 0 (for minutes), and present the badge.

With the Star Feature, press the star (*) key followed by number 0 and present the badge.

To invoke Timed Override with PIN Only:

- 1. Select the terminal Cardholder Override/Shunt option in the Access tab.
- 2. Set the badge **Override** option in the Security Options tab.
- 3. Select the terminal **PIN Only** option in the Card Type tab. **PIN Only** works exclusively with 5-digit algorithmic PINs.
24-10685-157 Rev. D

- 4. Set the panel **PIN Code Type** to **Algorithmic**.
- 5. Set the panel **PIN Code Digits** to **5**.
- 6. To start Timed Override:

Without the Star Feature, enter the PIN, press the star (*) key, enter the number of minutes, and press the # key.

With the Star Feature, enter the PIN, press the star (*) key followed by number 0, enter the number of minutes, and press the # key.

7. To stop Timed Override:

Without the Star Feature, enter the PIN, press the star (*) key, enter 0 (for minutes), and press the # key.

With the Star Feature, enter the PIN, press the star (*) key followed by number 0, and press the # key.

To invoke Timed Override with Card ID:

- 1. Select the terminal Cardholder Override/Shunt option in the Access tab.
- 2. Set the badge **Override** option in the Security Options tab.
- To invoke Timed Override using badge at any time, set the terminal PIN Suppression in the Timezone tab to <none>. Otherwise, Timed Override is invoked only during active time zones.
- 4. Select the terminal **Card ID** option in the Card Type tab.
- 5. Verify that the terminal **PIN Only** option in the Card Type tab is <u>not</u> selected.
- Verify that the terminal PIN + Card ID option in the Card Type tab is <u>not</u> selected.

7. To start Timed Override:

Without the Star Feature, enter the Card ID number, press the star (*) key, enter the number of minutes, and press the # key.

With the Star Feature, enter the Card ID number, press the star (*) key followed by number 0, enter the number of minutes, and press the # key.

8. To stop Timed Override:

Without the Star Feature, enter the Card ID number, press the star (*) key, enter 0 (for minutes), and press the # key.

With the Star Feature, enter the Card ID number, press the star (*) key followed by number 0, and press the # key.

To invoke Timed Override with PIN and Card ID:

- 1. Select the terminal Cardholder Override/Shunt option in the Access tab.
- 2. Set the badge **Override** option in the Security Options tab.
- 3. Select the terminal **PIN + Card ID** option in the Card Type tab.
- 4. Verify that the terminal **PIN Only** option in the Card Type tab is <u>not</u> selected.
- 5. To start Timed Override:

Without the Star Feature, enter the PIN, enter the Card ID number, press the star (*) key, enter the number of minutes, and press the # key.

With the Star Feature, enter the PIN, enter the Card ID number, press the star (*) key followed by number 0, enter the number of minutes, and press the # key. 6. To stop Timed Override:

Without the Star Feature, enter the PIN, enter the Card ID number, press the star (*) key, enter 0 (for minutes), and press the # key.

With the Star Feature, enter the PIN, enter the Card ID number, press the star (*) key followed by number 0, and press the # key.

To invoke Timed Override with PIN and Badge:

- 1. Select the terminal Cardholder Override/Shunt option in the Access tab.
- Set the badge Override option in the Security Options tab.
- 3. Set the terminal **PIN Suppression** in the Timezone tab to an inactive time zone.
- 4. Verify that the terminal **Allow PIN After Badge** option in the Flags tab is <u>not</u> selected.
- 5. To start Timed Override:

Without the Star Feature, enter the PIN, press the star (*) key, enter the number of minutes, and present the badge.

With the Star Feature, enter the PIN, press the star (*) key followed by number 0, enter the number of minutes, and present the badge.

6. To stop Timed Override:

Without the Star Feature, enter the PIN, press the star (*) key, enter 0 (for minutes), and present the badge.

With the Star Feature, enter the PIN, press the star (*) key followed by number 0, and present the badge.

To invoke Timed Override with PIN and Badge, allowing PIN after badge:

- 1. Select the terminal Cardholder Override/Shunt option in the Access tab.
- 2. Set the badge **Override** option in the Security Options tab.
- 3. Set the terminal **PIN Suppression** in the Timezone tab to an inactive time zone.
- 4. Select the terminal Allow PIN After Badge option in the Flags tab.
- 5. To start Timed Override:

Without the Star Feature, enter the PIN, press the star (*) key, enter number of minutes, present the badge¹, and press the # key.

With the Star Feature, enter the PIN, press the star (*) key followed by number 0, enter the number of minutes, present the badge¹, and press the # key.

6. To stop Timed Override:

Without the Star Feature, enter the PIN, press the star (*) key, enter 0 minutes, present the badge¹, and press the # key.

With the Star Feature, enter the PIN, press the star (*) key followed by number 0, present the badge¹, and press the # key.

¹) You may present the badge at any time before pressing the # key.

Invoking Panel Card Events from a Keypad

Note: When invoking panel card events using CK705 or CK720 panels Version 2.2, use the keypad sequence of the star (*) key followed by number 2.

To invoke Panel Card Events with Badge:

- 1. Set the panel card event **Trigger Type** to **Card/Keypad Code.**
- To invoke a Panel Card Event using a badge at any time, set the terminal PIN Suppression in the Timezone tab to <none>. Otherwise, the Panel Card Event is invoked only during active time zones.
- 3. To activate the event:

Without the Star Feature, press A, enter the keypad code, and present the badge.

With the Star Feature, press the star (*) key followed by number 1, enter the keypad code, and present the badge.

4. To deactivate the event:

Without the Star Feature, press D, enter the keypad code, and present the badge.

With the Star Feature, press the star (*) key followed by number 4, enter the keypad code, and present the badge.

To invoke Panel Card Events with PIN Only:

1. Set the panel card event **Trigger Type** to **Card/Keypad Code** or **Card/PIN/Keypad Code**.

- 2. If set to **Card/PIN/Keypad Code**, set the terminal **PIN Suppression** in the Time-zone tab to an inactive time zone.
- 3. Select the terminal **PIN Only** option in the Card Type tab. **PIN Only** works exclusively with 5-digit algorithmic PINs.
- 4. Set the panel **PIN Code Type** to **Algorithmic**.
- 5. Set the panel **PIN Code Digits** to **5**.
- 6. To activate the event:

Without the Star Feature, enter the PIN, press A, enter the keypad code, and press the # key.

With the Star Feature, enter the PIN, press the star (*) key followed by number 1, enter the keypad code, and press the # key.

7. To deactivate the event:

Without the Star Feature, enter the PIN, press D, enter the keypad code, and press the # key.

With the Star Feature, enter the PIN, press the star (*) key followed by number 4, enter the keypad code, and press the # key.

To invoke Panel Card Events with Card ID:

- 1. Set the panel card event **Trigger Type** to **Card/Keypad Code**.
- To invoke a Panel Card Event using Card ID at any time, set the terminal PIN Suppression in the Timezone tab to <none>. Otherwise, the Panel Card Event is invoked only during active time zones.
- 3. Set the terminal **Card ID** option in the Card Type tab.
- 4. Verify that the terminal **PIN Only** option in the Card Type tab is <u>not</u> selected.
- 5. Verify that the terminal **PIN + Card ID** option in the Card Type tab is <u>not</u> selected.

6. To activate the event:

Without the Star Feature, enter the Card ID number, press A, enter the keypad code, and press the # key.

With the Star Feature, enter the Card ID number, press the star (*) key followed by number 1, enter the keypad code, and press the # key.

7. To deactivate the event:

Without the Star Feature, enter the Card ID number, press D, enter the keypad code, and press the # key.

With the Star Feature, enter the Card ID number, press the star (*) key followed by number 4, enter the keypad code, and press the # key.

To invoke Panel Card Events with PIN and Card ID:

- 1. Set the panel card event **Trigger Type** to **Card/Keypad Code** or **Card/PIN/Keypad Code**.
- 2. If set to **Card/PIN/Keypad Code**, set the terminal **PIN Suppression** in the Timezone tab to an inactive time zone.
- 3. Select the terminal **PIN + Card ID** option in the Card Type tab.
- 4. Verify that the terminal **PIN Only** option in the Card Type tab is <u>not</u> selected.
- 5. To activate the event:

Without the Star Feature, enter the PIN, enter the Card ID number, press A, enter the keypad code, and press the # key.

With the Star Feature, enter the PIN, enter the Card ID number, press the star (*) key followed by number 1, enter the keypad code, and press the # key. 6. To deactivate the event:

Without the Star Feature, enter the PIN, enter the Card ID number, press D, enter the keypad code, and press the # key.

With the Star Feature, enter the PIN, enter the Card ID number, press the star (*) key followed by number 4, enter the keypad code, and press the # key.

To invoke Panel Card Events with PIN and Badge:

- 1. Set the panel card event **Trigger Type** to **Card/Keypad Code** or **Card/PIN/Keypad Code**.
- 2. Set the terminal **PIN Suppression** in the Timezone tab to an inactive time zone.
- 3. Verify that the terminal **Allow PIN After Badge** option in the Flags tab is <u>not</u> selected.
- 4. To activate the event:

Without the Star Feature, enter the PIN, press A, enter the keypad code, and present the badge.

With the Star Feature, enter the PIN, press the star (*) key followed by number 1, enter the keypad code, and present the badge.

5. To deactivate the event:

Without the Star Feature, enter the PIN, press D, enter the keypad code, and present the badge.

With the Star Feature, enter the PIN, press the star (*) key followed by number 4, enter the keypad code, and present the badge.

To invoke Panel Card Events with PIN and Badge, allowing PIN after badge:

- 1. Set the panel card event **Trigger Type** to **Card/Keypad Code** or **Card/PIN/Keypad Code**.
- 2. Set the terminal **PIN Suppression** in the Timezone tab to an inactive time zone.
- 3. Select the terminal Allow PIN After **Badge** option in the Flags tab.
- 4. To activate the event:

Without the Star Feature, enter the PIN, press A, enter the keypad code, present the badge¹, and press the # key.

With the Star Feature, enter the PIN, press the star (*) key followed by number 1, enter the keypad code, present the badge¹, and press the # key.

5. To deactivate the event:

Without the Star Feature, enter the PIN, press D, enter the keypad code, present the badge¹, and press the # key.

With the Star Feature, enter the PIN, press the star (*) key followed by number 4, enter the keypad code, present the badge¹, and press the # key.

¹) You may present the badge at any time before pressing the # key.

Quick Guide to Using Keypad Readers

Use the following quick guide to determine the key sequence at a keypad reader required for a particular action. This section assumes that you have configured all terminal and panel settings for this action.

Note: Use the terminal Star Feature if you want to invoke Panel Card Events on a keypad that does not have the A and D keys.

Legend						
Keypad Code	Enter the Keypad Code.	badge	Present the badge.			
PIN Card ID Minutes	Enter the PIN number. Enter the Card ID number. Enter the number of minutes.	* 0 1 # A D	Press the specified key.			

Invoking Access Requests from a Keypad				
With Badge				
To request access: badge				
With PIN Only				
To request access: PIN #				
With Card ID				
To request access: Card ID #				
With PIN and Card ID				
To request access: PIN Card ID #				
With PIN and Badge				
To request access: PIN badge				
With PIN and Badge, allowing PIN after Badge				
To request access: PIN badge ¹ #				
¹) You may present the badge at any time before pressing the # key, that is, before, during or after you enter the PIN.				
Invoking Air Crew Access Requests from a Keypad				

To request access without Star Feature:	В	Air Crew PIN #
To request access with Star Feature:	* 2	Air Crew PIN #

Invoking Timed Overrides from a Keypad

With Badge

To start override without Star Feature: To stop override without Star Feature: To start override with Star Feature: To stop override with Star Feature:

With PIN Only

To start override without Star Feature: To stop override without Star Feature: To start override with Star Feature: To stop override with Star Feature:

With Card ID

To start override without Star Feature: To stop override without Star Feature: To start override with Star Feature: To stop override with Star Feature:

With PIN and Card ID

To start override without Star Feature: To stop override without Star Feature: To start override with Star Feature: To stop override with Star Feature:

With PIN and Badge

To start override without Star Feature: To stop override without Star Feature: To start override with Star Feature:

To stop override with Star Feature:



To start override without Star Feature:

To stop override without Star Feature:

To start override with Star Feature:

To stop override with Star Feature:



¹) You may present the badge at any time before pressing the # key, that is, before, during or after you enter the PIN and the Timed Override sequence.

Invoking Panel (Card Events from a Keypad			
With Badge				
To activate event without Star Feature:	A Keypad Code badge			
To deactivate event without Star Feature:	D Keypad Code badge			
To activate event with Star Feature:	* 1 Keypad Code badge			
To deactivate event with Star Feature:	* 4 Keypad Code badge			
With PIN Only				
To activate event without Star Feature:	PIN A Keypad Code #			
To deactivate event without Star Feature:	PIN D Keypad Code #			
To activate event with Star Feature:	PIN * 1 Keypad Code #			
To deactivate event with Star Feature:	PIN * 4 Keypad Code #			
With Card ID				
To activate event without Star Feature:	Card ID A Keypad Code #			
To deactivate event without Star Feature:	Card ID D Keypad Code #			
To activate event with Star Feature:	Card ID * 1 Keypad Code #			
To deactivate event with Star Feature:	Card ID * 4 Keypad Code #			
With PIN and Card ID				
To activate event without Star Feature:	PIN Card ID A Keypad Code #			
To deactivate event without Star Feature:	PIN Card ID D Keypad Code #			
To activate event with Star Feature:	PIN Card ID * 1 Keypad Code #			
To deactivate event with Star Feature:	PIN Card ID * 4 Keypad Code #			
With PIN and Badge				
To activate event without Star Feature:	PIN A Keypad Code badge			
To deactivate event without Star Feature:	PIN D Keypad Code badge			
To activate event with Star Feature:	PIN (*) 1 Keypad Code badge			
To deactivate event with Star Feature:	PIN (*) 4 Keypad Code badge			
With PIN and Badge, allowing PIN after Badge				
To activate event without Star Feature:	PIN A Keypad Code badge ¹ #			
To deactivate event without Star Feature:	PIN D Keypad Code badge ¹ #			
To activate event with Star Feature:	PIN * 1 Keypad Code badge ¹ #			

¹) You may present the badge at any time before pressing the # key, that is, before, during or after you enter the PIN and the Panel Card Event sequence. Use the keypad sequence * 2 if using CK705 or CK720 panels Version 2.2.

Appendix H: Troubleshooting

his section explains the authentication process for a P2000 user. This helps you understand what goes on behind the scenes, the reason for each step, and how to troubleshoot when problems arise.

Authentication Process

Windows Authentication

The first level of authentication for a P2000 Workstation is the connection to the P2000 Server. The Workstation must connect to the Server over the network to gain access to the database. Your Windows operating system performs this authentication. The Workstation sends to the Server the username and password that the user used when logging on to Windows. The Server then compares this username and password with the users configured in Windows. To connect the Workstation to the Server, this username and password must be a valid account on the Server.

The P2000 Server installation creates three Windows user groups, which you can assign to a user account to allow connection to the Server. The P2000 installation creates the following user groups:

User Group	Properties
PEGASYS Users	Connects to the Server and data- base over the network.
PEGASYS Administrators	Connects to the Server and data- base over the network, and also have database administrative rights (needed to drop and create database tables, and to restore the database).
PEGASYS MIS Users	Connects to the Server and MIS Interface portions of the data- base.

SQL Server Authentication

The second level of authentication for a P2000 Workstation is the SQL Server database. The Workstation connects to the SQL Server with an ODBC connection. The ODBC connection passes a username and password to the SQL Server to be authenticated. The default configuration of a P2000 ODBC connection is to pass the Windows username and password. The username and password that the ODBC connection sends must be a valid account in SQL Server for the Workstation to connect to the database. The P2000 Server installation creates SQL Server accounts for each of the three Windows user groups. Since SQL Server has accounts for the user groups that the P2000 Server installation created, assigning a Windows user account to one of those groups automatically grants access to the SQL Server database.

P2000 Authentication

The third level of authentication for a P2000 Workstation is the list of users configured in the P2000 software. When the P2000 software is started, the user is presented with a login screen. The username and password that the user enters is compared with the users configured in the P2000 software. The Workstation is also checked against the list of valid workstations configured into the P2000 system.

Testing the Workstation

Start the P2000 software and log on with the correct username and password. If the login succeeds, everything is OK. If the login fails, see P2000 Login Troubleshooting on page 603.

Troubleshooting Workstation Problems

If the P2000 Login dialog box displays, follow P2000 Login Troubleshooting on page 603. Otherwise, follow P2000 Network Troubleshooting on page 604.

For troubleshooting CCTV, see CCTV Control Troubleshooting on page 605.



P2000 Login Troubleshooting





CCTV Control Troubleshooting

606 APPENDIX H Troubleshooting

Appendix I: Secured Premises Notification Settings

he steps in this section are specific for panels that support the Panel Card Event feature, and are necessary to ensure UL 1076 compliance when you use a panel card event to unsuppress (arm) protected premise alarm signals.

According to UL 1076 requirements, if you unsuppress alarms at the protected premises (for example, through a panel card event), when this event is invoked, you must receive an indication, either audible or visible, that the P2000 Server received the message that the panel generated after the event was processed. If you do not receive the expected indication, then either the panel is offline from the Server or the panel did not process the panel card event request.

Before you define the Host event configuration (see page 608), you should verify the following settings. Use your discretion to program any parameters not specified.

Configuration

Cardholder Configuration

1. Create a badge for a cardholder with an **Event Privilege** equal to or greater than the panel card event privilege level used for suppressing or unsuppressing protected premise alarms.

See Entering Badge Information on page 267 for detailed instructions.

Panel Configuration

1. The panel must contain at least one input and one output terminal, in addition to a reader terminal. An acceptable alternative is a terminal that includes input, output, and reader capabilities, such as the S300-DIN-RDR2S module.

See Configure Hardware Components on page 53.

Input Point Configuration

- 1. Set the protected premise input point Status to Enable.
- 2. Set the **Disabled During Time Zone** option to **<none>**.
- 3. From the **Alarm Priority** drop-down list, select 4, 3, 2, 1, or 0, depending on individual company policy for protected premise alarms.

See Create Input Points on page 90.

Output Point Configuration

- 1. Set the output point Active State to Timed.
- 2. Set the **Duration** to 5 seconds or longer.
- 3. You must wire the output point to an audible or visible indicator. Depending on the terminal type used and the device selected, you may need to supply external power for the indicating device.
- 4. The indicator must be visible or audible from the point (location) the panel card event is deactivated.

See Create Output Points and Groups on page 88.

Input Group Configuration

1. Define the input group to use with the panel card event, and that includes the protected premise alarm input points defined in Input Point Configuration on page 607.

See Create Input Groups on page 97.

Panel Card Event Configuration

- 1. Select an appropriate **Privilege Level** to use with the card.
- 2. Set the event Trigger Type to Card/Keypad Code or Card/PIN/Keypad Code.
- Set the Event Duration to 0. (The panel card event must <u>not</u> specify an event duration time.)
- In the Input Group box, select Enable and Suppress, and select the affected Input Group (previously defined).
- 5. In the Valid Readers for Current Event box, select the readers to use for initiating the card event.

See Create Panel Card Events on page 99.

Host Event Configuration

To meet the UL requirement, you must create a Host event to be triggered when a panel card event is deactivated.

- 1. Create an Event.
- 2. Make sure the event Allow Manual Trigger flag is <u>not</u> selected.
- 3. Define the **Trigger** condition as:
 - Category: Badge
 - Type: Panel Card Event Deactivated
 - Condition: Badge
 - Logic: make appropriate selection
 - Value: make appropriate selection

Note: The **Logic** and **Value** selected must include the badges that are allowed to unsuppress protected premise alarms.

- 4. Define the Action condition as:
 - **Delay**: 00:00:00 (none)
 - Category: Outputs
 - **Type**: Set Output Timed
 - Outputs: select the output defined in Output Point Configuration on page 607
 - Duration: 0 seconds

See Creating Events on page 349.

Sequence of Events

The following information describes a typical sequence of events given the configurations described before.

- 1. Applicable protected premise alarms are in a secure state and are not suppressed.
- 2. An authorized cardholder initiates (activates) a panel card event, which suppresses an input group including protected premise alarm signals.
- 3. All protected premise alarm signals associated with the panel card event are now suppressed and do not report to the host.
- 4. An authorized cardholder deactivates the previously activated panel card event.
- 5. All protected premise alarm signals associated with the panel card event are now unsuppressed (armed) and report to the host (if the panel is online).
- 6. The host, having received the panel card event deactivate message, initiates its event and sets the appropriate output point.
- 7. The output point activation causes an audible or visible indicator to be annunciated at the location where the panel card event was deactivated.

Appendix J: Secured Premises Notification Settings for Mercury Panels with Keypad DM-21 (MRDT)

he following steps are specific for panels that support the intrusion feature, and are necessary to ensure UL 1076 compliance when you use a Mercury intrusion keypad terminal DM-21 (MRDT) to unsuppress (arm) protected premise alarm signals.

Note: Throughout this section, the terms DM-21 and MRDT are used interchangeably and refer to the Mercury intrusion keypad terminal.

According to UL 1076 requirements, if you unsuppress alarms at the protected premises (for example, through the arming command at a DM-21 intrusion keypad terminal), then you must receive an indication, either audible or visible, that the P2000 Server received the message that the area was armed after the command was processed. If you do not receive the expected indication, then either the panel is offline from the Server or the panel did not process the arming command as requested.

Before you define the Host event configuration (see page 610), you should verify the following settings. Use your discretion to program any parameters not specified.

Cardholder Configuration

1. Create a badge that has access rights to the DM-21 intrusion keypad terminal and that can manage protected premise alarms.

See Entering Badge Information on page 267 for detailed instructions.

Mercury Hardware Configuration

1. Create a Mercury panel that contains at least one terminal with an available output, in addition to the DM-21 intrusion keypad terminal, and the defined protected premise input points.

See Configure Mercury Panels and Components on page 179.

Input Point Configuration

1. Set each protected premise input point **Sta-***tus* to **Enable**.

See Configure Mercury Inputs on page 196.

Output Point Configuration

- 1. Set the output point Status to Enabled.
- 2. Set the Drive Mode to Normal.
- 3. Set the Offline Mode to No Change.
- 4. Set the Active State to Timed.
- 5. Set the **Duration** to 5 seconds or longer.
- 6. You must wire the output point to an audible or visible indicator. Depending on the terminal type used and the device selected, you may need to supply external power for the indicating device.
- 7. The indicator must be visible or audible from the point (location) the DM-21 intrusion terminal is used to arm the system.

See Configure Mercury Outputs on page 200.

Mercury Intrusion Zone Configuration

- 1. Create a Mercury intrusion zone that includes the protected premise input point defined in Input Point Configuration on page 609.
- 2. Set the Mercury intrusion zone to **Enabled**.
- 3. Set the **Point Type** in the Mercury tab to **Input Point**.
- Edit your Alarm Category in the Alarm Options tab to set the Alarm Priority to 4, 3, 2, 1, or 0, depending on individual company policy for protected premise alarms.

See Configuring Mercury Intrusion Zones on page 337.

Mercury Intrusion Area Configuration

1. Create a Mercury intrusion area that includes the Mercury intrusion zone previously defined, which includes the protected premise input points defined in Input Point Configuration on page 609.

See Configuring Mercury Intrusion Areas on page 338.

Host Event Configuration

To meet the UL requirement, you must create a Host event to be triggered when a user arms an area that includes the protected premise input points from the DM-21.

- 1. Create an Event.
- Make sure the event Allow Manual Trigger flag is not selected.
- 3. Define the Trigger condition as:
 - Category: Intrusion Area
 - **Type**: Armed (transition)
 - Condition: Area Name
 - Logic: make appropriate selection
 - Value: make appropriate selection

Note: The **Logic** and **Value** selected must include the areas from which protected premise alarms can be unsuppressed.

- 4. Define the Action condition as:
 - **Delay**: 00:00:00 (none)
 - Category: Outputs
 - Type: Set Output Timed
 - Outputs: select the output defined in Output Point Configuration on page 609
 - Duration: 0 seconds

See Creating Events on page 349.

Sequence of Events

The following information describes a typical sequence of events given the configurations described before.

- 1. Applicable protected premise alarms are in a secure state and are not suppressed.
- 2. An authorized cardholder initiates a disarm command at the DM-21, which suppresses a Mercury intrusion area including protected premise alarm signals.
- 3. All protected premise alarm signals associated with the panel are now suppressed and do not report to the host.
- 4. An authorized cardholder arms the previously disarmed area.
- 5. All protected premise alarm signals associated with the area are now unsuppressed (armed) and report to the host (if the panel is online).
- 6. The host, having received the arm command message, initiates its event and sets the appropriate output point.
- 7. The output point activation causes an audible or visible indicator to be annunciated at the location where the DM-21 intrusion keypad terminal was armed.

Index

Numerics

24 Hour Zone 338

Α

Abort Time 390 Access Grant Message 216 Access Grant Message on Door Open Only 73 Access Groups 38, 247 Access Levels 179 Access Method 158 Access Privileges 259 Access Requests 8 badge privileges 8 invalid badges 8 time 8 valid badges 8 Access Rights 271 Access Template 273 apply options to badges 274 Access Templates 251 Access Time 77 Account Disabled 24 Account Type 24 Acknowledgement Required before Completion 93 ACR Number 191 Action Date/Time 289 Action Interlock Errors 383 Action Interlock Operation 381 Action Interlocks 381 Action Interlocks tab 382 Actions 351 create an action 352 definitions 352 order of occurrence 352 Activate TTL-2 149 Activate TTL-2 and Continuously Beep 149 Activated Devices 395 Active Directory 23 Active State 88 Active States 201 Active Tours 395 Active-off 95 Active-on 94 AD Account 23, 446 AD Profile 24, 446 ADA Compliance 225 ADA Indicator 180

ADA Relay Connector 80 ADA Relay Delay 80, 193 ADA Relay Mode 193 ADA Relay Time 80 Add Hardware Module 83 Add Visitor 276 sponsor information 278 Address 72 ADS Repository Name 385 ADS/ADX 385 ADS/ADX server 384 Aimetis Interface Service 467 Air Crew PIN 68 Air Crew Pin 83 alarm beep 290 Alarm Category 285, 289 Alarm Category Filters 243 Alarm Colors 292 Alarm Debounce Time 75 Alarm Description 289 Alarm Details 292 Alarm Escalation Ranges 242 Alarm Instruction 92 Alarm Late 391 Alarm Monitoring 285 acknowledge alarms 286, 290 activate an event 292 alarm handling 286 alarm monitor definitions 288 audible alarm button 290 complete an alarm 287, 291 date/time 288 escalation 288 locate alarms on maps 290 priorities 288 priority sounds 289 refresh the window 287 remove an alarm 287, 291 respond 287, 290 Alarm Options 35 Alarm Popup 92 Alarm Priority 92 Alarm Processing Group 24 Alarm Shunt Only for Auxiliary Access 72 Alarm Site 290 Alarm Skip 391 Alarm State 289 Alarm Status 289 Alarm Timezone 92 Alarms 9

door alarms 9 external device alarms 9 host alarms 10 remote alarms 10 software only alarms 9 Alarms, Auxiliaries, Macros and Tours 413 Allow Any IP Address 47 Allow devices 380 Allow expansion 323 Allow Manual Trigger 350 Allow Multiple Alarm Handling 25 Allow PIN after Badge 72 Allow PIN before Badge 193 Alternate Enterprise Site 440 Always upload when greater than 59 American Dynamics Switch 555 Maximum and Default Values 556 Supported CCTV Controls 555 Supported CCTV Event Actions 555 Supported OPCWrite Event Actions 556 Annunciation Mode Enabled 77 Annunciator 332 Anti Passback 139, 158 Anti Tailgate 73 Anti-Passback 77 Anti-Tailgating 192 Any Guard 391 Any Void Card 100 Application Path 48 Apply Security Options 'Enterprise' 442 Apply Security Options Enterprise 270 Approval Levels 446 Approved Visits 277, 455 Area Alarms Setting 312 Area Control 310 Area Filters 315 configure the Area 310 control the Area 313 display details 315 reports 318 Terminals and Inputs Points 312 Area Details 315 Area Filters 315 Area Layout 317 Aritech Intrusion Alarms 340

Aritech Intrusion Server 333 armed 332 Assa Ablov DSR Interface Service 467 Assa Abloy Facility Parameters 166 Assa Abloy Locks 164 Assa Abloy Panel 171 Assa Ablov Terminals 174 Assigning Operators 22 Assisted Access 79, 193 Assisted Access Time 193 Assisted Shunt Time 193 Associated AV Channel 93 Associated Real Time Map 93 At Risk 320, 331 Audit Trail 40, 429 Authorized Users 430 Auto Badge Management 279 Auto Disarm 339 Auto Duress Alarm 391 Auto Forward 390 Auto Process 446 Auto Relock 109 Auto Reverse 390 Auto Start 467 Automatic Employee IDs 256 Automatic Software Updates 472 Aux Input Monitoring 110 Aux Output Control 111 Auxiliary Access 9 AV Service 467 Avigilon Interface Service 467

В

B420 Configuration Rules 335 Backup Controller Name 227 Backup Data (Append) 487 Backup Data (Overwrite) 487 Backup DB to Flash Interval 57 Backup Device 41 Backup Images (Append) 487 Backup Images (Overwrite) 487 Backup IP Address 227 Backups 490 advanced 491 automatic 492 backup device 490 manual 491 restoring database 493 BACnet Action Interlocks 381 BACnet Interface 57, 377 System Setup 379 Theory of Operation 377 BACnet Internal Address 380 BACnet object 377 BACnet Query String 381 BACnet Routed 380 BACnet Service 377, 467 BACnet Site Parameters 379 BACnet Troubleshooting 382

Badge Data badge field definitions 268 entering badge information 267 Facility Code 268 issue level 268 viewing 274 Badge Edit Style 38 Badge Format 150, 153, 160, 212 Badge Formats 252 Badge ID Allowed 138 Badge Information 274 Badge Override 138 Badge Purpose 269 Badge Purposes 253 Badge Reason 269 Badge Reasons 253 Badge Resync 280 Badge Station 20, 372 Badge Trace Alarm for Denied Access 35 Badge Trace Alarm for Granted Access 35 Badge Transaction History 274 Badge Type 38 Base Name 84 Base64 47 Basic Configuration 6 Basic System Components 2 external device 5 field panels 4 Server 2 system printer 4 terminals 5 workstations 3 Baud Rate 62 Begin Suppression 309 BetaTech Switch Protocol 557 Maximum and Default Values 558 Supported CCTV Controls 557 Supported CCTV Event Actions 558 Supported OPCWrite Event Actions 558 Switch Configuration 557 Bind Server 42 Blanking Time 283, 284 Bosch Interface Service 467 Bosch Intrusion 334 Bosch Intrusion Alarms 341 BQT Reader with LCD 74 Broadcast Port Number 61 Bulk Badge Change 275 Bypass 478 Bypass Off 343 Bypass On 343 bypassed 332 Bypassed on startup 338

С

Cabinet Access Control 231 Cabinet Configuration 233 Calculate Digital Signature 487, 496 Calibrate 82 Calibrate with Resistor 140, 143 Calibration 95 Camera Auxiliaries, Patterns and Presets 420 Camera Controls 418, 425 Camera Movement Actions 553 Cameras 408, 417 Card Bits to Use 150 Card Data Formatting 194 Card Events 10 Card Format 181 Card Format Types with Offline Support 194 Card Format Types without Offline Support 194 Card Formats 182 Card Mode 104 Card Only 100 Card Parity 102 Card Track 125 Card Type 81 Card/Keypad Code 100 Card/PIN Code 100 Card/PIN/Keypad Code 100 Cardholder Data 261 cardholder email address 447 Cardholder Information 359 Cardholder Override 158 Cardholder Override/Shunt 78 Cardholders cardholder field definitions 261 cardholder image 264 cardholder information 260 cardholder types regular 261 visitor 261 edit cardholder information 266 Journals 264 searching 266 user defined fields 265 visitor sponsor 263 CCTV 401 Components 408 Control 421 Event Actions 426 Naming Conventions 405 Reports 428 Server 408, 409 Standard Control Buttons 422 Switch Communications 412 System Hardware 404 CCTV Server 467 CCTV Server Namespace 575 CCTV Switch Protocols 553 Central 77

Directory Services Password import custom reports 522 Validation 27, 446 Directory Services Path 27, 42 Disable Alarm 92 Disable While Terminal Unsecure 112 Disabled During Time Zone 90 Disarmed 332 Display All alarm options 292

Directive Services Password

Validation 42

Change Style 270 D Chime Flag 338 CK721-A and S321-IP Data Import and Export 496 CK721A/S321IP Data Import and Export 487 Clear DSR 169 Clear Lock 172 Clear Text 47 CLIC Components 114 CLIC PIN¹¹¹ Commend Intercom 432 Commend Outputs 433, 435 Comms Server 35 Communication downloads 8 Daylight Savings 126 operating modes 7 Daylight Savings Used 137 central 7 DB Server 35 DCOM Configuration 589 shared 7 DCOM Installation 589 transactions 8 Communication Modes 7 Company 262 Debounce Time 162 Company definition 249 Decoding Rules 213 Concealed UDFs 26 Default Alarm Colors 292 Configure Cameras 417 Default Reader Mode 192 Configure CCTV Servers 409 Default Status 339 Configure Monitors 414 Default Timezone 248 Configure Switches 410 Defined Pulse Period 113 Connect Interval 175 Degraded 328 Connection String 185 Delay Downloads Until 475 Contractor Request 453 Delay Trigger 338 Control all Doors 304 Control Point Number 201 Control Station Groups 437 Delete all badges from OSI Control Sub-Stations 437 Delete all hardware from OSI Camera 425 Monitor 424 Switch 423 Convert to Current Version After Restore 494 COP Destination When Connected 228 Delete history older than 59 Count All 312 Delete Selected Alarm 487 Count Inputs 312 Count Terminals 312 Counters 305 De-Muster 323, 329 Create NT user account on Deny If Door Open 73 server 25 Department 262 Cross Site Access Group Editing 35 Department definition 250 Current Count 316 Destination Entry Computer 224, Current Firmware Version 485 Custom Card Formats 69 Device ID 385 Custom Configuration Number 57 Dial Number Length 433 Custom Reports 522 Direct Output Control 216

central Enterprise site 440

change password at next logon 25

Chain Rules 206

local 7

Controls

Change Password 28

D620 Mode 223 D620-ECG Elevator 217 Database and Namespace 404 Database External Trigger 47 Database Maintenance 486 advanced backups 491 automatic backups 492 backup device 490 database backup 490 database restore 493 manual backups 491 Database Server 440 Database Table Definitions 522

199

226

edit reports in Crystal 523

export existing reports 523

Display asterisks instead of pin code 35 Door controls 303 Door Forced - Alarm 109 Door Forced - Warning 109 Door Groups 235 Door Masks 233 Door Names 232 Door Open - Alarm 109 Door Open - Warning 109 Door Open Warning 78 Door Sensors 131 Door Service Router 169 Debounce Scan Count 194, 195, Door Tracking 234 DOP Destination When Connected 228 DOP Source When Connected 228 Download Access Groups of badge 43 Download badges with Undefined entry/exit status 43 Download Function 463 Download options 43 Download Service 467 Download Status 464 by panel 465 Delayed download for badges and Download to disabled panels 43 access groups 43 Download to STI-E 271 Downstream Connections 185 database 487 Drill 329 database 487 Drive Mode 195, 201 delete badges from panel before DSR 164 download 464 DSR Downloading 170 DSR Status 177 delete elevators from panel before Dual Ethernet 58 download 464 Delete Expired Visitor Badges 487 Duplicate Maps 366 Duplicate Object Name Errors 382 Duress 101 Duress Alarm 392 Delete Unused Access Groups 487 Delete Visitors Without Badges 487 DVR 428 DX4020 Configuration Rules 335 Е

Edit Button Image 367 Egress Actions 109 Elevator 62 Elevator Access Grant 216 Elevator Configuration 221 Elevator with feedback 191

create custom reports 522

Elevator without feedback 191 Elevators 215 EMail 45 Email 262 **Emergency Access Disable 453** Emergency Override 234 Empty Alarms 487 Empty Alarms History 487 Empty Archive Database 487 Empty Audit History 488 Empty Download Queue 488 Empty Fire Data 488 Empty Guard Tour Note 488 Empty Saved Muster Data 488 Empty Smart Download Queue 488 Empty Transaction History 488 Enable Codes 68 Enable Input Suppression Messages 62 Enable Mifare Encoding 460 Enable Monitoring Action 109 Enable Otis PIN 224 Enable Panel Relay Group Outputs 61 Enable PIN Duress 63 Enable Printing 360 Enable Secondary Interfaces 136 Encoder Configuration 458 Encoding Rules 213 Encryption 62, 135, 147, 155 Endura Interface Service 468 Enforce Entry/Exit 60 Enforce Limitations 37 Enterprise 3, 439 Access Groups 441 Global Access Rights 442 Parameters 440 Sites 263, 440 Time Zones 441 Entry Delay 200 Entry Exit Delay 91 Escalation 93 Escalation based upon visibility 94 **Escalation Increment** 94 Escalation Repeat 94 **Escalation Service** 468 Escalation Timeout 94 Evaluate Exported Data 502 Evaluating Imported Data 499 Event Action Types 535 Event Actions 351 Event Counters 354 add event counters 354 reset event counters 355 view event counters 354 Event Privilege 271 Events 10 card events 10 create events 349 event configuration 349 system events 10

timed events 10 Exact Match 267, 275, 281, 315 Executive Privilege 271 Exit Delay 200 Expand Zone 330 Expiration Period for Requests 445 Export 364 Export CK721-A and S321-IP Data 501 Extended Access 9 Extended Access Flag 123, 153 Extended Access Time 123 Extended Shunt Time 124 External Event Trigger 46 External IPs 380 External Trigger Service 468

F

Facility Code Only when Offline 72 Facility Codes 81 Failed Attempts Lockout 159 failed download connections 475 failed download transfers 475 FASC-N Badges 269 FASC-N Only 38 Fast Flash 89, 305 FDA Backup 41 FDA Backup Performed 488 FDA Backups 493 FDA Retention Policy 41 FDA Title 21 CFR Part 11 429 File External Trigger 46 Fire Alarm 297 Fire Devices Configuration 299 Fire Panel Status Details 476 Fireman Override 222 First Person Through 176 Fixed IP Address 135 Fixed Period 109 Flags 306 flash memory 482 Floor Groups 231 Floor Masks 220 Floor Names 220 Floor Tracking 207, 224 Force Logoff 471 Force Value 306 Forced Arm 343, 478 Forced Door 96 Forced Door/Propped Door 102 Format media on backup 492 forward and reverse 7 Found in DB 277, 455 Four-Digit PINs 87 FS (Full Screen) 283 Fully Qualified Name 384

G

General ASCII Protocol 554

commands supported 554 Generate namespace based on protocol defaults 412 Geutebrück Switch Protocol 559 Maximum and Default Values 561 Supported CCTV Controls 559 Supported CCTV Event Actions 560 Supported OPCWrite Event Actions 560 Global Badge Entry/Exit Status Synchronization 34 Global In-X-It Tracking 34 Global Sub-Station 435 Grant Only 391 Group Controller Address 62 Guard 387 Guard Tour 386 adding stations 392 assigning to a specific guard 391 assigning tour badges 387 configuring guard tours 388 control all tours 395 controlling guard tours 395 Details 398 forward and reverse 386 guard tour priority 388 principles and definitions 386 scheduled times 390 system hardware 387 tour abort 387 traversal time 394 Guard Tour Control 395 Guard Tour Priority 271 Guard Tour Reports 400 Guard Tour Service 386, 468

Н

Hardware Components 53 Hardware Module 83 Heartbeat Interval 146 Heartbeat Transmit Interval 135, 155 Help 16 context sensitive 15 online 16 HID Corporate 1000 81 HID Facility Parameters 153 HID Input Points 160 HID Interface Service 468 HID Output Points 162 HID Panels 152 HID Terminals 156 Hide from MIS 255 Hide reports 523 High Level Interface 62, 223 High Priority 465 High Speed RS485 56 History Retention Period 136

Hold Time 194, 199 Holiday 51 Holiday Calendar 52 Holiday Types 51, 52 Host Fails Deny 77 Host No Reception Timeout 136, 155 Host Poll Timeout 58 Hours On Site 346 Reporting 347 Zones 346 HTTP Disconnect Delay 136

I

I/O Latching 76 I/O Linking 76, 94 Ignore Characters 65 Image Recall 282 activate 283 filters 282 Image Recall FS 283 Import Standard Values 162 importing an image 374 Importing CK721-A and S321-IP Data 496 Index 72 Initialize media on backup 492 Inoperable 328 Input Count 316 Input Groups 97 Input Monitoring 112 Input Point Calibration 180 Input Point Suppression 309 Input Points 90 non-alarms 10 Input/Output Mode 138 Insert Macro 98 Instruction Conventions 14 menu shortcuts 15 Intercom 430 Control 436 Events 438 Exchange 431 Real Time Map Control 438 Stations 434 Intercom Interface Service 468 Intercom Transaction History Reports 438 Interior Zone 338 Intrusion Alarms 340 Intrusion Area 332 Intrusion Configuration 333 Intrusion Control 342 Intrusion Detection 331 Intrusion Events 345 Intrusion Interface Service 468 Intrusion Panel Status Details 475 Intrusion Status 344 Intrusion Transactions 344 Inverted 201

IO Modules 301 IP Address 57, 58 IPL version 474 Isonas Input Points 150 Isonas Interface Service 468 Isonas Output Points 151 Isonas Panels 146 Isonas Terminals 147 Item Name Filters 241

J

Journal 264

Κ

Key Switch Enabled 77 Keyless Override/Shunt Time 79 Keypad 591 Keypad Code 100 Keypad Credential Length 123 Keypad Mode 191 Kill All Reports 488 KONE HLI/KONE ELINK High Level Interface 217 Kone IP Controller Id 227 KONE IP Elevators 226, 229 Kone IP Group 227 KONE IP High Level Interface 217 KONE IP Portal 230

L

LAN (local area network) 3 Language selection 48 Last Badging Terminal 281 Last Badging Terminal Group 281 Last poll communication 474 Latch Output 61 Latching 199 Late Alarm 392 Launch Automatically 20 LED Mode 191 Legacy panel access group download disable 43 Load Archive Database from Backup 488 Load Language Reports 507 Local 77 Local Alarms 44, 288 Local Anti-Passback Forgiveness 104 Local Configuration 48 Local Site 47 Lockout 303 Lockout Mode 178 Log Operator Action 392 Log Output Status Message 64, 75, 145, 477 Log Reader Strike Message 64, 73 Log Tour Operation 392

Log Type 199 Logging on to P2000 11 changing the default login name 12 default login values 12 passwords 11 Super User 12 User Name 11 Logging Out of P2000 13 Loop Communication 7 Loop Configuration 54 Loop Number 58 Loop Timeout 58 Low Level Interface 216, 223 Lowest Floor for Group Controller 62

Μ

M3/M5 Workstations 377 Machine Room Enclosure 224, 226 Mag Format 65 Magnetic Stripe 125 Main Menu 5 Manager Flag 123 Manual Conventions 2 Manual Process 446 Manual Reset 391 Manual Tour 390, 397 map icons 364 Map Maker 360, 362 create an importable image 363 image sets 366 import an image 363 map attachments 366 normal map 363 place device icons 364 popup map 363 system map 363 Mark Secondary Tables 488 Master Station 435 Max Allowed 311 Max Allowed Alarmed 314 Max Badge Number 38 Max Inactive Period 34 Max Issue Level 38 Max PIN Code Digits 35 Max Security Level 38 Max. consecutive Invalid Logins 42 Maximum Queue Length 247 Maximum Retries 185 Mercury Elevator Floors 208 Mercury Elevator Inputs 209 Mercury Elevator Outputs 209 Mercury Elevators 206, 207 Mercury Facility Parameters 179 Mercury Inputs 196 Mercury Interface Service 468 Mercury Intrusion 337 Mercury Intrusion Areas 338 Mercury Intrusion Zones 337

Mercury Legacy Mode 180 Mercury Outputs 200 Mercury Panel Type 184 Mercury Panels 179, 183 Mercury Procedures and Triggers 202 Mercury Terminals 187 Message Filter Configuration 288, 356 Message Filter Group 21, 24, 44, 288 Message Filter Groups 244 Message Filtering 236, 237 Message Forwarding 296 Message Rejected Errors 382 Message Routing 245 Message Routing Status 290 Message Types 239, 543 Message Void Period 247 Metasys 377 Metasys system 383 Mifare Encoder 458 Migrate 256 Migrate Panel 488 Milestone Interface Service 468 Mimic 94 Min Required 311 Min Required Alarmed 314 MIS image folder 376 MIS Interface 375 input and output tables 376 partitioned systems 376 prerequisites 375 using the interface 376 MIS Interface Service 468 Momentary Auxiliary Access 73, 138 Monitor Controls 424 Monitor Loop Tamper 54 Monitor Point Number 199 Monitor Sequences 416, 554 Monitoring Remote Alarms 287 Monitors 408, 414 Mouse Conventions 14 MSEA 94 MSEA Graphic 94 MSEA Graphics 383 MSEA Registration 385 Multi-Card Access Time Out 180 Muster 319 Muster Control 321 Muster Control Service 468 Muster Reports 322 Muster Shift Setup 323 Muster Startup Rules 322 Muster Terminals 319, 324 Muster Zone 319 Muster Zone Alarm Settings 323 Mustered 320, 331 Mustering 319 control 327

define Muster Zones 320 events 326 reports 330

Ν

NAE controller 384 Name for DNS Address Resolution 135 Namespace Changing Number of Items 407 Naming Items 405 Number of Items 406 Number of Permitted Items 406 Namespace and Database 404 Namespace entries to be generated 412 Namespace Tags 576 Alarm 587 Auxiliary 587 Camera 583 Macro 587 Monitor 581 Pattern 588 Preset 588 Sequence 588 Switch 576 Tour 587 Naming Conventions 53 Navigating through the System 14 Network Communication 6 Network Panel 474 Network Timeout 57 New Firmware Version 485 Nice Interface Service 468 N-Man Rule 80 No Access Group Archive to Flash 57 No Badge Archive to Flash 57 No Change-of-State 199 No Configuration Archive to Flash 57 No Fault-to-Fault 199 No Green Light on Aux Access 73 None.wav 290 Non-latching 199 Normal and FASC-N 38, 269 Normal Popup 92 Normal Priority 465 Notification Class objects 377 Number of Doors 35 Number of Floors 35 Numeric Key Pad 148

0

ODBC Data Source 48 Offline Card Search 77 Offline Mode 196, 201 Offline Reader Mode 191 Offset / Append Value 180 OnSSI Interface Service 468 **OPC** Aritech 333 OPC Name 411 OPC Proxy Service 469 OPC Server 353 OPC Tag 353 OPC Tags 334 Open for Access Time 303 Operating the System 259 Operational Mode 145, 224 **Operator Controls** 303 control doors 303 control panel relays 305 Operator Name Filters 243 Operators 21 Optimize for LAN 48 Optimize for WAN 48 Option Keys 32 OSI Facility 122 OSI Interface Service 469 OSI Panels 120 OSI portals 127 OSI Terminals 129 OSI wireless readers 480 Otis Compass 218 Otis Compass Elevator Modes 219 Otis Compass Elevator Options 273 Otis EMS - Security / BMS Protocol 217 Otis Interface Service 469 Otis PIN 226 Otis Unsecured Elevators 225 Out Of Order Alarm 392 Out of Sync 176 Output Control 304 Output Delay 62 Output Groups 89 **Output Points 88** Output Relays 10 activated by events 10 activated manually 10 input linking 10 output linking 10 Override 271 Override Reset Threat Level 76, 308

Ρ

P2000 Account 23 P2000 Authentication 602 P2000 Location 3 P2000 Remote Server 288, 357 P2000 Services 466 P2000 Services Definitions 467 P2000-Metasys 377 P900 CLIC Controls 305 counters 305 flags 306 trigger event 306 P900 Counters 114 P900 Flags 115 P900 Inputs 112 P900 Outputs 112 P900 Panels 103 P900 Sequence Files 103 P900 SIO Handler Service 469 P900 Terminals 107 P900 Trigger Events 116, 306 P900 Trigger Links 119 Paired Reader 191 Paired, Master 191 Paired, Slave 191 Panasonic Switch Protocol 562 Maximum and Default Values 563 Supported CCTV Controls 562 Supported CCTV Event Actions 563 Supported OPCWrite Event Actions 563 Switch Configuration 562 Panel avg. clock drift (seconds) 475 Panel Card Events 99 Panel Card Formats 69 Panel Comparison Matrix 547 Panel Components 65 Panel Configuration 55 Panel Details 474 Panel Holidays 67 Panel Lost AC 102 Panel Low Battery 102 Panel max clock drift (seconds) 475 Panel Poll Interval 58 Panel Relay Control 305 Panel Status When DSR is Down 169 Panel Tamper 102 Panel Time Zones 66 Panel Types 36 Panel UTC Offset 137, 156, 186 Panels 4, 53 Parity Definition 212 Partial Match 267, 275, 281, 315 Partition Name Filters 240 Partitions 11, 369 creating partitions 371 deleting partitions 371 regular 370 super user 370 types 370 Password Mode 47 Password never expires 25 Password Policy 41 Password Validation 41 Password Verification 15 Peer to Peer Badge Sync 60 Pelco Switch Protocol 564 Macro Programming 566 Maximum and Default Values 566 Recording Patterns 566

Supported CCTV Controls 564 Supported CCTV Event Actions 565 Supported OPCWrite Event Actions 565 Periodic Service 469 Permission Groups 21 Permissions 25 Personalized Access Groups 273 Personnel In Group 328 Philips Burle Switch Protocol 567 Cabling Configuration 569 Maximum and Default Values 569 Supported CCTV Controls 568 Supported CCTV Event Actions 568 Supported OPCWrite Event Actions 568 Switch Macros 567 PIN + Card ID 87 PIN After Badge 176 PIN Append 180 PIN Code 268 PIN Code Digits 61 PIN Code Offset 180 PIN Code Retry 102 PIN Code Timed Override 64 PIN Code Type 61 PIN Codes 86 PIN Duress 87 PIN Duress Mode 180 PIN Only 86 Pin Pad 110 PIN Plus 1 Duress 64, 74 PIN Required 138, 176 PIN Required when Offline 72 PIN Retry Alarm 88 poll 7 Port 186 Port Configuration 43 Portal Packet Ratio 481 Portal Signal Strength 480 Pre Max Allowed 311 Pre Max Allowed Alarmed 314 Preferred Loop Direction 59 Preferred Primary Communication Path 57 Preprocessed reports 510 Primary Badge Format 124, 168 Print All 290, 360 Print Displayed 290, 360 Priority Ranges 242 Priority Service 468 Priority Values 379 Privilege Level 99 Procedures 202 Process Received Remote Messages 44, 288, 357 Processing Mode 446 Processor Rule 338

Programmer Flag 123 Property Number 381 Propped Door 96 Protocol 411 Protocol Type 62 Proximity Reader 148 Public 20 Public Access Timezone 208, 225 Push to Talk 437

Q

Query String 56, 290, 379 Query String Filters 240 Queued Download Actions 465

R

Radionics 294 Random Watch 390 Rapid Eye Interface Service 469 Raw Data 214 RAW reports 510 Read Configuration 336 Reader 72 Reader Holdoff Time 104 Reader Mode 138 Reader Override Timezone Enable 73 Reader Packet Ratio 481 Reader Sign On Badge 124 Reader Signal Strength 480 Readers with Keypads 129 Readers without Keypads 129 Real Time List 356 color coded transactions 359 printing 359 view all options 358 view specific options 358 Real Time List Transactions 357 Real Time Map 360 activate events 362 create a real time map 362 open a door 362 sub maps and attachments 360 view the real time map 361 Real Time Map Alarms 365 Reboot 132 Reboot on any failure 467 Reboot Panel 484 Receiving Messages (sec) 45 Record Persistence 430 Record Retention 430 Record Validation 430 Redundancy 429 Reestablish Delay 58 Region Number 433 Registration Parameters 6, 32 Relay Enabled 77 Relay Time 109 Re-lock on Door Open 73

Remain Time 396 Remote Alarms 45, 287, 288 Remote Message Service 44, 287, 356.469 Remote Messages in Real Time 356 Remote Partitions 26 Remote Servers 245 Remove Access Groups from **Disabled Badges** 488 Remove Expired Access Groups from Badges 488 Repeat Transaction Delay 104 Report Alarm 234 Report Configuration 522 Report Delay 91 Report Disarmed Not Ready to Arm 339 Report on Terminal 102 Report Strike Status 138 Reporting Delay 61 Reports 507 alarm history report 515 cardholders without badges report 519 cardholders-preprocessed report 517 custom reports 522 database table definitions 522 definitions 510 field/table relationship 522 load language reports 507 panel report 520 print 508 samples 515 transaction history report 521 Request Approval 452 Request Approvers 447 Request Queue 502 Request Queue Service 469 Request Queue View 502 details 505 filtering 504 Request Status 452, 453 Required Approval Levels 445 Required Cardholder Fields 254 Required Fields 261 Required fields 265 Rescuer 320, 331 Resend All Events 336 Resend Attempt Interval 136, 155 Reset Counters 475 Reset Counters to Zero 488 Reset Panel Before Download 188, 464 Reset Reserved Autobadge Numbers 489 Reset Time 475 ResetAck 343, 478 Response Required before Completion 93 Response Text 294

create 294 Restart on 1st failure then reboot 467 Restart on 2 failures then reboot 467 Restart on failure 467 Restore from foreign backup 494 Restore to archive 494 Restrict Storage 59 Resume Normal Operation 304 Retention Period 41 Retention Policy 40 Return Address 45 Return to Normal 303 Reverse Reading 72 Reverse Swipe Duress 74 Reverse Track 95 REX Contact 157 REX Input 149 RMS 44 RS232 External Trigger 46 RTL Route Service 469 Run Time 390

S

S321 SIO Handler Service 469 S321-DIN Panels 484 S321-IP Input Points 140 S321-IP Interface Service 469 S321-IP Output Points 144 S321-IP Panels 133 S321-IP Terminals 137 Save the Log File 501 SaveXAction 432, 433, 438 Scramble Mode 61 searching for cardholders 266 Secure Authentication 42 Secured Premises Notification Settings 607, 609 Secure-off 95 Secure-on 94 Security Level 64, 271, 307 Security Level By Color 308 Security level control 307 Security Options 270 Send COP 227 Send DOP 227 Send Email to Request Approvers 445 Sequester 331 Sequester Terminals 319, 325 Sequestered 320 Serial Loops 54 Serial Panel 474 Server 2 Service Controls 470 stop and start services 470 stop/star a specific service 470 stop/start all services 470 Service Monitor 470 Service Override 222, 234

Service Pack 472 Service Startup Configuration 466 Session Type 471 Set Alarm Color 396 Set all Input Status to Unknown 489 Set all Output Status to Unknown 489 Set all Panel Status to Unknown 489 Set all Terminal Status to Unknown 489 Set Computer Default Language 489 Set Panel Relay When Active 91 Shared 77 Shared Path 472 Show All 314, 315 Show Only 314, 315 Show UDF Fields 283 Shrink Database 489 Shunt Alarm on Request to Exit 138 Shunt Only on REX 193 Shunt Terminal 110 Shunt Time 78 Shunt Warning Auto Off 78 Shunt/ADA Relay 196 SIA Device 295 SIA Interface 294 SIA Interface Service 469 SIA Message View 295 Sign On Key 123 Silence 344 SIO 187 SIO Handler Service 469 SIO Number 189 Site Director 384, 385 Site Name Filters 239 Site Parameters 33 Site Parameters Printing 35 Skip Alarm Cancel 339 Slow Flash 89, 305 Smart Download Control 465 Smart Download Rules 43 Smart Download Service 469 SMTE Service 469 SMTP Hello Domain 45 SMTP Server 45 **SNMP 136** Soft Alarms 101 Soft Input Points 56 Soft In-X-It 73, 102 Software Updates 472 Special Access 9, 35, 80, 271 basic access override 9 auxiliary access 9 extended access 9 timed override 9 granting badge privileges 9 Special Access Flags 100 sponsors 263 SQL Server Authentication 601

Standard Reports 507 run a standard report 508 Star Feature 74 static text objects 365 Station Group 435 Station Type 393 Statistics Update Interval 131 STI-E 76 Stop Suppression 309 Sub-Station 435 Super User 12, 370 Support Regions 433 Suppress 100 Suppress Input Points 309 Swipe PIN 111 Switch Controls 423 Switch Protocols 407, 553 American Dynamics 555 BetaTech 557 communications 553 General ASCII 554 Geutebrück GST Interface 559 Panasonic 562 Pelco 564 Philips Burle 567 Ultrak 570 Vicon 572 Switches 408, 410 Sync cardholder/badge active flags 489 Synchronize OSI Transaction Counter 489 System Components 32 System Configuration 17 System Events 10 System Maintenance 463 System Override 60 System Overview 6 System Status 473 Fire Detector 479 Fire IO Module 479 Fire Zone 479 Input Terminals 476 Inputs 477 Integration Components 481 Intrusion Annunciators 478 Intrusion Areas 478 Intrusion Zones 478 Legend 474 Mustering Zones 477 OTIS Elevator Status 477 Output Terminals 476 Outputs 477 Reader Terminals 476 Security Level Terminals 477 Wireless Parameters 480 System Validation 495

Т

Tamper Monitoring 110, 112

TCP/IP External Trigger 46 Template Terminal 85 Temporary Access 272 Terminal Count 316 Terminal Down 96 Terminal Groups 85 Terminal Lost AC 102 Terminal Low Battery 102 Terminal Siblings 187 Terminal Status to "Unknown" when Panel Offline 40 Terminal Tamper 102 Terminals 70 Terminals associated with Timezone 39 This Location Only 454 Time Before Propped Door Reported 159 Time Blocks 49 Time Offset 60, 105 time pairs 39 Time Zones 49 Timed Button 222 Timed Events 10 Timed Override 9, 78 Timed Override/Anti-Tailgate 60 Timed Shunt 78 Timed Suppression 309 Timed/Pulse 305 Timezone Checking 60 Today Only 453 Toolbar 16 Tour Activation 387 Tour Alarms Setting 392 Tour Badge 387 Tour Badge priority 388 Tour Configuration 388 Tour Configuration Report 400 Tour Notes 399 Tour Notes Report 400 Tour Sequence Number 393 tour shunt devices 395 Tour Station 392 Tour Transaction Report 400 Tour Types 390 Trace 271 Track 94 Track Movement 325 Track On Input Open 224 Track On Transition Only 224 Transmit Filter 246 Transmit Queue 246 Transmit Session 247 Transmitting Messages (sec) 45 Trapped 320, 331 traverse time 394 Trigger Logic 350 Trigger Manually 355 Trigger Types 525 Triggers 204 create triggers 349

edit a trigger condition 351 field definitions 351 manual triggers 355 trigger conditions 349 Tristate Check Boxes 407 Troubleshooting CCTV Control 605 Login 603 Network 604 Workstation Problems 602 Turnstile 191

U

UDF Choices 255 UI Style 446 UIstyle 458 Ultrak Switch Protocol 570 Maximum and Default Values 571 Supported CCTV Controls 570 Supported CCTV Event Actions 570 Supported OPCWrite Event Actions 571 Switch Configuration 570 Uncalibrate 82.95 Under PIN Control 111 unique time pairs 40 Unlock 303 Unlock All Doors 304 Unlock Door 149 Unlocked Time Zone 109 unreliable icons 361 unsuppress protected premise alarms 607, 609 Update CK7xx Panels 482 Update Database Default Strings 489 Update Mercury Panels 485 Update Preprocessed Report Archive tables 489 Update Preprocessed Report tables 489 Update S321-DIN Panels 484 Upload 59 Upload only when greater than 59 Upload Service 468 Use Authorized SMTP 45 Use Encryption 42 Use Extended Addressing 84 Use for XmlRpc 380 Use Operator Account / Profile Authentication 446 User Accounts 28 User Authentication 446 User Defined Fields 254, 265 User Name 289 User Site 289 Username Formatting 42 Using a Keypad Reader 591

invoking access requests 591 invoking air crew access 592 invoking panel card events 595 invoking timed overrides 592 Quick Guide 597

۷

Valid & Unauthorized 74 Validate 452 Validate Digital Signature 489, 495 Verify Password for Critical Functions 25 Version description 474 Vicon Switch Protocol 572 Camera Lens Speed Control 573 Maximum and Default Values 574 Momentary and Latched Auxiliaries 573 Supported CCTV Controls 572 Supported CCTV Event Actions 573 Supported OPCWrite Event Actions 573 Switch Configuration 572 Video Imaging 371 defining a workstation 372 printing a badge 373 specifications 372 viewing and printing a badge 374 View Backup Contents 494 View Inoperable Hardware 330 Violation Alert Period 41 VIP Access 225 VIP Indicator 180 Visitor Escort Mode 80 Visitor Information 276 Visitor Management 452 Visitor Request 452 Field Definitions 455 sponsor 456 Visitor Validity Period 34 visitors 261

W

Wakeup Communication 166 WAMS 120 Wandering 320, 331 Warning Auto Off 79 Warning Output Group 78, 79 Warning Time 78, 79 Watchdog Service 469 Web Access 443 Alarm Monitor 451 Area Search 451 Audit 452 Badge Print 451 Badge Resync 451 Cardholder Search 450

Command Outputs 451 Customizing the interface 457 Door Command 451 Employee Services 450 Guard Services 451 In Out Displays 451 Logging on 450 Management Services 451 Menu Permissions 262, 444 Options 445 Processing requests 453 Submitting Requests 450 Web Request Queue Status 444 WebBadging Setup 452 Windows Authentication 601 Workstation Status 471 Workstation Test 602 Workstations 19 Alarm Monitor 20 location 20 Workstations and Operators 19 World Time Zone 136, 156, 186 Write Panel Database to Flash Memory 482

Х

XmlRpc 47 XmlRpc Interface Service 469 XPortal Interface Service 469

Ζ

Zenitel Intercom 432 Zone 327 Zone Hardware Status 328 Zone Name 321 Zone Status 327 Zone Terminals 319, 324

Security Solutions (805) 522-5555 www.johnsoncontrols.com

We welcome your comments at <u>BE-techpubs-security@jci.com</u>.