# Old Company Name in Catalogs and Other Documents

On April 1<sup>st</sup>, 2010, NEC Electronics Corporation merged with Renesas Technology Corporation, and Renesas Electronics Corporation took over all the business of both companies. Therefore, although the old company name remains in this document, it is a valid Renesas Electronics document. We appreciate your understanding.

Renesas Electronics website: http://www.renesas.com

April 1<sup>st</sup>, 2010 Renesas Electronics Corporation

Issued by: Renesas Electronics Corporation (http://www.renesas.com)

Send any inquiries to http://www.renesas.com/inquiry.

#### Notice

- 1. All information included in this document is current as of the date this document is issued. Such information, however, is subject to change without any prior notice. Before purchasing or using any Renesas Electronics products listed herein, please confirm the latest product information with a Renesas Electronics sales office. Also, please pay regular and careful attention to additional and different information to be disclosed by Renesas Electronics such as that disclosed through our website.
- Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
- 3. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part.
- 4. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
- 5. When exporting the products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations. You should not use Renesas Electronics products or the technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations.
- 6. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
- 7. Renesas Electronics products are classified according to the following three quality grades: "Standard", "High Quality", and "Specific". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below. You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application categorized as "Specific" without the prior written consent of Renesas Electronics. Further, you may not use any Renesas Electronics. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for an application categorized as "Specific" or for which the product is not intended where you have failed to obtain the prior written consent of Renesas Electronics. The quality grade of each Renesas Electronics product is "Standard" unless otherwise expressly specified in a Renesas Electronics data sheets or data books, etc.
  - "Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots.
  - "High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anticrime systems; safety equipment; and medical equipment not specifically designed for life support.
  - "Specific": Aircraft; aerospace equipment; submersible repeaters; nuclear reactor control systems; medical equipment or systems for life support (e.g. artificial life support devices or systems), surgical implantations, or healthcare intervention (e.g. excision, etc.), and any other applications or purposes that pose a direct threat to human life.
- 8. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
- 9. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or system manufactured by you.
- 10. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
- 11. This document may not be reproduced or duplicated, in any form, in whole or in part, without prior written consent of Renesas Electronics.
- 12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.
- (Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majorityowned subsidiaries.
- (Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



# **Application Note**

Multimedia Processor for Mobile Applications

# Timer

-----

**EMMA Mobile1** 

Document No.S19894EJ1V0AN00Date PublishedAug. 2009

© NEC Electronics Corporation 2009 Printed in Japan

# PREFACE

Purpose	The purpose interface.	e of this document is to specify the usage of the Timer		
Organization	<ul> <li>This documer</li> <li>Introduction</li> <li>Usage of</li> <li>Example</li> <li>Timer Drive</li> </ul>	nt includes the following: ion Timer Interface of Timer Operation iver Function		
Notation	Here explains	s the meaning of following words in text:		
	Note	Explanation of item indicated in the text		
	Caution	Information to which user should afford special attention		
	Remark	Supplementary information		
Related document	The following	tables list related documents.		

#### **Reference Document**

Document Name	Version/date	Author	Description
S19265E 11\/01 IM00 ASMUGIO pdf	1st edition	NECEL	ASMU/GIO User's
319203E317000000_A300000.pdf		NLOLL	Manual
S19268EJ1V0UM00_1chip.pdf	1st edition	NECEL	1 Chip User's Manual
S19266EJ1V0UM00_TIMER.pdf	1st edition	NECEL	Timer User's Manual
S19907EJ1V0AN00_GD.pdf	1st edition	NECEL	GD Spec

#### Disclaimers

- The information contained in this document is subject to change without prior notice in the future. Refer to the latest applicable data sheet(s) and user's manual when designing a product for mass production.
- No part of this document may be copied or reproduced in any form or by any means without the prior written consent of NEC Electronics. NEC Electronics assumes no responsibility for any errors that may appear in this document.
- NEC Electronics does not assume any liability for infringement of patents, copyrights or other intellectual property rights of third parties by or arising from the use of NEC Electronics products listed in this documents or any other liability arising from the use of such products. No license, express, implied or otherwise, is granted under any patents, copyrights or other intellectual property rights of NEC Electronics or others.
- Descriptions of circuits, software and other related information in this document are provided for illustrative purposes in semiconductor product operation and application examples. The incorporation of these circuits, software and information in the design of a customers' equipment shall be done under the full responsibility of the customer. NEC Electronics assume no responsibility for any losses incurred by customers or third parties arising from the use of these circuits, software and information.
- While NEC Electronics endeavors to enhance the quality, reliability and safety of NEC Electronics products, customers agree and acknowledge that possibility of defects thereof cannot be eliminated entirely. To minimize risks of damage to property or injury (including death) to persons arising from defects in NEC Electronics products, customers must incorporate sufficient safety measures in their design, such as redundancy, firecontainment and anti-failure features.

#### Note)

- 1. "NEC Electronics" as used in this document means NEC Electronics Corporation and also includes its majority-owned subsidiaries.
- 2. "NEC Electronics products" means any product developed or manufactured by or for NEC Electronics (as defined above)

# CONTENTS

Chapter 1 Introduction
1.1 Outline
1.2 Development Environment
Chapter 2 Usage of Timer Interface
2.1 Timer Overview
2.2 Timer Details
Chapter 3 Example of Timer Operation 10
3.1 Example of General Operation11
3.1.1 Operation Flow11
3.1.2 Operation Detail 12
3.2 Example of Set Watchdog 16
3.2.1 Operation Flow 16
3.2.2 Operation Detail
Appendix A Timer Driver Function19
A.1 Timer Driver Function List
A.2 Timer Driver Function Detail
A.2.1 Initialize Timer
A.2.2 Start Timer
A.2.3 Stop Timer
A.2.4 Pause Timer
A.2.5 Resume Timer
A.2.6 Get Timer Configure
A.2.7 Timer TI0 Interrupt Handler
ANNEX Modification History

# LIST OF TABLES

Table 1-1 Hardware Environment	6
Table 1-2 Software Environment	6
Table 2-1 Calculation of Timer Count	8
Table A-1 Timer Driver Function List	19

### LIST OF FIGURES

Figure 2-1 Timer Operation Overview	7
Figure 3-1 Example of General Operation	11
Figure 3-2 Example of Set Watchdog	16
Figure A-1 Initialize Timer	21
Figure A-2 Start Timer	23
Figure A-3 Stop Timer	25
Figure A-4 Pause Timer	27
Figure A-5 Resume Timer	29
Figure A-6 Get Timer Configure	31
Figure A-7 Timer TI0 Interrupt Handler	33

# **Chapter 1 Introduction**

# 1.1 Outline

This document introduces how to use the timer interface of EMMA Mobile1, including the following functions:

- How to set general operation of timer (start, pause, resume and stop).
- How to set watchdog.

The timer module (ATIM) is a programmable timer counter that enables 32-bit counting (1 to 0xFFFFFFF).

About the details of functions please refer to "**CHAPTER 1 OVERVIEW**" of EMMA Mobile1 Timer user's manual.

### **1.2 Development Environment**

• Hardware environment of this project is listed as below.

**Table 1-1 Hardware Environment** 

Name	Version	Maker
EMMA Mobile1 evaluation board (PSKCH2Y-	-	NEC Electronics
S-0016-01)		
PARTNER-Jet ICE ARM	M20	Kyoto Microcomputer Co. Ltd

• Software used in this project is listed as below.

#### Table 1-2 Software Environment

Name	Version	Maker
GNUARM Toolchain	V4.3.2	GNU
WJETSET-ARM	V5.10a	Kyoto Microcomputer Co. Ltd

# Chapter 2 Usage of Timer Interface

### 2.1 Timer Overview



Figure 2-1 Timer Operation Overview

# 2.2 Timer Details

(1). Open clocks.The related registers are as follow: ASMU\_GCLKCTRL3ENA; ASMU\_GCLKCTRL3;

 (2). Reset release.
 The related registers are as follow: ASMU\_RESETREQ1ENA; ASMU\_RESETREQ1;

(3). Set count clock.
The related registers are as follow:
ASMU\_DIVTIMTIN;
ASMU\_TI0TIN\_SEL;
ASMU\_TI2TIN\_SEL;
ASMU\_TI3TIN\_SEL;
ASMU\_TGnTIN\_SEL;

The Timers have 3 clock source, PLL3, 32K, 32.768K. And a wide range of counting is possible by using a combination of input frequency and timer count settings. The following table shows setting examples. The term [seconds] in this table refers to the interval at which the TOUT signal is asserted.

TIN	Timer Count Setting Value			
(Input Frequency)	0000_0000H	0000_FFFFH	FFFF_FFFH	
32.768 kHz	30.52 * 10 <sup>E-6</sup> [seconds]	2 [seconds]	131071.99 [seconds]	
15.616 MHz	64.04 * 10 <sup>E-9</sup> [seconds]	4.20 * 10 <sup>E-3</sup> [seconds]	275.04 [seconds]	

 Table 2-1 Calculation of Timer Count

Expression: (1/TIN) \* (Count setting value + 1).

Example: 1/32.768 kHz \* (0000\_FFFFH + 1) = 30.52 \* 10<sup>E-6</sup> \* 65536 = 2 [seconds].

(4). Set count out value.

The related registers are as follow:

TIM\_xxx\_OP; TIM\_xxx\_CLR; TIM\_xxx\_SET;

#### Note:

xxx = TI0/TI1/TI2/TI3/TW0/TW1/TW2/TW3/TG0/TG1/TG2/TG3/TG4/TG5.

(5). Enable interrupt.The related registers are as follow: SEC\_IT0\_IENS1;

INTC\_IT0\_IEN1;

(6). Start timer.

The related registers are as follow: TIM\_xxx\_OP;

(7). Get timer configure.The related registers are as follow: TIM\_xxx\_SET; TIM\_xxx\_RCR;

(8). Timer interrupt handler.
The related registers are as follow:
INTC\_IT0\_IIR;
SEC\_IT0\_IDSS1;
INTC\_IT0\_IDS1;
TIM\_xxx\_OP;

# **Chapter 3 Example of Timer Operation**

The following contents show 2 examples about timer interface:

- How to set the general operation of timer
- How to set watchdog about timer.

### 3.1 Example of General Operation

#### 3.1.1 Operation Flow



Figure 3-1 Example of General Operation

About the timer function, please refer to the "Appendix A Timer Driver Function".

#### 3.1.2 Operation Detail

(1). Initialize TIO.

The process calls the "em1\_timer\_init()" function. The "em1\_timer\_init()" function finishes the following functions for TI0:

- Open TI0\_TIN.
   ASMU\_GCLKCTRL3ENA[0] = 1b;
   ASMU\_GCLKCTRL3[0] = 1b;
   ASMU\_GCLKCTRL3ENA[0] = 0b;
- Open ATIM\_PCLK.
   ASMU\_GCLKCTRL3ENA[14] = 1b;
   ASMU\_GCLKCTRL3[14] = 1b;
   ASMU\_GCLKCTRL3ENA[14] = 0b;
- Reset TI0.
   ASMU\_RESETREQ1ENA[0] = 1b;
   ASMU\_RESETREQ1[0] = 0b;
   ASMU\_RESETREQ1ENA[0] = 0b;
- Reset release TI0.
   ASMU\_RESETREQ1ENA[0] = 1b;
   ASMU\_RESETREQ1[0] = 1b;
   ASMU\_RESETREQ1ENA[0] = 0b;

Set the divisor of PLL3.
 ASMU\_DIVTIMTIN = Divisor;

"Divisor" is an input value. Details about how to set the "Divisor" please refer to the "Chapter 3.2.49 Timer clock frequency division setting register" of EMMA Mobile1 ASMU/GIO user's manual.

• Set PLL3 to TI0 clock.

ASMU\_TIOTIN\_SEL[1:0] = 00b;

Details about how to select clock source, please refer to the "Chapter 3.2.44 TI0\_TIN/TW0\_TIN setting register" of EMMA Mobile1 ASMU/GIO user's manual.

Stop TI0.
 TIM\_TI0\_OP[2:0] = 000b;

(2). Start TI0.

The process calls the "em1\_timer\_start()" function. The "em1\_timer\_start()" function finishes the following functions for TIO:

- Enable TI0.
   TIM\_TI0\_OP[0] = 1b;
- Clear the internal timer count registers of TI0. TIM\_TI0\_CLR[1] = 1b;
- Set value setting register of TI0.
   TIM\_TI0\_SET = setting\_value;
   "setting\_value" is input timer register value at which the timer counts out.
- TI0 interrupt.

   irq\_hook[54] = interrupt\_handler;
   // "irq\_hook" is interrupt function vector table. "54" is TI0 interrupt number.

   SEC\_IT0\_IDSS1[22] = 1b;
   INTC\_IT0\_IDS1[22] = 1b;
   INTC\_IT0\_IIR[22] = 1b;
   INTC\_IT0\_IIR[22] = 1b;
   INTC\_IT0\_IENS1[22] = 1b;
- Start TI0. TIM\_TI0\_OP[2:0] = 111b; // Enable TI0 and TOUT signal, Start TI0.
- (3). Delay some time, then pause TI0.

The process calls the "em1\_timer\_pause()" function. The "em1\_timer\_pause()" function finishes the following functions for TIO:

Pause TI0.
 TIM\_TI0\_OP[2:0] = 101b;

// Enable TI0 and TOUT signal, disable start TI0.

(4). Get TI0 configure.

The process calls the "em1\_timer\_get\_config()" function. The "em1\_timer\_get\_config()" function finishes the following functions for TIO:

Get TI0 configure.
 Count1 = TIM\_TI0\_RCR; // TIMER0 real count read register

If register TIM\_TI0\_RCR is not equal to 0, start TI0 successfully.

is

(5). Delay some time, then get TI0 configu The process calls the "em1_timer_get_ The "em1_timer_get_config()" function f	re. config()" function. inishes the following functions for TI0:
<ul> <li>Get TI0 configure.</li> <li>Count2 = TIM_TI0_RCR;</li> </ul>	// TIMER0 real count read register
If Count1 is equal to Count2, pause TI0 su	iccessfully.
<ul><li>(6). Resume TI0.</li><li>The process calls the "em1_timer_resu</li><li>The "em1_timer_resume()" function finite</li></ul>	ime()" function. ishes the following functions for TI0:
<ul> <li>Resume TI0.</li> <li>TIM_TI0_OP[2:0] = 111b;</li> </ul>	// Enable TI0 and TOUT signal, Start TI0.
<ul><li>(7). Delay some time, then stop TI0.</li><li>The process calls the "em1_timer_stop".</li><li>The "em1_timer_stop()" function finished</li></ul>	()" function. Is the following functions for TI0:
<ul> <li>Disable TI0 interrupt. irq_hook[54] = NULL;</li> <li>SEC_IT0_IDSS1[22] = 1b; INTC_IT0_IDS1[22] = 1b;</li> </ul>	<ul> <li>// "irq_hook" is interrupt function vector table. "54"</li> <li>TI0 interrupt number.</li> <li>// Disable TI0 secure interrupt.</li> <li>// Mask TI0 interrupt.</li> </ul>
<ul> <li>Stop TI0.</li> <li>TIM_TI0_OP[2:0] = 000b;</li> </ul>	// Disable TI0 and TOUT signal, Stop TI0.
<ul><li>(8). Get TI0 configure.</li><li>The process calls the "em1_timer_get_ The "em1_timer_get_config()" function f</li></ul>	config()" function. inishes the following functions for TI0:
<ul> <li>Get TI0 configure.</li> <li>Count1 = TIM_TI0_RCR;</li> </ul>	// TIMER0 real count read register
If register TIM_TI0_RCR is 0, stop TI0 suc	cessfully.
(9). Start TI0.	

This process is the same to process (2), please refer to it.

#### (10) Call interrupt handler.

If TI0 interrupt occurs, call interrupt handler "em1\_timer\_int\_ti0". The "em1\_timer\_int\_ti0" function finishes the following functions for TI0:

•	Disable TI0 interrupt.	
	SEC_IT0_IDSS1[22] = 1b;	// Disable TI0 secure interrupt.
	INTC_IT0_IDS1[22] = 1b;	// Mask TI0 interrupt.
•	Clear TI0 interrupt source.	
	INTC_IT0_IIR[22] = 1b;	// Clear TI0 interrupt source.
•	Enable TI0 interrupt.	
	SEC_IT0_IENS1[22] = 1b;	// Enable TI0 secure interrupt.
	INTC_IT0_IEN1[22] = 1b;	// Disable TI0 interrupt mask.

# 3.2 Example of Set Watchdog

#### 3.2.1 Operation Flow



Figure 3-2 Example of Set Watchdog

About the timer function, please refer to the "Appendix A Timer Driver Function".

#### 3.2.2 Operation Detail

(1). Initialize TW0.

The process calls the "em1\_timer\_init()" function. The "em1\_timer\_init()" function finishes the following functions for TW0:

- Open TW0\_TIN.
   ASMU\_GCLKCTRL3ENA[10] = 1b;
   ASMU\_GCLKCTRL3[10] = 1b;
   ASMU\_GCLKCTRL3ENA[10] = 0b;
- Open ATIM\_PCLK.
   ASMU\_GCLKCTRL3ENA[14] = 1b;
   ASMU\_GCLKCTRL3[14] = 1b;
   ASMU\_GCLKCTRL3ENA[14] = 0b;
- Reset TW0.
   ASMU\_RESETREQ1ENA[4] = 1b;
   ASMU\_RESETREQ1[4] = 0b;
   ASMU\_RESETREQ1ENA[4] = 0b;
- Reset release TW0.
   ASMU\_RESETREQ1ENA[4] = 1b;
   ASMU\_RESETREQ1[4] = 1b;
   ASMU\_RESETREQ1ENA[4] = 0b;
- Set 32K to TW0 clock.
   ASMU\_TIOTIN\_SEL[17:16] = 10b;

Details about how to select clock source, please refer to the "Chapter 3.2.44 TI0\_TIN/TW0\_TIN setting register" of EMMA Mobile1 ASMU/GIO user's manual.

- Stop TW0.
   TIM\_TW0\_OP[2:0] = 000b;
- (2). Start TW0.

The process calls the "em1\_timer\_start()" function. The "em1\_timer\_start()" function finishes the following functions for TW0:

- Enable TW0.
   TIM\_TW0\_OP[0] = 1b;
- Clear the internal timer count registers of TW0.
   TIM\_TW0\_CLR[1] = 1b;

- Set value setting register of TW0.
   TIM\_TW0\_SET = setting\_value;
   "setting\_value" is input timer register value at which the timer counts out.
- TW0 interrupt.
   irq\_hook[58] = interrupt\_handler;

 $SEC_IT0_IDSS1[26] = 1b;$ 

 $INTC_IT0_IDS1[26] = 1b;$ 

 $SEC_{IT0}IENS1[26] = 1b;$ 

 $INTC_IT0_IEN1[26] = 1b;$ 

 $INTC_IT0_IIR[26] = 1b;$ 

// "irq\_hook" is interrupt function vector table. "58" is TW0 interrupt number.

// Disable TW0 secure interrupt.

// Enable TW0 interrupt mask.

- // Clear TW0 interrupt source.
- // Enable TW0 secure interrupt.
- // Disable TW0 interrupt mask.
- Start TW0.
   TIM\_TW0\_OP[2:0] = 111b;

// Enable TW0 and TOUT signal, Start TW0.

(3). Enable watchdog.

This process set watchdog register.

Enable watchdog reset.
 WDT\_INT\_RESET[0] = 1b;
 When the TW0 counts out, the system will reset, or there is something wrong with TW0.

# Appendix A Timer Driver Function

# A.1 Timer Driver Function List

The following table shows the timer driver interface functions:

Class	Function Name	Function Detail	
	em1_timer_init	Initialize the timer.	
	em1_timer_start	Start the timer.	
	em1_timer_stop	Stop the timer.	
	em1_timer_pause	Pause the timer.	
	em1_timer_resume	Stop the timer.	
	em1_timer_get_config	Get configure of timer.	
	em1_timer_int_ti0	TI0 interrupt handler.	
	em1_timer_int_ti1	TI1 interrupt handler.	
	em1_timer_int_ti2	TI2 interrupt handler.	
Driver	em1_timer_int_ti3	TI3 interrupt handler.	
Function	em1_timer_int_tw0	TW0 interrupt handler.	
	em1_timer_int_tw1	TW1 interrupt handler.	
	em1_timer_int_tw2	TW2 interrupt handler.	
	em1_timer_int_tw3	TW3 interrupt handler.	
	em1_timer_int_tg0	TG0 interrupt handler.	
	em1_timer_int_tg1	TG1 interrupt handler.	
	em1_timer_int_tg2	TG2 interrupt handler.	
	em1_timer_int_tg3	TG3 interrupt handler.	
	em1_timer_int_tg4	TG4 interrupt handler.	
	em1_timer_int_tg5	TG5 interrupt handler.	

	Table A-1	Timer	Driver	Function	List
--	-----------	-------	--------	----------	------

# A.2 Timer Driver Function Detail

#### A.2.1 Initialize Timer

#### [Function Name]

em1\_timer\_init

#### [Format]

DRV\_RESULT em1\_timer\_init(uchar timer\_num, uchar tin\_src, uint div);

#### [Argument]

Parameter	Туре	I/O	Detail	
timer_num	uchar	I	Timer number	
tin_src	uchar	I	Timer clock source	
div	uint	I	PLL3 divisor	

#### [Function Return]

DRV\_OK: The function executes successfully.

DRV\_ERR\_PARAM: The input parameter is error.

#### [Flow Chart]





#### **Note:** y = 0, 1, 2 or 3.

xxx = TI0/TI1/TI2/TI3/TW0/TW1/TW2/TW3/TG0/TG1/TG2/TG3/TG4/TG5.

#### [Note]

(1). Check the parameter valid.

The number of timer should not exceed the max number. The clock should be in the selectable clock source. 21/34

#### A.2.2 Start Timer

#### [Function Name]

em1\_timer\_start

#### [Format]

DRV\_RESULT em1\_timer\_start(uchar timer\_num, uint setting\_value);

#### [Argument]

Parameter	Туре	I/O	Detail
timer_num	uchar	I	Timer number
setting_value	uint	I	Timer setting value

#### [Function Return]

DRV\_OK: The function executes successfully.

DRV\_ERR\_PARAM: The input parameter is error.

#### [Flow Chart]



Figure A-2 Start Timer

**Note:** xxx = TI0/TI1/TI2/TI3/TW0/TW1/TW2/TW3/TG0/TG1/TG2/TG3/TG4/TG5.

#### [Note]

(1). Check the parameter valid.

The number of timer should not exceed the max number.

#### A.2.3 Stop Timer

#### [Function Name]

em1\_timer\_stop

### [Format]

DRV\_RESULT em1\_timer\_stop(uchar timer\_num);

#### [Argument]

Parameter	Туре	I/O	Detail
timer_num	uchar	I	Timer number

#### [Function Return]

DRV\_OK: The function executes successfully.

 $\mathsf{DRV\_ERR\_PARAM}$ : The input parameter is error.

#### [Flow Chart]





Note: xxx = TI0/TI1/TI2/TI3/TW0/TW1/TW2/TW3/TsG0/TG1/TG2/TG3/TG4/TG5.

#### [Note]

(1). Check the parameter valid.

The number of timer should not exceed the max number.

#### A.2.4 Pause Timer

#### [Function Name]

em1\_timer\_pasue

#### [Format]

DRV\_RESULT em1\_timer\_pause(uchar timer\_num);

#### [Argument]

Parameter	Туре	I/O	Detail
timer_num	uchar	I	Timer number

#### [Function Return]

DRV\_OK: The function executes successfully.

 $\mathsf{DRV\_ERR\_PARAM}$ : The input parameter is error.

#### [Flow Chart]



Figure A-4 Pause Timer

**Note:** xxx = TI0/TI1/TI2/TI3/TW0/TW1/TW2/TW3/TG0/TG1/TG2/TG3/TG4/TG5.

# [Note]

(1). Check the parameter valid.

The number of timer should not exceed the max number.

#### A.2.5 Resume Timer

#### [Function Name]

em1\_timer\_resume

#### [Format]

DRV\_RESULT em1\_timer\_resume(uchar timer\_num);

#### [Argument]

Parameter	Туре	I/O	Detail
timer_num	uchar	I	Timer number

#### [Function Return]

DRV\_OK: The function executes successfully.

DRV\_ERR\_PARAM: The input parameter is error.

#### [Flow Chart]



Figure A-5 Resume Timer

# **Note:** xxx = TI0/TI1/TI2/TI3/TW0/TW1/TW2/TW3/TG0/TG1/TG2/TG3/TG4/TG5.

# [Note]

(1). Check the parameter valid.

The number of timer should not exceed the max number.

#### A.2.6 Get Timer Configure

#### [Function Name]

em1\_timer\_get\_config

#### [Format]

DRV\_RESULT em1\_timer\_get\_config(uchar timer\_num, uint \*pRCR);

#### [Argument]

Parameter	Туре	I/O	Detail
timer_num	uchar	I	Timer number
pRCR	uint *	0	Timer count register

#### [Function Return]

DRV\_OK: The function executes successfully.

DRV\_ERR\_PARAM: The input parameter is error.

#### [Flow Chart]





#### **Note:** xxx = TI0/TI1/TI2/TI3/TW0/TW1/TW2/TW3/TG0/TG1/TG2/TG3/TG4/TG5.

#### [Note]

(1). Check the parameter valid.

The number of timer should not exceed the max number.

# A.2.7 Timer TI0 Interrupt Handler

# [Function Name]

em1\_timer\_int\_ti0

### [Format]

void em1\_timer\_int\_ti0(void);

# [Argument]

None.

#### [Function Return]

None.

#### [Flow Chart]



Figure A-7 Timer TI0 Interrupt Handler

# **ANNEX Modification History**

Number	Modification Contents	Author	Date
Ver 1.00	New version		Aug.4., 2009