



# **High Voltage Variable Frequency Speed Control System Operation Manual**



**SHENZHEN INVT ELECTRIC CO., LTD.**

# Content

<b>Content .....</b>	<b>2</b>
<b>Introduction .....</b>	<b>5</b>
<b>Precautions</b>	<b>1..... 6</b>
1.1 Safety notes.....	6
1.2 Relevant design standards of the high voltage variable frequency speed control systems.....	9
<b>Product Overview</b>	<b>2 ..... 12</b>
2.1 Technical features.....	12
2.2 Brief introduction of features .....	15
2.3 Product application fields .....	19
2.4 System composition and principle of work.....	20
2.4.1 System composition.....	20
2.5 Public technical parameters, specifications and models .....	24
2.5.1 Model description.....	24
2.5.2 Descriptions of data plate model .....	25
2.5.3 General parameters of the system .....	25
2.6 System profile and size parameters .....	28
2.6.1 System profile.....	28
2.6.2 System size parameters .....	29
<b>System transportation, storage and waste disposal</b>	
<b>3.....</b>	<b>36</b>
3.1 The transportation of high voltage variable frequency speed control systems.....	36
3.2 Arrival acceptance check .....	39
3.3 Storage and conditions .....	40
3.4 Storage of spare parts.....	41
3.5 Product waste treatment .....	42
<b>System InsTALLATION AND WIRING</b>	<b>4 ..... 43</b>
4.1 Installation of cabinet bodies .....	43

	Content
4.2	Installation of the high voltage parts ..... 48
4.3	Wiring of user terminals ..... 56
<b>System debugging and running</b>	<b>5 ..... 63</b>
5.1	Items of detection and confirmation before debug running ..... 64
5.2	Tests of powering on for control cabinets and tests after power-on 65
5.2.1	Powering on for control cabinet ..... 65
5.2.2	Testing..... 65
5.2.3	Test whether the power alarm is normal ..... 68
5.2.4	Test insulation resistance and voltage..... 69
5.2.5	Motor parameter setting ..... 70
5.3	Power on for main loop and power-on debugging ..... 70
5.3.1	High-voltage on whole machine..... 70
5.3.2	Correction of the unit voltage and temperature ..... 70
5.3.3	Disconnecting the motor and no-load running..... 71
5.4	Test with motors..... 71
5.4.1	No-load test with motors..... 71
5.4.2	Motor testing with load..... 72
<b>Operation of the variable frequency speed control system</b>	<b>6..... 73</b>
6.1	Description of bypass cabinet ..... 74
6.1.1	Auto-bypass cabinet ..... 75
6.1.2	Manual bypass cabinet..... 76
6.2	Control cabinet Introduction ..... 76
6.3	Operation steps of variable frequency speed control system..... 78
<b>Human-machine interface</b>	<b>7 ..... 82</b>
7.1	Keyboard ..... 82
7.1.1	The outline of keyboard and the position in the system..... 82
7.1.2	General introduction of the functions of the buttons on the keyboard 83
7.1.3	Description of keyboard operations ..... 85
7.2	Touch screen ..... 90
7.2.1	Introduction of the touch screen..... 90

7.2.2 The meanings of the touch screen operations .....	91
<b>Detailed Functional Description      8 .....</b>	<b>102</b>
P0 Group - Basic Function .....	102
P1 Group - Start and Stop Control .....	109
P2 Group - Motor Parameters .....	115
P3 Group - Auxiliary function .....	116
P4 Group - V/F Control Parameter .....	121
P5 Group - Input terminals .....	125
P6 Group - Output terminals .....	136
P7 Group – Human-Machine interface .....	144
P8 Group - Fault record .....	149
P9 Group - PID Control .....	151
PA Group - Multi-step speed control .....	157
Pb Group - Protection parameter .....	160
PC Group - Serial communication .....	166
Pd Group - Unit state query .....	168
PE Group - Factory Setting .....	179
<b>Warning information and fault solution      9 .....</b>	<b>180</b>
9.1 System Fault .....	181
9.2 Unit fault .....	185
9.3 The action after fault .....	187
9.4 Action after warning .....	188
9.5 Common Faults and Solutions .....	190
<b>Maintenance      10 .....</b>	<b>191</b>
10.1 Daily Maintenance .....	191
10.2 Periodic Maintenance .....	191
<b>Appendix      1 .....</b>	<b>197</b>
<b>Appendix      2 .....</b>	<b>200</b>
<b>Appendix      3 .....</b>	<b>208</b>

## Introduction

Thank you for purchasing the high voltage variable frequency speed control system of our company. CHH series high voltage variable frequency speed control systems are the multilevel high voltage variable frequency speed control systems manufactured by our company, and are applicable to 3-phase high voltage induction motors. Please read and comprehend the contents stated in this manual before use to ensure proper usage. Improper usage will result in abnormal running or the reduction of the service life.

This user manual is only applicable to the CHH Series High voltage variable frequency speed control systems of our company.



Please keep this manual with the variable frequency speed control system under safe custody for use whenever it is necessary.

# Precautions



1

## 1.1 Safety notes


### Sign convention

	<b>Danger:</b> If you ignore it or not handle properly, will result in bodily injury or even death.
	<b>Warning:</b> There is dangerous situation. If ignore it, may result in personal injury or serious damage to equipment.

### About usage

 <b>Warning</b>	
<p>✧ Before installation, wiring, operation, maintenance check. Ensure enough master to the contents of this manual for proper use. Ensure to be familiar with the machinery situation and all relevant safety precautions.</p>	
 <b>Danger</b>	
<p>✧ The high voltage variable frequency speed control systems of this series are only applicable to 3-phase high voltage induction motors, and cannot be put into other applications, as it would result in danger.</p> <p>✧ Under the circumstances of application where the failure of this product may cause accidents or loss, corresponding safety measures must be provided for emergencies.</p>	

### About transit

 <b>Warning</b>	
<p>✧ During moving, transporting and placing, equipment should be kept level.</p> <p>✧ Lifting equipment, ensure the lifting equipment strength is enough to lift and the process should be gentle.</p> <p>✧ Don't leave line head, paper, metal debris, tools and other foreign objects in</p>	

the variable frequency control system.

- ✧ When the components of the variable frequency control system are damaged, prohibit any installation and operation.
- ✧ Do install the fence if necessary (marked with high voltage danger signs). It shouldn't be removed while the equipment is running.

### About installation



**Danger**

- ✧ It is required to configure the grounding lines strictly in accordance with the requirement of the technical guidance in the manual and the national standard configurations.
- ✧ The wiring operation must be carried out by professional electrical technicians.
- ✧ The operation can only be carried out after confirming that the control circuit and the main circuit both have no voltage input.
- ✧ The I/O cables must be wired according to the instructions, and no error is allowed, otherwise the equipment may be damaged.
- ✧ Confirm that the input power supply complies with the requirement of the product technical specifications.
- ✧ The I/O lines must meet the requirement of insulation and capacity.
- ✧ The high voltage frequency inverter should be installed in fire-retardant materials, such as metal trestle, concrete floor surface.
- ✧ Don't place flammable items near the cabinet of the high voltage frequency inverter, including equipment drawings and manual, etc.

### About wiring



**Danger**

- ✧ A high voltage circuit breaker must be equipped at the power supply side of the high voltage frequency inverter for circuit protection.
- ✧ Reliable grounding is required.

- ✧ The wiring must be implemented under the guidance of the professionals of our company, according to the relevant electrical safety standards.
- ✧ The main body of the equipment must be installed in place before the wiring operations.
- ✧ It is required to confirm the consistency of the phase number of the input power and the rated input voltage with the ratings of the frequency inverter.
- ✧ The output terminals (U, V and W) must not be connected to AC power supplies.
- ✧ The I/O cables are accord with relevant national or industry standards for insulation, capacity and other requirements.

### About operation



#### **Danger**

- ✧ The variable frequency speed control system can be connected to the power supply only after the electrical cabinet doors are all closed, and the cabinet doors must not be opened after the power supply is connected.
- ✧ The switch must not be operated with wet hands.
- ✧ When trip and rebooting occurs, the peripheral system specially designed shall be able to guarantee personal and equipment safety.
- ✧ When the variable frequency speed control system is switched on, even if it is in the stopping state, the terminal may still be charged and must not be touched.
- ✧ The start-stops of the high voltage frequency inverter shall not be operated using the methods of connecting or disconnecting the main circuit.
- ✧ Control cabinet and other cabinet use optical fiber isolation technology and there is no high voltage, but it can be operated by authorized personnel.
- ✧ Don't disconnect the fan's power supply during operation; otherwise this will lead to overheating damage to system equipment.
- ✧ Confirm that the good ventilation system is installed indoors, maintain the ambient temperature at  $-5 \sim +45^{\circ}\text{C}$ .
- ✧ The operation of the input cabinets, phase-shifting transformer cabinet, power unit cabinet and the bypass cabinet must comply with high-pressure



operating procedures.

- ✧ The input cabinets, phase-shifting transformers cabinets, power unit cabinet and the bypass cabinet are danger zone, so don't open the door during operation after power on (system includes a locking device).

#### About maintenance and replacement



##### Warning

- ✧ Maintenance repair and replacement are completed by the relevant qualification requirements personnel in accordance with relevant operating procedures.
- ✧ Please don't touch any part inside of the cabinet body, if the voltage and temperature is not ensured.
- ✧ Allow to check the variable frequency control system after high-voltage power cut off for 30 minutes and the power unit indicator light turns off.
- ✧ Grounding resistance should often check according to the requirements of equipment operation and national standards. If grounding resistance does not meet the requirements, it will be dangerous.

#### About disposal



##### Warning

- ✧ The discarded parts and components shall be disposed of as industrial waste.

## 1.2 Relevant design standards of the high voltage variable frequency speed control systems

The design and manufacturing of CHH Series high voltage variable frequency speed control systems are referred to the latest version of national standards (GB or GB/T), the standards of International Electrotechnical Commission (IEC) and International System of Units (SI). As the lowest design technical indices, the technical parameters of the relevant parts can meet the

requirements of the national standards (GB or GB/T) and the standards of International Electrotechnical Commission (IEC).

Part of the technical standards referenced by the design:

IEC 76	Power Transformers
IEC 529	European (ECC) water protection specifications
IEC 1131/111 PLC	Correlative norms
IEC 68	Correlative tests
IEC68-2-6	Anti-vibration standards
IEC68-2-27	Anti-impact standards
IEC 1175	Design of signals and connections
IEC 801	Electro-magnetic radiation and anti-surge-interference
IEC 870	Communication protocol;
IEC1000-4-2	ESD immunity test
IEC1000-4-3	RF radiation electromagnetic field interference-resistant test
IEC1000-4-4	First Transient/Burst Immunity test
IEC1800-3	Standards of EMC conduction and radiated interference
EN50082-2	General standards of industrial environment
IEEE519	Recommended Practices and Requirements for Harmonic Control in Electrical Power Systems
89/336EC	CE Mark
NFPA 70	State Electrical Appliance Code
NFPA 77	Recommended anti-electrostatic methods;
OCMA NWGIREV2	Noise Level Norms
ISO/IEC 11801	International electrical wiring
NEMA	American National Electrical Manufacture Association
GB 12326	Quality of electric energy supply - Admissible voltage fluctuation and flicker
GB/T 14549	Quality of electric energy supply - Harmonics in public supply network
GB 1094.1~1094.5	Power transformers
GB 6450	Dry-type power transformers

---

GB/T 10228	Specification and technical requirements for dry-type power transformers
GB 17211	Loading guide for dry-type power transformers
GB 311.1	Insulation co-ordination for high voltage transmission and distribution equipment
DL/T 620	Overvoltage protection and insulation coordination for AC electrical installations
GB/T 3859.1	Semiconductor converters - Specification of basic requirements
GB/T 3859.2	Semiconductor converters - Application guide
GB/T 3859.2	Semiconductor converters - Transformers and reactors
JB4276	Technical specifications for the packing of power converter
GB/T 13384-1992	General specifications for packing of mechanical and electrical product
GB/T4064-1983	General guide for designing of electrical equipment to satisfy safety requirements
GB4028-1993	Degrees of protection provided by enclosures (IP code) and other relevant standards currently used

---

## Product Overview

## 2

### 2.1 Technical features

CHH Series high voltage variable frequency speed control systems are the voltage-source variable frequency speed control systems of a new generation featuring direct output of high voltage designed and manufactured by our company, implementing a perfect high voltage waveform output via the cascade of multi-level H-Bridge power units, and can directly drag the high voltage asynchronous motors without the need of boosting, and without the necessity of additional installation of any wave filter; the harmonic index complies with the most strict requirements of IEC (International Electrotechnical Commission) and GB (national standard) on grid harmonic. CHH Series high voltage variable frequency speed control systems are applicable to three-phase alternating current motor under standard high voltage (3kV, 6kV, 10kV), providing the following features:

#### **1 Small content of input harmonic**

CHH Series high voltage variable frequency speed control systems adopt trans-phase multiple rectifying technology on the power supply side; the harmonic on the grid side has little pollution and high power index, meeting the requirement of GB 14549-93 standard and IEEE std 519-1992 power quality standard on the harmonic distortion of voltage and current, and will not produce any harmonic interference to the other electrical equipment on the same grid.

#### **2 Low output harmonic**

CHH Series high voltage variable frequency speed control systems adopt the trans-phase multiple (PWM) pulse-width modulation technology on the output side, with very little output harmonic, and can adapt to various kinds of motors without the necessity of output filter equipment. Since the output voltage has low distortion and good sine degree of waveforms; the motor has low running noise, small torque pulsation and low productivity of heat.

#### **3 High power factor**

CHH Series high voltage variable frequency speed control systems adopt the trans-phase multiple (PWM) pulse-width modulation technology, and can

maintain high power factors in the full speed range, with the full load power factor of over 0.95, thereby reducing the issues of low utilization rate of the users' power transformer equipment and the power factor compensation on the user end caused by the low power factors.

#### **4 Strong voltage adaptability**

The input voltage has strong adaptability, allowing the fluctuating of grid-side voltage between 10%~15%. AVR function is provided to automatically adjust the output voltage according to the fluctuation of the grid voltage. CHH Series high voltage variable frequency speed control systems can continue run when the grid voltage fluctuate less than 85% ~65% rating or greater than 110% ~120% rating in a short time.

#### **5 Supporting smooth rebooting after power recovery**

While running, after the instantaneous power interruption of the grid and the recovery of the running conditions of the re-power-up system, if corresponding function codes are configured, then the system can be rebooted automatically after power-up. If the start-up mode is set to Rotation speed tracking Start-up, then the high voltage variable frequency speed control systems can automatically detect the rotation speed of the motors in 2.0 seconds, implementing no-impact reboot and recovering the operation to the configured state, avoiding the impact caused by the interference of electricity and ensuring the continuous operation reliability for the running of motor, thereby avoiding the loss caused by unnecessary shut-downs.

#### **6 High reliability and convenient maintenance**

The IGBT power module of CHH Series high voltage variable frequency speed control systems has the relatively large design margin of voltage and current; the triggering and overcurrent protection of the IGBT module uses the specialized driver module circuit, providing very high reliability.

CHH Series high voltage variable frequency speed control systems use optical fiber for the transmission of control signals, the electrical cabinets and PCBs of all functions are provided with reliable electromagnetic shielding features.

CHH Series high voltage variable frequency speed control systems adopt the modular design of "Power electronic building blocks" type for implementing the perfect structural process design, the unit-components of the same sizes are designed for universality; if any failure occurs, they can be replaced with

simple tools within a few minutes, very conveniently and easily.

## **7 Alarm and failure protection functions**

CHH Series variable frequency speed control system provide abundant features of alarming and protections, wherein over 11 kinds of failure messages related to the power units are already provided, all of which can be examined using the function codes in PD group.

If any failure occurs, the variable frequency speed control system can automatically record the information of the running environment of the last 3 failures, and the touch screen can record more.

## **8 Power unit bypass features:**

When any failure occurs to a certain power unit of the variable frequency speed control system, the power unit can be bypassed through the bypass function, and the frequency inverter shall be derated for further running. Users can choose manual bypassing or automatic bypassing of the unit by manipulating the function codes.

## **9 Soft start with no surge current**

CHH Series high voltage variable frequency speed control systems have the Soft start capability to which no other system can compare. The start-up time shall be configured by the user. The internal function of over-current stall acceleration was also provided for suppressing the impact current produced at the start-up of the motor, ensuring the safe running of the motor and lengthening its service life, and to enable the rapid start-up of the grids and motors with no impact. This feature can also effectively avoid the breaking of electric squirrel cage bar in the motor and other failures of motors.

## **10 Reducing motor abrasion, saving maintenance costs**

Blower, pumps and other loads use CHH Series high voltage variable frequency speed control systems for adjusting the rotating speed of the motor to adjust the output, which not only fulfills the objective of energy saving, but also significantly reduces the mechanical abrasion of the motor and its loads, saving maintenance costs for the users.

## **11 Abundant user terminal interfaces**

Standard CHH Series high voltage variable frequency speed control systems shall be equipped with abundant I/O ports: 3-channel analog inputs, 4-channel analog outputs, 16-channel digital inputs, 8-channel relay outputs, 1-channel

high-speed pulse input and 1-channel high-speed pulse output. All I/O ports are programmable, which facilitates the users to use these ports to build up their own application system, and also guarantees the system has good extensibility.

### **12 Abundant human-computer interface features**

The human-machine interaction of CHH Series high voltage variable frequency speed control systems adopt the dual configuration of touch screens and digital keyboards, providing abundant functions of setting, display and operations and friendly human-machine interface. Users can conveniently understand the running state information of the system via the interfaces, and implement the control to the high voltage variable frequency speed control systems according to the requirement of process control.

### **13 Reduce the abrasion of motor and the cost of maintenance**

Loads, such as fans and pumps can apply CHH high voltage variable frequency speed control system to adjust the motor output. This method is not only good for energy-saving, and also for reducing the abrasion of motor and loads and the cost of maintenance.

## **2.2 Brief introduction of features**

### **1 Frequency settings**

Supporting multiple ways for specifying the running frequency, such as:

- 1) Specifying by keyboard
- 2) Specifying by communication (the touch screen uses this scheme)
- 3) Specifying by analog signal inputs
- 4) Specifying by high-speed pulse
- 5) Specifying by adjusting the PID control: automatically adjusting the frequencies through the comparison of PID specifying and feedback. This is particularly convenient when applied in constant pressure water supply systems.
- 6) Multi-stage speed specifying: multiple frequency bands and the acceleration/deceleration time can all be specified in the variable frequency speed control system. These frequency bands can be switched flexibly by the selecting through the terminals.
- 7) Also, for the flexibility of the control of running frequencies, CHH Series

frequency inverters support 2 frequency sources, either of which, or the combination of the sum, difference and maximum values of which can be selected to be used as the actual running frequency.

Users can not only use the frequencies to control frequencies, but are also allowed to flexibly perform fine-tunings of increasing or decreasing to the running frequency by pressing the up/down buttons or manipulating the digital terminals.

For the settings related to running frequency, please refer to the descriptions of the function codes in P0 Group.

## **2 Acceleration/Deceleration time**

CHH Series high voltage variable frequency speed control systems support 4 groups of acceleration/deceleration time. Users can choose the current acceleration/deceleration time by various combinations of the multi-functional terminals.

## **3 Running control methods**

There are three different ways of starting up, meeting the application requirements on different occasions.

- 1) Direct start-up;
- 2) DC braking first, and then start (as for the fan-type loads, the inversion phenomenon exists; first ensure the rotating speed of the motor to be zero by the DC braking, then start the motor, in order to avoid the rush current being generated while starting up);
- 3) Rotation speed tracking start-up: the variable frequency speed control system will firstly examine the current rotating speed of the motor, and then directly start up based on it.

2 Ways of stopping:

- 1) Deceleration stop;
- 2) Free stop.

Supporting the selections of 3 different start-stop control command channels, including:

- 1) Keyboard control;
- 2) Terminal control;
- 3) Communication control.

The settings of the start-up and shut-down of the variable frequency speed



control system shall refer to the descriptions of the relevant function codes in P1 Group; for the settings of the start-stop control command channels, please refer to the descriptions of the function codes in P0 Group.

#### **4 AVR function**

CHH Series high voltage variable frequency speed control systems can automatically adjust the duty cycle of the output PWM signals according to the fluctuation of the grid voltage, thereby reducing the impact of the fluctuation of the grid voltage on the output voltage. Users can choose whether to enable the AVR function in P0 Group.

#### **5 Miscellaneous functions**

CHH Series variable frequency speed control systems support the settings of the inching function and the hopping frequency, the usage of these functions is as follows:

- 1) Inching function: This function is mainly used for debugging, and is capable of individually setting the inching frequency and acceleration/deceleration time.
- 2) Hopping frequency: CHH Series variable frequency speed control system can specify 2 hopping frequency points at most, which are mainly used for avoiding the resonance points in the machineries, and preventing the equipment from being damaged due to resonances.

For the information of the detailed settings, please refer to the relevant description of the function codes in Group P3.

#### **6 Torque increase function controlled by V/F**

CHH Series variable frequency speed control system provides the function of low-frequency torque increasing, which is mainly used to solve the problems of lack of magnetic flux led by the voltage loss caused by stator resistors under low-frequency. Users can specify the torque increase value and the speed range of the torque increase in the function codes in Group P4.

#### **7 Selections of multiple V/F curves**

CHH Series variable frequency speed control system provides multiple forms of V/F curves (e.g. multi-points V/F curves, power of 1.3, power of 1.7, V/F curves to power of 2.0), with which various load requirements can be met. Users can choose the suitable V/F curves among the function parameters in Group P4.

## **8 The configuration of programmable user terminals**

Standard CHH Series high voltage variable frequency speed control systems are equipped with abundant I/O terminals and the terminals are all programmable, thereby guaranteeing the flexibility and extensibility of the system. For the detailed terminal functions, please refer to the detailed specifications of the function codes in Group P5 and P6.

## **9 Real-time monitoring of running parameters**

CHH Series high voltage variable frequency speed control systems provide abundant parameter monitoring functions. In the running state, it is allowed to monitor the running frequency, given frequency, grid voltage, output voltage, output current, running speed, output power, output torque, PID specifying, PID feedback, terminal state, analog input value and time.

In the stopping state, it is allowed to monitor the given frequency, grid voltage, terminal state, analog input value and the current stage of the multi-stage speed.

Users can select the monitoring object to be displayed using the function codes, and can also examine the relevant parameters with the touch screen. The monitoring objects are viewed by the keyboard via the relevant function codes in Group P7.

## **10 PID control**

PID control function can realize the closed-loop application similar to the constant water supply; it provides flexible settings of PID parameters to meet the requirements of the users on different occasions. For the details, please refer to the detailed specifications of the function codes in Group P9.

## **11 Multi-stage speed control**

For the systems requiring frequent speed changes, CHH Series variable frequency speed control system can provide the running modes of multi-stage speed. Users can flexibly choose the speed stage currently used via the terminals. For the detailed settings of multi-stage speed, please refer to the specifications of the function codes in Group PA.

## **12 Fault protection functions**

CHH Series variable frequency speed control systems provide abundant functions for protection; some functions can be flexibly configured through the parameters of the function codes, such as: overvoltage stall, overcurrent stall,

phase loss detections, etc. For the details, please refer to the detailed specifications of the function codes in Group Pb.

The parameters in Group Pd can also be configured to shield the failure information of certain power units.

The information of the running environment of the variable frequency speed control system at the times of recent 3 failures are recorded in the parameters in Group P8, in the meantime, the failure information of the corresponding power units shall be displayed in the function codes in Group Pd.

CHH Series high voltage variable frequency speed control systems also support the alarming function. While alarming: system uses acoustic-optic prompts without shutdown, the system will automatically reset that alarm according to the fixed period of time, users can select whether the alarming function is shielded and configure the reset interval time of alarming.

### **13 Modbus communication function**

CHH Series variable frequency speed control systems provide the support of standard Modbus communication protocols. Users can use their own systems to implement the control and set the frequency inverter through Modbus protocols, for the detailed relevant information about Modbus, please refer to the detailed description of the function codes in Group PC.

**Note: The touch screen and the frequency inverter are connected by using Modbus protocols; if the touch screen is used, users will not be able to use Modbus communication.**

## **2.3 Product application fields**

CHH Series high voltage variable frequency speed control systems are mainly applied to blowers and pumps and on other occasions when a great amount of energy can be saved through speed control. The detailed applications are as follows:

Thermal power: draught fans, supply blowers, dust collecting fans, compressors, water supply pumps, mortar pumps, etc.

Metallurgical mining: draught fans, ventilation fans, dust collecting fans, sand pumps, descaling pumps, centrifugal feed pumps, etc.

Petrochemical: draught fans, gas compressors, injection pumps, submersible pumps, main pipe pumps, boiler water supply pumps, brine pumps, mixers,

etc.

Cement manufacturing: kiln draught fans, raw meal grinding draught fans, pressure supply blowers, main dust collecting fans, cooler dust collecting fans, cooler exhaust fans, preheating tower blowers, sorting device blowers, kiln gas blowers, etc.

Water supply and sewage treatment: sewage pumps, clear water pumps, mixed flow pumps, oxygen delivery blowers, etc.

Others: Drive mechanical devices, wind turbines, wind tunnels, etc.

## **2.4 System composition and principle of work**

CHH Series high voltage variable frequency speed control systems adopt power unit series connecting technology, which not only solves the problem of device withstand voltage, but also solves the problem of loop current, the trans-phase overlapping of inter-level output voltage greatly improves the harmonic performance of the system output voltage and decreases the  $du/dt$  of the output voltage, lowering the input side harmonics through current multiple technology, and reducing the harmonic pollution to the grids.

The main control part of CHH Series high voltage variable frequency speed control systems use Digital Signal Processor (DSP) as the control core, supplemented by SLSI programmable logic devices (FPGA), analog input (AI), analog output (AO), digital input (SI), relay output (RO) units.

The human-machine interfaces are composed of digital keyboards and touch screens.

The control signals of the main control part and the unit control part are transmitted through optical fiber, effectively avoiding electromagnetic interference and guaranteeing the reliability of the transmission of the system control signals.

### **2.4.1 System composition**

The overall structure of a high voltage variable frequency speed control system of CHH Series is composed of phase-shifting transformer cabinets, power unit cabinets and control cabinets, manual switching cabinets and automatic switching cabinets can also be equipped according to the user's requirements in actual use.




Figure 2.1 Outline schematic drawing of the frequency inverter

### 1 Transformer cabinet

The cabinet is equipped with a phase-shifting transformer on the inside, the phase-shifting transformer adopts the dry-type structure, with the insulation level of Level-H; it also adopts the connection method of trans-phase prolonged edge delta, reducing the grid-side harmonics of the high voltage variable frequency speed control system. The basis of the phase-shifting transformer is connected to the load-bearing framework of the cabinet body through screw bolts.

The input of the phase-shifting transformer cabinet is 3-phase high voltage (through the bypass cabinet). The output of the phase-shifting transformer cabinet is 3-phase low voltage signals forming certain electrical angle between each other after the shape alteration of the prolonged edge delta, each of the signals shall be separately connected to the input side of the power unit of each phase.

The phase-shifting transformer cabinet can monitor the temperature of the phases of the phase-shifting transformer in real time, and provide the functions of overheating alarm and failure protection. The default configuration of the system is that when the temperature of the phase-shifting transformer is over  $130^{\circ}\text{C}$ , the system will prompt an alarm message but will not stop; when the temperature is over  $150^{\circ}\text{C}$ , the system will start the over-temperature failure protection and freely stops.

### 2 Power unit cabinet

The power unit cabinet is used for placing power units; the main control

cabinet uses fiber communication to control the actions of the power units. Every power unit is pushed in through the front door of the power unit cabinet and fixed on the power unit cabinet with screws (fixed through the FRP on the rear or under the rear). The sensor of output voltage and current shall also be placed into the power unit cabinet.

The input of the power unit cabinet is connected to the output of the phase-shifting transformer; the output signal from the power unit on each phase shall be connected in series one after another to establish a 3-phase voltage output to be connected to the bypass cabinet, in order to control the operation of the motor.

The Input 3-phase electricity of the power unit shall be wired through the backdoor of the power unit cabinet; the output of the 3-phase power unit shall be separately connected using copper bars, connecting the connecting terminal on the side close to the phase-shifting transformer cabinet in to the bypass cabinet (or lead-in cabinet) through cables; connecting the starting points of the 3 phases on the side close to the main control cabinet together with copper bars to establish the midpoint of a star-shaped connection.

The power unit cabinet is used for installing and placing high-voltage power units, the power unit uses an H-bridge structure, the output side is directly connected in a series, composing the high voltage output of the high voltage frequency inverter. The input of the power unit is 3-phase rectifying input, which corresponds to the output of the phase-shifting transformer. The control panel interacts with the power unit through the signals of optical fibers, the main transmission signal is the drive signal, failure and alarm signals and other control signals of power units.

The sensor of output current and the rotating speed tracking circuit board are installed in the interior of the power unit cabinet.

### **3 Control cabinet**

The control cabinet is the brain of the entire variable frequency speed control system. It uses a separate UPS for power supply. The UPS has 2 channels of power input (main and standby power supply), when the main power supply is invalid, the system will automatically switch to the standby power supply. When the UPS is broken but one channel of the main standby power supply is still valid, the electricity for the control cabinet will be provided by the main

standby power supply. When the UPS or one channel of the main standby power supply fails, the system will prompt an alarm, which ensures that the system can be used in the worst power supply environment.

The input signals of the control cabinet are: the contactor state signal of the bypass cabinet (according to the configuration), I/O voltage, current detection signals, the feedback signal of each power unit and the users operation via the human-machine interface, etc.

The output signals of the control cabinet are: the control signal of the power units (optical fiber), the control signal of the fans and the contactor control signals of the bypass cabinet.

Touch screens, keyboards and other human-machine interfaces area all installed on the control cabinet.

The programmable terminals open to users for using are also installed on the control cabinet.

#### **4 Bypass cabinet**

CHH100 Series of the high voltage frequency inverter provide several standard bypass cabinets for users to select. The bypass cabinets mainly realize the functions below:

User I/O connection terminals; power frequency/variable frequency conversion function; relevant affiliated electrical protection measures; in the meantime, the insulation of the phase-shifting transformer with the distribution system is also provided.

The input of the bypass cabinet is the users' 3-phase high voltage distribution; it shall be connected to the phase-shifting transformer via K1 (QS1).

The output of the bypass cabinet is the 3-phase frequency conversion output of the power unit cabinet; it will be directly connected to the motor via K2 (QS2).

The bypass cabinet also provides the power frequency bypass contactor K3 (QS3), once any failure occurs to the frequency inverter, users can directly switch the motor to the state of power frequency via the vacuum contactor K3 (QS3) to effectively guarantee the consistent running of the system. Inside the bypass cabinet, K2 and K3, QS2 and QS3 implement the interlocking through logic.

The current transformers are installed inside the bypass cabinet to provide the

actual input voltage and current information to the control cabinet.




Figure 2.2 Schematic drawings of Manual and automatic bypass cabinets  
As shown in the drawing above, this is a typical configuration of bypass cabinets, wherein the QS1, QS2 and QS3 are the manual knife switches; the K1, K2 and K3 are the vacuum contactors. Users can choose to use manual bypass cabinet or automatic bypass cabinet as needed.

## 2.5 Public technical parameters, specifications and models

### 2.5.1 Model description




Figure 2.3 Product model definitions of CHH Series frequency inverters



### 2.5.2 Descriptions of data plate model




Figure 2.4 Product Code of the high voltage frequency inverter

**CHH100 SERIES INVERTER**

**MODEL** CHH100-355-06

RATED POWER 355 kW RATED OUTPUT CURRENT 27

RATED INPUT VOLTAGE 6 kV OUTPUT VOLTAGE RANGE 0~6

RATED INPUT FRQ 50 Hz OUTPUT FRQ RANGE 0~120

深圳市英威腾电气股份有限公司  
ShenZhen INVT Electric CO.,LTD

Figure 2.5 Data plate of the high voltage frequency inverter

### 2.5.3 General parameters of the system

Items	Technical specifications
Rated capacity	236kVA~10000kVA
Rated power	185kW~8000kW
Input voltage	3/6/10kV +10% -15%
Input frequency	50/60Hz±10%
Number of power units on each phase	3 or 4 of 3kV; 5 or 6 of 6kV; 8 or 9 of 10kV
Input power factor	>97% (under rated load)
System efficiency	>96% (under rated load)
Output frequency	0~120Hz (continuously adjustable)

Items		Technical specifications
Output voltage		0~rated input voltage
Overload capacity		120% rated current protection for 60s; 150% rated current protection for 1s
Control interface		touch screen 、 keyboard
Acceleration/deceleration time		0.1~3600S can be set up.
Control characteristics		V/F control, multiple V/F curves are available to be selected
High/low voltage insulation method		High and low voltages are insulated by optical fiber
Communication		RS485 physical ports, supporting Modbus standard communication protocols
Digital input		16-channel digital inputs
Digital output		8-channel relay outputs
Analog input		3-channel analog input terminals AI1, AI2, AI3 AI1, AI2: 0~10V/0~20mA, AI3: -10V~10V
Analog output		4-channel analog output AO1~AO4, output range: AO1, AO2: 0~10V, AO3, AO4: 0~10V/0~20mA
High-speed pulse input		Range: 0~50kHz
High-speed pulse output		Range: 0~50kHz
Noise level		< 75dB
Harmonics		Meeting the requirements of national standard GB 14549-93 and IEEE 519-1992 power quality standards.
Protection functions	System fault	Acceleration overcurrent, deceleration overcurrent, constant speed overcurrent, acceleration overvoltage, deceleration overvoltage, constant speed overvoltage, grid undervoltage, motor overload, inverter overload, output missing phase, phase-shifting transformer overheating, external fault input ,

Items		Technical specifications
		communications failure, current-detect failure, EEPROM read and write failures, PID feedback disconnection fault, clock failure, illegally open door failure, fan failure, UPS power failure.
	Unit Fault	Uplink communications failure, downlink communications failure, dead area wrong, unit overvoltage, unit undervoltage, unit power failure, unit overheating, unit missing phase, unit power-down, VCE failure, hardware overvoltage failure, unit bypass failure.
Protection level		IP20
Cooling method		Forced-air cooling
Using environment		Indoors, altitude of below 1000m (the higher altitude shall be used after derating with additional correction factor), no corrosive, explosive gas or dust, no direct sunlight, etc.
Ambient temperature		-10℃~+40℃ (if >40℃, additional installation of forced-air cooling equipment)
Ambient humidity		5~95%, no condensation
Vibration		5.9m/s <sup>2</sup> below 0.5g




Figure 2.6 Relation chart of the altitude and derating index

## 2.6 System profile and size parameters

### 2.6.1 System profile




Figure 2.7 Outline structural chart of the high voltage frequency inverter




Figure 2.8 Inner schematic drawing of the high voltage frequency inverter

### 2.6.2 System size parameters

**Table of the Basic parameters of CHH100 Series of frequency inverter (6kV)**

Serial NO.	Model	Rated voltage (kV)	Rated capacity (kVA)	Rated current (A)	Motor power (kW)	Dimension W3×H×D (mm)	Stand ard weight (kg)	Inlet air flow (M3/H)	Manual bypass cabinet W1(mm)	Automat ic bypass cabinet W2(mm)	Isolated automatic bypass cabinet W5 (mm)
1	CHH100-185-06	6	236	23	185	3000×2690×1000	1990	5500	1000	800	1000
2	CHH100-0200-06	6	255	25	200	3000×2690×1000	1975	5500	1000	800	1000
3	CHH100-0220-06	6	280	27	220	3000×2690×1000	2015	5500	1000	800	1000
4	CHH100-0250-06	6	315	30	250	3000×2690×1000	2095	5500	1000	800	1000
5	CHH100-0280-06	6	350	33	280	3000×2690×1000	2095	5500	1000	800	1000
6	CHH100-0315-06	6	400	37	315	3000×2690×1000	2095	5500	1000	800	1000
7	CHH100-0355-06	6	440	42	355	3000×2690×1000	2255	5500	1000	800	1000
8	CHH100-0400-06	6	500	48	400	3000×2690×1000	2325	5500	1000	800	1000
9	CHH100-0450-06	6	560	54	450	3600×2690×1200	5600	12300	1000	800	1000

Serial NO.	Model	Rated voltage (kV)	Rated capacity (kVA)	Rated current (A)	Motor power (kW)	Dimension W3xHxD (mm)	Stand ard weight (kg)	Inlet air flow (M3/H)	Manual bypass cabinet W1(mm)	Automat ic bypass cabinet W2(mm)	Isolated automatic bypass cabinet W5 (mm)
10	CHH100-0500-06	6	600	60	500	3600x2690x1200	5700	12300	1000	800	1000
11	CHH100-0560-06	6	690	67	560	3600x2690x1200	6050	12300	1000	800	1000
12	CHH100-0630-06	6	750	75	630	3600x2690x1200	6200	12300	1000	800	1000
13	CHH100-0710-06	6	880	84	710	3600x2690x1200	6350	12300	1000	800	1000
14	CHH100-0800-06	6	980	95	800	3600x2690x1200	6500	12300	1000	800	1000
15	CHH100-0900-06	6	1100	106	900	3700x2690x1200	7390	19300	1000	800	1000
16	CHH100-1000-06	6	1250	118	1000	3700x2690x1200	7690	19300	1000	800	1000
17	CHH100-1120-06	6	1370	132	1120	3900x2690x1200	9040	27600	1000	800	1000
18	CHH100-1250-06	6	1500	146	1250	3900x2690x1200	9140	27600	1000	800	1000
19	CHH100-1400-06	6	1700	164	1400	3900x2690x1200	9270	27600	1000	800	1000
20	CHH100-	6	1900	185	1600	3900x2690x	9320	27600	1000	800	1000

Serial NO.	Model	Rated voltage (kV)	Rated capacity (kVA)	Rated current (A)	Motor power (kW)	Dimension W3xHxD (mm)	Stand ard weight (kg)	Inlet air flow (M3/H)	Manual bypass cabinet W1(mm)	Automat ic bypass cabinet W2(mm)	Isolated automatic bypass cabinet W5 (mm)
	1600-06					1200					
21	CHH100-1800-06	6	2200	220	1800	5900x2690x1200	11710	41500	1000	800	1000
22	CHH100-2000-06	6	2400	229	2000	5900x2690x1200	12000	41500	1000	800	1000
23	CHH100-2240-06	6	2700	261	2240	5900x2690x1500	12560	41500	1000	800	1000
24	CHH100-2500-06	6	3000	281	2500	5900x2690x1500	12930	41500	1000	800	1000
25	CHH100-2800-06	6	3300	324	2800	5900x2690x1500	13310	41500	1000	800	1000
26	CHH100-3150-06	6	3700	363	3150	7100x2970x1500	15395	58500	1000	800	1000
27	CHH100-3550-06	6	4500	428	3550	7100x2970x1500	16050	58500	1000	800	1000
28	CHH100-4000-06	6	5000	482	4000	7100x2970x1500	16800	58500	1000	800	1000

**Table of the basic parameters of CHH100 Series of frequency inverters (10kV)**

Serial NO.	Model	Rated voltage (kV)	Rated capacity (kVA)	Rated current (A)	Motor power (kW)	Dimension W3xHxD (mm)	Stand ard weight (kg)	Inlet air flow (M3/H)	Manual bypass cabinet W1(mm)	Automat ic bypass cabinet W2(mm)	Isolated automatic bypass cabinet W5 (mm)
1	CHH100-0220-10	10	295	17	220	3500x2690x1000	2860	5500	1000	800	1000
2	CHH100-0250-10	10	330	19	250	3500x2690x1000	2960	5500	1000	800	1000
3	CHH100-0280-10	10	360	21	280	3500x2690x1000	3030	5500	1000	800	1000
4	CHH100-0315-10	10	400	24	315	3500x2690x1000	3090	5500	1000	800	1000
5	CHH100-0355-10	10	450	27	355	3700x2690x1000	3110	11700	1000	800	1000
6	CHH100-0400-10	10	500	30	400	3700x2690x1000	3160	11700	1000	800	1000
7	CHH100-0450-10	10	570	33	450	3700x2690x1000	3220	11700	1000	800	1000
8	CHH100-0500-10	10	630	37	500	3700x2690x1000	3320	11700	1000	800	1000
9	CHH100-0560-10	10	710	41	560	3700x2690x1000	3390	11700	1000	800	1000
10	CHH100-0630-10	10	800	46	630	3700x2690x1000	3570	11700	1000	800	1000
11	CHH100-	10	870	51	710	4400x2690	8570	16400	1000	800	1000



Serial NO.	Model	Rated voltage (kV)	Rated capacity (kVA)	Rated current (A)	Motor power (kW)	Dimension W3xHxD (mm)	Stand ard weight (kg)	Inlet air flow (M3/H )	Manual bypass cabinet W1(mm)	Automat ic bypass cabinet W2(mm)	Isolated automatic bypass cabinet W5 (mm)
	0710-10					×1200					
12	CHH100-0800-10	10	980	57	800	4300×2690 ×1200	8770	16400	1000	800	1000
13	CHH100-0900-10	10	1100	64	900	4600×2690 ×1200	10230	28900	1000	800	1000
14	CHH100-1000-10	10	1200	71	1000	4600×2690 ×1200	10370	28900	1000	800	1000
15	CHH100-1120-10	10	1370	79	1120	4600×2690 ×1200	10590	28900	1000	800	1000
16	CHH100-1250-10	10	1500	88	1250	4600×2690 ×1200	10870	28900	1000	800	1000
17	CHH100-1400-10	10	1700	98	1400	4600×2690 ×1200	11120	28900	1000	800	1000
18	CHH100-1600-10	10	1900	112	1600	4800×2690 ×1200	12774	33100	1000	800	1000
19	CHH100-1800-10	10	2200	127	1800	5000×2690 ×1500	13494	33100	1000	800	1000
20	CHH100-2000-10	10	2400	141	2000	5000×2690 ×1500	13814	33100	1000	800	1000
21	CHH100-2240-10	10	2700	157	2240	5000×2690 ×1500	14242	33100	1000	800	1000

Serial NO.	Model	Rated voltage (kV)	Rated capacity (kVA)	Rated current (A)	Motor power (kW)	Dimension W3xHxD (mm)	Stand ard weight (kg)	Inlet air flow (M3/H)	Manual bypass cabinet W1(mm)	Automat ic bypass cabinet W2(mm)	Isolated automatic bypass cabinet W5 (mm)
22	CHH100-2500-10	10	3000	175	2500	5000x2970 x1500	14392	33100	1000	800	1000
23	CHH100-2800-10	10	3600	205	2800	5000x2970 x1500	14642	33100	1000	800	1000
24	CHH100-3150-10	10	4000	230	3150	7100x2940 x1500	18850	58100	1000	800	1000
25	CHH100-3550-10	10	4500	260	3550	7100x2940 x1500	19580	58100	1000	800	1000
26	CHH100-4000-10	10	5000	290	4000	7100x2940 x1500	19840	58100	1000	800	1000
27	CHH100-4500-10	10	5600	326	4500	7100x2940 x1500	20750	58100	1000	800	1000
28	CHH100-5000-10	10	6300	362	5000	8300x2970 x1500	22210	70200	1000	800	1000
29	CHH100-5600-10	10	7000	405	5600	8300x2970 x1500	22780	70200	1000	800	1000
30	CHH100-6300-10	10	8000	456	6300	10800x297 0x1500	30970	93600	1000	800	1000
31	CHH100-7100-10	10	9000	512	7100	10800x297 0x1500	32790	93600	1000	800	1000

**Note:** The outline dimensions of the high voltage variable

**frequency speed control systems listed in the table above are the standard sizes. Their outline dimensions may differ to the outline dimension of the high voltage variable frequency speed control systems listed in the table due to the requirements of the actual users.**

## **System transportation, storage and waste disposal**

### **3**

The functional unit electrical cabinets of CHH Series high voltage variable frequency speed control systems are assembled tested and packaged as a whole before delivery from factory. During the transportation, the cabinet bodies must be transported as a whole. To improve the reliability of the variable frequency speed control system, and avoid the high voltage variable frequency speed control system being damaged during the transportation, this chapter identifies the basic requirements for transportation and storage. The environmental requirements of transportation and storage specified in detail in this chapter must all be strictly abided by. Any violation of the relevant requirement in this chapter will influence the service life of the high voltage variable frequency speed control system.

### **3.1 The transportation of high voltage variable frequency speed control systems**

The outer packaging of CHH Series high voltage variable frequency speed control systems can endure the external impact from the sea, land or air transportation, but appropriate protection measures must be taken to avoid the pollution of water immersing and dust. Also, during the process of sea, air and land transportation, the impact of damage caused by mechanical external shocks and rough handling must be avoided. To realize correct shipping, disassembling and storage, please note that all relevant precautions and indication and instruction tags are marked on the packing boxes. We recommend entrusting logistic companies with a good reputation and credit with the lifting and transportation of high voltage variable frequency speed control systems.

Transportation: CHH Series high voltage variable frequency speed control systems can be transported by trucks, trains, airplanes, ships and any other vehicles. During the transportation, the products must be handled with care. Exposure to rain and sunlight are both strictly forbidden, no severe vibration, impact and upend is allowed.

Moving: the power unit cabinets, phase-shifting transformer cabinets and shifting cabinets can be packaged separately for moving. There are two moving methods:

- Forklifts
- Cranes

1. Ensure the maximum bearing weight of the forklift. The relieving (600mm~1200mm) should be at least 1.5m long and its thickness should be less than 90mm, so when the device is too long or too short, two forklifts can work together. While hoisting, it is required to be hoisted on the position designated. The geometric centre of the four tags is really the center of the device. Below is the figure:




Figure 3.1 Hoisting with package

In the bottom of the inverter, there are forklift holes. After unpacking, there are three moving methods:

- Cranes or chain hoisting
- Forklifts
- Rolling bars

Cranes or chain hoisting—Hoist via the rapes through the forklift holes and ensure the rape doesn't impact on the cabinet directly.




Figure 3.2 Cabinet hoisting

Forklift— Ensure the maximum bearing weight of the forklift. The relieving (600mm~1200mm) should be at least 1.2m long and its thickness should be less than 50mm and the width should be less than 50mm. While moving, a piece of wood is needed at the corner of the relieving in order to prevent the cabinet from damage.




Figure 3.3 Moving with forklifts

Rolling bars—this is the simplest method. Put rows of parallel rolling bars on the floor to move the cabinet. (The length of the rolling bar should exceed the thickness of the cabinet. The diameter is more than 50mm and the space between the rolling bars is more than 500mm).




Figure 3.4 Moving with rolling bars




Figure 3.5 Hoisting for high voltage inverters

### 3.2 Arrival acceptance check

After receiving the high voltage variable frequency speed control equipment that you ordered, if there is anything wrong with the products you ordered or they don't comply with the specifications that you ordered, please contact the agent from whom you order the equipment or contact the nearest office of our company.

- ① Check the data tags of the high voltage variable frequency speed control systems and confirm the models and specifications of the equipment you ordered.
- ② Check whether any damage has occurred during the handling and transportation on the appearance, such as damage to the cabinet body appearance, any deformation to the door and sideboards and any falling off of the inner devices, etc.

- ③ Open the cabinet door and check the situation inside the cabinet, and check for the occurrence of the loosening of the control cables, water immersion, as well as missing or damaged devices.
- ④ Contrasting to the supply lists, check if there's any shortage and other issues of the equipment that you ordered, to prevent the omission of parts.

**Note: Since the configuration requirements of the user to the high voltage variable frequency speed control systems are different, the configurations of the high voltage variable frequency speed control systems of same capabilities will also differ.**

### 3.3 Storage and conditions

Inappropriate methods of storage of power electronic equipment will affect the service lives of the equipment, or even result in the failure of the equipment.

Table – Storage environment conditions

Items	Specifications	
Storage temperature	-40~+70℃, the change of air temperature of less than 1℃/Min	Don't put in the places where condensation and freezing occurs due to acute changes of temperature.
Relative humidity	≤95%	
Preservation environment	Keep away from direct sunlight, dust, corrosive gas, flammable gas, oil mist, vapor or water dripping.	

General requirements:

- ① Don't place it directly on the ground; place it on appropriate supporting objects.
- ② If there is any impact of humidity, appropriate desiccating agent shall be provided: each unit of desiccating agent (30g) absorbs 6g of water content. According to the packaging materials used, you will need the desiccating agent of the following amounts: Polyethylene metal film: 10 units per square meter; aluminum metal film: 8 units per square meter.
- ③ Using polyethylene materials or aluminum metal film as the protective packaging can prevent the water content from infiltrating.



- ④ Regular inspections: During the whole storage period, the inspection of the storage state and packaging state of the equipment shall be carried out once a month. Focus, in particular, on mechanical damage and the damage caused by humidity, temperature or fire hazard. If the packaging is damaged or you have found that the equipment has been damaged, you should immediately check the equipment damage situation, and store the variable frequency speed control system according to the requirements mentioned above after repairing the damaged equipment.

### **3.4 Storage of spare parts**

After receiving CHH Series high voltage variable frequency speed control systems, check immediately whether there is any damage to the spare parts, and if any damage to the spare parts is found, please report it to our company. Our company will not undertake any product quality guarantee responsibility for the damages caused by external shocks or external environment within the product quality guarantee period. Within the quality guarantee period, to prevent the equipment spare parts from being damaged, please pay attention to the following items: there must be no vibration or impact at the storage place, and it is a requirement to prevent damage from moisture, frost, temperature, dust and gravels. The environmental conditions shall meet the requirements of temperature and humidity: The spare parts must be stored in a dry original packing box with no flying insects, and kept away from corrosive gas. The relative air humidity shall be less than 95%, and the storage temperature of the spare parts shall be  $-5^{\circ}\text{C}\sim+55^{\circ}\text{C}$ . The circuit boards must be stored in anti-static packing bags with no leakage of moisture-proof agent, and must be kept away from corrosive gases that will cause damage to the circuit boards or gases containing alkali-saline or other impurities and mustn't be frozen. If you find that the humidity has surpassed the maximum allowable extent in the air, environmental protection measures such as cooling, heating, dehumidifying and other methods shall be taken to guarantee the environmental conditions for storing the spare parts.

The power unit is equipped with electrolytic capacitors on the inside, the long-term power-off of the electrolytic capacitors will lead to the deterioration

of their electrical characteristics; therefore, the preservation shall be carried out in the method of electrifying once every year.

### 3.5 Product waste treatment



- ✧ When the product packs and the products are being discarded, they shall be treated as industrial waste, otherwise injury accidents or environmental pollution may occur.

The packaging of CHH Series high voltage variable frequency speed control systems shall be designed with the minimum usage of the packing materials that have adverse effects on the environment; some of the packing materials can be recycled and reused. The treatment of the packing materials shall comply with the national standard related to environmental protection.

While discarding the devices inside the high voltage variable frequency speed control systems, the electrolytic capacitors, PCBs, electronic components and other parts need to be treated with correct methods for any part of them not to cause harm to the surroundings. These treatment methods can refer to the national legislation and regulations to the environment protection.

---

## System Installation and Wiring

## 4

The main bodies of CHH Series high voltage variable frequency speed control systems are composed of the phase-shifting transformer cabinet, power units cabinet, bypass cabinets(optional), main control cabinets and others. Wiring cabinets or bypass cabinets are also included according to the user's choice, therefore, as for different projects, the arrangement and layout of the equipment shall be determined according to the appropriate positions, with the layout and installation diagrams provided.

### 4.1 Installation of cabinet bodies

#### 1 Requirement of running environment

The efficiency of CHH Series high voltage variable frequency speed control systems is over 96%, the loss of 4% will be basically converted into heat. Therefore, the cooling issue of the high voltage variable frequency speed control systems needs to be taken into consideration. If the installation environment of the high voltage variable frequency speed control systems is narrow and the ambient temperature is high, additional installation of forced-air cooling unit or air conditioning cooling devices is needed. It is recommended to adopt the exhaust air rate of larger than  $1\text{M}^3/\text{s}$  every 200kW of capacity during air cooling; and when air conditioning cooling is used, more than 4HP of air conditioners shall be configured for every 200kW of capacity.

#### 2 Requirements of space for cabinet placement

For the drawings of the cabinet dimension, outline dimension and the bottom plate installation of the variable frequency speed control system, please refer to the drawings related to engineering technical information. All cabinet bodies shall be installed according to the drawings and sufficient spacing shall be provided in the periphery, in order to guarantee the air flow, the maximum door swinging and the space required for maintenance, and also providing the channel for entering the installation basis (aisle spacing, etc.) and ensuring the space for the auxiliary equipment used for providing the transportation of the variable frequency speed control system.






Figure 4.1 Schematic Drawing 1 of installation requirements of the high voltage frequency inverter (Front view, unit: mm)



W=600, 800

Figure 4.2 Schematic Drawing 2 of installation requirements of the high voltage frequency inverter (Side view, unit: mm)



W1=600, 800

Figure 4.3 Schematic Drawing 3 of installation requirements of dual-row layout for high voltage frequency inverter (Side view, unit: mm)

The basic requirements of the widths of the surrounding channels of the cabinet are shown in the figure above and the table below.

Minimum width of the surrounding channels of high voltage variable frequency speed control systems		
Layout mode	Maintenance channel	Running channel
Dual-row layout	1m	2.0m
Single-row layout	1m	1.5m

The cooling air duct of the variable frequency speed control system is shown in the figure below. To guarantee sufficient cooling, it must be guaranteed that the distance between the top of the variable frequency speed control system and the roof complies with the requirement of the relevant national regulations. For further reducing ambient temperature, the user can install centralized ventilation air ducts for transmitting the hot air through centrifugal blower and directly lead it to the outside through the air ducts.




Figure 4.4 Schematic drawing of the cooling air ducts of the high voltage frequency inverter

### 3 The requirement of the foundation installation of the variable frequency speed control system

The cabinet bodies of CHH Series high voltage variable frequency speed control systems must be vertically installed onto the concrete casting foundation framework made of flat steel channels, the overall roughness of the surface shall be less than 5mm. The foundation must be made of non-combustible materials and have smooth and abrasion-free surface, and shall be moisture-proof and able to bear the weight of the variable frequency speed control system. The cable ducts must be made of non-combustible material and have smooth and abrasion-free surface, and shall be moisture-proof and dust-proof, providing the measures for preventing the animals from entering.





Figure 4.5 Schematic drawing of the basic requirements of installation of the high voltage frequency inverter

### 4 Installation of cabinet bodies

The high voltage variable frequency speed control system is composed of more than 3 cabinet bodies (this depends on the power size and the layout mode). According to the requirement, a single cabinet or multiple cabinets can be placed upon the foundation steel channels vertically using traveling crane or forklift. The phase-shifting transformer cabinet must be installed separately. The cabinet bodies shall be assembled, connected, positioned and aligned, then shall be directly welded onto foundation steel channels, the connecting wires inside the cabinets and the ones between the cabinets shall be installed under the guidance of the professional from our company.

In some cases, the power units shall be separately packaged for transportation, and they are installed into the power unit cabinets under the guidance of the professionals from our company after arriving at the destination.

	<ul style="list-style-type: none"><li>✧ It shall be installed onto the non-combustible structure made of basic steel channels, otherwise it may cause fire.</li><li>✧ Ensure that various kinds of fibers, paper scraps, sawdust, metal fragments and other foreign matters don't enter into the cabinet or adhere to the radiators; otherwise it may cause accidents or fire.</li></ul>
---	--

The following installation guide is applicable to the general installations in industrial environment. If the application in special environment and occasions is required, please make inquiry to our company for detailed installation procedures.

1. Before the machinery installation, please be sure to meet all environmental conditions described in the previous points.
2. Examine the basic level with level instruments. The allowable maximum overall roughness is less than 5mm. If the ground surface is not flat, then it must be smoothed.
3. Move to the installation position. Please refer to the requirement in Chapter 3.
4. Open all cabinet doors, and carefully inspect possible transportation damage of the variable frequency speed control system and the attached equipment thereof. If any part is damaged or missing, please immediately contact the technical service department of our company and the corresponding transportation company. Please note the opening methods of cabinet doors.
5. Check whether the cabinet door can be fully opened or closed; if not, the cabinet body needs to be adjusted. Examine the position-restraint locks on the doors: after the power is turned on, aside from the doors of the main control cabinets, no other front doors and back doors can be opened. The illegal opening of cabinet doors will trigger the alarm.
6. Perform the fine adjustment of the cabinet bodies, and fix the adjacent cabinet bodies tightly with binding bolts.

7. Under the guidance of the professionals of our company, connect the wiring inside the cabinet bodies, install and fix the power units.

**Note: Please pay attention to the methods for opening the cabinet door; forced opening of cabinet door is forbidden, otherwise the equipment will be damaged.**

## 5 Installation checking

Table of basic installation check items of plate cabinet:

Working procedure	Inspection items	Quality standard	Inspection methods and apparatus
Basic installation	Basic steel non-straightness	<1 mm/m	Pull wire for inspection
	Error levelness	(or <5 mm/full length)	Track level bar inspection
	Basic centerline error	±5mm	Inspect with ruler
	Plate cabinet basis and ground fixing mode	≤10mm	Inspect with leveler or communication pipes
	Elevation difference	Consistent to the ground elevation	Inspect with leveler or communication pipes
	Basic layout	According to the design	Inspect with contrast to the drawings
	Number of basic steel grounding points	>2 points	Inspect by observation
	Grounding connection	Firm, with good conduction	Inspect by wrenching and guiding

## 4.2 Installation of the high voltage parts

### 1 Standard requirement of high voltage distributions



The high voltage power supply needs to pass through the main circuit breaker and then shall be connected to CHH Series high voltage variable frequency speed control systems; it is allowed to close the main circuit breaker only after receiving the high voltage closing permit signal.

The high voltage power supply of the main circuit breaker shall be directly connected into the input terminal of the bypass cabinets (or incoming cabinets) of the variable frequency speed control system without the need of passing through the input reactor.

The variable frequency output of high voltage variable frequency speed control systems is directly connected to high voltage motors via the output terminals of the bypass cabinets (or incoming cabinets).



✧ The input and output terminals cannot be connected incorrectly, otherwise the high voltage variable frequency speed control systems will be damaged.

## 2 Wiring of the bypass cabinets of high voltage variable frequency speed control systems

Terminal ID		Terminal name	Remarks
Input	L1	Main circuit power supply input, 1 <sup>st</sup> phase sequence	Connect to 3-phase high voltage AC power supply, 1 <sup>st</sup> phase sequence
	L2	Main circuit power supply input, 2 <sup>nd</sup> phase sequence	Connect to 3-phase high voltage AC power supply, 2 <sup>nd</sup> phase sequence
	L3	Main circuit power supply input, 3 <sup>rd</sup> phase sequence	Connect to 3-phase high voltage AC power supply, 3 <sup>rd</sup> phase sequence
Output	U	High voltage frequency inverter output, 1 <sup>st</sup> phase sequence	Connect to 3-phase AC high voltage motor, 1 <sup>st</sup> phase sequence
	V	High voltage frequency inverter output, 2 <sup>nd</sup> phase sequence	Connect to 3-phase AC high voltage motor, 2 <sup>nd</sup> phase sequence
	W	High voltage frequency	Connect to 3-phase AC high

		inverter output, 3 <sup>rd</sup> phase sequence	voltage motor, 3 <sup>rd</sup> phase sequence
--	--	--	--

**Note:** The phase sequence of U, V and W output of the high voltage variable frequency speed control systems may be inconsistent with the phase sequence of power supply L1, L2 and L3; on the occasions when the power frequency power supply bypass is needed, please check the I/O phase sequences of the high voltage variable frequency speed control systems, and make the phase sequence of both consistent, otherwise the system may not work normally.

### 3 Requirements of equipment and cables

#### ◆ Main circuit breaker

The main circuit breaker may be the vacuum or gas insulation circuit breaker. It must not only meet the requirement of the supply voltage and current, but also the requirement of the rated voltage and current of the phase-shifting transformer on the primary side. Its basic electrical characteristic also has to be able to bear the closing impulse current of the transformer and the failure current caused by the secondary side short circuit of the transformer within 100ms, and won't cause trip.

#### ◆ Protective equipment

The high voltage switch on the power side of CHH Series high voltage variable frequency speed control systems shall be configured with reasonable protection, the setting of the protection definite value shall be carried out in reference to the following principles:

When the winding on the primary side or the incoming cables on the primary side of the phase-shifting transformer fails, the switch must conduct immediate trip. The setting value of the protection current must be sure to dodge the excitation surge current for switching-in no-load without trip (this can be set as 8 to 10 times of the rated current of the phase-shifting transformer).

The fault protection of the secondary side of phase-shifting transformers adopts the method of delayed trip. When short circuit failure occurs to the winding on the secondary side of the phase-shifting transformer, the cables connecting the secondary side of the phase-shifting transformer with system units, and the unit input bridge rectifier, the incoming switch can be flipped open. With short delay of protection, the time settings can be adjusted and can

be set to ensure the phase-shifting transformer of no trip will occur during the period of excitation surge current. The movement current setting value can be set as twice the rated current of the rectifying transformer, so as to ensure that when failure occurs on the secondary side of the rectifying transformer, trip will be performed within 500ms.

Overload protection (optional) is a long-time overload protection with the feature of inverse time limit, and can protect the long-time overload of transformers and cables.

If the system is part of a high-voltage large-capacity motor reconstruction project, the vertical protection of the high voltage motor shall quit during the variable frequency operation, and shall be put in during the power frequency bypass, the switching function needs to be realized in the technical schemes.

◆ **Primary side cables of transformers**

No special requirement to the cables between the primary side of the transformer and the circuit breaker is proposed. The rated voltage shall be consistent with the circuit voltage on the primary side. The rated current of cables shall comply with the protection setting value of the transformer. The reduced capacity shall be designed according to the maximum expected ambient temperature, cooling factors and the other factors required by local electrical regulations, and the installation shall be completed according to the standard for medium-voltage devices.

◆ **Cables which connects to the motors**

No special requirement of the Cables from CHH Series high voltage variable frequency speed control systems to the motors is proposed. It is recommended that the length to be no longer than 1000 meters, the case that the field cable length is larger than 1 kilometer shall be proposed in the order. The rated voltage of the cables is consistent with the corresponding motor models; the rated current of the cables shall comply with the motor models and the permit overload current for motor protection. The capacitance lowering of cables shall refer to the highest ambient temperature, cooling factors and the other factors required by local electrical regulations. The installation shall be completed according to the standard for high-voltage devices.

Since the waveforms of the output voltage and current of CHH Series high voltage variable frequency speed control systems are close to standard sine

waves, no special shielding is required for the cables. Therefore there is no need to take special measures for the common mode current.

#### **4 High voltage wiring**

The cabling of main power supply and the motor must comply with national standards, please refer to the specifications and recommendation of the cable manufacturers.

- ◆ It is recommended to use separately shielded armored 3-phase cables; if single-phase cables are used, the combination of three cables is required to ensure the EMC characteristics.
- ◆ If the area of the shielding layer of the cables is less than 50% of the area of a 1-phase cross section, then an additional grounding line must be provided to prevent the shielding layer of the cables from overheating.
- ◆ The cable terminations must comply with the requirement of the cable manufacturers, the cables connectors must be installed at the terminations.
- ◆ The grounding of the grounding terminals of the corresponding cables must comply with the national standard of electrical installation.

#### **5 Equipment grounding**

The user shall be sure to provide good grounding wires with grounding resistance of less than 4 ohms, copper bars shall be used for connecting the cabinet bodies of CHH Series high voltage variable frequency speed control systems, the connecting wires between the grounding points of whole sets of devices and the grounding points of grids shall use the copper-core cables with the cross-section of no less than 50 mm<sup>2</sup>. The detection of grounding system is required before being put into operation, in order to guarantee the equipment and personal safety.

#### **6 Precautions**



- ◆ All connections of the electrical installations of high voltage variable frequency speed control systems must be installed by experienced electricians according to the national standards related to electrical installations.
- ◆ All high-voltage connectors must receive insulation treatment to

ensure good insulation.

- ◆ The high voltage connecting positions must be kept clean and meet the requirement of the corresponding cleanliness.
- ◆ All work must be carried out while the main power supply and the auxiliary power supplies are all disconnected.
- ◆ Connect the main incoming cables and the output motor cables correctly, otherwise the equipment of the whole variable frequency speed control system will be seriously damaged when the power is turned on.
- ◆ The phase sequence of output cables is related to the rotating direction of the motor, please connect the U, V and W according to the requirement of load turning directions, and perform tests before formally putting into operation.
- ◆ High-voltage electrical insulation distances must meet the requirements of electrical safety distance in order to avoid short circuit.



- ✧ **Before cabling, please confirm that the input power supply has been cut off.** There is the risk of electric shock and fire.
- ✧ **Please call electric engineering professionals to perform the cabling operation.** There is the risk of electric shock and fire.
- ✧ **Please be sure to make reliable grounding of the cabinet bodies.** There is the risk of electric shock and fire.
- ✧ **Please be sure to test the normal functioning of the power/variable frequency switch and the emergency breaking buttons before power is turned on.** There is risk of injuries (users shall take the responsibility of cabling).
- ✧ **Please don't touch the output terminals directly,** the output terminals of the variable frequency speed control system must not be connected to the casing, there mustn't be short connections between output terminals. There is the risk of electric shock and causing short circuit.

	<ul style="list-style-type: none"> <li>✧ <b>Please check whether the AC main circuit power supply is consistent with the rated voltage of the variable frequency speed control system</b>, otherwise there will be risks of injury and fire hazard.</li> <li>✧ <b>The voltage resistance test shall be performed according the manual</b>; otherwise it will cause the damage to the semi-conductor components and others.</li> <li>✧ <b>Please use the screw driver of designated torque to tighten the terminals</b>, otherwise there will be the risk of fire.</li> <li>✧ <b>Please don't connect the input power supply line to the output U, V and W terminals</b>. Putting voltage on the output terminals will cause the inner damage of the variable frequency speed control system.</li> </ul>
	<ul style="list-style-type: none"> <li>✧ All high-voltage connectors must receive insulation treatment to ensure good insulation. The high voltage connecting positions must be kept clean and meet the requirement of the corresponding cleanliness.</li> <li>✧ The electrical insulation distance of the high voltage positions must comply with the requirement of electrical safe distance to avoid any short circuit caused by the electric discharge.</li> <li>✧ The electric insulation detection test to the input end of the system shall be performed after the short-connecting and grounding of the iron core of the phase-shifting transformer and all secondary output end; <b>while performing the electric insulation detection test to the output end of the system, no units output is allowed to be connected into the output cables; otherwise the power units will be damaged.</b></li> <li>✧ After the completion of all connections, the detection of electric insulation properties shall be carried out to the input end of the system, the experimental voltage shall use the reference value as follows: for 6kV system, it shall be</li> </ul>

	<p>25kV, for 10kV system, it shall be 35kV. During the field hand-over test, the actual insulation test voltage shall choose 75% of the value mentioned above. If the air humidity is apparently too large on the spot, or there's the situation that the humidity is relatively large for a long time in the long-term storage environment before the installation, commissioning and operation of the system, if the equipment are found to be damped before putting into operation, then further voltage withstand test must not be carried out, in order to avoid the equipment being damaged. The voltage withstand test shall be performed after using non-fire heating source for drying.</p> <p>✧ The indicators at the high voltage positions must be clear and eye-catching to avoid errors.</p> <p>✧ Installation of large-current positions: to enable the variable frequency speed control system to meet the technical properties, great attention must be paid to the installation of large-current positions (All incoming terminals and output terminals with the current flow of larger than 10A shall be considered large current terminals). The key points are:</p> <ul style="list-style-type: none"> <li>◆ Terminals shall be made of the materials with excellent conductive properties, such as oxygen-free copper terminals, silver-plating or tin-plating fasteners and other connecting materials.</li> <li>◆ All terminals shall be carefully cleaned with ethanol before connecting.</li> <li>◆ Connections of all connectors shall be very reliable, the fasteners shall be tightened with wrenches, the important connectors shall be wrenched tight reliably with torque wrenches to ensure the contact resistance is less than 2 milliohms.</li> <li>◆ The fasteners of all large-current connecting positions shall include spring rings, which shall be pressed flat</li> </ul>
--	---

	<p>after fastening.</p> <p>◆The large-current connecting wires shall use appropriate current density to avoid the heating and the consequent impact on equipment use.</p>
--	---

### 4.3 Wiring of user terminals

#### 1 General introduction of user terminals

CHH Series high voltage variable frequency speed control systems provide the terminals of 16 channels of digital inputs, 8 channels of relay outputs, 3 channels of analog inputs, 4 channels of analog outputs, 1 channel of high-pulse input and 1 channel of high-pulse output. All user terminals are programmable and can be specified using the function codes.

CHH Series high voltage variable frequency speed control systems connect all terminals the user used onto the terminal blocks. Please carry out the wiring from the terminal blocks while using.

##### 1) Description of the terminal ports the users used

Classification	Terminal markings	Terminal functions	Technical specifications
Upper communication	485+	485 communication positive pole	1. Standard 485 Physical interface, supporting standard MODBUS communication protocols
	485-	485 communication negative pole	
Digital input	S1~S16	Switch input terminals	1. Forming the optical coupler isolation input with COM 2. The input voltage can only be the 24V provided by the system 3. The suspension of terminals will be regarded as disconnected 4. Input impedance: 3.3kΩ



Classification	Terminal markings	Terminal functions	Technical specifications
	HDI	High pulse input terminals	<ol style="list-style-type: none"> <li>Forming the optical coupler isolation input with COM</li> <li>The input voltage can only be the 24V provided by the system</li> <li>The suspension of terminals will be regarded as disconnected</li> <li>Input impedance: 1.1k<math>\Omega</math></li> </ol>
24V power supply	+24V	24V power supply provided by the system, for the use of digital input and high-pulse input.	<ol style="list-style-type: none"> <li>Maximum output current 150mA</li> </ol>
	COM	24V Powers supply grounding	
10V Power supply	+10V	+10V power supply provided by the system, for the use of analog input	<ol style="list-style-type: none"> <li>Maximum output capability 20mA</li> </ol>
	GND	+ 10V Powers supply grounding	

Classification	Terminal markings	Terminal functions	Technical specifications
Analog input	AI1 and AI2	Analog input terminals. Support the inputs of voltage and current.	<ol style="list-style-type: none"> <li>Forming a loop connection with GND</li> <li>It is recommended to use the +10V provided by the frequency inverter as the input voltage.</li> <li>For voltage input, voltage range 0~+10V; for current input, current range 0~20mA, 20mA current responds to +5V.</li> <li>Input impedance: 20k<math>\Omega</math> (voltage) /250<math>\Omega</math> (current).</li> </ol>
	AI3	Analog input terminals. Only support voltage input, the input range permits negative voltage	<ol style="list-style-type: none"> <li>Forming a loop connection with GND</li> <li>It is recommended to use the +10V provided by the frequency inverter as the input voltage.</li> <li>Voltage input range is -10V~+10V.</li> <li>Impedance of voltage input is 20k<math>\Omega</math>.</li> </ol>
Analog output	AO1 and AO2	Analog output terminals, Only support voltage output	<ol style="list-style-type: none"> <li>Outputting the voltage corresponding to the GND terminals.</li> <li>Output voltage range 0~+10V</li> <li>Maximum output loop current range 0~2mA, minimum input impedance of external circuit 5k<math>\Omega</math>.</li> </ol>

Classification	Terminal markings	Terminal functions	Technical specifications
	AO3 and AO4	Analog output terminals. Support the outputs of voltage and current.	<ol style="list-style-type: none"> <li>1. Outputting the voltage and current corresponding to the GND terminals.</li> <li>2. While voltage output: Output voltage range 0~+10V, output permit impedance<math>\geq 5K\Omega</math></li> <li>3. While current output: Output current range 0~20mA, output permit impedance 100~500<math>\Omega</math></li> </ol>
Relay output	RO1~RO8	Relay output terminals	<ol style="list-style-type: none"> <li>1. Contact point definition: A and B Normally closed, C Normally open.</li> <li>2. Contact capacity: AC250V/3A, DC30V/3A.</li> </ol>
Digital output	HDO	High speed pulse output terminal	<ol style="list-style-type: none"> <li>1. Output frequency range: 0~50kHz.</li> <li>2. Forming optical coupling insulation with COM.</li> </ol>

## 2) Wiring diagram of user terminals





Figure 4.6 Wiring diagram of user terminals of the high voltage frequency inverter

## 2 Precautions



- Usually, the user control wires shall not use the wires with reinforced insulation. If wire insulators are damaged due to certain reasons, then the intrusion of the high voltage into the control circuit is possible. This is not permitted for European Low Voltage Directive. If this situation occurs, electric shock or equipment damage may occur.

	<ul style="list-style-type: none"> <li>✧ If shielding cables are used, the each cable shielding layer can only be grounding at the single-ended.</li> <li>✧ To ensure the normal work of the variable frequency speed control system, it must be guaranteed that work of various signal lines is normal without being affected by various electromagnetic interference. Therefore, during the installation of user control wires, the correct installation of these signal lines must be focused on in the following aspects.</li> <li>✧ Separate wiring of the signal wires and power cord, especially the large-current high voltage wires, must be ensured to avoid electromagnetic interference. The control cables shall not be wired parallel to the power cables. If this situation is inevitable, the distance between the control cables and main cables must be kept as a minimum 30cm. The control cables and power cables shall be cross-wired perpendicularly.</li> <li>✧ Separate wiring of digital signal lines and analog signal lines is required to avoid mutual interference.</li> <li>✧ If the signal lines and power cords must be wired in the same place, then the shielding measures shall be taken to the signal lines, so as to reduce the interference produced by power cords to the signal lines as much as possible.</li> <li>✧ Avoid the parallel wiring of signal lines and power cords so as not to produce mutual interference.</li> <li>✧ The grounding of signal lines must be connected to shielded wires reliably; the shielded layer must also be reliably grounded at one single termination.</li> <li>✧ If necessary, the signal lines can be connected to the external through the threading of metal conductive casing pipes. In this way, various interference signals can be reliably isolated to ensure the normal operation of the variable frequency speed control system.</li> <li>✧ For reducing the interference and attenuation of the</li> </ul>
--	---

	control signals, the connection length of the control signal lines shall be limited within 50m.
	<ul style="list-style-type: none"> <li>✧ After the wiring is completed, please be sure to check.</li> <li>✧ Whether there is anything wrong with the wiring.</li> <li>✧ Whether there is any residue of the screws and connectors inside the equipment.</li> <li>✧ Whether there is any loosening of the screws.</li> <li>✧ Whether the bare conductors of the terminal parts are connected to other terminals.</li> </ul>

## System debugging and running

5

The debugging of CHH Series high voltage variable frequency speed control systems must be carried out under the guidance of the professionals of our company. The function testing, debugging and parameter settings must be carried out strictly according to the relevant regulations and the instruction manual of the high voltage frequency inverter of our company.

During debugging, users must provide at least 2 professional electricians as the running staff required by the debugging, and the running staff must comply with the following conditions:

- Familiar with the high voltage electrical equipment and the corresponding safety standards.
- Familiar with the users' load driving process.
- Authorized to operate on high voltage equipment (Power circuit breakers and other high voltage transmission switches, etc.).
- Authorized to operate on drive devices.



- ✧ Ensure the high voltage variable frequency speed control systems are correctly wired, and all electrical cabinet doors are closed before connecting to the power supply. The cabinet doors can't be opened after the power is turned on.
- ✧ Correctly setting the function parameters of the high voltage variable frequency speed control system.
- ✧ While booting, the system is designed to ensure personal and equipment safety.
- ✧ When the power of the variable frequency speed control system is turned on, even if it is in the state of shutdown, the terminals are still electrified and must not be touched.
- ✧ The running and stopping of the high voltage variable frequency speed control systems can not be operated by the methods of connecting or disconnecting the main circuit.

## **5.1 Items of detection and confirmation before debug running**

1. Check the input power supply complies with the inverter. The input voltage of the inverter is recorded on the name plate of the back door.
2. The maximum output voltage matches the rated voltage of the motor on the name plate.
3. The control voltage matched the rated voltage of the inverter designated in the technical protocol.
4. The rated power on the name plate of the motor matches that of the inverter.
5. Ensure the two high voltage cables are tightly connected to the phase shifting transformer. The connectors are the "0" tapings from three coils of the phase shifting transformer. When the grid voltage is low, connect them to "-5%", but when the grid is high, connect them to "+5%".
6. Ensure the cables between the phase shifting transformer and power unit cabinet have been connected properly and tightly.
7. Check and ensure all wiring and configuration are proper and tight. Ensure all electric equipments are marked (red sign).
8. Ensure all electric equipments are connected tightly and there is no damage and paint-removing to the cabinet. If there is, check the back of the damaged parts and other components, cables.
9. Check all connecting cables. Ensure there is no conductor outside because of the abrasion and transportation.
10. Check whether all the terminals and fixing elements and other parts are marked or not. If there is any discrepancy, contact with the factory and correct it.
11. Ensure all covers are connected correctly and tightly.
12. Ensure all fans are installed properly and they can work normally.
13. Ensure all control and main power supplies are connected normally and comply with the local electric regulations.



14. Check all the wirings are tight and correct.
15. Comply with the standard safety precautions and load laws and regulations during external wiring. Keep certain distance between the low voltage wires and other wires.
16. Apply shield cables as the external control cables for the assurance of EMC.
17. If there is anything wrong, contact the supplier.

## **5.2 Tests of powering on for control cabinets and tests after power-on**


### **5.2.1 Powering on for control cabinet**

1. Ensure that L1, L2 and L3 are disconnected to high voltage inputs.
2. Start the UPS; when the keyboard on the running panel of the frequency inverter displays “-CHH-” and is flashing, the 7 LED lights shall all be turned on. After 2 seconds, all LED lights shall go out except the ones that correspond to Hz.
3. The interface of the touch screen shall display the initialization interface, and finally pop up the Login button. After pressing the login button of the person in charge, the system will enter the main interface and prompt that the DC bus lacks voltage.
4. Observe deviation of the temperature displayed on the phase-shifting transformer cabinet and the actual ambient temperature, and if it is less than 1℃, it will indicate that the deviation is normal.

### **5.2.2 Testing**

1. Automatic bypass system

Test whether the work of K1, K2 and K3 are normal

1. Ensure that L1, L2 and L3 are disconnected from the high voltage power supply.
2. In the touch screen interface  Function Settings, click the settings button within the Running Mode box on the interface of Function Settings; Enter the

Power/Variable Frequency Switch interface.

3. Click Variable Frequency in the interface.
4. The sound of the contactor can be heard twice, and then the power supply indicator lights and variable frequency indicator lights of the bypass cabinet will be turned on.
5. Measure the on-off of K1, K2 and K3 with a multimeter, now K1 and K2 are on, and K3 is off.
6. Click "Cut off high voltage" in the interface.
7. One beep of the contactor can be heard; the indicator light of bypass cabinet will go out.
8. Measure the on-off of K1, K2, K3 with a multimeter, now K1, K2 and K3 are all off.
9. Click "Power frequency" in the interface.
10. One beep of the contactor can be heard; the indicator lights on the leftmost of the bypass cabinet are turned on.
11. Measure the on-off of K1, K2 and K3 with a multimeter, now K1 and K2 are off, and K3 is on.
12. UPS power-down, reboot the UPS after the system is all power down.
13. Reboot the UPS, then, after switching the power on, you will hear a beep of the contactor sound, the indicator lights of the bypass cabinet will go out.
14. Click "Variable frequency" in the interface, and wait until the 2 indicator lights on the leftmost of the bypass cabinet are both turned on.
15. Press the emergency breaking switch on the control cabinet, and you will hear one beep of the contactor.
16. Measure the on-off of KM1, KM2 and KM3 with a multimeter, now KM1 and KM2 are off, and KM3 is on.
17. Turn the emergency breaking knob to the normal position.
18. Measure the on-off of KM1, KM2 and KM3 with a multimeter, now KM1 and KM2 are on, and KM3 is off.

## 2. Manual bypass system

Test whether the work of QS1, QS2 and QS3 are normal.

1. Ensure that L1, L2 and L3 are disconnected from the high voltage power supply.
2. Switch on QS1 on the manual cabinet and measure QS1 are on with a

multimeter (at the same time, QS3 is off). Watch the on-off of isolator and ensure the state complies with the reality.

3. Switch on QS2 on the manual cabinet and measure QS2 are on with a multimeter (at the same time, QS3 is off). Watch the on-off of isolator and ensure the state complies with the reality.

4. In the touch screen interface, QS1 and QS2 are switched on and QS3 is switched off. The LED for the variable frequency on the shifting cabinet is on.

5. Switch off QS1 and QS2 and switch on QS3 on the manual cabinet. Measure QS3 is on with a multimeter. Watch the on-off of isolator and ensure the state complies with the reality.

6. In the touch screen interface, QS1 and QS2 are switched off and QS3 is switched on. The LED for the power frequency on the shifting cabinet is on.

### 3. Automatic bypass system with isolation

Test whether the work of K1, K2, K3, QS1 and QS2 are normal.

1. Ensure that L1, L2 and L3 are disconnected from the high voltage power supply.

2. Switch on QS1 on the manual cabinet and measure QS1 are on with a multimeter. Watch the on-off of isolator and ensure the state complies with the reality.

3. Switch on QS2 on the manual cabinet and measure QS2 are on with a multimeter. Watch the on-off of isolator and ensure the state complies with the reality.

4. In the touch screen interface---->Function Settings, click the settings button within the Running Mode box on the interface of Function Settings; Enter the Power/Variable Frequency Switch interface.

5. Click Variable Frequency in the interface.

6. The sound of the contactor can be heard twice, and then the power supply indicator lights and variable frequency indicator lights of the bypass cabinet will be turned on.

7. Measure the on-off of K1, K2 and K3 with a multimeter, now K1 and K2 are on, and K3 is off.

8. Click "Cut off high voltage" in the interface.

9. One beep of the contactor can be heard; the indicator light of bypass cabinet will go out.

10. Measure the on-off of K1, K2, K3 with a multimeter, now K1, K2 and K3 are all off.
11. Click "Power frequency" in the interface.
12. One beep of the contactor can be heard; the indicator lights on the leftmost of the bypass cabinet are turned on
13. Measure the on-off of K1, K2 and K3 with a multimeter, now K1 and K2 are off, and K3 is on.
14. UPS power-down, reboot the UPS after the system is all power down.
15. Reboot the UPS, then, after switching the power on, you will hear a beep of the contactor sound, the indicator lights of the bypass cabinet will go out.
16. Click "Variable frequency" in the interface, and wait until the 2 indicator lights on the leftmost of the bypass cabinet are both turned on.
17. Press the emergency breaking switch on the control cabinet, and you will hear one beep of the contactor.
18. Measure the on-off of KM1, KM2 and KM3 with a multimeter, now KM1 and KM2 are off, and KM3 is on.
19. Turn the emergency breaking knob to the normal position.
20. Measure the on-off of KM1, KM2 and KM3 with a multimeter, now KM1 and KM2 are on, and KM3 is off.

### **5.2.3 Test whether the power alarm is normal**

1. Main control cabinet is power on, turn the switch of the input power supply 1(Q1) open, the system will trigger the alarm of Power supply 1.
2. Close the switch of the input power supply 1 (Q1), the system alarm disappears.
3. Open the switch of the input power supply 2 (Q2), the system will trigger the alarm of Power supply 2.
4. Close the switch of the input power supply 2 (Q2), the system alarm disappears.
5. Close the UPS, the system will trigger the alarm of UPS.
6. Boot the UPS, the system alarm disappears.

Note: Before debugging, it is necessary to set P3.20 "the time of alarm reset interval" to non-0 parameter, otherwise even if the input power is disconnected, the system does not generate alarms.

### 5.2.4 Test insulation resistance and voltage

#### ■ Test insulation resistance

1. Respectively short connect L1, L2 and L3 and short connect U, V and W.
2. Main control cabinet is power on, switch the system to the power frequency work state via the touch screen.
3. Measure the inner resistance between the short-connected L1, L2, L3, U, V, W and the cabinet body; the resistance shall be over 20MΩ.
4. Measure the insulation resistance between each power unit casing and the cabinet body with a withstanding voltage tester; the resistance shall be over 20MΩ.

**Note: The voltage level of insulation resistance tester is requested: 2500V/> 500M Ohm.**

#### ■ Test insulation voltage

1. Disconnect the wiring of three-phase transformer temperature sensor.
2. Remove the three arrester of the transformer.
3. The bypass cabinet and phase-shifting transformer cabinet will be test in accordance with the following criteria:

Cabinet	Part	Power (kV)		f (Hz)	T (S)	Note
		6kV	10kV			
Bypass cabinet	A phase to B, C phase and earth	16	22.5	50	60	
	B phase to A, C phase and earth	16	22.5	50	60	
	C phase to A, B phase and earth	16	22.5	50	60	
Phase-shifting transformer cabinet	primary winding to phase shifting winding, ground and auxiliary winding	16	22.5	50	60	Short connect of every windings in the secondary side
	phase shifting winding to primary winding, ground and auxiliary winding	16	22.5	50	60	Short connect of every windings in the secondary side

	among phase A, B and C of secondary winding	16	22.5	50	60	Short connect of secondary side's each phase winding
--	---	----	------	----	----	--

Note:

1. Above positions of components (such as K1, k2, k3, QS1, QS2 and QS3) can be found in the electrical and wiring diagrams.
2. When doing dielectric voltage withstand test, the power units must disconnect with the dielectric voltage withstand test components.
3. After doing dielectric voltage withstand test, it must check and make sure the inductive electricity been discharged.

### 5.2.5 Motor parameter setting

Complete the parameter settings of the function codes of P2.01~P2.05 according to the data plate of the motor.

## 5.3 Power on for main loop and power-on debugging

### 5.3.1 High-voltage on whole machine

1. Connect L1, L2 and L3 separately to the high voltage inputs. Make sure the U, V and W are disconnected to the motor; and the system is in the state of power-off. Close all cabinet doors.
2. Switch the system to variable frequency state via the touch screen.
3. Connect to the high voltage according to the operation procedures (when it is the first time to connect to high voltage power supply, all staffs need to stay over 3 meters away from the cabinet).
4. After over 6 seconds after power is turned on, the ready LED (Yellow LED) is turned on.

Note: ensure the voltage degree of the inverter is the same as that of the high voltage input; otherwise the inverter will be damaged.

### 5.3.2 Correction of the unit voltage and temperature

1. Make sure that L1, L2, L3 are separately connected to the high voltage inputs. Make sure U, V and W are disconnected to the motor, and the variable

frequency speed control system is working in the state of variable frequency.

2. Log in the touch screen as the person in charge, and enter the parameters in Pd group.
3. Observe Pd.03~Pd.29, the temperature deviation displayed shall be no more than 2°C.
4. Observe Pd.30~Pd.56, the voltage deviation of the unit shall be no more than 50V.
5. If the deviation exceeds the above range, please confirm with the factory technician.

### **5.3.3 Disconnecting the motor and no-load running**

1. Keep the power-on configuration of 5.3.2, and connecting to a high voltage.
2. Press "**RUN**" button on the keyboard, and run at 50Hz.
3. It can be listened and checked whether there's any abnormal sound or noise when the blower starts (please test the variable frequency speed control system with thin A4 paper in it for each enclosure air inlet, if it is inhaled look inside the normal, otherwise the direction is not correct); if no noise or abnormal sound is heard and the running is steady, then the air blower is working normally.

## **5.4 Test with motors**

### **5.4.1 No-load test with motors**

1. Connect L1, L2 and L3 separately to the high voltage inputs; connect U, V and W to the high voltage motor. Connect to the input power supply, switch the frequency inverter to variable frequency state.
2. Set the output frequency to 10Hz while testing with the motor, then increase the frequency to 20Hz after the motor is running steadily, then increase to the rated frequency of the motor with this method and start the motor, and run at 50Hz.
3. During the whole process, there is no abnormal sound or vibration of the motor, and the running is steady.
4. Press the Slowdown & Stop button, the output frequency of the frequency

inverter has decreased. And press the “coast to stop” command when it decreases to about 5Hz.

5. After blocking the pulse, press the Start command again, then the frequency inverter will reach the current rotating speed within 2 seconds, and steadily accelerate the motor to 50Hz. (Previously shall be P1.0 to "speed track to start")

6. No jump fault is allowed during the deceleration process.

Note: ensure the voltage degree of the inverter is the same as that of the motor; otherwise the inverter will be damaged.


#### **5.4.2 Motor testing with load**

1. Run the motor to 50Hz with actual load.
2. Enter Group Pd, detect Pd.03~Pd.29, the difference between the detected temperature and the actual ambient temperature must not be more than 30℃.
3. In the procedure of deceleration and acceleration, the frequency inverter can not jump failure, otherwise please contact with the factory technician to adjust relevant parameters.



## Operation of the variable frequency speed control system

### 6

	<ul style="list-style-type: none"><li>✧ Running without complying with the guidance of Chapter 1-Safety Notes is very dangerous.</li><li>✧ Only the staff that have received training and obtained the permission of the user's organization can perform the operation to the variable frequency speed control system.</li><li>✧ The description in this chapter only takes the bypass cabinet of our company as an example; the different application requirements will cause the changes of the wiring principles of the bypass cabinet, please refer to the description in this chapter and make up the operation procedures according to the wiring principles of the actual bypass cabinet.</li></ul>
---	--

In this chapter, all normal running procedures after completing the installation and debugging of CHH Series high voltage variable frequency speed control systems are introduced in detail step by step, and all necessary operation steps are numbered, the operation must be precisely carried out strictly according to these operation steps. For the detailed operation of K1, K2 and K3 of bypass cabinets, please refer to (the content in 5.2.2).

## 6.1 Description of bypass cabinet




Figure 6.1 Outline structure schematic drawing of manual and automatic bypass cabinet

#### **6.1.1 Auto-bypass cabinet**

Power indicator light: Indicates the state of K1 , if K1 is closed, then phase-shifting transformer high-voltage power supply and power unit input circuit connection already in place.

Variable frequency indicator light: Indicates the state of K2, if K2 is closed, then power unit to output terminal of the bypass cabinet connections has gotten ready, high voltage inverter system can drive the motor.

Power frequency indicator light: Indicates the state of K3, if K3 is closed, then the high voltage inverter system is in bypass state, can direct drive motor by the power frequency.

### 6.1.2 Manual bypass cabinet

Power display device: Indicates the higher-voltage has reached to the bypass cabinet. The high-voltage power supply of bypass cabinet already exists, prohibit from opening all the doors of bypass cabinet at this time.

Variable frequency indicator light: Indicates the state of QS2, if QS2 is closed, then power unit to output terminal of the bypass cabinet connections has gotten ready. The high voltage inverter system can drive the motor.

Power frequency indicator light: Indicates the state of QS3, if the QS3 is closed, then the high voltage inverter system is in bypass state, can direct drive motor by the power frequency.

## 6.2 Control cabinet Introduction




Figure 6.2 Schematic shape diagram of control cabinet


As shown in the figure:

**Fault indicator light and warning light:** This indicator light indicates that the variable frequency speed control system is in the state of fault or warning. If any fault occurs, then the fault indicator light and the warning light will be turned on. If any warning occurs, then the fault indicator light and warning light will light up and go out intermittently taking 2 seconds as the interval.


**Running indicator light:** This indicator light indicates whether the variable frequency speed control system is in the state of running, and if so, the indicator light will be turned on.

**Ready indicator light:** It indicates whether the variable frequency speed control system is in the state of ready & standby, and if the system is power up but is not running, and no fault is detected, then the indicator light is turned on.

**Emergency breaking button:** when the main control panel is damaged, or other faults that can't be normally controlled occur to the system, users can directly disconnect K1 through physical lines by pressing the emergency breaking switch, and thereby minimize the losses.

	<ul style="list-style-type: none"> <li>✧ If the emergency button had been pressed down, please release it, after cutting off the high voltage, and then the power can be turned on.</li> <li>✧ If the system is running at power frequency, the emergency button is invalid. In this case, if it needs to cut off the high voltage power supply, the only way is to turn off the superior hierarchical level power supply directly or send the command of cutting off the high voltage power supply to the system directly.</li> <li>✧ When choosing the manual bypass cabinet, the emergency breaking button only can control the superior hierarchical level high voltage breaker or contactor, it couldn't control the knife switches in the bypass cabinet. Please connect the control part with the superior hierarchical level control circuit.</li> </ul>
---	--

### 6.3 Operation steps of variable frequency speed control system


	✧ Even if the high voltage is cut off, wait for 30 minutes to touch the body of the variable frequency speed control system. Otherwise, electric shock accidents may occur since the DC bus of the power units is electrified.
---	--

#### 1 Power on

1: Make sure that the debugging and running operations of the variable frequency speed control system has already been completed according to the instructions in Chapter 5.


2: Power up the main control cabinet.

3: Check and make sure that the settings of all parameters related to transmission system are correct. The parameters that must be examined include the parameters related to the frequency settings, the operation control modes and the V/F curves described in Section 2.2.

	✧ In order to guarantee the safety and normal start-up of the equipment, the parameters that have special impact on the start-up must be carefully confirmed.
---	---

4: Confirm that the manual disconnected switch (if manual disconnected switch is provided) is in the closing state, and confirm that current K1, K2 and K3 are all under the open state.

5: Close all doors (control cabinet can be excluded).

	✧ If some cabinet doors are not reliably closed, the system will report the alarm, and will not be able to work normal.
---	---

6: Send the operation instructions of variable frequency down to the system (can be sent down via the touch screen or terminals, the sending down by terminals needs to send pulse signals to the terminals configured as "Variable frequency operation" function).

7: The DCS in the upper level waits for the high voltage closing permit signal to be fed back by the variable frequency speed control system, and after receiving the signal, close the high voltage switch in the upper level, then power up with high voltage.

8: After the power up, check whether the ready indicator light of the control

cabinet is on, or check whether the high-voltage variable frequency speed control feeds back the ready signals.

## 2 Start-up

- 1: Perform the power up according to the required operations of power up.
- 2: Check whether CHH System is ready and whether the Ready indicator light of the control cabinet is on, then confirm that the fault and warning indicator lights on the control cabinet are out. If any fault or warning exists, then the fault elimination can be carried out according to the warning information provided on the keyboard/touch screen, referring to the methods described in Chapter 9-Fault detection and elimination in this document.
- 3: Specify the running frequency in accordance with the designated frequency specifying mode.
- 4: Specify the running control signals according to the designated control mode.


## 3 Deceleration shutdown

Carry out the shutdown operation according to the control mode.

**Note: Before the frequency output is not lowered down to the shut-down frequency, if starting signal is given again, the system will raise the frequency to the specified target frequency.**

## 4 Free shutdown

After free stopping, the variable frequency speed control system stops the voltage output; the motor rotates freely and will gradually slow down under the impact of the load and friction.

	<ul style="list-style-type: none"><li>✧ Whether the working condition allows the free shut-down of the motor needs to be fully estimated.</li><li>✧ During the process of free shutting down, due to the residual magnetism, voltage may still exist in the output cables.</li><li>✧ After shutdown, do not touch the main circuit and motor, this is because the DC voltage of the frequency inverting part still exists.</li></ul>
---	--


## 5 Power off

- 1: Execute the shutdown or free shutdown operations of the variable frequency speed control system.

2: Send down the power-off command to the frequency system (can be sent down via the touch screen or terminals).

3: If the high-voltage switch in the upper-level is also controlled by the system, the system will first break off the high voltage switch in the upper level, then break off the switch of the bypass cabinet. If the high-voltage switch in the upper-level is not controlled by the system, the system will break off the switch of the bypass cabinet.

4: If the high-voltage switch in the upper-level is not controlled by the system, it is necessary to manually break off the high-voltage switch in the upper-level after the switch of the bypass cabinet is directly broken off by the system.

	<ul style="list-style-type: none"><li>✧ After the AC incoming wire is disconnected, it will take at least 30 minutes for the DC voltage to drop to the safe value.</li><li>✧ As long as the system is still electrified, please don't get near the bypass cabinet, transformer cabinet, power unit cabinet and the circuits related to the motors</li></ul>
---	---

## 6 Fault treatment

Step 1: If the main control system is judged to be working abnormally, it is required to manually press the emergency breaking button of the control cabinet, and then the bypass cabinet will immediately cut off the high voltage input.


Step 2: When any failure occurs during normal operation, after the failure occurs to the power unit, CHH Series variable frequency speed control systems can choose to directly cut off the high voltage or choose bypass running according to the settings. The system-level faults of CHH Series variable frequency speed control systems are classified as light faults and severe faults. For the light faults, free shut-down shall be performed; and for the severe faults, the high voltage shall be directly cut off.

Step 3: Shut down the variable frequency speed control system

Step 4: Power off

Step 5: 30 minutes after cutting off the power, the faults that occurred shall be treated according to the fault treatment methods in Chapter 9.




	✧ If Emergency breaking button is pressed, it is required to first turn the emergency breaking knob to the Reset position after the fault is excluded, so as to perform the Power/Variable frequency switching normally.
---	--

## 7 Maintenance of the variable frequency speed control system

Step 1: Execute power-off operation of the variable frequency speed control system.

Step 2: If bypass cabinets are chosen, and the load still needs to run, switch firstly the frequency inverter to the power frequency running state via the bypass cabinet.

	✧ Due to the live-running of the bypass cabinet, the incoming wires still carry high voltage, so the bypass cabinet must not be opened during the maintaining process.
---	--

Step 3: Open the transformer cabinet body, connect the grounding wires on the input side of the transformer, and take good measures of safety grounding.

Step 4: Perform the maintenance of the transformer cabinets and power cabinets.

Step 5: After the maintenance, remove the safety grounding wires on the input side of the transformer.

Step 6: If the system is not running with power frequency bypass, and it is required to recover the running of the variable frequency speed control system, switch to the variable frequency running according to the procedures of power-up and booting-up. If the system is running with power frequency bypass, and it is required to recover the running of the variable frequency speed control system, firstly set the boot mode to speed tracking boot up, then boot and run using the method of switching the power and variable frequency switch to the mode of variable frequency.

## Human-machine interface

7




Figure 7.1 Schematic drawing of the human-machine interface of the high voltage frequency inverter

### 7.1 Keyboard

#### 7.1.1 The outline of keyboard and the position in the system

All default configurations of each high voltage variable frequency speed control system of CHH Series include a keyboard. The keyboard is connected to the high voltage variable frequency speed control system via the keyboard

## Operation of the variable frequency speed control system

wires. All operations of controls, parameter settings, state query and fault reset shall be performed through the keyboard. The position of the keyboard in the variable frequency speed control system and the meanings of the buttons are as follows:














Figure 7.2 Schematic drawing of the operation panel

### 7.1.2 General introduction of the functions of the buttons on the keyboard

#### 1) Preliminary introduction of buttons

Button symbols	Name	Function descriptions
	Program or Exit button	Enter and exit the running interface, or return from a menu at a certain level to the menu of the upper level.
	Data check button	Within the running interface, enter the menu at the next level; if the menu is on the 3rd level at this time, then the pressing of this button will confirm the numerical value shown in the menu of this level.
	UP Increment	Increment of data or function codes

## Operation of the variable frequency speed control system

	button	
	DOWN Decrement button	Decrement of data or function codes
	Shift button	Switching between the Fault interface and the Parameter Display interface, as well as cycle-shifting the parameters shown in the Parameter Display interface to the right
	Run button	This is used for running operation under the mode of Keyboard Operation
	Stop/Reset button	In Running state, pressing this button can be used for stopping the running operation, which is constrained by the function codes P7.04; While in fault state, this can be used for resetting the faults, which is not restricted by the function codes P7.04.
	Warning/Fault reset button	In the Fault or Warning state, the faults and warnings can all be reset by pressing this combination of buttons, without influencing the actions of the current variable frequency speed control system.
	Quick Jog button	The function of this button is determined by the function codes in P7.03
	Combination	Pressing RUN button and STOP/RST button simultaneously, the variable frequency speed control system stops freely

### 2) Description of functional indicator lights

Indicator light name	Description of indicator light
RUN/TUNE	Indicator light in Running state: Lights off means the variable frequency speed control system is in the Stop state; the flashing of light means the variable frequency speed control system is in the Parameter Self-study state; lights on means the variable frequency speed control system is in the Running state.

## Operation of the variable frequency speed control system

Indicator light name	Description of indicator light
FWD/REV	Forward & Reverse indicator light: Lights off indicates the system is in the Forward state; Lights on indicates the system is in the Reverse state.
LOCAL/REMOTE	Control Mode indicator light: Lights off indicates the Keyboard Control mode; lights flashing indicates the Terminal Control state; lights on indicates the Remote Communication Control state.
TRIP	Overload Pre-alarm indicator light: lights off represents the Normal state; lights flashing represents the Overload Pre-alarm state; lights on represents the Fault state.

### 3) Description of unit indicator lights

Symbol characteristics	Description of symbol contents
Hz	Frequency unit
A	Current unit
V	Voltage unit
RPM	Rotation speed unit
%	Percentage

### 7.1.3 Description of keyboard operations

#### 1 Description of keyboard interface hierarchies




Figure 7.3 Converting relation drawing of the keyboard operation interfaces

The keyboard operation interfaces are divided into 3 categories of Fault interface, State Query interface and Operation interface. The display contents are as follows:

### Operation of the variable frequency speed control system

Name	Content	Remarks
Fault interface	Displays the Warning/Fault code if it is in Warning or Fault state; displays P-oFF if it is in Power-off state	1) This interface does not exist in normal state, only when the high voltage power is off or it is in the state of Warning/Fault, will this interface appear. Now this interface is used as the basic interface. 2) The interface disappears P-oFF after the reset of Warning/Fault state; if it is in power-off state, then the interface disappears after the high voltage power up.
State Query interface	Displaying current bus voltage, specified frequency and other information.	1) While high voltage power up and there is no warning/fault, this interface is regarded as the basic interface. For the details, please refer to the 2 State Query
Operation interface	Users operate the function codes in this interface.	1) Enter into this interface only when the user needs to query or modify the information of the function codes. 2) For the details, please refer to the 3 Functional parameter settings.

The introduction of the conversion among the 3 categories of interfaces:

#### (1) In Warning/Fault state

- 1) All 3 interfaces exist, Fault interface is the basic interface.
- 2) In the Fault interface, press **>>/SHIFT** button, enter the State Query interface.
- 3) If the system is now in the last query state of the State Query interface, press **>>/SHIFT** button, enter Fault interface.
- 4) In the Fault interface/State Query interface, press **PRG/ESC** button, enter the Operation interface.
- 5) In the 1<sup>st</sup> level menu of the Operation interface, press **PRG/ESC** button, enter the Fault interface.

#### (2) In Normal state

- 1) There is only the State Query interface and Operation interface; State Query interface is the basic interface.
- 2) In the State Query interface, press PRG/ESC button, enter the Operation

interface.

3) In the 1st level menu of the Operation interface, press PRG/ESC button, enter the State Query interface.

**Note: The so-called Basic Interface means the interfaces displayed in the default state without any other operation.**

## 2 State query


The State Query interface is for checking the current voltage, current, output frequency and other work-related state values of the variable frequency speed control system.

In different state (Running and Shutdown) of the variable frequency speed control system, the content of the keyboard displayed in the Query interface is specified by relevant function codes, the relations of the function codes correspondent to the state of the variable frequency speed control system and the query content are as follows:

State	The function codes correspondent to the query content
Running	During the running process of the variable frequency speed control system, the state parameters that can be queried via the keyboard are configured by the function codes P7.06, P7.07
Shutdown	When the variable frequency speed control system is in the Shutdown state, the state parameters that can be queried via the keyboard are configured by the function codes P7.08

The digital keyboard can only display 1 of the parameters once.

Users can use the buttons on the keyboard to rotate right the displayed parameters. The details are introduced as follows:

Button	Operation
	The displayed parameters rotate to the right. Display the next state in the state parameter display array. If the parameter currently displayed is the last one in the array, then the first one in the array will be displayed after rotating to the right.

**Note: the aligning sequence of the Display states in the State parameter display array is the same as that of the parameters of the corresponding function codes.**

## 3 Functional parameter settings

## Operation of the variable frequency speed control system

The settings of functional parameters shall be completed in the Operation interface, the whole process from selecting function codes to completing the settings of function codes requires 3 levels of menus to complete. The descriptions of the 3 levels of menus are as follows:

Menu name	Menu function
1 <sup>st</sup> Level menu	Display and modify the group number of the current function code.
2 <sup>nd</sup> Level menu	Display and modify the identifier number of the current function code (Sub function codes)
3 <sup>rd</sup> Level menu	Display and modify the value of the current function code.

In the Fault interface/Parameter inquiry interface, press **PRG/ESC** button to enter the 1<sup>st</sup> level menu of the Operation interface. The group number of the function codes required to be selected can be modified by using the **▲/▼** buttons in this level of menu. Pressing **PRG/ESC** button in the 1<sup>st</sup> level menu will return to the Basic interface.

In the 1<sup>st</sup> level menu, press **DATA/ENT** button to enter the 2<sup>nd</sup> level menu of the Operation interface. In the menu of this level, we can switch the modified bit number by pressing the **>>/SHIFT** button, and modify the sub-function number below the specified bit number by pressing the **▲/▼** button. Press **PRG/ESC** button in the 2<sup>nd</sup> level menu to return to the menu of the 1<sup>st</sup> level;

In the 2<sup>nd</sup> level menu, press **DATA/ENT** button to enter the 3<sup>rd</sup> level menu of the Operation interface. In the menu of this level, we can modify the current function code (the value determined by the group number of the function codes in the menu of the 1<sup>st</sup> level and the sub-function code numbers in the menu of the 2<sup>nd</sup> level). If it is permitted now, users can modify the value of the function code. During the modification, we can select the bit number to be modified by pressing the **>>/SHIFT** button, and increase or decrease the numerical value by pressing the **▲/▼** button.

Note: Not all function codes are allowed to be modified; the function codes allowed to be modified in the current state shall have the flicker bits.

In the menu of the 3<sup>rd</sup> level, pressing the **DATA/ENT** button or the **PRG/ESC** button can both return to the menu of the 2<sup>nd</sup> level. The difference is that pressing **DATA/ENT** button indicates that this is valid for the modifications made to the menu of the 3<sup>rd</sup> level, and the sub-function code number shall be



added by 1 after returning to the menu of the 2<sup>nd</sup> level; while pressing the **PRG/ESC** button indicates that this is invalid to the modifications made to the menu of the 3rd level, and the sub-function code numbers will stay the same after returning to the menu of the 2<sup>nd</sup> level.

#### **4 Fault /Warning and Reset**

When fault or warning occurs in the variable frequency speed control system, the variable frequency speed control system will be locked to Fault/Warning, now even if the condition of Fault /Warning has been eliminated; the variable frequency speed control system is still in the Fault /Warning state. Doing so can provide the capability of locking the fault or warning occurred instantaneously and occasionally, and better protection of the system.

Users must exclude the fault/warning first, and can not perform the resetting until the fault and warning have all be eliminated. Reset method: If it is in the Warning state, the resetting can only be performed by pressing **STOP/RST+DATA/ENT**; if it is in the Fault state, the resetting can be performed either by pressing **STOP/RST+DATA/ENT** or by pressing **STOP/RST**.

The so-called Fault/Warning resetting function means removing the locking of Fault /Warning, and checking the state of the fault or warning currently occurred in real-time. If the Fault /Warning resetting is performed in the state of Fault /Warning and the fault /Warning has been eliminated, then the current state will be switched to the normal state.

#### **Note:**

- 1. If the fault is not excluded, the Fault state can be switched to the normal state even by clicking.**
- 2. The difference between Fault and Warning: Fault represents the abnormality that can cause damages; Warning represents the abnormality that can cause fault if not attached with importance. In the Fault state, the variable frequency speed control system will choose to freely shut down or cut off the high voltage according to the property of the fault; and will not affect the current operation state of the variable frequency speed control system in Warning state.**
- 5 Automatically search for the parameters different from the ex-factory values**

By setting P7.03 to 2, after clicking the **QUICK/JOG** button, the frequency inverter will automatically search for the parameters currently different from the ex-factory values, and store them in the Quick Debugging menu according to the sequence of the function codes for the users to view and configure. The length of the shortcut menu buffer is 16, the recorded parameters will be searched by the sequence of the function codes, and when there are more than 16 parameters recorded, the parameters over 16 will not be displayed. If it displays "NULLP" after clicking **QUICK/JOG**, then it is regarded that all current parameters are the same as the ex-factory parameters.

## 6 Functions summary of ▲/▼ buttons

The functions of ▲/▼ buttons.

Interface		Function
Fault interface		Invalid
State Query interface		Increase/decrease the frequency currently configured (perform fine-tuning to the configured frequency).
Operation interface	Menu of the 1 <sup>st</sup> level	Increase/decrease the group number of the current function code
	Menu of the 2 <sup>nd</sup> level	Increase/decrease the number of the current sub-function code
	Menu of the 3 <sup>rd</sup> level	Increase/decrease the numerical value of the current function code

## 7.2 Touch screen

### 7.2.1 Introduction of the touch screen

The touch screen is connected to the main control panel via the Modbus communication protocol, which will take up the Modbus communication resource of the variable frequency speed control system. Therefore, the CHH Series high voltage variable frequency speed control systems configured by using the touch screen will no longer support the other Modbus control functions.

### 7.2.2 The meanings of the touch screen operations

After the power-on of the touch screen, the Login interface will first pop up, users can choose the corresponding user names and input passwords to log in. after logging in, and the main interface of the touch screen will appear. Users can click the corresponding buttons in the main interface for performing different operations.

As for some setting operations, the clicking will generate the corresponding specialized interface, which is referred to as the sub-interface. Sometimes, clicking the corresponding buttons on the sub-interface will also pop up the corresponding specialized interface for running; therefore, the sub-interface is hierarchical. In order to make the distinction, the main interface is called the 1<sup>st</sup> level interface; the specialized sub-interface popped up from the main interface is called the 2<sup>nd</sup> level interface, and so on.

For the area of numerical settings, a common setting interface will pop up after clicking to permit the user to input figures, the interfaces of this category are called Common interface, and not grouped under the category of sub-interface.

#### 1 The main work interface of the touch screen




Figure 7.4 Schematic drawing of the touch screen main interface

The schematic drawing of the main interface of the touch screen is shown in the figure above, the main interface of which is mainly divided into the following areas:

Operation of the variable frequency speed control system

Serial NO.	Area	Buttons and content	Meanings
1	Setting area	Function setting button	By clicking the Function Settings button, we can configure the running command channel and frequency specifying methods of the variable frequency speed control system and other setting methods related to controlling in the popped-up dialog box
		Parameters setting button	By clicking the Parameter settings button, we can configure the function codes of the variable frequency speed control system and examine the values of all function codes in the popped-up dialog box.
2	History area	Running recording button	Recording the historical start-stop information of the variable frequency speed control system
		Alarm button	Recording the historical fault information of the variable frequency speed control system
3	Operation area	Emergency stop	If the running command channel is used for communication, then after pressing this button, the variable frequency speed control system will freely stop.
		Deceleration stop	If the running command channel is used for communication, then after pressing this button, the variable frequency speed control system will stop with deceleration.
		Forward running	If the running command channel is used for communication, then after pressing this button, the variable frequency

Operation of the variable frequency speed control system

Serial NO.	Area	Buttons and content	Meanings
			speed control system will be forward running
		Reverse running	If the running command channel is used for communication, then after pressing this button, the variable frequency speed control system will be reverse running
		Frequency settings	If the frequency specifying channel is used for communication, then after pressing this button, the dialog box will pop up for setting the running frequency of the variable frequency speed control system
		Normal inching turning	After pressing this button, the system will be running forward in the inching mode; after releasing this button, the system will stop the inching operation.
		Reverse inching turning	After pressing this button, the system will be running reversely in the inching mode; after releasing this button, the system will stop the inching operation.
		Language option	There are two options in English and Chinese
4	Monitoring area	Running frequency	The actual running frequency of the variable frequency speed control system
		Setting frequency	The configured frequency of the variable frequency speed control system
		Motor speed	Displays the actual rotating speed of the current motor

Operation of the variable frequency speed control system

Serial NO.	Area	Buttons and content	Meanings
		Output power	Displays the percentage taken by the output power of the current motor of the rated power
		Output voltage	The output voltage of the variable frequency speed control system
		Input voltage	The input voltage of the variable frequency speed control system
		Output current	The output current of the variable frequency speed control system
		Output torque	The actual torque output percentage of the variable frequency speed control system
		Power/Variable frequency state	It is on the left side of this area, and displays the state of all high-voltage switches of the current high voltage variable frequency speed control system in graphic mode.
		Running state	The text box above this area, displaying the high voltage variable frequency speed control system is currently in the state of Power-frequency operation, Variable frequency operation, Standby, or Fault.
		Running mode	Displays the Power/Variable frequency state of the variable frequency speed control system, and the specification method of the running command.
5	Reset area	Fault reset	If any fault occurs to the variable frequency speed control system, the variable frequency speed control system will keep locking that fault until

## Operation of the variable frequency speed control system

Serial NO.	Area	Buttons and content	Meanings
			the fault is unlocked by clicking the Fault Reset. Whichever control method is used, the Fault Reset button can always unlock the fault.
6	Exit area	Exit button	Click this button to exit the current user.
7	Running state area	Running state parameters query	Query by functional parameter P7.06 ~ P7.07

### 2 Log-in interface of touch screen

After the frequency inverter is power on, or the user has exited the main interface, the touch screen will display the Log-in interface. There are 3 types of running staff for the Log-in interface, including:

Operators: These staffs can start and stop the variable frequency speed control system.

Persons in charge: These staffs are applicable to the technical persons in charge of the organization and can perform the configuration and running of the variable frequency speed control system.

Manufacturer: These staffs can only be used for the manufacturer of the variable frequency speed control system; herein we will not make any more introductions.

The operation permissions of the Operation area owned by the running staff are as follows:

Area	Operator	People in charge
Settings area	Running not allowed	Running allowed
History area	Viewing allowed	Viewing allowed
Operation area	Running allowed	Running allowed
Monitoring area	Viewing allowed	Viewing allowed
Exit area	Running allowed	Running allowed
Reset area	Running allowed	Running allowed
Running state area	Running allowed	Running allowed

### 3 Description of 2<sup>nd</sup> level interface

#### 1) The buttons for generating 2<sup>nd</sup> level interfaces.

The buttons for setting area and history area can both generate the 2<sup>nd</sup> level interfaces.

**2) The description of the 2<sup>nd</sup> level interface popped up by clicking Function Settings button.**

Figure 7.4 Schematic drawing of the Function Settings 2nd level interface

This interface is mainly used to set some commonly used control parameters, which are:

Running mode is used for controlling the Power /Variable frequency switching of the variable frequency speed control system, and this group box displays that it is currently in the state of Variable frequency, Power frequency or Power-off; the motor running mode settings is for entering the menu of the 3rd level configured by the running mode.

Frequency mode is mainly for controlling the specification method of the running frequency. This group box displays in the sequence of: Specification method of frequency source A, Specification method of frequency source B and the actual frequency source is composed of which frequency source or several frequency sources.

Clicking the white edit-box on the right of the function code will pop up the corresponding selection dialog box for selecting and setting.

Password modifying is mainly for modifying the password of the Person-in-charge property.

Unit Bypass is mainly for setting the mode of unit bypass after the unit fault occurs, i.e. manual bypass or automatic bypass.

Command Channel is mainly for setting the mode through which the start-stop



of the variable frequency speed control system is controlled.

3) The description of the 2<sup>nd</sup> level interface popped up by clicking Parameter Settings button.




Figure 7.5 Schematic drawing of the Parameter Settings 2<sup>nd</sup> level interface. The upmost groups are the ones that need to be configured. After pressing the corresponding buttons, the settings interface of the corresponding function code group will pop up. The downmost groups display the operation state, since the modification of the function codes are closely related to the operation state. The Return button is for returning to the previous menu.

4) The description of the 2<sup>nd</sup> level interface popped up by clicking Operation Recording button

Run Record						Record-cycle setting			5	Second	
Item	Time	Date	STATUS	SET FREQ	OUT FREQ	IN VOLT	OUT VOLT	OUT CURR	SPEED	OUTPOWER	
30	09:21	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
29	09:21	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
28	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
27	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
26	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
25	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
24	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
23	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
22	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
21	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
20	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
19	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
18	09:20	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
17	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
16	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
15	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
14	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
13	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
12	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
11	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
10	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
9	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
8	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
7	09:19	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
6	09:18	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
5	09:18	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
4	09:18	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
3	09:18	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
2	09:18	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
1	09:18	20/10/10	0	0.00	0.00	0	0	0.0	0	0.0	
Download to U-Disk											RETURN

Figure 7.6 Schematic drawing of the Running recoding 2nd level interface. This interface is mainly for popping up the running historical records of the frequency inverter. The buttons below are for the operations of turning pages

and deleting records.

### 5) Description of the 2<sup>nd</sup> level interface popped up by pressing Fault recording button

Header: 06/13/10 15:04:45 当前故障: 代码=NONE; 频率=0.00; 电压=0.0; 电压=0.0

故障描述: 加速过电流

故障可能原因:

1. 加速太快
2. 电网电压偏低
3. 变频调速系统功率偏小

解决措施:

1. 增大加速时间
2. 检查输入电源
3. 选用功率大一档的变频调速系统

Bottom Bar: 历史故障记录 | 删除所有故障 | 返回

Figure 7.7 Schematic drawing of the Fault Recording 2<sup>nd</sup> level interface

When the user presses the Fault Recording button or the fault of the frequency inverter exists, this interface will pop out. The main interface is for displaying the fault information. The Previous and Next button on the right are for querying the previous and next fault information; Delete This and Delete All buttons are for deleting the fault information the users don't need.

### 6) Description of the 2<sup>nd</sup> level interface popped up by pressing Running state button.

Run Status Display

RUN FREQ:	0.00	Hz	OUT TORQ:	0.0	%
SET FREQ:	0.00	Hz	PID Set:	0.0	%
IN VOLT:	0	V	PID Feedback:	0.0	%
IN CURR:	0.0	A	INPUT STATUS:	0000	
OUT VOLT:	0	V	OUTPUT STATUS:	0000	
OUT CURR:	0.0	A	AI1:	0.0	%
SPEED:	0	rpm	AI2:	0.0	%
OUTPOWER:	0.0	%	AI3:	0.0	%

RETURN

Figure 7.8 Schematic drawing of the run state 2nd level interface

When the user presses the Running state button, this interface will pop out. The main interface is for displaying the parameters information of running.

#### 4 Description of 3-level interface

##### 1) The 2<sup>nd</sup> level interface that can generate the 3<sup>rd</sup> level interface

The 2<sup>nd</sup> level interface popped up by pressing Parameter Settings button can generate the 3<sup>rd</sup> level interface.

##### 2) Description of the Parameter Settings 3<sup>rd</sup> level interface

RUN/STOP CTRL P1:			
00 START MODE(0-2) 0:Start directly	06 STOP BRAK FREQ(0.00-P0.07) 0.00 Hz	12 RESTART ACT(0-1) 0:Disabled	
01 START FREQ(0.00-10.00) 0.00 Hz	07 STOP BRAK DELAY(0.0-50.0) 0.0 S	13 RESTART DELAY TIME(0.0-3600.0) 0.0 S	
02 HOLD TIME(0.0-50.0) 0.0 S	08 STOP BRAK CURR(0.0-120.0) 0.0 %	14 STOP SWITCH ACT(0-1) 0:Disabled	
03 START BRAK CURR(0.0-120.0) 0.0 %	09 STOP BRAK TIME(0.0-50.0) 0.0 S	15 QF CLOSE DELAY(0.0-3600.0) 0.0 S	
04 START BRAK TIME(0.0-50.0) 0.0 S	10 FWD/REV DEAD TIME(0.0-3600.0) 0.0 S	16 READY SEND DELAY(0.0-3600.0) 0.0 S	
05 STOP MODE(0-1) 0:DEC Stop	11 ACT(FREQ<P0.09)(0-2) 0: Run at P0.09		
STATUS: <b>Fault</b>		RETURN	

Figure 7.9 Parameter Settings 3<sup>rd</sup> level interface

The main interface is mainly for displaying the value and state of the function codes. Users can click corresponding function codes to perform the setting and modifying operations.

##### 3) The interface of the 3<sup>rd</sup> level sub-menu popped up by Running Mode Settings




Figure 7.10 Schematic drawing of the Running Mode Settings 3<sup>rd</sup> level interface

Current Running Mode displays the current variable frequency speed control

system is in Variable frequency, Power frequency or Power-off.

The lower-left button represents the required operations. Under the current operation, if button operation is allowed, then this button is black, otherwise the button is grey.

The lower-right graph displays the current specific action state of the contactor of the variable frequency speed control system and the distribution of the high voltage.

#### 4) The description of the 3rd level sub-menu popped up by software version

CELL	MCU EDIT	CPLD EDIT	CELL	MCU EDIT	CPLD EDIT	CELL	MCU EDIT	CPLD EDIT
A1	0.00	0.00	B1	0.00	0.00	C1	0.00	0.00
A2	0.00	0.00	B2	0.00	0.00	C2	0.00	0.00
A3	0.00	0.00	B3	0.00	0.00	C3	0.00	0.00
A4	0.00	0.00	B4	0.00	0.00	C4	0.00	0.00
A5	0.00	0.00	B5	0.00	0.00	C5	0.00	0.00
A6	0.00	0.00	B6	0.00	0.00	C6	0.00	0.00
A7	0.00	0.00	B7	0.00	0.00	C7	0.00	0.00
A8	0.00	0.00	B8	0.00	0.00	C8	0.00	0.00
A9	0.00	0.00	B9	0.00	0.00	C9	0.00	0.00

STATUS: **Fault** RETURN

Figure 7.11 Schematic drawing of the software edition 3rd level interface

This interface mainly displays the current software version of FPGA and power unit of the variable frequency speed control system

#### 5. Description of common interfaces

**RUN/STOP CTRL P1:**

00 START MODE(0-2) 0:Start directly

01 START FREQ(0.00-10.00) 0.00 Hz

02 HOLD TIME(0.0-60.0) 0.0 S

03 START BRAK CURR(0.0-120.0) 0.0 %

04 START BRAK TIME(0.0-60.0) 0.0 S

06 STOP MODE(0-1) 0:DEC Step

06 STOP BRAK FREQ(0.00-P0.07)

0:Start directly

1:DC Brake & Start

2:Speed trace start

10 FWDREV DEAD TIME(0.0-3600.0) 0.0 S

11 ACT(FREQ<P0.09)(0-2) 0:Run at P0.09

12 RESTART ACT(0-1) 0:Disabled

13 RESTART DELAY TIME(0.0-3600.0) 0.0 S

14 STOP SWITCH ACT(0-1) 0:Disabled

15 OF CLOSE DELAY(0.0-3600.0) 0.0 S

16 READY SEND DELAY(0.0-3600.0) 0.0 S

STATUS: **Fault** RETURN

Figure 7.12 Schematic drawing of the common interface of Parameter Settings

As for the input of enumeration type, the enumeration interface as shown in

the figure above will pop out after clicking; users can complete the settings by clicking the corresponding items.

**RUN/STOP CTRL P1:**

00 START MODE(0-2)  
0: Start directly

01 START FREQ(0.00-10.00)  
0.00 Hz

02 HOLD TIME(0.0-50.0)  
0.0 S

03 START BRAK CURR(0.0-120.0)  
0.0 %

04 START BRAK TIME(0.0-50.0)  
0.0 S

05 STOP MODE(0-1)  
0: DEC Stop

06 STOP BRAK FREQ(0.00-P0.07)  
0.00 Hz

07 STOP BRAK DELAY(0.0-50.0)  
0.0 S

08 STOP BRAK CURR(0.0-120.0)  
0.0

09 STOP BRAK TIME(0.0-50.0)  
0.0

10 FWDREV DEAD  
0.0

11 ACT(FREQ<P0.0)  
0: Run at P0.09

12 RESTART ACT(0-1)  
0: Disabled

13 RESTART DELAY TIME(0.0-3600.0)  
0.0 S

14 STOP SWITCH ACT(0-1)  
0.0 S

15 STOP SWITCH DELAY(0.0-3600.0)  
0.0 S

**STATUS:**

**RETURN**

Figure 7.13 Schematic drawing of the common interface of Parameter Number Settings

As for the input of number type, the settings interface as shown in the figure above will pop out after clicking; users can carry out the settings of numbers by the popped-out soft keyboard.

## Detailed Functional Description 8

### P0 Group - Basic Function

Function Code	Name	Description	Setting Range	Factory Setting
P0.00	Speed control mode	0: V/F control 1: Vector control(reserved)	0~1	0

Select speed control mode of the inverter.

0: V/F control

V/F control: It is suitable for general purpose application such as pumps, fans etc. and it can also drive several motors.

Function Code	Name	Description	Setting Range	Factory Setting
P0.01	Run command source	0: Keypad 1: Terminal 2: Communication	0~2	0

The control commands of inverter include: starting, stopping, forward running, reverse running, jogging, and fault reset and so on.

0: Keypad "(LOCAL/REMOT" LED extinguished)

Both **RUN** and **STOP/RST** key are used for running command control. If Multifunction key **QUICK/JOG** is set as FWD/REV switching function, Reference the description of specific functions P7.03.

**In running state, pressing **RUN** and **STOP/RST** simultaneously will cause the inverter to coast to stop.**

1: Terminal (LED flickering)

The operation, including forward running, reverse running, forward jogging, reverse jogging etc. can be controlled by multifunctional input terminals.

2: Communication (LED lights on)

The running operation of inverter can be controlled through communication (Modbus). If you set "2" then can operate by touch-screen.

**Note: CHH series high voltage inverter communicate channel is used by touch screen.**

Function Code	Name	Description	Setting Range	Factory Setting
P0.02	Keyboard and Terminal UP/DOWN setting	0: Valid, save UP/DOWN value when power off 1: Valid, do not save UP/DOWN value when power off 2: Invalid 3: Valid during running, clear when power off	0~3	0

Modify the setting frequency of the system through “▲” and “▼” and terminal UP/DOWN. The setting method not only can combine all frequency setting channels (exclude multi-step speed), but also can realize the inch-adjusting for the setting frequency.

0: Valid, save UP/DOWN value when power off.

User can adjust the reference frequency by UP/DOWN. The value of UP/DOWN can be saved when power off.

1: Valid, do not save UP/DOWN value when power off.

User can adjust the reference frequency by UP/DOWN, but the value of UP/DOWN will not be saved when power off.

2: Invalid.

User can not adjust the reference frequency by UP/DOWN. The value of UP/DOWN will be cleared if P0.02 is set to 2.

3: Valid during running, clear when power off

User can adjust the reference frequency by UP/DOWN when inverter is running. When inverter power off, the value of UP/DOWN will be cleared

Note:

- UP/DOWN function can be achieved by keypad (▲ and ▼) and multifunctional terminals.
- Reference frequency can be adjusted by UP/DOWN.
- UP/DOWN has highest priority which means UP/DOWN is always active no matter which frequency command source is.

- When the factory setting is restored (P0.18 is set to be 1), the value of UP/DOWN will be cleared.

**Note: The value of UP/DOWN will be cleared when user restore the inverter.**

Function Code	Name	Description	Setting Range	Factory Setting
P0.03	Frequency A command source	0: Keypad 1: AI1 2: AI2 3: AI3 4: HDI1 5. Multi-Step speed 6: PID 7: Communication	0~7	0
P0.04	Frequency B command source	0: AI1 1: AI2 2: AI3 3: HDI	0~3	0
P0.05	Reference selection of frequency B	0: Maximum frequency 1: Frequency A command	0~1	0
P0.06	Combination of frequency source	0:A 1:B 2:A+B 3:Max(A,B)	0~3	0

CHH series inverter have two command sources A and B channel, A command source is general channel, B command source is assistant channel, Real frequency setting consist of the two channels, Frequency command selection refer to P0.05 and P0.06.






Figure 8.1 A, B channel combination diagram

**Note:**

1. Current or voltage signals of analog input is selectable by jumper.
2. AI1, AI2, AI3 is programmable analog input terminals, please refer to description of P5 group.
3. When the command source is HDI. Please set its percentage by referring to description of P5 group.
4. Standards for HDI setting: 24V, 0.0~50.0 kHz.
5. When the A frequency channel select multi-speed control, the variable frequency speed control system will run by multi-stage speed. Through setting the combination of P5 Group select the currently running stage; through setting the combination of PA Group select the currently running frequency.
6. P0.03 = 5 (multi-stage speed control) meaning as follows: When the multi-stage speed input is 0 ,A frequency source depends on the frequency of the 0 speed; at this time UP / DOWN apply the fine-tuning value for the multi-stage speed 0.
7. When the Frequency channel is selected to Modbus communication, the user can write the frequency to the cell of address 2000H by Modbus, specific content can refer to the Communications Agreement.
8. P0.06 is used for selecting the method of main setting frequency, the 0, 1, 2 corresponding combination function can be switched via terminals (P5 group).

Function Code	Name	Description	Setting Range	Factory Setting
P0.07	Maximum frequency	P0.08~120.00Hz	P0.08~120.00Hz	50.00Hz

**Note:**

1. The frequency reference should not exceed maximum frequency.
2. Actual acceleration time and deceleration time are determined by maximum frequency. Please refer to description of P0.11 and P0.12.
3. Set the maximum output frequency. It is the basis of the acceleration/ deceleration time and the running frequency setting.

Function Code	Name	Description	Setting Range	Factory Setting
P0.08	Upper frequency limit	P0.09~ P0.07	P0.09~ P0.07	50.00Hz
P0.09	Lower frequency limit	0.00 Hz ~ P0.08	0.00 ~ P0.08	0.00Hz

**Note:**

1. Upper and lower frequency limit of the variable frequency speed control system.
2. Restrictions on the relationship between frequencies: Maximum frequency  $\geq$  Upper frequency  $\geq$  setting frequency  $\geq$  lower frequency.

Function Code	Name	Description	Setting Range	Factory Setting
P0.10	Keyboard setting frequency	0.00 Hz ~ P0.07	0.00 ~ P0.07	50.00Hz

When the instruction of A frequency is selected to "Keyboard Settings", the function code value is the initial frequency value of the variable frequency speed control system.

Function Code	Name	Description	Setting Range	Factory Setting
P0.11	Acceleration time 0	0.1~3600.0s	0.1~3600.0s	Depend on model
P0.12	Deceleration	0.1~3600.0s	0.1~3600.0s	Depend

Function Code	Name	Description	Setting Range	Factory Setting
	time 0			on model

Acceleration time is the time of accelerating from 0Hz to maximum frequency (P0.07). Deceleration time is the time of decelerating from maximum frequency (P0.07) to 0Hz. Please refer to following figure.




Figure 8.2 Acceleration and Deceleration time

When the setting frequency equals to the maximum frequency, the actual acceleration and deceleration time will be in accordance with the setting time.

When the reference frequency is less than the maximum frequency, the actual acceleration and deceleration time will be less than the setting time.

The actual acceleration (deceleration) time = the setting time \* reference frequency/ maximum frequency.

CHH series inverter has 4 groups of acceleration and deceleration time.

1<sup>st</sup>: P0.11, P0.12;

2<sup>nd</sup>: P3.00, P3.01;

3<sup>rd</sup>: P3.02, P3.03;

4<sup>th</sup>: P3.04, P3.05.

The acceleration and deceleration time can be selected by combination of multifunctional ON-OFF input terminals.

Function Code	Name	Description	Setting Range	Factory Setting
P0.13	Running direction selection	0:Default direction running 1:Opposite direction running 2:Forbid reverse	0~2	0

0: Default orientation run. After the power of the variable frequency inverter is connected, the variable frequency inverter will run in accordance with the actual direction.

1: Opposite direction running. It is used for changing the direction of motor, and it is equivalent to changing the direction of motor by changing the cable.

When the factory setting is restored, the rotation direction of motor may be restored to its original state. Please be cautious to use.

2: Forbid reverse. It is used for forbidding the variable frequency inverter reverse running. Such as on the occasions which needs to switch between Industrial Frequency and variable frequency occasion.

Function Code	Name	Description	Setting Range	Factory Setting
P0.14	Carrier frequency setting	0.5~2.0kHz	0.5~2.0kHz	0

**Note: The factory setting is optimal in most cases, modification of this parameter is not recommended, if the carrier frequency exceeds the factory setting, the inverter must be derated.**

Function Code	Name	Description	Setting Range	Factory Setting
P0.15	Motor parameters autotuning	0: No action 1: Autotuning (Reserved)	0~1	0
P0.16	Restore parameters	0: No action 1: Restore factory setting 2: Clear fault records	0~2	0

**Note: After P0.16 function operation is completed, this function code will**

**restore to 0 automatically. The parameters of P2 group will not return.**

Function Code	Name	Description	Setting Range	Factory Setting
P0.17	AVR function	0: Disabled 1: Enabled all the time 2: Disabled during deceleration	0~2	1

AVR (Auto Voltage Regulation) function ensures the output voltage of inverter stable no matter how the DC bus voltage changes. During deceleration, if AVR function is disabled, the deceleration time will be short, and the output voltage of Inverter will change with the input voltage (or DC bus voltage).

### **P1 Group - Start and Stop Control**

Function Code	Name	Description	Setting Range	Factory Setting
P1.00	Start Mode	0: Start directly 1: DC braking and start 2: Speed tracking and start	0~2	0

0: Start directly: Start the motor from the starting frequency.

1: DC braking and start: Inverter will output DC current firstly and then start the motor at the starting frequency. Please refer to description of P1.03 and P1.04. It is suitable for the motor which have small inertia load and may reverse rotation when start.

2: Speed tracking and start: Inverter detects the rotation speed and direction of motor, then start running to its reference frequency based on current speed. This can realize smooth start of rotating motor with big inertia load when instantaneous power off.

Function Code	Name	Description	Setting Range	Factory Setting
P1.01	Starting frequency	0.00~10.00Hz	0.00~10.00	0.00Hz

Function Code	Name	Description	Setting Range	Factory Setting
P1.02	Hold time of starting frequency	0.0~50.0s	0.0~50.0	0.0s

The inverter will start from the starting frequency (P1.01), and after hold time of starting frequency (P1.02), the running frequency of inverter will increase to reference frequency. If the reference frequency is less than starting frequency, inverter will be at stand-by state. The starting frequency couldn't be limited by the lower frequency.

**Note: When the inverter starts directly, if the reference frequency is less than starting frequency, the inverter will be at stand-by state. Inverter has no output.**

Function Code	Name	Description	Setting Range	Factory Setting
P1.03	DC Braking current before start	0.0~120.0%	0.0~120.0	0.0%
P1.04	DC Braking time before start	0.0~50.0s	0.0~50.0	0.0s

**Note:**

1. P1.03: Before starting, the value of DC braking current is the percentage of rated current of the variable frequency inverter.
2. P1.04: It is duration of the DC current. DC braking is invalid when P1.04 is set to be 0.
3. The bigger the DC braking current, the greater the braking torque will get.

Function Code	Name	Description	Setting Range	Factory Setting
P1.05	Stop Mode	0:Decelerate to stop 1:Coast to stop	0~1	0

0: Decelerate to stop

When the stop command takes effect, the inverter decreases the output frequency according to the selected deceleration time till stop.

1: Coast to stop

When the stop command takes effect, the inverter blocks the output immediately. The motor coasts to stop by its mechanical inertia.

Function Code	Name	Description	Setting Range	Factory Setting
P1.06	Starting frequency of stop braking	0.00~P0.07(Maximum frequency)	0.00~P0.07	0.00Hz
P1.07	Waiting time before stop braking	0.0~50.0s	0.0~50.0	0.0s
P1.08	DC braking current	0.0~120.0%	0.0~120.0	0.0%
P1.09	DC braking time	0.0~50.0s	0.0~50.0	0.0s

Starting frequency of stop braking: During deceleration, start the DC braking when running frequency reaches the starting frequency. If the value of stop braking starting frequency is 0, DC braking is invalid; the variable frequency speed control system will stop according to the set deceleration time.

Waiting time before DC braking: Inverter blocks the output before starting the DC braking. After this waiting time, the DC braking will start. It is used to

prevent over-current fault caused by DC braking at high speed.

DC braking current: The value is the DC braking current Imposed. The bigger the DC braking current, the greater the braking torques.

DC braking time: The time used to perform DC braking.




Figure 8.3 DC braking diagram

Function Code	Name	Description	Setting Range	Factory Setting
P1.10	Dead time of FWD/REV	0.0~3600.0s	0.0~3600.0	0.0s

Set the hold time at zero frequency in the transition between forward and reverse running. It is shown as following figure:




Figure 8.4 FWD/REV dead time diagram



Function Code	Name	Description	Setting Range	Factory Setting
P1.11	Action when running frequency is less than lower frequency limit	0: Running at the lower frequency limit 1: Stop 2: Stand-by	0~2	0

This function code determines the running state of the variable frequency control system, when reference frequency is less than lower frequency limit, Stand-by: Inverter will stand-by when the reference frequency is less than lower frequency limit. When the reference frequency is higher than or equal to lower frequency limit again, the inverter will start to run automatically.

Function Code	Name	Description	Setting Range	Factory Setting
P1.12	Restart after power off	0: Disabled 1: Enabled	0~1	0
P1.13	Delay time for restart	0.0~3600.0s	0.0~3600.0	0.0s

P1.12: When inverter is running, after power off and power on again, what state will the inverter be.

0: Disabled: Inverter will not automatically restart when power on again.

1: Enabled: When inverter is running, after power off and power on again, the inverter will automatically restart after delay time for restart (P1.13) (If the inverter is terminal control, must ensure that the running terminals are still in the closed state), otherwise the inverter will not automatically restart.

**Note: This function may cause serious consequences, please use it with cautious.**

# Detailed functional description

Function Code	Name	Description	Setting Range	Factory Setting
P1.14	High voltage switching action select when stopping	0:Cut off high voltage supply 1:Holding	0~1	1

The function decides whether cut off high voltage automatically after system stopping.

0: Cut off high voltage: the system will stop according to instruction, cut off the main circuit high voltage automatically (If it also controls the higher vacuum circuit breaker, then it will break the higher vacuum circuit breaker at the same time).

1: Holding: The system will stop according to instruction, but do not cut off high voltage automatically until receiving high voltage breaking signals.

Function Code	Name	Description	Setting Range	Factory Setting
P1.15	Waiting time of switching on	0.0~3600.0s	0.0~3600.0	10.0s

System receive switching on signals, P1.15 is the waiting time which contain switching cabinet action time, system fault self-testing time and sending enable signal time of high voltage switching on.

The waiting time is used to protect the unit from assault because of short time between adjacent switching on.

Function Code	Name	Description	Setting Range	Factory Setting
P1.16	Waiting time of running in	0.0~3600.0s	0.0~3600.0	10.0s

Function Code	Name	Description	Setting Range	Factory Setting
	order.			

The waiting time of running in order is calculated from finished charging of DC bus to signal sending of running in order to upgrade DCS after vacuum contactor high voltage switching on.

The time is used to make sure DC bus charging completely, and reducing the assault of grid voltage.

## P2 Group - Motor Parameters

Function Code	Name	Description	Setting Range	Factory Setting
P2.00	Inverter Model	0:Asynchronous motor 1:Synchronous motor (Reserved)	0~1	Depend on model
P2.01	Motor rated power	4.0~7100.0kW	4.0~7100.0	Depend on model
P2.02	Motor rated frequency	10.00~P0.07	10.00~P0.07	50.00Hz
P2.03	Motor rated speed	1~36000rpm	1~36000	Depend on model
P2.04	Motor rated voltage	0~20000V	0~20000	Depend on model
P2.05	Motor rated current	0.1~1000.0A	0.1~1000.0	Depend on model

### Note:

1. The motor parameters is particularly important in motor protection and the voltage output, so be sure to set the parameters in accordance

with the setting parameters.

2. In order to achieve superior performance, the rated power of the inverter should match the motor. If the bias is too big, the control performances of inverter will be deteriorated distinctly.

3. Resetting the rated power of the motor (P2.01) can initialize P2.06~P2.10 automatically.

Function Code	Name	Description	Setting Range	Factory Setting
P2.06	Motor stator resistance	0.001~65.535Ω	0.001~65.535	Depend on model
P2.07	Motor rotor resistance	0.001~65.535Ω	0.001~65.535	Depend on model
P2.08	Motor leakage inductance	0.1~6553.5mH	0.1~6553.5	Depend on model
P2.09	Motor mutual inductance	0.1~6553.5mH	0.1~6553.5	Depend on model
P2.10	Current without load	0.01~655.35A	0.01~655.35	Depend on model

The parameters from P2.06~P2.10 are reserved temporarily in V/F control.

### P3 Group - Auxiliary function

Function Code	Name	Description	Setting Range	Factory Setting
P3.00	Acceleration time 1	0.1~3600.0s	0.1~3600.0	Depend on model
P3.01	Deceleration time 1	0.1~3600.0s	0.1~3600.0	Depend on

Function Code	Name	Description	Setting Range	Factory Setting
				model
P3.02	Acceleration time 2	0.1~3600.0s	0.1~3600.0	Depend on model
P3.03	Deceleration time 2	0.1~3600.0s	0.1~3600.0	Depend on model
P3.04	Acceleration time 3	0.1~3600.0s	0.1~3600.0	Depend on model
P3.05	Deceleration time 3	0.1~3600.0s	0.1~3600.0	Depend on model

Acceleration and deceleration time can be switched between groups 0 to 3 according to multi-function digital input terminals by different combinations of acceleration and deceleration time. The meaning of the different acceleration and deceleration time is the same. For details, please refer to description of P0.11 and P0.12.

Function Code	Name	Description	Setting Range	Factory Setting
P3.06	Jog frequency	0.00~P0.07	0.00~P0.07	5.00Hz
P3.07	Jog acceleration time	0.1~3600.0s	0.1~3600.0	Depend on model
P3.08	Jog deceleration time	0.1~3600.0s	0.1~3600.0	Depend on model

Jog start-stop manner of in operation: directly starting and decelerating to stop.

Jog acceleration time means the required accelerate time from 0Hz to

maximum output frequency (P0.07) of the inverter.

Jog deceleration time means the required decelerate time from the maximum output frequency (P0.07) to 0Hz time of the inverter.

Function Code	Name	Description	Setting Range	Factory Setting
P3.09	Skip frequency 1	0.00~P0.07	0.00~P0.07	0.00Hz
P3.10	Skip frequency bandwidth 1	0.00~P0.07	0.00~P0.07	0.00Hz
P3.11	Skip frequency 2	0.00~P0.07	0.00~P0.07	0.00Hz
P3.12	Skip frequency bandwidth 2	0.00~P0.07	0.00~P0.07	0.00Hz

**Note:**

1. By means of setting skip frequency, the inverter can keep away from the mechanical resonance with the load. The inverter can set two skip frequencies, if two skip frequencies are 0, the skip function is invalid.




Figure 8.5 Skip frequency diagram

Function Code	Name	Description	Setting Range	Factory Setting
P3.13	Auto reset times	0~3	0~3	0
P3.14	Auto reset interval	0.1~100.0s	0.1~100.0	1.0s

Auto reset times: When the inverter is selected automatic fault reset, the times of automatic reset can be set by the user. When the number of consecutive reset more than the set value, the fault will cause the inverter stopping, require manual intervention.

Auto reset interval is to set the interval from the fault occur to auto reset take effect.

Function Code	Name	Description	Setting Range	Factory Setting
P3.15	FDT level	0.00~P0.07	0.00~P0.07	50.00Hz
P3.16	FDT lag	0.0~100.0%	0.0~100.0	5.0%

When the output frequency reaches a certain preset frequency (FDT level), output terminal will output an ON-OFF signal until output frequency drops below a certain frequency of FDT level (FDT level - FDT lag), as shown in following figure.




Figure 8.6 FDT Level diagram

**Note: FDT lag is relative to the percentage of FDT level.**

Function Code	Name	Description	Setting Range	Factory Setting
P3.17	Frequency arrival detecting range	0.0~100.0%	0.0~100.0	0.0%

When output frequency is within the detecting range of reference frequency, an ON-OFF signal will be output.




Figure 8.7 Frequency arriving detection diagram.

**Note: Frequency arrival detecting range is relative to the percentage of P0.07.**

Function Code	Name	Description	Setting Range	Factory Setting
P3.18	Over modulation selection	0:Invalid 1:Valid	0~1	0

This parameter can increase the utilization of DC bus to raise output voltage when system works with full load and low grid voltage (85% rated voltage below) for long time.



Function Code	Name	Description	Setting Range	Factory Setting
P3.19	Operation mode of cooling fans	0: Automatic stopping 1: Operating all the time	0~1	0

0: Automatic stopping: Cooling fans work during system operation time, the fans stop after the system stopped for 30s.

1: The fan works all the time when the system is powering on.

Function Code	Name	Description	Setting Range	Factory Setting
P3.20	Alarm reset intervals	0.1~3600.0s, 0.0: Alarm function invalid	0.0~3600.0s	0.0s

**Note:**

1. Alarm reset intervals is used for resetting alarm when the system comes out unusual state which is not serious enough to cause damage, but it may lead to error.
2. The user can use P3.20 to select whether it needs alarm report or not and reset intervals.

## P4 Group - V/F Control Parameter

The parameters of the group is only valid for V/F control (P0.00=0).

Function Code	Name	Description	Setting Range	Factory Setting
P4.00	V/F curve selection	0: Linear curve 1: User-defined curve 2: Torque-stepdown curve (1.3 order) 3: Torque-stepdown curve (1.7 order) 4: Torque-stepdown curve (2.0 order)	0~4	0

0: Linear curve. It is applicable for normal constant torque load.

1: User-defined curve. It can be defined through setting (P4.05~P4.10).

2~4: Torque\_stepdown curve. It is applicable for variable torque load, such as blower, pump and so on. Please refer to following figure.

**Note: The  $V_b$  corresponds to the motor rated voltage;  $f_b$  corresponds to the motor rated frequency in the figure below.**




Figure 8.8 Multiple V/F curve diagram

Function Code	Name	Description	Setting Range	Factory Setting
P4.01	Torque boost	0.1~10.0% (0.0 Automatic)	0.0~10.0	1.0%
P4.02	Torque boost cut-off	0.0~50.0% (motor rated frequency)	0.0~50.0	20.0%

Torque boost will take effect when output frequency is less than cut-off frequency of torque boost (P4.02). Torque boost can improve the torque performance of V/F control at low speed.

The value of torque boost should be determined by the load. The heavier the load, the larger the value should be set.

But this value should not be too large, otherwise may cause the motor over excitation and over-heat or the inverter would be tripped by over-current or over-load.

If value of function is set to 0, the inverter will boost the output torque according to the load automatically. Please refer to following diagram.

**Torque boost cut-off:** If value of output frequency is less than cut-off frequency, the torque boost is valid, otherwise the torque boost is invalid.




Figure 8.9 Manual torque boost diagram.

Function Code	Name	Description	Setting Range	Factory Setting
P4.03	V/F slip compensation	0.0~200.0%	0.0~200.0	0.0%

The motor's slip changes with the load torque, which results in the variance of motor speed. The inverter's output frequency can be adjusted automatically through slip compensation according to the load torque. Therefore the change of speed due to the load change can be reduced. The value of compensated slip is dependent on the motor's rated slip which can be calculated as below:

$$P4.03 = (f_b - n \cdot p / 60) / f_b$$

Where  $f_b$  is motor rated frequency (P2.02),  $n$  is motor rated speed (P2.03), and  $p$  is pole pairs of motor.

Function Code	Name	Description	Setting Range	Factory Setting
P4.04	Auto energy saving selection	0: Energy saving invalid 1: Energy saving valid	0~1	0

Energy saving operation is that while there is a light load, it will reduce the inverter output voltage by detecting the load current and saves energy.

**Note:** the function have particular effect to fan, pumps etc.

Function Code	Name	Description	Setting Range	Factory Setting
P4.05	V/F frequency 1	0.00~P4.07	0.00~P4.07	0.00Hz
P4.06	V/F voltage 1	0.0~100.0% (Motor rated voltage)	0.0~100.0	0.0%
P4.07	V/F frequency 2	P4.05~P4.09	P4.05~P4.09	0.00Hz
P4.08	V/F voltage2	0.0~100.0% (Motor rated voltage)	0.0~100.0	0.0%
P4.09	V/F frequency 3	P4.07~P2.02	P4.07~P2.02	0.00Hz
P4.10	V/F voltage 3	0.0~100.0% (Motor rated voltage)	0.0~100.0	0.0%

P4.05~P4.10 are used to set the user-defined V/F curve. The value should be set according to the load characteristic of motor.

**Note:**

1.  $V1 < V2 < V3$ ,  $f1 < f2 < f3$ .
2. The voltage corresponding to low frequency should not be set too high, otherwise it may cause motor overheat or inverter fault.




Figure 8.10 V/F curve setting diagram.

**Note:** V/F voltage is relative to the percentage of motor rated voltage

**(P2.04).**

Function Code	Name	Description	Setting Range	Factory Setting
P4.11	PWM mode selection	0: SPWM 1 1: SPWM 2	0~1	0

P4.11 is used to select the way of modulate waveform.

0: SPWM 1, sine waveform with triple-harmonics

1: SPWM 2, standard sine waveform

**P5 Group - Input terminals**

CHH series have 16 multifunction digital input terminals, 3 analog input terminals and 1 high speed pulse input terminal.

Function Code	Name	Description	Setting Range	Factory Setting
P5.00	S1 Terminal function	0~39	0~39	0
P5.01	S2 Terminal function	0~39	0~39	0
P5.02	S3 Terminal function	0~39	0~39	0
P5.03	S4 Terminal function	0~39	0~39	0
P5.04	S5 Terminal function	0~39	0~39	0
P5.05	S6 Terminal function	0~39	0~39	0

Function Code	Name	Description	Setting Range	Factory Setting
P5.06	S7 Terminal function	0~39	0~39	0
P5.07	S8 Terminal function	0~39	0~39	0
P5.08	S9 Terminal function	0~39	0~39	0
P5.09	S10 Terminal function	0~39	0~39	0
P5.10	S11 Terminal function	0~39	0~39	0
P5.11	S12 Terminal function	0~39	0~39	0
P5.12	S13 Terminal function	0~39	0~39	0
P5.13	S14 Terminal function	0~39	0~39	0
P5.14	S15 Terminal function	0~39	0~39	0
P5.15	S16 Terminal function	0~39	0~39	0

Setting value	Function	Description
0	Invalid	Please set unused terminals to be invalid to avoid malfunction.
1	Forward	When the run command channel is set as terminal control, the run command of inverter is given by the two terminal functions.
2	Reverse	
3	3-wire control	Please refer to description of P5.18.
4	Jog forward	Please refer to description of P3.06~P3.08.
5	Jog reverse	
6	Coast to stop	The inverter blocks the output immediately. For large inertia loads and without limiting the stop time, it is advised to apply the methods. It has the same meaning as P1.05.
7	Reset fault	Resets faults that have occurred. It has the same function as <u>STOP/RST</u> .
8	External fault normal open input	The function of the terminals is to receive the external fault .Stop the inverter and output a alarm when a fault occurs in a peripheral device.
9	External fault normal close input	
10	Up command	The reference frequency of inverter can be adjusted by UP command and DOWN command. Use this terminal to clear the value of UP/DOWN setting. Up command: frequency increment instruction,. Down command: descending order of frequency, Clear UP/DOWN: The terminal is used to clear the value of setting by UP / DOWN. It will take the value of frequency back to the instruction given by
11	Down command	
12	Clear UP/DOWN	

Setting value	Function	Description			
13	Clear UP/DOWN (Temporary )	the frequency channel. Clear UP/DOWN (Temporary); The terminal is used to clear the value of setting by UP / DOWN temporarily when it is valid. the frequency value back to normal when the terminal is invalid			
14	ACC/DEC time selection1	4 groups of ACC/DEC time can be selected by the combination of these two terminals.			
15	ACC/DEC time selection 2	ACC/DEC time selection 2	ACC/DEC time selection1	ACC/DEC time	
		OFF	OFF	ACC/DEC time 0 (P0.11 and P0.12)	
		OFF	ON	ACC/DEC time 1 (P3.00 and P3.01)	
		ON	OFF	ACC/DEC time 2 (P3.02 and P3.03)	
		ON	ON	ACC/DEC time 3 (P3.04 and P3.05)	
16	Multi-step speed reference1	16 steps speed control can be realized by the combination of these four terminals. For details, please refer to the description of P0 and PA group.			
17	Multi-step speed reference 2	<b>Note: multi-speed 1 is low bit, and multi-speed 4 is high bit.</b>			
18	Multi-step speed reference 3	Multi-sp eed terminal 4	Multi-sp eed terminal 3	Multi-sp eed terminal 2	Multi-sp eed terminal 1
19	Multi-step speed reference 4	BIT3	BIT2	BIT1	BIT0



Setting value	Function	Description																
20	Multi-step speed pause	Shield the function of multi-speed terminals and keep the set value as the current state.																
21	Switch between A and B	Switching the channel of frequency can be realized by these terminals.																
22	Switch between A and A+B	When the system frequency is given by A-channel and the function of terminal 21 act, the channel of frequency by given will switch to B-channel; after the terminal 21 return the channel of frequency will switch to A-channel. No. 22, 23 function is invalid.																
23	Switch between B and A+B	<p>The function of No. 22,23 similar to the function of No. 21.</p> <table><tr><td><div>P0.06 Terminal</div></td><td>A</td><td>B</td><td>A+B</td></tr><tr><td>13 valid</td><td>B</td><td>A</td><td></td></tr><tr><td>14 valid</td><td>A+B</td><td></td><td>A</td></tr><tr><td>15 valid</td><td></td><td>A+B</td><td>B</td></tr></table>	<div>P0.06 Terminal</div>	A	B	A+B	13 valid	B	A		14 valid	A+B		A	15 valid		A+B	B
<div>P0.06 Terminal</div>	A	B	A+B															
13 valid	B	A																
14 valid	A+B		A															
15 valid		A+B	B															
24	Pause PID	If PID adjustment is paused , inverter keeps output frequency unchanged.																
25	Pause operation	Pause operation make inverter decelerate to stop, preserve all of running parameters .The inverter recover the running state as before after pause operation disappear.																
26	ACC/DEC ramp hold	Pauses acceleration or deceleration and maintains output frequency. When this terminal is disabled, acceleration/deceleration is restarted.																
27~29	Reserved	Reserved																
30	Variable frequency running	System change From switch off state to variable frequency state of inverter by pulse signal of the terminal. If inverter is under other state, the																

Setting value	Function	Description
		terminals are invalid.
31	Power frequency running	System change From Switch off state to power frequency state of inverter by pulse signal of the terminal. If inverter is under other state, the terminals are invalid.
32	Switching from variable frequency to power frequency.	Switch variable frequency state to power frequency state of inverter by pulse signal of the terminal. If inverter is under other state, the terminals are invalid.
33	Switching from power frequency to variable frequency.	Switch power frequency state to variable frequency state of inverter by pulse signal of the terminal which is from high voltage control DCS, if inverter is under other state, the terminals are invalid. Note: Function of 30~33 is valid only for the inverter containing switching cabinet, If not, they are invalid.
34	Emergency breaking input of high voltage	Send a signal by through the terminal 1 to cut off high voltage of inverter.
35	Running command switch to keypad	If you input 1 signal to the terminal, running command switch to keypad whatever the command source is valid.
36	Running command switch to terminals	If you input 1 signal to the terminals, running command switch to terminals whatever the command source is valid.

Setting value	Function	Description
37	Running command switch to communication	If you input 1 signal to the terminals, running command switch to remote host whatever the command source is valid.
38	Input signals of high voltage switching on.	Terminal with the function connect to feed back signals from up level switcher of high voltage. The inverter can detect current state of up level high voltage switcher.
39	Reserved	Reserved

Function Code	Name	Description	Setting Range	Factory Setting
P5.16	Polar selection of input terminal	0x0000~0xFFFF	0000~FFFF	0000

Setting polar selection of ON/OFF input terminals, each terminal takes up one bit, 0: normal open, 1: normal close.

S16	S15	S14	S13	S12	S11	S10	S9	S8	S7	S6	S5	S4	S3	S2	S1
BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT	BIT
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

Function Code	Name	Description	Setting Range	Factory Setting
P5.17	Filter time of digital signal	0~10	0~10	5

Set S1~S16 terminals filter time of sampling, and increasing the parameter can Increase anti-interference ability to prevent incorrect operation.

Function Code	Name	Description	Setting Range	Factory Setting
P5.18	Terminal control run mode	0: Two-wire control mode 1 1: Two-wire control mode 2 2: Three-wire control mode 1 3: Three-wire control mode 2	0~3	0

This parameter defines four different control modes that control the inverter operation through external terminals.

0: two-wire control mode 1: Enable terminal and direction terminal are combined. This is the most frequently used two-line mode. The direction of forward or reverse motor is determined by the definition of FWD, REV terminal command.

K1	K2	Run command
OFF	OFF	Stop
ON	OFF	FWD
OFF	ON	REV
ON	ON	Stop




Figure 8.11 Two-wire control mode

1: two-wire control mode 2: Enable terminal is separate from direction terminal. START/STOP command is determined by FWD terminal. Run direction is determined by REV terminal.

K1	K2	Run command
OFF	OFF	Stop
ON	OFF	FWD
OFF	ON	Stop
ON	ON	REV




Figure 8.12 Two-wire control mode 2

2: three-wire control mode 1: SB1: Start button. SB2: Stop button (NC), K: Run

direction button, Terminal SIn is the multifunctional input terminal of 0~39. The terminal function should be set to be 3 (3-wire control).

When the SIn is closed, the run command generated by the FWD (terminal rising edge is effective), the direction control by the REV (REV terminals opened refer to forward direction; REV terminals closed refer to reverse direction). When SIn disconnected, FWD, REV control is invalid, Inverter will stop.




Figure 8.13 Three-wire control mode 1

3: three-wire control mode 2:

SB1: Forward run button

SB2: Stop button (NC)

SB3: Reverse run button

Terminal SIn is the multifunctional input terminal of 0~39. The terminal function should be set to be 3 (3-wire control).

When the SIn is closed, the run command generated by the FWD or REV (terminal rising edge is effective), the direction control by the FWD and REV. When SIn disconnected, FWD, REV control and FWD control are invalid, FWD and REV terminals (both rising edge), respectively refer to the inputs of Forward and reverse run command




Figure 8.14 Three-wire control mode 2

**Note:** During 2-wire control mode, when the FWD / REV terminals is active, the stop command generated by other sources can't cause inverter shutdown, the inverter will not run after the stop command disappears even if FWD/REV terminal is enabled. In order to cause the inverter rerunning, you must re-trigger the FWD / REV. For example, during terminal control, through the keyboard **STOP/RST** stop (refer to P7.04).

Function Code	Name	Description	Setting Range	Factory Setting
P5.19	UP setting change rate	0.01~50.00Hz/s	0.01~50.00	0.50 Hz/s
P5.20	DOWN setting change rate	0.01~50.00 Hz/s	0.01~50.00	0.50 Hz/s

This parameter is used to determine how fast UP/DOWN setting changes.

Function Code	Name	Description	Setting Range	Factory Setting
P5.21	AI1 lower limit	0.00~P5.23	0.00~P5.23	0.00V
P5.22	AI1 lower limit corresponding setting	-100.0~100.0	-100.0~100.0	0.0%
P5.23	AI1 upper limit	P5.21~10.00	P5.21~10.00	10.00V
P5.24	AI1 upper limit corresponding setting	-100.0~100.0	-100.0~100.0	100.0%
P5.25	AI1 filter time constant	0.00~10.00s	0.00~10.00	0.10s

These parameters determine the relationship between analog input voltage and the corresponding setting value. When the analog input voltage exceeds the range between lower limit and upper limit, it will be regarded as the upper limit or lower limit.

If the signal of analog input is current signal, the current signal of 0mA~20mA corresponds to the voltage of 0V~5V.

For different applications, the corresponding value of 100.0% analog setting is different. For details, please refer to description of each application.




Figure 8.15 Relationship between AI and corresponding setting

AI1 input filter time: Adjusting the analog input sensitivity. Increase the value of the appropriate analog can enhance the anti-interference, but it will weaken the sensitivity of analog inputs.

Function Code	Name	Description	Setting Range	Factory Setting
P5.26	AI2 lower limit	0.00~P5.28	0.00~P5.28	0.00V
P5.27	AI2 lower limit corresponding setting	-100.0~100.0	-100.0~100.0	0.0%
P5.28	AI2 upper limit	P5.26~10.00	P5.26~10.00	10.00V
P5.29	AI2 upper limit corresponding setting	-100.0~100.0	-100.0~100.0	100.0%
P5.30	AI2 filter time constant	0.00~10.00s	0.00~10.00	0.10s
P5.31	AI3 lower limit	-10.00~P5.33	-10.00~P5.33	0.00V
P5.32	AI3 lower limit corresponding setting	-100.0~100.0	-100.0~100.0	0.0%
P5.33	AI3 upper limit	P5.31~10.00	P5.31~10.00	10.00V
P5.34	AI3 upper limit	-100.0~100.0	-100.0~100.0	100.0%

Function Code	Name	Description	Setting Range	Factory Setting
	corresponding setting			
P5.35	AI3 filter time	0.00~10.00s	0.00~10.00	0.10s

Please refer to description of AI1.

**Note: AI2 support voltage 0 ~ 10V or 0 ~ 20mA current input (with AI1 the same), AI3 only supports voltage input, the input range:-10V ~ 10V.**

Function Code	Name	Description	Setting Range	Factory Setting
P5.36	HDI1 lower limit	0.000kHz~P5.38	0.000kHz~P5.38	0.000 kHz
P5.37	HDI1 lower limit corresponding setting	-100.0~100.0	-100.0~100.0	0.0%
P5.38	HDI1 upper limit	P5.36~50.000kHz	P5.36~50.000	50.000k
P5.39	HDI1 upper limit corresponding setting	-100.0~100.0	-100.0~100.0	100.0%
P5.40	HDI1 filter time	0.00~10.00	0.00~10.00	0.10s

This group of function code defines the corresponding relationships of high-speed pulse input port for high-speed pulse input pulse frequency. The description of P5.21~P5.25 is similar to AI1.

## P6 Group - Output terminals

CHH series have 8 multifunction Relay output terminals (RO1~RO8), 4 analog output terminals (AO1~AO4) and 1 high speed pulse output terminal (Only as high-speed pulse output).



## Detailed functional description

Function Code	Name	Description	Setting Range	Factory Setting
P6.00	Relay 1 output selection	0~20	0~20	0
P6.01	Relay 2 output selection	0~20	0~20	0
P6.02	Relay 3 output selection	0~20	0~20	0
P6.03	Relay 4 output selection	0~20	0~20	0
P6.04	Relay 5 output selection	0~20	0~20	0
P6.05	Relay 6 output selection	0~20	0~20	0
P6.06	Relay 7 output selection	0~20	0~20	0
P6.07	Relay 8 output selection	0~20	0~20	0

Setting Value	Function	Description
0	No output	Output terminal has no function.
1	Run FOR/REV	ON: During forward/reverse run.
2	Fault output	ON: Inverter is in fault state.
3	FDT reached	Please refer to description of P3.15 and

Setting Value	Function	Description
		P3.16.
4	Frequency reached	Please refer to description of P3.17.
5	Zero speed running	ON: The running frequency of inverter is zero.
6	Variable frequency state	ON: inverter working in variable frequency state.
7	Power frequency state	ON: inverter working in power frequency state.
8	Running time reached	ON: Running time to reach setting value.
9	Upper frequency limit reached	ON: Running frequency reaches the upper value.
10	Lower frequency limit reached	ON: Running frequency reaches the lower value.
11	Ready for running	ON: Inverter is ready (no fault, power is ON).
12	Alarm output	ON: Alarm(Not serious enough for error)
13	Permission of high voltage switcher on	Inverter receive Variable frequency, it should pass self-testing and time of waiting for swithing on, and then send signals to up level(operation platform or high voltage switcher), The up level will switch on the high voltage switcher after the receiving.
14	Emergency breaking of high voltage	When inverter need to break with high voltage switcher ,send signals to up level (operation platform or high voltage switcher) to break the high voltage switcher to protect inverter.
15	State of running channel	Inverter running

Setting Value	Function	Description
16	State of power unit bypass	Power unit bypass running
17	Signal of buffer relay when powering on	
18~20	No output	

**Note:** ON means that the normal open contact of relay is closed, and the normal close contact of relay is open.

Function Code	Name	Description	Setting Range	Factory Setting
P6.08	HDO ON-OFF output selection	0~24	0~24	0
P6.09	AO1 output selection	0~24	0~24	0
P6.10	AO2 output selection	0~24	0~24	0
P6.11	AO3 output selection	0~24	0~24	0
P6.12	AO4 output selection	0~24	0~24	0

Analog output terminal AO1 and AO2 provide 0~10V voltage output, while Analog output terminal AO3 and AO4 can provide both 0~10V voltage and 0~20mA current signal, it is selectable by the jumper J3 (AO3) and J4 (AO4) on the I/O board.

The Range of HDO Open Collector High-speed pulse output is 0~50.000 kHz.

AO/HDO output functions are indicated in the following table:

Setting Value	Function	Range
0	Running frequency	100% : maximum frequency
1	Reference frequency	100% : maximum frequency
2	Inverter output current RMS	100% : 2* inverter rated current
3	Motor current RMS	100% : 2* motor rated current
4	Output voltage	100% : 2* inverter rated voltage
5	Output power	100% : 2* rated power
6	Output torque	100% : 2* rated torque
7	AI1 voltage	100% : 10V
8	AI2 voltage	100% : 10V
9	AI3 voltage	100% : 10V
10	Input line voltage of RS	100% : 1.5* rated voltage peak value
11	Input line voltage of ST	100% : 1.5* rated voltage peak value
12	Input line voltage of TR	100% : 1.5* rated voltage peak value
13	Output line voltage of AB	100% : 1.5* rated voltage peak value
14	Output line voltage of BC	100% : 1.5* rated voltage peak value
15	Output line voltage of CA	100% : 1.5* rated voltage peak value
16	Input current of R phase	100% : 1.5* rated Current peak value
17	Input current of S phase	100% : 1.5* rated Current peak value
18	Input current of T phase	100% : 1.5* rated Current peak value

Setting Value	Function	Range
19	Output current of A phase	100% : 1.5* rated Current peak value
20	Output current of B phase	100% : 1.5* rated Current peak value
21	Output current of C phase	100% : 1.5* rated Current peak value
22	A phase modulate waveform	100% : Full voltage
23	B phase modulate waveform	100% : Full voltage
24	C phase modulate waveform	100% : Full voltage

Function Code	Name	Description	Setting Range	Factory Setting
P6.13	HDO lower limit	0.00%~P6.15	0.00~P6.15	0.00%
P6.14	HDO lower limit corresponding output	0~50.000kHz	0~50.000	0.000kHz
P6.15	HDO upper limit	P6.13~100.0%	P6.13~100.0	100.0%
P6.16	HDO upper limit corresponding output	0~50.000kHz	0~50.000	50.000kHz

These parameters determine the relationship between High-speed pulse output frequency and the corresponding output value. When the high speed pulse output value exceeds the range between lower limit and upper limit, it will output the upper limit or lower limit.

For different applications, the corresponding value of 100.0% high speed pulse output is different. For details, please refer to description of each application.




Figure 8.16 Relationship between HDO and corresponding setting.

Function Code	Name	Description	Setting Range	Factory Setting
P6.17	AO1 lower limit	0.0~P6.19	0.0~P6.19	0.00%
P6.18	AO1 lower limit corresponding output	0.00~10.00V	0.00~10.00	0.00V
P6.19	AO1 upper limit	P6.17~100.0	P6.17~100.0	100.0%
P6.20	AO1 upper limit corresponding output	0.00~10.00V	0.00~10.00	10.00V
P6.21	AO2 lower limit	0.00~P6.23	0.00~P6.23	0.00%
P6.22	AO2 lower limit corresponding output	0.00~10.00V	0.00~10.00	0.00V
P6.23	AO2 upper limit	P6.21~100.0	P6.21~100.0	100.0%
P6.24	AO2 upper limit corresponding	0.00~10.00V	0.00~10.00	10.00V

Function Code	Name	Description	Setting Range	Factory Setting
	output			
P6.25	AO3 lower limit	0.0~P6.27	0.00~P6.27	0.00%
P6.26	AO3 lower limit corresponding output	0.00~10.00V	0.00~10.00	0.00V
P6.27	AO3 upper limit	P6.25~100.0	P6.25~100.0	100.0%
P6.28	AO3 upper limit corresponding output	0.00~10.00V	0.00~10.00	10.00V
P6.29	AO4 lower limit	0.00~P6.31	0.00~P6.31	0.00%
P6.30	AO4 lower limit corresponding output	0.00~10.00V	0.00~10.00	0.00V
P6.31	AO4 upper limit	P6.29~100.0	P6.29~100.0	100.0%
P6.32	AO4 upper limit corresponding output	0.00~10.00V	0.00~10.00	10.00V

The function is similar to HDO terminals.

**Note:** When AO is current output, 1mA is corresponding to 0.5V. For details, please refer to description of each application.




Figure 8.17 Relationship between AO and corresponding setting.

### P7 Group – Human-Machine interface

Function Code	Name	Description	Setting Range	Factory Setting
P7.00	User password	0~65535	0~65535	0

The password protection function will be valid when set to be any nonzero data.

When P7.00 is set to be 00000, the user's password set before will be cleared and the password protection function will be disabled.

After the password has been set and becomes valid, the user can not access menu if the user's password is not correct. Only when a correct user's password is input, the user can see and modify the parameters. Please keep user's password in mind.

Function Code	Name	Description	Setting Range	Factory Setting
P7.01	LCD language selection	0:Chinese 1:English	0~1	0

The function is only valid for LCD keypad, which is used to select the language type of LCD keypad.



Function Code	Name	Description	Setting Range	Factory Setting
P7.02	Parameter copy	0: Invalid 1: Upload parameters to LCD 2: Download parameters from LCD	0~2	0

The function code of the function chose the way to copy parameters. Parameter copy function embedded in the LCD keypad.

**Note: When upload or download operation completes, the parameter will restore to 0 automatically.**

Function Code	Name	Description	Setting Range	Factory Setting
P7.03	<b>QUICK/JOG</b> function selection	0: Jog running 1: FDW/REV switching 2: Search the parameters which value is different from factory settings.	0~2	0

**QUICK/JOG** is a multifunctional key, whose function can be defined by setting parameters.

0: Jog: Press **QUICK/JOG**, the inverter will jog.

1: FWD/REV switching: Press **QUICK/JOG**, the running direction of inverter will reverse.

Note: It is only valid when by the keyboard command channel.

2: Search the parameters which value is different from factory settings. Please press this key; the inverter will automatically search the different parameters.

Function Code	Name	Description	Setting Range	Factory Setting
P7.04	<b>STOP/RST</b> function selection	0: Valid when keypad control 1: Valid when keypad or terminal control 2: Valid when keypad or	0~3	0

Function Code	Name	Description	Setting Range	Factory Setting
		communication control 3: Always valid		

**Note:**

1. The value of P7.04 only determines the STOP function of **STOP/RST**.
2. The fault reset function of **STOP/RST** is always valid.

Function Code	Name	Description	Setting Range	Factory Setting
P7.05	Time setting	00.00~23.59	00.00~23.59	Real time

The function code is used to set the current clock.

Function Code	Name	Description	Setting Range	Factory Setting
P7.06	Running state display selection 1	0~0xFFFF	0~0xFFFF	0FFF
P7.07	Running state display selection 2	0~0xFFFF	0~0xFFFF	0000

There are 26 state parameters of CHH inverter display on two function codes of P7.06 and P7.07, 16 general states displayed in P7.06 and the others are display on P7.07. For details, please refer to the function table as below.

Function Code for each one bit need to display state information. If Bit is 0, the parameter will not be displayed; If Bit is 1. The parameter will be displayed.

Press **» /SHIFT** to scroll through these parameters in right order.

When you set function code P7.06 and P7.07, first of all need to display state information according to set up every code of the functions, and then set the values of the two functional code from the binary number converted to hex system for a few. Finally input to the corresponding function code.

The corresponding state information of P7.06's each bit is described in the following table:

BIT15	BIT14	BIT13	BIT12	BIT11	BIT10	BIT9	BIT8
AI3	AI2	AI1 value	Output terminal state	Input terminal state	PID feed back	PID preset	Output torque
BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0
Output power	line speed	Rotation speed	Output current	Output voltage	Input voltage	Frequency setting	Running frequency

The corresponding state information of P7.07's each bit is described in the following table (10 low bits of P7.07 are available and high 6 bit are reserved.)

BIT15	BIT14	BIT13	BIT12	BIT11	BIT10	BIT9	BIT8
Reserved	Reserved	Reserved	Reserved	Reserved	Reserved	Inverter output terminals state	Inverter input terminals state
BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0
Time	Running time	Current percentage of inverter rated current	Current percentage of motor rated current	Input current	Input power factor	Current steps of Multi-step	HDI frequency

**Note: The input/output terminal state of bit 11 and bit 12 in P7.06, bit 8 and bit 9 in P7.07 are displayed by decimal numbers, which convert to hex numbers with each bit represent the terminal ON/OFF state.**

For example: input terminal display 10, which means S2 and S4 are switched on, the others are switched off, for details, please refer to P8.08 and P8.09.

Function Code	Name	Description	Setting Range	Factory Setting
P7.08	Stop state display selection	0~0xFFFF	0~0xFFFF	0x0FFF

P7.08 determines the display parameters in stop state. The setting method is

similar with P7.06 and P7.07.

The display content corresponding to each bit of P7.07 is described in the following table:

BIT15	BIT14	BIT13	BIT12	BIT11	BIT10	BIT9	BIT8
Reserved	Reserved	Inverter output terminals state	Inverter input terminals state	RTC time	Current steps of multi-steps	HDI frequency	AI3
BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0
AI2	AI1	PID feedback	PID preset	Output terminal state	Input terminal state	Input voltage	Frequency setting

Function Code	Name	Description	Setting Range	Factory Setting
P7.09	Display coefficient of rotational speed	0.1~999.9%	0.1~999.9	100.0%

Mechanical speed=120×running frequency×P7.09/ Motor poles, it is used for regulating rotation speed display, have no effect to actual speed.

Function Code	Name	Description	Setting Range	Factory Setting
P7.10	Display coefficient of linear speed	0.1~999.9%	0.1~999.9	1.0%

Linear speed=mechanical speed×P7.10, it is used for regulating line speed display error, have no effect to actual speed.

Function Code	Name	Description	Setting Range	Factory Setting
P7.11	DSP	Manufacturers Version		

Function Code	Name	Description	Setting Range	Factory Setting
	software version	Control		
P7.12	Accumulated running time	0~65535h	0~65535	

DSP Software version: Indicates current software version of DSP

Accumulated running time: Displays accumulated running time of inverter.

## P8 Group - Fault record

CHH series inverter can record recent three fault times and the running frequency, output current, bus voltage information of last fault. Fault type and environmental Information is impermissible to modify, user can clean to be 0 of the fault information by P0.16.

Function Code	Name	Description	Setting Range	Factory Setting
P8.00	Last second fault type			
P8.01	Last time fault type			
P8.02	Type of current fault			

0: No Fault

There are two system fault and unit fault because of its structure.

Please refer to inverter fault code principle.

EXX.YY, If XX=00, means system fault, If XX≠0, means unit fault and YY is fault code.

For more details, Please refer to chapter 9.

Function Code	Name	Description	Setting Range	Factory Setting
P8.03	Running			0.00Hz

Function Code	Name	Description	Setting Range	Factory Setting
	frequency of current fault			
P8.04	Output current of current fault			0.0A
P8.05	DC bus voltage of current fault			0.0V
P8.06	DC bus voltage of current fault unit			0
P8.07	Unit temperature of current fault			0.0
P8.08	Input terminal state of current fault	The following table format		0
P8.09	Output terminal state of current fault	The following table format		0
P8.10	Time of current fault			00.00

The state of current fault input terminals is a decimal number.

For all of digital input terminals state order during last fault, please refer to table as below.

BIT15	BIT14	BIT13	BIT12	BIT11	BIT10	BIT9	BIT8
S16	S15	S14	S13	S12	S11	S10	S9
BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0
S8	S7	S6	S5	S4	S3	S2	S1

ON: 1, OFF: 0, it shows the state of digital input signal during fault.

The state of current fault output terminals is a decimal number.

For all of digital output terminals state order during last fault, Please refer to table as below.

BIT15	BIT14	BIT13	BIT12	BIT11	BIT10	BIT9	BIT8
Reser ved	Reserv ed	Reser ved	Reserv ed	Reser ved	Reserv ed	Reser ved	Reserv ed
BIT7	BIT6	BIT5	BIT4	BIT3	BIT2	BIT1	BIT0
RO8	RO7	RO6	RO5	RO4	RO3	RO2	RO1

ON: 1, OFF: 0, it shows the state of digital output signal during fault.

P8.06 and P8.07 is used to record fault unit state during fault.

## P9 Group - PID Control

PID control is a common used method in process control, such as flow, pressure and temperature control. The principle is firstly detect the bias between preset value and feedback value, then calculate output frequency of inverter according to proportional gain, integral and differential time. Please refer to following figure.




Figure 8.18 PID control diagram

Function Code	Name	Description	Setting Range	Factory Setting
P9.00	PID preset source	0: Keypad 1: AI1	0~9	0

Function Code	Name	Description	Setting Range	Factory Setting
	selection	2: AI2 3: AI3 4: AI1+AI2 5: AI2+AI3 6: AI1+AI3 7: HDI 8: Multi-step 9: Communication		

These parameters are used to select PID preset and feedback source.

**Note:**

1. When the frequency set PID, that is the value of P0.03 is 6, the group function decides the target volume channels of this PID parameter.
2. Goal value of the process PID given is relative value, 100% of preset value is corresponding to 100% of feedback value.
3. System operate in relative value (0 ~ 100%), in the default condition. The values of PID and feedback are based on 100% corresponds to 10V.
4. Preset source and feedback source must not be same, otherwise PID will be malfunction.

Function Code	Name	Description	Setting Range	Factory Setting
P9.01	Keypad PID preset	0.0~100.0%	0.0~100.0	0.0%

P9.00 = 0, that is the target sources is the keyboard. Need to set this parameter. The value of this parameter is the system feedback value.

Function Code	Name	Description	Setting Range	Factory Setting
P9.02	PID feedback source selection	0: AI1 1: AI2 2: AI3 3: AI1+AI2 4: AI2+AI3	0~7	0



Function Code	Name	Description	Setting Range	Factory Setting
		5: AI1+AI3 6: HDI 7: Communication		

Please select the PID feedback channel through this parameter.

**Note: Preset channel and feedback channel shouldn't be the same; otherwise, PID can not be effectively controlled.**

Function Code	Name	Description	Setting Range	Factory Setting
P9.03	PID output character selection	0: Positive 1: Negative	0~1	0

0: Positive. When the feedback value is greater than the preset value, output frequency will be decreased to get the actual value reach the preset value.

1: Negative. When the feedback value is greater than the preset value, output frequency will be increased to get the actual value reach the preset value.

Function Code	Name	Description	Setting Range	Factory Setting
P9.04	Proportional gain (Kp)	0.00~100.00	0.00~100.00	0.10
P9.05	Integral time (Ti)	0.01~10.00s	0.01~10.00	0.10s
P9.06	Differential time (Td)	0.00~10.00s	0.00~10.00	0.00s

Optimize the responsiveness by adjusting these parameters while driving an actual load.

#### **Adjusting PID control:**

Use the following procedure to activate PID control and then adjust it while monitoring the response.

1. Enabled PID control (P0.03=6)
2. Increase the proportional gain (Kp) as far as possible without creating oscillation.

1. Reduce the integral time ( $T_i$ ) as far as possible without creating oscillation.
2. Increase the differential time ( $T_d$ ) as far as possible without creating oscillation.

Making fine adjustments:

First set the individual PID control constants, and then make fine adjustments.

- Reducing overshooting

If overshooting occurs, shorten the differential time and lengthen the integral time.




Figure 8.19 Reducing overshooting diagram.

- Rapidly stabilizing control state

To rapidly stabilize the control conditions even when overshooting occurs, shorten the integral time and lengthen the differential time.




Figure 8.20 Rapidly stabilizing diagram

- Reducing long-cycle oscillation

If oscillation occurs with a longer cycle than the integral time setting, it means that integral operation is strong. The oscillation will be reduced as the integral time is lengthened.




Figure 8.21 Reducing long-cycle oscillation diagram

- Reducing short-cycle oscillation

If the oscillation cycle is short and oscillation occurs with a cycle approximately the same as the differential time setting, it means that the differential operation is strong. The oscillation will be reduced as the differential time is shortened.




Figure 8.22 Reducing short-cycle oscillation diagram.

If oscillation cannot be reduced even by setting the differential time to 0, then either lower the proportional gain or raise the PID primary delay time constant.

Function Code	Name	Description	Setting Range	Factory Setting
P9.07	Sampling cycle (T)	0.01~100.00s	0.01~100.00	0.10s
P9.08	Bias limit	0.0~100.0%	0.0~100.0	0.0%

Sampling cycle T: refers to the sampling cycle of feedback value. The PI regulator calculates once in each sampling cycle. The bigger the sampling cycle, the slower the response is.

Bias limit defines the maximum bias between the feedback and the preset. PID stops operation when the bias is within this range. Setting this parameter correctly is helpful to improve the system output accuracy and stability.




Figure 8.23 Relationship between bias limit and output frequency.

Function Code	Name	Description	Setting Range	Factory Setting
P9.09	Feedback lost detecting value	0.0~100.0%	0.0~100.0	0.0%
P9.10	Feedback lost detecting time	0.0~3600.0s	0.0~3600.0	1.0s

When feedback value is less than feedback lost detecting value continuously for the period determined by feedback lost detecting time, the inverter will alarm feedback lost failure (E00.17).

**Note:** 100% of Feedback lost detecting value is the same as 100% of Keypad PID preset.

Function Code	Name	Description	Setting Range	Factory Setting
P9.11	PID dormancy wake up	0.0~100.0%	0.0~100.0	0.0%

Function Code	Name	Description	Setting Range	Factory Setting
	value			
P9.12	PID dormancy delay time	0.0~3600.0s	0.0~3600.0	1.0s

PID dormancy wake up value: IF PID feed back $\neq$  dormancy value, PID will be wake up, then inverter frequency increase from 0 until PID feedback reach PID preset again.

PID dormancy delay time: If not 0. PID dormancy valid, PID feedback reach PID preset and work steadily, Inverter will work in current state for PID dormancy delay time, and then reduce frequency to 0 according to preset entering dormancy state until PID dormancy wake up.




Figure 8.2:

Frequency increase after inverter start, PID feedback increase too. When the feed back reach preset value, inverter maintain current state and PID walk into dormancy delay time P9.12 (Constant output frequency, keep PID within bias limit), inverter frequency reduce to 0 in the decrease time, because of system inertia, PID feedback reduce slowly. When feedback value reach to the wake up value (P9.11), inverter wake up from dormancy state, then frequency increase, PID feedback increase too.

### PA Group - Multi-step speed control

Function Code	Name	Description	Setting Range	Factory Setting
PA.00	Multi-step	-100.0~100.0%	-100.0~100.0	0.0%

Function Code	Name	Description	Setting Range	Factory Setting
	speed 0			
PA.01	Multi-step speed 1	-100.0~100.0%	-100.0~100.0	0.0%
PA.02	Multi-step speed 2	-100.0~100.0%	-100.0~100.0	0.0%
PA.03	Multi-step speed 3	-100.0~100.0%	-100.0~100.0	0.0%
PA.04	Multi-step speed 4	-100.0~100.0%	-100.0~100.0	0.0%
PA.05	Multi-step speed 5	-100.0~100.0%	-100.0~100.0	0.0%
PA.06	Multi-step speed 6	-100.0~100.0%	-100.0~100.0	0.0%
PA.07	Multi-step speed 7	-100.0~100.0%	-100.0~100.0	0.0%
PA.08	Multi-step speed 8	-100.0~100.0%	-100.0~100.0	0.0%
PA.09	Multi-step speed 9	-100.0~100.0%	-100.0~100.0	0.0%
PA.10	Multi-step speed 10	-100.0~100.0%	-100.0~100.0	0.0%
PA.11	Multi-step speed 11	-100.0~100.0%	-100.0~100.0	0.0%
PA.12	Multi-step speed 12	-100.0~100.0%	-100.0~100.0	0.0%
PA.13	Multi-step speed 13	-100.0~100.0%	-100.0~100.0	0.0%
PA.14	Multi-step speed 14	-100.0~100.0%	-100.0~100.0	0.0%
PA.15	Multi-step speed 15	-100.0~100.0%	-100.0~100.0	0.0%

**Note:**

1. 100% of multi-step speed is corresponding to the maximum frequency (P0.07).
2. When you select a multi-segment speed, require to set PA.00 ~ PA.15 to determine the frequency and the direction of their operation. Multi-stage speed determines the sign of the direction of multi-stage speed. Negative number means the reverse run. Multi-stage speed range can be set straight within - fmax ~ fmax.
3. CHH series inverter can be set to 16 speed by a designated number of input terminals combined coding options, corresponding to multi-stage speed 0 to multi-stage speed 15.




Figure 8.25 Multi-steps speed operation diagram

Set S1~S4 as multi-steps input terminals, S1=S2=S3=S4=OFF, Frequency source is determined by P0.03~P0.06. If not all of S1, S2, S3, S4 are OFF, the inverter work at Multi-steps mode, it is more priority than Keypad, analog input, high speed pulse input, communication. 16 steps are combinatorial by S1, S2, S3, S4 code.

Multi-steps speed start-stop is determined by the function code P0.01, multi-steps speed control process as shown above. The relationship between multi-steps terminal S1, S2, S3, S4 and multi-steps speed is displayed in the following table.

S1	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON
S2	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF	ON	ON
S3	OFF	OFF	OFF	OFF	ON	ON	ON	ON	OFF	OFF	OFF	OFF	ON	ON	ON	ON
S4	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON	ON	ON	ON	ON	ON	ON
Step	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

**Pb Group - Protection parameter**

Function Code	Name	Description	Setting Range	Factory Setting
Pb.00	Reserved	Reserved	Reserved	
Pb.01	Output phase-failure protection	0: Disabled 1: Enabled	0~1	1

Output phase-failure protection is to select whether the output phase-failure protection is effective.

Function Code	Name	Description	Setting Range	Factory Setting
Pb.02	Motor overload protection	0: Disabled 1: Normal motor(With the low-speed compensation) 2: Variable frequency motor(Without the low-speed compensation)	0~2	2

0: No protection: The inverter haven't motor overload protection feature (caution). The inverter hasn't overload protection.

1: For normal motor, the lower the speed, the poorer the cooling effect will be. Based on this reason, if output frequency is lower than 30Hz, inverter will reduce the motor overload protection threshold to prevent normal motor from overheat.

2: As the cooling effect of variable frequency motor has nothing to do with running speed, it is not required to adjust the motor overload protection threshold.

Function Code	Name	Description	Setting Range	Factory Setting
Pb.03	Motor overload protection current	20.0~120.0%(Motor rated current)	20.0~120.0	100.0%






Figure 8.26 Diagram of motor overload protection

The value can be determined by the following formula:

Motor overload protection current = (Allowable maximum load current of motor / inverter rated current)  $\times$  100%

This parameter is normally used when rated power of inverter is greater than rated power of motor.

Function Code	Name	Description	Setting Range	Factory Setting
Pb.04	Frequency drop threshold of Instantaneous power-down	70.0~110.0%(Standard bus voltage)	70.0~110.0	80.0%
Pb.05	Decrease rate of frequency drop	0.00~P0.07(Maximum frequency)	0.00~P0.07	0.00Hz

If Pb.05 is set to be 0, the frequency drop of Instantaneous power-down function is invalid.

The frequency drop of Instantaneous power-down function enables the inverter to perform low-voltage compensation when DC bus voltage drops below Pb.04. The inverter can continue to run without tripping by reducing its output frequency and feedback energy from motor.

**Note:** Setting these two parameters according to load inertia and the actual load, can cause the inverter to continue to run during switch the power grid.

Function Code	Name	Description	Setting Range	Factory Setting
Pb.06	Over-voltage stall protection	0: Disabled 1: Enabled	0~1	0
Pb.07	Over-voltage stall protection point	105~140%	105~140	120%

During deceleration, the motor's decelerating rate may be lower than that of inverter's output frequency due to the load inertia. At this time, the motor will feed the energy back to the inverter, resulting in DC bus voltage rise. If no measures taken, the inverter will trip due to over voltage.

During deceleration, the inverter detects DC bus voltage and compares it with over-voltage stall protection point. If DC bus voltage exceeds Pb.07, the inverter will stop reducing its output frequency. When DC bus voltage become lower than Pb.10, the deceleration continues, as shown in following figure.




Figure 8.27 Over-voltage stall function

Function Code	Name	Description	Setting Range	Factory Setting
Pb.08	Automatic current-limiting level	50~200%	50~200	120%
Pb.09	Limiting rate of	0.00~10.00Hz(0.00:	0.00~10.00	10.00

Function Code	Name	Description	Setting Range	Factory Setting
	frequency drop	invalid)		

During acceleration of inverter, the actual motor speed rise rate may lower than the output frequency rise rate because of too big load. If no measures to take, inverter will trip caused by over-current.

During running, by detecting the output current, and comparing with the automatically limit value ( $Pb.08 * \text{inverter rated current}$ ), if more than the automatically limit value, the function of automatic current-limiting is valid.

Please refer to the following diagram:




Figure 8.28 Over-current stall function

Function Code	Name	Description	Setting Range	Factory Setting
Pb.10	Input over voltage pre-warning threshold	105~125%	105~125	110%

Pb.10 is to set the input voltage pre-warning threshold, when actual input voltage exceed the point, inverter will warn, the setting value is corresponding to percentage of input rated voltage.

Function Code	Name	Description	Setting Range	Factory Setting
Pb.11	Unit bypass function	0: Manual bypass 1: Auto bypass	0~1	0
Pb.12	Unit manual bypass bit selection	0x000~0x1FF	000~1FF	Depend on Inverter voltage

Pb.11 is used to set inverter bypass function.

0: manual bypass: If unit appear failure, inverter will stop and indicate error. If user want to bypass failure unit, it's necessary to set Pb.12 to bypass the failure unit after stopping.

1: Auto bypass: If unit appear failure, inverter will not stop and bypass failure unit automatically. Pb.12 is invalid.

CHH series high voltage inverter support maximum 9 units in series, each bit of Pb.12 corresponding to unit number in series. Pb.12 is indicated as hexadecimal system, each bit corresponding to one unit. If bit=1, No bypass, If bit=0, means bypass the unit.

Function Code	Name	Description	Setting Range	Factory Setting
Pb.13	Hardware over current threshold	50~200%	50~200	150%

Pb.13 is used to set the system's hardware over-current point. When the system output current exceeds the hardware over-current point, the system will report over-current fault.

Function Code	Name	Description	Setting Range	Factory Setting
Pb.14	Power frequency bypass	0: Manual power frequency bypass 1: Auto power frequency	0~1	0

Function Code	Name	Description	Setting Range	Factory Setting
	when failure	bypass		

The inverter switches to power frequency when failure.

0: Manual bypass: Inverter failure, system choose coast to stop or cut off high voltage input when coast to stop according to seriousness.

1: Auto bypass: Coast to stop and switch to power frequency when inverter error.

Function Code	Name	Description	Setting Range	Factory Setting
Pb.15	Low-frequency restraining oscillation factor	0~100	0~100	10
Pb.16	High-frequency restraining oscillation factor	0~100	0~100	0
Pb.17	Boundary of restraining oscillation	0.00~120.00Hz	0.00~120.00	20.00Hz

In different condition, need to adjust the restraining oscillation factor (through high-frequency Pb.16, low-frequency vibration Pb.15 inhibitory factor). That is an increase of restraining oscillation factor may increase the value of the motor vibration suppression of intensity.

Boundary of restraining oscillation specified the frequency range of low-frequency restraining oscillation factor and high-frequency restraining oscillation factor. When the operating frequency is less than Pb.17, use Pb.15 for restraining the oscillation; when the operating frequency is higher than Pb.17, use Pb.16 for restraining the oscillation.

**Note: The low-frequency, high-frequency restraining oscillation factor is not as high as possible, when the motor does not set matching, will**

**increase the motor current shock.**

## PC Group - Serial communication

CHH series high voltage variable frequency speed control system supports standard modbus communication protocol. In the communication network, the inverter can only exist as a slave node. This Group of function Code is used to set the communication. For more information on Modbus communication protocol refer to appendix.

Function Code	Name	Description	Setting Range	Factory Setting
PC.00	Local address	1~247,( 0: the broadcast address)	1~247	1

This parameter determines the slave address used for communication with master. In the same Modbus network, the address can not be repeated.

Function Code	Name	Description	Setting Range	Factory Setting
PC.01	Baud rate selection	0: 1200BPS 1: 2400BPS 2: 4800BPS 3: 9600BPS 4: 19200BPS 5: 38400BPS	0~5	4

This parameter can set the data transmission rate during serial communication.

**Note: The baud rate of master and slave must be the same. (Note: BPS stands for the bit per second, how many bits per second).**

Function Code	Name	Description	Setting Range	Factory Setting
PC.02	Data parity	0~5	0~5	1

Setting communication format: Communication (RTU) parity mode: odd parity (O), even parity (E), no parity (N), end of the bit number (1bit, 2bit), the bit number of bytes (7bit, 8bit).

The relationship between the value of function and the corresponding data

parity code refer to following table:

	0	1	2	3	4	5
RTU(8)	(N, 1)	(E, 1)	(O, 1)	(N, 2)	(E, 2)	(O, 2)

Function Code	Name	Description	Setting Range	Factory Setting
PC.03	Communication delay time	0~200ms	0~200	5

This parameter refers to the interval between receiving end signal and sending response data to upward-bit machine. If the response delay is less than the system processing time, the response time based on the system processing time. If the response delay is longer than the system processing time, the system processing time should wait until the delay time. Then send data.

Function Code	Name	Description	Setting Range	Factory Setting
PC.04	Communication timeout delay	0.1~100s (0.0: invalid)	0.0~100	0.0s

When the value is zero, this function will be invalid. When communication interruption is longer than the non-zero value of PC.04, the inverter will alarm communication error (E00.13).

Setting this parameter, you can monitor the communications state during communicating.

Function Code	Name	Description	Setting Range	Factory Setting
PC.05	Communication error action	0: Alarm and coast to stop 1: No alarm and continue to run 2: No alarm but stop according to P1.06 (if P0.03=2) 3: No alarm but stop according to P1.06 (All	0~3	1

### Detailed functional description

Function Code	Name	Description	Setting Range	Factory Setting
		control mode)		

This function code is used to select action mode when communication error occurs to the inverter.

Function Code	Name	Description	Setting Range	Factory Setting
PC.06	Response action	Unit's place of LED 0: Response to writing 1: No response to writing Ten's place of LED 0: Reference not saved when power off 1: Reference saved when power off Hundred's place of LED 0: Virtual terminal function Invalid 1: Virtual terminal function Invalid	0x000~0x111	000

**Note:** This function LED' unit, 10, 100 is in the range of 0 ~ 1.

Function Code	Name	Description	Setting Range	Factory Setting
PC.07	Reserved			

### Pd Group - Unit state query

CHH series inverter can query power unit temperature, DC bus voltage, warning etc, it's more accurate to know the state of power unit.

Function Code	Name	Description	Setting Range	Factory Setting
Pd.00	A-Phase unit	0x000~0x1FF	000~1FF	Depend on voltage



Function Code	Name	Description	Setting Range	Factory Setting
	indication			
Pd.01	B-phase unit indication	0x000~0x1FF	000~1FF	Depend on voltage
Pd.02	C-phase unit indication	0x000~0x1FF	000~1FF	Depend on voltage

The error of power unit can be neglected of each phase (A, B, C). It is indicated in Pd.00~Pd.02.

CHH series high voltage inverter support maximum 9 power units in series, the function of low 9 bits relative to each phase power unit, the function is defined with hexadecimal system

If the bit =1, the corresponding power unit error is not neglected, If the bit=0, means power unit error is neglected.

**Note: The function is only used to neglect warning during power unit error, the power unit error fault information can be queried by fault inquiry function.**

Function Code	Name	Description	Setting Range	Factory Setting
Pd.03	Unit A1 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.04	Unit A2 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.05	Unit A3 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.06	Unit A4 temperature indication	0.0~100.0℃	0.0~100.0℃	

Detailed functional description

Function Code	Name	Description	Setting Range	Factory Setting
Pd.07	Unit A5 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.08	Unit A6 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.09	Unit A7 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.10	Unit A8 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.11	Unit A9 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.12	Unit B1 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.13	Unit B2 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.14	Unit B3 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.15	Unit B4 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.16	Unit B5 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.17	Unit B6	0.0~100.0℃	0.0~100.0℃	

Function Code	Name	Description	Setting Range	Factory Setting
	temperature indication			
Pd.18	Unit B7 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.19	Unit B8 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.20	Unit B9 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.21	Unit C1 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.22	Unit C2 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.23	Unit C3 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.24	Unit C4 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.25	Unit C5 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.26	Unit C6 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.27	Unit C7 temperature	0.0~100.0℃	0.0~100.0℃	

Function Code	Name	Description	Setting Range	Factory Setting
	indication			
Pd.28	Unit C8 temperature indication	0.0~100.0℃	0.0~100.0℃	
Pd.29	Unit C9 temperature indication	0.0~100.0℃	0.0~100.0℃	

**Note:** All of the function codes are used to display the temperature of A1~A9, B1~B9 and C1~C9. They are read-only.

Function Code	Name	Description	Setting Range	Factory Setting
Pd.30	Unit A1 DC bus voltage indication	0~2000V	0~2000	
Pd.31	Unit A2 DC bus voltage indication	0~2000V	0~2000	
Pd.32	Unit A3 DC bus voltage indication	0~2000V	0~2000	
Pd.33	Unit A4 DC bus voltage indication	0~2000V	0~2000	
Pd.34	Unit A5 DC bus voltage indication	0~2000V	0~2000	

Function Code	Name	Description	Setting Range	Factory Setting
Pd.35	Unit A6 DC bus voltage indication	0~2000V	0~2000	
Pd.36	Unit A7 DC bus voltage indication	0~2000V	0~2000	
Pd.37	Unit A8 DC bus voltage indication	0~2000V	0~2000	
Pd.38	Unit A9 DC bus voltage indication	0~2000V	0~2000	
Pd.39	Unit B1 DC bus voltage indication	0~2000V	0~2000	
Pd.40	Unit B2 DC bus voltage indication	0~2000V	0~2000	
Pd.41	Unit B3 DC bus voltage indication	0~2000V	0~2000	
Pd.42	Unit B4 DC bus voltage indication	0~2000V	0~2000	

Function Code	Name	Description	Setting Range	Factory Setting
	indication			
Pd.43	Unit B5 DC bus voltage indication	0~2000V	0~2000	
Pd.44	Unit B6 DC bus voltage indication	0~2000V	0~2000	
Pd.45	Unit B7 DC bus voltage indication	0~2000V	0~2000	
Pd.46	Unit B8 DC bus voltage indication	0~2000V	0~2000	
Pd.47	Unit B9 DC bus voltage indication	0~2000V	0~2000	
Pd.48	Unit C1 DC bus voltage indication	0~2000V	0~2000	
Pd.49	Unit C2 DC bus voltage indication	0~2000V	0~2000	
Pd.50	Unit C3 DC bus	0~2000V	0~2000	

Function Code	Name	Description	Setting Range	Factory Setting
	voltage indication			
Pd.51	Unit C4 DC bus voltage indication	0~2000V	0~2000	
Pd.52	Unit C5 DC bus voltage indication	0~2000V	0~2000	
Pd.53	Unit C6 DC bus voltage indication	0~2000V	0~2000	
Pd.54	Unit C7 DC bus voltage indication	0~2000V	0~2000	
Pd.55	Unit C8 DC bus voltage indication	0~2000V	0~2000	
Pd.56	Unit C9 DC bus voltage indication	0~2000V	0~2000	

**Note:** All of the function codes are used to display the bus voltage of A1~A9, B1~B9, C1~C9. They are read-only.

Function Code	Name	Description	Setting Range	Factory Setting
Pd.57	Unit A1	0~0xFFFF	0000~FFFF	

Function Code	Name	Description	Setting Range	Factory Setting
	fault indicated value			
Pd.58	Unit A2 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.59	Unit A3 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.60	Unit A4 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.61	Unit A5 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.62	Unit A6 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.63	Unit A7 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.64	Unit A8 fault indicated value	0~0xFFFF	0000~FFFF	



Function Code	Name	Description	Setting Range	Factory Setting
Pd.65	Unit A9 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.66	Unit B1 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.67	Unit B2 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.68	Unit B3 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.69	Unit B4 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.70	Unit B5 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.71	Unit B6 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.72	Unit B7 fault indicated	0~0xFFFF	0000~FFFF	

Function Code	Name	Description	Setting Range	Factory Setting
	value			
Pd.73	Unit B8 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.74	Unit B9 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.75	Unit C1 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.76	Unit C2 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.77	Unit C3 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.78	Unit C4 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.79	Unit C5 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.80	Unit C6 fault	0~0xFFFF	0000~FFFF	

Function Code	Name	Description	Setting Range	Factory Setting
	indicated value			
Pd.81	Unit C7 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.82	Unit C8 fault indicated value	0~0xFFFF	0000~FFFF	
Pd.83	Unit C9 fault indicated value	0~0xFFFF	0000~FFFF	

**Note:** All of the function codes are used to display the fault of A1 ~ A9, B1 ~ B9 and C1 ~ C9. They are read-only.

### PE Group - Factory Setting

This group is the factory setting parameter group. It is prohibited for user to access.

## Warning information and fault solution 9

CHH series high voltage inverter have perfect protection and alarm functions, when fault occurs to the inverter, the inverter indicates fault state and implement stopping protection, power unit bypass, acousto-optic alarm, cut off high voltage input automatically according to alarm level. Having instructions on fault alarm and the general methodology in the touch-screen, the user may be quick to judge fault and make appropriate policy response by the guidance of alarm interface.

CHH series high voltage inverter have two kinds fault, 1: unit fault 2: system fault, express as EX1X2.Y1Y2. X1X2 means system fault or unit fault. Y1Y2 is fault code.

X1X2=00, means system fault, Y1Y2 is system fault code.

For unit fault, X1 means the phase of fault unit. X2: The unit in the location of fault phase, Y1Y2: first fault code of error unit.

CHH series high voltage inverter provides alarm function. When inverter is in abnormal state but the fault is not serious enough to damage, the inverter cause acousto-optic alarm and not stop during alarm time. Inverter can auto reset or manual reset when alarm. There are two type alarm of CHH series high voltage inverter, Unit alarm and system alarm, it is express as AX1X2.Y1Y2,

X1X2: Alarm unit

Y1Y2: Alarm code

X1X2=00, System fault

Y1Y2: System fault code

For unit fault, X1 means fault phase, X2 means The unit in the location of fault phase, Y1Y2: first fault code of error unit.

Fault is divided into three kinds:

Serious fault: The fault causes alarm, shut down and cut off the high voltage power supply. For example: system fault in the motor overload (E00.08), inverter system overload (E00.09), the output phase lack (E00.10), phase-shifting transformer overheating (E00.11), EEPROM Operation Failure (E00. 16), the clock failure (E00.18), power over-voltage fault (E00.21) and all

the units fault.

Light fault: The fault causes alarm, shut down but will not cut off the high voltage power supply. Refer to system failures other than serious fault.

Warning: Only alarm but non-stop machine. It refers to system-level and unit-level warning alarm.

## 9.1 System Fault

Fault Code	Fault Type	Reason	Solution
E00.01	Over-current when acceleration	1. Acc time is too short. 2. The voltage of grid is too low.	1.Increase Acc time 2.Check input power supply 3.Select bigger power range inverter
E00.02	Over-current when deceleration	1.Dec time is too short 2.Load inertia torque is too large 3.Inverter rated power is too small	1. Increase Dec time 2.Select bigger power range inverter
E00.03	Over-current when constant speed running	1.Load sudden change or abnormal 2.Voltage of Grid is too low 3.Inverter rated power is too small	1.Check load or reduce load sudden change 2.Check input power supply 3.Select bigger power range inverter
E00.04	Over-voltage when acceleration	1.Input voltage abnormal 2.sudden cut off power, rotation motor restart	1.Check input power supply 2.Avoid stop and restart
E00.05	Over-voltage when deceleration	1.Dec time is too short 2.Load inertia torque is too large	1. Increase Dec time 2.Check input power supply

## Warning information and fault solution

Fault Code	Fault Type	Reason	Solution
		3.Input voltage abnormal	
E00.06	Over-voltage when constant speed running	1.Input voltage variation abnormal 2.Load inertia too large	1.Select bigger power range inverter
E00.07	Grid under-voltage	Grid voltage is too low	1.Check the power supply of Grid
E00.08	Motor overload	1. Grid voltage is too low. 2. Motor rated current setting is incorrect 3. Motor blockage or the load with large mutation 4. Inverter rated power is too large	1. Check the power supply of Grid 2. Reset the motor rated current 3. Check the load, regulate the amount of torque 4. Select the appropriate motor
E00.09	Inverter overload	1. Acc time is too short. 2. re-start the rotation motor 3. Grid voltage is too low. 4. Load is too heavy	1. Increase Acc time 2. Avoid stop and restart 3. Check the power supply of Grid 4. Select bigger capacity inverter.
E00.10	Output phase failure	1. U, V, W missing-phase (or three-phase load is severe asymmetry)	1.Check the wiring 2. Check motor and cables
E00.11	Phase-shifting transformer over heating	1.Over load 2.Environment temperature is too high 3.Temperature	1.check external signal cable and shield layer ground right or not

Fault Code	Fault Type	Reason	Solution
		controller fault 4. Transformer cooling fault 5. Interference of protection circuit 6. Control cable shield layer is not grounding correctly	2. Check transformer load and environment temperature compare to rated value. 3. check install condition 4. check control cable shield layer grounding right or not 6. Check temperature controller and other circuit.
E00.12	External fault	SI external fault input terminal take effect.	1. Inspect external equipment. 2. Check the P5 group of input terminal function setting
E00.13	Communication fault	1. Improper baud rate setting. 2. Receive wrong data. 3. Communication is interrupted for Long time	1. Set proper baud rate. 2. Press <b>STOP/RESET</b> to reset Ask for support 3. Check communication devices and signals.
E00.14	Current detection fault	1. Wires or connectors of control board are loose 2. Power supply is damaged	1. Check the wiring. 2. Ask for support. 3. Ask for support. 4. Ask for support.

## Warning information and fault solution

Fault Code	Fault Type	Reason	Solution
		3. Hall sensor is damaged. 4. Amplifying circuit is abnormal.	
E00.15	Motor autotuning fault	Reserved	Reserved
E00.16	EEPROM fault	1. Read/Write fault of control parameters 2. EEPROM damaged	1. Press <b>STOP/RESET</b> to reset. Ask for support 2. Ask for support.
E00.17	PID feedback fault	1. PID feedback is disconnected. 2. PID feedback source disappears.	1. Inspect PID feedback signal wire. 2. Inspect PID feedback source.
E00.18	Clock chip fault	1. Clock chip damaged 2. Low battery	Ask for support.
E00.19	Output grounding fault	1. Output cable or motor have single phase grounding	1. Check external cable and motor grounding or not 2. Use M OHM meter checking the insulation of motor and motor cable
E00.20	Cabinet door switcher fault	1. Cabinet door is not closed completely 2. Cabinet door switcher error 3. Control cable shield is not grounding.	1. Check the cabinet door state, 2. Check the switcher and touch point of cabinet door.
E00.21	Grid overvoltage	Grid voltage is 20%	1. Decrease input



Fault Code	Fault Type	Reason	Solution
		higher than rated voltage	Grid voltage 2. Adjustment of phase-shifting transformer terminal

## 9.2 Unit fault

CHH series high voltage inverter allows the unit reports all of current faults. There are 12 bits, each bit corresponding to one kind of fault; the inverter will report the fault according to EX1X2. Y1Y2 when unit fault without the fault shield, Fault unit X1X2 means the first unit with error. Fault code Y1Y2 is corresponding to the fault bit of first fault unit.

All of fault information can be found with function code Pd.57~Pd.83

Refer to the relationship between fault bit and fault type.

For example, A5 unit upstream communication failure occurred, then the fault code reported is: EA5.01, Pd.61 fault code is: 0x0001.

Fault bit	Fault Name	Reason	Solution
1	Unit optical fiber uplink communication fault	1. Tie-in loose 2. Optical fiber damage 3. Unit fault	1. Re-plug in tie-in 2. Replace optical fiber 3. Ask for service
2	Unit optical fiber downlink communication fault	1. Tie-in loose 2. Optical fiber damage	1. Re-plugin tie-in 2. Replace optical fiber 3. Ask for service
3	Unit is not ready	Control board of unit fault	1. Replace fault unit 2. Ask for service
4	Unit overvoltage	1. Big inertia of load, decrease too fast 2. Current vibration 3. Grid voltage is too	1. Set longer decrease time 2. Reduce input voltage

## Warning information and fault solution

<b>Fault bit</b>	<b>Fault Name</b>	<b>Reason</b>	<b>Solution</b>
		high 4. Unit error	3. Ask for service
5	Unit under-voltage	1. Grid voltage is too low	1. Check grid voltage
6	Unit power supply fault	1. Unit drive board fault 2. Unit power board fault	1. Ask for service
7	Unit overheating	1. Environment temperature is too high 2. Unit cooling channel is not clear 3. Cabinet tightness and cooling condition are not good	1. Reduce environment temperature 2. Ask for service 3. Clear dusty filter
8	Unit input phase lacking	1. Unit input terminals wiring error 2. Phase-shifting transformer fault 3. Unit fuse broken	1. Check and reconnect the input wire 2. Ask for service
9	Unit power fall	1. Unit input terminals wiring error 2. Unit fault	1. Check and reconnect the input wire 2. Ask for service
10	Upper bridge VCE fault	1. Unit output short circuit 2. H bridge direct connection 3. Unit drive error	1. Ask for service
11	Lower bridge VCE fault	1. Unit output short circuit 2. H bridge direct connection 3. Unit drive error	1. Ask for service

Fault bit	Fault Name	Reason	Solution
12	Hardware overvoltage	1. Big load inertia, and the deceleration time is too short 2. Current vibration 3. Grid overvoltage 4. Unit fault	1. Increase the deceleration time 2. Reduce input voltage 3. Ask for service
13	Unit do not match	The power unit is incorrect	1. Ask for service
14	Bypass unit failure	1. Bypass relay fault 2. Bypass relay wiring error	1. Replace bypass relay 2. Check bypass relay wiring

### 9.3 The action after fault

After CHH series high voltage inverter fault, the system latches and indicates fault information, acousto-optic alarm begin.

For system fault, the inverter will coast to stop. For series system fault, such as if temperature of phase shift transformer exceeds 150℃. The system will coast to stop with cutting off high voltage.

For unit fault, use bypass fault unit according to requirement for derating run without measure to process unit fault. If you check fault unit, stop inverter and cut off high voltage. Bypass fault unit is only used to deal with one fault unit. If the fault units are more than one, and the unit is not on the bypass location, the system will trigger fault and cut off high voltage.

CHH high voltage inverter latch fault until the user removes the fault. Push the button to reset the inverter.

The keypad of the inverter can latch last three fault information, environment information. The touch screen can latch last several hundred fault information, environment information.



Please do not reset and re-run the inverter if do not know the reason of fault, treat the fault after confirming the fault

	<p>level and reason.</p> <ul style="list-style-type: none"> <li>✧ CHH series inverter is complicated electronics converter equipment. Inspection or repair must under the instruction of manufacture engineer.</li> <li>✧ Please make sure the power supply is off and filter capacitor discharge completely during inspection or repair.</li> </ul>
--	--

## 9.4 Action after warning

### 1. System warning introduction

Alarm code	Alarm Name	Reason	Solution
A00.01	Input over voltage	1. Grid voltage too high	Make sure grid voltage within rated voltage vibration range +/-15%
A00.02	Phase shift transformer overheating	1. Overload 2. Environment temperature too high 3. Temperature controller fault 4. Cooling fault. 5. Protection circuit wire under interference. 6. Control cable shield is not right grounding	1. Check external signal cable and shield layer ground right or not 2. Check transformer load and environment temperature compare to rated value. 3. Check install condition 4. Check control cable shield layer grounding right or not 6. Check temperature controller and its circuit.
A00.03	Main control power supply off	1. Main Control Power Supply Power-down or not plugged 2. Control cabinet main control power	1. Inspect main control power supply, make sure connector plug-in 2. Check and make sure Q1 close 3. Check K7 work state,

Alarm code	Alarm Name	Reason	Solution
		supply switcher open(Q1) 3. Control cabinet main control power supply feed back relay K7 fault	Please replace K7 if it can not work properly 4. Ask for service
A00.04	Alternative control power supply off	1. Off or not plugged 2. Control cabinet Alternative control power supply switcher open(Q2) 3. Control cabinet alternative control power supply feed back relay K8 fault	1. Inspect main control power supply, make sure connector plug-in 2. Check and make sure Q2 close 3. Check K8 work state, Please replace K8 if it can not work properly 4. Ask for service
A00.05	FAN fault	1. The power supply for fan from phase shifting transformer is off 2. Control cabinet fan's power supply switcher (Q3) open. 3. Control cabinet fan's power supply feed back relay (K10) fault.	1. Check phase-shifting auxiliary winding circuit access is ok or not 2. Check and make sure Q3 close 3. Check K10 work state, Please replace K10 if it can not work properly 4. Ask for service
A00.06	UPS fault	1. UPS is not connect properly 2. UPS fault 3. UPS state feed back relay (K9) fault	1. Make sure Ups connected and right operation 2. Check K9 work state, 3. Ask for service

## 2. Unit warning introduction

Alarm code	Alarm Name	Reason	Solution
Ann.01	Unit over heating	1.Fan fault 2.Poor cabinet tightness and cooling condition 3. Heavy load and current	1. Ask for technical support 2. Select bigger inverter 3. Clear dusty on filter net

**Note:** nn is the number (1-27) of alarm unit.

## 9.5 Common Faults and Solutions

The inverter may have following faults or malfunctions during operation. Please refer to the following solutions.

### **No light of indicator after power on:**

- 1) Using keypad/touch screen check. There is input voltage or not. When there is high voltage, the indicator light.
- 2) Check corresponding unit if there is voltage or not through PD.30~PD.56, If not, cut off input and check the wiring between phase shifting transformer and unit.
- 3) The unit has voltage, but the indicator is not light, then please check virtual unit of inverter corresponding to unit with input voltage.

### **Over voltage during decelerating:**

- 1) Check input voltage if too high or not
- 2) Increase decreasing time.

## Maintenance

## 10

In order to prevent the fault of inverter and to make it operate smoothly in high-performance for a long time, the user must inspect the inverter periodically. The following table indicates the inspection content.

### 10.1 Daily Maintenance

Items to be Checked	Inspection content	Means/ criterion
Operation environment	1. Temperature, humidity, dust, vapor, leakage, grease contamination, gases, 2. Hazardous material	Visual indication See or use instrument check if need the technical regulation
Touch screen	Clear	Visual indication display clear
Frame work structure	1. Abnormal vibration or sound 2. Screw bolt loose or not 3. Damage out of shape 4. Dusty or defile or not	Visual indication normal
cooling fan	Abnormal vibration or sound or not	Visual, auditory normal
Cooling channel	Block, attached material or not	Visual indication normal
phase-shifting transformer	1. Abnormal temperature or not 2. Abnormal sound or not	Visual, auditory, check interface
High voltage contactor	1. Abnormal vibration or not 2. Abnormal sound or not	Visual, auditory normal

### 10.2 Periodic Maintenance

General steps of periodic maintenance and inspection

- (1)Cut off all of the power supply for high inverter including main power supply and auxiliary power supply
- (2)Confirm Item (1) after waiting for 30 min, confirm power unit discharge.
- (3)Make sure switcher open and grounding correctly
- (4)Open cabinet door of high inverter, check the item one by one according to periodic maintenance.
- (5)Implement maintenance of high voltage
- (6)Confirm the maintenance and inspection work
- (7)Finish the maintenance and inspection
- (8)Confirm main power supply, control power supply and control circuit connected properly.
- (9)Make sure without tools or foreign material in cabinet. No other hidden trouble
- (10)Make sure filter do not block
- (11)Electric cabinet door close
- (12)Power on again to make sure maintenance and inspection,
- (13)Fill in maintenance and inspection report
- (14)Hand in receipt maintenance and inspection report.



## High Voltage Variable Frequency Speed Control System

### Maintenance List

N o.	Check Locati on	Check Item	Check content	Cycle				check method	check standard	Inspec tion	Not es
				Dai ly	Regular(year)						
					1	2	3				
1	All	Environ ment	The ambient temperature, humidity, dust, etc.	•				Observation	Ambient temperature -10 ~ 40 ℃, unfrozen; humidity below 90%,non-conden sation	Therm ometer  hygro meter	
2		Entire system	Abnormal vibration and abnormal noise	•				Observation and hearing	No exceptions		
3		Main supply voltage	Voltage is normal	•				Observe the interface shows the input voltage	Rated voltage-15% , +10%		
4		Control Supply Voltage	Voltage is normal	•				Measurement control part of the input voltage	AC220V±10%	Multi- meter	
5		Man-ma chine interfac e	Show information is abnormal, the operation is accurate	•				Observation	displayed in the normal range, and operation normal		
6			Dust filter	Congestion, dust is too much	•				Observation	With an A4 size paper filter	

# Maintenance

N o.	Check Locati on	Check Item	Check content	Cycle				check method	check standard	Inspec tion	Not es
				Dai ly	Regular(year)						
					1	2	3				
									should be firmly adsorbed, no obvious dust.		
7	Main circuit	All	Insulation resistance test (phase-shifting transformer insulation case)		●			(1)insulation resistance values should be within the normal range	(1)≥ 100MΩ (2)~(3)No exceptions	Insulati on ohmm eter DC 2500V	
			Loose parts		●	●	●	(2)Check and tighten			
			Abnormal heating parts		●	●	●	(3)Observation			
			Cleaning				●				
8		Connect ing conduct or and wires	(1)Conductor is tilted		●	●	●	Observation	No exceptions		
			(2)Wire insulation is damaged, aging		●	●	●				
9		Termi nals	broken		●	●	●	Observation	No exceptions		
10		Filter capacito r	(1)fluid leakage	●	●	●	●	(1)~(2)Observati on (3)Measured by capacitance meter	(1)~(2)No exceptions (3)Rated Capacity ≥ 85%	Capaci tance Meter	
			(2)expansion	●	●	●	●				
			(3)electrostatic capacity				●				
11		Relay	(1)abnormal noise (2)Contact is rough,		●	●	●	Observation and hearing	No exceptions		

## Maintenance

No.	Check Location	Check Item	Check content	Cycle				check method	check standard	Inspection	Notes
				Daily	Regular(year)						
					1	2	3				
			broken								
12	Control Protection circuit	Action Check	The balance of the output voltage		•			(1)Measuring the output terminals U, V, W phases voltage (2)At simulation run position, associated test	(1)Measuring output voltage on the control cabinet, alternate differential voltage is less 10V (2)The high-voltage switch can switch on after "switch allow" is given. The high-voltage switch is immediately breaking when press emergency stop button.	Multimeter	
			Interlock switch is normal, protection circuit indicating normal		•						
13	Cooling system	Cooling Fans	Abnormal vibration and sound	•				(1)Rotated by hand without power. (2)Check and tighten	(1)Smooth rotation (2)No exceptions		
			Loose parts		•	•	•				
14	Display	Display	Man-machine	•				(1)Observation			Con

# Maintenance

N o.	Check Locati on	Check Item	Check content	Cycle			check method	check standard	Inspec tion	Not es	
				Dai ly	Regular(year)						
					1	2					3
	y		interface display is normal				(2)Cleaning with cotton yarn, without organic solvents			firm ed nor mal	
		Cleaning		•							
15		Indicato r	Light and right	•			Consistent with the requirements	Meeting the design requirements			
16		Instrum ent	Normal	•			Recognized the value	Meet rated value			
17	Electro motor	All	Abnormal vibration and sound	•			(1)Observation and hearing	No exceptions			
			Abnormal odor	•							(2)Observation
18		Insulatio n resistan ce	Insulation resistance test		•		Removed U, V, W wiring	≥ 50MΩ	Insulati on ohmm eter DC 2500V		

## Appendix

## 1

### **General knowledge of EMC**

EMC is the abbreviation of electromagnetic compatibility, which means the device or system has the ability to work normally in the electromagnetic environment and will not generate any electromagnetic interference to other equipments. EMC includes two subjects: electromagnetic interference and electromagnetic anti-jamming.

According to the transmission mode, Electromagnetic interference can be divided into two categories: conducted interference and radiated interference. Conducted interference is the interference transmitted by conductor. Therefore, any conductors (such as wire, transmission line, inductor, capacitor and so on) are the transmission channels of the interference.

Radiated interference is the interference transmitted in electromagnetic wave, and the energy is inverse proportional to the square of distance.

Three necessary conditions or essentials of electromagnetic interference are: interference source, transmission channel and sensitive receiver. For customers, the solution of EMC problem is mainly in transmission channel because of the device attribute of disturbance source and receiver can not be changed.

Different electric and electronic devices, because of its various EMC standards and degrees, have different EMC capacities.

Like other electric or electronic devices, inverter is not only an electromagnetic interference source but also an electromagnetic receiver. The operating principle of inverter determines that it can produce certain electromagnetic interference noise. And the same time inverter should be designed with certain anti-jamming ability to ensure the smooth working in certain electromagnetic environment. The following is its EMC features:

- ① Input current is non-sine wave. The input current includes large amount of high-harmonic waves that can cause electromagnetic interference, decrease the grid power factor and increase the line loss.
- ② Output voltage is high frequency PWM wave, which can increase the

temperature rise and shorten the life of motor. And the leakage current will also increase, which can lead to the leakage protection device malfunction and generate strong electromagnetic interference to influence the reliability of other electric devices.

- ③ As the electromagnetic receiver, too strong interference will damage the inverter and influence the normal using of customers.
- ④ In the system, EMS and EMI of inverter coexist. Decrease the EMI of inverter can increase its EMS ability.

In order to ensure all electric devices in the same system to work smoothly, this section, based on EMC features of inverter, introduces EMC installation process in several aspects of application (noise control, site wiring, grounding, leakage current and power supply filter). The good effective of EMC will depend on the good effective of all of these aspects.

### **1. Noise control**

All the connections to the control terminals must use shielded wire. And the shield layer of the wire must ground near the wire entrance of inverter. The ground mode is 360 degree annular connection formed by cable clips. It is strictly prohibitive to connect the twisted shielding layer to the ground of inverter, which greatly decreases or loses the shielding effect.

Connect inverter and motor with the shielded wire or the separated cable tray. One side of shield layer of shielded wire or metal cover of separated cable tray should connect to ground, and the other side should connect to the motor cover. Installing an EMC filter can reduce the electromagnetic noise greatly.

### **2. Site wiring**

Power supply wiring: the power should be separated supplied from electrical transformer. Normally it is 5 core wires, three of which are fire wires, one of which is the neutral wire, and one of which is the ground wire. It is strictly prohibitive to use the same line to be both the neutral wire and the ground wire

Device categorization: there are different electric devices contained in one control cabinet, such as inverter, filter, PLC and instrument etc, which have different ability of emitting and withstanding electromagnetic noise. Therefore, it needs to categorize these devices into strong noise device and noise sensitive device. The same kinds of device should be placed in the same area, and the distance between devices of different category should be more than

20cm.

Wire Arrangement inside the control cabinet: there are signal wire (light current) and power cable (strong current) in one cabinet. For the inverter, the power cables are categorized into input cable and output cable. Signal wires can be easily disturbed by power cables to make the equipment malfunction. Therefore wiring, signal cables and power cables should be arranged in different area. It is strictly prohibitive to arrange them in parallel or interlacement at a close distance (less than 20cm) or tie them together. If the signal wires have to cross the power cables, they should be arranged in 90 angles. Power input and output cables should not either be arranged in interlacement or tied together, especially when installed the EMC filter. Otherwise the distributed capacitances of its input and output power cable can be coupling each other to make the EMC filter out of function.

### **3. Grounding**

Inverter must be ground safely in operation. Grounding enjoys the priority in all EMC methods because it does not only ensure the safety of equipment and persons, but also is the simplest, most effective and lowest cost solution for EMC problems.

Grounding has three categories: special pole grounding, common pole grounding and series-wound grounding. Different control system should use special pole grounding, and different devices in the same control system should use common pole grounding, and different devices connected by same power cable should use series-wound grounding.

## Appendix

## 2

### Interfaces

RS485: asynchronous, half-duplex.


Default: 8-E-1, 19200bps. See Group PC parameter settings.

### Communication Modes

1. The protocol is Modbus protocol. Besides the common register Read/Write operation, it is supplemented with commands of parameters management.
2. The drive is a slave in the network. It communicates in 'point to point' master-slave mode. It will not respond to the command sent by the master via broadcast address.
3. In the case of multi-drive communication or long-distance transmission, connecting a 100~120Ω resistor in parallel with the master signal line will help to enhance the immunity to interference.

### Protocol Format

Modbus protocol supports both RTU and ASCII mode. The frame format is illustrated as follows:



Modbus adopts "Big Endian" representation for data frame. This means that when a numerical quantity larger than a byte is transmitted, the most significant byte is sent first.

### RTU mode

In RTU mode, the Modbus minimum idle time between frames should be no



less than 3.5 bytes. The checksum adopts CRC-16 method. All data except checksum itself sent will be counted into the calculation. Please refer to section: CRC Check for more information. Note that at least 3.5 bytes of Modbus idle time should be kept and the start and end idle time need not be summed up to it.

The table below shows the data frame of reading parameter 002 from slave node address 1.

Node addr.	Command	Data addr.		Read No.		CRC	
0x01	0x03	0x00	0x02	0x00	0x01	0x25	0xCA

The table below shows the reply frame from slave node address 1

Node addr.	Command	Bytes No.	Data		CRC	
0x01	0x03	0x02	0x00	0x00	0xB8	0x44

### ASCII mode

In ASCII mode, the frame head is "0x3A", and default frame tail is "0x0D" or "0x0A". The frame tail can also be configured by users. Except frame head and tail, other bytes will be sent as two ASCII characters, first sending higher nibble and then lower nibble. The data have 7/8 bits. "A"~"F" corresponds to the ASCII code of respective capital letter. LRC check is used. LRC is calculated by adding all the successive bytes of the message except the head and tail, discarding any carries, and then two's complementing the result.

Example of Modbus data frame in ASCII mode:

The command frame of writing 0x0003 into address "0x1000" of slave node address 1 is shown in the table below:

LRC checksum = the complement of  $(01+06+10+00+0x00+0x03) = 0xE5$

	Frame head	Node addr.		Command		Data addr.			
Cod e		0	1	0	6	1	0	0	0
ASCI I	3A	30	31	30	36	31	30	30	30
Data to write				LRC		Frame tail			

0	0	0	3	E	5	CR	LF
30	30	30	33	45	35	0D	0A

### Protocol function

Different respond delay can be set through drive's parameters to adapt to different needs. For RTU mode, the respond delay should be no less than 3.5 bytes interval, and for ASCII mode, no less than 1ms.

The main function of Modbus is to read and write parameters. The Modbus protocol supports the following commands:

0x03	Read inverter's function parameter and state parameters
0x06	Write single function parameter or command parameter to inverter

All drive's function parameters, control and state parameters are mapped to Modbus R/W data address.

The data addresses of each function parameters please refer the sixth column of chapter 9.

The data address of control and state parameters please refer to the following table.

Parameter Description	Address	Meaning of value	R/W Feature
Control command	1000H	0001H: Forward	W/R
		0002H: Reverse	
		0003H: JOG forward	
		0004H: JOG reverse	
		0005H: Stop	
		0006H: Coast to stop	
		0007H: Reset fault	
		0008H: JOG stop	
Inverter state	1001H	0001H: Forward running	R
		0002H: Reverse running	
		0003H: Standby	
		0004H: Fault	
		0005H: POFF state	
Communicatio	2000H	Communication Setting Range	W/R

Parameter Description	Address	Meaning of value	R/W Feature
n setting		(-Fmax~Fmax)	
	2001H	If it is set as PID (preset value or feedback value), the value is the percentage of the PID.	
	2002H	0001H:variable frequency	
		0002H:power frequency	
		0003H:switch to power frequency from variable frequency	
		0004H: switch to variable frequency from power frequency	
		0005H:Cut off high voltage	
State parameters	3000H	Output frequency	R
	3001H	Reference frequency	R
	3002H	DC Bus voltage	R
	3003H	Output voltage	R
	3004H	Output current	R
	3005H	Rotation speed	R
	3006H	Output power	R
	3007H	Output torque	R
	3008H	PID preset value	R
	3009H	PID feedback value	R
	300AH	Input terminal state	R
	300BH	Output terminal state.	R
	300CH	Input of AI1	R
	300DH	Input of AI2	R
	300EH	Input of AI3	R
	300FH	HDI frequency	R
	3010H	Reserved	R
	3011H	Reserved	R

Parameter Description	Address	Meaning of value	R/W Feature
	3012H	Step No. of multi-step	R
	3013H	Reserved	R
	3014H	Reserved	R
	3015H	Reserved	R
	3016H	Device code	R
	3017H	Power state: Bit0:K1 state Bit1:K2 state, Bit2:K3 state, Bit3:QF state Bit4:variable frequency state Bit5:power frequency state Bit6: Running state ready state. Bit7:bypass unit state Bit8: 0 - manual bypass 1 - Auto bypass	R
	3018H	Input terminal state	R
	3019H	Output terminal state	R
	301AH	Effective unit selectable bit	R
	301BH	Running control channel: 0:Keypad 1:Terminal 2:Communication	R
	301CH	Fault information code is the same as the serial number of function code. The date sent to the host computer is the hexadecimal data, not fault character.	R

Parameter Description	Address	Meaning of value	R/W Feature
	301DH	Alarm information code is the same as the serial number of function code. The date sent to the host computer is the hexadecimal data, not fault character.	R
	301EH	Reserved	
	301FH	FPGA version number	R
	3020H	A1 unit version number	R
	3021H	A2 unit version number	R
	3022H	A3 unit version number	R
	3023H	A4 unit version number	R
	3024H	A5 unit version number	R
	3025H	A6 unit version number	R
	3026H	A7 unit version number	R
	3027H	A8 unit version number	R
	3028H	A9 unit version number	R
	3029H	B1 unit version number	R
	302AH	B2 unit version number	R
	302BH	B3 unit version number	R
	302CH	B4 unit version number	R
	302DH	B5 unit version number	R
	302EH	B6 unit version number	R
	302FH	B7 unit version number	R
	3030H	B8 unit version number	R
	3031H	B9 unit version number	R
	3032H	C1 unit version number	R
	3033H	C2 unit version number	R
	3034H	C3 unit version number	R
	3035H	C4 unit version number	R
	3036H	C5 unit version number	R

Parameter Description	Address	Meaning of value	R/W Feature
	3037H	C6 unit version number	R
	3038H	C7 unit version number	R
	3039H	C8 unit version number	R
	303AH	C9 unit version number	R
	5000H	This address stores the fault type of inverter. The meaning of each value is same as P7.15.	R

The above shows the format of the frame. Now we will introduce the Modbus command and data structure in details, which is called protocol data unit for simplicity. Also MSB stands for the most significant byte and LSB stands for the least significant byte for the same reason. The description below is data format in RTU mode. The length of data unit in ASCII mode should be doubled.

Protocol data unit format of reading parameters:

Request format:

Protocol data unit	Data length(bytes)	Range
Command	1	0x03
Data Address	2	0~0xFFFF
Read number	2	0x0001~0x0010

Reply format (success):

Protocol data unit	Data length(bytes)	Range
Command	1	0x03
Returned byte number	2	2* Read number
Content	2* Read number	

If the operation fails, the inverter will reply a message formed by failure command and error code. The failure command is (Command+0x80). The error code indicates the reason of the error; see the table below.

Value	Name	Meaning
01H	Illegal command	The command from master can not be executed. The reason maybe:

Value	Name	Meaning
		<ol style="list-style-type: none"> <li>1. This command is only for new version and this version can not realize.</li> <li>2. Slave is in fault state and can not execute it.</li> </ol>
02H	Illegal data address.	Some of the operation addresses are invalid or not allowed to access.
03H	Illegal value	<p>When there are invalid data in the message framed received by slave.</p> <p>Note: This error code does not indicate the data value to write exceed the range, but indicate the message frame is an illegal frame.</p>
06H	Slave busy	Inverter is busy(EEPROM is storing)
10H	Password error	The password written to the password check address is not same as the password set by P7.00.
11H	Check error	The CRC (RTU mode) or LRC (ASCII mode) check not passed.
12H	Written not allowed.	<p>It only happen in write command, the reason maybe:</p> <ol style="list-style-type: none"> <li>1. the data to write exceed the range of according parameter</li> <li>2. The parameter should not be modified now.</li> <li>3. The terminal has already been used.</li> </ol>
13H	System locked	When password protection take effect and user does not unlock it, write/read the function parameter will return this error.

## Appendix

## 3

### *List of function parameters*

The function parameters of CHH100 series inverters have been divided according to the function. Each function group contains certain function codes applying 3-class menus. For example, "P8.08" means the eighth function code in the P8 group function, PE group is factory reserved, and users are forbidden to access these parameters.

For the convenience of function codes setting, the function group number corresponds to the first class menu, the function code corresponds to the second class menu and the function code corresponds to the third class menu.

1. Below is the instruction of the function lists:

**The first column** "Function code": codes of function parameter group and parameters;

**The second column** "Name": full name of function parameters;

**The third column** "Description": Detailed illustration of the function parameters

**The forth column** "Setting range": the effective setting range of the function parameters which will displayed on the LCD;

**The fifth column** "Factory Setting": the original factory set value of the function parameter;

**The sixth column** "Modify": the modifying character of function codes (the parameters can be modified or not and the modifying conditions), below is the instruction:

"○": means the set value of the parameter can be modified on stop and running state;

"◎": means the set value of the parameter can not be modified on the running state;

"●": means the value of the parameter is the real detection value which can not be modified.



(The inverter has limited the automatic inspection of the modifying character of the parameters to help users avoid mismodifying)

2. "Parameter radix" is decimal (DEC), if the parameter is expressed by hex, then the parameter is separated form each other when editing. The setting range of certain bits are 0~F (hex).

3." Factory setting" means the function parameter will restore to the default value during default parameters restoring. But the detected parameter or recorded value won't be restored.

4. For a better parameter protection, the inverter provides password protection to the parameters. After setting the password (set P7.00 to any non-zero number), the system will come into the state of password verification firstly after the user press **PRG/ESC** to come into the function code editing state. And then "0.0.0.0.0." will be displayed. Unless the user input right password, they cannot enter into the system. For the factory setting parameter zone, it needs correct factory password (remind that the users can not modify the factory parameters by themselves, otherwise, if the parameter setting is incorrect, damage to the inverter may occur). If the password protection is unlocked, the user can modify the password freely and the inverter will work as the last setting one. When P7.00 is set to 0, the password can be canceled. If P7.00 is not 0 during powering on, then the parameter is protected by the password. When modify the parameters by serial communication, the function of the password follows the above rules, too.

Function Code	Name	Description	Setting range	Factory Setting	Modify
P0 group Basic function					
P0.00	Speed control mode	0: V/F control 1: Vector control(reserved)	0~1	0	●

Function Code	Name	Description	Setting range	Factory Setting	Modify
P0.01	Run command source	0: Keypad 1: Terminal 2: Communication	0~2	0	○
P0.02	UP/DOWN setting	0: Valid, save UP/DOWN value when power off 1: Valid, do not save UP/DOWN value when power off 2: Invalid 3: Valid during running, clear when power off	0~3	0	○
P0.03	Frequency A command source	0: Keypad 1: AI1 2: AI2 3: AI3 4: HDI1 5: Multi-Step speed 6: PID 7: Communication	0~7	0	○
P0.04	Frequency B command source	0: AI1 1: AI2 2: AI3 3: HDI	0~3	0	○
P0.05	Scale of frequency B command	0: Maximum frequency 1: Frequency A command	0~1	0	○
P0.06	Frequency command selection	0:A(P0.03) 1:B(P0.04) 2:A+B 3:Max(A,B)	0~3	0	○
P0.07	Maximum	P0.08~120.00Hz	10.00~120	50.00Hz	◎

Function Code	Name	Description	Setting range	Factory Setting	Modify
	frequency		.00		
P0.08	Upper frequency limit	P0.09~ P0.07(Maximum frequency)	P0.09~P0.07	50.00Hz	○
P0.09	Lower frequency limit	0.00 ~ P0.08(Upper frequency limit)	0.00~P0.08	0.00Hz	○
P0.10	Keypad reference frequency	0.00 ~ P0.07(Maximum frequency)	0.00~P0.07	50.00Hz	○
P0.11	Acceleration time 1	0.1~3600.0s	0.1~3600.0	Depend on model	○
P0.12	Deceleration time 1	0.1~3600.0s	0.1~3600.0	Depend on model	○
P0.13	Running direction selection	0: Forward 1: Reverse 2: Forbid reverse	0~2	0	◎
P0.14	Carrier frequency setting	0.5~2.0kHz	0.5~2.0	0	◎
P0.15	Motor parameters autotuning	0: No action 1: Autotuning	0~1	0	◎
P0.16	Restore parameters	0: No action 1: Restore factory setting 2: Clear fault records	0~2	0	◎
P0.17	AVR function	0: Disabled 1: Enabled all the time 2: Disabled during	0~2	1	◎

Function Code	Name	Description	Setting range	Factory Setting	Modify
		deceleration			
P1 group Start and Stop Control					
P1.00	Start Mode	0: Start directly 1: DC braking and start 2: Speed tracking and start	0~2	0	⊙
P1.01	Starting frequency	0.00~10.00Hz	0.00~10.0 0	0.00Hz	⊙
P1.02	Hold time of starting frequency	0.0~50.0s	0.0~50.0	0.0s	⊙
P1.03	DC Braking current before start	0.0~120.0%	0.0~120.0	0.0%	⊙
P1.04	DC Braking time before start	0.0~50.0s	0.0~50.0	0.0s	⊙
P1.05	Stop Mode	0:Deceleration to stop 1:Coast to stop	0~1	0	○
P1.06	Starting frequency of DC braking	0.00~P0.07Hz(Maximum frequency)	0.00~P0.0 7	0.00Hz	○
P1.07	Waiting time before DC braking	0.0~50.0s	0.0~50.0	0.0s	○
P1.08	DC braking current	0.0~120.0%	0.0~120.0	0.0%	○
P1.09	DC braking time	0.0~50.0s	0.0~50.0	0.0s	○
P1.10	Dead time of	0.0~3600.0s	0.0~3600.	0.0s	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
	FWD/REV		0		
P1.11	Action when running frequency is less than lower frequency limit	0: Running at the lower frequency limit 1: Stop 2: Stand-by	0~2	0	⊙
P1.12	Restart after power off	0: Disabled 1: Enabled	0~1	0	○
P1.13	Delay time for restart	0.0~3600.0s(Depend on P1.12)	0.0~3600.0	0.0s	○
P1.14	High voltage switcher action selection when stop	0:cut off high voltage supply 1:Holding	0~1	1	○
P1.15	Waiting time of switching on	0.0~3600.0s	0.0~3600.0s	10.0 s	○
P1.16	Waiting time of running in order	0.0~3600.0s	0.0~3600.0s	10.0 s	○
P2 group Motor parameters					
P2.00	Inverter Model	0:Asynchronous motor 1:Synchronous motor(reserved)	0~1	0	●
P2.01	Motor rated power	4.0~5000.0kW	4.0~5000.0	Depend on model	⊙

Function Code	Name	Description	Setting range	Factory Setting	Modify
P2.02	Motor rated frequency	0.01~P0.07(Maximum frequency)	0.01~P0.07	50.00Hz	☉
P2.03	Motor rated speed	1~36000rpm	1~36000	985rpm	☉
P2.04	Motor rated voltage	0~20000V	0~20000	Depend on model	☉
P2.05	Motor rated current	0.1~1000.0A	0.1~1000.0	Depend on model	☉
P2.06	Motor stator resistance	0.001~65.535Ω	0.001~65.535	Depend on model	○
P2.07	Motor rotor resistance	0.001~65.535Ω	0.001~65.535	Depend on model	○
P2.08	Motor leakage inductance	0.1~6553.5mH	0.1~6553.5	Depend on model	○
P2.09	Motor mutual inductance	0.1~6553.5mH	0.1~6553.5	Depend on model	○
P2.10	Current without load	0.01~655.35A	0.01~655.35	Depend on model	○
P3 group Auxiliary function					
P3.00	Acceleration time 2	0.1~3600.0s	0.1~3600.0	Depend on model	○
P3.01	Deceleration time 2	0.1~3600.0s	0.1~3600.0	Depend on	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
				model	
P3.02	Acceleration time 3	0.1~3600.0s	0.1~3600.0	Depend on model	○
P3.03	Deceleration time 3	0.1~3600.0s	0.1~3600.0	Depend on model	○
P3.04	Acceleration time 4	0.1~3600.0s	0.1~3600.0	Depend on model	○
P3.05	Deceleration time 4	0.1~3600.0s	0.1~3600.0	Depend on model	○
P3.06	Jog run frequency	0.00~P0.07	0.00~P0.07	5.00Hz	○
P3.07	Jog acceleration time	0.1~3600.0s	0.1~3600.0	Depend on model	○
P3.08	Jog deceleration time	0.1~3600.0s	0.1~3600.0	Depend on model	○
P3.09	Skip frequency 1	0.00~P0.07	0.00~P0.07	0.00Hz	○
P3.10	Skip frequency bandwidth 1	0.00~P0.07	0.00~P0.07	0.00Hz	○
P3.11	Skip frequency 2	0.00~P0.07	0.00~P0.07	0.00Hz	○
P3.12	Skip frequency bandwidth 2	0.00~P0.07	0.00~P0.07	0.00Hz	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
P3.13	Auto reset times	0~3	0~3	0	○
P3.14	Reset interval	0.1~100.0s	0.1~100.0	1.0s	○
P3.15	FDT level	0.00~P0.07	0.00~P0.07	50.00Hz	○
P3.16	FDT lag	0.0~100.0%	0.0~100.0	5.0%	○
P3.17	Frequency arrive detecting range	0.0~100.0%	0.0~100.0	0.0%	○
P3.18	Over modulation selection	0:Invalid 1:Valid	0~1	0	○
P3.19	Operation mode of cooling fans	0: Normal operating 1: Operating all the time	0~1	0	○
P3.20	Alarm reset intervals	0.0:Alarm invalid 0.1~3600.0s	0.0~3600.0	0.0	○
P4 group V/F Control Parameter					
P4.00	V/F curve selection	0:Linear curve 1: User-defined curve 2:Torque_stepdown curve (1.3 order) 3:Torque_stepdown curve (1.7 order) 4: Torque_stepdown curve (2.0 order)	0~4	0	◎
P4.01	Torque boost	0.0%:(AUTO)0.1%~10.0 %	0.0~10.0	0.1%	○
P4.02	Torque	0.0%~50.0 % ( Motor rated	0.0~50.0	20.0%	◎



Function Code	Name	Description	Setting range	Factory Setting	Modify
	boost cut-off	frequency)			
P4.03	V/F slip compensation	0.0~200.0%	0.0~200.0	0.0%	○
P4.04	Auto energy saving selection	0:Invalid 1:Valid	0~1	0	◎
P4.05	V/F frequency 1	0.00Hz~P4.07	0.00~P4.07	0.00Hz	○
P4.06	V/F voltage 1	0.0%~100.0% (Motor rated voltage)	0.0~100.0	0.0%	○
P4.07	V/F frequency 2	P4.05~P4.09	P4.05~P4.09	0.00Hz	○
P4.08	V/F voltage2	0.0%~100.0%	0.0~100.0	0.0%	○
P4.09	V/F frequency 3	P4.07~P2.02( Motor rated frequency)	P4.07~P2.01	0.00Hz	○
P4.10	V/F voltage 3	0.0%~100.0%( Motor rated voltage)	0.0~100.0	0.0%	○
P4.11	PWM mode selection	0:PWM 1 1:PWM 2	0~1	0	◎
P5 group Input terminals					
P5.00	S1 Terminal function	0:Invalid 1:Forward 2:Reverse 3:3-wire control 4:Jog forward 5:Jog reverse 6:Coast to stop 7:Reset fault 8:External fault normal open input	0~39	0	◎
P5.01	S2 Terminal function		0~39	0	◎
P5.02	S3 Terminal function		0~39	0	◎
P5.03	S4 Terminal function		0~39	0	◎
P5.04	S5 Terminal function		0~39	0	◎

Function Code	Name	Description	Setting range	Factory Setting	Modify
P5.05	S6 Terminal function	9:External fault normal close input	0~39	0	⊙
P5.06	S7 Terminal function	10:Up command 11:DOWN command	0~39	0	⊙
P5.07	S8 Terminal function	12:Clear UP/DOWN 13:Clear UP/DOWN	0~39	0	⊙
P5.08	S9 Terminal function	(Temporary) 14:ACC/DEC time	0~39	0	⊙
P5.09	S10 Terminal function	selection1 15:ACC/DEC time selection 2	0~39	0	⊙
P5.10	S11 Terminal function	16:Multi-step speed reference1 17:Multi-step speed	0~39	0	⊙
P5.11	S12 Terminal function	reference 2 18:Multi-step speed reference 3	0~39	0	⊙
P5.12	S13 Terminal function	19:Multi-step speed reference 4 20:Multi-step speed	0~39	0	⊙
P5.13	S14 Terminal function	pause 21:Switch between A and B	0~39	0	⊙
P5.14	S15 Terminal function	22:Switch between A and A+B 23:Switch between B and A+B	0~39	0	⊙
P5.15	S16 Terminal function	24:Pause PID 25:Pause operation 26:ACC/DEC ramp hold 27~29:Reserved 30:Available frequency	0~39	0	⊙

Function Code	Name	Description	Setting range	Factory Setting	Modify
		running(Pulse) 31:Power frequency running(Pulse) 32Switching from variable frequency to power frequency(Pulse) 33: Switching from power frequency to variable frequency. (Pulse) 34: Emergency breaking input of high voltage(Pulse) 35: Running command switch to keypad 36: Running command switch to terminals 37: Running command switch to communication 38: Input signals of high voltage switch on. 39:Reserved			
P5.16	Polar selection of input terminal	0x0000~0xFFFF	0000~FFFF F	0000	○
P5.17	Filter time of ON/OFF	1~10	1~10	5	○
P5.18	terminals control mode	0: 2-wire control mode 1 1: 2-wire control mode 2 2: 3-wire control mode 1 3: 3-wire control mode 2	0~3	0	◎

Function Code	Name	Description	Setting range	Factory Setting	Modify
P5.19	UP setting change rate	0.01~50.00Hz/s	0.01~50.0 0	0.50Hz/s	○
P5.20	DOWN setting change rate	0.01~50.00Hz/s	0.01~50.0 0	0.50Hz/s	○
P5.21	AI1 lower limit	0.00V~P5.23	0.00~P5.2 3	0.00V	○
P5.22	AI1 lower limit corresponding setting	-100.0%~100.0%	-100.0~10 0.0	0.0%	○
P5.23	AI1 upper limit	P5.21~10.00V	P5.21~10. 00	10.00V	○
P5.24	AI1 upper limit corresponding setting	-100.0%~100.0%	-100.0~10 0.0	100.0%	○
P5.25	AI1 filter time constant	0.00s~10.00s	0.00~10.0 0	0.10s	○
P5.26	AI2 lower limit	0.00V~P5.28	0.00~P5.2 8	0.00V	○
P5.27	AI2 lower limit corresponding setting	-100.0%~100.0%	-100.0~10 0.0	0.0%	○
P5.28	AI2 upper limit	P5.26~10.00V	P5.26~10. 00	10.00V	○
P5.29	AI2 upper limit corresponding setting	-100.0%~100.0%	-100.0~10 0.0	100.0%	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
P5.30	AI2 filter time constant	0.00s~10.00s	0.00~10.00	0.10s	○
P5.31	AI3 lower limit	-10.00V~P5.33	-10.00~P5.33	-10.00V	○
P5.32	AI3 lower limit corresponding setting	-100.0%~100.0%	-100.0~100.0	-100.0%	○
P5.33	AI3 upper limit	P5.31~10.00V	P5.31~10.00	10.00V	○
P5.34	AI3 upper limit corresponding setting	-100.0%~100.0%	-100.0~100.0	100.0%	○
P5.35	AI3 filter time constant	0.00s~10.00s	0.00~10.00	0.10s	○
P5.36	HDI1 lower limit	0.000 KHz~P5.38	0.000~P5.38	0.000KHz	○
P5.37	HDI1 lower limit corresponding setting	-100.0%~100.0%	-100.0~100.0	0.0%	○
P5.38	HDI1 upper limit	P5.36~50.000KHz	P5.36~50.000	50.000KHz	○
P5.39	HDI1 upper limit corresponding setting	-100.0%~100.0%	-100.0~100.0	100.0%	○
P5.40	HDI1 filter time constant	0.00s~10.00s	0.00~10.00	0.10s	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
P6 group    Output terminals					
P6.00	Relay 1 output selection	0:No output 1:Run FOR/REV 2:Fault output	0~20	0	○
P6.01	Relay 2 output selection	3:FDT reached 4:Frequency reached 5:Zero speed running	0~20	0	○
P6.02	Relay 3 output selection	6:Variable frequency 7:Power frequency 8: Run time reached	0~20	0	○
P6.03	Relay 4 output selection	9:Upper frequency limit reached 10:Lower frequency limit	0~20	0	○
P6.04	Relay 5 output selection	11:Ready for high voltage power on	0~20	0	○
P6.05	Relay 6 output selection	12:Alarm output 13: Permission of high voltage switcher on	0~20	0	○
P6.06	Relay 7 output selection	14: Emergency breaking of high voltage 15:State of running channel	0~20	0	○
P6.07	Relay 8 output selection	16:State of power bypass 17~20: No output	0~20	0	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
P6.08	High-speed pulse HDO output selection	0:Running frequency(100% corresponds to maximum frequency) 1:Reference frequency(100% corresponds to maximum frequency) 2:Inverter output current(100% corresponds to 2 times rated current)	0~24	0	○
P6.09	AO1 output selection	3:Motor current(100% corresponds to 2 times rated current) 4:Output voltage(100% corresponds to 1.2 times rated voltage)	0~24	0	○
P6.10	AO2 output selectio	5:Output power(100% corresponds to two times motor rated power)	0~24	0	○
P6.11	AO3 output selection	6:Output torque(100% corresponds to two times motor rated torque)	0~24	0	○
P6.12	AO4 output selection	7:AI1 voltage 8:AI2 voltage 9:AI3 voltage (100% corresponds to 10V) 10:Input line voltage of RS 11:Input line voltage of ST 12:Input line voltage of TR	0~24	0	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
		13:Output line voltage of AB 14:Output line voltage of BC 15:Output line voltage of CA 16:Input current of R phase 17:Input current of S phase 18:Input current of T phase 19:Output current of A phase 20:Output current of B phase 21:Output current of C phase 22:A phase modulate waveform 23:B phase modulate waveform 24:C phase modulate waveform			
P6.13	HDO lower limit	0.00%~P6.15	0.00~P6.15	0.00%	○
P6.14	HDO lower limit corresponding output	0.000~50.000kHz	0.000~50.000	0.000kHz	○
P6.15	HDO upper	P6.13~100.0%	P6.13~100	100.0%	○



Function Code	Name	Description	Setting range	Factory Setting	Modify
	limit		.00		
P6.16	HDO upper limit corresponding output	0.0~50.000kHz	0.000~50.000	50.000kHz	○
P6.17	AO1 lower limit	0.0%~P6.19	0.0~P6.19	0.0%	○
P6.18	AO1 lower limit corresponding output	0.00V~10.00V	0.00~10.00	0.00V	○
P6.19	AO1 upper limit	P6.17~100.0%	P6.17~100.0	100.0%	○
P6.20	AO1 upper limit corresponding output	0.00V~10.00V	0.00~10.00	10.00V	○
P6.21	AO2 lower limit	0.0%~P6.23	0.0~P6.23	0.0%	○
P6.22	AO2 lower limit corresponding output	0.00V ~10.00V	0.00~10.00	0.00V	○
P6.23	AO2 upper limit	P6.21~100.0%	P6.21~100.0	100.0%	○
P6.24	AO2 upper limit corresponding output	0.00V~10.00V	0.00~10.00	10.00V	○
P6.25	AO3 lower limit	0.0%~P6.27	0.0~P6.27	0.0%	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
P6.26	AO3 lower limit corresponding output	0.00V~10.00V	0.00~10.0 0	0.00V	○
P6.27	AO3 upper limit	P6.25~100.0%	P6.25~100 .0	100.0%	○
P6.28	AO3 upper limit corresponding output	0.00V~10.00V	0.00~10.0 0	10.00V	○
P6.29	AO4 lower limit	0.0%~P6.31	0.0~P6.31	0.0%	○
P6.30	AO4 lower limit corresponding output	0.00V ~10.00V	0.00~10.0 0	0.00V	○
P6.31	AO4 upper limit	P6.29~100.0%	P6.29~100 .0	100.0%	○
P6.32	AO4 upper limit corresponding output	0.00V~10.00V	0.00~10.0 0	10.00V	○
P7 group Human-Machine interface					
P7.00	User password	0~65535	0~65535	0	○
P7.01	LCD language selection	0:Chinese 1:English	0~1	0	○
P7.02	Parameter copy	0: Invalid 1: Upload parameters to LCD	0~2	0	◎

Function Code	Name	Description	Setting range	Factory Setting	Modify
		2: Download parameters from LCD Note: The parameter automatically return to 0 after 1 ~ 2 operation			
P7.03	<u>QUICK/JOG</u> function selection	0: Jog running 1: FDW/REV switching 2: Search the parameters different from the factory settings	0~2	0	○
P7.04	<u>STOP/RST</u> function selection	0: Valid when keypad control 1: Valid when keypad or terminal control 2: Valid when keypad or communication control 3: Always valid	0~3	0	○
P7.05	Time setting	00.00~23.59	00.00~23.59	00.00	○
P7.06	Running state display selection 1	0x0000~0xFFFF BIT0:Running frequency(Hz) BIT1:Setting frequency (Hz) BIT2:Input voltage(V) BIT3:Output voltage(V) BIT4:Output current(A) BIT5:Running speed(rpm) BIT6: Linear speed BIT7: Output power rating (%)	0~FFFF	0FFF	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
		BIT8: Output torque (%) BIT9: PID giving value (%) BIT10: PID Feedback value (%) BIT11: Input terminal state BIT12: Output terminal state BIT13: Analog AI1 Value(V) BIT14: Analog AI2 Value(V) BIT15: Analog AI3 Value(V)			
P7.07	Running state display selection2	0x0000~0xFFFF BIT0: HDI frequency value BIT1: Current step of multi-steps BIT2: Input power factor (%) BIT3: Input current(A) BIT4: Percentage of current relate to motor rated current (%) BIT5: Percentage of current relate to inverter rated current (%) BIT6: Running time BIT7: Time display BIT8: Inverter input terminals state BIT9: Inverter Output terminal state	0000~FFF F	0000	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
		BIT10~BIT15			
P7.08	Stop state display selection	0x0000~0xFFFF BIT0:Frequency setting BIT1: Input voltage BIT2:User input terminal state BIT3:User output terminal state BIT4:PID giving value BIT5:PID feedback value BIT6:Analog AI1 value BIT7:Analog AI2 value BIT8: Analog AI3 value BIT9:HDI Frequency BIT10: Current step of Multi-step BIT11:RTC time BIT12:Inverter input terminals state BIT13:Inverter output terminals state BIT14~ BIT15:Reserved	0000~FFF F	0FFF	○
P7.09	Display coefficient of speed	0.1~999.9% Mechanical speed $=120 \times \text{Running frequency} \times P7.09 / \text{polar number}$	0.1~999.9 %	100.0%	○
P7.10	Display coefficient of line speed	0.1~999.9% Linear speed= Mechanical speed $\times P7.10$	0.1~999.9 %	1.0%	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
P7.11	DSP software version	Manufacturers Parameters		Depend on mode	●
P7.12	Accumulated running time	0~65535h		0	●
P8 group Fault record					

Function Code	Name	Description	Setting range	Factory Setting	Modify
P8.00	Last two fault types	E00.mm-- System fault Mm (Fault types): 00:No fault 01:Acceleration over current (E00.01) 02:Deceleration over current (E00.02) 03:Constant speed over current(E00.03) 04: Acceleration over voltage (E00.04) 05:deceleration over voltage (E00.05) 06: Constant speed over voltage (E00.06) 07:Grid undervoltage fault (E00.07) 08:Motor overload (E00.08) 09:Inverter overload (E00.09) 10:output phase lacking (E00.10) 11:Transformer overheating (E00.11) 12:External fault (E00.12) 13:485 communication fault (E00.13) 14:Current detecting fault (E00.14) 15:Motor autotuning fault (E00.15) 16:EEPROM Operation Fault (E00.16)			●

Function Code	Name	Description	Setting range	Factory Setting	Modify
P8.01	Last time fault type				●
P8.02	current fault type				●
P8.03	Running frequency of current fault			0.00Hz	●
P8.04	Output current of current fault			0.0A	●
P8.05	DC bus voltage of current fault			0.0V	●
P8.06	DC bus voltage of current fault unit			0	●
P8.07	Temperature of current fault unit			0.0	●
P8.08	Input terminal state of current fault			0	●
P8.09	Output terminal state of current state			0	●
P8.10	Time of current fault			00.00	●
P9 group PID Control					



Function Code	Name	Description	Setting range	Factory Setting	Modify
P9.00	PID preset source selection	0: Keypad(P9.01) 1: AI1 2: AI2 3: AI3 4: AI1+AI2 5: AI2+AI3 6: AI1+AI3 7:HDI 8:Multi-step 9:Communication	0~9	0	○
P9.01	Preset PID given	0.0%~100.0%	0.0~100.0	0.0%	○
P9.02	PID feedback source selection	0: AI1 1: AI2 2: AI3 3: AI1+AI2 4: AI2+AI3 5: AI1+AI3 6: HDI 7:Communication	0~7	0	○
P9.03	PID output characteristics	0: Positive 1: Negative	0~1	0	○
P9.04	Proportional gain (Kp)	0.00~100.00	0.00~100.00	1.00	○
P9.05	Integral time (Ti)	0.01~10.00s	0.01~10.00	0.10s	○
P9.06	Differential time (Td)	0.00~10.00s	0.00~10.00	0.00s	○
P9.07	Sampling cycle (T)	0.01~100.00s	0.01~100.00	0.10s	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
P9.08	PID control deviation limits	0.0~100.0%	0.0~100.0	0.0%	○
P9.09	Feedback lost detecting value	0.0~100.0%	0.0~100.0 %	0.0%	○
P9.10	Feedback lost detecting time	0.0~3600.0s	0.0~3600.0	1.0s	○
P9.11	PID dormancy wake up value	0.0~100.0%	0.0~100.0	0.0%	○
P9.12	PID dormancy delay time	0.0~3600.0s	0.0~3600.0	1.0s	○
PA group Multi-step speed control					
PA.00	Multi-step speed 0	-100.0~100.0%	-100.0~100.0	0.0%	○
PA.01	Multi-step speed 1	-100.0~100.0%	-100.0~100.0	0.0%	○
PA.02	Multi-step speed 2	-100.0~100.0%	-100.0~100.0	0.0%	○
PA.03	Multi-step speed 3	-100.0~100.0%	-100.0~100.0	0.0%	○
PA.04	Multi-step speed 4	-100.0~100.0%	-100.0~100.0	0.0%	○
PA.05	Multi-step speed 5	-100.0~100.0%	-100.0~100.0	0.0%	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
PA.06	Multi-step speed 6	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.07	Multi-step speed 7	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.08	Multi-step speed 8	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.09	Multi-step speed 9	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.10	Multi-step speed 10	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.11	Multi-step speed 11	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.12	Multi-step speed 12	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.13	Multi-step speed 13	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.14	Multi-step speed 14	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
PA.15	Multi-step speed 15	-100.0~100.0%	-100.0~10 0.0	0.0%	<input type="radio"/>
Pb group Protection parameter					
Pb.00	Reserved	Reserved			●
Pb.01	Output phase-failure protection	0: Disabled 1: Enabled	0~1	1	<input type="radio"/>
Pb.02	Motor overload protection	0: Disabled 1: Normal motor 2: Variable frequency motor	0~2	2	<input checked="" type="radio"/>
Pb.03	Motor overload	20.0%~120.0%	20.0~120. 0	100.0%	<input type="radio"/>

Function Code	Name	Description	Setting range	Factory Setting	Modify
	protection current				
Pb.04	Frequency drop threshold of Instantaneous power-down	70.0~110.0%	70.0~110.0	80.0%	○
Pb.05	Decrease rate of Frequency drop	0.00Hz~P0.07	0.00Hz~P0.07	0.00Hz	○
Pb.06	Over-voltage stall protection	0: Disabled 1: Enabled	0~1	0	○
Pb.07	Over-voltage stall protection point	105~140%	105~140	120%	○
Pb.08	Automatic current-limiting level	50~200%	50~200	120%	○
Pb.09	Decline rate of frequency during current-limiting	0.00~10.00HZ (0.00 means invalid of over-current stall)	0.00~10.00	10.00	○
Pb.10	Input over-voltage pre-warning threshold	105~120%	105~120	110%	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
Pb.11	Unit bypass function	0:Manual bypass 1:Auto bypass	0~1	0	○
Pb.12	Unit manual bypass bit selection	0x000~0x1FF	000~1FF		○
Pb.13	hardware over-current threshold	50~200%(inverter rated current)	50~200	150%	◎
Pb.14	Power frequency bypass when failure	0:Manual power frequency bypass 1:Auto power frequency bypass	0~1	0	○
Pb.15	Low-frequency restraining oscillation factor	0~100	0~100	10	○
Pb.16	High-frequency restraining oscillation factor	0~100	0~100	0	○
Pb.17	Boundary of restraining oscillation	0.00~120.00HZ	0.00~120.00	20.00	○
PC group Serial communication					
PC.00	Local address	1~247	1~247	1	○
PC.01	Baud rate selection	0:1200BPS 1:2400BPS 2:4800BPS	0~5	4	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
		3:9600BPS 4:19200BPS 5:38400BPS			
PC.02	Data format	0: RTU, 1 start bit, 8 data bits, no parity check, 1 stop bit. 1: RTU, 1 start bit, 8 data bits, even parity check, 1 stop bit. 2: RTU, 1 start bit, 8 data bits, odd parity check, 1 stop bit. 3: RTU, 1 start bit, 8 data bits, no parity check, 2 stop bits. 4: RTU, 1 start bit, 8 data bits, even parity check, 2 stop bits. 5: RTU, 1 start bit, 8 data bits, odd parity check, 2 stop bits.	0~5	1	○
PC.03	Communication delay time	0~200ms	0~200	5	○
PC.04	Communication timeout delay	0.0 invalid, 0.1~100.0s	0.0~100.0	0.0s	○
PC.05	Communication error	0: Alarm and coast to stop 1: No alarm and continue	0~3	1	○

Function Code	Name	Description	Setting range	Factory Setting	Modify
	action	to run 2: No alarm but stop according to P1.06 (if P0.03=2) (Only communication control mode) 3: No alarm but stop according to P1.06(All control mode)			
PC.06	Communications action selection	Unit's place of LED 0: Response to writing 1: No response to writing Ten's place of LED 0: Reference not saved when power off 1: Reference saved when power off Hundred's place of LED 0: Virtual Terminal is invalid 1: Virtual Terminal is valid	0x000~0x111	000	○
PC.07	Reserved				●
Pd group Unit state query					
Pd.00	A-Phase effective unit indication	0x000~0x1FF	000~1FF		●
Pd.01	B-phase effective unit indication	0x000~0x1FF	000~1FF		●
Pd.02	C-phase	0x000~0x1FF	000~1FF		●

Function Code	Name	Description	Setting range	Factory Setting	Modify
	effective unit indication				
Pd.03	Unit A1 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.04	Unit A2 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.05	Unit A3 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.06	Unit A4 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.07	Unit A5 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.08	Unit A6 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.09	Unit A7 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.10	Unit A8 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.11	Unit A9 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.12	Unit B1 temperature	0.0~100.0℃	0.0~100.0		●



Function Code	Name	Description	Setting range	Factory Setting	Modify
	indication				
Pd.13	Unit B2 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.14	Unit B3 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.15	Unit B4 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.16	Unit B5 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.17	Unit B6 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.18	Unit B7 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.19	Unit B8 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.20	Unit B9 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.21	Unit C1 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.22	Unit C2 temperature indication	0.0~100.0℃	0.0~100.0		●

Function Code	Name	Description	Setting range	Factory Setting	Modify
Pd.23	Unit C3 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.24	Unit C4 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.25	Unit C5 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.26	Unit C6 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.27	Unit C7 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.28	Unit C8 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.29	Unit C9 temperature indication	0.0~100.0℃	0.0~100.0		●
Pd.30	Unit A1 DC bus voltage indication	0~2000V	0~2000		●
Pd.31	Unit A2 DC bus voltage indication	0~2000V	0~2000		●
Pd.32	Unit A3 DC bus voltage indication	0~2000V	0~2000		●
Pd.33	Unit A4 DC	0~2000V	0~2000		●

Function Code	Name	Description	Setting range	Factory Setting	Modify
	bus voltage indication				
Pd.34	Unit A5 DC bus voltage indication	0~2000V	0~2000		●
Pd.35	Unit A6 DC bus voltage indication	0~2000V	0~2000		●
Pd.36	Unit A7 DC bus voltage indication	0~2000V	0~2000		●
Pd.37	Unit A8 DC bus voltage indication	0~2000V	0~2000		●
Pd.38	Unit A9 DC bus voltage indication	0~2000V	0~2000		●
Pd.39	Unit B1 DC bus voltage indication	0~2000V	0~2000		●
Pd.40	Unit B2 DC bus voltage indication	0~2000V	0~2000		●
Pd.41	Unit B3 DC bus voltage indication	0~2000V	0~2000		●
Pd.42	Unit B4 DC bus voltage indication	0~2000V	0~2000		●
Pd.43	Unit B5 DC bus voltage	0~2000V	0~2000		●

Function Code	Name	Description	Setting range	Factory Setting	Modify
	indication				
Pd.44	Unit B6 DC bus voltage indication	0~2000V	0~2000		●
Pd.45	Unit B7 DC bus voltage indication	0~2000V	0~2000		●
Pd.46	Unit B8 DC bus voltage indication	0~2000V	0~2000		●
Pd.47	Unit B9 DC bus voltage indication	0~2000V	0~2000		●
Pd.48	Unit C1 DC bus voltage indication	0~2000V	0~2000		●
Pd.49	Unit C2 DC bus voltage indication	0~2000V	0~2000		●
Pd.50	Unit C3 DC bus voltage indication	0~2000V	0~2000		●
Pd.51	Unit C4 DC bus voltage indication	0~2000V	0~2000		●
Pd.52	Unit C5 DC bus voltage indication	0~2000V	0~2000		●
Pd.53	Unit C6 DC bus voltage indication	0~2000V	0~2000		●

Function Code	Name	Description	Setting range	Factory Setting	Modify
Pd.54	Unit C7 DC bus voltage indication	0~2000V	0~2000		●
Pd.55	Unit C8 DC bus voltage indication	0~2000V	0~2000		●
Pd.56	Unit C9 DC bus voltage indication	0~2000V	0~2000		●
Pd.57	Unit A1 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.58	Unit A2 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.59	Unit A3 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.60	Unit A4 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.61	Unit A5 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.62	Unit A6 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.63	Unit A7 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.64	Unit A8 fault	0x0000~0xFFFF	0000~FFF		●

Function Code	Name	Description	Setting range	Factory Setting	Modify
	indicated value		F		
Pd.65	Unit A9 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.66	Unit B1 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.67	Unit B2 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.68	Unit B3 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.69	Unit B4 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.70	Unit B5 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.71	Unit B6 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.72	Unit B7 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.73	Unit B8 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.74	Unit B9 fault indicated	0x0000~0xFFFF	0000~FFF F		●

Function Code	Name	Description	Setting range	Factory Setting	Modify
	value				
Pd.75	Unit C1 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.76	Unit C2 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.77	Unit C3 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.78	Unit C4 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.79	Unit C5 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.80	Unit C6 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.81	Unit C7 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.82	Unit C8 fault indicated value	0x0000~0xFFFF	0000~FFF F		●
Pd.83	Unit C9 fault indicated value	0x0000~0xFFFF	0000~FFF F		●