# **i-cut Production Console**

# User Manual





# Contents

1.	Preface	9
2.	Change Record	
3.	Welcome	
4.	Using this manual	
	4.1 Main Sections	
	4.2 Name Styles and Symbols	
	4.3 Pictures and Illustrations.	13
5.	System Description	
	5.1 Font size in User Interface	
	5.2 Naming Conventions	
	5.2.1 My Jobs List	
	5.2.2 Opened Job	
	5.2.3 Tool Configuration	
	5.3 Menu Bar	17
	5.3.1 File	
	5.3.2 Edit	
	5.3.3 View	19
	5.3.4 Selection	
	5.3.5 Job	
	5.3.6 Layer	
	5.3.7 Curves	
	5.3.8 Machine	
	5.3.9 Advanced	
	5.3.10 Help	
	5.4 My Jobs List	
	5.4.1 Compact View	
	5.4.2 Extended View	
	5.4.3 Select a File	
	5.4.4 My Jobs Actions	27
	5.4.5 Options Bar	
	5.5 Opened Job	
	5.5.1 Open a Job	
	5.5.2 Select a Job	
	5.5.3 Close a Job	
	5.5.4 Ready for Execution	
	5.6 Opened Job, select Cutting Key	
	5.7 Opened Job, Layers Setup	

	5.7.1 Layers Tab	34
	5.7.2 Select Layer	36
	5.7.3 Include a Layer	37
	5.7.4 Layer Sequence	. 37
	5.7.5 Edit Selected Layer	. 38
	5.7.6 Layer Types	40
	5.7.7 Add new Layer	. 40
	5.7.8 Add Regmark Layer	. 41
	5.7.9 Copy Layer and Curves	43
	5.7.10 Copy Layer, no Curves	44
	5.7.11 Remove Layer	. 44
	5.7.12 Remove Empty Layers	44
5.8	Opened Job, Production Setup	. 45
	5.8.1 Number of Copies	. 45
	5.8.2 Quality	. 46
	5.8.3 Material Handling	. 46
	5.8.4 Registration	. 49
	5.8.5 Position	. 52
	5.8.6 Step and Repeat	. 53
	5.8.7 Tool Head Parking	. 54
5.9	Toolbar	. 55
	5.9.1 Zoom Tool	. 55
	5.9.2 Zoom In	. 56
	5.9.3 Zoom Out	. 56
	5.9.4 Fit to Job	. 56
	5.9.5 Fit to Board	. 57
	5.9.6 Fit to Table	. 57
	5.9.7 Edit Points	. 57
	5.9.8 Show Curve Directions	. 57
	5.9.9 Show Curve Points	58
	5.9.10 Show Tool Path	. 58
	5.9.11 Vacuum Zones	. 58
	5.9.12 Park Position	58
	5.9.13 Show Table Rulers	59
	5.9.14 Reference Point	. 59
	5.9.15 Bounding Box	59
	5.9.16 Show Rulers	60
5.10	) Properties Bar	. 60
	5.10.1 Flute/Grain Direction	61
5.1	1 Machine Panel	
	5.11.1 Machine Panel Views	. 62
	5.11.2 Machine Panel Functions	. 64
	5.11.3 Machine Panel Toolbar	.73



5.11.4 Machine Panel Statusbar	
5.12 Machine Connection	
6. Before We Start	
6.1 Introduction	
6.2 About Table	
6.3 Table Presets	
6.3.1 Installed by default	
6.3.2 Optional	
6.4 About Registration	
6.4.1 Adding Registration Marks	
6.4.2 Types of Registration Marks	
6.4.3 Compensation Types	
6.4.4 About Compensation Types	
6.5 File Preparation for iPC	
6.5.1 File Types	91
6.5.2 Defining Cut Paths	
6.6 Import Presets	
6.6.1 Using Import Presets	93
6.6.2 Import Preset and Cutting Key	94
6.6.3 View Import Presets	95
6.6.4 Select Import Preset	
6.6.5 Manage Import Presets	
6.7 Cutting Keys	
6.7.1 Select Cutting Keys	
6.7.2 Favorite Cutting Keys	
6.7.3 Create new Cutting Key	
6.7.4 Update Cutting Key	
6.7.5 Cutting Key Manager	
6.7.6 Import Cutting Keys	
6.7.7 Global Cutting Keys	
6.7.8 i-script Link	
6.8 Configure Tools	
6.8.1 Depth Control, Tools	
6.9 Materials and Boards	
7. Get Started	
7.1 Start Up Sequence	
7.2 Shut Down Sequence	
8. Work Flow	
8.1 File Import	
8.1.1 My Jobs List	
8.1.2 Create Job	
8.2 Opened Job	

8.2.1 Layers View / Production View	
8.2.2 Opened Job Edit	
8.3 Prepare for Production	
8.3.1 Layer Setup, manual	
8.3.2 Layer Setup using Cutting Key	
8.3.3 Production Setup	
8.4 Save Job	
8.5 Running a Job	
8.5.1 Execute a Job	
8.5.2 No Registration	
8.5.3 Reading Registration Marks	
8.5.4 Registration using Laser Pointer	
8.5.5 Edge Recognition	131
9. Optimal Production Workflow	
10. Edit Job, Advanced	
10.1 Job Modifications	
10.1.1 Rotate 90 deg. CW	
10.1.2 Rotate 90 deg. CCW	
10.1.3 Mirror Horizontal	
10.1.4 Mirror Vertical	
10.1.5 Remove Double Lines and Sequence	
10.1.6 Remove Double Lines and Join Across Gaps	
10.1.7 Optimize for Production	
10.1.8 Move Job to Reference Point	
10.1.9 Move Open Curves to Separate Layer	
10.2 Curve Modifications	
10.2.1 Select a Curve	
10.2.2 Move	
10.2.3 Jog Curves	
10.2.4 Scale Curve	150
10.2.5 Mirror Curve	
10.2.6 Rotate Curve	
10.2.7 Merge Curves	
10.2.8 Invert Curve Direction	
10.2.9 Lead-in/Lead-out	
10.2.10 Tool Offset	
10.2.11 Optimize Shape	
10.2.12 Remove Curves	
10.3 Curve Segment Modifications	
10.3.1 Select a Curve Segment	
10.3.2 Add Corner	
10.3.3 Add Arc	

# ESK0 😌

10.3.4 Add Bezier	
10.3.5 Split Curve	
10.3.6 Close Curve	
10.3.7 Add Regmark	
10.4 Curve Point Modifications	
10.4.1 Select a Point	
10.4.2 Edit Point	
10.4.3 Remove Point	166
10.4.4 Smooth	
10.4.5 Add Regmark	
10.4.6 Use as Start Point	
10.4.7 Add Lead-in/Lead-out	
10.4.8 Split Curve	169
10.4.9 Close Curve	
10.5 Add new Geometry	
10.5.1 Add Regmark	
10.5.2 Add Square	
10.5.3 Add Circle	
10.5.4 Add Ellipse	
10.5.5 Add Rectangle	
11. Job Alternatives, Advanced	
11.1 Step and Repeat	
11.2 Add Nested Layout	
11.2.1 Configure Layout	
11.2.2 Create Nested Layout	179
11.2.3 Edit Nested Layout	
11.3 Jobs Longer than Table	
11.4 Jobs with Bar Codes	
11.5 Job including Reverse Operation	
11.6 Stop at Tool Select	
11.7 Multi-pass Depth	
11.8 Milling functions	
11.9 MultiZone Production	
11.9.1 Introduction	
11.9.2 User Interface	191
11.9.3 Workflow	
11.9.4 Registration	
11.9.5 More Zones	
11.9.6 Rotated Table View	
12. Direct Commands	
12.1 iPC Commands	199
13. Backup and Restore	

13.1 Backup System Parameters	
13.2 Restore System Parameters	
13.3 Backup Cutting Key	
13.4 Restore Cutting Key	
14. iPC Configurations	
14.1 Layers View / Production View Orientation	
14.2 General	
14.3 Production	
14.3.1 Table Presets	
14.3.2 Read Furthest Registration Mark First	
14.3.3 Step X-axis before Y-axis	
14.3.4 Break Long Lines	
14.4 Feeder Connection	
14.5 Lead-in/Lead-out	
14.6 Backup	
14.7 Language	
14.8 Reference Points	
14.8.1 Main Reference Point	
14.8.2 User Defined Reference Points	
15. Machine Connection and Configuration	
15.1 Machine Configuration	
15.1.1 Hardware Configuration	
15.1.2 Setup	
15.1.3 Installation	217
15.2 Tool Configuration	
15.2.1 Adjust Active Tool	
15.2.2 More	
15.3 Camera Operations	
15.4 Service Menu	
15.4.1 Message Display	
15.4.2 Memory Dump	
15.4.3 Position Display	
15.4.4 Show Vacuum Dialog	
15.4.5 Emulate Panel	
15.4.6 Tool Holder Select	
15.5 About	
13.5 About	
15.5.1 Maintenance Info	
15.5.1 Maintenance Info	
15.5.1 Maintenance Info 15.6 Terminate Machine Connection	
15.5.1 Maintenance Info 15.6 Terminate Machine Connection 15.7 Logging	231 231 231 231 231

# ESK0 😌

16.1 File Save Structure	
17. About Licenses	
18. Keyboard Shortcuts	
19. Using ai-cut/i-cutCDR	
20. i-script	

1

# 1. Preface

#### User Manual for i-cut Production Console iPC, version 1.2

**Note:** We remind you that only the Esko staff, or persons having received appropriate training, are allowed to handle, manipulate or do repairs on the system.

#### ©Copyright 2015, Esko-Graphics Kongsberg AS, Norway

All Rights Reserved.

This copyright does not indicate that this work has been published.

This material, information and instructions for use contained herein are the property of Esko-Graphics Kongsberg AS. There are no warranties granted or extended by this document. Furthermore, Esko-Graphics Kongsberg AS does not warrant, guarantee or make any representations regarding the use, or the results of the use of the system or the information contained herein. Esko-Graphics Kongsberg AS shall not be liable for any direct, indirect, consequential or incidental damages arising out of the use or inability to use the system or the information contained herein. The information contained herein is subject to change without notice. Revisions may be issued from time to time to advise of such changes and/or additions.

No part of this system may be reproduced, stored in a data base or retrieval system, or published, in any form or in any way, electronically, mechanically, by print, photoprint, microfilm or any other means without prior written permission from Esko-Graphics Kongsberg AS.

This document supersedes all previous dated versions.

Correspondence regarding this publication should be forwarded to:

**Global support** 

**Esko-Graphics Kongsberg AS** 

Document no: D3389

Part no: 32599854

**Esko-Graphics Kongsberg AS** 

www.esko.com P.O.Box 1016, N-3601 Kongsberg, Norway Tel: +47 32 28 99 00 Fax: +47 32 28 85 15 / 32 28 67 63 2 ESKO 🕄

# 2. Change Record

Date	Ву	Description
dd-mm-yy		
18-06-2014	jhbe	First edition of this document
15-10-2014	jhbe	About Licenses chapter has been modified.
20-02-2015	jhbe	Camera operation chapter has been updated with i-Camera information.
31-03-2015	jhbe	Document is updated according to iPC ver 1.2
11-06-205	jhbe	Reverse Operations in combination with Step and Repeat, update.
		Description of compensation type <b>Move Job</b> is improved.
		Types of <b>Registration Marks</b> - chapter has been updated.
25-06-2015	jhbe	Tool Up Angle, description has been updated.
		Registration using <b>Laser Pointer</b> , chapter has been updated.

# 3. Welcome

Welcome to the Kongsberg i-cut Production Console User Manual.

Throughout this manual, the abbreviation iPC is used for i-cut Production Console.

This manual will provide a complete and detailed description of all iPC functions.

It is aimed for operators of Kongsberg Cutting Tables and people preparing files for such equipment.

Note: Some of the functions and equipments described in this manual are optional.

4 ESKO😔

# 4. Using this manual

# 4.1 Main Sections

The manual is divided into the following main sections:

#### **System Description**

- A short-form description of the User Interface.
- All menues and tool bars are described one by one.

#### **Before We Start**

In this chapter, important **Basic Topics** are discussed:

- File Preparation
- Import Presets
- Cutting Keys
- Registration
- Configure Tools

#### **Workflow Description**

A typical workflow is described, with detailed information about each step:

- 1. Get Started
- 2. File Import
- 3. Opened Job
- 4. Prepare for Production, Manually
- 5. Prepare for Production using Cutting Key
- 6. Edit Production Setup
- 7. Save a Job
- 8. Run a Job

#### **Advanced Section**

Optional functions for the Advanced User are available in the chapters:

- Edit Job Possible modifications to the Opened Job.
- Job Alternatives Additional processing alternatives available.

#### **Backup and Restore**

- How to configure a proper **Backup** regime.
- How to initiate a **Backup**.
- How to restore from **Backup**.

#### **iPC Configuration**

• Option settings, specifying the general behaviour of the system.

#### **Appendices**

- Install Software
- Keyboard Shortcuts a complete list of Keyboard Shortcuts available.
- iPC Commands iPC command language.

# 4.2 Name Styles and Symbols

Name or style	Description
Pop-up dialog	This is the dialog that appears when you click the <b>Right Mouse Button</b> .
Start button	The italic style indicates this is a button on the <b>Operator Panel</b> .
ок	The bold style indicates this is a button or function in the <b>Graphical User Interface</b> (GUI).
Machine Configuration	Link to topic.
Menu Bar->Edit-> Options	Menu selection: From <b>Menu Bar</b> , select <b>Edit</b> and then <b>Options</b> .
HW	This symbol indicates that the function depends upon actual hardware.
	If hardware is not available, this functions is hidden.
C <del>irre</del>	This symbol indicates that the function is license dependant.

# 4.3 Pictures and Illustrations

#### Orientation

In this document, pictures and illustrations related to the Cutting Table are viewed as shown here:





In the User Interface, several Viewing Options are available.

5

# 5. System Description



This chapter will explore the iPC User Interface in detail.

# 5.1 Font size in **User Interface**

Ensure your font size setting is 100%. iPC will not work with bigger fonts.

# 5.2 Naming Conventions

The iPC User Interface appears in two different views, depending upon the mode you work in:





## 5.2.1 My Jobs List



- 1 Menu Bar
- 2 Options Bar
- 3 Opened Job Preview

**4 - Windows Toolbar** with **Machine Connection icon** 

- 5 Machine Panel
- 6 My Jobs Actions
- 7 My Jobs List
- 8 Select Compact / Extended View
- 9 Job Tabs

## 5.2.2 Opened Job



- 1 Menu Bar
- 2 Toolbar
- 3 Layers View / Production View, see below

5

- 4 Properties Bar
- 5 Job Setup. Comprises Layers Setup and Production Setup.
- 6 Job Tabs.

## **5.2.3 Tool Configuration**

Be aware the difference between Tool Configuration and Configure Tools:

#### **Configure Tools**

Edit Tool Settings to be used in a Layer

#### **Tool Configuration**

Maintain the Tool Configuration on the connected Cutting Table.

# 5.3 Menu Bar



The following Menu Bar entries are available:

•

Advanced

- File Layer
- Edit
   Curves
  - View Machine
- Selection

٠

Job • Help

17



### 5.3.1 File

Menu Bar->File

The following menu items are available:

New Job (Ctrl+N)	Close Job (Ctrl+W)
Create an empty <b>Job</b> .	Close the <b>Opened Job</b> .
You can add/edit geometry using the <i>Toolbar</i> functions.	
Open File (Ctrl+O)	Save Job (Ctrl+S)
Open an Input File, add it to My Jobs List.	Save <b>Opened Job</b> Job.
	The <b>Job</b> is saved using the iPC .cut format.
Open via Barcode	Save Job As (Ctrl+Shift+S)
See Jobs with Bar Codes	Save Opened Job.
	You are prompted for destination folder and file name.
Add Nested Layout	Export
Open the Add Nested Layout dialog.	Export <b>Opened Job</b> to pdf.
Create a <b>Nested Layout</b> for import to <b>My Jobs</b> List	
Edit Nested Layout	Reload
	Reload <b>Opened Job</b> . All changes you have made to the job will be lost.
	Exit
	Terminate <b>iPC</b> .

## 5.3.2 Edit



Menu Bar->Edit

The following menu items are available:

#### Undo (Ctrl+Z)

Undo previous operation(s).

### Options

- Options settings.
- Basic Configuration.
- Default value settings.

For more information, go *here*.

## 5.3.3 View



Menu Bar->View

All View functions relates to Opened Job displayed in Layers View / Production View window.

The following menu items are available:

<b>Zoom Tool</b> By the mouse, define a zoom area.	<b>Table View Orientation</b> Select viewpoint for Layers View / Production View
Zoom In (Ctrl+Add) Click to zoom in.	Reference PointThe selected Reference Point is shown in the Layers View / Production View window.
<i>Zoom Out</i> (Ctrl+Subtract) Click to zoom out.	Table RulersCutting Table Rulers are shown in the LayersView / Production View window (machine dependant).
Fit to Job (Ctrl+Shift+J)) Opened Job will fill the Layers View / Production View window.	Vacuum Zones Selected Vacuum Zones are indicated in the Layers View / Production View window.
<i>Fit to Table</i> (Ctrl+Shift+T) A picture of the Cutting Table including the Opened Job will fill the Layers View / Production View window.	<b>Parking Position</b> Show current <b>Park Position</b> as a symbol in the <b>Layers View / Production View</b> window.
<i>Curve Direction</i> An arrow on each curve indicates curve direction.	Bounding Box Show a Bounding Box surrounding Opened Job.



<i>Curve Points</i> Curve Points are visible, available for edit.	<b>Bounding Box</b> Show a <b>Bounding Box</b> surrounding <b>Opened</b> <b>Job</b> .
<i>Tool Path</i> The <b>Tool Path</b> is shown.	Rulers Add Rulers to Layers View / Production View.

### 5.3.4 Selection



All **Selection** functions relates to **Opened Job**.

The following menu items are available:

Select All Curves (Ctrl+A) In Opened Job, select all Curves. Deselect All Curves (Ctrl+D) In Opened Job, deselect all Curves.

### 5.3.5 Job

Menu Bar->Job
All Job functions relates to Opened Job.
The following menu items are available:



<i>Rotate 90<sup>0</sup> CW</i> Rotate the entire <b>Job</b> .	<b>Remove Double Lines and Sequence</b> Use this function to remove double lines and optimize cutting sequence in a <b>Job</b> .
<i>Rotate 90<sup>0</sup> CCW</i> Rotate the entire <b>Job</b> .	Remove Double Lines, Join Across Gaps Double lines will be removed. Gaps between consecutive lines that are below a certain limit will be joined.

Mirror Horisontally Mirror Opened Job.	<b>Optimize for Production</b> Opens the <b>Optimize for Production</b> dialog.
Mirror Vertically	Move Job to Reference Point
Mirror <b>Opened Job</b> .	The lower left corner of <b>Opened Job</b> will be placed in currently selected <b>Reference Point</b> .
	The corner is the lower left corner of the surrounding rectangle.
	Move Open Curves to Separate Layer
	Use this function to separate <b>Open Curves</b> from <b>Closed Curves</b> .

# 5.3.6 Layer

Menu Bar->Layer	
All Layer functions relates to Opened Job.	
The following menu items are available:	
Add Layer (Ctrl+L)	Copy Layer with Curves (Ctrl+Shift+C)
Opens the <i>Add Layer</i> dialog.	The currently selected <b>Layer</b> is copied, geometry included.
Add Regmark Layer	Remove Layer (Shift+Del)
Opens the Add Regmark Layer dialog.	The currently selected Layer(s) are removed.
Edit Layer	Remove Empty Layers (Ctrl+U)
Opens the <i>Edit Layer</i> dialog.	Layer(s) with no geometry are removed.
Copy Layer without Curves (Ctrl+C)	Remove Hidden Layers
The currently selected Layer is copied, no	Hidden Layer(s) are removed.

## 5.3.7 Curves



geometry included.

Menu Bar->Curves



#### All Curves functions relates to Selected Curve(s).

The following menu items are available:



Move (Ctrl+M)	Merge Curves
Move Selected Curves	Merge Selected Curves
Jog Curves	Invert Curve Direction (Ctrl+Shift+I)
Jog Selected Curves	Invert Curve Direction for Selected Curves
Scale (Ctrl+T)	Lead-in/Lead-out
Scale Selected Curves	Add Lead-in/Lead-out to Selected Curves
Mirror (Ctrl+Shift+M)	Tool Offset
Mirror Selected Curves	Apply Tool Offset to Selected Curves
Rotate (Ctrl+Shift+R)	Optimize Shape
Rotate Selected Curves	Optimize Selected Curves
	For more information, go here.
Edit Points	Remove Curves
Enter Edit Point Mode	Remove Selected Curves

## 5.3.8 Machine



Menu Bar->Machine

Functions for the connected **Cutting Table**.

The following menu items are available:

Connect Connect to Cutting Table	<b>Set Table Top Reference</b> On the <b>Cutting Table</b> , execute the <b>Table Top</b> <b>Reference</b> wizard.
<b>Start Spindle Warm Up</b>	<i>Adjust Tool Height</i>
On the <b>Cutting Table</b> , a <b>Spindle Warm Up</b>	On the <b>Cutting Table</b> , execute the Adjust <b>Tool</b>
sequence is executed.	<b>Height</b> wizard.

Start Vacuum Cleaner Vacuum Cleaner on/off control.	<i>Material Measurement</i> On the <b>Cutting Table</b> , a <b>Measure Material</b> <b>Thickness</b> sequence is executed.
<i>Identify Tools</i> On the <b>Cutting Table</b> , execute a <b>Tool</b> Identification sequence.	Vacuum Zones Select Vacuum Zones suitable for <b>Opened</b> Job.
	<b>Direct Commands</b> Select functions for immediate execution on the <b>Cutting Table</b>

Note: For daily use, some of these functions are easy available also from Machine Panel.

## 5.3.9 Advanced

The following menu items are available:	
Materials and Boards	Backup Configuration
Functions to maintain a list of available <i>Materials and Boards</i> .	Initiate a <b>System Backup</b> .
Cutting Keys	Restore Configuration
Functions to maintain <b>Cutting Keys</b> .	Initiate a <b>System Restore</b> .
Manage Presets	Log Options (Ctrl+Alt+Shift+L)
Functions to maintain Import Presets.	Configure the Log Options available.
Configure Tools	
Functions to <i>Configure Tools</i> to be used in Layers.	

# 5.3.10 Help

Menu Bar->Help

5 ESKO 😪

The following menu items are available:

User Manuals F1	Knowledge Base
i-cut Production Console User Manual online	Buy accessories online
Kongsberg Table User Manual online	About i-cut Production Console
Online Support	License Manager

# 5.4 My Jobs List

Isoa Production Conscie      Tite Edit View Selection Job Layer Curv      My Jobs BP007 and +		-		-	ESKOO
Hand Biological Control Contro			Yee.Dest		
Add Remove Create Job 0	1				
10411c Vector Zones Table top refere	E La	+ P?		Since start. Spindle power. Measured rotations: Material thickness:	

My Jobs List is a file list showing jobs you have imported into iPC. It can be seen as a "to do" list.

A preview of the selected file is displayed in the **Selected Job Preview** window.

**My Jobs List** is available in two different views; **Compact View** and **Extended View**, selected from (1):

Switch to Compact View	Select Compact View	
Switch to Extended View	Select Extended View	

## 5.4.1 Compact View



Each file is identified by an icon showing the geometry and its filename. In addition, **Job Size** and **Last Modified** is available.

## 5.4.2 Extended View

Switch to Compac	t View						
File	Full Filename	Due Date	*	Customer	Job Size	Material	Material Thickn
REIN.acm	D:\jb_files\REIN				270 x 270 mm		
Eboxmc.acm	D:\jb_files\Ebox				600 x 410 mm		
Geometry Test Reg.acm	D:\jb_files\Geom	10.10.2011		Esko-Graphi	640 x 440 mm	M-26/125	
BP097.ard	D:\jb_files\BP09				540 x 420 mm	M-32/200	
frkanter aom	D:\b_fies\frkart				730 x 1100 mm		

Each file is identified by it's file name.

In addition, the following columns are available:

- File name and file path
- Due Date
- Customer
- Job Size
- Material
- Material Thickness

- Design Date
- Designer Name
- Flute Direction
- Matrix if this job require a matirx function
- Modification Date

This information (metadata) is fetched from the Input File.

If the information is available or not, depends upon if the CAD system / Job Preparation software used supports such data.

5 ESKO 😔

If a job is saved using the iPC .cut format, the metadata are stored as part of the .cut file.

#### Sort by Column

Double-click a Column header will sort the file list by the column content. Another double-click will sort the content in opposite order.

#### **Modify Columns displayed**



Select columns to be displayed.

### 5.4.3 Select a File

Select a Job in My Jobs List



#### Single Click

The file is selected, available for:

• My Jobs Actions functions (1).

5

#### • Options Bar (2)

A preview of the selected file is shown in the **Selected Job Preview** window (3).

#### **Double Click**

From the selected file, a new **Job** is created, shown as a separate **Job Tab**. The same function is achieved using the **Create Job** button in **My Jobs Actions**.

### 5.4.4 My Jobs Actions

The following entries are available:

Add	Add a job to <b>My Jobs List</b> .
Remove	Remove the Selected Job from My Jobs List.
Open	Open the Selected Job in My Jobs List.
Open	The new <b>Job</b> is shown as a separate <b>Job Tab</b> .
	The same function is achieved by doubleclicking the Job in My Jobs List.
<b>*</b>	The following Actions are available:
*	Add
	Add a job to <b>My Jobs List</b> .
	Add Nested Layout
	Add Nested Layout to My Jobs List.
	<b>Nested Layout</b> is prepared in a separate dialog.
	The result can be saved to My Jobs List.
	Edit Nested Layout
	Edit the selected Nested Layout
	Open
	Open the Selected Job in My Jobs List.
	Remove Job (Del)
	Remove the selected <b>Job</b> from <b>My Jobs List</b> .
	Remove Unreferenced Jobs
	Jobs in <b>My Jobs List</b> where the corresponding file is missing, will be removed
	from <b>My Jobs List</b> .
	Sort Jobs
	This function is available in <b>Compact View</b> only
	Sort My Jobs List by:



•	Added Date
•	Name
•	Modified Date
•	Size
•	Due Date
•	Ascending
•	Descending

# 5.4.5 Options Bar



The following toolbar entries are available:

Switch to Table View	Preview of Selected File is shown inside a Cutting Table view.
Switch to File View	Preview of <b>Selected File</b> fills the window.
Import Preset: Import Preset:	From the drop-down menu, select the <i>Import Preset</i> to use.
<u>View Preset</u>	Open the View Import Preset dialog showing selected Import Preset.

# 5.5 Opened Job



A Job is identified as a separate tab including the actual file name on Job Tabs (1).

You can have several **Jobs** opened, all identified with its own tab.

A preview of the selected Opened Job is shown in the Layers View / Production View window (3).

You can edit a Job using the available Toolbar functions (2).

You can edit a **Job** while another job is executed on the **Cutting Table**. In this way, you can prepare next **Job** for execution.

During execution, a **Job** is locked for editing.

A Job contains two main groups of information; Layers Setup and Production Setup.

## 5.5.1 Open a Job

You create a Job from My Jobs List:



Creating an empty **Job** is available as:

E	Menu Bar->File->New Job.
	A new, empty <b>Job</b> is created.

### 5.5.2 Select a Job



i≣ My Jobs	REIN.acm	× BP09	7.ard ×	
Layer	s	Productio	Retup	0
Cutting Key: <u>n</u>	one			
•		1	ъ т.	
			* 🔊	
Tool: Cre	ase 0		-	
Depth: 🔆	0 mm   ‡		0 mm	
Speed XV:	50 m/min			

Jobs are selected using the Job Tabs. The selected Job Tab is highlighted.

## 5.5.3 Close a Job

Closing a **Job** is available from:

	Menu Bar->File->Close Job.
	Opened Job is closed.
×	Job Tab->Close.

If the Job to be closed has been modified, a Save As dialog appears.

The Job will be saved in the .cut - format regardless the format of the Input File.

In My Jobs List, the new .cut file will replace previous version.

## 5.5.4 Ready for Execution



To prepare a **Job** for execution, complete **Layers Setup** (1) and **Production Setup** (2).

To simplify this task, use **Cutting Keys** (3) as described in next chapter.

	Layers Setup and Production Setup are properly set.
<b>▼</b>	The <b>Job</b> is ready for execution.
•	This <b>Job</b> is not properly prepared for execution.
$\circ$	Click on the text to get more information.
▲ Job is ready for production with warning(s).	This <b>Job</b> is ready, but you should check the warnings.
	Click on the text to get more information.
	The <b>Job</b> is checked for the following, potential error conditions:
	<ul> <li>A big curve, typically a rectangle, is included in the Camera / Regmark Layer.</li> </ul>
	<ul> <li>The Regmark Layer is not the first Layer in the Layer List.</li> </ul>
	• The Job contains two Regmark Layers.
	• A Cut Layer is placed before a Crease Layer.
	Non Reverse operation Layers are placed before     Reverse operation Layers.

In the Properties Bar (4), you find the status indicator for Job ready:

# 5.6 Opened Job, select Cutting Key



i-cut Produc	tion Cons	ole			
<u>F</u> ile <u>E</u> dit	<u>V</u> iew	Selection	<u>J</u> op	Layer	<u>C</u> urves
i≣ My Job	s BP	9097.ard	×		
La	yers		Proc	luction S	etup
Cutting Key:	<u>none</u>				
•			1	1 6	5 C
	e			4	*
Tool:	Crease (	)			
Depth:	0 mm	ļ‡	↔ (	) mm	
Speed XY:	50 m/min	I			

After a new **Job** is created, no **Cutting Key** is selected, unless it is specified in the selected **Import Preset**.

Cutting Key:	Leave <b>Cutting Key</b> = None to run <i>without using <b>Cutting Key</b></i> .
	Press none to open the Cutting Key selection dialog

5

# 5.7 Opened Job, Layers Setup



iPC organizes all geometry and registration data into **Layers** and assigns a unique set of options to each **Layer**.

When importing a file, iPC separates the contents into Layers.

The separations are defined by the Import Mapping.

Layers defines tools, tool parameters and registration types.

When you run a job, iPC will produce that job based on the order, selection and configuration of your **Layers**.

All Layers for an Open Job are located in Layer Setup:

5 ESKO😔

# 5.7.1 Layers Tab



1 - Cutting Key	6 - Layer Name
2 - Layer Actions	7 - Expand / Collapse
3 - Selected Layer	8 - Show / Hide Layer
4 - Edit Layer Button	9 - Layer Display Color
5 - Tool Icon	10 - Layer Order

#### Expand / Collapse



# 1 - Selected Layer is highlighted and expanded

A sub-set of **Tool Parameters** are displayed in the **Layer**.

The number of parameters will change, depending upon the actual tool selected. For more information, see below.

#### 2 - Not selected Layer is compressed

A sub-set of **Tool Parameters** are displayed in the **Layer**.

#### 3 - Layer is collapsed

Layer is collapsed, showing just the Layer Name

### Layer Window

• •	Crease	*
Tool:	Crease 1541	•
Depth: 📫	2 mm   ‡  👫	2 mm
Speed XY:	50 m/min	

	Layer Display Color Color used when the Layer geometry is displayed in Layers View.
	Click to open the <b>Color Selection</b> dialog.
•	Show / Hide Layer
	Indicates if this <b>Layer</b> is visible, and thereby included or not, see <i>Include a Layer</i> .
	Single Layer View
	Press <b>Alt</b> + this icon to display only this <b>Layer</b> in <b>Layers View</b> .
▼	Expand Layer.
•	Collapse Layer.
*	Edit Layer Button
*	Invoke the <i>Edit Layer</i> dialog. All Layer parameters are available for edit.
	Tool Icon showing the tool currently assigned to this Layer.
	The <b>Tool</b> is mounted on the <b>Cutting Table</b> .
	Tool Icon showing the tool currently assigned to this Layer.
	The <b>Tool</b> is currently not mounted.
Tool:	Select Tool
1001.	From the drop-down list, select <b>Tool</b> to be used for this <b>Layer</b> .
<u></u>	Specify <b>Tool Depth</b> .
+	Increase the value to go deeper into the material.
1	Specify <b>Tool Depth along Flute</b> .
	Specify Tool Depth across Flute.
\$	Edit Layer Button



	Invoke the <i>Edit Layer</i> dialog. All <b>Layer</b> parameters are available for edit.
Speed X/Y	Specify execution speed for this Layer.
?	No <b>Tool</b> is currently assigned for this <b>Layer</b> . Use the <b>Select Tool</b> function to specify tool to use.

# 5.7.2 Select Layer

A Layer is selected by a Mouse Click inside the surrounding frame:

ø		1	Ľ	rg (	7 C
				¢	
Tool: Cr	rease 0				
Depth: 📲 0 r	mm	Depth: 🖶	0 mm		
Speed XY: 50	m/min				
				\$	
Tool:	serPointer				•
Speed XY:	50 m/min	2			

A selected **Layer** is identified by a highlighted frame.
### 5.7.3 Include a Layer



- 1 Include/exclude all Layers
- 2 Include/exclude this Layer

Click the button to change state:

0	Enable Layer
•	Layer is included in Opened Job.
	The geometry belonging to this Layer is visible in Layers View.
	The geometry belonging to this <b>Layer</b> will be included in the output processing.
	Layer is excluded.
	The geometry belonging to this Layer is not visible in Layers View.
	The geometry belonging to this Layer will not be included in the output processing.
Alt +	Press Alt + Enable Layer
$\mathbf{O}$	This Layer is included, all other Layers are excluded.
	Press a second time to include the <b>Layers</b> again.

### 5.7.4 Layer Sequence

The execution sequence on the **Cutting Table** is determined by the **Layer Order**, starting from the top of the list.





You can re-arrange the execution sequence by moving Layers up or down:

- 1. Select the actual Layer.
- 2. While you keep the Left Mouse Button down, move the Layer up or down.
- 3. When at wanted position, release the Left Mouse Button.

### 5.7.5 Edit Selected Layer

₽	Opened Job->Layers Tab->Edit Layer
⇒	Menu Bar->Layer->Edit Layer

Layer <u>N</u> ame:	Crease		Layer Color
Туре:	Crease	•	
Tool:	Crease 1541	•	
Registration Type:	From Production Setup	•	
Speed X/Y:	50 m/min		
Acceleration:	100		
Depth flute dependation	ant		
Depth: +	2 mm   ‡	ж	2 mn
Reverse operation			
		ОК	Cancel

The content of the Edit Layer dialog will change, depending upon selected Tool.

For Milling tool parameters, go here

#### Layer Name

Enter the name you want for the Layer.

Depth, Flute Dependant

The original name is derived from the <b>Input File</b> and the <b>Import Mapping</b> .	If enabled, you can specify <b>Depth Across</b> and <b>Depth Along</b> flute independently.		
Layer Type Select <i>Layer Type</i> .	Depth: Specify Tool Depth. Increase the value to go deeper into the material.		
<b>Tool</b> From the drop down list, select the tool to use when this <b>Layer</b> is processed. Note: Tools above the horisontal line are currently available on the machine.	Depth Along Specify Tool Depth along Flute. The value can be entered as: • xx mm • xx in • xx % Depth limitations		
<b>Registration Type</b> From the drop down list, select the wanted <b>Registration Type</b> . For details, see <i>Registration</i> .	Depth Across Specify Tool Depth across Flute. The value can be entered as: • xx mm • xx in • xx % Depth limitations		
<b>Speed X/Y</b> Specify the execution speed for this <b>Layer</b> .	<b>Reverse Operation</b> Specify if this <b>Layer</b> should be executed on the reverse side of the sheet.		
Acceleration Specify the acceleration to be used as a % - value of maximum acceleration available.	Layer Color         Select the color to use when this Layer is displayed in Layers View.         Press the Layer Color bar to open the Color dialog.		



### 5.7.6 Layer Types

Layer Types are used by Cutting Keys and some Advanced Job menu features.

**Layer Type** is a property of a **Layer**, typically defining which operations (cut, crease, etc) to perform on a layer.

Layer Type is assigned to a Layer during Import Mapping, based upon certain properties in the Input File, like Layer Name, Color or Line Type.

Some design applications can also define the Layer Type directly.

Alternatively, the Layer Type can be selected in the Edit Layer dialog.

### Layer Types

The following Layer Types are available:

- Unknown
- Cut
- Crease
- Partial Cut
- Perf Cut
- Bevel Cut
- V-notch
- Plot
- Kiss Cut

- Drill
- Regmark
- Braille
- Crease Across Grain
- Reverse Crease
- Reverse Crease Across Grain
- Wash Out
- Engraving
- Free use 1, 2,3

### 5.7.7 Add new Layer

⇒	Menu Bar->Layer->Add Layer
	Opened Job->Layers Tab->Add Layer

Layer <u>N</u> ame:	New Layer		Layer Color
Туре:	Unknown	•	
Tool:		•	
		QK	Cancel

Note: Do not use this entry to create a Regmark Layer.

### Layer Name

Enter the name you want for the Layer.

## Layer Type

Select Layer Type.

### Tool

From the drop down list, select the tool to use when this **Layer** is processed. Note: Tools above the horisontal line are currently available on the machine.

### Layer Color

Select the color to use when this **Layer** is displayed in **Layers View**. Press the **Layer Color** bar to open the **Color** dialog.

The **Add Layer** dialog box will change depending upon the **Tool** selected. To fill in the other parameters for the **Layer**, see *Edit Layer*.

### 5.7.8 Add Regmark Layer

Menu Bar->Layer->Add Regmark Layer...

41

# 5 ESKO 🕄

dd Regmark Layer		X
Name: Regmark22		<u>O</u> K <u>Cancel</u>
Coordinates are:		
Distance from Corner of \	Nork Area	
Distance from Corner of E	Enclosing Rectangle	
Add	x	Y
Add Top <u>L</u> eft:	X 12,7 mm	Y -12,7 mm
▼ Top <u>L</u> eft:	12.7 mm	-12.7 mm
<ul> <li>✓ Top Left:</li> <li>✓ Top Right:</li> </ul>	12,7 mm	-12.7 mm
Top Left: Top Right: Bottom Left:	12.7 mm 12.7 mm 12.7 mm	-12.7 mm -12.7 mm -12.7 mm

Normally, the position of the Registration Marks is included in the Input File.

If, for any reason, you have **Input Files** without **Registration Mark** information, you can use the **Regmark Layer** to specify the size and position of **Registration Marks** relative to the corners of the job.

Note: Registration Marks created this way are always circular.

### Name

Enter the Name you want for the Layer.

#### **Coordinates are Absolute**



The coordinates for the **Registration Marks** are specified in the same coordinate system as the geometry.

### Coordinates are Distance from Corner of Work Area



The coordinates for the **Registration Marks** are relative to corner of the **Work Area**.



### Coordinates are Distance from Corner of Enclosing Rectangle

The coordinates for the Registration Marks are relative to the corner of the enclosing rectangle.

<b>Top Left</b> Select if a top left <b>Registration Mark</b> should be used. Enter coordinates for the <b>Registration Mark</b> .	<b>Top Right</b> Select if a top right <b>Registration Mark</b> should be used. Enter coordinates for the <b>Registration Mark</b> .
Bottom Left	Bottom Right
Select if a bottom left <b>Registration Mark</b> should be used.	Select if a bottom right <b>Registration Mark</b> should be used.
Enter coordinates for the Registration Mark.	Enter coordinates for the Registration Mark.
<b>Regmark Size</b> Enter the size of the <b>Registration Mark</b> .	

### 5.7.9 Copy Layer and Curves

**1.** Select the **Layer** you want to copy.



**2.** The copy function is available as:



### 5.7.10 Copy Layer, no Curves

- 1. Select the Layer you want to copy.
- 2. The copy function is available as:



Menu Bar->Layer-> Copy Layer Without Curves

Opened Job->Layers Tab->Copy Layer Without Curves

### 5.7.11 Remove Layer

- 1. Select the Layer you want to delete.
- 2. The delete function is available as:



### 5.7.12 Remove Empty Layers



Menu Bar->Layer->Remove Empty Layers...

All Layers without curves will be removed.

## 5.8 Opened Job, Production Setup



### 5.8.1 Number of Copies

⇒	Opened Job->	Production Setup
l	Layers	Production Setup
Copies:	1	Table 1: 1 copies
Quality:	Accuracy	Spe 
		<i></i>

### Copies

Specify Number of Copies to produce.

Table

5



Displays the **Job Layout** on *Table 1* (X x Y)

- X Number of Copies along X.
- Y Number of Copies along Y.

### 5.8.2 Quality

#### Accuracy

The performance is optimized to achieve maximum accuracy.

#### Speed

The performance is optimized to achieve maximum speed. Less accuracy is a possible consequence.

### **5.8.3 Material Handling**

Opened Jol	b->Production Setup->N	Naterial Handling
✓ Material Handling		
<u>T</u> able Preset:	Park After Table Manu 👻	
Eeed to front of table		
Sheet Feeding Length:	0 mm	
Pre-load Sheets:	1	
Skip table if registration	n mark is not found	
Skip Table <u>A</u> fter:	20 seconds	
<u>M</u> aterial Measurement:	Optimized measurement -	
Function groups:		
Table Preset		
Material Feed		
Skip Table		
Material Measureme	ent	

### Table Preset

**Table Preset** defines some basic behaviour of the system.From the drop-down list, select one of the **Table Presets** available.For more information about **Table Preset**, go *here*.

### Material Feed Functions

Note: These features are available only when **Sheet Feed Table Preset** is selected.

#### Feed to front of table

### ΗW



Automatically feed sheets to the front of the table.

The feeding length is calculated using the **Table to Feeder** distance and the **Width** parameters in the **Options** dialog.

Notes: This function is for Sheet Feeder operations only.

#### **Sheet Feeding Length**





Sets the distance your device will feed the sheet(s) when using Sheet Feeder.

Setting the value properly ensures minimum feed time. The **Feed Length** is usually approximately equivalent to the sheet length or slightly larger.

If multiple sheets are on the table at one time, the length may be set slightly smaller.

Multiple sheets on the table maximizes vacuum hold-down.

Note: This function is for **Sheet Feeder** operations only.

#### **Pre-load Sheets**



ΗW



Specify the number of sheets to be loaded at the start of your production.

Use this function when you have **Multiple Sheets** on the table, and you need to load more than one sheet before production start.

### Skip Table Functions

Note: These features are available only when Sheet Feed or Roll Feed Table Preset is selected.



#### Skip Table if Registration Mark is not found

If the **Registration Mark** is not found, iPC will automatically skip the **Table** during **Sheet Feed** or **Roll Feed** productions.

The **Skip Table** feature allows iPC to run with less human intervention by automatically avoiding production breaks due to mis-loaded sheets or damaged **Registration Marks**. Note: If **Registration Mark** is not found on two successive sheets, the execution will stop.

#### **Skip Table After**

Entering a number of seconds in the **Skip Table After** field delays the skipping of the table. Use this function to provide some time for manual correction.

### Material Measurement

Decide how to carry out the Material Thickness measurement.

From the drop-down list, select:

#### **Optimized Measurement**

- If No Registration material is measured in two opposite corners of the material.
- If Registration material is measured in the position of the first Registration Mark.

#### **Measure at Laser Position**

The material is measured in current **Laser position**. Successive sheets are measured in the same postition. Note: This function is available when **No Registration** is selected only.

### 5.8.4 Registration



Registration Types

Opened Jol	o->Production Setup->R	egistration->Registration Type
▼ Registration		
Registration Type:	None -	
Compensation:	•	
Search Area:		
Ask Confirmation for First	Mark:	
Adaptive registration Accuracy	Speed	

From the drop down list, select wanted **Registration Type**: *None*, *Registration Marks*, *Edge Recognition*.

Note: If the **Opened Job** includes a **Regmark Layer**, the **None** alternative is not available.

For more information, see *Registration Types*.

### No Registration Marks

No Registration, the Job is executed at the position of the selected Reference Point + Offset, if any.

Use Registration Marks

Read Registration Marks.



### **Compensation Types**

### Select from the following Compensation Types:

- Move Job
- Placement
- Register Curve
- Register Layer
- Linear Compensation
- Full Compensation

For more information, see Compensation Types.

### Search Area

### НW

Different ways of Registration Mark search is available:



### Manual

The center of every **Registration Mark** is defined manually using the arrow keys on your keyboard and a live camera image or **Laser Pointer**.



### Center Only

iPC attempts to locate each **Registration Mark** automatically. If it is unable to locate a mark, you are prompted to manually position the camera using the arrow keys on your keyboard. iPC will only recognize the intended **Registration Mark** if it is near the center of the camera image.



#### Normal

This option is nearly identical to **Center Only**, except that the **Registration Mark** doesn't need to be near the center of the camera image for iPC to recognize it.

As long as the mark is completely within the camera image, iPC will automatically reposition the camera directly over the center of the mark before reading its position.



#### Extended

If the **Registration Mark** is not completely within the camera image, iPC expands the field of view by moving the camera to up to four additional overlapping positions around the original image.

Ask Confirmation for First Mark



For the first Register Mark in each Job, you will be asked for confirmation.

### Adaptive Registration

Select this option to optimize Register Mark read, focusing on:

#### Accuracy

Read all Registration Marks available in order to achieve maximum accuracy.

#### Speed

Minimize the number of **Registration Marks** used in order to achieve maximum speed. Less accuracy is a possible consequence.

Will take effect from the second **Table** of a job.

### Use Edge Recognition

Use Edge Recognition to find correct job position.

<ul> <li>Registration</li> </ul>				
Registration Type:		Edge Recognition 🗸		
Sheet Position:	↦	0	mm	Reset
	1	0	mm	
Check <u>E</u> dge Distance:		200	mm	
Check Direction:			6	

#### **Sheet Position**

Specify the distance from **Selected Reference Point** where the camera should search for the sheet corner.

#### **Check Edge Distance**

Specify the measuring distance to be used.

#### **Check Direction**

Select which direction to measure:



#### Corner and X

**Sheet Corner** and a position **Check Edge Distance** from corner in X-direction is detected.



Corner and Y

**Sheet Corner** and a position **Check Edge Distance** from corner in Y-direction is detected.



ESKO 😚

Corner, X and Y

**Sheet Corner** and a position **Check Edge Distance** from corner in both X and Y-direction is detected.

Use Corner only

Sheet Corner only is detected.

### 5.8.5 Position



### **Reference Point**

Select the Reference Point to use.

### Move Job to Reference Point



The lower left corner of the surrounding rectangle of current **Job** will be placed in selected **Reference Point**.

### Offset

Reset

If you want to place the job with an offset to selected Reference Point, add proper:

1	- X offset values

- Y offset values

Offset values are set to zero.

#### **Update Automatically**

This is a function for **Jobs** containing **Registration Marks**. The **Job Position** is updated after each **Job**: A modified start position for one **Job** will be used as start position for the next **Job**.

### 5.8.6 Step and Repeat

Opened Job->Production Setup->Ste	p and Repeat
Copies: 6 Table 1: 6 copies Accuracy 1 Speed	
Position     (Main Reference Point)	
✓ Step and Repeat	
2 III 3 Update Copies	
25,4 mm 25,4 mm 560,4 mm ↓ 430,4 mm	
Number of Copies along X.	<b>Number of Copies</b> along Y.
Gap between copies along X.	Gap between copies along Y.
Step size between copies along X	Step size between copies along Y.
Update Copies Copies field (1) is updated by Number of Copies along X mulitplied with Number of Copies along Y.	

Notes:

• You enter either Gap or Step size.



### 5.8.7 Tool Head Parking

I Job->Production Setup->	Tool Head Parking	3
k position		
⊨ þ mm		
1 0 mm		
	k position ↓ ↓ ↓ mm	▶

Specify **Park Position** after **Job** finished.

If current **Production Setup** contains a **Park** command, the machine will move to the specified **Park Position**.

Ρ	Drag to set <b>Park Position</b> In <b>Table View</b> , place the <b>Mouse Pointer</b> on the <b>Park</b> icon, press <b>Left Mouse</b> <b>Button</b> and drag the icon into wanted <b>Park Position</b> .
$\mapsto$	Set Park Position Enter X-coordinates for Park Position
1	Enter Y-coordinates for Park Position
	Coordinates are relative to Main Reference Point.
	Coordinates are relative to lower right of the <b>Job</b> .
	Coordinates are relative to upper right of the <b>Job</b> .

## 5.9 **Toolbar**



Toolbar content will change depending upon if you work in Layers Setup or Production Setup:

Function	Layers Setup	Production Setup
Zoom Tool	х	x
Zoom In	x	x
Zoom Out	x	x
Fit to Job	x	x
Fit to Table	x	x
Edit Points	x	
Show Curve Directions	x	
Show Curve Points	x	
Show Tool Path	х	x
Vacuum Zones		x
Park Position		x
Show Table Rulers		x
Show Reference Point		x
Bounding Box	Х	x
Show Rulers	x	

### 5.9.1 Zoom Tool





By the mouse, define a **Zoom** area.

### 5.9.2 Zoom In

⇒	Menu Bar->View->Zoom In
⊕ <b>、</b>	Toolbar->Zoom In
⇒	Ctrl+Add

Click to **Zoom** in.

### 5.9.3 Zoom Out

⇒	Menu Bar->View->Zoom Out
$\Theta_{\mathbf{k}}$	Toolbar->Zoom Out
⇒	Ctrl+Minus

Click to **Zoom** out.

### 5.9.4 Fit to Job

⇒	Menu Bar->View->Fit to Job
	Toolbar->Fit to Job
⇒	Ctrl+0

**Opened Job** will fill Layers View / Production View.

### 5.9.5 Fit to Board

<b>*</b>	Toolbar->Fit to Board
⇒	Ctrl+Shift+J

Opened Job will fill the board displayed in Layers View / Production View.

### 5.9.6 Fit to Table



Cutting Table including the Opened Job will fill Layers View / Production View.

### 5.9.7 Edit Points



### Enter Edit Point Mode.

On selected curve, the Curve Points are highlighted, available for edit.

### **5.9.8 Show Curve Directions**





Show **Curve Direction**. An arrow at the start of each curve indicates **Curve Direction**.

### **5.9.9 Show Curve Points**

ESKO ()

5



All Curve Points are highlighted.

### 5.9.10 Show Tool Path



Use this function to visualize the **Tool Path** of a **Milling Tool**.

### 5.9.11 Vacuum Zones

⇒	Menu Bar->View->Vacuum Zones
++ ++	Toolbar->Vacuum Zones

Current Vacuum Zone configuration is shown in Layers View / Production View.

### 5.9.12 Park Position



Menu Bar->View->Park Position

Р	Toolbar->Show Parking Point
P	Current <b>Park Position</b> is shown in Layers View / Production View.

### 5.9.13 Show Table Rulers

⇒	Menu Bar->View->Table Rulers
	Toolbar->Show Table Rulers

Cutting Table Rulers are shown in Layers View / Production View.

### 5.9.14 Reference Point



### 5.9.15 Bounding Box

⇒	Menu Bar->View->Bounding Box
	Toolbar->Show Bounding Box



i-cut Production Console



The **Bounding Box** for the **Opened Job** is displayed.

### 5.9.16 Show Rulers



Rulers are shown in Layers View / Production View.

## 5.10 Properties Bar

i-cut Production Console		00
		ESK00
III My Jobs EPOIS and × EP097 and ×		C Shot
Layers Production Setup		
Copies: 13 Table 1.1 copies		
Quality: Accuracy Devel		
Material Handling (ParkAterTable)		
* Registration		
Registration Type: None •		
Compensation 4		
Adaptive registration Accuracy Speed		
Position (Main Reference Point)		
Step and Repeat     (1 x 1)		
Tool Head Parking (0 mm, 0 mm)		
10412b	Tatal See 30 x 607 mm Flate Seal Directors 🚍 🔹 👎	

From the **Properties Bar**, the following information is available, either in **Layers View** or **Production View**:

#### **Curves:**

Number of curves in **Opened Job** 

### Points:

Number of curve points in Opened Job

### Size:

The size of **Opened Job** (X  $\times$  Y).

This is the size of one copy of the Job; not influenced by Step and Repeat values.

#### **Total Size:**

The size of **Opened Job** (X x Y). This is the size of of the complete **Job**; including **Step and Repeat**.



Current Mouse Pointer position (X) relative to the selected Reference Point.

Y: ←

Current Mouse Pointer position (Y) relative to the selected Reference Point.

### 5.10.1 Flute/Grain Direction



Normally, the Flute Direction is specified in the Input File.

Manually, the Flute Direction is altered from: Properties Bar->Flute Direction drop-down menu.

## 5.11 Machine Panel





Machine Panel provides information about the Job currently executed on the Cutting Table.

The overall status of Job Execution is displayed as:

### Edit Job / Idle Mode - job preparation



Error Mode - error, execution has stopped.

iPC Message Box will provide more information.

### 5.11.1 Machine Panel Views

It is possible to configure how the Machine Panel is displayed on the screen:



i-cut Production Console

5



### **Position at Right**







### Maximize

_				
i i i i i i i i i i i i i i i i i i i		Select vacuum zones	0	Start spindle warm up
	Ŧ	Set table top reference	¥	Clean table
	<u>):</u>			Measure material thickness
i i i i i i i i i i i i i i i i i i i	18		J?	identify tools
				а

### 5.11.2 Machine Panel Functions

The **Machine panel** functions available will change depending upon the status of the system. The following states are defined:

### **Execution Mode**

• Executing

#### Idle Mode

- Material Replacement
- Stop
- Job finished

### Error Mode

- Error
- Error/Pause
- Safety stop
- Regmark not found

### Executing



- 1 Name of file being run.
- 2 Status of Current Job
- Inner circle Current Table
- Outer circle Current Job

### 3 - Stop Production dialog

Stops production after **Current Table**. Modify Job is then available.

### 5 - Number of Copies

Number of copies produced/Total number of copies requested.

### 6 - Producing copy

Copy number currently prodused

#### 9 - Finish all copies

Estimated time until all requested copies are completed.

### 10 - Current table

Estimated time until **Current Table** is completed.

Note: Not for first **Table**, visible for successive **Tables** only.

- Time elapsed since start of Current Job
- Spindle Power
- Measured rotation speed (RPM)
- Measured material thickness



### **Material Replacement**



1 - Name of file executed.

### 2 - Status of Current Job

- Replace material.
- Press Start to continue.

#### 4 - Start Production dialog

- Produce remaining copies.
- Restart from current Table
- Restart all.

#### 5 - Number of Copies

Number of copies produced/Total number of copies requested.

#### 6 - Producing copy

Copy number currently prodused

#### 8 - Machine Panel Toolbar

#### 11 - Performance information

- Time elapsed since start of Current Job
- Spindle Power
- Measured rotation speed (RPM)
- Measured material thickness

Note: This state is entered when:

- If **Park after Table** is enabled and the **Table** is completed.
- Execution stop after this Table is enabled.

### Stop



### 1 - Name of file executed.

### 2 - Status of Current Job

- Production stopped by operator.
- Machine moved to Park Position.

### 4 - Start Production dialog

- Produce remaining copies.
- Restart from current Table
- Restart all.

### 5 - Number of Copies

Number of copies produced/Total number of copies requested.

### 7 - Start on copy

Copy number that will be produced if you continue execution.

### 8 - Machine Panel Toolbar

#### 11 - Performance information

- Time elapsed since start of Current Job
- Spindle Power
- Measured rotation speed (RPM)
- Measured material thickness

Note: This state is entered when:

- If Stop is pressed twice
- Execution is stopped from Machine Panel.



### Job finished

Produced: duobox2010.Cut	1
	2
Finished production.	
<ul> <li>Image: Image: Image:</li></ul>	8
Since start: 5:09 Spindle power: Measured rotations: Material thickness: 0.3 mm	11
•=	103050

1 - Name of file executed.

**2 - Status of Current Job** Job is completed.

#### 8 - Machine Panel Toolbar

- Time elapsed since start of Current Job
- Spindle Power
- Measured rotation speed (RPM)
- Measured material thickness

### Error



1 - Name of file executed.

### 2 - Status of Current Job

Information about the error condition.

**3 - Stop Production dialog** Stops production.

8 - Machine Panel Toolbar

- Time elapsed since start of Current Job
- Spindle Power
- Measured rotation speed (RPM)
- Measured material thickness

### Pause



1 - Name of file executed.

### 2 - Status of Current Job

- Production paused by operator
- Press Start to continue.

### 3 - Stop Production dialog

Stops production after **Current Table**. Modify Job is then available.

#### 5 - Number of Copies

Number of copies produced/Total number of copies requested.

### 6 - Producing copy

Copy number currently prodused

8 - Machine Panel Toolbar

- Time elapsed since start of Current Job
- Spindle Power
- Measured rotation speed (RPM)
- Measured material thickness

### Safety stop



Regmark not found



#### 1 - Name of file executed.

### 2 - Status of Current Job

Machine stop due to safety error. Information about the error condition.

### 3 - Stop Production dialog

Stops production.

8 - Machine Panel Toolbar

- Time elapsed since start of Current Job
- Spindle Power
- Measured rotation speed (RPM)
- Measured material thickness



-=

### iPC Pause functions



10305d

ESK0 😳
#### Stop in Execution Mode



#### Stop when in Pause



When we press Stop while in Pause:

Stop production after this Table:

• System enters Idle Mode

• Modify job is available.

- System enters Idle Mode
- Modify job is available.

### 5.11.3 Machine Panel Toolbar



#### Vacuum Zones







#### Select Vacuum Zones suitable for Opened Job.

Proper selection is important to achieve the best possible material hold down.

#### Intelligent Vacuum Control

**Vacuum Zones**, suitable for the **Opened Job**, are automatically selected, based upon the size of the job (**Bounding Box**).

#### Table Top Reference



On the Cutting Table, execute the Table Top Reference wizard.

The table top level measurement in current Laser Pointer position is updated.

Measure on top of Cutting Underlay; no material.

#### Adjust Tool Height



On the Cutting Table, execute the Adjust Tool Height wizard.

5

#### Camera View



ΗW

Enter the Camera View dialog for manual camera picture inspection.

For more information, go here.

#### Spindle Warm Up



НW

On the Cutting Table, a Spindle Warm Up sequence is executed.

#### **Start Vacuum Cleaner**



### ΗW

Vacuum Cleaner on/off control.

For machines with **Milling Tool** installed.

May be used for manual dust removal after job execution.



#### **Material Thickness Measurement**



Menu Bar->Machine->Material Measurement

Machine Panel->Material Thickness

On the Cutting Table, a Measure Material Thickness sequence is executed.

Material thickness measurement is done as part of Job Execution.

This function is typically used when you need to know the thickness of the material before you start the job.

Measured thickness is displayed in the Status part of the Machine Panel.

#### **Identify Tools**



On the Cutting Table, a Tool Identification sequence is executed.

Use this after the insertion of a new tool.

### 5.11.4 Machine Panel Statusbar



#### Since start

Elapsed time since **Job** start, in secs.

### Spindle power Current Milling Spindle power usage, as a %-value of maximum.

Measured rotations Current Milling Spindle rotation (RPM).

Material thickness Measured Material Thickness (mm / in.)

# 5.12 Machine Connection



From Windows Toolbar, invoke Machine Connection.

For more information, go to Machine Connection and Configuration.

6 ESKO 😚

# 6. Before We Start

# 6.1 Introduction

In this chapter, we will describe some important concepts and parameters used in iPC that are essential in order to achieve optimal performance on your machine:

- Table
- Table Preset
- Registration
- File Preparation
- Import Presets
- Cutting Keys
- Configure Tools

# 6.2 About Table

It is important to understand the term Table used in this manual:

#### **Cutting Table**

Do not get confused by the term **Cutting Table**, which is the machine we use when processing our materials, as cutting, creasing, milling.

#### Table

The term Table describes the part of a job that fits into the Work Area of the Cutting Table.

#### Example 1

Ten copies of a printed or non-printed sheet is requested, only one sheet can be placed on the **Cutting Table** at a time.

Such a request will be executed as ten Tables.

Manual or automatic feeding will be initiated between each **Table**, depending on **Table Preset** selected.

A job is divided into two parts as it is longer than the table.

During execution, you complete the first **Table**. Then the material is fed forward to move the second part of the job into the work area. Then, the second **Table** is executed.

#### Example 2

A roll with printed decals should be cut.

The roll includes two columns of decals.

Three rows of decals fits within the Work Area of the Cutting Table.

In order to cut the roll, a Step and Repeat of 3 x 2 should be requested.

Each Table consist of 6 copies

When total **Number of Copies** is set to e.g. 100, a conveyor feed will be executed between each **Table**, given that a **Roll Feed Table Preset** is selected.



# 6.3 Table Presets

Table Preset defines some basic behaviour of the system.

A set of frequently used Table Presets are installed by default.

In addition, you can add and delete specialized factory made presets to suit your need.

#### Select Table Preset

Opened Job->Production Setup->Material Handling->Table Preset

#### **Maintain Table Preset**



Menu Bar->Edit->Options...->Production->Table Presets

#### **Table Presets**

The following Table Presets are installed by default:

### 6.3.1 Installed by default

Park after Table



Before starting, place the first sheet on the table top.

- 1 When Start is pressed, this will happen:
- Copy 1 will be produced, or
- The number of copies specified by Step and Repeat is produced.
- 2 Tool head will move to Park Position.
- 3 Material Replacement is displayed in Machine Panel .
- 4 Operator should replace material in same position, then press Start.

5 - Remaining copies will be produced in the same way until specified **Number of Copies** are produced.

Vacuum and Blow Back are switched on / off automatically as an integrated part of this process.

#### Park after Table, Manual Vacuum

Before start, place the first sheet on the table top.

1 - When *Start* is pressed, copy 1, alternatively the number of copies given by **Step and Repeat**, is produced.

- 2 Tool head will move to Park Position.
- 3 Material Replacement is displayed in Machine Panel.
- 4 Operator should replace material in same position, then press Start.

5 - Remaining copies will be produced in the same way until specified **Number of Copies** are produced.

Vacuum and Blow Back is manual, to be controlled by the operator from Operators Panel.

#### **Roll Feed**

#### ΗW

Conveyor solution is required.

First copy on the roll must be placed on the table top before starting.

1 - When *Start* is pressed, copy 1, alternatively the number of copies given by **Step and Repeat**, is produced.

2 - Traverse will move to the back of the **Cutting Table** to transport the conveyor and the roll forward. Feeding distance is defined by **Sheet Feeding Length**, alternatively fed to front of table if **Feed to front of table** is selected.

3 - Second copy is produced. (First regmarks will have to be identified manually unless step distance is specified correctly.)

4 - Traverse will feed next copy (Regmarks will now be identified automatically.)

5 - Sequence continues until specified Number of Copies are produced.

Vacuum and Blow Back are switched on / off automatically as an integrated part of this process.

#### Sheet Feed, Feed Before



Requires **Sheet Feeder** and conveyor.

Start without any sheet on the table top.

- 1 When *Start* is pressed
- The number of sheets defined by **Pre-load Sheets** (default 1) is loaded on to the table top by the **Sheet Feeder** and the conveyor + traverse.
- Feeding distance is defined by **Sheet Feeding Length**, alternatively fed to front of table if **Feed to front of table** is selected.

2 - First sheet, alternatively the number of copies given by **Step and Repeat** in Y direction, is produced while **Sheet Feeder** is picking up the next sheet. First regmarks has to be identified manually.

- 3 Traverse will move to the back of the table to transport the conveyor and the sheet forward.
- 4 Second copy is produced. Normally the regmarks are now found automatically.

5 - **Sheet Feeder** will simultaneously pick next sheet, but is, during first copies, learning when operation should start to present the sheet in due time.

- 6 Traverse will feed next sheet.
- 7 Sequence continues until specified Number of Copies are produced.

Vacuum and Blow Back are switched on / off automatically as an integrated part of this process.

#### MultiZone Production

•••••

See separate chapter.

### 6.3.2 Optional

**Roll Feed, Double Blow-back** 





Conveyor solution is required.

First copy on the roll must be placed on the table top before starting.

1 - When *Start* is pressed, copy 1, alternatively the number of copies given by **Step and Repeat**, is produced.

2 - Traverse will move to the back of the **Cutting Table** to transport the conveyor and the roll forward. Feeding distance is defined by **Sheet Feeding Length**, alternatively fed to front of table if **Feed to front of table** is selected.

3 - One extra Blow Back sequence is completed in order to get rid of wrinkles in the material.

4 - Second copy is produced. (First regmarks will have to be identified manually unless step distance is specified correctly.)

5 - Traverse will feed next copy (Regmarks will now be identified automatically.)

6 - Sequence continues until specified Number of Copies are produced.

Vacuum and Blow Back are switched on / off automatically as an integrated part of this process.

#### Sheet Feed, No Feed Before



Requires Sheet Feeder and conveyor.

Start with a sheet on the table top.

1 - When Start is pressed

2 - First sheet, alternatively the number of copies given by **Step and Repeat** in Y direction, is produced while **Sheet Feeder** is picking up the next sheet. First regmarks has to be identified manually.

3 - Traverse will move to the back of the table to transport the conveyor and the sheet forward. Feeding distance is defined by **Sheet Feeding Length**, alternatively fed to front of table if **Feed to front of table** is selected.

4 - Second copy is produced. Normally the regmarks are now found automatically.

5 - **Sheet Feeder** will simultaneously pick next sheet, but is, during first copies, learning when operation should start to present the sheet in due time.

6 - Traverse will feed next sheet.

7 - Sequence continues until specified Number of Copies are produced.

Vacuum and Blow Back are switched on / off automatically as an integrated part of this process.

#### Sheet Feed, No Feed Before, Double Blow Back



#### Requires Sheet Feeder and conveyor.

Start with a sheet on the table top.

1 - When Start is pressed

2 - First sheet, alternatively the number of copies given by **Step and Repeat** in Y direction, is produced while **Sheet Feeder** is picking up the next sheet. First regmarks has to be identified manually.

3 - Traverse will move to the back of the table to transport the conveyor and the sheet forward. Feeding distance is defined by **Sheet Feeding Length**, alternatively fed to front of table if **Feed to front of table** is selected.

- 4 One extra **Blow Back** sequence is completed in order to get rid of wrinkles in the material.
- 5 Second copy is produced. Normally the regmarks are now found automatically.

6 - **Sheet Feeder** will simultaneously pick next sheet, but is, during first copies, learning when operation should start to present the sheet in due time.

- 7 Traverse will feed next sheet.
- 8 Sequence continues until specified Number of Copies are produced.

Vacuum and Blow Back are switched on / off automatically as an integrated part of this process.

#### **Barcode Sheet Feed**

#### ΗW

Requires Sheet Feeder and conveyor.

As for **Sheet Feed**, but loading commands are different to cover for **Barcode** reading. To be used when each sheet in the stack includes a (potentially unique) **Barcode**. Please note! Automatic production by **Barcode** is currently not supported

#### Manual Sheet Feed, Feed Before

#### ΗW

Conveyor required, but no Sheet Feeder.

Start without a sheet on the table top.

- 1 When *Start* is pressed:
- The number of sheets defined by **Pre-load Sheets** (default 1) is loaded on to the table top by the conveyor and the traverse.
- The operator must be ready to present sheets for pickup at the rear of the machine.
- Feeding distance is defined by **Sheet Feeding Length**, alternatively fed to front of table if **Feed** to front of table is selected.

# 6 ESKO 😚

2 - First sheet, alternatively the number of copies given by **Step and Repeat** in Y direction, is produced.

3 - First regmark has to be identified manually.

4 - Traverse will move to the back of the table to transport the conveyor and the sheet forward. Feeding distance is defined by **Sheet Feeding Length**, alternatively fed to front of table if **Feed to front of table** is selected.

5 - Second copy is produced. Normally the regmarks are now found automatically.

6 - Conveyor + traverse simultaneously picks up next sheet presented by the operator, but is, during first copies, learning when operation should start to present the sheet in due time.

7 - Conveyor + traverse will feed next sheet.

8 - Sequence continues until specified Number of Copies are produced.

Vacuum and Blow Back are switched on / off automatically as an integrated part of this process.

#### Manual Sheet Feed, No Feed Before

### ΗW

Conveyor required, but no Sheet Feeder.

Start with a sheet on the table top.

1 - When Start is pressed

2 - First sheet, alternatively the number of copies given by **Step and Repeat** in Y direction, is produced. First regmarks has to be identified manually.

3 - Traverse will move to the back of the table to transport the conveyor and the sheet forward. Feeding distance is defined by **Sheet Feeding Length**, alternatively fed to front of table if **Feed to front of table** is selected.

4 - Second copy is produced. Normally the regmarks are now found automatically.

5 - Conveyor + traverse simultaneously picks up next sheet presented by the operator, but is, during first copies, learning when operation should start to present the sheet in due time.

- 6 Conveyor + traverse will feed next sheet.
- 7 Sequence continues until specified Number of Copies are produced.

Vacuum and Blow Back are switched on / off automatically as an integrated part of this process.

# 6.4 About **Registration**

### 6.4.1 Adding Registration Marks

In order to achieve perfect print to cut alignment, all printed jobs destined for finishing with your iPC device should contain **Registration Marks**.

By adding **Registration Marks** to both the print and cut files, you are providing iPC with the necessary information to register the **Cut Path** to the **Printed Graphic**.

The placement and total number of **Registration Marks** depends upon the required cutting tolerance and the predicted amount of distortion.

i-cut Layout is a software package from Esko that has functions to automate the process of adding **Registration Marks**.

The same algorithm is used in ai-cut; is a special plug-in for Illustrator<sup>®</sup> and CorelDraw<sup>®</sup>, available from Esko.

Using those tools greatly simplifies the process of adding **Registration Marks**, but you should still understand the basic concepts explained in this section.

For more information about ai-cut, go here.





Poor triangulation of distorted graphics with only Improved triangulation of distorted graphics with four **Registration Marks**.

Understanding the **Registration** capabilities of iPC will help you decide how many marks to add to your job, and where to place those marks. Review the **Registration Types** section of this manual for more information on **Registration**.

For the best possible compensation, **Registration Marks** should be placed around, and inside (if possible) the cut path in a triangular relationship to one another. Jobs with tighter cutting tolerances require more **Registration Marks**.

The more marks, the smaller each triangulated area becomes, and the more accurately iPC will be able to compensate for distortion in that area.

If there are specific areas within the job that are more critical than others, more **Registration Marks** should be added to those areas. It's difficult to accurately predict the amount of distortion that will occur in any printed job; therefore we suggest you always include more **Registration Marks** than you think you will need.

You can always remove unnecessary **Registration Marks** later in iPC, but once the job is printed it is impossible to add more **Registration Marks**.



Jobs longer than your cutting table will be divided and produced by iPC in sections. Adding **Registration Marks** along these divisions will improve registration and alignment of cut paths between sections.

### 6.4.2 Types of Registration Marks



Circle:	3 mm < D < 12 mm	1/8 in. < D < 1/2 in.	
Mask:	D >= d + 4 mm	D >= d + 5/32 in.	
Donut:	4 mm < D < 12 mm	5/32 in. < D < 1/2 in.	
	1 mm < T < D/4	3/64 in. < T < D/4	
Cross:	4 mm < D < 15 mm	5/32 in. < D < 19/32 in.	
	1 mm < T < D/4	3/64 in. < T < D/4	

iPC supports four types of Registration Marks; circle, mask, donut and cross.

The machine will search for Registration Marks and detect any of these automatically.

Thus, there is no function to specify type of **Registration Marks**.

A circle is the best choice for nearly all scenarios. If there is a high amount of reflection or insufficient contrast between the color of the printed **Registration Marks** and the background, a donut shape may provide iPC with a better regmark reading result.

#### Important to know about Registration Marks

These are the rules for interpreting a Regmark Layer:

- A closed contour is one Registration Marks with position in the geometric center.
- A curve with 3 points is a corner detection.
- A curve with 2 points is an edge detection.



If you have a simple cross made of two crossing lines in the input file, you will get an output that is unpredictable. It might be interpreted as two corners (A) or three edges (B).

Use a closed contour as specified above.

### 6.4.3 Compensation Types

The **Compensation Type** dictate how iPC will register and modify **Cut Paths** based on the information it collects from reading **Registration Marks**.

The following **Compensation Types** are available:



#### •

- Placement
- Register Curve
- Move Job
- Register Layer
- Linear Compensation
- Full Compensation

In order to complete the picture, we have included here also the description of two registration methods not using **Registration Marks**:

- No Registration Marks, use Ruler
- Edge Recognition

#### No Registration Marks, use Ruler



Sheet positioning against the **Ruler** ensures correct cut-out.



It is a pre-requisite that the graphics is correctly positioned relative to sheet corner.



#### Notes:

- It is a pre-requisite that the Cutting Table is equipped with Rulers.
- The offset from Reference Point to geometry must be known.
- This method is not recommended if the job contains graphics that the cut-out must align to.

#### **Edge Recognition**



**Sheet Position** is unknown, cut-out is wrong



Sheet Position is obtained by Edge Recognition



Cut-out is perfect

It is a pre-requisite that the graphics is correctly positioned relative to sheet corner.

#### Notes:

- The offset from sheet edge to geometry must be known (the bounding box of the job).
- A straight sheet corner is presumed.
- This method is not recommended, as there is no compensation involved.

#### Placement

This simplest form of **Registration** rotates and positions all curves in all layers as one. Size, shape and relative positioning of the curves all remain intact.



The position and rotation of the graphics is unknown



Using **Registration Marks** to obtain correct positioning.

#### **Register Curve**

Each curve is produced at the exact size and shape defined by the file, but registered individually from all other curves in the file; compensating for positional and rotational changes in the printed job.



The position and the rotation of the graphics is not known.



Using **Registration Marks** to modify the position and rotation of each curve individually.

#### Move Job

Specifically targeted for textile signage to fit inside a frame, which during finishing is nested together in a layout with other objects.

- Each curve keep the original size and shape.
- Each curve is moved individually based upon it's center of gravity and local distortion close to that specific curve.
- Each curve is rotated based upon overall measured rotation.



The position and rotation of the graphics is unknown



We are using Registration Marks to:

- Modify the position of each curve individually.
- Modify the rotation of each curve according to the overall calculated rotation for all curves.

Important to know about Move Job:

- You need bleed.
- Move Job is made to avoid a bad rotation of the first curve. If you use **Register Curve**, the rotation of the first curve is based upon the local **Registration Marks**. In case of bad spacing, the first curve might be rotated out of scope.
- Using **Move Job** ensures that the rotation of the first curve is aligned with the rotation of the other curves in the job.



#### **Register Layer**

Similar to Register Curve, this registration type compensates each Layer individually. All curves in each Layer will maintain exact size, shape and relative positioning.

#### **Linear Compensation**

This **Registration Type** offers the second highest level of compensation.

When Linear Compensation is selected, iPC applies an average compensation for each curve. The size, shape, offset and rotation of all curves are altered to compensate for linear distortion in the printed graphic. Linear Compensation is rarely used because Full Compensation provides superior registration and compensation, but is still included as an option.





unknown.

The position, rotation and size of the graphics is Using Registration Marks to modify position, rotation and scale of the cut-out.

#### **Full Compensation**

When selected, iPC adjusts the position of each point on every curve individually according the positions of the three Registration Marks closest to those points.

This feature compensates for all types of distortion, including: offset, scale, rotation, skew and compound distortion. Full Compensation offers the highest level of compensation available and provides the closest possible match of cut path to printed graphic.



Position and shape of graphics is unknown



Using Registration Marks to re-calculate the shape of the graphics.

6

### 6.4.4 About Compensation Types

One Registration Type is selected for each Job (Opened Job->Production Setup->Registration).

Jobs printed with large amounts of bleed or jobs that must maintain an exact overall size, or contain cuts that must maintain an exact relative size may require using **Placement**, **Register Curve**, **Register Layer**.

Just a few marks around the outer edge of each path or group of paths provide sufficient information for these **Registration Types**.

Jobs that require precise **Cut to Print Registration**, or precise outer border width should be produced with **Full Compensation**.

Unstable materials such as flexible or applied graphics also most often require **Full Compensation** for proper **Registration**.

Jobs produced with traditional printing methods, like screen printing, contains the greatest amount of distortion.

Digitally printed jobs generally contain less distortion, but accuracy varies greatly from printer to printer. Producing digitally printed jobs with tight tolerances still requires compensation, especially if the job is printed on a flexible substrate.

# 6.5 File Preparation for iPC

### 6.5.1 File Types

#### **iPC Input Files**

The following file types are available for iPC import:

- iPC files: .cut, .script, .nest.
- Curve files: .acm, .ard, .mfg, .dxf, .ai, .pdf, .cf2, .ds2.

#### .script

Output from the *i-script* work flow. Contains cut data separated from a graphics file. For more information, go *here*.

#### .nest

This file type contains a saved Nested Layout.

Adobe Illustrator<sup>®</sup> is widely used for file preparation, but any vector-based design or drafting software capable of outputting one or more of the compatible file types may be used.



#### **iPC Output Files**

.cut

A **Job** saved as a .cut file contains all settings made to the file. Thus, no **Import Presets** are active when importing such files.

Note: Often, i-script files use the extension .cut instead of .script.

### 6.5.2 Defining Cut Paths

Every job imported into iPC requires cut paths, which are vector curves made of line segments, arcs, Bezier points, etc. These paths are normally created or defined in your **Design Software**.

The cut quality of your finished jobs is the direct result of the quality of the cut paths you create. iPC has some basic tools for optimizing cut path quality and improving processing speed, but poorly drawn paths will produce poor cutting results.

The best cut paths are smooth curves that wrap perfectly around the simplest and most intricate details.

Poor cut paths consist of curves that wander in and out of registration, or rough curves made from an excessive number of points. Vectorization of raster graphics often generates poor curves that must be refined manually before cutting. To ensure proper registration between printed graphic and cut, each cut path and registration mark must be perfectly aligned to the associated graphic and registration mark in the print file.

Jobs generated from Structural Design Systems like ArtiosCAD will be optimized for best cutting quality and no additional optimization is necessary.

Normally the cut and print data are created at the same time and separated into two files before the job is produced. This file separation can be done manually before printing or, if the job is going to be digitally printed, the *i-script workflow* enables compatible RIP softwares to automatically separate the files before outputting to the printing device.

# 6.6 Import Presets

6

### 6.6.1 Using Import Presets

#### **Basic function**



We use **Import Presets** to automate the process of converting the geometry in the **Input File** into ready to cut curves in iPC **Layers**.

#### **Import Preset Options**



In addition to the basic mapping function, **Import Presets** can include also **Cutting Key**, **Optimization** and a **Description**.

Using this combination will automate the whole job of converting an **Input File** to a **Job** ready for execution.

6 ESKD 🕄

### 6.6.2 Import Preset and Cutting Key

**Import Preset Function** 

Input file		маррии	g Preset	 iPC Layers
ayer name	Test	Layer names	Layer type	Layer type
Crease Line		Crease	Crease	Perforation
	$\langle \rangle$	▼Perforation	Perforation	 
Perforation	$\mid$ $\times$	<b>√</b> Cut	Cut	Cut
		Everything else	Unknown	
Cut				generic  

This figure shows the basic operation of Import Preset.

The iPC Layers created by this process must be modified with tool settings.



Using Cutting Key, sample 1

In this case, the Input File content is organized into Layers.

Layer Names in the Input File are compared to Layer Names in the Import Preset.

The corresponding Layer Type is used to select the proper Cutting Key.

If properly prepared, the **iPC Layers** created by this process are complete, with tool selection and tool settings in place.

Input file	Mappir	ng Preset	Cutting Key	iPC	Layers
Tool Tes no ?		Layer type		Layer type	Tool setting
P1	→P1	Crease	Crease Perforation	Crease	Crease tool - speed 50 m/min - depth 75%
P2	P2	Perfor- ation	▼ Cut Reverse	<ul> <li>Perforation</li> </ul>	Knife tool - speed 50 m/min - depth 50%
P4	P3 Every- ►thing	Cut	crease	Cut	Knife tool - speed 100% - throughcut
	else	UNKIWI		Reverse crease	Crease tool - depth 75% - reverse crease
				▶ None	

Using Cutting Key, sample 2

In this case, the Input File content is organized using Tool numbers, used for ACM file format.

Tool numbers in the Input File are compared to Tool numbers in the mapping part of the Import Preset.

The corresponding Layer Type is used to select the proper Cutting Key.

If properly prepared, the **iPC Layers** created by this process are complete, with tool selection and tool settings in place.

### 6.6.3 View Import Presets



View Import Preset "Esk Preset	o Default" Name: Edito Default	×
Category General Mapping Cuting Key Optimize Curves	General Desorption: Esko factory default including: Esko default mappings for all file formats No Cutting Key Standard optimizing	
		Qose

Use this function to explore the content of selected **Import Preset**.

For information about the different parameters, see *Create...* 



### 6.6.4 Select Import Preset



Menu Bar->File->Open->Import Preset

**Options Bar->Import Preset** 

The selected Import Preset is used when reading the selected Input File.

### 6.6.5 Manage Import Presets

Menu Bar->Advanced->Manage Presets->Import Presets... X Manage Import Presets New... Create a new Import Preset. Import Presets For more information, go here. Esko Defaul <u>N</u>ew .... Test Preset View View/Edit View/Edit selected Import Preset. <u>C</u>opy... View button is available for all Esko Import Delete Presets. Edit button is available for all Self-defined Import Presets. Esko Import Presets are not available for editing. Copy... Create a new Import Preset based upon an existing one. Delete OK Cancel Delete selected Import Preset. Note: You are not allowed to delete any Esko Import Presets.

#### Create new Import Preset



Menu Bar->Advanced->Manage Presets->Import Presets->New...

Go through each **Category** to enter relevant information:

#### General

lame: Test Import Preset	
neres ingres i reads	
General Description:	
Test Import Preset	
	QK Cancel
	Description:

#### **Preset Name**

Enter the name of the new Import Preset.

#### Description

Enter a description.

The description is used to recognize the Import Preset for later use.

#### Mapping

Pre	set Name: Test Import Preset		
ategory	Mapping		
Seneral	File Type	Mapping Preset	View
Mapping Outting Key	ACM	Standard ArtiosCAD for Kongsberg	
Optimize Curves	ARD/MFG	ArtiosCAD Corrugated	
	CF2	Esko Default	
	DDES2	Esko Default	
	DXF	Esko default inch	
	PDF	Esko layer name based	
	i-script	Esko layer type and name based	

#### File Type

This is a list of supported **File Types**. Select the **File Type** to use and select **Mapping Preset**:

#### **Mapping Preset**

Open the drop down list to see all alternatives available. Initially, the factory default mapping is used for each file format. If you have created your own **Import Preset Mapping**, it will be available from this menu. For more information, go *here*.



#### View

View the selected Import Preset Mapping.

#### **Cutting Key**

F	reset Name: Tes	Import Prese	t.	
stegory	Cutting Ke	,		
Seneral Mapping	🔳 Use	Cutting Key		
Utting Key	Materia		ACM ~	
Optimize Curves	Thickne	55.	02mm *	
	Details:		MutiCut HP Miling v	
	Tgol:		BIT-MUS06-4006-50C1 -	
		BIT G43		
	V Kee	o original laye	er colors	
	Cre	te unmatche	ed layers	

#### **Use Cutting Key**

Enable and select a Cutting Key to combine Import Preset Mappings and Cutting Keys.

Using this combination correct will automate the entire process of reading an **Input File** and convert it to a proper **Layer** setting.

The link between Import Mappings and Cutting Keys is Layer Types.

The **Import Mapping** will result in a number of **Layers** with certain **Layer Types**. Selected **Cutting Key** also includes **Layers** with defined **Layer Types**. These two sets of **Layers** will be matched based on **Layer Types**.

#### **Keep Original Layer Colors**

If relevant, the Layer Colors from the Input File are kept.

#### **Create Unmatched Layers**

When this function is selected:

If the **Cutting Key** include **Layers** that is not populated from the **Input File**, selected mapping, these **Layers** are created as empty layers. Can be useful if geometry has to be moved between **Layers** after import.

When this function is disabled: Such data is ignored.

6

#### **Optimize Curves**

rie	set Name: Test Import Preset		
stegory	Optimize Curves		
Seneral Mapping Autting Key	Optimizing Type: St	andard 🔹	
Optimize Curves	Connect open curves	Maximum Distance:	0,1 mm
	Eeject small curves	Maximum Size:	0,1 mm
	Avoid overcuts	Minimum Angle:	15
	Set curve direction:	Counter Clockwise v	
	Invert curve direction	for inside curves	
	Move job to reference	e point	

Add Optimize Curves functions. For details, go here.

Please note that for **Import Presets** there are one more **Optimizing Type** available, called "No Optimization".

This option should be selected when the geometry is already optimized for cutting in the source application, typically CAD systems like ArtiosCAD.

#### Mapping Import Presets

Menu Bar->Advanced->Manage Presets->Mapping Presets...

age Mapping Presets		
Mapping Presets		
<ul> <li>ACM</li> <li>ARD/MFG</li> </ul>	<u>N</u> ew	
	<u>E</u> dit	
DXF     PDF	Delete	

+

From the list of supported **File Formats**, select actual format and press the **+** sign in front of the requested **File Format**.

The view is expanded to show all defined Mapping Presets for the selected format.

#### New...

Create a new Mapping Preset.

From the list of supported file formats, select actual format and press **New**... For more information, go *here*.

#### View/Edit...



Man	age Mapping Presets	×
	Mapping Presets	
	ACM	New
	default	
	MyACM-mapping	Edit
	ARD/MFG	
		<u>C</u> opy
	DDES2	Datas 1
	DXF	Delete
	PDF	

The Default Mapping Preset is available for viewing only.

To modify a default Mapping Preset, make a copy of it, edit and save it using a new name.

User Defined Mapping Presets are available for editing.

For more information, go here.

#### Сору...

Create a copy of an existing **Mapping Preset**. From the list of supported **File Formats**, select actual format and press **Copy...**.

For more information, go here.

#### Delete

Delete the selected Mapping Preset.

Create a new Mapping Preset

Menu Bar->Advanced->Manage Presets->Mapping Presets->New...

#### **Create a new Mapping Preset**

Manage Mapping Presets		
Mapping Presets		
<ul> <li>ACM default MyACM-mapping</li> <li>ARD/MFG</li> <li>CF2</li> <li>DDES2</li> <li>DXF</li> <li>PDF</li> </ul>	New           Edit	

From the list of supported File Formats, select actual format and press New ...

The new **Mapping Preset** will be added to the already existing **Mapping Presets** for the actual format.

6

#### **Edit Mapping Preset**

P-Number	i-cut Layer Name	i-cut Layer Type	New
1	-> 1	Crease	Duplicate
_	-> 3	■ 0x	
Everything els.	-> <do import="" not=""></do>		Move Up
			Move Down
			Berrove
			Tenore

**Mapping Preset** is basically a table of rules for how to convert the **Input File** into **iPC Layers**. There are different rules for different formats.

#### **Preset Name**

Enter a name for the new Mapping Preset.

#### New

Add a new line to the table.

#### Duplicate

Create a duplicate of selected line in the table in order to make a similar entry in the mapping table.

#### Move Up

Move selected line one step up.

#### Move Down

Move selected line one step down.

#### Remove

Remove selected line.

#### **Mapping Preset for different formats**





ACM format Mapping Preset	PDF format Mapping Preset (color based)
Using wildcards	Ignore text
When searching text fields, it is possible to use wildcards, as "Cut*".	Text in the Input File is omitted
·	Import trim box
	Specify if a trim box should be included.
	Trim box = bounding rectangle.
	i-cut Layer name
	i-cut Layer name for trim box.
	Trim box Layer type
	Layer Type for trim box.

General

Input File parameters will differ, depending upon the different file formats.

i-cut Layer Name Layer Name to use in iPC.

i-cut Layer Type Layer Type to use in iPC.

# 6.7 Cutting Keys



Menu Bar->Advanced->Cutting Keys

A specific setup of Layers can be saved for later re-use.

Such a data set is called a Cutting Key.

Each **Cutting Key** is identified by

- Material
- Material Thickness
- Details description
- Tool description

Please note that it is up to the user to decide which of these parameters to use and how. In particular, the **Details** parameters are designed for "free purpose".

Thus a list of Cutting Keys will look like this:

Material	Thukness	Details	Teol	Ceator	URL	Date
Foam Board - Soft	Gran	Oscillate Cut	420 Single Edge Knife	Hout	http://kouttools	07/14/2010 14:56:2
Foam Board - Soft	6mm	Oscillate Cut	VHM 11 K-Ke 42441626	EskaAtwork	htps://eskoln	08/17/2010 15:31.4
Folding Carton	200 gram priege	Kivle Cut (Single Edge) • Crease	216 Single Edge Krife = 3pt 15mm Crease	iout	htp://outrook	07/14/2010 23:41:3
Folding Carton	200 gram priegen	Kivle Cut (Single Edge) - Dease	T15 Single Edge Kinfe 42441212 + 3pt 15nm 34030858	EskaAnwork	htps://eskalin	08/17/2010 15:33.1
Folding Carton	400 gram priage	Krife Cut (Single Edge) + Dease	216 Single Edge Knife + 3pt 15mm Crease	Hout	http://louticols	07/14/2010 23 43 0
Folding Carton	400 gram priage	Krife Cut (Single Edge) + Crease	T16 Single Edge Kinfe 42441212 + 3pt 15mm 34030858	EskaAdwork	htps://eskolin	08/17/2010 15:33 2
Honeycomb Board	10mm	Ceciliate Cut	427 Single Edge Knife	Hout .	http://outtools	08/17/2010 16 45 5
Honeycomb Board	10mm	Ceciliate Cut	VHM 11 Kv/e 42441626	Eska Anwork	htps://eskalin	05/16/2011 11:38.4
Honeycomb Board	10mm	Oscillate Cut - Fold	VHM 11 Kvte 42441626 + TRZ 511-W 42440503	EskaAtwork	htps://eskolin	05/16/2011 11:39:1
ioneycomb Board	20mm	Oscillate Cut	429 Single Edge Kinfe	i-out	http://louticols	05/17/2010 16:48:1
Honeycomb Board	20mm	Ceollate Cut	VHM 24-023 Krife 42437293	EskoAtvolk	https://eskolin	05/16/2011 11:39:5

As seen from the illustration, a Cutting Key contains more fields than the selection fields.

The Layers parameters contained in a Cutting Key are not visible until the Cutting Key is applied to a Job

Use Cutting Keys to ensure uniform processing and repeatable quality of the products produced.

Using the features provided, you maintain a library of **Cutting Keys** for the substrates you most often produce.

iPC includes a standard library of **Cutting Keys** for common materials that may be edited and customized.

In addition, you can download new libraries from your iPC dealer.

### 6.7.1 Select Cutting Keys

Opened Job->Layers->Cutting Key	,
E My Jobs BP097.ard × Layers Production Setup Cutting Key: none	Click <u>none</u> to invoke <b>Cutting Key</b> selection dialog.
<ul> <li>✓ ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '</li></ul>	
Layers Production Setup	The <b>Cutting Keys</b> listed above the horisontal line are the <b>Favorite Cutting Keys</b> .
ACM, BIT-MUS06-4006-50C1 Folding Carton, point	See <i>below</i> for more details.
Crease Select Cutting Key by Attrivities	Select Cutting Key by Attributes
Tool: Add to Favorites	If the actual Cutting Key is not available
Save Cutting Key	among the <b>Favorites</b> , you can select by
Generic perf     ?       Tool:	Attributes.

#### **Select Cutting Key by Attributes**

Specify the different selection criterias in order to decide correct Cutting Key:

i≣ My Jobs	BP045.a	rd ×				
Layers Production Setup						
						]
Step 1: Select	Step 1: Select the appropriate material attributes:					
Material:	Folding Cart	on			•	]
Thickness:	200 gsm				•	
Details:	Static Knife	+ Creas	е		•	
Tool:	BLD-SF216	+ Creas	e Whe	el	-	
🔽 Keep or	iginal layer colo	ors		More i	nfo	
🔽 Create u	nmatched laye	rs				
Step 2: Select	the appropria	te laye	r types	:		1.
• •			₽	- 0	Â	
Layer Type: Regmark Tool: Camera						
					0	
•	Crease			\$	1	ш
Layer Type:	Crease				•	
Tool:				-		
Depth: 🐥	0 mm					
Speed XY:	50 m/min					
•	Cut			₽	?	

#### Material

From the drop down list, select the material you are about to process.

Note: If this list is empty, you have to import a set of **Cutting Keys** in order to continue (*Import Cutting Keys*).

#### Thickness

From the drop down list, select material thickness.

#### Details

From the drop down list, select the description that fits your job.

#### Tool

From the drop down list, select tooling.

#### **Keep Original Layer Colors**

When this function is selected: Layer colors used in the **Input File** are kept.

#### **Create Unmatched Layers**

When this function is selected:

If the **Cutting Key** include **Layers** that is not populated from the **Input File**, selected mapping, these **Layers** are created as empty layers. Can be useful if geometry has to be moved between **Layers** after import.

When this function is disabled: Such data is ignored.

✓	Layer Setup is accepted.
×	Layer Setup is cancelled.

If the Layer and Production Setup is as wanted, you are now ready to execute the job.

If your preferred configuration is not available as a **Cutting Key**:

- Manually edit current Layer settings to suit your need.
- You can as well change the Layer Type. Available Layer Types will be those included in selected Cutting Key.

- See Edit Selected Layer. •
- Save it as a new Cutting Key: •



Opened Job->Layers->Cutting Key->Save Cutting Key

Menu Bar->Advanced->Cutting Keys->Save as Cutting Key....

### 6.7.2 Favorite Cutting Keys



The Cutting Keys listed above the horisontal line are the Favorite Cutting Keys.

From the list, select the preferred Favorite

#### Select this Cutting Key

Press button to accept this Cutting Key.



#### Add to Favorite Cutting Keys

Select the Cutting Key as described above. Press the Cutting Key again to invoke the

#### **Remove from Favorite Cutting Keys**

Menu Bar->Advanced->Cutting Key->Manage

Original	Favorite Name	Material	Thickness	Details	Tool	Creator		Edit
1		Feam Beard	05mm	Vib. Knife +	BLD-SR6310	Esko		
V		Feam Beard	06mm	Vib. Knife	BLD-SR6310	Esko		Delete
		Foam Board	06mm	Vib. Knife +	BLD-SR6310	Esko		
V		Feam Board	12mm	Vib. Knife	BLD-SR6310	Esko		
1	Folding Carton, p	Folding Carton	200 gsm	Static Knife +	BLD-SE216 +	Fako		
1		Folding Carton	400 gsm	Static Knife +	BLD-S BLD-SF21	6 + Crease Wheel -	15mm - 3	Export
		Honeycomb	06mm	Vib. Knife +	BLD-SR6310	Esko		CAPON
		Honeycomb	10mm	Vib. Knife +	BLD-SR6310	Esko		Import
V		Honeycomb	16mm	Vib. Knife +	BLD-SR6310	Esko		
P**		Magnet	01mm	Rigid Material	BLD-DR8160	Esko Modifie		
		MDF	03mm	MultiCut HP	BIT-MUS06-4	Esko		
×.		MDF	06mm	MultiCut HP	BIT-MUS06-6	Esko		
		MDF	06mm	MultiCut Milling	BIT-MUS06-6	Esko		
1		MDF	12mm	MultiCut HP	BIT-MUS06-6	Esko		
1		MDF	12mm	MultiCut Milling	BIT-MUS06-6	Esko		
		MDF	20mm	MultiCut HP	BIT-MUS06-6	Esko		
1		Papercore Bo	06mm	Vib. Knife +	BLD-SR6310	Esko		
1		Papercore Bo	10mm	Vib. Knife +	BLD-SR6310	Esko	1	
1		Papercore Bo	16mm	Vib. Knife +	BLD-SR6310	Esko		
		Polycarbonate	01mm	Rigid Material	BLD-DR8160	Esko		
		Polypropylene	01mm	Rigid Material	BLD-DR8160	Esko		
1		PVC - Expan	01mm	MutiCUT HP	BIT-MUS06-3	Esko		
4		PVC - Expan	01mm	Rigid Material	BLD-DR8160	Esko		
		PVC - Expan	03mm	MutiCUP HP	BIT-MUS06-4	Esko		
V		PVC - Expan	03mm	MultiCut Milling	BIT-AUS06-4	Esko		
131		PVC - Exnan	03mm	Rinid Material	BLD-DR8160	Fskn		

Edit Cutting Keys	×			
Material Attrib	utes:			
Material:	Folding Carton			
Thickness:	200 gsm			
Detail:	Static Knife + Crease			
Tool:	BLD-SF216 + Crease Wheel - 15mm			
Name:	Show as favorite			
Show Info:	<ul> <li>Tool image</li> <li>Cutting Key text</li> </ul>			
Comments: BLD-SF216 G42441212 Crease Wheel - 15mm - 3 point G34030858				
OK Cancel				

- 1. Select the **Cutting Key** you want to remove from list.
- 2. Select Edit to enter the Edit Cutting Key dialog.

In the dialog, disable Show as favorite.

# 6.7.3 Create new Cutting Key

A new **Cutting Key** is created based upon **Opened Job**. Thus, to create a new **Cutting Key**, follow these steps:



- 1. Open the actual Job.
- 2. Complete Edit Layers settings to suit your need.
- 3. Save the setting as a new Cutting Key:

Omened			Kay Cave	Cutting Kay
Openeu	JUD->Layers	->Culling	ney->Save	• Cutting Key

Menu Bar->Advanced->Cutting Keys->Save as Cutting Key....

<u>M</u> aterial:	ACM	•	New Material	Save
Thickness:	02mm	-	New Thickness	Cancel
<u>D</u> etails:	MutiCut HP Miling	•	New Details	
Tgol:	BIT-MUS06-4006-50C1			
	BIT-MUS06-4006-50C1 G42451112		<ul> <li>Show Tool Image</li> <li>Show Cutting Key Text</li> </ul>	

<ul> <li>Material</li> <li>From the drop down list, select material to use.</li> <li>If actual material is not available:</li> <li>1. Click New Material.</li> <li>2. Enter the name of the new material.</li> <li>3. Click OK.</li> </ul>	<b>Show Tool Image</b> Select this option if you want to illustrate this <b>Cutting Key</b> alternative using an image. Browse for the image file.
Thickness From the drop down list, select material to use. If actual thickness is not available, click <b>New</b> <b>Thickness</b> and enter wanted thickness. Note: To avoid creating <b>Cutting Keys</b> for each material thickness, use a more general name.	Show Cutting Key Text Select this option if you want to describe in more detail the content or how to use this Cutting Key. Enter wanted text in the edit box.
<b>Details</b> From the drop down list, select the details description that suits your job. If not found, click <b>New Details</b> and enter wanted details description.	Save Click Save to create the new Cutting Key. All Layer parameters are saved as part of this Cutting Key.
<b>Tool</b> Enter a description of the actual tool configuration	

### 6.7.4 Update Cutting Key

To modifiy an existing **Cutting Key**, follow these steps:
- 1. Open a Job.
- 2. Select the Cutting Key to use.
- 3. Modify Layers to suit your need.
- 4. Apply the modifications (Opened Job->Layers->Apply)
- 5. Select the Cutting Key again.
- 6. Update the Cutting Key with the modified parameters:

Opened Job->Layers->Cutting Key->Save Cutting Key...

Menu Bar->Advanced->Cutting Keys->Save Cutting Key...

#### 6.7.5 Cutting Key Manager

Menu Bar->Advanced->Cutting Keys->Manage...

A list of all Cutting Keys available is displayed:

Parametre Bard         Ohm         Ve. Wei + V45         BLS SR310 + B.         Exist         10525/2011 12.93 4           Parametre Bard         Som         Ve. Kriet + V45         BLS SR310 + B.         Exist         10525/2011 12.93 4           Parametre Bard         Som         Ve. Kriet + V45         BLS SR310 + B.         Exist         10525/2011 13.005           Parametre Bard         Som         Ve. Kriet + V45         BLS SR310 + B.         Exist         10525/2011 13.005           Parametre Bard         Som         Ve. Kriet + V45         BLS SR310 + B.         Exist         10525/2011 13.005           PACE-Spanded         Ohm         Rigs Maeria Kriet BLS OR5105         Exist         10522/2011 13.035         Exist           VFC -Spanded         Ohm         Rigs Maeria Kriet BLS OR5105         Exist         10522/2011 13.035         Exist           VFC -Spanded         Ohm         Rigs Maeria Kriet BLS OR5105         Exist         10522/2011 13.035         Exist           VFC -Spanded         Ohm         Rigs Maeria Kriet BLS OR5105         Exist         10522/2011 13.033         Exist           VFC -Spanded         Ohm         Rigs Maeria Kriet BLS OR5105         Exist         10522/2011 13.033         Exist           VFC -Spanded         Ohm	Orginal	Material	Thickness	Details	Tool	Creator	Date		OK
ID         Pagestrase Board         Tome         Vel. XV6 - VLOS - III.0.561010 - III.         Exc.         1005200113.0005           ID         Pagestrase Board         Stem         Vel. XV6 - VLOS - III.0.561010 - III.         Exc.         1005200113.0005           ID         Pagestrase Board         Otm         Rigit Material XV6 - III.0.561101 - Exc.         1005202013.0005           ID         Polycoborke         Otm         Rigit Material XV6 - III.0.561101 - Exc.         1005202013.10.005           ID         Polycoborke         Otm         Rigit Material XV6 - III.0.56110 - Exc.         1005202013.10.005           ID         PC/C. Espacedo         Otm         Rigit Material XV6 - III.0.56110 - Exc.         1005202013.10.035           ID         PC/C. Espacedo         Otm         Rigit Material XV6 - III.0.561400         Exc.         1005202013.10.135         Exc.           ID         PC/C. Espacedo         Otm         Rigit Material XV6 - III.0.564400         Exc.         1005202013.10.435         IIII.0.564400         IIII.0.564400         IIIII.0.564400         IIIIII.0.564400         IIIIII.0.564400         IIIIIII.0.564400         IIIIIIII.0.564400         IIIIIIIIII.0.564400         IIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIIII		Papercore Board	06mm	Vb. Knfe • VI45	BLD-SR5310 + B	Esko	109/25/2013 12:59:44		
Polycatorize         OTmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/23/2013 12:53 13           Polycompolyce         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/23/2013 12:53 13           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/23/2013 13:02:39           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/23/2013 10:29           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/23/2013 10:39           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/23/2013 10:39           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/25/2013 10:39           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/25/2013 10:34           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/25/2013 10:34           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/25/2013 10:34           PX-C Expanded         Otmin         Rgd Meetral Kofe 8LD CR3150         Exists         105/25/2013 10:34	2	Papercore Board	10mm	Vb. Kn/e + V145	8LD-SR6310 + 8	Esko	109/25/2013 13:00:07		Cancer
Polycopylene         Otime         Right Meeting Vol.         BLO-PR31MD         Exists         109/22/03133022           PK-C-Deparked         Otime         MALCUT-PM Mail	1	Papercore Board	16mm	Vb. Krife • V145	BLD-SR6310 + B	Esko	H09/25/2013 13:00:25		
PIC - Expanded         Ohm         NALCUT HP Mail         BIT MUSDG-3006         Exist         105/25/031 10 19.29           VIC - Expanded         Ohm         Right Meet RVel         BLO R0110         Exist         105/22/031 10 19.59           VIC - Expanded         Ohm         Right Meet RVel         BLO R0110         Exist         105/22/031 10 19.56           VIC - Expanded         Ohm         MALCUT HP Mail         017 MUSDG-4006         Exist         105/22/031 10 19.56           VIC - Expanded         Ohm         MALCUT HP Mail         017 MUSDG-4006         Exist         105/22/031 10 19.56           VIC - Expanded         Ohm         MALCUT HP Mail         017 MUSDG-4006         Exist         105/22/031 10 19.57         Exist           VIC - Expanded         Ohm         Reg Meetric Kive         ELO R0150         Exist         105/22/031 10 19.27         Exist           VIC - Expanded         Ohm         Reg Meetric Kive         ELO R0150         Exist         105/22/031 10 19.27         Exist		Polycarbonate	01mm	Rgid Material Knfe	BLD-DR3150	Esko	F09/23/2013 12:59:13		
PIC - Espando         Ohm         Pigd Resent Kinfer BLD-DR3180         Exists         109/22/2013 13:03:55         Desc           PIC - Espando         Ohm         NAC/UHP Ma         IF14000F-0006	2	Polypropylene	01mm	Rgid Material Kni	8LD-DR8150	Esko	109/23/2013 13:00:29		
IV:         Espanded         Ohm         MACUP HP Mail.         017.401056-4006         Eske         105/25/201101956           IV:         Figure Additional Additectual Additectual Additiona Additectual Additional Additectual	1	PVC - Expanded	01mm	MUBOUT HP MA	BIT-MUS06-3006	Esko	109/25/2013 10:19:29		Edt
PV-C-Sparked Ohm NALCUP+PM. [FT:40056-4006. Elle 16952/301101956     PV-C-Sparked Ohm NALCUP+PM. [FT:40056-4006. Elle 16952/301101956     PV-C-Sparked Ohm Agu/MeestWe ELOF61150 Elle 16952/301130.45     PV-C-Sparked Ohm Agu/MeestWe ELOF61150     PV-C-Sparked		PVC - Expanded	01mm	Rgid Material Knfe	BLD-DR3150	Esko	109/23/2013 13:03:58		Dutate
PVC - Expanded         OBm         Rgid Material Kwife         BLD-DR3150         Editor         109/23/2013 13:04:59         Epote           8VC - Expanded         Omm         Material Kwife         BLD-DR3150         Editor         109/23/2013 13:04:59         Epote	1	PVC - Expanded	03mm	MUSCUP HP Ma	BIT-MUS06-4006	Esko	109/25/2013 10:19:56		Uelete
2 810 Emercial New March 10 Ma 817.011076.0112 Edua 109.05.011110.2023	1	PVC - Expanded	03mm	NubCut Miling	BIT-AUS06-4008	Esko	109/23/2013 13:04:35		
PVC - Expanded 06mm MutcUT HP M8 817-MUS06-6012 Esko F09/25/2013 10:20:23		PVC - Expanded	03mm	Rgid Material Knfe	BLD-DR3150	Esko	109/23/2013 13:04:59	U (	Epot
	1	PVC - Expanded	05mm	MURCUT HP MA	8IT-MUS06-6012	Esko	109/25/2013 10:20:23		

#### Edit

- 1. Select one Cutting Key by highlighting the actual line in the table.
- 2. Click the Edit button.
- 3. In the Edit Cutting Key dialog, update relevant information:

# 6 ESKD 😚



#### Material

Update material information.

#### Thickness

Update thickness information.

#### Detail

Update details description.

**Tool** Update tool information.

#### Show Tool Image

Update if you want to illustrate this **Cutting Key** using an image. Browse for the image file.

#### Show Cutting Key Text

Update if you want to describe this **Cutting Key** using text. Enter wanted text in the edit box.

Note: To edit the Layer Parameters, go to Update Cutting Key.

#### Delete

- 1. Select one Cutting Key by highlighting the actual line in the table.
- 2. Click the Delete button.

#### Export

Using a common set of **Cutting Keys** inside a company or between co-operating companies will standardize the production process and secure the quality of the products produced.

Use the Export function to distribute Cutting Keys used.

1. Select one or more Cutting Keys by highlighting the actual line(s) in the table.

- 2. Click the Export button.
- 3. You are asked for a destination folder and file name.

#### Import

For more information, see Import Cutting Keys.

#### 6.7.6 Import Cutting Keys



Use this function to:

- Include Cutting Keys received from co-operating sites.
- Import/include Cutting Keys provided by the supplier.

By default, Cutting Keys are stored in this folder:

C:\Users\UserName\My Documents\i-cut Production Console\CuttingKeys

Backup Cutting Keys files are stored in this folder:

C:\Users\UserName\My Documents\i-cut Production Console\CuttingKeyBackup

ting Key N	lanager	-					<b>×</b>
Original N	laterial	Thickness	Details	Tool	Creator	Date	OK Cancel
							Edt Delete
							Export Import

Select Import





#### **Replace Library**

Current set of **Cutting Keys** is completely replaced by the imported keys.

Update Library Existing Cutting Keys are updated. New Cutting Keys are added.

Expand Library Add only new Cutting Keys.

Existing Cutting Keys are kept unchanged.

#### Merge Library

All imported **Cutting Keys** are added to current set of keys.

In case of conflicts, the imported **Cutting Key** name is modified.

Enter Yes if ok



Original	Material	Thickness	Details	Tool	Creator	Date ~	ОК
	ACM (Dbond-Alu	2mm	Fold	Hispeed folding	EskoArtwork	105/31 ::	Cancel
1	ACM (Dbond-Alu	2mm	Miling - High Detail	3854 Router Bt. (	ieut i-XL	H05/31	Cancel
1	ACM (Dbond-Alu	2mm	Miling - High Detail	3862 Router Bt (	ieut i-XL	H05/31	
1	ACM (Dbond-Alu	2mm	Miling - High Detail	Multipurpose Bt (	EskoArtwork	H05/31	
V	ACM (Dbond-Alu	2mm	Miling - Low Detail	3880 Router Bt (	i-cut i-XL	H05/31	
1	ACM (Dbond-Alu	2mm	Miling - Low Detail	3888 Router Bt (	Hout HXL	H05/31	Edit
1	ACM (Dbond-Alu	3mm	Fold	Hispeed folding	EskoArtwork	H05/31	Delete
8	ACM (Dbond-Alu	3mm	Miling - High Detail	3854 Router Bt (	i cut Modified by:	H04/15	Deveve
1	ACM (Dbond-Alu	3mm	Miling - High Detail	3862 Router Bt (	ieut i-XL	H05/31	
V	ACM (Dbond-Alu	3mm	Miling - High Detail	Multipurpose Bt (	EskoArtwork	H05/31	Export
V	ACM (Dbond-Alu	3mm	Miling - Low Detail	3880 Router Bt (	Hout HXL	H05/31	Import
1	ACM (Dbond-Alu	3mm	Miling - Low Detail	3888 Router Bt (	Hout HXL	H05/31	angeons.
1	ACM (Dbond-Alu	4mm	Fold	Hispeed folding	EskoArtwork	H05/31	
<b>1</b>	ACM (Dbond-Alu	4mm	Miling - High Detail	3854 Router Bt (	i-cut Modified by:	F04/14	
1	ACM (Dbond-Alu	4mm	Miling - High Detail	3862 Router Bt (	icut i-XL	H05/31	
1	ACM (Dbond-Alu	4mm	Miling - High Detail	Multipurpose Bit (	EskoArtwork	H05/31	
1	ACM (Dbond-Alu	4mm	Miling - Low Detail	3880 Router Bt (	i-cut i-XL	H05/31	
V	ACM (Dbond-Alu	4mm	Miling - Low Detail	3888 Router Bt (	i-cut i-XL	H05/31	
1	Acrylic	10mm	Miling - High Detail	3874 Router Bt (	Hout HXL	H05/31	
	Acrylic	10mm	Miling - Low Detail	3880 Router Bt (	i out i-XL	H05/31	
191	Sanka	10mm	Million , Low Datal	2000 Douter Dr /	George Contraction	105/01	

The list of available Cutting Keys is updated.

#### 6.7.7 Global Cutting Keys



Menu Bar->Advanced->Cutting Keys->Global Cutting Keys...

Message	X
1	Cutting Key settings should be dealt with carefully. Changes might cause your iPC system to be unstable. Do you want to continue?
	Yes <u>N</u> o

Global Cutting	Keys Dialog	×
<mark>⊡ U</mark> se Globa <u>P</u> ath:	al Cutting Keys Browse Copy Global Keys To Local Copy Local Keys To Global	OK Cancel

Use Global Cutting Keys to standardize the workflow towards the Cutting Table.

Using the same **Cutting Keys** within a work group for instance, will ensure a common solution to common tasks.

#### **Use Global Cutting Keys**

Enable use of Global Cutting Keys.

Path

Browse for the global destination folder.

#### **Copy Global Cutting Keys to Local**

**Global Cutting Keys** will be copied to your local destination. Before copy, your current local **Cutting Keys** will be backed up.

#### **Copy Local Cutting Keys to Global**

**Local Cutting Keys** will be copied to your global destination. Before copy, the current **Global Cutting Keys** will be backed up.

#### 6.7.8 i-script Link

Menu Bar->Advanced->Cutting Keys->i-script Link...

#### Cutting Keys are key elements in iPC.



i-script Link	×
Cutting Key Name:	
	Edit
	<u>R</u> emove
	<u>о</u> к
	<u>C</u> ancel

Some RIP and layout applications allow you to include material names in the **i-script** files they generate for iPC.

When you open a file containing a material name in iPC, you are prompted to associate (link) that name to a specific **Cutting Key**.

Once the material name is associated, each time a file containing that material name is opened, the associated **Cutting Key** will be loaded automatically.

The **i-script** Link feature allows you to edit or remove these associations using the **i-script** Link dialog.

Current associations appear in the Cutting Key name list.

To edit or remove an association, select it, then click the Edit or Remove button.

Selecting **Edit** allows you to choose a **Cutting Key** using the standard Material/Thickness/Details/ Tool menus.

## 6.8 Configure Tools



Menu Bar->Advanced->Configure Tools



Use this function to maintain your Tool Settings.

The **Tool Settings** provided in this dialog will be used for the initial setting when tools are selected for the different **Layers**.

Initial settings are twofold:

- 1. Is the setting relevant for the tool
- 2. If yes, what should the default value be

Please note that these settings are carefully defined by the supplier for each tool, and should be changed by qualified personell only.

When used in a Layer, the Tool Settings can be modified to suit that particular job.

A modification of **Tool Settings** within a **Layer** will not modify the general **Tool Settings** maintained from this dialog.

The type and number of parameters in this dialog will change depending upon the selected tool.

We do not show the dialogs for each tools, but a list of parameters covering all tools is provided:

#### Name

From the drop-down list, select the **Tool** you want to edit. Note: In the drop-down list, all possible tools are shown. Normally, at a customer site, just a sub-set is available.

#### Туре

From the drop down list, select the **Tool Type** used for this **Tool**. For some **Tools**, correct **Tool Type** is required when using **Cutting Keys**.

#### Velocity

Specify the Execution Speed for this Tool.

#### Acceleration

Specify the Acceleration to be used as a % - value of maximum acceleration available.

#### Depth, Flute Dependant

If enabled, you can specify Depth Across Flute and Depth Along Flute independently.

#### **Depth Referenced from Top**





If enabled, depth is referenced from **Top of Material**. If disabled, depth is referenced from **Top of Cutting Underlay**.

#### Depth Along



Specify cutting/creasing depth **Along Flute** direction. Can be specified as % of **Material Thickness** or mm / inch.

#### **Depth Across**



Specify cutting/creasing depth **Across Flute** direction. Can be specified as % of **Material Thickness** or mm / inch.

#### **Tool Up Angle**

If a direction change is above this angle, the tool will be lifted in the corner. The following rules applies:

- Tool Up Angle is valid for knife tools only.
- Tool Up Angle is default 30 deg.

#### NOTE!

Tool Up Angle is 14 deg if:

- Tool is RotaCut knife.
- Tool has a Lag value.
- Tool has Circle Adjustment value.
- Tool has Width value.

#### Stop at Tool Select

Execution will stop when this tool is selected; waiting for operator intervention. In the **Edit Field**, add the text to be displayed when execution stops. If the **Edit Field** is emptly, a default text is displayed.

#### **Knife Overcut**

Add an offset to the **Start** and **End** point of a line. Use this function to achieve correct cut in corners. Both positive and negative values are allowed.

#### **Circle Adjustment**

Use this parameter to adjust the quality of a circle when cutting with knife. Increase/reduce the value to increase/reduce the radius of the circle. Use a test sample to verify optimal setting.

#### **Reverse Operation**

Specify if this layer should be executed on the reverse side of the sheet.

#### Multi-pass

See *Multi-pass Depth* for more information.

#### 6.8.1 Depth Control, Tools

For some tools, the maximum allowed depth is superviced:

ТооІ	Maximum allowed depth (mm/in.)
HD Crease	5 mm/0.2 in.
Crease Tool	5 mm/0.2 in.
MicroCut Tool	2 mm/0.08 in.
Drill Tool	2 mm/0.08 in.
Milling Tool	1 mm/0.04 in.

## 6.9 Materials and Boards



In **Layers View / Production View**, it is a prerequisite for correct display of job relative to the actual board, that the material and board information is correctly specified.



Use the shown dialog to select and maintain materials and boards available.

Notes:

- 1. For some functions, as Nested Layout, correct material information is mandatory.
- **2.** This function is not fully implemented yet.

Materials	List of defined materials.		
	Materials do not have size.		
Material Name	Name of selected material.		
Boards	List of defined boards.		
	Boards have size.		
	One material can have several boards.		
Board Name	Name of selected board.		
Length	Length of selected board.		
Roll Feed	Specify if this is a roll of material.		
Width	Width of selected board.		
Thickness	Thickness of selected board		
Structural direction	Select between:		
	None		
	Along Length		
	Along Width		
+	Add new material or board.		
-	Remove selected material or board		
Duplicate	Duplicate selected material.		

# 7. Get Started

Instructions about software installation is available in a separate chapter - *Install software*. Once installation is completed, iPC may be opened for the first time.



Launch the program using the **Desktop Icon** or **Windows Start menu**.

## 7.1 Start Up Sequence

If the PC is connected to a Cutting Table, follow this start-up sequence:

- 1. Ensure the Cutting Table is free from obstructions and ready to run.
- 2. Power up the Cutting Table according to the User Manual for the table.
- 3.

From Desktop, double-click the **iPC Icon**.

- 4. On the Cutting Table, complete the start-up sequence as described in the User Manual.
- 5. The iPC User Interface will now appear on the PC screen and you are ready to start.

## 7.2 Shut Down Sequence

Follow these steps to properly shut down your system:

- 1. Shut down the Cutting Table according to description in the User Manual.
- 2. Close iPC using Menu Bar->File->Exit.



## 8. Work Flow

There are three different ways to get ready for production:

- 1. Open an already prepared and saved cut file-> produce
- 2. Create a job using Esko default Import Preset.
  - Apply a **Cutting Key** or manually apply **Layer** information.
  - Optimize if necessary and produce.
- 3. Create a job with a customized Import Preset-> produce

The basic workflow is illustrated in this figure:

Add Input Files Input File My Jobs Lis Import Preset Cutting	Ready for Production Execution
	10122a

In the following chapters, each step is described.

## 8.1 File Import

#### 8.1.1 My Jobs List

#### Import Files to My Jobs List



⇒	My Jobs Actions->Add
⇒	My Jobs Actions->Actions->Add

Look in:	🎉 þ_fles		- 😳 🦻	• 🖽 🕫		
(An	Name	*	Date modified	Туре	Size	-
~	BP045.ard		24.04.2009 14:1	6 ARD File	16 KB	
Recent Places	BP096.ard		28.01.2010 16:3	4 ARD File	4 KB	1
	8P097.ard		28.04.2009 12:2	0 ARD File	18 KB	
2	🗟 Eboxmc.ac	m	01.02.2013 11:1	6 ACM File	4 KB	
Desktop	🔊 firkanter.a		08.04.2014 15:3		3 KB	
<b></b>	R Geometry		10.10.2011 12:5	-	6 KB	
<b>1</b>	MoreSqua	res.acm	26.06.2013 12:5		1 KB	
Libraries	Fle name:	i-cut job			- Add	
i 🌉	Files of type:	All Supported Files			<ul> <li>Cano</li> </ul>	el
Computer	Import Preset:	Sko Default			¥	
Network			efault including: appings for all fi	le formats	^ -	

#### **Import Preset**

Select Import Preset to use when importing selected Input File.

The different **Import Preset** selections available in the **File Open** dialog specifies different rules for how to transfer information from the **Input File** to the **iPC Job**.

The following Import Presets are included from factory:

#### Esko Default

Default mapping for all file formats. **Layer** based; layers in the **Input File** are converted to **Layer Types**. No **Cutting Key**. Standard **Optimizing**.

Esko - No Optimization Default mapping for all file formats. Layer based; layers in the Input File are converted to Layer Types. No Cutting Key. No Optimizing.

#### **Specify default Import Preset**

You can specify which **Import Preset** should be the default selection. For more information, go *here*.

#### **Create your own Import Preset**

You can create your own **Import Preset** as well as copy and modify the default setup. For more information, see *Manage Import Presets*.

#### **View Import Preset**

This is a link to the Edit Import Preset dialog.



#### My Jobs List Options



Several options are available to the files in My Jobs List:

- Different List Views
- Add or remove files from the list
- Sort by different parameters
- Different **Preview** alternatives
- Select Import Preset
- Create Job

For more information, see *My Jobs List*.

#### 8.1.2 Create Job

	Create Job	Ready for Production
	: 📕 Opened Job	Execution
(Cutting K	iey)	
		10122d



For more information, go here

## 8.2 Opened Job

Add Input File My Jobs List Create Job Opened Job Layers Setup Production Setup 10122	
Job Bar->Select Job	

The Job Tab for the Opened Job is highlighted:



#### 8.2.1 Layers View / Production View

A range of view possibilities are available to **Opened Job**:

- Define a **Zoom Area**
- Zoom In
- Zoom Out
- Make Job fill the window
- Make the **Cutting Table** fill the window
- Show Rulers
- Show Curve Direction

- Show Curve Points
- Show Tool Path
- Show Flute Direction
- Show Reference Point
- Show Cutting Table Rulers
- Show Vacuum Zones
- Show Park Position

#### 8.2.2 Opened Job Edit

A range of edit possibilities are available to **Opened Job**:

- Job Modifications edit the entire Job.
- Curve Modifications edit single curves.
- Curve Point Modifications edit single points.



## 8.3 Prepare for Production



Prepare for Production consist of two main tasks:

- Ensure the Layers Setup is proper.
- Ensure the Production Setup is proper.

#### 8.3.1 Layer Setup, manual

#### Not using Cutting Keys





#### **Edit Layers**

For each Layer, specify the Tool and Tool Parameters to use.

Note: Layer Type is not required when running without using Cutting Keys

For more information, see **Opened Job, Layers**.

### 8.3.2 Layer Setup using Cutting Key



#### Select Cutting Keys



Click <u>none</u> to invoke **Cutting Key** selection dialog.

The **Cutting Keys** listed above the horisontal line are the **Favorite Cutting Keys**.

#### Select Cutting Key by Attributes

If the actual **Cutting Key** is not available among the **Favorites**, you can select by **Attributes**.

#### Modify Layers

You can modify **Layer Setup**. For more information, see *Opened Job, Layers*.

#### 8.3.3 Production Setup





#### Number of Copies



**Opened Job->Production Setup->Copies and Quality** 



From this dialog, set:

- Copies specify number of copies to produce. More information.
- Quality select wanted performance. More information.

#### **Material Handling**



**Opened Job->Production Setup->Material Handling** 

#### НW

From this dialog, specify functions for **Conveyor Feed** operations:

- Table Preset Select the Table Preset function to use.
- Feed to front of table the sheet is moved to the front of the Cutting Table. (Table Preset dependant)
- Sheet Feeding Length specify the lenght to feed the material. (Table Preset dependant)
- **Pre-load Sheets** specify how many sheets to pre-load before execution start. (**Table Preset** dependant)
- Skip table if **Registration Mark** is not found specify to avoid unwanted stops. (**Table Preset** dependant)
- Skip Table After adding a delay allows the operator to fix the problem. (Table Preset dependant)
- Material Measurement decide how to carry out the measuring sequence.

For more information, go here.

#### Registration



From this dialog, specify:

• Registration Type - select to use Registration Marks or Edge Detection.

#### Use Registration Marks

- Compensation Type select Compensation Type.
- Search Area select the size of the area where the camera will search for Registration Marks.
- Ask Confirmation for First Mark on the first Registration Marks in a job, always wait for confirmation.
- Adaptive Registration Select if registration optimization is wanted; high Speed or high Accuracy.

#### Use Edge Recognition

- Sheet Position specify the distance from Main Reference Point to the surrounding rectangle for the job.
- Check Edge Distance specify the measuring distance to be used.
- Check Direction select which direction to measure.

For more information, go here.

#### Position

**Opened Job->Production Setup->Position** 

From this dialog, set:

- Reference Point select what Reference Point to use.
- Move Job to Reference Point regardless the reference point used in the actual job, place the job in selected Reference Point.
- Offset If there is an offset from selected Reference Point to the job, add values for X and Y.
- Update Automatically The Job Position is updated after each copy.

For more information, go here.

#### **Step and Repeat**

Opened Job->Production Setup->Step and Repeat

•<del>;</del>

From this dialog, specify the number of copies along X and Y to be laid out on one Table.

Specify Step or Gap values.

For more information, go here.



#### **Tool Head Parking**



**Opened Job->Production Setup->Tool Head Parking** 

Specify a park position after **Job** is finished.

For more information, go here.

## 8.4 **Save Job**

At any stage in the **Prepare for Production** process, you can save the **Opened Job** for later use:



Opened Job will be saved using iPC .cut file format.

It is recommended to save the job when any modifications to **Layers**, **Production Setup** or geometry is changed within iPC.

All relevant information is kept in the .cut format, which is not the case for any external format.

To open a saved Job File, use the standard File Open functions.

## 8.5 Running a Job



#### 8.5.1 Execute a Job



Execution will start if:

- The Cutting Table is up and running, ready for execution See Cutting Table User Manual.

- The Job is properly prepared See *Ready for Execution*.

#### 8.5.2 No Registration

These are the specific steps to follow to execute a Job not using Registration Marks:

- 1. The Job contains no Regmark Layer.
- 2. Place the Sheet of Material onto the Cutting Table.
- **3.** If you use a **Fixed Reference Point**, position the **Sheet of Material** correct relative to the reference point. If available, we recommend using **Table Rulers** for this purpose.
- 4. If User Defined Reference Point is used, ensure the reference point is correctly positioned on the sheet.

For more information, see Cutting Table User Manual.

#### 8.5.3 Reading Registration Marks



These are the specific steps to follow to execute a Job using Registration Marks:

- 1. The Job contains a Regmark Layer with Tool Type = Camera.
- 2. Registration using Registration Marks is enabled.
- 3. A proper Compensation Type is selected.



#### **Confirm Registration Mark**



Select between:

- Automatic camera detection
- Manual registration

It is important that the **Registration Mark** found on the material is the same as the one highlighted in **Job View** 

Jog to the correct mark, by keyboard arrows, or by **Operator panel**.

Confirm when correct mark is found.

$\checkmark$	Confirm that this is correct <b>Registration Mark</b> The same confirmation is available as:
	Enter from PC keyboard.
	• Start on <b>Operator Panel</b> .
	Move between Registration Marks
M	Move to the last <b>Registration Mark</b>
K	Move to the first <b>Registration Mark</b>

#### 8.5.4 Registration using Laser Pointer



If no camera is available, the Laser Pointer will be used for registration.

These are the specific steps to follow

- 1. The Job contains a Regmark Layer with Tool = Camera.
- 2. Registration using Registration Marks is enabled.
- 3. A proper Compensation Type is selected.

Laser Pointer will be used as pointing device.

#### 8.5.5 Edge Recognition

#### **\_\_\_\_**

Opened Job->Production Setup->Registration->Registration Type->Edge Recognition

These are the specific steps to follow to execute a **Job** using **Edge Recognition**:

1. The Job has a defined offset from Sheet Edge to geomety (surrounding rectangle).

The distance is entered as Production Setup->Position->Offset.

- 2. Registration using Edge Recognition is enabled.
- 3. For more information, go here.

# 9. Optimal Production Workflow



Standardize each step to achieve the **Optimal Production Workflow**:

1 Import Input File Combine Import Preset and Cutting Key

2 Create Job Use Cutting Key to establish correct Layer configuration.

**3 Modify Job Setup.** The **Job** is ready for execution.

4 Ensure material is in place Sheets of Material - Vacuum hold down Roll Feed - Enter material Sheet Feeder - Load material

5 Press Start to execute

ESK0 😳

# 10. Edit Job, Advanced

All drawing and editing of curves is normally completed in the CAD system / Job Preparation software used before the file is imported to iPC.

Although iPC is not intended to be a design program, it does provide some basic tools for making minor corrections to imported files.

The tools are grouped into three different levels:



- Job Modifications
- Curve Modifications
- Curve Point Modifications

## 10.1 Job Modifications

The Job Modification functions will modify the Opened Job as one entity.

#### 10.1.1 Rotate 90 deg. CW

Menu Bar->Job->Rotate 90 deg. CW

**Opened Job** is rotated.

#### 10.1.2 Rotate 90 deg. CCW

Menu Bar->Job->Rotate 90 deg. CCW

Opened Job is rotated.

#### **10.1.3 Mirror Horizontal**



Menu Bar->Job->Mirror Horizontal



**Opened Job** is mirrored.

#### **10.1.4 Mirror Vertical**

Menu Bar->Job->Mirror Vertical

Opened Job is mirrored.

#### **10.1.5 Remove Double Lines and Sequence**



Menu Bar->Job->Remove Double Lines and Sequence

To explain this function, we use an example:





We have a **Job** that consist of a set of squares, programmed to be completed one by one.

Use the **Remove Double Lines and Sequence** function to:

- Improve cutting quality by removing double lines.
- Improve cutting quality by reducing number of corner passings.
- Increase overall performance by reducing tool operations and corner passings.
- Increase overall performance by reducing tool up movements.

Line segments along a straight line will be executed one by one.

All X-axis lines will be executed first.



Subsequently, the Y-axis lines will be executed.

## **10.1.6 Remove Double Lines and Join Across Gaps**



To explain this function, we use an example:



5 5 1 10006e We have a **Job** that consist of a set of squares, designed to be completed one by one.

Between each square, there is a gap.

Lines can be extended across gaps as this area is waste.

Use the **Remove Double Lines and Join Across Gaps** function to:

- Improve cutting quality by removing double lines.
- Improve cutting quality by reducing number of corner passings.
- Increase overall performance by reducing tool operations and corner passings.
- Increase overall performance by reducing tool up movements.

Line segments along a straight line will be combined into one, continous line.

All X-axis lines will be executed first.





Subsequently, the Y-axis lines will be executed.

Note: The maximum gap size for this function to work is 1 mm / 0.04 in.

#### **10.1.7 Optimize for Production**

#### Menu Bar->Job->Optimize for Production

In the Optimize for Production dialog, select Optimizing Type:

- Standard
- Sample Making

Note: Optimizing Type = No Optimization selection is available only as part of Import Preset.

# No Optimization

Use "No Optimizing" when curve sequences have been optimized before importing to iPC.

Any manual operations on the curves after import will therefore issue a warning. If you ignore this warning, the optimized curve sequencing might be lost.

#### Move Job to Reference Point



The lower left corner of the job will be placed in currently selected Reference Point.

Any offset from (0,0) used in the Input File is ignored.

Use this function to place the **Job** correctly on your material.

Pn	eset Name: Test Preset			
Category	Optimize Curves			
General Mapping Cutting Key	Optimizing Type: Stand	dard 💌		
Optimize Curves	Connect open curves	Maximum Distance:	0,1 mm	
	Reject small curves	Maximum Size:	0,1 mm	
	Avoid overcuts	Minimum Angle:	15	
	Set curve direction:	Counter Clockwise 👻		
	Invert curve direction for	inside curves		
	Move job to reference po	ant		

Standard Optimization is mainly used to optimize files used in a graphical workflow.

**Connect Open Curves** 



Curve segments that are close to each other are connected. Select **Connect Open Curves** to:

• Increase performance.

# 10 ESKO 🕄

• Improve cutting quality.

Specify d = Maximum Distance where curve connection is allowed.

#### **Reject Small Curves**

Small, freestanding curve elements are omitted.

Select Reject Small Curves to:

- Remove unwanted curves and stray points.
- Increase performance.
- Improve cutting quality.

Specify d = Maximum Size of a curve segment that can be omitted.

#### **Avoid Overcuts**



Lines will be cut and direction will be modified if the angle is above a specified limit. This to avoid visible knife overcuts.

#### **Set Curve Direction**



Specify an overall rule for curve execution direction.

Typical use:

Often, when milling, the left side of the path has a smoother surface compared to the right side. Use this function to optimize the quality of your product.

#### Invert Curve Direction for Inside Curves



Specify an overall rule for curve execution direction.

This is an extension to the **Set Curve Direction** function, see above.

If the blue part is your product and you want a smooth surface outside and inside, you have to invert the curver direction for the inner curve.

#### Move Job to Reference Point



The lower left corner of the job will be placed in currently selected Reference Point.

Any offset from 0,0 used in the **Input File** is ignored.

Use this function to place the **Job** correctly on your material.

#### Optimize, Sample Making

Optimize for **Sample Making** is normally used to achieve maximum cutting and creasing quality for **Corrugated** and **Folding Carton** designs.

Please note that:

- Most Sample Making operations will be applied on Layer Type Cut and Crease only.
- The relevance of this feature is dependant upon whether any optimization is performed during output from the CAD / Job Preparation software.

Features available in **Optimize for Sample Making** are similar to optimizing features in ArtiosCAD from Esko.

Select parameters in the following Categories:

# 10 ESKO 🕄

- General general optimizing functions.
- Round Slots functions to avoid tear in narrow slots.
- Overcut & Corners functions to avoid tear and overcut in corners.
- Over-Crease functions to improve performance during crease.

#### General

Optimize for Production			<b></b> X
Category Optimize Curves General Round Slots Overcut & Corners Over-Crease	Optimize Curves / General Optimizing Type: Sample Making Be sure your job contains layers of type "Cut" or "Crease" (ayer options). Curves will be optimized for sample making. Later manual operations on the curves will therefore issue a warning, If you ignore this warning, the optimized curve sequencing might be lost.		
	Crease Cut Back: Add layer for second cross Cut across gaps	2 mm ss grain tool	
	<u>Connect open curves</u> <u>Reject small curves</u>	Maximum Distance:	0,1 mm 0,1 mm
	Move job to reference po	int QK	Cancel

#### **Crease Cut Back**



Increased crease quality; avoid crease line outside wanted position.

d - distance to use when shortening the crease lines.

#### Add layer for second cross grain tool

A new Layer for Cross Grain Crease is created.

Adding a separate **Layer** allows for more flexible setup for crease along / across grain, as different tooling.

#### **Cut Across Gaps**



Increased performance.

#### **Connect Open Curves**



Curve segments that are close to each other are connected. Select **Connect Open Curves** to:

- Increase performance.
- Improve cutting quality.

Specify d = Maximum Distance where curve connection is allowed.

#### **Reject Small Curves**

Small, freestanding curve elements are omitted.

Select Reject Small Curves to:

- Remove unwanted curves and stray points.
- Increase performance.
- Improve cutting quality.

Specify d = Maximum Size of a curve segment that can be omitted.

#### Move Job to Reference Point





The lower left corner of the job will be placed in currently selected Reference Point.

Any offset from 0,0 used in the Input File is ignored.

Use this function to place the **Job** correctly on your material.

#### **Round Slots**

<b>Optimize for Production</b>				×
Category Optimize for Production Optimize Curves General Round Slots Overcut & Comers Over-Crease	Optimize Curves / Roun Select a round slot m $3 \downarrow j_{2}$ Continuous cut		$\begin{array}{c} 2 \\ 1 \\ 2 \\ 3 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1 \\ 1$	~
	]	<u> </u>	K Cancel	

**Round Slot Method, Continous Cut** 



Risk for material tear.

- d Tear Distance. The maximum distance where the Round Slot Method will work.
- a Tear Angle. The maximum angle where the Round Slot Method will work.

#### Round Slot Method, Reverse Last Line



Risk for material tear is reduced.



#### Round Slot Method, Cut "Short" Line Last

Risk for material tear is reduced.

#### **Overcut & Corners**



**Reverse at T-junctions** 

# 10 ESKO 🕄



Risk for material tear is reduced.

#### **Split Lines connection Corners**



Improve cutting quality in corners.

#### **Automatically Round Corners**



Improve cutting quality in corners.

r - Radius. Corner radius.

L - Length of adjacent line segments. This function will work on corners where L is above specified value.
#### **Over-Crease**

Optimize for Production	1	×
Category	Optimize Curves / Over-Crease	
Optimize Curves General Round Slots Overcut & Comers Over-Orease	Maximum lenght of cut to over-crease:	
	Maximum gap to over-crease:	
	3 mm	
	QK Cancel	1
		-

#### Maximum Length of Cut to Over-crease



A crease line will continue on top of a cut line.

Increased performance.

L - Maximum length of line element where this function will work.

#### Maximum Gap to Over-crease



A crease line will continue across a gap.

Increased performance.

L - Maximum length of gap where this function will work.



## 10.1.8 Move Job to Reference Point



Menu Bar->Job->Move Job to Reference Point

#### Move Job to Reference Point



The lower left corner of the **Job** will be placed in currently selected **Reference Point** + **Offset**, both defined in **Production Setup**.

Any offset from 0,0 used in the Input File is ignored.

Use this function to place the **Job** correctly on your material.

# 10.1.9 Move Open Curves to Separate Layer



Menu Bar->Job->Move Open Curves to Separate Layer

Some functions, as **Wash Out** using the **Milling Tool**, requires **Closed Curves** in order to operate properly.

Use this function to separate **Open Curves** from **Closed Curves**.

# 10.2 Curve Modifications

Curve Modifications are carried out on Selected Curve(s) in a Opened Job.

## 10.2.1 Select a Curve

Select one Curve



Using the **Mouse Pointer**, select the curve you want to modify. The **Selected Curve** is highlighted.

#### Select Multiple Curves



1) While Ctrl is active, use the Mouse Pointer to select the curves you want to modify.

2) Use the **Mouse Pointer** to draw a rectangle around wanted curves.

The Selected Curves are highlighted.

# 10.2.2 Move...



# 10 ESKO 😚



┝►	The indicated direction refers to the selected Layers View / Production View Orientation.
	If standard view is selected, this is the +X direction.
<b>_</b>	If standard view is selected, this is the +Y direction.

Select between Distance or Position:

#### Distance

Specify the distance to move the **Selected Curve(s)**.

#### Position

Specify the new coordinates (X and Y) for the Selected Curve(s).

#### Anchor

Select Anchor Point for the new coordinates (X and Y).

#### Center of Curve(s)

The coordinates specified are relative to the center of the Selected Curve(s):



#### Lower left of Curve(s)

The coordinates specified are relative to the lower left corner of the **Selected Curve(s)**:



#### **Keep Original**

The original, **Selected curve(s)** are kept unchanged. A copy of the **Selected curve(s)** is made, ready to be moved:



## 10.2.3 Jog Curves



Use Keyboard Arrows to move the Selected Curve(s):





# 10.2.4 Scale Curve

⇒		Menu Bar->Cu	urves-
⇒		Ctrl+T	
Scale			X
Scal	e		
	Ì	100	%
	H	100	%
Size	1 H	54,6 mm 168 mm	
I M Anch		Aspect Ratio	
<u> </u>	(eep Origi	inal <u>O</u> K <u>C</u> ancel	

Scale by Factor or Size:

#### Scale

Specify a scale factor to use when scaling the **Selected Curve(s)**.

Size

Specify the new, overall size for the Selected Curve(s).

#### Maintain Aspect Ratio

When checked, the X/Y relationship of the original curves is kept.

#### Extend from Center of Curve(s)

Scale is carried out relative to the center of the Selected Curve(s):



#### Extend from Lower Left of Curve(s)

Scale is carried out relative to the lower left corner of the Selected Curve(s):



#### **Keep Original**

The original, **Selected Curve(s)** are kept unchanged. A copy of the **Selected Curve(s)** is made, ready to be scaled.

## 10.2.5 Mirror Curve







Mirrors/flips the Selected Curve(s) according to the selected options.

Curves may be mirrored Vertically or Horizontally.

#### Vertical (up/down)

Specify vertical mirroring.

#### Horizontal (left/right)

Specify horizontal mirroring.

#### Center of Selected Curve(s)

Selected mirroring is carried out around the center of the Selected Curve(s):



Center of All Curve(s) Selected mirroring is carried out around the center of the All Curve(s):



#### Center of Work Area

Selected mirroring is carried out around the center of actual Work Area:



#### Keep Original

The original, **Selected Curve(s)** are kept unchanged. A copy of the **Selected Curve(s)** is made, ready to be mirrored.

# 10.2.6 Rotate Curve



# 10 ESKO 😌



Note: Rotataing curves or the entire job will not change the flute/grain direction of the job.

However, if you want to change the flute/grain direction, this can be done from Menu Bar->Job->Rotate  $90^{\circ}$  CW or CCW.

#### **Clockwise/Counter Clockwise**

Specify rotation direction.

#### Center of Selected Curve(s)

Rotation is carried out around center of Selected Curve(s):



#### Center of All Curve(s)

Rotation is carried out around center of All Curve(s):





#### **Center of Work Area**

Rotation is carried out around center of Work Area:



#### **Keep Original**

The original, **Selected Curve(s)** are kept unchanged. A copy of the **Selected Curve(s)** is made, ready to be rotated.

# 10.2.7 Merge Curves



Multiple overlapping curves can be combined into a single continuous curve using the **Merge Curves** feature.

This can be useful in creating a single shape from multiple objects such as overlapping letter shapes.

#### Replace Existing Curves



The new curve(s) replaces existing curves:



#### Generate new Layer

The new curve(s) are placed in a new **Layer**. Specify the **Name** of the new **Layer**.

## **10.2.8 Invert Curve Direction**

⇒	Menu Bar->Curves->Invert Curve Direction
⇒	Ctrl+Shift+I

The execution direction for the **Selected Curve(s)** is inverted.

This function is useful in combination with other **Edit** features like **Split Curve** to optimize cutting directions.

# 10.2.9 Lead-in/Lead-out



Menu Bar->Curves->Lead-in/Lead-out

	d-ins and lead-outs
Default Settings:	
Add:	✓ Lead-ins
	Lead-outs
Position:	○ <u>O</u> utside curves
	Inside curves
	Depends on the tool
Lead-in Radius:	10 mm
Lead-out Radius:	10 mm

# 10.2.10 Tool Offset



#### **Tool Offset**

ool Compensati	on		X
Tool Diameter:		3 mm	<u>о</u> к
Where:	Outside	-	Cancel
Direction:	Counter Cloc	kwi 🔻	
Wash Out Smal	Curves	Threshold:	5 mn
Replace Existence	sting Curves		
<u>G</u> enerate Ne	w Layer	Name:	Tool Compensation

#### i-cut Production Console

# 10 ESKO😔



Tool Offset can be used to achieve correct size of the final product when milling.

Please note that normally, the compensation for **Milling Bit** diameter is done with the **Layer** parameters **Tool Offset** and **Tool Diameter**.

The main reason for using this Edit function is to keep the Layer Offset values for later use.

Can also be used for e.g. adding a Cut Layer with a certain offset outside a Kiss Cut layer.

#### **Tool Diameter**

Specify the diameter of the tool to use. The offset is set to half the diameter.

#### Where

Specify if the tool should be **Outside** or **Inside** the **Closed Curve**. **Wash Out**. See below.

#### Wash Out Small Curves

Wash Out is a function to mill the entire area of a **Closed Curve** into chips. Useful as small pieces of waste may block the suction system..

Use this function to wash out all **Closed Curves** smaller than the **Treshold** value. For more information, see below.

#### Direction

Specify the execution direction for the tool.

#### Replace Existing Curve(s)

The new curve(s) replaces existing curve(s):

#### Generate new Layer

The new curve(s) are placed in a new **Layer**. Specify the **Name** of the new **Layer**.

Wash Out



Menu Bar->Curves->Tool Offset->Where->Wash Out



Wash Out is a function to mill the entire area of a Closed Curve. Use this function to wash out the Selected Curve.

# 10.2.11 Optimize Shape

🔶 Mer	nu Bar->C	urves->Optimiz	e Shape	
Optimize Curves		X	Ŋ	
Tolerance:	<mark>.1 mm</mark>	QK Cancel		
Break Long Lines	Length:	0 mm		
Make Sharp Corners     Make Rounded Corners	<u>R</u> adius:	6 mm		
<ul> <li><u>Replace Existing Curves</u></li> <li><u>Generate New Layer</u></li> </ul>	<u>N</u> ame:			

**Optimizing** improves the cutting performance of curves by re-drawing them to a specified tolerance as lines and arcs.

Curves are automatically optimized when producing, but the **Optimize Curves** feature is available for optimization of curves before production occurs, and provides greater control over the optimization of your curves.

#### Tolerance

Curves are automatically optimized using the specified Tolerance.

A low value will maintain the quality of the Input File.

A high value will increase performance, but the cutting quality might be reduced, depending upon the material used.

# 10 ESKO 😚

#### **Break Long Lines**

This function divides a (long) line into line segments with specified length.

One example:

You are about to cut a big rectangle in a flexible material, with a high demand for **Print to Cut** alignment.

By compensation to the corners of the rectangle only, the result is not optimal, despite a high number of **Registration Marks**.

Shorter lines allows for more accurate Print to Cut alignment.

Note: Break Long Lines can be applied for all jobs from **Menu Bar->Edit->Options->Production**.

#### **Make Sharp Corners**

Rounded Corners with specified Radius are converted to Sharp Corners.

#### Make Rounded Corners

Sharp Corners are converted to Rounded Corners with specified Radius.

#### **Replace Existing Curves**

The new curve(s) replaces existing curves:

#### Generate new Layer

The new curve(s) are placed in a new **Layer**. Specify the **Name** of the new **Layer**.

# 10.2.12 Remove Curves



#### Remove Selected Curve.

Confirm to complete:



# 10.3 Curve Segment Modifications

# 10.3.1 Select a Curve Segment

#### **Enter Edit Point Mode**

*	Toolbar->Edit Points
⇒	Menu Bar->Curves->Edit Point

#### Select Curve Segment

Select Curve Segment using the Mouse Pointer:



#### **Edit Curve Segment Menu**

While pointing at the Curve Segment, press the Right Mouse Button.

The Edit Curve Segment Menu appears:

- Add Corner
- Add Arc
- Add Bezier
- Split Curve
- Close Curve
- Add Regmark

# 10.3.2 Add Corner



Selected Curve Segment->Right Mouse Button Menu->Add Corner



Add a Corner Point in Current Position.

Current Position - using the Mouse Pointer, point to a position on the Selected Curve.

# 10.3.3 Add Arc

Selected Curve Segment->Right Mouse Button Menu->Add Arc

Add an Arc Point in Current Position.

Current Position - using the Mouse Pointer, point to a position on the Selected Curve.

### 10.3.4 Add Bezier

Selected Curve Segment->Right Mouse Button Menu->Add Bezier

Add a Bezier Point in Current Position.

Current Position - using the Mouse Pointer, point to a position on the Selected Curve.

### 10.3.5 Split Curve



Split Curve	×
<u>Remove</u> Curve Segment	<u>O</u> K
✓ Gap	Cancel
Gap <u>S</u> ize: 10 mm	

#### **Remove Curve Segment**

Remove the Curve Segment currently pointed at.





#### Gap

A Gap with length Gap Size is inserted in Current Position.

Current Position - using the Mouse Pointer, point to a position on the Selected Curve.



# 10.3.6 Close Curve



The Selected Open Curve is closed.





# 10.3.7 Add Regmark

⇒	Selected Curve Segment->Right Mouse Button Menu->Add Regmark
⇒	Selected Curve Point->Right Mouse Button Menu->Add Regmark
⇒	Layers View / Production View->Right Mouse Button Menu->Add Regmark

Add Regmark			×
Position:	X 379,2 mm	Y 287,7 mm	<u>Q</u> K
	O Center		Cancel
<b>C</b>	C Lower Left		
<u>S</u> ize:	6,4 mm		
Layer:	Regmark	•	

A new Registration Mark will be created in the Mouse Pointer position:

<b>N</b>		
	•	•

#### Position X and Y

Specify the coordinates for the new **Registration Mark**. Entering values here will override the **Mouse Pointer** position.

#### Center/Lower Left

Specify if the coordinates are relative to the center or the lower left corner of the Job.

Size

Specify the size of the new Registration Mark.

Layer

Specify the **Layer** for the new curve. The **Regmark Layer** is default.

# 10.4 Curve Point Modifications

# 10.4.1 Select a Point

#### **Enter Edit Point Mode**



#### Select Curve Point

Select Curve Point using the Mouse Pointer:



#### **Edit Curve Point menu**

While pointing at the Curve Point, press the Right Mouse Button.

The Edit Curve Point menu appears:

• Edit Point



- Remove Point
- Smooth
- Add Regmark
- Use as Start Point
- Add Lead-in/Lead-out
- Split Curve
- Close Curve

### 10.4.2 Edit Point



Selected Point->Right Mouse Button Menu->Edit Point

Point		×
<u>X</u> :	379 mm	<u>O</u> K
<u>Y</u> :	369 mm	Cancel
<u>T</u> ype:	Comer •	

Move Selected Point to a new position.

#### X/Y

Specify the coordinates for the new position.

#### Туре

Specify the corner type:

- Corner
- Arc the new point is a point on an arc
- Bezier the new point is a point on a Bezier curve
- True Type
- Bow
- Tangent

### 10.4.3 Remove Point



Selected Point->Right Mouse Button Menu->Remove Point

The Selected Point is deleted.

# 10.4.4 Smooth

Selected Point->Right Mouse Button Menu->Smooth

# 10.4.5 Add Regmark



Add Regmark			×
Position:	X 379,2 mm	Y 287,7 mm	<u>Q</u> K
	<ul> <li>Center</li> <li>Lower Left</li> </ul>		Cancel
<u>S</u> ize:	6.4 mm		
Layer:	Regmark 👻		

A new Registration Mark will be created in the Mouse Pointer position:



#### Position X and Y

Specify the coordinates for the new **Registration Mark**. Entering values here will override the **Mouse Pointer** position.

#### Center/Lower Left

Specify if the coordinates are relative to the center or the lower left corner of the Job.



#### Size

Specify the size of the new Registration Mark.

Layer Specify the Layer for the new curve. The **Regmark Layer** is default.

# 10.4.6 Use as Start Point



The Selected Point is used as Start Point:



## 10.4.7 Add Lead-in/Lead-out

Selected Point->Right Mouse Button Menu->Add Lead-in/Lead-out

ions			2
ead-in / Lead-out Sett	ings		
Remove all lead	l-ins and lead-outs		
Default Settings:			
Add:	Lead-ins		
	Lead- <u>o</u> uts		
Position:	O Outside curves		
	Inside curves		
	○ <u>D</u> epends on the	tool	
Lead-in Radius:	20 mm		
Lead-out Radius:	20 mm		
	,		
Preferences Help		Cancel	ОК

# 10.4.8 Split Curve



#### **Remove Curve Segment**

Remove the Curve Segment currently pointed at.





#### Gap

A Gap with length Gap Size is inserted in Current Position.

Current Position - using the Mouse Pointer, point to a position on the Selected Curve.



# 10.4.9 Close Curve



The Selected Open Curve is closed.



# 10.5 Add new Geometry

#### Layers View / Production View->Right Mouse Button Menu

The following menu items are available:

- Add Regmark
- Add Square
- Add Circle
- Add Ellipse
- Add Rectangle

## 10.5.1 Add Regmark



Add Regmark			×
Position:	X 379.2 mm	Y 287,7 mm	<u>о</u> к
	Center		Cancel
<u>S</u> ize:	Cower Left		
Layer:	Regmark 👻		



#### A new Registration Mark will be created in the Mouse Pointer position:

	N	
1		
	· · · · · · · · · · · · · · · · · · ·	
1.00		

#### Position X and Y

Specify the coordinates for the new Registration Mark. Entering values here will override the Mouse Pointer position.

#### **Center/Lower Left**

Specify if the coordinates are relative to the center or the lower left corner of the Job.

#### Size

Specify the size of the new **Registration Mark**.

#### Layer

Specify the Layer for the new curve. The Regmark Layer is default.

## 10.5.2 Add Square

Г

⇒	Layers View / Production View->Right Mouse Button Menu->Add Squar		
Add Square		×	
Position:	X Y 378.1 mm 368.2 mm	ОК	
	© Center	Cancel	
	<ul> <li>Lower Left</li> </ul>		
<u>S</u> ize:	6.4 mm		
Layer:	Crease 👻		

Add a Square in Mouse Pointer Position.

#### Position X and Y

Specify the coordinates for the new Square.

Entering values here will override the Mouse Pointer position.

#### Center/Lower Left

Specify if the coordinates are relative to the Center or the Lower Left Corner of theJob.

#### Size

Specify the size of the Square.

#### Layer

Specify the Layer for the new curve.

# 10.5.3 Add Circle



Add Circle			×
Position:	X 368,2 mm	Y 405,8 mm	<u>Q</u> K
	<ul> <li>Center</li> <li>Lower Left</li> </ul>		Cancel
<u>S</u> ize:	6,4 mm		
Layer:	Crease	•	

Add a Circle in Mouse Pointer Position.

#### Position X and Y

Specify the coordinates for the new **Circle**. Entering values here will override the **Mouse Pointer** position.

#### Center/Lower Left

Specify if the coordinates are relative to the center or the lower left corner of the Job.

#### Size

Specify the size (diameter) of the new Circle.

#### Layer

Specify the Layer for the new curve.

# 10.5.4 Add Ellipse



Layers View / Production View->Right Mouse Button Menu->Add Ellipse



Add Ellipse			×
Position:	X 379,2 mm	Y 368,2 mm	<u>O</u> K
	<ul> <li>Center</li> <li>Lower Left</li> </ul>		Cancel
<u>S</u> ize:	12.7 mm	6,4 mm	
Layer:	Crease	•	

#### Add an Ellipse in Mouse Pointer Position.

#### Position X and Y

Specify the coordinates for the new **Ellipse**. Entering values here will override the **Mouse Pointer** position.

#### Center/Lower Left

Specify if the coordinates are relative to the center or the lower left corner of the Job.

#### Size

Specify the size (X/Y) of the new Ellipse.

#### Layer

Specify the Layer for the new curve.

## 10.5.5 Add Rectangle

Layers View / Production View->Right Mouse Button Menu->Add Rectangle

dd Rectangle			<b>×</b>
Position:	X 379,7 mm	Y 369,7 mm	<u>0</u> K
	<ul><li>Center</li><li>Lower Left</li></ul>		Cancel
<u>S</u> ize:	12.7 mm	6,4 mm	
Layer:	Crease	•	

Add a Rectangle in Mouse Pointer Position.

#### Position X and Y

Specify the coordinates for the new **Rectangle**. Entering values here will override the **Mouse Pointer** position.

#### Center/Lower Left

Specify if the coordinates are relative to the center or the lower left corner of the Job.

#### Size

Specify the size (X/Y) of the new **Rectangle**.

# Layer

Specify the **Layer** for the new curve.



# 11. Job Alternatives, Advanced

# 11.1 Step and Repeat

Opened Job->Production Setup->Step and Repeat			
Com.			
Use Step and Repeat when you want more than one copy of Opened Job:			
TrimX GapX			

For more information, go here.

TrimY

# 11.2 Add Nested Layout



Use **Add Nested Layout** when you want to merge different designs together and treat these as one job.

Normally, this function is relevant for non-printed material only.

Note: This function is not fully implemented yet.

A separate Nesting Window appears, where all Nesting functions are maintained:



#### Available Jobs

This is **My Jobs List** as you know it from before, with the possibility to **Add**, **Remove** and **Sort** files in the list.

#### **Used Jobs**

This is a list of **Files** selected for **Nesting**, and the number of **Copies** currently specified. Use the **+** and **-** buttons to modify number of copies.

#### Layout

Configure Layout.

Auto Nest Not Implemented Yet.

Add to Nest

Add **Selected File** to **Nested Layout**. For more information, go *here*.

# 11.2.1 Configure Layout





Nesting Layout	×
<u>B</u> oard: Nesting on Foamboard Abc (620 x 380 mm)	<u>O</u> K ▼ <u>C</u> ancel
X: Y: <u>T</u> rim: 0 mm 0 mm <u>G</u> ap: 0 mm 0 mm	Gap (Y)
C Stack in X ⓒ Stack in Y	8 Experimental States of the second states of the s
Allow Rotation     € 180     C 90     C Free	
Snap: Distance: 10 mm	

From this dialog, configure the overall rules for this Nested Layout.

When creating a new Nested Layout, this dialog is the start point.

#### Board

From the drop down list, select actual **Board** This function is not implemented yet.

#### Trim and Gap

Specify the Trim and Gap values:



#### Stack in X/Y

Specify if the Nested Layout should start placing jobs along X or Y.

#### **Allow Rotation**

Specify if Rotation is allowed.

180 - the only Rotation Angle allowed.

90 - the only Rotation Angle allowed.

Free - You can specify Rotation Angle to use.

#### Snap

Specify a Snap Distance.

If two jobs are moved closer to each other than the **Snap Distance**, they will be moved together to use one common line.

# 11.2.2 Create Nested Layout



Start creating a new Nested Layout by adding files to the Layout using the above commands.

When files are loaded and placed as wanted, press OK to save the Nested Layout.

The **Nested Layout** can be re-opened for later edit.

The new **Nested Layout** will be added to **My Jobs List**, ready to be handled in the same way as any other file.

That means you can add Nested Layouts into new Nested Layouts.

By the above commands, the **Copy** dialog is invoked.

Layout is available in two ways, by Copies or Step and Repeat:

#### Copies

Copy REIN.acm		×
Copies		<u>О</u> К
C Step 'n Repeat		<u>C</u> ancel
Number of Copies:	1	
Copies in X:	4	
Copies in <u>Y</u> :	3	
Max no. of Copies on Board:	12	
These options are also av	ailable by right-clicki	ng any design.

#### Specify Number of Copies.

The copies are distributed according to the rules in Layout Configuration.



#### **Step and Repeat**

Copy REIN.acm	×
<ul> <li>C Copies</li> <li>● Step 'n Repeat</li> </ul>	<u>Q</u> K <u>C</u> ancel
Number of Copies:	1
Copies in X:	4
Copies in <u>Y</u> :	3
Max no. of Copies on Board:	4x3
These options are also available by right-clicking any design.	

Specify how many Copies you want along X and Y.

# 11.2.3 Edit Nested Layout



#### Select a Copy for Edit

Use the **Mouse Pointer** to select a copy for edit. The **Selected Copy** is surrounded by a frame.

#### **Edit a Selected Copy**

#### Move

With the **Mouse Pointer**, point inside the **Selected Copy**. Keep left **Mouse Button** down and move the **Selected Copy** to wanted position. Release the button.

#### Delete

Right-click inside the **Selected Copy**.
From the menu, select **Delete**.

Add Copy Right-click inside the Selected Copy. From the menu, select Add Copy.

Number of Copies... Right-click inside the Selected Copy. From the menu, select Number of Copies... The Copy dialog is opened.

## 11.3 Jobs Longer than Table

If your cutting device is equipped with an automated conveying system, you may be able produce jobs that are larger than your cutting table.

iPC supports production of jobs longer than the table by dividing the job into multiple sections and producing those sections automatically.

This function is enabled, ready to execute as soon as a job longer than the table is processed.

## 11.4 Jobs with Bar Codes



		r

Menu Bar->File->Open via Barcode

The following rules applies:

- Currently, using **Bar Codes** for automatic production is not available.
- QR and Data Matrix codes are supported.
- The function is available for i-Camera.

### Workflow

The sheet of material is placed on the table top.

After invoking the Jobs with Bar Codes function, you enter a wizard.



Put the sheet o	n the table and press the Start button on the	ope	rators panel.
Barcode jobs in			Deres
F:\C60BORREI	PROG\C64.ruler.table.dual.single		Browse
Import Preset:	😌 Esko Default	•	View Preset
	Description "Esko Default": Esko factory default including: Esko default mappings for all file formats No Cutting Key	*	



You are asked for

- A folder name; where the **Input files** are located.
- The Import Preset to use.

- Press Start.
- By jog, move camera in a position where the **Bar Code** is visible inside the camera picture.



- Press Accept to use the Bar Code and continue.
- The **Bar Code** is red, and the corresponding **Input File** is opened.
- The **Job** is ready for production.
- Press Start to continue.
- The Job is completed



- Press Skip to ignore this Bar Code.
- The Input File folder name is remembered from one job to another.
- The **Bar Code** location is remembered from one job to another.

## 11.5 Job including Reverse Operation



Menu Bar->Advanced->Configure Tools



Workflow







Step 2 - the sheet is aligned towards the **Left Ruler**.

**Reverse Operations** are completed.

The rest of the job is completed.

A typical use of **Reverse Operation** is when you want to add a **Crease** line on the front side of a material that you normally prepare from the rear side.

This function requires that the table is equipped with Left and Right Rulers.

Note: Reverse Operation is not available on machines with conveyor belt.

### **Reverse Operations in combination with Step and Repeat**

For each copy defined by **Step and Repeat**, you have to move the sheet; first against the **Right Ruler**, then against the **Left Ruler**:





## 11.6 Stop at Tool Select

### Menu Bar->Advanced->Configure Tools

Use this function to stop execution before the actual Layer is executed.

One example of use is if you want to change a **Milling Bit** in the middle of a job.

For more information, go here.

## 11.7 Multi-pass Depth



Multi-pass Depth is available for the following tools:

- Crease tools
- Knife tools
- Milling tools

**General Tool Configuration** 



Menu Bar->Advanced->Configure Tools

Name:	Crease 154	1		•	Edit	1	QK
Type:	Crease			•		<i>.</i>	Cancel
Velocity )	vY:	50 m/min					
Accelerat	ion:	100					
Depth Flu	te Dependant:	Default					
	ferenced from Top						
Depth: -	*	0 mm	‡		ж	0 mm	
Tool-up A							
Reverse		Default					
V Multi-pass	Depth:	0 mm					
		Measure	Ma	terial Thicknes	s:	0 mm	
Web Thic	kness:	0 mm	Br	ishing Pass Off:	set:	0 mm	

### **Tool Configuration for Opened Job**



Opened Job->Layers Tab->Edit Layer

Menu Bar->Layer->Edit Layer...

dit Layer			<u> </u>
Layer <u>N</u> ame:	Cut		Layer Color
Туре:	Cut	•	
Tool:	HP Milling 0	•	
Registration Type:	From Production Setup	•	
Speed X/Y:	6 m/min		
Speed Z:	1 m/min		
Acceleration:	50		
Depth: +	0 mm		
Stop at tool select			
Spindle RPM:	40000		
Tool Offset:	Outside 👻	Direction:	Counter Cloc
Tool Diameter:	4 mm		
Small Curves:	🔲 Wash out	Threshold:	0 mm
Multi-pass <u>D</u> epth:	5 mm		
	Measure	Material Thickness:	0 mm
Web Thickness:	0 mm	Einishing Pass Offset:	0 mm
🗖 Drill holes			
		ОК	Cancel

Milling and Multi-pass is described in a separate chapter.

General

### **Multi-pass Depth**

Specify the maximum depth to be processed in each pass.

### Measure / Material Thickness



Specify if the **Material Thickness** should be taken from the **Material Thickness** measurement performed at the beginning of the job.

If not, specify the thickness.

Material Thickness is used when calculating the depth of each pass.

Web Thickness Web Thickness is not relevant for Crease and Knife cutting operations. Milling and Multi-pass is described in a separate *chapter*.

Finishing Pass OffsetFinishing Pass is not relevant for Crease and Knife cutting operations.Milling and Multi-pass is described in a separate *chapter*.

## 11.8 Milling functions



### General

All settings are maintained from Edit Layer dialog.



Layer <u>N</u> ame:	Cut		Layer Color
Туре:	Cut	-	
Tool:	HP Milling 0	-	
Registration Type:	From Production Setup	•	
Speed X/Y:	6 m/min		
Speed Z:	1 m/min		
Acceleration:	50		
Depth: +	0 mm		
Stop at tool select		[	
Spindle RPM:	40000		
Tool Offset:	Outside 🗸	Direction:	Counter Cloc 👻
Tool Diameter:	4 mm		
Small Curves:	🔲 <u>W</u> ash out	Threshold:	0 mm
Multi-pass <u>D</u> epth:	5 mm		
	Measure	Material Thickness:	0 mm
Web Thickness:	0 mm	Einishing Pass Offset:	0 mm
Drill holes			

### Layer Type

Layer type Cut is used for milling.

### Tool

Select the Milling Tool available.

### Stop at Tool Select

Stop at Tool Select will make the machine stop before the execution of the actual Layer is started.

The text entered in the **Stop at Tool Select** field will be displayed.

Use this function in jobs with multiple milling operations requiring different milling bits.

Use the text field to describe the new **Milling Bit** to be entered.

Spindle RPM

Specify RPM.

### **Tool Offset**

Specify if the **Milling Bit** should be inside or outside the closed curve, or in the center of the line. For **Closed Curves**, we also have the **Wash Out** function available.

### Direction

Specify the milling direction around a **Closed Curve**. This setting has huge impact on the finished product quality. Note: This function will override the original direction of the curve.

### **Tool diameter**

Specify the Milling Bit diameter.

All **Closed Curves** will be offset half the value, outside or inside, dependant upon **Tool Offset** selection.

### Wash Out Small Curves

Use this function to Wash Out all Closed Curves smaller than the Treshold value.

### Multi-pass depth

Specify the maximum depth to be milled in each pass. Recommendation: This value should be limited to 1 - 1.5 times the **Milling Bit** diameter.

### Measure / Material Thickness

Specify if the material thickness should be taken from the material thickness measurement performed at the beginning of the job.

If not, specify the thickness.

Material thickness is used when calculating the depth of each pass.

## 11 ESKO😌

### Web Thickness

When producing a job with multiple passes, specifying a **Web Thickness** offsets the depths of all passes so that only a thin amount of material is left for an additional final pass.

The vacuum hold-down strength of all cutting devices have limitations, and small parts may shift on the cutting surface when they are routed.

The result is an undesired cut on the edge of the part where the **Milling Bit** made contact during the shift.

This effect is eliminated or greatly reduced using Web Thickness.

When the **Milling Bit** has less material to cut on the final pass, there is less chance of the part moving when the cut is completed because there is less force applied to the part by the **Milling Bit**.

### **Finishing Pass Offset**

Spesify the offset to be used for the last finishing pass.

### **Drill holes**

Select this option to drill holes.

### Multi pass milling



**Multi-pass Milling** is required if you want to mill through a material where the thickness is bigger than 1 - 1.5 times the **Milling Bit** diameter.



### Finishing Pass Milling

A **Finishing Pass** is the last pass of a multi-pass production.

This pass is slightly offset, or contracted, from the other passes.

The result is a final pass that shaves the entire edge of the part; removing any evidence of the multi-pass production and producing a smooth edge.

iPC will automatically increase the **Tool Offset** to compensate for the Finishing Pass and produce the curves at the intended size.

### Wash Out



### Use Layer Type: Wash Out

Wash Out is a function to mill the entire area of a Closed Curve.

Use this function to wash out the **Closed Curves** in the **Layer**.

### **Drill holes**



### Use Layer Type: Drill

When you specify that a **Layer** should drill holes, holes will be drilled in the center of **Closed Curves**.

A typical example is shown at left.

Geometry (circles) will be converted into holes and drilled.

## 11.9 MultiZone Production

### 11.9.1 Introduction





### Concept



For MultiZone Production, the Cutting Table Work Area is separated into two or more Working Zones.

Each **Working Zone** correspond to one or more **Vacuum Zones** on the **Cutting Table**.

Thus, the number of **Working Zones** available depends upon the acual machine model.

For more information, see **User Manual** for the actual machine.

To explain the function, we use a machine with two **Working Zones** (1 and 2).

When a Job is properly prepared, a simple MultiZone Production workflow could be described as:

- 1. You place one sheet of material in Working Zone 1.
- 2. You start the Job.
- **3.** While the **Job** in **Working Zone** 1 is processed, you prepare **Working Zone** 2 with a sheet of material.
- 4. When processing of Working Zone 1 is completed, the machine automatically start processing the Job in Working Zone 2 if you have marked Working Zone 2 as Ready. If not, machine will stop in the defined Parking Position.
- 5. You remove the processed material from Working Zone 1 and load a new sheet of material.
- 6. The process repeats.

Vacuum for the different **Working Zones** is switched on and off automatically, as an integrated part of the process.



How to initialize MultiZone Production

**Opened Job->Production Setup** 

MultiZone Production is available by:

- Selecting MultiZone Production Table Preset (1).
- Select a suitable Vacuum Zones configuration (2).
- Specify Number of Copies > 1 (3)

### 11.9.2 User Interface



During **MultiZone Production**, the **Layer View / Production View** window is separated into **Working Zones** that corresponds to the zones on the **Cutting Table**.

In the illustration, you see **Working Zone** 1 and 2.

On top of each zone, there is a **Status Bar** (3).

From the **Status Bar**, you read the processing status and you press the bar to go from one state to another.

### **Status Bar functions**



### Producing

The production in this **Working Zone** is on-going. The icon shows the live progress.

### Waiting for Operator (Replacing Material)

This state is set when the production is finished in one **Working Zone** and this **Working Zone** is not ready for production.

Remove processed material from the **Working Zone**.

Enter new material into the Working Zone.

Press the Status Bar button to enter the Ready to Produce state.

Note: The traverse cannot move over this zone, unless the user pressed the **Status Bar** button to enter the **Ready to Produce** state.



### **Ready to Produce**

Processed material is removed from the **Working Zone** and new material is in place.

You have pressed the Status Bar button to enter the Ready to Produce state.

Note: You can press this button again to go back to the **Waiting for Operator** state.



#### Produced

This state is set when the production is finished and another **Working Zone** is not ready for production.

When the Working Zone is ready, press Start to continue.

### 11.9.3 Workflow

ESK0 😳

11

### Workflow



### 1 - Prepare for the Job.

In **iPC**, the prepared **Job** is displayed (1). On the Cutting Table (2), place a sheet of material in **Working Zone** 1.

Use adhesive tape to mark the position of the sheet (3).

The tape position will be the reference for the next sheet produced on this zone

### Vacuum Zones

By default, all **Vacuum Zones** connected to a **Working Zone** are selecteted.



To achieve proper material fixture, configure the **Vacuum Zones** to be optimal for the actual job.

Alternatively, use Intelligent Vacuum Control.

### 2 - Press Start.

Working Zone 1 enters Producing state.



### 3 - Load material into Working Zone 2.

Use adhesive tape to mark the position of the sheet (1).

The tape position will be the reference for the next sheet produced on this zone

In iPC, press the Status Bar button to enter the Ready to Produce state in Working Zone 2.

4 - Job finished, Working Zone 1. Job in Working Zone 2 starts automatically.





5 - Replace material, Working Zone 1.

When ready, press the **Status Bar** button to enter the **Ready to Produce** state in **Working Zone** 1.

6 - Working Zone 1 Ready to Produce. Job in Working Zone 2 continues until completed.



11

ESK0 😌



7 - Working Zone 2 completed.
Job in Working Zone 1 starts automatically.
Replace material in Working Zone 2.
The process repeats until the specified
Number of Copies are completed.

### 11.9.4 Registration

### Job has Registration Marks

Use MultiZone Production in combination with any of the Registration Types available.

### **Job without Registration Marks**

### Use MultiZone Production in combination with Edge Recognition.

This workflow is aimed for unprinted material.

In this workflow, we allow to define the sheet position for the first production on each zone. Once that is done, the production will continue without registering the sheet edges.

Opened Job->Production Setup->Registration->Register First Table only.

11 ESKO😌

### 11.9.5 More Zones



Depending upon the actual **Cutting Table** model, we can have 2, 3 or 4 **Working Zones**.

- Instead of defining the sheet position on 2 zones, this should be done for all zones.
- Once the sheet positions are known, the user can replace sheets on the **Working Zone** that is busy producing and press the corresponding **Status Bar** to tell that the working zone is ready to continue production.
- If the user replace the sheets in time the production will continue smoothly.
- If the user can not replace the sheets in time the production will stop and the user will be asked to replace the material.

### Safety Rules



In the situation above, **Working Zone** 1 and 2 are ready to continue, while **Working Zone** 3 is waiting for material replacement.

When **Working Zone** 4 completes, the normal workflow will be to go to the next **Working Zone** that is ready and continue processing there.

But, in this case, the traverse will pass a **Working Zone** where material replacement is supposed to take place.

Execution will stop.

The operator has to ensure it is safe to continue before *Start* is pressed.

### 11.9.6 Rotated Table View

In case the Layers View / Production View is rotated 90°, the User Interface looks like this:



12 ESKO 😔

## 12. Direct Commands

### **Direct Commands Menu**



Set Table Top Reference	
Adjust Tool Height	
Show <u>C</u> amera	
Direct Commands	1. Feed Table Ctrl+1
	2. Vacuum On Ctrl+2
	3. Vacuum Off Ctrl+3
	4. Move To 0,0 Ctrl+4
	Edit Commands

Use this menu to select functions for immediate execution on the  $\ensuremath{\textbf{Cutting Table}}.$ 

Each menu item is configurable, using the Edit Commands... function:

### Edit Commands...



Menu Bar->Machine->Direct Commands->Edit Commands...

Edit Direct Comn	ands Dialog		×
Menu Text 1:	Feed Table	Default 1	<u>O</u> K
Command 1:	%%SHF 3138099	*	<u>C</u> ancel
Menu Text 2:	Vacuum On	Default 2	
Command 2:		*	
Menu Text 3:	Vacuum Off	Default 3	
Command 3:		*	
Menu Text 4:	Move To 0,0	Default 4	
Command 4:	D2X0Y0		

### Menu Text 1

Specify the text that describes Command 1.

This text will be displayed in the Direct Commands Menu, Line 1.

### Command 1

Specify the command to be executed when Line 1 (Ctrl+1) is selected in the Direct Commands Menu.

For a list of available commands, see Appendix.

You can edit the command directly or add a command using the + function.

### Menu Text 2-4, Commands 2-4

Description similar to Menu Text 1 and Command 1.

For further information, see *Table Preset*.

## 12.1 iPC Commands

Use **iPC Commands** to prepare:

• Direct Commands

Conveyer belt Speed and Acceleration (%SSA)	Sheet Feed (%SHF) Syntax: %SHF <distance> <start position=""></start></distance>
Syntax: %SSA <speed> <acceleration>.</acceleration></speed>	Command to move the conveyer belt the
Command to limit belt speed and acceleration. Values are percentage of maximum.	specified distance. Start position is optional. Value specified in 1/1000 mm.
i-cut Delay (I-SD)	Sheet Feeder Communication On (I-FM 1)
Syntax: I-SD <time>;</time>	Syntax: I-FM 1;
Execution is delayed <time> msec.</time>	Sheet feeder communication enabled.
i-cut Message (I-MS)	Sheet Feeder Communication Off (I-FM 0)
Syntax: I-MS <message>.</message>	Syntax: I-FM 0;
Dispaly a <message> to the Operator.</message>	Sheet feeder communication disabled.
i-cut Park (I-PK)	Vacuum pump, start and stop of (%PMP)
Syntax: I-PK.	Syntax: %PMP <on off="">.</on>
Move to <b>Park Position</b> .	Command to turn the vacuum pump on and off.
Reference Point selection(%SRE)	Vacuum suction direction control (%SUC)
Syntax: %SRE<1>/ <x>.</x>	Syntax: %SUC <on off="">.</on>
Switches between main fixed reference point (1) and panel defined reference point (X)	Switches between suction (on) and <b>Quick</b> <b>Release</b> / <b>Blow Back</b> (off)

13 ESKO 😚

## 13. Backup and Restore

After your system has been fully configured, you should back it up using the **Backup and Restore** system.

Performing a backup will save all of iPC's essential parameters into a number of files.

If your system stops performing properly or you accidentally alter your configuration, you can easily restore all settings to their exact state as when the backup was performed. Backups may be performed either manually or automatically.

### Please note:

- iPC backup stores all iPC configuration settings to a number of files on the file system.
- Backup of the file system is the responsibility of the customer.

For information about how to configure an automatic backup sequence, see *Backup*, *schedule*.

## 13.1 Backup System Parameters

### Manual Backup of System Parameters

Menu Bar->Advanced->Backup Configuration...

Each time Manual Backup is invoked, you enter a File Save dialog.

Specify a proper file name and click Save.

Use this function to backup your system both before and after performing upgrades.

## 13.2 Restore System Parameters

### **Restore System Parameters**

Menu Bar->Advanced->Restore Configuration...

Each time **Restore** is invoked, you enter a **File Open** dialog.

Select the file you would like to restore and click Open.

We strongly recommend you always backup your system manually before performing a restore.

## 13.3 Backup Cutting Key

Menu Bar->Advanced->Cutting Keys->Backup...

Use this function to complete a manual backup of the complete set of **Cutting Keys**. You are asked for a destination folder and file name.

Scheduled backups will follow the selected sequence, independent from any manual backup.

## 13.4 Restore Cutting Key

Menu Bar->Advanced->Cutting Keys->Restore...

Use this function to restore the complete set of Cutting Keys.

For more information, see Import Cutting Keys.



## 14. iPC Configurations

The **iPC Configuration** setting is a set of options specifying the general behaviour of the system. After first installation, you should go through each option in order to ensure proper setting.

## 14.1 Layers View / Production View Orientation



Alternatives:  $180^{\circ}$ 0<sup>0</sup> 90<sup>°</sup> 180<sup>0</sup> 270<sup>0</sup> 10295a

Select viewpoint for Layers View / Production View.

Viewpoint and Operator Panel position should be co-ordinated, in order to get correct Jog Direction.

For more information, see Hardware Configuration.

## 14.2 General



202

ategories	General Settings	
eneral roduction	Machine Type:	Kongsberg XL series
eeder Connection ead-in / Lead-out	Work Area Length:	1290 mm
ead-in / Lead-out lackup	Work Area Width:	2230 mm
anguage leference Points	Table to Feeder Distance	e: 0 mm
	<u>U</u> nits:	mm 👻
	Speed Units:	m/min 👻
	Import Units:	mm 👻
	Default Import Preset:	😳 Esko Default 👻
	Ask confirmation when	n creating jobs with the default Import Pr
	Show flute/grain direct	tion
	Show apply Cutting K	Key sort warning
	Remove finished jobs from	m My Jobs: Show dialog 👻

### Machine Type

The Machine Type connected is displayed.

### Work Area Length:

The measured length of the Work Area.

### Work Area Width:

The measured width of the Work Area.

## Table to Feeder Distance HW

This value, which is relevant only if a **Sheet Feeder** is connected, affects the **Feed to front of table** option in the **Production Setup**.

The sum of the **Table to Feeder Distance** and Width parameter defines the feed length required to feed a sheet of material to the front of your device's work area.

### Units

Select Units to be used in the User Interface (mm or inch).

### **Speed Units**

Select Units to be used for speed in the User Interface (m/min or ips).

### **Import Units**

Select **Units** to be used for **File Import**. **Units** specified in the **Input File** will override this setting for that particular file.

### **Default Import Preset**





Select Default Import Preset to be used for File Import.

### Ask for confirmation when creating jobs with the Default Import Preset

When enabled, you will be asked for confirmation each time a file is imported using the **Default Import Preset**.

Use this function to avoid unintended use of the Default Import Preset.

### Show flute/grain direction

Show / hide the flute /grain direction symbol from the Properties Bar.

### Show apply Cutting Key sort warning

Show / hide warning message after you Accept a Cutting Key.

### Remove finished jobs from My Jobs

From the drop-down list, decide how to handle **Finished Jobs**:

Never = Never remove job from My Jobs List.

Always = Automatically remove Finished Jobs from My Jobs List on close.

Show Dialog = This dialog appear at close of a Finished Job:



## 14.3 Production



General Production Preder Connection Leadin / Lead-out Backup Language Reference Points Bead furthest n Registration Mark Step x-axis bel Break long line	Load
Production Lead-in / Lead-out Backup Language Reference Points	Load
Lead-in / Lead-out Backup Language Reference Points Bead furthest n Registration Mark	Load
Lagoung Language Reference Points Bead furthest n Registration Mark	agistration mark first
Backup Language Reference Points	agistration mark first
Reference Points  Reference Points  Registration Mark  Step x-axis bet  Registration Jine	
<ul> <li>☐ Bead furthest n</li> <li>Registration Mark</li> <li>☐ Step χ-axis bet</li> <li>☐ Break long line</li> </ul>	
Registration Mark	
Step χ-axis bel Break long line	Size Tolerance: 75 %
🖾 Break long line	
🖾 Break long line	
	ore y-axis
	th: 50 mm

## 14.3.1 Table Presets

### General

**Table Preset** is a set of commands that is sent to the **Cutting Table** each time a **Job** is executed.You select the **Table Preset** to use from the *Production Setup->Material Handling* dialog.By default, several **Table Presets** that are suitable for most production scenarios are installed.

More factory made  $\ensuremath{\textbf{Table Presets}}$  are available in the folder

Esko->i-cut Production Console->Production Options.

If needed, add these to existing presets using the Load function.

Note: Only Table Presets configured for current Machine Configuration can be installed.

Use these functions to maintain Table Presets:

### Delete

Delete selected Table Preset.

Load... Load Table Preset from file.

## 14.3.2 Read Furthest Registration Mark First



Define Registration Mark read sequence:



### **Un-checked**

Normal sequence.

### Checked

The sequence is:

- 1. Read the **Registration Mark** in the furthest X-position.
- 2. Read the rest of the Registration Marks using the normal sequence.

This function improves the calculation of placement and rotation of curves on large sheets, but it will increase the execution time.

### 14.3.3 Step X-axis before Y-axis

### Define Step and Repeat priority:

### **Un-checked**

The entire column (Y) will be executed first before moving to next column.

### Checked

The entire row (X) will be executed first before moving to next row.

### 14.3.4 Break Long Lines

This function divides a (long) line into line segments with specified length.

By this, compensation is improved.

One example:

You are about to cut a big rectangle in a flexible material, with a high demand for **Print to Cut** alignment.

By compensation to the corners of the rectangle only, the result is not optimal, despite a high number of **Registration Marks**.

Shorter lines allows for more accurate Print to Cut alignment.

## 14.4 Feeder Connection





Categories	Feeder Connection Se	ettings	
General Production Feeder Connection	E Feeder Connec	tion	
acad-in / Lead-out Backup Language Reference Points	Eort No: Baudrate: Parity: DataBit: StopBit: Elow Control:	COM1	

iPC may communicate with a Sheet Feeder through a serial line.

If necessary, provide relevant parameters.

To establish communication between iPC and your feeder, follow these instructions:

- 1. Connect the feeder to your computer using an available serial COM port, or USB-to-Serial adapter
- 2. From your Windows Device Manager, locate the COM port settings of the port to which the sheet feeder is connected.
- **3.** Change the settings to: COM Port Number: As found in (2), Bits per second: 9600, Data bits: 8, Parity: Odd, StopBits: 1, Flow control: None
- 4. In the **Feeder Connection** dialog, adjust the parameters to match the corresponding values in your Device Manager.
- 5. Enable iPC communication on your sheet feeder's touch screen interface.
- **6.** Open your iPC Configuration window and verify that the Feeder option is presently available. If it is not, contact your iPC dealer to request a license upgrade.

## 14.5 Lead-in/Lead-out







ptions			<b>-</b> ×
Categories	Lead-in / Lead-out Sett	ings	
General Production Feeder Connection	🖾 Remove all lead	ins and lead-outs	
Lead-in / Lead-out	Default Settings:		
Backup Language	Add:	V Lead-ins	
Reference Points		Lead-guts	
	Position:	Outside curves	
		Inside curves	
		O Depends on the tool	
	Lead-in Radius:	20 mm	
	Lead-out Radius:	20 mm	
	Show this dialog	when applying Lead-in/Lead-out	
Restore Default Setting	s Preferences Help	<u>Ok</u>	<u>C</u> ancel

The Lead-in/Lead-out feature is primarily used for routing.

Adding **Lead-in/Lead-out** to a curve opens and extends the curve dynamically at production time so that cutting begins and ends inside or outside the path.

This is important for routing because the initial plunge into, and final lift out of the material may produce cutting results which are inconsistent with the rest of the part.

For information about how to apply Lead-in and/or Lead-out, see:

- 1. Curve Modifications.
- 2. Curve Point Modifications.

In the **Lead-in/Lead-out** option dialog described here, specify default values to use when **Lead-in** and/or **Lead-out** is applied.

The following parameters are available:

### Outside

Lead-ins and Lead-outs are added to the outside of the curve(s) to which they are applied.

### Inside

Lead-ins and Lead-outs are added to the inside of the curve(s) to which they are applied.

### **Depend on Tool**

Both the inside or outside position and the radius of the **Lead-ins** and **Lead-outs** depends upon the tool parameters in the **Edit Layer** dialog for the **Layer(s)** on which the intended curves reside.

### Lead-in/Lead-out

Select whether Lead-ins and/or Lead-outs will be applied.

### Radius

The **Lead-ins** and **Lead-outs** are always generated as absolute arcs, with the Radius defining the size. The Radius should be large enough to account for the diameter of the **Milling Bit** or laser beam.

### Show this dialog when applying Lead-in/Lead-out

When enabled, this dialog is displayed when the **Lead-ins** and **Lead-outs** are applied from the **Edit Curve** and **Edit Curve Point** dialogs.

## 14.6 Backup

<b>—</b> Me	enu Bar->Edit->Options>Schedu	e Backup
Options		
Categories	Backup Settings	
General Production Feeder Connection Lead-in / Lead-out Btokup Language Reference Points	Backup Location: C:\Users\yhbe\Documents\i-cut\Backup   Backup Schedule  How Often: Weekly What Day: Sunday What Time: 12:00 Backup is performed at first i-cut Production Console startup after defined backup schedule	
Restore Default Settings	s Preferences Help QK Cancel	

Use this dialog to configure the automatic **Backup Sequence**. For **System Backup**, choose automatic backups to occur **Daily**, **Weekly** or **Monthly**. For more information, see **Backup and Restore**.

## 14.7 Language





Options	×
Categories	Language Settings
Categones General Production Feeder Connection Leadvin / Lead-out Backup Language Reference Points	Language Settings Use:
Restore Default Setting	ps Preferences Help QK Cancel

### Windows Default Language

The language displayed in the **User Interface** defaults to the **Windows Operating System** language.

### **Enforce Language**

Select this option if:

- 1. Your current Windows language is not supported by iPC.
- **2.** You prefer to select a different language.

Select the desired language from the corresponding drop-down list and click OK.

Restart **iPC** to activate the new language setting.

## 14.8 Reference Points



Menu Bar->Edit->Options...->Reference Points

ategories	Reference Points Settings
eneral roduction	Name: Position (X, Y):
eeder Connection	Panel Reference Point (0, 0 mm) New
id-in / Lead-out skup	Main Reference Point (0, 0 mm)
nguage	
erence Points	
	Details:
	Name: Main Reference Point
	Position: X: 0 mm
	Y: 0 mm Update
	Press "Start" on operator's panel to move laser pointer to current reference point position. Press the "Update" button to set the reference point position to the laser position. (0, 0 mm)

### About Reference Points

To position a job on the table, Reference Points are used.

For the actual job, the selected Reference Point has co-ordinates X=0, Y=0.

## 14.8.1 Main Reference Point



The Main Reference Point (R) is a fixed Reference Point on the table.

You can select it from the list of **Reference Points** in the dialog, but you can not modify or delete this **Reference Point**.



### 14.8.2 User Defined Reference Points



### **Create User Defined Reference Points**

- 1. Click the New button to create a new User Defined Reference Point.
- 2. Enter the name of the reference point in the Name edit field.
- 3. Set the reference point position by:
  - a. Enter X/Y co-ordinates into the **Position** fields in the dialog.

The co-ordinates are relative to the Main Reference Point.

b. Click the Update button to set coordinates of the Reference Point in current Laser Position.

Click OK to activate the new Reference Point setting.

### **Delete a User Defined Reference Point**

In the list of reference points, highlight the User Defined Reference Point you want to delete.
 Click Delete.

### **Panel Reference Point**

The Panel Reference Point is a special version of User Defined Reference Points.

It is selected from the list of reference points in the dialog.

You can set the Panel Reference Point in three different ways:

1. Enter X/Y - co-ordinates into the **Position** fields in the dialog.

The co-ordinates are relative to the Main Reference Point.

- 2. Click the Update button to set Panel Reference Point in current Laser Position.
- 3. Press the Set Reference Point button on Operators Panel.

Panel Reference Point is set to current Laser Position.

_×_	

Set Reference Point button on C-series

Set Reference Point button on XL, XN, XE, XP, V-series



# 15. Machine Connection and Configuration





### From Windows Toolbar, invoke Machine Connection.

The following menu items are available:

- Machine Configuration
- Tool Configuration
- Service Menu
- About...
- Terminate Machine Connection

Note: These functions covers basic system settings, normally done once.

To be maintained by **Trained Personnel** only.

## 15.1 Machine Configuration

## 15.1.1 Hardware Configuration

achine configuration	
HW configuration Setup Installation	
Vecuum/Blowback 2 vecuum pumps Use pumps for blowback Vecuum setup	
Operator panel	
Front panel	
Conveyor mounted	
Ruler Rulers mounted	
Camera	
Camera setup	
Router setup	
OK Cancel Apply Help	
2 Vacuum Pumps	Use Pumps for Blow Back
Specify if this system is configured with 2	This system is configured with <b>2 Vacuum</b>
Specify if this system is configured with 2	
Specify if this system is configured with <b>2</b> /acuum Pumps.	This system is configured with <b>2 Vacuum</b>
Specify if this system is configured with 2 /acuum Pumps. /acuum Setup	This system is configured with <b>2 Vacuum</b> <b>Pumps</b> and the pumps provides <b>Blow Back</b> .
Specify if this system is configured with 2 /acuum Pumps. /acuum Setup From this dialog, select the hardware vacuum configuration you have on your Cutting Table;	This system is configured with <b>2 Vacuum Pumps</b> and the pumps provides <b>Blow Back</b> . <b>Rulers Mounted</b>
Specify if this system is configured with 2 /acuum Pumps. /acuum Setup From this dialog, select the hardware vacuum configuration you have on your Cutting Table;	This system is configured with <b>2 Vacuum Pumps</b> and the pumps provides <b>Blow Back</b> . <b>Rulers Mounted</b> Specify if this system has <b>Cutting Table</b>
Specify if this system is configured with 2 /acuum Pumps. /acuum Setup From this dialog, select the hardware vacuum configuration you have on your Cutting Table; humber of vacuum sections.	This system is configured with <b>2 Vacuum Pumps</b> and the pumps provides <b>Blow Back</b> . <b>Rulers Mounted</b> Specify if this system has <b>Cutting Table</b>
Specify if this system is configured with 2 /acuum Pumps. /acuum Setup From this dialog, select the hardware vacuum configuration you have on your Cutting Table; humber of vacuum sections.	This system is configured with <b>2 Vacuum Pumps</b> and the pumps provides <b>Blow Back</b> . <b>Rulers Mounted</b> Specify if this system has <b>Cutting Table</b>
Specify if this system is configured with 2 /acuum Pumps. /acuum Setup From this dialog, select the hardware vacuum configuration you have on your Cutting Table; humber of vacuum sections. Operator Panel	This system is configured with <b>2 Vacuum</b> <b>Pumps</b> and the pumps provides <b>Blow Back</b> . <b>Rulers Mounted</b> Specify if this system has <b>Cutting Table</b> <b>Rulers</b> mounted.
Specify if this system is configured with 2 <b>/acuum Pumps</b> . <b>/acuum Setup</b> From this dialog, select the hardware vacuum configuration you have on your <b>Cutting Table</b> ; humber of vacuum sections. <b>Operator Panel</b> Specify <b>Operator Panel</b> position.	This system is configured with <b>2 Vacuum Pumps</b> and the pumps provides <b>Blow Back</b> . <b>Rulers Mounted</b> Specify if this system has <b>Cutting Table Rulers</b> mounted. <b>Camera Setup</b>
Specify if this system is configured with 2 <b>/acuum Pumps</b> . <b>/acuum Setup</b> From this dialog, select the hardware vacuum configuration you have on your <b>Cutting Table</b> ; humber of vacuum sections. <b>Operator Panel</b> Specify <b>Operator Panel</b> position. This information will define <b>Jog Direction</b> for	This system is configured with 2 Vacuum Pumps and the pumps provides Blow Back. Rulers Mounted Specify if this system has Cutting Table Rulers mounted. Camera Setup Enter the Camera Setup dialog.
-	This system is configured with 2 Vacuum Pumps and the pumps provides Blow Back. Rulers Mounted Specify if this system has Cutting Table Rulers mounted. Camera Setup Enter the Camera Setup dialog.

For more information about these settings, see User Manual for the Cutting Table.



### 15.1.2 Setup



### Machine Connection->Machine Configuration->Setup

V configuration Setup	Installation			
Vacuum/Blowback				
Standard blowback usin	gfan 💌			
Operator panel				
Jog speed				
	%			
>> 100	%			
Incremental jog				
0.01	-			
>> 0.10	mm			
Conveyor Splt sheet feed Sheet feed correction		0.00	mm	
Speed		10	*	
Acceleration		10	*	
Tool height calibration mo	de			
Manual adjustment	*			
ĺ	Default			
		_		

### Vacuum/Blow Back

Specify installed Vacuum/Blow Back solution.

Standard blowback using fan

Blow Back is provided by a separate fan.

• Vacuum based blowback

Blow Back is provided by the Vacuum pump

### Jog Speed

Specify low and high Jog Speed as a percent of maximum speed.

### **Incremental Jog**

Specify the Step Size for low and high Incremental Jog

### **Split Sheet Feed**

Normally, material feed is carried out as one continous movement. Select this option to divide the material feed into two separate movements. Useful to avoid unwanted safety breaks for certain material sizes.

### **Sheet Feed Correction**
15

Add a correction value. A positive value will increase the movement.

### **Conveyor Speed**

Specify **Conveyor Speed** as a percent of maximum allowed speed. For optimal feed operation, some materials requires a reduced conveyor speed.

### **Conveyor Acceleration**

Specify **Conveyor Acceleration** as a percent of maximum allowed acceleration. For optimal feed operation, some materials requires a reduced conveyor acceleration.

### Tool height calibration mode

Select calibration mode:

- Manual adjustment use the manual procedure for tool height calibration.
- Automatic measurement use X-pad for tool height calibration

Note: this choice is relevant on machines with X-pad only.

### Default

All parameters are set to factory default.

For more information about these settings, see User Manual for the Cutting Table.

### 15.1.3 Installation

	Machine Connection->Machine Configuration->Installation						
[	Machine configuration						
	HW configuration       Setup         Machine setup       Set main reference position         >>>       Register table size         >>>       Adjust X1 to X2 angle         >>>       Set nuller position         >>>       Map table top surface         >>>       Calibrate Measuring Pad						
	OK Cancel Apply Help						

# 15 ESKO 🕄

### Set Main Reference Position

Invoke the **Set Reference Point** wizard. Follow wizard instructions. Note: Complete this function for all **Tool Holders**.

### Register Table Size

Invoke the **Register Table Size** wizard. Follow wizard instructions.

### Adjust X1 to X2 angle

Invoke the Adjust **X1 to X2 angle** wizard. Follow wizard instructions.

### Set Ruler Position

Invoke the Set **Ruler Position** wizard. Follow wizard instructions.

### Map Table Top Surface

Invoke the Map **Table Top Surface** wizard. Execute on top of the **Vacuum Table**, no **Cutting Underlay** or **Conveyor Belt**. Follow wizard instructions.

### **Table Top Reference**

Update table top level measurement in current **Laser Pointer** position. Measure on top of cutting underlay; no material.

### **Calibrate Measuring Pad**

Invoke the Calibrate **Measuring Pad** wizard. Follow wizard instructions.

For more information about these settings, see User Manual for the Cutting Table.

### 15.2 Tool Configuration



Machine Connection->Tool Configuration

figuration			0	-
Identified tools	o	O		
Ballpoint Pen 57	1 - X None	~ 🗙 None	*	
			Adjust active to	ol.
			Identity tools	
OK	Apply He	þ	More	

### **Identified Tools**

The tools currently mounted on the **Cutting Table** are displayed.

### Select a Tool

By the radio buttons, select the **Tool** to update.

### **Identify Tools**

Complete a Tool identification sequence.

### 15.2.1 Adjust Active Tool



### General

Tool adjustment is carried out using wizards.

All tools need to be adjusted in the Tool holder position they will be used.

We recommend to use a sheet of quality carton or corrugated to perform these wizards.

### About adjustments



### **Tool Height**



The tool tip should touch the surface of the cutting underlay.

### Lag setting



The knife lag depends upon the blade adapter.

### **Rotation adjustment**



Adjust tool angle tangential to moving direction.

### Center offset adjustment



Adjust tool sideways until centered.

### **Camera Calibration**



Compensate for camera offset and lens distortion. For more information, go *here*.

### **Offset Adjustment**



Adjust offset relative to Laser Pointer.

For more information about tool adjustment, see Cutting Table User Manual.

### 15.2.2 More

More	×
🔲 Ignore the automatic tool iden	Nification
Delete tools	Add tools
ID number : 1189	ID number :
Tool: Crease 0 V	
Delete the tool	Add the tool
ОК Не	qle

The More dialog contains selections to Ignore, Delete or Add to the Tool List.

The Tool List contains Tools that you can select for the available Tool Positions.

### Ignore Automatic Tool Identification

**Ignore Automatic Tool Identification** may be used when the **Automatic Tool Detection** fails, and manual tool selection is necessary.

If Ignore Automatic Tool Identification is checked, Tool Setup remains unchanged after:

- Table Zero Position sequence
- Identify Tools function

#### **Delete Tool**

Use **Delete Tool** when a **Tool** is no longer in use. The deleted **Tool** will no longer be available in the **Tool List** in the **Edit Layer** dialog.

### Add Tool

Use Add Tool to

- Add new Tools
- Add tools that fails during Automatic Tool Detection

The Tool is added to the Tool List.

### 15.3 Camera Operations



### **Show Camera**





### **Camera Setup**



Machine Connection->Machine Configuration->HW Configuration->Camera Setup

Prerequisites:

15

- The camera has to be visible as an imaging device from device manager.
- Necessary camera driver has to be installed (Epix driver if i-cut camera).

NAME         TYPE         TOOULEAD         DRIVER         STATUS         Edit           DSHOW Camera 0         Toohead         MultiCUT HP         DirectShow:R66F(640,460)         Connected         Delete         Camera.           DSHOW Camera 0         Toohead         Feelved         Direction:         Delete         Camera.	Camera Configuration	-	<b>—×</b>	If using i-cut camera, select add i-cut
<ul> <li>Give the camera a proper name</li> <li>Give the camera a proper name</li> <li>Select type of camera (Tool head, In-stack)</li> <li>Select OK to save your settings.</li> <li>The connected Tool head is marked by a (*) in</li> </ul>	DSHOW Camera 0 Toolhead MulbCUT HP DSHOW Camera 0 Toolhead PlexiHead DSHOW Camera 0 Toolhead PowerHead DSHOW Camera 0 Toolhead FlexiHead A. DSHOW Camera 0 Toolhead FlexiHead A.	DirectShow:RGBY(640,480) Connected DirectShow:RGBY(640,480) Connected DirectShow:RGBY(640,480) Connected DirectShow:RGBY(640,480) Connected DirectShow:RGBY(640,480) Connected	Delete Add I-Cut Camera Refreah	<ul><li>camera.</li><li>In the list of cameras, select the one currently connected</li></ul>
Cancel OK	Camera Configuration - Multicut HP	Type: Toohead Toohead: () Multicut HP No tooholder Peerinead Multicut Peerinead Cut () Multicut HP		<ul> <li>Select type of camera (Tool head, In-stack)</li> <li>Select OK to save your settings.</li> <li>The connected Tool head is marked by a (*) in</li> </ul>

### i-Camera Configuration

Machine Connection->Machine Configuration->HW Configuration->Camera Setup

If your system is equipped with i-Camera, some additional functions are available:

Camera Configuration	Refresh the view.
NuMe         TYPE         TOQUERD         DRNER         STATUS         Edit           Tordivel         Toohead         MulbQUT         ScorpionR68(2128), 1024)         Connected         Distribut         Delete           DSHOW Cames 0         Toohead         PowerHead         DerectShow:RG87(640, 480)         Stored         Delete           DSHOW Cames 0         Toohead         PowerHead         DerectShow:RG87(640, 480)         Stored         Add I-Out Camera           DSHOW Cames 0         Toohead         No toohel         Ptxd:RG87(20, 480)         Connected         Add I-Out Camera           EPIX         Undefined         No toohel         Ptxd:RG8(720, 480)         Connected         Refresh	<ul><li>Select actual camera.</li><li>Select Edit.</li></ul>
Camera Configuration - UCS SN-0393	<ul> <li>From this dialog, you can:</li> <li>Name the camera.</li> <li>Select type of tool head.</li> <li>Select tool head.</li> <li>Select Enable Advanced Settings to adjust parameters.</li> </ul>

#### i-cut Production Console

# 15 ESKO 😔

Toohead •
FlexiHead
20
dvanced Settings
Auto
s: 🗌 — 109
Auto
100
Auto 100
100
· · · · · ·
Reset to Default Values
: Minimize reflections
Cancel OK

#### Note:

Before any adjustment, ensure proper camera height:

Press **Manual Tool down** to move camera into correct position.

Press OK to complete.

#### **Image Quality**

Adjust and test settings in order to obtain stable and accurate **Registration Marks**.

#### Capture Mode

Select **Minimize Reflections** to use the internal camera light (default).

Select **No Illumination** and the internal camera light will be switched off.

#### **Offset Adjustment**

Machine Connection->Tool Configuration->Adjust Active Tool->Offset Adjustment

nfiguration		
Identified tools	0 0	
Rigid Material K	nite ~ 🗙 None ~ 🗙	None ~
۲		Adjust active tool
Camera		Identity tools
ОК	Apply Help	Measure all tools More



Two initial steps are mandatory:

- Complete Offset Adjustment between Laser Pointer and all tool positions.
- Select one tool, preferably a knife tool, as the common reference tool between Laser Pointer and Camera.

Select **Offset Adjustment** and complete the wizard.

### **Camera Calibration**





Camera calibration wizard

	While the shee do:
1 Jog the toolhead away, then remove the cutout carefully with a sharp object. Take care not to move the sheet or harm the edges of the remaining hole.	<ol> <li>Jog the too</li> <li>Carefully re</li> </ol>
2 Click "Next" to continue.	Reference 3. Press Next
Back Next Finish Cancel	
Mera calibration wizard	<ol> <li>Verify that the second s</li></ol>
Show center indicator Back Nex Prish Cancel	
, 	The <b>Camera (</b>
Progress	complete.
Finished!	Correct compl
Offset update [mm] Calibration [um/pixel]	Press <b>Finish</b> .
X: +3.39 X: 95.1 (0.5%) Y: +0.47 Y: 95.5 (+0.2%)	
NOTE: The values above give an indication of the accuracy of a single detection. The total accuracy of a job with register mark depends on numerous other factors, such as print distortion and the number and locations of register marks. SUCCESS! Click 'Finish' to save the calibration values or 'Cancel' to use the old values.	
Back Next Finish Cancel	

et is kept in place by vacuum on,

- l head away.
- move the cutout from the Mark.
- .

×

- the mark is correctly detected.
- t.

Calibration wizard will now

etion is indicated as displayed.

15



Press Close to terminate the procedure.

Note: **Camera View** will be oriented according to *Layers View / Production View*.

### 15.4 Service Menu

Note:

The Service Menu functions are available for certified service personnell only.

They are not aimed for table operators.

### 15.4.1 Message Display

Message display		<b>×</b>	
nfo: XL-MachineConnection: 1	030, Dev:01 / Mar 4 2014,	11:25:39	
nfo: Started: Tuesday, April 15	, 2014 08:52		
Info: Send Common part and lin Info:	e O from setup		
Info: Versions MCU: 0 SCU: 0 1	CU: 0 PCU: 0		
Info: SystemStart: Tue Apr 150 Info:	8:52:20 2014		
Info: TableType: "XL 4x Med.	height"		
🔽 Popup on warnings	Show: All	-	
Always on top			
Log messages	Help	Close	

### **Popup on Warnings**

Select if you want the **Message Display** window displayed for each warning message. Error messages are always displayed.



### Always on Top

Select if you want the Message Display on top of your Desktop.

### Log Messages

When enabled, all messages are logged for later examination. Useful for trouble shooting.

### Show

Specify at what level messages are shown:

- All all kind of messages are displayed.
- Important Only
- Critical Only

### 15.4.2 Memory Dump



Invoke the Memory Dump application.

To be used for Software Maintenance.

File         Year         Cu           Image: H         S         L         C         F         D         +2         Go         R         MCU         Scu         Tcu         R         Auto           004404F8         00440518         00440518         00440538         00440538         00440538         00440538         00440538         00440548         00440548         00440578         00440588         00440588         00440588         0044058 <t< th=""><th>E Mem</th><th></th><th>Þ</th><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th></th><th>00</th><th>x</th></t<>	E Mem		Þ											00	x
H         S         L         C         F         D         +2         Go         R         MOU         Scu         TOU         Auto           00440508         00440518         00440518         00440518         00440518         00440518         00440518         00440558         0044	<u>Eile ⊻</u> ie	sw <u>⊊</u> u													
00440518 00440518 00440528 00440538 00440538 00440538 00440558 00440578 00440578 00440578 00440578 00440578 0044058 0044058 0044058 0044058 0044058 0044058 0044058 0044058 0044058		н	s	L	с	F	D	+2	Go	R	MCU SCU	TCU	R Auto		^
	00441 00441	0508 0518 0528 0538 0558 0558 0558 0558 0558 0588 058													

For more information, see Hwtest User Manual

### **15.4.3 Position Display**

Machine Connection->Service Menu->Position Display

Position display			×
X	0.00	mm	<ul> <li>Table ref.</li> <li>Hr and z</li> </ul>
Y	0.00	mm	© 0E POS © 0E POSZHR
	(	Cancel	Help

For more information, see User Manual for Cutting Table .

### 15.4.4 Show Vacuum Dialog

Select Vacuum Zones
Click a vacuum zone to select or deselect:
Close

Select Vacuum Zones suitable for Opened Job.

Note: This dialog is available from: Machine Panel->Vacuum Zones

### 15.4.5 Emulate Panel

Machine Connection->Service Menu->Emulate Panel

A function for **Software Maintenance**.



### **15.4.6 Tool Holder Select**



#### Select Tool holder for test.

This function is available when iPC is dis-connected from Cutting Table only.

### 15.5 About ...

P	© 1984 - 2013 Esko-Graphics Kongsberg			System versi	on: 1030	1030, Dev:01 / Mar 4 2014, 11:24:16		
¥	This cop	yright notice does	not	Machine type		XL 45	XL 4x Med. height	
	indicate that this work has been published			Machine size	:	1465	1465 x 2525 mm	
				Workarea all	1450	0 x 2370 mm		
	Current status	Date: 15.04.2014	Run time	minutes		First time star 22.10.2013	ted	
	Current status				Bv	Since last mai	ntenance	
	Maintenance	19.11.2013	•	hours	YOU	0	hours	
							ОК	

### **System Version**

Version number and date of the installed software.

Machine Size Machine size as obtained by the **Register Table Size** function

Work Area all Tools

**Machine Type** 

Type name of connected **Cutting Table**.

Nominal **Work Area** available for all tools in the currently mounted **Tool holder**.

### 15.5.1 Maintenance Info

Current Status	
Date	First Time Started
Todays date.	Date when the system was running for the first time.
Run Time	
Total number of hours the machine has been running (executing).	
Maintenance	
Date	Ву
Date when last maintenance was carried out.	Initials of the person who completed last maintenance.
Run Time	Since Last Maintenance
Hour counter when last maintenance was carried out.	Number of execution hours since last maintenance.

### 15.6 Terminate Machine Connection

Use this function to terminate the connection to the **Cutting Table**.

To re-connect: Menu Bar->Machine->Connect

### 15.7 Logging

### 15.7.1 General



### **Bug report**

A Bug report should consist of:

- A detailed, step by step description of what happened.
- If found at a customer site also a confirmation that the bug can be reproduced in the lab.
- Sometimes a description of the expected behavior will also be a help.
- A .zip file of the log folder, with at least the files:
- • i-cut Production Console.log
  - iPcDeveloperLog.txt
  - Last KB ACM file.log
  - Last KB Mat file.log
  - MCDeveloperLog.txt.

### 15.7.2 Log Settings



From this dialog, specify the log level.

For log settings to take effect, restart iPC.

The default setting will always be Service Log.

Initiating a log should be carried out only if requested by Esko personnel.

#### Procedure

To invoke logging:

#### In the Log Settings dialog, check Use integrated logging system and Log to File.

To reduce the size of the log file, please do as little as possible:

- Start iPC.
- Do the test and nothing else.
- Stop iPC.
- · Zip the log folder and copy to your server.

#### Notes:

• Log type **Debug** or **Trace** will seriously affect performance and must be used for short periods of time.

• Never leave a machine in any other setting than Service Log.



## 16. Install Software

For information about software installation, see the **Installation Manual** for the actual machine. Available on the Documentation DVD.

### 16.1 File Save Structure

Computer->xxx->My Documents->i-cut Production Console

Documents library

i-cut Production Console

Name

Backup

Cutting Keys

Exports

MC

Production Options

Sample Files

User Manual

Options.xml

This is the default file save structure.

Backup

**Cutting Keys** 

Exports

MC

**Production Options** 

Sample Files

User Manual

17

## 17. About Licenses

### iPC has four main licenses.

Installed license is available from Menu Bar->Help->License Manager...

### i-cut Production Console Basic

Basic license cover only basic functions. No camera functions.

### i-cut Production Console Packaging Production

Packaging Production license cover all main topics for production, but less functionality regarding edit, milling and camera distortion compensations.

### i-cut Production Console Sign Std

Sign Std license covers all features for V-series.

### i-cut Production Console Sign Prod

Sign Prod license is the main license that covers all features in iPC software.

Feature	Basic	Pack Prod	Sign Std	Sign Prod	Details
Base	х	х	x	х	Enable all base functionality including start of application
Line_edit		х	X	х	Enable all manual geometry editing. Basic version will be "read only", like XL-Guide
Avoid_overcut			X	x	Enable <b>Layer</b> feature to automatically split lines and change cut directions, mainly for printed materials
Registration_and_ placement		x	X	х	Enable edge / regmark reg. and placement (position / rotation) compensation. Registration device is HW dependant
Barcode		x		х	Enable use of camera for reading barcodes, which enables automated workflow. Barcode scanner always supported
Linear		х	х	х	Enable linear and differential scale
Non_linear			x	х	Enable non linear (full) distortion compensation
Intelligent Marks			X	х	Enable Adaptive Registration
Non Stop		х		х	Enable more than 1 copy (table) productions
Milling			x	х	Enable advanced milling features, like Lead-in/Lead-out, Multi-pass, Wash Out, Tool Diameter Compensation



Feature	Basic	Pack Prod	Sign Std	Sign Prod	Details
Add_Nested_Layo	ut x	x	x	х	Enable dialog for merging designs onto same board based on bounding boxes or manual positioning
Step_and_repeat	x	x	X	х	Enable <b>Step and Repeat</b> the "i-cut way"
MultiZone production		x		х	

## 18. Keyboard Shortcuts

Alt + Click	Select All Curves					
Alt + Left						
Alt + Right						
Alt + Up	Jog Selected Curve(s)					
-						
Alt + Down						
CTRL + -	Zoom Out					
CTRL + +	Zoom In					
CTRL + 0	Fit to Data					
CTRL + A	Select All Curves					
CTRL + Alt + Shift + L	Log Options					
CTRL + Alt + M	Maintenance Interval update					
CTRL + C	Copy Layer(s)					
CTRL + D	Deselect All Curves					
CTRL + L	Add Layer					
CTRL + M	Move Selected Curves					
CTRL + N	New File					
CTRL + O	Open File					
CTRL + S	Save File					
CTRL + Shift + A	Select All Layers					
CTRL + Shift + C	Copy Layer(s) with Curves					
CTRL + Shift + D	Deselect All Layers					
CTRL + Shift + I	Invert Curve Direction					
CTRL + Shift + J	Fit to Job					
CTRL + Shift + M	Mirror Selected Curves					
CTRL + Shift + R	Rotate Selected Curves					
CTRL + Shift + S	Save File As					
CTRL + Shift + T	Fit to Table					
CTRL + T	Scale Selected Curves					
CTRL + U	Remove Unused Layers					
CTRL + W	Close File					
CTRL + Z	Undo					
Delete	Remove Selected Curves					
F1	Help					
Shift + Delete	Remove Layers					



## 19. Using ai-cut/i-cutCDR

ai-cut is an addon to Adobe Illustrator.

i-cutCDR is an addon to CorelDraw versions X3, X4 and X5.

These addons provides tools to automatically add iPC Register Marks to designs.

For more information, see separate User Manuals.

## 20. i-script

PREPRESS	PRIN	TING	FINISHING
Design stations	RIP s	tation	IPC
	i-s		script file
		printer OUTPUT	IMAGE FINISHING
10298a			

In a traditional workflow, image data and cut data are generated as separate files out from the Design station.

i-script is a workflow where image data and cut data are separated in the RIP process.

The big advantage is that modifications made during the RIP process are maintained both for the image data and the cut data.

i-script is adapted by leading RIP and printer producers.

**i-script** file format is as well used for data transfer from Esko applications like i-cut Layout and ArtiosCAD to iPC.