

DS100 Serial Device Server Technical Manual*

Tibbo
TECHNOLOGY



Please, register at www.tibbo.com to receive update notifications

Version: 2.2a

Tibbo Technology, Inc. 2001, 2002

* Formerly User's Manual

DIREKTRONIK

e-mail: info@direktronik.se

tel: 08-52 400 700 fax: 08-520 18121

Thank you for taking an interest in Tibbo's Products!

Always check for updates!

Our every Product is an "ongoing Project". Basing on our Customer's feedback we are constantly working on improving and enhancing the DS100 Serial Device Server. Chances are, the *User's Manual* you are reading now is outdated. Visit our website at www.tibbo.com for up-to-the-minute firmware, software, and documentation. You can also subscribe to our periodic e-mail newsletter to stay informed on the latest developments at **Tibbo Technology**.

The DS100 can be customized in many ways. Have an idea? [Let us know now!](#)

Is this Manual for you?

This User's Manual was designed to serve as a reference for Software Developers and System Integrators seeking in-depth information on the DS100 functionality and programming. If you are an End-user with a task to connect your serial device to the network then you most probably should turn to our *Connectivity Manual*. This Manual is a user-level document that details the installation, setup, and use of the DS100 Serial Device Server and *Tibbo Device Server Toolkit* software (including *Virtual Serial Port Driver*).

This Manual assumes that the Reader is a technical specialist with a knowledge of Ethernet and TCP/IP networking

Is your firmware up to date?

This Manual describes the functionality of the DS100 Serial Device Server running V2.2x firmware. If your DS100 has an older firmware you need to upgrade to this new firmware first. See [Firmware Download Mode](#) for a complete information on how to upgrade the DS100.

Seeking further assistance

If you cannot find an answer to your question or problem you are encouraged to send us an e-mail:

- support@tibbo.com for technical problems
- feedback@tibbo.com for your suggestions
- sales@tibbo.com for sales inquiries
- info@tibbo.com for all “other” inquiries

How to print out this Manual

This Manual is supplied in two forms: screen-optimized and print-optimized. Use the screen-optimized document (*DS100 Technical Manual*) to conveniently view the Manual on your PC screen. Use the print-optimized version of the above (*DS100 Technical Manual (print)*) to make a hardcopy of the Manual. The printed version arranges 2 small document pages per single A4 sheet.

Table of Contents

1.	Introduction	6
1.1.	What is the DS100?	6
1.2.	Three basic ways of using the DS100	6
2.	Controls, operating modes, and signals	7
2.1.	DS100 connectors and controls	7
2.2.	Operating modes	8
2.3.	Summary of Status LED signals	8
3.	Operation in the Normal Mode	Error! Bookmark not defined.
3.1.	General information	9
3.2.	Slave and Master routing modes	11
3.3.	Serial→Ethernet data routing	15
3.4.	Buffer-related issues	18
4.	Programming the DS100	19
4.1.	General information	19
4.2.	Serial Programming Mode	20
4.3.	Network Programming	22
5.	Available commands and replies	25
5.1.	List of commands	25
5.2.	List of possible reply codes	25
5.3.	Detailed Command description	26
6.	Available Settings	32
6.1.	List of Settings by groups	32
6.2.	Detailed Setting description	33
7.	Available Parameters	44
7.1.	List of Parameters	44
7.2.	Detailed Parameter description	44
8.	Firmware Download Mode	46
8.1.	Downloading new firmware file	46
8.2.	Initializing the DS100	48
8.3.	Possible download problems and LED signaling	49
9.	I/O Connector pin assignment & Cable wiring	50
9.1.	DS100 I/O connector pin assignment	50

9.2.	RS232 cable wiring	50
9.3.	Ethernet cable wiring	51
10.	Specifications, packing & ordering Information	52
10.1.	Specifications & packing information	52
10.2.	Ordering Information	52

1. Introduction

1.1. What is the DS100?

The DS100 is a *Serial Device Server*. The main function of the DS100 is to *network-enable* existing serial devices. Using the DS100 you can connect practically any serial device with RS232 interface to an Ethernet Local Area Network (LAN). You can then communicate with your serial device from any PC (or other device) connected to your LAN. And if your LAN has a direct connection to the Internet, then you can access and control your serial device from anywhere in the world!

1.2. Three basic ways of using the DS100


- **If you have a serial device and an existing PC software to control it** then you can use the DS100 in conjunction with our *Virtual Serial Port Driver* (VSPD). *Virtual Serial Ports* (VSPs) created by the driver are logical COMs that behave like standard hardware COMs but in reality transparently reroute the data via the TCP/IP network to the DS100 and the serial device attached to it. *By using the VSPs you can continue using your existing PC software without any modification.*
- **If you have a serial device and are creating a new PC software to control it** then you can communicate with the DS100 directly (without VSPD). The DS100 transmits the data using industry-standard UDP/IP and TCP/IP communications protocols. Most software development packages like *Visual Basic* from *Microsoft®* provide an easy to use components that simplify exchanging data with the DS100. Turn to our tutorial *Using VB to communicate with the DS100/EM100* for more information
- **If you have two serial devices** that you want to link over the network you can use two DS100s at both sides to create a Virtual Serial Link over the TCP/IP network.

For more information on how to use the DS100 with different kinds of serial devices please turn to our *Connectivity Manual*.

* Provided that you have assigned a valid "true" IP-address to the DS100. "True" IP-address is the address that is unique Internet-wide.

2. Controls, operating modes, and signals

2.1. DS100 connectors and controls



- **Setup Buttons.** Pressing either button while the DS100 is in the [Normal Mode](#) forces the DS100 into the [Serial Programming Mode](#). Powering the DS100 up with either button pressed puts the DS100 into the [Firmware Download mode](#).
- **Status LEDs** indicate DS100's operating mode/conditions. See [Summary of Status LED signals](#)
- **Power Jack-** use DC12V, 200mA (min.) power adaptor
- **Ethernet Status LEDs-** Green LED blinks when the data packet is received, Red LED indicates network data collision error
- **Ethernet (10BaseT) port-** connects to the LAN
- **Serial (RS232) port-** connects to the serial device. This port is also used for DS100 setup in the [Serial Programming Mode](#) and to download new firmware in the [Firmware Download Mode](#).

2.2. Operating modes

The DS100 has three modes of operation:

- **Normal Mode** is entered after the DS100 is powered up with neither [Setup Button](#) pressed. It is in the Normal Mode that the DS100 performs its Ethernet↔Serial data routing. [Network Programming](#) of the DS100 can also proceed in the Normal Mode in parallel with the data routing
- **Serial Programming Mode** is entered when either [Setup Button](#) is pressed or [escape sequence](#) is sent into the DS100's serial port while the DS100 is in the Normal Mode. This mode is used to program the DS100's functioning parameters ([Settings](#)) via the serial port
- **Firmware download mode** is entered when the DS100 is powered up with either [Setup Button](#) pressed. This mode is used to download new firmware file into the DS100.

2.3. Summary of Status LED signals

This Section details the Status LED signaling for the [Normal](#) and [Serial Programming](#) Modes. LED signaling in the [Firmware Download Mode](#) is detailed in [Possible download problems and LED signaling](#).

Entering the Normal Mode	Red and Green LEDs blink 3 times
Setting error, cannot enter the Normal mode	Red LED is blinking constantly (Initialize the DS100)
In the Normal Mode : <ul style="list-style-type: none"> • Slave Routing Mode • Master Routing Mode <ul style="list-style-type: none"> • Destination IP-address is not reachable* • Destination IP-address is reachable* 	Green LED is constantly on Green LED is blinking Green LED is constantly on Red LED blinks momentarily
When buffer overflow is detected	Red LED blinks momentarily
In the Serial Programming mode	Green and Red LEDs are blinking (Green-Red-Green...)

*The DS100 is constantly sending pings to the [Destination IP-address](#) when in the [Master Routing Mode](#) (once in every 5 seconds). The Green Status LED is blinking if no reply is received. The Green Status LED is constantly on when the destination replies to pings.

3. DS100 operation (Normal Mode)

3.1. General information

The main function of the DS100 is to route the data between its Ethernet and serial ports. Routing means that the data received into the serial port is sent out via the Ethernet port and vice versa. Data routing is effected through two routing buffers, one for each routing direction.

The DS100 performs the routing in the *Normal Mode* of operation. A number of user-programmable *Settings* and *Parameters* define the way the DS100 works in the Normal Mode. Settings define *permanent functionality* of the DS100 and are programmed into the DS100 via its serial port in the [Serial Programming Mode](#) or via the network in the [Network Programming Session](#). Parameters are *temporary overrides* for certain Settings. Parameters can be changed via the network only. For more information see [Programming the DS100](#).

Ethernet port and network communications

The Ethernet port of the DS100 is of 10BaseT type. Just like any other Ethernet device each DS100 has a unique [Ethernet \(MAC\) Address](#) and must be assigned a valid [IP-address](#) to function properly on the network.

Logically, the DS100's network interface has two ports. A user-definable [Data Port](#) is used to exchange the data between the DS100 and other stations on the network. Another port called *Command Port* has a fixed number 65535 (FFFF Hex) and is used to send programming commands to the DS100's over the network.

The DS100 can exchange data with remote stations using the UDP/IP or TCP/IP transport protocols as defined by the [Transport Protocol](#) Setting. Depending on the [Routing Mode](#) Setting the DS100 can act as a network Slave or Master (see [Slave and Master routing modes](#) for details).

Other network-related settings include [Destination IP-address](#), [Destination Data Port Number](#), [Gateway IP-address](#), [Netmask](#), and [Connection Timeout](#) (see [Available Settings](#) for a complete description of all Settings).

Besides UDP and TCP protocols used for data transmission the DS100 also supports ARP and ICMP (ping) protocols. You can ping the DS100 just like any other device on the TCP/IP network.

Serial port

The serial port of the DS100 supports TX, RX, CTS, and RTS signals and can work at baudrates up to 115200. In the Normal Mode the serial port transmits the data between the DS100 and attached serial device. In the [Serial Programming Mode](#) the port is used to program the DS100's Settings.

Settings that define the operation of the serial port include the [Baudrate](#) (150~115200bps), [Parity](#) (none, even, or odd), [Bits Per Byte](#) (7 or 8), and [Flow Control](#) (none or CTS/RTS). Each of these Settings has a matching [Parameter](#) that overrides the value of a corresponding Setting. (see [Available Settings](#) for a complete description of all Settings).

Routing buffer

The data between the Ethernet port and the serial port is routed via two independent 255-byte buffers, one for each routing direction. Buffers are necessary because the Ethernet and the serial port operate at different speeds and in different ways. Ethernet carries the data in "packets" (i.e. groups of data), while the serial port sends and receives a serial "stream" where each data byte is independent. Here is how the DS100 transforms the Ethernet packets into the serial stream and back:

- **Ethernet →serial** data routing is simple: the DS100 outputs the contents of arriving Ethernet data packets byte by byte via the serial port. The DS100 does not check or filter the contents of data being routed in the Ethernet→serial direction
- **Serial →Ethernet** routing requires grouping arriving serial data into packets and is more complicated. Several Settings define exactly what serial data is accepted into the buffer and when

and how this data is combined into an Ethernet packet and sent out. Detailed information on the subject can be found in [Serial→Ethernet data routing](#).

3.2. Slave and Master routing modes

The DS100 routes the data in one of two modes as defined by the [Routing Mode](#) Setting:

- **In the Slave Routing Mode** the DS100 never sends any data transmission in the serial port→Ethernet direction before it receives some data from the remote station first (i.e. the data in the Ethernet→serial direction). The serial data received into the DS100's serial port before the remote station "contacts" the DS100 is discarded. In the Slave Mode the DS100 will "work" with any station on the network that contacts it;
- **In the Master Routing Mode** the DS100 does not wait for the remote station to send the data first and routes the data in the serial→Ethernet direction as soon as there is a data to be sent. The data is always sent to a specific destination (as defined by the [Destination IP-address](#) and [Destination Data Port Number](#) Settings of the DS100). Also, the DS100 only accepts the data sent from the remote station whose IP-address matches the one set in the [Destination IP-address](#). The DS100 will discard the data sent from any other IP. Note, that data port number of the sender is not verified so the data can be sent from any port.

When to use the Slave and Master Routing Modes

- **Use the Slave Routing Mode** to network-enable serial devices that never send out the data by themselves but instead are "polled" for data from the PC. Examples of such devices are time recorders, access control panels and other "hardware terminals".
- **Use the Master Routing Mode** to network-enable serial devices that send out the data "spontaneously" i.e. without waiting for the request from PC. Examples of such devices are barcode scanners and other "readers" that just output the data after each successful read.
- **Also use the Master Routing Mode** in cases when the serial data must flow independently in both directions (i.e. Ethernet→serial and serial→Ethernet). This is the case when you are creating a

virtual serial link over the TCP/IP network. Both sides of the link have DS100s pointing at each other. The link must work as a plain serial cable and this means that both DS100 must be in the Master Routing Mode.

Required network settings for the Slave and Master Routing Modes

- **In the Slave Routing Mode** the DS100 only "responds" to other stations on the network. When the DS100 receives the data from remote station it memorizes this station's IP-address and data port number. When routing the data in the serial→Ethernet direction the DS100 will reply to this IP-address and data port number. Therefore, the only network settings that must be set in the Slave Routing Mode are the DS100's own [IP-address](#) and the [Data Port Number](#). *This is true even if there is a router between the remote station and the DS100. You don't have to set the Netmask and Gateway IP when using the DS100 in the Slave Routing Mode;*
- **In the Master Routing Mode** the DS100 needs to be able to send the data to a predefined remote station at any time. This means that not only DS100's own [IP-address](#) and [Data Port Number](#) must be set but also the [Destination IP-address](#) and the [Destination Data Port Number](#). If the destination remote station and the DS100 are residing in different network segments then the [Netmask](#) and [Gateway IP-address](#) must also be set.

Slave and Master routing modes vs. UDP/IP and TCP/IP transport protocols

UDP/IP and TCP/IP provide completely different data transmission so DS100s behavior in the Slave and Master Routing Modes is slightly different under UDP/IP and TCP/IP [Transport Protocols](#).

- **UDP/IP [Transport Protocol](#)**
 - **Slave Routing Mode.** All UDP data packets arriving from any remote station and addressed to the [Data Port](#) of the DS100 are routed to the serial port. For the serial→Ethernet direction the DS100 always sends the data to the IP-address and the port number that were received in the last (latest) UDP packet. Once the DS100 receives a UDP packet from a different station it will start sending all its serial→Ethernet data to this new station. After power up and before the

DS100 receives the first UDP data packet the DS100 doesn't have any IP-address and port number to send the data to so all the data received into the DS100's serial port is simply discarded.

- **Master Routing Mode.** The DS100 only accepts and routes to the serial port the data packets that have originated from the remote station whose IP-address matches the one defined by the [Destination IP-address](#) Setting. Source data port number need not match the one defined by the [Destination Data Port Number](#) Setting so the packet can be sent from any port. Whenever the DS100 has the data to transmit in the serial→Ethernet direction it will send the data to the [Destination IP-address](#) and [Destination Data Port Number](#). *The packet will be sent to the [Destination Data Port Number](#) even if the packet received by the DS100 from the remote station originated at a different port. Therefore, it possible that the DS100 will be receiving the data from one port but sending it to another port!*
- **TCP/IP [Transport Protocol](#)**
 - **Slave Routing Mode.** The DS100 will accept an incoming TCP connection from any station on the network. The DS100 will not attempt to establish a connection with a remote station by itself even if the DS100 has the data to transmit in the serial→Ethernet direction. Once the remote station has established the connection the data can flow independently in either direction. Pending serial→Ethernet data received by the DS100 prior to the TCP connection establishment is discarded when the connection is established.
 - **Master Routing Mode.** The DS100 will both accept an incoming TCP/IP connection and attempt to establish a connection with the remote station by itself depending on which side sends that data first- remote station or attached serial device. Incoming TCP connection will only be accepted from a station whose IP-address matches the one defined by the [Destination IP-address](#) Setting of the DS100. Source port number need not match the one defined by the [Destination Data Port Number](#) Setting so the connection can be initiated from any port. When the DS100 needs to initiate a TCP/IP connection the it will attempt to connect to the [Destination IP-address](#) and [Destination Data Port Number](#). Once the connection has been established the data can flow independently in either direction. Note that unlike in case of

UDP/IP there will never be a situation when the DS100 receives the data from one port but sends the data to another port. Once the TCP/IP connection has been established both sides exchange the data using a single port on each side.

Connections with more than two nodes

In many real-life situations it is often necessary to have several PCs (network stations) access the same serial device through the DS100 ("many clients to one data source") or have many serial devices (each connected to the network via its own DS100) send the data to a single PC ("many data sources to one client").

An example of "many clients to one source" installation is a hardware terminal or sensor that can be polled for data from many PCs on the network. A typical "many sources to one client" situation is when several barcode scanners must send the data to a single PC on the network.

- **Many clients to one data source** operation is achieved by using the DS100 in the Slave Routing Mode. The DS100 will reply to any sender in this mode, so any station will be able to access the serial device attached to the DS100.
 - **UDP/IP [Transport Protocol](#)** should not be used if there is a chance that several different clients will send the requests to the same DS100/serial device at the same time. Data mix up will result on the serial side and the DS100 won't be able to route the data back to the respective sender of each command correctly.
 - **TCP/IP [Transport Protocol](#)** can be used safely since when one client is already connected to the DS100 others won't be able to gain access to the same DS100 until this client disconnects. To prevent one client from holding the TCP/IP connection to the DS100 indefinitely there is a [Connection Timeout](#) Setting that defines after how long the DS100 will abort the connection in case there is no data transfer in any direction.
- **Many data sources to one client** operation is achieved by using the DS100 in the Master Routing Mode. In this mode the DS100 will route all its serial→Ethernet data to the [Destination IP-address](#)

and [Destination Data Port Number](#). Any number of DS100s can be set to send the data to the same destination.

- **UDP/IP [Transport Protocol](#)** can be used in this arrangement but you must make sure that each serial data block output by the serial device (for instance, a complete barcode from a barcode scanner) is sent out in a single UDP packet. Potential data mix up can occur on the receiving end if the serial data block is transmitted in several UDP packets and several DS100 are sending data at the same time. The upside of using the UDP/IP is that you will only need to maintain one listening socket on the receiving end to get the data from all data sources (unless, of course, you want to distinguish between the data sources). Several DS100's Settings define how the incoming serial data is combined into Ethernet packets so you can make sure that the serial data block from your serial device is not split into several packets (see [serial→Ethernet data routing](#) for details).
- **TCP/IP [Transport Protocol](#)** can be used safely but you will have to maintain a separate socket on the receiving end for every data source sending the data.

3.3. Serial→Ethernet data routing

The DS100 provides a way to choose which incoming serial data is accepted into the serial→Ethernet buffer, how this data is combined into Ethernet packets and when it is sent out via the Ethernet port.

Serial data blocks

The DS100 treats all incoming serial data as a sequence of data blocks. The term “data block” here does not mean that the DS100 is only capable of working with a structured serial data. An absolutely random serial stream can also be processed- as one continuous infinite serial data block.

Serial data blocks begin when a *start condition* is detected and end when a *stop condition* is detected. After the start condition is detected the DS100 begins recording the incoming serial data into the serial→Ethernet buffer. Thus, the start condition is said to *open* the serial data block.

When the stop condition is detected the DS100 seizes recording the data into the buffer and attempts to send out all the data accumulated in the buffer via the Ethernet port. Therefore, the stop condition *closes* the serial data block. The inter-block serial data i.e. the data received after the stop condition is detected and before the next start condition is detected is discarded.

Besides the start and stop conditions there is also a *break condition*. When the break condition is detected the DS100 doesn't close the serial data block (i.e. it continues recording subsequent serial data into the serial→Ethernet buffer) but sends out the data already accumulated in the buffer through the Ethernet port. Break conditions provide a way to subdivide large serial data blocks.

Start conditions

The [Start On Any Character](#) Setting defines if the DS100 recognizes any character received into the serial port as a start condition or requires a predefined [Start Character](#) to open the serial data block. When [Start On Any Character](#) is set to “yes” the DS100 will accept any character following the end of the previous serial data block as the beginning of the next block.

When [Start On Any Character](#) is set to “no” the DS100 will only open the serial data block when one of the preset [Start Characters](#) is received. Up to three different [Start Characters](#) can be defined.

[Start Characters](#) received after the serial data block has been opened are treated as normal characters and do not “restart” the serial data block.

Stop conditions

Up to three different [Stop Characters](#) can be defined to close the serial data block.

Once one of the preset [Stop Characters](#) is detected the DS100 closes the serial data block and attempts to send out the contents of the serial→Ethernet buffer via the Ethernet port. All subsequent serial data is ignored until the next start condition is met.

The use of [Start Characters](#) and [Stop Characters](#) assumes that these characters will not be encountered in the data block body. Some communications protocols use checksums (or other forms of data

integrity verification). Checksum can potentially take any value and occasionally match the ASCII codes of the [Stop Characters](#). To avoid possible confusion some communications protocols put the checksum bytes *behind* the [Stop Characters](#). The DS100 deals with this by allowing to define a [Number Of Post-characters](#) for each enabled [Stop Character](#). For example, if the [Number Of Post-characters](#) for a certain [Stop Character](#) is set to 2 then the DS100 will additionally receive and count as belonging to the current serial data block 2 bytes of data after this [Stop Character](#) has been encountered.

Break conditions

The [Maximum Data Length](#) Setting defines the maximum number of data bytes in the serial→Ethernet buffer. (can be set between 32 and 255). Once this number is reached the DS100 attempts to send out the contents of the buffer via the Ethernet port. This Setting only works when the UDP/IP [Transport Protocol](#) is selected. This is because TCP/IP has its own way to determine what size of data chunks is best for transmission over the network.

The [Maximum Intercharacter Delay](#) Setting defines the maximum time gap between the arrival of two consecutive serial characters into the serial port (can be defined in 10ms increments between 10ms and 2.55 sec). Once this time is exceeded the DS100 attempt to send out the contents of the serial→Ethernet buffer via the Ethernet port. Setting the [Maximum Intercharacter Delay](#) to 0 disables the function.

Default start/stop/break configuration

By default (i.e. after the [Initialization](#)) the DS100 is configured to handle a random data stream that doesn't have any structure. To achieve this the [Start On Any Character](#) is set to "yes", no [Stop Characters](#) are defined, the [Maximum Intercharacter Delay](#) is set to 10ms, and the [Maximum Data Length](#) is set to 255 bytes (the latter is needed only for the UDP/IP [Transport Protocol](#)). As a result the very first byte received into the serial port is regarded as a beginning of the serial data block that never ends. Once there amount of data in the serial→Ethernet buffer reaches the limit or there is a gap in the serial transmission the DS100 combines all serial data it has already received and sends it out.

Practice shows that this arrangement works very well not only for a random data flow but also for structured data. Consider, for example, a case in which a hardware terminal attached to the DS100

exchanges the data with PC using command-reply communications protocol. In this situation every time the hardware terminal finishes transmitting a reply to the PC it starts waiting for the next command to process. This creates a gap in the serial data coming into the DS100's serial buffer. After a small delay of 10ms the DS100 routes the (end of) reply to the PC. The 10ms delay slows a system down a little bit but is, in fact, negligible for most serial applications.

3.4. Buffer-related issues

When using the DS100 be careful not to overflow its internal Ethernet→serial and serial→Ethernet buffers. The overflow can occur because of the difference in receive/transmission speeds on the Ethernet and the serial sides of the DS100 (Red Status LED blinks momentarily when overflow happens). In addition, the internal receiving buffer of the attached serial device can potentially overflow if the DS100 outputs the serial data too fast.

- **Ethernet→Serial buffer**
 - **UDP/IP [Transport Protocol](#).** The Ethernet→serial buffer can easily overflow because the Ethernet is much faster than the serial port and UDP/IP has no inbuilt protection against buffer overflows. UDP/IP should not be used to send continuous data flow and is only suitable for sending short data blocks that can fit in the buffer.
 - **TCP/IP [Transport Protocol](#)** has an inbuilt protection from buffer overflowing. You can safely send the data of any size.
- **Serial→Ethernet buffer.** The only way to protect the buffer is to enable the RTS/CTS [Flow Control](#) in the DS100 and on the attached serial device. This way the DS100 will be able to signal the serial device to stop transmitting the data once the buffer becomes full.
- **Internal receiving buffer of the attached serial device.** This buffer can also be protected by using the RTS/CTS to regulate the exchange of data between the DS100 and the serial device.

Using TCP/IP and RTS/CTS is the most reliable way of transmitting data through the DS100

4. Programming the DS100

4.1. General information

Settings and Parameters

The operation of the DS100 in the [Normal Mode](#) is controlled by a number of user-definable *Settings* and *Parameters*:

- **Settings** define the *permanent functionality* of the DS100. Settings are stored in the non-volatile memory and are preserved even when the DS100 is switched off. After having been changed new Setting values take effect only after the DS100 is restarted (rebooted)
- **Parameters** are *temporary overrides* for certain Settings. Changing Parameters have an immediate effect on the DS100 operation. Parameters are preserved only until the DS100 is switched off or restarted.

Ways of programming the DS100

The DS100 can be programmed in two different ways:

- **Through the serial port** of the DS100 in a [Serial Programming Mode](#)
- **Over the network** using UDP packets sent to a *command port* 65535 (FFFF Hex). This method is called [Network Programming](#)

There are several differences between the [Serial Programming Mode](#) and the [Network Programming](#):

- [Serial Programming Mode](#) is a separate mode of operation. The DS100 is not performing its data routing function when in the [Serial Programming Mode](#). In contrast the [Network Programming](#) is not a separate mode of operation but a *method* of programming. [Network Programming](#) can proceed in parallel with the normal operation of the DS100.

- Certain commands can only be executed through the network. Some commands have different result when executed in the [Serial Programming Mode](#) and through the [network](#) ([Initialize](#) command)
- [Serial Programming Mode](#) can always be entered, even when the DS100 is not properly setup and needs to be [Initialized](#). [Network Programming](#) can only be used when the DS100 is already functional.

Groups of commands

The DS100 is programmed using programming commands that fall into three categories:

- **Setup commands** are used to program the [Settings](#) of the DS100. Setup commands can be issued both in the [Serial Programming Mode](#) and using the [Network Programming](#), in a so-called [Network Setup Session](#).
- **Parameter commands** are used to change the [Parameters](#). These commands can only be sent over the [network](#).
- **Broadcast commands** are sent in the Ethernet broadcast mode and are used for automatic discovery of the DS100s on the network and over-the-network assignment of new IP-addresses. Naturally, the Broadcast commands can only be sent over the [network](#).

See [Available commands and replies](#) for a complete description of all commands.

4.2. Serial Programming Mode

Serial Programming Mode is a separate mode of operation that can only be used to edit [Settings](#) (via [Setup commands](#)). [Parameter commands](#) and [Broadcast commands](#) cannot be issued in the Serial Programming Mode.

Serial Programming is effected by sending commands to and receiving replies from the DS100's serial port.

Entering the Serial Programming Mode

There are two ways of entering the Serial Programming Mode:

- **By pressing either [Setup Button](#) while in the [Normal Mode](#).** This forces the DS100 to enter the Serial Programming Mode with default communications parameters of 38400-8-N-1, flow control="none".
- **By sending an escape sequence of three consecutive SOH (ASCII code 1) characters to the serial port ("soft entry").** The [Soft Entry](#) Setting of the DS100 defines if escape sequence will work. [Soft Entry](#) is disabled by default. Escape characters must be sent at a *current baudrate*. When entering the Serial Programming Mode through escape sequence the DS100 preserves the *current baudrate*, defined by the [Baudrate](#) Setting. However, the parity is still set to "none", number of bits- to 8, and the flow control- to "none" regardless of the values of [Parity](#), [Bits Per Byte](#), and [Flow Control](#) Settings.

The state of the RTS (output) line of the DS100 must be ignored when in the Serial Programming Mode. Therefore, you must disable the flow control on your PC (if you use PC to setup the DS100) or in the attached serial device (if the serial device does the programming) for the duration of the Serial Programming Mode.

Exiting Serial Programming Mode

You can exit the Serial Programming Mode either by switching the DS100 off and back on again or by using the [Exit](#) command. In both cases the DS100 restarts operation using the new Setting values.

Serial command and reply format

All commands sent to the DS100 in the Serial Programming Mode must have the following format:

STX (2)	Command code	Setting name (if any)	Setting value (if any)	CR (13)
---------	--------------	-----------------------	------------------------	---------

STX (ASCII code 2) and **CR** (ASCII code 13) provide necessary encapsulation. **Command code** field always consists of one character (i.e. "S", "G", etc.). **Setting name** and **Setting value** fields are only required for certain commands. **Setting name** always consists of two characters (i.e. "BR", "SA", etc.). **Setting value** format depends on the type of Setting.

All replies returned by the DS100 in the Serial Programming Mode have the following format:

STX (2)	Reply code	Setting value (if any)	CR (13)
---------	------------	------------------------	---------

Reply code is always present and informs you of the command processing status (OK, failed, etc.). **Setting value** field is only present for commands that return Setting values.

4.3. Network Programming

[Setup commands](#), [Parameter commands](#), and [Broadcast commands](#) can all be sent over the network. [Parameter commands](#) and [Broadcast commands](#) can be sent at any time. Executing [Setup commands](#) requires a *Network Setup Session* to be opened first.

Network programming is effected by sending commands to and receiving replies from the command port (65535 or FFFF Hex) of the DS100. Each command and reply must be sent in its own UDP packet.

Opening Network Setup Session (Login)

The Network Setup Session is opened by logging in using a [Login](#) command. Correct password matching that defined by the [Login Password](#) Setting must be supplied. Login command must be used even if the [Login Password](#) is set to NULL (default after the [Initialization](#)).

If you forgot the password you can use the [Serial Programming Mode](#) to set a new password since the [Serial Programming Mode](#) is not password-protected.

Closing Network Setup Session

Network Setup Session is closed either by switching the DS100 off and back on again or by using an [Exit](#) command. In both cases the DS100 restarts operation using the new Setting values.

Command and reply format for Setup and Parameter commands

The format of [Setup](#) and [Parameter Commands](#) and replies sent via the network is similar to that of [Setup commands](#) and replies exchanged in the [Serial Programming Mode](#) with the only exception that STX and CR characters are not required- sending each command and reply in a separate UDP packet provides a necessary encapsulation already.

[Setup](#) and [Parameter Commands](#) have the following format:

Command code	Setting/Parameter name	Setting/Parameter value
--------------	------------------------	-------------------------

Command code field always consists of one character (i.e. "S", "G", etc.). **Setting/Parameter name** field and **Setting/Parameter value** fields are optional and only required for certain commands. **Name** always consists of two characters (i.e. "BR", "SA", etc.). **Value** format depends on the type of Setting/Immediate.

All replies sent by the DS100 over the network have the following format:

Reply code	Setting/Parameter value
------------	-------------------------

Reply code field is always present and informs you of the command processing status (OK, failed, etc.). **Setting/Parameter value** field is only present for replies that return values.

Format of Broadcast commands

[Broadcast commands](#) have no unified format. Format of each [Broadcast command](#) and corresponding reply is described in [Available commands](#).

5. Available commands and replies

5.1. List of commands

Code	S	N	B	L	Description
Setup commands					
L		+			Login (open Network Setup Session)
S	+	+		+	Set (write) new Setting value
G	+	+		+	Get (read) current Setting value
I	+	+		+	Initialize (restore Settings to their default factory values)
E	+	+		+	Exit Serial Programming Mode/Network Setup Session (restart the DS100)
V	+	+			Get firmware version
Parameter commands					
P		+			Change Parameter value
Broadcast commands					
X		+	+		Request echo from all listening DS100s
A		+	+		Assign new IP-address to the DS100 with the specified Ethernet address

Columns: "S"- command is available in the [Serial Programming mode](#); "N" -command can be issued through the [network](#); "B"- command can be issued through the [network](#) in broadcast mode; "L"- when issued through the [network](#) this command requires prior [login](#) ([Network Setup Session](#) must be opened first).

5.2. List of possible reply codes

Code	Description
A	Completed successfully, may be followed by data (if this command returns data)
C	Invalid command, Setting/Parameter name, or Setting/Parameter value
F	Command execution failed (internal error or malfunction)
D	Access denied. This reply code can only be sent in response to a network command. It means that you haven't logged in properly or have supplied an incorrect Login Password .

5.3. Detailed Command description

Command and reply strings below are shown without STX and CR characters. STX/CR encapsulation is required when sending commands via the serial port (see [Serial command and reply format](#) for details).

Login (L)

Opens [Network Setup Session](#) for the programming of DS100's Settings over the network

Command format: "**L***ppp...p*", where *ppp...p*- login password

Possible replies: "A", "F", "D"

Can be issued through the [network](#) only (broadcast not allowed)

Login password is defined by the [Login Password](#) Setting. Default password is NULL but login is still required to open the [Network Setup Session](#).

F reply may happen because of the DS100's internal malfunction (for example, inability to retrieve current password from the non-volatile memory). D reply code is returned when the supplied password is incorrect.

Set (S)

Set (write) new Setting value

Command format: "**S***nnvvv...v*", where *nn*- Setting name, *vvv...v*- Setting value

See [Available Settings](#) for a complete description of Settings

Possible replies: "A", "C", "F", "D"

Can be issued in the [Serial Programming Mode](#) or through the [network](#) in the [Network Setup Session](#) (broadcast not allowed, prior login required)

C reply code is returned if the Setting name is incorrect or new Setting value is invalid (out of range, has invalid formatting, etc.). **F** reply may happen because of the DS100's internal malfunction (for example, failure to save new Setting value into the non-volatile memory). **D** reply code is returned when command is issued through the [network](#) and the [Network Setup Session](#) is not opened (i.e. without prior login).

Example. Set the [IP-address](#) of the DS100 to "192.168.100.40":

```
SIP192.168.100.40
A
```

Get (G)

Get (read) current Setting value

Command format: "**Gnn**", where **nn**- Setting name

See [Available Settings](#) for a complete description of Settings

Possible replies: "**A***vvv...v*", "**C**", "**F**", "**D**", where *vvv...v*- Setting value

Can be issued in the [Serial Programming Mode](#) or through the [network](#) in the [Network Setup Session](#) (broadcast not allowed, prior login required)

C reply code is returned if the Setting name is incorrect. **F** reply is returned when current Setting value is invalid or could not be retrieved (situation can be rectified by setting correct value using the [Set](#) command or using the [Initialize](#) command to restore all Settings to their default factory values). **D** reply code is returned when command is issued through the [network](#) and the [Network Setup Session](#) is not opened (i.e. without prior login).

Example. Get the [IP-address](#) of the DS100:

```
GIP
A192.168.100.40
```

Initialize (I)

Initializes the DS100 (restores all Settings to their default factory values)

Command format: "**I**"

Possible replies: "**A**", "**F**", "**D**"

Can be issued in the [Serial Programming Mode](#) or through the [network](#) in the [Network Setup Session](#) (broadcast not allowed, prior login required)

This command performs the following: (1) all Settings are restored to their default values with the following exceptions: (a) [Factory Ethernet address](#) is not initialized (because it contains unique address set by the factory), and (b) [IP-address](#) and [Current Ethernet Address](#) of the DS100 is not initialized in case this command is issued through the [network](#); (2) in case the command is issued in the [Serial Programming Mode](#) the value of the [Factory Ethernet address](#) Setting is copied into the [Current Ethernet address](#) Setting.

If this command fails (**F** reply code), this maybe because the [Factory Ethernet address](#) Setting contains invalid value. In this case initialize it first by setting any address you can think of (i.e. "204.134.165.0.44.55") **but make sure that the first number is even**, then try to use the Initialize command again. **D** reply code is returned when command is issued through the [network](#) and the [Network Setup Session](#) is not opened (i.e. without prior login).

Exit (E)

Exits the [Serial Programming Mode](#) or [Network Setup Session](#), also restarts the DS100 which puts new Setting values into effect

Command format: "**E**"

Possible replies: no reply in case of success, "**D**"

Can be issued in the [Serial Programming Mode](#) or through the [network](#) in the [Network Setup Session](#) (broadcast not allowed, prior login required)

No reply is returned in case of successful execution because the DS100 restarts. **D** reply code is returned when command is issued through the [network](#) and the [Network Setup Session](#) is not opened (i.e. without prior login).

Get firmware version (V)

Gets firmware version of the currently loaded firmware

Command format: "**V**"

Possible replies: "**Avvv...v**", where **vvv...v** - version string

Can be issued in the [Serial Programming Mode](#) or through the [network](#) (broadcast not allowed, prior login is not required)

The version string is always encapsulated in "<" and ">" characters, begins with the version number in the "X.XX" format and possibly contains a small comment after a space. Version numbering follows this system: change in the first digit- major release, change in the second digit- new minor features or alterations, change in the third digit- bug fixes but no functionality changes.

Example:

```
V
A<V2.20 RELEASE2 final>
```

Parameter (P)

Changes Parameters of the DS100

Command format: "**Pppv**", where **pp**- parameter, **v**- value if any

See [Available Parameters](#) for a complete description of Parameters

Possible replies: "**A**", "**C**", "**D**"

Can be issued through the [network](#) only (broadcast not allowed, prior login not required)

The DS100 only accepts Parameter command when the [Remote Control](#) is set to "yes".

C reply code is returned if supplied parameter name or value is incorrect. **D** reply code is returned if command is rejected because the [Remote Control](#) is set to "no".

Echo (X)

Request Echo from all listening DS100s

Command format: "**X**"

Possible replies: "**Aether_addr/port_num**", where **ether_addr** is [Current Ethernet Address](#) of the DS100, **port_num**- current [Data Port Number](#)

Can be issued through the [network](#) only (broadcast mode should be used)

This command can be utilized to auto-detect all the DS100s on a local network segment. When sent in the broadcast mode it reaches all locally attached DS100s. Each DS100 then replies with its [Current Ethernet Address](#) and [Data Port Number](#) ([IP-address](#) is not returned because it is already contained in the IP-packet's header). Reply will reach the sender even when the [IP-address](#) of the DS100 is not valid. Ethernet address of each particular DS100 is needed for an over-the-network assignment of the new IP-address to the designated DS100 using the [Assign](#) command.

It is noteworthy that broadcast packets cannot penetrate routers, bridges, etc. and, therefore, are confined to a local network segment. Consequently, it is impossible to use this command to discover the DS100s outside the local network segment.

Example:

```
X
A192.168.100.40/1001
```

Assign (A)

Assign new IP-address to the DS100 with the specified Ethernet (MAC) address

Command format: "**Aether_addr**/**password****ip_addr**", where **ether_addr**- Ethernet (MAC) address of the DS100 that is to be assigned a new IP-address, **password**- [Login Password](#) for this DS100, **ip_addr**- new [IP-address](#) to be assigned.

Possible replies: this command is never replied to

Can be issued through the [network](#) only (broadcast mode should be used)

This command is used to assign a new IP-address to the DS100 with specific Ethernet (MAC) address. When sent in the broadcast mode this command reaches all locally attached DS100s. Only the DS100 whose [Current Ethernet Address](#) matches that in the **ether_addr** field of the command will change its [IP-address](#) to **ip_addr** value (provided that correct [Login Password](#) has been supplied in the **password** field). This command is never replied to but its result can be verified using [Echo](#) command.

This command is useful when you need to assign a valid IP-address to the uninitialized DS100. Using the [Set](#) command to change the [IP-address](#) Setting of the DS100 is not possible at this time since executing this command requires the DS100 to have a valid IP-address already. Having to supply a valid password is usually not an issue since uninitialized (ex-factory) DS100 have a NULL password.

It is noteworthy that broadcast packets cannot penetrate routers, bridges, etc. and, therefore, are confined to a local network segment. Consequently, it is impossible to assign a new IP-address using this command to the DS100s outside the local network segment.

Example: set the IP-address of the DS100 whose Ethernet address is 0.1.2.3.4.5 and login password is "pwd1" to 192.168.100.40

A0.1.2.3.4.5/pwd1/192.168.100.40

6. Available Settings

6.1. List of Settings by groups

The following is a complete list of all available Settings. Setting values are set and retrieved using [Set](#) and [Get](#) commands:

Code	Description
Network-related Settings	
RM	Routing mode (slave/master)
IP	IP-address of the DS100
DI	Destination IP-address. Only relevant in the Master Routing Mode
PN	Data Port Number of the DS100 (0...65534)
DP	Destination Data Port Number (0...65535). Only relevant in the Master Routing Mode
TP	Transport Protocol (UDP/TCP)
CT	Connection Timeout (never/1...255min). Only relevant with TCP Transport Protocol
GI	Gateway IP-address. Only relevant in the Master Routing Mode
NM	Netmask. Only relevant in the Master Routing Mode
PW	Login Password for the Network Setup Session
Serial port-related Settings	
BR	Baudrate (150/300/1200/2400/4800/9600/19200/38400/57600/115200bps)
PR	Parity (none/even/odd)
BB	Bits Per Byte (7/8)
FC	Flow Control (none/RTS-CTS)
RC	Remote Control of DS100's Parameters via Parameter Commands (enable/disable)
SE	Soft Entry (by escape sequence) into the Serial Programming Mode (enable/disable)
Serial→Ethernet routing Settings	
ML	Maximum Data Length (32...255bytes). Only relevant with UDP Transport Protocol
MD	Maximum Intercharacter Delay (disabled/10...2550ms)

SA	Start On Any Character (no/yes)
F1, F2, F3	Start Characters, Enable/Disable. Not relevant when Start On Any Character= "yes"
S1, S2, S3	Start Characters, ASCII code. Not relevant when Start On Any Character= "yes"
U1, U2, U3	Stop characters, Enable/Disable
E1, E2, E3	Stop characters, ASCII code
P1, P2, P3	Stop characters, Number Of Post-characters
System Settings	
EA	Current Ethernet (MAC) address
FE	Factory (default) Ethernet (MAC) address
SI	Serial Interface (full-duplex/half-duplex/auto)

6.2. Detailed Setting description

Routing Mode (RM)

Selects [Slave or Master Routing Mode](#)

Set command format: "**SRM***x*", where *x*- 0- Slave Routing Mode, 1- Master Routing Mode

Get command format: "**GRM**"

Default: 0 (Slave)

See also: ---

IP-address (IP)

Defines own IP-address of the DS100

Set command format: "**SIP***ip_addr*", where *ip_addr* must be in the "dot-decimal" format, i.e. "192.168.100.40"

Get command format: "**GIP**"

Default: 127.0.0.1

See also: [Ethernet port and network communications](#)

Destination IP-address (DI)

Defines the Destination IP-address. Only relevant in the [Master Routing Mode](#)

Set command format: "**SDI***ip_addr*", where *ip_addr* must be in the dot-decimal format, i.e. "192.168.100.40"

Get command format: "**GDI**"

Default: 127.0.0.2

See also: [Ethernet port and network communications](#)

Data Port Number

Defines own data port number for the DS100

Set command format: "**SPN***port_num*", where *port_num* must be in the 0...65534 range

Get command format: "**GPN**"

Default: 1001

Port number 65535 cannot be used since it is reserved for a command port.

See also: [Ethernet port and network communications](#)

Destination Data Port Number

Defines the destination data port number. Only relevant in the [Master Routing Mode](#)

Set command format: "**SDP***port_num*", where *port_num* must be in the 0...65535 range

Get command format: "**GDP**"

Default: 1001

See also: [Ethernet port and network communications](#)

Transport Protocol (TP)

Selects UDP/IP or TCP/IP communications protocol for data transmission

Set command format: "**STP*t***", where *t*- 0- UDP/IP protocol, 1- TCP/IP protocol

Get command format: "**GTP**"

Default: 0 (UDP/IP)

See also: [Ethernet port and network communications](#), [Slave and Master routing modes vs. UDP/IP and TCP/IP transport protocols](#), [Buffer-related issues](#)

Connection Timeout (CT)

Specifies timeout (in minutes) for the TCP/IP connection in case no data is transmitted in any direction

Set command format: "**SCT*tout***", where *tout* is the connection timeout in minutes (0-255). Value of 0 disables this function (connection never times out)

Get command format: "**GCT**"

Default: 5 (5 minutes)

When no data is exchanged across the TCP/IP connection for a specified number of minutes the DS100 will abort the connection automatically (by sending a RESET packet). This Setting prevents an idle client (connection) from "holding" the DS100 indefinitely.

See also: [Ethernet port and network communications](#), [Connections with more than two nodes](#) (many clients to one data source under TCP/IP [Transport Protocol](#))

Gateway IP-address (GI)

Defines the IP-address of the default gateway. Only relevant in the [Master Routing Mode](#)

Set command format: "**SIP*gateway_ip***", where *gateway_ip* must be in the "dot-decimal" format, i.e. "192.168.100.40"

Get command format: "**GGI**"

Default: 127.0.0.1

Defines the IP-address of the default gateway to which the DS100 sends the data in case the [Destination IP-address](#) is not on the local network segment. Whether the [Destination IP-address](#) is local or not is defined by the [Netmask](#) Setting.

See also: [Ethernet port and network communications](#)

Netmask (NM)

Defines the IP-address range for the local network segment. Only relevant in the [Master Routing Mode](#)

Set command format: "**SNM*netmask***", where *netmask* must be in the "dot-decimal" format, i.e. "255.255.255.0"

Get command format: "**GNM**"

Default: 0.0.0.0 (any [Destination IP-address](#) is considered to be local)

The Netmask defines whether the [Destination IP-address](#) is considered to be on the local network segment or foreign network segment. In the latter case the DS100 sends the data to the default [Gateway IP-address](#) rather than to the [Destination IP-address](#) directly.

See also: [Ethernet port and network communications](#)

Login Password (PW)

Defines login password for the [Network Setup Session](#)

Set command format: “**SPW***password*”, where *password* is the login password (0-6 characters long, valid characters are those with ASCII codes in the 32...127 range).

Get command format: “**GPW**”

Default: NULL

You need to [Login](#) even when the password is set to NULL (i.e. password has a zero length).

See also: ---

Baudrate (BR)

Sets the baudrate of the DS100's [serial port](#). Can be overridden by the [Baudrate](#) Parameter.

Set command format: “**SBR***b*”, where *b*: 0-.1200bps, 1- 2400bps, 2- 4800bps, 3- 9600bps, 4- 19220bps, 5- 38400bps, 6- 57600bps, 7- 115200bps, 8- 150bps, 9- 300bps, 10- 600bps

Get command format: “**GBR**”

Default: 5 (38400bps)

See also: ---

Parity (PR)

Selects the parity mode of the DS100's [serial port](#). Can be overridden by the [Parity](#) Parameter.

Set command format: “**SPR***p*”, where *p*: 0-.Disabled, 1- Even, 2- Odd

Get command format: “**GPR**”

Default: 0 (Disabled)

See also: ---

Bits Per Byte (BB)

Defines the bits/byte mode of the DS100's [serial port](#). Can be overridden by the [Bits Per Byte](#) Parameter.

Set command format: “**SBB***b*”, where *b*: 0-.7 bits/byte, 1- 8 bits/byte

Get command format: “**GBB**”

Default: 1 (8 bits/byte)

See also: ---

Flow Control (FC)

Selects the flow control mode for the DS100's [serial port](#). Can be overridden by the [Flow Control](#) Parameter.

Set command format: “**SFC***f*”, where *f*: 0-.none, 1- RTS/CTS (hardware)

Get command format: “**GFC**”

Default: 0 (none)

You are recommended to choose the RTS/CTS flow control whenever possible

See also: [Buffer-related issues](#)

Remote Control (RC)

Enables/Disables DS100's Parameter changing through the [Parameter](#) command

Set command format: “**SRC***p*”, where *p*: 0-.Disabled, 1- Enabled

Get command format: “**GRC**”

Default: 1 (Enabled)

See also: ---

Soft Entry (SE)

Enables/disables entry into the [Serial Programming Mode](#) by [escape sequence](#)

Set command format: “**SSEs**”, where **s**: 0-Disabled, 1- Enabled

Get command format: “**GSE**”

Default: 0 (Disabled)

See also: ---

Maximum Data Length (ML)

Defines the amount of data in the serial→Ethernet buffer at which the [break condition](#) will be generated and the contents of the buffer will be sent out via the Ethernet port. Only relevant when the UDP/IP [Transport Protocol](#) is selected

Set command format: “**SMLlen**”, where **len** is the length of data in bytes (32-255)

Get command format: “**GML**”

Default: 255

See also: [Serial→Ethernet data routing](#) ([Break conditions](#))

Maximum Intercharacter Delay (MD)

Defines the time gap after the arrival of the most recent serial character into the serial port which, when exceeded, leads to a [break condition](#) and makes the DS100 send out the contents of the serial→Ethernet buffer via the Ethernet port

Set command format: “**SMDdel**”, where **del** is the maximum intercharacter delay (0-255). Value of 0 disables this function. Actual delay is calculated as *del* X 10ms, i.e. it can be in the 10-2550ms range.

Get command format: “**GMD**”

Default: 1 (10 ms)

See also: [Serial→Ethernet data routing](#) ([Break conditions](#))

Start On Any Character (SA)

Defines if the next [serial data block](#) is [opened](#) on any character received or only when one of pre-defined [Start Characters](#) is received

Set command format: “**SSAs**”, where **s**: 0- No (new [serial data block](#) is [opened](#) on predefined [Start Characters](#) only), 1- Yes (new [serial data block](#) is [opened](#) on any character)

Get command format: “**GSA**”

Default: 1 (Yes)

See also: [Serial→Ethernet data routing](#) ([Start conditions](#))

Start Character, Enable/Disable (F1, F2, F3)

Three separate Settings to enable/disable start characters 1, 2, and 3 (ASCII codes of start characters are defined by [Start character, ASCII Code](#) Settings). Not relevant when [Start On Any Character](#) is set to “yes”

Set command format: “**SF1e**”, “**SF2e**”, “**SF3e**”, where **e**: 0- Disabled, 1- Enabled

Get command format: “**GF1**”, “**GF2**”, “**GF3**”

Default: 0 (Disabled)

See also: [Serial→Ethernet data routing](#) ([Start conditions](#))

Start Character, ASCII Code (S1, S2, S3)

Three separate Settings to define the ASCII codes of start characters 1, 2, and 3 (start characters are enabled/disabled through [Start Character, Enable/Disable](#) Settings). Not relevant when [Start On Any Character](#) is set to “yes”

Set command format: “**SS1c**”, “**SS2c**”, “**SS3c**”, where **c** is an ASCII code of the start character (0-255)

Get command format: “**GS1**”, “**GS2**”, “**GS3**”

Default: 0

See also: [Serial→Ethernet data routing](#) ([Start conditions](#))

Stop Character, Enable/Disable (U1, U2, U3)

Three separate Settings to enable/disable stop characters 1, 2, and 3 (ASCII code of stop characters are defined by [Stop character, ASCII Code](#) Settings)

Set command format: “**SU1e**”, “**SU2e**”, “**SU3e**”, where **e**: 0- Disabled, 1- Enabled

Get command format: “**GU1**”, “**GU2**”, “**GU3**”

Default: 0 (Disabled)

See also: [Serial→Ethernet data routing](#) ([Stop conditions](#))

Stop Character, ASCII Code (E1, E2, E3)

Three separate Settings to define the ASCII codes of stop characters 1, 2, and 3 (stop characters are enabled/disabled through [Stop character, Enable/Disable](#) Settings)

Set command format: “**SE1c**”, “**SE2c**”, “**SE3c**”, where **c** is an ASCII code of the stop character (0-255)

Get command format: “**GE1**”, “**GE2**”, “**GE3**”

Default: 0

See also: [Serial→Ethernet data routing](#) ([Stop conditions](#))

Stop Character, Number of Post Characters (P1, P2, P3)

Three separate Settings to define the number of post characters to follow stop characters 1, 2, and 3 (ASCII codes of stop characters are defined by [Stop character, ASCII Code](#) Settings, stop characters are enabled/disabled through [Stop character, Enable/Disable](#) Settings)

Set command format: “**SP1n**”, “**SP2n**”, “**SP3n**”, where **n** in a number of Post-characters (0-255)

Get command format: “**GP1**”, “**GP2**”, “**GP3**”

Default: 0

See also: [Serial→Ethernet data routing](#) ([Stop conditions](#))

Current Ethernet Address (EA)

Defines current Ethernet (MAC) address of the DS100

Set command format: “**SE Ae_addr**”, where **e_addr** must be in the “dot-decimal” format, i.e. “100.101.102.103.104.105”.

Get command format: “**GEA**”.

Default: copied from the [Factory Ethernet address](#) Setting

This Ethernet address is used by the DS100 during operation.

See also: [Initialize \(I\)](#)

Factory Ethernet Address (FE)

Keeps default Ethernet address

Set command format: “**SFE e_addr**”, where **e_addr** must be in the “dot-decimal” format, i.e. “1.2.3.4.5.6”

Get command format: “**GFE**”

Default: unique number for each DS100 produced

This Setting contains a default Ethernet address assigned to a particular DS100 during production. **Tibbo Technology** initializes each DS100 to different Ethernet address number. You are advised to never change it. If you want to change the Ethernet address of the DS100 do this by changing the value of the [Current Ethernet Address](#) Setting. During the [Initialization](#), the value of this Setting is copied into the [Current Ethernet Address](#) thus restoring factory Ethernet address for use.

See also: [Initialize](#)

Serial Interface (SI)

Selects full-duplex or half-duplex mode for serial interface

Set command format: “**SSI*i***”, where *i*: 0- RS232, 1- RS485, 2- Auto

Get command format: “**GSI**”

Default: 2 (Auto)

For the DS100 to operate properly, always keep this Setting at “Auto” (as selected by default)

7. Available Parameters

7.1. List of Parameters

The following is a complete list of all available Parameters. Parameters are set using [Parameter](#) command:

Name	Description
BR	Baudrate (150/300/1200/2400/4800/9600/19200/38400/57600/115200bps)
PR	Parity (none/even/odd)
BB	Bits Per Byte (7/8)
FC	Flow Control (none/RTS-CTS)

7.2. Detailed Parameter description

Baudrate (BR)

Changes current baudrate of the DS100's [serial port](#). This Parameter overrides the [Baudrate](#) Setting

Command format: “**PBR*b***”, where *b*: 0- 1200bps, 1- 2400bps, 2- 4800bps, 3- 9600bps, 4- 19220bps, 5- 38400bps, 6- 57600bps, 7- 115200bps, 8- 150bps, 9- 300bps, 10- 600bps

See also: ---

Parity (PR)

Changes current parity mode of the DS100's [serial port](#). This Parameter overrides the [Parity](#) Setting

Command format: “**PPR*p***”, where *p*: 0- Disabled, 1- Even, 2- Odd

See also: ---

Bits Per Byte (BB)

Changes current bits/byte mode of the DS100's [serial port](#). This Parameter overrides the [Bits Per Byte](#) Setting

Command format: "**PBB**b****", where **b**: 0-.7 bits/byte, 1- 8 bits/byte

See also: ---

Flow Control (FC)

Changes current flow control mode of the [serial port](#). This Parameter overrides the [Flow Control](#) Setting

Command format: "**PFC**f****", where **f**: 0-.none, 1- RTS/CTS

See also: ---

8. Firmware Download Mode

Internal firmware of the DS100 can be upgraded in the field. We are constantly working on the DS100 functionality enhancement, so new firmware versions are released quite often. New firmware versions are posted at www.tibbo.com. You are advised to register at our site so we can let you know when the new firmware becomes available.

Red Status LED is blinking after you have downloaded new firmware and the DS100 doesn't seem to work? [You have forgotten to initialize the DS100!](#)

8.1. Downloading new firmware file

New firmware file is downloaded into the DS100 through its RS232 port. To download the firmware file you'll need any PC software that supports an XMODEM communications protocol (checksum version). Suitable software packages are *Term95* (part of a *Norton Commander* package), *QMODEM* (a very popular DOS program), and a *HyperTerminal*. The latter is especially widespread because it comes with every *Windows* distribution. Procedures below assume the use of *HyperTerminal* for *Windows*.

The *HyperTerminal* is normally found in the *Start*→ *Programs*→ *Accessories*→ *Communications*→ *HyperTerminal* folder. If it is not there, then you must have opted it out when installing *Windows* on your PC. Follow the instructions below to add *HyperTerminal* to your system (be sure to have your *Windows* distribution CD handy!):

- Go to the *Control Panel* (*Start*→ *Settings*→ *Control Panel*) and double-click on the *Add/Remove Programs* icon- the *Add/Remove Programs* dialog will open
- Click on *Windows Setup* tab to view the list of optional installation components
- Choose *Communications* in the *Components* list and click *Details*
- In the *Communications* window, select the *HyperTerminal* (it must be "checked")
- Press *OK* to close *Communications* window, press *OK* again to close *Add/Remove Programs*

47

- You will possibly be asked to insert the *Windows* CD at this point. Do this and follow the instructions on the screen.

Once the *HyperTerminal* is installed, follow the procedures below to download new firmware file into the DS100:

- Switch the DS100 off
- Connect the DS100's Serial port to the PC using [WAS-1455](#) or similar cable
- Launch the *HyperTerminal* and configure it as follows:
 - When the *Connection Description* dialog opens, type any descriptive string (like "DS100") and press *OK*
 - When the *Connect to* dialog opens, select an appropriate COM port from the *Connect Using* drop-down box (for example, "Direct to COM1")
 - When the *COM Properties* dialog appears, set communications parameters as follows: *Bits per second*: 38400, *Data bits*: 8, *Parity*: None, *Stop bits*: 1, *Flow control*: None. Click *OK* when done- the *HyperTerminal's* main window will appear
 - Now choose *File→Properties* from the *Main* menu- the *Properties* dialog will appear
 - Click on the *Settings* tab and press the *ASCII Setup* button- the *ASCII Setup* dialog will open
 - Check (enable) three options: *Echo typed characters locally*, *Send line feeds with line ends*, and *Append line feeds to incoming line ends*
 - Click *OK* twice to close both dialogs
 - *Optional*: you may want to save this *HyperTerminal* configuration for the future use. This way you won't have to go through this elaborate setup again next time. Choose *File→Save* from the *Main* menu to save this configuration under the filename you've chosen for your connection

48

- Choose *Transfer→ Send file* from the *Main* menu- the *Send file* dialog will appear
- In the *Send file* dialog, select the firmware file that you want to download into the DS100 and choose the *Xmodem protocol* from the *Protocol* drop-down box. Click *OK* when finished
- The *Xmodem file send* for a dialog will be displayed
- Press either [Setup Button](#) on the back of the DS100 and power the DS100 up while keeping the Button pressed- the download will start. You may release the Button at this point
- DS100's Green Status LED is blinking during the download, and the *HyperTerminal* shows the file transfer progress
- When the download is finished, switch the DS100 off and back on again. If the Red Status LED starts blinking this means that the DS100's Settings need to be initialized. Do not exit the *HyperTerminal* and proceed to the next Section for further instructions

8.2. Initializing the DS100

[Initialize](#) command is used to initialize the DS100 after the new firmware download.

- Make sure the DS100 is powered up and press either [Setup Button](#). The DS100 will enter the [Serial Programming Mode](#)
- In the *HyperTerminal* window type <CTRL+B> followed by capital "I" and press <ENTER> key. Pressing <CTRL+B> sends an STX character (appears on the *HyperTerminal's* screen as a "smiley face") while pressing <ENTER> sends CR character (see [Serial command and reply format](#) for more information)
- The DS100 should reply with STX-"A"-CR which means that command was completed successfully. The whole dialog should look like this:

☺I

☺A

- Switch the DS100 off and back on again- the DS100 should start normal operation.

8.3. Possible download problems and LED signaling

A number of errors can occur when downloading new firmware file. All errors are expressed as Red Status LED signals (“blinking patterns”):

One long signal	Timeout while waiting for the data from PC
One long + one short signal	Communications error (XMODEM error)
One long + two short signals	File is too big and cannot fit in the DS100s memory
One long + three short signals	DS100 program memory (FLASH) failure

Every time you power the DS100 up its internal firmware is checked for being valid. If the firmware is valid, the DS100 starts normal operation. If the firmware you have downloaded is not valid then one of the following may occur:

- If you’ve been downloading a correct firmware file but the download wasn’t finished, then the DS100 will blink its Red and Green Status LEDs rapidly
- If you’ve downloaded a wrong file, then the DS100 will not show “any signs of life” on startup.



In both cases, make sure you are trying to download correct firmware file and repeat the downloading process.

9. I/O Connector pin assignment & Cable wiring

9.1. DS100 I/O connector pin assignment

The DS100 has one 10BaseT (Ethernet) port and one RS232 (Serial) port. Pin assignment is shown in the table below:

To avoid common confusion, all pins are designated as inputs and outputs with respect to the DS100.

RS232M (Serial) port		10BaseT (Ethernet) port	
			
#1	No connection	#1	TX+
#2	RX (Input)	#2	TX-
#3	TX (Output)	#3	RX+
#4	No connection	#4	No connection
#5	Ground	#5	No connection
#6	No connection	#6	RX-
#7	RTS (Output)	#7	No connection
#8	CTS (Input)	#8	No connection
#9	No connection		

9.2. RS232 cable wiring

There are two kinds of RS232 cable suitable for use with the DS100: DS100-to-Device (WAS-1404) and DS100-to-PC (WAS-1455). You can use your own cable in case the standard one is not suitable. Cable wiring is presented in the table below:

DS100-to-Device (WAS-1404)		DS100-to-PC (WAS-1455)	
DB9M (Male)	DB9F (Female)	DB9F (Female)	DB9F (Female)
#2 ←	→ #2	#2 ←	→ #3
#3 ←	→ #3	#3 ←	→ #2
#5 ←	→ #5	#5 ←	→ #5
#7 ←	→ #7	#7 ←	→ #8
#8 ←	→ #8	#8 ←	→ #7

Important note: you need to have a DS100-to-PC cable to be able to [download new firmware](#).

9.3. Ethernet cable wiring

Most Ethernet installations require cables of substantial and variable length, so you will probably need to make your own cables. For testing purposes **Tibbo** supplies two kinds of Ethernet cables: device-to-hub (WAS-1499) for connections through a standard Ethernet hub, and device-to-device (WAS-1498) for connections without a hub (i.e. directly from one Ethernet device to another).

Device-to-hub (WAS-1499)	
Side A	Side B
#1 ← (*)	→ #1
#2 ← (*)	→ #2
#3 ← (**)	→ #3
#4 ←	→ #4
#5 ←	→ #5
#6 ← (**)	→ #6
#7 ←	→ #7
#8 ←	→ #8

(*) #1, #2
must share
the same
twisted pair;

(**) #3, #6
must share
the same
twisted pair;

Device-to-device (WAS-1498)	
Side A	Side B
#1 ← (*)	→ #3
#2 ← (*)	→ #6
#3 ← (**)	→ #1
#4 ←	→ #4
#5 ←	→ #5
#6 ← (**)	→ #2
#7 ←	→ #7
#8 ←	→ #8

10. Specifications, packing & ordering Information

10.1. Specifications & packing information

Ethernet interface:	10BaseT Ethernet
Serial interface:	RS232, DB9M, signals: RX, TX, RTS, CTS, Ground
Network Protocols	UDP, TCP, ICMP (ping), ARP
Data buffers	Two independent 255-byte buffers (for Ethernet→serial and serial→Ethernet data transmission)
Power supply:	DC 12V, 150mA
Operation Temperature	0-55 C°
Operating relative humidity	10-90%
Unit dimensions (including connectors)	95mm(L) x 57mm(W) x 30mm(H)
Carton dimensions (DS100R/ DS100R-KIT)	130mm(L) x 100mm(W) x 65mm(H)/ 325mm(L) x 145mm(W) x 90mm(H)
Gross weight (DS100R/ DS100R-KIT)	950g/ 170g

10.2. Ordering Information

DS100R-	Bare DS100 in the individual carton (no accessories included except a Velcro sticker for wall mounting)
DS100R-E-KIT	DS100 with accessories: ARP-1014 (110V), WAS-1455, WAS-1404, WAS-1499, WAS-1498, DSK-T001
DS100R-U-KIT	Same as the above but with the ARP-1015A (220V) power adaptor
ARP-1014	AC 110V/ DC 12V power adaptor
ARP-1015A	AC 220V/ DC12V power adaptor
WAS-1455	DS100-to-PC RS232 180cm cable (required for firmware downloading!)
WAS-1404	DS100-to-Device RS232 140cm cable
WAS-1499	Device-to-hub Ethernet 180cm cable
WAS-1498	Device-to-device Ethernet 180cm cable
DSK-T0001	Official CD with all the latest documentation and software