



SignalPoint



INSTALLATION GUIDE

Table of Contents

Section	Page No
UU1. INTRODUCTION	3
2. WARNINGS AND CAUTIONS	3
3. UNPACKING	3
4. INSTALLATION	4
5. CONTROL PANEL - REMOVING ITEMS BEFORE MOUNTING	4
6. MOUNTING THE ENCLOSURE TO A WALL	4
7. REPLACING ITEMS AFTER MOUNTING	4
8. MOUNTING DIAGRAMS	5
9. POWERING THE SYSTEM	6
10. EXTERNAL WIRING	7
10.1 HARDWIRED SOUNDER	7
10.2 HARDWIRED CALL POINT	7
10.3 DEVICE WIRING	7
11. INSTALLATION ADVICE	8
12. DEVICE INSTALLATION	22
12.1 INPUT/OUTPUT UNITS	22
13. CONTROLLER INFORMATION	23

1. Introduction

This manual provides an installation guide to the SignalPoint Fire Control Panel and peripheral devices. It is important that for correct installation, the instructions given in this manual are followed. Should you have any questions regarding the installation of the Signal Point system, please ring our technical Helpline No 08712 710804 (0800-1800 Mon-Fri), or alternatively your regional technical support representative.

Whilst this manual provides an overall installation guide, refer to the User Manual for details on how to operate the system.

2. Warnings and Cautions

It is very important that the procedures in this installation manual are carefully followed. This will prevent injury.

The user of this manual should be a suitably trained installer and should be familiar with all of the relevant regulations.

When installing the system, it is important to use the correct fixings, which are suitable for the type of surface being secured to.

SignalPoint includes components, susceptible to damage from Electro Static Discharge (ESD). These components can be permanently damaged through routine handling, if precautions are not observed. Where handling is unavoidable, adequate earthing precautions should be taken. E.g. an earthed wrist strap.

Minimise the handling of static sensitive PCB devices. Also always transport "loose" PCB's in containers, manufactured with ESD protective properties. Also avoid placing static sensitive devices on plastic surfaces.

3. Unpacking

SignalPoint control panels are simple to install, provided that the recommended procedures in this manual are followed. Refer to the Engineers Operating Guide for details on the programming of system operation, and the User Manual for the overall system operation.

Care should be taken when handling. Dropping any of the parts onto hard surfaces may cause damage to the case and internal circuitry.

Products should be kept in their packaging until installation. This minimises any risk of damage. Retain all packaging until the installation activities have been completed. Any products surplus to requirements, or requiring returning to EMS, should be returned in the original packaging.

**CONTROL PANELS ARE SUPPLIED WITH ALL
DETECTOR ZONES IN TEST. PLEASE REFER TO THE
ENGINEERS OPERATING GUIDE TO MAKE ACTIVE.**

4. Installation

Following the Site Survey, System Control Panels should be positioned as stated considering: -

The recommended minimum distance between metal objects or equipment for the aerial is 400mm.

The recommended minimum distance to any electrical equipment is 2 metres, (See Figure 1).

5. Control Panel - Removing Items before Mounting

Before mounting the unit, it is necessary that certain items be removed, so as to prevent the risk of damage to the internal circuitry.

Remove the Door Assembly from the Back Box. To achieve this, disconnect the Ribbon Cables and Earth links, loosen the hinge screws on the Back Box side of the hinge and pull the door away. Ensure that the Door Assembly is suitably stored and that ESD precautions are observed (see Figure 2).

Establish the required cable entries. Knockouts should be made prior to fixing the Back Box to the wall.

Ensure that the Back Box is free of swarf and other debris.

6. Mounting the Enclosure to a Wall

It is recommended that the Control Panel be mounted in accordance with the site survey so that the display is at eye level.

Achieve this firstly by securing it to the wall, via the single fixing "keyhole", located in the top centre of the box. The box should be hung and levelled, allowing holes to be marked out for each of the four remaining mounting holes (shown on figure 3).

Once the Back Box is fitted to the wall, all external cabling should be run to the box, including the provision of an unswitched 240 volt supply. The mains cable should be dressed away from the main radio PCB and should be as short as possible.

7. Replacing Items after Mounting

Replace the Door assembly by reversing the steps given in Section 5, ensuring that all electrical connections, including the earth leads, are made.

Ensure that both UHF and VHF aerials are fitted to the top of the Control Panel. To ensure correct fitment, the aerial identified with the coloured band must be fitted to the connector identified with the coloured band. If high gain aerials are to be used they must be positioned in accordance with the site survey.

8. Mounting Diagrams




Figure 1

IMPORTANT:
IF FRONT PANEL IS TO BE
REMOVED, THE REAR SCREWS
ONLY ARE TO BE RELEASED
THE PANEL SHOULD EASILY
SLIDE OFF.




Figure 2




Figure 3

9. Powering the System

The SignalPoint Control Panel has an internal 3 amp power supply and charger as standard. On larger systems and where hard-wired sounder circuits are used, it may be necessary to provide an additional power supply or increase the size of the system power supply and charger. When using an additional power supply, it should be mounted in an appropriate cabinet adjacent to the control panel. Should this be impractical, the maximum distance between the Control Panel and power supply/charger should not exceed 3 metres. Ensure that the voltage drop between the supply and the main panel does not exceed 0.5v.

The 240V power supply to the Control Panel must be made by way of an individual fused spur, situated adjacent to the Control Panel. The fused spur must have its own power supply circuit fitted with a 3 Amp fuse. Affix a red circuit breaker, labelled "Fire Alarm, Do Not Switch Off", to the circuit. It is recommended that the circuit breaker be secured from unauthorised access. The fused spur should be similarly labelled as "Fire Alarm".

When powering up, the following procedure must be followed.

If the panel is switched off, apply the mains power to the unit and connect the batteries (observing the correct polarity).

After the system has completed its initialisation sequence, the display will show, Figure 4 followed by Figure 5




Figure 4




Figure 5

When the Control Panel is first powered up, the "General Fault" LED will illuminate and the fault buzzer will sound. This continues whilst the system initialises itself and runs through self-test routines.

Once initialised, the green "Power" LED will illuminate. At this time the "General Fault" LED will also be illuminated, whilst the display will indicate a "PR" fault. Press "SILENCE ALARM" followed by "RESET" to clear this LED. The Control Panel will run through a series of diagnostic self tests. The illumination of the applicable LED and the sounding of the fault buzzer will indicate any errors on the display.

Under normal non fault conditions, the display will indicate status as "Normal" (see Figure 6). If the Key Switch is left in the "On" position, the display will indicate that the panel is in "Access mode" (see Figure 7).




Figure 6




Figure 7

10. External Wiring

10.1 Hardwired Sounder

The SignalPoint Control Panel includes provision for two hardwired sounder circuits. The circuitry monitors two pairs of conductors fitted with 4k7 End of Line resistors. No connection to the control Panel should be made at this stage. The maximum current permitted is 250mA per circuit.

10.2 Hardwired Call Point

The SignalPoint Control Panel includes provision for a hardwired Call Point interface. The Control Panel monitors this input via a 4k7 End of Line resistor. No connection to the Control Panel should be made at this stage.

Note: The external connections & wiring must be tested in the conventional manner. Under no circumstances should the system circuitry be tested using a meggar tester, once the connections to the control panel, or peripherals, has been made.

10.3 Device Wiring

Using an Ohmmeter, check both sounder circuits to ensure that they have a 4.7k ohm resistance across the connections and that the resistance between each connection and the Control Panel earth point is greater than 20 M Ohm.

Check any Call Point external wiring. The resistance across the Call Point connection should read 4.7k. Ensure that the resistance between each connection and the Control Panel earth point is greater than 20 M Ohm.

Once external wiring circuits have been checked, make the connections to the control panel. The Control Panel should be powered down prior to termination. Connect all external wiring to the applicable Control Panel terminals (see drawing p02910). Upon completion of this, re-power the Control Panel.

11. Installation Advice.

Ensure that you have all equipment required to complete the system installation.

Ensure that the correct fixings and fasteners are used for all installation work.

Observe ESD precautions.

Familiarise yourself with the system details and layout, before commencing any installation activity. Any anomalies must be addressed with the Surveyor, End user or the equipment supplier.

Ensure that the Control Panel back box is clean and free of swarf prior to fitting the internal assemblies.

Also ensure that aerials are fitted with anti tamper cones before applying 230V to the control panel.

The 240V power supply to the Control Panel must be made by way of an individual fused spur, situated adjacent to the Control Panel. The fused spur must have it's own power supply circuit fitted with a 3 Amp fuse. Affix a red circuit breaker, labelled "Fire Alarm, Do Not Switch Off", to the circuit. It is recommended that the circuit breaker be secured from unauthorised access. The fused spur should be similarly labelled as "Fire Alarm".

Wherever practical, fix detectors so that the red LED faces the main entrance to the room.




Should it be necessary to remove the two aerials fitted to the Control Panel, ensure that when refitted, the coloured band on the aerial corresponds with the coloured disk on the BNC connector on the panel.

Ensure that the 240V AC mains supply is fused and unswitched.

DWG No. PO2911

E.M.S. Ltd UNIT 11 Sea St. Herne Bay, Kent CT6 8JZ Tel : 01227 369570

DO NOT SCALE.



2507-2 PCB

F10 = 3.15A PRINTER FUSE
 F9 = 0.5A REMOTE RECEIVER FUSE
 F8 = 3.15A AUXILIARY 24V INPUT FUSE
 F7 = 3.15A BATTERY FUSE
 F5 = 3.15A A.C. INPUT FUSE
 F3 = 0.125A 24V MONITOR FUSE
 F2 = 0.5A HARDWIRED SOUNDER 1 FUSE
 F1 = 0.5A HARDWIRED SOUNDER 2 FUSE

ISS. NO.	1	HERNE BAY, KENT CT6 8JZ	MATERIAL	N/A	DESCRIPTION	DWG No.
MOD No.	M01589					
DRAWN	CDU	THE PRINT AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY AND MAY NOT BE USED IN WHOLE OR IN PART WITHOUT WRITTEN APPROVAL.			USED ON	SHT. OF.
CHECKED						
APPROVED.						
INIT.	SIG					
DATE						


DWG No. **PO2989**

E.M.S. Ltd UNIT 11 Sea St. Herne Bay, Kent CT6 8JZ Tel : 01227 369570


DO NOT SCALE.

ASSEMBLY INSTRUCTIONS AERIAL ANTI-TAMPER CONE.

'CONE' PO3117
(SEE OPPOSITE FOR VARIATIONS).



ALL ANTI-TAMPER 'CONES' SHOULD BE HELD IN PLACE BY M3 KNURLED THUMBSCREWS (PT No FASM3X0.5KNTHUMBNUITS) 2 OFF PER 'CONE'



AERIAL TYPES :

RFS-5520/AV VHF
RFS-5521/AU UHF

AERIAL TYPES :

RG213U
LOW LOSS CABLE
ASSEMBLIES

AERIAL TYPES :

HI-GAIN AERIALS
USING RG58
CABLE ASSEMBLIES

ISS. NO.	C
MOD No.	
DRAWN	INT. SIB
CHECKED	DATE
APPROVED	JPC
	27-11-97

EMS HERNE BAY, KENT CT6 8JZ
THE PRINT AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY AND MAY NOT BE USED IN WHOLE OR IN PART WITHOUT WRITTEN APPROVAL.

TOLERANCES UNLESS OTHERWISE STATED ABOVE	MATL.	N/A
GENERAL ±0.3mm	FINISH.	N/A
HOLE CDS. 0-0.1mm		

DESCRIPTION.
AERIAL TAMPERPROOF BRACKET ASSEMBLY INSTRUCTIONS
USED ON SIGNALPOINT CONTROL PANEL

DWG No. **PO2989**
SHT. OF


DWG No. **PO2989**

E.M.S. Ltd UNIT 11 Sea St. Herne Bay, Kent CT6 8JZ Tel : 01227 369570

DO NOT SCALE.


'CONE' PO3117

(SEE OPPOSITE FOR VARIATIONS).



ALL ANTI-TAMPER 'CONES' SHOULD BE HELD IN PLACE BY M3 KNURLED THUMBSCREWS (PT No FASM3X0.5KNTHUMBNUITS) 2 OFF PER 'CONE'

ASSEMBLY INSTRUCTIONS AERIAL ANTI-TAMPER CONE.



AERIAL TYPES :

HI-GAIN AERIALS USING RG58 CABLE ASSEMBLIES

AERIAL TYPES :

RG213U LOW LOSS CABLE ASSEMBLIES

AERIAL TYPES :

RFS-5520/AV VHF
RFS-5521/AU UHF

ISS. NO.	C
MOD No.	
DRAWN	INT. SIB
CHECKED	DATE
APPROVED	27-11-97
	JPC

EMS HERNE BAY, KENT CT6 8JZ
THE PRINT AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY AND MAY NOT BE USED IN WHOLE OR IN PART WITHOUT WRITTEN APPROVAL.

TOLERANCES UNLESS OTHERWISE STATED ABOVE	MATL.	N/A
GENERAL ±0.3mm	FINISH.	N/A
HOLE CDS. ±0.1mm		



DESCRIPTION.
AERIAL TAMPERPROOF BRACKET ASSEMBLY INSTRUCTIONS
USED ON SIGNALPOINT CONTROL PANEL

DWG No. **PO2989**
SHT. OF


DWG NO. P04334
DO NOT SCALE.

E.M.S. Ltd UNIT 11 Sea St. Herne Bay, Kent CT6 8JZ Tel : 01227 369570


SCREEN OF CABLE TO BE EARTHED AT ONE CONTROL PANEL ONLY.
ALL OTHER SCREENS CONNECTED TO "THROUGH CONNECTION"



IMPORTANT:
2 METERS MINIMUM PHYSICAL DISTANCE BETWEEN PANELS




MASTER PANEL



SLAVE PANEL

ISS. NO.	3	HERNE BAY, KENT CT6 8JZ		TOLERANCES UNLESS OTHERWISE STATED ABOVE		DWG No. P04334
MOD No.		MATL.	N/A			SHT. OF.
DRAWN	CUU	FINISH:	N/A	DESCRIPTION. SIGNALPOINT HARDWIRED LAN CONNECTION DIAGRAM		
CHECKED				USED ON		
APPROVED.						

EMS
THE PRINT AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY AND MAY NOT BE USED IN WHOLE OR IN PART WITHOUT WRITTEN APPROVAL.



SCREEN OF CABLE TO BE EARTHED AT ONE CONTROL PANEL ONLY. ALL OTHER SCREENS CONNECTED TO "THROUGH CONNECTION"

MAXIMUM CABLE DISTANCE 1000m

IMPORTANT:
2 METERS MINIMUM PHYSICAL DISTANCE BETWEEN THE FIRE PANEL AND REMOTE.

UHF REMOTE RECEIVER

ISS. NO. 4		HERNE BAY, KENT CT6 8JZ		MATERIAL N/A		DESCRIPTION. SIGNALPOINT TO UHF REMOTE RECEIVER WIRING DIAGRAM		DWG No. P03045	
MOD No.		THE PRINT AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY AND MAY NOT BE USED IN WHOLE OR IN PART WITHOUT WRITTEN APPROVAL.		FINISH N/A		USED ON		SHT. OF.	
DRAWN		INIT. SIG		DATE		TOLERANCES UNLESS OTHERWISE STATED ABOVE		SIMILAR TO P03045	
CHECKED		CDU				GENERAL +/-0.3mm			
APPROVED.						HOLE CRS. +/-0.1mm			

E.M.S. Ltd UNIT 11 Sea St. Herne Bay, Kent CT6 8JZ Tel : 01227 369570


DWG NO. P03045

DO NOT SCALE.

DWG NO. P03265


E.M.S. Ltd UNIT 11 Sea St. Herne Bay, Kent CT6 8JZ Tel : 01227 369570

DO NOT SCALE.




SCREEN OF CABLE TO BE EARTHED AT ONE CONTROL PANEL ONLY. ALL OTHER SCREENS CONNECTED TO "THROUGH CONNECTION".

MAXIMUM CABLE DISTANCE 1000m



UHF RADIO LAN MODULE

IMPORTANT:
2 METERS MINIMUM PHYSICAL DISTANCE BETWEEN THE FIRE PANEL AND REMOTE.




SIMILAR TO P03045

ISS. NO. MOD No.	4	HERNE BAY, KENT CT6 8JZ		MATL.	N/A	DESCRIPTION.		DWG No.
DRAWN	INIT.	THE PRINT AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY AND MAY NOT BE USED IN WHOLE OR IN PART WITHOUT WRITTEN APPROVAL.		FINISH.	N/A	SIGNALPOINT TO LAN MODULE WIRING DIAGRAM		P03265
CHECKED	SIG					USED ON		SHT. OF.
APPROVED.	DATE					HOLE CRS. +/-0.1mm		
						GENERAL +/-0.3mm		
						UNLESS OTHERWISE STATED ABOVE		

DWG No. P03421
DO NOT SCALE.

E.M.S. Ltd UNIT 11 Sea St. Herne Bay, Kent CT6 8JZ Tel : 01227 369570

24V PSU / CHARGER



ISS. NO.	2
MOD No.	
DRAWN	CDU
CHECKED	
APPROVED	

EMS HERNE BAY, KENT CT6 8JZ
THE PRINT AND INFORMATION CONTAINED HEREIN ARE PROPRIETARY AND MAY NOT BE USED IN WHOLE OR IN PART WITHOUT WRITTEN APPROVAL.



MATL.	N/A
FINISH.	N/A

TOLERANCES UNLESS OTHERWISE STATED ABOVE	GENERAL +/-0.3mm
HOLE CDS.	+/-0.1mm

DESCRIPTION.
AUXILIARY CHARGER CONNECTION DETAILS FOR ADDITIONAL BATTERY BACK UP REQUIREMENTS USED ON



DWG No.	P03421
SHT.	OF.

VIEW WITH LID /
COVER
REMOVED




Output led flashes in alarm condition

FRONT VIEW




Item No.	A	Revision	1
Manufacturer	AS ABOVE	Material	AS ABOVE
Part No.	PO4242	Part Name	MK3 I/O UNIT
Quantity	1	Description	MAIN ASSEMBLY INFO
Drawn By		Checked By	
Approved By		Approved Date	
<p>BMS BMS SYSTEMS AND SERVICES (UK) LTD 1000 WOODHURST ROAD, WOODHURST, WEST SUSSEX, BN9 7JF, UK TEL: 01273 996170 FAX: 01273 996171 EMAIL: SALES@BMS-UK.COM WEBSITE: WWW.BMS-UK.COM</p>			
<p>ALL INFORMATION CONTAINED HEREIN IS UNCLASSIFIED AND IS NOT TO BE USED IN ANY MANNER THAT COULD BE DETERMINED TO BE A DISCLOSE OF TRADE SECRETS OR PROPRIETARY INFORMATION WITHOUT THE WRITTEN APPROVAL OF BMS SYSTEMS AND SERVICES (UK) LTD.</p>			
<p>Finish: CLEAN</p>			
<p>Size: 100 x 100 x 100 mm</p>			
<p>Page No: PO4242</p>			

Typical Panel Layout




Typical Panel Layout Including UHF Remote Receiver




**Note: All panels and aerials to be at least 2m apart
Maximum cable run for RS485 Bus 1Km**

Typical LAN Panel Layout Including LAN Module




Note : All panels and aerials to be at least 2m apart
Maximum cable run for RS485 Bus 1 Km

Typical LAN Panel Layout Including LAN Module and UHF Remote Receiver



**Note: All panels and aerials to be at least 2m apart
Maximum cable run for RS485 Bus 1 Km**

Typical Hardwired Panel Network Layout



**Note: All panels and aerials to be at least 2m apart
Maximum cable run for RS485 Bus 1 Km**

12 Device Installation

12.1 Input/Output Units

Ensure that all I/O Units are sited in accordance with the survey and design details.

Remove the two lid retaining screws situated on the front cover. The front section of the unit can now be removed exposing the inside of the device. See Figure 4.




Figure 4

Offer the unit up to the wall and using the back plate as a template mark out the four fixing holes. The unit can be fixed to the wall and all external wiring connections made.

When all connections have been made to the unit the lid can be re-fixed.

12.2 Half Watt Transmitters

Ensure that all Half Watt Transmitters are sited in accordance with the survey and design details.

Remove of the four lid retaining screws situated on the front cover. The front section of the unit can now be removed exposing the inside of the device. See Figure 5.

Ensure that all Half Watt Transmitters are sited in accordance with the survey and design details.

Remove of the four lid retaining screws situated on the front cover. The front section of the unit can now be removed exposing the inside of the device. See Figure 5.




Figure 5

Offer the unit up to the wall and using the back plate as a template mark out the four fixing holes. The unit can be fixed to the wall and all external wiring connections made.

When all connections have been made to the unit the lid can be re-fixed.

13. Controller Information**TECHNICAL INFORMATION FOR THE SIGNALPOINT CONTROLLER**

Dimensions:	330mm x 450mm x 116mm
Operating Frequencies:	VHF – 173.2 MHz – 173.5MHz (receiver) UHF – 458.5 MHz – 459.5 MHz (transmitter)
Operating Temperature:	-10 to 55 degrees C
Humidity:	Up to 75% non-Condensing.
Channel Spacing:	25 kHz
Output Transmitter Power:	0.75W (500 mW) (+ 27DBH)
Supply:	240v 50 Hz
Current Consumption:	260mA in standby
Operating Voltages:	24v DC nominal
Battery space:	2 x 12volt 9Ah batteries (not supplied) EMS only recommend: Panasonic Model No: UP-RW1245P1 or a battery of equivalent specification
Inputs:	1 x 27v DC
Outputs:	2 x 0.25amp 24v DC sounder outputs 2 x auxiliary fire relays 2 x auxiliary fault relays 1 x RS 485 serial port 1 x RS 232 serial port
Recommended battery replacement intervals:	Standby 9Ah batteries – 2 years Lithium clock and RAM batteries – 5 years (Re-order no – 5-5812)



EMS Group Head Office
Technology House,
Sea Street
Herne Bay,
Kent CT6 8JZ
England
Tel: +44 (0) 8712 710804
Fax: +44 (0) 1227 369679
Email: enquiries@emsgroup.co.uk

www.emsgroup.co.uk



An
ISO 9001:2008
Approved Company



Dealer Information:

The information contained within this literature is correct at time of publishing. The EMS Group reserves the right to change any information regarding products as part of its continual development enhancing new technology and reliability. The EMS Group advises that any product literature issue numbers are checked with its head office prior to any formal specifications being written.