


## 1 Connections

Connect the peripherals and cameras based on the diagram below.



When the exacqVision System boots, exacqVision Server automatically starts as a background service and begins recording. The operating system will then auto login to the **user** account. Both **user** and **admin** accounts are configured to start exacqVision Client immediately upon login.

## 2 Linux User Setup

Your exacqVision System has been configured to take advantage of operating system security features. The factory configuration includes two operating system accounts; **admin** and **user**. The default passwords should be changed by the operator and written and stored in a secure fashion to prevent unauthorized access or modifications to the system. To change the passwords, complete the following steps:

- 1.) Log off the **user** account by clicking the red power button in the lower left corner of the screen.
- 2.) Log in to the **admin** account using the default password (admin256).
- 3.) From the Start Menu, select System Administration and then Users & Groups.
- 4.) Select the account for which you want to change the password.
- 5.) Under Set Password By Hand, enter the new password and confirm it.
- 6.) Click OK, and then click OK again.




Once the exacqVision Server begins recording video, it will continue even if no user is logged in or no exacqVision Client is running. It will stop recording only if:


- The exacqVision system is shut down
- The exacqVision core.exe process is stopped

To prevent this from happening inadvertently or maliciously, the ability to shut down the computer or access the operating controls has been restricted from the **user** account. To shut down the system or perform maintenance, it will be necessary to switch to the **admin** account.

## 3 exacqVision User Setup


The exacqVision Server can be accessed from multiple exacqVision Clients that can be run either on the exacqVision Server or from remotely networked computers. Each operating system account maintains separate settings for exacqVision Client. These settings include usernames, passwords, and network addresses required for the exacqVision Client to access exacqVision Servers. By default, both the **user** and **admin** operating system accounts have settings that provide administrator access to the instance of exacqVision Server running on the local exacqVision system.


To protect the exacqVision Server, it is recommended that you configure a new user on the exacqVision Server with Restricted privileges. To add new users, click the Setup  toolbar button. Expand the server's setup menu by clicking the plus button (+) next to the exacqVision Server  in the tree, and then click Users . Click the New User button. Type in the name and password for the new user you are adding, and then confirm the password.



Username	Group
admin	Full Admin
newuser	Restricted

From the Group drop-down list, select the permission level for the user.

	<b>Restricted:</b>	Access to live video and search/playback functions
	<b>User Admin:</b>	Access to live video, search/playback functions, and user setup
	<b>Power User:</b>	Access to all features except user setup
	<b>Administrator:</b>	Access to all features of the system

In the Authorized Sources tree, select the cameras that the user can access for live and recorded, and then click Apply  to add the new user to the exacqVision Server. For more detailed instructions, see the User Setup section of the exacqVision User Manual or the context-sensitive online help file.

## 4 System Setup

For complete information on configuring your system, see the *System Installation Checklist* or the *exacqVision Users Manual*.