

ACE

(Advanced Cryogenic Electronics)

USER'S MANUAL



HP-224
March 2013

H **HOFFER FLOW CONTROLS, INC.**
Perfecting Measurement™

107 Kitty Hawk Lane • P.O. Box 2145 • Elizabeth City, North Carolina 27906-2145
1-800-628-4584 • (252) 331-1997 • FAX (252) 331-2886
www.hofferflow.com • Email: info@hofferflow.com

Notice

HOFFER FLOW CONTROLS, INC. MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

This manual has been provided as an aid in installing, connecting, calibrating, operating, and servicing this unit. Every precaution for accuracy has been taken in the preparation of this manual; however, HOFFER FLOW CONTROLS, INC. neither assumes responsibility for any omissions or errors that may appear nor assumes liability for any damages that may result from the use of the products in accordance with information contained in the manual.

HOFFER FLOW CONTROLS' policy is to provide a user manual for each item supplied. Therefore, all applicable user manuals should be examined before attempting to install or otherwise connect a number of related subsystems.

During installation, care must be taken to select the correct interconnecting wiring drawing. The choice of an incorrect connection drawing may result in damage to the system and/or one of the components.

Please review the complete model number of each item to be connected and locate the appropriate manual(s) and/or drawing(s). Identify all model numbers exactly before making any connections. A number of options and accessories may be added to the main instrument, which are not shown on the basic user wiring. Consult the appropriate option or accessory user manual before connecting it to the system. In many cases, a system wiring drawing is available and may be requested from HOFFER FLOW CONTROLS.

This document contains proprietary information, which is protected by copyright. All rights are reserved. No part of this document may be photocopied, reproduced, or translated to another language without the prior written consent of HOFFER FLOW CONTROLS, INC.

HOFFER FLOW CONTROLS' policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering. The information contained in this document is subject to change without notice.

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the Hoffer Flow Controls Customer Service Department, telephone number (252) 331-1997 or 1-800-628-4584. BEFORE RETURNING ANY PRODUCT(S) TO HOFFER FLOW CONTROLS, PURCHASER MUST OBTAIN A RETURNED MATERIAL AUTHORIZATION (RMA) NUMBER FROM HOFFER FLOW CONTROLS' CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned RMA number should then be marked on the outside of the return package and on any correspondence.

FOR **WARRANTY** RETURNS, please have the following information available BEFORE contacting HOFFER FLOW CONTROLS:

1. P.O. number under which the product was PURCHASED,
2. Model and serial number of the product under warranty, and
3. Repair instructions and/or specific problems relative to the product.

FOR **NON-WARRANTY** REPAIRS OR **CALIBRATIONS**, consult HOFFER FLOW CONTROLS for current repair/calibration charges. Have the following information available BEFORE contacting HOFFER FLOW CONTROLS:

1. P.O. number to cover the COST of the repair/calibration,
2. Model and serial number of the product, and
3. Repair instructions and/or specific problems relative to the product.

LIMITED WARRANTY

HOFFER FLOW CONTROLS, INC. ("HFC") warrants HFC's products ("goods") described in the specifications incorporated in this manual to be free from defects in material and workmanship under normal use and service, but only if such goods have been properly selected for the service intended, properly installed and properly operated and maintained. This warranty shall extend for a period of (1) year from the date of delivery to the original purchaser (or eighteen (18) months if the delivery to the original purchaser occurred outside the continental United States). This warranty is extended only to the original purchaser ("Purchaser"). *Purchaser's sole and exclusive remedy is the repair and/or replacement of nonconforming goods as provided in the following paragraphs.*

In the event Purchaser believes the goods are defective, the goods must be returned to HFC, transportation prepaid by Purchaser, within twelve (12) months after delivery of goods (or eighteen (18) months for goods delivered outside the continental United States) for inspection by HFC. If HFC's inspection determines that the workmanship or materials are defective, the goods will be either repaired or replaced, at HFC's sole determination, free of additional charge, and the goods will be returned, transportation paid by HFC, using the lowest cost transportation available.

Prior to returning the goods to HFC, Purchaser must obtain a Returned Material Authorization (RMA) Number from HFC's Customer Service Department within 30 days after discovery of a purported breach of warranty, but no later than the warranty period; otherwise, such claims shall be deemed waived. See the Return Requests/Inquiries Section of this manual.

If HFC's inspection reveals the goods are free of defects in material and workmanship or such inspection reveals the goods were improperly used, improperly installed, and/or improperly selected for service intended, HFC will notify the purchaser in writing and will deliver the goods back to purchaser upon (i) receipt of Purchaser's written instructions and (ii) the cost of transportation. If Purchaser does not respond within 30 days after notice from HFC, the goods will be disposed of in HFC's discretion.

HFC does not warrant these goods to meet the requirements of any safety code of any state, municipality, or any other jurisdiction, and purchaser assumes all risk and liability whatsoever resulting from the use thereof, whether used singly or in combination with other machines or apparatus.

This warranty shall not apply to any HFC goods or parts thereof, which have been repaired outside HFC's factory or altered in any way, or have been subject to misuse, negligence, or accident, or have not been operated in accordance with HFC's printed instructions or have been operated under conditions more severe than, or otherwise exceeding, those set forth in the specifications for such goods.

THIS WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. HFC SHALL NOT BE LIABLE FOR ANY LOSS OR DAMAGE RESULTING, DIRECTLY OR INDIRECTLY, FROM THE USE OF LOSS OF USE OF THE GOODS. WITHOUT LIMITING THE GENERALITY OF THE FOREGOING, THIS EXCLUSION FROM LIABILITY EMBRACES THE PURCHASER'S EXPENSES FOR DOWNTIME, DAMAGES FOR WHICH THE PURCHASER MAY BE LIABLE TO OTHER PERSONS, DAMAGES TO PROPERTY, AND INJURY TO OR DEATH OF ANY PERSON. HFC NEITHER ASSUMES NOR AUTHORIZES ANY PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OR USE OF HFC'S GOODS, AND THERE ARE NO AGREEMENTS OR WARRANTIES COLLATERAL TO OR AFFECTING THE AGREEMENT. *PURCHASER'S SOLE AND EXCLUSIVE REMEDY IS THE REPAIR AND/OR REPLACEMENT OF NONCONFORMING GOODS AS PROVIDED IN THE PRECEDING PARAGRAPHS. HFC SHALL NOT BE LIABLE FOR ANY OTHER DAMAGES WHATSOEVER INCLUDING INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.*

Disclaimer:

Specifications are subject to change without notice.
Some pages are left intentionally blank.

TABLE OF CONTENTS

1.	GENERAL INFORMATION.....	1
1.1.	INTRODUCTION.....	1
1.2.	DESCRIPTION.....	1
1.3.	PRECAUTIONS.....	2
1.4.	PREPARATION FOR SHIPMENT.....	2
1.5.	SPECIFICATIONS.....	3
1.6.	EQUIPMENT ACCESSORIES.....	4
2.	OPERATIONS OVERVIEW.....	5
2.1.	INTRODUCTION.....	5
2.2.	OPERATION KEY FUNCTIONS.....	5
2.3.	PROGRAM MODE CONTROL.....	6
3.	OPERATING MODE.....	9
3.1.	INTRODUCTION.....	9
3.2.	OPERATING MODE ACCESS.....	9
3.3.	OPERATOR KEY FUNCTIONS.....	10
3.4.	DISPLAY FIELDS.....	11
3.5.	WARNING MESSAGES DURING DELIVERIES.....	13
3.6.	PUMP INTERLOCK (OPTIONAL).....	14
3.7.	PRINTING.....	17
4.	MAINTENANCE MODE.....	19
4.1.	INTRODUCTION.....	19
4.2.	MAINTENANCE MODE ACCESS.....	19
4.3.	KEYBOARD ENTRY.....	20
4.4.	MAINTENANCE MODE FIELDS.....	21
5.	CALIBRATION MODE.....	27
5.1.	INTRODUCTION.....	27
5.2.	CALIBRATION MODE ACCESS.....	27
5.3.	KEYBOARD ENTRY.....	28
5.4.	CALIBRATION FIELDS.....	29
6.	CONFIGURATION MODE.....	33
6.1.	INTRODUCTION.....	33
6.2.	CONFIGURATION MODE ACCESS.....	33
6.3.	KEYBOARD ENTRY.....	34
6.4.	CONFIGURATION FIELDS.....	35
7.	FIELD COMMISSIONING.....	41
8.	INSTALLATION GUIDE.....	43
8.1.	ELECTRONICS ENCLOSURE INSTALLATION.....	43
8.2.	INTERCONNECTING CABLE INSTALLATION.....	43
8.3.	FIELD COMMISSIONING.....	44
8.4.	WIRING CONNECTIONS OPTIONAL PRINTER.....	44
9.	SERVICE GUIDE.....	45
9.1.	TROUBLE SHOOTING.....	45
9.2.	TROUBLESHOOTING THE MEASUREMENT TRANSDUCER FOR DUAL COIL SYSTEMS.....	48
9.3.	CORRECTIVE ACTIONS.....	49
9.4.	TESTING.....	52
9.5.	WEIGHT SCALE CALIBRATION.....	54
9.6.	REPLACEMENT PARTS.....	55
10.	OPERATIONS.....	57
10.1.	DELIVERY PROCEDURE.....	57
11.	SYSTEM CHECKOUT.....	59
11.1.	SYSTEM CHECKOUT PROCEDURE.....	59
12.	APPENDIX: DRAWINGS.....	63


LIST OF FIGURES

Figure 1: ACE front view.....	1
Figure 2: ACE Display and Keyboard.	5
Figure 3: Program Mode access flowchart.....	6
Figure 4: Operating Mode Access Chart.....	9
Figure 5: Operating Mode flowchart.....	11
Figure 6 Pump Interlock Control flowchart	16
Figure 7: Maintenance Mode access flowchart.....	19
Figure 8: Maintenance Mode flowchart.....	21
Figure 9: Calibration Mode access flowchart.....	27
Figure 10: Calibraton Mode flowchart.....	29
Figure 11: Configuration Mode access flowchart.....	33
Figure 12: Configuration Mode flowchart.....	35
Figure 13: TM-295 Dip Switch Settings.....	38

1. GENERAL INFORMATION

1.1. INTRODUCTION

Figure 1: ACE front view.



The ACE, Advanced Cryogenic Electronics, is a truck mounted flow metering system designed to facilitate the delivery of cryogenic fluids. The system uses an internal computer to accurately record and display deliveries in the required units. An optional printer allows the system to off load delivery information and ACE setup parameters. ACE has been designed to meet the requirements of the cryogenic metering section of NIST HANDBOOK 44 and OIML R -81. The ACE system microcontroller design enables the unit to be firmware upgradeable. This allows the unit to meet the future needs of the cryogenics industry.

1.2. DESCRIPTION

The system is composed of a turbine flowmeter, electronics console, a metering run mounted on the delivery truck, and an optional printer. The electronics portion of the ACE is provided in a small electronics enclosure with military style electrical fittings. Instantaneous indication of the flowrate and flowing temperature is provided as well as a total flow indicator and an accumulative total indicator. Temperature compensation is provided to allow for the proper delivery totals. Optional versions are available which cover CO₂, LH₂, LNG, ETHYLENE, LPG, and other products.

1.3. PRECAUTIONS

1.3.1. STATIC ELECTRICITY

The ACE uses high speed CMOS circuitry which is sensitive to static damage. User should observe accepted safety practices for the handling of electronic devices. All spare electronic parts are shipped in special packages to avoid static damage. Follow these precautions when servicing the equipment.

Once the ACE is installed, grounded, and interconnected, the odds of static discharge damage are greatly reduced. Should a malfunction due to static discharge be suspected, it may be necessary to turn the power OFF and then ON after a 10 seconds delay to restore normal operation.

Low humidity environments increase the potential for static build up. In these conditions the operator should touch a grounded conductive surface prior to touching controls on the ACE.

CAUTION- ACE CONTAINS STATIC-SENSITIVE DEVICES. STANDARD PRACTICES FOR STATIC-SENSITIVE PARTS SHOULD BE OBSERVED.

1.3.2. WELDING

Welding should not be performed in close proximity to the ACE or its interconnecting cables. If welding under these conditions must be performed, disconnect all cables from the ACE. Failure to do so may result in damage to the unit.

1.4. PREPARATION FOR SHIPMENT

1.4.1. SHIPPING AND HANDLING

In the event of a malfunctioning system, the following guidelines should be observed for the preparation and shipment of the unit in question. Failure to do so may result in the material reaching its destination damaged.

1.4.2. COMPLETE ACE UNIT

- If it is determined that the entire ACE unit needs to be returned for service, follow these steps:
- Wrap the complete unit in a cushioning type of material.
- Secure the wrapped unit in a commercial grade shipping container.
- Label the exterior container with bold letters stating "HANDLE WITH CARE".
- Clearly mark the box and paperwork with the RMA number.
- Ship the material back to HFC using the following address:

Hoffer Flow Controls, Inc
107 Kitty Hawk Lane
Elizabeth City, NC 27909, USA

1.4.3. ELECTRONIC SUBCOMPONENTS

Electronic subcomponent refers to the printed circuit board or any other related electronic component.

- The electronic component should be wrapped in a material conforming to MIL -B-81705, Type II, and packaged in a heat sealed bag conforming to MIL -P-81997. These steps are necessary to protect the equipment from electrostatic charges that may occur during handling.
- The packaged unit should then be marked with a sensitive electronic device caution label conforming to MIL -STD-129, App endix C. The equipment should then be wrapped in cushioning material, and placed into a close fitting box conforming to PPP -B-636 Domestic class.
- The exterior shipping container should be marked with a sensitive electronic device caution label conforming to MIL-STD-129, Appendix C.

1.5. SPECIFICATIONS

- Display: 32-character, alphanumeric, LED backlit, LCD supertwist display, 0.3" character height.
- Keypad: 5 key (Explosion Proof version - 4 keys).
- Optional Printer.
- Operating temperature: -20 to +70 °C (-4 to +158 °F).
- Storage temperature: -40 to +90 °C (-40 to +194 °F).
- Flowmeter input: sensitivity 10 mVrms, RF and bandpass filtered.
- Temperature probe: 1000 ohm, platinum RTD - compatible.
- Self test capabilities: Coil failures, RTD failures, low power, computer operation, memory test and circuitry failure detection.
- Compensation range:

<i>Fluid</i>	<i>Compensation Range</i>
LIN	75 to 125 °K
LOX	90 to 130 °K
LAR	85 to 125 °K
LH2	20 to 31 °K
LNG	-260 to -160 °F (-162 to -107 °C)
CO2	-60 to 30 °F (-51 to -1 °C)
LPG	0 to 125 °F (-18 to 52 °C)
Ethylene(C2H4)	158 to 250 °K

- Power Input: 12 Vdc (9.3 to 15 Vdc) standard. Optional 115/220 Vac with a power pack converter or 24 Vdc (16 to 30 Vdc).
- Optional pump interlock output.
- Optional pulse output.
- Optional heater for low temperature operation.

1.6. EQUIPMENT ACCESSORIES

- ACC-5A Count Tester.
- ACC-45V Pressure Transmitter Simulator.
- ACC-11 Temperature Probe Simulator, LIN/LOX/LAR.
- ACC-36 Temperature Probe Simulator, LH2.
- ACC-15 Temperature Probe Simulator, CO2 and Ethylene.
- ACC-62 Temperature Probe Simulator, LNG.
- ACC-58 Temperature Probe Simulator, LPG.
- SCA6CC2-T Temperature Probe Cable.
- SCA6CC2-S Signal Cable.
- SCA4CU3-P Power Cable.

2. OPERATIONS OVERVIEW


2.1. INTRODUCTION

The ACE is an advanced flow metering system used in bulk liquid delivery systems. These systems are primarily used for the delivery of industrial gases. The ACE uses a turbine flowmeter input, temperature input, and an optional pressure input to calculate and record the delivered amount of fluid.

Before and during the delivery run, the ACE will provide warning messages if there is an equipment failure or if the unit is operating outside the programmed flow range.

2.2. OPERATION KEY FUNCTIONS

Figure 2: ACE Display and Keyboard.




Program control keys consist of the **MODE** (left arrow), **SELECT** (down arrow), **CLEAR** (right arrow), **PRINT** (up arrow), and **CONTROL** key.

Data entry and option selection are performed using the **CLEAR** and **PRINT** keys. Parameters are displayed in two forms, either label fields or numeric fields. Numeric fields require the entry of numbers using a combination of the **PRINT** and **CLEAR** keys. The **CLEAR** key moves the cursor to the right, one character at a time. The **PRINT** key causes the selected number to increment by one. Label fields display English messages showing the option currently selected for a setup option or parameter. Alternate selections may be viewed and selected by pressing the **PRINT** key.

- **MODE** - Advances from one mode of operation to another.
- **SELECT** - Scrolls down through the selected mode field entries.
- **CONTROL** - Scrolls up through the selected mode field entries.
- **PRINT** - Changes the selection in label fields. Increments the number when in a numeric field. At the end of a delivery initiates the printing of the delivery ticket if the unit has a printer. Also saves the delivery information in memory.
- **CLEAR** - Moves the cursor over one character during numeric data entry.

2.3. PROGRAM MODE CONTROL

Figure 3: Program Mode access flowchart.



2.3.1. OVERVIEW

The ACE has four modes of program control, they are OPERATING, MAINTENANCE, CALIBRATION, and CONFIGURATION. The OPERATING mode is used during delivery. MAINTENANCE mode provides clearing of ACCUM TOTAL, self -test, and troubleshooting features. CALIBRATION mode stores parameters that affect the accuracy of the ACE. The CONFIGURATION mode stores the parameters that affect the operational status of the ACE.

2.3.2. PASSWORD PROTECTION

The ACCUM TOTAL clearing function, the RESTORE NEW UNIT function, the CALIBRATION mode, and the CONFIGURATION mode are protected by a password to prevent unauthorized personnel from modifying system settings. All ACE systems are shipped from the factory with a password of 2001. It is recommended that this password be changed when the unit is received. Any password from 0001 to 9999 is acceptable. The password should be confidential information shared only by the service technician and his supervisor.

2.3.3. CHANGING MODES

To enter the CALIBRATION mode, press the **MODE** key twice, "PASSWORD" will appear on the display. Use the **PRINT** and **CLEAR** keys to enter in the password. Upon completion of entering the password, depress the **MODE** key to advance to the CALIBRATION mode. If an incorrect password is entered, the unit will return to the OPERATING mode. Once in the CALIBRATION mode, use the **SELECT** or **CONTROL** keys to scroll through the fields. To change a field value use the **CLEAR** and **PRINT** keys. Pressing the **MODE** key while in the CALIBRATION mode shifts the unit into the CONFIGURATION mode. In the CONFIGURATION mode, use the **SELECT** or **CONTROL** keys to scroll through the fields and the **PRINT** and **CLEAR** keys to change setup values. Pressing the **MODE** key while in the CONFIGURATION mode returns the ACE to the OPERATING mode

WARNING - YOU MUST REMEMBER THE PASSWORD OR YOU WILL NOT BE ABLE TO CLEAR THE ACCUM-TOTAL or ENTER THE ACE CALIBRATION AND CONFIGURATION MODES.

THIS PAGE LEFT INTENTIONALLY BLANK.


3. OPERATING MODE

3.1. INTRODUCTION

The OPERATING mode is used to perform bulk deliveries of cryogenic fluids from transport trucks. Before and during the delivery the ACE provides warning messages if the unit is being operated outside the programmed temperature, pressure, or flow range. For equipment failures the ACE displays diagnostic messages. There are also helpful messages to aid in making deliveries and printing tickets.

3.2. OPERATING MODE ACCESS

Figure 4: Operating Mode Access Chart



The OPERATING mode is the normal or default mode of operation of the ACE. If the unit is in the MAINTENANCE mode, press the **MODE** key twice to place the ACE into the OPERATING mode. If the unit is in the CALIBRATION mode, press the **MODE** key twice, or if in CONFIGURATION mode press the **MODE** key to return the ACE to the OPERATING mode.

3.3. OPERATOR KEY FUNCTIONS


The key functionality is as follows:

- **MODE** - Advances from one mode of operation to another. When in the OPERATING mode, pressing this key once changes the unit to the MAINTENANCE mode. Pressing the MODE key twice while in the MAINTENANCE returns the unit to the OPERATING mode. If the mode key is accidentally pressed in the OPERATING mode, press the key twice to return back to the OPERATING mode.
- **SELECT** - Scrolls down through the display fields.
- **CONTROL** - Scrolls up through the display fields.
- **PRINT** – Initiates the printing of tickets and logs the delivery information.
- **CLEAR** - When pressed twice, clears the most recent delivery total, resets the ticket printing function, and clears the internal error log.

3.4. DISPLAY FIELDS

The Delivery Total is the default field displayed in the Operating Mode. Press the **SELECT** key to scroll to other fields in the Operating Mode. The ACE automatically returns to the Delivery Total field in 30 seconds if no key is pressed.

Figure 5: Operating Mode flowchart.



3.4.1. DELIVERY TOTAL

During a delivery, this field displays the total compensated equivalent delivery based on the units of measure selected in the CONFIGURATION mode.

3.4.2. ACCUM. TOTAL

This field displays the total compensated amount of product metered since this field was last cleared.

3.4.3. FLOWRATE

Displays the volumetric flowrate in GAL/MIN or LIT/MIN dependent on the setting of SYS OF MEASURE.

3.4.4. FLOWRATE

Displays the mass flowrate of the product in LBS/MIN or KG/MIN dependent on the setting of SYS OF MEASURE.

3.4.5. TEMPERATURE

During a delivery, this field displays the temperature of the fluid. If a temperature probe is not in use or fails, the unit displays the Default Temperature stored in the CALIBRATION mode.

3.4.6. PRESSURE

This field displays fluid pressure if a pressure transmitter is used. If a pressure transmitter is not in use or fails, the unit displays the default pressure stored in the CALIBRATION mode.

3.4.7. DENSITY

During a delivery, this field displays the fluid density based on the method of compensation.

3.4.8. TIME

Displays the time of day.

3.4.9. DATE

Displays the date.

3.4.10. AUDIT TRAIL CAL

Displays the audit number last used. This field increments by one whenever the CALIBRATION mode is entered and settings are changed. Service personnel can not modify this field.

3.4.11. AUDIT TRAIL CONF

Displays the audit number last used. This field increments by one anytime that the CONFIGURATION mode is entered and settings are changed. Service personnel can not modify this field.

3.5. WARNING MESSAGES DURING DELIVERIES

ACE has a number of warning messages which may alternately flash when something is wrong during a delivery. These messages detect both system problems and errors in operation.

3.5.1. LOW FLOW WARNING

The flow rate has fallen below the limits of the LOW FLOW LIMIT set in the CALIBRATION mode. It is normal to see this error message when cooling down and when switching over from recirculation to product delivery.

3.5.2. HI FLOW WARNING

Means that the flow rate has exceeded the maximum limits of the HIGH FLOW LIMIT, set in the CALIBRATION MODE. This message may also appear if the meter is being gas spun by cold gas. This can occur even if the delivery total is inhibited by the gas cutout feature. HI FLOW WARNING error is reported on the Trip Report.

3.5.3. TWO PHASE WARNING

Means that the liquid is approaching a point where it may contain bubbles which will cause over registration of the delivery total. Here again, it is normal to see this message while the meter is being cooled down.

3.5.4. GAS INHIBIT ON

Occurs when the conditions in the delivery reach a point where the meter system determines there is no longer liquid in the meter run. This message appears before and during cool down and after the delivery has been completed. This is a normal part of a delivery. If it happens during a delivery, it is possible that the pump has lost prime. GAS INHIBIT error is reported on the Trip Report.

3.5.5. COMP RANGE OUT

Means the fluid is out of accurate measurement range. This occurs if the liquid is too hot or cold. This message will appear in normal operation during cool down and after the delivery is complete. The COMP RANGE OUT error message is reported by the Trip Report.

3.5.6. PULSE FAILURE

This error is displayed on PTB approved systems when the dual pulse output of the flowmeter does not agree in frequency, phase, and amplitude. The PULSE FAILURE error is reported on the Trip Report.

NOTE: The PRT OUT OF PAPER and PRINTER OFF LINE error messages are only enable when DEVICE ATTACHED is set to TM-295 ERR. CHK.

3.5.7. PRT OUT OF PAPER

This message is displayed when an attached TM -295 ERR CHK printer runs out of paper during a print cycle. When this error occurs, insert a form into the printer and depress the **PRINT** key to generate the delivery ticket.

3.5.8. PRINTER OFF LINE

This message is displayed when an attached TM -295 ERR CHK printer does not respond to a print command. To correct this error, first check that the printer's power is on. If the printer is turned on, then check the wiring from the printer to the ACE.

Please see the SERVICE GUIDE section for other messages that may be displayed.

3.6. PUMP INTERLOCK (OPTIONAL)

The ACE uses a cool down timer and a gas detection function (GAS INHIBIT) to enable or inhibit the PUMP INTERLOCK. The Interlock Delay Countdown Timer is used to program the amount of time that should elapse before the pump can be started. Before the pump can be started, the gas detection feature ensures that liquid exists at the pump. To configure the Interlock Delay Countdown Timer, use the following settings in the Configuration Mode.

3.6.1. INTERLOCK DELAY

The Interlock Delay setting, sets the amount of time that the ACE allows for pump cool down. After time-out the gas detection function will check for the presence of liquid at the pump before the pump is energized. Delay time is adjustable from 0 to 99 minutes, in 1 minute increments. A value of "0" disables the Interlock countdown timer.

3.6.2. INTER TEMP SETPT (Interlock Temperature Set-point)

This is the temperature that ACE uses to initiate the Interlock Delay Countdown Timer. Enter a value corresponding to the temperature at which the Interlock Delay Countdown Timer is to start.

The Pump Interlock control operates based on the following conditions:

1. The Interlock Delay count down timer will be enabled when the fluid temperature reaches the Interlock Temperature Set-point.
2. When the Interlock Delay Countdown Timer is enabled, the Pump Cooling message is displayed until the delay has timed out. The Interlock delay can be set from 0 to 99 minutes. For example, if the delay is set to 5 minutes, the following will occur.
 - A. The ACE will monitor the fluid temperature.
 - B. When the fluid temperature reaches the Interlock Temperature Set -point, the ACE enables the Interlock Delay Countdown Timer.
 - C. When the Interlock Delay Countdown Timer is engaged, the " PUMP CLG *mm:ss*" message is displayed. Where *mm* is the number of minutes left in the countdown period and *ss* is the number of seconds left in the countdown.
 - D. At the end of the of the Interlock Delay countdown, the system enables the Pump Interlock relay, if liquid is present. If gas is detected, then the pump will wait until liquid is detected.
 - E. If a GAS INHIBIT error occurs, then the system inhibits the Pump Interlock after a 2 second delay and waits until the fluid conditions returns to a liquid state. After

the fluid condition returns to a liquid state, the ACE enables the Pump Interlock relay. During operation, if at any time the temperature exceeds the Interlock Temperature Set-point, the ACE inhibits the Pump Interlock and resets the Pump Interlock Control.


3.6.3. Austria Approved ACE Systems.

For Austria approved ACE systems there are several additional requirements for the pump interlock control. They are:

1. No errors are recorded during the first minute of operation.
2. The pump interlock is disabled when any monitored error occurs for more than one minute. See *Table 2, Monitored Error Faults*.
3. The pump interlock is disabled when the flowrate is less than $\frac{1}{2}$ of the Minimum Flowrate value for more than one minute.
4. The pump interlock is disabled immediately on Probe Open and/or Probe Short errors.
5. For a Pulse Failure error, the pump interlock is disabled if the accumulated total of missing pulses exceeds 5% of the minimum delivery.

After the pump shuts down due to the conditions above, a ticket must be printed and the **CLEAR** key must be pressed twice to reset the ACE to normal operation. See *Section 3.7.3*.

Figure 6 Pump Interlock Control flowchart



3.7.

PRINTING

This section only applies to those systems connected to a printer. The ACE records and assigns a drop number every time the **PRINT** key is pressed after making a delivery. A delivery occurs when the display is zeroed at the beginning of the drop and the **PRINT** key is depressed twice at the end of the drop.

When a printer not being used on the trailer, a log of the delivery may be maintained by pressing the **PRINT** key twice. This holds the delivery information in the ACE memory and allows for the printing of the Trip Report summary later.

NOTE: The Meter Code requires the ticket to be in the printer prior to the starting of the delivery.

NOTE: The PRT OUT OF PAPER and PRINTER OFF LINE error messages are only enabled when DEVICE ATTACHED is set to TM295 ERR. CHK and a TM-295 printer is attached to the ACE.

3.7.1. PRINTING THE DELIVERY TICKET

Use the following procedure to print delivery tickets:

1. Press the **RELEASE** key on the printer keypad. Insert the ticket into the slip printer tray with the ticket face up and the top of the form directed into the printer.
2. Press the **FORWARD** or **REVERSE** key to lock the form in place and to orient the form in the print starting position.
3. Make the delivery.
4. Press the **PRINT** key and the **RDY DELIVERY FRM** message appears on the display. Press the **PRINT** key a second time and the ACE initiates the printing of the delivery ticket. If a **PRINTER OFF LINE** error appears, this indicates that either the power is not applied to the printer or that the wiring between the ACE and the printer is defective. If the printer power switch is turned on and the power light of the printer is off, check the power and communications wiring between the ACE and the printer. After the printer errors are corrected, press the **PRINT** key twice on the ACE to initiate the delivery ticket printing cycle. If the printer runs out of paper during printing, the **PRT OUT OF PAPER** error message is displayed and the printing cycle stops. Insert the paper into the printer and repeat this step.
5. After the ticket is printed, the ACE returns to the operating state.
6. Press the **RELEASE** key on the printer to remove the ticket.

3.7.2. DUPLICATE PRINTING

- Should the ticket be illegible, lost, or jammed in the printer, a duplicate ticket may be printed by repeating the previous steps. The words **DUPLICATE TICKET** are printed at the bottom of the ticket. Duplicate tickets can be printed until the **CLEAR** key is pressed twice.
- If you accidentally turn the ACE off before printing a delivery ticket, return the power and the ACE will restore the reading at the time the unit was turned off.

3.7.3. AUSTRIA APPROVED ACE SYSTEMS.

For Austria approved ACE systems there are several additional requirements for the printed delivery tickets. Those requirements are:

1. If the pump is shut down due to the conditions listed in Section 3.6.3, the asterisks (*) are removed from the total. See *Table 2 Monitored Error Faults*.
2. If the total that is accumulated when errors occurs during the delivery process exceeds the Maximum Allowable Error requirements, the asterisks (*) are removed from the total on the delivery ticket.
3. If the total that is accumulated during a delivery is less the Minimum Delivery quantity, the asterisks (*) are removed from the Delivery Ticket.

The Austria approved ACE systems uses the Flowmeter Size setting located in Configuration Mode to set the values for Minimum Flowrate, Maximum Flowrate, and Minimum Delivery. See *Table 1 Austria Flowmeter Size Selection*.

Table 1 Austria Flowmeter Size Selection

Flowmeter Size	Min. Flowrate l/min (gal/min)	Max. Flowrate l/min (gal/min)	Min. Delivery kg (lbs)
DN25	46.0 (12.152)	230 (60.760)	10 (22.046)
DN40	100 (26.417)	500 (132.086)	100 (220)
DN50	170 (44.909)	850 (224.546)	100 (220)

Table 2 Monitored Error Faults

Monitored Error Faults For Austria Approved Systems		
Monitored Errors	Is Error reported on trip report?	Are the Asterisks printed on the ticket as define by the fault conditions listed in Section 3.6.3?
PROBE OPEN	Yes	No
PROBE SHORT	Yes	No
PRES OVERRANGE	Yes	No
PRES SIG LOST	Yes	No
GAS INHIBIT ON	Yes	No
COMP RANGE OUT	Yes	No
HIGH FLOW WARNING	Yes	No
LOW FLOW WARNING Flow < 50% of Minimum Flow value.	No	No
PULSE FAILURE	Yes	No

3.7.4. PTB APPROVED ACE SYSTEMS.

For PTB approved ACE systems, if a Pulse Failure occurs during a delivery, the asterisks (*) will be removed from the total on the delivery ticket.

4. MAINTENANCE MODE

4.1. INTRODUCTION


The service personnel are required to periodically calibrate and adjust the equipment, maintain records of calibration, perform preventive maintenance, and troubleshoot malfunctions. The ACE helps to perform these functions.

The ACE has extensive self-test capabilities. The system self-tests with each power-up and continues testing the cables and probes as it is being used. The operator is informed of any problems by warning messages.

The ACE system has a number of built-in test facilities. These test facilities allow for diagnosing and correcting meter problems without the need for specialized equipment.

4.2. MAINTENANCE MODE ACCESS

Figure 7: Maintenance Mode access flowchart.



To enter the MAINTENANCE mode press the **MODE** key while in the OPERATING mode. To exit the MAINTENANCE mode, press the **MODE** key twice. Upon reentry into the MAINTENANCE mode, the ACE displays the last MAINTENANCE field displayed, if power has not been interrupted. While in the MAINTENANCE mode, if no keys are pressed for a predetermined amount of time, the ACE automatically returns to the OPERATING mode. This predetermined amount of time is dependent on the DIS TIME OUT SEC as set in the CONFIGURATION mode.

4.3. **KEYBOARD ENTRY**

Field parameters are presented in two basic forms:


- **NUMERIC FIELDS** are used for date and serial number storage. The **CLEAR** key and the **PRINT** key are used for data entry in these fields.
- **TEST FIELDS** display messages showing which test is currently selected. Press the **PRINT** key to execute the test.

The key functionality is as follows:

- **MODE** - Advances from one mode of operation to another. When in the OPERATING mode, pressing this key once changes the ACE to the MAINTENANCE mode.
- **SELECT** - Scrolls down through the display fields.
- **CONTROL** - Scrolls up through the display fields.
- **PRINT** - Commands the ACE to print a report, increment a number when in a numeric field, or execute a test.
- **CLEAR** - Moves the cursor to the next digit when in a numeric entry field.

4.4. MAINTENANCE MODE FIELDS

Figure 8: Maintenance Mode flowchart.



4.4.1. CLEAR TOTALIZER

This utility is used to reset the Accumulated Total to zero. The operator in the Operating mode can not clear the ACCUM TOTAL display. To clear the ACCUM TOTAL, follow the steps listed below.

- Press the **CLEAR** key while CLEAR TOTALIZER is displayed in the Maintenance mode and the Password Entry field will be displayed.
- Enter the password by using the **CLEAR** and **PRINT** keys.
- Press the **MODE** key. If the correct password is entered, the system clears the Accumulated Total, displays the CLEARED TOTALIZER message momentarily and returns to the Operating mode. If an incorrect password is entered, the system returns to the OPERATING mode.
- Not available on Austrian systems.

4.4.2. FLUID TYPE

On PTB and AUSTRIA approved multi-fluid systems use the **PRINT** key to select the fluid:

- LIN
- LOX
- LAR

When the Fluid Type is changed in the Maintenance mode, the Audit Trial Con display is incremented by one.

4.4.3. DELIVERY MODE

On PTB and AUSTRIA approved CO2 systems use the **PRINT** key to select:

- **SINGLE PIPE:** The SINGLE hose delivery counts all product delivered through the meter on the totalizer. No correction is made for a vapor return or vapor balance line.
- **DUAL PIPE:** A DUAL hose delivery occurs when a vapor return or vapor balance line is used in conjunction with the liquid delivery line. When the DUAL pipe method is selected, the totalizer automatically deducts the displaced vapor from the delivered total.

When the DELIVERY MODE is changed in the Maintenance mode, the Audit Trial Con display is incremented by one.

NOTE The PRT OUT OF PAPER and PRINTER OFF LINE error messages are only enabled when DEVICE ATTACHED is set to TM-295 ERR CHK.

4.4.4. PRINT TRIP RPT

Use the following procedure to print a Trip report.

1. Press the **RELEASE** key on the printer keypad. Insert the Trip report form into the slip printer tray with the form face up and the top of the form directed into the printer.
2. Press the **FORWARD** or **REVERSE** key to lock the form in place and to orient the form in the printing starting position.

3. Press the **PRINT** key and RDY TRIP REPORT appears on the screen. Press the **PRINT** key a second time and the system starts printing the Trip Report. If PRINTER OFF LINE error message appears, it indicates that either the power is not applied to the printer or that the wiring between the ACE and the printer is defective. If the power switch is turned on and the power light of the printer is off, check the wiring between the ACE, the printer, and the power source. After the printer errors are corrected, depress the **PRINT** key on the ACE to start the Trip Report.
4. This step only applies to ACE systems that are using the TM -295 FDW printer. If the printer runs out of paper before the end of the trip report, press the RELEASE key on the printer and insert the next Trip Report form into the printer. The ACE continues to print the trip report. If paper is not inserted into the printer within 90 seconds, the ACE system resets the Trip Report printing operation. The "CLR SUMMARY LOG" message does not appear until a complete trip report is printed.
5. The trip report consists of the last 20 deliveries or the number of deliveries made since the delivery log was last cleared, whichever is less. At the end of the trip report, the ACE also prints a Maintenance report. The Maintenance report advises the service personnel of any problems encountered during any of the deliveries. This report prints only those deliveries where problems were detected.
6. Following completion of the printing of the delivery log, the ACE displays "CLR SUMMARY LOG?". Clearing the log is accomplished by depressing the **CLEAR** key. This action erases the old delivery information and resets the delivery drop number to zero.
7. If there were problems printing the trip report, respond to "CLR SUMMARY LOG?" by depressing the **SELECT** key. This action does not alter the contents of the delivery information log. Then repeat the steps necessary to print a trip report.

NOTE: The PRT OUT OF PAPER and PRINTER OFF LINE error messages are only enabled when DEVICE ATTACHED is set to TM-295 ERR CHK.

4.4.5. PRINT SETUP

This function initiates the printing of the system Calibration and Configuration parameters. Use the following procedure to print the Setup Report.

1. Press the RELEASE key on the printer keypad. Insert the form into the slip printer tray with the ticket face up and the top of the form directed into the printer.
2. Press the FORWARD or REVERSE key to lock the form in place and to orient the form in the printing starting position.
3. Press the **PRINT** key and RDY SETUP RPT appears on the display. Press the **PRINT** key again and the system starts printing the SETUP report. If a PRINTER OFF LINE error message appears, it indicates that either the power is not applied to the printer or that the wiring between the ACE and the printer is defective. If the power switch is turned on and the power light of the printer is off, check the wiring between the ACE, the printer, and the power source. After the printer errors are corrected, depress the **PRINT** key twice on the ACE to start the Trip Report.
4. If the printer runs out of paper or the ACE displays PRT OUT OF PAPER error, insert paper into the printer and repeat step 3.
5. After the Setup Report has completed printing, press the RELEASE key on the printer to release the form.

4.4.6. TRIM ADR1

The TRIM ADR1 TEST utility aids in factory adjustment of the temperature input signal conditioner. It is not intended for use by field service personnel.

4.4.7. TRIM ADR2

The ADR2 TEST utility aids in factory adjustment of the pressure input signal conditioner. It is not intended for use by field service personnel.

4.4.8. COIL RESISTANCE

The COIL RESISTANCE TEST displays the resistance in ohms of the flowmeter pickup coil. Under normal operation, this is the resistance generated by the flowmeter pickup coil and the signal cable. This option can accurately measure up to approximately 3500 ohms. Therefore, an open circuit will be designated as any value above this value. This test should be completed with a warm coil. Normal coil resistance should be in the range of 1600 -2500 ohms. If the coil resistance reading is higher or lower the coil may need to be replaced.

4.4.9. RTD RESISTANCE

The RTD RESISTANCE TEST displays the resistance in ohms of the temperature probe input. Under normal operation, this is the resistance generated by the temperature probe. Normal RTD resistance measurements will be in the range of 175 -1200 ohms depending on the temperature. If the reading is higher or lower the RTD may need to be replaced.

4.4.10. COIL FREQUENCY

This test displays the frequency being generated by the ACE turbine flowmeter pickup coil.

4.4.11. SELF TEST

This test verifies the counting circuitry of the circuit board. This test runs a circuit loopback test from the pulse output through the flowmeter signal conditioner back to the flow totalization and rate detector. If the circuitry is functioning, "LOOP BACK PASSED" is displayed. If the test fails, "LOOP BACK FAILED" is displayed. Should the test fail, this indicates a malfunctioning printed circuit board. Repairs at this level should only be performed at HFC.

4.4.12. DISPLAY TEST

Checks all the display positions and characters for proper operation and appearance. During the test the display must be monitored for proper operation. The unit displays from 0 to 9 and from A to Z. To initiate the test press the **PRINT** key. To exit this test, depress the **SELECT** key.

4.4.13. KEY TEST

Verifies keyboard operation and wiring. After initiating this test with the **PRINT** key, the unit displays the information for each key pressed by the operator. The field changing and mode control keys will be enabled after the test is terminated. To terminate the test, do not press any keys for 3 seconds.

4.4.14. PRINTER TEST

Verifies proper operation of the printer connected to the ACE. Proper operation is verified by printing alphanumeric characters.

4.4.15. PULSE OUT TEST

This test verifies the pulse output option. This test also verifies that any equipment connected to this output is receiving the correct number of pulses. Press the **PRINT** key and 1000 pulses are sent out of the pulse output

4.4.16. PROVER IN TEST

Verifies the operation of the prover input and wiring to the remote prover switch. The prover input controls the pulse accumulator of the ACE system. The ACE displays SWITCH OFF when the pins of the prover input connector are shorted. With no connection at the prover input connector SWITCH ON is displayed on the ACE.

4.4.17. RS-232 ECHO TEST

The RS-232 ECHO TEST is currently disabled. Perform the PRINTER TEST to verify the operation of the RS-232 serial port.

THIS PAGE LEFT INTENTIONALLY BLANK.

5. CALIBRATION MODE


5.1. INTRODUCTION

The CALIBRATION mode is used to set the ACE calibration parameters. The ACE is preprogrammed from the factory based on user specifications. All numeric calibration parameters for ACE are entered in U.S. customary units of measure regardless of the unit of measure selected.

CAUTION - WHEN MAKING CHANGES IN THE CALIBRATION MODE, THE ACE MUST BE RETURNED TO THE OPERATING MODE BEFORE TURNING THE POWER OFF. ANY CHANGES WILL NOT BE UPDATED IN MEMORY IF THE POWER IS REMOVED BEFORE RETURNING THE SYSTEM TO THE OPERATING MODE.

5.2. CALIBRATION MODE ACCESS

Figure 9: Calibration Mode access flowchart.



To enter the CALIBRATION mode from the OPERATING mode, press the **MODE** key twice. Upon pressing the **MODE** key for the second time, the screen prompts for the password. Use the **CLEAR** and **PRINT** key to enter in the password . After the correct password is entered press the **MODE** key to enter the CALIBRATION mode. To exit the CALIBRATION mode and return to the OPERATING mode, press the **MODE** key twice. To exit the CALIBRATION mode and move to the CONFIGURATION mode press the **MODE** key once. After initial power up, the AVERAGE K₁-FACTOR field is the default field selected upon entry into the CALIBRATION mode. For LPG systems METER K₁-FACTOR is the default entry when the CALIBRATION mode is enter after initial power -up. If the CALIBRATION mode is reentered, assuming no power loss, the unit displays the last CALIBRATION field selected.

5.3. **KEYBOARD ENTRY**

Calibration parameters are presented in two forms:


- **NUMERIC FIELDS** - are used for calibration data, date, time, and other required numeric setup data. The **CLEAR** and **PRINT** keys are used for data entry in these fields.
- **LABEL FIELDS** - shows the currently selected option. To change the option press the **PRINT** key.

Key functions are as follows:

- **MODE** - Advances from one mode of operation to another. When in the CALIBRATION mode, pressing this key changes the unit to the CONFIGURATION mode. Pressing the **MODE** key again returns the program to the OPERATING mode.
- **SELECT** - Scrolls down through the selected mode field entries.
- **CONTROL** - Scrolls up through the selected mode field entries.
- **PRINT** - Changes the selection in label fields. In numeric fields the **print** key increments the number the cursor is under by one.
- **CLEAR** - Moves the cursor over one character during numeric data entry.

5.4. CALIBRATION FIELDS

Figure 10: Calibraiton Mode flowchart.



5.4.1. AVERAGE KFACTOR

Use the **CLEAR** and **PRINT** keys to enter the average K -Factor from the flowmeter calibration data sheet. For LPG ACE units enter the K-FACTOR that is stamped on the flowmeter.

5.4.2. AVERAGE M-FACTOR (LPG VERSION)

For LPG systems use the **CLEAR** and **PRINT** key to enter the average M -Factor from the flowmeter calibration data sheet.

5.4.3. BLADES

Use the **CLEAR** and **PRINT** keys enter the number of number of blades on the turbine flowmeter rotor. Examine the flowmeter to determine the number of blades.

5.4.4. DEFAULT TEMPERATURE

Use the **CLEAR** and **PRINT** keys to enter the default temperature for the ACE to use in the case of a temperature probe failure. This value is also used when the temperature method is set to MANUAL.

5.4.5. DEFAULT PRESSURE

The DEFAULT PRESSURE is in PSIA, and is the pressure that the ACE uses if the MANUAL transmitter method is chosen or if the pressure transmitter fails. This parameter may be used as part of the density calculation or in the cavitation warning error messages. It is recommended that this be set equal to the nominal discharge pressure at the flowmeter.

5.4.6. DEFAULT DENSITY

Enter the default density for the selected fluid. This value is automatically selected when the manual density method is chosen.

LINEARIZATION: ACE performs flowmeter linearization if the K-factor (M-Factor for LPG) method is set to linearize. The frequency parameters are entered in units of Hz. The K-Factor is entered in units of pulses per gallon. M-Factor is the ratio of meter total to the actual total. This data comes from the factory supplied flowmeter calibration data sheet or from independent calibration runs. Frequency 1 and K-factor (M-factor) 1 and other similarly numbered entries, form five table point pairs. NOTE - THE LINEARIZATION PAIRS MUST BE ENTERED STARTING WITH THE LOWEST FREQUENCY FIRST.

5.4.7. FREQUENCY 1-5

Frequency 1 -5 are the frequencies at which the five K/M -Factors are specified. The five frequencies programmed into the ACE correspond to the five K/M-Factors, respectively. Use the **CLEAR** and **PRINT** key to program the numerical values representing the frequencies. For proper operation, all frequencies must be programmed with one digit after the decimal point (i.e. 234.5).

5.4.8. K/M-FACTORS 1-5

K/M-Factors 1-5 are the flowmeter characteristics used to calibrate the ACE system when the system FLOW CAL METHOD is set to LINEARIZE. On non-LPG systems, the K-Factors are specified in units of PULSES/GALLON. On the LPG system, the M-FACTOR is unit-less.

5.4.9. DATA AVERAGE

The DATA AVERAGE feature is used to smooth out readings for the flow rate, temperature, and pressure that may fluctuate due to rapidly changing conditions. Valid data average entries are 01 to 99. The unit will average data before displays are updated for the number of times data average is set. The lower the data average number, the faster the display responds to changing conditions. The higher the data average number, the slower the ACE responds to changing conditions.

5.4.10. PULSE WEIGHT

The pulse weight is the calibration factor used for the pulse output option. It represents the amount of mass in pounds for pulse out. Use the **CLEAR** and **PRINT** keys to enter the desired pulse weight. The maximum pulse output rate is 123 pulses per second. The pulse weight determines the amount of delivery total in pounds that each output pulse represents. A pulse weight of 1.0 makes each pulse equal to a one pound of the delivery total (i.e., 1 pulse = 1 pound). A pulse weight of 0.1 causes each pulse to equal 1/10 pound of a delivery total (1 pulse = 1/10 pound).

5.4.11. HIGH FLOW LIMIT

HIGH FLOW LIMIT is the flow rate in GPM where the HIGH FLOW WARNING message is displayed. Enter the maximum flow rate for the flowmeter in GPM. If the flow rate during a delivery run is higher than the HIGH FLOW LIMIT, a message is displayed warning of the high flow condition. The flow rate should be reduced until the message is no longer displayed. Selected by the flowmeter size in Austrian systems.

WARNING - CONTINUOUS OPERATION OF A TURBINE FLOWMETER ABOVE THE MANUFACTURER'S SUGGESTED MAXIMUM FLOWRATE WILL REDUCE THE SERVICE LIFE OF THE FLOWMETER.

5.4.12. LOW FLOW LIMIT

LOW FLOW LIMIT is the flow rate in GPM where the LOW FLOW WARNING message is displayed. Enter the minimum flow rate for the flowmeter in GPM. If the flow rate during a delivery run is lower than the LOW FLOW LIMIT, a message is displayed warning of the low flow condition. The flow rate should be increased until the message is no longer displayed. Selected by the flowmeter size in Austrian systems.

CAUTION - FOR CALIBRATION AND CONFIGURATION MODE CHANGES TO BE UPDATED IN THE ACE MEMORY, THE ACE MUST BE PLACED BACK INTO THE OPERATING MODE.

THIS PAGE LEFT INTENTIONALLY BLANK.

6. CONFIGURATION MODE


6.1. INTRODUCTION

The configuration mode is used to program the ACE configuration parameters. The ACE is preprogrammed from the factory based on user specifications. All numeric configuration parameters for the ACE are entered in U.S. customary units of measure regardless of the unit of measure selected.

CAUTION - WHEN MAKING CHANGES IN THE CONFIGURATION MODE, IT IS IMPORTANT THAT YOU RETURN THE ACE TO THE OPERATING MODE BEFORE TURNING THE ACE OFF. THE CHANGES WILL NOT BE UPDATED IN MEMORY IF YOU DO NOT LEAVE THE MODE BEFORE TURNING THE ACE OFF.

6.2. CONFIGURATION MODE ACCESS

Figure 11: Configuration Mode access flowchart.



To enter the CONFIGURATION mode from the OPERATING mode, press the **MODE** key twice. The next screen prompts for the password. Use the **CLEAR** and **PRINT** keys to enter the password. Press the **MODE** key to enter the CALIBRATION mode. Press the **MODE** key again to gain access to the CONFIGURATION mode. If the CONFIGURATION mode is reentered, assuming no power loss, the unit displays the last CONFIGURATION field selected.

6.3. **KEYBOARD ENTRY**

Configuration parameters are presented in two forms:


- **NUMERIC FIELDS** - for calibration data, date, time, and other required setup numeric data. The **CLEAR** and **PRINT** keys are used for data entry in these fields.
- **LABEL FIELDS** - displays messages showing the currently selected option. To change the option, press the **PRINT** key.

The key functionality is as follows:

- **MODE** - Advances from one mode of operation to another. When in the CONFIGURATION mode pressing this key once changes the unit to the OPERATING mode.
- **SELECT** - Scrolls down through the selected mode field entries.
- **CONTROL** - Scrolls up through the selected mode field entries.
- **PRINT** - Changes the selection in label fields. In numeric fields this key increments the number the cursor is under by one.
- **CLEAR** - Moves the cursor over one character during numeric data entry.

6.4. CONFIGURATION FIELDS

Figure 12: Configuration Mode flowchart.



6.4.1. FLUID TYPE

For multi-fluid systems use the **PRINT** key to select the fluid type:

- LIN,
- LOX
- LAR.

6.4.2. DELIVERY MODE

For CO2 system use the **PRINT** key to select:

- SINGLE PIPE: The SINGLE hose delivery counts all product delivered through the meter on the totalizer. No correction is made for a vapor return or vapor balance line.
- DUAL PIPE: A DUAL hose delivery occurs when a vapor return or vapor balance line is used in conjunction with the liquid delivery line. When the DUAL pipe method is selected, the totalizer automatically deducts the displaced vapor from the delivered total.

6.4.3. SYSTEM OF MEASUREMENT

Use the **PRINT** key to select the appropriate system of measurement for the displays of total, flowrate, density, temperature, and pressure.

- U. S. CUSTOMARY
- METRIC

6.4.4. UNIT OF MEASURE

To define the delivery units, use the **PRINT** key to select:

- VOL@NBP
- MASS
- GAS@NTP

The delivery total displays the following units depending on the SYSTEM OF MEASUREMENT and UNIT OF MEASURE settings.

UNITS	U.S. CUSTOMARY	METRIC
GAS@NTP	FT3	M3
VOL@NBP	GALLONS	LITERS
MASS	POUNDS	KILOGRAMS

6.4.5. K-FACTOR/M-FACTOR METHOD

The ACE offers two ways of calculating the volumetric flowrate. The first uses the AVERAGE K-FACTOR/M-FACTOR from the flowmeter calibration data sheet. The second, LINEARIZED K/M, uses five Frequency/K-factor or Frequency/M-factor pairs from the flowmeter calibration data sheet. The computer measures the flowmeter frequency and calculates the K-factor/M-factor based on the table entries. If the LINEARIZED K/M factor method is chosen, enter valid frequency and K-factor/M-factor pairs. The LPG unit uses M-factors, all other units uses K-factors. Use the **PRINT** key to select:

- LINEARIZED K/M
- AVERAGE K/M-FACTOR

6.4.6. TEMPERATURE METHOD

The ACE requires knowledge of the flowing temperature for density calculations and for proper operation of the cavitation warning messages. If a temperature transmitter is installed and functional, set this option to TRANSMITTER. If no transmitter is present set this option to MANUAL. Use the **PRINT** key to select:

- MANUAL uses Default Temperature.
- TRANSMITTER

6.4.7. PRESSURE METHOD

The ACE requires knowledge of the flowing pressure density calculations and for proper operation of the cavitation warning messages. If a pressure transmitter is installed and functional, set this option to TRANSMITTER. If no pressure transmitter is present set this option to MANUAL. Use the **PRINT** key to select:

- MANUAL uses Default Pressure.
- TRANSMITTER

6.4.8. DENSITY METHOD

The ACE calculates fluid density based on the fluid selected, temperature, and pressure. Use the **PRINT** key to select:

- MANUAL uses Default Density.
- TEMPERATURE
- TEMP & STEEL, only for LPG systems.
- TEMP & PRESS
- TEMP PRESS & ST, only for LPG systems.

6.4.9. FLOWMETER SIZE

For Austria approved ACE systems, the Minimum Flowrate, Maximum Flowrate, and Minimum Delivery settings are dependent on the size of the Flowmeter. See *Table 1 Austria Flowmeter Size Selection*. Use the **Print** key to select:

- DN25
- DN40
- DN50

6.4.10. FLOWMETER S/N

Use the **CLEAR** and **PRINT** keys to enter the flowmeter serial number.

6.4.11. NEXT SERVICE DAY

Use the **CLEAR** and **PRINT** keys to enter the next PMS due date.

6.4.12. TRAILER NUMBER

Use the **CLEAR** and **PRINT** keys to enter the trailer's ID number.

6.4.13. DEVICE ATTACHED

This setting selects the type of printer that is connected to the ACE. Select from:

- TM-290; Use this setting for printers that do not respond to Error Checking commands and for TM-295 printers that are set to the non -error checking mode. Use this setting for ACE systems that do not have a printer attached.
- TM-295 ERR. CHK.; Use this setting if the attached printer responds to the “ESC v” command. The “ESC v” command returns the paper status of the printer. Check your printer documentation for the “ESC v” command. The return code for the presence of paper is hex value 1. Use this setting when the Hoffer supplied printer Epson TM -295 printer is configured for error checking.

Use the table below to configure the Epson TM-295 printer.

Figure 13: TM-295 Dip Switch Settings

Switch	TM-295 Function	Non-Error checking	Error Checking
1	Data reception error	ON- <i>Ignored</i>	OFF - <i>Prints “?”</i>
2	Receive buffer capacity	OFF- <i>512 Bytes</i>	OFF - <i>512 Bytes</i>
3	Handshaking	OFF - <i>DTR/DSR</i>	ON - <i>XON/XOFF</i>
4	Word Length	OFF - <i>8 Bits</i>	ON - <i>7 Bits</i>
5	Parity Check	OFF - <i>Disable</i>	ON - <i>Enable</i>
6	Parity Selection	OFF	ON - <i>Even</i>
7	Transmission Speed (A)	OFF - <i>9600</i>	OFF - <i>9600</i>
8	Transmission Speed (B)	OFF - <i>9600</i>	OFF - <i>9600</i>

6.4.14. BAUD RATE

Baud rate is the speed that data is transferred between the ACE and the attached printer. Both the ACE and the attached printer must be set for the same baud rate. Use the **PRINT** key to select:

- 9600(default)
- 4800
- 2400
- 1200
- 600
- 300
- 150
- 75

6.4.15. HANDSHAKE

Handshake is a communication protocol used to inform the ACE to pause the transmission of data to the printer attached to the RS-232 port. Use the **PRINT** key to select:

- NONE: Use this setting if there is no printer attached to the ACE.
- HARDWARE DTR (default): Use HARDWARE DTR when the attached printer is configured for non-error checking.
- XON/XOFF: Use this setting when the Hoffer supplied Epson TM -295 printer is attached and the printer is configured for error checking.

6.4.16. PARITY

PARITY setting determines the data format used to transmit DELIVERY, SETUP, and TRIP REPORT information to the attached printer. Use **PRINT** key to select:

- OFF: Use this setting for 8 data bits, no parity check.
- ON: Use this setting for 7 data bits, even parity.

To use PARITY data format with the attached printer, the printer dip switches must be set to:

- Word Length = 7 bits,
- Parity Check = Yes,
- Parity Selection = Even.

6.4.17. PASSWORD

The ACE is shipped from the factory with the password 2001. A unique password is required to protect the Accumulated Total, Configuration Mode, and Calibration Mode. The password should be established during the commissioning. Use the **CLEAR** and **PRINT** keys to enter a unique password from 0001 to 9999. This password should be kept confidential. Contact HFC if the password is misplaced

WARNING - YOU MUST REMEMBER YOUR PASSWORD OR YOU WILL NOT BE ABLE TO CLEAR THE ACCUMULATED TOTAL AND ENTER THE CALIBRATION AND CONFIGURATION MODES.

6.4.18. DIS TIME OUT SEC

This setting controls the amount of time that is allowed to elapse before the display automatically returns to the Delivery Total after the SELECT and MODE keys are depressed in the OPERATING or MAINTENANCE modes. A value of zero disables the automatic return to the Delivery Total. Valid entries are 0 to 999 seconds.

6.4.19. DATE

The ACE keeps track of the current date. Enter the date in the *mm/dd/yy* format. The ACE prevents you from entering an invalid date such as Feb 30.

6.4.20. DAY OF THE WEEK

The ACE keeps track of the day of the week. Select the appropriate day by pressing the **PRINT** key.

6.4.21. TIME

The ACE has a 24-hour clock. Enter the current time in the format of *hh:mm:ss*.

6.4.22. RESTORE NEW UNIT

This function restores the ACE to the factory default Calibration and Configuration parameters. Before restoring to the factory defaults, it is recommended to print out the current setup of the instrument. Please see the description for Print Setup in the Maintenance section for instructions on printing the Calibration and Configuration parameters. To restore the system to the factory default settings, first press the **PRINT** key on the ACE when RESTORE NEW UNIT is displayed in the CONFIGURATION mode. Use the **PRINT** and **CLEAR** keys to enter the password. After entering the password, press the **MODE** key. If the correct password is entered, the system resets and restores the Calibration and Configuration parameters to the factory defaults. After the restoring operation, the system returns to the OPERATING mode. If an incorrect password is entered, the system stays in the CONFIGURATION mode and returns to the RESTORE NEW UNIT display. This function is not available on PTB approved ACE systems.

CAUTION - FOR CALIBRATION AND CONFIGURATION MODE CHANGES TO BE UPDATED IN THE ACE MEMORY, YOU MUST PLACE THE ACE BACK INTO THE OPERATING MODE.

7. FIELD COMMISSIONING

ACE Systems are setup at the factory. A setup sheet accompanies shipment of each system. Follow these instructions below to complete this review.

THE CALIBRATION AND CONFIGURATION PARAMETERS MUST BE REVIEWED PRIOR TO USING ACE FOR CUSTOMER DELIVERY.

1. Apply power to the ACE system.
2. Enter the CALIBRATION mode by first pressing the **MODE** key twice. Next enter the default factory password of “2001” using the **CLEAR** and **PRINT** keys. After entering the password, press the **MODE** again and the system enters the CALIBRATION mode.
3. Press the **SELECT** key and review each piece of calibration information against the factory setup sheet to insure accuracy. Correct any discrepancies by using the **PRINT** and **CLEAR** keys to enter the correct calibration settings.
4. Upon reaching LOW FLOW LIMIT, depress the **MODE** key to enter the CONFIGURATION mode.
5. Press the **SELECT** key and review each piece of configuration information against the factory setup sheet to insure accuracy. Correct any discrepancies by using the **PRINT** and **CLEAR** keys to enter the correct configuration values.
6. Upon reaching the PASSWORD field in the CONFIGURATION mode, enter a unique password.
7. After completing your review, depress the **MODE** key to return to the OPERATING mode, then press then the **MODE** to enter the MAINTENANCE mode.
8. Press the **MODE** key twice to return to the OPERATING mode. The system is now ready to be used in the field.
9. Using the Maintenance Mode section instructions, scroll through the MAINTENANCE mode to ensure that the system is operating properly prior to releasing it to service.

THIS PAGE LEFT INTENTIONALLY BLANK.

8. INSTALLATION GUIDE

This section includes information specific to the ACE electronics. For installation information on the turbine flowmeter, temperature probe, pressure probe, or other equipment refer to the individual items technical manuals.

8.1. ELECTRONICS ENCLOSURE INSTALLATION

Please note the following when mounting the ACE system.

- The ACE should be mounted at eye-level for the best viewing angle.
- Install the ACE on a horizontal surface near the access door of the trailer. Allow enough clearance for easy access to the signal cables.

CAUTION!

TRUCK MOUNTED SYSTEMS MUST ENDURE SEVERE VIBRATION ON THE ROAD. THE ACE HAS BEEN DESIGNED TO WITHSTAND THESE CONDITIONS IF INSTALLED IN THE HORIZONTAL POSITION. MOUNTING IN THIS POSITION IS CRITICAL TO ALLOW THE SHOCK MOUNTS TO FUNCTION PROPERLY.

- Please refer to the installation drawings located in the back of this manual.

WARNING!

DO NOT OVER TIGHTEN MOUNTING BOLTS. RECOMMENDED TIGHTENING TORQUE IS 105 LBS-IN. OVER TIGHTENING MAY CAUSE SHOCK MOUNTS TO BREAK.

8.2. INTERCONNECTING CABLE INSTALLATION

- Install and secure cables to avoid contact with cold pipes.
- Attach the cables to the appropriate connector on the back of the ACE.
- The power cable is a three wire cable. Red lead connects to positive (+) battery lead. Black lead connects to negative (-) lead. White lead connects to chassis ground.
- The ACE has no power switch. Hoffer recommends providing the electronics with a direct power lead from the battery. This will reduce interference from other operating systems. If a switch is required, HFC recommends using the main power switch on the trailer.
- Install dust caps on any unused connections.
- Tighten all cable assemblies.
- Please refer to the installation drawings located in the back of this manual.

8.3. FIELD COMMISSIONING

After the installation of components is complete, the setup parameters must be reviewed prior to using the ACE for customer delivery. See the FIELD COMMISSIONING chapter for information.

8.4. WIRING CONNECTIONS OPTIONAL PRINTER

- The ACE printer requires two cables for proper operation. One cable is for connection to the ACE and the other for connection to the DC power supply. Connect both cables to the printer and to the ACE
- Please refer to the installation drawings located in the back of this manual.

9. SERVICE GUIDE

9.1. TROUBLE SHOOTING

The ACE provides extensive self-checking capabilities which will assist in troubleshooting and repairing a malfunctioning system. The following is a troubleshooting guide for corrective action in the field.

CONDITION	POSSIBLE CAUSE	CORRECTIVE ACTION
"PROBE OPEN" MESSAGE	Bad cable connection	Reconnect cable
	Bad cable	Test cable using an ohm meter
	Bad RTD	Replace temperature probe
	Bad PCA-134	Replace/Repair PCA-134
"PROBE SHORT" MESSAGE	Bad cable	Test cable using an ohm meter
	Bad RTD	Replace temperature probe
	Bad PCA-134	Replace/Repair PCA-134
"COIL OPEN" MESSAGE Note: Message not displayed on Dual Coil Systems.	Bad cable connection	Reconnect cable
	Bad cable	Replace cable
	Bad coil	Replace pickup coil
	Bad PCA-134	Replace/Repair PCA-134
"COIL SHORT" MESSAGE Note: Message not displayed on Dual Coil Systems.	Bad cable	Test cable with an ohm meter
	Bad coil	Replace pickup coil
	Bad PCA-134	Replace/Repair PCA-134
"TOTAL READ" MESSAGE	Read collision	Maybe self-correcting. If not, replace Microcontroller/memory integrated circuit.
	Bad PCA-134	Replace/Repair PCA-134
"FAILED LOOP BACK" MESSAGE	Circuitry Failure	Replace/Repair PCA-134
"COP TIME OUT"	Software/Setup error	Maybe self-correcting. If not, replace Microcontroller/memory integrated circuit.

CONDITION	POSSIBLE CAUSE	CORRECTIVE ACTION
"RATE MALFUNCTION" MESSAGE	Software error	Maybe self-correcting. Disconnect and re-apply power.
"EEPROM FAILURE" MESSAGE	Defective IC	Replace Microcontroller integrated circuit.
"2 PHASE WARNING" MESSAGE	Operator error	Operator allowed pressure and/or temperature to be within 25 PSI of the saturated pressure during a delivery. Take no action.
"GAS INHIBIT ON" MESSAGE	Operator error	Operator began a delivery run before the system was fully cooled down
"HIGH FLOW WARNING" MESSAGE	Operator error	Operator gas spun the meter during a delivery run
	High flow setpoint is set to low	Raise the setpoint in the setup mode.
"LOW FLOW WARNING" MESSAGE	Operator error	Operator started the delivery run at a flow rate that was outside the meter range or below the low flow setpoint.
	Low flow setpoint is set to low	Raise the low flow setpoint in the setup mode.
"COMP RANGE OUT" MESSAGE	Operator error	Operator began delivery before the system was fully cooled down.
	Temperature detector error	Test the temperature feature using simulator.
"PULSE FAILURE" MESSAGE <i>Only displayed on PTB and Austria approved and Dual Coil systems.</i>	Occurs when the dual pulse output of the flowmeter does not agree in frequency, phase and amplitude.	System has detected noise or the flowmeter transducer has failed. See section 9.2, "TROUBLESHOOTING THE MEASUREMENT TRANSDUCER FOR DUAL COIL SYSTEMS."

During operation, certain malfunctions may be observed. The following is a troubleshooting guide for corrective action in the field.

OBSERVED CONDITION	SUGGESTED CORRECTIVE ACTION
ACE not functioning, no lights on front panel lit.	Check power cable
	Check fuse F-1 on front panel
	Check/Repair ACE internal wiring
No display, printer light on	Check fuse F-2
	Check/Repair internal wiring to PCA-134
	Check fuse on PCA-134
	Check/Repair PCA-134
Garbage on Display	Turn the ACE off then on
	If problem persist, contact HFC
Character on display is distorted	Test the keyboard using the keyboard test in the maintenance mode
	Replace display if characters are distorted
Front panel key inoperative	Test the keyboard using the keyboard test in the maintenance mode
	Check the internal cable wiring and connectors
	Replace keyboard
	Repair/Replace PCA-134
Printer inoperative, but light is on	Press the test key on the printer
	If test fails replace printer
	Run the printer test from the maintenance
ACE inaccurate	Verify operation using signal simulators. See chapter 9 for details.
	Verify that the setup parameters are correct for the system configuration.
	Inspect the flowmeter internals to ensure proper operation.
	Prove meter and recalibrate.
ACE does not keep correct time and date	Replace battery located on PCA-134 board. See section 9.3.2, "INTERNAL BATTERY REPLACEMENT."

9.2. TROUBLESHOOTING THE MEASUREMENT TRANSDUCER FOR DUAL COIL SYSTEMS

9.2.1. GENERAL

The object of this testing is to verify the checking facility, to verify the presence of the measurement transducer, its correct operation and the correctness of the data.

9.2.2. TEST EQUIPMENT

The following test equipment is required:

1. Two ACC5A count testers.
2. Two Frequency Counters.
3. DVM (Digital Multimeter)

9.2.3. FLOWMETER CHECK

Use the DVM to check the resistance of the coils on the Flowmeter. The coil resistance of the Flowmeter coils should be $1800 \pm 20\%$ ohms.

9.2.4. TEST SETUP

- Connect the DC supply to the power connector of ACE. Pin A is the positive supply voltage, Pin B is the power supply common, and Pin C is the chassis connection.
- Connect one ACC5A to the signal input and the second ACC5A to the signal 2 input.
- Set the amplitude of both ACC5As to the 200 mV position.
- Connect the frequency counters across the ACC5As. Connect the positive lead of the frequency counter to the white wire and the negative lead of the frequency counter to the black wire.

9.2.5. TEST PROCEDURE

- Turn power on both ACC5As and the ACE unit.
- Adjust the output frequency of both ACC5As to obtain a frequency of $1000.0 \text{ Hz} \pm 1 \text{ Hz}$.
- Stop both ACC5As from generating a test signal. Clear the displayed total on the ACE unit. Select 100K counts on the ACC5As
- Simultaneously start both of the ACC5A. Observe that the ACE unit is counting.
- Vary the output frequency of one of the ACC5As, while observing the frequency counter. Observe that the ACE unit stops flow totalization when the difference of the two signals is greater than or equal to $10 \text{ Hz} \pm 2 \text{ Hz}$, and displays the error message "PULSE FAILURE".
- Perform the above steps at the test frequency of 150 Hz.
- With both test signals equal to each other, interrupt one signal by either stopping one ACC5A or by disconnecting the signal cable. Observe that the ACE unit stops flow totalization, and displays the error message "PULSE FAILURE". Perform this test with both cables.

9.2.6. ACCEPTANCE CRITERIA

Successful operation will be determined by flow totalization being stopped upon the following criteria:

- When the difference in the input frequency is $10 \text{ Hz} \pm 2 \text{ Hz}$.
- When the input signal is interrupted.

9.3. CORRECTIVE ACTIONS

If the ACE can be powered up, enter the MAINTENANCE mode and use the PRINT SETUP function to create a setup report of the Calibration and Configuration parameters. After the corrective actions are completed use this setup report to verify the Calibration and Configuration parameters. Please see the FIELD COMMISSIONING section of this manual.

CAUTION - THE FOLLOWING PROCEDURES SHOULD BE PERFORMED BY QUALIFIED SERVICE PERSONNEL ONLY. ACE IS A STATIC-SENSITIVE DEVICE AND STANDARD PRACTICE FOR STATIC-SENSITIVE PARTS SHOULD BE OBSERVED.

9.3.1. FUSE REPLACEMENT

The ACE has three fuses, two external and one internal. Should any one of these fuses require replacement the following procedures should be used.

EXTERNAL FUSE:

- Disconnect the power.
- Press in on the fuse cap and twist clockwise.
- Pull fuse holder out of socket and remove the fuse from the holder.
- Verify fuse measures a short with an ohm meter.
- If an open is measured, replace the fuse with a 2amp, AGC.
- Reinstall the fuse holder by pressing and turning clockwise.

INTERNAL FUSE:

- Disconnect the power.
- Remove the front panel screws from the ACE.
- Remove the internal printed circuit board.
- Carefully remove the fuse from the holder.
- Verify fuse measures a short with an ohm meter.
- If an open is measured, replace the fuse with a 1amp, AGC.
- Reinstall the internal electronics. Reconnect power.

9.3.2. INTERNAL BATTERY REPLACEMENT

The built in time clock and memory uses a lithium battery to maintain time, date, and calculated totals when the power supply is turned off. This battery should last approximately four years under normal operating conditions. If the unit does not maintain the proper time, date, and totals after power has been restored to the unit, the lithium battery should be replaced. For battery replacement use the following procedure.

- Disconnect the power.
- Remove the front panel screws from the ACE.
- Disconnect the connectors going to the front panel.
- Remove the printed circuit board.
- Carefully remove the battery located in the center of the board.
- Replace the battery with a compatible new battery.
- Reinstall the printed circuit board into its slot and attach appropriate connectors.
- Reassemble the ACE and reconnect power.
- Go into the CONFIGURATION mode and reset the time and date.
- Before making the next delivery, clear the error log by pressing the **CLEAR** key twice.

9.3.3. FIRMWARE UPGRADE INSTALLATION

The firmware of the ACE is stored in a EPROM located on the main board. This replaceable EPROM allows for periodic upgrades and/or corrective actions to be performed in the field. The ACE displays an SC code during power up. This SC code is the firmware configuration code. When ordering EPROM replacements or upgrades, please give this SC code to the HFC representative. To replace the EPROM, follow these steps:

1. Print the current Calibration and Configuration settings by using the Print Setup utility in the MAINTENANCE mode.
2. Disconnect power.
3. Remove front panel and the main PCB board.
4. Cut the securing tie-down from the U18. Observe the orientation of the EPROM. Carefully remove integrated circuit U18. U18 is the chip with a label on it.
5. Carefully, install the revised replacement chip taking care not to damage any of the leads. Secure U18 using string or cord-tie material.
6. Reassemble the ACE and reconnect power.
7. Verify and adjust setup parameters in the Calibration and Configuration modes.

9.3.4. DISPLAY CONTRAST ADJUSTMENT PROCEDURE

The display contrast and viewing angle is factory -adjusted for eye level. However, the display contrast may be adjusted for optimum viewing angle and contrast after installation.

1. Remove power.
2. Remove the front panel being careful not to strain the interconnecting cables. Using electrical tape, isolate the rear side of the front panel so that the PCB board or other electrical connections cannot create an electrical short to the case.
3. Apply power.
4. Using a small, nonmetallic screwdriver, turn the Display Contrast control clockwise to darken the display or counterclockwise to lighten the display. Please refer to the drawing in the back of this manual for location of the Display Contrast adjustment.
5. After completing the adjustments remove power.
6. Remove the electrical tape applied during step 2 from the front panel and reattach the front panel to the ACE.
7. Re-apply power and check the operation of the display. If the Contrast of the display is not suitable, repeat the steps in this procedure.

9.3.5. MICROCONTROLLER/MEMORY REPLACEMENT

If replacement of the Microcontroller/memory chip is necessary, refer to the instructions which accompany the new chip. An overview of the steps follows.

1. Print current setup data.
2. Disconnect power to the ACE.
3. Remove the front panel of the ACE.
4. Disconnect the wiring harness going to the front panel from the main PCB.
5. Remove the main PCB card.
6. Using a PLCC removal tool, carefully remove the 68HC11 chip being careful not to crack or damage the socket housing. Please refer to the drawings in the back of the manual for the location of the 68HC11 Microcontroller.
7. Install the replacement chip taking care not to bend any of the leads.
8. Install the main PCB back into the ACE.
9. Reconnect the wiring harnesses from the front panel to the main PCB board.
10. Attach the front panel back on to the ACE being careful not to pinch the wiring harnesses.
11. Reconnect power. Allow the ACE to perform a boot -up self test. The ACE should perform a SETUP MEMORY step as part of the first boot -up sequence. If it does not, go to the CONFIGURATION mode and perform the RESTORE NEW UNIT function.
12. Using the setup data printed on the first step, enter the CALIBRATION and CONFIGURATION modes and restore the setup data. Please see the Calibration and Configuration sections of the manual for instructions on entering the setup data.

9.3.6. SENSITIVITY ADJUSTMENT PROCEDURE

The SENSITIVITY is a control used to eliminate false pickup by increasing the signal threshold. This control has been factory adjusted to a level that is satisfactory for the flowmeter size and pickup coil supplied with the system. The SENSITIVITY adjustment is located on the main PCB board inside of the ACE. Please refer to drawings in the back of this manual for location of SENSITIVITY adjustment.

1. Enter the CONFIGURATION Mode of the ACE and set DIS TIME OUT SEC to "999."
2. Remove power.
3. Remove front panel of the ACE.
4. Using electrical tape, isolate the rear side of the front panel so that the PCB board and other electrical connections cannot create an electrical short to the case.
5. Remove the MAIN PCB board.
6. Turned the SENSITIVITY adjustment CCW (counterclockwise) 1/8 of a turn. CCW adjustments reduces the ACE flowmeter input sensitivity to noise. CW (clockwise) adjustments increase the sensitivity of the flowmeter input.
7. Insert the MAIN PCB board back into the ACE.
8. Reapply power.
9. Test the unit to determine if the noise pickup problem has been eliminated. Enter the MAINTENANCE mode and press the **SELECT** key several times until frequency is displayed. Allow fluid to flow through the flowmeter and observe the frequency displayed on the ACE. If the noise problem is eliminated continue with Step 10. If the noise problem is still evident, remove power and return to Step 5.
10. Remove power.

11. Remove the electrical tape applied in Step 4. Attach the front panel back on to the ACE being carefully not to pinch the wiring harnesses.
12. Reapply power.
13. Enter and CONFIGURATION mode of the ACE and restore the DIS TIME OUT SE C setting.

9.4. TESTING

9.4.1. TEMPERATURE

1. Remove power from the ACE.
2. Connect appropriate temperature simulator to the ACE temperature input.
3. Power up the ACE.
4. Enter the CONFIGURATION mode and verify TEMPERATURE METHOD is set for TRANSMITTER.
5. While in the CONFIGURATION mode and set DIS TIME OUT SEC to “0.”
6. Return the unit to the OPERATING mode.
7. Press the **SELECT** key until the temperature is displayed.
8. Range the temperature simulator through all selections to verify proper operation of the ACE. All displayed readings should be within one degree or less.
9. If this test fails, contact HFC for further instructions.
10. After testing is completed, enter the CONFIGURATION mode and restore the DIS TIME OUT SEC setting.
11. Remove power and restore the unit to its original condition.

9.4.2. PRESSURE

1. Remove power from the ACE.
2. Connect the appropriate pressure simulator to the ACE pressure input.
3. Power up the ACE.
4. Verify that the CONFIGURATION mode PRESSURE METHOD is set for TRANSMITTER.
5. While in the CONFIGURATION mode and set DIS TIME OUT SEC to “0.”
6. Return the unit to the OPERATING mode.
7. Press the **SELECT** key until the pressure is displayed.
8. Range the pressure simulator through all selections to verify proper operation of the ACE. All displayed readings should be within five PSI or less.
9. If this test fails, contact HFC for further instructions.
10. After testing is completed, enter the CONFIGURATION mode and restore the DIS TIME OUT SEC setting.
11. Remove power and restore the unit to its original condition.

9.4.3. INPUT PULSE TESTING

1. Remove power from the ACE.
2. Connect the ACC-5A count simulator to the ACE signal input.
3. Power up the ACE.
4. Enter the COFIGURATION mode set DIS TIME OUT SEC to “999.”
5. Power up the ACC-5A pulse tester.
6. Take the appropriate steps listed earlier in this manual to put the ACE unit into the FREQUENCY field of the MAINTENANCE mode.
7. Set the ACC-5A for 100,000 counts.
8. Press the ACC-5A start key and observe the ACE frequency displayed.
9. Adjust the ACC-5A frequency adjust knob to obtain different frequencies.
10. The ACE should display a relatively constant reading for each selection. If this test fails, contact HFC for further instructions.
11. After testing is completed, enter the CONFIGURATION mode and restore the DIS TIME OUT SEC setting.
12. Remove power and restore the unit to its original condition.

9.5. WEIGHT SCALE CALIBRATION

The ACE unit is specifically designed to work with individual turbine flowmeter calibration reports. Turbine flowmeters, when properly used, have been found to be more accurate than most weight scales in determining the amount of product delivered. For best results, use a Hoffer portable Transfer Standard SY -14B to perform ACE system calibrations. Only use this procedure as a last resort. This procedure requires the use of two tankers. One full of fresh cold product and a empty tanker. Place the full tanker onto the scales. Hook up the piping so that the full tanker will be pumping off to the empty tanker. Use the following procedure:

1. Power up the ACE unit and enter the CALIBRATION mode.
2. Record the AVERAGE K -FACTOR. For LPG systems, record the AVERAGE M -FACTOR.
3. Enter the CONFIGURATION mode. Set the K -FACTOR METHOD to AVERAGE K -FACTOR. Set UNIT OF MEASURE to MASS. For LPG system set the M -FACTOR METHOD to AVERAGE M-FACTOR.
4. Return the ACE to the OPERATING mode.
5. Pressurize and cool down the piping and flowmeter.
6. Press the **CLEAR** key on the ACE twice to clear the total.
7. Weigh the tanker and record its INITIAL WEIGHT. After weighing the tanker start the pump.
8. To determine the TEST SAMPLE SIZE, divide the scale increment by the accuracy requirement. For example, if scale increment is 10 pounds and the accuracy requirement is 0.5%, then $10 \text{ pounds} / 0.005 = 2000 \text{ pounds}$. It is best to use a accuracy requirement equal to the linearity rating of the flowmeter.
9. Open the discharge valve and allow the tanker on the scales to pump off an amount of fluid equal to the TEST SAMPLE SIZE. After the TEST SAMPLE SIZE is pumped, close the discharge valve. Weigh the tanker again, this is the tanker FINAL WEIGHT. Calculate the SCALE TOTAL subtracting the FINAL WEIGHT from the INITIAL WEIGHT.
10. Record the DELIVERY_TOTAL displayed on the ACE.
11. For non LPG systems use the following equation to calculate the new AVERAGE K-FACTOR:

$$AVERAGE_K_FACTOR_{NEW} = \frac{DELIVERY_TOTAL}{SCALE_TOTAL} \times AVERAGE_K_FACTOR_{OLD}$$

12. For LPG systems use the equation below to calculate the new AVERAGE M-FACTOR:

$$AVERAGE_M_FACTOR_{NEW} = \frac{SCALE_TOTAL}{DELIVERY_TOTAL} \times AVERAGE_M_FACTOR_{OLD}$$

12. Enter the ACE CALIBRATION mode and enter the new AVERAGE K -FACTOR on non LPG systems. For LPG systems, enter the new AVERAGE M-FACTOR.
13. Repeat Steps 6 through 9 to verify the new calibration is within the accuracy requirements. If the new calibration is not within the accuracy requirements then repeat Steps 6 through 12.

9.6.

REPLACEMENT PARTS

- EXTERNAL FUSE, F2, 2A, AGC
- INTERNAL FUSE, PCB FUSE, 1A, AGC
- BATTERY, PCB MAIN, PANASONIC BR2330
- PCA 134-LLL-(*) (LIN,LOX,LAR)
- PCA 134-CO2-(*) (CO2)
- PCA 134-LH2-(*) (LH2)
- ACE-CA101 MAIN CABLE ASSEMBLY
- ACE-CA102 HEATER CABLE ASSEMBLY
- ACE-CA103 KEY CABLE ASSEMBLY
- PCA16-BIJ2 DISPLAY PC BOARD
- Specify voltage of +12 or +24 VDC when ordering.

THIS PAGE LEFT INTENTIONALLY BLANK.

10. OPERATIONS

10.1. DELIVERY PROCEDURE

10.1.1. POWERING UP

Apply power to the ACE. This allows the internal heaters to warm the display in order to prevent fogging in cold weather.

After power is applied, the following messages are displayed:

1. "SELF CHECK"
"SC-AXXXXXXX": This is the firmware configuration code. When ordering EPROM replacements or upgrades, please give this SC code to the HFC representative.
2. "ACE 6.rr.x(C)HFC" "- FLUIDS -----"

Where:

- rr = Current revision of firmware.
- x = Metrological Control number for type approvals, where;
 - 1 = OIML: Metric references are 15 °C and 101.325 kPa.
 - 2 = USA systems: Metric references are 21 °C and 101.325 kPa.
 - 3 = THAILAND: Metric references are 27 °C and 101.325 kPa.
 - 4 = PTB (Germany): Metric references are 15 °C and 1 BAR.
 - 5 = OIML/DUAL COIL: Metric references are 15 °C and 101.325 kPa.
 - 6 = SIRIM (Indonesia/Singapore) Metric references are 30 °C and 101.325 kPa.
 - 7 = AUSTRIA: Metric references are 15 °C and 1 BAR.

3. "OPERATING MODE"

The ACE system self -checks when power is first applied. A flashing message indicating the source of a malfunction is displayed if the system is not functioning properly. It is normal to see COMP RANGE OUT, GAS INHIBIT, and TWO PHASE WARNING error messages until the meter run is pressurized and cool down has been completed.

The ACE is fault tolerant. If there is a problem with a sensor, the system will detect the problem and substitute a suitable value until the problem is corrected. No action by the operator is required, however, messages indicating the source of the problem are displayed alternately with "DELIVERY" or other display units. The system may be used to complete deliveries, but the problem should be corrected as soon as possible.

Certain failures are of such a nature that the system cannot provide a measurement of the delivery until the problem is corrected.

10.1.2. COOLING DOWN THE METER

The metering code requires that the piping run to the flowmeter be cooled down prior to beginning a delivery. The piping arrangement on your trailer allows this operation to be performed simultaneously with the cooling down of the pump. The fluid may need to be

recirculated for a short time to complete the meter cool down. For Pump Interlock equipped systems refer to Section 3.6, "PUMP INTERLOCK (OPTIONAL)."

On compensated ACE systems, proper cool down has been achieved when the ACE unit stops flashing the COMP RANGE OUT message.

Once cool down is complete, the delivery may begin.

10.1.3. CLEARING THE TOTAL

The metering code requires that the delivery total be cleared to zero after the meter has been cooled down.

When power is first applied, the ACE will display the delivery total of the most recent delivery. To clear the old delivery total, depress the **CLEAR** key twice.

Pressing the **CLEAR** key twice, also clears the internal log of equipment malfunctions and operator errors that occurred during cool down. The only malfunctions which will be recorded on the maintenance report are those that occur between the time the **CLEAR** key is depressed twice and the **PRINT** key sequence is completed.

10.1.4. MAKING THE DELIVERY

To make a delivery, simply open the appropriate valves on the trailer and on the receiving vessel.

Observe the display to see how much product has been transferred at any time. The display is updated every few seconds with the current delivery amount. Use the **SELECT** key to look at other variables the system is measuring (See below). Each time the **SELECT** key is depressed, the display advances to the next item on the list. The display returns to the delivery total if the ACE is left idle for the value of the DISPLAY TIME OUT parameter set in the CONFIGURATION mode.

Variables:

- Delivered mass total
- Accumulative mass total
- Volumetric flow rate
- Mass flow rate
- Temperature
- Pressure
- Density (Non LPG systems)
- Vol Correction Factor (LPG systems)
- Specific Gravity (LPG systems)
- Time and Date
- Audit Trail Cal (Calibration)
- Audit Trail Con (Configuration)

10.1.5. DELIVERY COMPLETION

Close the appropriate valves to stop the delivery. The ACE does not allow printing and trip recording if flowrate is present. With the flow stopped, obtain a printed ticket or record the final delivery total.

11. SYSTEM CHECKOUT

11.1. SYSTEM CHECKOUT PROCEDURE

The ACE system accuracy may be verified by using flow and temperature simulators. The required test equipment is as follows:

FLUID TYPE	REQUIRED EQUIPMENT
LIN,LOX,LAR	<ul style="list-style-type: none">• ACC11 TEMPERATURE SIMULATOR• ACC5A COUNT TESTER• DIGITAL MULTIMETER
LH2	<ul style="list-style-type: none">• ACC36 TEMPERATURE SIMULATOR• ACC45V PRESSURE SIMULATOR• ACC5A COUNT TESTER• DIGITAL MULTIMETER
CO2	<ul style="list-style-type: none">• ACC15 TEMPERATURE SIMULATOR• ACC5A COUNT TESTER• DIGITAL MULTIMETER
LNG	<ul style="list-style-type: none">• ACC62 TEMPERATURE SIMULATOR• ACC5A COUNT TESTER• DIGITAL MULTIMETER

11.1.1. Testing ACE CO2 Systems

Prior to the beginning of testing, for CO2 systems, perform a printout of the setup information as testing will require changes to the setup information. Perform the following changes to the unit setup.

- Enter the MAINTENANCE mode
Print the setup parameters.
- Enter the CALIBRATION mode and change the following parameters:
Set AVERAGE K-FACTOR to 100.00
Set DEFAULT PRESSURE to 500 PSIA
- Enter the CONFIGURATION mode and change the following parameters:
Set SYSTEM OF MEASURE to U.S. CUSTOMARY or METRIC dependent on the testing requirements.

Set UNIT OF MEASURE to MASS.

Set K-FACTOR METHOD to AVERAGE K-FACTOR.

Set DENSITY METHOD to TEMPERATURE and PRESSURE.

- Return to the OPERATING mode.
- Connect the flow and temperature simulators to the ACE unit.
- The following chart indicates the expected delivery totals, when simulating 10000 pulses and the corresponding temperature. All results are given in pounds (LB) and kilograms (KG).

TEMPERATURE OF CO2	EXPECTED TOTAL SINGLE PIPE MODE		EXPECTED TOTAL DUAL PIPE MODE	
	LB	KG	LB	KG
°F				
-60	971.88	440.84	954.40	432.91
-50	954.61	433.00	931.20	422.39
-40	936.86	424.95	909.30	412.45
-30	918.57	416.66	886.10	401.93
-20	899.42	407.97	861.30	390.68
-10	879.26	398.83	834.80	378.66
0	857.82	389.10	806.00	365.60
10	834.70	378.61	774.60	351.35
20	809.29	367.09	740.00	335.66
30	780.54	354.05	694.90	315.20

11.1.2. Testing ACE LINLOXLAR, LNG, and LH2 systems

Prior to the beginning of testing perform a printout of the setup information as testing will require changes to the setup information. Perform the following changes to the unit setup.

- Enter the MAINTENANCE mode: a
Print the setup parameters.
- Enter the CALIBRATION mode and change the following parameters:
Set AVERAGE K-FACTOR to 100.00.
- Enter the CONFIGURATION mode and change the following parameters:
Set SYSTEM OF MEASURE to U.S. CUSTOMARY or METRIC dependent on the testing requirements.
Set UNIT OF MEASURE to MASS.
Set K-FACTOR METHOD to AVERAGE K-FACTOR.
Set DENSITY METHOD to TEMPERATURE.

- Return to the OPERATING mode.
- Connect the flow and temperature simulators to the ACE unit.
- The following charts indicate the expected delivery totals, when simulating 10000 pulses and the corresponding temperature. All results are given in pounds (LB) and kilograms (KG).

TEMPERATURE °K	EXPECTED TOTAL					
	LIN		LOX		LAR	
	LB	KG	LB	KG	LB	KG
80	664.67	301.49				
85	644.31	292.25			1174.26	532.64
90	622.64	282.42	953.04	432.29	1148.74	521.06
95	599.57	271.96	932.12	422.80	1122.01	508.94
100	574.75	260.70	910.29	412.90	1094.18	496.31
105	547.62	248.40	887.67	402.64	1065.14	483.14
110	517.59	234.77	864.10	391.95	1034.59	469.28
115			839.28	380.69	1002.18	454.58
120			812.81	368.68	967.50	438.85
125			784.22	355.72	930.15	421.91

TEMPERATURE OF LH2 °K	EXPECTED TOTAL	
	LB	KG
20	59.35	26.92
21	58.39	26.49
22	57.36	26.02
23	56.27	25.52
24	55.08	24.98
25	53.80	24.40
26	52.41	23.77
27	50.88	23.08
28	49.18	22.31
29	47.24	21.43
30	44.95	20.39





TEMPERATURE	EXPECTED TOTAL					
	LNG97		LNG95		LNG93	
	LB	KG	LB	KG	LB	KG
-260	365.25	165.67	375.51	170.33	383.04	173.74
-250	358.39	162.56	368.26	167.04	376.56	170.81
-240	350.87	159.15	361.30	163.88	369.28	167.50
-230	343.65	155.88	353.65	160.41	361.30	163.88
-220	335.88	152.35	346.32	157.09	353.65	160.41
-210	328.45	148.98	338.43	153.51	346.32	157.09
-200	319.81	145.06	330.07	149.72	337.58	153.12
-190	310.88	141.01	320.58	145.41	328.45	148.98
-180	299.73	135.96	310.88	141.01	319.05	144.72
-170	289.35	131.25	299.73	135.96	308.02	139.71
-160	-*-	-*-	-*-	-*-	-*-	-*-

-*- Gas Inhibit activated.

12. APPENDIX: DRAWINGS

THIS PAGE LEFT INTENTIONALLY BLANK.

DWG NO.	500-0162	SH	1	REV	C
REVISIONS					
ZONE	REV	DESCRIPTION	DATE	APP	
A		REDRAWN TO SHOW NEW DESIGN.	(DW) 4-27-92		
B		DEL. PROVER, ADD PRESS. & PUMP INTERLOCK	930319	JD	
C		DRAWING NO WAS ACE-117.	950817		



- MS3102-E-10SL-4P (SIGNAL)
- MS3102E-10SL-3S (PRESSURE)
- MS3102E-10SL-3P (POWER)
- MS3102E-14S-7P (PUMP INTERLOCK)
- MS3102E-14S-7S (TEMP LIN/LOX/LAR)
- MS3102E-14S-2S (TEMP LIF2 ONLY)
- MS3102E-14S-6S (RS232 PORT PRINTER)

REPLACES ACE-117

H HOFFER FLOW CONTROLS, INC
ELIZABETH CITY, NC 27909

INSTALLATION DRAWING -
ACE

REV	C
SIZE	C
CAGE CODE	33321
DWG NO	500-0162
SCALE	NONE
SHEET	1 OF 4

DATE	4-27-92
CHECK	JD
PRODUCTION	
PROJ ENG	KRH
MACH SHOP	

MATERIAL	
FINISH	

APPLICATION	
NEXT ASSY	USED ON

CONFIDENTIAL PROPERTY OF HOFFER FLOW CONTROLS, INC. THIS DRAWING IS TO BE USED ONLY FOR THE PURPOSES SPECIFIED. IT IS NOT TO BE REPRODUCED OR USED FOR ANY OTHER PURPOSE. EXCEPT AS AUTHORIZED IN WRITING BY HFC, MUST BE RETURNED ON REQUEST TO THE OFFICE OF ORIGIN OR OTHER PURPOSE FOR WHICH INTENT.

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. DIMENSIONS IN OTHER UNITS SHALL BE HELD AS FOLLOWS:
 2 PLACE DECIMALS ± .01
 3 PLACE DECIMALS ± .005
 FRACTIONAL ± 1/32"

1

REV C

SH 3

DWG NO. 500-0162

2

REV

DESCRIPTION

DATE

APP

3

4

3

2


1

4

3

2

1



REAR VIEW

FRONT VIEW

HOFFER FLOW CONTROLS INC
MODEL ACE

HOFFER FLOW CONTROLS, INC.
VIEWING AREA 3.876 x .938
MODEL ACE-LIN/LOX/LAR TEMP/COMP 75° TO 1256K

- MS3102-E-10SL-4P (SIGNAL)
- MS3102E-10SL-3S (PRESSURE)
- MS3102E-10SL-3P (POWER)
- MS3102E-14S-7P (PUMP INTERLOCK)
- MS3102E-14S-7S (TEMP LIN/LOX/LAR)
- MS3102E-14S-2S (TEMP LH2 ONLY)
- MS3102E-14S-6S (RS232 PORT PRINTER)

ACE INSTALLATION
FRONT AND REAR VIEWS

REPLACES ACE-117


DRAWN	DW	SIZE	C	CAGE CODE	33321	DWG NO	500-0162	REV	C
CHECKED	JD	SCALE	NONE					SHEET	3 OF 4

4

3

2

1



NOTE:
 ALLOW AN ADDITIONAL 4" MINIMUM
 BEHIND UNIT FOR MATING CONNECTORS
 AND CABLES.

ACE INSTALLATION
 SIDE VIEW


DWG NO.	500-0162	SH	4	REV	C
REVISIONS					
ZONE	REV	DESCRIPTION	DATE	APP	

REPLACES ACE-117

DRAWN	DW	SIZE	C	CAGE CODE	33321	DWG NO	500-0162	REV	C
CHECKED	JD	SCALE	NONE					SHEET	4 OF 4

DWG NO.	ACE-708	SH	1	REV	C
REVISIONS					
ZONE	REV	DESCRIPTION	DATE	APP	
A		REDRAWN	1-21-92		
B		DRAWING NO. WAS ACE-708. (DIM)	950818		JD
C		CORRECTED CABLE PART NUMBERS. DRAWING NO. WAS 700-0004	070919		V.K.

NOTE: CABLE PART NUMBERS SHOWN ARE STANDARD LENGTH.
PART NUMBER WILL VARY IF CUSTOM LENGTH IS SPECIFIED.




REPLACES 700-0004

H HOFFER FLOW CONTROLS, INC ELIZABETH CITY, NC 27909	
TITLE INTERCONNECTING WIRING, PRINTER / ACE	
SIZE C	CASE CODE 33321
SCALE NONE	DWG NO ACE-708
SHEET 1 OF 1	

MATERIAL	CONTRACT/IN	DATE
	DRAWN	1-21-92
	CHECK	JD
	QA	HC
	PROJ ENG	KRH
		1-21-92
		1-21-92
COMMERCIAL PROPERTY OF HOFFER FLOW CONTROLS, INC. NOT TO BE REPRODUCED OR USED FOR ANY OTHER PURPOSE EXCEPT AS AUTHORIZED IN WRITING BY HFC. MUST BE RETURNED OR DESTROYED AT THE REQUEST OF HOFFER FLOW CONTROLS, INC. FOR WHICH LEAD.		
UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN INCHES. THE SIZE OF RAW MATERIAL SHALL BE THE SIZE HELD AS FOLLOWS: 1/16" 0.0015" 1/32" 0.0020" 1/64" 0.0025" 3 PLACE DECIMALS FRACTIONAL ANGULAR 1/32"		
APPLICATION	USED ON	
NEXT ASSY		

REVISIONS		
ZONE	REV	DESCRIPTION
A		DRAWING NO WAS ACE-316.
		(CS) 950817
		DATE
		APP

NOTES:
 1. PIN 'A' MUST BE WIRED TO POSITIVE DC VOLTAGE. FAILURE TO OBSERVE POLARITY WILL CAUSE OVERRIDE OF PUMP INTERLOCK FEATURE.



REPLACES ACE-316

H HOFFER FLOW CONTROLS, INC
 ELIZABETH CITY, NC 27909

TITLE
 CASE WIRING,
 LIN/LOX/LAR/C02
 WITH PUMP INTERLOCK

SIZE	CAGE CODE	DWG NO	SHEET
C	33321	700-0006	1 OF 1

DATE	950131
CHECK	J.DFEFO
PRODUCTION	
PRO ENG	
MACH SHOP	


MATERIAL	
FINISH	

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. DIMENSIONS IN PARENTHESES ARE FOR INFORMATION ONLY. THE SIZE OF RAW MATERIAL SHALL BE HELD AS FOLLOWS:
 2 PLACE DECIMALS ± .015
 3 PLACE DECIMALS ± .005
 FRACTIONAL ANGULAR ± 1/32"

CONFIDENTIAL PROPERTY OF HOFFER FLOW CONTROLS. NOT TO BE REPRODUCED OR USED FOR ANY OTHER PURPOSE, EXCEPT AS AUTHORIZED IN WRITING BY HFC. MUST BE RETURNED ON REQUEST TO HOFFER FLOW CONTROLS OR OTHER PURPOSE FOR WHICH SENT.

APPLICATION	USED ON
NEXT ASSY	

DWG NO.	ACE-316	SH	1	REV	C
REVISIONS					
ZONE	REV	DESCRIPTION	DATE	APP	
	A	DRAWING NO WAS ACE-316.	(CS) 950817	JD	
	B	DRAWING NO WAS 700-0006, ADDED WIRE FROM TEMP. PIC C TO TBI-7	060224	V.K.	
	C	REVISED PER ECP 500-31	080606	V.K.	
	D	ADDED OPTIONAL BLUE TOOTH CONNECTOR PER ECP 566	100331	JJ	



NOTES:

1. RELAY COIL VOLTAGE SHOULD BE THE SAME AS VDC IN, SPECIFY +12V OR +24V.
2. ACE-B: REMOVE JP15 FOR 3-WIRE RTD "PROBE OPEN" IS DISPLAYED IF 2-WIRE CABLE IS CONNECTED.
3. PIN 'A' MUST BE WIRED TO POSITIVE DC VOLTAGE. FAILURE TO OBSERVE POLARITY WILL CAUSE OVERRIDE OF PUMP INTERLOCK FEATURE.

DATE	950131
CHECK	J.DEFEO
PRODUCTION	
PROJ ENG	
MACH SHOP	


DRAWN	SWEET	MATERIAL
CHECK	J.DEFEO	
PRODUCTION		
PROJ ENG		
MACH SHOP		
FINISH		
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. TOLERANCES OTHER THAN THE SIZE OF RAW MATERIAL SHALL BE AS FOLLOWS:		
3 PLACE DECIMALS ± .01		
2 PLACE DECIMALS ± .005		
1 PLACE DECIMALS ± .005		
FRACTIONAL ± 1/25		
ANGULAR ± 1/2°		
CONFIDENTIAL PROPERTY OF HOFFER FLOW CONTROLS, INC. (HFC) NOT TO BE DISCLOSED TO OTHERS, REPRODUCED, OR USED FOR ANY OTHER PURPOSE, EXCEPT AS AUTHORIZED IN WRITING BY HFC. MUST BE RETURNED OR DESTROYED FOR WHICH LEFT.		
APPLICATION		
NEXT ASSY		USED ON

DATE	950131
CHECK	J.DEFEO
PRODUCTION	
PROJ ENG	
MACH SHOP	

H HOFFER FLOW CONTROLS, INC ELIZABETH CITY, NC 27909	
TITLE	
ACE-B CASE WIRING 7.5 VOLT POWER	
SCALE	NONE
CASE CODE	33321
DWG NO	ACE-316
REV	D
SHEET	1 OF 1

DATE	950131
CHECK	J.DEFEO
PRODUCTION	
PROJ ENG	
MACH SHOP	

NOTES:
 1. RELAY COIL VOLTAGE SHOULD BE THE SAME AS VDC IN. SPECIFY +12 OR +24V.




ZONE	REV	DESCRIPTION	DATE	APP
A		SIGNAL INPUT CONNECTOR WAS MS3102E-10SL-4S.	950501	.D
B		DRAWING NO WAS ACE-314.	950817	.D
C		DRAWING NO WAS 700-0009	000221	
D		PER ECP 500-3T, REMOVED ALL MS CONNECTORS	101109	V.K.
E		REVISED PER ECP 601, REMOVED F2, ADDED TB2	130321	.D


CONTRACT/AN		DATE	
DRAWN	SWEET	940803	
CHECK	J.DEFEO	940803	
QA			
PROJ ENG			
MATERIAL		FINISH	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. TOLERANCES OTHER THAN THE SIZE OF RAW MATERIAL SHALL BE HELD AS FOLLOWS: 1 PLACE DECIMALS ± .01 2 PLACE DECIMALS ± .005 3 PLACE DECIMALS ± .001 FRACTIONAL ± 1/32" ANGULAR			
CONFIDENTIAL PROPERTY OF HOFFER FLOW CONTROLS, INC. (HFC) NOT TO BE DISCLOSED TO OTHERS, REPRODUCED, OR USED FOR ANY OTHER PURPOSE, EXCEPT AS AUTHORIZED IN WRITING BY HFC. MUST BE RETURNED OR DESTROYED FOR WHICH INTENT.			
NEXT ASSY		USED ON	
APPLICATION		3	
H OFFER FLOW CONTROLS, INC		ELIZABETH CITY, NC 27909	
CASE WIRING, ACE-B		EXPLOSION PROOF	
SIZE	CASE CODE	DWG NO	REV
C	33321	ACE-314	E
SCALE	NONE		SHEET 1 OF 1

DWG NO.	ACE-721	SH	1	REV	B
REVISIONS					
ZONE	REV	DESCRIPTION	DATE	APP	
	A	ZND4 REMOVED MODE. SELECT. CLEAR, PRINT & CONTROL. DRAWING NO. WAS ACE-721.	950628	JD	
	B	PER ECP 500-31, DRAWING NO. WAS 800-0039	101006	V.K.	



PARTS LIST		
QUANTITY	DESCRIPTION	PART NO.
1	CABLE ASSEMBLY	ACE-CA103
5	PUSH BUTTON SWITCH	ITW 59-211



PARTS LIST +12VDC			
QUANTITY	DESCRIPTION	MANUFACTURER	PART NO.
1	CABLE ASSEMBLY	MOLEX	ACE-CA102
2	POWER RESISTOR	DALE	25 OHM 10W
1	THERMOSTAT	TI	6786-2-2



PARTS LIST +24VDC			
QUANTITY	DESCRIPTION	MANUFACTURER	PART NO.
1	CABLE ASSEMBLY	MOLEX	ACE-CA102
2	POWER RESISTOR	DALE	100 OHM 10W
1	THERMOSTAT	TI	6786-2-2



DATE	5-21-92
DRAWN	DW
CHECK	J.DEFEO
PRODUCTION	
PROJ ENG	KRH
MACH SHOP	

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. TOLERANCES OTHER THAN THE SIZE OF RAW MATERIALS SHALL BE HELD AS FOLLOWS:

1 PLACE DECIMALS ± .01

2 PLACE DECIMALS ± .005

3 PLACE DECIMALS ± .001

FRACTIONAL ± 1/32"

CONFIDENTIAL PROPERTY OF HOFFER FLOW CONTROLS, INC. (HFC) NOT TO BE DISCLOSED TO OTHERS, REPRODUCED OR USED FOR ANY OTHER PURPOSE, EXCEPT AS AUTHORIZED IN WRITING BY HFC. MUST BE RETURNED ON OTHER PURPOSE FOR WHICH LENT.

SCALE	NONE
SHEET	1 OF 1

REPLACES 800-0039

HOFFER FLOW CONTROLS, INC
ELIZABETH CITY, NC 27909

MISCELLANEOUS
ACE WIRING AND
PARTS LISTS

SIZE	C	CAGE CODE	33321	DWG NO	ACE-721	REV	B
------	---	-----------	-------	--------	---------	-----	---

APPLICATION

USED ON

NEXT ASSY

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4

1

2

3

4


1

REVISIONS

REV	DESCRIPTION	DATE	APP
F	FOR REV A-E REF REV. E ADDED 2nd CABLE TO SHOW WITHOUT CONNECTOR	100309	JJ

- NOTES:
- SPECIFY CABLE LENGTH WHEN ORDERING.
 - CABLE PART NO.
SCA-XC(DB)5-RS
 - USE CABLE TYPE ALPHA 5599/5, 5310 OR EQUAL.
 - PIN 20 ON DB25P W/HOOD WIRED FOR PRINTER BUSY.


CN-
MS3106F-14S-6P



CN-
DB25P W/HOOD



CN-
DB25P W/HOOD



(REPLACES 100-2067)

DRAWN		RLG	DATE
MATERIAL		CHECK	
FINISH		PRODUCTION	
UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES; TOLERANCES OTHER THAN HELD AS FOLLOWS:		PROJ ENG	
CONFIDENTIAL PROPERTY OF HOFFER FLOW CONTROLS, INC. (HFC) NOT TO BE DISCLOSED TO OTHERS, REPRODUCED, OR USED FOR ANY OTHER PURPOSE, EXCEPT AS AUTHORIZED IN WRITING BY HFC. MUST BE RETURNED ON DEMAND, ON COMPLETION OF ORDER OR OTHER PURPOSE FOR WHICH LENT.			
NEXT ASSY		± .01	REV
USED ON		± .005	F
APPLICATION		± 1/64	
		ANGULAR	
		± 1/2"	
SIZE	CAGE CODE	DWG NO	REV
A	33321	SCA-914	F
SCALE	NONE	SHEET	1 OF 1



HOFFER FLOW CONTROLS, INC.
ELIZABETH CITY, NC 27909

TITLE
GENERAL PURPOSE
RS-232 CABLE--
ACE