

K Intelligent **box**



S32

S32

2 AXIS POSITION CONTROLLER

KARAÇİM ELEKTRONİK


BESEVLER KUCUK SANAYI SITESI ERTUGRUL CAD.

SATIS BLOKLARI NO:18/3 - BURSA

TEL : +90 (224) 441 12 97

FAX : +90 (224) 441 98 05

e-MAIL : info@karacimelektronik.com



PRINCIPLES OF OPERATION

The S32 controller is used to position machinery to any desired absolute position with 2 speed reversing drives on the basis of fast / slow / stop.

The controller outputs can be selected to operate :

1. Forward and reverse contactors.
2. Run and reverse, fast and slow for inverter systems.
3. Run and reverse, fast and slow for two speed motors.

Position is monitored by means of an incremental encoder (NPN). The actual position of the axis is displayed at all times. The controller calculates the difference between the actual and demanded position and sets the outputs to give the direction and speed to move the demanded position.

If the distance is greater than the value set in parameter "slow speed distance" the drive will first set off at high speed, as it reaches the distance from the demanded position equal to this parameter, the drive will drop to its low speed. It will now run at the slow speed until it reaches a distance from the demanded position equal to stop offset of the machinery then the drive stops.

The offset value which is due to inertia of the machinery learned by controller automatically. If positioning does not occur within the limits set in parameter "tolerance", the controller will try to carry it out again and again till the maximum set in "number of trials".

After the last attempt, positioning has not been carried out correctly, "position Ok" contacts will not close indicating something wrong, press stop and check the system.


Providing a speed low enough is used, the overrun will be consistent at all positions, then the stopping accuracy of +/- 0.1 mm can be achieved.

Retract value for the backstop set in the parameters would be used for example on a sheet metal bender, where backstop has to retract (move to a higher count value) whilst the bend is taking place.

MANUAL SETTING-UP

To setup the machine and getting correct direction of rotation and correct encoder signals, proceed as follows:

1. Select manual mode
2. Press one of the keys 1, 2, 6, 7 to check the correct direction and fast / slow speed.
 - If incorrect, change the cabling accordingly.
3. Press forward key (1 or 6), the actual display should count up (in positive quadrant).
 - If incorrect direction of count is present, interchange A / B cables of encoder.





DISPLAY and KEYS

	Y AXIS DISPLAY : Actual value is displayed for manual and single modes. In auto mode, it shows the value programmed before.
	X AXIS DISPLAY : Actual value is displayed for manual and single modes. In auto mode, it shows the value programmed before.
	COUNTER DISPLAY : It shows number of operations done (counts the count input) Press C to clear the count value.
	PROGRAM NO DISPLAY : Selected program no (1..99)
	STEP NO DISPLAY : Selected step no (1..33)
	SELECTED MODE : Leds indicate what mode is selected. (M)anual: Manual positioning, (S)ingle: Single positioning, (A)uto: Programmed mode
	OK LED : Operation is allowed only if OK led lighted. e.g. Ok led is lighted off during positioning and operation is not allowed.

	START : Run / Enter
	STOP : Stop / Exit
	Mode select
	Prpgram entry
	Display clear / Counter clear
	Program or Step delete
	RETRACT function select

	CALIBRATION (Only in Manual mode)
	CONFIGURATION (Only in Manual mode)
	Slow Motion for selected axis (Only in Manual)
	Fast Motion for selected axis (Only in Manual)
	Numerical keypad





MANUAL MODE (Y-axis and X-axis)

M key is pressed to light the led of desired axis and M led.

1 2 Press 1 or 2 for SLOW forward or reverse positioning

6 7 Press 6 or 7 for FAST forward or reverse positioning

SINGLE MODE

M key is pressed to light the S led for single positioning.

Press START

Y-axis display blinks (ready for value entry), Press numerical keys for the desired Y position.

Press START to enter the written value.

X-axis display blinks (ready for value entry), Press numerical keys for the desired X position

Press START


Counter display blinks (ready for value entry), Press numerical keys for the desired count.


Press START to enter the values,

Positioning is carried out, when the position is found correctly OK contacts close (its led is on). In this position, operations are counted, when the count is reached OK contacts open.

COUNT CLEAR

C Press C to clear the counter. (Only in Manual and Single mode)

 **M** Press M to light the Auto led.


↓
 **0..9** Prog No display blinks (ready for entry)
 Press numerical keys for the desired program no.


↓
 Press START to enter.


Positioning is carried out for step 01 position values. If the position is found correctly, OK contacts close. Operations are counted, when the count is reached OK contacts open, then positioning is carried out for step 02 and it continues as before. When the recorded steps are finished (max. 33 steps) it returns to step 01 and wait for start.



AUTO MODE (REPEAT)

 **M** Press M to blink the Auto led.


↓
 **0..9** Prog No display blinks (ready for entry)
 Press numerical keys for the desired program no.


↓
 Press START to enter.

Positioning is carried out for each step as in the auto mode. When the recorded steps are finished, it returns step 01 and repeats the program again. This continuous operation (repeating the program) is exited by pressing STOP.



PROGRAM VISUALIZATION

 **M** Press M to light the auto led.


↓
 **0..9** Prog No display blinks.
 Press numerical keys for the desired program no.

↓
 **P** Press P.

↑
 Step 01 position and count values are displayed. With each press P, steps are visualized one after the other. Press STOP to exit.

RETRACT FUNCTION



Backstop has to retract (set retract value in parameters) whilst the bend is taking place to bring to safe position.


 Press RETR key to light its led.
 Press RETR key to cancel to retract function.


NOT : Retract Function

When retract input is closed, after retract delay (Pr.21), backstop is retracted for retract distance (Pr.22). By count input closing, positioning to original position takes place.


Pr.21 : Retract delay
 Pr.22 : Retract distance








PROGRAM ERASE





During the programming ;

1. If a new program is written over an old program, to erase the displayed step and the remaining steps, press DEL and then press START.
2. Erasing ALL programs : Press and keep pressing DEL, and energy is applied, release DEL. After 15 sec, all programs are erased.



DOUBLE POINT CALIBRATION






PARAMETER TABLE

	Pr.No		Fact.default
	Y	X	
SLOW SPEED DISTANCE (mm)	01	11	0.50 / 30.0
PITCH (mm/tour)	02	12	0.16 / 10.00
ENCODER (pulse / tour)	03	13	100 / 100
DECIMAL POINT = 0.5	04	14	2 / 1
TOLERANCE (mm)	05	15	0.02 / 0.2
(Reserved)	06	16	1 / 1
TOL.WINDOW BLANKING (No=0, Yes=1)	07	17	1 / 1
MINIMUM SET (mm)	08	18	1.00 / 10.0
MAXIMUM SET (mm)	09	19	100.00 / 750.0
NUMBER of TRIALS	10	20	10 / 10


	Pr.No	Fact.default
RETRACT DELAY (0.01 sn)	21	0.20
RETRACT DISTANCE (mm)	22	5.0
(Reserved)	23	0
PASSW (4 digit) S.Pass = 1974	24	1971

EX-FACTORY PARAMETERS LOAD



FUNCTION	DATA
Supply voltage	24VAC (+/-10%)
Position sensor	Encoder (A,B ch.), 12VDC / PNP, 10 kHz
Inputs	6 Digital inputs, 12 VDC/PNP
Outputs	7 Relay outputs, 3A, NO
Ambient temperature	0..50°C
Front Dimensions	W x H = 192 mm x 96 mm
Depth (excl. terminals)	D = 86 mm
Panel cut-out	W x H = 186 mm x 92 mm

KLEMENS BAĞLANTILARI



No	DESCRIPTION
1	PE Protective Earth
2	L Supply Line
3	N Supply Neutral

4	COM (+) Common
5	ENABLE [1] Enable (NO)
6	START External Start (NO)
7	STOP [2] External Stop (NC)
8	COUNT Count Input (NO)
9	RETRACT Retract Input (NO)
10	RESET Reserved
11	OK Ready Output (NO)
12	







NOT

[1] ENABLE must be shorted to common to enable the positioning.

[2] STOP must be shorted to common to enable the positioning. (NK)

No	DESCRIPTION
20	PE Protective Earth
21	(+) Encoder Supply 12VDC
22	A Encoder X - Ch. A
23	B Encoder X - Ch. B
24	(-) Encoder Supply GND
25	FORW X Forward
26	BACK X Backward
27	COM Common
28	S/F Open = Slow Close = Fast
29	

30	PE Protective Earth
31	(+) Encoder Supply 12VDC
32	A Encoder Y - Ch. A
33	B Encoder Y - Ch. B
34	(-) Encoder Supply GND
35	FORW Y Forward
36	BACK Y Backward
37	COM Common
38	S/F Open = Slow Close = Fast
39	

ERROR MESSAGE	DESCRIPTION	TO DO
	Hardware Error (Y Axis)	<i>Apply to manufacturer</i>
	Hardware Error (X Axis)	<i>Apply to manufacturer</i>
	Out of limits (parameters 8, 9, 18, 19)	<i>Check the given set values</i>
	No change on the display during calibration	<i>Check encoder connections and mechanism</i>
	Incorrect direction of count during calibration	<i>Check encoder connections and change ch.A / B</i>
	Position is not found	<i>Check and again try</i>

INSTALLING



Attention ! :

To ensure a perfect function of the S32 the following insatllation guide-lines must be strictly observed and followed. Otherwise the guarantee expires and Karaçim takes no liability and guarantee for malfunctions or damages e.g. by incorrect installed wires or other external sources of error or interference, which are exactly explained below.

To guarantee a perfect operation of the S32, the following (external) measures have to be taken additionally :

PLACE OF INSTALLATION

Don't install the controller near to sources of interference generating strong inductive or capacitive interferences or strong electrostatic fields.
Install the external power supply directly beside the controller to avoid long low voltage wires.

POWER SUPPLY

Use a galvanic separation over an additional transformer.

WIRE INSTALLATION

Install all wires for low voltage and encoders always separately from power wires.
Avoid to install these wires close to any contactor or contactor wires.

SHIELDING

All external signal wires have to be installed shielded :

1. Rotary encoder wires
2. Wires for all other input signals
3. Wires for all output signals
4. Wires from the power supply to the S32

All shields have to be connected centrally low ohm to PE (Earth potential), connect only one-sided at the S32.

IMPORTANT !

1. Don't connect the S32 GND tp PE
2. Don't connect the shielding on both sides to PE
3. If the protective ground potential is heavily "contaminated" by interference voltages, try to connect the shielding to the GND potential instead of PE.

FAULT CLEARANCE

If there occurs interferences in spite of applying all above mentioned measures proceed as follows:

1. Add RC elements over contactor coils of AC contactors (for example 0,1 uF/100ohm)
2. Add recovery diodes over DC inductances
3. Add RC elements over each engine phase (in connector box of the engine)
4. Install a power filter before the external power supply