



**M2M i-LINK
POINT-TO-MULTIPOINT
INSTALLATION INSTRUCTIONS**

1 TABLE OF CONTENTS

1	TABLE OF CONTENTS.....	2
2	GENERAL.....	3
3	INSTALLATION	4
3.1	SUB-STATIONS.....	4
3.2	MAIN STATION (PC).....	4
4	CONNECTING THE INPUTS AND OUTPUTS	5
4.1	INPUTS OF THE SUB-STATION	5
4.2	PULSE INPUT	5
4.3	DIGITAL OUTPUTS.....	5
5	PROGRAM.....	6
6	SETTINGS	7
7	USING THE PROGRAM.....	8
7.1	START	8
7.2	OPERATION WINDOW	8
7.3	COM- PORT	8
7.4	SUB-STATION ADDRESS	8
7.5	GENERAL	9
7.6	SENDING DIGITAL DATA	9
7.7	RECEIVING DIGITAL DATA	9
7.7.1	Manual (default)	9
7.7.2	Auto	10
7.7.3	Time	10
7.8	PULSES (COUNTER INPUT 1, TICK) UPDATING. TICKS PER UNIT. UNIT.....	10
7.8.1	Additive count is chosen	10
7.8.2	Additive count is NOT chosen	10
7.8.3	Pulse divider, Ticks per Unit:	11
7.8.4	Pulse unit, (Tick).....	11
7.9	EDIT FUNCTIONS	11
7.9.1	Set layout style	11
7.9.2	Set name.....	11
7.9.3	Input/Output names.....	11
7.9.4	Save sub-station.....	11
7.9.5	Save all sub-stations.....	11
7.9.6	Load sub-station	11
7.9.7	Close sub-station	12
7.9.8	Exit	12
8	CHANNEL CHANGE.....	13
8.1.1	Selecting a new channel	13
9	INDICATORS.....	15
9.1	FUNCTIONS AND OUTCOMES	15
9.2	BOTTOM BAR	15
10	FACTORY SETTINGS.....	16
11	CONNECTION EXAMPLES	17

2 GENERAL



Dear Customer,

This installation manual provides you in brief with all the essential information you need to get your cordless SATEL M2M i-LINK Multipoint package in working condition. The wireless SATELLINE radio modem enables the devices' mutual communication. SATELLINE radio modems operate on license-free radio frequencies and can therefore be taken into use immediately without separate permission from the authorities. All of the settings etc. needed for a connection have already been adjusted so all you have to do is the final hook-up.

The M2M Multipoint Package

This package enables you to wirelessly control and monitor the operations of two sub stations with one main station. The equipment makes it possible to send and receive 2 status signals (switch or other digital status), collect pulse information. All changes in the sub-station digital or pulse are transmitted to the main station display as visible output. Correspondingly, separate controlling is possible directly from the main station to the sub-stations.

Contents of the M2M Package:	Number in the picture:
3 pcs of radio modems with antennas	(1 and 2)
2 pcs of i-LINK I/O-converters	(3)
3 pcs of power supplies	(4)
3 pcs of antenna installation plates	(5)
3 pcs of antenna cables	(6)
1 pc of MINI-LINK PC Multipoint program	
1 pc of installation instructions	



3 INSTALLATION

The installation part consists of the installation and how to make the wiring (CONNECTING THE INPUTS AND OUTPUTS). The use of the program is explained in the paragraph USING THE PROGRAM.

Choose the places for installations where the products may be easily mounted. If at all possible, choose a place where there is nothing to obstruct (walls, etc.) the transmission of radio signals 'between' the devices' antennas.

3.1 SUB-STATIONS

1. Connect the antenna cable (6) to Installation plate (5).
2. Connect the antenna (1) to the installation plate.
3. Connect the antenna cable to the radio modem (2).
4. Connect the power supply (4) to the i-LINK screw couplings 9-30VDC. Connect the power supply's black wire to the negative pole (-) and the red wire to the positive pole (+).
5. Connect the i-LINK to the radio modem so that it is locked.

Make these connections to the other equipment(s) as well.

Note! The antennas can also be connected directly to the radio modems without the cable and installation plate, if needed.

The sub-stations are now installed.

3.2 MAIN STATION (PC)

1. Connect the antenna cable (6) to the installation plate (5).
2. Connect the antenna (1) to the installation plate.
3. Connect the antenna cable to the Radio Modem (2).
4. Connect the interface cable (7) to the radio modem (so that it is locked) and the PC's COM port.
5. Connect the power supply (4) to the wall socket.

The main station is now installed.

Note! The antennas can also be connected directly to the radio modems without the cable and installation plate, if needed.

4 CONNECTING THE INPUTS AND OUTPUTS

Once you have installed the M2M package, all you need to do is just connect the actual inputs and outputs.

4.1 INPUTS OF THE SUB-STATION

Connect switch status or other data to D1 or D2 input of the sub-station, so that you get a status change in the input, i.e. +12 V / 24 V 'ON or OFF'. You can take the + (plus) Voltage from the + -screw of the i-LINK, or from the separate + -output next to it.


4.2 PULSE INPUT

Input pulses are connected to the P (Pulse Input) screw. The maximum frequency is 10 kHz. Reading occurs at the pulse edge. The function can be used by the MINI-LINK PC program.

4.3 DIGITAL OUTPUTS

Changes in the sub-station outputs are done by using commands on the main station display. When the main station input is pressed, the respective sub-station output relay contacts changes accordingly. The relay contacts are normally open. Each contact can be connected independently, and can perform the desired function by using them to connect plus or minus Voltage to the desired device. The contacts can also be used to control a 12-24 Volt device at maximum of 1 Amperes.


When all inputs and outputs are connected, mount the power supply to the mains voltage. For more information concerning the functions of the i-LINK, see the user manual in the M2M package.



5 PROGRAM

SATEL MINI-LINK PC is a Point-to-Multipoint program, that can be used to drive several SATEL i-LINK sub-stations connected to SATELLINE radio modems. The maximum number of sub-stations is 15 pcs. The program makes it possible to operate systems which are connected to the I/O -ports, to change values, monitor the radio link and Multipoint operation etc.

Minimum requirements:
PC 286, SATELLINE radio modem,
SATEL i-LINK,
MINI-LINK PC program,
COM Port baud rate min. 9600 b/sec
Windows 95, 98, 2000, XP



6 SETTINGS

NOTE!


If you are using SATEL M2M i-LINK package, all settings in this page are already done and you may continue from the next page.

SETTINGS OF THE SATELLINE RADIO MODEM AND i-LINK:



- The radio modem PORT settings are: 9600 kbps, "N-8-1".
- M/P-switch is in M-position.
- Before connecting the device to a power supply, connect first all inputs and outputs that are to be used.
- Set addresses to both units, for example (1)100 0000 and (1)010 0000. The first (1) is the Multipoint switch that must be in set to "1"-position.
- When both units have these basic settings the supply voltage can be connected.

7 USING THE PROGRAM

7.1 START

Instal the attached CD to your PC and open the SATEL MINI-LINK PC program by double clicking the  Satel_Mini-Link_PC_v.... -icon.


7.2 OPERATION WINDOW

Open a new operation window from the toolbar list by clicking the  -button on the upper left corner, or Open by clicking on the File Menu, opening "New Slave". Open your own window to all sub-stations. Note that the maximum number of sub-stations in this program is 16. Arrange the display by using the Windows Menu or the  -buttons.

7.3 COM- PORT


Open the COM- port from the toolbar list by clicking "Master Config" and select "Open ComPort". Set the same parameters as you have set for the SATELLINE radio modem and SATEL i-LINK, then press OK.

If there are no COM -port settings, the program will automatically ask for them.



7.4 SUB-STATION ADDRESS

When the new sub-station is opened, the program will automatically set the address for it. To make manual adjustments, click anywhere on the empty table using the right mouse button, and select "Set slave address". Insert the new address, and then press OK.



THE BASIC SETTINGS HAVE NOW BEEN ESTABLISHED AND THE SATEL MINI-LINK PC IS READY TO SEND AND RECEIVE INFORMATION.

7.5 GENERAL

Changes in the sub-station **outputs** are done by using commands on the main station display. Changes in the sub-station **inputs** are shown respectively on the main station display.


When the sub-station Inputs D1...D2 level changes from 0 to +12 ... +24 Vdc or vice versa, the indicator in the main station display changes respectively. Grey represents OFF- and green ON-state.

When the main station' digital output is pressed, the respective sub-station output relay contacts changes accordingly. The relay contacts are normally open. Each contact can be connected independently, and can perform the desired function by using them to connect plus or minus Voltage to the desired device. The contacts can also be used to control +12 ... +24 Vdc devices at maximum of 1 Amperes.

The Pulse information (for example electric meter) is seen in the window in the "Counter Input" (Tick) box.

7.6 SENDING DIGITAL DATA

To change the sub-station's digital value, click the grey "Digital Output" circle dot. During the transmission the dot is yellow. When the transmission is done (in about 1 sec), the circle will change to green. If the transmission fails, the "Operation" signal will turn red.




7.7 RECEIVING DIGITAL DATA

The **digital inputs** and **pulse** information from the sub-stations will be updated to the main station window when the main station updates occurs. There are three different modes to update the data; **manual**, **auto** or **time**. The settings can be done separately for each window (sub-station).



7.7.1 Manual (default)

For manual update – click anywhere on the empty table using the right mouse button - select "Set update mode", and press "Manual". Using this setting, the sub-station information for the chosen window is updated only when "Manual Update" circle-dot in this window is pressed.



7.7.2 Auto

For automatic update – click anywhere on the empty table using the right mouse button - select “Set update mode”, and press “Auto”.

Using this setting, the sub-station information for the chosen window is updated with maximum speed. If only one sub-station has an auto setting, the update speed is about 1 second. Every new auto setting increases the update time.

NOTE!

Use this setting for the sub-stations only, if it is absolutely necessary. The Auto setting makes maximal use of the radio frequency. The continuous reservation of radio frequency is not generally recommended.

7.7.3 Time


Using this setting, the update information from the sub-station to the chosen window will be in accordance with the “Select time” setting.

For a Time based update – click anywhere on the empty table using the right mouse button - select “Set update mode”, and press “Time”, select the time and press SET. The time interval can be from 5 seconds up to ...24 hours.



7.8 PULSES (COUNTER INPUT 1, TICK) UPDATING. TICKS PER UNIT. UNIT.

The latest pulse information will be shown in the window when the sub-station is updated (manual, auto or time). Pulse reading type can be "additive" or "once".



7.8.1 Additive count is chosen

When ☒ Additive count is chosen, the new counter value is added to the previous value at every update. (Example: Current value is 20. Sub-station is updated when 3 new pulses has been received. New counter value will be $20+3=23$).

7.8.2 Additive count is NOT chosen

When ☐ Additive count is not chosen, the new counter value replaces the previous value. (Example: Current value is 20. Sub-station is updated whe 3 new pulses has been received. New counter value will be 3).

NOTE! If the pulse reading occurs for example once a month, the update type shouds be Manual. When Manual update is pressed a new reading is shown and the previous one is reset.

7.8.3 Pulse divider, Ticks per Unit:

When **Ticks per Unit** is greater than 1, the incoming pulses are multiplied with this number. When **Ticks per Unit** is less than 1 (for example 0,1), the incoming pulses are divided with this number.


7.8.4 Pulse unit, (Tick).

The default Unit "Tick" is replaced by typing new text.

7.9 EDIT FUNCTIONS

7.9.1 Set layout style

The inputs and outputs can be seen in the window simultaneously or separately, depending on the settings. Click anywhere on the empty grey area of the sub-station window using the right mouse button, select "Set layout style" and set it for "Normal", "Input only" or "Output only".




7.9.2 Set name

Select "Set Name" – type a new name and press OK.

7.9.3 Input/Output names

Click normally at the name that you want to change and it opens for editing. Make the changes and press OK.




7.9.4 Save sub-station

Saves the current Sub-station to the PC. Click anywhere on the empty grey area of the sub-station window using the right mouse button, select "Save Settings", browse for the file path and press OK.


7.9.5 Save all sub-stations

Select FILE - "Save All", select path and save. This function will save all sub-stations using their current names.




7.9.6 Load sub-station

Select FILE - "Load Slave(s)" and open the file. Because the information of the now loaded sub-station may be different from what it currently is, the program asks "Do you want to update slave(s)? Select Yes / No".



7.9.7 Close sub-station

This will close only the individual sub-station, not the whole program.
Click anywhere on the empty grey area of the sub-station window using the right mouse button, select Close. In the event that the sub-station has not been saved, the program asks "Are you sure you want to close slave? Select Yes / No." However, it is recommended to either save the individual sub-station or the whole workspace (File- Save Workspace...)



7.9.8 Exit

Select FILE – EXIT. If any of the sub-stations are still open, the program asks "Are you sure?"
Select Yes /No.

8 CHANNEL CHANGE

This feature makes it possible to change the working channel to another one in case there is doubt that the current channel is not free from disturbance.

8.1.1 Selecting a new channel

Open the Window menu. Select "Show Channel Selector".

1. When the program is opened first time, it shows "Your current channel is not known and therefore all the scan controls are unavailable. Do you want to check it now? (Recommended)".





2. Press Yes (recommended). Now the program checks the operation channel. As a result of the scan the current channel will be shown at the bottom bar of the window.

3. The next information tag is "Scan all channels? (Recommended)". Press Yes.


As a result of the scan there will be a list of the channels with dBm-signal strength information. This dBm tells the possible interference i.e. "quality" of the channels. The best value is -120 dBm (the bigger the better).

4. The program shows "All channels scanned. Automatically select best channel? (Recommended)". Press Yes.



5. If the current channel is good to be used and free from interferences the colour of the channel button is green and the channel will not be changed.



6. If there is some interference and the current channel is **not** good to be used the colour of the channel button is yellow (medium interference) or red (strong interference). Press “Yes”, and the program will automatically set the system to operate on the new channel.



7. Manual change to the channel that has the best signal, greatest RSSI-value, is done by selecting “Change to Selected Channel”. Press “Yes”, and the program will automatically set the all sub-stations to operate on the new channel.



9 INDICATORS

9.1 FUNCTIONS AND OUTCOMES

i-LINK	Function	Outcome	Outcome	Outcome
Operation	Status of the operation	Green = OK	Yellow= In operation	Red= Fail
Digital output	State of the outputs	Green = OK	Yellow= In operation	Grey= OFF
Digital input	State of the inputs	Green = OK	Yellow= In operation	Grey= OFF

9.2 BOTTOM BAR

Text	Function
Manual or Auto	Shows the analog input update selection
"00:00:00"	Shows the input update time
Address:	Shows the address of the sub-station

10 FACTORY SETTINGS

The i-LINK I/O-converter is shipped with the following default settings (unless specifically ordered with settings other than those listed below):

M2M Point-to-Point

FIXED SETTINGS DEFINED AT THE TIME OF ORDER	
PRTCL, protocol -switch	P = Point-to-point
ADDRESS	0000000

M2M Point-to-Multipoint

FIXED SETTINGS DEFINED AT THE TIME OF ORDER	
PRTCL, protocol -switch	P-to-MP = Point-to-Multipoint
ADDRESS	1000000 and 0100000

11 CONNECTION EXAMPLES




Point-to-Multipoint



Point-to-Point



Opening of the Radio
modem's lock pins with
a screw driver





P.O.Box 142, FI-24101 SALO, Finland
Street: Meriniitynkatu 17, FI-24100 SALO, Finland
Tel +358 2 777 7800, Fax +358 2 777 7810, E-mail info@satel.com
www.satel.com