

BAC-105-02B



certificate of approval
(ISO9001)

CONSTANT TEMPERATURE & HUMIDITY OPERATING MANUAL

This is a product we, bumyang, tightly control quality through all the process from design to assembly with our experience and state-of-the art technology as a specialized air-conditioner maker.

BUMYANG

MODELS : UCU 30M, UCU 50M, UCU 80M, UCU 100M, UCU 150J, 200J, 250J, 300J

Before using your air conditioner please read this manual carefully and keep it for future reference

CONTENTS


Safety sign	2
Safety precaution	3
Installation precaution	6
How to install	7
Name of parts	9
Operation precaution	10
Economic operation	12
Repair & management	13
Air filter cleaning	13
Evaporation cleaning	14
When the machine is to be used again	15
When the machine is to be finished	15
Trouble shooting	16
Cautions of handling refrigerant	17
quality of supply water	18
How to use controller	19

Safety sign


To prevent injury to the user and property damage, the following instructions must be followed




This symbol indicates the possibility of death or serious injury.



This symbol indicates the possibility of injury or damage to properties only



This symbol indicates the possibility of slight injury or damage to this machine.



This symbol indicates the possibility of use efficiency and escape with injury.

Safety precaution

Improper installation will cause water leakage, electrical shock, or fire.
Please confirm the following important points during installing.




DANGER

Do not damage or use an unspecified power cord.

It may cause explosion or fire,
Do not modify power cord length or share the outlet with other appliance.

It may cause explosion or fire,
Do not power cord drawing or bending.
It may cause electric shock or fire.



Do not use home consent, use circuit breaker or leakage breaker for exclusive power and the machine.


It may cause electric shock or fire.
Fuse is used with specified rating.

Do not use wire or copper wire. It may cause fire.

Remove and re-installed the machine, please consult authorized dealer or specialist for the installation work.

Do not put a stove etc. where is exposed to direct air flow.

It may affect combustion.



Please consult authorized specialist for the installation work.

This machine must be grounded

It may cause electric shock. if grounding is not perfect.

Do not operate with wet hand.

It will cause electrical shock.




Do not disjoint or repair and change.

It may cause trouble, electric shock, fire. Need to contact us or service center.

Do not install the machine at place where leakage of gas may occur or in an explosive atmosphere.

It may cause explosion or fire,



	WARNING
---	----------------

When the operates the unit, do not open the air flow inlet.

It may cause electric shock.

Do not clean the machine with water.

It may cause electric shock or fire.



Used Air filter certainly.

It may cause trouble, because dust into the unit.

Do not expose the skin directly to cool air for long periods of time.


damage your health

Do not operates and stop the machine during long time, turn off the power or circuit breaker.

prevent from unexpected damage.

Do not insert anything in to the air inlet/outlet.

Since the fan rotates high speed, it may cause injury or damage the machine.



Do not step on the unit and do not put anything on it.

It may cause on injury and dropping and fall down.

	CAUTION
---	----------------

Do not apply an insecticide or flammable spray.

It may cause a fire or deformation of the unit.



Check if any obstacle prevent air from flown into indoor/outdoor unit.

It may cause bad operation condition.

Not Install the harmful to neighborhood because outdoor unit's noise and hot air.

It may cause neighborhood's trouble.

Do not press the LCD surface.

It may cause break down.

Do not press the 2 buttons for once.

It may cause unexpectable operations.

Cleaning the air filter once in 2 weeks.

It may cause bad operation condition.

Do not put a pat or house plant where it will be exposed direct air flow.

This could injure the pat or plant.

Do not operates machine's grill forcibly.

It may cause break down.





Do not clean the machine surface by oil or grease.

It may cause change of color.



Power is off, after machine operation is stop finally.

Use the long time, ventilate 1 or 2 times in 2 hours.

Installation precaution

Improper installation will cause water leakage, electrical shock, or fire.
Please confirm the following important points during installing.



CAUTION

1. No installation place

Do not install the unit at place where firearms, narrow alley, road stopped. It may cause trouble or very open after service.

2. Installation

Install the unit at place where good air flow, install easily, not trouble neighborhood because unit's noise and hot air.

Secure mini-mum service area and where customer wanted.

3. Input the power cord

Used certified power cord and install the leakage breaker where need to place.

This machine must be grounded.

Do not damage or use an unspecified power cord. Do not modify power cord length or share the outlet with other appliances.

4. Delivery of customer

At first, explain the safety sign and user's manual.


Finally, check the leakage gas and serve a reference form(install confirmation, installer, name card) and then clean the machine and place.

How to install


Improper installation will cause water leakage, electrical shock, or fire.
Please confirm the following important points during installing and install area.

INSTALL AREA


UCU 30M - 100M




UCU 150, 200J (in case of right pipe)



Please check service area is securely.
Check if any obstacle prevent air from
flown into unit. It may cause bad
operation condition.



It is very dangerous if gas leaks near the
air conditioner. Avoid this place.




Install air conditioner on a flat surface
taking into account the weight of air
conditioner. If this space is not
suitable, noise or vibration may occur.



Do not put a stove etc.

ELECTRIC WIRING


- (1) The leased circuit of air conditioner should be connected with power source.
- (2) Earth should be connected to avoid electric shock.
- (3) Transportation or rewiring of air conditioner should be done in counsel with expert engineer.
- (4) power cable should be protected.
- (5) In case of installing NFB in main supply, user must install it.




Check the electric wire for proper earth connection to prevent electric shock.



Check if air filter is installed. If air conditioner operates without air filter, dust collection effect deteriorates and air conditioner is contaminated to cause trouble.



Check if any obstacle prevent air from flown into outdoor unit. Obstacle deteriorates air conditioner performance and causes higher over rate. It also causes the safety device to operate.



Please check the cooling water circulated. When cooling tower installed, check opened the valve, operated fan of cooling tower and cooling water pump. Any other water used, check opened the valve and circulated cooling water.



When the machine was stop, check closed valve, stoped cooling tower fan and cooling water pump. Check the humidifier water pipe and supplied water in the machine.

Install thermostat and humidity adjuster sensor in the following place


- o free from direct discharge air
- o good ventilation
- o averaged temperature and humidity

Humidify piping


- o Please contact the water supply piping to strainer in the machine.
- o If the stop valve installed side of water supply pipe, it was convenience.

Name of parts


UCU 30M, 50M, 80M, 100M



UCU 150J, 200J




Operation precaution



Do not clean the machine with water. It may cause electric shock or fire.




Do not apply an insecticide or flammable spray or paint. It may cause a fire or deformation of the unit.




Do not put a pet or house plant where it will be exposed direct air flow. This could injure the pet or plant.



CAUTION



When fuse is blown out, replace it with new one with specified rating. If fuse is blown out frequently, thoroughly check the cause. If any fuse with no specified rating is used, compressor may fail or fire may break out.




When the power supply is cut off, please turn off the machine.



The machine is not intended for use by young children or infirm persons without supervision.



Do not repaired and modified when the machine is operating. It will cause injury and electric trouble.




Do not exposed the body cool air for long period of time. It will be catch cold or catch a similar symptoms.



Do not operates and stop the machine during long time, turn off the power or circuit breaker.


The first start operating, displayed WATER EMPTY SIGNAL. It's not fault. The signal reset when the water supply in humidify.



If machine operates without air filter, dust collection effect deteriorates and machine is contaminated to cause trouble.

When use warm water or steam, remove water in steam heater before the machine is running. If existed water in, freezing heater, heater caused broken.


Economic operation




Keep blinds or curtains closed. Do not let direct sunshine enter the room when the machine is in operation.




Adjust the vertical/horizontal airflow grill direction by hand. When vertical airflow grill is upper, rising the effect of cooling.



Indoor temperature and outdoor temperature differential gap is 5 degrees suitably.



Ventilate the room occasionally. Since windows are kept closed, it is a good idea to open them and ventilate the room now and then.



Make sure that the doors and windows are shut tight. Avoid opening doors and windows as much as possible to keep the cool air in the room.



Do not clean the machine surface by oil or grease. It may cause change of color.


Repair & management




CAUTION

Air filter cleaning


An air filter removes dust from air to clean the exhausted wind. If it not cleaned for a long while, dust accumulates on the filter which interferes with air flow and deteriorates the cooling performance. in this case overheating may occur during cooling operation to cause fire. clean it once or more every month.




when suction grill is slightly pulled forward, the suction grill comes forward.



Put the air filter and electric dust filter while grasping their upper part, the air filter and dust collector filter come out.



When suction grill is remove, air filter is seen. Check if the connector ring is firmly connected with suction grill. if not, connect it with suction grill.



Remove dust from the filter using clean water, and leave it until it is dried. The assemble the filter.


Before checking air filter, disconnect the power

Do not clean air filter using hot water, steam, gasoline or thinner.


After cleaning it using water, leave it in the shaded place until it is dried.

Evaporation cleaning


If evaporator operates a long while, dust accumulates on the surface of evaporator. Clean evaporator once or more every month as follows :



Untied link on the suction grill.



When injection water while directing water hose toward evaporator, dust is easily removed.



Removed suction grill carefully.



CAUTION

1. Before cleaning evaporator, disconnect power.
2. Use case so that electric parts are not wetted with water.
3. If dust accumulates on the evaporator a long while, it is required to use steam to remove dust. In this case contact us.

Bearing lubrication

If bearing runs out of oil, friction or noise occurs. Lubricate bearing once every 3 or 4 months. Remove the rear plate of blower chamber, and pour machine oil into the bearing lubrication hole.

Oiling times

used condition		times
only summer season		once in a season
yearly	cooling	once in 6 month
	cooling/heating	once in 3 or 4 month

When the machine is to be used again

When the machine is to be used again, check the following items and machine is operated.


Take off the safekeeping cover on the machine.

Clean the air-filter and evaporator, re-install it indoor unit.

Check the air inlet and outlet of the indoor/outdoor are not blocked.

How to check V-belt tension

If V-belt tension is not normal, fan does not operate normally. When pressing fan V-belt with hand, it should be pressed down 10mm or so.



CAUTION

Turn off the circuit breaker surely, before checking.

When the machine is to be finished

Turn off the circuit breaker surely.

For prevent drain pipe clogged, remove dust in the drain pipe,

Condensed water should be fully drained. If the drainage is incomplete, water may be freezing and drain pipe will cause breakdown.

Operated the machine on air circulation mode for 2 to 3 hours. because drying inside the machine.

When the machine is stopped for a long time, put the machine on the safekeeping cover.

When the machine is operated during spring or fall, operated the machine on air circulation mode.



Trouble shooting

Check the following points before requesting repairs or service. If the fault persists, please contact your dealer or service center.

trouble	cause	action
Does not operate	Check turn off the power?	Turn on the circuit breaker
	power is interrupted.	disconnect the safety switch for safety.
	Electricity is failed?	Check the other machine is operated.
	fuse is blown out or breaker switch tripped.	replace fuse, and return breaker switch to original position.
Only fan operated, but compressor is not.	room temp. below the set temp.(cooling)	machine is normal. Since comp. stops by room sensor, it automatically resumes operation when the room temp. is above the set temp.
Only fan operated, but electric heater is not.	room temp. above the set temp.(cooling)	machine is normal. it automatically resumes operation when the room temp. is below the set temp.
Both fan and compressor operate, but stop soon.	cooling water does not circulated	circulate cooling water
	cooling water is not sufficient	added cooling water
	When used cooling tower	
	1. fan does not operated	1. fan operate
	2. fan rotates in a reverse direction	2. check correct direction
3. air suction or discharge hole is clogged with dust	3. remove dust	
4. tank strainer is clogged with dust	4. remove dust & scale	
5. water injection nozzle is clogged	5. cleaning nozzle	
wind speed is insufficient while fan operates	fan rotates in a reverse direction	change the wiring
	air filter is clogged	clean or replace the air filter
water leaks out of machine	drainage pipe is clogged	clean drainage pipe

If the cause is not removed after taking above actions or if the cause is not include into above category. Please contact us, and advise us of the type and manufacturing number of your air conditioner. Then we would implement service immediately.





Caution of handling refrigerant

When replace or supply the refrigerant, please consult authorized dealer or specialist for the installation work.

Leakage refrigerant or not operate the machine, worked non-specialist.



Do not replace or supply work by user.

Shortage refrigerant, it caused bad conditions or cooling effect deteriorates by machine.



Quality of supply water

1. Check the quality of supply water as follow items.

items	default
PH(25)	6.8 - 8.0
conductivity(25) : $\mu\ell/cm$	200 below
chloride ion Cl- : mg Cl-/	50 below
sulfuric ion SO_4^{2-} : mg $SO_4^{2-}/$	50 below
acid consumer amount(PH 4.8) : mg $CaCO_3/$	50 below
mg $CaCO_3/$	70 below
Fe : mg Fe/	0.3 below
ammonoum ion NH_4^+ : mg $NH_4^+/$	0.2 below
ion SiO_2 : mg $SiO_2/$	30 below
ion S_2^- : mg $S_2^-/$	none

2. Do not control of quality of supply water it may cause not use humidifier for long times.
3. When need after service, please contact your dealer or service center.

Don't used quality of supply water, it may cause water level sensor trouble and leakage water.

Please cleaning the cylinder once in 2 weeks.
(check the water level sensor)


How to use controller

CONTENTS

Name of parts	21
How to use and operation	23
Control function	27
Temperature function	
Humidity function	
Cooling control	
Heating control	
Humiditing control	
Dehumiditing control	
Fan control	
Humidifier control	
Trouble shooting	32


Name of Part

Display Part



- | | |
|---|--|
| <p>(1) RUN/STOP switch
Every time this switch is pressed, operation shifts between stop and start up.</p> <p>(2) DISPLAY. SCAN switch
Every time this switch is pressed, present operation status or output status is displayed on LCD.</p> <p>(3) EDIT switch
When this switch is pressed once, the desired operating conditions is set. Pressing this switch once more after the desired operating condition is entered. Then pressing this switch once more, the desired operating condition is finished.</p> <p>(4) ENTER switch
After pressing this switch, the desired operating condition is entered. Every time this switch is pressed, control shifts to the next desired operating condition.</p> <p>(5) DOWN switch
Setting value decreases.</p> <p>(6) UP switch
Setting value increases.</p> <p>(7) POWER ON/OFF switch
Connects and disconnects the MICOM power.</p> | <p>(1) RUN lamp
Lights up during operation, and goes out when air conditioner stops.</p> <p>(2) HEATER 1,2,3 lamp
Indicates one of 1, 2, and 3 heater being operated.</p> <p>(3) COMPRESSOR 1,2,3,4 lamp
Indicates one of 1, 2, 3 and 4 compressor being operated.</p> <ul style="list-style-type: none"> - in case of compressor 1 or 2 cycle :
COMPRESSOR 1,2 lamp - in case of compressor 3 cycle :
COMPRESSOR 1,2,3 lamp - in case of compressor 4 cycle :
when used AHU controller <p>(4) HUMIDIFIER 1,2 lamp
Indicates one of 1 and 2 humidifier being operated.</p> <p>(5) WATER lamp
Indicates that water is fed into humidifier tank. If water is not fed within 25 seconds, system is troubled.</p> <p>(6) FAN lamp
Indicate that fan operates.</p> <p>(7) ERROR lamp
Indicate system failure</p> <p>(8) POWER lamp
Indicates power is supplied to MICOM.</p> |
|---|--|

Main Control Part



How to use & operation

RUN and STOP

- (1) Connect main power circuit breaker.
- (2) Turn on POWER ON/OFF switch. Display appears in the following sequence:

CRC 2004 Controller BUMYANG AIR CO.,LTD
--POWER ON RESET-- set data restore ..!
*** SYSTEM READY *** --POWER ON RESET--
Press a RUN switch to start a system..!

- (3) Pressing RUN/STOP switch, machine operates. And he display appears in the following sequence:

*** System Start *** MODE = auto humi / temp
*** System Start *** Local Start Running
* OUTPUT CONDITION * Heating = N STEP

- (4) Pressing RUN/STOP switch once more, machine stops. And display appears in the following sequence:

*** SYSTEM READY *** -- LOCAL STOP --
Press a RUN switch to star a system..!

If power interrupts during normal operation and power is reconnected, operation automatical starts even if RUN/STOP switch is not pressed.

How to check the operation condition when machine stops

- (1) Pressing DISPLAY/SCAN switch, display appears in the following sequence:

*** ROOM CONDITION *** 16.5 37%RH	room temperature and humidity
** SET POINT(CPA) ** 24.0 55%RH	desired temperature and humidity
** SET POINT(PB) ** 3.0 degC 10%RH	desired proportion belt(PB)
** SET POINT(STEP) ** 1.5 degC 10%RH	desired step temperature and humidity(AHU)
** SET POINT(DB) ** 1.0 degC 5%RH	desired desensitized belt(DB)
** SET POINT(HUMI AMP) AMPARE 15.6[A]	desired regular currant of humidify

- (2) Pressing DISPLAY/SCAN switch once more, display returns to the original conditions:

How to check the operation condition during operation

(1) Pressing DISPLAY/SCAN switch, display appears in the following sequence:

*** ROOM CONDITION *** 16.5 37%RH	room temperature and humidity
** SET POINT(CPA) ** 24.0 55%RH	desired temperature and humidity
** SET POINT(PB) ** 3.0 degC 10%RH	desired proportion belt(PB)
** SET POINT(DB) ** 1.0 degC 5%RH	desired desensitized belt(DB)
** OUTPUT STATUS *** INDOOR FAN ON/OFF	fan output
** OUTPUT STATUS *** E - HEAT 1 : ON/OFF	heater 1 output
** OUTPUT STATUS *** E - HEAT 2 : ON/OFF	heater 2 output
** OUTPUT STATUS *** E - HEAT 3 : ON/OFF	heater 3 output
** OUTPUT STATUS *** COMPRESS 1 : ON/OFF	compressor 1 output
** OUTPUT STATUS *** COMPRESS 2 : ON/OFF	compressor 2 output
** OUTPUT STATUS *** COMPRESS 3 : ON/OFF	compressor 3 output
** OUTPUT STATUS *** HUMI HEAT 1 : ON/OFF	humidify 1 output
** OUTPUT STATUS *** HUMI HEAT 2 : ON/OFF	humidify 2 output
** OUTPUT STATUS *** WATER S-V/V : ON/OFF	water solenoid valve output

(2) Pressing DISPLAY/SCAN switch, display appears in the following sequence:

*** System Start *** MODE = auto humi/temp
*** System Start *** Local Start Running
* OUTPUT CONDITION * Heating = N STEP

How to set operation mode:

- (1) Pressing EDIT switch, one of following seven operation modes appears :

choice condition..! 1. auto humi/temp ?	humidify and temperature are automatically controlled
choice condition..! 2. auto temp only ?	temperature is automatically controled
choice condition..! 3. auto humi only ?	humidity is automatically controled
choice condition..! 4. auto cool only ?	only cooling operation is carried out
choice condition..! 5. auto heat only ?	only heating operation is carried out
choice condition..! 6. auto fan only ?	only fan operates
choice condition..! 7. REM/LOCAL select?	select REMOTE/LOCAL running method

- (2) Pressing UP or DOWN switch, the following seven operation modes appears sequentially. When desired operating mode appears, press ENTER switch. Operating mode is entered, and control shifts to the next desired operating mode
- (3) When you intend to finish setting operating condition at this point, press EDIT switch. If switch is not pressed in 5 seconds, it automatically finishes.

How to set the desired operating conditions:

- (1) Press EDIT switch to set the mode. When ENTER switch is pressed to set the desired temperature, the following is displayed:

* EDIT TEMP(CPA) ** 24 (UP/DOWN)	setting temperature(CPA)
* EDIT HUMI(CPA) ** 55%RH (UP/DOWN)	setting humidity(CPA)
* EDIT TEMP(DB) ** 1.0degC (UP/DOWN)	setting temperature desensitized belt(DB)
* EDIT HUMI(DB) ** 5%RH (UP/DOWN)	setting humidity desensitized belt(DB)
* EDIT TEMP(PB) ** 3.0degC (UP/DOWN)	setting temperature (CPA)
* EDIT HUMI(PB) ** 10%RH (UP/DOWN)	setting humidity proportion belt(PB)
* EDIT TEMP(STEP) ** 1.5degC (UP/DOWN)	setting STEP temperature(AHU)
* EDIT HUMI(STEP) ** 10%RH (UP/DOWN)	setting STEP humidity(AHU)
* EDIT HUMI AMPERE ** 15.6 [A] (UP/DOWN)	setting regular currant of humidify

- (2) When you want setting menus displayed, **UP** or **DOWN** switch is pressed to set the desired points and then pressed **ENTER** switch. so the desired points are stored.
- (3) And then displayed next menu.

When you intend to finish setting operation condition at this point, press EDIT switch. If switch is not pressed in 5 seconds, it automatically finishes.

If machine stops or power interrupts, CPA, PB, DB, and PID time are stored in the semiconductor element. So there is no need to set them again.

The following are displayed on the LCD depending on the control status during operation : 3CYCLE)


*** System Start *** MODE = auto humi/temp	temperature and humidity automatic control mode
*** System Start *** MODE = auto temp only	temperature automatic control mode
*** System Start *** MODE = auto humi only	only humidity automatic control mode
*** System Start *** MODE = auto cool only	only cooling automatic control mode
*** System Start *** MODE = auto heat only	only heating automatic control mode
*** System Start *** MODE = auto fan only	only fan running control mode
* OUTPUT CONDITION * Heating = N STEP	N step operates during heating operation
* OUTPUT CONDITION * Cooling = HI/MIDDLE/LOW	high, middle or low cooling operation
* OUTPUT CONDITION * Humidify = HI/LOW	strong or weak humidifier operation
* OUTPUT CONDITION * Dehumidify = HI/MIDDLE/LOW	high, middle or low dehumidifier operation
* OUTPUT CONDITION * Heat & Humi = HI/LOW	strong or weak heater and humidify operation
* OUTPUT CONDITION * Heat & Dehumi = HI/LOW	strong or weak heater and dehumidify operation
* OUTPUT CONDITION * Cool & Humi = HI/MIDDLE/LOW	high, middle or low cooling and humidifier operation
* OUTPUT CONDITION * Cool & Dehumi = HI/MID/LOW	high, middle or low cooling and dehumidifier operation
* OUTPUT CONDITION * FAN Running only	only fan operation
* OUTPUT CONDITION * Water Supply	water supply for humidity
* OUTPUT CONDITION * Draining...	draining for humidity

CONTROL FUNCTION


Temperature function

Depending on the difference between the set temperature and room temperature sensed by sensor, the following temperature controller functions:


- (1) room temperature display range : 0 ~ 50
 - 1) room temperature less then 0 : LO display
 - 2) room temperature more then 50 : HI display
- (2) room temperature control range : 10 ~ 40 (default : 25) CPA
- (3) desensitized belt(DB) temperature(DB, controlled output does not respond to the slight fluctuation in room temperature) : 0.2 ~ 5.0 (default : 0.5) DB
- (4) proportional range or step control range(PB, proportional control range) : 0.5 ~ 10.0 (default : 1.5) PB
- (5) step temperature control range : 0.5 ~ 5 (default : 1.5) STEP
- (6) example for the control depending on the temperature setting
 [in case of CPA = 25 , PB = 3 , DB = 1 , STEP = 1]
 - in case of compressor use 1 or 2 unit(2cycle)



- in case of compressor use 3 unit(3cycle)



- in case of AHU unit




Humidity function

Depending on the difference between the set humidity and room humidity sensed by sensor, the following humidity controller functions :


- (1) room humidity display range : 25%RH ~ 90%RH
 - 1) room humidity less then 25%RH : LO% display
 - 2) room humidity more then 90%RH : HI% display
- (2) room humidity control range : 30%RH ~ 80%RH(default : 55%RH) CPA
- (3) desensitized belt(DB) humidity(DB, controlled output does not respond to the slight fluctuation in room humidity) : 1%RH ~ 10%RH(default : 1%RH) DB
- (4) proportional range or step control range : 2%RH ~ 20%RH(default : 2%RH) PB
- (5) step humidity control range : 2%RH ~ 20%RH(default : 5%RH) STEP
- (6) example for the control depending on the humidity setting

[in case of CPA = 55%, PB = 5%, DB = 2%]


- in case of compressor use 1 or 2 unit(2cycle)



- in case of compressor use 3 unit(3cycle)



- in case of AHU unit



Cooling control

If room temperature is higher than desensitized belt(DB) temperature as compared with desired temperature, 3 step control is carried out depending on the temperature difference .($T = \text{room temperature} - \text{desired temperature}$)

- (1) $(DB + PB/3 + PB/3) < T$ three coolers operate simultaneously(cooling high)
- (2) $(DB + PB/3) < T < (DB + PB/3 + PB/3)$ two coolers operate simultaneously(cooling middle)
- (3) $DB < T < (DB + PB/3)$ one cooler operates(cooling low)
- (4) $T < DB$ cooler stops
- (5) Compressor 1, 2 and 3 should operate in turn every 10 operations taking into account the duty rate of compressor 1, 2 and 3. Re-operation is only permitted in 3 minutes after operation stops.
- (6) In case of used AHU controller, 4step controlled depend on step temperature.

Heating control

If room temperature is lower than desensitized belt(DB) temperature as compared with desired temperature, 7 step binary control is carried out depending on the temperature difference.($T = \text{desired temperature} - \text{room temperature}$)

- (1) $DB + PB < T < DB + 2PB$ heater operates in 7 steps(heating= 7 step)
- (2) $DB < T < DB + PB$ 7 step control depending on $PB/7$ step
- (3) $T < DB$ heater stops
- (4) If machine stops while heater operates, fan continues to operate one minute, and then stops.
- (5) The capacity ration of electric heater is 1 : 2 : 4, and controlled in 7 steps by micro computer as follows :

STEP	HEATER 1	HEATER 2	HEATER 3
0	OFF	OFF	OFF
1	ON	OFF	OFF
2	OFF	ON	OFF
3	ON	ON	OFF
4	OFF	OFF	ON
5	ON	OFF	ON
6	OFF	ON	ON
7	ON	ON	ON

(capacity ratio = 1:2:4)

- (6) In case of used AHU controller, 3step controlled depend on step temperature.

Humidifier control

($H = \text{desired humidity} - \text{room humidity}$)

- (1) $(DB + PB/2) < H < DB + PB$ two humidifiers operate simultaneously(humidify High)
- (2) $DB < H < DB + PB/2$ one humidifier operates(humidify Low)
- (3) $H < DB$ humidifier stops
- (4) In case of used electric steam humidifier, 1step controlled.
- (5) In case of used AHU controller, 2step controlled depend on step humidity.

Dehumidifier control

(H = room humidity - desired humidity)

- (1) $(DB + PB/3 + PB/3) < Hu$ three dehumidifiers(compressors) simultaneously(cooling high)
- (2) $(DB + PB/3) < Hu$ $(DB + PB/3 + PB/3)$ two dehumidifiers(compressors) simultaneously(cooling middle)
- (3) $DB < Hu$ $(DB + PB/3)$ one humidifier(compressor) operates(cooling low)
- (4) $Hu > DB$ dehumidifier(compressor) stops.
- (5) Compressor 1, 2 and 3 should operate in turn every 10 operations taking into account the duty rate of compressor 1, 2 and 3. Re-operation is only permitted in 3 minutes after operation stops.
- (6) In case of used AHU controller, no operation function.

Fan control

- (1) fan operation/stop
When operation lamp light up, fan always operates regardless of temperature control.
- (2) staying fan operation
If machine stops during heater operation, Fan continue to operate a minute to prevent overheating of indoor unit.
 - fan staying time = 55 ± 5 second
 - any other case = 5 ± 2 second
- (3) in case of error happened, fan operation
if error happened relate to compressor and heater during machine operation, stop compressor and heater instantly, but fan continue to operate a minute and then stop automatically.

Compressor re-operation prevention time control

If compressor resumes operation, it starts operation in 3 minutes in order to protect compressor and to ensure satisfactory operation.
Compressor re-operation prevention time = 3minute.

Humidifier control

- (1) Pan-type humidifier
 - 1) When power is on, Water supply begins before the humidifier is turned on.
 - 2) The alarm system gets turned on when the water level sensor is disabled or during 25 second.(water empty error)
 - 3) Water keeps flowing into the system until the water level reaches high level. If level sensor was sensing, stops water supply.
 - 4) Stops water supply, humidifier was running.
 - 5) A1-A2 : OFF, A1-A3 : OFF => water supplied, check error time(25 second)
 - 6) A1-A2 : ON, A1-A3 : OFF => previous condition continued
 - 7) A1-A2 : ON, A1-A3 : ON => stop water supply
 - 8) When error happened, turned on buzzer, humidifier stops.
- (2) Electric steam humidifier
 - 1) This humidifier produces steam by conducting current on the electrode inside of the cylinder.
 - 2) Water supply begins after the humidifier is turned on.
 - 3) Water keeps flowing into the system until the machine reaches 110% of full load ampere or until the water level reaches its maximum.

- 4) The system keeps heating water inside of the cylinder until it reaches 90% of full load ampere.
 - 5) Water supplying process resumes when the system drops down to 90% of its full load ampere.
 - 6) The alarm system gets turned on when the water level sensor is disabled for 2 hours or when the electric current is under 2 ampere.(WATER EMPTY ERROR)
 - 7) When 140% of the current conduction occurs, the system drains water automatically and it stops operation 20 second. If this process happens several times, alarm gets turned on.(HUMIDIFIER FAULT ERROR)
- (3) Drain control
- 1) Applied only electric steam humidifier.
 - 2) The system drains water periodically when the impurity concentration inside the cylinder needs to be diluted.
 - 3) When 140% of the current conduction occurs, the system drains water automatically and it stops operation 20 second.
 - 4) Humidifier gets automatically stoped during the water drain.
 - 5) Drain time is automatically during 3 seconds every 20 minutes.
 - 6) Drain time is automatically during 1 minutes every 12 hours.
 - 7) In case of pressed drain switch(on the MAIN PCB), the system drains water automatically and it stops operation 20 second.
 - 4) It's possible to Drain switch input is during humidifier stops.

Condensate leak control

If water collects in the machine due to problems with cooler or dehumidifier, operation stops and error is displayed.(C/D WATER OVER LOAD)

Humidifier water level control

In order to keep proper water level of humidifier tank, the water feed valve is controled by level sensor read to adjust the humidifier water level. This control is only possible in automatic temperature and humidity control mode or in humidity control mode.

SELF-TROUBLE DIAGNOSTIC FUNCTION

When machine fails, err lamp light up and following display appears :

display	remark	
*** SYSTEM ERROR *** INDOOR FILTER CLOG	suction hole filter is clogged	
*** SYSTEM ERROR *** AXP CONTACT OPEN	- air cooling type : cooling tower fails or does not operate - water cooling type : poor external auxiliary signal	
*** SYSTEM ERROR *** INDOOR FAN OVER LOAD	indoor blower motor overload (overload relay operates)	
*** SYSTEM ERROR *** OUTDOOR 1 OVER LOAD	- air cooling type : comp1 overload - water cooling type : outdoor unit 1 overload	high/low pressure switch over currant relay, thermal protector
*** SYSTEM ERROR *** OUTDOOR 2 OVER LOAD	- air cooling type : comp2 overload - water cooling type : outdoor unit 2 overload	high/low pressure switch over currant relay, thermal protector
*** SYSTEM ERROR *** OUTDOOR 3 OVER LOAD	- air cooling type : comp3 overload - water cooling type : outdoor unit 3 overload	high/low pressure switch over currant relay, thermal protector
*** SYSTEM ERROR *** OVER HEATING(BURN)	heater or humidifier overheating	over heating protector
*** SYSTEM ERROR *** C/D WATER OVER FLOW	condensate overflow	
*** SYSTEM ERROR *** ROOM SENSOR TROUBLE	poor temperature and humidity sensor open or short	
*** SYSTEM ERROR *** WATER EMPTY	insufficient humidifier water	
*** SYSTEM ERROR *** HUMIDIFIER FAULT	humidifier over currant	exceed the 140% setting regular currant
*** SYSTEM ERROR *** OUT FAN 1 OVER LOAD	outdoor unit fan1 overload(AHU)	over currant relay thermal protector
*** SYSTEM ERROR *** COMPRESSOR 1 OVER LOAD	comp1 overload(AHU)	high/low pressure switch over currant relay, thermal protector
*** SYSTEM ERROR *** OUT FAN 2 OVER LOAD	outdoor unit fan2 overload(AHU)	over currant relay thermal protector
*** SYSTEM ERROR *** COMPRESSOR 2 OVER LOAD	comp1 overload(AHU)	high/low pressure switch over currant relay, thermal protector

INDOOR FILTER CLOG, INDOOR FAN OVER LOAD, C/D WATER OVER FLOW, ROOM SENSOR TROUBLE, HUMIDIFIER FAULT ERROR happened, stop machine automatically. After error fixed, and then RUN switch pressed error was reset, machine operated by one more run switch pressed.

The following phenomena does not mean trouble:

- (1) When room temperature is displayed LO or HI : This product displays room temperature between 0 40 , and displays L or HI if room temperature exceeds this range.
- (2) When room humidity is displayed LO%RH or HI%RH : This product displays room humidity between 30 80%RH, and displays LO%RH or HI%RH if room humidity exceeds this range.
- (3) In principle the micro computer of this product is designed in the manner that two compressor and humidifiers are installed, respectively(2 steps). For some models, however, it is designed in the manner that one E.A of compressor and humidifier are installed, respectively(1 step). In this case compressor and humidifier are displayed on LCD in 2 steps. For the models equipped with each one E.A of compressor and humidifier, compressor or humidifier is operating in one step if one of compressor 1 or 2, or one of humidifier 1 or 2 operates. If the machine used three E.A of compressor, operation condition displayed on LCD in 3 steps. In case of used AHU controller, displayer 4 step.