

DNI Group

Logic Emulation
ASIC Verification
Algorithm Acceleration

User Manual

DNV7F1A

DNV7F1A

User Manual

DOCUMENT PATH

I:\work\out\2012-11-02\DNV7F1A_manual_rev03.docx

LAST SAVED BY

Ivan Yulaev

LAST SAVE DATE

2012-11-03

Contents

1	INTRODUCTION	5
1.1	AUDIENCE.....	5
1.2	CONVENTIONS.....	5
1.3	RESOURCES.....	5
2	QUICK START GUIDE	8
2.1	STEPS TO FOLLOW	8
3	HARDWARE	18
3.1	OVERVIEW	18
3.2	VIRTEX 7 FPGA	20
3.3	CLOCK RESOURCES.....	21
3.4	NMB BUS	25
3.5	240-PIN 72-BIT DIMM (DDR3) CONNECTORS	27
3.6	DAUGHTER CARD CONNECTORS	29
3.7	FPGA CONFIGURATION	34
3.8	MARVELL CPU	35
3.9	CONFIG FPGA	42
3.10	RS232.....	43
3.11	USER LEDS	44
3.12	SPI FLASH.....	45
3.13	EEPROM	46
3.14	USER CLOCK OUTPUTS	46
3.15	USER ASSORTED I/O	47
3.16	USER SATA.....	48
3.17	USER SFP+	49
3.18	GTX EXPANSION (DNSEAM_NS)	50
3.19	USER PCI EXPRESS	51
3.20	USER USB 3.0.....	53
3.21	USER GTX SMAS.....	54
3.22	ENCRYPTION	55
3.23	JTAG.....	55
3.24	MECHANICAL	56
3.25	POWER	58
3.26	HEAT	58
3.27	RESET	59
3.28	XADC.....	61
3.29	LED REFERENCE LIST	62
3.30	TEST POINT REFERENCE LIST	64
4	SOFTWARE	66
4.1	EMU HOST SOFTWARE	66

4.2	WRITING YOUR OWN SOFTWARE.....	72
4.3	HOW EMULIB WORKS	72
4.4	MARVEL ENVIRONMENT	73
4.5	MORE INFORMATION	80
5	REFERENCE DESIGN	81
5.1	NMB SPACE MAP	81
5.2	COMPILING	82
6	TROUBLESHOOTING	83
6.1	GENERAL PROCEDURE	83
7	ORDERING INFORMATION	84
7.1	PART NUMBER	84
7.2	HOW TO ORDER	84
7.3	BOARD OPTIONS	84
7.4	COMPLIANCE INFORMATION	84
8	GLOSSARY	85

1 INTRODUCTION

Welcome to the DNV7F1A FPGA-based ASIC Prototyping Platform. This manual will assist in setting up, using, and understanding the hardware aspects of this product.

1.1 Audience

This product is marketed and sold to engineers who are familiar with circuit board design, physically probing AC waveforms, programming FPGAs, wiring HDL code, reading device data sheets, reading C source code, and writing software. The provided support material all assumes that the user already has these skills.

1.2 Conventions

Computer input or output

~~Bad advice you should ignore~~

<http://links.to.web.pages>

1.3 Resources

The following list includes the resources that you are expected to make use of.

1.3.1 Website

The product page for this product is on the internet, here:

<http://www.dinigroup.com/DNV7F1A.html>

This page contains:

- Block Diagram of the board
- Marketing Product description
- List of supported features
- Latest Errata
- Latest software and firmware update package
- Latest version of this document.

1.3.2 Product Package

The board comes with a USB memory stick with files on it. On the root directory, there is a file called "Support Package Contents.pdf" that describes the contents and the directory structure.

This package contains the software installed on the board as well as the software that should be installed on your host computer.

1.3.3 Reference Design

The product package contains a set of FPGA designs written in Verilog HDL that produce working configuration files for the FPGAs on the DNV7F1A. Project files and batch script files that use Xilinx Vivado to build the designs are also provided. These example files can be used to quickly create working .bit files for the FPGAs.

The reference design implements every feature on the board, including DDR3 memory, Rocket I/O, and others. You are free to adopt any of the device controllers used in this reference design.

For most customers, the most interesting part of the reference design will probably be the UCF file, which contains a list of all the usable signals connected to the FPGA and the correct IOSTANDARD attribute to use with each.

1.3.4 Schematics and Netlist

This user manual does not list specifications for all of the devices connected to the FPGAs, and so to correctly use them, you will have to refer to the device datasheet and the schematic. The schematic is provided in PDF format. If you need a machine-readable format, you can use the provided ASCII netlist of the board. The ASCII netlist contains only nets on the DNV7F1A that are connected to usable I/O on the FPGA.

1.3.5 Other Relevant Documentation

The principal form of control and communication with the DNV7F1A system is via the Emu software tools. This manual will discuss the use of Emu in performing basic operations on the board, such as FPGA configuration, clock setting, and data transfer. For a more detailed overview of the Emu software, please see the Emu manual at this URL:

http://www.dinigroup.com/product/data/DNV7F1A/files/Emu_Manual.pdf

Two of the primary board interfaces, the DINAR1 general-purpose I/O interface, and the DNSEAM_NS high-speed serial breakout, are proprietary to Dini Group. These are intended to be used for I/O breakout from the DNV7F1A main board. This manual will describe the interfaces and their connection to the user FPGA on the DNV7F1A. To obtain a better understanding of the interfaces, especially if you want to design a custom daughter board, please see the relevant specifications on the product CD: /Daughtercards/Specifications.

1.3.6 Device Datasheet Library

There is a PDF datasheet provided for every part used on the board. It is in the user support package, see [/Documentation/Datasheets](#).

1.3.7 Xilinx

Questions about the use of Virtex 7 FPGAs or Vivado that aren't specific to the DNV7F1A should be directed to Xilinx.

1.3.8 EMAIL AND Telephone Technical support


Email support@dinigroup.com for the best and quickest connection to an actual Engineer that will be able to directly answer your questions.

Phone support is also available Pacific Standard Time from 9AM to 5PM from Monday through Friday, excluding USA federal holidays. Support is available in English. Support for boards purchased through distributors can additionally be provided by the distributor. Distributors are listed in the ordering information section.

Telephone (USA): 858-454-3419

2 Quick Start Guide

This section will walk through an example session using the board.



2.1 Steps to Follow

2.1.1 Examine Contents of Box

The box containing the product should have come with the following units:

- ☐ DNV7F1A board (green -> revision 3)
- ☐ RS232 serial Cable
- ☐ DB9-to-IDC cable adapter
- ☐ USB Stick containing user support package
- ☐ USB Stick containing FPGA .bit files and a shell script.

- ☐ Packing foam
- ☐ ATX Power supply
- ☐ PCI Express cable
- ☐ PCI Express host adapter card


2.1.2 Before you power on

Take ESD precautions whenever handling the board.

Place the board on a clear desk with static control padding. You can use the silver-colored bag the board comes wrapped in as a static control surface. Make sure you neutralize the static in your fingers with the surface before every time you contact the board.


2.1.3 Connect a system to host PC interface

At least one host PC-facing interface should be connected to allow the user to interact with the DNV7F1A. These interfaces are described in this section.



2.1.3.1 Install the PCI Express adapter board in a PCI Express slot (optional)

During the course of your project, if you intend to control the board using PCI Express, then you should complete this step.



The board fits into any 8x or 16x PCI Express slot. Make sure the computer is powered off when you install the board into it. There are two x4 cable connectors on the board. You should use only the bottom one with the DNV7F1A because the DNV7F1A PCI Express interfaces only support 1x or 4x PCI Express links. The top connector on the PCI Express cable adapter card is for use with 8x links.

Connect one end of the provided PCI Express cable to the bottom connector of the adapter card, and the other end of the cable to the DNV7F1A. The correct connector is labeled “PCIE Marvell” for use with the Emu software. For general-purpose applications, use this connection. If you require higher throughput and lower latency on the link, you may connect the PCIe cable to the “Configuration FPGA PCIe” port and use the PCIEDIRECT interface through Emu. See the Emu manual for details on selecting the interface from the host software.

2.1.3.2 Connect Ethernet Cable

This step is optional. During the course of your project, if you intend to use Ethernet to control the board, then you should complete this section.


Have a computer network. In order to be able to access the board over the network, the network must support DHCP. Otherwise, the board will fail to have a usable IP address. Connect the RJ45 connector on the DNV7F1A to your network. If DHCP is not available a static IP address can be assigned to the board. See the Emu User Manual for more information. Traffic must be allowed on certain ports in order for the Emu Software to communicate with the board. See the Emu User Manual for more information.

2.1.3.3 Connect USB Cable

This step is optional. During the course of your project, if you intend to control the board directly from a computer over USB, then you should complete this step.

Connect a USB cable from the host computer to the "USB type B" connector on the board. If the board is plugged into PCI Express, the computer that connects to the board with USB does not necessarily need to be the same computer.

2.1.3.4 Connect MV78200 RS232



The MV78200 processor may be accessed via RS232. If you are using the board without a chassis interface with the header circled above, otherwise use the top header on the front of the chassis. The RS232 port provides a root shell within the Linux environment running on the CPU; this may be used (via DiniCMOS) to configure FPGAs, set clocks, etc. See the DiniCMOS documentation (part of the Emu manual) for more details. In general, this interface is not recommended; for new users, it is recommended to use of the Emu-compatible interfaces listed earlier in this section.

2.1.3.5 Connect FPGA JTAG


This is just a JTAG connection to the user FPGA. See section 3.23. This is if you want to configure the FPGA directly and talk to it over JTAG, f.ex. for debugging with Chipscope.

2.1.4 Connect power cables

The DNV7F1A requires an ATX power header, an EPS (8 pin CPU power), and a PCIe Graphics power cable to be attached, to power the board. These should all come from the same power supply. It is recommended that the power supply use a single rail for these connections. If your power supply does not feature a single +12V rail, do not connect the PCIe graphics power header. No performance degradation will be experienced in this configuration.

2.1.5 Power on the board

If you are using the board in a chassis, simply flip the switch on the front panel. Otherwise, install a jumper in header J21 positions 9-10 (pictured below), and then turn on the power supply.



The board has a self-boot process that takes 30 to 45 seconds.

2.1.6 Using a USB pen drive to control the board

The board is provided with a USB pen drive that has on it a Linux shell script (startup.sh). If you plug the USB stick into the board, then the board will automatically run the shell script. The shell script on the provided pen drive will cause the FPGAs to load with the reference design .bit files. You can tell that the .bit files are loading because after each FPGA configures, a blue LED will appear on the board. A USB pen drive left connected to the board will execute each time the board is powered on, allowing the user to customize clock settings, FPGA load files, and other features, without the need for host control or software intervention.

2.1.7 Host Software

Whether the board is connected to a computer using USB, MV78200 PCI Express or Ethernet, the board is controlled using a program that Dini Group has provided called "Emu". The Emu program is provided in source and as binaries on the user support package. See the Emu User Manual for additional information on installing and using the Emu software.

The rest of this guide will assume you are using a Windows computer, however you can also use

Linux. If you are using Linux the instructions may be slightly different, although the Emu program is cross-platform and should operate in the same way irrespective of the host PC OS.

If you are using PCI Express then you need to install a PCI Express driver. This can be done in Windows using the "device manager". The driver files are provided in the support package /Host_Software/emu/Drivers/windows_pci. Windows should detect the Dini Group board when it is attached to the system, and prompt you to help it locate a driver; just have it find a driver in this location.


If you are using USB then you will need to install a USB driver. [Linux does not require a USB driver]. This can be done in Windows using the "device manager". The driver files are provided in the support package /Host_Software/emu/Drivers/windows_usb.

Ethernet does not require a driver.

2.1.8 Selecting a board


Run the provided "emu" program, located in the user support package here:
/Host_Software/emu/App/out_release/emu_gui_win32.exe

This window will appear.



From the "Board" menu, choose "select board". If you are connected to the board over PCI Express, USB and Ethernet simultaneously, then there will be three options in the pull-down menu. Each interface is treated like a separate board. From the pull-down menu, you can see the serial number of each board. The serial number in this menu should match the serial number located on a sticker near DIMM D of your board.

Once you have selected a board, your window should look like this.



Comment [i1]: Update! [EMU SOFTWARE]

2.1.9 Configure an FPGA

You can configure an FPGA by clicking on the image of it in EMU and selecting "configure" from the pop-up window. There are some example .bit files that you can use in the support package located at

/FPGA_reference_designs/Programming Files/dn0247_dnv7f1a/user_fpga/MAINTTEST

Be sure to choose bit files that are compiled for the correct type of FPGA that you have installed on the board, as indicated by the folders they are stored in. For example for a XC7V2000T part, make sure to select from the "V2000T" sub-directory of MAINTTEST.

After the FPGA successfully configures, a blue dot will appear next to any configured FPGA.

2.1.10 Setting board controls and options

The primary board settings that you will need to modify are the clock settings. There are three clocks on the board that have modifiable options. Let's change the clock frequency of G0 just for kicks.


In the EMU window, click on the right side where it says "CLOCKS: G0". A pop-up menu will allow you to change the frequency of clock G0. You can also change the frequency using the "Clocks/Temps" menu in the menu bar. The clock frequency of the four main clocks are periodically measured and displayed on the screen.

<screen clipping of clock setup>

Comment [i2]: Add [EMU SOFTWARE]

2.1.11 Hardware Verification Test

To run the hardware test, from the "Test" menu, select "selected tests".



Comment [i3]: Update [EMU SOFTWARE]

The tests that you can run now are the temperature test, clock test, blockram test, intercon test, lvds test and flash test. Let's skip the DRAM test and the "factory tests" for now. After you hit the

"OK" button, the program will ask you to locate the "bit file directory". This is where the test FPGA load files are stored. Select this folder in the user support package:

/FPGA_Reference_designs/Programming Files

After each test runs, the Emu window will print "PASS" or "FAIL", and at the end of testing a summary will be presented with the results of each test that was run.


Note that the factory tests require specialized hardware and therefore cannot be run in the field. The DRAM test requires that DDR3 SODIMM memory units are installed in the available SODIMM slots, with the slots set for the correct voltage level. If these conditions are not met then the test will fail.

3 Hardware

This section describes the board hardware.

3.1 Overview


Below is a block diagram of the board.



The board contains one Xilinx Virtex-7 FPGAs in the "FF1761" package. There are 5 different Xilinx part numbers that come in this package, the VX330T, VX485T, V585T, VX690T, and V2000T. All 5 of these are compatible with this board (in any speed grade) although the 10Gbps interfaces can only be used with -2 speed grades and faster.

The Virtex 6 "ConfigFPGA" is not intended for your use, so you should think of it as more of a "controller/bus switch/monitor".

Note that two different diagrams exist; the VX330T/VX485T diagram shows some functionality lost due to the reduced pin count of the smaller devices. The 330/485 diagram is re-printed below:



To connect to other systems, or off-board I/O, there are three "daughtercard" connectors provided. In the block diagram these appear as yellow rectangles. The user is expected to buy a daughter card that contains the I/O interface that is required, or to design their own.

Three DDR3 sockets (red rectangles) are on the board to provide bulk memory for use in the FPGA. You can use standard, off-the-shelf laptop memory (SODIMM), or you can use one of the many memory technology DIMMs that the Dini Group provides.

Getting data on and off the board is accomplished through the Marvell CPU. It provides USB, Ethernet, PCI Express, interfaces. It connected to the user FPGAs through the "NMB" interface, which provides an easy-to-use 20-30MB link to the user FPGA. A high-speed PCI Express only NMB solution is also available if greater bandwidth is required; up to 380MB/s. Contact Dini Group support for more information. The standard NMB interface inside the FPGA and on the host PC is

very simple, because all of the software and hardware between has already been designed, proven, and optimized.

3.2 Virtex 7 FPGA

The Virtex 7 FPGA provides the latest features, largest sizes, and fastest speeds from Xilinx.

3.2.1 Stuffing Options

Below there is a table that describes the major differences between the available FPGAs. Only FPGAs that Xilinx sells in the "1761" (FF, FFG, FH, FHG) packages are compatible with this board.

FPGA	Speed Grades	Flip-flops	Equivalent ASIC Gates	All Board Features?	25x18 multipliers	Memory (bits)
VX330T	1, 2, 3	408,000	14.1M	N	1,120	27M
V585T	1, 2, 3	728,400	4.2M	Y	1,260	28.6M
VX485T	1, 2, 3	607,200	3.5M	N	2,800	37M
VX690T	1, 2, 3	866,400	4.99M	Y	3,600	52.9M
V2000T	1, 2	2,443,200	3.4M	Y	2,160	46.5M

Each V2000T FPGA can emulate approximately 14.1 million ASIC gates reasonably; however this is only an estimate. It is strongly recommended that you synthesize your actual ASIC design, mapping to FPGA technology to get an accurate FPGA utilization estimate.

3.2.2 Speed Grades

Xilinx FPGAs usually come in three speed grades. There is no rule of thumb to estimate which speed grade you will need to run your design at your target frequency. You will only know this once you have run a synthesis, with FPGA place-and-route, targeting the actual FPGA device that you will be using.

The transceivers are limited to 6.6Gbps for the -1 speed grades, 10.3125Gbps for the -2 speed grades, and 12.5Gbps for the -3 speed grades. Verify your transceiver performance requirements before selecting your FPGA. Notably, to run 10Gbps Ethernet and PCIe GEN3, -2 speed grade or faster parts must be used.

3.2.3 Upgrades

If you would like to install smaller/slower FPGAs when you order the board, and later upgrade FPGAs to larger parts, this is possible; however you should request this before ordering the board because there are risks involved in attempting to add FPGAs to an existing board. Costs associated with the upgrade should be negotiated with Dini Group sales.

3.2.4 Small FPGAs

Some FPGA types, notabbling the VX330T and VX485T, do not support some of the on-board interfaces. The interfaces that are not available in these smaller parts are:

1. PCIe connection #2
2. DINAR1 #2
3. Mictor and 0.1" header
4. User FPGA SATA connections (device and host)

3.2.5 Safe Handling of FPGAs

There are three easy ways to break the FPGAs.

1) Static electricity

Make sure you keep the board on a static controlled surface, and that you neutralize your body with that surface before handling the board. Especially sensitive are the FPGA I/Os. These are exposed on the daughter card headers and other connectors.

2) High Voltage

The FPGA I/O can only withstand voltages between GND and the VCCO power supply. When interfacing the board to some external I/O, make sure your I/O signals are driven at levels that do not exceed VCCO. If you do not know what VCCO is, then you probably should not be interfacing the board to some external I/O. Note that the maximum allowable VCCO on Virtex 7 is 1.8V. If you are interfacing with a 3.3V device, then you will need voltage translators.

3) Board warp

If the board undergoes mechanical stress, the FPGA pins (balls) can separate from the PCB and result in non-connected signals. The most common mechanical stress occurs when installing and removing connectors. Make sure that when installing a connector, you are supporting the connector from the opposite side, so that board warp does not absorb the force of the insertion. The board baseplate and stiffeners should be left installed to help reduce flex on the V7F1A system.

3.3 Clock Resources

The board provides many clocking resources for general use. The sources and speeds of these clocks are designed to be as flexible as possible to accommodate a wide range of applications.

3.3.1 Clock pins on the FPGA

Xilinx Virtex-7 parts have removed the notion of "global clock" pins. The two types of clock-capable I/O on the part (excluding the GTX transceiver reference clocks) are MRCC and SRCC pins. The difference between the pins mostly apply to phase-sensitive applications (such as clocking a source-synchronous interface) or applications demanding the use of higher-performance regional buffers (BUFMR or BUFR) rather than global clock resource (BUFG).


Either MRCC or SRCC pins may be used to route to a BUFG or to a clock management tile (CMT). Either type of pin may be used to clock regional clock resources (i.e. a bank) associated with the bank into which the clock is connected. MRCC pins have the ability to clock as many as three clock regions using BUFMRs; this is useful when designing fast, wide, source-synchronous interfaces (i.e. a DDR3 SODIMM interface or similar).

The DNV7F1A's user FPGA is pinned out to maximize the amount of clocking resources available to the user and ensure flexibility across all board-level interfaces. For more details on how to clock a particular interface, please see the relevant section further on in this chapter.

Any clock signal going into the FPGA must be terminated to function correctly. This includes all in-board clock resources. For differential clocks, it is usually sufficient to enable the DIFF_TERM attribute on the IBUFDS element used for the clock input. Make sure you enable DIFF_TERM for all of the relevant clocks in your design!


3.3.2 Global Networks

The global clocks are high accuracy, low jitter programmable synthesizers connected to user FPGA MRCC pins. There is no set function for these clock networks. They may be used to clock logic or any on-board interface, although in general dedicated clock sources are provided for all high-speed interfaces.




3.3.3 Clocks G0, G1, G2

The clocks G0, G1 and G2 are from a synthesizer that can produce any frequency from 2KHz to 700MHz with a 50ppm tolerance or better. They also have the option of being used with either a differential or single-ended off-board signal generator.




The synthesizer used is a high-performance, low jitter, high-precision clock generator chip, the Si5326. To change the clock frequency you can use the EMU software.



The clocks G0, G1 and G2 can also be set to distribute a signal from an external source. Note that the Si5326 cannot accept input frequencies lower than 2kHz. For very low input frequencies you may consider using the user FPGA SMA inputs described in section 3.3.4.

3.3.4 User FPGA SMA inputs


There is a single pair of AC-coupled SMAs connected to an MRCC clock input pair on the user FPGA.



There is no defined purpose for this input. Given that it is on an MRCC pair it is possible that it would be useful for sending a clock into the user FPGA.


3.3.5 DDR3_DELAY Clock

This clock source provides the user FPGA with (by default) a 200MHz reference clock. The Dini Group reference designs use this clock as a calibration frequency for IODELAY elements. The user may use this clock for any purpose in their designs. The frequency of this clock may be reset through the Emu software.



3.3.6 DDR3 Reference Clock

The DDR3 DIMM interface has a dedicated oscillator clock source, used for providing the SYSCLK necessary for the Xilinx MIG core to function. This oscillator operates at 200MHz by default but may be set to another frequency via the Emu software.



3.3.7 GTX Transceiver Reference Clocks

All of the GTX interfaces have some form of REFCLK allocated for them by the DNV7F1A. Usually this consists of either a selectable-frequency oscillator (the choices are usually relevant for the interface bit rate) or an externally-provided clock source, f.ex. for the PCIe downstream interface. The REFCLK implementations are interface-specific and are described in the relevant sections of this chapter.

3.3.8 From the DINAR1 Interfaces

The DINAR1 interface designates pairs for clocking the interface. Please see the section that describes the DINAR1 interfaces.

3.3.9 NMB

The NMB interface includes one clock signal running at 50 or 100MHz. This clock is free-running, and is not configurable. It is received by the FPGA from the configuration FPGA.

3.3.10 Generating clocks from FPGAs

Clocks may be generated in an FPGA using a CMT, PLL, or other logic. That means you can do all of your frequency generation in the FPGA, if so desired.

3.4 NMB Bus

The NMB bus is the primary means you will use to get high quantities of data on and off the board. If you want to use the provided software (EMU) to push data to the board over USB, Ethernet and PCI Express, then you are required to interface to NMB in your FPGA design.

3.4.1 Protocol

You are expected to know nothing about the protocol of NMB and only interface to it using the provided HDL interface wrapper in your FPGA on one end, and in the EMU C++ code on the other end. This short section describes the implementation of the interface. I recommend you skip this "protocol" section. It is useless to know anything here.

The NMB interface is a physically point-to-point connection from each FPGA to the configuration FPGA. The point-to-point connection consists of 40 signal wires, which are used as 20 LVDS pairs. These pairs are further divided into 10 signals in each direction, with 1 clock signals, 1 control signal and 8 data signals. The clock frequency of the interface is 1GHz (500 MHz clock with DDR capture). The theoretical throughput is therefore 1GB/sec in both directions simultaneously.

The protocol supports four channels, demand mode, bursts, interrupts, link detection, some FIFO flags, and more. The data to/from the FPGA is stored in buffers in the DRAM of the Marvell processor.

3.4.2 User Interface

An HDL module is provided in the support package here:
`/FPGA_Rerence_designs/common/NMB/nmb_user_interface.v`

See Documentation/Manual/Dini Buses User FPGA Design Manual.pdf and Documentation/Manual/PCIe DMA (ConfigFPGA design) User Manual.pdf for details on implementing the NMB FPGA module. More or less the `nmb_user_interface.v` provides a simple `Address/DataIn/DataOut` type interface. You should think of the interface as a memory space.

On the C++ side of the NMB there are simple functions like `emu_nmb_read(address, buffer, size)` that can be used to view this memory space. The code for this is found in the support package here `/Host_Software/emu/App/out_release/[release]/Software/emu/App/source/EMULIB/diniboard.h`

See Documentation/Manual/Emu_Manual.pdf for details on the Host side of NMB communication.

3.4.3 Memory Spaces

For additional information, read the Emu Manual sections on NMB:
`/Documentation/Manual/Emu_Manual.pdf`

The memory space is 64-bit. Each address represents a single byte (NMB uses "byte addressing"), however the data is required to be read and written in blocks of 32-bits. Addresses supplied to the interface must be divisible by 4. Therefore, the bottom 2 bits of the address space are unused and always zero.

Additionally, since there are no chip-selects on the NMB bus, it is necessary to pre-allocate address ranges for devices on the bus. On this board, there is only one device; the NMB address ranges that it responds to on the bus is given here:

Target	Starting Address	End Address
FPGA A	0x00000000_00000000	0x00FFFFFF_FFFFFFFF

3.4.4 Error Conditions

Occasionally error conditions may occur and the interface may return error codes. There is no defined way to distinguish these error codes from real data. The error codes are as follows:

ERROR CODE	MEANING
0xDEADBEE0_DEADBEE1	Read request to the configFPGA timed out.
0xDEADBEE2_DEADBEE3	Read request to the user design (BARs 1,2,4) timed out
0xDEADBEE4_DEADBEE4	Read request to configFPGA while the config interface is in reset. The config interface may be in reset because the config clock (Spartan FPGA - > PCIe FPGA) is not being properly received or the BAR0 register for resetting the config interface is set high or the DMA engines are being cleared.
0xDEADBEE5_DEADBEE5	Read request to user space while the user interface is in reset. The config interface may be in reset because the BAR0 register for resetting the user interface is set high or the DMA engines are being cleared.

3.5 240-pin 72-bit DIMM (DDR3) Connectors

For memory expansion, the DNV7F1A has a single 240-pin, 72-bit DDR3 DIMM connector. This connector supports UDIMMs up to 8GB at the time of printing.

If you require another type of memory (not DDR3) please contact Dini Group. We may have (or be able to manufacture) a custom DIMM to your requirements.

3.5.1 Memory Interface Generator

The provided reference design uses a memory controller that is based on the memory controller that is produced by the "Memory Interface Generator" (MIG), part of the Xilinx Vivado software. However it has been modified. The modifications allow the use of dual-rank DIMMs, and also set some parameters automatically, such as RAS and CAS latencies, and total DIMM density.

Some of the signals that are connected between the SODIMM connector and the FPGA are not used by MIG. These include the SODIMM "NC" (no connect) pins, the upper two address pins, and the EVENTn pin.

If you want to use MIG you should use the HDL files produced by MIG, and use the UCF file provided by Dini Group, removing the unused signals.

3.5.2 IO Standards

The DIMM interface is voltage-selectable. When using DDR3 memory, it is suggested to use the 1.5V IO voltage. When using this voltage, signals to the SODIMM should be of the IO Standard SSTL15_T_DCI, DIFF_SSTL15, SSTL15, or LVCMOS15. The necessary board features to make SSTL work properly are provided. See the sample UCF files provided with the MainRef example design for details. See Xilinx UG586 for exact guidelines on which signaling standards should be used for which pins.

The EVENTn pin is also voltage selectable. It will be the same voltage as the rest of the DIMM. There are some LED signals on the FPGA that are connected to the DIMM bank. The IOSTANDARD attribute of these signals must be changed to match the voltage of the DIMM.


The IIC signals (SDA and SCL) are fixed at +1.8V and should use a 1.8V standard.

3.5.3 Voltage Selection

Off-the-shelf DDR3 DRAM always uses 1.5V core power and IO signaling levels. If you are using DRAM, then you would never need to change the voltage output of the DRAM interfaces. However, when using alternate memory modules from Dini Group, or when designing your own daughter cards, you may need to supply a different voltage to the DIMM and to the attached pins of the FPGA.

The DIMM uses its own power regulator for DIMM V_{CC} and FPGA V_{CCO} on the DIMM banks. The voltage on this regulator is selectable through a jumper. Position 1-2 set the DIMM voltage to +1.8V, position 2-3 sets it to +1.5V, and no jumper sets the DIMM voltage to +1.35V. **The voltage change must be performed without power applied to the board. Changing the voltage while the board is powered may damage the V7F1A.** After performing the voltage change please make sure to probe the DIMM voltage test point to make sure it is set as expected.

The location of the test point and the meaning of the two available positions is drawn below.



3.5.4 Daughter cards

Since the pins that connect to the DIMM interface on the Virtex-7 FPGA are not dedicated, it is possible to develop custom daughter cards that plug into the DIMM connector.

The signals on the DnV7F1A circuit board are routed as 40 or 50-ohm impedance. (Almost) every signal connecting to the DIMM is length-matched, including the feedback clock, please see the length-matching guidelines in UG586 to determine what matching to expect. Length reports are available by request.

3.5.5 Clocking

Clocking of the DIMM interface is accomplished by using the dedicated Si598 oscillator connected to the user FPGA bank 38. This clock should be used as the SYSCLK by the MIG core. The dedicated DIMM oscillator provides a 200MHz clock to the user FPGA; it can also be re-programmed to provide almost any frequency between 10 and 800MHz.

3.6 Daughter Card Connectors

The primary means of interfacing between the FPGA and external I/O interfaces are through the three DINAR1 GPIO expansion connectors. These are three high-speed high-density connectors on the top side of the board, containing 150 single-ended signals each (72 differential).

This section will mainly cover the DNV7F1A-specific features of these connectors. For a general connector spec, please see the DINAR1 Interface Specification, available on the product USB media.

3.6.1 I/O Electrical

Each DINAR1 I/O banks connects to an FPGA bank. The DINAR1 connectors fit into a single SLR column, so the entire interface can be clocked using a BUFMR (f.ex. when implementing a 64-bit wide memory interface). The DINAR1 spec is followed completely by the DNV7F1A board.

Note that under no circumstances should any signal above +1.8V be driven into the DINAR1 header. This includes +3.3V signals. Voltage translation must be used for these applications.

3.6.2 Power

The DNV7F1A can supply up to 500mA of power per DINAR1 I/O bank. The voltage regulators can be set to supply +1.8V or +1.2V power to the daughter board. By default (as shipped) +1.2V power is provided; removing the VADJ jumpers along the north edge of the board sets the on-board V_{CCO} supplies to +1.8V. In accordance to the interface spec the daughter board should supply the necessary V_{CCO} voltage to the main board, however, if you make a mistake on your daughter board, using the mainboard regulators may be useful.

3.6.3 I/O Header Mechanical

The main board uses the Samtec SEAF-20-05.0-S-10-2-A-K-TR connector.

The daughter board uses the Samtec SEAM-20-07.0-S-10-2-A-K-TR connector.

The V7F1A is the "main board" side of the interface. The mating card is called the "daughter board".

For daughter board mechanical specifications, including information on what mounting points are provided on the mother board, please see the DINAR1 spec.

3.6.4 Clock Pins

DINAR1 clock pins are connected to MRCC, SRCC pins on the main board. On bank 1 of the DINAR1 interface, 100 Ω differential termination is provided across the P and N pins on the MRCC pins. This is so that a differential clock can be inserted into these clock pairs even when a I/O voltage other than +1.8V is used (Xilinx FPGAs require +1.8V for DIFF_TERM). Keep this in mind of these pins are used for something other than LVDS inputs.

3.6.5 Net Lengths

All DINAR1 signals are length-matched in accordance with the DINAR1 spec. They are routed as 50 Ω "loosely-coupled" traces. The signal lengths are about 300mm on the DNV7F1A.

3.6.6 Physical Spec

See DINAR1 spec section 3.

3.6.7 Insertion and removal

Due to the small dimensions of the very high speed DINAR1 connector system, the pins on the plug and receptacle of the DINAR1 connectors are very delicate.

When plugging in a daughter card, make sure to align the daughter card first before pressing on the connector. Be absolutely certain that both the small and the large keys at the narrow ends of the DINAR1 line up BEFORE applying pressure to mate the connectors!

Place it down flat, then press down gently.

Mating can be started from either end. Locate and match the connector's A1 position marking [triangle] for both the Plug and Receptacle. (Markings are located on the long side of the housing.) Rough alignment is required prior to connector mating as misalignment of >0.8mm could damage connector contacts. Rough alignment of the connector is achieved through matching the Small alignment slot of the plug housing with the Small alignment key of the receptacle housing and the large alignment slot with the large alignment key. Both connector housings have generous lead-in around the perimeter and will allow the user to blind mate assemble the connectors. Align the two connectors by feel and when the receptacle keys start into the plug slots, push down on one end and then move force forward until the receptacle cover flange bottoms on the front face of the plug.

Like mating, a connector pair can be unmated by pulling them straight apart. However, it requires less effort to un-mate if the force is originated from one of the slot/key ends of the assembly. (Reverse procedure from mating) Mating or un-mating of the connector by rolling in a direction perpendicular to alignment slots/keys may cause damage to the terminal contacts and is not recommended.

3.6.8 Clocking Methods


A wide variety of clocking topologies were considered when designing the DINAR1 interface. There should be at least one clocking method possible that will meet your needs. A list of reasonable clocking methods are listed and diagramed below.

3.6.8.1 Manual phase alignment

You can use a PLL inside the FPGA to manually align the phase of a clock that you send from the FPGA to a DINAR1 daughter card.


3.6.8.2 Source-Synchronous inputs

Since the signals to the daughter card are length-matched, you can rely on a tight timing relationship between the clock and data that you send from the daughtercard to the FPGA. Since the FPGA has a zero-hold-time input, sending a clock from the DINAR1 card whose rising edges are aligned with the data transitions on your data lines will result in reliable communication with the FPGA. **Source-Synchronous interfaces are the preferred way of clocking a high-speed interface across the DINAR1 connection.**




3.6.8.3 Source-synchronous outputs

You can repeat this setup in the opposite direction, as long as the hold time on the device on the DINAR1 card is zero or negative. **Source-Synchronous interfaces are the preferred way of clocking a high-speed interface across the DINAR1 connection.**



3.6.8.4 Skewed Clocks

The I/O on the FPGA can be used on either rising or falling edges of a clock, so it is easy to invert the clock on the FPGA device, so that it operates 180 degrees out of phase with the daughter card. Or you can invert the clock as you output it to the daughter card. The maximum frequency of the interface when using this method is effectively reduced by half.




3.6.9 Incorrect Clocking Methods

The following are methods that don't work.

3.6.9.1 Hold time violation

The following diagram shows a method that potentially violates hold time on the device on the DINAR1 card.



3.6.9.2 PLL cascade

When using PLLs in the FPGA, make sure that there is not another PLL anywhere in the feedback loop of the PLL or it will result in an unreliable phase output.

3.6.10 How to make a daughter card

It is recommended that you start with one of the Dini Group daughter cards as a design template. The ORCAD schematic, and layout files are all provided on the Dini Group website for several daughter cards. The DINAR1_OBS is a good starting point for a new daughter card design. Please make sure to read and understand the DINAR1 spec before designing a daughter board.


3.7 FPGA CONFIGURATION

3.7.1 SelectMAP

High speed select map configuration is controlled by the ConfigFPGA and Marvell CPU. FPGAs can be configured over Ethernet, USB, PCIe, from USB Flash Drives, external SATA hard drives, from onboard NAND Flash on the Marvell Processor, and more. See the EMU Manual for more information on these Configuration methods.


3.7.2 JTAG

A standard JTAG header is provided to which a Xilinx Platform USB JTAG cable or other JTAG cable can be connected. All seven FPGAs are on a single JTAG chain and can be configured using the Xilinx Impact software. This JTAG port can also be used for JTAG-based FPGA debug.



3.8 Marvell CPU

The clock networks, off-board I/O, NMB and configuration is controlled by a Marvell ARM CPU. This section describes the hardware attached to the Marvell processor. For information about programming the Marvell and the software running on the Marvell, see the software section of this manual, and the Emu User Manual.




The primary purpose of the Marvell processor is to pump data from a host interface (PCI Express, Gigabit Ethernet, SATA, Flash, or USB) to and from the user's design in the FPGA.

Additionally, these host interfaces can also be used to control the settings of the board's resources, like clock synthesizers, FPGA configuration, and logic resets.

The software that comes pre-loaded on the Marvel processor is running the Linux operating system. For this section, it is assumed that you have a working understanding of Linux.

3.8.1 RS232

The console output of Linux is directed to an RS232 port. In order to connect a terminal to this port, you will need to set the terminal settings to 19200 baud, 8bit, no parity, no flow control, 1 stop bit.




The Linux console is connected to a shell, so you can interact with the system, however the main purpose of the console is to receive kernel debugging messages, so it is recommended that you instead use a telnet terminal, as this shell will be much less chatty.

In order to interact with the boot loader, or see output from the boot process, you must use the RS232 console, you cannot use telnet for these purposes.

3.8.2 PCI Express

The Marvell device natively contains a PCI Express device. The PCI express pins of the Marvell processor are connected directly to an iPass cable connector on the DNV7F1A board. The provided PCIe cable and adapter card can be used to connect to a host PC.




The device appears as three 1MB memory regions to the host machine. You are expected to use the Emu software and drivers (source code provided) to interface with PCI Express. There is no description available of the function of DNV7F1A as a PCI Express device.

For faster and lower latency PCIe accesses to the user FPGA memory space, use the Configuration FPGA PCIe interface. See section 3.9.1 for details.

3.8.3 SATA

The Marvell device contains natively two SATA host ports. In the pre-installed software these ports are managed by Linux, and you are not intended to directly interact with SATA hardware. Instead, when a device is installed, it is automatically mounted as a storage device with a filesystem.

From that point, you should use Linux scripts and programs to interact with the mounted filesystem.




3.8.4 DEV Bus: NAND

The root file system of the Linux installation is contained on the NAND Flash device connected to the Marvell's "device bus". The NAND is 256MB in size, with the first 100MB already assigned to the Linux installation. This memory space can be used for storing (a few) configuration bitfiles or other data.

3.8.5 USB

The Marvell device natively provides a USB host and peripheral device. The two "media" devices are managed by Linux. You are not expected to interact directly with the host ports. Instead, when a device is detected, Linux automatically mounts the devices as storage devices with filesystems. They can then be interacted with as a file-based device.




The single "host" interface is intended to be used as a connection to a host PC that will be used with the provided "EMU" software. You are expected to use the EMU controller library to interact with this device.

3.8.6 IIC Bus: Temperature Sensors

The temperature sensors for the user FPGAs, for the Marvell processor and for the config FPGA are connected to the Marvell's two-wire serial interface. The installed software will poll these IIC interfaces and measure the temperature of the FPGAs. If the FPGAs are not within a specified temperature range, the software will automatically clear the overheated FPGA both to alert the user to the problem, and to prevent damage to the FPGAs.

3.8.7 ICE

There is an interface for running a hardware debugger on the Marvell processor. It is not expected that anyone will use this interface, and no header is factory installed, so details are omitted here.



3.8.8 SDRAM


The Marvell environment has 1GB of DRAM managed by Linux.

3.8.9 SPI Bus: Flash

The linux kernel and uboot bootloader are contained on a SPI flash device. The marvell boots by running instructions from address 0x0 of the SPI flash device. There is a 4-pin SPI programming header attached to this SPI flash. **Typically it is unnecessary for the user to access this header; do not attempt to program the Marvell SPI flash unless directed to do so by a support engineer.**

3.8.10 Ethernet

The Marvell Processor natively contains three gigabit Ethernet ports. Only one of these three ports are enabled. The Ethernet port is managed by Linux. You are expected to use standard Linux programming APIs to access these ports from the Marvell side of the link, and to write your own software for the host side of the link. The provided Emu software can be used to communicate with the board over Ethernet, and you can use the communication framework provided to interact with the board from your own application. The MV78200 linux terminal is accessible via ssh.



3.8.11 Multi-CPU

The Marvell Processor has two CPUs. The first, CPU0 is used by the Linux operating system. Since the Linux kernel running on the MV78200 does not support symmetric multi-processing, the second CPU, CPU1 must be operated in un-hosted mode, in its own area of DRAM, without accessing devices. I/O must be accomplished through CPU0 under Linux.

The use of PCI Express and the DMA engine in the configuration FPGA is possible. Interrupts may also be used by CPU1. The second CPU is disabled by default.

3.9 Config FPGA

The "second" FPGA on the board, the config FPGA (FPGA Q) is not really intended for the user. It is a "cleanup" FPGA that controls all the clock circuits on the board, configures the other FPGAs, and multiplexes the NMB bus from the Marvell CPU to the user FPGAs. You don't need to know anything about it or how it works. You are encouraged to skip this section.

3.9.1 PCI Express

The config FPGA is connected to the Marvell processor through a PCI Express interface. The config FPGA is a PCI Express endpoint, and the Marvell acts as a root port.

The configuration FPGA has its own PCIe cable interface, independent from the one described just prior. It is accessible from the host system via the AETEST software & library. This interface is less user-friendly than Emu but is much faster for FPGA memory space accesses.

3.9.2 Configuring the Config FPGA

The configuration FPGA loads itself off of an on-board SPI flash. The contents of this flash are programmed by the MV78200 and updated automatically as part of the firmware upgrade procedure. Thus, the user should never have to do anything manually to program the configuration FPGA.

3.9.3 RS232

The "config" FPGA passes through the user's RS232 signals to the RS232 buffer. This is completely transparent to the user; the configuration FPGA is simply acting as a voltage translator. Please reference section 3.10 for details on user FPGA pinout for this interface.

3.9.4 Count Clocks

All of the boards "global clocks" are connected to the config FPGA. The config FPGA measures the frequency so that software can report it.

3.9.5 JTAG

The config FPGA has a dedicated JTAG chain and connector that can be used with the IMPACT program from Xilinx. This interface has no purpose.

3.9.6 Device Bus

The "config FPGA" has a "device bus" interface connected between it and the Marvell CPU. In this way the CPU can access the config FPGA as a memory-mapped device. This interface serves no purpose on this board.

3.9.7 Blink LEDs

The config FPGA is connected to 6 green LEDs. It blinks these LEDs incessantly. The LEDs have no purpose or meaning.

3.9.8 Controlling Clocks

The control signals for the "global clock" synthesizer chips, and the multiplexer chips are connected to the config FPGA. Software is able to set these control signals, in order to configure the clocks per the user's inputs

3.9.9 Clock MUX

The config FPGA serves as one stage of multiplexers for the clocking network. On the schematic you may see that clocks G0, G1 and G2 come from the config FPGA. The config FPGA drives out clock signals coming from the user FPGAs on the "TO_SPARTAN" wires, depending on software settings.

3.9.10 Configuring the FPGAs

The configuration FPGA is connected to the "selectmap" configuration bus of the six user FPGAs. It uses this bus to configure and read back the configuration data of the user FPGAs.


3.9.11 Marvel to NMB Bridge

The NMB interface connects each user FPGA to the config FPGA. The data that goes to and from the FPGA winds up in the Marvell CPU's DRAM. Since the config FPGA has a PCI Express link to the Marvell Processor, it is able to directly manipulate memory in the Marvell's DRAM. The config FPGA has a DMA controller inside of it that pushes data directly from the FPGAs to the Marvell DRAM. This is entirely abstracted away via the NMB interface; the user logic should simply implement the NMB engine, and the user software should deal with either the Emu board control software or the AETEST library.

For details about the function of DMA controller see the "PCIe DMA (ConfigFPGA design) User Manual" PDF document.

3.10 RS232

There is a pair of signals (RX and TX) for RS232 "Serial" communication to the FPGAs.



Please use the below pins on the user FPGA for this interface.

Pin	Function
U0.AM38	RS232 RX (fpga input)
A0.AN38	RS232 TX (fpga output)

3.11 USER LEDS


The user FPGA has 8 LEDs connected to it. The GPIO pins for the LEDs drive a n-channel FET, so driving the output high will turn on the relevant LED. LVCMOS levels should be used.



If you pulse a signal to them, then they will be varying levels of brightness. They are sort of yellow in color.

3.12 SPI FLASH


The user FPGA has attached to it a SPI flash chip.



The chip used is Micron M25P128, with 128Mbits of storage space. The interface is SPI. The SPI signals on the FPGA are +1.8V, and are translated up to +3.3V. When calculating timing for this interface please be sure to account for the delay added by the TI SN74AVCH1T45 level translators.


3.13 EEPROM


There is an I²C EEPROM connected to the user FPGA. The purpose of this memory is to store information about an integrated network controller (if one is used) such as the MAC address. You are of course free to use this memory however you'd like.



3.14 USER CLOCK OUTPUTS


The user FPGA has a pair of SMAs that may be used for clock output. Also, there is no reason that these SMAs could not be used as a clock output. Note that since the clock is AC coupled a step clock (or very low frequency constant clock) may not propagate to the output. The clock frequency should be about 1MHz or faster.






3.15 USER ASSORTED I/O

The user FPGA has a 0.1" header and a mictor attached to bank 12. There is no specific function for these connections; they can be used for general signals I/O and/or debug. The V_{CC0} powering these interfaces (on bank 12) is +1.8V. **Note that these headers are connected directly to the FPGA pins; they are NOT +3.3V tolerant. Only signal levels between GND and +1.8V should be applied to these headers.**






There is a dedicated oscillator connected to an appropriate REFCLK input. The frequency select pins of the oscillator are connected to the FPGA so that the user can select an appropriate REFCLK frequency for SATA I or SATA II or even SATA III.



The below photo shows the location of the SATA connectors.



3.17 USER SFP+

The user FPGA attaches to four SFP+ connectors; they occupy GTX tile 117. This connector may be used for Fibrechannel, 1 and 10 gigabit Ethernet, and SAS applications via an adapter. The line rate is limited by what the user FPGA supports, -1 speed grade devices cannot operate the GTX xcvr at 10Gbps.

Sideband signals are also attached to the user FPGA. Each SFP+ has a dedicated set of sideband lines (including the I²C interface). Voltage translation is provided as necessary. The sideband signals are attached to FPGA bank 13; please see the GTX SIDEBAND page in the schematic for the sideband signal to FPGA pin mapping.

An oscillator is provided for REFCLK generation. The oscillator can operate at four different frequencies: 100MHz, 125MHz, 150MHz, 156.25MHz. 125MHz can be used for both 1GbE and 10GbE. The oscillator pads are compatible with standard 5x7mm 6-pin SMD oscillators. If you require different frequencies contact the factory.

Please see the **GTX SFP+** page of the schematic for a drawing of the SFPs, GTX tile 117, and the SFP support circuitry.


NOTE: POLARITY IS SWAPPED ON THE FOLLOWING NETS:

SFP1: MGT_SFP1_RXp/MGT_SFP1_RXn

SFP3: MGT_SFP3_RXp/MGT_SFP3_RXn

SFP4: MGT_SFP4_RXp/MGT_SFP4_RXn, MGT_SFP4_TXp/MGT_SFP4_TXn

The SFP connectors and cages are shown below.




3.18 GTX Expansion (DNSEAM_NS)

The DNV7F1A features two DNSEAM_NS GTX expansion connectors. These are high-performance mezzanine connectors for breaking out GTX transceivers to commonly used connectors types. Available DNSEAM_NS expansion cards include SFP+, SATA, Infiniband, and Samtec BullsEye. Please inquire to sales@dinigroup.com for card availability or if you require a particular high-speed serial interface.

Each connector has on it eight transceivers lanes (RX and TX), 16 SelectIO signals, 4 REFCLK signals, and over 50W of power on +3.3V, +12V, and +1.8V rails. The daughter board is expected to supply the REFCLK signals to the main board; there are four pairs dedicated to this on the DNSEAM_NS interface.

The DNSEAM_NS daughter boards mount to the bottom of the board, and attach to the baseplate which sits between the main board and the daughter board. The photo below shows the location of the two DNSEAM_NS connectors as seen from the bottom of the board, although in this case the baseplate is not attached; if the baseplate were in this photo, the rest of the board would not be visible, only the DNSEAM_NS connectors would be visible through their apertures in the baseplate.



A detailed electrical and mechanical spec, including the connector pin-out, signaling levels, routing rules, mechanical requirements, and connector part numbers, is provided for the DNSEAM_NS interface, please find it on your board support package. If you are designing a custom DNSEAM_NS card, it must comply with the DNSEAM_NS spec. We provide design reviews for DNSEAM_NS expansion boards, inquire please send requests to support@dinigroup.com

3.19 USER PCI EXPRESS

The user FPGA has two 4-lane PCI Express cable connections attached to GTX tiles 113 and 112. This allows the DNV7F1A to be used to prototype PCI Express IP. The PCIe interfaces comply with the PCI Express Cabling Specification, and are compatible with Molex iPASS PCIe cables (other vendors are available).

Each cable connection can be configured as an upstream or a downstream device; changing between the two requires either adding or removing the optocoupler devices, and adding/removing the optocoupler bypass resistors. The clock direction must also be changed, once again by moving around SMD resistors. **By default both ports are configured as downstream connections. If you know ahead of time what orientation you need, contact the factory and we can make sure the board ships configured correctly.** Otherwise you'll need to find someone proficient in soldering SMD components to help you with this.


Each PCIe interface has an associated REFCLK. On the DNV7F1A, a PLL "jitter attenuator" is used to filter the clock going to the FPGA. There is an on-board 100MHz clock source which is used to drive both the PLL and the cable REFCLK connection when the board is configured as an upstream device. When the board is configured as a downstream device, the PCIe cable clock is connected to the PLL and thereby drives the FPGA.

The sideband signals are connected through optoisolators when the board is configured as a downstream device. As a side effect, all of the sideband signals have their logic inverted when going through the isolator, i.e. driving high into one side of the isolator will cause the other side to go low. So, when configured as a downstream device, make sure to invert the sideband signals in your FPGA logic.

The below table describes relevant device stuffing for each PCI Express interface, when configured as either an upstream or a downstream device.

Interface	Configuration	Installed (0 Ω for resistors)	Not Installed
PCIe #1	Upstream	R489, R484, R491, R486, R1366, R1369, R1364, R1360, R1394	R485, R490, U93, U94
PCIe #1	Downstream	R485, R490, U93, U94	R489, R484, R491, R486, R1366, R1369, R1364, R1360, R1394
PCIe #2	Upstream	R571, R566, R573, R568, R1462, R1448, R1451, R1446, R1444	R567, R572, U107, U106
PCIe #2	Downstream	R567, R572, U107, U106	R571, R566, R573, R568, R1462, R1448, R1451, R1446, R1444


The PCIe ports are circled in the below drawing:




3.20 USER USB 3.0

The DNV7F1A has a single USB 3.0 port, type B, on the front panel. The SuperSpeed Rx/Tx lines are connected to an FPGA GTX transceiver, while the USB full-speed/high-speed lines are handled through a discrete PHY chip.

The superspeed lines connect to FPGA GTX tile 114. The user is expected to implement their own USB 3.0 IP for these lines. The high-speed lines are connected as “sideband signals” to SelectIO bank 13. A USB3317 PHY is used to convert an 8-bit LVCMOS bus to the USB 1.1/2.0 differential pair.



The USB 3.0 port is circled in red in the photo below:




3.21 USER GTX SMAs

Three GTX channels, each comprised of Rx, Tx diff pairs, are connected to SMA coaxial connectors on the board. These have no specific intended function, and can be connected to a wide variety of sources capable of communicating via high speed serial connections. For example, Xilinx HW-AFX-SMA-SATA can be used to convert a single GTX channel to a SATA connection.

Note that the SMA RX connections are AC coupled, while the TX connections are not. An AC coupling capacitor can be inserted onto the TX lines if this is necessary for your application, see the GTX SMA schematic page p. 21 to identify the capacitor part designators.


The SMA connectors for the GTX transceivers are circled in the following image. Note that the transceivers are labeled (channel #, direction, polarity) in the board silkscreen. This isn't visible in the photo but you should be able to use the marking on your board to determine how to hook up this interface.



3.22 ENCRYPTION

The Virtex 7 FPGA allows the use of encrypted bit files. You would want to encrypt a bit file if you want some person to pay you for the use of your IP, or to not steal it and reverse engineer it.

In order to support encryption, we have provided the necessary battery on the board. This battery supplies voltage to the VBATT pin of the FPGA, even when the board is off. It also provides power to the VBAT pin of the real time clock on the board.



The above photo shows where one might install a battery on the DNV7F1A. The DNV7F1A comes with a battery installed that will last for quite some time.

Use an LR44 or SR44 battery. An SR44 battery tolerates heat better but they have similar capacity and lifetimes. These batteries should impress a voltage of +1.5V (nominal). **Do not use batteries with a nominal voltage higher than this; applying a voltage in excess of +1.9V will damage the board.**


In order to change the battery without the loss of the encryption key, you can apply a voltage of +1.5V to TP1, and then replace the battery. Make sure to re-install the plastic battery tray when replacing the battery.

3.23 JTAG

The FPGA JTAG chain of the Virtex 7 FPGAs is available for your use. It isn't used by any other circuit on the board. It connects right up to a header that the Xilinx programmer cable connects to. The


Xilinx Impact software or other JTAG software can be used. JTAG based debug programs such as Xilinx Chipscope can also be used.

The configuration FPGA is not attached to the same chain as the user FPGAs.



3.24 MECHANICAL

The following diagram illustrates the mechanical dimensions of the DNV7F1A.



If you are designing a daughter board (either DNSEAM_NS or DINAR1), please see the relevant spec for the daughter board outline and mounting hole locations. Reference designs with OrCAD schematics and PADS layout files are provided on request.

If you are designing a chassis for this board, we provide top-layer Gerber and DXF files by request. Since these are the controlling documents for the board layout we recommend you design your chassis based on them. We also provide the baseplate layout, including all of the positions and sizes of the mounting holes. Contact support@dinigroup.com to request these files.

3.25 POWER

This section discusses the power requirements of the DNV7F1A.

3.25.1 Power Headers

There are two power headers on this board, the 24-pin ATX header and the 6-pin “PCI Express Graphics” power header. They are both in the north-west corner of the board. Both should be connected when the board is in use.

Any off-the-shelf ATX power supply rated for 300W or greater (on the +12V rail) is suitable for powering the DNV7F1A. Please use a supply with “single +12V rails”. Among many other vendors, most Corsair-branded supplies have this feature. An appropriate ATX supply is shipped with each board.

3.25.2 Estimating Power Draw

Most of the power draw for the DNV7F1A comes from either the daughter boards or the user FPGA, and is therefore application dependent. By design, the maximum power the DNV7F1A is allowed to dissipate is 400W from the +12V rail and 7.5W from the +5.0V rail. This assumes a very, very aggressive design in the user FPGA, dissipating about 100W, all transceivers being used, and daughter boards utilizing the maximum power allowable by their specifications. With the user FPGA de-configured and no daughter boards installed, the auxiliary circuitry on the board will draw well under 100W. Thus, adding your daughter board, high-speed serial transceiver, and user FPGA power to 100W should provide a reasonable ceiling for the total system power dissipation.

All of these numbers ignore the efficiency of the ATX power supply.

3.26 HEAT

3.26.1 Total thermal performance

The FPGA heat sinks that come installed on the board are each capable of dissipating one Watt for every 0.4 degrees (in Celsius) that the FPGA under it raises above the ambient temperature. For example, if you are using the board in a room at 25 degrees, and you configure one of the FPGAs with a design that uses 50 Watts, the core temperature of the FPGA will rise by 20 degrees, for a total temperature of 45 degrees. Note that ambient (air near the board) temperature measurements must be taken at full power.

You can use the Xpower tool in Xilinx to determine how much power your FPGA design uses. The amount of power that your FPGA uses may limit the maximum ambient temperature that your board can operate in. The FPGA is not guaranteed to function properly at core temperatures above 85 degrees C.

3.26.2 FANS

The fans that are sitting on top of the heat sink are plugged into the board for power. They have a tachometer. The frequency of operation, in revolutions per minute, can be read from the EMU host software. The fan uses a 4-pin "PWM" fan header which allows the configuration FPGA to control the fan speed. With the fan unit included with the DNV7F1A system, this should occur transparently with no user interaction required.

If your fans start to make a grinding noise, the bearings have worn out and they need to be replaced. We will send you new ones.

3.26.3 Temperature Sensors

The user FPGA has a temperature sensor attached to it to measure the temperature of the FPGA core ("die temperature"). Since correct operation of the FPGA is not guaranteed by Xilinx when the core temperature goes above 85C degrees, we helpfully reset the FPGA for you when the temperature hits 85C. This also prevents the temperature from increasing further and reaching the point at which permanent damage can result. This behavior can be changed if you want, but you'll have to email support@dinigroup.com and ask us how.

3.27 RESET

There is a board-wide reset circuit called "SYS_RESET". Its purpose is as follows:

- 1) Cause power supplies to come up in a particular order
- 2) Cause each device on the board to get a reset pulse after power is applied as required by the device datasheet with the minimum pulse width specified in the datasheet
- 3) Prevent the user from using the board if any power supply is malfunctioning (and to indicate the malfunctioning power supply with status LEDs).
- 4) Allow the user a way to reset the board to a repeatable state without having to power the board down and back up.

3.27.1 Power Sequencing

The power supplies are allowed to supply voltage in a particular order. This is controlled by the requirements of the multi-rail devices on the board.

3.27.2 Power supply failure detection


There is a comparator circuit on the board to detect when any of the voltages on the board falls below some minimum voltage. If this happens, the result is like holding down the "SYS RESET" button. A red LED comes on, and the board won't work at all. Typically, many LEDs will come on, one for the supply that has failed, and one for each supply after the sequenced supply. If you give us a list of the red FAULT LEDs that are illuminated, we can use this to determine which power supply has failed. Often power supply failures are caused by a blown fuse which can often be fixed in the field and not require a time-consuming RMA.

3.27.3 Reset Button

The "SYS_RESET" button asserts the same signal that the power fail circuit does. It resets the entire board, similar to what a power-off then power-on cycle does.


The SYS_RESET button does not cause the power supplies to power down or the power-up sequence to be repeated.

Here is a photo showing the location of the SYS_RESET button.



3.27.4 User Reset

There is another reset button on the board called the "USER RESET" button. It is located as shown below.




This button has nothing to do with the power monitors or power on. All it does is assert the USER_RESETh signal to the FPGA (FPGA_USER_RESETh_A, active-low, connected to user FPGA pin AH35). It can (and should) be used as a general-purpose logic reset in the user FPGA design.

The USER_RESETh signal to the FPGA is also automatically asserted by the configuration FPGA while it is configuring FPGAs. After an FPGA is configured, the config FPGA will de-assert the USER_RESETh signal. For this reason it is useful for the purpose of resetting your logic. Additionally, software can assert this signal. The Emu software does so when the "FPGA->Reset" menu option is chosen.

3.28 XADC

Each Virtex 7 FPGA has an internal block called the XADC. The system monitor is enabled on the DNV7F1A, although the internal V_{REF} source should be used for this block. The VP and VN (analog) inputs of the FPGA are connected to a low-pass filter and a through-hole test point.



You can also read back the voltages on these pins, the FPGA temperature, and the VCCINT and VCCAUX voltages using IMPACT and the JTAG chain, or by instantiating the XADC block in your design. See [Xilinx 7 Series FPGAs XADC User Guide \(UG480\)](#) for details on using XADC functionality within your design.

3.29 LED REFERENCE LIST

There are a lot of LEDs on the board. This list describes them. In general, you can search for the text in the “Meaning” column, or for the reference designator, in the schematic to gain more knowledge about what makes them turn on and off.

REF. DES.	COLOR	MEANING
DS1	GREEN	(reserved)
DS2	RED	MV78200 Core Voltage Failure
DS3	RED	MV78200 “uncore” voltage failure
DS4	GREEN	MV78200 SATA1 activity
DS5	RED	MV78200 software reset asserted
DS6	GREEN	MV78200 SATA0 activity
DS7	RED	Firmware not configured
DS8	RED	+2.8V supply failure
DS9	RED	POR reset asserted
DS10	GREEN	Configuration FPGA Status
DS11	RED	Front panel logic reset asserted
DS12	GREEN	Configuration FPGA Status
DS13	RED	Device USB overcurrent
DS14	GREEN	Configuration FPGA Status
DS15	RED	User FPGA Core voltage failure
DS16	RED	+5.0V failure (from ATX supply)

DS17	RED	MV78200 NAND flash busy
DS18	GREEN	Configuration FPGA Status
DS19	RED	Configuration FPGA core voltage failure
DS20	RED	+2.5V clock power failure
DS21	GREEN	Configuration FPGA Status
DS22	RED	Configuration FPGA Status
DS23	GREEN	MV78200 to configuration FPGA link active
DS24	RED	G2 synthesizer loss of lock
DS25	RED	G1 synthesizer loss of lock
DS26	RED	G0 synthesizer loss of lock
DS27	RED	MV78200 lost connection to configuration FPGA
DS28	RED	MGTA _{VCC} (Configuration FPGA) failure
DS29	RED	MGTA _{VTT} (configuration FPGA) failure
DS30	RED	+1.8V power failure
DS31	RED	DIMM power failure
DS32	BLUE	Configuration FPGA DONE (configured)
DS33	RED	MV78200 V _{TT} failure
DS34	RED	DIMM V _{TT} failure
DS35	RED	+3.3V clock power failure
DS36	RED	+3.3V clock power failure
DS37	RED	+2.5V clock power failure
DS38	RED	+2.7V power failure
DS39	RED	+1.3V power failure
DS40	RED	MGTV _{CCAUX} power failure (user FPGA)
DS41	RED	MGTA _{VTT} power failure (user FPGA)
DS42	RED	MGTA _{VTT} power failure (user FPGA)
DS43	RED	V _{CCAUX} power failure (user FPGA)
DS44	RED	+3.3V power failure
DS45	RED	+2.5V power failure
DS46	RED	V _{CCAUX IO} power failure
DS47	YELLOW	User FPGA LED (user-defined)
DS48	YELLOW	User FPGA LED (user-defined)
DS49	YELLOW	User FPGA LED (user-defined)
DS50	YELLOW	User FPGA LED (user-defined)
DS51	RED	+3.3V clock power failure
DS52	RED	+3.3V clock power failure
DS53	BLUE	User FPGA DONE (configured)
DS54	YELLOW	User FPGA LED (user-defined)
DS55	YELLOW	User FPGA LED (user-defined)
DS56	RED	MGTA _{VCC} power failure (user FPGA)
DS57	RED	MGTA _{VCC} power failure (user FPGA)

DS58	YELLOW	User FPGA LED (user-defined)
DS59	YELLOW	User FPGA LED (user-defined)
DS77	RED	(reserved)
DS78	GREEN	ATX power OK
DS79	GREEN	+12V power present

3.30 TEST POINT REFERENCE LIST

There are a lot of test points on the board. This list describes them. The reference designator in the left-hand column appears on the circuit board, and can be searched for in the schematic. The net names in the PIN columns are schematic net names, which can also be searched for in the schematic.

TESTPOINT	PIN 1	PIN 2	PIN 3	PIN 4
TP1	VBATT_D2	GND		
TP2	RST_PEX0n_CPU	PCIE_CPU_CPERSTn_FPGA b		
TP3	+1.0V_CPU	GND		
TP4	+12V	GND		
TP5	+1.1V_CPU	GND		
TP6	+12V	GND		
TP7	SATA_USB_TP			
TP8	+0.9V_VTT_M	GND		
TP9	PEX_TP			
TP10	+3.3V	GND		
TP11	+2.5V	GND		
TP12	3.3V_ATX	GND		
TP13	Ge0_TSTP			
TP14	DEV_READY			
TP15	GND			
TP16	minus12.0V_ATX	GND		
TP17	DEV_BURST			
TP18	RST_PORn	GND		
TP19	RST_CPUUn	GND		
TP20	+1.8V_CPU	GND		
TP21	+5.0V	GND		
TP22	minus5.0V_ATX			
TP24	5.0VSB_ATX			
TP25				
TP26	GND			
TP27	+2.5V_CLK_LDO	GND		
TP28	5.0V_ATX			


TP29	+1.0V_MGTAVCC_Q	GND		
TP30	GND			
TP31	+3.3V	PCIE_Q_PWR	PCIE_Q_PWR_RTN	GND
TP32	+1.2V_MGTAVTT_Q	GND		
TP33	GND			
TP34	+DIMM_VCCO	GND		
TP35	+1.0V_MGTAVCC_0	GND		
TP36	+1.2V_MGTAVTT_0	GND		
TP37	GND			
TP38	+1.8V_VCCAUX	GND		
TP39	+1.8V_MGTAVCCAUX	GND		
TP40	+2.5V_CLK_LDO_LOCAL_2	GND		
TP41	+1.2V_MGTAVTT_1	GND		
TP42	+2.0V	GND		
TP43	+3.3V	PCIE1_PWR	PCIE1_PWR_RTN	GND
TP44	+1.0V_MGTAVCC_2	GND		
TP45	GND			
TP46	GND			
TP47	+1.0V_MGTAVCC_1	GND		
TP48	+1.0V_VCCINT_A	GND		
TP49	+2.5V_CLK_LDO_LOCAL	GND		
TP50	GND			
TP51	+3.3V	PCIE2_PWR	PCIE2_PWR_RTN	GND
TP52	+1.3V	GND		
TP53	CFG_VP_0r	GND		
TP54	FPGA_XADC_VPr	FPGA_XADC_VNr		
TP55	DIMM_NC3			
TP56	DIMM_NC4			
TP57	DIMM_NC5			
TP58	DIMM_NC6			
TP59	DIMM_NC7			
TP60	DIMM_NC8			

4 Software

Using the board requires configuring FPGAs, setting board controls such as clock frequency settings, and transferring data on and off board. For these purposes software has been provided. The best place to find details about the Emu software and programming API is in the "Emu_Manual.pdf" which can be found in the user package under [/Host software/Emu/Documents/Emu_manual.pdf](#)


4.1 Emu host software

In the user support package, under [Host software/Emu/App](#), there is a program called "EMU". It can be used on Windows or Linux PCs. This program allows you to control the board.



Comment [i4]: Update me [EMU SOFTWARE]

The window shown above the is the main window of EMU.

A screenshot of a Windows command prompt window titled "C:\kirin\CUST_CD\DNV6F6PCIE\Host_Software\emu\App\Bin\emu_cmd_win32.exe". The window shows the EMU Text-Based Utility interface. It starts with "Emu Version 1.0.9, compiled May 24 2010" and "Initializing...". A separator line of asterisks follows, with "EMU TEXT-BASED UTILITY" in the center. Below this, it says "Compiled May 24 2010" and "Version 1.0.9". The prompt "SELECTED BOARD: NONE" is shown. Another separator line is followed by "Main Menu" in the center. The menu options are listed: "1> Board Menu", "2> FPGA Menu", "3> Clocks/Temps Menu", "4> Data Menu", "5> Test Menu", "M> Map", and "Q> Quit". The prompt "Enter selection:" is at the bottom.

```
C:\kirin\CUST_CD\DNV6F6PCIE\Host_Software\emu\App\Bin\emu_cmd_win32.exe
Emu Version 1.0.9, compiled May 24 2010
Initializing...

*****
***** EMU TEXT-BASED UTILITY *****
*****
Compiled May 24 2010
Version 1.0.9

SELECTED BOARD: NONE
*****
*****      Main Menu      *****
*****

1> Board Menu
2> FPGA Menu
3> Clocks/Temps Menu
4> Data Menu
5> Test Menu
M> Map
Q> Quit
Enter selection:
```

There is also a command-line version of EMU.

4.1.1 Selecting a board

To connect to a board using the EMU program, make sure the board is connected to the computer either over Ethernet, USB, or PCI Express. If the board is connected to Ethernet, make sure the network supports DHCP, or else you may not be able to connect to the board. If DHCP is not available, see the Emu_Manual.pdf document for more information on setting up a static IP address.

When using USB on Windows, a USB driver must be installed before the EMU program can detect the board. The Windows USB driver is located here:

Host_Software/emu/Drivers/win32_usb

The driver can be installed using Device Manager. Note that Linux does not require a USB driver.

When using PCI Express on Windows, a PCI Express driver must be installed before the EMU program can detect the board. The Windows PCI Express driver is located here:

Host_Software/emu/Drivers/win32_pci


The driver can be installed using Device Manager.

When using PCI Express on Linux, a driver is required. The Linux PCI Express driver is located here:

Host_Software/emu/Drivers/linux86_pci

There is also provided a shell script that will load the kernel module, and create suitable device nodes on the file system. You must have root privileges to run this shell script.

In Emu, from the Board menu, select Board->Select Board. A drop-down menu will appear allowing you to select which board you wish to control, and over which interface. If you have multiple boards connected to the system, you can only control one at a time using each instance of the Emu program. After you have selected the board, the main window will update to show a picture of the board you are using.



Note that it may take about a minute from the time a board is powered on until when it becomes selectable from the EMU window. This is the time it takes the Marvell CPU to boot into Linux.

4.1.2 Configuring FPGAs

To configure an FPGA you can select the option FPGA->Configure FPGA from the menu bar. Or you can click on the photo of the board near one of the FPGA labels and select "configure FPGA" from the pop-up window. The program will ask for the path to the .bit file that you wish to use.

When the FPGA is done being configured, a blue dot will appear next to any FPGA that has been configured. The dot will stay blue until you clear the FPGA. Also note that a blue LED will light on the board itself.

You can clear an FPGA by clicking on it, and selecting "clear" from the pop-up window.

4.1.3 Clocks

There are 3 global clock networks on the board that have user-controllable settings. Each of those clocks has its frequency continually monitored and displayed on the main EMU window on the right side of the board photo. (The "Auto-Update" check box controls if EMU monitors the board for changes, or whether it only updates the screen when the user does an action).

To change the settings of the clocks, you can click on the text displaying that clock's frequency. A pop-up window will display options for the clock. Each clock may have different options, and all options may not be available for all clocks. For example, clocks G0, G1 and G2 can be set to a user-specified frequency, but USER_L and USER_R can not.

4.1.4 Sending data to and from the FPGA

The EMU program can also be used to transfer data to and from the FPGAs. The name of the interface on the FPGA that can be accessed from EMU is called "NMB". The "NMB" interface can be thought of as an address space. The EMU program can read and write to addresses on that space. Select "NMB Advanced" from the "Data" menu. There are also several other NMB options to play with including a memory space browser and file transfer functions.


In order to transfer data to your FPGA, your design must implement an NMB endpoint. The code necessary to implement an NMB endpoint is provided in the user package at
`/FPGA_Reference_designs/common/nmb`

For help in understanding this endpoint, read the document here:
`/Documentation/Manual/Dini Buses User FPGA Design Manual.pdf`

The "main ref" reference design provided is here:
`/FPGA_Reference_designs/Fpga_programming_files/user_fpga/main_ref`
Correctly implements an NMB endpoint. You can load these test files into one or more FPGAs and use EMU's NMB functions to send data to the reference design.

4.1.5 Hardware Tests

To detect hardware failures, the EMU program is capable of testing the board. If you want to run a complete hardware test of the board, select the board in emu. From the Test Menu, select "Selected Tests". This window will appear.



All of the check boxes are tests on the board that can be run independently. The items in the "Factory Tests" area all require specialized test fixture hardware to pass, so they will be of limited use to users for testing the board. The tests in the "field tests" area can all pass without special test fixtures. Note that the DRAM Test requires that there is a DDR3 DIMM (any density) installed in the DIMM slot on the board. If it is not installed, the test will fail.

Before running, the test may ask for the path to the ".bit" files used to program the FPGAs. A directory with an appropriate structure is provided on the user package in this location:

/FPGA_Reference_Designs/Programming_Files

After the test(s) complete, the program will print out a message like this:

```
ONESHOT: rocketio_field_test PASSED
#####
ONESHOT: CUSTOM TEST COMPLETE.
rocketio_field_test : PASS
```


```
*****  
CUSTOM TEST (REP 1/1) PASSED  
DN0200_DN2076K10 1003019  
18:18:02 5/26/2010
```

Comment [i5]: Update me [EMU SOFTWARE]

If the test stops or fails, you may need to hit the "q" key to regain control of the EMU program.

4.1.6 Command Line version

The EMU program compiles into two versions. The GUI version and the command-line version. Both versions can run in Windows or in Linux.



The menu options in the command-line version and in the GUI version are identical. The command-line version lends itself well to scripting.

4.1.7 Scripting with EMU

The command-line version of EMU uses stdin and stdout for input and output, and so it is possible to write scripts that interact with it. In this way you potentially can use the board without ever having to write any software of your own.

If you run the program with the -c switch, then EMU processes commands from stdin instead of presenting the text menu. Run EMU with the -h script for a list of available commands. The parameters for each command are identical to what EMU would expect if the same command was run from the text menu. Experiment with each command from the text menu to learn how to put it into a script.

4.1.8 Emu on the Marvell Linux environment

The command-line version of EMU is also installed on the Linux system that is installed on the Marvell CPU. This allows EMU commands to be issued to the board using the RS232 terminal or over a telnet session to the board. The command is “emu_mv”.


4.2 Writing your own software

To write your own software it is recommended that you start by attempting to compile the existing gui or command-line version of Emu. There is an Emu software manual that describes the process in the support package.

/Host_Software/emu/Documents

4.3 How EmuLib works

The Emu program and EMULIB communicate to the board through a tall stack of software linking the host PC to the Marvell processor, the Marvell processor to the FPGA I/Os, and the FPGA I/Os to your HDL.



If you want to implement your own software that uses EmuLib to talk to the board from the host PC side, you are expected to understand and use the interface provided by the file `diniboard.h` (See the software Emu User Manual for details), found in the user package. On the FPGA side, you are expected to understand and use the interface provided by the file `nmb_user_interface.v` also found in the user package. See documentation here:

/Documentation/Manual/Dini Buses User FPGA Design Manual.pdf

The layers of software and hardware in between should operate transparently. For no particular reason details are given here:

- 1) Your C++ code calls `nmb_write()` function in the `diniboard.h` interface.
- 2) The `emulib` library determines which of the three interfaces the board is connected on. Let's assume ethernet
- 3) The `emulib` library creates a packet of data with a header and the data you supplied.
- 4) `Emulib` sends the packet to a special port at the ip address of the board.
- 5) On the board, a program called `DiniCmos` is listening to that very same port. It takes the data in the packet and drops it in the DRAM of the marvel.
- 6) Over PCI Express the `DiniCmos` program sets some registers in the DMA controller in the configuration FPGA.
- 7) The data is transferred to the configuration FPGA and then over the appropriate NMB link to the target FPGA.

4.4 Marvel Environment

The Marvell CPU is running a complete Linux operating system. Most standard Linux applications and utilities are already installed. You are able to program the Marvell processor with your own code so that the board can operate as a stand-alone device, without the need for a host computer in production environments.

4.4.1 Linux Provided

The Linux kernel on the board is version 2.6.22.18 as of this writing.

There is no particular name for the "distribution" on the board, however many of the common Linux utilities are provided by `busybox`.

4.4.2 Operating from the shell terminal

You can get a linux shell terminal by using `telnet` to access the board. The board will register its host name with the dhcp server, if the dhcp server supports dns. The host name of the board is:

DNV7F1A-xxxxxxx

where `xxxxxxx` is the 7-digit serial number of the board. The serial number can be found on the serial number sticker near the user FPGA, specifically, next to the user FPGA LEDs. The host name of the board can also be found by connecting to the Marvell RS232 terminal and typing "hostname" at the prompt. To do this without knowing the hostname and connecting to the board over a network, follow the instructions in the next paragraph.

You can also access a terminal using the RS232 connector located near the lower right corner of the board, labeled "Marvell Serial". This connector is a standard computer "serial" port. The 2 x 5 connector can be connected to with the provided IDC-to-DB9 adapter cable.

The terminal settings are:

Baud: 19200
Data Bits: 8
Parity: None
Stop Bits: 1
Flow Control: OFF
Emulation: VT200

The RS232 output is also the system console, so you will also see system messages on your terminal in addition to the shell output. If this bothers you, you can use telnet instead. To do this, follow the instructions in the previous paragraph.

4.4.3 Running EMU in the terminal

You can run EMU from the linux terminal. From here you can configure FPGAs, set clocks, and send data to and from FPGAs. The command is "emu_mv". Using the program is identical to using the command-line version on the EMU program on the host. You should connect to the board by ip address at address 127.0.0.1, which happens automatically when "emu_mv" is run.

If you really want, you can also control other boards from this board over Ethernet.

4.4.4 Compiling code on the Marvell

The compiler GCC and standard C headers and libraries are installed on the board. You can compile standard C and C++ programs that run in user space. For more information see the "Marvell Processor" section in the Emu_Manual.pdf.

4.4.5 Kernel Space

If you want to run code on the Marvell Processor in kernel space, the complete kernel code is required. The kernel code is not installed on the board, so compiling kernel mode code for the board cannot be done on the board. For this, you will need a build environment. Likewise, to modify the kernel itself also requires a separate build environment. We can provide a VMWare virtual machine with a cross-compiler installed that is capable of building the kernel and kernel modules. Alternatively, a cross-compile platform can be set up. See the Emu_Manual.pdf for additional information on building the kernel and the uboot boot loader.

When modifying the kernel, you should maintain your code as diff files, because if and when Dini Group modifies the kernel, we will not provide you with a change list, and you will have to re-report your changes to the new kernel source. Alternately, you can develop the kernel changes you require and provide the change list to Dini Group, and we will mainline your changes.

Note that you may not need to make kernel modifications at all. We have provided a device located at
/dev/mem

That gives user-mode programs read/write access to the CPU0 memory space. If the only thing you need to do is access protected kernel memory, we recommend you just use this method.

4.4.6 Boot Sequence

When the board powers on, the CPU executes, in place, address 0xF60000 of the SPI device. In this case, the SPI device is an ATMEL data flash. The data flash contains code that initializes DRAM and loads the last 512KB of memory from the data flash into DRAM. The last 512KB of flash contains a u-boot bootloader image.

When u-boot runs, it reads a set of environment variables off the flash. It runs the u-boot command defined by the "bootcmd" variable. That command will copy the entire contents of the data flash image from address 0x0 of the data flash to address 0x2000000 of DRAM. At address 0x0 in the data flash is a compressed linux binary image. u-boot uncompresses the image and jumps to it. U-boot can pass a single string of information to the linux image, called the "boot arguments". The value of these boot arguments can be modified using u-boot environment variables.

Linux boots, setting up all the devices, including NAND flash. The NAND flash shows up as four MTD block devices, representing four different regions in the NAND flash. As the last step of booting, it mounts a JFFS2 file system from one device, specified in the boot arguments. Before starting a shell for the user, linux will run a shell script on the filesystem called startup.sh. This script loads the software that Dini Group wrote that controls the FPGAs and other functions of the board. This program is called "DiniCmos" and runs in the background. You don't need to worry about it.

See the Emu_Manual.pdf document for additional information about u-boot, kernel, and the root filesystem. There is a chapter in there called "The Marvell Processor" that is really good.

4.4.7 Compiling U-boot

Like the kernel, compiling u-boot requires a virtual machine or cross-compile platform. It is not recommended that you do this. Instead, submit your change request to Dini Group so that we can mainline your changes. See the Emu_Manual.pdf for additional information.

4.4.8 Creating the Root File system

There is no root file system build process. Instead we maintain a golden image in the form of a .tar file containing the contents of the root file system on the Marvell. Changes have to be made to the .tar file manually.

4.4.9 Update the software and firmware

When updates are made to the root file system or to the host software or drivers, an email is sent out to the emu-update mailing list. To subscribe to this mailing list, send an email to:

emu-update@dinigroup.com

with "Subscribe" in the subject line. The latest software package is always available at:

http://www.dinigroup.com/files/web_packs/emu.zip

The following sections give instructions on advanced update techniques for updating the various pieces of the firmware running on the board. Typically the Root File System (RFS) is the only firmware piece that users will ever update. For the best instructions on doing a firmware update, see the Emu_Manual.pdf file. Advanced users only may read the following section, but typically should not attempt any of these procedures without contacting support@dinigroup.com first.

4.4.9.1 Installing a kernel update

To get the current version of the Linux kernel, you can check the boot messages for this line:

```
## Booting image at 02000000 ...
Image Name:   Linux-2.6.22.18
Created:      2010-04-02   1:27:51 UTC
Image Type:   ARM Linux Kernel Image (uncompressed)
Data Size:    2840632 Bytes =  2.7 MB
Load Address: 00008000
Entry Point:  00008000
Verifying Checksum ... OK
```

Check the "Created" date.

1) Connect the serial terminal to the board.

2) Power on the board. You should see u-boot boot messages in the terminal. At some point u-boot should print

```
Hit any key to stop autoboot: 3
```

At this step, press any key. You will then receive a u-boot prompt like this

```
>>
```

3) Type this u-boot command

```
protect off 1:0-63
```

U-boot will print this:

```
Un-Protect Flash Sectors 0-63 in Bank # 1
.....
done
```

4) boot into linux by typing this u-boot command

```
boot
```

5) Once linux is done booting you will receive a command prompt like this

```
-sh#
```

6) Type the following command

```
mount -t tmpfs tmpfs /mnt/ram -o size=32M
```

7) Type the following command

```
cd /mnt/ram
```

8) Get the update files from the Dini Group website. Put these files on the board. If you have the board connected to an internet-enabled network, you can use the `wget` command.

```
wget http://dinigroup.com/~marvellfiles/uImage
```

If you do not have access to the internet, then you will need to use some other method to transfer files to the board. You can use a USB key, a network mount, or any other linux trick you know.

9) Type this command

```
cat uImage > /dev/partition_spi
```

This command updates the Linux kernel. If this command fails, the recovery procedure is still possible, but is more complicated.

10) Type this command

```
reboot
```

It is important that you use the `reboot` command, and do not simply power-cycle the board. If you power cycle the board, then the SPI flash may not get written completely due to write buffering.

4.4.9.2 Installing an RFS (root file system) update

This procedure will result in the loss of user data on the Linux file system. Back up your data. To check the version number of your root file system, you can type this Linux command:

```
cat /root/image.date
```

1) Connect the serial terminal to the board.

2) Power on the board. You should see u-boot boot messages in the terminal. At some point u-boot should print

Hit any key to stop autoboot: 3

At this step, press any key. You will then receive a u-boot prompt like this

>>

3) At the prompt, type this command

run 'spi_boot_recoveryfs'

5) Once Linux is done booting you will receive a command prompt like this

-sh#

6) At the command prompt type this Linux command

sh /root/recover.sh

7) The recovery process takes about 10 minutes, plus longer for the 180MB download from dinigroup.com. Wait patiently.

8) When the recovery script is complete. Type this at the shell prompt

Reboot

Do not power off the card without typing "reboot" or "halt" and waiting until the kernel totally shuts down. The "sync" command can also help. Otherwise the NAND Flash may become corrupt due to write buffering in linux.

4.4.9.3 Installing a U-boot update

A failure during this process will cause the board to be un-recoverable. Please consult Dini Group before starting this process. There is normally no reason for the user to use this procedure. To check your current version of u-boot, you can check the boot messages for this line

The compile date of mv_main.c is May 14 2010

1) Connect the serial terminal to the board.

2) Power on the board. You should see u-boot boot messages in the terminal. At some point u-boot should print

Hit any key to stop autoboot: 3

At this step, press any key. You will then receive a u-boot prompt like this

>>

3) Type this u-boot command

```
protect off 1:0-63
```

U-boot will print this:

```
Un-Protect Flash Sectors 0-63 in Bank # 1
.....
done
```

4) boot into Linux by typing this u-boot command

```
boot
```

5) Once Linux is done booting you will receive a command prompt like this

```
-sh#
```

6) Type the following command

```
mount -t tmpfs tmpfs /mnt/ram -o size=32M
```

7) Type the following command

```
cd /mnt/ram
```

8) Get the update files from the Dini group website. Put these files on the board. If you have the board connected to an internet-enabled network, you can use the `wget` command.

```
wget http://dinigroup.com/~marvellfiles/u-boot-db78200_MP.bin
wget http://dinigroup.com/~marvellfiles/update_uboot
wget http://dinigroup.com/~marvellfiles/uImage
```

If you do not have access to the internet, then you will need to use some other method to transfer files to the board. You can use a USB key, a network mount, or any other Linux trick you know.

9) Type this command

```
chmod 500 update_uboot
```

10) Type this command

```
./update_uboot
```

11) Type this command

```
diff new_contents.bin u-boot-db78200_MP.bin
```

The file `new_contents.bin` contains the current contents of the SPI flash. This command is to make sure that the update was written successfully to the SPI flash. If this diff fails (shows the files are different) then something went wrong with the update, and you should not turn off your board. If you turn off the board at this time, the board will never boot again, and you will have to send it back to the factory for re-programming.

12) Was the diff clean? If not then stop here!!

13) Type this command

```
cat uImage > /dev/partition_spi
```

This command updates the Linux kernel. If this command fails, the recovery procedure is still possible, but is more complicated.

12) Type this command

```
reboot
```

It is important that you use the `reboot` command, and do not simply power-cycle the board. If you power cycle the board, then the SPI flash may not get written completely due to write buffering.

4.5 More Information

The Emu manual has more, and possibly more up-to-date, information on the MV78200 environment and how to perform firmware upgrades on your board. You can find it online at http://www.dinigroup.com/product/data/DNV7F1A/files/Emu_Manual.pdf.

5 REFERENCE DESIGN

FPGA reference code is provided in the Customer Support Package at:

/FPGA_Reference_Designs/boards/dn0247_dnv7f1a/MainRef

A very large portion of the design is contained in generic HDL modules which can be found in:

/FPGA_Reference_Designs/common

Much of this generic Verilog HDL code can be very useful in writing custom designs.

5.1 NMB Space Map

The upper 8 bits of the NMB address select the FPGA. 0x00=FPGA A, which is the only user FPGA on this board. This is true for all NMB designs, it is not specific to the MainRef example design.

The MainRef sample design implements the following memory spaces. The underscore is to make the 64-bit addresses easier to read and should be omitted when entering addresses into software.

0x00010000_00000000: BLOCKRAM

0x00020000_00000000: DRAM

0x00040000_00000000: INTERCON TEST CONTROLS

0x00080000_00000000: REGISTERS

The REGISTERS space looks roughly like this:

0x08: NMB_REG_IDCODE (Always reads 0x05000211)

0x10: NMB_REG_DESIGNTYPE

NMB_DESIGNTYPE_NO_NMB	(0x00000000)
NMB_DESIGNTYPE_MISC	(0x34560000)
NMB_DESIGNTYPE_MAINREF	(0x34561111)
NMB_DESIGNTYPE_LVDSABC	(0x34562222)
NMB_DESIGNTYPE_LVDSBCA	(0x34563333)
NMB_DESIGNTYPE_FASTINTERCON	(0x34564444)

0x18: NMB_REG_SODIMMSIZE

0x20: NMB_REG_SODIMMEEPROM

0x60: NMB_REG_LVDSINTERCONBANKS

0x68: NMB_REG_SINGLEINTERCONBANKS

0x70: NMB_REG_SPIFLASH

0x78: NMB_REG_RS232

0x80: NMB_REG_VRN_PULLUPS

0x88: NMB_REG_VRP_PULLDOWNS

0x90: NMB_REG_MISC_PULLUPS
0x98: NMB_REG_MISC_PULLDOWNS
0xA0: NMB_REG_SPD_SCL
0xA8: NMB_REG_SPD_SDA
0xB0: NMB_REG_SINGLEFAST_TYPE
0x100: NMB_REG_ROCKETIO_STATUS
0x108: NMB_REG_ROCKETIO_TXRESET
0x110: NMB_REG_ROCKETIO_RXRESET
0x118: NMB_REG_USB2_PHY_ID
0x800: NMB_REG_CLKSTART

5.2 Compiling

The MainRef design builds in the Xilinx ISE software. Scripts for building it are found at:

```
/FPGA_Reference_Designs/boards/dn2047_dnv7f1a/MainRef/buildxst
```

There are many, many Verilog macro `defines that control how the design compiles. These are found at the top of the main Verilog file:

```
/FPGA_Reference_Design/boards/dn0247_dnv7f1a/MainRef/source/fpga.v
```

6 TROUBLESHOOTING

General tips for troubleshooting are presented here. If in doubt, send an inquiry to support@dinigroup.com before attempting anything that may damage the board.

6.1 General Procedure

If a board is not functioning properly follow this general procedure for troubleshooting:

1. Disconnect all peripherals, cables, daughtercards, and anything else that can be disconnected
2. Visually inspect the board for damage- burn marks, physical damage, etc.
3. Using a Multimeter, probe all power testpoints for GND shorts. Use the TEST POINT REFERENCE LIST in this manual to locate power test points.
DO NOT POWER ON THE BOARD IF ANY POWER RAIL IS SHORTED TO GND. If any shorts are present, stop now and send email to support@dinigroup.com with the findings.
4. Plug power back in to all 3 power connectors and power on the board. Look for RED LEDs that indicate things are broken. Note that the clock LOL (loss of lock) LEDs will be on until linux finishes booting (about 30 seconds), and this is normal.
If any RED LEDs are on, stop now and send email to support@dinigroup.com with the Led reference designators noted. The board will not boot if any power fault LEDs are lit.
5. [OPTIONAL]: Use a multimeter to probe each testpoint checked in step 3, only this time check that the voltage is correct. BE VERY CAREFUL NOT TO SHORT ANYTHING WITH YOUR MULTIMETER PROBES. If any voltage rails do not match their nominal value, stop now and send email to support@dinigroup.com with the findings.
6. Connect to the Marvell serial port (J18) with the supplied adapter. Terminal settings are 19200bps, no parity, no flow control. Power cycle the board and watch for text on this terminal. If no text is seen stop now and send email to support@dinigroup.com with the findings.
7. If text is seen, wait a minute for linux to boot. Eventually it will print out something like:
DiniCmos Version: 2011.07.26
DN0247_DNV7F1A- 1201001
DiniCmos is now ready for host connections
Pressing enter will then give a linux prompt. If this stage is not reached, stop now and send email to support@dinigroup.com with the findings. Include all of the text that came out of the serial port that did not result in a successful linux boot.

7 ORDERING INFORMATION

7.1 Part Number

All orders should reference the product as “DNV7F1A”.

7.2 How to Order

Send email to sales@dinigroup.com for all sales inquiries. North American sales are handled directly by the main Dini Group office in La Jolla, CA. Dini Group also has sales representation all over the world. Include your geographic location in your sales inquiry so we may direct your request to the appropriate sales office. Alternately you may visit our sales page to find your regional rep: <http://www.dinigroup.com/new/sales.php>.

7.3 Board Options

The number, type, speed grade, and position of FPGAs must be specified. DRAM options must be requested specifically. Chassis requests must be discussed. Many daughtercards are available, see www.dinigroup.com for more information. Contact sales@dinigroup.com to discuss available board options or for recommendations for your application.

7.4 Compliance Information

7.4.1 EMISSIONS CERTIFICATIONS

We are willing to obtain an FCC, CE, or other certification for volume production. Inquire at sales@dinigroup.com.

7.4.2 ROHS

The board is ROHS compliant. We can obtain a certification if necessary for volume production.

7.4.3 PCI-SIG

The board passes our internal PCI Express compliance test. If you need the board added to the PCI-SIG integrator's list for some reason, this may be done upon special request.

8 Glossary

You can expect this manual, marketing materials, diagrams, emails and source code from Dini Group to contain a lot of shorthand and imprecise phraseology. To ensure consistency and precision, here is a list of terms and words that we use throughout our documentation:

Term	Meaning
.bit file Load file Configuration file Bitstream Hex file (rarely)	All of these words interchangeably refer to the file containing the data for the SRAM configuration bits for the FPGA. This file is generated by the Xilinx "bitgen" program.
BUFG BUFH BUFIO BUFR DCM IDDR IDELAY ISERDES MMCM ODDR ODELAY OSERDES	Each of these are primitive HDL modules available in the Virtex 6 FPGA. It is assumed that the reader is familiar with the behavior and use of any primitives mentioned in each section. Please see the Virtex 6 user guide for the behavior of these modules.
Core IP Verilog VHDL Design	These words refer interchangeably to HDL code.
DCI	Digitally controlled impedance. It refers to the ability of the FPGA to output optimally-terminated signals.
DIFF_TERM	Attribute that can be set on differential inputs to differentially end-terminate them.
DLL PLL MMCM	Delay-locked loop Phase-locked loop something something clock manager These words are (incorrectly) used interchangeably in this guide.
DDR	Usually means "double data rate", meaning that a signal's value is significant on both rising and falling edges of a clock. Sometimes this guide also uses "DDR" to refer to "DRAM", just to add confusion.
DRIVE attribute Drive strength	This refers to the ability of the FPGA to produce a variety of output impedances on its I/O.

FPGA Q Config FPGA NMB Bridge Spartan	These words are used interchangeably to refer to the controller FPGA on the DNV7F1A, which is not generally available for user designs.
GND Ground	This refers to both a net on the DNV7F1A, and to the absolute potential of that net at any given time. When an absolute voltage is given in this manual, it should be interpreted as a voltage relative to this net.
IOSTANDARD attribute	This is an attribute of the I/O buffer primitive.
ISE / Vivado Bitgen iMpact XST CoreGen MIG	These are software programs provided by Xilinx
LOC constraint	This is a constraint type that controls which physical pin on the FPGA device an I/O will be mapped to.
MB KB	Megabyte. Usually 1,000,000 bytes, but sometimes 1,048,576 bytes. Kilobyte. Usually 1,000 bytes, but sometimes 1,024 bytes.
Mbs Mb/s MTs MT/s	Mega(b)its divided by seconds. Mega(T)ransfers per second. These are used interchangeably with MHz, to avoid any possible confusion when dealing with DDR interfaces
MHz	1,000,000 divided by seconds.
Mux	Multiplexer
MV78200 Marvell Processor CPU MCU uP	The on-board processor manufactured by Marvell.
Net Signal Rail Plane	These interchangeably refer to a physical wire on the printed circuit board. A net on the circuit board is all points that are electrically shorted together.
NMB Main Bus	These interchangeably refer to the 40-signal bus between each FPGA and the configuration FPGA.
Bus	This word can mean any one of the following: An interface that is more than one signal wide. An interface that has more than two endpoints. An interface.
PCIE	PCI Express
RGMII SGMII	This is an interface specification used for Ethernet physical interface devices.
RocketIO GTP GTX MGT	In this guide, these all refer interchangeably to the 10Gbps+, high-speed serial transceivers available on Virtex-7 devices.

RS232 Serial Port	This could refer to one of the following: The serial port on a computer The connector on the DNV7F1A that is intended to connecting to a computer's serial port.
SATA	Serial ATA
SEAM Serial Daughtercard	These refer to three connectors attached to FPGAs A,C and D. These connectors carry high-speed serial signals from the Virtex-6 FPGAs. SEAM refers to the name of the Samtec brand connector series that were selected for this board.
SFP	Small form-factor pluggable module. This refers to the socket attached to FPGA F that is intended for Gigabit Ethernet.
SMA	These are little gold-colored screw-in coax connectors that are on the board in various places
DDR3 SDRAM DIMM	These all refer interchangeably to the DIMM connector attached to the user FPGA on the DNV7F1A
Source Synchronous	This refers to a clocking strategy that involves introducing a controlled amount of clock skew to devices with respect to each other.
SPI	I don't know what it stands for. Serial something interface maybe?? It is the protocol used for the serial Flash on this board.
SSTL LVDS LVCMOS HCSL HSTL CML LVTTTL LVDS_EXT	These are all signaling standards. They each require certain voltage levels and termination schemes.
System Synchronous	A clocking strategy where each device receives a low-skew clock. In this guide, I often use this word as shorthand for "using one of the provided global clock networks"
UCF	I used this as shorthand for "the set of place-and-route constraints that you input into ISE". It refers to the .ucf file extension of Xilinx ISE constraint files. It stands for "Universal Constraint File".
CC GC MRCC SRCC VREF VRN VRP	These are all special-purpose I/O pins on the Virtex 6 FPGA. For each section that mentions one of these pins, you are expected to know the purpose and usage of each.
XAPP UG	These refer to reference documents produced by Xilinx.