



Laboratory Equipment Manufacturer
www.mrclab.com



Refrigerated Incubator Shakers Operation Manual **LOM-150/150-2**



PLEASE READ THIS MANUAL CAREFULLY BEFORE OPERATION

3, Hagavish st. Israel 58817 Tel: 972 3 5595252, Fax: 972 3 5594529 mrc@mrclab.com

MRC.VER.01-3.14


Contents

● SPECIFICATIONS	p3
● PANEL.....	p4
● KEY DESCRIPTION.....	p4
● OPERATIONSDESCRIPTION.....	p4-p12
(1)Power.....	P4
(2)Temperature control.....	P5-P7
2.1 Temperature setting	p6
2.2 Parameter setting.....	p7-p11
● LOCK	
● Correct temperature tolerance(SHIF)	
● auto-calculating	
● Manual controlled	
(3)Speed control.....	p10
3.1 Shaking setting	p11-p12
● Error message and trouble shooting for temperature controller	p13-p14
● MAINTENANCE & CLEANING.....	p15
● WARRANTY CARD.....	p16

SPECIFICATIONS DESCRIPTION

SPECIFICATIONS	MODEL			
	LOM-90#9 \$!&		LCM-98#9 \$!&8	
TEMP. RANGE	0°C to 60°C		Ambient to 60°C	
TEMP. ACCURACY	±0.1°C			
TEMP. CONTROL	PID Controller			
TEMP. DISPLAY	LED Digital Display			
SHAKING STROKE	25.4mm (3-point gravity balance orbiting)			
SHELF	1 (adjustable)			
SHAKING SPEED	30 to300 r.p.m.		30 to150 r.p.m.	
TIMER	999H / 999M / 999S			
HEATER	900W			
PLATFORM	Single		Double	
COMPRESSOR	1/4hp		None	
POWER VOLTAGE	110 V,60 Hz /220V,50Hz			
INSIDE MATERIAL	Stainless steel			
OUTSIDE BODY	Powder painting			
PLATFORM DIMENSIONS	480x380mm			
CHAMBER DIMENSIONS	600x500x500 mm			
OVERALL DIMENSIONS	680x690x890 mm			
WEIGHT(Approx.)	98		90	

PANEL& KEY DESCRIPTION



1. Main power switch: turn on/off main power

Cooling switch: turn on to start compressor (No this function)

Shaking speed switch: turn on to start shaking

Lamp switch: turn on / off the lamp

2. Temp. Control: display setting and actual temperature

3. Speed control: display setting and actual speed

OPERATIONS DESCRIPTION

After making sure voltage, please plug in 110V/ 220V socket.

(1.) Power:

POWER on, setting temperature

SPEED on, setting speed of shaking

(2.) Temperature control

- 1: Key for Setting/selecting: to select parameter for viewing or adjusting**
- 2: Key for decreasing gradually: to decrease parameter.**
- 3: Key for increasing gradually: to increase parameter**
- 4: return/ confirm key:**
 - a. have monitor returned to PV value, display present measuring value and setting value**
 - b. clear latch alarm (when alarm condition has been eliminated)**
 - c. exit manual control mode, auto-calculating mode, and calibrating mode**
 - d. clear error message or auto-calculating error message**
 - e. restart constant temperature timer**
 - f. Display output percentage on failure mode, with manual control.**
- 5 : Display actual temperature, parameter and error message**
- 6 : Display setting value, parameter and control output value**
- Z: auto-calculating LED (See the page 8)**

8: Manual controlled LED (See the page 8)

9: Over Low LED (No this function)

10: Over heat LED (See the page 9)

11: Heating LED (See the page 9)

12: centigrade LED: LED on: means temperature is centigrade

13: Fahrenheit LED: LED on: means temperature is Fahrenheit

2.1 Setting temperature

1. PV displays the actual temperature in chamber.



2. SV displays the setting temperature

Press  to increase temperature gradually.

Press  to decrease temperature gradually.

3. Setting temperature upon what you need.

2.2 Setting parameter

1. Press select key for 5 seconds to display , then release select key and re-press select key to modify temperature parameter.
2. SHIF setting is completed, and then press  to make sure.

Note When LOCK =NONE and no parameter is locked, user can change it freely.

1. LOCK=SET, all functions/parameters are locked.
2. LOCK=USER, all parameters are locked except S/P.
3. LOCK=ALL, all parameters are locked to prevent from being changed

- **Modify inaccurate temperature value(SHIF)**

In normal condition, set SHIF to “0”, sometimes PV value is inaccurate because of detecting from different point; at this time please modify it by SHIF value.

(When SHIF=0, then PV=100°C

If SHIF setting = 20.00, then PV= 120°C

If SHIF setting = -10.0 then PV= 90°C

For Example:


PV(actual temperature) is 100°C and SV(temperature setting) is also 100°C,

If Thermometer appears 120 °C or 90°C

Then set SHIF= 20 or -10


- **Auto-calculating LED:**

Instrument has been set the best PID value; we suggest executing auto-calculating when temperature is unstable.

Enter auto-calculating: press selecting key until  is displayed then release selecting key. Press selecting key again for 5 seconds to enter auto-calculating(* all parameters setting must be correct before executing auto-calculating and must be LOCK = NONE.)

- **Manual controlled LED**

enter manual control mode for testing or system failure.

Enter manual control mode: Keep pressing selecting key until  is displayed then release; pressing selecting key about 5 seconds to enter manual control mode.


( means OP1 output percentage,  means OP2 output percentage)

- Over Low LED

LED on: means temperature OverLow protection is on: press select key, PV displays SP3, SV displays default Over Low protected value: -5 °C

- Over Heat LED

LED on: means overheat protection is on: press select key, PV displays SP2, SV displays default overheat temperature protected value: +5 °C

For example: the setting temperature is 100 °C, and default overheat protected value is +5 °C; when rising to 105 °C  LED will be on and stop heating.

- Heating LED

LED on: means heating now (*If the machine includes timer, chamber temperature start dropping after time out; at this time there is no heating though heating LED is on)

(3.) Speed control of shaking

PV: Display actual RPM (revolutions per minute)

SV: Display setting RPM or TIME



Hour indicator Led



Minute indicator Led



Second indicator Led

1. **P/S** (Power on/off): Press **P/S** to suspend working, or
Press **P/S** for 5 seconds to power on/off.

2. **▲** Increase key: Press it to increase parameter value.

3. **▼** Decrease key: Press it to decrease parameter value.

4. **S**: Set RPM (revolutions per minute) / shift-key:

At set timing mode:

S: Parameter Key: Press for 5 seconds to enter parameter key

LO- set lowest speed(default value: 20RPM)

HR- set highest value(default value: 300RPM)

ARR: adjust inaccuracy

5. **T**: Set timing (Sound alarm 10 times when time up).

T: **LOCK**(Press for 5 seconds to enter “LOCK”)

.....**SET – SET PARAMETER TO LOCK**(default)

ALL – SET “LOCK ALL KEYS”

..... (At LOCK mode, no key is operative. Only displays
LOCK .)

NOO: UNLOCK

OPERATIONS DESCRIPTION

1. Press [P/S] key for 5 seconds to power on, PV displays actual speed and SV displays setting speed.

2. Set Shaking speed

Press ▲ to increase gradually

Press ▼ to decrease gradually

Set RPM (revolutions per minute)

3. Timer setting(At suspend mode):

Press T first to set timing, indicator Led on

Then press ▲, ▼ to select hour, minute, second

Press T, SV flash

Press ▲ to increase gradually

Press ▼ to decrease gradually

After setting, press T to make sure, then press P/S to start to count down.

Press S to display RPM

Press T to display time

4. default slow-start/stop, rpm range 10~250










5. default rpm: 100

6. default time: nil

TROUBLESHOOTING

SITUATION	CAUSE	TROUBLESHOOTING
1.LED is off when power on	a. NO power input b. Power plug is loose c. Abnormal voltage input d. Fuse blowout e. Power cord disconnection or bad connection	a. Check power supply system b. Plug in firmly or replace the socket c. Check power supply and stop using temporarily d. Check power voltage and reset e. Replace switch f. Replace power cord
2.After temperature setting,Heating LED=(OUT1) is off	a. Chamber(bath)inside actual temperature is higher than setting temperature b. PT platinum breakdown c. Thermometer output signal···nil	a. Waiting for temperature dropping or cooling b. Replace c. Ask for repair
3.Heating LED is on but temperature can not rise	a. Heater disconnection b. Bad heater circuit c. Bad control circuit d. High temperature protection-setting, locking e. Water level of floating ball is too low(water bath)	a. Ask for repair b. Ask for repair c. Ask for repair d. Reset e. Water supply
4.Temperature keep rising and out of control	a. Temperature is out of control b. Heater circuit is out of control c. P.I.D.value is not correct d. S.S.R. breakdown	a. Ask for repair b. Ask for repair c. Re-calculating automatically d. Ask for repair
5.Temperature can not drop down	a. cold media run out b. compressor breakdown	a. Ask to repair b. Ask to repair
6.temperature tolerance is large	a. Temperature is unstable b. P.T.D.value is not set or not correct c. Temperature setting is too close to room temperature d. circulating fan or motor cannot work e. PT platinum bad connection f. Air circulation inside is blocked	a. Suspend for 30 minute b. Re-calculating AT automatically c. Add cooling system or dropping ambient temperature d. Ask for repair e. Ask for repair f. Improve articles placement

Error message and trouble shooting for temperature controller

error code	display symbol	error description	trouble shooting
4		Parameter setting conflict, for example: When OUT2=COOL, user cannot select DIRT,PB and TI can not be "0"	If user selects OUT2=COOL to control cool/heat, then PB and TI can not be "0" and OUT1 should select REVR.
10		Function code error during signal communication	Use correct function code
11		Communication error: register address out of range	Do not issue an over-range register address to the slave
14		Try to change the "read only data" or to change the "protected data value" during signal communication	Avoid changing "read only data" or "protected data value"
15		Data address is overflowed during signal communication	Avoid input data overflowed
26		Auto calculating failure	<ol style="list-style-type: none"> 1. Try again 2. Don't change the setting value during auto calculating 3. PB/TI can not be "0". 4. Press "R"key 5. Give up auto calculating
29		Permanent storage EEPROM fault	send it back to maker for repair
30		Cold junction compensation for thermocouple malfunction	send it back to maker for repair
39		Input sensor break, or input current below 1mA if 4-20mA is selected, or input voltage below 0.25V if 1-5V is selected	send it back to maker for repair

MAINTENANCE & CLEANING

1. Please follow specification to use the specified socket.
Do not use old or loosened socket, and not use same socket with other machines. Instead of general extended line, please use single circuit and specified extended line to avoid overload, and to ensure operating smoothly and service life. Please make sure voltage before use; we are not responsible for any damage caused by insufficient voltage.
2. Please install it on smooth floor to avoid shaking and noise.
3. When moving, please do not tilt over angle of 45 degree, cooling performance will be affected if over 45 degree.
If it has been tilted over 45 degree please keep still for 2 -- 4 hours before switching on cooling system to prevent damage of compressor
4. Please switch off main power and open door for 2~3 days to dry inside and parts, and to extend its service life

WARRANTY CARD

Product Name	
Model Number	
Serial Number	
Date of purchase	
Warranty period	
Company Stamp	 (Invalid without company stamp)

Condition of warranty

- 1. One-year warranty from the date of purchase.**
- 2. In case damage is under normal condition of use within warranty, we will repair at no charge.**
- 3. In case any manufacturing defect is found, it will be replaced with a new one free of charge.**
- 4. Damage caused by card lost, human negligence, misuse or acts of God during warranty, we will repair at a reasonable charge.**
- 5. This warranty card is invalid without company stamp, and will not be re-issued in case it is lost.**