


Product may vary slightly from what is illustrated. / Este producto puede variar ligeramente del que aparece ilustrado. / Le produit peut différer légèrement de celui illustré.



† Consumer replaceable / Reemplazable por el consumidor / Remplaçable par le consommateur

How to Use

This product is for household use only.

- Before first use unpack the product and remove packing material. Handle the Chopping Blade and Slice/Shred disc carefully; they are very sharp.
- Wash all parts except the Base. Be sure to read this Use & Care Book, paying special attention to the sections on "How to Use" and "Care and Cleaning" to learn the correct methods for taking the unit apart and cleaning.

Note: Do not attempt to chop ice in this food processor; it will damage the Bowl and dull the Chopping Blade. This unit will not whip cream, beat egg whites to a desirable volume, grind coffee beans or spices with a high oil content, or slice or shred hard-cooked eggs, marshmallows, or soft cheeses.

Controls

On — When this button is pressed, the unit will run continuously until the Off button is pressed. Use the On position for longer processing tasks, such as making dressings, smooth spreads, peanut butter, dips, etc.

Off — The Processor should always be left in the Off position when the unit is not in use.

Pulse — The Pulse position must be pressed and held for the unit to operate. When it is released, the unit will stop. Use Pulse for short processing tasks, such as chopping nuts, raw meats, or vegetables. This lets you check processed results and control the fineness.

IMPORTANT: For your protection this unit has an Interlock System. The processor won't operate unless the Bowl is properly locked onto the Base (see illustration on the Base). The Tab on the Cover must be correctly locked into the slot on the Base so that the lock (†) on the Cover lines up with the Handle. Be sure the Cover is turned fully into the slot toward LOCK until you hear it click into place. Do not attempt to operate the unit without the Bowl and Cover correctly locked in place. Be sure the Base is on a flat, dry, clean surface before you begin processing.

To Slice Or Shred

1. Place the Bowl over the Center Post in the Base with the handle at the left. Turn the bowl towards the Base until it drops down into place. Snap the Bowl in towards the Base and be sure the Locking Tab locks into place (A).

2. To process into a serving/mixing bowl using the Continuous Flow Food Chute (FP1400 Only), place the Disc Stem onto the Center Post in the Bowl and slip the Discharge Disc onto the Stem.

Note: Be sure you have the appropriate side of the Discharge Disc up for leafy or other vegetables. The Tabs on the Disc should be up for leafy vegetables. Grasp the Slice/Shred Disc by the Hub or very carefully by its edge with the desired side (Slice or Shred) up and push it down onto the Disc Stem over the Discharge Disc. Remember to remove the Shield from the Food Chute/Cover. To process directly into the Bowl, follow the same procedure only do not use the Discharge Disc and be sure the Shield is pushed down into place. Clip the Food Fingers onto the Food Chute to keep food from tilting and help get even slices.

For models without the Continuous Flow Food Chute (FP1300),

place the Disc Stem onto the Center Post in the Bowl, then carefully grasp the Slice/Shred Disc by its Hub with the desired side (Slice or Shred) up and push it down onto the Disc Stem.

3. Place the Food Chute/Cover onto the Bowl so that its Tab is facing the Base. Twist the Food Chute/Cover in toward the Base to LOCK until you hear it click into place.

4. Plug the cord into an electrical outlet.

5. Use the Food Guide to help you prepare food for slice/shred processing. Fill the Food Chute with food and position the Pusher over the food.

6. Select the Hi or Lo Speed, then press down lightly but firmly on the Food Pusher while pressing the desired Pulse or On Control.

Note: Let the Processor do the work. Heavy pressure will not speed up operation. Do not use the Processor continuously for more than 3 minutes at a time.

7. After processing food, press the control to Off or release the Pulse Control. Allow the Disc to stop rotating. Twist the Food Chute/Cover toward UNLOCK to remove the Cover.

8. Carefully pull the Slice/Shred Disc (and in the case of the FP1400, the Discharge Disc) off the Stem, remove the Stem, unlock the Bowl by turning it away from its Base, and lift the Bowl off.

To Use The Chopping Blade

The Chopping Blade speeds up many everyday tasks and is designed to chop, crumb, grind, mince and mix quickly.

1. Place the Bowl over the Center Post in the Base with the handle at the left. Turn the Bowl towards the Base until it drops down into place. Snap the Bowl in towards the base and be sure the Locking Tab locks into place (A).

2. Grasp the Chopping Blade by its center shaft and slide it down onto the Center Post. (B)

3. Place the Food Chute/Cover onto the Bowl so that its Tab is facing the Base. Twist the Food Chute/Cover in toward the Base to LOCK until you hear it click into place.

4. Plug the cord into an electrical outlet.

5. Use the Food Guide to help you prepare food for chopping/mincing/mixing and crumbing. Fill the Bowl with food.

Como usar

Este producto es para uso doméstico solamente.

- Antes de utilizar por primera vez, desempaque el producto y retire el material de embalaje manejando con prudencia la cuchilla de picar y el disco de rebanar/desmenuzar; dichas piezas tienen filo agudo.
- Lave todas las partes con excepción de la base. Asegúrese de leer a cabalidad este manual de uso y cuidado prestando especial atención a las secciones "Como usar" y "Cuidado y limpieza" para que aprenda los métodos correctos y necesarios para desarmar la unidad y como limpiarla.

Nota: No trate de picar hielo en este procesador de alimentos; dañará el motor y hará que pierda el filo la cuchilla para picar. Esta unidad no bate crema, no bate las claras de huevo a punto de nieve, no muela café ni especies con alto contenido de aceite, no rebana huevos cocidos, dulces de malvavisco, ni quesos suaves.

Controles

- "On" (encendido) — Cuando se oprime este botón, la unidad funciona continuamente hasta oprimirse el botón "Off" (apagado). Se recomienda la posición "On" para procesar aderezos para ensaladas, pastas para untar, mantequilla de maní, dips, etc.
- "Off" (apagado) — La unidad debe de permanecer en la posición "Off" siempre que no esté en uso.

Pulse — La posición de pulso debe de oprimirse y sostenerse para que funcione la unidad. Al soltarse, la unidad deja de funcionar. Use esta posición para las funciones cortas tales como, el picar nueces, carne picada, o vegetales. Esto le permite supervisar el resultado de lo que está procesando y así controlar la textura.

IMPORTANTE: Como medida de protección, esta unidad cuenta con un mecanismo de cierre de seguridad. El procesador no funciona a menos que el recipiente esté seguro en la base (consulte la ilustración referente a la base). La guía en la cubierta debe estar colocada apropiadamente en la ranura de la base para que el seguro de sierra (†) ilustrado en la CUBIERTA se alinee con el asa. Por favor no trate de operar la unidad sin antes haber colocado el recipiente y la tapa apropiadamente. Antes de usar la unidad, asegúrese de colocarla sobre una superficie plana, seca y limpia.

Rebanar o desmenuzar

- Coloque el recipiente sobre la guía del centro de la base con el asa hacia la izquierda. Gire el recipiente sobre la base hasta encagar. Oprima el recipiente para que entre en la base y asegúrese que la guía del seguro de cierre quede ajustada (A).
- Para procesar alimentos dentro de otro recipiente o tazón, use el conducto de flujo continuo (Solamente en el modelo FP1400). Coloque el vástago del disco en la guía central de la base y deseche el disco separador sobre el vástago. **Nota:** Asegúrese de colocar hacia arriba el lado apropiado del disco separador cuando procese vegetales de hojas o aquellos en general. Las guías del disco separador deben de estar hacia arriba para los vegetales de hoja. Sujete el disco para rebanar o desmenuzar por la guía o con mucho cuidado por el borde con el lado que desea usar hacia arriba y deslicelo hacia abajo contra el vástago. Para rebanar o desmenuzar zanahorias, zucchini, papas, etc.) para obtener rebanadas completas, y permitir un flujo continuo.
- Both the FP1300 and FP1400 are designed to let you use the Disc in combination with the Chopping Blade. Just position the Chopping Blade in the Bowl and press the Slice/Shred Disc with the desired side (Slice or Shred) down onto the Hub of the Chopping Blade. Using the 2 parts together can eliminate having to pre-cut foods into cubes — perfect when shredding and chopping cheese such as parmesan to get a finer grinded result.
- Clogging in the Continuous Flow Side Chute: (FP1400 Only)**
Occasionally sliced or shredded food may clog in the Side Chute. Follow these tips to avoid clogging:
 - Be sure the Shield is removed entirely when using the Continuous Flow Side Chute. It is normal for some pieces to fall into the processor bowl.
 - Use a large serving bowl to help catch sputter from the Side Chute and turn the bowl as it fills to prevent food buildup in the exit chute.
 - Be sure to use the correct side of the Discharge Disc — for leafy vegetables (lettuce, cabbage, etc.) and shredding (carrots, zucchini, potatoes, etc.), use the tall Tab side up; for slicing other foods, use the short Tab side up.
 - Use the Food Fingers with the Side Chute to help steady food, keep slices whole, and allow for continuous feeding.
 - Use Lo speed for foods that have clogged in the past. Some foods, like carrots, are prone to clogging and you may get better results by simply processing them directly into the food processor bowl.
 - If clogging does occur, never stick anything up the chute to try to dislodge the food. Shut off and unplug the machine, then unscrew the Cover/Food Chute to clear the blockage.

IMPORTANT: For your protection this unit has an Interlock System. The processor won't operate unless the Bowl is properly locked onto the Base (see illustration on the Base). The Tab on the Cover must be correctly locked into the slot on the Base so that the lock (†) on the Cover lines up with the Handle. Be sure the Cover is turned fully into the slot toward LOCK until you hear it click into place. Do not attempt to operate the unit without the Bowl and Cover correctly locked in place. Be sure the Base is on a flat, dry, clean surface before you begin processing.

Para los modelos sin la característica del conducto de flujo continuo (FP1300),

coloque el vástago del disco en la guía dentro del recipiente y sujetelo el disco para rebanar y desmenuzar por la guía o con mucho cuidado por el borde con el lado que desea usar hacia arriba y deslicelo hacia abajo en el vástago del disco.

Nota: Be sure you have the appropriate side of the Discharge Disc up for leafy or other vegetables. The Tabs on the Disc should be up for leafy vegetables. Grasp the Slice/Shred Disc by the Hub or very

carefully by its edge with the desired side (Slice or Shred) up and push it down onto the Disc Stem over the Discharge Disc. Remember to remove the Shield from the Food Chute/Cover. To process directly into the Bowl, follow the same procedure only do not use the Discharge Disc and be sure the Shield is pushed down into place. Clip the Food Fingers onto the Food Chute to keep food from tilting and help get even slices.

Care and Cleaning

This product contains no user serviceable parts. Refer service to qualified service personnel.

Note: Do not attempt to sharpen the cutting edges of the Chopping Blade or the Reversible Disc. They are permanently sharpened at the factory and will be ruined by attempted sharpening.

Cleaning

1. Before cleaning, be sure the unit is Off and the cord is unplugged.

2. Whenever possible, rinse parts immediately after processing for easy cleanup.

3. Wipe the Base and feet with a damp cloth and dry thoroughly. Stubborn spots can be removed by rubbing with a damp cloth and a mild, non-abrasive cleaner. Do not immerse the Base in liquid.

4. All removable parts can be washed by hand or in a dishwasher. To remove the Food Fingers, simply pull up on the clip portion.

If washing by hand, wash in sudsy water, rinse, and dry thoroughly.

5. If necessary, use a small nylon brush blade to thoroughly clean the Bowl and Food Chute/Cover; this type of brush will also help prevent cutting yourself on the Chopping Blade and Slice/Shred Disc.

If washing in a dishwasher, place removable parts on the top rack only — not in or near the utensil basket.

6. Some staining of parts may occur. Use a paste of 2 tablespoons baking soda/1 tablespoon water — apply to stains and let stand overnight. Rinse and dry.

7. Do not use rough scouring pads or cleansers on any plastic or metal parts.

8. Do not fill the Bowl with boiling water or place any of the parts in boiling water. Some foods, such as carrots, may temporarily stain the Bowl. To remove stains, make a paste of 1 tablespoon baking soda and two tablespoons warm water. Apply the paste to the stains and rub with a cloth. Rinse in sudsy water and dry.

9. Do not allow the Chopping Blade, Slice/Shred Disc or Discharge Disc (FP1400 Only) to soak in water for long periods of time.

10. Use the Food Guide to help you prepare food for slice/shred processing. Fill the Bowl with food and position the Pusher over the food.

11. Select the Hi or Lo Speed, then press down lightly but firmly on the Food Pusher while pressing the desired Pulse or On Control.

12. After processing food, press the control to Off or release the Pulse Control. Allow the Disc to stop rotating. Twist the Food Chute/Cover toward UNLOCK to remove the Cover.

13. Carefully pull the Slice/Shred Disc (and in the case of the FP1400, the Discharge Disc) off the Stem, remove the Stem, unlock the Bowl by turning it away from its Base, and lift the Bowl off.


14. Place the Bowl over the Center Post in the Base with the handle at the left. Turn the Bowl towards the Base until it drops down into place. Snap the Bowl in towards the base and be sure the Locking Tab locks into place (A).

15. Grasp the Chopping Blade by its center shaft and slide it down onto the Center Post. (B)

16. Place the Food Chute/Cover onto the Bowl so that its Tab is facing the Base. Twist the Food Chute/Cover in toward the Base to LOCK until you hear it click into place.

17. Plug the cord into an electrical outlet.

18. Use the Food Guide to help you prepare food for chopping/mincing/mixing and crumbing. Fill the Bowl with food.



7. Despues de procesar alimentos, oprima el control "Off" (apagado) o suelte el botón de pulso. Permita que la cuchilla pare por completo. Gire la tapa hacia la posición UNLOCK para retirarla.

8. Sujete la cuchilla con el vástago y retírela. Desenganche el recipiente girándolo en dirección contraria a la base para poder aclararla. Vacie los alimentos procesados.

Consejos para procesar alimentos:

Líquidos

- Los líquidos calientes (no hirviendo) y los alimentos calientes pueden procesarse en el recipiente.
- Asegúrese de procesar pocas cantidades de líquido — de 3 a menos tazas a la vez. Las cantidades más grandes pueden derramarse.

Tamaño de los alimentos, preparación, e introducción

- Cuando se usan diferentes alimentos para una misma receta, procese los ingredientes secos primero y los húmedos después. Esto reduce la cantidad de veces que se debe de lavar y secar el recipiente.
- **Con el modelo FP1400,** se puede rebanar o desmenuzar en forma continua directamente dentro de otro recipiente o tazón para servir usando el conducto de flujo continuo con el disco separador. Esto resulta práctico especialmente cuando se está preparando una gran cantidad de ensalada de repollo ya que no hay necesidad de parar la unidad para vaciar las 8 tazas del recipiente. También le permite mezclar los demás ingredientes (mayonesa, vinagre, condimentos) directamente dentro del recipiente en el que va a servir la comida.

Ambos modelos el FP1300 y el FP1400 han sido diseñados para permitirle hacer uso del disco en combinación con la cuchilla para picar. Solo tiene que colocar la cuchilla dentro del recipiente y oprimir el disco con el lado deseado (rebanar o desmenuzar) hacia abajo deslizándolo sobre el vástago de la cuchilla. El uso de estas dos partes juntas puede eliminar el tener que partir de antemano los alimentos en cubos — perfecto para desmenuzar y picar queso tal como el Parmesano cuando se desee un resultado de textura más fina.

Ostrucción en el conducto lateral de flujo continuo: (Modelo FP1400)
Ocasionalmente los alimentos rebanados o desmenuzados pueden obstruir el conducto lateral. A fin de que esto no suceda, por favor siga los siguientes consejos:

- Retírese por completo el protector cuando se use el conducto lateral de flujo continuo