

## 【Precautions】

The scale should always be used in an environment, which is free from excessive air currents, corrosives, vibration, and temperature or humidity extremes. These factors will affect displayed weight readings. Before starting the operation of the scale, please read the following instructions below to operate the scale properly.

### **DO NOT** use the scale:

- next to open windows or doors causing drafts or rapid temperature changes.
- near air conditioning or heat vents.
- near vibrating, rotating or reciprocating equipment.
- near magnetic fields or equipment that generates magnetic fields.
- on a rough work surface

### **1. Loosen the delivery protection screw ( this screw can't be removed )**

Please find the delivery protection screw in the bottom of the scale. Loose it according to the instruction sticker next to it

- **Before use the scale** Loose the screw counter-clockwise to the end
- **Before move the scale** Tighten the screw clockwise to the end

### **2. Install the weighing pan**

Put on the weighing pan to complete the installation.


### **3. Leveling the scale**

The scale is equipped with four level adjusters. Adjust the scale to a level position with four level adjusters until the bubble appears in the center circle of the level indicator.

### **4. Recharging battery**

Recharging battery when the battery sign  starts blinking. When battery is being charged, the LED indicated by the word CHARGE on the display panel will be RED, the LED will become GREEN when the indicator has been charged to full capacity (charging time is about 8 hours).


## 【Function Keys】



- ① **WEIGHT** : Display weight value.
- ② **UNIT WEIGHT** : Display unit weight value.
- ③ **TOTAL COUNT (PCS)** : Display total pieces of the weight.
- ④  : Tare weight value is set.
- ⑤  : The weight return to zero point.
- ⑥ **PRESET TARE** : Tare weight is set.
- ⑦  : Sampler is insufficient.
- ⑧  : Under accumulation.



- ⑨  : The unit weight is lower than 4/5 e.
- ⑩  : Battery is low.
- ⑪ **CHARGE** : Red LED light is on while the battery is Charging;  
Green LED light is on when Charging is completed.
- ⑫ **ACAI** : ACAI is enabled.
- ⑬ **STABLE** : The weight value is stable.
- ⑭ **NET** : Net weight.

### 【 Keyboard 】






- 1**    : **Number & letter** keys.  as space key when edit label.
- 2**  : To key in **decimal point** / to enter **function** setup.
- 3**  : To reset the weight to **zero**.
- 4**  : To **clear** the key-in.
- 5**  : To switch **Gross / Net** weight.
- 6**  : Input **Unit Weight**.
- 7**  : To **sampling**.
- 8**  : To **Accumulate** / To enter label editing mode / To next parameter.
- 9**  : To **delete the accumulated data** / to display year, date, time / To previous parameter.
- 10**  : To **call up an accumulated data** / to access the accumulated data.
- 11**  : To **select** / to set the **Hi** value of weight or piece / To change to next content of parameter.
- 12**  : To **select** / to set the **Lo** value of weight or piece / To change to previous content of parameter.
- 13**  : **Tare**.
- 14**  : To **give up** any setting and **return to normal weighing status**.
- 15**  : To set/call up **unit weight ID** ; To **enable / switch on** relay output function under Hi/Lo setting.
- 16**  : To **print** ; To **disable / switch off** relay output function under Hi/Lo setting.


## 【Zero-Point】

	<p>(1)The scales zero point is shown as left diagram with <math>\rightarrow 0 \leftarrow</math>.</p>
	<p>(2)Press  key if you see the display shown as left without <math>\rightarrow 0 \leftarrow</math>, but  appears.</p>
	<p>(3)Here you see the zero point <math>\rightarrow 0 \leftarrow</math> again.</p> <p>PS: The range of the zero point is <math>\pm 2\%</math> of the capacity. For example, the zero rang of 30K is 600g</p>

## 【Tare】

	<p>(1) Put a container weighing 0.100 kg on the pan.</p> <p>(2) Press  key when  appears.</p>
	<p>(3) TARE' symbol  appears and the arrow points to the word 'NET'. The net weight is 0.000 kg</p>
	<p>(4) Put a 3kg weight master into the container. The net weight is 3.000 kg.</p>
	<p>(5) Press  key</p>
	<p>(6) The arrow points to the symbol 'NET' disappears. The gross weight is 3.100 kg</p> <p>(7) Press  again and the display is showing net weight again.</p>
	<p>(8) Remove all objects from the pan. When  and  appears, press  to cancel the tare .</p>
	

## 【Pre- Tare】






	<p>(1) For example the container is weighing 123g , then press <b>1</b> <b>2</b> <b>3</b>.</p>
	<p>(2) The 123g are blinking in the unit weight display..</p>
	<p>(3) Press <b>TARE</b> key</p>
	<p>(4) The arrows point the 'NET' &amp; 'PRESET TARE' symbol <b>T</b> in the weight display.</p>

## 【Counting Method 1— Key In Unit Weight】



	<p>(1) For example the unit weight is 1.2 g.</p> <p>Press   </p>
	<p>(2) The unit weight display is showing 1.2 g and is blinking.</p>
	<p>(3) Press  key</p>
	<p>(4) The display of the unit weigh is 1.2000g</p>
	<p>(5) You can start to count.</p>
	<p>PS: If the unit weight is less than 0.8e, Then the display is shown as left. You can operate the counting func. But the accuracy is low. Take 30kg x1g, 0.8e=0.8g</p>

Note: When the scale have a unit weight in the unit weight display, and if you turn off the scale it will memorize the unit weight. This means that when you turn on the scale again the previously unit weight will again appear in the unit weight display.

## 【Counting Method 2—Sampling】

		<p>(1) Put container on the pan and press  key., put part of the sample about 300g into the container.</p>
		<p>(2) For example the quantity is 20 pieces Press  </p>
		<p>(3) The number 20 is blinking. In the unit weight display.</p>
		<p>(4) Press  key.</p>
		<p>(5) The scale will calculate the unit weight.</p>
		<p>(6) You get a unit weight of 15.090g in this example</p>
		<p>(7) After you get the unit weight, you can start counting the parts in bulk or big quantities.</p>

## 【 Manual Accumulation 】



	<p>(1) Put container on the pan and press  key.</p> <p>Put objects into the container and start counting,</p>
	<p>(2) Wait for the  symbol to appear.</p>
	<p>(3) Press  key</p>
	<p>(4)The display shows ACC 1 and is blinking .</p> <p>This is the first accumulation.</p>
	<p>(5)The display will show as left chart when there get accumulated the  above  will on.</p>

PS:

When the weight is less than 20e, it will go into accumulation setting mode.




Take 30kg x1g, 20e=20g

## 【Manual Print】




	<p>(1) Put container on the pan and press  key.</p> <p>Put objects into the container.</p>
	<p>(2) Wait for the  symbol to appear.</p>
	<p>(3) Press  key to print.</p>
<p>PS: When the weight is less than 20e, it will go into print setting mode. Take 30kg x1g, 20e=20g</p>	

## 【Set / Choose A Print Form】



EZ-2P/BP-443D set 0~99 forms; SH-24 set 0~15 forms

 <p>The scale display shows 'WEIGHT' and 'UNIT WEIGHT' at the top. The weight display shows '0.0000' and the unit weight display shows '0'. Below that is 'TOTAL COUNT(PCS)' with '0'. To the right is a keypad with a hand pointing to the print key (a circle with a diagonal line and 'Prt').</p>	<p>(1) Under normal weighing mode press  when the pan is empty. (If there is object on the pan and you press  then it will print out automatically)</p>
 <p>The scale display shows 'WEIGHT' and 'UNIT WEIGHT' at the top. The weight display shows '0.0000' and the unit weight display shows '0'. Below that is 'TOTAL COUNT(PCS)' with 'Prt-00'.</p>	<p>(2)  is blinking in the total count display</p>
 <p>A keypad with a hand pointing to the number '9' key.</p>	<p>(3) For example if you wish to print the 9th form, press  and,</p>
 <p>The scale display shows 'WEIGHT' and 'UNIT WEIGHT' at the top. The weight display shows '0.0000' and the unit weight display shows '0'. Below that is 'TOTAL COUNT(PCS)' with 'Prt-9'.</p>	<p>(4) You will see Prt- 9 blinking in the total count display (press  if you want to choose another print form and repeat step (3))</p>
 <p>A keypad with a hand pointing to the print key (a circle with a diagonal line and 'Prt').</p>	<p>(5) Press  key to complete the setting and return to normal weighing mode.</p>




## 【Set Print Mode】

	<p>(1) Under normal weighing mode press  when the pan is empty. (If there is object on the pan and you press  then it will print out automatically)</p>
	<p>(2)  is blinking in the total count display</p>
	<p>(3) Press  key</p>
	<p>(4) The unit weight display will be blinking.</p>
	<p>(5) Press  or  to choose print mode</p> <ul style="list-style-type: none"> <li> Manual</li> <li> Print after  mark appears</li> <li> Print when quantity is okay (with check function)</li> <li> Print when weight is okay (with check function)</li> <li> Print continuously</li> <li> No action</li> </ul>
	<p>(6) Press  to save the print mode and return to normal weighing mode.</p>




## 【 Select The Printer Model 】

	<p>(1) Under normal weighing mode keep pressing  for about three seconds.</p>
	<p>(2) You will enter into parameter settings.</p>
	<p>(3) Press  or  to switch between the parameters.</p>
	<p>(4) Repeat step (3) until P-5 appear.</p>
	<p>(5) Press  or  to choose printer model.</p>
	<p>(6) Press  or  to save and go to next parameter setting or press  to save the setting and return to normal weighing mode.</p>

## 【 Set RS-232 Baud Rate 】


	<p>(1) Under normal weighing mode keep pressing  for about three seconds.</p>
	<p>(2) You will enter into parameter settings..</p>
	<p>(3) Press  or  to switch between the parameters.</p>
	<p>(4) Repeat step (3) until P-6 appear.</p>
	<p>(5) Press  or  to choose baud rate 19200/ 9600/4800/2400</p>
	<p>(6) Press  or  to save and go to next parameter setting or press  to save the setting and return to normal weighing mode.</p>

## 【RS-232 Data Format】

	<p>(1) Under normal weighing mode keep pressing  for about three seconds.</p>
	<p>(2) You will enter into parameter settings.</p>
	<p>(3) Press  or  to switch between the parameters.</p>
	<p>(4) Repeat step 3 until P-7 appear.</p>
	<p>(5) Press  or  to choose Data Format n,7,1/o,7,1/e,7,1/n,8,1/o,8,1/e,8,1</p>
	<p>(6) Press  or  to save and go to next parameter setting or press  to save the setting and return to normal weighing mode.</p>

## 【Samples Of BP-443D / EZ-2P Print Forms】

10 print forms is preset by manufacturer



### Note :

- (1) Please contact your supplier/-dealer for additional EZ-2P & BP-443D print forms.
- (2) A memory card has to be installed in EZ-2P. (BP-443D memory card is standard)
- (3) A RTC-device has to be installed in EZ-2P if you need to print time/-date. (BP-443D RTC is standard)
- (4) The print forms are installed into the printers through PC. Please email us and we will make the requested print form for you.

**【 Sample Of SH-24 Print Forms 】** ..... 16 forms

**Prt08-15 print forms with unit weight    Prt08-15 print forms with tare weight**

<b>Prt-00</b>	0.379kg 3.7930g 100PCS
<b>Prt-01</b>	2002/01/01 00:09:23 0.379kg 3.7930g 100PCS
<b>Prt-02</b>	ABC COMPANY 0918-123456 0.379kg 3.7930g 100PCS
<b>Prt-03</b>	2002/01/01 00:09:23 ABC COMPANY 0918-123456 0.379kg 3.7930g 100PCS
<b>Prt-04</b>	#1 0.379kg 3.7930g 100PCS
<b>Prt-05</b>	2002/01/01 00:09:23 #1 0.379kg 3.7930g 100PCS
<b>Prt-06</b>	ABC COMPANY 0918-123456 #1 0.379kg 3.7930g 100PCS
<b>Prt-07</b>	2002/01/01 00:09:23 ABC COMPANY 0918-123456 #1 0.379kg 3.7930g 100PCS

<b>Prt-08</b>	N.W: 0.379 kg U.W: 3.7930 g TOTAL: 100 PCS
<b>Prt-09</b>	2002/01/01 00:09:23 N.W: 0.379 kg U.W: 3.7930 g TOTAL: 100 PCS
<b>Prt-10</b>	ABC COMPANY 0918-123456 N.W: 0.379 kg U.W: 3.7930 g TOTAL: 100 PCS
<b>Prt-11</b>	2002/01/01 00:09:23 ABC COMPANY 0918-123456 N.W: 0.379 kg U.W: 3.7930 g TOTAL: 100 PCS
<b>Prt-12</b>	#1 N.W: 0.379 kg U.W: 3.7930 g TOTAL: 100 PCS
<b>Prt-13</b>	2002/01/01 00:09:23 #1 N.W: 0.379 kg U.W: 3.7930 g TOTAL: 100 PCS
<b>Prt-14</b>	ABC COMPANY 0918-123456 #1 N.W: 0.379 kg U.W: 3.7930 g TOTAL: 100 PCS
<b>Prt-15</b>	2002/01/01 00:09:23 ABC COMPANY 0918-123456 #1 N.W: 0.379 kg U.W: 3.7930 g TOTAL: 100 PCS

<b>Prt-08</b>	N.W: 0.379 kg T.W: 0.100 kg G.W: 0.479 kg
<b>Prt-09</b>	2002/01/01 00:09:23 N.W: 0.379 kg T.W: 0.100 kg G.W: 0.479 kg
<b>Prt-10</b>	ABC COMPANY 0918-123456 N.W: 0.379 kg T.W: 0.100 kg G.W: 0.479 kg
<b>Prt-11</b>	2002/01/01 00:09:23 ABC COMPANY 0918-123456 N.W: 0.379 kg T.W: 0.100 kg G.W: 0.479 kg
<b>Prt-12</b>	#1 N.W: 0.379 kg T.W: 0.100 kg G.W: 0.479 kg
<b>Prt-13</b>	2002/01/01 00:09:23 #1 N.W: 0.379 kg T.W: 0.100 kg G.W: 0.479 kg
<b>Prt-14</b>	ABC COMPANY 0918-123456 #1 N.W: 0.379 kg T.W: 0.100 kg G.W: 0.479 kg
<b>Prt-15</b>	2002/01/01 00:09:23 ABC COMPANY 0918-123456 #1 N.W: 0.379 kg T.W: 0.100 kg G.W: 0.479 kg

When **ALLO3** appear under Display of accumulation, press .the printout will like as following.







```

2002/01/01 00:09:23
ABC COMPANY
0918-123456
1) 0.100 kg 10 PCS
2) 0.100 kg 10 PCS
3) 0.100 kg 10 PCS
-----
0.300 kg 30 PCS
U.W.=10.000 g
    
```

Note :

- (1) If you wish the SH-24 should be able to print date & time, the scale needs an optional module RS-232+RTC.
- (2) If you have a printer that you think is compatible with the SH-24, then just connect the scale and the printer and remember to choose print model **normal** (even it is not the SH-24). Please choose own of the print formats from Prt-00 to Prt-15 and if the print appears correct, means that the printer is compatible with the SH-24.

## 【 Activate The Serial Number Function 】





	<p>(1) Keep pressing  for about three seconds</p>
	<p>(2) You will enter into parameter settings.</p>
	<p>(3) Press  or  to switch between the settings.</p>
	<p>(4) Repeat step (3) until seeing P-2 appear.</p>
	<p>(5) Press  or  to select serial number on/-off</p> <p><i>on</i> Showing serial No.  <i>off</i> No serial no. showing</p> <p>If you turn on the serial No., it will be shown in the total count display.</p> <p>Please see example in step (7)</p>
	<p>(6) Press  or  to save and go to next parameter setting or press  to save the setting and return to normal weighing mode.</p>
	<p>(7) Example of how the serial number is displayed when serial number is activated.</p> <p><b>Note :</b> If the scale get pieces the total count display will show piece instead.</p>

## 【Set The Serial Number Mode】

	<p>(1) Under normal weighing mode press </p>
	<p>(2) The displays will show as below (if not, please press )</p>
	<p>(3) Press  or  to choose serial number mode</p> <p> No action.</p> <p> The serial no. plus 1 when  sign appear.</p> <p> The serial no. plus 1 when quantity is between HI – LO limits.</p> <p> The serial no. plus 1 when weight is between HI – LO limits</p>
	<p>(4) Press  to save setting and return to normal weighing mode.</p>

**【 Set Max Serial Number 】** .....limit 99999

The max serial number is 99999, but you can change the max serial number as shown below.


	<p>(1) For example if you wish to change the max serial number to 12, then you need to do the following steps below. Press <b>1</b>, <b>2</b>,</p>
	<p>(2)The unit weight display is blinking</p>
	<p>(3) Press <b>M+R</b> to complete the setting and,</p>
	<p>(4) Return to the normal weighing mode.</p>

**Note:**

When the serial number reach the max, the unit weight display will flash סתירה and beep for 3 second, afterwards return to normal weighting mode.

And because it already reached the max serial number, it will reset to 1 when the serial number do increase 1.

## 【 Change The Serial Number 】





	<p>(1) If you want to change the serial no. to 12, then Press <b>1</b>, <b>2</b></p>
	<p>(2) The unit weight display is blinking</p>
	<p>(3) Press  to complete the setting and,</p>
	<p>(4) Return to the normal weighing mode. <b>Note</b> : The serial no. is starting from 12</p>

## 【Set / Choose Accumulation Mode】

	<p>(1) Under normal weighing mode and when the pan is empty then press  (If there is a object on the pan, it will accumulate.)</p>
	<p>(2) The display of the total count is blinking.</p>
	<p>(3) Press  or  to choose accumulation mode</p> <p> Manual</p> <p> Accumulate when  sign appear</p> <p> Accumulate when quantity is between HI – LO limits</p> <p> Accumulate when weight is between Hi – LO limits.</p>
	<p>(4) Press  to save the settings and return to normal weighing mode.</p>

## 【Set The Max Amount Of Accumulations】 ..... the limit is 50

The max accumulation number is 50, but you can change the max accumulation number as shown below.

	<p>(1) For example if you wish to change the max accumulation number to 12, then you need to do the following steps below. Press <b>1</b>, <b>2</b>,</p>
	<p>(2)The unit weight display is blinking</p>
	<p>(3)Press <b>M+</b> to complete the settings and,</p>
	<p>(4) Return to the normal weighing mode. Now you can accumulate up to 12 times only. <b>Note:</b> You can change the max accumulation back to 50 times, by repeating the above steps.</p>

### For example,



max amount of accumulations=12, when accumulate to 12 amount, the displays will show as following, and beep for 3 second. but **ARC-12** still blink waiting operator to do action.




### 3 Actions as following

- (1) press **PRINT**, then it'll print every set and total, **ARC-12** still blink  
(it's only for normal printer like SH-24.Label printer couldn't do it)
- (2) press **ESC** to return normal weighting mode, and still keep those accumulation.  
(but if you try to accumulate another set, it'll appear **OW-12** to warn)
- (3) press **M+** twice, delete all accumulation.

## 【 Display Of Accumulation 】


	<p>(1) Under normal weighing mode press </p>
	<p>(2) The display will show the value of the last accumulation</p>
	<p>(3) Repeat step (1) and you will see the total accumulations.</p>
	<p>(4) Press any number key to select a certain accumulation. Example, to select the 12 accumulation press , </p>
	<p>(5) The display will show the twelfth accumulation.</p> <p>NOTE : You can press , then repeat step (4) to see the accumulation that you want.</p>
	<p>(6) If you press ,  then the display will show the amount of the all accumulations, since there is no accumulation number 13</p>
	<p>(7) Press  and return to the normal weighing mode.</p>

**【 Print While Display Of Accumulation 】** .....only for SH-24

<p><b>Print one set of accumulation</b></p> <p>Enter display of accumulation, when it show single set press </p>		
	<p>2002/01/01 00:09:23                  ABC COMPANY                  0918-123456                  1) 0.100 kg 10 PCS</p>	
<p><b>Print total accumulation</b></p> <p>Enter display of accumulation, when it show total, press </p>		
	<p>Weight on the scale will                  Print out as following.</p> <p>2002/01/01 00:09:23                  ABC COMPANY                  0918-123456                  1) 0.100 kg 10 PCS                  2) 0.100 kg 10 PCS                  3) 0.100 kg 10 PCS                  -----                  0.300 kg 30 PCS                  U.W.=10.000 g</p>	<p>No weight on the scale                  Will print out as following.</p> <p>2002/01/01 00:09:23                  ABC COMPANY                  0918-123456                  0.300 kg 30 PCS                  U.W.=10.000 g</p>

## 【 Delete Accumulations 】

### Delete one single accumulation

	<p>(1) Enter the Display of accumulation.</p> <p>(2) Press any number key to select a certain accumulation.. Example to select the 12 accumulation press <b>1</b>, <b>2</b></p>
	<p>(3)The display will show the twelfth accumulation.</p>
	<p>(4)Press <b>M-</b> to delete the twelfth accumulation value.</p>
	<p>(5)The display will now show as left chart.</p>
	<p>(6)Repeat steps (2)(3)(4) to delete the accumulation value you don't need. Then press <b>ESC</b> and return to the normal weighing mode.</p>

## Delete all accumulation

	<p>(1) To delete all accumulation it is important to have all accumulation appearing in the unit weight display like ALL 12</p>
	<p>(2) Press </p>
	<p>(3) If you want to delete all accumulation then go to step 4 and if you don't want to delete all accumulation go to step 5.</p>
	<p>(4) Press  again to delete all accumulations. The scale returns automatically to the normal weighing mode.</p>
	<p>(5) If you don't want to delete, press  and return to the normal weighing mode.</p>



## 【Set The High Limit Of The Pieces】

	<p>(1) Under normal weighing mode press <b>Hi</b> key.</p>
	<p>(2) The display of the total count will show the last hi limit. (If the weight is blinking ,  , press <b>SMP1</b> )</p> <p>PS : arrow points the Hi</p>
	<p>(3) For example if the Hi limit is 2013, then          Press <b>2 0 1 3</b></p>
	<p>(4) The value 2013 is blinking in the total count display</p>
	<p>(5) Press <b>Hi</b> again and the setting is completed</p>

## 【Set The Low Limit Of The Pieces】


	<p>(1) Under normal weighing mode press <b>Lo</b> key</p>
	<p>(2) The display of the total count will show the last low limit. (If the weight is blinking press <b>SMPL</b>)</p> <p>PS : arrow point to low</p>
	<p>(3) For example if the LO limit is 1987, then</p> <p>press <b>1 9 8 7</b></p>
	<p>(4) The value 1987 is blinking in the total count display.</p>
	<p>(5) Press <b>Lo</b> key again and the setting is completed</p>

## 【 Enable / Disable The Piece Checking Function 】

	<p>(1) Under normal weighing mode press <b>Lo</b> key</p> <p>PS: Pressing <b>Hi</b> key is the same.</p> <p>PS: You don't have to operate both step (3) and (4). Do one of them.</p>
	<p>(2) Make sure the total count is blinking, if not press <b>SMP/L</b> key.</p>
	<p>(3) Press <b>Hi</b> if you want to enable Hi &amp; Lo checking function.</p>
	<p>(4) Press <b>Lo</b> if you want to disable the Hi &amp; Lo checking function.</p>
	<p><b>NOTE :</b></p> <p>There is an arrow between PRESET TARE and NET, when you enable the Hi &amp; Lo checking function. The arrow disappears when disable the Hi &amp; Lo checking function.</p>

Execute step(1)(2)(3) to enable Hi/Lo checking Function ( Now light tower is available )  
 Execute step(1)(2)(4) to disable Hi/Lo checking Function




## 【Set The High Limit Of The Weight】

	<p>(1) Under normal weighing mode press the  key</p>
	<p>(2) The display of the weight is blinking and the arrow in the display of the total count points to high limit. (If the display of the total count is blinking then press )</p> <p>PS: ▶ point to Hi (without <i>LRrE</i> showing)</p>
	<p>(3) For example if Hi limit is 1.023kg, then press </p>
	<p>(4) The high limit 1.023kg is blinking in the weight display.</p>
	<p>(5) Press  key again and the setting is completed</p>

## 【Set The Low Limit Of The Weight】

 <p>A keypad diagram with 20 buttons arranged in a 4x5 grid. The buttons are: Row 1: 1, 2, 3, SMP, M++; Row 2: 4, 5, 6, UWS, M; Row 3: 7, 8, 9, CE, MR; Row 4: 0, %, HI, ZERC, TARE; Row 5: %, %, Lo, %, ESC. A hand icon is pointing to the Lo key.</p>	<p>(1) Under normal weighing mode press <b>Lo</b> key</p>
 <p>A scale display with two screens. The top screen shows 'WEIGHT' and 'UNIT WEIGHT'. The weight display shows '0.997' with a '10' superscript. The unit weight display shows '0'. Below the screens is a 'TOTAL COUNT (PCS)' display showing '0'. A hand icon is pointing to the right side of the display.</p>	<p>(2) The display of the weight is blinking and the arrow in the display of the total count points to low limit. (If the display of the total count is blinking then press <b>UWS</b>)</p> <p>PS: ▶ point to Lo (without <i>LR-E</i> showing)</p>
	<p>(3) For example if the Lo limit is 0.987kg, then press <b>9</b> <b>8</b> <b>7</b></p>
 <p>A scale display similar to the previous one, but the weight display now shows '0.987' with a '10' superscript. The unit weight display still shows '0'. The total count display shows '0'.</p>	<p>(4) The low limit of 0.987kg is blinking in the weight display.</p>
 <p>A keypad diagram identical to the first one, with a hand icon pointing to the Lo key.</p>	<p>(5) Press <b>Lo</b> key again and the setting is completed.</p>

## 【 Enable / Disable The Weight Checking Function 】



	<p>(1) Under normal weighing mode press <b>Lo</b> key</p> <p>PS: Pressing <b>Hi</b> is the same.</p> <p>PS: You don't have to operate both step (3) and (4). Do one of them.</p>
	<p>(2) Make sure the weight display is blinking, if not press  key.</p>
	<p>(3) Press  if you want to enable Hi &amp; Lo checking function.</p>
	<p>(4) Press  if you want to disable the Hi &amp; Lo checking function.</p>
	<p><b>NOTE :</b></p> <p>There is an arrow between PRESET TARE and NET, when you enable the Hi &amp; Lo checking function. The arrow disappears when disable the Hi &amp; Lo checking function.</p>

Execute step(1)(2)(3) to enable Hi/Lo checking Function ( Now light tower is available )  
 Execute step(1)(2)(4) to disable Hi/Lo checking Function

## 【Set The High Limit Of The Tare Value】

	<p>(1) Under normal weighing mode press <b>Hi</b> key</p>
	<p>(2) The display of the total count will show <b>LRrE</b> if not, press <b>TARE</b>.</p> <p>PS: ▶ points to Hi and the <b>LRrE</b> is on the display.</p>
	<p>(3) For example the Hi limit is 0.579kg, then press <b>5</b> <b>7</b> <b>9</b>.</p>
	<p>(4) The display of the tare weight will show 0.579kg blinking in the weight display.</p>
	<p>(5) Press <b>Hi</b> key again and the setting is completed</p>

## 【Set The Low Limit Of The Tare Value】

	<p>(1) Under normal weighing mode press <b>Lo</b> key</p>
	<p>(2) The display of the total count will show <b>TOTAL COUNT (PCS)</b>  if not, press .</p> <p>PS: ▶ points to Lo and the <b>LArE</b> is on the display.</p>
	<p>(3) For example if the Lo limit is 0.573kg, then press <b>5</b> <b>7</b> <b>3</b></p>
	<p>(4) The display of the tare weight will show 0.573kg, which is blinking in the weight display.</p>
	<p>(5) Press <b>Lo</b> key again and the setting is completed.</p>

## 【 Enable / Disable The Auto-Tare Checking Function 】




 <p>A keypad diagram with 5 rows and 5 columns of buttons. The buttons are: Row 1: 1, 2, 3, SMP, M+; Row 2: 4, 5, 6, UWS, M; Row 3: 7, 8, 9, CE, MR; Row 4: 0, %, HI, ZERC, TARE; Row 5: %, %, Lo, %, ESC. A hand icon is pointing to the Lo key.</p>	<p>(1) Under normal weighing mode press <b>Lo</b> key</p> <p>PS: Pressing <b>Hi</b> is the same.</p> <p>PS: You don't have to operate both step (3) and (4). Do one of them.</p>
 <p>Two digital scale displays. The top display shows 'WEIGHT' and 'UNIT WEIGHT' with values '0573' and '0'. The bottom display shows 'TOTAL COUNT(PCS)' with 'LArE'. A hand icon points to the 'Lo' key on the keypad in the previous step.</p>	<p>(2) Make sure the display of the total count show <b>LArE</b>. If not press <b>TARE</b>.</p> <p>PS: ▶ points to Lo and <b>LArE</b> showing.</p>
 <p>A keypad diagram identical to the first one, but with a hand icon pointing to the TARE key.</p>	<p>(3) Press <b>TARE</b> if you want to enable auto tare checking function.</p>
 <p>A keypad diagram identical to the first one, but with a hand icon pointing to the Lo key.</p>	<p>(4) Press <b>Lo</b> if you want to disable the auto tare checking function.</p>

Execute step(1)(2)(3) to enable Auto-Tare Function

Execute step(1)(2)(4) to disable Auto-Tare Function






## 【 Saving ID - Method 1 】

Possible to save up to 50 ID



	<p>(1) Under normal weighing mode press  </p> <p> </p>
	<p>(2) The unit weight display is blinking.</p>
	<p>(3) Press  key</p>
	<p>(4) Key in a number from 0 to 49.</p>
	<p>(5) Press   for example.</p>
	<p>(6) The ID 12 should be blinking in the total count display.(If you want to save into another ID, then press . Then you need to do step (5) again)</p>
	<p>(7) Press  to confirm.</p>
	<p>(8) You have now saved 1.2300g into the ID-13 .</p>

## 【Saving ID - Method 2】


Possible to save up to 50 ID

	<p>(1) There is a unit weight already existing (maybe based on sampling).</p>
	<p>(2) Press .</p>
	<p>(3) Key in a number from 0 to 49.</p>
	<p>(4) Press   for example.</p>
	<p>(5) The number 13 should be blinking in the total count display. (If you want to save into another ID, then press . Then you need to do step (4) again)</p>
	<p>(6) Press  to confirm.</p>
	<p>(7) You have saved 1.2300g into the ID-13.</p>



## 【Call Up ID】




	<p>If the unit weight display is not showing 0, please press  first</p> <p>(1) Under normal weighing mode press </p>
	<p>(2) The value of the ID-00 is 1.0300 g.</p>
	<p>(3) Press   to call up ID-13.</p>
	<p>(4) The number 13 is blinking in the total count display.</p>
	<p>(5) Press  to confirm and the scale is ready for counting.</p>
	<p>(6) The value of the ID-13 is 1.2300g and appears in the unit weight display.</p>

## 【 Pre-Tare By ID 】





	<p>If the unit weight display is not showing 0, please press  first</p> <p>(1) Under normal weighing mode press </p>
	<p>(2) The value of the ID-00 is 1.0300 g.</p>
	<p>(3) Press   to call up ID-13.</p>
	<p>(4) The number 13 is blinking in the total count display.</p>
	<p>(5) Press  to execute pre-tare by value of 123.00 g. ( that is value of ID-13)</p>
	<p>(6) The arrows point the 'NET' &amp; 'PRESET and TARE' symbol  appears in the weight display.</p>

## 【Customize Your Own Label】

	<p>(1) Under normal weighing mode keep pressing  until you see the display shown as below.</p>
	<p>(2) If the displays are blank, means that no label form has ever been saved in the scales memory.</p> <p>PS: The label can save up to 32 characters ▶ pointing at Hi means the front 16 characters can be edited.</p>
	<p>(3) Keep pressing and releasing . The display will show 2, R, b, C in order. Choose R for example.</p>
	<p>(4) Press  or do nothing in a second to edit the next character. Press  to move leftwards and  to move rightwards.</p>
	<p>(5) You can key in another character.</p>
	<p>(6) Repeat steps (3),(4),(5) until you finish your first 16 characters.</p>

	<p>(7) After the front 16 characters, press  key to edit the next 16 characters. You can see the display as below</p>
	<p>(8) You can now key in the next 16 characters.</p> <p>Note: Now ▶ is pointing at Lo</p>
	<p>(9) Do as procedures (3),(4),(5)</p>
	<p>(10) Press  to save the label setting and the scale will return to normal weighing mode.</p> <p><b>PS.1</b> In step (6), if you key in “...” then the label will print into two lines.</p> <p><b>PS.2</b> If you key in two empty blocks the word behind the block will not appear on the label.</p> <p><b>PS.3</b> When you press  you will clear up the 16 characters showing on the displays.</p>

## 【 Label Example 】

<p>■ Example for 2-line print out separate by  from press  twice</p>	
 <p style="text-align: right;">the first 16 characters</p>  <p style="text-align: right;">the last 16 characters</p>	<p>➤ print company's name and telephone number</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p><b>Title: ABC COMPANY</b> <b>Tel : 0981-123456</b></p> </div> <p style="text-align: right;">BP-443D</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p><b>ABC COMPANY</b> <b>0981-123456</b></p> </div> <p style="text-align: right;">SH-24</p>
 <p style="text-align: right;">the first 16 characters</p>  <p style="text-align: right;">the last 16 characters</p>	<p>➤ print brand and spec</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p><b>brand: LTYPE WIRE</b> <b>spec: D 15-20MM</b></p> </div> <p style="text-align: right;">BP-443D</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> <p><b>LTYPE WIRE</b> <b>D 15-20MM</b></p> </div> <p style="text-align: right;">SH-24</p>
<p>■ all the characters behind two space won't be save.</p>	
 <p style="text-align: right;">2 space</p>	<p>Input two space by pressing . Then press  to save the label. It is only saved <i>r-13n</i>, and get rid of those characters behind the 2 space.</p>
<p>■ press  to clear now 16 characters</p>	
 <p>(1)press </p>	<p>(1)press </p>
	<p>(2)The 16 characters is clear and return to the first place.</p>

## 【 Show / Readjust The Time 】

	<p>(1) Under normal weighing mode press , then you see the displays show as below.</p>
	<p>(2) You can see the time/-date.</p>
	<p>(3) Press  to enter into readjusting mode.</p>
	<p>(4) Go into readjusting mode. PS : The time will not be running when you adjust the time/-date.</p>
	<p>(5) Press  for moving cursor right. (or press  for moving cursor left)</p>
	<p>(6) For example, if you want to readjust the minute then repeat step (5) to move the cursor to the minute section.</p>
	<p>(7) Press </p>
	<p>(8) The time has been adjusted</p>







(9) Press  to save the setting and return to normal weighing mode when you have finished readjusting.

**Note**

This scale is not installed with RTC so the time setting won't be memorized after switch off. Please set correct time whenever the scale is switched-on. ( unless the scale is using RS-232 with RTC, then there is no such problem, please contact your supplier for RS-232 with RTC )

**【 ACAI Parameter 】**

In the below example the parameter is set at 15

	+		chart1 : normal sampling
	+		chart2 : One of the objects is short of 20g
	+		chart3 : One of the object's unit weight have 20g surplus
<p>* If you set the average parameter (p-4) to OFF, means that the scale will do the ACAI in all situations..</p> <p>* If you set the average parameter to 15, the scale will not work as seen in chart 2 &amp; 3., which means that if there is a object shortage or more than <math>\pm 15\%</math> of the unit weight, the scale will not do the sampling.</p> <p>* Whether it works or not, depend on the object's tolerance of weight.</p>			

## 【 Sampling With ACAI Function 】

**ACAI**(Automatic Counting Accuracy Improvement) : ACAI is used to calculate a more precise unit weight. User needs to repeat each procedure until the total quantity reaches users' packing quantity or target quantity.

	<p>(1) Put a container on the weighing pan and remember to tare the container. Put a sample of 20 pieces into the container.</p>
	<p>(2) Key in 20</p>
	<p>(3) The number "20" is blinking in the unit weight display.</p>
	<p>(4) Press  key.</p>
	<p>(5) The scale is calculating the unit weight.</p>
	<p>(6) The unit weight is 15.018g. If the ▼ above ACAI shows means that ACAI is activated.</p>

	<p>(7) Put another 10 pieces into the container.</p> <p>PS: The additional pieces must be less than the pieces already in the container and more than 5 pieces.</p>
	<p>(8) When you hear a beep sound, you get an even more accurate unit weight value of 15.007g.</p>
	<p>(9) Repeat steps (6)(7) and you get an even more accurate value. Remove all sample objects from the container, and ▼ above ACAI will disappear. Scale is ready for precise counting.</p>
	<p>(10) You can now count the same objects again with the more accurate unit weight value.</p>

### 【 Data Protection 1 】

	Unit weight	Hi/LO setting	Serial No/Acc setting
Save <b>99990</b> to ID49	unlock	unlock	unlock
Save <b>99991</b> to ID49	<b>lock</b>	unlock	unlock
Save <b>99992</b> to ID49	unlock	<b>lock</b>	unlock
Save <b>99993</b> to ID49	<b>lock</b>	<b>lock</b>	unlock
Save <b>99994</b> to ID49	unlock	unlock	<b>lock</b>
Save <b>99995</b> to ID49	<b>lock</b>	unlock	<b>lock</b>
Save <b>99996</b> to ID49	unlock	<b>lock</b>	<b>lock</b>
Save <b>99997</b> to ID49	<b>lock</b>	<b>lock</b>	<b>lock</b>


#### Note:

- (1) The procedure to Save 9999X to ID49 is the same as Saving ID (Method 1)
- (2) It seems that you save 9999x to ID49, but it is just a virtual action for protection decode, and ID49 still keep it's original data.
- (3) If you try to lock Unit weight, there must be a unit weight on the display, otherwise, the scale will beep three times to warn you.


## ■ Lock Description

<b>Unit weight lock</b>	<p>The advantage of the unit weight lock, is to prevent anybody to alter/-modify the unit weight, without access to the unlock code.</p> <ol style="list-style-type: none"> <li>(1) You can only lock one single unit weight</li> <li>(2) When you don't require the locked unit weight you can press the  to clear the unit weight display, which means that the scale can be used to simple weighing.</li> <li>(3) You can press  to call the locked unit weight directly.</li> </ol>
<b>Hi/LO setting lock</b>	<p>The advantage of the Hi/Lo setting lock is to prevent anybody to alter /-modify the Hi/Lo setting without access to the unlock code.</p> <p>You can press ,  key to call up the Hi/Lo setting, but it becomes read-only data and you can't modify the data.</p>
<b>Serial No/Acc setting lock</b>	<p>Function is as following</p> <ol style="list-style-type: none"> <li>(1) to prevent any change of serial No, maximum serial No, and serial No mode.</li> <li>(2) to prevent any change of maximum Accumulation setting and accumulation mode.</li> </ol> <p>The advantage is to make sure that when you are doing serial No increase or accumulation is under control. For example, you set accumulation mode to weight, then it couldn't be change to manual ,stable or other, that make sure that every time the scale do Accumulation is in weight spec.</p>


## ■ How To Lock The Unit Weight

	<p>(1) Assume that there already get unit weight 1.23g.</p>
	<p>(2) Then you press , , , , </p>
	
	<p>(3) Press  key</p>
	
	<p>(4) And key in , </p>
	
	<p>(5) Press  to lock the unit weight.</p>
	<p>Now you have locked the unit weight and this is the only available unit weight the scale can use. Any changes require the access unlock code.</p>

## ■ How To Unlock The All Settings





	<p>(1) In normal weighing mode press, , , , , </p>
	
	<p>(2) Then you need to press the  key</p>
	
	<p>(3) And press ,  which will unlock the all settings.</p>
	
	<p>(4) Press  key to confirm that you will unlock the all settings.</p>

**【Data Protection 2】** ..... 50 set of ID

	<p>(1) Under normal weighing mode, press  for 3 seconds to enter the basic parameter settings.</p>
	<p>(2) The scale is now in the basic parameter setting mode. press  for 3 seconds to enter the advance parameter settings.</p>
	<p>(3) The scale is now in the advance parameter setting mode. Press  or  to switch between the parameters. Repeat step 3 until AP-10 appear</p>
	<p>(4) AP-10 will appear in the weight display. Press  or  to select between ,    → Unlock   → Lock, the value of 50 set ID will be protected and locked and you can't change any of the 50 ID. The data becomes read-only data.</p>
	<p>(5) Press  or  to save and go to next advanced parameter setting or press  to save the setting and return to normal weighing mode.</p>

Note: To unlock the protection you need to set the AP-10 parameter to 0 (Unlock).

## 【Parameter Settings】

	<p>(1) Under normal weighing mode keep pressing  key for about 3 seconds.</p>
	<p>(2) You will now enter parameter settings as show by the left chart.</p>
	<p>(3) Press  or  to switch between the parameters.</p>
	<p>(4) Repeat step (3) till the parameter you want to reset shows.</p>
	<p>(5) Press  or  to reset the parameter.</p>
	<p>(6) Press  or  to save the setting and go to next parameter setting.</p>
	<p>(7) Press  to save and return to the normal weighing mode.</p>

## 【Parameters Description】

### P- 0 : power(default : off )

( item : off/ 10/20/30/40/50/60/70/80/90min )

\* If P-0 = 10, when there is no object on scale for ten min, it will shut off automatically.

### P- 1 : backlight (default : auto)

*off* : always off      *on* : always on

*Auto* : turn on when the weight is greater than 20e

### P- 2 : serial number display ( default : off )

*off* : never display      *on* : will display when piece is zero

\* The scale will saving the latest serial number when it be turn off normally.

As it is shut off improperly, the memory won't be saved, like plug off the power cable.

### P- 3 : beep sound ( default : in )

*in*: when check is OK      *out*: when check is Hi / Lo      (*in, out* using scale's buzzer)  
*E-in*: when check is OK      *E-out* : when check is Hi / Lo      (*E-in, E-out* using light tower's buzzer)

### P-4 : average ACAI ( default : off )

( item : off/5/10/15/20/25/30/35/40/45 )

### P- 5 : printer ( default : normal )

( item : normal / EZ-2P / BP-443D )      normal as SH-24 or compatible printer

### P- 6 : baudrate ( default : 9600 )

( item : 19200/9600/4800/2400 )

### P- 7 : data ( default : n81 )


(item : n81/o81/e81/n71/o71/e71)

## 【 The Rule For Using The Keypad 】

1. Press  and return to the normal weighing mode in any situations.
2. Press  to clear the wrong input.
3. There will be short beep whenever you press any key; a long beep sound indicates successfully setting and three beep sounds indicate an error.

## 【 Connector 】


### Scale To Printer



### Scale To PC

When you want a scale to transmit data to PC continuously.


- (1) Using a cable as following to connect Scale and PC
- (2) Set printer mode as continue
- (3) Scale data will be sent to PC continuously. (of course, you must have the receiving software on the PC)




## 【 Data Protocol 】

- **Output Data When Print Mode Set As Continue**

Case1: No unit weight on Scale



Case2: with unit weight on Scale



( header1: ST=STABLE      US=UNSTABLE)      ( header2: NT=NET      GS=GROSS)

examples for Case1:

ST/NT + 12.350 kg  
US/GS + 30.000 lb

examples for Case2:

ST/NT + 10.000 kg,1.0000 g, 10000 PCS  
US/GS + 30.000 lb,0.0010 lb, 30000 PCS

- **Input Commands**

“T” = perform TARE function

“Z” = perform ZERO function

## 【 Applications 】

### ■ Quality Checking According To Weight.

For example a batch of PDA outer casing box is weighing 79~82g

- (1) Set the Hi limit at 0.082 kg, Lo limit at 0.079 kg
- (2) Enable the HI/LO checking function
- (3) Start weighing now and carry out the HI/LO (weights) checking function.

**Note :** You may set the beeping sounds according to your needs.

Please refer to P-3. for parameter of Beeping Sounds.

### ■ Control Check On Each Packing According To Weights.

A factory is a manufacturer of DVD player, the standard packing weights of one DVD player is 1.731kg inclusive of :

DVD player	1.200	kg
Adaptor	0.148	kg
User Manual	0.090	kg
Packing Material	0.293	kg

-----  
Total Weights      1.731    kg

Assume that a standard error of  $\pm 30$  g is allowed for every packing . So ,

- (1) Set the HI limit for weight at 1.761 kg, LO limit at 1.701 kg
- (2) Enable the HI/LO checking function
- (3) Start weighing now and carry out the HI/LO (weights) checking function.

**Note :**

- (1) You may set the beeping sounds according to your needs. Please refer to P-3. for parameter of Beeping Sounds.
- (2) Sometime the scale is unable to read the shortage of item if for example :  
If there are 2 adaptors in this packing which are now  $0.148\text{kg} \times 2 = 0.296\text{kg}$   
and there are shortage of 0.150g in packing material which at the end still made up to the total of 1.733kg .

### ■ Construct A ID Memory Chart ( ID Memory )

For easy reference , you may construct a chart indicating all the ID of each item from 0~49 .Please refer to 【saving ID – Method 1】 .

## ■ Control Check On Each Packing According To Pieces .

Assumed that a box of pen knife is weights 5.500kg . Each box contains 50 pieces of pen knife and each pen knife is 0.100kg . The empty box weighed 0.500kg . So ,the net weights of each box is  $50 \times 0.100\text{kg} = 5.000 \text{ kg}$  and gross weights of each box is 5.500kg .

Now , we want to check each packing according to pieces .

- (1) set the pre-tare at 500g ( weight of the empty box )
- (2) key in unit weight of pen knife as 100g
- (3) set the hi limit ( pieces ) 50 pcs , lo limit (pieces) at 50 pcs
- (4) enable the hi/lo checking function .
- (5) start weighing now and carry out the hi/lo checking function.

Note :

- (1) You may set the beeping sounds according to your needs. Please refer to P-3. for parameter of Beeping Sounds.
- (2) you may perform the control check according to weights control checking. Please refer to the application on Control check on each packing according to weights.

## ■ Auto Tare On The Weight Of Boxes , Basket Or Container

If a fruits monger want to pack his fruits in a standard packing basket . He wish that the weight of the basket will be auto tare-off when the basket is place on the weighing pan, and when he remove the basket , the scale will cancel off the tare value and return to zero.

Assumed that the weight of the basket is 0.450 ~0.480kg

- (1) Under the HI/LO checking for TARE , set the HI limit 0.480g, Lo limit at 0.450g.
- (2) Enable the HI/LO checking function
- (3) Place the basket on the pan , you will hear a beep sound. The display show like  indicate that the weight of basket has been tare .
- (4) start packing the fruits .
- (5) after complete the packing , remove the whole basket, when the scale reaches the zero point, you will hear a beep sound and TARE will be canceled.

## ■ Control The Total Production Volume According To Serial Number

- (1) enter the parameter setting and turn on the serial number
- (2) set the mode of serial number according to weight ( within the HI/LO limit), serial number will add 1.
- (3) start weighing, when the weight is stable and is within the HI/LO limit , the number will add 1.

## ■ With This Function , The Total Production Volume And Weight Of Packing Can Be Checked According To Serial Number .

### ■ Control The Production According To The Maximum Serial Number.

Assumed that a production line need to do the packing for every 100 standard items produced :

- (1) turn on the serial number
- (2) set the mode of serial number according to weight ( within the HI/LO limit), serial number will add 1.
- (3) set the maximum serial number to be 100
- (4) start weighing, when the weight is stable and is within the HI/LO limit , the number will add 1.
- (5) when the serial number reach 100 , the unit weight display will show a blinking  and beeping sounds , meaning that have reached 100 standard items and you can do the packing now.
- (6) the serial number will return and start from 1 again , after the 100<sup>th</sup> serial number ,

### ■ Difference Printing Format For Difference Products

This scale is well equipped with 100 difference printing format according to your needs . Please refer to 【label & sample of the printing forms】 .

### ■ Print The Product Name And Specifications ( Label Setting )

You may key in the product name and specification and print the label using the printer because this scale is equipped with the A ~ Z alphabets . Please refer to 【sample of print forms】 .

### ■ Using The Tower Light To Indicate A Defect Or Shortage In Production

The examples of production control mentioned above can be more effective by Using a tower light connecting to the scale. The advantage of the tower light is to overcome the noisiness in the production line and enable the users to check the production through the signals of the tower light .

### ■ Please Contact Your Nearest Agent Or Sales Person If You Have Others Special Requirements Related To The Scale.

## 【FAQ】

### ■ Why can't the printer print out, when I connect to the scale?

1. Make sure the parameter P-5 model be set correctly.
2. Make sure P-6 and P-7 match the printer.
3. If EZ-2P or BP-443D are being used, they should have download the printer format before.

### ■ Why does the Hi & Lo checking not work?

1. Make sure you have enabled the function.
2. The value of Lo is greater than Hi.

### ■ How do check if my printer compatible to the scale ?

1. Under parameter setting P-5 , select the "normal" printer .
2. check the baud rate ( P-6) and the data (P-7) is compatible to printer.  
If it is not , please change the setting accordingly .
3. When you weight and  sign appeared, press  key to print . If the printer able to print meaning that this printer can replace the SH-24 printer .

### ■ Why are there no sounds in the Hi & Lo checking function?

Make sure P-3 is set correctly

### ■ Why do I have to reset the time every time I turn on the scale?

The scale needs an optional RTC.

## 【 LCD Characters 】

0	1	2	3	4	5	6	7	8	9
0	1	2	3	4	5	6	7	8	9

A	B	C	D	E	F	G	H	I	J	K	L	M
A	b	C	d	E	F	G	H	i	J	K	L	ñ



N	O	P	Q	R	S	T	U	V	W	X	Y	Z
n	o	P	q	r	S	t	U	v	w	x	y	Z

## 【 Error Messages 】




Error Message	Reasons	Solutions
<i>E noEE</i>	The CPU unable to read the EEPROM	Return To The Manufacturer
<i>E CALF</i>	Unable to read the 3 points calibration range	Do the 3 points calibration
<i>PH<sub>1</sub></i>	Zero Point is Too High	Make sure the pan is empty when turn on the scale or perform the 3 points calibration.
<i>PL<sub>0</sub></i>	Zero Points is Too low	Make sure the pan is on the scale or perform the 3 points calibration.
<i>E UnSt</i>	Unstable Zero Point	(1)Make sure there is no winds or vibration .  (2)Change the stability /vibration parameter accordingly.
<i>CLF-b</i>	Battery for RTC is too weak	Replace a new battery or press  to abort
-----	Overload (The weights on the pan is more than +9e of the max. capacity )	Take away the overloaded objects.
<i>d<sub>1</sub> FFE</i>	Unable to accumulate due to contradiction in net weight and net weight with quantity . You cannot accumulate this two together .	Press  key twice to clear the all the accumulation or press  key to return to normal weighing mode .
<i>ou- 15</i>	The last accumulation is more than the preset accumulation allowed .	Press  key twice to clear the all the accumulation or press  key to return to normal weighing mode .

## 【 Option 】


### ■ Only One Optional Device Being Used

	Option	Application	Remark
AP1	<p>OP-03 One RS232 port (with RTC function)</p> 	<p>+</p>  <p>BP-443D</p>	<p>Can print out Bar Code</p> 
AP2	<p>OP-03 One RS232 port (with RTC function)</p> 	<p>+</p>  <p>SH-24</p>	<p>Can print out accumulation data</p> 
AP3	<p>OP-03 One RS232 port (with RTC function)</p> 	<p>+</p>  <p>LED Display</p>	<p>→ Only the weighing data can be shown on LED Display</p>
AP4	<p>OP-01 One set of relay contacts</p> 	<p>+</p>  <p>LED Light Tower</p>	<p>→ Three light of light tower to indicate three different situation, easy to see, besides it's buzzer is loud enough even in a noisy place.</p>

■ Two Optional Devices Being Used





	Option	Remark
AP5	<p>OP-05</p>  <p>Two RS232 ports (with RTC function)</p>	 <p>BP-443D</p>  <p>PC</p> <p>or</p>  <p>LED Display</p>
AP6	<p>OP-06</p>  <p>One set of relay contacts and one RS232 port (with RTC function)</p>	 <p>BP-443D</p>  <p>LED Light Tower</p>
AP7	<p>OP-06</p>  <p>One set of relay contacts and one RS232 port (with RTC function)</p>	 <p>LED Light Tower</p>  <p>PC</p> <p>or</p>  <p>LED Display</p>

■ Three Optional Devices Being Used

	Option	Remark
<p>AP8</p>		 <p>BP-443D</p>
	<p>OP-07</p>  <p>One set of relay contacts and two RS232 ports (with RTC function)</p>	 <p>LED Display</p>
		 <p>LED Light Tower</p>

## 【 Relay Module Diagram 】

■ **Relay Output :**

Alarm	
HI	
OK	
LO	

■ **Relay Contact Spec**

1A/24VDC , 0.5A/125VAC , 0.25A/250VDC