



Building Automation

Industrial Automation

Systems

User Manual

MFD-Titan Multi-Function Display

06/03 AWB2528-1480GB



Think future. Switch to green.

For Immediate Delivery call KMParts.com at (866) 595-9616

All brand and product names are trademarks or registered trademarks of the owner concerned.

1st published 2003, edition date 06/03

© Moeller GmbH, 53105 Bonn

Author: Dieter Bauerfeind
Editor: Heidrun Riege
Translator: Terry Osborn

All rights reserved, including those of the translation.

No part of this manual may be reproduced in any form (printed, photocopy, microfilm or any other process) or processed, duplicated or distributed by means of electronic systems without written permission of Moeller GmbH, Bonn.

Subject to alteration without notice.

Printed on bleached cellulose.
100 % free from chlorine and acid.

For Immediate Delivery call KMParts.com at (866) 595-9616



Warning! Dangerous electrical voltage!

Before commencing the installation

- Disconnect the power supply of the device.
- Ensure that devices cannot be accidentally restarted.
- Verify isolation from the supply.
- Earth and short circuit.
- Cover or enclose neighbouring units that are live.
- Follow the engineering instructions (AWA) of the device concerned.
- Only suitably qualified personnel in accordance with EN 50110-1/-2 (VDE 0105 Part 100) may work on this device/system.
- Before installation and before touching the device ensure that you are free of electrostatic charge.
- The functional earth (FE) must be connected to the protective earth (PE) or to the potential equalisation. The system installer is responsible for implementing this connection.
- Connecting cables and signal lines should be installed so that inductive or capacitive interference does not impair the automation functions.
- Install automation devices and related operating elements in such a way that they are well protected against unintentional operation.
- Suitable safety hardware and software measures should be implemented for the I/O interface so that a line or wire breakage on the signal side does not result in undefined states in the automation devices.
- Ensure a reliable electrical isolation of the low voltage for the 24 volt supply. Only use power supply units complying with IEC 60364-4-41 (VDE 0100 Part 410) or HD 384.4.41 S2.
- Deviations of the mains voltage from the rated value must not exceed the tolerance limits given in the specifications, otherwise this may cause malfunction and dangerous operation.
- Emergency stop devices complying with IEC/EN 60204-1 must be effective in all operating modes of the automation devices. Unlatching the emergency-stop devices must not cause restart.
- Devices that are designed for mounting in housings or control cabinets must only be operated and controlled after they have been installed with the housing closed. Desktop or portable units must only be operated and controlled in enclosed housings.

- Measures should be taken to ensure the proper restart of programs interrupted after a voltage dip or failure. This should not cause dangerous operating states even for a short time. If necessary, emergency-stop devices should be implemented.
- Wherever faults in the automation system may cause damage to persons or property, external measures must be implemented to ensure a safe operating state in the event of a fault or malfunction (for example, by means of separate limit switches, mechanical interlocks etc.).

Contents

<hr/>	
About This Manual	7
Device designation	7
Writing conventions	7
<hr/>	
1 MFD-Titan	9
Target readership	9
Proper use	9
– Improper use	9
Overview	10
Device overview	12
– MFD devices at a glance	12
– Type references for the MFD-Titan	14
MFD operation	14
– Buttons	14
– Moving through menus and choosing values	15
– MFD-Titan Status display	16
– Status display for local expansion	17
– MFD-Titan advanced Status display	17
– MFD-Titan LED display	17
– Selecting or toggling between menu items	25
– Cursor display	26
– Setting values	26
<hr/>	
2 Installation	27
Mounting	27
Connecting the expansion unit	45
Terminals	45
– Tool for cage clamp terminals	45
– Connection cross-sections of the MFD cage clamp terminal cables	45
– Tool for slot-head screws for easy expansion unit	45
– Connection cross-sections of screw terminal cables	45
Connecting the power supply	46
– Cable protection	48

Connecting the inputs	49
– Connecting easy-AC inputs	49
– Connecting MFD-DC inputs	53
Connecting the outputs	58
Connecting relay outputs	59
– MFD-R..	59
– EASY6..-..RE..	59
– EASY2..-RE	60
Connecting transistor outputs	60
– MFD-T..	60
– EASY6..-DC-TE	61
Connecting analog outputs	63
– Connecting servo valves	63
– Setpoint entry for a drive	64
Connecting the NET network	64
– Accessories	64
– Cable length and cross-sections	66
– Plugging and unplugging network cables	68
Connecting the serial interface	70
Expanding inputs/outputs	73
– Local expansion	73
<hr/>	
3 Commissioning	77
Switching on	77
Setting the menu language	77
MFD operating modes	78
Creating your first circuit diagram	79
– Testing the circuit diagram	86
– Fast circuit diagram entry	89
Configuring an easy-NET network	90
– Entering the network station number	91
– Changing the easy-NET network configuration	94
– Displaying the Status display of other stations	94
Configuring the interface for the COM-LINK mode	96
– Setting up the COM-LINK	97
Terminal mode	101
– Terminal mode	101

4	Wiring with MFD-Titan	111
	MFD-Titan operation	111
	– Buttons for drawing circuit diagrams and function block usage	111
	– Usable relays and function blocks (coils)	119
	– Markers, analog operands	122
	– Circuit diagram display	125
	– Saving and loading programs	127
	Working with contacts and relays	128
	– Creating and modifying connections	131
	– Inserting and deleting a circuit connection	133
	– Aborting circuit diagram entry	134
	– Searching for contacts and coils	134
	– “Go to” a circuit connection	135
	– Deleting the circuit connection	135
	– Switching via the cursor buttons	136
	– Checking the circuit diagram	137
	– Function block editor	138
	– Checking function blocks	142
	– Coil functions	143
	Function blocks	148
	– Analog value comparator/threshold value switch	150
	– Arithmetic function block	153
	– Data block transfer	164
	– Boolean sequence	175
	– Counters	178
	– Frequency counters	185
	– High-speed counters	189
	– Comparators	200
	– Text output function block	202
	– Data function block	203
	– PID controller	205
	– Signal smoothing filter	211
	– GET, fetch a value from the network	214
	– Seven-day time switch	216
	– Year time switch	221
	– Value scaling	225
	– Jumps	229
	– Master reset	232

- Numerical converters 233
- Operating hours counter 239
- PUT, send a value onto the network 240
- Pulse width modulation 242
- Setting date/time 245
- Set cycle time 247
- Timing relay 249
- Value limitation 262
- Example with timing relay and counter function block 264

5 Visualization with MFD-Titan 269

6 easy-NET Network, COM-LINK Serial Connection 271

- Introduction to easy-NET 271
- easy-NET network topologies, addressing and functions 272
 - Loop through the unit wiring method 272
 - T connector and spur line 272
 - Position and addressing of the operands via easy-NET 274
 - Possible write and read authorisation in the network 276
- Configuration of the easy-NET network 277
 - Station number 277
 - Transmission speed 277
 - Pause time, changing the write repetition rate manually 278
 - Automatic change of the RUN and STOP mode 279
 - Input/output device (REMOTE IO) configuration 280
 - Station message types 281
 - Transfer behaviour 281
 - Signs of life of the individual stations and diagnostics 282
- Introduction to COM-LINK 286
 - Topology 286
 - Configuration of the COM-LINK 290

7	MFD Settings	295
	Password protection	295
	– Password setup	296
	– Selecting the scope of the password	297
	– Activating the password	298
	– Unlocking MFD	299
	Changing the menu language	302
	Changing parameters	303
	– Adjustable parameters for function blocks	304
	Setting date, time and daylight saving time	305
	Changing between winter/summer time (DST)	306
	Activating input delay (debounce)	308
	– Deactivating debounce (input delay)	308
	Activating and deactivating the P buttons	309
	– Activating the P buttons	309
	– Deactivating the P buttons	310
	Startup behaviour	310
	– Setting the startup behaviour	310
	– Behaviour when the circuit diagram is deleted	311
	– Behaviour during upload/download to card or PC	311
	– Possible faults	312
	– Card startup behaviour	312
	– Terminal mode	313
	Setting LCD contrast and backlight	314
	Retention	316
	– Requirements	317
	– Setting retentive behaviour	317
	– Deleting ranges	318
	– Deleting retentive actual values of markers and function blocks	318
	– Transferring retentive behaviour	319
	Displaying device information	320

8	Inside MFD	323
	MFD Program cycle	323
	– How MFD evaluates the high-speed counters CF, CH and CI	327
	– Memory management of the MFD-Titan	327
	Delay times for inputs and outputs	328
	Monitoring of short-circuit/overload with EASY..-D.-T..	331
	Expanding MFD-Titan	333
	– How is an expansion unit recognised?	333
	– Function monitoring of expansion units	334
	QA analog output	336
	Loading and saving programs	336
	– MFD without display and keypad	336
	– Interface	336
	– Memory card	337
	– EASY-SOFT-PRO	342
	Device version	344

	Appendix	345
	Technical data	345
	– General	345
	– CPU, real-time clock/timing relay/memory	353
	– Transistor outputs	360
	– Analog output	363
	– easy-NET network	364
	List of the function blocks	366
	– Function blocks	366
	– Function block coils	367
	– Function block output (operands)	370
	– Other operands	370
	Memory requirement	371

	Index	373
--	--------------	------------

About This Manual

This manual describes the installation, commissioning and programming (circuit diagram generation) of the MFD-Titan control relay.

A specialist knowledge of electrical engineering is needed for commissioning and creating circuit diagrams. When active components such as motors or pressure cylinders are controlled, parts of the system can be damaged and persons put at risk if the MFD device is connected or programmed incorrectly.

Device designation

This manual uses the following abbreviated designations for different device models:

- MFD-Titan
- MFD

Writing conventions

Symbols used in this manual have the following meanings:

► Indicates actions to be taken.



Attention!

Warns of the possibility of light damage.



Caution!

Warns of the possibility of serious damage and slight injury.



Warning!

Warns of the possibility of substantial damage, serious injury or death.



Indicates interesting tips and additional information

For greater clarity, the name of the current chapter is shown in the header of the left-hand page and the name of the current section in the header of the right-hand page. This does not apply to pages at the start of a chapter and empty pages at the end of a chapter.

1 MFD-Titan

Target readership

MFD must only be installed and wired up by trained electricians or other persons familiar with the installation of electrical equipment.

A specialist knowledge of electrical engineering is needed for commissioning and creating circuit diagrams. When controlling active components such as motors or pressure cylinders, parts of the system can be damaged and persons put at risk if MFD is connected or programmed incorrectly.

Proper use

MFD is a programmable device that provides HMI, switching, closed-loop and open-loop control functions, and can be used to replace relay and contactor controls as well as being used as an MFD device. MFD must be properly installed before use.

The display and operating unit of the MFD is protected to IP65 and does not normally require any special housing protection. The rear MFD units are designed as mounting units and must be installed in an enclosure, control cabinet or a service distribution board. Both the power feed and the signal terminals must be laid and covered so as to prevent accidental contact.

The installation must comply with regulations for electromagnetic compatibility (EMC).

The power up of the MFD must not cause any hazards arising from activated devices, such as unexpected motor startups or power ups.

Improper use

MFD should not be used as a substitute for safety-related controls such as burner or crane controls, emergency-stop or two-hand safety controls.

Overview

MFD-Titan is an electronic HMI unit and control relay with the following features:

- Logic functions,
- Timing relay and counter functions,
- Time switch functions,
- Arithmetic functions,
- PID controllers,
- Operator and display functions.

MFD-Titan is a display, HMI, control and input device in one. With MFD-Titan you can create solutions for domestic applications as well as for tasks in machine and plant construction. MFD-Titan is a modular and flexible device.

The integral easy-NET network enables the connection of up to eight easy-NET stations to form a single control system. Each easy-NET station can contain a program. This allows the design of systems using high-speed controllers with decentralised intelligence.

In Terminal mode, the MFD can be used to control any device in the network and display data from it, regardless of whether it is an easy800 or an MFD. In this mode, the MFD makes its keypad and display available to the other device for use.

Two devices, MFD easy800 or MFD, can be connected simply via the serial interfaces.

Circuit diagrams are connected up using ladder diagrams, and each element is entered directly via the MFD display. For example, you can:

- connect make and break contacts in series and in parallel
- switch output relays and auxiliary contacts,
- define outputs as coils, impulse relays, rising or falling edge-triggered relays or as latching relays,

- select timing relays with different functions:
 - on-delayed,
 - on-delayed with random switching,
 - off-delayed,
 - off-delayed with random switching,
 - on and off delayed,
 - on and off delayed with random switching,
 - on and off delayed with random switching,
 - single pulse,
 - synchronous flashing,
 - asynchronous flashing.
- use up and down counters,
- count high-speed signals:
 - up and down counters with upper and lower limit values,
 - preset,
 - frequency counters,
 - high-speed counters,
 - count incremental encoder values.
- compare values,
- display graphics, texts, variables, enter setpoints, display flashing values and graphics, change and replace graphics and texts by pushbutton,
- process additional inputs and outputs,
- use 7-day and year time switches,
- count operating hours (operating hours counter),
- communicate via the integrated easy-NET network,
- set up point-to-point communication via the serial interface,
- provide closed-loop control with P, PI and PID controllers,
- scale arithmetic values,
- output manipulated variables as pulse-width modulated signals,
- run arithmetic functions:
 - add,
 - subtract,

- multiply,
- divide.
- track the flow of current in the circuit diagram
- load, save and password-protect circuit diagrams

If you prefer to wire up MFD-Titan from a PC, then use EASY-SOFT-PRO. EASY-SOFT-PRO allows you to create and test your circuit diagram on the PC. All display and operator functions on the MFD device are created exclusively using the EASY-SOFT-PRO software. EASY-SOFT-PRO is also used to print out your circuit diagram in DIN, ANSI or easy format.

Device overview

MFD devices at a glance

Display and operating unit




Figure 1: Overview of the display and operating unit

- ① DEL button
- ② Graphic display
- ③ ALT button
- ④ LEDs for signalling
- ⑤ Mode button
- ⑥ Right, down cursor buttons
- ⑦ OK button
- ⑧ Left, up cursor buttons
- ⑨ ESC button

Power supply and CPU




Figure 2:T Device overview of power supply and CPU

- ① Power supply
- ② easy-NET terminals
- ③ EASY-LINK terminal
- ④ Interface for memory card, PC and point-to-point connection
- ⑤ Power supply / operating mode LED
- ⑥ easy-NET LED

Inputs/outputs





Figure 3:T Device overview of inputs/outputs

- ① Inputs
- ② Analog output (optional)
- ③ Outputs

Type references for the MFD-Titan



MFD operation

Buttons



DEL: Delete object in circuit diagram

ALT: Special functions in circuit-diagram, Status display

Cursor buttons <> ^v:

Move cursor

Select menu items

Set contact numbers, contacts and values

OK: Next menu level, Save your entry
















ESC: Previous menu level, Cancel

*:Toggle between visualization display and Status display
close Terminal mode




In visualization applications, the operating unit can be used for other functions than the ones stated above. In this case the buttons are assigned the function selected in the application. The standard button functions are only restored when you leave the application.

Moving through menus and choosing values


-  and  Show System menu
-  Go to next menu level
Select menu item
Activate, modify, save your entry
-  Return to last menu level
Cancel your entry since the last **OK**
-    Change menu item
Change value
-   Change place
- Function of P buttons:
- | | | | |
|---|-----------|---|----------|
|  | Input P1, |  | Input P2 |
|  | Input P3, |  | Input P4 |
-  and  Reset the MFD display

Selecting main and system menu


Status display




Date display



MFD-Titan Status display




Status display for local expansion



On: 1, 2, 3, 4/Off:...

RS = Expansion functioning correctly

MFD-Titan advanced Status display



- RE : Retention switched on
- I : Debounce switched on
- NT1 : easy-NET station with station address
- COM The COM connection is active
- AC : AC expansion functioning correctly
- DC : DC expansion functioning correctly
- GW : Bus coupling module detected
GW flashes: Only easy200-easy detected. I/O expansion not detected.
- ST : When the power supply is switched on, MFD switches to STOP mode

MFD-Titan LED display

MFD-Titan features two LEDs on the back of the MFD-CP... power supply /CPU device. These indicate the status of the power supply (POW) and the RUN or STOP operating mode (→ Fig. 1, Page 12).

Table 1: Power supply/RUN-STOP mode LED

LED OFF	No power supply
LED continuously lit	Power supply present, STOP mode
LED flashing	Power supply present, RUN mode

Table 2: easy-NET LED (easy-NET)

LED OFF	easy-NET not operational, fault, in configuration
LED continuously lit	easy-NET is initialised and no station has been detected.
LED flashing	easy-NET operating fault-free

The front of the MFD-80.. device has a green LED and a red LED. These can be used in your visualization application as light indicators.

The following applies to Terminal mode:

Green LED

Table 3: Power supply/RUN-STOP mode LED

LED OFF	No power supply
LED continuously lit	Power supply present, STOP mode
LED flashing	Power supply present, RUN mode

Red LED


Table 4: Fault on the easy-NET

LED OFF	Operation correct
LED continuously lit	easy-NET remote device faulty

Menu structure

Main menu without password protection

► You access the main menu by pressing **OK**.



Main menu

```

PROGRAM...  ↑
STOP RUN  ✓
PARAMETERS
SET CLOCK... ↓
TERMINAL MODE
  
```

```

PROGRAM...
DELETE PROGRAM
CARD...
  
```

```

DEVICE-CARD
CARD-DEVICE
DELETE CARD ?
  
```

REPLACE ?

```

DEVICE-CARD
CARD-DEVICE
DELETE CARD ?
  
```

REPLACE ?

```

DEVICE-CARD
CARD-DEVICE
DELETE CARD ?
  
```

DELETE ?

Parameter display

Parameters

```

PROGRAM...  ↑
STOP RUN  ✓
PARAMETERS
SET CLOCK... ↓
TERMINAL MODE..
  
```

```

PROGRAM...  ↑
STOP RUN  ✓
PARAMETERS
SET CLOCK... ↓
TERMINAL MODE..
  
```

Display for date and time setting

```

SET CLOCK
DST SETTING
  
```

```

HH:MM  --:--
DD.MM  --.---
YEAR   ----
  
```

```

HH:MM  14:23
DD.MM  03.10
YEAR   2001
  
```

```

SET CLOCK
DST SETTING
  
```

```

NONE ✓
MANUAL ✓
EU ✓
GB ✓
US ✓
  
```

```

SUMMERTIME START
DD.MM : --.---
SUMMERTIME END
DD.MM : --.---
  
```

Only one selection is possible.

```

PROGRAM...
STOP RUN  ✓ ↑
PARAMETERS
SET CLOCK...
TERMINAL MODE.. ↓
  
```


```

STATION ID: 0
START MODE
  
```

```


Connection
establishment
in progress...
  
```


Main menu with password protection




MFD-Titan system menu


- ▶ The System menu is accessed by simultaneously pressing DEL and ALT.






System menu




System menu




System menu




This list is only created in Station 1.
 This list only appears if station 1 has been selected.




Fault scenario with ID conflict.




Fault scenario with network fault.



System menu



Selecting or toggling between menu items




Cursor ^v



Select or toggle


Cursor display



The cursor flashes.

Full cursor █/:

- Move cursor with < >
- in circuit diagram also with ^ v




Value M/M

- Change position with < >
- Change values with ^ v

Flashing values/menus are shown in grey in this manual.

Setting values



- Change value ^ v
- Select cursor position in value < >
- Change value at position ^ v



Store entries



Retain previous value

2 Installation

The MFD must only be installed and wired up by qualified electricians or other persons familiar with the installation of electrical equipment.



Danger of electric shock!

Never carry out electrical work on the device while the power supply is switched on.

Always follow the safety rules:

- Switch off and isolate,
- Ensure that the device is no longer live,
- Secure against reclosing,
- Short-circuit and ground,
- Cover adjacent live parts.

The MFD is installed in the following order:

- Mounting,
- Wiring up the inputs,
- Wiring up the outputs,
- Wiring up the NET network (if required),
- Setting up the serial interface (if required),
- Connecting the power supply.

Mounting

Install the display/operating unit of the MFD in the front of a control cabinet, a service distribution board, operator panel or in an enclosure. Install the power supply/CPU module and the input/output module so that all the terminals are protected against direct contact, liquids and dust during operation.

When using the MFD without a display/operating unit, snap it onto a DIN EN 50022 top-hat rail or fix it in place using fixing brackets. The MFD can be mounted either vertically or horizontally.

➔ When using the MFD with expansion units, connect the expansion concerned before mounting (see ➔ page 45).

For ease of wiring, leave a gap of at least 3 cm between the MFD terminals and the wall or adjacent devices.




Figure 4: Clearances to the MFD

Fitting the protective membrane

For special applications such as in the food industry, the operating unit must be protected against the ingress of dust, liquids etc.

For this use the specially designed protective membrane.

Fit the protective membrane before mounting the display/ operating unit.




Figure 5:T Fitting the protective membrane

- ① Protective membrane
- ② display/operating unit module

► Place the protective membrane over the display/operating unit.



Caution!

Ensure that the membrane fits snugly in the groove of the display/operating unit.

Otherwise a proper seal cannot be guaranteed and particles may enter underneath the membrane. This may cause malfunctions in the keypad.

In food industry applications, there is the risk of bacteria building up underneath the membrane.




Figure 6: Correct position of the protective membrane



If the protective membrane has to be replaced, the display/operating unit has to be removed. Replace the membrane and refit the device.

Mounting the protective cover

The protective cover is provided for using the device in aggressive environments. This protects the display and the operating unit against mechanical damage or destruction. Protection to IP65 is maintained.

The protective cover can be opened so that the operating unit can be used.

The protective cover can be closed with a sealing facility to provide protection against unauthorised operation.

Before mounting the display/operating unit, fit the protective cover.




Figure 7:T Removing the front frame

- Remove the front frame as shown in the figure.

The protective cover can be mounted in two different positions. Choose the position that is most suitable for the application at hand and your requirements.




Figure 8:T Position of the protective cover




Figure 9: Mounting the protective cover

► Mount the protective cover as shown in the figure.

Sealing the protective cover




Figure 10: Sealing the protective cover

The grip handle of the protective cover is provided with holes that can be used in any mounting position. You can fit a wire or similar material through these holes in order to seal the cover. If the wire is provided with a lead seal, the cover is sealed. The cover can then only be opened by breaking the seal or the wire.

Mounting the display/operating unit, "front mounting"




Figure 11: Drill holes for the MFD

- ▶ Drill and punch out two 22.5 mm diameter holes. The diameter is the same as is normally required for control circuit devices.



Observe the following technical requirements:

- The hole spacing is 30 mm.
- The maximum thickness of the front plate for mounting the power supply/CPU module must not be more than 6 mm.
- The maximum thickness of the front plate for mounting an expansion unit with a top-hat rail in addition to the power supply/CPU module must not be more than 4 mm.
- Leave enough space at the side for the power supply/CPU module, and if necessary, the expansion unit.
- In order to ensure protection to IP65, the surface of the mounting front must be even and smooth.




Figure 12: Mounting the display/operating unit

The protective membrane or the protective cover must be fitted.

- ▶ Fit the display/operating unit in the punched fixing holes.





Figure 13: Screw fastening the display/operating unit

► Screw fasten the display/operating unit.

The tightening torque must be between 1.2 and 2 Nm



Ensure that the correct torque is used. If the tightening torque is too low or high, this may impair the seal.



Use the combination box spanner with the designation M22-MS.

Removing the display/operating unit, “front mounting”

► Unscrew the fixing element and remove the display/operating unit.

Mounting the power supply/CPU module

If you wish to add expansion units to the power supply/CPU module, the top-hat rail must be fitted beforehand.

Fitting the top-hat rail

Ensure that the cutout of the top-hat rail was prepared for the fixing shafts according to the specified dimensions.




Figure 14: Top-hat rail with cutout



The two fixing shafts of the display/operating unit are designed for a 2 space unit expansion device.

If you wish to fit wider expansion units, the top-hat rail must be supported at a third support point.

This third support point should be located in the area 216 mm from the end of the device. It should not be possible to twist the top-hat rail.

**Caution!**

The fixing shafts of the display/operating unit are designed for mounting the expansion units. Other devices such as contactors must not be mounted on this top-hat rail.

Attach the expansion unit before fitting the top-hat rail.






Figure 15: Fitting the top-hat rail

- ▶ Fit the top-hat rail in the groove using the slide catch of the power supply/CPU module and the expansion unit.
- ▶ Turn the top-hat rail towards the housing.
- ▶ Let the top-hat rail snap into position.
- ▶ Press the power supply/CPU module onto the fixing shaft.




**Mounting the inputs/outputs onto the power supply/
CPU module**







The inputs/outputs can be mounted before or after mounting the power supply/CPU module onto the fixing shaft.



Removing the inputs/outputs



- ▶ Press the two catches together.
- ▶ Pull one side out of the catch.
- ▶ Pull the other side out of the second catch.




- ▶ Remove the I/O module.

Removing the power supply/CPU module

The power supply/CPU module can be removed with or without the I/O module.



If there is another fixing point for the top-hat rail, apart from the one for the display/operating unit, undo it.



Use a screwdriver with a 100 x 3.5 mm slot width.


- ▶ Insert the screwdriver into the lug of the fixing shaft catch.

- ▶ Lever out the slide catch.
- ▶ Pull out the power supply/CPU module from the fixing shafts.


Mounting on top-hat rail

The power supply/CPU module can be mounted on a top-hat rail without the display/operating unit.


The fastening catches must be removed in order to mount the device on a fastened top-hat rail.



- ▶ Remove the spring with a screwdriver.



- ▶ Pull the slide catch out of the guide and remove it.



- ▶ Hook the MFD to the top edge of the top-hat rail and hinge into place while pressing down slightly.
- ▶ Press down lightly on both the device and the top-hat rail until the unit snaps over the lower edge of the top-hat rail.

The MFD will clip into place automatically.


- ▶ Check that the device is seated firmly.

The device is mounted vertically on a top-hat rail in the same way.

Screw mounting

The power supply/CPU module can be screwed onto a mounting plate without the display/operating unit.

For screw mounting on a mounting plate, fixing brackets must be used that can be fixed to the back of the MFD. The fixing brackets are available as an accessory.



Three fixing brackets are sufficient for a device with four fixing points.




Figure 16: Screw mounting for the MFD




Figure 17: Screw mounting for the EASY2...-




Figure 18: Screw mounting for the easy600

Connecting the expansion unit




Figure 19: Connecting expansion units

Terminals

Tool for cage clamp terminals

Slot-head screwdriver, width 3.5 mm x 0.6 mm.

Connection cross-sections of the MFD cage clamp terminal cables

- Solid: 0.2 to 4 mm² (AWG 24 - 12)
- Flexible with ferrule: 0.2 to 2.5 mm² (AWG 24-12)

Tool for slot-head screws for easy expansion unit

Slot-head screwdriver, width 3.5 x 0.6 mm, tightening torque 0.6 Nm.

Connection cross-sections of screw terminal cables

- Solid: 0.2 to 4 mm² (AWG 22 - 12)
- Flexible with ferrule: 0.2 to 2.5 mm² (AWG 22 - 12)

Connecting the power supply



The required connection data for both device types MFD-DC, **easy-DC** with 24 V DC and **easy-AC** with standard voltages of 100 V to 240 V AC are given in the Chapter "Appendix", Page 345.

The MFD-Titan devices run a system test for one second after the power supply has been switched on. Either RUN or STOP mode will be activated after this time depending on the default setting.

EASY...-AC-.E expansion units




Figure 20: Power supply on the AC expansion units



Attention!

A short current surge will be produced when switching on for the first time. Do not switch on easy AC via Reed contacts since these may burn or melt.

DC power supply for the MFD




Figure 21: Power supply on the MFD

The MFD power supply/CPU module supplies the necessary power supply to itself, the display, the input/output electronics, the easy-LINK, and optionally the easy-NET.



The MFD device power supply/CPU module is protected against reverse polarity. Ensure the correct polarity of the terminals to ensure that the MFD functions correctly.

EASY...-DC-E DC expansion units




Figure 22: Power supply on the DC expansion units



easy DC is protected against polarity reversal. To ensure that easy works correctly, ensure that the polarity of each terminal is correct.

Cable protection

With easy-AC, easy-DC and the MFD power supply/CPU module, provide cable protection (F1) for at least 1 A (slow).



When easy or the MFD is switched on for the first time, its power supply circuit behaves like a capacitor. Use a suitable device for switching on the power supply and do not use any reed relay contacts or proximity switches.

Connecting the inputs

easy or MFD inputs switch electronically. Once you have connected a contact via an input terminal, you can reuse it as a contact in your MFD circuit diagram as often as you like.




Figure 23: Connecting the inputs

Connect contacts such as pushbutton actuators or switches to easy or MFD input terminals.

Connecting easy-AC inputs



Caution!

For easy-AC, connect the inputs to the same line as the power feed in accordance with the VDE, IEC, UL and CSA safety regulations. Otherwise easy will not detect the switching level and may be damaged or destroyed by overvoltage.




Figure 24: EASY...-AC-E expansion unit

Connect the inputs, for example, to pushbutton actuators, switches or relay/contactors contacts.

Input signal voltage range

- OFF signal: 0 V to 40 V
- ON signal: 79 V to 264 V

Input current

- R1 to R12
0.5 mA/0.25 mA at 230 V/115 V

Cable lengths

Severe interference can cause a “1” signal on the inputs without a proper signal being applied. Observe therefore the following maximum cable lengths:

- R1 to R12: 40 m without additional circuit

The following applies to expansion units:

With longer cables, connect a diode (e.g. 1N4007) for 1 A, minimum 1 000 V reverse voltage, in series to the easy input. Ensure that the diode is pointing towards the input as shown in the circuit diagram, otherwise easy will not detect the 1 state.




Figure 25: easy-AC with a diode on the inputs

Two-wire proximity switches have a residual current with the "0" state. If this residual current is too high, the easy input may detect a "1" signal.

If inputs with a higher input current are required, an additional input circuit must be used.

Increasing the input current

The following input circuit can be used in order to prevent interference and also when using two-wire proximity switches:




Figure 26: Increasing the input current



When using a 100 nF capacitor, the drop-out time of the input increases by 80 (66.6) ms at 50 (60) Hz.

A resistor can be connected in series with the circuit shown in order to restrict the inrush current.




Figure 27: Limitation of the inrush current with a resistor

Complete devices for increasing the input current are available under the type reference EASY256-HCI.




Figure 28: easy600 with EASY256-HCI



The increased capacitance increases the drop-out time by approx. 40 ms.

Connecting MFD-DC inputs

Use input terminals I1 to I12 to connect pushbutton actuators, switches or 3 or 4-wire proximity switches. Given the high residual current, do not use 2-wire proximity switches.

Input signal voltage range

- I1 to I6, I9, I10
 - OFF signal: 0 to 5 V
 - ON signal: 15 V to 28.8 V
- I7, I8, I11, I12
 - OFF signal: < 8 V
 - ON signal: > 8 V

Input current

- I1 to I6, I9, I10, R1 to R12: 3.3 mA at 24 V
- I7, I8, I11, I12: 2.2 mA at 24 V




Figure 29: MFD-DC



The digital inputs must have the same voltage as the power supply of the MFD.




Figure 30: EASY...-DC-E

Connecting analog inputs

Inputs I7, I8, I11 and I12 can also be used to connect analog voltages ranging from 0 V to 10 V.

The following applies:

- I7 = IA01
- I8 = IA02
- I11 = IA03
- I12 = IA04

The resolution is 10-bit = 0 to 1023.



Caution!

Analog signals are more sensitive to interference than digital signals. Consequently, more care must be taken when laying and connecting the signal lines. Incorrect switching states may occur if they are not connected correctly.

- ▶ Use shielded twisted pair cables to prevent interference with the analog signals.
- ▶ For short cable lengths, ground the shield at both ends using a large contact area. If the cable length exceeds 30 m or so, grounding at both ends can result in equalisation currents between the two grounding points

and thus in the interference of analog signals. In this case, only ground the cable at one end.

- ▶ Do not lay signal lines parallel to power cables.
- ▶ Connect inductive loads to be switched via the MFD outputs to a separate power feed, or use a suppressor circuit for motors and valves. If loads such as motors, solenoid valves or contactors are operated with MFD via the same power feed, switching may give rise to interference on the analog input signals.

The following circuits contain examples of applications for analog value processing.



Ensure that the reference potential is connected. Connect the 0 V of the power supply unit for the different setpoint potentiometers and sensors shown in the examples to the 0 V terminal of the MFD power feed.

Setpoint potentiometer




Figure 31: Setpoint potentiometer, setpoint potentiometer with upstream resistor

Use a potentiometer with a resistance of $\leq 1 \text{ k}\Omega$, e.g. $1 \text{ k}\Omega$, 0.25 W .

Temperature sensor, Brightness sensor, 20 mA sensor




Figure 32: Temperature sensor, brightness sensor, 20 mA sensor

4 to 20 mA (0 to 20 mA) sensors can be connected easily without any problem using an external 500Ω resistor.

The following values apply:

- $4 \text{ mA} = 0.2 \text{ V}$
- $10 \text{ mA} = 4.8 \text{ V}$
- $20 \text{ mA} = 9.5 \text{ V}$

(according to $U = R \times I = 478 \Omega \times 10 \text{ mA} \sim 4.8 \text{ V}$)

Connecting high-speed counters and frequency generators

High-speed counter signals on the MFD-Titan can be counted correctly on inputs I1 to I4 independently of the cycle time.




Figure 33: High-speed counter, frequency generator

Connecting incremental encoders

Inputs I1, I2 and I3, I4 on the MFD-Titan can each be used for the high-speed counting of an incremental encoder independently of the cycle time. The incremental encoder must generate two 24 V DC square wave signals with a 90° phase shift between them.




Figure 34: Connecting incremental encoders

Connecting the outputs

The Q... outputs function inside MFD as isolated contacts.




Figure 35: Output "Q"

The respective relay coils are actuated in the MFD circuit diagram via the output relays Q 01 to Q 04 or S 01 to S 06 (S 08). You can use the signal states of the output relays as make or break contacts in the MFD circuit diagram for additional switching conditions.

The relay or transistor outputs are used to switch loads such as fluorescent tubes, filament bulbs, contactors, relays or motors. Check the technical thresholds and output data before installing such devices (see → chapter "Appendix", from Page 345).

Connecting relay outputs MFD-R..




Figure 36: MFD-R.. relay outputs

EASY6...RE..




Figure 37: EASY6...RE.. relay outputs

EASY2...-RE




Figure 38: EASY2...-RE.. relay outputs

Unlike the inputs, the MFD-R.., EASY6...-RE relay outputs can be connected to different lines.



Do not exceed the maximum voltage of 250 V AC on a relay contact. If the voltage exceeds this threshold, flashover may occur at the contact, resulting in damage to the device or a connected load.

Connecting transistor outputs

MFD-T..




Figure 39: MFD-T.. transistor outputs

EASY6..-DC-TE




Figure 40: EASY6..-DC-TE transistor outputs

Parallel connection:

Up to four outputs can be connected in parallel in order to increase the power. The output current will increase in this case to a maximum of 2 A.



Caution!

Outputs may only be connected in parallel within a group (Q1 to Q4 or Q5 to Q8, S1 to S4 or S5 to S8), such as Q1 and Q3 or Q5, Q7 and Q8. Outputs connected in parallel must be switched at the same time.



Caution!

Please note the following when switching off inductive loads:

Suppressed inductive loads cause less interference in the entire electrical system. For optimum suppression the suppressor circuits are best connected directly in the proximity of the inductive load.

If inductive loads are not suppressed, the following applies: Several inductive loads should not be switched off simultaneously to avoid overheating the driver blocks in the worst possible case. If in the event of an emergency stop the +24 V DC power supply is to be switched off by means of a contact, and if this would mean switching off more than one controlled output with an inductive load, then you must provide suppressor circuits for these loads (→ following diagrams).




Figure 41: Inductivity with suppressor circuit

Behaviour with short-circuit/overload

Should a short circuit or overload occur on a transistor output, this output will switch off. The output will switch on up to maximum temperature after the cooling time has elapsed. This time depends on the ambient temperature and the current involved. If the fault condition persists, the output will keep switching off and on until the fault is corrected or until the power supply is switched off (→ Section "Monitoring of short-circuit/overload with EASY..-D.-T..", Page 331).

Connecting analog outputs

MFD-RA.. and MFD-TA.. each have an analog output QA 01, 0 V to 10 V DC, 10 bit resolution (0 to 1023). The analog output allows you to control servo valves and other final controlling elements.



Caution!

Analog signals are more sensitive to interference than digital signals. Consequently, more care must be taken when laying and connecting the signal lines. Incorrect switching states may occur if they are not connected correctly.

Connecting servo valves




Figure 42: Connecting servo valves

Setpoint entry for a drive




Figure 43: Setpoint entry for a drive

Connecting the NET network

MFD-Titan with network connection (MFD-CP.-NT) can be used for creating the NET network. Up to eight devices can be connected to this network. Further information can be found in the Chapter "easy-NET Network, COM-LINK Serial Connection", Page 271.

Accessories

Connection plug:

8-pole RJ45, EASY-NT-RJ45

Connection assignment of the RJ45 socket on the device




Figure 44: RJ45 socket

Connection cable:

4-pair twisted cable; → Section "Technical data",
Page 345




Figure 45: Connection assignment

ECAN_H data cable, pin 1, cable pair A

ECAN_L data cable, pin 2, cable pair A

Ground cable GND, pin 3, cable pair B

Select cable SEL_IN, pin 4, cable pair B



Minimum operation with easy-NET functions with the cables ECAN_H, ECAN_L and GND. The SEL_IN cable is only used for automatic addressing.

Table 5: T Prefabricated cables, RJ45 plug on both ends

Cable length cm	Type designation
30	EASY-NT-30
80	EASY-NT-80
150	EASY-NT-150

Material for self-manufactured cables

100 m $4 \times 0.18 \text{ mm}^2$: EASY-NT-CAB

Required crimping tool for RJ45 plug: EASY-RJ45-TOOL

Bus termination resistor

The first and last stations in the network must be provided with a bus termination resistor.

- Value: 124Ω
- Termination connector: EASY-NT-R

Cable length and cross-sections

For correct operation of the network the cable lengths, cross-sections and cable resistances must correspond to the following table.

Cable length m	Cable resistance mΩ/m	Cross-section	
		mm ²	AWG
up to 40	≦ 140	0.13	26
up to 175	≦ 70	0.25 to 0.34	23, 22
up to 250	≦ 60	0.34 to 0.5	22, 21, 20
up to 400	≦ 40	0.5 to 0.6	20, 19
up to 600	≦ 26	0.75 to 0.8	18
up to 1000	≦ 16	1.5	16

The surge impedance of the cables used must be 120 Ω.

Calculating the cable length with known cable resistance

If the resistance of the cable per unit of length is known (resistance per unit length R' in Ω/m), the entire cable resistance R_L must not exceed the following values. R_L depends on the selected baud rates:

Baud rate kBaud	Cable resistance R_L Ω
10 to 125	≤ 30
250	≤ 25
500 1000	≤ 12

l_{\max} = maximum cable length in m

R_L = Total cable resistance in Ω

R' = Cable resistance per unit length in Ω/m

$$l_{\max} = \frac{R_L}{R'}$$

Calculating cross-section with known cable lengths

The minimum cross-section is determined for the known maximum extent of the network.

l = cable length in m

S_{\min} = minimum cable cross-section in mm^2

ρ_{cu} = resistivity of copper, if not otherwise stated $0.018 \Omega\text{mm}^2/\text{m}$

$$S_{\min} = \frac{l \times \rho_{\text{cu}}}{12.4}$$



If the result of the calculation does not yield a standard cross-section, the next larger cross-section is used.

Calculating length with known cable cross-section

The maximum cable lengths are calculated for a known conductor cross-section

l_{\max} = cable length in m

S = minimum cable cross-section in mm^2

ρ_{Cu} = resistivity of copper, if not otherwise stated $0.018 \Omega\text{mm}^2/\text{m}$

$$l_{\max} = \frac{S \times 12.4}{\rho_{\text{Cu}}}$$

Plugging and unplugging network cables

MFD-Titan is provided with two RJ45 network sockets.

The socket 1 in the first station is for the bus terminating resistor. For other stations, socket 1 is used for plugging in the incoming cable. Socket 2 is used for the outgoing cable or for the bus termination resistor on the last physical station in the network.




Figure 46: Bus termination resistors

- ① First station on the NET network
- ② Bus termination resistor
- ③ Last station on the NET network
- ▭ Physical location, place
- Station number

Both RJ45 interfaces are visible after the cover plate has been removed.

When a cable is plugged in, the mechanical connection must be audible (click) and visible [1](#).

Before a plug or cable is removed, the mechanical locking feature must be undone [2](#), [3](#).




Figure 47: Plugging and unplugging cables

Connecting the serial interface

The MFD power supply/CPU module is provided with a multi-function interface. This can be used to set up point-to-point communication between different devices. The interface is also used for connecting EASY-SOFT-PRO.

The following device configurations are possible:


- MFD with MFD,
- MFD with easy800 (from device version 04).

The serial interface must be implemented using special cables.


The standard MFD-800-CAB cable is 2 m in length.



The MFD-800-CAB cable must not be lengthened in order to ensure compliance with EMC requirements.



- ▶ Remove the interface cover or other plugs from the interface.
- ▶ Fit the connectors in the devices.



It must be ensured in all circumstances that the connector with the marking POW-Side is fitted in the interface of the MFD device. The serial interface only functions if the MFD device is providing the power feed required for the interface cable.




Figure 48: Point-to-point serial interface

Expanding inputs/outputs You can add expansion units to all MFD types with an easy LINK connection in order to increase the number of inputs and outputs:

Expandable easy basic units	Expansion units	
MFD-CP8-..	EASY618-..-RE	<ul style="list-style-type: none"> • 12 AC inputs, • 6 relay outputs
	EASY620-..-TE	<ul style="list-style-type: none"> • 12 DC inputs, • 8 transistor outputs
	EASY202-RE	2 relay outputs, common ¹⁾
Special expansion units for connecting to other bus systems are shown in the latest product catalogue.		

1) Common supply for multiple outputs

Local expansion

Local expansion units are fitted directly next to the power supply/CPU module with an easy-LINK connection.

- ▶ Connect the easy expansion unit via the easy-LINK-DS plug connector.




Figure 49: Connecting local expansion units with MFD-CP8..



The following electrical separation is implemented between the power supply/CPU module of the MFD device and the expansion unit (separation always in local connection of expansion unit)

- Simple isolation 400 V AC (+10 %)
- Safe isolation 240 V AC (+10 %)

Units may be destroyed if the value 400 V AC +10 % is exceeded, and may cause the malfunction of the entire system or machine!



MFD power supply/CPU modules and expansion units can be fed by different DC power supplies.

Remote expansion


Remote expansion units can be installed and run up to 30 m away from the basic unit.



Warning!

The two-wire or multiple-wire cable between the devices must adhere to the insulation voltage requirement which is stipulated for the installation environment. Otherwise, a fault (ground fault, short-circuit) may lead to the destruction of the units or injury to persons.

A cable such as NYM-0 with a rated operational voltage of $U_e = 300/500$ V AC is normally sufficient.



$$U_e = 300/500 \text{ V}$$

Figure 50: Connecting remote expansion units to the MFD-Titan



Terminals E+ and E- of the EASY200-EASY are protected against short-circuits and polarity reversal. Functionality is only ensured if E+ is connected with E+ and E- with E-.

3 Commissioning

Switching on

Before startup check whether the power supply, inputs, outputs, the serial interface and the easy-NET connection are properly connected:

- 24 V DC version:
 - Terminal +24 V: +24 V voltage
 - Terminal 0 V: 0 V voltage
 - Terminals I1 to I12, R1 to R12:
Actuation via +24 V
- 230 V AC version
 - Terminal L: Phase conductor L
 - Terminal N: Neutral conductor N
 - Terminals R1 to R12:
Actuation via phase conductor L

If you have already integrated devices into a system, secure any parts of the system connected to the working area to prevent access and ensure that no-one can be injured if, for example, motors start up unexpectedly.

Setting the menu language

When you switch on MFD for the first time, you will be asked to select the menu language.



- ▶ Use the cursor buttons ^ or v to select the language required.
 - English
 - German
 - French
 - Spanish
 - Italian
 - Portuguese
 - Dutch
 - Swedish
 - Polish
 - Turkish

► Press **OK** to confirm your choice and press **ESC** to exit the menu.

easy will then switch to the Status display.



You can change the language setting at a later date, if you wish, see → Section "Changing the menu language", Page 302.

If you do not set the language, MFD will display this menu every time you switch on and wait for you to select a language.

MFD operating modes

MFD operating modes - RUN, STOP and TERMINAL MODE.

In RUN mode the MFD continuously processes a stored program until you select STOP, disconnect the power supply or switch to TERMINAL MODE. The program, parameters and the MFD settings are retained in the event of a power failure. All you will have to do is reset the real-time clock after the back-up time has elapsed. Circuit diagram entry is only possible in STOP mode.



Caution!

In RUN mode, the MFD will immediately run the program saved in the unit when the power supply is switched on. This will not happen if STOP or TERMINAL mode was set as startup mode. In RUN mode outputs are activated according to the switch logic involved.

The following applies to devices without display/operating unit:

- Memory card containing a valid circuit diagram must be fitted.
- Device must be switched on.

If the device has no program, the program stored on the memory card is loaded automatically and the device immediately starts running the program in RUN mode.

Creating your first circuit diagram

The following single line diagram takes you step by step through wiring up your first circuit diagram. In this way you will learn all the rules, quickly enabling you to use MFD for your own projects.

As with conventional wiring, you use contacts and relays in the MFD diagram. With MFD, however, you no longer have to connect up components individually. At the push of a few buttons, the MFD circuit diagram produces all the wiring required. All you have to do is then connect any switches, sensors, lamps or contactors you wish to use.




Figure 51: Lamp controller with relays

In the following example, MFD carries out all the wiring and performs the tasks of the circuit diagram shown below.





Figure 52: Lamp controller with MFD

Starting point Status display



When you switch on MFD, it opens the Status display immediately to show the switching state of the inputs and outputs. It also indicates whether the MFD is already running a program. Note: If another display is visible, a visualization mask is shown.



The examples were written without the use of expansion units. If an expansion unit is connected, the Status display will first show the status of the basic unit and then the status of the expansion unit before showing the first selection menu.



► Press **OK** to switch to the main menu.

Press **OK** to switch to the next menu level, and press **ESC** to move one level back.



OK has two other functions:


- Press **OK** to save modified settings.
- In the circuit diagram, you can also press **OK** to insert and modify contacts and relay coils.

In this case MFD must be in STOP mode.



► Press **OK 2 x** to enter the circuit diagram display via menu items PROGRAM... → PROGRAM. This is where you will create the circuit diagram.


Circuit diagram display



The circuit diagram display is currently empty. The cursor flashes at the top left, which is where you will start to create your diagram.

The location of the cursor is indicated in the status line. L: = Circuit connection (line), C: = Contact or coil (contact), B: = Free memory available in bytes. Start value 7944, with the first three circuit connections already generated.

The MFD-Titan circuit diagram supports 4 contacts and one coil in series. The MFD-Titan display can display 6 circuit diagram contact fields.



Use the ^ v < > cursor buttons to move the cursor over the invisible circuit diagram grid.

The first four columns are contact fields, the fifth column is a coil field. Each line is a circuit connection. MFD automatically connects the contact to the power supply.





Figure 53: Circuit diagram with inputs I1, I2 and output Q1

► Now try to wire up the following MFD diagram.

Switches S1 and S2 are at the input. I 01 and I 02 are the contacts for the input terminals. Relay K1 is represented by the relay coil Q 01. The symbol Q identifies the coil's function, in this case a relay coil acting as a contactor. Q 01 is one of the MFD output relays.

From the first contact to the output coil


With MFD, you work from the input to the output. The first input contact is **I 01**.



▶ Press **OK**.


MFD proposes the first contact **I 01** at the cursor position.

I flashes and can be changed, for example, to a **P** for a pushbutton input using the cursor buttons \wedge or \vee . However, nothing needs to be changed at this point.



▶ Press **OK** \times , to move the cursor across the **01** to the second contact field.

You could also move the cursor to the next contact field using the \gt cursor button.




▶ Press **OK**.

Again, MFD inserts a contact **I 01** at the cursor position. Change the contact number to **I 02**, so that break contact S2 can be connected to input terminal I2.

▶ Press **OK** so that the cursor jumps to the next position and press cursor button \wedge or \vee to change the number to **02**.




You can press **DEL** to delete a contact at the cursor position.



▶ Press **OK** to move the cursor to the third contact field.

You do not need a third relay contact, so you can now wire the contacts directly up to the coil field.

Wiring


MFD displays a small arrow  in the circuit diagram when creating the wiring.

Press **ALT** to activate the wiring arrow cursor and use the cursor buttons $\wedge \vee \langle \rangle$ to move it.



ALT also has two other functions depending on the cursor position:

- In the left contact field, you can press **ALT** to insert a new empty circuit connection.
- The contact under the cursor can be changed between a make and break contact by pressing the **ALT** button.



The wiring arrow works between contacts and relays. When you move the arrow onto a contact or relay coil, it changes back to the cursor and can be reactivated with **ALT** if required.



MFD automatically wires adjacent contacts in a circuit connection up to the coil.

- ▶ Press **ALT** to wire the cursor from **I 02** through to the coil field.



The cursor changes into a flashing wiring arrow and automatically jumps to the next possible wiring position.


- ▶ Press the cursor button \rangle . Contact **I 02** will be connected up to the coil field.



You can use **DEL** to erase a connection at the cursor or arrow position. Where connections intersect, the vertical connections are deleted first, then, if you press **DEL** again, the horizontal connections are deleted.

- ▶ Press the cursor button \triangleright again.

The cursor will move to the coil field.



- ▶ Press **OK**.

MFD inserts the relay coil $\text{C} \ 01$. The specified coil function C and the output relay $\text{C} \ 01$ are correct and do not have to be changed.

Your first working MFD circuit diagram now looks like this:




Figure 54: Your first circuit diagram

= visible area

- ▶ Press **ESC** to leave the circuit diagram display. The SAVE menu appears.



Figure 55: SAVE menu

= visible area

- ▶ Press the **OK** button.

The circuit diagram is stored.

Once you have connected pushbutton actuators S1 and S2, you can test your circuit diagram straight away.

Testing the circuit diagram

```

PROGRAM...
STOP / RUN
PARAMETERS
SET CLOCK...

```

► Switch to the main menu and select the STOP RUN menu option.

With a tick at RUN or STOP you switch to the RUN or STOP operating modes.

MFD runs in the mode indicated by the tick.

► Press the **OK** button. MFD will change to RUN mode.



The mode assigned the tick is always active.

The Status display shows the current mode and the switching states of the inputs and outputs.

```

I 12.....
      I      P-
MO 14:42
Q 1.....  RUN

```

► Change to the Status display and press pushbutton actuator S1.

The contacts (boxes) for inputs I1 and I2 are activated and relay Q1 picks up. This is indicated on the numbers which are displayed.

Power flow display

MFD allows you to check circuit connections in RUN mode. This means that you can check your circuit diagram via the built-in power flow display while it is being processed by the MFD.

► Change to the Circuit diagram display and press pushbutton actuator S1.

The relay picks up. MFD shows the power flow.

```

I 01====I 02=====Q 01
L: 1 C:1 RUN

```

Figure 56: Power flow display: Inputs I1 and I2 are closed, relay Q1 has picked up

■ = visible area

- ▶ Press pushbutton actuator S2, that has been connected as a break contact.

The circuit connection is interrupted and relay Q1 drops out.




Figure 57: Power flow display: Input I1 is closed, input I2 is open, relay Q1 has picked up

■ = visible area

- ▶ Press **ESC** to return to the Status display.



With MFD you can test parts of a circuit diagram before it is entirely completed.

MFD simply ignores any incomplete wiring that is not yet working and only runs the finished wiring.

Power flow display with Zoom function

MFD enables you to check the following at a glance:

- all four contacts plus one coil in series
- and 3 circuit connections

- ▶ Change to the Circuit diagram display and press the ALT button. Press pushbutton actuator S1.





Figure 58: Power flow display in Zoom function: Input I1 and I2 are closed, relay Q1 picked up

- Contact closed, coil is triggered
- Contact opened, coil dropped out


- ▶ Press pushbutton actuator S2, that has been connected as a break contact.

The circuit connection is interrupted and relay Q1 drops out.



Use the cursor buttons ^ v < > to move between the contacts or coil.

- ▶ Press the cursor button >.



The cursor moves to the second contact.

- ▶ Press the ALT button. The display changes to display status with contact and/or coil designation.




Figure 59: Power flow display: Input I1 is closed, input I2 is open, relay Q1 has dropped out

■ = visible area

Deleting the circuit diagram

- ▶ Switch the MFD to STOP mode.



MFD must be in STOP mode in order to extend, delete or modify the circuit diagram.

- ▶ Use PROGRAM... to switch from the main menu to the next menu level.
- ▶ Select DELETE PROGRAM

```
PROGRAM...
DELETE PROGRAM
```

The MFD will display the prompt DELETE?

- ▶ Press **OK** to delete the program or **ESC** to cancel.
- ▶ Press **ESC** to return to the Status display.

Fast circuit diagram entry

You can create a circuit diagram in several ways: The first option is to enter the elements in the circuit and then to wire all the elements together. The other option is to use the enhanced operator guidance of MFD and create the circuit diagram in one go, from the first contact through to the last coil.

If you use the first option, you will have to select some of the elements in order to create and connect up your circuit diagram.

The second, faster option is what you learned in the example. In this case you create the entire circuit connection from left to right.

Configuring an easy-NET network

If you want to work with the easy-NET network and communicate with several stations, the network must be configured first.

Proceed as follows:

- ▶ Connect all network stations. easy-NET socket 2↑ to easy-NET socket 1↓.
- ▶ The first station 1 (socket 1↓) and the last station (socket 2↑) must be provided with a network termination resistor ①.
- ▶ Connect all stations to the power supply.




Figure 60: Example topology with two easy-NET stations

- ① Network termination resistor
- Physical location
- Station number

- ▶ Switch on the power supply on all stations.
- ▶ Ensure that all stations have a power supply. The POW LED must light up or flash. It is only possible to configure the stations which are supplied with voltage.

- ▶ Proceed to the first physical station (Location 1). This station has the termination resistor inserted on socket 1.



The following tasks are only possible in STOP mode.

Entering the network station number

- ▶ Simultaneously press the **DEL** and **ALT** buttons while easy displays the Status display.

```
SECURITY...
SYSTEM...
MENU LANGUAGE
CONFIGURATOR...
```

The System menu appears

Select the CONFIGURATOR menu option.

- ▶ Press the **OK** button.

```
NET...
COM...
LINK....
```

The NET menu appears.

- ▶ Press the **OK** button.

```
NET
PARAMETERS...
STATIONS...
CONFIGURE
```

The NET PARAMETERS... menu appears.

- ▶ Press the **OK** button.

```
NET-ID : 00 ↑
BAUDRATE: 125KB
BUSDELAY: 00
SEND IO ✓ ↓
REMOTE RUN
REMOTE IO
```

- ▶ Press the **OK** button and select the station number with **^** and **v**. In this case the station number (NET-ID) "01".

- ▶ Press the **OK** button.

```
NET-ID : 01 ↑
BAUDRATE: 125KB
BUSDELAY: 00
SEND IO ✓ ↓
REMOTE RUN
REMOTE IO
```

- ▶ Exit the NET PARAMETERS menu with **ESC**.



The station designated station number 1 is the active station. For this reason the REMOTE RUN and REMOTE IO functions are not available.

Entering network stations

Only the network station at physical location 1 with station number 1 has a station list.



The left-hand column is the physical location. You can only assign a physical location to unused station numbers. Physical location 1 is permanently assigned to station number 1.

1	1	↑
2	0	
3	0	
4	0	↓

- ▶ Use the ^ and v cursor buttons to select the STATION menu and press the **OK** button.
- ▶ Proceed to the station with physical address 2.
- ▶ Select the required physical location with the ^ and v cursor buttons. Press the **OK** button.
- ▶ Use cursor buttons ^ and v to select station number 2.
- ▶ Press the **OK** button.

1	1	↑
2	2	
3	0	
4	0	↓

At physical location 2, the station has been assigned station address 2.

- ▶ Press **ESC** to return to the STATIONS menu item.

Configuring an easy-NET network

The easy-NET network can only be configured from station 1.

Requirement:

All stations are correctly connected to the network and the termination resistors have been connected.

All stations have a power supply and are in STOP mode. The POW LED is permanently lit. The NET LED is permanently lit.



If the connected stations are configured, all stations automatically switch to the STOP mode.

```
NET PARAMETERS...
STATIONS...
CONFIGURE
```

► Proceed to the CONFIGURE menu item and press the **OK** button.

```
CONFIGURE?
```

You will be asked to acknowledge whether you want to configure the system.

► Press the **OK** button.

```
CONFIGURATION
IN
PROGRESS.
```

The message on the left appears:

All NET LEDs on the stations which are assigned station numbers higher than 1 (2 to 8) switch to the OFF state of easy-NET.

As soon as the configuration has been successfully completed, the NET LEDs on all stations flash. The easy-NET network is ready for operation.



An error message will appear if a station is assigned a station address which does not correspond to the physical location in the station list.

```
ERR: ID-CONFLICT
OVERWRITE
CONFIGURATION ?
```

If you want to overwrite the station address press the **OK** button. The configuration can be aborted by pressing the **ESC** button.

Changing the easy-NET network configuration

The configuration of the easy-NET network can be modified at any time at station 1, physical location 1.

- ▶ The NET parameters are modified as described for inputting parameters for the first time.

Station addresses in the STATIONS menu are changed as follows:

- ▶ Go to the physical location which is to be modified.
- ▶ Press the **OK** button.



Existing station numbers can only be modified to free, non-assigned station numbers. If all eight numbers are assigned, all station numbers which are to be modified must be set to zero. Thereafter, all station numbers can be reassigned. (MFD-Titan sets all station numbers to zero which are assigned a physical location behind the leading zero.)

- ▶ Select the required station number with the \wedge and \vee cursor buttons and confirm your input with the **OK** button.
- ▶ Configure all easy-NET stations again using the CONFIGURATION menu.



Further information concerning the easy-NET network topic can be found in Chapter "easy-NET Network, COM-LINK Serial Connection", Page 271.

Displaying the Status display of other stations

On every device with a display, you can display the states of the inputs and outputs of each network station.

```

1I12.....
  I NT1   P-
MO 06:42
1Q1.....  RUN

```

- ▶ Change to the Status display and press the **ESC** button. The cursor changes to the display of the network station NT.. and flashes. The station number is displayed in front of the inputs and outputs.

```

3I12.....7....
  I NT3   P-
MO 06:42
3Q1.3..6..  RUN

```

- ▶ Change the number of the required station with the ^ and v cursor buttons.
- ▶ Press the **OK** button.

```

3R12.....7....
  I NT3 DC P-
MO 06:45
3S1.3..6..  RUN

```

- ▶ If you want to view the state of the inputs and outputs of a local expansion, press the **OK** button.

If you press the **ESC** button again or the **OK** button, the display of the input and output states of the station is terminated.



The station showing the status on its display cannot read its own data from the network.

Example: NT3 flashes on station 3. The inputs and outputs 3I.., 3R.., 3Q.. and 3S.. cannot be displayed.

If the NT3 display is not flashing, the inputs and outputs are shown.

Configuring the interface for the COM-LINK mode

If you wish to set up point-to-point communication with another station, this can be done using either the serial interface or easy-NET. The MFD must be provided with a display and operating unit. The connection must be configured for this purpose (→ see also 286).



Ensure that the other station supports the COM-LINK mode.

Proceed as follows:

- ▶ Connect both stations together.

Only use original connection cables. The connector marked POW-Side must be plugged into an MFD. The MFD feeds the interface electronics of the connection line at both ends.

- ▶ Connect both stations to the power supply.




Figure 61: Example with both COM stations.

The MFD is the active station and the second station is the remote station.

- ▶ Switch on the power supply at both stations.

- ▶ Ensure that the power supply for both stations is switched on. The POW LED must light up or flash. It is only possible to configure the stations which have an active power supply.
- ▶ Go to the MFD device that is the active station running the serial interface.



The following tasks are only possible in STOP mode.

Setting up the COM-LINK



Caution!

The MFD device can either run as a station on the easy-NET or as a station in a COM-LINK connection. Do not switch an MFD device running as an easy-NET station to COM-LINK. If this is done on easy-NET in RUN mode, the entire easy-NET network will be deactivated. There will be no further data transfer.

Solution:

- ▶ Deactivate the COM-LINK.
 - ▶ Re-enter the easy-NET address.
 - ▶ Switch the power supply off and then on again.
 - ▶ Reconfigure the easy-NET on station 1.
- ▶ Simultaneously press the **DEL** and **ALT** buttons with the Status display active.

The System menu appears

```
SECURITY...
SYSTEM...
MENU LANGUAGE
CONFIGURATOR...
```

Select the CONFIGURATOR menu option.

- ▶ Press the **OK** button.

Select the COM... menu option.

```
NET..
COM...
LINK....
```

- ▶ Press the \vee button.
- ▶ Press the **OK** button.

```

BAUDRATE: 9600B
COM-LINK
REMOTE MARKER...

```

The menu BAUDRATE: 9600B will appear. The two baud rates are for 9600 or 19200 baud. Select the baud rate that your connection will support.
Baud rate selection.



Select 19200 baud as the baud rate. Badly laid cables may give rise to electromagnetic interference. Select 9600 baud as the baud rate. If this is not satisfactory, the connection cable must be laid in a different location.

▶ Press the **OK** button.

```

BAUDRATE:19200B
COM-LINK
REMOTE MARKER...

```

Select 19200 baud as the baud rate.

▶ Press the \vee or \wedge button.

▶ Confirm with the **OK** button.

Switch on the COM connection.



The COM-LINK must only be switched at the active station. Two devices with COM-LINK \checkmark switched on cannot communicate with each other.

▶ Press the \vee button.

▶ Press the **OK** button.

```

BAUDRATE:19200B
COM-LINK ✓
REMOTE MARKER...

```

The tick on the COM-LINK menu item indicates that COM-LINK has been selected.

No tick means that COM-LINK has not been selected.



The following applies to the active station:

If you wish to run data transfers between the two devices in both directions, you must select the marker range on the active station.

```
BAUDRATE:19200B
COM-LINK ✓
REMOTE MARKER...
```

- ▶ Select the REMOTE MARKER menu item.

The following selection will only be displayed if the COM-LINK menu item has been ticked.

- ▶ Press the **OK** button.

```
READ:
1MD00 + 1MD00
WRITE:
1MD00 + 1MD00
```

The data is physically located in the second station, i.e. the remote station.



The active station reads and writes data from and to the markers of the remote station. At the same time, the remote station has read and write access to the same marker range.

Ensure that both stations do not have write access to the same markers simultaneously. The last write operation will be the one that is retained.

Example:

READ 1MD2 -> 1MD2

WRITE 1MD3 -> 1MD3

The MFD device accesses the markers with station address 1x... These markers correspond to the local markers MD2 and MD3 in the remote station.

These marker double words contain:

MD2, MW3, MW4, MB5; MB6, MB7, MB8, M33 to M64

MD3, MW5, MW6, MB9, MB19, MB11, MB12; M65 to M96

The following marker ranges can be selected:

1MD1 to 1MD20

This corresponds to the following range in the remote station:

MD1 to MD20

```

READ:
 1M000 + 1M000
WRITE:
 1M000 + 1M000
    
```

- ▶ Press the **OK** button.
- ▶ Use the \wedge button to select the start of the READ marker range.

```

READ:
 1M011 + 1M014
WRITE:
 1M000 + 1M000
    
```

- ▶ Use the $\>$ button to enter the upper limit of the READ range.
- ▶ Use the \wedge button to select the value.
- ▶ Confirm the entry with the **OK** button.

```

READ:
 1M011 + 1M014
WRITE:
 1M000 + 1M000
    
```

```

READ:
 1M011 + 1M014
WRITE:
 1M000 + 1M000
    
```

- ▶ Use the \vee button to enter the WRITE range.
- Enter the WRITE range.

```

READ:
 1M011 + 1M014
WRITE:
 1M015 + 1M017
    
```

- ▶ Press **ESC** to leave the entry menu.

The COM-LINK has now been set. No COM settings are required at the remote station.

```

BAUDRATE: 9600B
COM-LINK  ✓
REMOTE MARKER...
    
```

- ▶ Press **ESC** to return to the Status display.

```

I 12.4.67. . . .
  I COM P-
FR 02:02 ST
@ . . . . . STOP
    
```

The entry in the second COM line indicates that the COM connection is active.

Terminal mode**Terminal mode**

The MFD device also supports the TERMINAL MODE operating mode. This allows you to remotely control other devices. This is especially useful if the other device is located in an inaccessible place. Terminal mode can also be used to show the menus and displays of devices that do not have their own display or operating unit. Terminal mode can be used both with the serial interface and in the easy-NET. The serial interface enables you to access a remote device. If you use the easy-NET network, all other network stations can be addressed.



Terminal mode is a separate operating mode like RUN mode. It only functions when a program is not running. For this mode to be active, the MFD must be in STOP mode.



All connected devices must also support Terminal mode.

The following topologies are permissible.

Terminal mode using the point-to-point serial interface




Figure 62: Terminal mode using the point-to-point serial interface

Terminal mode using the easy-NET topology




Figure 63: Terminal mode using the easy-NET topology

In the above topology, the physical location is not identical to the station number. The MFD device was connected in the middle of the network line. Terminal mode functions irrespective of the device location and station number.




Figure 64: Terminal mode in easy-NET with two MFD devices

The above topology allows two MFD devices to be run in easy-NET Terminal mode. Each MFD device can run with the other devices in Terminal mode.




Figure 65: Terminal mode in easy-NET as well as via two serial interfaces

The above topology is a combination of easy-NET operation and serial interface operation. Bear in mind the access rights of the individual devices in easy-NET and in the corresponding serial interface.



Caution!

Data collision!

In order to ensure proper operation, the following conditions must be observed.

The following applies:

If there is more than one MFD device in Terminal mode, each MFD device must access a different easy-NET station.

A device running in Terminal mode must not access any two devices communicating with each other in Terminal mode.

If a PC with EASY-SOFT (-PRO) or an MFD device with a serial interface is in active communication with an easy-NET station, this station must not be accessed at the same time in Terminal mode via the easy-NET.

Proceed as follows:

Your easy-NET or your serial interface must be running correctly.

▶ Press the **OK** button from the Status Display.

The first menu will appear.

```
PROGRAM...
STOP / RUN
PARAMETERS
SET CLOCK...
```

▶ Press the **^** button.

This will display the TERMINAL MODE menu item.

```
STOP / RUN
PARAMETERS
SET CLOCK...
TERMINAL MODE...
```

▶ Press the **OK** button.

The START MODE menu item will flash.

```
STATION ID: 0
START MODE
```

▶ Press the **^** button.

```
STATION ID: 1
START MODE
```

Select the second station. This station will control the display and respond to the operating unit.



Station ID:

- 0 = Station at the serial interface
- 1 = Station 1 easy-NET
- 2 = Station 2 easy-NET
- 3 = Station 3 easy-NET
- 4 = Station 4 easy-NET
- 5 = Station 5 easy-NET
- 6 = Station 6 easy-NET
- 7 = Station 7 easy-NET
- 8 = Station 8 easy-NET

▶ Press the **OK** button.

```
STATION ID: 0
START MODE
```

Select your station.

- ▶ Press the \vee or \wedge button.
- ▶ Press the **OK** button.

```
STATION ID: 0
START MODE
```

Select the START MODE menu option.

- ▶ Press the \vee button.
- ▶ Press the **OK** button.

```
STATION ID: 2
START MODE
```

In this case the easy-NET station 2 is connected.

```
Connection
establishment
in progress...
```

The MFD tries to establish connection to the selected device. The text flashes.

Once the connection is established, the menu appears or the Status display in which the selected device is active.




If the text "Connection establishment in progress..." is displayed for longer than 10 s, the connection to the selected device is faulty. Press **ESC** to cancel the selection. Rectify the fault. Try to re-establish the connection.

The following applies if the device to be operated is in RUN mode and is displaying a mask:

This mask is not displayed in Terminal mode.

MFD message: "The remote device is in Graphic mode."

- ▶ Press the ALT and **ESC** button simultaneously. This will call up the Status display.



The easy-NET station 2 controls the display of the MFD device.



The activation of Terminal mode is indicated by the flashing star at the top right of the Status display.



Caution!

In Terminal mode, you can operate a device that may be positioned far from your actual location. All access rights that you would also require "locally" are granted to you. It is not always possible to obtain a view of the situation "locally". Use of this operating mode and the execution of any changes to device settings should only be carried out with the utmost caution.

A device with a display and operating unit can also be operated locally. In this case, operation at the device concerned is always faster than operation via Terminal mode. Bear in mind that this may lead to conflicts that may trigger faults or unforeseen events.



In Terminal mode, the MFD device makes its display and operating unit available to the connected device. Only data for the display and the status of the buttons is sent via the connection. This ensures that the local data of the connected device is not destroyed in the event of a communication fault.

Close Terminal mode.

Press the * button to close the Terminal mode.

```
STATION ID: 2
START MODE
```



The * button cannot be assigned to other tasks if you wish to use Terminal mode in your application. Use the * button to change from the visualization to the Status display. Otherwise the Terminal mode menu cannot be reached.

► Press the * button.

This returns you back to your local device.

```
STATION ID: 2
START MODE
```

► Press the **ESC** button twice.

The Status display of the MFD device is active.

```
I ..345..89...
  I           P-
SA 06:47      ST
@ 2 4        STOP
```







The flashing star at the top right of the display is no longer present.

4 Wiring with MFD-Titan

This chapter describes all the functions available with MFD-Titan.

MFD-Titan operation


Buttons for drawing circuit diagrams and function block usage



-  Delete circuit connection, contact, relay or empty line in the circuit diagram
-  Toggle between break and make contact
Connect contacts and relays
Add circuit connections
- 
 - ^ v Change values
Cursor up, down
 - < > Change place
Cursor left, right
- Cursor buttons set as P buttons:
 - < Input P1, ^ Input P2
 - > Input P3, v Input P4
-  Undo setting from previous **OK**
Exit current display or menu
-  Change, add contact/relay
Save setting
-  Terminal mode on/off


Operating principles

The cursor buttons in the MFD-Titan circuit diagram perform three functions. The current mode is indicated by the appearance of the flashing cursor.

- Move
- Entering
- Connect

 In Move mode you can use $\wedge \vee \langle \rangle$ to move the cursor around the circuit diagram in order to select a circuit connection, contact or relay coil.

  Use **OK** to switch to Entry mode so that you can enter or change a value at the current cursor position. If you press **ESC** in Entry mode, MFD-Titan will undo the most recent changes.

 Press **ALT** to switch to Connect mode for wiring contacts and relays. Press **ALT** again to return to Move.

Press **ESC** to leave the circuit diagram and parameter display.



MFD-Titan performs many of these cursor movements automatically. For example, MFD-Titan switches the cursor to Move mode if no further entries or connections are possible at the selected cursor position.

Opening the parameter display for function blocks with contacts or coils

If you specify the contact or coil of a function relay type in Entry mode, MFD-Titan automatically switches from the contact number to the function block parameter display when you press **OK**.

Press \rangle to switch to the next contact or coil field without entering any parameters.

Program

A program is a sequence of commands which the MFD-Titan executes cyclically in RUN mode. An MFD-Titan program consists of the necessary settings for the device, easy-NET, COM-LINK, password, system settings, a circuit diagram and/or function blocks and/or the visualization masks.

The circuit diagram is that part of the program where the contacts are connected together. In RUN mode a coil is switched on and off in accordance with the current flow and the coil function specified.

Function blocks

Function blocks are program elements with special functions. Example: timing relays, time switches, arithmetic function blocks. Function blocks are elements provided with or without contacts and coils as required. In RUN mode the function blocks are processed according to the circuit diagram and the results are updated accordingly.

Examples:

Timing relay = function block with contacts and coils

Time switch = function block with contacts

Visualisation masks

Visualisation masks are the sections of programs containing the display and operator functions.

Relays

Relays are switching devices which are electronically simulated in MFD-Titan. They actuate their contacts according to their designated function. A relay consists of a coil and at least one contact.



Contacts

You modify the current flow with the contacts in the MFD-Titan circuit diagram. Contacts such as make contacts carry a 1 signal when closed and 0 when open. Every contact in the MFD-Titan circuit diagram can be defined as either a make contact or a break contact.

Coils

Coils are the actuating mechanisms of relays. In RUN mode, the results of the wiring are sent to the coils, which switch on or off accordingly. Coils can have seven different coil functions.

Table 6: a Usable contacts

Contact	MFD-Titan display
 Make contact, open in release position	I, Q, M, A, ... Other contacts → Table
 Break contact, closed in release position	\bar{I} , \bar{Q} , \bar{M} , \bar{A} , ... Other contacts → Table

MFD-Titan works with different contacts, which can be used in any order in the contact fields of the circuit diagram.

Table 7: a Contacts

Contact	Make contact	Break contact	Number	Page
Inputs				
Inputs of a network station * = Station address 1 to 8	*I	* \bar{I}	01...12	274
COM slave inputs	1I	1 \bar{I}	01...12	
MFD-Titan input terminal	I	\bar{I}	01...12	–
Cursor button	P	\bar{P}	01...04	–
Network station expansion input terminal * = Station address 1 to 8	*R	* \bar{R}	01...12	274
Input terminal for expansion unit COM slave	1R	1 \bar{R}	01...12	
Input terminal for expansion unit	R	\bar{R}	01...12	–
Bit inputs via the network * = Station address 1 to 8	*RN	* $\bar{R}\bar{N}$	01...32	274

Contact	Make contact	Break contact	Number	Page
Diagnostics inputs				
Expansion network station status * = Station address 1 to 8	*I	* \bar{I}	14	333
Network station short-circuit/overload * = Station address 1 to 8	*I	* \bar{I}	15...16	331
COM slave expansion unit status	1I	1 \bar{I}	14	
COM slave short-circuit/overload	1I	1 \bar{I}	15...16	
Expansion status	I	\bar{I}	14	333
Short-circuit/overload	I	\bar{I}	15...16	331
Short-circuit/overload in expansion network station * = Station address 1 to 8	*R	* \bar{R}	15...16	331
Short-circuit/overload in COM slave expansion	1R	1 \bar{R}	15...16	
Short circuit/overload with expansion	R	\bar{R}	15...16	331
Outputs				
Deactivate backlight of the MFD display	LE	$\bar{L}\bar{E}$	01	
Red LED of MFD display	LE	$\bar{L}\bar{E}$	02	
Green LED of MFD display	LE	$\bar{L}\bar{E}$	03	
MFD-Titan output MFD network station * = Station address 1 to 8	*Q	* \bar{Q}	01...08	274
COM slave output	1Q	1 \bar{Q}	01...08	
MFD-Titan output	Q	\bar{Q}	01...08	—
MFD-Titan output expansion with network station * = Station address 1 to 8	*S	* \bar{S}	01...08	274
Output of COM slave expansion	1S	1 \bar{S}	01...08	
MFD-Titan output expansion	S	\bar{S}	01...08	—
Bit outputs via the network * = Station address 1 to 8	*SN	* $\bar{S}\bar{N}$	01...32	274

Contact	Make contact	Break contact	Number	Page
Other contacts				
Markers	M	\bar{M}	01...96	122
COM slave marker (REMOTE MARKER)	1M	1 \bar{M}	01...96	289
Jump label	:		01...32	229
Diagnostics messages	ID	ID	01...16	283
COM slave diagnostics messages	1ID	1 \bar{ID}	01...16	289
Function blocks				
Analog value comparator function block	A X Q1	A X Q1	X=01...32	150
Arithmetic value overflow (CARRY) function block	AR X CV	$\bar{A}\bar{R}$ X CV	X=01...32	153
Zero arithmetic value (zero) function block	AR X ZE	$\bar{A}\bar{R}$ X ZE	X=01...32	153
Data block comparator function block, error: number of elements exceeded	BC X E1	$\bar{B}\bar{C}$ X E1	X=01...32	157
Data block comparator function block, error: range overlap	BC X E2	$\bar{B}\bar{C}$ X E2	X=01...32	157
Data block comparator function block, error: invalid offset	BC X E3	$\bar{B}\bar{C}$ X E3	X=01...32	157
Data block comparator function block, comparison result	BC X E0	$\bar{B}\bar{C}$ X E0	X=01...32	164
Data block comparator function block, error: number of elements exceeded	BT X E1	$\bar{B}\bar{T}$ X E1	X=01...32	164
Data block transfer function block, error: range overlap	BT X E2	$\bar{B}\bar{T}$ X E2	X=01...32	164
Data block transfer function block, error: invalid offset	BT X E3	$\bar{B}\bar{T}$ X E3	X=01...32	164
Boolean sequence function block, value zero	BV X ZE	$\bar{B}\bar{V}$ X ZE	X=01...32	175

Contact	Make contact	Break contact	Number	Page
Counter function block, upper setpoint value exceeded (Overflow)	C X OF	C̄ X OF	X=01...32	178
Counter function block, lower setpoint value undershot (Fall below)	C X FB	C̄ X FB	X=01...32	178
Counter function block, actual value equal to zero	C X ZE	C̄ X ZE	X=01...32	178
Counter function block, actual value has exceeded counter range (CARRY)	C X CV	C̄ X CV	X=01...32	178
Frequency counter function block, upper setpoint value exceeded (Overflow)	CF X OF	C̄F X OF	X=01...04	185
Frequency counter function block, lower setpoint value undershot (Fall below)	CF X FB	C̄F X FB	X=01...04	185
Frequency counter function block, actual value equal to zero	CF X ZE	C̄F X ZE	X=01...04	185
High-speed counter function block, upper setpoint value exceeded (Overflow)	CH X OF	C̄H X OF	X=01...04	189
High-speed counter function block, lower setpoint value undershot (Fall below)	CH X FB	C̄H X FB	X=01...04	189
High-speed counter function block, actual value equal to zero	CH X ZE	C̄H X ZE	X=01...04	189
High-speed counter function block, actual value has exceeded counter range (CARRY)	CH X CV	C̄H X CV	X=01...04	189
Incremental encoder counter function block, upper setpoint value exceeded (Overflow)	CI X OF	C̄I X OF	X=01...02	195
Incremental encoder counter function block, lower setpoint value undershot (Fall below)	CI X FB	C̄I X FB	X=01...02	195
Incremental encoder counterfunction block, actual value equal to zero	CI X ZE	C̄I X ZE	X=01...02	195

Contact	Make contact	Break contact	Number	Page
Incremental encoder counter function block, actual value has exceeded counter range (CARRY)	CI X CV	CI X CV	X=01...02	195
Comparator function block, less than	CP X LT	CP X LT	X=01...32	200
Comparator function block, equal to	CP X EQ	CP X EQ	X=01...32	200
Comparator function block, greater than	CP X GT	CP X GT	X=01...32	200
Text output function block	D X Q1	D̄ X Q1	X=01...32	202
Data function block	DB X Q1	DB X Q1	X=01...32	203
PID controller, value range of manipulated variable exceeded	DC X LI	DC X LI	X=01...32	205
Receive a variable from a station (Get)	GT X Q1	GT X Q1	X=01...32	205
Seven-day time switch	HW X Q1	HW X Q1	X=01...32	216
Year time switch function block	HY X Q1	HY X Q1	X=01...32	221
Master reset, sets all outputs and markers to zero state	MR X Q1	MR X Q1	X=01...32	232
Operating hours counter function block, set time reached	OT X Q1	OT X Q1	X=01...04	239
Operating hours counter, value overflow (CARRY)	OT X CV	OT X CV	X=01...04	239
Send a variable to the network, enable active Put	PT X Q1	PT X Q1	X=01...32	240
Pulse width modulation, error minimum on or off time exceeded	PW X E1	PW X E1	X=01...02	242
Send date and time via the network (easy-NET) function block	SC X Q1	SC X Q1	X=01	245
Timing relay function block	T X Q1	T X Q1	X=01...32	249

Usable relays and function blocks (coils)

MFD-Titan provides various relay types as well as function blocks and their coils for wiring in a circuit diagram.

Relay/function block	MFD-Titan display	Number	Coil	Parameter
Outputs				
MFD-Titan output relays, network stations (only network master) * = Station address 2 to 8	*Q	01...08	✓	–
MFD-Titan output relay	Q	01...08	✓	–
MFD-Titan output relay expansion, network stations (only network master) * = Station address 2 to 8	*S	01...08	✓	–
MFD-Titan expansion output relay	S	01...08	✓	–
Bit outputs * = Station address 1 to 8	*SM	01...32	✓	–
General coils				
Markers	M	01...96	✓	–
COM slave marker (REMOTE MARKER)	1M	01...96	✓	–
Jump label	:	01...32	✓	–
Function blocks				
Analog value comparator function block	A	01...32	–	✓
Arithmetic function block	AR	01...32	–	✓
Data block comparator, activate	BC X EN	01 32	✓	✓
Transfer data block, trigger coil	BT X T_	01 32	✓	✓
Boolean sequences	BV	01...32	–	✓
Counter function block, counter input	C X C_	X=01...32	✓	✓

Relay/function block	MFD-Titan display	Number	Coil	Parameter
Counter function block, direction	C X D _L	X=01...32	✓	✓
Counter function block, set counter value (Preset)	C X SE	X=01...32	✓	✓
Counter function block, reset counter value	C X RE	X=01...32	✓	✓
Frequency counter function block, activate counter (enable)	CF X EN	X=01...04	✓	✓
High-speed counter function block, direction	CH X D _L	X=01...04	✓	✓
High-speed counter function block, activate counter (enable)	CH X EN	X=01...04	✓	✓
High-speed counter function block, set counter value (Preset)	CH X SE	X=01...04	✓	✓
High-speed counter function block, reset counter value	CH X RE	X=01...04	✓	✓
Incremental encoder counter function block, set counter value (Preset)	CI X SE	X=01...02	✓	✓
Incremental encoder counter function block, activate counter (enable)	CI X EN	X=01...02	✓	✓
Incremental encoder counter function block, reset counter value	CI X RE	X=01...02	✓	✓
Comparator function block	CP	X=01...32	—	✓
Activate text output function block (enable)	D X EN	X=01...32	✓	✓
Data function block, trigger coil	DB X T _L	X=01...32	✓	✓
PID controller, activate	DC X EN	X=01...32	✓	✓
PID controller, activate P component	DC X EP	X=01...32	✓	✓
PID controller, activate I component	DC X EI	X=01...32	✓	✓
PID controller, activate D component	DC X ED	X=01...32	✓	✓
PID controller, accept manual manipulated variable	DC X SE	X=01...32	✓	✓
Activate signal smoothing filter	FT X EN	X=01...32	✓	✓

Relay/function block	MFD-Titan display	Number	Coil	Parameter
Get from network station function block	GT	X=01...32	–	✓
Seven-day time switch	HW	X=01...32	–	✓
Year time switch function block	HV	X=01...32	–	✓
Activate value scaling function block	LS X EN	X=01...32	✓	✓
Master reset function block	MR X T ₋	X=01...32	✓	✓
Activate numerical converter function block	NC X EN	X=01 32	✓	✓
Function block operating hours counter, enable	OT X EN	X=01...04	✓	✓
Operating hours counter function block, reset	OT X RE	X=01...04	✓	✓
Send to the network (easy-NET) function block, trigger	PT X T ₋	X=01...32	✓	✓
Activate pulse width modulation function block	PW X EN	X=01...02	✓	✓
Send time to the network (easy-NET) function block, trigger	SC X T ₋	X=01	✓	–
Activate set cycle time function block	ST X EN	X=01		
Timing relay function block, trigger control coil (enable)	T X EN	X=01...32	✓	✓
Timing relay function block, stop	T X ST	X=01...32	✓	✓
Timing relay function block, reset	T X RE	X=01...32	✓	✓
Activate value limitation function block	VC X EN	X=01...32	✓	✓

The switching behaviour of these relays is set by the coil functions and parameters selected.

The options for setting output and marker relays are listed with the description of each coil function.

The function block coil functions and parameters are listed with the description of each function block type.

Markers, analog operands

Specific markers are available for actively addressing values or inputs/outputs.

Table 8: a Markers

Markers	MFD-Titan display	Number	Value range	Access type r = Read w = Write
Analog operand				
Marker 32 bit	MD	01...96	32 bit	r, w
Marker 16 bit	MW	01...96	16 bit	r, w
Marker 8 bit	ME	01...96	8 bit	r, w
Marker 1 bit	M	0...96	1 bit	r, w
Analog inputs basic unit	IA X	X=01...04	10 bit	r
Analog output	OA X	X=01	10 bit	r, w

When using the COM communication mode, you can make the following data accesses on the slave. Note the REMOTE MARKER SETTING in the following table.

Markers Analog operand	MFD-Titan display	Number	Value range	Access type r = Read w = Write
Marker 32 bit	1MD	01...20	32 bit	r, w
Marker 16 bit	1MW	01...40	16 bit	r, w
Marker 8 bit	1MB	01...80	8 bit	r, w
Marker 1 bit	1M	0...96	1 bit	r, w
Analog inputs basic unit	1IA X	X=01...04	10 bit	r
Analog output	1OA X	X=01	10 bit	r

The following rules apply if you want to use selective binary operands (contacts) from the markers MD, MW, MB:

Table 9: T Composition of the markers

Applies to MD, MW, MB, M	Left = most significant bit, byte, word			Right = least significant bit, byte, word
32 bit	MD1			
16 bit	MW2		MW1	
8 bit	MB4	MB3	MB2	MB1
1 bit	M32 to M25	M24 to M17	M16 to M9	M8 to M1
32 bit	MD2			
16 bit	MW4		MW3	
8 bit	MB8	MB7	MB6	MB5
1 bit	M64 to M57	M56 to M49	M48 to M41	M40 to M33
32 bit	MD3			
16 bit	MW6		MW5	
8 bit	MB12	MB11	MB10	MB9
1 bit	M96 to M89	M88 to M81	M80 to M73	M72 to M65
32 bit	MD4			

Applies to MD, MW, MB, M	Left = most significant bit, byte, word			Right = least significant bit, byte, word
16 bit	MW8		MW7	
8 bit	MB16	MB15	MB14	MB13
32 bit	MD5			
16 bit	MW10		MW9	
8 bit	MB20	MB19	MB18	MB17
...				
...				
...				
32 bit	MD23			
16 bit	MW46		MW45	
8 bit	MB92	MB91	MB90	MB89
32 bit	MD24			
16 bit	MW48		MW47	
8 bit	MB96	MB95	MB94	MB93
32 bit	MD25			
16 bit	MW50		MW49	
32 bit	MD26			
16 bit	MW52		MW51	
...				
...				
32 bit	MD48			
16 bit	MW96		MW95	
32 bit	MD49			
32 bit	MD50			
...				
32 bit	MD95			
32 bit	MD96			

Number formats

MFD makes computations with a signed 31 bit value.

The value range is:

-2 147 483 648 to +2 147 483 647

With a 31 bit value, the 32nd bit is the sign bit.

Bit 32 = state "0" means a positive number.

Example:

0000 0000 0000 0000 0000 0100 0001 0010_{bin} =
412_{hex} = 1042_{dec}

Bit 32 = 1 means a negative number.

Example:

1111 1111 1111 1111 1101 1100 1010 1110_{bin} =
FFFDCAE_{hex} = -9042_{dec}




The marker byte (MB) and marker word (MW) number formats are unsigned.

Circuit diagram display

In the MFD-Titan circuit diagram, contacts and coils of relays are connected up from left to right - from the contact to the coil. The circuit diagram is created on a hidden wiring grid containing contact fields, coil fields and circuit connections. It is then wired up with connections.

- Insert contacts in the four **contact fields**. The first contact field on the left is automatically connected to the voltage.
- Insert the relay coil to be controlled together with its function and designation in the **coil field**. The coil designation consists of the coil name, coil number and function block from the function designation. The coil function defines the method of operation of the coil.
- Every line in the circuit diagram forms a **circuit connection**. With the MFD-Titan up to 256 circuit connections can be wired in a circuit diagram.



- **Connections** are used to produce the electrical contact between relay contacts and the coils. They can be created across several circuit connections. Each point of intersection is a connection.
- The number of free bytes is displayed so that you can recognise how much **memory** is available for the circuit diagram and function blocks.

MFD-Titan circuit diagram display

For greater legibility, the circuit diagram display of the MFD-Titan shows two contacts per circuit connection or one contact plus a coil in series. A total of 16 characters per circuit connection and three circuit connections plus the status line can be displayed simultaneously.

You can move between the contact fields with the < > cursor buttons. The number of the circuit connection and the contact are displayed in the lower status line.

```

I 01----I 02---
Q 01----HVD1Q1
L: 1 C:1 B:7840
  
```



The circuit diagram display performs two functions:

- In STOP mode it is used to edit the circuit diagram.
- In RUN mode it is used to check the circuit diagram using the Power flow display.

Saving and loading programs

MFD-Titan provides you with two ways of saving circuit diagrams externally:

- Saving to a memory card
- Saving on a PC with EASY-SOFT-PRO.

Once they have been saved, programs can be reloaded into MFD-Titan, edited and run.

All program data is saved in MFD-Titan. In the event of a power failure the data will be retained until the next time it is overwritten or deleted.

Memory card

Each memory card contains a circuit diagram which is inserted into the MFD-Titan interface.

The MFD-Titan behaves in the following manner in accordance with the type and setting.

Requirement:

A valid circuit diagram must be stored on the card.

Variants with display:

- ▶ Go to the CARD menu and load the circuit diagram into the unit in STOP mode via CARD → DEVICE.

CARD MODE setting → page 312.

Variants without display:

If the circuit diagram on the card is different to the circuit diagram in the device, the program from the card is loaded as soon as the power supply is turned on.

EASY-SOFT-PRO


EASY-SOFT-PRO is a PC program for creating, testing and managing MFD-Titan programs, visualization applications and circuit diagrams.

Completed programs are exchanged between the PC and MFD-Titan via the connection cable. Once you have transferred a circuit diagram, you can start MFD-Titan straight from your PC.

Working with contacts and relays

In MFD-Titan circuit diagrams, the switches, buttons and relays of conventional circuit diagrams are connected up using input contacts and relay coils.

Conventional circuit




MFD-Titan circuit diagram

MFD-Titan connection

- Connect make contact S1 to input terminal I1
 - Connect make contact S2 to input terminal I2
 - Connect load H1 to output Q1
- S1 or S2 switch on H1.

MFD-Titan circuit diagram:




First specify which input and output terminals you wish to use in your circuit.

The signal states on the input terminals are detected in the circuit diagram with the input contacts I, R* or RN. The outputs are switched in the circuit diagram with the output relays Q, S or SN.


Entering and changing contacts and relay function coils

Contacts

An input contact is selected in the MFD-Titan via the contact name and contact number.




Example: input contact




A contact of a function relay is assigned the name of the function block, the number and the contact function.

Example: contact of comparator function block



If the contact on a network station is used, the address of the station is placed before the contact name.


Example: contact of an easy-NET station




Coils

With a relay coil or function block select the coil function, coil or function block name, coil or function block number as well as coil of the function block. With coils of an easy-NET network station, the network address is selected before the coil name.

Example: relay coil output



Relay coil for timing relay function block with control coil



Relay coil of an easy-NET station



A full list of all the contacts and relays is given in the overview starting on Page 114.

I 01 Values for contacts and coil fields are changed in Entry mode. The value to be changed flashes.



MFD-Titan proposes the contact **I 01** or the coil **C 01** when starting entries in an empty field.

- ▶ Move the cursor using the < > ^v buttons to a contact or coil field.
- ▶ Press **OK** to switch to Entry mode.
- ▶ Use < > to select the position you wish to change, or press **OK** to jump to the next position.
- ▶ Use ^v to modify the value at the position.

MFD-Titan will leave Entry mode when you press < > or **OK** to leave a contact field or coil field.

In the contact field to change I 01 to I 02	In the coil field change C 01 to S 00
I 01 I 01 I 02	C 01 C 01 C 01 C 00
Q > 02 ^	J < M > 02 v
M or 03	S T or 03
HW OK 04	R C or OK
C 05	P :
T .	D .
P .	S :
D
S 99
:
...
> or OK	> or OK

Deleting contacts and coils

- ▶ Move the cursor using the buttons < > ^ v to a contact or coil field.
- ▶ Press **DEL**.

The contact or the coil will be deleted, together with any connections.

Changing make contacts to break contacts

Every contact in the MFD-Titan circuit diagram can be defined as either a make contact or a break contact.

- ▶ Switch to Entry mode and move the cursor over the contact name.
- ▶ Press **ALT**. The make contact will change to a break contact.
- ▶ Press **OK** 2 x to confirm the change.




Figure 66: Change contact I 03 from make to break

Creating and modifying connections

Contacts and relay coils are connected with the arrow in the Connect mode. MFD-Titan displays the cursor in this mode as an arrow.

- ▶ Use < > ^ v to move the cursor onto the contact field or coil field from which you wish to create a connection.



Do not position the cursor on the first contact field. At this position the **ALT** button has a different function (Insert circuit connection).

- ▶ Press **ALT** to switch to Connect mode.
- ▶ Use < > to move the diagonal arrow between the contact fields and coil fields and ^ v to move between circuit connections.
- ▶ Press **ALT** to leave Connect mode.

MFD-Titan will leave the mode automatically when you move the diagonal arrow onto a contact field or coil field which has already been assigned.



In a circuit connection, MFD-Titan automatically connects contacts and the terminal to the relay coil if there are no empty fields in-between.

Never work backwards. You will learn why wiring backwards does not work in Section "Effects on the creation of the circuit diagram" on Page 326.




Figure 67: Circuit diagram with five contacts, invalid

When wiring more than four contacts in series, use one of the 96 M marker relays.




Figure 68: Circuit diagram with M marker relay

Deleting connections

- ▶ Move the cursor onto the contact field or coil field to the right of the connection that you want to delete. Press **ALT** to switch to Connect mode.
- ▶ Press **DEL**.

MFD-Titan will delete a connection. Closed adjacent connections will be retained.

If several circuit connections are connected to one another, MFD-Titan first deletes the vertical connection. If you press **DEL** again, it will delete the horizontal connection as well.



You cannot delete connections that MFD-Titan has created automatically.

Close the delete operation with **ALT** or by moving the cursor to a contact or coil field.

Inserting and deleting a circuit connection

The MFD-Titan circuit diagram display shows three of the 256 circuit connections on the display at the same time. MFD-Titan automatically scrolls up or down the display to show hidden circuit connections – even empty ones – if you move the cursor past the top or bottom of the display.

A new circuit connection is added below the last connection or inserted above the cursor position:

- ▶ Position the cursor on the **first** contact field of a circuit connection.
- ▶ Press **ALT**.

The existing circuit connection with all its additional connections is “shifted” downwards. The cursor is then positioned directly in the new circuit connection.





Figure 69: Inserting a new circuit connection

Saving circuit diagrams

▶ Press the **ESC** button to save a circuit diagram.



The menu on the left appears in the status line.

▶ Press **OK** to save the entire program, circuit diagram and function blocks.


After saving you will be in the CIRCUIT DIAGRAM menu.

Aborting circuit diagram entry

▶ If you want to exit without saving the circuit diagram, press **ESC**.

▶ Use the cursor buttons ^v to select the CANCEL menu.

▶ Press **OK**.




The circuit diagram is closed without saving.

Searching for contacts and coils

You can search for contacts and coils in the following way:


▶ Press **ESC**. Use the cursor buttons ^v to select the SEARCH menu.

▶ Press **OK**.



▶ Select the desired contact, coil and number with the v and < > cursor buttons.

With function relays, select the function block, the number and the coil.



▶ Confirm the search with the **OK** button.

```

I 01----I 02---
Q 01----HY01Q1J
L: 1 C:1 B:7140

```

The device will search for the first occurrence of the contact or coil from the start of the search to the end of the circuit diagram. If no contact or coil is found, the MFD-Titan circuit diagram editor will continue the search from the start of the circuit diagram. If a contact or coil is found, the MFD-Titan editor automatically jumps to the respective field in the circuit diagram.

“Go to” a circuit connection

The MFD-Titan circuit diagram editor provides a Go To function in order to enable fast access to a circuit connection.

- ▶ Press **ESC** and use the ^v cursor buttons to select the GO TO menu.
- ▶ Press **OK**.
- ▶ Select the required circuit connection (L... ..) with the ^v cursor buttons.

```

I 01----I 02---
Q 01----HY01Q1J
L: 1 C:1 B:7140

```

The first contact on the circuit connection is always indicated.

- ▶ Press **OK**.

```

I 01----I 02---
Q 01----HY01Q1J
L: 1 C:1 B:7140

```

The cursor remains stationary at the required circuit connection contact L 1.

Deleting the circuit connection


MFD-Titan only removes empty circuit connections (without contacts or coils).

- ▶ Delete all the contacts and coils from the circuit connection.
- ▶ Position the cursor on the first contact field of the empty circuit connection.
- ▶ Press **DEL**.

The subsequent circuit connection(s) will be "pulled up" and any existing links between circuit connections will be retained.

Switching via the cursor buttons

With MFD-Titan, you can also use the four cursor buttons as hard-wired inputs in the circuit diagram.



The buttons are wired in the circuit diagram as contacts P 01 to P 04. The P buttons can be activated and deactivated in the → System menu.

The P buttons can also be used for testing circuits or manual operation. These button functions are also useful for servicing and commissioning purposes.

Example 1

A lamp at output Q1 is switched on and off via inputs I1 and I2 or by using cursor buttons ^ and v.




Figure 70: Switch Q1 via I1, I2, ^, or v

Example 2

Input I1 is used to control output Q1. I5 switches over to cursor operation and via M 01 disconnects the circuit connection I 01.





Figure 71: I5 switches over to the cursor buttons.



The P buttons are only detected as switches in the Status menu.

The Status menu display shows whether the P buttons are used in the circuit diagram.



Displayed on the Status display:

- P: button function wired and active
- P2: button function wired, active and P2 button ^ pressed
- P-: button function wired and not active
- Empty field: P buttons not used

Checking the circuit diagram

MFD-Titan contains a built-in measuring device enabling you to monitor the switching states of contacts, relays and function block coils during operation.

► Create the small parallel circuit below and save it.




Figure 72: Parallel circuit

- Switch MFD-Titan to RUN mode via the main menu.
- Return to the circuit diagram display.

You are now unable to edit the circuit diagram.



If you switch to the circuit diagram display and are unable to modify a circuit diagram, first check whether MFD-Titan is in STOP mode.

The circuit diagram display performs two functions depending on the mode:

- STOP: Creation of the circuit diagram
- RUN: Power flow display

► Switch on I3.




Figure 73: Power flow display

In the power flow display, energized connections are thicker than non-energized connections.

You can follow a current-carrying connection across all circuit connections by scrolling the display up and down.

The bottom right of the power flow display indicates that the controller is in RUN mode. (→ Section "Power flow display with Zoom function", Page 87).



The power flow display will not show signal fluctuations in the millisecond range. This is due to the inherent delay factor of LCD displays.

Function block editor

The MFD-Titan has the FUNCTION RELAYS menu in order to edit the function blocks without circuit diagrams. The function blocks are an inherent component of the program.

Calling the function blocks via the FUNCTION RELAYS menu




Figure 74: Explanation of the function block display

Display of the function blocks for editing





Figure 75: Function block display during editing

Editing function blocks

- ▶ Go to the FUNCTION RELAYS menu.
- ▶ Press the **OK** button.



The following display appears if no function blocks are present.

The cursor flashes.

- ▶ Press the **OK** button.

```
AR01
L:001      B:1988
```

The editor for inputting a function block is displayed.

Select the desired function block and number with the ^\< > cursor buttons.

```
AR01 ADD      +
CF10          +
T 18 ?X      -
L:001      B:6488
```

The functions of the individual function blocks are explained in the individual function block descriptions on the following pages.

This display appears if there are function blocks present.

The function blocks are created in the sequence in which they were edited.

Calling up function blocks from the circuit diagram

If you enter a function block parameter from the circuit diagram, you will jump from the circuit diagram editor to the function block editor automatically. Once you have assigned the parameters, you will return to the position where you left the circuit diagram with Save or Cancel. The operation is carried out in the same way as with circuit diagram operation.

```
T 01 X? M:S +
>I1 20:30
>I2
QV>MD96
L:001      B:1808
```

Example: timing relay function block

Function block:	Timing relay
Switch function:	On-delayed with random switching
Time range:	M:S (Minute:Seconds)
Set time >I1:	20 min 30 s
Actual time QV>:	Copied to MD96

Assigning operands to an > input of a function block



Only the following variables can be assigned to the input of a function block:

- Constants, e.g.: 42,
- Markers such as MD, MW, MB,
- Analog output QA,
- Analog inputs IA,
- All output variables of the function blocks ...QV>

Assigning operands to a QV > output of a function block



Only markers such as MD, MW, MB or the analog output QA can be assigned to a variable output of a function block.

Deleting operands on the function block inputs/ outputs

Position the cursor on the required operand.

- ▶ Press the **DEL** button.

```
T 01 X? M:S +
>I1 ■■:30
>I2
QV> MD96
```

The operand is deleted.

```
T 01 X? M:S +
>I1 ■■
>I2
QV>MD96
L:001 B:7808
```

Deleting an entire function block

Ensure that all contacts and coils of the function block are deleted.

- ▶ Select the required function block from the list.

```
AR01 ADD +
CP10 +
T 18 ?X -
L:002 B:7808
```

In this case CP10.

- ▶ Press the **DEL** button.

```
AR01 ADD      +
T 18 ?X      -
L:001
```

The function block is deleted.

Checking function blocks

You can check function blocks in the same way as circuit diagrams. The device is in RUN mode.

Checking from the circuit diagram:

Position the cursor on a contact or a coil of the required function block. Press **OK**.

```
T 01 X? M:S +
>I1 20:30
>I2
QV> 14:42
.. EN..
```

The function block will be displayed, in this case a timing relay.

- >I1= set time of the timing relay,
- QV> = the actual value is 14 minutes 42 seconds,
- The enable coil is actuated, EN is visible.

If a coil of a function block is actuated in RUN mode, the coil name with the coil designation will appear on the display.

Checking the function block via the function block editor:

You access the function block list via the FUNCTION RELAYS menu.

Select the required function block:

```
AR01 ADD      +
CF10          +
T 18 ?X      -
L:001      RUN
```

In this case the arithmetic function block AR01 in the Adder mode.

► Press the **OK** button.

```
AR01 ADD      +
>I1 20056
>I2 1095
QV> 21151
```

The function block is presented with the actual values and the result.

Displaying the operands when checking the function blocks:

If you want to know which operands are used on the function block inputs and outputs when checking the function block, press the **ALT** button on the displayed value.

```
ARD1 ADD      +
>I1 C 01QV>
>I2  1095
QV> MD 56
```

The operand is displayed.

- >I1 = Actual value of counter C 01
- >I2 = Constant 1095
- QV> = Marker double word MD56

► Press the **ALT** button again.

```
ARD1 ADD      +
>I1  20056
>I2  1095
QV> 21151
```

The display shows the values.

Coil functions

You can set the coil function to determine the switching behaviour of relay coils. The following coil functions are assigned to all coils:

Table 10: Coil function

MFD-Titan display	Coil function	Example
C	Contacteur function	C001, C002, C504, C:01, CM07, ..
J	Impulse relay function	J003, JM04, J008, JS07, J:01, ..
S	Set	S008, SM02, SD03, SS04, ..
R	Reset	R004, RM05, RD07, RS03, ..
J̄	Contacteur function with negated result	J006, JM96, ..
J↑	Cycle pulse with rising edge	JM01, ..
J↓	Cycle pulse with falling edge	JM42, ..



The function block descriptions state which coil functions can be used with the function block concerned.

Rules for wiring relay coils

Relay with contactor function



A coil should only be used once in order to retain an overview of the relay states. However, retentive coil functions such as \mathbb{S} , \mathbb{R} , \mathbb{J} can be used several times.

The following applies to non-retentive coil functions such as \mathbb{C} (contactor), \mathbb{N} (negated contactor), \mathbb{I} , \mathbb{F} (rising and falling edge detection): Each coil must only be used once. The last coil in the circuit diagram determines the status of the relay.

Exception: When working with jumps, the same coil can be used twice.

Coil with contactor function \mathbb{C}

The output signal follows immediately after the input signal and the relay acts as a contactor.




Figure 76: Signal diagram of contactor function

Impulse relay \mathbb{J}

The relay coil switches whenever the input signal changes from 0 to 1. The relay behaves like a bistable flip-flop.




Figure 77: Signal diagram of impulse relay

A coil is automatically switched off if the power fails and if STOP mode is active. Exception: Retentive coils retain signal 1 (see → Section "Retention", Page 316).

"Set" S and "Reset" R coil function

The "Set" S and "Reset" R coil functions are normally used in pairs.

The relay picks up when the coil is set (A) and remains in this state until it is reset (B) by the coil function.

The supply voltage is switched off (C), the coil does not have a retentive effect.




Figure 78: Signal diagram of "Set" and "Reset"

If both coils are triggered at the same time, priority is given to the coil in the circuit diagram with the higher circuit connection number. This is shown in the above signal diagram in section B.




Figure 79: Simultaneous triggering of Q 01

In the example above, the reset coil has priority with simultaneous triggering of the set and reset coils.

Coil negation (inverse contactor function) \bar{I}

The output signal is simply an inversion of the input signal; the relay operates like a contactor with contacts that have been negated. If the coil is triggered with the 1 state, the coil switches its make contacts to the 0 state.




Figure 80: Signal diagram of inverse contactor function

Rising edge evaluation (cycle pulse) \uparrow

If the coil is only meant to switch on a rising edge, this function will be applied. With a change in the coil state from 0 to 1, the coil switches its make contacts to the 1 state for one cycle.




Figure 81: Signal diagram of cycle pulse with rising edge

Falling edge evaluation (cycle pulse) \downarrow

If the coil is only meant to switch on a falling edge, this function will be applied. With a change in the coil state from 1 to 0, the coil switches its make contacts to the 1 state for one cycle.




Figure 82: Signal diagram of cycle pulse with falling edge



A set coil is automatically switched off if the power fails and if the device is in STOP mode. Exception: Retentive coils retain signal 1 (see → Section "Retention", Page 316).

Function blocks

The function blocks are used to simulate some of the devices used in conventional open-loop and closed-loop control systems. MFD-Titan provides the following function blocks:

- Analog value comparator/threshold controller (only with MFD-Titan 24 V DC variants)
- Arithmetic,
 - addition, subtraction, multiplication, division
- Compare data blocks
- Transfer data blocks
- Boolean sequences
- Counters,
 - up and down counters with upper and lower threshold values, preset
 - frequency counters,
 - high-speed counters,
 - incremental encoder counters
- Comparators
- Text, output freely editable texts, enter values
- Data function block
- PID controllers
- Smoothing filters
- Value scaling
- Pulse width modulator
- Read (GET) data from the easy-NET
- Time switches,
 - weekday/time
 - year, month, day (date),
- Numerical converters
- Master reset
- Operating hours counter
- Write (PUT) data to the easy-NET
- Synchronisation of date and time via the easy-NET
- Timing relays
 - on-delayed,
 - on-delayed with random switching,

- off-delayed, also retriggerable
- off-delayed with random switching, also retriggerable
- on and off delayed,
- on and off delayed with random switching,
- single pulse,
- synchronous flashing,
- asynchronous flashing,
- Set cycle time
- Value limitation

The following applies to function blocks:



The most recent actual values are cleared if the power supply is switched off or if MFD-Titan is switched to STOP mode. Exception: Retentive data keeps its state (→ Section "Retention", Page 316).

The most recent actual values are transferred to the operands every cycle. The data function block is an exception.



Attention!

The following applies to RUN mode: MFD-Titan processes the function block after a pass through the circuit diagram. The last state of the coils is used for this.



If you want to prevent other people from modifying the parameters, change the access enable symbol from "+" to "-" when creating the circuit diagram and setting parameters and protect the circuit diagram with a password.



Attention!

The function blocks are designed so that a function block output can be assigned directly to the input of another function block. This enables you always to have an overview of which value is transferred.

If different data formats are used, such as if the first function block uses 32 bits and an 8-bit or 16-bit format is used for further processing, sign value errors or value errors may occur when transferring from one function block to another one.

Analog value comparator/threshold value switch

MFD-Titan provides 32 analog value comparators from A 01 to A 32.

With an analog value comparator or threshold value switch you can, for example, compare analog input values with a setpoint value.

All MFD-Titan DC variants have analog inputs.

The following comparisons are possible:

- Function block input $\gt I1$ **greater than or equal to, equal to, less than or equal to** function block input $\gt I2$
- Using the factors $\gt F1$ and $\gt F2$ as inputs enables you to amplify and adjust the values of the function block inputs.
- The $\gt OS$ function block input can be used as an offset for the $\gt I1$ input.
- The $\gt HV$ function block input is used for the positive and negative switching hysteresis of the input $\gt I2$. The contact switches according to the selected comparison mode of the function block.




Figure 83: MFD-Titan circuit diagram with analog value comparators

```
A 02 GT      +
>I1
>F1
>I2
>F2
>OS
>HY
```

Parameter display and parameter set for analog value comparators:

A 02	Function block analog value comparator number 02
GT	Greater than mode
+	Appears in the parameter display
>I1	Comparison value 1
>F1	Gain factor for >I1 ($>I1 = >F1 \times \text{value}$)
>I2	Comparison value 2
>F2	Gain factor for >I2 ($>I2 = >F2 \times \text{value}$)
>OS	Offset for the value of >I1
>HY	Switching hysteresis for value >I2 (Value HY applies to positive and negative hysteresis.)

Inputs

The function block inputs >I1, >F1, >I2, >F2, >OS and >HY can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Analog value comparator operating modes

Parameter	Function
GT	>I1 greater than >I2
EQ	>I1 equal to >I2
LT	>I1 less than >I2

Contacts

A 01Q1 to A 32Q1

Memory requirement of the analog value comparator

The analog value comparator function block requires 68 bytes of memory plus 4 bytes per constant on the function block inputs.




Figure 84: Signal diagram of the analog value comparator

- 1: actual value on >I1
- 2: setpoint value on >I2
- 3: hysteresis on >HV
- 4: switching contact (make contact)
- 5: offset for value >I1

6: actual value plus offset

- Range A: Compare $\text{I1} > \text{I2}$
 - The actual value I1 increases.
 - The contact switches when the actual reaches the setpoint value.
 - The actual value changes and falls below the value of the setpoint value minus the hysteresis.
 - The contact goes to the normal position.
- Range B: Compare $\text{I1} < \text{I2}$
 - The actual value drops.
 - The contact switches if the actual reaches the setpoint value.
 - The actual value changes and rises above the value of the setpoint value plus hysteresis.
 - The contact goes to the normal position.
- Range C: Compare $\text{I1} > \text{I2}$ with offset
 - This example behaves as described in Range A. The offset value is added to the actual value.
- Comparison $\text{I1} = \text{I2}$
 - The contact switches on:
 - If the setpoint is exceeded with the actual value rising.
 - If the setpoint is undershot with the actual value decreasing.
 - The contact switches off:
 - If the hysteresis limit is exceeded with the actual value rising.
 - If the hysteresis limit is undershot with the actual value decreasing.

Arithmetic function block

MFD-Titan provides 32 arithmetic function blocks AR01 to AR32.

The arithmetic function block is used for arithmetic operations. All four basic arithmetic operations are supported:

- add,
- subtract,
- multiply,
- divide.

Inputs

The function block inputs $\rangle I1$ and $\rangle I2$ can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Actual value ...QV>

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

An arithmetic function block is not wired in the circuit diagram.

```
AR32 ADD      +
  \I1
  \I2
  QV>
```

Parameter display and parameter set for arithmetic function blocks:

AR32	Arithmetic function block number 32
ADD	Addition mode
+	Appears in the parameter display
\I1	First value
\I2	Second value
QV>	Result of the addition

Only constants can be modified in the parameter display of a function block.

Arithmetic function block modes

Parameter	Function
ADD	Addition of summand value $\rangle I1$ plus summand $\rangle I2$
SUB	Subtraction of minuend $\rangle I1$ minus subtrahend $\rangle I2$
MUL	Multiplication of factor $\rangle I1$ by factor $\rangle I2$
DIV	Division of dividend $\rangle I1$ by divisor $\rangle I2$

Value range

The function block operates in the integer range from $-2\,147\,483\,648$ to $+2\,147\,483\,647$.

Behaviour when value range is exceeded

- The function block sets the switching contact AR..CY to status 1.
- The function block retains the value of the last valid operation. The value is zero when it is first called.

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

AR01CY to AR32CY: CARRY overflow bit, value on function block output greater than or less than the value range.

AR01ZE to AR32ZE: ZERO zero bit, value on function block output is equal to zero.

Coils

The arithmetic function block does not have any coils.

Memory requirement of the arithmetic function block

The arithmetic function block requires 40 bytes of memory plus 4 bytes per constant on the function block inputs.

Addition

$$42 + 1000 = 1042$$

$2\,147\,483\,647 + 1 =$ last valid value of this arithmetic operation, due to overflow (CARRY)

AR..CY = Status 1

$$-2048 + 1000 = -1048$$

Subtraction

$$1134 - 42 = 1092$$

$-2147483648 - 3$ = last valid value of this arithmetic operation, due to overflow (CARRY)

AR..CY = Status 1

$$-4096 - 1000 = -5096$$

$$-4096 - (-1000) = -3096$$

Multiplication

$$12 \times 12 = 144$$

1000042×2401 = last valid value of this arithmetic operation, due to overflow (CARRY)

Correct value = 2401100842

AR..CY = Status 1

$$-1000 \times 10 = -10000$$

Division

$$1024: 256 = 4$$

1024: 35 = 29 (the places after the decimal point are omitted.)

1024: 0 = last valid value of this arithmetic operation, due to overflow (CARRY)

(mathematically correct: "Infinite")

AR..CY = Status 1

$$-1000: 10 = -100$$

$$1000: -10 = -100$$

$$-1000: (-10) = 100$$

$$10: 100 = 0$$

Data block comparator

MFD-Titan provides 32 function blocks BC01 to BC32 for comparing values of two consistent marker ranges. The comparison is in byte format. The following marker types can be compared:

- MB,
- MW,
- MD.

The function block is enabled in the circuit diagram.





Figure 85: MFD-Titan circuit diagram with enabling of data block comparator function block



Parameter display and parameter set for a data block comparator:

BC27	Data block comparator function block number 27
+	Appears in the parameter display
>I1	Start of comparison range 1
>I2	Start of comparison range 2
>NO	Number of elements to be compared in bytes per range. Value range 1 to + 383

Only constants can be modified in the parameter display of a function block.

According to the operands at the inputs >I1 and >I2 the following operating modes are possible:

Inputs

The function block inputs >I1, >I2 and >NO can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Specifying the marker range without offset

If MB, MW or MD markers are specified at both $\>I1$ and $\>I2$ the number of the markers is the start of comparison range 1 or 2.

Specifying the marker range with offset

If you wish to work with an offset, specify one of the following variables at function block input $\>I1$ or $\>I2$:

- Constant,
- Actual value ..QV of a function block,
- Analog input IA.,
- Analog output QA..

The value at the input is taken as the offset to marker MB01.

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- -: Access disabled

Contacts

BC01E1 to BC32E1: the number of comparison elements exceeds one of the comparison ranges.

BC01E2 to BC32E2: the two comparison ranges overlap.

BC01E3 to BC32E3: the specified offset of the comparison ranges is outside of the permissible range.

BC01EQ to BC32EQ: output of the comparison result. Only valid if the BC..EN enable has been triggered.
 Status 0 = Comparison ranges not equal,
 Status 1 = Comparison ranges equal.

Coils

BC01EN to BC32EN: Enable coil of the data block comparator function block.

Memory requirement of the data block comparator function block

The data block comparator function block requires 48 bytes of memory plus 4 bytes per constant on the function block inputs.

Function of the data block comparator function block

The data block comparator function block compares two consistent data blocks.

The comparison is active if the BC..EN (enable) is triggered.



No data blocks are compared if an error is present.

The error outputs E1, E2 and E3 are evaluated regardless of the status of the enable.

Example:

Comparison of marker blocks, definition of marker ranges direct

Two marker blocks are to be compared. Block 1 starts at MB10, Block 2 at MB40. Each block is 10 bytes long.

Parameters of BC01 function block:

Comparison range 1: >I1 MB10

Comparison range 2: >I2 MB40

Number of bytes: >N0 10

Comparison range 1	Value of marker range 1 (decimal)	Comparison range 2	Value of marker range 2 (decimal)
MB10	39	MB40	39
MB11	56	MB41	56
MB12	88	MB42	88
MB13	57	MB43	57
MB14	123	MB44	123
MB15	55	MB45	55
MB16	134	MB46	134
MB17	49	MB47	49
MB18	194	MB48	194
MB19	213	MB49	213

The comparison result of the function block BC01 is: BC01EQ = 1, the data block ranges have the same content.

Example:

Comparison of marker blocks, definition of a marker range with offset

Two marker blocks are to be compared. Block 1 starts at MB15, Block 2 at MB65. Each block is 4 bytes long.

Parameters of BC01 function block:

Comparison range 1: >I1 MB15

Comparison range 2: >I2 64

Number of bytes: >NO 4

Marker MB01: 1



Comparison range 2: Constant 64:
MB01 plus Offset: 1 + 64 = 65 → MB65.

Comparison range 1	Value of marker range 1 (decimal)	Comparison range 2	Value of marker range 2 (decimal)
MB15	45	MB65	45
MB16	62	MB66	62
MB17	102	MB67	102
MB18	65	MB68	57

The comparison result of the function block BC01 is: BC01EQ = 0, the data block ranges do not have the same content.

MB18 are MB68 not identical.

Example:

Comparison of marker blocks, definition of a marker range in a different format.

Two marker blocks are to be compared. Block 1 starts at MB60, Block 2 at MD80. Each block is 6 bytes long.

Parameters of BC01 function block:

Comparison range 1: >I1 MB60

Comparison range 2: >I2 MD80

Number of bytes: >NO 6



The comparison is in byte format. MD80 has 4 bytes. Therefore the first two bytes of MD81 are also compared.

Comparison range 1	Value of marker range 1 (decimal/binary)	Comparison range 2	Value of marker range 2 (decimal/binary)
MB60	45/ 00101101	MD80 (Byte 1, LSB)	1097219629/ 010000010110011000111110 00101101
MB61	62/ 00111110	MD80 (Byte 2)	1097219629/ 0100000101100110 00111110 00101101
MB62	102/ 01100110	MD80 (Byte 3)	1097219629/ 01000001 01100110 0011111000101101
MB63	65/ 01000001	MD80 (Byte 4, MSB)	1097219629/ 01000001 011001100011111000101101
MB64	173/ 10101101	MD81 (Byte 1, LSB)	15277/ 00111011 10101101
MB65	59/ 00111011	MD81 (Byte 2)	15277/ 00001000 10101101

The comparison result of the function block BC01 is: BC01EQ = 0, the data block ranges do not have the same content.

MB65 and MD81 (Byte 2) are not identical.

Example:

Comparison of marker blocks, range violation error.

Two marker blocks are to be compared. Block 1 starts at MD60, Block 2 at MD90. Each block is 30 bytes long.

Parameters of BC01 function block:

Comparison range 1: >I1 MD60

Comparison range 2: >I2 MD90

Number of bytes: >NO 30



The comparison is in byte format. MD90 to MD96 is 28 bytes. The number of bytes is 30 bytes.

The error message "Number of comparison elements exceeds one of the comparison ranges" is output.

BC01E1 is 1.

Example

Comparison of marker blocks, range overlap error.

Two marker blocks are to be compared. Block 1 starts at MW60, Block 2 at MW64. Each block is 12 bytes long.

Parameters of BC01 function block:

Comparison range 1: `>I1 MW60`

Comparison range 2: `>I2 MW64`

Number of bytes: `>N0 12`



The comparison is in byte format. MW60 to MW64 is 8 bytes. The number of bytes is 12 bytes.

The error message "Comparison ranges overlap" is output.

BC01E2 is 1.

Example:

Comparison of marker blocks, invalid offset error.

Two marker blocks are to be compared. Block 1 starts at MW40, Block 2 at MW54. The block length is specified by the value of the counter C 01QV.

Parameters of BC01 function block:

Comparison range 1: `>I1 MW40`

Comparison range 2: `>I2 MW54`

Number of bytes: `>N0 C 01QV`



The value of C 01QV is 1024. This value is too big. The value at `>N0` can be between 1 and +383.

The message "The specified offset of the comparison ranges is outside of the permissible range" is output.

BC01E3 is 1.

Data block transfer

MFD-Titan is provided with 32 function blocks BT01 to BT32 for transferring values from one marker range (Copy data). The marker ranges can be overwritten with a particular value (data initialisation). The following marker types can be transferred and overwritten:

- MB,
- MW,
- MD.

The function block is enabled in the circuit diagram.





Figure 86: MFD-Titan circuit diagram with enabling of transfer data block function block



Parameter display and parameter set for a data block transfer function block:

BT01	Data block transfer function block number 07
INI	INI mode, initialise marker ranges
+	Appears in the parameter display
>I1	Source range start
>I2	Destination range start
>NO	Number of elements to be written in bytes per range. Value range 1 to + 383

Only constants can be modified in the parameter display of a function block.

Operating modes of the transfer data block function block

Parameter	Function
INI	Initialise marker ranges
CPV	Copy marker ranges

Inputs

The function block inputs $\>I1$, $\>I2$ and $\>NO$ can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Specifying the marker range without offset

If MB, MW or MD markers are specified both at $\>I1$ and at $\>I2$, the number of markers defines the source or destination range.

Specifying a marker range with offset

If you wish to work with an offset, specify one of the following variables at function block input $\>I1$ or $\>I2$

- Constant,
- Actual value ..QV of a function block,
- Analog input IA..,
- Analog output QA..

The value at the input is taken as the offset to marker MB01.

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- -: Access disabled

Contacts

BT01E1 to BT32E1: the number of marker bytes exceeds the source or destination range.

BT01E2 to BT32E2: source and destination range overlap. Only valid for CPY mode, copy marker ranges.

BT01E3 to BT32E3: the specified offset is invalid.

Coils

BT01T_ to BT32T_: trigger coil of the transfer data block function block.

Memory requirement of the transfer data block function block

The transfer data block function block requires 48 bytes of memory plus 4 bytes per constant at the function block inputs.

Function of the transfer data block function block

The transfer data block comparator function block has two operating modes.



No data blocks are initialised or copied if an error occurs.

Initialising INI marker ranges

There is one source range and one destination range. The source range is specified at $\text{I}1$. The length of the source range is one byte. The destination range is specified at $\text{I}2$. The length of the destination range is specified by the number of bytes at the NI input.

The content of the source range is transferred to the marker bytes in the destination range.

The function block executes the transfer if there is a rising edge from 0 to 1 at the BT..T_ (Trigger) coil.

The error outputs E1, E2 and E3 are evaluated regardless of the status of the trigger.

Example:

Initialising marker blocks, specifying marker ranges directly

The value of marker byte 10 is to be transferred to marker bytes 20 to 29.

Parameters of BT01 function block:

Source range: >I1 MB10

Destination range:>I2 MB20

Number of bytes: >NO 10

Source range	Value of source marker range (decimal)	Destination range	Value of destination marker range (decimal)
MB10	123	MB20	123
		MB21	123
		MB22	123
		MB23	123
		MB24	123
		MB25	123
		MB26	123
		MB27	123
		MB28	123
		MB29	123

After a rising edge from 0 to 1 at coil BT01T_ the value 123 is present in the marker bytes MB20 to MB29.

Example:

Initialisation of marker blocks, definition of a range with offset

The content of marker byte MB15 is to be transferred to marker bytes MB65 to MB68.

Parameters of BT01 function block:

Source range: >I1 MB15

Destination range: >I2 64

Number of bytes: >NO 4

Marker MB01: 1



Destination range: Constant 64:
Marker MB01 plus Offset: 1 + 64 = 65 → MB65.

Source range	Value of source marker range (decimal)	Destination range	Value of destination marker range (decimal)
MB15	45	MB65	45
		MB66	45
		MB67	45
		MB68	45

After a rising edge from 0 to 1 at coil BT01T_ the value 45 is present in the marker bytes MB65 to MB68.

Example:

Initialisation of marker blocks, definition of a range in a different format.

The value of marker byte MB60 is to be transferred to MD80 and MD81.

Parameters of BT01 function block:

Source range: >I1 MB60

Destination range: >I2 MD80

Number of bytes: > >NO 8



The transfer is in byte format. MD80 has 4 bytes and MD81 has 4 bytes, which means that <NO has the value 8.

Comparison range 1	Value of marker range 1 (decimal/binary)	Comparison range 2	Value of marker range 2 (decimal/binary)
MB60	45/ 00101101	MD80 (Byte 1, LSB)	757935405/ 0010110100101101 00101101 00101101
		MD80 (Byte 2)	757935405/ 0010110100101101 00101101 00101101
		MD80 (Byte 3)	757935405/ 0010110100101101 00101101 00101101
		MD80 (Byte 4, MSB)	757935405/ 00101101 001011010010110100101101
		MD81 (Byte 1, LSB)	757935405/ 0010110100101101 00101101 00101101
		MD81 (Byte 2)	757935405/ 0010110100101101 00101101 00101101
		MD81 (Byte 3)	757935405/ 00101100 01011011 0010110100101101
		MD81 (Byte 4, MSB)	757935405/ 00101101 001011010010110100101101

After a rising edge from 0 to 1 at coil BT01T_ the value 757935405 is present in the marker double words MD80 and MD81.

Example:

Transfer of marker byte, range violation error.

The value of marker byte MB96 is to be transferred to MD93, MD94, MD95 and MD96. The length is 16 bytes.

Parameters of BT01 function block:

Source range: >I1 MD96

Destination range: >I2 MD93

Number of bytes: >NO 16



The transfer is in byte format. MD93 to MD96 is 16 bytes. 18 bytes were incorrectly defined as length.

The error message "Number of elements exceeds the destination range" is output.

BT01E1 is 1.

Example:

Transfer of marker bytes, invalid offset error.

The value of marker byte MB40 is to be transferred to MW54 and subsequent marker words. The block length is specified by the value of the counter C 01QV.

Parameters of BC01 function block:

Comparison range 1: $\gt I1 MB40$

Comparison range 2: $\gt I2 MW54$

Number of bytes: $\gt N0 C 01QV$



The value of C 01QV is 788. This value is too big. The value at $\gt N0$ can be between 1 and +383.

The message "The specified offset of the destination range is outside of the permissible range" is output.

BT01E3 is 1.

CPY mode, copy marker ranges

There is one source range and one destination range. The source range is specified at $\gt I1$. The destination range is specified at $\gt I2$. The length of the source and destination range is specified by the number of bytes at the $\gt N0$ input.

The content of the source range is copied to the marker bytes in the destination range.

The function block executes the copy operation if there is a rising edge from 0 to 1 at the BT..T_ (Trigger) coil.

The error outputs E1, E2 and E3 are evaluated regardless of the status of the trigger.

Example:

Copy of marker blocks, definition of marker ranges direct

The content of marker bytes 10 to 19 is to be transferred to marker bytes 20 to 29.

Parameters of BT01 function block:

Source range: >I1 MB10

Destination range: >I2 MB20

Number of bytes: >NO 10

Source range	Value of source marker range (decimal)	Destination range	Value of destination marker range (decimal)
MB10	42	MB20	42
MB11	27	MB21	27
MB12	179	MB22	179
MB13	205	MB23	205
MB14	253	MB24	253
MB15	17	MB25	17
MB16	4	MB26	4
MB17	47	MB27	47
MB18	11	MB28	11
MB19	193	MB29	193

After a rising edge from 0 to 1 at coil BT01T_ the content of MB10 to MB19 is copied to the marker bytes MB20 to MB29.

Example:

Copying of marker blocks, definition of a marker range with offset

The content of marker bytes MB15 to MB18 is to be copied to marker bytes MB65 to MB68.

Parameters of BT01 function block:

Source range: >I1 MB15
 Destination range: >I2 64
 Number of bytes: >NO 4
 Marker MB01: 1



Destination range: Constant 64:
 Marker MB01 plus Offset: 1 + 64 = 65 → MB65.

Source range	Value of source marker range (decimal)	Destination range	Value of destination marker range (decimal)
MB15	68	MB65	68
MB16	189	MB66	189
MB17	203	MB67	203
MB18	3	MB68	3

After a rising edge from 0 to 1 at coil BT01T_ the content of MB15 to MB18 is copied to the marker bytes MB65 to MB68.

Example:

Copying of marker blocks, definition of a marker range in a different format.

The value of marker byte MD60 to MD62 is to be copied to MW40 to MW45.

Parameters of BT01 function block:

Source range: >I1 MD60
 Destination range: >I2 MW40
 Number of bytes: >NO 12



The transfer is in byte format. 12 bytes are to be copied. The range MD60 to MD62 is 12 bytes. This is copied to the range MW40 to MW45.

Comparison range 1	Value of marker range 1 (decimal/binary)	Comparison range 2	Value of marker range 2 (decimal/binary)
MD60	866 143 319/ 0011 0011 1010 0000 0100110001010111	MW40 (LSW)	19543/ 0011 0011 1010 0000 0100110001010111
MD60	866 143 319/ 00110011 10100000 0100110001010111	MW41 (MSW)	13216/ 00110011 10100000 0100110001010111
MD61	173 304 101/ 0000 1010 0101 0100 0110100100100101	MW42 (LSW)	26917/ 0000 1010 0101 0100 0110100100100101
MD61	173 304 101/ 0000101001010100 0110100100100101	MB43 (MSW)	2644/ 0000101001010100 0110100100100101
MD62	982 644 150/ 0011 1010 1001 0001 1111010110110110	MB44 (LSW)	62902/ 0011 1010 1001 0001 1111010110110110
MD62	982 644 150/ 0011101010010001 1111010110110110	MB45 (MSW)	14993/ 0011101010010001 1111010110110110

After a rising edge from 0 to 1 at coil BT01T_ the values are copied to the appropriate range.

Example:

Copying of marker bytes, destination range violation error.

The value of marker bytes MB81 to MB96 is to be transferred to MD93, MD94, MD95 and MD96. The length is 16 bytes.

Parameters of BT01 function block:

Source range: >I1 MB81

Destination range: >I2 MD93

Number of bytes: >NO 16



The transfer is in byte format. MD93 to MD96 is 16 bytes. 18 bytes were incorrectly defined as length.

The error message "Number of elements exceeds the destination range" is output.

BT01E1 is 1.

Example

Comparison of marker blocks, range overlap error.

12 bytes are to be copied starting from MW60. MW64 is specified as destination address.

Parameters of BT01 function block:

Comparison range 1: >I1 MW60

Comparison range 2: >I2 MW64

Number of bytes: >NO 12



The copy operation is in byte format. MW60 to MW64 is 8 bytes. The number of bytes is 12 bytes.

The error message "Both ranges overlap" is output.

BC01E2 is 1.

Example:

Copying of marker bytes, invalid offset error.

The value of marker word MW40 is to be copied to MW54 and subsequent marker words. The block length is specified by the value of the counter C 01QV.

Parameters of BT01 function block:

Comparison range 1: >I1 MW40

Comparison range 2: >I2 MW54

Number of bytes: >NO C 01QV



The value of C 01QV is 10042. This value is too big. The value at >NO can be between 1 and +383.

The message "The specified offset of the destination range is outside of the permissible range" is output.

BT01E3 is 1.

Boolean sequence

MFD-Titan provides 32 function blocks from BV01 to BV32 for Boolean operations with values.

The following possibilities are provided by the Boolean sequence function block:

- Masking out of particular bits from values,
- Bit pattern recognition,
- Bit pattern modification.

A Boolean sequence function block is not wired in the circuit diagram.

```
BV27 AND      +
  >I1
  >I2
  QV>
```

Parameter display and parameter set for Boolean sequence function block:

BV27	Boolean sequence function block number 27
AND	AND operation mode
+	Appears in the parameter display
>I1	First value
>I2	Second value
QV>	Result of the sequence

Only constants can be modified in the parameter display of a function block.

Operating modes of the Boolean sequence function block

Parameter	Function
AND	AND operation
OR	OR operation
XOR	Exclusive OR operation
NOT	Negation of the Boolean value of >I1

Value range

32 bit signed value

Inputs

The function block inputs I1 and I2 can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Actual value ...QV>

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- -: Access disabled

Contacts

BV01ZE to BV32ZE: ZERO zero bit, value on output function block is equal to zero

Coils

The Boolean sequence function block does not have coils.

Memory requirement Boolean sequence function block

The Boolean sequence function block requires 40 bytes of memory plus 4 bytes per constant on the function block inputs.

Function of Boolean sequence function block

The function block creates the sequence depending on the operating mode.



If you sequence a negative value, e.g.: -10_{dec} , the CPU will form the two's complement of the amount.

Example:

$-10_{\text{dec}} = 1000\ 0000\ 0000\ 0000\ 0000\ 0000\ 0000\ 1010_{\text{bin}}$

Two's complement =

$1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 1111\ 0110_{\text{bin}} =$

$\text{FFFFFF}_{\text{hex}}$

Bit 32 is the signed bit and remains as 1.

AND Boolean sequence

Value $\rangle \mathbf{I1}$: $13219_{\text{dec}} = 0011\ 0011\ 1010\ 0011_{\text{bin}}$

Value $\rangle \mathbf{I2}$: $57193_{\text{dec}} = 1101\ 1111\ 0110\ 1001_{\text{bin}}$

Result QV>: $4897_{\text{dec}} = 0001\ 0011\ 0010\ 0001_{\text{bin}}$

OR Boolean sequence

Value $\rangle \mathbf{I1}$: $13219_{\text{dec}} = 0011\ 0011\ 1010\ 0011_{\text{bin}}$

Value $\rangle \mathbf{I2}$: $57193_{\text{dec}} = 1101\ 1111\ 0110\ 1001_{\text{bin}}$

Result QV>: $65515_{\text{dec}} = 1111\ 1111\ 1110\ 1011_{\text{bin}}$

XOR Boolean sequence

Value $\rangle \mathbf{I1}$: $13219_{\text{dec}} = 0011\ 0011\ 1010\ 0011_{\text{bin}}$

Value $\rangle \mathbf{I2}$: $57193_{\text{dec}} = 1101\ 1111\ 0110\ 1001_{\text{bin}}$

Result QV>: $60618_{\text{dec}} = 1110\ 1100\ 1100\ 1010_{\text{bin}}$

NOT Boolean sequence

Value $\>I1$: $13219_{dec} =$
 $00000000000000000011001110100011_{bin}$

Value $\>I2$: Omitted

Result QV>: $-13220_{dec} =$
 $11111111111111111100110001011100_{bin}$

The NOT sequence operates according to the following rules:

$\>I1$, positive value

Negate value of $\>I1$ and subtract 1:

$$-|\>I1| - 1 = \>I2$$

$\>I1$, Negative value

Value of $\>I1$ and subtract 1:

$$|\>I1| - 1 = \>I2$$

Counters

MFD-Titan provides 32 up/down counters from C 01 to C 32. The counter relays allow you to count events. You can enter upper and lower threshold values as comparison values. The contacts will switch according to the actual value. To specify a start value, for example, counting from the value 1200, this can be implemented using a "C.." counter.

The "C.." counters are cycle time dependent.

Wiring of a counter

You integrate a counter into your circuit in the form of a contact and coil. The counter relay has different coils and contacts.



To prevent unpredictable switching states, use each coil of a relay once only in the circuit diagram.




Figure 87: MFD-Titan circuit diagram with counter relay

```

C 20      +
>SH
>SL
>SV
QV>

```

Parameter display and parameter set for the counter relay:

C 20	Counter relay function block number 20
+	Appears in the parameter display
>SH	Upper setpoint
>SL	Lower setpoint
>SV	Defined actual value (Preset)
QV>	Actual value in RUN mode

In the parameter display of a counter relay you change setpoint values and/or the preset value and the enabling of the parameter display.

Value range

The function block operates in the integer range from -2 147 483 648 to 2 147 483 647.

Behaviour when value range is exceeded

The function block sets the switching contact C .. CY to the status 1 and retains the value of the last valid operation.



The counter C counts every rising edge on the counter input. If the value range is exceeded, the switching contact C ..CY switches to status 1 for one cycle per rising edge detected.

Inputs

The function block inputs $\>SH$, $\>SL$ and $\>SV$ can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Actual value ...QV>

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

- C 01OF to C 32OF: Actual value \geq upper setpoint
- C 01FB to C 32FB: Actual value \leq Lower setpoint value
- C 01ZE to C 32ZE: Actual value = zero
- C 01CY to C 32CY: Value range exceeded

Coils

- C 01C_ to C 32C_: counter coils, count with rising edge
- C 01D_ to C 32D_: count direction definition, status 0 = count upwards, status 1 = count downwards
- C 01RE to C 32RE: Reset actual value to zero
- C 01SE to C 32SE: accept defined actual value with rising edge.

Memory requirement of the counter relay

The counter relay function block requires 52 bytes of memory plus 4 bytes per constant on the function block inputs.

Retention

Counter relays can be operated with retentive actual values. The number of retentive counter relays can be selected in the SYSTEM → RETENTION menu.

The retentive actual value requires 4 bytes of memory.

If a counter relay is retentive, the actual value is retained when the operating mode changes from RUN to STOP as well as when the power supply is switched off.

If MFD is started in RUN mode, the counter relay operates with the retentively saved actual value.

Function of the counter function block




Figure 88: Signal diagram of counter

- 1: counter coil C..C_
- 2: upper setpoint value >SH
- 3: preset actual value >SV
- 4: lower setpoint value >SL
- 5: counting direction, coil C..D_
- 6: accept preset actual value, coil C..SE
- 7: reset coil C..RE

8: contact (make contact) C..OF upper setpoint value reached, exceeded

9: contact (make contact) C..FB lower setpoint value reached, undershot

10: actual value equal to zero

11: out of value range

- Range A:
 - The counter has the value zero.
 - The contacts C..ZE (actual value equal to zero) and C..FB (lower setpoint value undershot) are active.
 - The counter receives counter values and increases the actual value.
 - C..ZE drops out as well as C..FB and also when the lower setpoint value is reached.
- Range B:
 - The counter counts upwards and reaches the upper setpoint value. The “upper setpoint value reached” contact C..OF becomes active.
- Range C:
 - The coil C..SE is briefly actuated and the actual value is set to the preset actual value. The contacts go to the respective position.
- Range D:
 - The counting direction coil C..D_ is actuated. If counting pulses are present, downward count is initiated.
 - If the lower setpoint value is undershot, the contact C..FB becomes active.
- Range E:
 - The reset coil C..RE is activated. The actual value is set to zero.
 - The contact C..ZE is active.
- Range F:
 - The actual value goes outside the value range of the counter.
 - The contacts become active according to the direction of the values (positive or negative).

High-speed counters

MFD-Titan provides various high-speed counter functions. These counter function blocks are coupled directly to the digital inputs. The high-speed counter functions are only available with MFD-DC inputs.

The following functions are possible:

- Frequency counters, measure frequencies **CF..**
- High-speed counters, count high-speed signals **CH..**
- Incremental encoder counters, count two-channel incremental encoder signals **CI..**

The high-speed digital inputs are I1 to I4.

The following wiring rules apply:

- I1: CF01 or CH01 or CI01
- I2: CF02 or CH02 or CI01
- I3: CF03 or CH03 or CI02
- I4: CF04 or CH04 or CI02



Every digital input I .. may only be used once by the CF, CH, CI function blocks.

The incremental encoder requires an input pair.

Example:

- I1: high-speed counter CH01
- I2: frequency counter CF02
- I3: incremental encoder channel A CI02
- I4: incremental encoder channel B CI02



Attention!

If an input is used several times, the last counter in the function block list is executed:

Example: function block list in the FUNCTION RELAYS menu:

```
CI01  
CF01  
CH01
```

All function blocks access digital input I1.

Only CH01 supplies the correct value.

Frequency counters

MFD-Titan provides four frequency counters which are CF01 to CF04. The frequency counters can be used for measuring frequencies. You can enter upper and lower threshold values as comparison values. The high-speed frequency counters are hardwired to the digital inputs I1 to I4.

The CF.. frequency counters operate independently of the cycle time.

Counter frequency and pulse shape

The maximum counter frequency is 3 kHz.

The minimum counter frequency is 4 Hz.

The signals must be square waves. The mark-to-space ratio is 1:1.

Measurement method

The pulses on the input are counted for one second irrespective of the cycle time, and the frequency is determined. The result of the measurement is made available as a value to the function block output CF..QV.

Wiring of a counter

The following assignment of the digital inputs apply.

- I1 counter input for the counter CF01
- I2 counter input for the counter CF02
- I3 counter input for the counter CF03
- I4 counter input for the counter CF04



To prevent unpredictable switching states, use each coil of a relay once only in the circuit diagram. Use a counter input for the CF, CH, CI counters only once.

Wiring of a frequency counter

You integrate a frequency counter into your circuit in the form of a contact and coil. The counter relay has different coils and contacts.




Figure 89: MFD-Titan circuit diagram with frequency counter

```
CF01      -
>SH
>SL
QV>
```

Parameter display and parameter set for frequency counter:

CF01	Frequency counter function block number 01
-	Does not appear in the parameter display
>SH	Upper setpoint
>SL	Lower setpoint
QV>	Actual value in RUN mode

In the parameter display of a counter relay you change setpoint values and/or the preset value and the enable of the parameter display.

Value range

The function block operates in the integer range from 0 to 5000
 1 kHz 1 = 1000

Behaviour when value range is exceeded

The value range cannot be exceeded as the maximum measured value is less than the value range.

Inputs

The function block inputs >SH and >SL can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ...QV> of another function block

Actual value ...QV>

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

- CF010F to CF040F: Actual value \geq Upper setpoint
- CF01FB to CF04FB: Actual value \leq Lower setpoint
- CF01ZE to CF04ZE: Actual value = Zero

Coils

CF01EN to CF04EN: enable of the counter with coil status = 1.

Memory requirement of the frequency counter

The frequency counter function block requires 40 bytes of memory plus 4 bytes per constant on the function block inputs.

Retention

The frequency counter does not retain actual values, as the frequency is remeasured continuously.

Function of the frequency counter function block




Figure 90: Signal diagram of frequency counter

- 1: counter input I1 to I4
- 2: upper setpoint value $\setminus S^H$
- 3: lower setpoint value $\setminus S^L$
- 4: enable CF..EN
- 5: upcontact (make contact) CF..OF upper setpoint value exceeded
- 6: contact (make contact) CF..FB lower setpoint value undershot
- 7: actual value equal to zero CF..ZE
- t_g : gate time for the frequency measurement

- The first measurements are made after the CF..EN enable signal has been activated. The value is output after the gate time has timed out.
- The contacts are set in accordance with the measured frequency.
- If the CF..EN enable signal is removed, the output value is set to zero.

High-speed counters

MFD-Titan provides four high-speed up/down counters CH01 to CH04 for use. The high-speed frequency counters are hardwired to the digital inputs I1 to I4. These counter relays allow you to count events independently of the cycle time. You can enter upper and lower threshold values as comparison values. The contacts will switch according to the actual value. To specify a start value, for example, counting from the value 1989, this can be implemented using a CH .. counter.

The CH.. counters operate independently of the cycle time.

Counter frequency and pulse shape

The maximum counter frequency is 3 kHz.

The signals must be square waves. The mark-to-space ratio is 1:1.

Wiring of a counter

The following assignment of the digital inputs apply.

- I1 counter input for the counter CH01
- I2 counter input for the counter CH02
- I3 counter input for the counter CH03
- I4 counter input for the counter CH04



To prevent unpredictable switching states, use each coil of a relay once only in the circuit diagram. Use a counter input for the CF, CH, CI counters only once.

You integrate a counter into your circuit in the form of a contact and coil. The counter relay has different coils and contacts.




Figure 91: MFD-Titan circuit diagram with high-speed counter

```

CH01      +
>SH
>SL
>SV
QV>
    
```

Parameter display and parameter set for high-speed counters:

CH01	High-speed counter function block number 01
+	Appears in the parameter display
>SH	Upper setpoint
>SL	Lower setpoint
>SV	Defined actual value (Preset)
QV>	Actual value in RUN mode

In the parameter display of a counter relay you change setpoint values and/or the preset value and enable of the parameter display.

Value range

The function block operates in the integer range from -2147483648 to 2147483647.

Behaviour when value range is exceeded

- The function block sets the switching contact CH..CY to status 1.
- The function block retains the value of the last valid operation.



Counter CH counts every rising edge on the counter input. If the value range is exceeded, the switching contact CH ..CY switches to status 1 for one cycle per rising edge detected.

Inputs

The function block inputs $\>SH$, $\>SL$ and $\>SV$ can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Actual value ..QV>

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01



The actual value is only cleared in RUN mode with a specific reset signal.

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

- CH01OF to CH04OF:Actual value \geq Upper setpoint
- CH01FB to CH04FB:Actual value \leq Lower setpoint
- CH01ZE to CH04ZE:Actual value = Zero
- CH01CY to CH04CY:Value range exceeded

Coils

- CH01EN to CH04EN: enable of the counter
- CH01D to CH04D: count direction definition,
Status 0 = count upwards,
Status 1 = count downwards
- CH01RE to CH04RE: reset actual value to zero
- CH01SE to CH04SE: accept preset actual value with rising edge.

Memory requirement of the high-speed counter

The high-speed counter function block requires 52 bytes of memory plus 4 bytes per constant on the function block inputs.

Retention

High-speed counter relays can be operated with retentive actual values. The number of retentive counter relays can be selected in the SYSTEM → RETENTION menu.

If a counter relay is retentive, the actual value is retained when the operating mode changes from RUN to STOP as well as when the power supply is switched off.

If MFD is started in RUN mode, the counter relay operates with the retentively saved actual value.




Figure 92: Signal diagram of high-speed counter

- 1: counter input I1 to I4
- 2: upper setpoint value $\gg H$
- 3: preset actual value $\gg V$
- 4: lower setpoint value $\gg L$
- 5: enable of the counter CH..EN
- 6: counting direction, coil CH..D

7: accept preset actual value, coil CH..SE

8: reset coil CH..RE

9: contact (make contact) CH..OF upper setpoint value reached, exceeded

10: contact (make contact) CH..FB lower setpoint value reached, undershot

11: contact (make contact) CH..ZE actual value equal to zero

12: out of value range

- Range A:
 - The counter has the value zero.
 - The contacts CH..ZE (actual value equal to zero) and CH..FB (lower setpoint value undershot) are active.
 - The counter receives counter values and increases the actual value.
 - CH..ZE drops out as well as CH..FB after the lower setpoint value is reached.
- Range B:
 - The counter counts upwards and reaches the upper setpoint value. The contact "upper setpoint value" CH..OF becomes active.
- Range C:
 - The coil CH..SE is briefly actuated and the actual value is set to the preset actual value. The contacts go to the respective position.
- Range D:
 - The counting direction coil CH..D is actuated. If counting pulses are present, downward count is initiated.
 - If the lower setpoint value is undershot, the contact CH..FB becomes active.
- Range E:
 - The reset coil CH..RE is activated. The actual value is set to zero.
 - The contact CH..ZE is active.
- Range F:
 - The actual value goes outside the value range of the counter.
 - The contacts become active according to the direction of the values (positive or negative).

High-speed incremental encoder counters

MFD-Titan provides two high-speed incremental encoder counters CI01 and CI02. The high-speed counter inputs are hardwired to the digital inputs I1, I2, I3 and I4. These counter relays allow you to count events independently of the cycle time. You can enter upper and lower threshold values as comparison values. The contacts will switch according to the actual value. You can use a CI.. counter if you wish to define a start value.

The CI.. counters operate independently of the cycle time.

Counter frequency and pulse shape

The maximum counter frequency is 3 kHz.

The signals must be square waves. The mark-to-space ratio is 1:1. The signals on channels A and B must lead or lag by 90°. Otherwise the counting direction cannot be determined.



Double the number of pulses are counted as a result of the internal method of operation of the incremental encoder. The incremental encoder evaluates the rising and falling edges. This ensures that the pulse count is not affected by oscillation of a signal edge. If the number of pulses are required, divide the value by two.

Wiring of a counter

The following assignment of the digital inputs apply:

- I1 counter input for the counter CI01 channel A
- I2 counter input for the counter CI01 channel B
- I3 counter input for the counter CI02 channel A
- I4 counter input for the counter CI02 channel B



To prevent unpredictable switching states, use each coil of a relay once only in the circuit diagram.

Use a counter input for the CF, CH, CI counters only once.

You integrate a counter into your circuit in the form of a contact and coil. The counter relay has different coils and contacts.



Figure 93: MFD-Titan circuit diagram with high-speed incremental encoder counter

```

CID1      +
>SH
>SL
>SV
QV>
  
```

Parameter display and parameter set for high-speed incremental encoder counter:

CID1	High-speed incremental encoder counter function block number 01
+	Appears in the parameter display
>SH	Upper setpoint
>SL	Lower setpoint
>SV	Defined actual value (Preset)
QV>	Actual value in RUN mode

In the parameter display of a counter relay you change setpoint values and/or the preset value and the enable of the parameter display.

Value range

The function block operates in the integer range from -2 147 483 648 to 2 147 483 647.

Each pulse is counted twice.

Example: value at CI..QV>= 42000

The counter has counted 21 000 pulses.

Behaviour when value range is exceeded

- The function block sets the switching contact CI..CY to status 1.
- The function block retains the value of the last valid operation.



Counter CI counts every rising edge on the counter input. If the value range is exceeded, the switching contact CI ..CY switches to status 1 for one cycle per rising edge detected.

Inputs

The function block inputs $\rangle SH$, $\rangle SL$ and $\rangle SW$ can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Actual value ..QV>

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01



The actual value is only erased in RUN mode with a selective reset signal.

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

- CI01OF to CI02OF:Actual value \geq Upper setpoint
- CI01FB to CI02FB:Actual value \leq Lower setpoint
- CI01ZE to CI02ZE:Actual value = Zero
- CI01CY to CI02CY:Value range exceeded

Coils

- CI01EN to CI02EN:Counter enable
- CI01RE to CI02RE:Reset actual value to zero
- CI01SE to CI02SE:Accept preset actual value with rising edge.

Memory requirement of the counter relay

The high-speed counter function block requires 52 bytes of memory plus 4 bytes per constant on the function block inputs.

Retention

High-speed counter relays can be operated with retentive actual values. The number of retentive counter relays can be selected in the SYSTEM → RETENTION menu.

If a counter relay is retentive, the actual value is retained when the operating mode changes from RUN to STOP as well as when the power supply is switched off.

If MFD is started in RUN mode, the counter relay operates with the retentively saved actual value.

Function of the high-speed incremental encoder counter function block




Figure 94: Signal diagram of high-speed incremental encoder counter

- 1: counter input channel A
- 2: counter input channel B
- 3: upper setpoint value $\gg H$
- 4: preset actual value $\gg V$
- 5: lower setpoint value $\gg L$
- 6: counter enable

- 7: accept preset actual value, coil CI..EN
- 8: reset coil CI..RE
- 9: contact (make contact) CI..OF upper setpoint value reached, exceeded
- 10: contact (make contact) CI..FB lower setpoint value reached, undershot
- 11: contact (make contact) CI..ZE actual value equal to zero
- 12: contact (make contact) CI..CY value range exceeded or undershot
- Range A:
 - The counter counts upwards.
 - The value leaves the lower threshold value and reaches the upper value.
- Range B:
 - The count direction changes to a downward count.
 - The contacts switch in accordance with the actual value.
- Range C:
 - The enable signal is set to 0. The actual value becomes 0.
- Range D:
 - The rising edge on the accept preset value coil sets the actual value to the preset value.
- Range E:
 - The reset pulse sets the actual value to zero.
- Range F:
 - The actual value goes outside the value range of the counter.
 - The contacts become active according to the direction of the values (positive or negative).

Comparators

Comparator function blocks allow you to compare constants and variables with one another.

The following comparisons are possible:

Function block input		Function block input
>I1	Greater than	>I2
	Equal to	
	Less than	





Figure 95: MFD-Titan circuit diagram with comparator



Parameter display and parameter set for the comparator function block:

CP02	Function block analog value comparator number 02
+	Appears in the parameter display
>I1	Comparison value 1
>I2	Comparison value 2

Inputs

The function block inputs >I1 and >I2 can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Contacts

- CP01LT to CP32LT, (less than)
 Contact (make contact) switches to status 1, if the value on >I1 is less than the value on >I2; >I1 < >I2.
- CP01EQ to CP32EQ, (equal to)
 Contact (make contact) switches to status 1, if the value on >I1 is equal to the value on >I2; >I1 = >I2.
- CP01GT to CP32GT, (greater than)

Contact (make contact) switches to status 1, if the value at $\text{I}1$ is greater than the value at $\text{I}2$; $\text{I}1 > \text{I}2$.

Memory requirement of the counter relay

The comparator function block requires 32 bytes of memory plus 4 bytes per constant on the function block inputs.

Text output function block

The MFD device provides 32 function blocks that operate in an easy800 as text output function blocks. These function blocks work in the MFD device as contacts and coils in the same way as in an easy800. In the MFD device, texts, actual value output and setpoint entry are implemented using the appropriate visualization elements.



The text function block was adopted from the easy800 so that the circuit diagram is compatible. This simplifies the processing of easy800 programs. easy800 programs with text function blocks can be loaded directly onto the MFD-Titan, either from the memory card or from EASY-SOFT-PRO. The contacts and coils are processed in the same way as in an easy800.

However, texts are not output.

The function block requires the entire memory, even if no texts have been transferred.



Do not use the text function block on the MFD device. This will use up memory unnecessarily with unused functions!




Figure 96: MFD-Titan circuit diagram with a text output function block

Contacts

A contact has been assigned to the text output function block.

D01Q1 to D32Q1, text function block is active.

Coils

D01EN to D32EN, enable of the text function block

Memory requirement of the text output function block

The text output function block function block requires 160 bytes of memory. This is irrespective of the text size.

Data function block

The data function block allows you to selectively save a value. Setpoint values for the function block can be saved in this manner.





Figure 97: MFD-Titan circuit diagram with data function block:



Parameter display and parameter set for the data function block:

DB16	Data block function block number 16
+	Appears in the parameter display
>I1	Input value
QV>	Actual value

Inputs

The function block input >I1 can be assigned the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8

- IA03: terminal I11
- IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Output

The function block output QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Contacts

DB01Q1 to DB32Q1

Contact (make contact) DB..Q1 switches to status 1 if the trigger signal is set to 1.

Coils

DB01T_ to DB32T_, acceptance of the value at >I1 with a rising edge.

Memory requirement of the data function block

The data block function block requires 36 bytes of memory plus 4 bytes per constant at the function block input.

Retention

Data function blocks can be operated with retentive actual values. The quantity can be selected in the SYSTEM → RETENTION menu.

Function of the data function block




Figure 98: Signal diagram of data function block

- 1: value at input >I1
- 2: trigger coil DB..T_
- 3: value on DB..QV>



The value at input >I1 is only transferred with a rising trigger edge to an operand (e.g.: MD42, QA01) on output >QV>. Output QV retains its value until it is overwritten.

PID controller

MFD-Titan provides 32 PID controllers DC01 to DC32. The PID controllers allow you to implement closed-loop control functions.



Caution!

A knowledge of closed-loop control is required in order to use the PID controllers.

The control system must be familiar so that the PID controller can function correctly.



Three separate manipulated variables can be output. One manipulated variable can be output via an analog output. Two manipulated variables can be processed via two pulse-width modulated outputs. It is therefore useful to run up to three closed-loop controllers per program simultaneously. Projects can be structured by selecting the controller number.

Example: Project with 3 devices

Program 1: Controller DC 10, 11

Program 2: Controller DC20, 21 and 22

Program 3: Controller DC30

Wiring a PID controller

You integrate a PID controller in your circuit as a contact and coil.




Figure 99: MFD-Titan circuit diagram with PID controller

```

DC02 UNP      +
>I1
>I2
>KP
>TN
>TV
>TC
>MV
GV>
  
```

Parameter display and parameter set for PID controller:

DC02	PID controller function block number 02
UNP	Unipolar mode
+	Appears in the parameter display
>I1	Setpoint of PID controller
>I2	Actual value of PID controller
>KP	Proportional gain K_p
>TN	Reset time T_n
>TV	Rate time T_v

>TC	Scan time
>MV	Manual manipulated variable
QV>	Manipulated variable

In the parameter display of a PID controller you set the operating mode, the setpoints and enable the parameter display.

Operating modes of the PID controller

Parameter	Manipulated variable is output as
UNP	Unipolar 12-bit value 0 to +4095
EIP	Bipolar 13-bit value (signed 12-bit value) -4096 to +4095

Inputs

The function block inputs >I1, >I2, >KP, >TN, >TV, >TC and >MV can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Actual value ...QV>

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Value range for inputs and outputs

		Value range	Resolution/unit
>I1	Setpoint of PID controller	-32768 to +32767	
>I2	Actual value of PID controller,	-32768 to +32767	
>KP	Proportional gain K_p	0 to 65535	in -- /%
>TN	Reset time T_n	0 to 65535	in 100/ms
>TV	Rate time T_v	0 to 65535	in 100/ms
>TC	Scan time	0 to 65535	in 100/ms
>MV	Manual manipulated variable	-4096 to +4095	
QV>	Manipulated variable	0 to 4095 (unipolar) -4096 to +4095 (bipolar)	

Example:

		Value at input	Value processed in the function block.
>KP	Proportional gain K_p	1500	15
>TN	Reset time T_n	250	25 s
>TV	Rate time T_v	200	20 s
>TC	Scan time	500	50 s
>MV	Manual manipulated variable	500	500

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

DC01LI to DC32LI, value range of the manipulated variable exceeded.

Coils

- DC01EN to DC32EN: Enable PID controller;
- DC01EP to DC32EP: Activate proportional component;
- DC01EI to DC32EI: Activate integral component;

- DC01ED to DC32ED: Activate the differential component;
- DC01SE to DC32SE: Activate the manual manipulated variable

Memory requirement of the PID controller

The PID controller function block requires 96 bytes of memory plus 4 bytes per constant on the function block input.

Function of the PID controller function block

The PID controller works on the basis of the PID algorithm. According to this, the manipulated variable $Y(t)$ is the result of the calculation of the proportional component, an integral component and a differential component.



The PID controller must be enabled so that it can work. Coil DC..EN is active. If coil DC..EN is not active, the entire PID controller is deactivated and reset. The manipulated variable is set to zero.

The corresponding coils for the P, I and D components must be active.

Example: If only coils DC..EP and DC..EI are activated, the controller operates as a PI controller.



The device calculates the manipulated variable every time the scan time T_c has elapsed. If the scan time is zero, the manipulated variable is calculated every cycle.

Equation of PID controller:

$$Y(t) = Y_P(t) + Y_I(t) + Y_D(t)$$

$Y(t)$ = calculated manipulated variable with scan time t

$Y_P(t)$ = Value of the proportional component of the manipulated variable with scan time t

$Y_I(t)$ = Value of the integral component of the manipulated variable with scan time t

$Y_D(t)$ = Value of the differential component of the manipulated variable with scan time t

The proportional component in the PID controller

The proportional component Y_P is the product of the gain (K_p) and the control difference (e). The control difference is the difference between the setpoint (X_s) and the actual value (X_i) at a specified scan time. The equation used by the device for the proportional component is as follows:

$$Y_P(t) = K_p \times [X_s(t) - X_i(t)]$$

K_p = proportional gain

$X_s(t)$ = Setpoint with scan time t

$X_i(t)$ = Actual value with scan time t

The integral component in the PID controller

The integral component Y_I is proportional to the sum of the control difference over time. The equation used by the device for the integral component is as follows:

$$Y_I(t) = K_p \times T_c/T_n \times [X_s(t) - X_i(t)] + Y_I(t-1)$$

K_p = proportional gain

T_c = Scan time

T_n = Integration time (also known as reset time)

$X_s(t)$ = Setpoint with scan time t

$X_i(t)$ = Actual value with scan time t

$Y_I(t-1)$ = Value of the integral component of the manipulated variable with scan time $t-1$

The differential component in the PID controller

The differential component Y_D is proportional to the change in the control difference. So as to avoid step changes or jumps in the manipulated variable caused by the differential behaviour when the setpoint is changed, the change of the actual value (the process variable) is calculated and not the change in the control difference. This is shown in the following equation:

$$Y_D(t) = K_p \times T_v/T_c \times (X_i(t-1) - X_i(t))$$

K_p = proportional gain

T_c = Scan time

T_v = Differential time of the control system (also called the rate time)

$X_i(t)$ = Actual value with scan time t

$X_i(t-1)$ = Actual value with scan time $t - 1$

Scan time T_c

Scan time T_c determines the duration of the interval in which the function block is called by the operating system for processing. The value range is between 0 and 6553.5 s.

If the value 0 is set, the cycle time of the device is the pause time between the function block calls.



The device cycle time varies according to the length of the program. With a scan time of 0 s, this may cause an irregular control response.



Use the Set cycle time function block (→ page 247) in order to keep the cycle time of the device constant.

Manual mode of the PID controller

A value must be present at the $\setminus MV$ input in order to set the manipulated variable directly. If the coil DC..SE is activated, the value at $\setminus MV$ is transferred as manipulated variable $\setminus UV$. This value is present for as long as the DC..SE coil is activated or the value at the $\setminus MV$ input is changed. If coil DC..SE is deactivated, the control algorithm is reactivated.



Extreme changes in the manipulated variable can occur when the manual manipulated variable is transferred or deactivated.



If the function block is running in UNI (unipolar) mode, a negative signed manipulated variable value will be output.

Signal smoothing filter

MFD provides 32 signal smoothing filters FT01 to FT32. The function block allows you to smooth noisy input signals.

Wiring a signal smoothing filter

You can integrate a signal smoothing filter into your circuit as a coil.




Figure 100: MFD-Titan circuit diagram with smoothing function block

```

FT11      +
>I1
>TG
>KP
QV>
    
```

Parameter display and parameter set for the FT function block:

FT11	FT PT1 signal smoothing filter function block, number 17
+	Appears in the parameter display
>I1	Input value
>TG	Recovery time
>KP	Proportional gain
QV>	Output value, smoothed



The recovery time T_g is the time in which the output value is calculated.

The recovery time T_g must be set so that it is an integer multiple of the cycle time or controller scan time T_c .

Inputs

The function block inputs $\>I1$, $\>I2$ and $\>KP$ can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Output

The function block output QV can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Value range for inputs and outputs

		Value range	Resolution/unit
$I1$	Input value of the function block	-32 768 to +32 767	
TG	Recovery time T_g	0 to 65 535	in 100/ms
KP	Proportional gain K_p	0 to 65 535	in -- /%
QV	Output value	-32 768 to +32 767	

Example:

		Value at input	Value processed in the function block.
TG	Recovery time T_g	250	25 s
KP	Proportional gain K_p	1500	15

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Coil

FT01EN to FT32EN, function block enable

Memory requirement of the FT function block

The FT function block requires 56 bytes of memory plus 4 bytes per constant on the function block input.

Function of the signal smoothing filter function block



The signal smoothing filter must be enabled so that it can work. Coil FT..EN is active. If coil FT..EN is not active, the entire function block is deactivated and reset. The output value is set to zero.

If the function block is called for the first time, the output value is initialised with the input value when the device is started or after a reset. This speeds up the startup behaviour of the function block.



The function block updates the output value every time recovery time T_g expires.

The function block operates according to the following equation:

$$Y(t) = [T_a/T_g] \times [K_p \times x(t) - Y(t-1)]$$

$Y(t)$ = calculated output value for scan time t

T_a = Scan time

T_g = Recovery time

K_p = proportional gain

$x(t)$ = Actual value with scan time t

$Y(t-1)$ = Output value with scan time $t - 1$

Scan time:

Scan time T_a depends on the set recovery time value.

Recovery time T_g	Scan time T_a
0.1 s to 1 s	10 ms
1 s to 6553 s	$T_g \times 0.01$

GET, fetch a value from the network

The function block allows you to selectively read (get) a 32 bit value from the network. The GET function block fetches data which another station has made available on the easy-NET network with a PUT function block.





Figure 101:MFD-Titan circuit diagram with GET function block



Parameter display and parameter set for the GET function block:

GT01	GET function block (fetch a value from the network), number 01
02	Station number from which the value is sent. Possible station number: 01 to 08
20	Send function block (PT 20) of the sending station. Possible function block number: 01 to 32
+	Appears in the parameter display
QV>	Actual value from the network

Output

The function block output QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Contacts

GT01Q1 to GT32Q1

Contact (make contact) GT..Q1 switches to status 1 if a new value transferred on the easy-NET network is present.

Memory requirement of the GET function block

The GET function block requires 28 bytes of memory.

GET diagnostics

The GET function block only functions when the easy-NET network is functioning correctly (→ Section "Signs of life of the individual stations and diagnostics", Page 282).

Function of the GET function block




Figure 102:Signal diagram of GET function block

1: GT..Q1

2: value on GT..QV>

Seven-day time switch

MFD-Titan is equipped with a real-time clock which you can use in the circuit diagram as a 7-day time switch and a year time switch.



The procedure for setting the time is described under Section "Setting date, time and daylight saving time" on Page 305.

MFD provides 32 seven-day time switches HW01 to HW32 for a total of 128 switching times.

Each time switch has four channels which you can use to set four on and off times. The channels are set via the parameter display.

The time is backed up in the event of a power failure and continues to run, although the time switch relays will no longer switch. The contacts are kept open when de-energized. Refer to Section "Technical data", Page 345 for information on the buffer time.

Wiring of a 7-day time switch

A 7-day time switch is integrated into the circuit diagram as a contact.




Figure 103:MFD-Titan circuit diagram with 7-day time switch

```

HW14 A      +
  >DY1
  >DY2
  >ON
  >OFF
    
```

Parameter display and parameter set for the 7-day time switch HW:

HW14	7-day time switch function block number 14
A	Time switch channel A
+	Appears in the parameter display
>DY1	Day 1
>DY2	Day 2
>ON	On time
>OFF	Off time

Channels

4 channels are available per time switch, channels A, B, C and D. These channels all act on the contact of the 7-day time switch.

Day 1 and day 2

Either the time period acts from day 1 to day 2, e.g. Monday to Friday, or for one day only.

Monday = MO, Tuesday = TU, Wednesday = WE, Thursday = TH, Friday = FR, Saturday = SA, Sunday = SU,

Time

00:00 to 23:59

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

HW01Q1 to HW32Q1

Memory requirement of the 7-day time switch

The 7-day time switch function block requires 68 bytes of memory plus 4 bytes per channel used.

Function of the 7-day time switch

The switching points are defined according to the parameters entered.

MO to FR: on the weekdays Mo, Tu, We, Th, Fr

ON 10:00, OFF 18:00: on and off switching times for the individual days of the week.

MO: every Monday

ON 10:00: switch on time

SA: every Saturday

OFF 18:00: switch off time

Switching on working days

Time switch HW01 switches on Monday to Friday between 6:30 and 9:30 and between 17:00 and 22:30.

HW01 A	+	HW01 B	+
>DY1 MO		>DY1 MO	
>DY2 FR		>DY2 FR	
>ON 06:30		>ON 17:00	
>OFF 09:30		>OFF 22:30	

Switching at the weekend

Time switch HW02 switches on at 16:00 on Friday and switches off at 6:00 on Monday.

HW02 A	+	HW02 B	+
>DY1 FR		>DY1 MO	
>DY2		>DY2	
>ON 16:00		>ON	
>OFF		>OFF 06:00	




Figure 104:Signal diagram of "weekend"

Overnight switching

Time switch HW03 switches on overnight at 22:00 Monday and switches off at 6:00 on Tuesday.

HW03 D	+
>DY1 MO	
>DY2	
>ON 22:00	
>OFF 06:00	




Figure 105:Signal diagram for night switching



If the Off time is before the On time, MFD will switch off on the following day.

Time overlaps

The time settings of a time switch overlap. The clock switches on at 16:00 on Monday, whereas on Tuesday and Wednesday it switches on at 10:00. On Monday to Wednesday the switching-off time is 22:00.

HWD4 A	+	HWD4 B	+
>DY1 MO		>DY1 TU	
>DY2 WE		>DY2 WE	
>ON 16:00		>ON 10:00	
>OFF 22:00		>OFF 00:00	




Figure 106:Signal diagram of overlaps



Switch-on and switch-off times are always based on the channel which switches first.

Response in the event of a power failure

The power is removed between 15:00 and 17:00. The relay drops out and remains off, even after the power returns, since the first switching-off time was at 16:00.

HWD5 A	+	HWD5 B	+
>DY1 MO		>DY1 MO	
>DY2 SU		>DY2 SU	
>OFF 16:00		>ON 12:00	
		>OFF 18:00	



When switched on, MFD always updates the switching state on the basis of all the available switching time settings.

24 hour switching

The time switch is to switch for 24 hours. Switch-on time at 0:00 on Monday and switch-off time at 0:00 on Tuesday.

HW20 A	+	HW20 B	+
>DY1 MO		>DY1 TU	
>DY2		>DY2	
>ON 00:00		>ON	
>OFF		>OFF 00:00	

Year time switch

MFD-Titan is equipped with a real-time clock which you can use in the circuit diagram as a 7-day time switch and a year time switch.



The procedure for setting the time is described under Section "Setting date, time and daylight saving time" on Page 305.

MFD provides 32 year time switches HY01 to HY32 for a total of 128 switching times.

Each time switch has four channels which you can use to set four on and off times. The channels are set via the parameter display.

The time and date are backed up in the event of a power failure and continue to run. However, the time switch relays will no longer continue to switch. The contacts are kept open when de-energized. Refer to Section "Technical data", Page 345 for information on the buffer time.

Wiring of a year time switch

A year time switch is integrated into the circuit diagram as a contact.





Figure 107:MFD-Titan circuit diagram with year time switch



Parameter display and parameter set for the year time switch HY:

HY30	Year time switch function block number 30
B	Time switch channel B
+	Appears in the parameter display
>ON	Switch on time
>OFF	Switch off time

Channels

4 channels are available per time switch, channels A, B, C and D. These channels all act on the contact of the year time switch.

Date

Day.Month.Year: DD.MM. YY

Example: 11.11.02

On/off switch points

ON: switch on time

OFF: switch off time



The switch on year must not be later than the switch off year. Otherwise the year time switch will not function.

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

HY01Q1 to HY32Q1

Memory requirement for the year time switch

The year time switch function block requires 68 bytes of memory plus 4 bytes per channel used.

Function of the year time switch function block

The year time switch can operate with ranges, individual days, months, years or combinations.

Years

ON: 2002 to OFF: 2010 means:

Switch on at 00:00 on 01.01.2002 and switch off at 00:00 01.01.2010.

Months

ON: 04 to OFF: 10 means:

Switch on at 00:00 on 1st April and switch off at 00:00 on 1st October

Days

ON: 02 to OFF: 25 means:

Switch on at 00:00 on the 2nd and switch off at 00:00 on the 25th

Rules for the year time switch

The contact switches in the defined years (ON to OFF), the defined months (ON to OFF) and in the days entered (ON to OFF).

Time ranges must be input with two channels, one for ON and one for OFF.

Overlapping channels:

The first ON date switches on and the first OFF date switches off.



Avoid incomplete entries. It hinders transparency and leads to unwanted functions.

```

HY01 A      +
>ON  --.---.02
>OFF --.---.05

```

Example 1

Year range selection

The year time switch HY01 should switch on at 00:00 on January 1 2002 and remain on until 23:59 on 31 December 2005.

```

HY01 A      +
>ON  --.03.--
>OFF --.09.--

```

Example 2

Month range selection

The year time switch HY01 should switch on at 00:00 on 01st March and remain on until 23:59 on 30th September.

```

HY01 A      +
>ON  01.---.--
>OFF 28.---.--

```

Example 3

Day range selection

The year time switch HY01 should switch on at 00:00 on the 1st of each month and remain on until 23:59 on the 28th of each month.

```

HY01 A      +
>ON  25.12.--
>OFF 26.12.--

```

Example 4

Holiday selection

The year time switch HY01 should switch on at 00:00 on the 25.12 each year and remain on until 23:59 on 26.12. "Christmas program"

Example 5

Time range selection

The year time switch HY01 should switch on at 00:00 on 01.05 each year and remain on until 23:59 on the 31.10. "Open air season"

```

HY01 A      +
>ON  01.05.--
>OFF --.---.--

```

```

HY01 B      +
>ON  --.---.--
>OFF 31.10.--

```

Example 6
Overlapping ranges

The year time switch HY01 channel A switches on at 00:00 on the 3rd of the months 5, 6, 7, 8, 9, 10 and remains on until 23:59 on the 25th of these months.

The year time switch HY01 channel B switches on at 00:00 on the 2nd in the months 6, 7, 8, 9, 10, 11, 12 and remains on until 23:59 on 17th of these months.

```

HY01  A      +
>ON   03.05.--
>OFF  25.10.--
    
```

```

HY01  B      +
>ON   02.06.--
>OFF  17.12.--
    
```

Total number of channels and behaviour of the contact HY01Q1:

The time switch will switch on at 00:00 from the 3rd May and off at 23:59 on the 25th May.

In June, July, August, September, October, the time switch will switch on at 00:00 on the 2nd of the month and switch off at 23:59 on the 17th.

In November and December, the time switch will switch on at 00:00 on the 2nd of the month and switch off at 23:59 on the 17th.

Value scaling

MFD provides 32 value scaling function blocks LS01 to LS32. The function block enables you to convert values from one value range to another one. In this way it is possible to reduce or increase values.

Wiring of a scaling function block

You can integrate a value scaling function block into your circuit as a coil.




Figure 108:MFD-Titan circuit diagram with LS value scaling

```

LS27      +
>I1
>X1
>Y1
>X2
>Y2
QV>

```

Parameter display and parameter set for the LS function block:

LS27	LS value scaling function block number 27
+	Appears in the parameter display
>I1	Input value, actual value source range
>X1	Lower value of source range
>Y1	Lower value of target range
>X2	Upper value of source range
>Y2	Upper value of target range
QV>	Output value, scaled

Inputs

The function block inputs >I1, >X1, >X2, >Y1 and >Y2 can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Output

The function block output QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Value range for inputs and outputs

		Value range
>I1	Input value of the function block	-2147483648 to +2147483647
>X1	Lower value of source range	
>X2	Lower value of target range	
>Y1	Upper value of source range	
>Y2	Upper value of target range	
QV>	Output value	

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Coil

VC01EN to VC32EN, function block enable

Memory requirement of the LS function block

The LS function block requires 64 bytes of memory plus 4 bytes per constant on the function block input.

Function of the function block



The scaling function block must be enabled so that it can work. Coil LS..EN is active. If coil LS..EN is not active, the entire function block is deactivated and reset. The output value is set to zero.

The function block operates according to the following equation:

$$Y(x) = X \times \frac{Y_2 - Y_1}{X_2 - X_1} + \frac{X_2 \times Y_1 - X_1 \times Y_2}{X_2 - X_1}$$

Y(x) = Actual output value of target range

X = Actual input value of source range

X₁ = Lower value of source range

X₂ = Upper value of source range

Y₁ = Lower value of target range

Y₂ = Upper value of target range




Figure 109: Value scaling function block – Reduce value range

- ① Source range
- ② Target range




Figure 110: Value scaling function block – Increase value range

- ① Source range
- ② Target range

Example 1:

The source range is a 10-bit value, source is the analog input IA01.

The target range has 12 bits.


```

LS01      +
>I1 IA01
>X1 0
>Y1 0
>X2 1023
>Y2 4095
QV>

```

Parameter display and parameter set for the LS01 function block:

The actual value at the analog input IA01 is 511.

The scaled output value is 2045.

Example 2:

The source range has 12 bits.

The target range has 16 signed bits.

>I1 = DC01QV

>X1 = 0

>X2 = 4095

>Y1 = -32768

>Y2 = +32767

The actual value at the analog input DC01QV 1789.

The scaled output value is -4137.

Jumps

Jumps can be used to optimise the structure of a circuit diagram or to implement the function of a selector switch. For example, jumps can be used to implement whether manual/automatic mode, or different machine programs are to be selected.

Jumps consist of a jump location and a jump destination (label).

Circuit diagram symbols for jumps

Contact	
Make contact ¹⁾	:
Numbers	01 to 99
Coils	⌚
Numbers	01 to 99
Coil function	⌚, ⌚, ⌚, ⌚, ⌚

1) can only be used as first leftmost contact

Function

If the jump coil is triggered, the circuit connections coming directly after it will not be processed. The states of the coils before the jump will be retained, unless they are overwritten in circuit connections that were not missed by the jump. Jumps are always made forwards, i.e. the jump ends on the first contact with the same number as that of the coil.

- Coil = jump when 1
- Contact only at the first left-hand contact position = Jump destination

The Jump contact point will **always be set to 1**



Backward jumps are not possible with MFD due to the way it operates. If the jump label does not come after the jump coil, the jump will be made to the end of the circuit diagram. The last circuit connection will also be skipped.

If a jump destination is not present, the jump is made to the end of the circuit diagram.

Multiple use of the same jump coil and jump contact is possible as long as this is implemented in pairs, i.e.:

Coil ⌚ :1/jumped range/Contact:1,
Coil ⌚ :1/jumped range/Contact:1 etc.

**Attention!**

If circuit connections are skipped, the states of the coils are retained. The time value of timing relays that have been started will continue to run.

Power flow display

Jumped ranges are indicated by the coils in the power flow display.

All coils after the jump coil are shown with the symbol of the jump coil.

Example

A selector switch allows two different sequences to be set.



- Sequence 1: Switch on Motor 1 immediately.
- Sequence 2: Switch on Guard 2, Wait time, then switch on Motor 1.

Contacts and relays used:

- I1 Sequence 1
- I2 Sequence 2
- I3 Guard 2 moved out
- I12 Motor-protective circuit-breaker switched on
- Q1 Motor 1
- Q2 Guard 2
- T I1 Wait time 30.00 s, on-delayed
- D I1 Text "motor-protective circuit-breaker tripped"

Circuit diagram:

Power flow display: I 01 selected:



Range from jump label 1 processed.

Jump to label 8.

Range to jump label 8 skipped.

Jump label 8, circuit diagram processed from this point on.

Master reset

The master reset function block allows you to reset the state of the markers and all outputs to the 0 state with a single command. Depending on the operating mode of this function block, it is possible to reset the outputs only, or the markers only, or both. 32 function blocks are available.





Figure 111:MFD-Titan circuit diagram with master reset function block



Parameter display and parameter set for the master reset function block:

MR16	Master reset function block number 16
Q	Reset outputs mode
+	Appears in the parameter display

Operating modes

- Q: Acts on the outputs Q., *Q., S., *S., *SN., QA01; *: network station address
- M: acts on the marker range MD01 to MD48.
- ALL: acts on Q and M.

Contacts

MR01Q1 to MR32Q1

The contact switches on the marker if the trigger coil MR..T has the 1 state.

Coils

MR01T to MR32T: trigger coils

Memory requirement of the data function block

The master reset function block requires 20 bytes of memory.

Function of the data master reset

The outputs or the markers are set to the 0 state in accordance with the operating mode when a rising edge is detected on the trigger coil.



The master reset function block should be used as the last function block in a program so that all data ranges are cleared reliably. Otherwise subsequent function blocks may overwrite the data ranges.

The contacts MR01Q1 to MR32Q1 assume the state of their own trigger coil.

Numerical converters

MFD-Titan provides 32 numerical converters NC01 to NC32.

A numerical converter function block enables you to convert BCD coded values to decimal values or decimal coded values to BCD coded values.

Wiring of a numerical converter

A numerical converter in the circuit diagram only has the enable coil.




Figure 112:MFD-Titan circuit diagram with numerical converter

```

NC02 BCD +
>I1
@V>
    
```

Parameter display and parameter set for the numerical converter:

NC02	Numerical converter function block number 02
BCD	Convert BCD code to decimal value mode
+	Appears in the parameter display
>I1	Input value
@V>	Output value

In the parameter display of a numerical converter you can change the mode and the enable of the parameter display.

Numerical converter modes

Parameter	Mode
BCD	Convert BCD coded values to decimal values
BIN	Convert decimal value to BCD coded values

Number range

Value	Number system
-161061273 to +161061273	BCD
-9999999 to +9999999	Decimal

BCD code	Decimal value
0001	1
0010	2
0011	3
0100	4
0101	5
0110	6
0111	7
1000	8
1001	9
1010 to 1111	Not permissible
10000	10
10001	11



The BCD code only allows the number range 0_{hex} to 9_{hex} . The number range A_{hex} to F_{hex} cannot be represented. The NC function block converts the impermissible range to 9.

Inputs

The function block input $\rightarrow I 1$ can be assigned the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Actual value ...QV>

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Coil

NC01EN to NC32EN: enable coil.

Memory requirement of the numerical converter

The numerical converter function block requires 32 bytes of memory plus 4 bytes per constant on the function block input.

Function of the numerical converter function block

The numerical converter function block must be enabled so that it can work. Coil NC..EN is active. If coil NC..EN is not active, the entire function block is deactivated and reset. The output value is set to zero.

BCD mode

The BCD value at $\text{I}1$ is provided in decimal format at the input. The binary value is formed from this. The binary value is interpreted as a BCD value. Values greater than 9 (1001) are set to the value 9. The BCD value is output as a decimal value at the output QV>.

Example 1:

Input value $\text{I}1$: +9_{dec}

Binary value: 1001

Decimal value QV>: + 9

Example 2:

Input value $\text{I}1$: +14_{dec}

Binary value: 1110

Decimal value QV>: + 9



The highest binary value represented in BCD is $1001 = 9$. All other higher binary values from 1010 to 1111 are output as 9. This behaviour is correct as BCD encoders normally don't generate these values.

Example 3:

Input value>I1: 19_{dec}

Binary value: 00010011

Decimal value QV>: 13

Example 4:

Input value>I1: 161061273_{dec}

Binary value: 1001100110011001100110011001

Decimal value QV>: 9999999

Example 5:

Input value>I1: -61673_{dec}

Binary value: 10000000000000001111000011101001

Decimal value QV>: -9099



Bit 32 is the sign bit. Bit 32 = 1 \rightarrow Sign = Minus.

Example 6:

Input value>I1: 2147483647_{dec}

Binary value: 01111111111111111111111111111111

Decimal value QV>: 9999999



Values greater than 161061273 are output as 9999999. Values less than -161061273 are output as -9999999 . The working range of the function block has been exceeded.

BIN mode

The decimal value is assigned to input I1 . The decimal value is represented as a BCD coded value. The BCD coded value is interpreted as a hexadecimal value and output as a decimal value at output QV>.

Example 1:

Input value >I1: +7_{dec}
BCD binary value: 0111
Hexadecimal value: 0111
Decimal value QV>: + 7

Example 2:

Input value >I1: +11_{dec}
BCD binary value: 00010001
Hexadecimal value: 00010001
Decimal value QV>: +17 (1 + 16)

Hexadecimal value:

Bit 0 has the value 1.

Bit 4 has the value 16

Total: Bit 0 plus Bit 4 = 17

Example 3:

Input value >I1: 19_{dec}
BCD binary value: 00011001
Hexadecimal value: 00011001
Decimal value QV>: 25 (1 + 8 + 16)

Example 4:

Input value >I1: 999999_{dec}
BCD binary value: 1001100110011001100110011001
Hexadecimal value: 1001100110011001100110011001
Decimal value QV>: 161061273

Example 5:

Input value >I1: -61673_{dec}
BCD binary value:
1000000000001100001011001110011
Hexadecimal value:
1000000000001100001011001110011
Decimal value QV>: -398963



Bit 32 is the sign bit. Bit 32 = 1 → Sign = Minus.

Example 6:

Input value >I1: 2147483647_{dec}
BCD binary value:
01111111111111111111111111111111

Hexadecimal value:
 01111111111111111111111111111111
 Decimal value QV>: 161061273



Values greater than 9999999 are output as 161061273. Values less than -9 999999 are output as -161061273. The working range of the function block has been exceeded.

Operating hours counter

MFD-Titan provides 4 independent operating hours counters. The counter states are retained even when the device is switched off. As long as the enable coil of the operating hours counter is active, MFD-Titan counts the hours in minute cycles.





Figure 113:MFD-Titan circuit diagram with operating hours counter.



Parameter display and parameter set for the operating hours counter function block:

OT04	Operating hours counter number 04
+	Appears in the parameter display
>I1	Upper threshold value in hours
QV>	Actual value of the operating hours counter

Contacts

OT01Q1 to OT04Q1

The contact switches when the upper threshold value has been reached (greater than or equal to).

Coils

- OT01EN to OT04EN: enable coil
- OT01RE to OT04RE: reset coil

Memory requirement of the operating hours counter

The operating hours counter function block requires 36 bytes of memory plus 4 bytes per constant on the function block input.

Function of the operating hours counter function block

If the enable coil OT..EN is triggered to the 1 state, the counter adds the value 1 to its actual value every minute (basic clock rate: 1 minute).

If the actual value on QV> reaches the setpoint value of >I1, the contact OT..Q1 switches for as long as the actual value is greater than or equal to the setpoint value.

The actual value is retained in the unit until the Reset coil OT..RE is actuated. The actual value is then set to zero.



Operating mode change RUN, STOP, Voltage On, Off, Delete program, Change program, Load new program. All these actions do not delete the actual value of the operating hours counter.

Accuracy

The operating hours counter is accurate to the nearest minute. If the enable coil signal is terminated within a minute, the value for seconds is lost.

PUT, send a value onto the network

The function block allows you to selectively send a 32 bit value onto the network. The PUT function block provides data on the easy-NET that another station indicates it requires via the GET function block.




Figure 114:MFD-Titan circuit diagram with PUT function block

```

PT01 11      -
>I1

```

Parameter display and parameter set for the PUT function block:

PT01	PUT function block (places a value onto the network), number 11
-	Does not appear in the parameter display
>I1	Setpoint value which is put onto the easy-NET network

Input

The function block input >I1 can be assigned the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Contacts

PT01Q1 to PT32Q1: state of the trigger coil

Coils

PT01T to PT32T: trigger coils

Memory requirement of the PUT function block

The PUT function block requires 36 bytes of memory plus 4 bytes per constant on the function block input.

PUT diagnostics

The PUT function block only functions when the easy-NET network is functioning correctly (→ Section "Signs of life of the individual stations and diagnostics", Page 282).

Function of the PUT function block




Figure 115: Signal diagram of PUT function block

1: trigger coil

2: trigger coil contact feedback

3: send

Pulse width modulation

MFD-Titan provides 2 pulse width modulation function blocks PW01 and PW02. The function blocks are connected directly to the outputs.

They are assigned as follows:

PW01 → Q1

PW02 → Q2



When using the pulse width modulation function block with a minimum on time of less than 1 s only use devices with transistor outputs.

The pulse width modulation function block is primarily used for outputting the manipulated variable of a PID controller. The maximum frequency is 200 kHz. This corresponds to a period duration of 5 ms. The maximum period duration is 65.5 s.

Wiring a pulse width modulation function block

A pulse width modulation function block is integrated in the circuit diagram as a contact or coil.



To prevent unpredictable switching states, use each coil of a relay once only in the circuit diagram.




Figure 116: MFD-Titan circuit diagram with pulse width modulation

FWD2	+
>SV	
>PD	
>ME	

Parameter display and parameter set for pulse width modulation:

FWD2	Pulse width modulation function block number 02
+	Appears in the parameter display
>SV	Manipulated variable input
>PD	Period duration in ms
>ME	Minimum on duration, minimum off duration in ms

The parameter display for a timing relay is used to modify the period duration, the minimum on time and the enabling of the parameter display.

Value and time ranges

Parameter	Value and time range	Resolution
SV	0 to 4095	1 digit
PD	0 to 65535	m
ME	0 to 65535	ms



The minimum time setting for the period duration is: 0.005 s (5 ms)

Inputs

The function block inputs >SV, >PD and >ME can be assigned the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12

- Analog output QA01
- Actual value ... QV> of another function block

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

PW01E1 to PW02E1, the minimum on duration or the minimum off duration was undershot.

Coils

PW01EN to PW02EN, enable coil.

Memory requirement of the function block

The pulse width modulation function block requires 48 bytes of memory plus 4 bytes per constant on the function block input.

Function of the pulse width modulation function block



The pulse width modulation function block must be enabled so that it can work. Coil PW..EN is active. If coil PW..EN is not active, the entire function block is deactivated and reset. The output value is set to zero.

The manipulated variable at function block input >SV is converted to a pulse string with a constant period duration. The pulse width is proportional to the manipulated variable >SV. The period duration and the minimum on duration can be selected as required within the specified limits.

The function block causes a direct output of the pulse to the corresponding output. The output image of the circuit diagram is always updated.



The following applies if the output of a pulse width modulator is used as a coil in the circuit diagram:

The state of the output is not refreshed from the circuit diagram.



The following applies to the minimum on duration:

- The minimum on duration is the same as the minimum off duration.
- The minimum on duration must not exceed 10 % of the period duration. The ratio of period duration/minimum on duration (P/M) determines which percentage of the manipulated variable has no effect. The minimum on duration must be set as low as possible so that the P/M ratio is as high as possible. If the minimum on duration must not be too low, due to the output relay, the period duration must be increased accordingly.
- The smallest permissible minimum on duration must not be less than 100 μ s.
- If the actual value of the pulse length is less than the minimum on duration, the minimum on duration has the effect of the pulse time. Note the state of the contact PW..E1.
- If the off duration of the pulse is less than the minimum off duration, outputs Q1 and Q2 are continuously in operation. Note the state of the contact PW..E1.

Setting date/time

This function block allows you to selectively place the date and time onto the network. All other stations accept the date and time of the sending station. The function block name is SC01 (send clock).

Figure 117:MFD-Titan circuit diagram with SC function block

Parameter display and parameter set for the SC function block:

The SC01 function block has no parameters as it is a triggered system service.

Coil

SC01T: trigger coil

Memory requirement of the SC function block

The SC function block requires 20 bytes of memory.

SC diagnostics

The SC function block only functions when the easy-NET network is functioning correctly (→ Section "Signs of life of the individual stations and diagnostics", Page 282).

Function of the date/time function block

If the trigger coil of the function block is activated, the current date, the day of the week and time from the sending station is automatically put onto the easy-NET network. All other network stations must accept these values.



The station that sends its date and time does this when the seconds value is zero.

Example: The trigger pulse is actuated at 03:32:21 (hh:mm:ss). The other stations are synchronised at 03:33:00. This time is accessed by all other stations.

This process can be repeated as often as desired. The trigger coil must be triggered again from the 0 to the 1 state.

Accuracy of time synchronisation

The maximum time deviation between the functional stations is 5 s.

Set cycle time

MFD-Titan provides one set cycle time function block ST01. The set cycle time function block is a supplementary function block for the PID controller.

The set cycle time function block provides a fixed cycle time for processing the circuit diagram and the function blocks.

Wiring a set cycle time function block

The ST set cycle time function block is integrated in the circuit diagram as a coil.



To prevent unpredictable switching states, use each coil of a relay once only in the circuit diagram.




Figure 118: MFD-Titan circuit diagram with enabling of set cycle time function block.



Parameter display for set cycle time:

ST01	Set cycle time function block number 01
+	Appears in the parameter display
>I1	Set cycle time

The parameter display is used to modify the set cycle time, the minimum on time and the enabling of the parameter display.

Time range

Parameter	Value and time range	Resolution
I1	0 to 1000	ms

Inputs

The function block input >I1 can be assigned the following operands:

- Constants

- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Coils

ST01EN, enable coil.

Memory requirement of the function block

The set cycle time function block requires 24 bytes of memory plus 4 bytes per constant on the function block input.

Function of the set cycle time function block

The function block is used to define a fixed cycle time.



The function block must be enabled so that it can work. Coil ST01EN is active. If coil ST01EN is not active, the entire function block is deactivated and reset.

Actual cycle time is less than the set cycle time:

If the maximum cycle time present is less than the set cycle time, the set cycle time is constant.

Actual cycle time is greater than the set cycle time:

If the maximum cycle time present is greater than the set cycle time, the set cycle time has no effect.



Attention!

The shorter the cycle time, the faster the control and regulation process.

Set as small a value for the set cycle time as possible. The processing of the function blocks, reading of the inputs and writing of outputs is only carried out once every cycle. Exception: All function blocks that are processed irrespective of the controller.

Timing relay

MFD-Titan provides 32 timing relays from T 01 to T 32.

A timing relay is used to change the switching duration and the make and break times of a switching contact. The delay times can be configured between 5 ms and 99 h 59 min.

Wiring a timing relay

You integrate a timing relay into your circuit in the form of a contact and coil. The function of the relay is defined via the parameter display. The relay is started via the trigger coil T..EN and can be selectively reset via the reset coil T..RE. The actual timeout running can be stopped via the third coil T..ST.



To prevent unpredictable switching states, use each coil of a relay once only in the circuit diagram.




Figure 119:MFD-Titan circuit diagram with timing relay.

```
T 02 X M:S +
>I1
>I2
@V>
```

Parameter display and parameter set for timing relay:

T 02	Timing relay function block number 02
X	On-delayed mode
M:S	Time range Minute: Seconds
+	Appears in the parameter display
>I1	Time setpoint value 1
>I2	Time setpoint value I2 (on a timing relay with 2 setpoint values)
@V>	Timed-out actual time in RUN mode

The parameter display for a timing relay is used to modify the switching function, time base or setpoint times and enable the parameter display.

Timing relay modes

Parameter	Switch function
X	On-delayed switching
?X	On-delayed with random time range
■	Off-delayed switching
?■	Off-delayed with random time range
X■	On and off delayed
□	Off-delayed with random time range, setpoint retriggerable
?□	Off-delayed with random time range, retriggerable
?X■	On and off delayed switching with random time, 2 time setpoints
∩	Single-pulse switching
∩	Switch with flashing, synchronous, 2 time setpoint values
∩	Switch with flashing, asynchronous, 2 time setpoint values

Time range

Parameter	Time range and setpoint time	Resolution
S 000.000	Seconds, 0.005 to 2 147 483.645 s (596 h) for constants and variable values	5 ms
M:S 00:00	Minutes: Seconds 00:00 to 99:59 only for constants and variable values	1 s
H:M 00:00	Hours: Minutes, 00:00 to 99:59 only for constants and variable values	1 min.



Minimum time setting:
0.005 s (5 ms).

If a time value is less than the MFD cycle time, the elapsed time will only be recognised in the next cycle.

Inputs

The function block inputs $\text{I}1$ and $\text{I}2$ can have the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Outputs**Actual value ...QV>**

The actual value ...QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Variable setpoint values

Behaviour of the setpoint value when variable values are used.

- Variable values can be used.
- Variable values must be transferred using operands.
- With the time base "s" the value is accepted as a "value in ms".
- The last position is rounded up to a zero or five.
- With the time base "M:S" the value is accepted as a "value in s".
- With the time base "H:M:" the value is accepted as a "value in M (minutes)".



The delay times are the same as described for the constants.

Example:

Time base "s"

The operand has the value 9504.

The time value is 9,500 s.

Operand value 45507

The time value is 45,510 s.

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Contacts

T 01Q1 to T 32Q1

Coils

- T 01EN to T 32EN: trigger coil;
- T 01RE to T 32RE: reset coil;
- T 01ST to T 32ST: stop coil.

Memory requirement of the timing relay

The time relay function block requires 48 bytes of memory plus 4 bytes per constant on the function block input.

Retention

Timing relays can be operated with retentive actual values. The number of retentive timing relays can be selected in the SYSTEM → RETENTION menu.

If a timing relay is retentive, the actual value is retained when the operating mode changes from RUN to STOP as well as when the power supply is switched off.

If MFD is started in RUN mode, the timing relay operates with the retentively saved actual value. The state of the trigger pulse must correspond to the function of the timing relay.

1 signal when:

- on-delayed,
- single pulse,
- flashing.

0 status for offdelayed.

Function of the timing relay function block**Timing relay, on-delayed with and without random switching**

Random switching

The contact of the timing relay switches randomly within the setpoint value range.




Figure 120:Signal diagram of timing relay, on-delayed (with and without random switching)

1: trigger coil T..EN

2: stop coil T..ST

3: reset coil T..RE

4: switching contact (make contact) T..Q1

t_s : setpoint time

- Range A:
The set time elapses normally.
- Range B:
The entered setpoint does not elapse normally because the trigger coil drops out prematurely.
- Range C:
The Stop coil stops the time from elapsing.




Figure 121: Signal diagram of timing relay, on-delayed (with and without random switching)

- Range D:
The Stop coil is inoperative after the time has elapsed.
- Range E:
The Reset coil resets the relay and the contact.
- Range F:
The Reset coil resets the time during the timeout sequence. After the Reset coil drops out, the time elapses normally.

Timing relay, off-delayed with and without random switching

Random switching, with and without retriggering

The contact of the timing relay randomly switches within the set value range.

Retriggering

When the time is running and the trigger coil is reactivated or deactivated, the actual value is reset to zero. The set time of the timing relay is timed out once more.




Figure 122:Signal diagram of timing relay, on-delayed (with/without random switching with/without retriggering)

1: trigger coil T..EN

2: stop coil T..ST

3: reset coil T..RE

4: switching contact (make contact) T..Q1

t_s : setpoint time

- Range A:
The time elapses after the trigger coil is deactivated.
- Range B:
The Stop coil stops the time from elapsing.
- Range C:
The Reset coil resets the relay and the contact. After the Reset coil drops out, the relay continues to work normally.
- Range D:
The Reset coil resets the relay and the contact when the function block is timing out.




Figure 123: Signal diagram of timing relay, on-delayed
(with/without random switching with/without retriggering)

- Range E:
The Trigger coil drops out twice. The set time t_s consists of t_1 plus t_2 (switch function not retriggerable).
- Range F:
The Trigger coil drops out twice. The actual time t_1 is cleared and the set time t_s elapses completely (retriggerable switch function).

Timing relay, on-delayed and off-delayed with and without random switching

Time value >I1: On-delayed time

Time value >I2: Off-delayed time

Random switching

The contact of the timing relay switches randomly within the setpoint value range.




Figure 124:Signal diagram of timing relay, on and off-delayed 1

1: trigger coil T..EN

2: stop coil T..ST

3: reset coil T..RE

4: switching contact (make contact) T..Q1

t_{s1} : pick-up time

t_{s2} : drop-out time

- Range A:
The relay processes the two times without any interruption.
- Range B:
The trigger coil drops out before the on-delay is reached.
- Range C:
The Stop coil stops the timeout of the on-delay.
- Range D:
The stop coil has no effect in this range.




Figure 125: Signal diagram of timing relay, on and off-delayed 2

- Range E:
The Stop coil stops the timeout of the off-delay.
- Range F:
The Reset coil resets the relay after the on delay has elapsed
- Range G:
The Reset coil resets the relay and the contact whilst the on delay is timing out. After the Reset coil drops out, the time elapses normally.




Figure 126: Signal diagram of timing relay, on and off-delayed 3

- Range H:
The Reset signal interrupts the timing out of the set time.

Timing relay, single pulse




Figure 127:Signal diagram of timing relay, single pulse 1

1: trigger coil T..EN

2: stop coil T..ST

3: reset coil T..RE

4: switching contact (make contact) T..Q1

- Range A:
The trigger signal is short and is lengthened
- Range B:
The Trigger signal is longer than the set time.
- Range C:
The Stop coil interrupts the timing out of the set time.




Figure 128:Signal diagram of timing relay, single pulse 2

- Range D:
The Reset coil resets the timing relay.
- Range E:
The Reset coil resets the timing relay. The Trigger coil is still activated after the Reset coil has been deactivated and the time is still running.

Timing relay, synchronous and asynchronous flashing

Time value >I1: Pulse time

Time value >I2: Pause time

Synchronous (symmetrical) flashing: >I1 equal >I2

Asynchronous flashing: >I1 not equal >I2




Figure 129:Signal diagram of timing relay, synchronous and asynchronous flashing

1: trigger coil T..EN

- 2: stop coil T..ST
- 3: reset coil T..RE
- 4: switching contact (make contact) T..Q1

- Range A:
The relay flashes for as long as the Trigger coil is activated.
- Range B:
The Stop coil interrupts the timing out of the set time.
- Range C:
The Reset coil resets the relay.

Value limitation

MFD-Titan provides 32 value limitation function blocks VC01 to VC32. The value limitation function block allows you to limit values. You can define an upper and lower limit value. The function block will then only output values within these limits.

Wiring of a value limitation function block

You can integrate a value limitation function block into your circuit as a coil.





Figure 130:MFD-Titan circuit diagram with VC value limitation



Parameter display and parameter set for the VC function block:

VC27	VC value limitation function block number 27
+	Appears in the parameter display
>I1	Input value
>SH	Upper limit value
>SL	Lower limit value
&V>	Output value limited

Inputs

The function block inputs $\rangle I1$, $\rangle SH$ and $\rangle SL$ can be assigned the following operands:

- Constants
- Markers MD, MW, MB
- Analog inputs IA01 to IA04
 - IA01: terminal I7
 - IA02: terminal I8
 - IA03: terminal I11
 - IA04: terminal I12
- Analog output QA01
- Actual value ... QV> of another function block

Output

The function block output QV> can be assigned the following operands:

- Markers MD, MW, MB
- Analog output QA01

Value range for inputs and outputs

		Value range
$\rangle I1$	Input value	-2 147 483 648 to +2 147 483 647
$\rangle SH$	Upper limit value	
$\rangle SL$	Lower limit value	
QV>	Output value	

Displaying the parameter set in the PARAMETERS menu

- + Access enabled
- – Access disabled

Coil

VC01EN to VC32EN, function block enable

Memory requirement of the value limitation function block

The value limitation function block requires 40 bytes of memory plus 4 bytes per constant on the function block input.

Function of the value limitation function block



The function block must be enabled so that it can work. Coil VC..EN is active. If coil VC..EN is not active, the entire function block is deactivated and reset. The output value is set to zero.

The value is accepted at input VC...I1 if the enable coil is active. If the value is greater than the upper limit value or less than the lower limit value, the respective limit value is output at VC..QV.

Example with timing relay and counter function block

A warning light flashes when the counter reaches 10. In the example, both function blocks C 01 and T 01 are wired.




Figure 131:Hardwiring with relays




Figure 132:Wiring with the MFD-Titan




Figure 133:MFD-Titan wiring and circuit diagram

Entering function block parameters from the circuit diagram.

You can access the parameter entry from the contact as well as from a coil.

- Enter the circuit diagram up to **C 01** as a coil.

C 01C is the counter coil of the counter 01 function block.





Figure 134:MFD-Titan wiring and circuit diagram

- ▶ Keep the cursor on the number.
- ▶ Press the **OK** button.



If the cursor is on the contact number, MFD-Titan will call up the parameter display when you press **OK**.



The first part of the parameter set of a counter is displayed.

- ▶ Move the cursor > over the + character to the value input behind >SH:
 - >SH means: function block input upper counter setpoint value
 - The + character means that the parameters of this timing relay can be modified using the PARAMETERS menu.
- ▶ Change the upper counter setpoint to 10:
 - Use < > to move the cursor onto the tens digit.
 - Use ^ v to modify the value of the digit.
- ▶ Press **OK** to save the value and **ESC** to return to the circuit diagram.



MFD-Titan has specific parameter displays for the function blocks. The meaning of these parameters is explained under each function block type.

- ▶ Enter the circuit diagram up to contact **T 01** of the timing relay. Set the parameters for **T 01**.

```
T 01 Ⅱ S +
>I1 002.000
>I2 002.000
QV>
```

The timing relay works like a flashing relay. The MFD-Titan symbol for the flashing relay is **Ⅱ**. The function is set on the top right beside the number in the parameter display.

The time base is set to the right of the "flashing" function. Leave the time base set to **S** for seconds.

- ▶ Move the cursor to the right over the **+** character in order to input the time setpoint value **>I1**.

If the same setpoint value is input for **>I1** and **>I2**, the timing relay functions as a synchronous flasher.

The **+** character means that the parameters of this timing relay can be modified using the PARAMETERS menu.

- ▶ Confirm the value input with **OK**.
- ▶ Press **ESC** to leave circuit diagram entry.
- ▶ Complete the circuit diagram.
- ▶ Test the circuit diagram using the power flow display.
- ▶ Switch MFD-Titan to RUN mode and return to the circuit diagram.

Each parameter set can be displayed using the power flow display for the circuit diagram.

- ▶ Move the cursor onto **C 01** and press **OK**.

```
C 01      +
>SL
>SV
QV>+0
```

The parameter set for the counter is displayed with actual and setpoint values.

- ▶ Move the cursor **∨** downwards until you see the value **QV>**.

- ▶ Switch the input I5. The actual value changes.

```
C 01      +
>SL
>SV
QV>+1
.. C_ .. ..
```

On the display **C_** indicates that the counting coil is actuated.

If the actual and upper setpoint values of the counter are the same, the timing relay switches the warning light on and off every 2 seconds.

```

T 01 1 S +
>I1 001.000
>I2
  QV> 0.550
.. EN..

```

Doubling the flashing frequency:

- ▶ Select the power flow display **T 01** and change the constant of the setpoint time to **001 . 000**.

When you press **OK**, the warning light will flash at twice the frequency.

On the display **EN** indicates that the enable coil is actuated.

Setpoint value settings with constants can be modified via the PARAMETERS menu.



The actual value is only displayed in RUN mode. Call up the parameter display for this via the power flow display or PARAMETERS menu.

5 Visualization with MFD-Titan

MFD-Titan is a display, HMI, closed-loop and open-loop control and input device in one. In the following description, the term "visualization" is used for the display and operator function.

This chapter is still in preparation. The complete chapter will be available in the next edition of this manual.

All visualization functions can only be programmed in EASY-SOFT-PRO.

The Help system in EASY-SOFT-PRO provides descriptions for all "visualization" requirements.

6 easy-NET Network, COM-LINK Serial Connection

Introduction to easy-NET

All MFD-Titan units have an easy-NET network interface connection. This network is designed for eight stations.

Using the easy-NET you can:

- Process additional inputs and outputs.
- Implement faster and improved control using decentralised programs.
- Synchronise date and time
- Read and write inputs and outputs.
- Send values to other stations.
- Receive values from other stations.
- Load programs from or to any station.

The easy-NET network is based on the CAN network (Controller Area Network). CAN is specified by the ISO 11898 standard. CAN has the following in-built features:

- Message oriented transmission protocol.
- Multimaster bus access capabilities with non-destructive bitwise bus arbitration via priority messaging (Arbitration: An instance which defines which hardware can use the bus next).
- Multicast broadcast messaging with receiver side message filtering.
- High level of real-time capability (short reaction time for high priority messages, short fault message get times).
- Functionality in environments with severe interference (short block lengths).
- High level of error security.



CAN has been used as the basis for the design of the easy-NET network. The messages have been adapted and optimised to suit the requirements of the MFD-Titan environment.

easy-NET network topologies, addressing and functions

The easy-NET allows the configuration of a line topology. There are two wiring methods which can be used for the required addressing options:

- “Loop through the unit” wiring arrangement,
- Wiring arrangement using a T connector and a spur line.

Loop through the unit wiring method

With this wiring method it is possible to implement the addressing of the stations via station 1 or the EASY-SOFT (-PRO). If the line is interrupted, the network is no longer operational from this point in the network.

T connector and spur line

Each device must be addressed individually with this wiring method by:

- Downloading the program,
- Downloading the address with EASY-SOFT (-PRO),
- Using the display or
- The device is already assigned an address.

If a spur line is removed on a station, all other devices in the network remain functional.



The spur line between the T connector and the device must not exceed 0.3 m. Otherwise communication via easy-NET may be impaired.

Topology and addressing examples

Physical location, place	Station number		Loop through the unit	T connector and spur line
	Example 1	Example 2		
1	1	1		
2	2	3		
3	3	4		
4	4	8		
5	5	7		
6	6	2		
7	7	6		
8	8	5		

- Example 1: physical location is the same as the station number
- Example 2: physical location is not the same as the station number (apart from location 1 being the same as station 1).

➔ Physical location 1 is always assigned as station 1. Station 1 is the only station which must be present.

Position and addressing of the operands via easy-NET

Stations	Basic unit		Local expansion		Network bit data		Network word data	
	Input I	Output Q	Input R	Output S	Input RN	Output SN	Receive	Send
1	1 I 1 to 16	1 Q 1 to 8	1 R 1 to 16	1 S 1 to 8	2 to 8 RN 1 to 32	2 to 8 SN 1 to 32	GT 1 to 32	PT 1 to 32
2	2 I 1 to 16	2 Q 1 to 8	2 R 1 to 16	2 S 1 to 8	1, 3 to 8 RN 1 to 32	1, 3 to 8 SN 1 to 32	GT 1 to 32	PT 1 to 32
3	3 I 1 to 16	3 Q 1 to 8	3 R 1 to 16	3 S 1 to 8	1, 2, 4 to 8 RN 1 to 32	1, 2, 4 to 8 SN 1 to 32	GT 1 to 32	PT 1 to 32
4	4 I 1 to 16	4 Q 1 to 8	4 R 1 to 16	4 S 1 to 8	1 to 3, 5 to 8 RN 1 to 32	1 to 3, 5 to 8 SN 1 to 32	GT 1 to 32	PT 1 to 32
5	5 I 1 to 16	5 Q 1 to 8	5 R 1 to 16	5 S 1 to 8	1 to 4, 6 to 8 RN 1 to 32	1 to 4, 6 to 8 SN 1 to 32	GT 1 to 32	PT 1 to 32
6	6 I 1 to 16	6 Q 1 to 8	6 R 1 to 16	6 S 1 to 8	1 to 5, 7, 8 RN 1 to 32	1 to 5, 7, 8 SN 1 to 32	GT 1 to 32	PT 1 to 32
7	7 I 1 to 16	7 Q 1 to 8	7 R 1 to 16	7 S 1 to 8	1 to 6, 8 RN 1 to 32	1 to 6, 8 SN 1 to 32	GT 1 to 32	PT 1 to 32
8	8 I 1 to 16	8 Q 1 to 8	8 R 1 to 16	8 S 1 to 8	1 to 7 RN 1 to 32	1 to 7 SN 1 to 32	GT 1 to 32	PT 1 to 32



The RN-SN connection is a point-to-point connection between the stations indicated. With RN and SN the number of the contact must have the same number as the coil. Example: 2SN30 from station 8 is sent to 8RN30 of station 2.



Every station with a circuit diagram has read access to the physical station inputs and outputs of other stations and can process them locally.

Example 1

Station 1 is to read the input I1 of station 2 and write to output Q1 of station 2. Station 2 does not have a circuit diagram.




Figure 135: Circuit diagram in station 1

Example 2:

Marker M 01 of station 4 is to switch the output Q1 of station 3 via the network. Both stations have a circuit diagram.




Figure 136: Circuit diagram in station 4: Set coil 01 in station 3




Figure 137: Circuit diagram in station 3: Get value from coil 01 in station 4

Functions of the stations in the network

The stations on the easy-NET can have two different functions:

- Intelligent stations with their own programs (stations 1 to 8)
- Input/output devices (REMOTE IO) without their own program (stations 2 to 8)



Station 1 must always have a circuit diagram.

Possible write and read authorisation in the network

The stations have differing read and write authorisation in the easy-NET network according to their functions and configuration.

Station 1

Authorised read access to all inputs and outputs of all stations regardless of the function. Observe the setting of SEND IO (→ Section "Send each change on the inputs/ outputs (SEND IO)", Page 279).

Authorised write access to the station's own local outputs.

Authorised write access to the physical digital outputs of the stations which are functioning as input/output devices.

Write authorisation to the network bit data 2 to 8 SN 1 to 32.

Stations 2 to 8

Input/output device function

No read and write authorisation.

Intelligent station function

Authorised read access to all inputs and outputs of all stations regardless of the function. Observe the setting of SEND IO (→ Section "Send each change on the inputs/ outputs (SEND IO)", Page 279).

Write authorisation to its own local outputs.

Write authorisation to the network bit data SN 1 to 32.

Configuration of the easy-NET network

easy-NET can be configured so that it can be optimised for your application.

Station number

The station number is identified as the easy-NET-ID: in the device. The station number can be set on devices with a display using the buttons on the MFD-Titan.



All the easy-NET settings are best carried out on station 1. The entire network can be configured via station 1. The configuration should only be carried out locally when a device is replaced.

Valid station numbers for operation are 01 to 08.

Station number 00 = factory default setting

With station number 00, double address assignment cannot occur when an existing device is being exchanged.

Transmission speed

The MFD-Titan device hardware allows you set transmission speeds between 10 and 1000 KBaud in specific stages. The length of all cables is determines the maximum permissible data transfer rate (→ Section "Technical data", Page 345).

The data transfer rate is set under the BAUDRATE: menu item.

Possible baud rates are: 10, 20, 50, 125, 250, 500 and 1000 KB

125 KB = factory default setting

Pause time, changing the write repetition rate manually

Every easy-NET network connection automatically determines the number of stations which are active on the network, the baud rate which is used and the total number of bytes which are transmitted. The minimum pause time which a device requires is automatically determined using this data in order to ensure that all devices can send their messages. If a pause time is to be increased, the value of the BUSDELAY: must be set greater than zero.

Value "1" doubles the pause time, value "15" will increase it by a factor of 16.

$$t_{pnew} = t_p \times (1 + n)$$

t_{pnew} = new pause time

t_p = pause time determined by the network

n = value on BUSDELAY



An increase in the pause time means that fewer messages (inputs, outputs, bit data, word data) are transferred per time unit.

The reaction speed of the entire controller depends on the baud rate, the pause time and the quantity of transferred data.

The smaller the amount of data transferred, the faster the reaction times of the system.



An increase in the pause time is only useful during commissioning. To ensure that the data for the power flow display is updated faster in the PC, a longer range for this data is created on the network within this pause time.

Send each change on the inputs/outputs (SEND IO)

The SEND IO function should be used if you wish to send any change in input or output status immediately to all other network stations. SEND IO should be activated if intelligent stations have read access to the inputs and outputs of other stations (2I 02, 8Q 01, etc.).

SEND IO ✓

This means that the quantity of messages on the network can increase significantly.



If high-speed counters are used, the SEND IO function should be deactivated. Otherwise the input data is written very rapidly onto the network as they change continuously, leading to unnecessary loading of the network.

If intelligent devices are required to exchange bit information, it should be implemented via RN and SN.

SEND IO ✓ = factory default setting

Automatic change of the RUN and STOP mode

REMOTE RUN should be activated if stations 2 to 8 are to automatically follow the mode change of station 1 during operation.



Input and output devices must always have SEND IO activated, to ensure that station 1 always receives up-to-date input and output data.



Intelligent stations with display only follow the operating mode change when the display is showing the Status display or a text.

The following is of utmost importance during commissioning!



Attention!

If several engineers are commissioning a machine or system involving several spatially separated elements via the easy-NET network, it must be ensured that REMOTE RUN is not activated.

Otherwise unwanted machine or system starts may occur during commissioning. The associated events depend on the machines or systems involved.

REMOTE RUN ✓ = factory default setting

Input/output device (REMOTE IO) configuration

All devices are factory set for operation as input and output devices. This has the advantage that devices can be used immediately as I/O devices, regardless of whether they have a display or not. You only need to assign the station number. This can be implemented via EASY-SOFT (-PRO) or on a Station 1 with a display.

If you want to assign a device as an intelligent station on the network, the REMOTE IO should be deactivated.

REMOTE IO

Figure 138:Remote IO deactivated

The standard settings for the input and output devices are:

SEND IO	✓
REMOTE RUN	✓
REMOTE IO	✓

Station number (easy-NET-ID) and baud rate can be specified via station 1.

Station message types

The easy-NET network recognises various message types. They are:

- Output data of station 1 (Q., S.) which is sent to stations without programs.
- Network outputs and inputs sent and received between stations with programs (*SN, *RN).
- Data sent and received via the network between stations with programs (PT and GT function blocks).
- Inputs, outputs, station status (I, R, Q, S) transfers.
- Loading programs to and from every station.

The easy-NET network is based on a CAN (Controller Area Network) system. Each message type has its own ID. The message priority is determined via the respective ID. This is important in transmission borderline cases to ensure that all messages reach their destination.

Transfer behaviour

Network CPU data transfer to program image

The MFD-Titan network connection is equipped with its own CPU. Network data can therefore be processed whilst the program is running. After each program cycle, the status of

the network data is written to the operand image of the program and the send data is read from the image. The program runs through the next cycle with this data.

Reading and sending the network data from the CPU

The network CPU of the station reads every message on the network. If the message is relevant to the station, it is accepted into a message memory.

If the content of a send message changes, it is sent. Transmission only occurs when there is no message on the network.

easy-NET is configured so that every station can send its messages. This means that the station must observe a pause time between sending messages. The pause time increases the higher the number of stations and the lower baud rate setting.

The number of stations is recognised by every station via a "sign of life" signal.



The following applies to fast message transfer:

- Set the fastest possible baud rate to suit the network length and cable cross-section.
- Fewer messages means faster messages.
- Avoid program downloads during the RUN mode.

Signs of life of the individual stations and diagnostics

The inputs and outputs message type is used as a "sign of life" recognition to ensure that the state of a station can be recognised by other stations. The states of the inputs and outputs are sent cyclically and at the set baud rate, irrespective of the SEND IO setting. If the inputs and outputs of a station are not recognised by other stations after a time determined by the baud rate, the station is deemed to be disconnected until the next "sign of life" is recognised.

Evaluation occurs at the following intervals:

Baud rate [KB]	Stations must send a "sign of life" every ... [ms]	Stations recognise the absence of a "sign of life" signal after [ms]
1000	60	180
500	60	180
250	120	360
125	240	720
50	600	1800
20	1500	4500
10	3000	9000

If the absence of a "sign of life" is detected, the respective diagnostics contact is set to 1.

Diagnostics contact	Station number
ID 01	1
ID 02	2
ID 03	3
ID 04	4
ID 05	5
ID 06	6
ID 07	7
ID 08	8



If a station does not send a "sign of life" signal (station not available, easy-NET interrupted), the respective diagnostics contact ID .. is activated.



Attention!

If the states of the inputs, outputs or data are required by a station without fail, the respective diagnostics contact should be evaluated and the information applied in accordance with its respective application.

If the respective diagnostics contacts are not evaluated, it may cause faults in your application.



The data to be read from a faulty station is set to 0 after the fault is detected.

Network transmission security

easy-NET is a CAN-based network. CAN is used in cars and commercial vehicles in all areas. The same fault recognition capability with data transfer applies as with CAN. A BOSCH study relating to undiscovered and corrupt messages determined the following:

The probability of non-discovery of a corrupted message (residual error probability) is: $< 10^{-10}$ message error rate.

The message error rate depends on:

- Bus loading
- Telegram length
- Malfunction frequency
- Number of stations

Example:

Network with:

- 500 KBaud
- average bus load 25 %
- average operating time 2000 h/year
- average error rate of 10^{-3} ,
i.e.: 1 message is faulty every 1000
- transmission of 1.12×10^{10} messages per year of which
 1.12×10^7 messages are faulty
- residual error probability: $r < 10^{-10} \times 10^{-3} = 10^{-13}$

This means: one of 10^{13} messages is so corrupt that the fault cannot be recognised as such. For a network, this corresponds to a working time of approx. 1 000 years.

Introduction to COM-LINK

The COM-LINK is a point-to-point connection using the serial interface. This interface connection allows the reading of input/output states as well as the reading and writing of marker ranges. This data can be used for setpoint entry or for display functions. The stations of the COM-LINK have different functions. The active station controls the entire interface connection. The remote station responds to the requests of the active station. The remote station cannot distinguish whether the COM-LINK is active or whether a PC with EASY-SOFT-PRO is using the interface.



The two devices must support the COM-LINK, e.g.: MFD and easy800 devices from device version 04 are COM-LINK enabled.



Only the MFD can be the active station in a COM-LINK connection.

Remote stations can be MFD or easy800.

Topology

The following topologies are possible:

Two devices, MFD as active station and easy800 or MFD as remote station.




Figure 139:COM-LINK connection to an easy800 or another MFD

Establishing a COM-LINK connection to an easy-NET station.




Figure 140:easy-NET operation and COM-LINK connections.

A COM-LINK connection can be established with an easy-NET station. The same conditions apply here as with operation without easy-NET.

Data accesses via COM-LINK

The following data access operations are possible from the active station to the remote station:

Active station, read		Remote station
Inputs	1I01 to 1I16	I01 to I16
Inputs of local expansion unit	1R1 to 1R16	R01 to R16
Outputs	1Q01 to 1Q08	Q01 to Q08
Outputs of local expansion unit	1S01 to 1S08	S01 to S08
Diagnostics bits of easy-NET	1ID01 to 1ID08	ID01 to ID08
Analog inputs	1IA01 to 1IA04	IA01 to IA04
Analog output	1QA01	QA01

Write/read accesses in the marker range

Active station	Remote station
1 MD01	MD01
1 MW01 1MW02	MW01 MW02
1 MB01 1MB02 1MB03 1MB04	MB01 MB02 MB03 MB04
1 M01 to 1 M32	M01 to M32
1 MD02	MD02
1 MW03 1MW04	MW03 MW04
1 MB05 1 MB06 1 MB07 1 MB08	MB05 MB06 MB07 MB08
1 M33 to 1 M64	M33 to M64
1 MD03	MD03
1 MW05 1 MW06	MW05 MW06
1 MB09 1 MB10 1 MB11 1 MB12	MB09 MB10 MB11 MB12
1 M65 to 1 M96	M65 to M96
1 MD04	MD04
1 MW07 1 MW08	MW07 MW08
....
....	

1 MD20				MD20			
1 MW39		1 MW40		MW39		MW40	
1 MB77	1 MB78	1 MB79	1 MB80	MB77	MB78	MB79	MB80

The normal rules for addressing the markers apply.



Ensure a clear separation of the write range of the two stations. The active station should write different markers to the remote station. Otherwise the markers in the last write operation will be overwritten.

Configuration of the COM-LINK

The active station must have the following settings in order for the COM-LINK connection to be functional:

- Baud rate,
- COM-LINK (active),
- Remote marker range (data exchange range).

Baud rate COM-LINK

The baud rate can be 9600 baud or 19200 baud.

```
BAUDRATE:19200B  
COM-LINK  
REMOTE MARKER...
```



In normal applications, select the higher baud rate of 19200 baud. The baud rate of 9600 baud should only be selected if the connection is frequently faulty.

Factory setting: 9600 baud

Activating COM-LINK

COM-LINK must be activated in order for it to function.

Factory setting: not active

```
BAUDRATE:19200B
COM-LINK  ✓
REMOTE MARKER...
```

The tick on the COM-LINK menu item indicates that COM-LINK is active.

Remote markers, COM-LINK data exchange range



The REMOTE MARKER.. menu only opens if a tick is displayed next to COM-LINK.

Select the REMOTE MARKER... menu option. Here you can determine, select and modify the data exchange range.

In the example the READ range was selected with the marker double words MD11 to MD15.

```
READ:
 1MD11 + 1MD15
WRITE:
 1MD16 + 1MD18
```

The WRITE range consists of the marker double words MD16 to MD18.

The entire data exchange range available is the marker range MD01 to MD20 of the remote station. The active station accesses these markers with 1MD*. The * indicates the number of the marker concerned.

The smallest possible unit for defining a marker range is an MD marker double word.

Example:

The read range of the active station is 1MD02.

The write range of the active station is 1MD03.

The read range of the remote station is therefore MD03.

The write range of the remote station is MD02.

Operating principle of the COM-LINK connection

The active station at the COM-LINK must be in RUN mode.

Data can only be exchanged with the active station in RUN mode.

The remote station must be in RUN or STOP mode.

The active station scans the remote station. The entire READ marker range is transferred as a string. The entire WRITE marker range is transferred as a string.



Data consistency

The data is located in the image range (data range storing the marker states) of the active station (1MD..) as well as in the image range of the remote station (MD..)

Each station writes data to its own image range asynchronously for data communication. As the serial interface transfers large data volumes slower than the devices overwrite the image ranges, the following applies: one marker double word 1MD., MD.. is consistent.

Within a program cycle, a marker double word that is overwritten via COM-LINK is not constant. The data via the COM-LINK is written to the status image over the course of the program cycle. This means that a different marker value can be present at the start of the program cycle to after the write operation via COM-LINK.

Sign of life detection COM-LINK, diagnostics contact ID09

In order to determine the proper functioning of the COM-LINK connection, the diagnostics contact ID09 is provided on the active station of the COM-LINK connection.

Status of diagnostics contact ID09	Status of the connection
"0"	COM-LINK connection operating correctly or no COM-LINK connection selected.
"1"	COM-LINK connection not functioning, faulty

The time required to detect that the COM-LINK is not working properly depends on the baud rate selected and the event concerned.

Baud rate	Time required for detection of faulty COM-LINK connection.	
	CRC error (data content incorrect)	No response, no hardware connection, remote station not in operation
9600 Baud	250 ms	1.5 s
19200 Baud	120 ms	0.8 s



Attention!

If the states of the inputs, outputs or data are required by a station without fail, the respective diagnostics contact should be evaluated and the information applied in accordance with its respective application.

If the respective diagnostics contacts are not evaluated, it may cause faults in your application.

7 MFD Settings

Settings can only be carried out on MFD models provided with buttons and LCD display.

EASY-SOFT -PRO can be used to set all models via the software.

Password protection

The MFD can be protected by a password against unauthorised access.

In this case the password consists of a value between 000001 and 999999. The number combination 000000 is used to delete a password.

Password protection inhibits access to selected areas. The System menu is always protected by an activated password.

The password can protect the following inputs and areas:

- Start or modification of the program
- Transfer of a circuit diagram to or from a memory card (display/operating unit variants).
- Change of the RUN or STOP mode.
- Calling and modification of function block parameters
- All settings of the real-time clock.
- Modifications of all system parameters.
- Communication with the individual device (looping to other devices possible).
- Switching off the password delete function.



A password that has been entered in MFD is transferred to the memory card together with the circuit diagram, irrespective of whether it was activated or not.

If this MFD circuit diagram is loaded back from the memory card, the password will also be transferred to MFD and is activated immediately.

Password setup

A password can be set via the System menu regardless of the RUN or STOP modes. You cannot change to the System menu if a password is already activated.

- ▶ Press **DEL** and **ALT** to call up the System menu.
- ▶ Select the menu option SECURITY... to enter the password.
- ▶ Press the **OK** button and change over to the PASSWORD... menu.
- ▶ If you press the **OK** button again, you will access the password input.

ENTER PASSWORD
█-----

If no password has been entered, MFD changes directly to the password display and displays six dashes: No password available.

- ▶ Press **OK**, six zeros will appear
- ▶ Set the password using the cursor buttons:
 - < > select position in password,
 - ^ v set a value between 0 to 9.

```
ENTER PASSWORD
  000042
```

- ▶ Save the new password by pressing **OK**.

Use **OK** to exit the password display and proceed with **ESC** and **∨** to the RANGE... menu.

The scope of the password has not yet been considered. The password is now valid but not yet activated.

Selecting the scope of the password

```
CIRCUIT DIAGRAM/↕
PARAMETERS
TIME
OPERATING MODE ↕
INTERFACE
DELETE FUNCTION
```

- ▶ Press the **OK** button.
- ▶ Select the function to be protected or the menu.
- ▶ Press the **OK** button in order to protect the function or menu (tick = protected).



Standard protection encompasses the programs and circuit diagram.

At least one function or menu must be protected.

- **CIRCUIT DIAGRAM:** The password is effective on the program with circuit diagram and non-enabled function blocks.
- **PARAMETERS:** The PARAMETERS menu is protected.
- **TIME:** Date and time are protected with the password.
- **OPERATING MODE:** The toggling of the RUN or STOP operating mode is protected.
- **INTERFACE:** The interface is inhibited for access to a connected device. Programs or commands to other devices connected via the NET network are routed further.
- **DELETE FUNCTION:** After four failed attempts to enter a password, the "DELETE FUNCTION?" prompt appears. This prompt is not displayed if selected. However, it is no longer possible to make changes in protected areas if you forget the password.

Activating the password

You can activate an existing password in three different ways:

- automatically when MFD is switched on again,
 - automatically after a protected circuit diagram is loaded
 - automatically if a telegram has not been sent on the PC interface 30 minutes after unlocking the device (using EASY-SOFT (-PRO),
 - via the password menu
- ▶ Press **DEL** and **ALT** to call up the System menu.
- ▶ Open the password menu via the menu option SECURITY...



CHANGE PW
ACTIVATE

MFD will only show this password menu if a password is present.



Make a note of the password before you activate it. If the password is no longer known, MFD can be unlocked (DELETE FUNCTION is not active), however, the circuit diagram and data settings will be lost.



Attention!

If the password is unknown or lost, and the delete password function is deactivated: The unit can only be reset to the factory setting by the manufacturer. The program and all data are lost.

- ▶ Select **ACTIVATE PW** and confirm with **OK**.

The password is now active. MFD will automatically return to the Status display.

You must unlock MFD with the password before you implement a protected function, enter a protected menu or the System menu.

Unlocking MFD

Unlocking MFD will deactivate the password. You can reactivate password protection later via the password menu or by switching the power supply off and on again.

▶ Press **OK** to switch to the main menu.

The PASSWORD... entry will flash.

▶ Press **OK** to enter the password entry menu.

```
PASSWORD...
STOP RUN /
PASSWORD...
SET CLOCK...
```



If MFD shows PROGRAM... in the main menu instead of PASSWORD..., this means that there is no password protection active.

```
ENTER PASSWORD
XXXXXX
```

MFD will display the password entry field.

▶ Set the password using the cursor buttons.

▶ Confirm with **OK**.

If the password is correct, MFD will return automatically to the Status display.

```
PROGRAM...
STOP
PARAMETERS
SET CLOCK...
```

The PROGRAM... menu option is now accessible so that you can edit your circuit diagram.

The System menu is also accessible.

Changing or deleting the password range

- ▶ Unlock MFD.
- ▶ Press **DEL** and **ALT** to call up the System menu.
- ▶ Open the password menu via the menu option SECURITY... and PASSWORD....



The CHANGE PW entry will flash.

MFD will only show this password menu if a password is present.



- ▶ Press **OK** to enter the password entry menu.
- ▶ Use **OK** to move to the 6-digit entry field.
- ▶ The current password will be displayed.



- ▶ Modify the six password digits using the cursor buttons.
- ▶ Confirm with **OK**.

Use **ESC** to exit the security area.



Deleting

Use number combination 000000 to delete a password.

If a password has not been entered already, MFD will show six dashes:

Password incorrect or no longer known

If you no longer know the exact password, you can try to re-enter the password several times.



The DELETE FUNCTION has not been deactivated.

```
ENTER PASSWORD
XXXXXX
```

You have entered an incorrect password?

▶ Re-enter the password.

```
DELETE ALL ?
```

After the fourth entry attempt MFD will ask whether you wish to delete the circuit diagram and data.

▶ Press

- **ESC**: No entry will be deleted.
- **OK**: Circuit diagram, data and password are deleted.

MFD will return to the Status display.



If you no longer know the exact password, you can press **OK** to unlock the protected MFD. The saved circuit diagram and all function relay parameters will be lost.

Pressing **ESC** will retain the circuit diagram and data. You can then make another four attempts to enter the password.

Changing the menu language

MFD-Titan provides ten menu languages which are set as required via the System menu.

Language	Display
English	ENGLISH
German	DEUTSCH
French	FRANCAIS
Spanish	ESPANOL
Italian	ITALIANO
Portuguese	PORTUGUES
Dutch	NEDERLANDS
Swedish	SVENSKA
Polish	POLSKI
Turkish	TURKCE



Language selection is only possible if MFD is not password-protected.

- ▶ Press **DEL** and **ALT** to call up the System menu.
- ▶ Select MENU LANGUAGE... to change the menu language.

```

ENGLISH      ↑
DEUTSCH     /
FRANCAIS
ESPANOL     ↓
ITALIANO
PORTUGUES
NEDERLAND
SVENSKA
POLSKI
TURKCE
  
```

The language selection for the first entry ENGLISH is displayed.

- ▶ Use **^** or **v** to select the new menu language, e.g. Italian (ITALIANO).
- ▶ Confirm with **OK**. ITALIANO is assigned a tick.
- ▶ Exit the menu with **ESC**.

```
SICUREZZA...
SISTEMA...
LINGUA MENU...
CONFIGURATORE...
```

MFD will now show the new menu language.

Press **ESC** to return to the Status display.

Changing parameters

MFD allows you to change function relay parameters such as timing relay setpoint values and counter setpoints without having to call up the circuit diagram. This is possible regardless of whether MFD is running a program or is in STOP mode.

- ▶ Press **OK** to switch to the main menu.
- ▶ Start the parameter display by selecting **PARAMETERS**.

```
T 03 11 S +
CPOB -
C 11 +
L: 1 RUN
```

All function blocks are displayed as a list.

The following preconditions must be fulfilled in order for a parameter set to be displayed:

- A function relay must have been included in the circuit diagram.
- The **PARAMETERS** menu must be available.
- The parameter set must have been enabled for access, indicated by the **+** character at the bottom right of the display.



Parameter sets can only be enabled or protected via the **FUNCTION RELAYS** menu, or via the circuit diagram with the **“+”** enable and with **“-”** inhibit parameter set characters.

```

T 03 U $ +
>I1 020.030
>I3 005.000
QV> 012.050

```

- ▶ Select the required function block with \wedge or \vee .
- ▶ Press the **OK** button.
- ▶ Scroll with the \wedge or \vee cursor buttons through the constants of the function block inputs.
- ▶ Change the values for a parameter set:
 - With **OK** in the Entry mode.
 - $\langle \rangle$ change decimal place
 - $\wedge \vee$ change the value of a decimal place
 - **OK** save constants or
 - **ESC** retain previous setting.

Press **ESC** to leave the parameter display.



Only constants on the function block inputs can be changed.

Adjustable parameters for function blocks

You can modify the function blocks used in the circuit diagram in three different ways:

- All circuit diagram parameters can be adjusted in STOP mode via the function block editor.
- Setpoints (constants) can be modified in RUN mode via the function block editor.
- Setpoints (constants) can be modified via the PARAMETERS menu.

Adjustable setpoint values are:

- The inputs with all function blocks if constants have been used.
- Switch on and off times with time switches.

In RUN mode MFD operates with a new setpoint as soon as it has been modified in the parameter display and saved with **OK**.

Setting date, time and daylight saving time

The easy800 devices are equipped with a real-time clock with date and time functions. The "time switch" function block can be used to implement time switch applications.

If the clock has not yet been set or if MFD is switched on after the buffer time has elapsed, the clock starts with the setting "WE 1:00 01.05.2002". The MFD clock operates with date and time so the hour, minute, day, month and year must all be set.



The time, such as: 1:00, indicates the version of the device operating system.

```
SET CLOCK
DST SETTING
```

```
HH:MM  00:27
DD.MM  05.05
YEAR :  2002
```

- ▶ Select SET CLOCK... from the main menu.

This will open the menu for setting the time.

- ▶ Select SET CLOCK.

- ▶ Set the values for day, time, month and year.
- ▶ Press the **OK** button to access the Entry mode.
 - < > Move between the parameters
 - ^ v Change the value.
 - **OK** Save day and time
 - **ESC** Retain previous setting.

Press **ESC** to leave the time setting display.

Changing between winter/ summer time (DST)

The easy800 models are fitted with a real-time clock. The clock has various possibilities for changing the DST setting. These are subject to different legal requirements in the EU, GB and USA.



The time change algorithm only applies to the northern hemisphere.

- NONE: no daylight saving time setting
- MANUAL: a user-defined date for the DST change
- EU: date defined by the European Union; Commences: last Sunday in March; Ends: last Sunday in October
- GB: date defined in Great Britain; Commences: last Sunday in March; Ends: fourth Sunday in October
- US: date defined in the United States of America: Commences: first Sunday in April; Ends: last Sunday in October

The following applies to all DST variants:

Winter time → Summer time: On the day of conversion, the clock moves forward one hour at 2:00 to 3:00

Summer time → Winter time: On the day of conversion, the clock moves back one hour at 3:00 to 2:00.

Select SET CLOCK... from the main menu.

This will open the menu for setting the time.


▶ Select the DST SETTING menu option.

```
SET CLOCK
DST SETTING
```


Selecting DST

MFD shows you the options for the DST change.

The standard setting is NONE for automatic DST changeover (Tick at NONE).



► Select the required variant and press the **OK** button.



Manual selection

You want to enter your own date.



The following applies to MFD-Titan devices:

The time change algorithm always calculates the date from the year 2000. Enter the time change for the year 2000.

- Proceed to the MANUAL menu and press 2 × **OK**.
 - < > Move between the parameters
 - ^ v Change the value.
 - **OK** Save day and time
 - **ESC** Retain previous setting.
- Press **ESC** to leave the display.
- Select the day and time at which summer time is to commence.
- Select the day and time at which summer time is to end.



The same time for conversion applies as for the legally determined variants (EU, GB, US).

Activating input delay (debounce)

Input signals can be evaluated by MFD with a debounce delay. This enables, for example, the trouble-free evaluation of switches and pushbutton actuators subject to contact bounce.

In many applications, however, very short input signals have to be monitored. In this case, the debounce function can be switched off.

- ▶ Press **DEL** and **ALT** to call up the System menu.
- ▶ Select the **SYSTEM** menu.



If MFD is password-protected you cannot open the System menu until you have "unlocked" it.

```
DEBOUNCE /      +
P BUTTONS
RUN MODE
CARD MODE      +
```

The input delay (debounce) is set with the DEBOUNCE menu item.

```
DEBOUNCE /      +
P BUTTONS
RUN MODE
CARD MODE      +
```

Activating debounce

If a tick ✓ is set beside **DEBOUNCE**, the input delay is set.

If this is not so, proceed as follows:

- ▶ Select **DEBOUNCE** and press **OK**.

Debounce mode will be activated and the display will show **DEBOUNCE /**.

Press **ESC** to return to the Status display.

Deactivating debounce (input delay)

If MFD is showing **DEBOUNCE** in the display, this means that Debounce mode has already been deactivated.

- ▶ Otherwise select **DEBOUNCE /** and press **OK**.

Debounce mode will be deactivated and the display will show **DEBOUNCE**.



How MFD input and output signals are processed internally is explained in Section "Delay times for inputs and outputs", from Page 328.

Activating and deactivating the P buttons

Even though the cursor buttons (P buttons) have been set as pushbutton actuator inputs in the circuit diagram, this function is not activated automatically. This prevents any unauthorised use of the cursor buttons. The P buttons can be activated in the System menu.



If MFD is password-protected you cannot open the System menu until you have "unlocked" it.

The P buttons are activated and deactivated via the P BUTTONS menu.

```

DEBOUNCE ✓      +
P BUTTONS
RUN MODE
CARD MODE      +
  
```

- ▶ Press **DEL** and **ALT** to call up the System menu.
- ▶ Select the SYSTEM menu.
- ▶ Move to the cursor to the P BUTTONS menu.

```

DEBOUNCE ✓      +
P BUTTONS
RUN MODE
CARD MODE      +
  
```

Activating the P buttons

If MFD is displaying **P BUTTONS** ✓, this means that the P buttons are active.

- ▶ Otherwise select P BUTTONS and press **OK**.

MFD changes the display to **P BUTTONS** ✓ and the P buttons are activated.


- ▶ Press **ESC** to return to the Status display.

```

DEBOUNCE ✓      +
P BUTTONS ✓      +
RUN MODE
CARD MODE      +
  
```

The P buttons are only active in the Status display. In this display you can use the P buttons to activate inputs in your circuit diagram.

Deactivating the P buttons

► Select **P BUTTONS**  and press **OK**.

MFD changes the display to **P BUTTONS** and the P buttons are deactivated.



The P buttons are automatically deactivated when loading a circuit diagram from the memory card or via EASY-SOFT (-PRO) to MFD, or when deleting a circuit diagram in MFD.

Startup behaviour

The startup behaviour is an important aid during the commissioning phase. The circuit diagram which MFD contains is not as yet fully wired up or the system or machine is in a state which MFD is not permitted to control. The outputs should not be controlled when MFD is switched on.

Setting the startup behaviour



The MFD models without a display can only be started in RUN mode.

Requirement: MFD must contain a valid circuit diagram.


► Switch to the System menu.



If MFD is protected by a password, the System menu will not be available until MFD is “unlocked” (see → Section “Unlocking MFD” from Page 299).

Specify the operating mode which MFD must use when the supply voltage is applied.

Activating RUN mode

If MFD displays **RUN MODE** , this means that MFD will start in Run mode when the supply voltage is applied.

DEBOUNCE	✓	+
P BUTTONS		
RUN MODE	✓	
CARD MODE		+

► Otherwise select RUN MODE and press **OK**.
RUN mode is activated.

► Press **ESC** to return to the Status display.

DEBOUNCE	✓	+
P BUTTONS		
RUN MODE		
CARD MODE		+

Deactivating RUN mode

► Select **RUN MODE** ✓ and press **OK**.

The RUN mode function is deactivated.

The default setting for MFD is for RUN MODE to be displayed. In other words, MFD starts in **RUN MODE** ✓ when the power is switched on.

Startup behaviour	Menu display	Status of MFD after startup
MFD starts in STOP mode	RUN MODE	MFD is in STOP mode
MFD starts in RUN mode	RUN MODE ✓	MFD is in RUN mode

Behaviour when the circuit diagram is deleted

The setting for the startup behaviour is an MFD device function. When the circuit diagram is deleted, this does not result in the loss of the setting selected.

Behaviour during upload/download to card or PC

When a valid circuit diagram is transferred from MFD to a memory card or the PC or vice versa, the setting is still retained.



The MFD models without a display can only be started in RUN mode.

Possible faults

MFD will not start in RUN mode:

- a program is not available in MFD.
- you have selected MFD startup in STOP MODE (RUN MODE menu).

Card startup behaviour

The startup behaviour with memory card is for applications where unskilled personnel change the memory card under no-voltage conditions.

MFD only starts in the Run mode if a memory card with a valid program is inserted.

If the program on the memory card is different to the program in MFD, the program from the card is loaded into easy and easy starts in RUN mode.

► Switch to the System menu.



If MFD is protected by a password, the System menu will not be available until MFD is "unlocked" (see → Section "Unlocking MFD" from Page 299).

Activation of card mode

Requirement: RUN MODE is active.

If MFD displays **CARD MODE** ✓, this means that when the power supply is switched on, MFD will only start in RUN mode if a memory card with a valid program has been inserted.

► Otherwise select **CARD MODE** and press **OK**.

MFD will start up with the program on the card.

► Press **ESC** to return to the Status display.

DEBOUNCE	✓	+
F BUTTONS		
RUN MODE	✓	
CARD MODE	✓	+

DEBOUNCE	✓	+
P BUTTONS		
RUN MODE	✓	
CARD MODE		+

Deactivation of card mode

► Select **CARD MODE** ✓ and press **OK**.

The RUN mode function is deactivated.

The MFD default setting is for display of the CARD MODE menu, i.e. MFD starts in RUN mode without the memory card when the power is switched on.

Terminal mode

The MFD-Titan also supports the TERMINAL MODE. Terminal mode enables the display and the keypad of the MFD to be used as a terminal for operating another device. In this operating mode you are thus able to remotely control all devices supporting Terminal mode operation. The interface to the other device can be implemented using the serial interface or easy-NET.



TERMINAL MODE operation is only possible if the MFD is in STOP mode.

Permanent TERMINAL MODE setting

In the SYSTEM menu you set the MFD to start in TERMINAL MODE when the power supply is switched on.

► Switch to the System menu.



If MFD is protected by a password, the System menu will not be available until MFD is "unlocked" (see → Section "Unlocking MFD" from Page 299).

Activating an automatic startup in TERMINAL MODE

Requirement: The MFD is in RUN or STOP mode without visualization (the System menu must be reachable).

```

F  BUTTONS      +
RUN  MODE
CARD  MODE
TERMINAL MODE  ✓ -
    
```

- ▶ Select **TERMINAL MODE** in the System menu and press **OK**.
- ▶ The next time that the MFD is started, it will establish the connection to the selected device.
- ▶ Press **ESC** to return to the Status display.



The correct station number must be selected in order for the MFD to start **TERMINAL MODE** with the correct station. (→ chapter "Commissioning", Page 77)

```

F  BUTTONS      +
RUN  MODE
CARD  MODE
TERMINAL MODE  -
    
```

Deactivating an automatic startup in TERMINAL MODE

- ▶ Select **TERMINAL MODE** ✓ and press **OK**.
The automatic starting in **TERMINAL MODE** has been deactivated.

The default setting of the MFD is for the display of the **TERMINAL MODE** menu, i.e. MFD starts in **RUN** or **STOP** mode when the power is switched on.

Setting LCD contrast and backlight

The backlight of the LCD display can be set to one of five stages in order to adapt it to local conditions. The display contrast can be set to one of five stages.

The contrast and backlight settings are implemented as device settings.

- ▶ Switch to the System menu.



If MFD is protected by a password, the System menu will not be available until MFD is "unlocked" (see → Section "Unlocking MFD" from Page 299).

```
SECURITY      +
SYSTEM...
MENU LANGUAGE
CONFIGURATOR... -
```

- ▶ Select the **SYSTEM** menu.
- ▶ Press the **OK** button.

```
RUN MODE      +
CARD MODE
TERMINAL MODE
DISPLAY...    -
```

- ▶ Use the \vee button to select the **DISPLAY** menu and press **OK**.

```
CONTRAST:    █ 0
LIGHTING:    75%
```

The menus for setting the contrast and backlight are displayed.

- ▶ Press the **OK** button and move to the contrast entry field. Use the \wedge and \vee cursor buttons to set the contrast to a value between -2 and $+2$.

```
CONTRAST:    +1
LIGHTING:    75%
```

- ▶ Select your setting.

```
CONTRAST:    █ +1
LIGHTING:    75%
```

- ▶ Complete your setting by pressing **OK**.

The contrast setting will be retained until it is modified.

```
CONTRAST:    +1
LIGHTING:    █ 75%
```

- ▶ Use the cursor buttons \wedge and \vee to move to the **LIGHTING** menu.

- ▶ Press the **OK** button.

```
CONTRAST:    +1
LIGHTING     75%
```

- ▶ Use cursor buttons \wedge and \vee to change the value in 25 % steps.

- ▶ Set the required backlighting.



The backlight will immediately change to the set value. 0, 25, 50, 75 and 100 % are possible values.

```
CONTRAST:    +1
LIGHTING     100%
```



MFD comes with the following factory setting:

The contrast is set to 0.

The backlight is set to 75 %.

Retention

It is a requirement of system and machine controllers for operating states or actual values to have retentive settings. What this means is that the values will be retained safely even after the supply voltage to a machine or system has been switched off and are also retained until the next time the actual value is overwritten.

The following operands and function blocks can be set to operate retentively:

- Markers
- Counter function blocks,
- Data function blocks and
- Timing relays.

Operating hours counter

easy800 provides four retentive operating hours counters. They are always retentive and can only be selectively deleted with a reset command.

Retentive data volume

200 bytes is the maximum memory range for retentive data (operating hours counters are not included).

Markers

A user-definable and consistent marker range can be declared as retentive.

Counters

All C., CH., and Cl. function blocks can be operated with retentive actual values.

Data function blocks

A user-definable consistent data function block range can be operated with retentive actual values.

Timing relays

A user-definable and consistent range for timing relays can be run with retentive actual values.

Requirements

In order to make data retentive, the relevant markers and function blocks must have been declared as retentive.



Attention!

The retentive data is saved every time the power supply is switched off, and read every time the device is switched on. The data integrity of the memory is guaranteed for 10^{10} read/write cycles.

Setting retentive behaviour

Requirement:

MFD must be in STOP mode.

- ▶ Switch to the System menu.



If MFD is protected by a password, the System menu will not be available until MFD is "unlocked" (see → Section "Unlocking MFD" from Page 299).

The default setting of MFD is for no retentive actual value data to be selected. When MFD is in STOP mode or has been switched to a de-energized state, all actual values are cleared.

RUN MODE	✓	+
CARD MODE		
LIGHTING	✓	
RETENTION		+

- ▶ Switch to STOP mode.
- ▶ Switch to the System menu.
- ▶ Proceed to the SYSTEM menu and continue to the RETENTION... menu.
- ▶ Press the **OK** button.

```

MB 00 -> MB 00 +
C 00 -> C 00
CH 00 -> CH 00 +
          B: 200

```

The first screen display is the selection of the marker range.

- ▶ ^v Select a range.
- ▶ Press **OK** to access the Entry modes.
 - < > Select a position from/to,
 - ^v Set a value.
- ▶ Save the input from .. to .. with **OK**.

Press **ESC** to exit the input for the retentive ranges.

Up to six different ranges can be selected.

```

CI 00 -> CI 00 +
DB 00 -> DB 00
T 00 -> T 00 +
          B: 200

```



The display on the lower right **B: 200** indicates the number of free bytes.

```

MB 01 -> MB 04
C 12 -> C 16
CH 00 -> CH 00
CI 00 -> CI 00
DB 01 -> DB 16
T 26 -> T 32
          B: 076

```

Example:

MB 01 to MB 04, C 12 to C 16, DB 01 to DB 16, T 26 to T 32 should be retentive.

124 bytes have been assigned to the retentive data range. 76 bytes are still available.

Deleting ranges

Set the ranges to be erased to the values from 00 to 00.

e.g.: **MB 00 -> MB 00**. The markers are no longer retentive.

Deleting retentive actual values of markers and function blocks

The retentive actual values are cleared if the following is fulfilled (applies only in STOP mode):

- When the circuit diagram is transferred from EASY-SOFT(-PRO) (PC) or from the memory card to MFD, the retentive actual values are reset to 0. This also applies when there is no program on the memory card. In this case the old circuit diagram is retained in MFD.
- When changing the respective retentive range.
- When the circuit diagram is deleted via the DELETE PROGRAM menu.

Transferring retentive behaviour

The setting for retentive behaviour is a circuit diagram setting. In other words, the setting of the retentive menu may also under certain circumstances be transferred to the memory card or by uploading or downloading from the PC.

Changing the operating mode or the circuit diagram

When the operating mode is changed or the MFD circuit diagram is modified, the retentive data is normally saved together with their actual values. The actual values of relays no longer being used are also retained.

Changing the operating mode

If you change from RUN to STOP and then back to RUN, the actual values of the retentive data will be retained.

Modifying the MFD circuit diagram

If a modification is made to the MFD circuit diagram, the actual values will be retained.

Changing the startup behaviour in the SYSTEM menu

The retentive actual values are retained in MFD regardless of the setting.

Modification of the retentive range

If the set retentive ranges are reduced, only the actual values saved in the range will remain.

If the retentive range is extended, the older data is retained. The new data is written with the current actual values in RUN mode.

Displaying device information

Device information is provided for service tasks and for determining the capability of the device concerned.

This function is only available with devices featuring a display.

Exception: Terminal mode with MFD-Titan.

easy800 enables the display of the following device information:

- AC or DC power supply
- T (transistor output) or R (relay output)
- C (clock provided)
- A (analog output provided)
- LCD (display provided)
- easy-NET (easy-NET provided)
- OS: 1.10.204 (operating system version)
- CRC: 25825 (checksum of the operating system).

► Switch to the System menu.



If MFD is protected by a password, the System menu will not be available until MFD is "unlocked" (see → Section "Unlocking MFD" from Page 299).

```
SECURITY      †
SYSTEM...
MENU LANGUAGE
CONFIGURATOR... †
```

- Select the SYSTEM menu.
- Press the **OK** button.

```
CARD MODE     †
DISPLAY...
RETENTION...
INFORMATION... †
```

- Use the button to select the INFORMATION menu and press **OK**.

This will display all device information.

```
DC TCA LCD NET
OS : 1.11.111
CRC: 63163
```

Example: MFD-80-B, MFD-CP8-NT, MFD-TA17

```
DC RC LCD
OS : 1.11.111
CRC: 63163
```

Example: MFD-80-B, MFD-CP8-ME, MFD-R16

Display in STOP mode.

```
DC RC LCD
OS : 1.11.111
CRC: - - -
```

Display in RUN mode.

The CRC checksum is not displayed.

► Press **ESC** to leave the display.

```
CARD MODE      +
DISPLAY...
RETENTION...
INFORMATION... +
```


8 Inside MFD


MFD Program cycle

In conventional control systems, a relay or contactor control processes all the circuit connections in parallel. The speed with which a contactor switches is thus dependent on the components used, and ranges from 15 to 40 ms for relay pick-up and drop-out.

With MFD the circuit diagram is processed with a microprocessor that simulates the contacts and relays of the circuit concerned and thus processes all switching operations considerably faster. Depending on its size, the MFD circuit diagram is processed cyclically every 0.1 to 40 ms.

During this time, MFD passes through six segments in succession.

How MFD evaluates the circuit diagram:



In the first four segments MFD evaluates the contact fields in succession. MFD checks whether contacts are switched in parallel or in series and saves the switching states of all contact fields.

In the fifth segment, MFD assigns the new switching states to all the coils in one pass.

The sixth segment is located outside of the circuit diagram. MFD uses this to:

Evaluating function blocks

- process the function blocks which are used: the output data of a function block is updated immediately after processing. MFD processes the function blocks according to the function block list (→ FUNCTION RELAYS menu) from top to bottom. You can sort the function block list with EASY-SOFT (-PRO) from Version 4.04. You can then, for example, use the results consecutively.
- establish contact to the "outside world": The output relays Q 01 to Q (S).. are switched and the inputs I1 to I (R).. are read once more.
- MFD also copies all the new switching states to the status image register.
- exchange all data on the easy-NET network (read and write).

MFD only uses this status image for one cycle. This ensures that each circuit connection is evaluated with the same switching states for one cycle, even if the input signals I1 to I12 change their status several times within a cycle.



The following must be observed when operating a PID controller function block!

The cycle time of the program must be less than the scan time of the controller. If the cycle time is greater than the controller scan time, the controller will not be able to achieve constant results.

COM-LINK data access during the program cycle

The data exchange with the point-to-point connection can be carried out in any segment of the program cycle. This data exchange increases the cycle time with both active and remote stations. Only use data that is absolutely necessary.

Loading visualization data

When setting a program to RUN that contains visualization data, the contents of the masks to be displayed have to be loaded. This operation is repeated every 200 ms. With large masks this can take up to one millisecond of cycle time.

The time required for loading in the event of a mask change depends on the size of the masks to be loaded. During a mask change, the new mask is loaded from the mask memory into the RAM.

The loading time can be calculated as follows:
mask size in byte multiplied by 80 μ s.

Example:

Mask size 250 bytes:

The loading time for the mask is: $250 \times 80 \mu\text{s} = 20 \text{ ms}$



If you require the MFD to have a small cycle time:

use several small masks so that the loading time is not too long during a mask change. Only display necessary information in the masks concerned.

The loading of mask data and mask changes can be implemented in any segment of the program cycle. Take this behaviour into account when considering the reaction time of your entire control system.




Distribute tasks amongst several devices in the eas--NET. easy800 for open and closed-loop control functions, MFD-Titan for display and operator functions.

Effects on the creation of the circuit diagram

MFD evaluates the circuit diagram in these six segments in succession. You should take into account two factors when creating your circuit diagram.

- The changeover of a relay coil does not change the switching state of an associated contact until the next cycle starts.
- Always wire forward or from top to bottom. Never work backwards.




Example: self-latching with own contact

Start condition:

Inputs I1 and I2 are switched on.
Q1 is switched off.

This is the circuit diagram of a self-latching circuit. If I1 and I2 are closed, the switching state of relay coil **Q 01** is "latched" via contact **Q 01**.

- **1st cycle:** Inputs I1 and I2 are switched on. Coil Q1 picks up.
- Contact **Q 01** remains switched off since MFD evaluates from left to right. The first coil field was already passed when MFD refreshes the output image in the 6th segment.
- **2nd cycle:** The self-latching now becomes active. MFD has transferred the coil states at the end of the first cycle to contact **Q 01**.



Example: Do not wire backwards

This example is shown in Section "Creating and modifying connections" Page 131. It was used here to illustrate how NOT to do it.

In the third circuit connection, MFD finds a connection to the second circuit connection in which the first contact field is empty. The output relay is not switched.

When wiring more than four contacts in series, use one of the marker relays.




Figure 141: Circuit diagram with M 01 marker relay

How MFD evaluates the high-speed counters CF, CH and CI

In order to evaluate the count pulses of 3 kHz, the high-speed counter function blocks operate with an interrupt routine. The length of the circuit diagram and the associated cycle time has no effect on the counter result.

Memory management of the MFD-Titan

The MFD is provided with three different memories.

- The working memory or RAM, size 8 KByte
The RAM only stores the data when the device power supply is active.
- The mask memory, size 24 KByte
The mask memory stores the visualization data created with EASY-SOFT-PRO retentively.
- The program memory, size 8 KByte
The program memory stores the program retentively.

Distribution of data in the RAM

When the power supply is switched on, the RAM stores the program, the retentive data and the masks to be displayed. This has a direct effect on the size of the program and the masks. The number of retentive data bytes reduces the memory available for program and masks. The largest mask to be displayed likewise reduces the memory available for the program.



Only use as much retentive data as is actually required.

The mask with the largest memory requirement reduces the memory available for the program. Several smaller masks allow more space for the program.

Use as small pictures as possible with 1 bit greyscale. The pictures should normally be 32 x 32 pixels in size in order to fully utilise the optimum brilliance of the display.

Delay times for inputs and outputs

The time from reading the inputs and outputs to switching contacts in the circuit diagram can be set in MFD via the delay time.

This function is useful, for example, in order to ensure a clean switching signal despite contact bounce.




Figure 142:MFD input assigned a switch

Delay times for the MFD inputs

The delay time for DC signals is 20 ms.




Figure 143: Delay times for MFD-DC

An input signal S1 must therefore be 15 V or 8 V (DA) for at least 20 ms on the input terminal before the switch contact will change from 0 to 1 (A). If applicable, this time must also include the cycle time (B) since MFD does not detect the signal until the start of a cycle.

The same debounce delay (C) applies when the signal drops out from 1 to 0.



If you use high-speed counter function blocks, the debounce delay time for the inputs is 0.025 ms. Otherwise it is not possible to count high-speed signals.

If the debounce is switched off, MFD responds to an input signal after just 0.25 ms.




Figure 144: Switching behaviour with input debounce disabled

Typical delay times with the debounce delay disabled are:

- On-delay for
 - I1 to I4: 0.025 ms
 - I5 to I12: 0.25 ms
- Off-delay for
 - I1 to I4: 0.025 ms
 - I5, I6 and I9 to I10: 0.4 ms
 - I7, I8, I11 and I12: 0.2 ms



Ensure that input signals are noise-free if the input debounce is disabled. MFD will even react to very short signals.

Monitoring of short-circuit/overload with EASY...D.-T..

Depending on the type of easy in use, it is possible to use the internal inputs I16, R15 and R16 to monitor for short-circuits or overloads on an output.

- MFD-Titan:
 - I16: Group fault signal for outputs Q1 to Q4.
- EASY620-D.-TE:
 - R16: Group fault signal for outputs S1 to S4.
 - R16: Group fault signal for outputs S5 to S8.

State	I16, R15 or R16
No fault found	"0" = switched off (make contact)
At least one output has a fault	"1" = switched on (make contact)



I16 can only be edited with MFD versions which have transistor outputs.

The following examples are for I16 = Q1 to Q4.

Example 1: Selecting an output with fault indication




Figure 145:Circuit diagram for fault output via I16

The above circuit diagram functions as follows:

If a transistor output reports a fault, M16 is set by I16. The break contact of M16 switches off output Q1. M16 can be cleared by resetting the MFD power supply.

Example 2: Output of operating state




Figure 146:Output of operating state

The above circuit operates as described in example 1. The signal light is triggered at Q4 for additional overload monitoring. If Q4 has an overload, it would "pulse".

Example 3: Automatic reset of error signal



Figure 147:Automatic reset of error signal

The above circuit diagram functions in the same way as Example 2. In addition the marker M16 is reset every 60 seconds by timing relay T08 (on-delayed, 60 s). Should I16 remain at 1, M16 will continue to be set. Q1 is set briefly to 1 until I16 switches off again.

Expanding MFD-Titan

You can expand MFD-Titan with easy models EASY618-.-RE, EASY620-D.-TE, EASY202-RE locally or use the EASY200-EASY coupling module for remote expansion with easy600 expansion. All available bus interface devices such as EASY204-DP, EASY221-CN, EASY205-ASI or EASY222-DN can be used if present.

Install the units and connect the inputs and outputs as described (see → Section "Connecting the expansion unit" Page 45).

You process the inputs of the expansion devices as contacts in the MFD circuit diagram in the same way as you process the inputs of the basic unit. The input contacts are assigned the operand designations R1 to R12.

R15 and R16 are the group fault inputs of the transistor expansion unit (→ Section "Monitoring of short-circuit/overload with EASY..-D.-T..", Page 331).

The outputs are processed as relay coils or contacts like the outputs in the basic unit. The output relays are S1 to S8.



EASY618-.-RE provides the outputs S1 to S6. The other outputs S7, S8 can be used internally.

How is an expansion unit recognised?

If at least one R . . contact or S . . coil/contact is used in the circuit diagram, the basic unit assumes that an expansion unit is connected.

Transfer behaviour

The input and output data of the expansion units is transferred serially in both directions. Take into account the modified reaction times of the inputs and outputs of the expansion units.

Input and output reaction times of expansion units

The debounce setting has no effect on the expansion unit.

Transfer times for input and output signals:

- Local expansion
 - Time for inputs R1 to R12: 30 ms + 1 cycle
 - Time for outputs S1 to S6 (S8): 15 ms + 1 cycle
- Decentralised expansion
 - Time for inputs R1 to R12: 80 ms + 1 cycle
 - Time for outputs S1 to S6 (S8): 40 ms + 1 cycle

Function monitoring of expansion units

If the power supply of the expansion unit is not present, no connection can be established between it and the basic unit. The expansion inputs R1 to R12, R15, R16 are incorrectly processed in the basic unit and show status 0. It cannot be assured that the outputs S1 to S8 are transferred to the expansion unit.



Warning!

Continuously monitor the functionality of the MFD expansion in order to prevent switching errors in the machine or plant.

The status of the internal input I14 of the basic unit indicates the status of the expansion unit:

- I14 = "0": expansion unit is functional
- I14 = "1": expansion unit is not functional

Example

Power can be applied to the expansion unit later than the basic unit. This means that the basic unit is switched to RUN when the expansion unit is absent. The following MFD circuit diagram detects if the expansion unit is functional or not functional.




Figure 148: Circuit diagram for expansion testing

As long as I 14 is 1, the remaining circuit diagram is skipped. If I 14 is 0, the circuit diagram is processed. If the expansion unit drops out for any reason, the circuit diagram is skipped. M 01 detects whether the circuit diagram was processed for at least one cycle after the power supply is switched on. If the circuit diagram is skipped, all the outputs retain their previous state.

QA analog output

The analog output operates with decimal values between 0 and 1023. This corresponds to a 10-bit resolution. At the output this corresponds to a physical voltage between 0 V and 10 V DC.

Negative values such as: -512 are evaluated as zero and output as 0 V DC.

Positive values greater than 1023, such as: 2047, are evaluated as 1023 and output as 10 V DC.

Loading and saving programs

You can either use the MFD interface to save programs to a memory card or use EASY-SOFT-PRO and a transmission cable to transfer them to a PC.

MFD without display and keypad

MFD models without buttons and a display can be loaded with the MFD program via EASY-SOFT-PRO or automatically from the fitted memory card every time the power supply is switched on.

Interface

The MFD interface is covered. Remove the cover carefully.




Figure 149: Remove cover and plug-in

To close the slot again, push the cover back onto the slot.

Memory card

The card is available as an accessory EASY-M-256K for MFD-Titan.

Circuit diagrams containing all the relevant data can be transferred from the EASY-M-256K memory card to MFD-Titan.

Each memory card can hold one MFD program.

Information stored on the memory card is "non-volatile" and thus you can use the card to archive, transfer and copy your circuit diagram.

On the memory card you can save:

- the program
- all the visualization data of the masks,
- all parameter settings of the circuit diagram,
 - the system settings,
 - debounce setting,
 - P buttons,
 - password,
 - retention on/off and range,
 - easy-NET configuration,
 - setting for automatic startup in Terminal mode
 - COM-LINK settings
 - Card mode.

► Insert the memory card in the open interface slot.




Figure 150:Fitting and removing the memory card



With MFD you can insert and remove the memory card even if the power supply is switched on, without the risk of losing data.

Loading or saving circuit diagrams

You can only transfer circuit diagrams in STOP mode.

The MFD versions without a keypad and display automatically transfer the circuit diagram from the inserted memory card to the MFD-CP8... when the power supply is switched on. If the memory card contains an invalid circuit diagram, MFD will keep the circuit diagram still present on the device.



If you are using a display without a keypad, load the programs with the EASY-SOFT-PRO software. The function for automatically loading from the memory card on power up is only supported on MFD-CP8.. without display and display operating unit.

```
PROGRAM
DELETE PROG
CARD
```

- ▶ Switch to STOP mode.
- ▶ Select PROGRAM... from the main menu.
- ▶ Select the CARD... menu option.

The CARD... menu option will only appear if you have inserted a functional memory card.

```
DEVICE-CARD
CARD-DEVICE
DELETE CARD
```

You can transfer a circuit diagram from MFDto the card and from the card to the MFD memory or delete the content of the card.



If the operating voltage fails during communication with the card, repeat the last procedure since MFDmay not have transferred or deleted all the data.

- ▶ After transmission, remove the memory card and close the cover.

Saving a circuit diagram on the card

- ▶ Select DEVICE-CARD.
- ▶ Confirm the prompt with **OK** to delete the contents of the memory card and replace it with the MFD circuit diagram.

```
REPLACE ?
```

Press **ESC** to cancel.


```
DEVICE-CARD
CARD-DEVICE
DELETE CARD
```

Loading a circuit diagram from the card

- ▶ Select the CARD-> DEVICE menu option.
- ▶ Press **OK** to confirm the prompt if you want to delete the MFDmemory and replace it with the card content.

Press **ESC** to cancel.

```
INVALID PROG
```

If there are transmission problems, MFD will display the INVALID PROG message.

This either means that the memory card is empty or that the circuit diagram on the card contains function relays that MFD does not recognise.

The analog value comparator function block is only available on 24 V DC versions of MFD. Programs with visualization components are only supported by the MFD.



If the memory card is password-protected, the password will also be transferred to the MFD memory and will be active immediately.

Deleting a circuit diagram on the card

- ▶ Select the DELETE CARD menu option.
- ▶ Press **OK** to confirm the prompt and to delete the card content.

```
DELETE ?
```

Press **ESC** to cancel.



Memory card compatibility of the programs

Memory cards with programs are always read by MFD-Titan devices with the newer (higher) operating system version. The program is executable. If programs are written with a newer operating system (higher number) on the memory card, this program can only be read and executed by the same version or a higher one.


EASY-SOFT-PRO

EASY-SOFT-PRO is a PC program for creating, testing and managing circuit diagrams for MFD.

→ You should only transfer data between the PC and MFD using the MFDPC interface cable, which is available as accessory EASY800-PC-CAB.

→ MFD cannot exchange data with the PC while the circuit diagram display is on screen.


Use EASY-SOFT-PRO to transfer circuit diagrams from your PC to MFD and vice versa. Switch MFD to RUN mode from the PC to test the program using the current wiring.



EASY-SOFT-PRO provides extensive help on how to use the software.

▶ Start EASY-SOFT-PRO and click on Help.

The on-line help provides all additional information about EASY-SOFT-PRO that you will need.



If there are transmission problems, MFD will display the INVALID PROG message.

▶ Check if the circuit diagram uses function relays which the MFDunit does not recognise:

The analog value comparator function relay is only available on the 24 V DC devices easy-DC and easy-DA.

→ If the operating voltage fails during communication with the PC, repeat the last procedure. It is possible that not all the data was transferred between the PC and MFD.




Figure 151:Fitting and removing EASY800-PC-CAB

► After transmission, remove the cable and close the cover.

Device version

Every MFD-Titan has the device version number printed on the rear of the device housing. The device version is indicated by the first two digits of the device number.

Example:

01-10000003886 DC 20.4 ...28.8 V 3 W
--

This device is of device version 01.

The device version provides useful service information about the hardware version and the version of the operating system.

Appendix

Technical data	General
MFD-80.. display/operating unit	MFD-80..
Front dimensions W × H × D	
With keys [mm]	86.5 × 86.5 × 21.5
[inches]	3.41 × 3.41 × 0.85
Without keys [mm]	86.5 × 86.5 × 20
[inches]	3.41 × 3.41 × 0.79
Total dimensions with fixing shaft W × H × D	
With keys [mm]	86.5 × 86.5 × 43
[inches]	3.41 × 3.41 × 1.69
Thickness of fixing wall (without intermediate top-hat rail) minimum; maximum	
[mm]	1; 6
[inches]	0.04; 0.24
Thickness of fixing wall (with intermediate top-hat rail) minimum; maximum	
[mm]	1; 4
[inches]	0.04; 0.16
Weight	
[g]	130
[lb]	0.287
Mounting	2 22.5 mm (0.886 in) holes Display fastened with two fixing rings
Maximum tightening torque of the fixing rings [Nm]	1.2 to 2

Protective membrane	MFD-XM-80
Dimensions W × H × D	
[mm]	88 × 88 × 25
[inches]	3.46 × 3.46 × 0.98
Weight	
[g]	25
[lb]	0.055
Mounting	Is fitted over the display/keypad (with Titan front ring)


Protective cover	MFD-XS-80
Dimensions W × H × D	
[mm]	86.5 × 94 × 25
[inches]	3.41 × 3.41 × 0.98
Weight	
[g]	36
[lb]	0.079
Mounting	Is fitted over the display/keypad (without Titan front ring)

Power supply/CPU module	MFD-CP8..
Dimensions W × H × D	
[mm]	107.5 × 90 × 30
[inches]	4.23 × 3.54 × 1.18


Power supply/CPU module	MFD-CP8..
Weight	
[g]	145
[lb]	0.32
Mounting	Fitted on the fixing shaft of the display or on the top-hat rail to DIN 50022, 35mm (without display) or by means of fixing feet (without display)

Inputs/outputs	MFD-R.., MFD-T..
Dimensions when fitted W × H × D	
[mm]	89 × 90 × 25
[inches]	3.5 × 3.54 × 0.98
Dimensions when removed W × H × D	
[mm]	89 × 90 × 44
[inches]	3.5 × 3.54 × 1.73
Weight	
MFD-R..; MFD-T..[g]	150; 140
MFD-R..; MFD-T..[lb]	0.33; 0.31
Mounting	Snap fitted into the power supply module


Dimensions of the MFD-80.. display/operating unit




Dimensions of the MFD-80-XM protective membrane




Dimensions of the MFD-80-XS protective cover



Dimensions of the MFD-CP8.. power supply/CPU module



Dimensions of the MFD-R.. I/O module, MFD-T..



General ambient conditions

Climatic conditions		
(damp heat constant to IEC 60068-2-78; cyclical to IEC 600618-2-30) (cold to IEC 60068-2-1, heat to IEC 60068-2-2)		
Ambient temperature Installed horizontally/vertically	°C, (°F)	-25 to 55, (-13 to 131)
Condensation (power supply unit/CPU; inputs/outputs)		Prevent condensation with suitable measures
Display legibility	°C, (°F)	-5 to 50, (-23 to 122)
Storage/transport temperature	°C, (°F)	-40 to 70, (-40 to 158)
Relative humidity (IEC 60068-2-30), non-condensing	%	5 to 95
Air pressure (operation)	hPa	795 to 1080
Ambient mechanical conditions		
Pollution degree		
Power supply unit/CPU; inputs/outputs		2
Display/operating unit		3
Degree of protection (EN 50178, IEC 60529, VBG4)		
Power supply unit/CPU; inputs/outputs		IP20
Display/operating unit		IP65
Display/operating unit with protective cover		IP65
Display/operating unit with protective membrane		IP65
Oscillations (IEC 60068-2-6)		
Constant amplitude 0.15 mm	Hz	10 to 57
Constant acceleration 2 g	Hz	57 to 150
Shocks (IEC 60068-2-27) semi-sinusoidal 15 g/11 ms	Shocks	18
Drop (IEC 60068-2-31)	Drop height	mm
		50
Free fall, when packed (IEC 60068-2-32)	m	1

Electromagnetic compatibility (EMC)		
Electrostatic discharge (ESD), (IEC/EN 61000-4-2, severity level 3)		
Air discharge	kV	8
Contact discharge	kV	6
Electromagnetic fields (RFI), (IEC/EN 61000-4-3)		
		V/m
		10
Radio interference suppression (EN 55011, EN 55022), limit class		
		B
Burst (IEC/EN 61000-4-4, severity level 3)		
Power cables	kV	2
Signal cables	kV	2
High energy pulses (Surge) MFD (IEC/EN 61000-4-5, severity level 2), power cable symmetrical		
		kV
		0.5
Line-conducted interference (IEC/EN 61000-4-6)		
		V
		10
Dielectric strength		
Measurement of the air clearance and creepage distance		EN 50178, UL 508, CSA C22.2, No 142
Dielectric strength		EN 50178
Tools and cable cross-sections		
Solid, minimum to maximum		
		mm ²
		0.2 to 4
		AWG
		24 to 12
Flexible with ferrule, minimum to maximum		
		mm ²
		0.2 to 2.5
		AWG
		24 to 12
Slot-head screwdriver, width		
		mm
		3.5 × 0.5
		inch
		0.14 × 0.02

Display/operating unit


		MFD-80, MFD80-B
Power supply		
Power supply using power supply unit/CPU MFD-CP8..		
LCD display		
Type		Graphic/monochrome
Visible area W x H	mm	62 x 33
Size of pixels	mm	0.4 x 0.4
Number of pixels (W x H)		132 x 64
Spacing (pixel centre to pixel centre)	mm	0.42
LCD backlight		Yes
Backlight colour		Yellow/green
The backlight can be used and programmed in visualization applications		Yes
LEDs		
The backlight can be used and programmed in visualization applications		2
Operating buttons		
Number		9
Can be used and programmed in visualization applications		9
Pushbutton illumination (LED)		
Number		5
Colour		Green

Power supply

		MFD-CP8...
Rated voltage		
Rated value	V DC, (%)	24, (+20, -15)
Permissible range	V DC	20.4 to 28.8
Residual ripple	%	≤ 5
Input current		
For 24 V DC, MFD-CP8., normally	mA	125
For 24 V DC, MFD-CP8., MFD-80., normally	mA	250
For 24 V DC, MFD-CP8., MFD-80., MFD-R., MFD-T., normally	mA	20
Voltage dips, IEC/EN 61131-2	ms	10
Heat dissipation		
For 24 V DC, MFD-CP8., normally	W	3
For 24 V DC, MFD-CP8., MFD-80., normally	W	6
For 24 V DC, MFD-CP8., MFD-80., MFD-R., MFD-T., normally	W	6.5

CPU, real-time clock/timing relay/memory

Backup/accuracy of real-time clock (see graph)



Accuracy of the real-time clock

Per day	s/day	± 5
Per year	h/year	± 0.5

Repetition accuracy of timing relays		
Accuracy of timing relay (from value)	%	± 0.02
Resolution		
Range "s"	ms	5
Range "M:S"	s	1
Range "H:M"	min	1
Circuit connections		256
Contacts in series		4
Coil per circuit connection		1
Program memory for program/circuit diagram		KByte
Program memory for display objects (visualization)		KByte
RAM working memory		KByte
Storage of programs (retentive)		FRAM
Retentive memory (retentive data, retentive)		FRAM
Size	Byte	200
Operating hours counter	Byte	16
Write-read cycles FRAM (minimum)		10 ¹⁰

Inputs

		MFD-R.., MFD-T..
Digital inputs		
Number		12
Inputs usable as analog inputs, (I7, I8, I11, I12)		4
Status display		LCD status display, if available
Electrical isolation		
To supply voltage		No
Between each other		No
To the outputs		Yes
To PC interface, memory card, easy-NET network, EASY-LINK		Yes
Rated voltage		
Rated value	V DC	24
0 signal		
I1 to I6 and I9 to I10	V DC	< 5
I7, I8, I11, I12	V DC	< 8
On 1 signal		
I1 to I6 and I9 to I10	V DC	> 15
I7, I8, I11, I12	V DC	> 8
Input current on 1 signal		
I1 to I6, I9 to I10 at 24 V DC	mA	3.3
I7, I8, I11, I12 at 24 V DC	mA	2.2
Delay time for 0 to 1		
Debounce ON		ms
Debounce off, typical		
I1 to I4	ms	0.025
I5, I6, I9, I10	ms	0.25
I7, I8, I11, I12	ms	0.15

		MFD-R.., MFD-T..
Delay time for "1" to "0"		
Debounce ON	ms	20
Debounce off, typical		
I1 to I4	ms	0.025
I5, I6, I9, I10	ms	0.25
I7, I8, I11, I12	ms	0.15
Cable length (unshielded)	m	100
High-speed counter inputs, I1 to I4		
Number		4
Cable length (shielded)	m	20
High-speed up and down counters		
Counting frequency	kHz	< 3
Pulse shape		Square wave
Mark-to-space ratio		1:1
Frequency counters		
Counting frequency	kHz	< 3
Pulse shape		Square wave
Mark-to-space ratio		1:1
Incremental encoder counters		
Counting frequency	kHz	< 3
Pulse shape		Square wave
Counter inputs I1 and I2, I3 and I4		2
Signal offset		90°
Mark to space ratio		1:1

		MFD-R.., MFD-T..
Analog inputs		
Number		4
Electrical isolation		
To supply voltage		No
To the digital inputs		No
To the outputs		Yes
To the easy-NET network		Yes
Input type		DC voltage
Signal range	V DC	0 to 10
Resolution analog	V	0.01
Resolution digital	Bit	10
	Value	0 to 1023
Input impedance	k Ω	11.2
Accuracy		
Two MFD devices, from actual value	%	± 3
Within a unit, from actual value, (I7, I8, I11, I12)	%	± 2
Conversion time, analog/digital		
Debounce ON:	ms	20
Debounce OFF:		Each cycle time
Input current	mA	< 1
Cable length (shielded)	m	30

Relay outputs

		MFD-R..
Number		4
Type of outputs		Relays
In groups of		1
Connection of outputs in parallel to increase the output		Not permissible
Protection for an output relay		
Miniature circuit-breaker B16	A	16
or fuse (slow-blow)	A	8
Potential isolation to mains power supply, input, PC interface, memory card, NET network, EASY-LINK		Yes
Safe isolation	V AC	300
Basic insulation	V AC	600
Mechanical lifespan	Switch operations	10×10^6
Contacts relays		
Conventional thermal current, (UL)	A	8, (10)
Recommended for load at 12 V AC/DC	mA	> 500
Protected against short-circuit $\cos \varphi = 1$ 16 A characteristic B (B16) at	A	600
Protected against short-circuit $\cos \varphi = 0.5$ to 0.7 16 A characteristic B (B16) at	A	900
Rated impulse withstand voltage U_{imp} contact coil	kV	6
Rated insulation voltage U_i		
Rated operational voltage U_e	V AC	250
Safe isolation to EN 50178 between coil and contact	V AC	300
Safe isolation to EN 50178 between two contacts	V AC	300

		MFD-R..
Making capacity, IEC 60947		
AC-15 250 V AC, 3 A (600 Ops/h)	Switch operations	300 000
DC-13 L/R \leq 150 ms 24 V DC, 1 A (500 Ops/h)	Switch operations	200 000
Breaking capacity, IEC 60947		
AC-15 250 V AC, 3 A (600 Ops/h)	Switch operations	300 000
DC-13 L/R \leq 150 ms 24 V DC, 1 A (500 Ops/h)	Switch operations	200 000
Filament lamp load		
1 000 W at 230/240 V AC	Switch operations	25 000
500 W at 115/120 V AC	Switch operations	25 000
Fluorescent tube with ballast, 10 \times 58 W at 230/240 V AC	Switch operations	25 000
Conventional fluorescent tube, compensated, 1 \times 58 W at 230/240 V AC	Switch operations	25 000
Conventional fluorescent tube, uncompensated, 10 \times 58 W at 230/240 V AC	Switch operations	25 000
Operating frequency, relays		
Mechanical switch operations	Switch operations	10 mill. (10^7)
Mechanical switching frequency	Hz	10
Resistive lamp load	Hz	2
Inductive load	Hz	0.5

UL/CSA

	Uninterrupted current at 240 V AC/24 V DC	A	10/8
AC	Control Circuit Rating Codes (utilisation category)		B300 Light Pilot Duty
	Max. rated operational voltage	V AC	300
	Max. thermal uninterrupted current $\cos \varphi = 1$ at B300	A	5
	Maximum make/break capacity $\cos \varphi k 1$ (Make/break) at B300	VA	3600/360
DC	Control Circuit Rating Codes (utilisation category)		R300 Light Pilot Duty
	Max. rated operational voltage	V DC	300
	Max. thermal uninterrupted current at R300	A	1
	Maximum make/break capacity at R300	VA	28/28

Transistor outputs

		MFD-T..
Number of outputs		4
Contacts		Semiconductors
Rated voltage U_e	V DC	24
Permissible range	V DC	20.4 to 28.8
Residual ripple	%	≤ 5
Supply current		
On 0 state, typical/maximum	mA	18/32
On 1 state, typical/maximum	mA	24/44
Reverse polarity protection		Yes
Attention! If voltage is applied to the outputs when the polarity of the power supply is reversed, this will result in a short circuit.		
Potential isolation to the inputs, supply voltage, PC interface, memory card, NET network, EASY-Link		Yes
Rated current I_e at state 1, maximum	A	0.5

		MFD-T..
Lamp load		
Q1 to Q4 without R_V	W	5
Residual current at state "0" per channel		< 0.1
Max. output voltage		
On 0 state with external load, 10 M Ω	V	2.5
On 1 state, $I_e = 0.5$ A		$U = U_e - 1$ V
Short-circuit protection		Yes
Thermal (Q1 to Q4) (evaluation with diagnostics inputs I16, I15)		
Short-circuit tripping current for $R_a \leq 10$ m Ω (depending on number of active channels and their load)	A	$0.7 \leq I_e \leq 2$
Maximum total short-circuit current	A	8
Peak short-circuit current	A	16
Thermal cutout		Yes
Maximum switching frequency with constant resistive load $R_L = 100$ k Ω (depends on program and load)	Switch operations/h	40000
Parallel connection of outputs with resistive load; inductive load with external suppression circuit (→ Section "Connecting transistor outputs", Page 60); combination within a group		Yes
Group 1: Q1 to Q4		
Maximum number of outputs		4
Total maximum current	A	2
Attention! Outputs must be actuated simultaneously and for the same time duration.		
Status display of the outputs		LCD Status display (if provided)

Inductive load without external suppressor circuit

General explanations:

$T_{0.95}$ = time in milliseconds until 95 % of the stationary current is reached

$$T_{0.95} \approx 3 \times T_{0.65} = 3 \times \frac{L}{R}$$

Utilisation category in groups for

- Q1 to Q4, Q5 to Q8

$T_{0.95} = 1 \text{ ms}$ $R = 48 \Omega$ $L = 16 \text{ mH}$	Utilisation factor per group $g =$		0.25
	Relative duty factor	%	100
	Max. switching frequency $f = 0.5 \text{ Hz}$ Max. duty factor DF = 50 %	Switch operations/h	1500
DC13 $T_{0.95} = 72 \text{ ms}$ $R = 48 \Omega$ $L = 1.15 \text{ H}$	Utilisation factor $g =$		0.25
	Relative duty factor	%	100
	Max. switching frequency $f = 0.5 \text{ Hz}$ Max. duty factor DF = 50 %	Switch operations/h	1500

Other inductive loads:

$T_{0.95} = 15 \text{ ms}$	Utilisation factor $g =$		0.25
$R = 48 \Omega$	Relative duty factor	%	100
$L = 0.24 \text{ H}$	Max. switching frequency	Switch operations/h	1 500
	$f = 0.5 \text{ Hz}$		
	Max. duty factor		
	DF = 50 %		
Inductive loading with external suppressor circuit for each load (→ Section "Connecting transistor outputs", Page 60)			
	Utilisation factor $g =$		1
	Relative duty factor	%	100
	Max. switching frequency	Switch operations/h	Depends on the suppressor circuit
	Max. duty factor		

Analog output

		MFD-RA17, MFD-TA17
Number		1
Electrical isolation		
To power supply		No
To the digital inputs		No
To the digital outputs		Yes
To the easy-NET network		Yes
Output type:		DC voltage
Signal range	V DC	0 to 10
Output current max.	mA	10
Load resistor	k Ω	1
Short-circuit and overload proof		Yes

		MFD-RA17, MFD-TA17
Resolution analog	V DC	0.01
Resolution digital	Bit	10
	Value	0 to 1023
Transient recovery time	µs	100
Accuracy (-25 to 55 °C), related to the range	%	2
Accuracy (25 °C), related to the range	%	1
Conversion time		Each CPU cycle

easy-NET network

		MFD-CP8-NT
Number of stations		8
Bus length/transmission speed ¹⁾	m/Kbaud	6/1000 25/500 40/250 125/125 300/50 700/20 1000/10
Electrical isolation		Yes
To power supply, inputs, outputs, EASY-LINK, PC interface, memory module		
Bus termination (→ accessories)		Yes
First and last station		
Plug connector (→ accessories)	poles	8
Type		RJ45

		MFD-CP8-NT
Cable cross-sections, with cable lengths and cable resistance/m		
Cross-section up to 1 000, < 16 mΩ/m	mm ² (AWG)	1.5 (16)
Cross-section up to 600, < 26 mΩ/m	mm ² (AWG)	0.75 to 0.8 (18)
Cross-section up to 400, < 40 mΩ/m	mm ² (AWG)	0.5 to 0.6 (20, 19)
Cross-section up to 250, < 60 mΩ/m	mm ² (AWG)	0.34 to 0.5 (22, 21, 20)
Cross-section up to 175, < 70 mΩ/m	mm ² (AWG)	0.25 to 0.34 (23, 22)
Cross-section up to 40, < 140 mΩ/m	mm ² (AWG)	0.13 (26)

- 1) Bus lengths above 40 m can only be achieved with cables with reinforced cross-section and connection adapter.

List of the function blocks Function blocks

Element	Meaning of abbreviation	Function block designation	Page
A	A nalog value comparator	Analog value comparator	150
AR	A rithmetic	Arithmetic	153
BC	b lock c ompare	Data block compare	157
BT	b lock t ransfer	Data block transfer	164
BV	B oolean s equence	Boolean sequence	175
C	c ounter	Counters	178
CF	c ounter f requency	Frequency counters	185
CH	c ounter h igh-speed	High-speed counters	189
CI	c ounter f ast i ncremental v alue e ncoder	High-speed incremental encoder	195
CP	c omparators	Comparators	200
D	d isplay	Text function block	202
DB	d ata b lock	Data function block	203
DC	DDC controller (direct d igital c ontrol)	PID controllers	205
FT	f ilter	PT1 signal smoothing filter	211
GT	G ET	GET network	205
HW	h ora ^(lat) w eek	Seven day timer	216
HY	h ora ^(lat) y ear	Twelve month timer	221
LS	l inear s caling	Value scaling	225
MR	m aster r eset	Master reset	232
NC	n umeric c oding	Numerical converters	233
OT	o perating t ime	Operating hours counter	239
PT	P UT	PUT network	240
PW	p ulse w idth modulation	Pulse width modulation	216
SC	s ynchronize c locks	Synchronise clock via network	245

Element	Meaning of abbreviation	Function block designation	Page
ST	set time	Set cycle time	221
T	timing relays	Timing relay	249
VC	value capsuling	Value limitation	262
:		Jumps	203

Function block coils

Coil	Meaning of abbreviation	Description
C_	count input	Counter input
D_	direction input	Count up/down indicator
ED	enable Differential component	Activate differential component
EI	enable integral component	Activate integral component
EN	enable	Enable module
EP	enable proportional component	Activate proportional component
RE	reset	Reset actual value to zero
SE	set enable	Set to a predefined value
ST	stop	STOP block processing
T_	trigger	Trigger coil

Function block contacts

Contact	Meaning of abbreviation	Description
CY	carry	Status "1", if the value range is exceeded; (carry)
E1	error 1	Error 1, dependent on function block
E2	error 2	Error 2, dependent on function block
E3	error 3	Error 3, dependent on function block
EQ	equal	Comparison result, status 1 if values equal.
FB	fall below	Status "1", if the actual value is less than or equal to the lower setpoint value;
GT	greater than	Status 1 if the value at I1 > I2;
LI	limit indicator	Value range manipulated variable exceeded
LT	less than	Status 1 if the value at I1 < I2;
OF	overflow	Status "1", if the actual value is greater than or equal to the upper setpoint value;
Q1	output (Q1)	Switch output
QV	output value	Current actual value of the function block (e.g. counter value)
ZE	zero	Status "1", if the value of the element input QV is equal to zero;

Function block inputs (constants, operands)

Input	Meaning of abbreviation	Description
F1	Factor 1	Gain factor for I1 ($I1 = F1 \times \text{Value}$)
F2	Factor 2	Gain factor for I2 ($I2 = F2 \times \text{Value}$)
HY	H ysteresis	Switching hysteresis for value I2 (Value HY applies to positive and negative hysteresis.)
I1	Input 1	1st input word
I2	Input 2	2nd input word
KP	Standard	Proportional gain
ME	M inimum make time	Minimum make time
MV	m anual v alue	Manual manipulated variable
NO	n umbers of elements	Number of elements
OS	O ffset	Offset for the value I1
PD	P eriod d uration	Period duration
SH	S etpoint h igh	Upper limit value
SL	S etpoint l ow	Lower limit value
SV	S et v alue	Defined actual value (Preset)
TC		Scan time
TG		Recovery time
TN	Standard	Rate time
TV	Standard	Reset time
X1	X1, interpolation point 1 abscissa	Lower value of source range
X2	Interpolation point 2 abscissa	Upper value of source range
Y1	Interpolation point 1 ordinate	Lower value of target range
Y2	Interpolation point 2 ordinate	Upper value of target range

Function block output (operands)

Input	Meaning of abbreviation	Description
QV	Output value	Output value

Other operands

Other operands	Description
MB	Marker byte (8-bit value)
IA	Analog input (if available on device!)
MW	Marker word (16-bit value)
QA	Analog output (if available on device!)
MD	Marker double word (32-bit value)
NU	Constant (number), value range from – 2 147 483 648 to +2 147 483 647

Memory requirement

The following table provides an overview of the memory requirement of the easy800 circuit connections, function blocks and their respective constants:

	Space requirement per circuit conn./function block	Space requirement per constant on the function block input
	Byte	Byte
Circuit connection	20	–
Function blocks		
A	68	4
AR	40	4
BC	48	4
BT	48	4
BV	40	4
C	52	4
CF	40	4
CH	52	4
CI	52	4
CP	32	4
D	160	
DC	96	4
DB	36	4
FT	56	4
GT	28	
HW	68	4 (per channel)
HY	68	4 (per channel)
LS	64	4
LS	64	4
MR	20	
NC	32	4

	Space requirement per circuit conn./function block Byte	Space requirement per constant on the function block input Byte
OT	36	4
PT	36	4
PW	48	4
SC	20	
ST	24	4
T	48	4
VC	40	4
:	–	–

Index

A	Actual values	149
	Add	
	Circuit connections	84
	Switching contact	83
B	Break contact	114
	Inverting	132
	Bus termination resistor	65
	Button	
	ALT	84
	DEL	84
	OK	81, 112
	Buttons	14
C	Cable cross-sections	66
	Cable length	66
	Cable lengths	50
	Cable protection	48
	Circuit connection	
	Number	126
	Circuit connections	
	Add new	84
	Deleting	133, 136
	Entering	132
	Insert	134
	Position in circuit diagram	126
	Circuit diagram	
	Checking	138
	Circuit connections	126
	Coil field	126
	Contact fields	126
	Deleting	89
	Display	82, 126
	Fast entry	89
	Grid	82, 126

Internal processing	323
Load	341
Operating buttons	112
Overview	126
Saving	339, 341
Testing	86, 138
Wiring	84, 132
Coil field	126
Coil function	
Contactor	144
Impulse relay	145
Latching relay	145
Overview	144
COM-LINK	286
Activation	289
Baud rate	289
Configuration	289
Data access	287, 325
Operating principle	290
Sign of life detection	291
Connecting the brightness sensor	55
Connecting transistor outputs	60
Connection	
20 mA sensor	55
Analog inputs	54
Analog output	62
Brightness sensor	55
Contactors, relays	58
Frequency generator	57
High-speed counters	57
Incremental encoder	57
MFD-DC inputs	53
NET network	64
Outputs	58
Proximity switch	53
Pushbutton actuators, switches	50, 53
Relay outputs	59
Serial interface	69
Setpoint potentiometer	55
Temperature sensor	55
Transistor outputs	60

Connection cross-sections	
MFD cables	45
Screw terminals	45
Contact fields	126
Counter relay	178, 195
Parameters	190, 196
Counter relays	
Parameters	186
Counters	
High-speed	57, 189
High-speed incremental encoder	195
Cursor display	26, 112
Cycle	323
<hr/>	
D	
Data consistency	291
DC power supply for the MFD	47
Debounce	
Setting	308
Delay time	
Input and output	328
Delay times	
For easy-DA	329
For easy-DC	329
Deleting retentive actual values	318
Device overview	12
Device version	343
Dimensions, easy	345
<hr/>	
E	
EASY...-AC-.E AC expansion units	46
Expanding	72
Expanding inputs	72
Expanding outputs	72
Expansion	
Local	72
Remote	74

F	Fixing brackets	42
	Frequency counters	185
	Function blocks	
	Evaluating	324
	List	367
	Function relay	
	Counter relay	195
	Counter, high-speed	189
	Counter, high-speed incremental encoder ..	195
	Counters	178
	Example	263
	Frequency counters	185
	Overview	148
	Time switch	216, 221
	Timing relay	249

I	Impulse relay	145
	Increasing the input current	51
	Incremental encoder	57, 195
	Input contacts	129
	Inrush current limitation	52
	Interface	336
	Interference	50
	Inverting	132

J	Jumps	229
----------	-------------	-----

L	Latching	144
	Latching relay	145
	LED display	17

M	Main menu	
	Overview	19
	Selection	16
	Make contact	114
	Inverting	132
	Marker relay	326
	Memory card	
	Deleting	340
	Insertion	338
	Memory management	
	Mask memory	327
	Program memory	327
	RAM	327
	Menu	
	Changing level	81
	Changing the language	302
	Language setting	77, 272
	Operator guidance	15
	Message	
	INVALID PROG	340, 341
	MFD	
	Evaluating the circuit diagram	323
	Operating modes	78
	Overview	12
	Mode	
	Changing	86
	Mounting	
	Display/operating unit	33
	Inputs/outputs onto the power supply/CPU module	38
	On top-hat rail	40
	Power supply/CPU module	36
	Protective cover	30
	Protective membrane	28
	Screw fixing	42
	Top-hat rail	36

<hr/>	
N	Network
	Addressing 273
	Automatic change of the RUN and STOP mode 279
	Cables 67
	Changing the write repetition rate 278
	Configuration of the COM-LINK 289
	Configuring input/output devices 280
	Connecting the NET network 64
	Data accesses via COM-LINK 287
	Introduction to COM-LINK 286
	Station message types 281
	Station signs of life 282
	Topology 273, 286
	Transfer behaviour 281
	Transmission security 285
	Network cables 67
<hr/>	
O	Operating principles 14
	Output relay 129
	Overload 62, 331
	Monitoring with EASY..-D.-T. 331
<hr/>	
P	P buttons 137
	Activating and deactivating 309
	Parameter display
	Counter relay 190, 196
	Timing relay 186
	Parameters
	Change 303
	Display 303
	Inhibit access 303
	Password
	Activation 298
	Change 300
	Deleting 300
	Protection removal 301
	Setup 296

Pause time	278
Physical location	68
Power failure	78
Power flow display	86, 87, 138
Program	323
Cycle	323
Load	336
Saving	336
<hr/>	
R Relay coil	
Change	129
Coil function	130, 144
Deleting	132
Entering	85, 129
Relays	
Connecting the outputs	59
Overview	119, 122, 126
Removing	
Inputs/outputs	39
Power supply/CPU module	39
Reset	145
Retention	
Setting behaviour	317
Transferring behaviour	319
Retention requirements	
Permitted easy models	317
Retentive behaviour	319
On circuit diagram transfer	319
Setting	317
RUN, start behaviour	78
RUN/STOP changeover	86

S	Screw mounting	42
	Sealing the protective cover	32
	Sensor (20 mA) connection	55
	Serial interface	69
	Set	145
	Setpoint potentiometer	55
	Setpoints	64, 149, 304
	Setting LCD backlight	314
	Setting LCD contrast	314
	Setting the LCD	314
	Setting the time	305
	Short-circuit	62, 331
	Monitoring with EASY..-D.-T..	331
	Startup behaviour	310, 312
	After the circuit diagram is deleted	311
	Basic setting	311, 313, 314, 315
	Possible faults	312
	Setting	310
	With upload/download to card or PC	311
	Station	
	Active	286
	Remote	286
	Status display	16
	Status image register	324
	Suppressing contact bounce	328
	Switching contact	132
	Change	129
	Contact name	129
	Contact number	129
	Cursor buttons	137
	Deleting	132
	Entering	83, 129
	Invert	84
	Overview	113
	System menu	
	Selection	16

T	Temperature sensor connection	55
	Terminal mode	78
	Tightening torque	45
	Time switch	
	24 hour switching	221
	Overnight switching	219
	Power failure	220
	Switching at the weekend	219
	Switching on working days	218
	Time overlaps	220
	Timing relay	
	On-delayed	244, 253
	Operating modes	250
	Wiring	249
	Tool for cage clamp terminals	45
	Tool for easy expansion unit	45
	Two-wire proximity switches	51
<hr/>		
V	Visualization data	
	Load	325
<hr/>		
W	Weekday setting	305
	Wiring	
	Backwards	326
	Deleting	84
	Entering	84
	Relay coils	144
	Rules	144

**Moeller GmbH
Industrieautomation
Hein-Moeller-Straße 7-11
D-53115 Bonn**

**E-Mail: info@moeller.net
Internet: www.moeller.net**

© 2003 by Moeller GmbH
Subject to alteration
AWB2528-1480GB IM-D/IM-D/xx 06/03
Printed in the Federal Republic of Germany (09/03)
Article No.: 267188



MOELLER 

Think future. Switch to green.

For Immediate Delivery call KMParts.com at (866) 595-9616