




**NxDBU**  
**OPTION MODULE**

**User Manual**

**Part Number**  
**1200158L1#HS**



901 Explorer Boulevard  
P.O. Box 140000  
Huntsville, AL 35814-4000  
Phone: (256) 963-8000

© 2000 ADTRAN, Inc.  
All rights reserved.  
Printed in USA.



*Notes provide additional useful information.*



*Cautions signify information that could prevent service interruption.*

**WARNING**

*Warnings provide information that could prevent damage to the equipment or endangerment to human life.*

## Federal Communications Commission Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio frequencies. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

***Shielded cables must be used with this unit to ensure compliance with Class A FCC limits.***



*Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.*

## Warranty and Customer Service

ADTRAN will replace or repair this product within five (5) years from the date of shipment if it does not meet its published specifications or fails while in service. For detailed warranty, repair and return information See the ADTRAN Equipment Warranty and Repair and Return Policy Procedure.

Return Material Authorization (RMA) is required prior to returning equipment to ADTRAN.

For Service, RMA requests, or more information, contact ADTRAN Technical Support listed on the inside back page of this manual.

## LIMITED PRODUCT WARRANTY

ADTRAN warrants that for five (5) years from the date of shipment to Customer, all products manufactured by ADTRAN will be free from defects in materials and workmanship. ADTRAN also warrants that products will conform to the applicable specifications and drawings for such products, as contained in the Product Manual or in ADTRAN's internal specifications and drawings for such products (which may or may not be reflected in the Product Manual). This warranty only applies if Customer gives ADTRAN written notice of defects during the warranty period. Upon such notice, ADTRAN will, at its option, either repair or replace the defective item. If ADTRAN is unable, in a reasonable time, to repair or replace any equipment to a condition as warranted, Customer is entitled to a full refund of the purchase price upon return of the equipment to ADTRAN. This warranty applies only to the original purchaser and is not transferable without ADTRAN's express written permission. This warranty becomes null and void if Customer modifies or alters the equipment in any way, other than as specifically authorized by ADTRAN.

EXCEPT FOR THE LIMITED WARRANTY DESCRIBED ABOVE, THE FOREGOING CONSTITUTES THE SOLE AND EXCLUSIVE REMEDY OF THE CUSTOMER AND THE EXCLUSIVE LIABILITY OF ADTRAN AND IS IN LIEU OF ANY AND ALL OTHER WARRANTIES (EXPRESSED OR IMPLIED). ADTRAN SPECIFICALLY DISCLAIMS ALL OTHER WARRANTIES, INCLUDING (WITHOUT LIMITATION), ALL WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THIS EXCLUSION MAY NOT APPLY TO CUSTOMER.

In no event will ADTRAN or its suppliers be liable to Customer for any incidental, special, punitive, exemplary or consequential damages experienced by either Customer or a third party (including, but not limited to, loss of data or information, loss of profits, or loss of use). ADTRAN is not liable for damages for any cause whatsoever (whether based in contract, tort, or otherwise) in excess of the amount paid for the item. Some states do not allow the limitation or exclusion of liability for incidental or consequential damages, so the above limitation or exclusion may not apply to Customer.



# Table of Contents

---

<b>List of Figures</b> .....	<b>xi</b>
<b>List of Tables</b> .....	<b>xiii</b>
<b>Chapter 1. Introduction</b> .....	<b>1-1</b>
Nx/DBU V.35 Option Module Overview .....	1-1
Functional Description.....	1-1
Features of the Nx/DBU Option Module .....	1-2
Nx Features.....	1-2
DBU Features.....	1-2
Features Common to the Nx and the DBU .....	1-3
Interfaces .....	1-3
Specifications of the Nx/DBU .....	1-4
Specifications: Nx56/64 (DCE Interface) .....	1-4
Specifications: DBU (DTE Interface) .....	1-5
Specifications: Nx56/64 and DBU .....	1-5
Physical Description .....	1-6
<b>Chapter 2. Installation</b> .....	<b>2-1</b>
Unpack & Inspect .....	2-1
ADTRAN Shipments Include .....	2-1
Customer Provides .....	2-1
Installing the Option Module .....	2-1
Placement of the Option Module .....	2-2
Power Connection.....	2-2
Wiring.....	2-3
Power-Up Testing and Initialization .....	2-4
<b>Chapter 3. Operation</b> .....	<b>3-1</b>
Overview .....	3-1
Front Panel Indicators/Buttons.....	3-1
Menu Structure .....	3-1

Nx/DBU Menus Are All Submenus.....	3-2
Operation .....	3-3
5)PORT Status .....	3-4
Operation .....	3-4
Nx/DBU Status Menu Options .....	3-5
1)DTE DATA/CLOCK .....	3-5
2)DTE STATUS .....	3-5
3)DTE PORT RATE .....	3-5
4)DBU DATA/CNTRL .....	3-6
5)DBU CONTROL .....	3-6
6)DBU STATUS .....	3-7
7)PORT CONFIG, Submenu of 2)CONFIG .....	3-7
Operation .....	3-7
1)Nx56/64 CONFIG Menu Options .....	3-8
1)DS0 RATE .....	3-8
2)TX CLK CNTRL .....	3-9
3)DATA .....	3-9
4)CTS .....	3-10
5)DCD .....	3-10
6)DSR .....	3-10
7)0 INHIB .....	3-10
8)INBAND MODE .....	3-10
9)TX CLK SOURCE .....	3-12
DBU CONFIG Menu Options.....	3-12
1)Backup Mode .....	3-12
2)Backup On .....	3-12
3)Pattern Verify .....	3-13
4)Backup Delay .....	3-13
5)Restore Delay .....	3-13
6)Retry Delay .....	3-14
7)Num Retries .....	3-14
8)Backup Testing .....	3-14
9)WKEND Lockout .....	3-14
A)Enable HR: .....	3-14
B)Disable HR: .....	3-15
Trap in DBU: .....	3-15
2)FACTORY RESTORE, Submenu of 3)UTIL .....	3-15
Operation.....	3-15
5)PORT UTILITY, Submenu of 3)UTIL .....	3-15
Operation.....	3-16
2)RUN SELF TEST, Submenu of 4)TEST .....	3-17
3)PORT TEST, Submenu of 4)TEST .....	3-17

---

Operation .....	3-17
1.1 Nx/DBU Menu Options .....	3-18
1)DTE Loopback .....	3-18
2)511 PATT .....	3-19
3)511RESULTS .....	3-19
4)DBU LOOPBACK: (OFF/ON) .....	3-19
5)DBU TEST .....	3-19
6)DBU DATA/CNTRL .....	3-20
7)DBU TST RESULT .....	3-20
<b>Appendix A. System Messages .....</b>	<b>A-1</b>
<b>Index .....</b>	<b>Index-1</b>



# List of Figures

---

Figure 1-1. Nx/DBU Option Module .....	1-6
Figure 2-1. Installing the Option Module .....	2-2
Figure 3-1. TSU 100 Main Menu Tree .....	3-2
Figure 3-2. Nx/DBU Option Module Menu Tree .....	3-3
Figure 3-3. Port Status Submenu.....	3-4
Figure 3-4. DBU Status Submenu .....	3-7
Figure 3-5. Port Configuration Submenu .....	3-8
Figure 3-6. Inband Remote Configuration.....	3-11
Figure 3-7. Port Utility Submenu .....	3-16
Figure 3-8. Port Name and Software Version.....	3-16
Figure 3-9. Port Test Submenu .....	3-17
Figure 3-10. DBU TST Result Submenu .....	3-20



# List of Tables

---

Table 2-1. Nx V.35 Winchester Pin Connection.....	2-3
Table 2-2. DBU V.35 Winchester Pin Connection.....	2-4
Table 3-1. Normal Mode Operation .....	3-9



## **Nx/DBU V.35 OPTION MODULE OVERVIEW**

The Nx/DBU V.35 option module is one of the option modules available for use with the following TSU units:

- TSU 100
- TSU 120
- TSU 600
- TSU 610

The Nx/DBU V.35 option module installs in the option slot of the TSU units and provides an additional synchronous V.35 interface port with dial backup capability. When used in these products, this interface port allows an additional DTE to have access to the T1 service with dial backup capability in the event of a T1 failure.

In the remainder of this manual, the module will be called the Nx/DBU option module.

## **Functional Description**

The Nx/DBU option module operates in the option slot of the TSU units and is under the control of the TSU. The Nx/DBU option module is configured from the front panel or by an external PC program. The internal menus for their configuration are part of the Nx/DBU option module and are automatically installed when the Nx/DBU is installed in a TSU unit.

## FEATURES OF THE NX/DBU OPTION MODULE

### Nx Features

- Data rates from 56 kbps to 2.048 mbps in 56K or 64K increments
- Includes an elastic store for adsorption of rate variations
- Executes and responds to V.54 looping codes
- Outputs a 50 percent duty cycle output clock at all rates
- Provides an inband control channel (8 kbps for network management communication)
- Generates and checks 511 test pattern toward network
- 511 pattern generator is capable of injecting errors

### DBU Features

- Can verify integrity of dial-up network with a test pattern without disrupting T1 data
- Detect no data transitions on the data received from the network, with verify over inband channel
- User-definable delay between call retries if backup connection is not successfully established
- User-definable verification of dial up network (Daily Weekly, or On Command) without T1 data disruption
- Backup can be initiated by:
  - Alarm conditions on network (AIS, RAI, or Red Alarm)
  - Absence of data transitions for a user-defined delay
- Uses 8 kbps channel to check end-to-end connectivity before activating backup
- Disable backup based on hour of day and weekend
- Uses pattern to validate backup dial network

## Features Common to the Nx and the DBU

The following features are common to the Nx and the DBU:

- Configurable by using a PC program (T-Watch)
- Menu operation for easy configuration
- Performs self-test of option card hardware
- Can install multiple Nx/DBU modules in a TSU 600
- Hot-swappable

## Interfaces

The following interfaces are used with the Nx/DBU:

- Two CCITT V.35 electrical (differential)
- Two V.35 Winchester connectors

## SPECIFICATIONS OF THE NX/DBU

### Specifications: Nx56/64 (DCE Interface)

<b>DCE Interface</b>	CCITT V.35 synchronous
<b>Rates</b>	56 kbps to 2.048 mbps in 56K or 64K increments
<b>Clock Options</b>	Internal or internal-invert
<b>Tests</b>	Local loopback (bilateral) Remote loopback (V.54)
<b>Test Pattern</b>	511 with errored seconds display and error inject capability
<b>Data Inversion</b>	Menu selectable
<b>1s Density Protection</b>	Force 1s to network after one second of consecutive zeros from DTE User-selectable (On/Off)
<b>CTS, DCD, DSR</b>	Normal or Force On
<b>Connector</b>	Winchester (V.35), female

**Specifications: DBU (DTE Interface)**

<b>DTE Interface</b>	CCITT V.35 synchronous
<b>Backup Delay</b>	1 sec, 3 sec, 10 sec, 30 sec, 1 min, 5 min, 10 min
<b>DBU Dialing</b>	DTR dialing
<b>Restore Delay</b>	1 sec, 3 sec, 10 sec, 30 sec, 1 min, 5 min, 10 min, Never
<b>Rates</b>	56 kbps through 2.048 mbps in 56K or 64K increments
<b>Clocking</b>	Routes external DCE clocks to external DTE when active
<b>Connector</b>	Winchester (V.35) female
<b>Test</b>	Loopback to DCE Test dialup network Force dial backup

**SPECIFICATIONS: NX56/64 AND DBU**

<b>Mechanical</b>	Mechanically compatible with option slot of all TSUs
<b>Environmental</b>	Operating temperature from 0 °C to 45 °C
<b>Tests</b>	Extensive self-test

## PHYSICAL DESCRIPTION

The Nx/DBU option module plugs into the option slot in the rear of the TSU family of products (see Figure 1-1).

The **PORT X.1** and **X.2** indication is linked to the port numbering philosophy of the TSU product family. The **X** represents the slot number into which the option module is plugged.

- The TSU 100 has one option slot; therefore the port designation is **1.1**.
- The TSU 120 has one option slot; therefore the port designation is **1.1**.
- The TSU 600 and TSU 610 each have six option slots; therefore the port numbers would be port **1.1** to port **6.1**. The numbers appear in the front panel LCD menu display.




Figure 1-1. Nx/DBU Option Module

## UNPACK & INSPECT

Carefully inspect the option module for any shipping damage. If damage is suspected, file a claim immediately with the carrier and then contact ADTRAN Technical Support. If possible, keep the original shipping container for use in shipping the option module back for repair or for verification of damage during shipment.

### ADTRAN Shipments Include

- The Nx/DBU Option Module
- *The Nx/DBU Option Module User Manual* (to be inserted into main TSU user manual)

### Customer Provides


- DTE cable
- DCE cable

## INSTALLING THE OPTION MODULE

## Placement of the Option Module

Figure 2-1 shows proper placement of the option module. Perform the following steps to install the option module:

1. Remove the cover plate from the TSU unit rear panel.
2. Slide the option module into the rear panel of the TSU unit until it is positioned firmly against the front of the unit.
3. Fasten the thumbscrews at both edges of the option module.



**Figure 2-1. Installing the Option Module**

## Power Connection

Each option module derives power from the base TSU unit. Power to the TSU is supplied by a captive 8-foot power cord.

## Wiring

The Nx/DBU option module has two V.35 Winchester-style connections. The Nx connections are defined in Table 2-1, below. The DBU connections are defined in Table 2-2 on page 2-4.

**Table 2-1. Nx V.35 Winchester Pin Connection**

<b>Pin</b>	<b>CCITT</b>	<b>Description</b>
<b>A</b>	<b>101</b>	Protective ground (PG)
<b>B</b>	<b>102</b>	Signal ground (SG)
<b>C</b>	<b>105</b>	Request to send (RTS) from DTE
<b>D</b>	<b>106</b>	clear to send (CTS) to DTE
<b>E</b>	<b>107</b>	Data set ready (DSR) to DTE
<b>F</b>	<b>109</b>	Received line signal detector (DCD) to DTE
<b>H</b>	-	Data terminal ready (DTR) from DTE
<b>J</b>	-	Ring Indicator (RI)
<b>L</b>	-	Local loopback (LL) from DTE
<b>N</b>	-	Remote loopback (RL) from DTE
<b>R</b>	<b>104</b>	Received data (RD-A) to DTE
<b>T</b>	<b>104</b>	Received data (RD-B) to DTE
<b>V</b>	<b>115</b>	RX clock (RC-A) to DTE
<b>X</b>	<b>115</b>	RX clock (RC-B) to DTE
<b>P</b>	<b>103</b>	Transmitted data (TD-A) from DTE
<b>S</b>	<b>103</b>	Transmitted data (TD-B) from DTE
<b>Y</b>	<b>114</b>	TX clock (TC-A) to DTE
<b>AA</b>	<b>114</b>	TX clock (TC-B) to DTE
<b>U</b>	<b>113</b>	External TX clock (ETC-A) from DTE
<b>W</b>	<b>113</b>	External TX clock (ETC-B) from DTE
<b>NN</b>	-	Test mode (TM) to DTE

Table 2-2. DBU V.35 Winchester Pin Connection

Pin	CCITT	Description
A	101	Protective ground (PG)
B	102	Signal ground (SG)
C	105	Request to send (RTS) to DCE
D	106	Clear to send (CTS) from DCE
E	107	Data set ready (DSR) to DCE
F	109	Received line signal detector (DCD) from DCE
H	-	Data terminal ready (DTR) to DCE
J	-	Ring Indicator (RI) from DCE
R	104	Received data (RD-A) from DCE
T	104	Received data (RD-B) from DCE
V	115	RX clock (RC-A) to DTE
X	115	RX clock (RC-B) from DCE
P	103	Transmitted data (TD-A) to DCE
S	103	Transmitted data (TD-B) to DCE
Y	114	TX clock (TC-A) from DCE
AA	114	TX clock (TC-B) from DCE

## POWER-UP TESTING AND INITIALIZATION

The option module executes a self-test during the power-up sequence, as described in the TSU manual. No initialization input is required. Upon power-up, any previously configured setting for the option module is automatically restored.

When the self-test is complete and configuration is successfully restored, the LED labeled **OK** in the module group on the front panel turns **ON**. For more information on front panel operation, see the *Operation* chapter of the appropriate TSU user manual.

If any alarms are detected during operation, the red LED labeled **ALARM** in the module group on the front panel turns **ON**.

## OVERVIEW

The Nx/DBU option module is controlled as part of the TSU using the same methods as described in the appropriate TSU user manual.

## Front Panel Indicators/Buttons

Refer to the description of the front panel indicators and buttons in the appropriate TSU user manual.

## Menu Structure

The Nx/DBU option module menus appear as a subset of, and operate the same as, menus for the TSUs. The menus are accessed by selecting **1.1 Nx/DBU** under the **PORT** menu items.

The main menu for the TSU 100 is used for illustrative purposes. The main menus for the other TSU units operate in a similar way. Figure 3-1 on page 3-2 shows the TSU 100 main menu with the **PORT 1.1 Nx/DBU** menu items printed in ***bold, italicized*** letters.

A complete TSU 100 menu tree diagram is found in the *TSU 100 User Manual*.





Figure 3-1. TSU 100 Main Menu Tree

## Nx/DBU Menus Are All Submenus

The Nx/DBU option module menus are accessed from and operated the same as menus for the TSU 100. Menu items in the main menu in Figure 3-1 printed in bold italics are submenu choices for the Nx/DBU option module. See Figure 3-2 on page 3-3 for the menu tree for each of these submenu options. Each of these submenu items is discussed in the following paragraphs. All are accessed by the same method.

## Operation

With the cursor on one of the four main menu choices, press **Enter** or the number key. The results are a display of the first two submenu items with the cursor on the first item. Use the **scroll down** key to place the cursor on the desired item then press **Enter**. This displays the first two submenu choices. The Nx/DBU option module menu tree selections are discussed in the sections following Figure 3-2.



**Figure 3-2. Nx/DBU Option Module Menu Tree**


## 5)PORT Status

The Status menu branch allows you to view the status of the TSU 100 operation. It displays the status of the monitored signal line on the Nx/DBU option module and the data rate for which the option module is configured.

### Operation

To display Figure 3-3 on the TSU 100, starting with the cursor on main menu item **STATUS**, do the following:

1. Press **Enter** or the number **1** key. This displays the first two Status submenu items with the cursor on **1)NI PERF RPTS**.
2. Use the **Scroll Down** key to place the cursor on **PORT STATUS** and press **Enter**. This displays the first available port.
3. Use the scroll keys to find **1.1 Nx/DBU** and press **Enter**.



**Figure 3-3. Port Status Submenu**

The base Nx interface offers the status screens listed in this manual. For other option modules, refer to the appropriate manual.

## Nx/DBU Status Menu Options

Select the **1.1 Nx/DBU**. The following five menu options are available:

### 1)DTE DATA/CLOCK

Shows the status (active or not active) of the following lines:

#### **TXD**

Transmit data to the DTE

#### **RXD**

Receive data from the DTE

#### **ETC**

External transmit clock from DTE

#### **LCK**

Lock status of the phase locked loop

### 2)DTE STATUS

Shows the status (active or not active) of the following lines:

#### **RTS**

Request to send from DTE

#### **CTS**

Clear to send to DTE

#### **DCD**

Data carrier detect to DTE

#### **DSR**

Data set ready to DTE

### 3)DTE PORT RATE

Displays the data rate to which the Nx port is set.

#### 4)DBU DATA/CNTRL

Shows the status (active or not active) of the following lines:

**TXD**

Transmit data to the DCE

**RXD**

Receive data from the DCE

**DCD**

Data carrier detect from DCE

**RI**

Ring indicate from DCE

#### 5)DBU CONTROL

Shows the status (active or not active) of the following lines:

**RTS**

Request to send to DCE

**CTS**

Clear to send from DCE

**DTR**


Data terminal ready to DCE

**DSR**

Data set ready from DCE

## 6)DBU STATUS

Shows current backup state (see Figure 3-4).



**Figure 3-4. DBU Status Submenu**

DBU SECS	Total seconds the option module has been in backup.
IN DBU - Yes	Module is in backup mode.
IN DBU - No	Module is not in backup mode.

To exit the display, see the the appropriate TSU user manual.


## 7)PORT CONFIG, Submenu of 2)CONFIG

The **7)PORT CONFIG** submenu is used for configuration of the Nx/DBU option module.

### Operation

To display the screen shown in Figure 3-5 on page 3-8, on the TSU 100, position the cursor on **CONFIG**, and do the following:

1. Press **Enter** or the number **2** key. This displays the first two Configuration submenu items with the cursor on **NETWORK (NI)**.
2. Use the **Scroll Down** key to place the cursor on **PORT CONFIG** and press **Enter**.
3. Use the scroll keys to identify **1.1 Nx/DBU** option module. Only the bottom line of the display changes.



**Figure 3-5. Port Configuration Submenu**

4. To select **PORT CONFIGURATION**, press **Enter**. This displays the following menu options:
  - **Nx56/64 CONFIG**
  - **DBU CONFIG**
5. Place the cursor over the desired option and press **Enter** to configure.

Menu options for the Nx56/64 and the DBU are given in the following pages.

## **1)Nx56/64 CONFIG Menu Options**

Select the **1)Nx56/64** menu option to access the following eight menu options:

### **1)DS0 RATE**

This sets the base rate of the interface. The actual data rate depends on the number of DS0s assigned to the DTE Data Rate Chart in the TSU 100 User Manual.

Choices - 56K or 64K

## 2)TX CLK CNTRL

Controls the clock used by the TSU 100 to accept the transmit (TX) data from the DTE. Normally this is set to **INTERNAL**.

If the interface cable is long, causing a phase shift in the data, the clock can be selected as **INT/INV** (Internal/Inverted). This switches the phase of the clock which should compensate for a long cable.

Choices - Normal or Invert

## 3)DATA

Used to control the inverting of the DTE data. This inversion can be useful when operating with a high level data link (HDLC) protocol. Often used as a means to ensure 1s density.

Choices - Normal or Invert

Table 3-1 shows the conditions which cause the port control signal to be deactivated.

**Table 3-1. Normal Mode Operation**

Signal	RTS	V.54 Loopback	511 Test ON	Self Test Active	Network test Active	No DS0 Mapped	Network Alarm*
CTS	Follows	Off	Off	Off	Off	Off	Off
DCD	-	-	-	Off	-	Off	Off
DSR	-	Off	Off	Off	Off	Off	-
- Do not care *Until backup becomes active							

#### 4)CTS

Used to control characteristics of CTS.

Choices - Normal or Force On (see Table 3-1 on page 3-9).

#### 5)DCD

Data Carrier Detect - Indicates to the DTE when a valid signal is being received at the Network Interface.

Choices - Normal or Force On (see Table 3-1 on page 3-9).

#### 6)DSR

Data Set Ready - This signal indicates to the DTE when the DCE is turned On and ready for operation.

Choices - Normal or Force On (see Table 3-1 on page 3-9).

#### 7)0 INHIB

If the Nx interface detects an uninterrupted string of 0s being transmitted toward the network. If 0s are transmitted for more than one second, then the TSU 100 forces 1s towards the network.


Choices - On or Off

#### 8)INBAND MODE

Inband Configuration Channel - Used to enable or disable an 8 kbps remote configuration channel (see Figure 3-6 on page 3-11).

When this option is set to **ON**, the first DS0 mapped to the Nx interface operates in 56K mode and the DTE clock rate is reduced by 8 kbps. The TSU uses this 8 kbps channel to send and receive configuration data across a T1 span. As shown in Figure 3-6, this allows the PC connected to the chain-in port on TSU 600 A to monitor/configure both TSU 600 A and B. This feature is useful when FDL connectivity is not available across the T1 span.

This 8 kbps channel is only taken out of the first DS0. If two 64K DS0s are mapped, the DTE rate would be 120 kbps instead of 128 kbps.



**Figure 3-6. Inband Remote Configuration**

When the inband configuration channel is enabled, the NxDBU uses the channel to verify end-to-end connectivity of the T1 network. This provides more robust monitoring of the primary network.



*Enabling the inband channel is especially useful in networks where alarms are not passed end-to-end. In these circuits, the inband channel should be On for complete DBU protection.*

## 9)TX CLK SOURCE

Controls the clock used by the DTE. Normally this is set to **INTERNAL**. If the DTE provides a clock with TX data, the clock selection is set to **EXTERNAL**. The NX 56/64 will depend on an externally supplied clock to accept the TX data.

Choices - INTERNAL or EXTERNAL

## DBU CONFIG Menu Options

Select the **DBU CONFIG** menu option to access the menu options discussed in this section.

### 1)Backup Mode

#### **Originate**

When a backup condition is detected, this end of the circuit activates the backup by initiating a call to the answer end.

#### **Answer**

This end of the circuit goes into backup when a call comes in and a backup condition is detected.

### 2)Backup On

This selects the conditions that use the Nx/DBU to initiate backup.

#### **Net Fail**

Backup occurs on Red Alarm, Yellow Alarm, Blue Alarm, and LOS.

**Net/Data Fail**

Backup occurs on the same conditions as Net Fail plus loss of data transitions on the data the Nx56/64 receives from the network.

**NOTE**

*When the inband channel is enabled, it is used to periodically verify the connection and detect backups. When enabled, this is the primary criteria used for detecting backup conditions.*

**3)Pattern Verify****Enable/Disable**

This selects whether or not the DBU will use its pattern generator and receiver to authenticate backup attempts. When the local and remote units are both Nx/DBUs, set to ENABLE; otherwise set to DISABLE.

**4)Backup Delay**

This selects the time allowed to elapse between the network going into alarm or no data transmissions and the backup beginning.

Choices: 1 sec, 3 sec, 10 sec, 30 sec, 1 min, 5 min, 10 min.

**5)Restore Delay**

This selects the time that elapses between the network going out of alarm or data and the backup call being taken down. If **NEVER** is selected, the user must deactivate the backup mode.

Choices: 1 sec, 3 sec, 10 sec, 30 sec, 1 min, 5 min, 10 min, never.

## 6)Retry Delay

This selects the time between redialing the external DCE after failed dial attempts.

Choices: 10 sec, 30 sec, 1 min, 5 min, 10 min

## 7)Num Retries

This selects the number of times the DBU will attempt to redial if unable to connect.

Choices: None, unlimited, 3 times, 10 times.

## 8)Backup Testing

This submenu sets the options for the automatic ISDN verification feature of the Nx/DBU. Verification of the backup circuit does not disrupt data of the T1.

### Backup Test

This selects the frequency of automatic backup circuit verification by the DBU.

Choices: Manual, hourly, daily, weekly

### Test Hour

This selects the hour of the day the backup test will occur

Choices: 0 to 23.

### Test Day

If weekly backup test is selected, this option will select which day to perform the test.

Choices: Monday through Sunday

## 9)WKEND Lockout

If no backup is desired from midnight Friday to midnight Sunday, set this selection to ON; otherwise set to OFF.

Choices: OFF, ON

## A)Enable HR:

The hour that the backup will be enabled can be entered from the numeric keyboard.

Choices: 0 to 23

**B)Disable HR:**

The hour that the backup will be disabled can be entered from the numeric keypad.

Choices: 0 to 23

**Trap in DBU:**

If traps are enabled (See Unit Configuration), this parameter will send either a single trap upon going into a DBU session or send repeated traps for the duration of the DBU session.

Choices: Single; Repeated



*For items A and B to function properly, verify that the time and date in the TSU are set correctly. Consult the appropriate TSU user manual for instructions for setting date and time.*

**2)FACTORY RESTORE, SUBMENU OF 3)UTIL**

This selection is used to restore the factory default settings for all pass-through option module parameters.

**Operation**

To return the unit to the opening main menu with all the factory default settings restored, do the following:

1. Follow the standard operating procedure to access the **3)UTIL** menu items.
2. With the cursor on **2)FACT RESTORE**, press **Enter**.


**5)PORT UTILITY, SUBMENU OF 3)UTIL**

The **5)PORT UTILITY** submenu is used to access the display of the current software information for each port installed in the unit. This information is required when requesting assistance from ADTRAN Technical Support or when updates are needed.

## Operation

To display the screen on the TSU 100 shown in Figure 3-7, do the following:


1. Follow the standard operating procedure to access the **3)UTIL** menu items.
2. With the cursor on **5)PORT UTILITY**, press **Enter**. This displays the first available port.



**Figure 3-7. Port Utility Submenu**

To display the port name and the software version installed as shown in Figure 3-8, do the following:

1. Use the scroll keys to move through the available ports, or enter the port number with the number key.
2. When the desired port name is displayed, press **Enter**.
3. Press **Cancel** to exit or to select another port.



**Figure 3-8. Port Name and Software Version**

## 2)RUN SELF TEST, SUBMENU OF 4)TEST

This menu item is used to execute both the internal test of the TSU and of the Nx/DBU. The results of the self-test are shown on the TSU 100 display. For additional information on self-test, see the *Operation* chapter of the appropriate TSU user manual.

To activate a self-test, do the following:

1. Follow the standard operating procedure to access the **4)TEST** menu items.
2. With the cursor on **2)RUN SELF TEST**, press **Enter**. The TSU display shows the test outcome.

## 3)PORT TEST, SUBMENU OF 4)TEST


This menu item is used to activate testing of specific data ports. It also controls the activation of loopbacks and the initiation of data test patterns. Test results are shown on the TSU display.



*The execution of Port Tests disrupts normal data flow in the port being tested.*

### Operation

To display Figure 3-9 on the TSU 100, place the cursor on **3)PORT TEST**, and press **Enter** or the number **3** key. This displays the available ports.



**Figure 3-9. Port Test Submenu**

## 1.1 Nx/DBU Menu Options

The **1.1 Nx/DBU** interface offers the following seven test functions:

### 1)DTE Loopback

Initiates a loopback.

#### **PRT/LOCAL**

The Nx port activates both a local loopback (back toward the DTE) and a port loopback when either is invoked.

#### **REMOTE**

The remote loopback causes a channelized V.54 code to be sent to the far end. The Nx at the far end activates a **PORT/LCL** loopback on detection of the V.54 code.

#### **REM V.54 CONT**

This loopback causes continuous V.54 code to be sent to the far end. The Nx at the far end activates a **PORT/LCL** loopback upon detection of the V.54 code.

#### **OFF**

The loop is deactivated.



*The TSU checks the remote loopback activation by detecting a proper response from the remote end. While waiting for the response, the display shows **Looping**. If successful, the display changes to **Looped Up**. If unsuccessful, the display shows **Failed**.*

---

## 2)511 PATT

Activates the generation of the 511 test pattern toward the T1 network. Options are:

### **On**

The pattern check circuitry is enabled and the test is started. The test is ended by selecting Off.

### **Off**

The pattern generation and check is disabled.

## 3)511RESULTS

Displays the results of the 511 test indicated in menu selection **2)511 PATT**.

The results are in the form of the number of errored seconds. The error count can be cleared by pressing the **Clear** key (**Shift + 9**). A bit error may be inserted into the data stream by pressing the **2** key.

## 4)DBU LOOPBACK: (OFF/ON)

Initiates a loopback from the DBU towards the external DCE.

## 5)DBU TEST

This selection is used to force a backup to occur even if a backup condition does not exist.

Choices: TESTS OFF, FORCED BACKUP, INTERFACE TST

### **TESTS OFF**

Turns off DBU tests.

### **FORCED BACKUP**

Used to force a backup regardless of time-of-day lock-outs or network conditions.

### **INTERFACE TST**

This test causes the external DCE to dial its stored number. After the connection is established the DBU will


send a test pattern to verify the backup network. This test does not disrupt data or the primary network.

### 6)DBU DATA/CNTRL

Allows status of DCD and RI to be monitored while the **INTERFACE TST** is on. If the dial up network is correctly configured and dialed up, there should be an asterisk (\*) over DCD.

### 7)DBU TST RESULT

When an interface test is active, this screen will show the total number of data blocks received and the number of blocks with errors (see Figure 3-10).



**Figure 3-10. DBU TST Result Submenu**

## ALARM MESSAGES

### Network Interface (NI)

**Red Alarm**

NI unable to align frame with incoming signal

**Yellow Alarm**

Remote alarm indication (RAI) being received from the far end

**Blue Alarm**

Unframed all 1s (AIS) being received at NI

**Loss of Signal**

No signal detected at NI

### Nx/DBU Option Module

**Clock Slip**

Difference in frequency of the data clock at the network and DTE

**PLL Alarm**

Unable to lock phase lock on the clock provided by the network interface

**Zeros Alarm**

All 0s data being sent to the network interface

**No EXT Clock**

No external transmit clock at DTE (when applicable)

**STATUS MESSAGES**

**Network Interface (NI)**

**Payload On**

Payload loopback activated

**Line On**

Line loopback activated

**Loopback Off**

All loopbacks deactivated

**Factory Restore**

Factory setting restored

**Power On**

Unit powered on

**Self-Test**

Internal self-test performed

## Nx/DBU Option Module

### **Loop-Up**

Data is looped back at both the network interface and the DTE interface of the card.

### **Remote Loop Up**

Sending a V.54 pattern in an attempt to loop up a remote device.

### **511 Pattern On**

Sending a 511 pattern towards the network interface

### **Loop Down**

Data is no longer looped back at the network interface or the DTE interface

### **511 Pattern Off**

No longer sending a 511 pattern towards the network interface



# Index

---

## Numerics

- 0 INHIB, Nx 56/64 config option 3-10
- 1.1 Nx/DBU Menu Options 3-18
- 511 PATT
  - (OFF/ON) 3-19
- 511RESULTS 3-19

## A

- ADTRAN Shipments Include 2-1

## B

- Backup Mode, DBU config 3-12
- Backup On, DBU config 3-12
- Backup Testing, DBU config 3-14

## C

- CCITT V.35, interface used with Nx/DBU 1-3
- Customer Service iv

## D

- Data Carrier Detect 3-10
- Data Set Ready 3-10
- DBU CONFIG Menu Options 3-12
- DBU CONTROL 3-6
- DBU DATA/CNTRL 3-6
- DBU Features 1-2
- DBU STATUS 3-7
- DBU TEST 3-19
- DBU TST RESULT 3-20
- DBU V.35 Winchester Pin Connection 2-4
- DCD, Nx 56/64 config options 3-10
- Disable HR, wkend lockout 3-15
- DS0 RATE, Nx56/64 Config option 3-8
- DSR, Nx 56/64 config option 3-10
- DTE DATA/CLOCK 3-5
- DTE STATUS 3-5

## F

- FACTORY RESTORE 3-15
- factory restore, operation 3-15
- Federal Communications commission Radio Frequency Interference Statement iv
- FORCED BACKUP, DBU test 3-19
- front panel indicator buttons, see TSU user manual 3-1

## I

- INBAND MODE, Nx/56/64 config options 3-10
- Installing the Option Module, how to 2-1
- INTERFACE TST, DBU test 3-19
- Interfaces, used with Nx/DBU 1-3

## N

- Num Retries, DBU config 3-14
- Nx Features 1-2
- Nx V.35 Winchester Pin Connection 2-3
- Nx/DBU menu tree 3-3
- Nx/DBU Option Module, features 1-2
- Nx/DBU V.35 Option module Overview 1-1
- Nx/DBU, overview 3-1
- Nx56/64 and DBU, mechanical specs
  - environmental specs 1-5
- Nx56/64 CONFIG 3-8
- NxDBU, Functional Description 1-1

## P

- Pattern Verify, DBU config 3-13
- PORT CONFIG 3-7
- port config, operation 3-7
- PORT Status 3-4
- port status, how to access 3-4
- PORT TEST 3-17
- port test, operation 3-17
- port utility, operation 3-16
- Power Connection, to the TSU unit 2-2

Power-Up Testing and Initialization 2-4  
product warranty v

## **R**

Restore Delay, DBU config 3-13  
RTS, CTS, DCD, DSR 3-5  
RTS, CTS, DTR, DSR, 3-6  
RUN SELF TEST 3-17

## **S**

Shipping damage, in case of 2-1  
Specifications  
    DBU (DTE Interface 1-5  
    Nx56/64 (DCE Interface) 1-4  
Status Menu, options 3-5

## **T**

tests 1-5  
TESTS OFF, DBU test 3-19  
TSU 100 menu tree 3-2  
TX CLK CNTRL, Nx56/64 config options 3-9  
TX CLK SOURCE, Nx 56/64 config option 3-12  
TXD, RXD, DCD, RI 3-6  
TXD, RXD, ETC, LCK 3-5

## **V**

V.35 Winchester connectors, interfaces used with  
Nx/DBU 1-3

## **W**

Warranty and Customer Service iv  
Wiring, pin connection 2-3  
WKEND Lockout, DBU config 3-14

# Product Support Information

## Pre-Sales Inquiries and Applications Support

Please contact your local distributor, ADTRAN Applications Engineering, or ADTRAN Sales:

Applications Engineering      (800) 615-1176

Sales      (800) 827-0807

## Post-Sale Support

Please contact your local distributor first. If your local distributor cannot help, please contact ADTRAN Technical Support and have the unit serial number available.

Technical Support      (888) 4ADTRAN

## Repair and Return

If ADTRAN Technical Support determines that a repair is needed, Technical Support will coordinate with the Customer and Product Service (CaPS) department to issue an RMA number. For information regarding equipment currently in house or possible fees associated with repair, contact CaPS directly at the following number:

CaPS Department      (256) 963-8722

Identify the RMA number clearly on the package (below address), and return to the following address:

ADTRAN, Inc.  
CaPS Department  
6767 Old Madison Pike  
Progress Center  
Building #6, Suite 690  
Huntsville, AL 35807

RMA # \_\_\_\_\_

