# USER'S MANUAL

COMPACT MACHINE ''NEO''

TEJT-C

### **FOREWORD**

This user's manual is a guide book for using TAJIMA embroidery machine TEJT-C "NEO" correctly. It describes about operation of the machine and items to notice for use. Please read this manual thoroughly, understand the contents, and then use the machine.

This manual is composed of the following contents.

[IMPORTANT SAFETY INSTRUCTIONS]

[IMPORTANT WARNING ITEMS FOR SAFE OPERATION]

[CONSTRUCTION OF THE MACHINE]

[BASIC OPERATION]

[SETTING•OPERATION]

[OUTLINE OF FUNCTION]

[ELECTRICAL COMPONENT]

[TROUBLESHOOTING AND MAINTENANCE]

Regarding optional devices, please refer to the user's manual of the device you have chosen.

This manual may contain discrepancies in detailed information when compared with the actual machine due to continued research and improvements. If any question about the machine or contents of this manual arises, please consult your TAJIMA distributor.

Please keep this manual near the machine for immediate reference. When this manual is not used, keep it carefully.

Tokai Industrial Sewing Machine Co., Ltd.

### IMPORTANT SAFETY INSTRUCTIONS

Operation of this machine requires correct operation and appropriate maintenance to ensure safety.

Please read the IMPORTANT SAFETY INSTRUCTIONS in this manual carefully and do not attempt operation or maintenance of the machine before you thoroughly understand the items written under IMPORTANT SAFETY INSTRUCTIONS.

Items that require your special attention on operation and maintenance of the machine are specified below with the warning symbol and signal word. These items must be strictly observed to ensure safety during operation and maintenance. Signal word definition is given below.

### **A** DANGER

Indicates that there is a lot of danger or death or serious injuries [\*1] if the instruction is not observed.

## **MARNING**

Indicates that there is a likelihood of death or serious injuries [\*1] if the instruction is not observed.

### **A** CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury [\*2] or property damage.

- \*1:A condition caused by electric shock, injury, fracture of a bone, etc., that leads to aftereffects, or an injury that necessitates hospitalization or visits to a hospital over a long period.
- \*2: An injury that does not necessitate hospitalization or visit to a hospital over a long period.



Items that may cause electric shock if not observed

- : Items that must be followed carefully to ensure safe operation
- : Instructive items regarding connection of grounding wire

: Items that must be observed to perform works comfortably

: Items that explain the contents of sentences in detail and items that complement the contents.

# Contents

FOREWORD IMPORTANT SAFETY INSTRUCTIONS

1.	IMPORTANT WARNING ITEMS FOR SAFE O	PERATION
	CARRYING	
	INSTALLATIONWIRING	
	INSTRUCTIONS FOR USE	
	WARNING LABELS	
	W/KKING E/BEES	1-3
2.	MACHINE CONSTRUCTION	
	NAME OF EACH PART	2-2
	MAIN SPECIFICATIONS	2-9
	AMBIENT NOISE LEVEL	2-9
3.	OPERATION BASICS	
	MACHINE START AND STOP	3-2
	PRECAUTIONS FOR HANDLING FLOPPY DISK DRIVE (OPTION)	
	PROGRAM INSTALLATION	
	OPERATION FLOW UP TO START OF EMBROIDERY	3-8
	EXPLANATION ON THE SCREEN	
	INSPECTIONS BEFORE STARTING OPERATION	
١.	DATA SET MENU	
	DATA INPUT (FLOPPY DISK)	4-2
	INPUT DATA (SERIAL CONNECTION 1)	
	INPUT DATA (SERIAL CONNECTION 2)	
	SELECT DATA	
	DELETE DATA	
	MEMORY MODE	4-10
	INITIAL MEMORY	4-11
5.	COLOR CHANGE	
	MODE SWITCHING	
	NEEDLE BAR SETTING (INPUT OF STEP)	
	NEEDLE BAR SETTING (CHANGE OF STEP)	
	SETTING FOR TEMPORARY STOP	5-5
<b>)</b> .	DESIGN EDIT	
	ROTATE	6-2
	MIRROR	
	REPEAT	6-4
7.	MACHINE SETTING	
	SCREEN	7-2
	THREAD BREAKAGE SENSOR	
	PRESET HALT (SETTING)	
	PRESET HALT (COUNTER)	
	TRIM LENGTH	
	TRIM TIMING	7-7
	JUMP CONVERSION	7-8
	AUTOMATIC JUMP	7-9
	A/S TIMING	7-10
	THE NUMBER OF INCHING TIMES	
	TIE SET (TIE STITCHING)	
	SATIN ADJUSTMENT	7-13

### CONTENTS

	BORING	7-14
	CORDING	7-15
	COM SPEED	7-16
	NETWORK	7-17
8.	FRAME SETTING	
	MANUAL SPEED	8-2
	OFFSET	
	ORIGIN RETURN	
	FRAME MODE	
	INITIAL	
9.	Manual operation	
	MANUAL COLOR CHANGE	9-2
	MANUAL ORIGIN RETURN	
	TRACE	
	OFFSET (SETTING FOR POSITION)	
	OFFSET (CHANGE OF POSITION)	9-6
	OFFSET (FRAME TRAVEL)	
	MANUAL THREAD TRIMMING	
	FRAME BACK/FORWARD (FEED UNIT)	9-9
	FRAME BACK/FORWARD (N-STITCH FEED)	
	FRAME FORWARD	
	FRAME BACK	9-12
40	). OUTLINE OF FUNCTIONS	
I	OUTLINE OF FUNCTIONS	
	ROTATE	10-2
	MIRROR	
	REPEAT	10-3
	OFFSET	10-4
	SATIN ADJUSTMENT	10-6
	TRACE	10-7
11	. ELECTRO-COMPONENT PARTS	
	POWER SUPPLY BOX	11-2
	POWER CARD	
	CONSOLE 1 CARD	
	COMPUTER CARD	
	CONSOLE 2 CARD	11-4
40	2. TROUBLESHOOTING AND MAINTENANCE	<b>=</b>
14	INCODELONGO INTO AND MAINTENANOL	=
14		
14	WHEN THE MACHINE IS STOPPED DURING OPERATIONWHEN TROUBLE OCCURS	12-2
14	WHEN THE MACHINE IS STOPPED DURING OPERATION	12-2

Electro-relative drawing

# 1.IMPORTANT WARNING ITEMS FOR SAFE OPERATION

CARRYING	1-2
INSTALLATION	1-2
WIRING	1-3
INSTRUCTIONS FOR USE	1-4
WARNING LABELS	1-5







#### Carrying

### **WARNING**

- Carrying of this machine should be performed by two or more persons. Dropping could cause injury or breakdown.
- When carrying the machine, hold the correct spots. Dropping could cause injury or breakdown.





# **A** CAUTION

Do not transport, store, and operate the machine in an area of which altitude exceeds 1,000m.

#### Installation

### **CAUTION**

- Do not use the machine in ambient temperature of 45°C or more, or 5°C or less at running, at a place with much humidity, and outside.

  It could cause breakdown.
- Do not use the machine at a place where strong electric field or magnetic field is generated by such as high output high-frequency generator, high-frequency welder, etc. It could cause injury or breakdown due to malfunction.
- Place the machine on a firm stand horizontally. Dropping could cause injury or breakdown.
- Install the machine so that the embroidery frame or the drive section of the machine does not hit things or wall near the machine.

  It could cause injury or damage of the machine.

### Wiring


Insulation resistance: 10M ohms or more (500 V megger)

### **A** CAUTION



Connect grounding wire of power cord to the ground (class D or more, grounding resistance 100 ohms or less).

If using the machine without grounding, there could be a danger of electric shock due to leak current.



IA09



#### Instructions for use

### WARNING



N Do not have your hands or face access to moving unit during running of the machine. Especially, the vicinity of needle is dangerous.

It could cause injury.



Do not damage, modify or heat the power or other wiring cords. Do not exert undue force to them, either,

Cord will be damaged causing fire or electric shock.



Insert power cord securely.

If electric poles of power plug touch metal, etc., it could cause fire or electric shock.



Keep away electric section from water and chemicals.

Circuit will have short-circuit causing fire or electric shock.


If entered, turn off the power switch and contact the distributor after turning off the primary power supply.




When pulling out power cord, hold the plug to pull out the cord.

Pulling out cord will cause cord and plug to be damaged causing fire or electric shock.

## CAUTION



By performing operation for total fitting, life of the machine will become longer, which will be useful to avoid unexpected troubles.



It could cause breakdown.

- Only the persons who are sufficiently trained for the operation must operate the machine. Wrong operation could cause injury.
- Read this user's manual thoroughly, understand the contents of operation securely, and then operate the machine.

Wrong operation could cause injury.


- Operate the machine with proper clothing and appearance. Operating the machine with improper clothing and appearance could cause injury.
- Do not ride on the machine. It could cause injury.
- Do not use the machine with take-up lever guard or cover of movable unit detached. It could cause injury.

FD11 1-4

#### **WARNING LABELS**

The machine has warning labels that bear instructions for safe operation. Machine operators must follow the instructions shown on the warning labels.


Do not detach this label or make it illegible by painting, etc. If a warning label is missed or damaged, please contact the distributor.



IA09 1-5

## 2. MACHINE CONSTRUCTION


NAME OF EACH PART	2-2
MAIN SPECIFICATIONS	2-9




### Ш

### Name of each part


#### 1. Main body of embroidery machine (multi needle machine)






- 1. Thread guide system
- 2. Tension base
- 3. Operation panel box
- 4. Color change motor
- 5. Thread holding motor
- 6. Jump motor
- 7. Needle bar case
- 8. Z-spec. frame
- 9. Needle plate
- 10. Stand
- 11. Leveling adjuster
- 12. Thread stand stud
- 13. X-axis motor
- 14. Main shaft motor
- 15. Y-axis motor
- 16. ATH Motor
- 17. FDD connector
- 18. Serial connector
- 19. Power supply connector
- 20. Oil draining hole

#### 2. Main body of embroidery machine (1-needle machine)






- 1. Thread guide system
- 2. Operation panel box
- 3. Take-up lever guard
- 4. Rotary-type tension disk
- 5. Thread holding motor
- 6. Thread wipe pin
- 7. Needle bar case
- 8. Z-spec. frame
- 9. Needle plate
- 10. Stand
- 11. Leveling adjuster
- 12. Thread stand stud
- 13. X-axis motor
- 14. Main shaft motor
- 15. Y-axis motor
- 16. ATH Motor
- 17. FDD connector
- 18. Serial connector
- 19. Power supply connector
- 20. Oil draining hole




#### 3. Table



To attach the table, insert brackets to the attaching openings so that they are fitted to the openings, and then tighten the screws.


When detaching the table, do not lose the screws.

#### 4. Thread course support bar



Remove the screw to move up the thread course support bar to the position where a screw hole exists, and then tighten the screw.

#### 5. Operation panel box



- 1. LCD display area
- 2. Operation panel
- 3. DIP switch
- 4. Speed controller
- 5. Buzzer
- 6. Emergency stop switch
- ⚠ Do not push the operation panel with a sharp-pointed object. It could cause breakdown.

FD11 2-5

## Ш

#### 6. DIP switch

#### DSW2

No.	Contents	OFF	ON
8	_	*	_
7	_	*	_
6	_	*	_
5	_	*	_
4	Satin conversion	* Adjusts stitch length of 1.5 mm and more	Corrects stitch length of 0.6 mm and more
3	Satin correction	* Corrects X and Y at the same time	Corrects X and Y individually
2	Origin of installation	* From floppy disk drive	From personal computer
1	Operation mode 2	* Usual operation mode	Installation mode Turn ON DSW1-1


#### DSW1

No.	Contents	OFF	ON
8	Main shaft accelera- tion	* Standard	Acceleration: High speed
7	_	*	_
6	_	*	_
5	_	*	_
4	Moving direction of the frame travel key	* Based on frame	Based on design
3	The number of times of buzzer	* 10 times	Once
2	LCD character display	* English	Japanese
1	Operation mode 1	* Usual operation mode	Test mode

- After changing DIP switch, turn on the power switch again.
- \*: Setting at shipment

**2-6** FD11


#### 7. Operation panel



- 1. Data set menu key
- 2. Color change set key
- 3. Design edit key
- 4. Machine setting key
- 5. Frame set key
- 6. Numerical keys
  [10]: Use this key for needle bar of number 10 and more
- 7. Escape (ESC) key
- 8. Clear key
- 9. Set (SET) key
- 10. Trace key
- 11. Frame forward key
- 12. Offset key
- 13. Frame back/forward (feed unit) switching key
- 14. Thread trimming (ATH) key
- 15. Frame back key
- 16. Frame travel key
- 17. Origin return key
- 18. Color change (automatic/manual) switching key
- Manual operation lamp Lights when manual color change is performed
- 20. Needle bar case left slide key
- 21. Needle bar case right slide key
- 22. Stop switch
- 23. Start switch


### Ш

#### 8. Power supply box



- 1. DC power supply connector
- 2. Power switch
- 3. AC power supply connector

### 9. Floppy disk drive



- 1. Disk ejection button
- 2. Operation indicator lamp
- 3. FDD connector

#### Main specifications

## CAUTION

When using the machine deviating from contents of specifications of power supply and power consumption, trouble may occur.

Specification	Contents of specifications
r.p.m.	120 - 1,200 rpm
Embroidery space	360 × 500 mm
Input data	Up to 280,000 stitches, 99 designs
Weight	80 kgs
Outside dimension	W 665 × L 805 × H 796 mm
Electric current*capac- ity*Hz	1.2A (200V) 225VA 50/60 Hz
Power supply•power consumption	Single-phase AC: 100- 120V, 200 - 240V Max. 220 W

The maximum number of revolutions is limited depending on frame setting or stitch length.

Insulation resistance: 10M ohms and more (500V megger)


## WARNING



Connect grounding wire of power cord to the ground (class D or more, grounding resistance 100 ohms or less). If using the machine without grounding, there could be a danger of electric shock due to leak current.

#### **Ambient noise level**

The ambient noise level of the machine is less than 85 dB. Measuring conditions are as follows.




- **♦**Measuring ambience (refer to the illustration shown left)
- **♦**Measuring position Measured at B and C of which height is 1.6 m from the floor, and higher value is adopted.
- **♦**Operating condition of the machine Cloth is stretched to the border frame, and satin stitch sewing of 4 mm stitch length is executed.
- **♦**R. P. M. The maximum number of revolutions of the machine
- **♦**Measuring tool Conformity to IEC61672-1: 2002 Class 1

IA09 2-9

### 3. OPERATION BASICS

MACHINE START AND STOP	3-2
PRECAUTIONS FOR HANDLING FLOPPY DISK DRIVE (OPTION	) 3-3
PROGRAM INSTALLATION	3-4
OPERATION FLOW UP TO START OF EMBROIDERY	3-8
EXPLANATION ON THE SCREEN	3-9
INSPECTIONS REFORE STARTING OPERATION	3-1/






#### **MACHINE START AND STOP**

#### 1. Power switch

The power switch is located on the power supply box.




When turning ON the power again, turn "OFF" the power switch and wait for two or three seconds. Then, turn it "ON".

#### 2. Emergency stop switch

To stop the machine in an emergency, press the emergency stop switch. Pressing the emergency stop switch will cause the main shaft to stop immediately.

To release the stop lock, turn the switch to the direction indicated by the arrow.




When releasing the emergency stop, do not move the frame.

#### 3. Start switch and stop switch

The start switch starts the machine and the stop switch stops the machine.

When starting the machine with the start switch kept to be pushed, the machine will start with inching. When the start switch is released, the speed will become normal speed.


Pressing the stop switch will cause the needle bar to stop at the fixed position.



#### PRECAUTIONS FOR HANDLING FLOPPY DISK DRIVE (OPTION)

### **A** CAUTION

- O not put the floppy disk near magnets or a TV set.
- O not expose the floppy disk to excessive heat, humidity, or direct sunlight.
- O not place objects on the floppy disk.
- O not stack floppy disks to store.
- Floppy disks do not last eternally. Data must be copied to backup floppy disks for storage.
- O Do not use damaged or deformed floppy disk, otherwise the floppy disk drive could be damaged.
- Clean the floppy disk drive once a month using a cleaning disk. If the head is foul, trouble to reading/writing data could occur.
- O not open the shutter. The disk may be soiled.
- To prevent the stored data from being erased, slide the tab of the write protect switch to open the write protect window of a floppy disk (write protect state).
- Insert a floppy disk slowly and carefully into the floppy disk drive. If a floppy disk is inserted impetuously, pressing the eject button may fail to eject the floppy disk and could cause the machine to be damaged.
- O not try to remove the floppy disk during data reading/ writing. The data in the floppy disk could be destroyed.



Do not use unformatted floppy disks.

FDII 3-3




#### **PROGRAM INSTALLATION**

#### When installing from personal computer


# **CAUTION**

When installing the panel program, design data and machine setting will be cleared.


1. Detach the switch cover




2. Turn ON the DSW2-1, 2-2, and DSW1-1




3. Connect the machine and personal computer with serial connector



4. Turn ON the power of the personal computer



5. Turn on the power switch of the machine



6. Set the floppy disk for installation to the personal computer




Program installation includes main program, XY program, and panel program. It is possible to install these programs through a personal computer or the floppy disk drive (FDD). The program installation is required when setting up the machine or upgrading the version. Perform the program installation after turning "OFF" the power switch.

After turning ON the power switch, the screen will become as shown below.

> INSTALL \*\*\*\*\* FROM PC

GC03 3-4

- 7. Execute "Tejt\_inst.exe"
- 8. Select the file to install




- 9. Press INSTALL key
- 10. Press key to start the installation
- 11.Installing




### 12.Installation is completed



13. Turn OFF the DIP switches DSW2-1, 2-2 and DSW1-1



14. Attach the switch cover



- "Tejt\_inst.exe" is included in the floppy disk.
- Press "Open" to select the file to install.
- The program file is also included in the floppy disk.
- Panel: Program related to panel
  Main: Program related to CPU
  Xy: Program related to drive system
- Pressing the install key will display the screen for confirmation.


When the installation is completed, turn "OFF" the power switch.

- Machine setting has returned to the initial setting. Change the machine setting according to need.
- If design data has been cleared, input it again.


## Ш

#### When installing from floppy disk drive


#### 1. Detach the switch cover




#### 2. Turn ON the DIP switches DSW2-1 and DSW1-1



#### 3. Set the program disk



4. Turn ON the power switch



5. Selection of program




When inserting the program disk after turning ON the power switch, the screen will become as shown below. Press the [SET] key to continue operation from 5.

\*\*\*\*\*\* INSTALL \*\*\*\*\*

SET KEY →FILE SEARCH

Main: Program related to CPU
XY: Program related to drive system
PANEL: Program related to panel

#### 6. Select "INSTALL"




#### 7. Start installation




#### 8. Installation




#### 9. Installation is completed



#### 10. Turn OFF the DIP switches DSW2-1 and DSW1-1



#### 11.Attach the switch cover




When installing plural programs, it is possible to select plural installation items by performing operations 5 and 6.

*****	INSTALL ****
1.MAIN	$\rightarrow$ install
2.XY	<b>→</b> -
3.PANEI	. →INSTALL

When the installation is completed, turn "OFF" the power switch.

- Machine setting has returned to the initial setting. Change the machine setting according to need.
- If design data has been cleared, input it again.


#### **OPERATION FLOW UP TO START OF EMBROIDERY**



#### **EXPLANATION ON THE SCREEN**

The descriptions below are explanation for LCD screen displayed at each situation. When it is possible to change setting, the operation button on the panel is displayed.


#### Main



```
*** TEJT-C series **

FRAME → FLAT-1 3

INITIAL→ ON-2 <D>
```



```
***** EMB START ****

TAJIMA12.DST $1

0/ 1027

01/15: NO.2* →[SET]
```

```
*** EMBROIDERING ***
TAJIMA12.DST $1
66/ 900 rpm
01/15:123-456789A<D>
```

```
**** EMB PAUSE ****
TAJIMA12.DST $1

$1

$19/ 1027

01/15:123 456789A<D>
```

```
***** EMB PAUSE ****
TAJIMA12.DST $1
159/ 1027
01/15: NO.4 $-1
```

• DATA SET MENU: Press



in the state of "Embroidery start" of MAIN.

1: Data input switching (PC: Serial/FD: Floppy disk)




Serial input

# DATA INPUT

**DESIGN SELECT** 

**DESIGN DELETE** 

a: Label name



FD input



c: Design number→Design name

d: The number of stitches of FD design

e: Remaining memory capacity (stitches)

2: Memory design selection



a: Memory number/total memory capacity → Design name



b: The number of stitches of memory design

c: Remaining memory capacity (stitches)

Design information

After selecting design



Design information 1: X size, position of right and left from the absolute coordinate

Design information 2: Y-size, position of back and forth from the absolute coordinate

Design information 3: The number of color changes (total steps), end position of XY



To return to data selecting screen

3: Memory design deletion



Design selection

a: Memory number/total memory capacity → Design name



b: The number of stitches of memory design

c: Remaining memory capacity (stitches)

Confirmation of deletion



N (No)



\*\*\*\*\* DATA MENU \*\*\*\*

1. INPUT DATA → PC-1

2. SELECT DATA

3. DELETE DATA

\*\*\* INPUT THRU PC \*\*

NAME → DATA-01-2 MEMORY→ 56897 ST-15

\*\*\*\* SELECT DATA \*\*\*

G1/23 > BIRD.TBF

STITCH> 10713 ST-1

MEMORY> 180876 ST-2

\*\*\*\*\* DATA MENU \*\*\*\*

1.INPUT DATA → PC

2.SELECT DATA ←2

3.DELETE DATA

1 \* SELECT DATA \*\*
01/12 → BIRD.TBF
STITCH→ 10713 ST-5
MEMORY→ 180876 ST-6

\*\*\* INFORMATION 1 \*\*

X SIZE → 72.7 mm

+X AREA → 40.8 mm

-X AREA → 31.9 mm

\*\*\* INFORMATION 3 \*\*
COLOR → 18
X END → - 0.6 mm
Y END → + 0.1 mm

\*\*\*\*\* DATA MENU \*\*\*\*

1.INPUT DATA → PC

2.SELECT DATA

3.DELETE DATA → 3

at \* DELETE DESIGN \*\*
01/03 → TAJIMA12.TBF
STITCH→ 1027 ST - D
MEMORY→ 180876 ST - C

\*\*\* DELETE DESIGN \*\*

DELETE OK ?

[Y=SET,N=ESC]

4: Input mode of memory design



a: Mode selection (Single/Multi)



Single: It is possible to perform embroidery without storing data in memory.

Multi: Input data to memory.

5: Memory initialization







Color change setting: Press



in the state of "Embroidery start" of MAIN.

- When automatic color change is performed
- Color change function is not available for use in 1-needle machine.
- 1: Color change mode (automatic/manual)



- The lamp will turn on when manual is set.
- 2: The current step/the number of total stitches: Color change





+ ten keys (numerical keys)

Insert "-: Temporary stop" using



- a: In the state of temporary stop of needle bar
- When manual color change is performed
- 1: Color change mode (automatic/manual) AUTO MANUAL



2: The current step/the number of total steps:

The current needle bar number CHANGE







\*\*\*\*\* DATA MENU \*\*\*\* 2.SELECT DATA 3.DELETE DATA 4 MEMORY MODE -4

MEMORY MODE \*\*\* MEMORY → MULTI-a

\*\*\*\* DATA MENU \*\*\*\* 3.DELETE DATA 4.MEMORY MODE 5 INITIAL MEMORY -5

\*\* INITIAL MEMORY \*\* DELETE ALL DATA OK ? [Y=SET,N=ESC]

\*\*\* COLOR CHANGE MODE → AUTC-1 01/15:123456789ABCDE

\*\*\* COLOR CHANGE \*\*\*  $\rightarrow$  AUTO MODE STOP -a 04/15:123-456789ABCD

COLOR CHANGE → MANUAL-1 MODE 01/15:



• Data setting: Press | Problem in the state of "Embroidery start" of MAIN.

1: Rotation (90° unit)



2: Mirror image reversion (OFF/X: Reversion based on X-axis/

Y: Reversion based on Y-axis)



DATA SETTING

FRAME SETTING



Repeat setting



b: The number of times of repeat (01 to 99)



c: Space (0 to 255 mm)





• Frame setting: Press in the state of "Embroidery start" of MAIN.

1: Manual frame travel speed (1 to 3)



2: Offset setting after completion of embroidery

(automatic/manual)




3: Origin return after completion of embroidery

(automatic/manual)



4: Frame mode (Flat/Cap/Cylinder/Border)



\*\* DESIGN EDIT ROTATE 2.REVERSE

\*\* REPEAT SETTING \*\* → HORIZONTAL -a DIR TIMES → 03 -b SPACE → 120 mm-C

1.MANUAL SPD  $\rightarrow$  1-1 2 2.OFFSET 3.ORIGIN RTN → AUTO

\*\* FRAME SETTING \*A 4.FRAME MODE→ FLAT 5.INITIAL  $\rightarrow$  on



in the state of "Embroidery start" of MAIN.

1: Display (Stitch/rpm)



2: Thread breakage sensor (OFF/1 to 5)



3: Preset halt



Preset setting

a: The number of total stitches (999999 stitches: max.)



It can be cleared.

b: The number of stitches for halt (0 to 999999 stitches) Ten keys (numerical keys)

4: Thread trimming length (1 to 17)



5: Thread trimming timing (-10 to +10)



6: Jump conversion (0 to 9 stitches)



7: Auto jump (OFF/ 4.0 to 9.9 mm)



8: Frame drive timing (AUTO/250°)



9: The number of inchings at start (2 to 9 times)



A: Tie stitching (So: "To perform" when starting embroidery/S-:

"Not to perform" when starting embroidery)



B: Satin stitch (-: Without correction, 1 to 5: 0.1 mm unit)



C: Boring (OFF/1 /2)



It is not available for use in 1-needle machine.

D: Cording (ON/OFF)



It is not available for use in 1-needle machine.

E: Communication speed (9600/19200/38400)



F: Network (1/2/OFF)



\*\* MACHINE SETTING \* 1.SCREEN → ST-1 2.THREAD SNS→ 2-2 3.PRESET HLT→ [SET]

\*\*\*\* PRESET HLT \*\*\*\*

1278 ST **√**a COUNTER-> PRESET → 30000 ST-b

\*\* MACHINE SETTING \* 4.TRIM LENG  $\rightarrow$  1-4

5.TRIM TMNG  $\rightarrow$  + 0-5 6.JUMP CONV → 3 ST-6

\*\* MACHINE SETTING 7 7 AUTO JUMP → OFF 8.A/S TMNG → AUTC-8 9.INCHING → 2 → 9

\*\* MACHINE SETTING A A TIE SET → So Eo B.SATIN ADJ → OFF -B → OFF →C C.BORING

\*\* MACHINE SETTIND\* D.CORDING → 9600 **月** E.COM SPEED

→ OFF-

F.NETWORK

#### **INSPECTIONS BEFORE STARTING OPERATION**

Before embroidering, execute inspections of the following items.

### **CAUTION**



When performing inspection before starting operation, be sure to turn OFF the power switch.


If performing inspection with the power turned ON, it may cause injury.

Inspecting item	State	Corrective measures	
Covers	Come off	Attach	
Thread	Come off	Set	
Tinead	Broken		
Needle	Bent	Replace	
recuic	Broken	Керіасе	
Rail on rotary hook	Proper quantity of oil is not adhered	Supply oil	

FD11 3-14

### 4. DATA SET MENU


DATA INPUT (FLOPPY DISK)	4-2
INPUT DATA (SERIAL CONNECTION 1)	4-4
INPUT DATA (SERIAL CONNECTION 2)	4-6
DELETE DATA	4-9
MEMORY MODE	4-10
INITIAL MEMODY	<i>1</i> ₋11




# Data input (floppy disk)

Input design data from floppy disk to the machine. Data of the input design will be set.

#### 1. Insert the floppy disk.




#### 2. Switch to "DATA MENU"








#### 3. Select "FD"








### 4. Reading the floppy disk








#### 5. Selection of design data







#### 6. Input







# 7. Set needle bar steps



Data set is to make design data become possible to perform embroidery.

The black square that blinks on the screen is the item to be selected.



When the machine is reading design data in the floppy disk, the message shown below will be displayed.

FILE SEARCHING

- Regarding error code"2BA", refer to p.12-2.
- When inputting "\*.TBF" data, data set will be performed after pressing [SET].


```
***** EMB START ****
BELL.TBF $1
0/ 2451
01/04:$\frac{1}{2}6B3$ <D>
```

If no setting for "Color change" in the input design data, set needle numbers to needle bar steps. Regarding how to set needle bars, refer to p.5-3.

# **8.** Set



# 9. Completion




The input data will be set.

FD11

# **INPUT DATA (Serial connection 1)**


The descriptions below are explanation for how to download design data from an external device that is connected serially to the machine. The input design data will be set.

1. Connect an external device with the machine using the serial cable.



- When performing serial connection, turn "OFF" the power of the machine and the external device.
- When connecting the external device with the machine, use the dedicated cable (option).
- When the power of the machine is turned ON, also turn "ON" the power of the external device.

#### 2. Turn "ON" the power of the machine



3. Switch to "DATA MENU"



4. Select "PC"




5. Read data from the external device



When pressing [SET], the design data transmitting from the external device will be displayed.

- 6. Transmit design data from the external device
- **7.** Set



During data transferring, the lamp of DATA blinks.



# 8. Completion of data set

\*\*\*\*\* EMB START \*\*\*\*
DATA-01 \$1
0/ 56897
01/12:123456789AB<D>

When reading "DST", the message will be displayed as shown below after inputting design data.

\*\*\* COLOR CHANGE \*\*\*
MODE → AUTO

01/12:

When setting color change, refer to p.5-3.


FD11 4-5

# 4. DAT

# **INPUT DATA (Serial connection 2)**


The descriptions below are explanation for how to select and download the design data in an external device, which is connected serially, from the embroidery machine side. The input design data will be set.

1. Connect an external device with the machine using the serial cable.



- When performing serial connection, turn "OFF" the power of the machine and the external device.
- When connecting the external device with the machine, use the dedicated cable (option).
- When the power of the machine is turned ON, also turn "ON" the power of the external device.

#### 2. Turn "ON" the power of the machine



#### 3. Switch to "DATA MENU"



#### 4. Select "PC"



### 5. Search for data of an external device



### 6. Select design data of an external device



When pressing [SET], the design data transmitting from the external device will be displayed.


Regarding error code"2BA", refer to p.12-2.

### **7.** Set

\*\*\* SELECT DATA \*\*
3 → D-01.DST
STITCH→ 1932 ST
MEMORY→ 257536 ST



### 8. Completion of data set



During data transferring, the lamp of blinks.



When reading "DST" data, the display below will appear after input of design data.



To set color change, refer to p.5-3.

HB03


#### **SELECT DATA**

Set design data in the memory of the machine.


#### 1. Switch to "DATA MENU"




#### 2. Select "SELECT DATA"




### 3. Decision



#### 4. Selection of design data



#### 5. Data set



```
***** EMB START ****
FLOWER.TBF $1
0/ 3972
01/05:159AB <D>
```


#### **DELETE DATA**

Select design data in the memory of the machine to delete.


# 1. Switch to "DATA MENU"



#### 2. Select "DELETE DATA"



### 3. Decision




#### 4. Selection of design data



#### 5. Deletion



# 6. Confirm




```
*** DELETE DESIGN **
07/11 → DOG.DST
STITCH→ 5098 ST
MEMORY→ 184848 ST
```

- It is possible to perform deletion continuously after deleting data.
- To return the screen to the "EMB START SCREEN", press "ESC" twice.


#### **MEMORY MODE**

This setting decides whether storing the design data in the memory or not when inputting it.

#### 1. Switch to "DATA MENU"




#### 2. Select "MEMORY MODE"



#### 3. Decision




#### 4. Selection of mode



# **5.** Set





- MULTI: To store input design to the memory
  - SINGLE: To store one design data to the memory and overwrite by new design data
- When setting the memory mode, data setting will be canceled.
- When "SINGLE" is set, input data from FD/PC.
- To return the screen to "EMB START SCREEN", press "ESC" twice.


#### **INITIAL MEMORY**

This setting erases all design data stored in the memory of the machine.

# 1. Switch to "DATA MENU"




#### 2. Select "INITIAL MEMORY"




#### 3. Initialize



#### 4. Confirm



#### 5. Completion



During initializing memory, the message will be displayed as shown below.

\*\*\* INITIALIZING \*\*\*

Since all design data has been erased, input data here.

To return the screen to "EMB START"

SCREEN" without data input, press "ESC". When data setting is not performed, the screen shown below will be displayed.

```
***** EMB START *****
. $1
0/ 0
01/00: (D)
```

# 5. COLOR CHANGE

MODE SWITCHING	5-2
NEEDLE BAR SETTING (INPUT OF STEP)	5-3
NEEDLE BAR SETTING (CHANGE OF STEP)	5-4
SETTING FOR TEMPORARY STOP	5-5



# Ш

# **Mode switching**

Set color change to automatic/manual.


#### 1. Switch to "COLOR CHANGE"




### 2. Select mode





#### 3. Setting



### 4. Completion







When setting to "manual", the needle bar number currently used will be displayed as shown below.

01/15: NO.D

To change needle bar, refer to manual operation p.5-3.

**5-2** 


# **Needle bar setting (Input of step)**

Set needle bar number to needle bar step.

1. Switch to "COLOR CHANGE"



2. Input needle bar number. (Example: Needle bar number 11)




3. Input needle bar number to the next step



4. Set the needle bar setting



5. Completion



To set other needle bars continuously, repeat operations 2 and 3, then press "SET".

Needle bar	1st nee- dle	•••	10th needle	11th needle
Opera- tion			+10+O	+10+1
Display	1	•••	Α	В

- Set needle bar numbers to all steps.

  All needle bars are displayed as "1" in 1-needle machine.
- When the number of needle bar numbers to be set is fewer than the number of color change steps, the remaining steps will be automatically compensated.

#### [Example]

When the number of color change steps is 5 and up to two steps for needle bar numbers are set (Needle bar number: 2, 5)

, .	/				
Needle bar step	1	2	3	4	5
Needle bar No.	2	5	2	5	2

: Compensated needle bar No.

# Ш

# **Needle bar setting (Change of step)**

Change needle bar number of needle bar step.

#### 1. Switch to "COLOR CHANGE"



#### 2. Select the needle bar step




#### 3. Input needle bar number. (Example: Needle bar number 11)



#### 4. Setting



#### 5. Completion



To set other needle bars continuously, repeat operations 2 and 3, then press "SET".

Needle bar	1st nee- dle	•••	10th needle	11th needle
Opera- tion			+10+0	+10+1
Display	1	•••	Α	В

# **Setting for temporary stop**

This setting will cause embroidery to stop temporarily when color change is performed.

## 1. Switch to "COLOR CHANGE"



#### 2. Select the needle bar step




#### 3. Select needle bar (Example: Stop before needle bar step 4)



#### 4. Setting





- To set other needle bar steps continuously, repeat operations 2 and 3 and then press "SET".
- When setting temporary stop, "-" will be inserted just before the set step.
- When performing embroidery with automatic setting for frame setting "Offset", the machine will stop temporarily after frame movement to the offset position before its performing color change.

# 6. DESIGN EDIT

ROTATE	6-2
MIRROR	6-3
REPEAT	6-4



# Ш

#### **Rotate**

This setting rotates design of which data has been set.


#### 1. Switch to "DESIGN EDIT"




# 2. Select angle




#### 3. Set



#### 4. Completion



- For details, refer to p.10-2.
- Rotation is performed in increments of 90°



To perform design edit continuously, perform "MIRROR, REPEAT" operation without pressing "SET".


#### Mirror

This setting reverses the design of which data has been set as a mirror image.

#### 1. Switch to "DESIGN EDIT"




### 2. Select reverse




### 3. Select reversing direction




# **4.** Set




# 5. Completion



For details, refer to p.10-2.





To perform design edit continuously, perform "ROTATE, REPEAT" operation without pressing "SET".

# Ш


# Repeat

This setting arranges design of which data has been set repeatedly.


#### 1. Switch to "DESIGN EDIT"




# 2. Select repeat




#### 3. Decision



#### 4. Setting for direction



#### 5. Selection of the number of times



#### 6. Setting for the number of times



#### 7. Selection of space

```
** REPEAT SETTING **
DIR → VERTICAL
TIMES → 04
SPACE → 0 mm
```

For details, refer to p.10-3.


Direction: Horizontal/Vertical

The number of times: 01 to 99

# 8. Setting for space



#### 9. Decision




#### 10.Set



### 11.Completion

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```

- Space: 0 to 255 mm
- Space means an interval between a design and the next design.



To perform design edit continuously, perform "ROTATE, MIRROR" operation without pressing "SET".

# 7. MACHINE SETTING

THREAD BREAKAGE SENSOR	7-3
PRESET HALT (SETTING)	7-4
PRESET HALT (COUNTER)	7-5
TRIM LENGTH	7-6
TRIM TIMING	7-7
JUMP CONVERSION	7-8
AUTOMATIC JUMP	7-9
A/S TIMING	7-10
THE NUMBER OF INCHING TIMES	7-11
TIE SET (TIE STITCHING)	7-12
SATIN ADJUSTMENT	7-13
BORING	7-14
CORDING	7-15
COM SPEED	7-16
NETWORK	7-17






#### **SCREEN**


This setting displays the number of stitches/rpm [\*1] during embroidery.

#### 1. Switch to "MACHINE SETTING"






#### 2. Select display mode





#### 3. Set





#### 4. Completion

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB</b>
```

#### SCREEN:ST/rpm

The number of total stitches of design of which data has been set

6/ 1027<sup>†</sup>

The number of revolutions (rpm) during running of the machine

6/ 240 rpm


### THREAD BREAKAGE SENSOR

This is the setting for thread breakage detection.

### 1. Switch to "MACHINE SETTING"




# 2. Select thread breakage sensor



#### 3. Select setting value



#### 4. Set



```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```

- Setting value: OFF, 1, 2, 3, 4, 5
  •OFF: Not to detect thread breakage
  •1 to 5: To detect thread breakage by set number of stitches
- ☆ The smaller the value, the higher the sensibility


# PRESET HALT (SETTING)

This setting makes the machine halt automatically when the number of stitches reaches the set value.


## 1. Switch to "MACHINE SETTING"




#### 2. Select preset halt



#### 3. Decision




#### 4. Select setting




#### 5. Input setting value




#### 6. Set



### 7. Completion



- To correct the setting value, press "CLEAR" to input value again.
- When the machine is topped by preset halt, the warning buzzer will sound and the message as shown below will be displayed.



Press the stop switch to release the preset halt, and perform necessary works.


# PRESET HALT (COUNTER)

This setting clears the accumulated number of stitches [\*1] of embroideries that have been done.

#### 1. Switch to "MACHINE SETTING"




#### 2. Select preset halt




#### 3. Decision




#### 4. Clear



#### 5. Set





To clear the setting value for preset, select "PRESET" and press "CLEAR" with the same manner as the previous page.


<sup>\*1:</sup> The counter is effective when preset halt is set.

# Ш


#### **TRIM LENGTH**

Set the length of remaining thread when thread trimming is performed.

#### 1. Switch to "MACHINE SETTING"




# 2. Switching of item to be displayed



#### 3. Selection of the setting value



#### 4. Set



## 5. Completion

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```

Setting value: 1 to 17

Short

Long


#### **TRIM TIMING**

Set timing to start thread trimming.


# 1. Switch to "MACHINE SETTING"



#### 2. Switching of item to be displayed




#### 3. Select thread trimming timing



#### 4. Selection of the setting value




#### **5.** Set



#### 6. Completion

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```





Perform adjustment according to thread trimming condition and thread to use.


### **JUMP CONVERSION**

This setting converts consecutive jump stitches into frame stepping [\*1].


#### 1. Switch to "MACHINE SETTING"

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<
```

#### 2. Switching of item to be displayed




# 3. Select jump conversion



#### 4. Selection of the setting value

```
** MACHINE SETTING *
4.TRIM LENG \(\to 1\)
5.TRIM TMNG \(\to + 0\)
6 JUMP CONV \(\to 3\) ST
```

#### 5. Set




- Setting value: 0,1,2, ••• 8, 9 0: Not to convert
- When the number of times of jump codes reaches the set value, the jump codes will be converted to frame stepping.

### **AUTOMATIC JUMP**

This setting converts longer stitches than the setting value to automatic jump.


#### 1. Switch to "MACHINE SETTING"




#### 2. Switching of item to be displayed




### 3. Selection of the setting value



### 4. Set





- Setting value: OFF, 4.0, ••• 9.9 (mm)
  OFF: Not to convert
- Keeping **\( \bigsip \)** pressed changes value quickly.

# Ш


### A/S TIMING

This setting sets timing [\*1] to start the embroidery frame drive.


#### 1. Switch to "MACHINE SETTING"




#### 2. Switching of item to be displayed




#### 3. Select A/S timing




#### 4. Selection of the setting value



#### 5. Set





- Setting value: Auto, 250°
  AUTO: Automatic adjustment
  250°: Frame drive with the same timing
- When setting to 250°, good thread tightening will be obtained in general, but the machine will be burdened.

### THE NUMBER OF INCHING TIMES


Set the number of inching times after thread trimming.

#### 1. Switch to "MACHINE SETTING"




#### When starting the machine manually after stopping the machine manually, the machine will not perform inching.


#### 2. Switching of item to be displayed



#### 3. Select the number of inching times




#### 4. Selection of the setting value



# Setting value: 2, 3, ••• 8, 9

#### 5. Set



```
***** EMB START ****
TAJIMA12.DST $1
         0/ 1027
01/15:123456789AB<D>
```

# П


# TIE SET (TIE STITCHING)

This is the setting for tie stitching when starting and/or ending embroidery.


# 1. Switch to "MACHINE SETTING"




### 2. Switching of item to be displayed




#### 3. Selection of the setting value



#### 4. Set



#### 5. Completion





So: Tie stitching is applied to start of embroidery

Eo: Tie stitching is applied to end of embroidery

S-, E-: No tie stitching is applied

When tie stitching is applied, the machine will reciprocate for one stitch.


#### **SATIN ADJUSTMENT**

This setting corrects satin stitch length.


# 1. Switch to "MACHINE SETTING"




# 2. Switching of item to be displayed




#### 3. Selection of satin correction



#### 4. Selection of the setting value



#### 5. Set



```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```


- Setting value: OFF, 1, 2, 3, 4, 5 OFF: No satin adjustment 1 to 5: 0.1 to 0.5 mm
- The adjusting value will be added to both sides of a stitch.

## Ш

#### **BORING**

This is the setting for boring device.


### 1. Switch to "MACHINE SETTING"






Not available to use in 1-needle machine.

#### 2. Switching of item to be displayed




### 3. Selection of the setting value






#### 4. Selection of the setting value





#### 5. Set



#### 6. Completion

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```

- OFF: Not equipped
  - 1: Equipped, without offset
  - 2: Equipped, 12 mm offset

#### **CORDING**


This is the setting for cording.

#### 1. Switch to "MACHINE SETTING"



Not available to use in 1-needle machine.

#### 2. Switching of item to be displayed




#### 3. Selection of the setting value



OFF: Not equipped ON: Equipped

#### 4. Set



#### 5. Completion




## Ш


#### **COM SPEED**

This is the setting for transmitting speed (bps) by serial connection.


### 1. Switch to "MACHINE SETTING"




#### 2. Switching of item to be displayed




#### 3. Selection of the setting value



#### 4. Selection of the setting value



#### **5.** Set



#### 6. Completion

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```

Setting value: 9600, 19200, 38400
Set the value according to the communication speed of the transmitting device.

#### **NETWORK**

This is the setting for network connection.


#### 1. Switch to "MACHINE SETTING"



#### 2. Switching of item to be displayed




#### 3. Selection of the setting value



#### 4. Selection of connection



#### 5. Set



#### 6. Completion

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```


OFF: Not to connect

1: Data transfer from PC

2: Reading data from DG/ML

### 8. FRAME SETTING

MANUAL SPEED	8-2
OFFSET	8-3
ORIGIN RETURN	8-4
FRAME MODE	8-5
INITIAI	9.0




# Ш

#### **MANUAL SPEED**


This setting sets speed when frame travel is performed manually.

#### 1. Switch to "FRAME SETTING"





#### 2. Select setting value






#### Setting value: 1, 2, 3

1	2	3
Low speed	Middle	Highspeed
	speed	

#### 3. Set





#### 4. Completion

8-2

```
***** EMB START ****
TAJIMA12.DST $1
0/ 1027
01/15:123456789AB<D>
```

FD11


#### **OFFSET**

This setting makes the frame move to offset position automatically/manually.

#### 1. Switch to "FRAME SETTING"




#### 2. Select offset



#### 3. Select setting value



#### 4. Set



#### 5. Completion

****	EMB	STA	RT ****
TAJI	MA12.	DST	<b>\$</b> 1
	(	)/ 1	027
01/15	<b>1</b> 234	1567	89AB <d></d>

#### Setting value: AUTO/MANUAL

Setting variet. ACTO/MAINOAL			
Auto	The frame will move au-		
	tomatically to offset posi-		
	tion at temporary stop or		
	end of embroidery		
Manual	The frame will not move		
	automatically		

#### **ORIGIN RETURN**


This setting makes the frame move to the design start position manually/automatically.

#### 1. Switch to "FRAME SETTING"






#### 2. Select origin return






#### 3. Select setting value






#### 4. Set








#### 5. Completion



#### Origin return



#### Setting value: AUTO/MANUAL

Details value 110 10/1111 (C112			
Auto	The frame will move to		
	the design start position		
	when embroidery is fin-		
	ished		
Manual	It is possible to stop or		
	perform frame back at		
	end position of embroi-		
	dery		

In case of manual setting
When performing next embroidery
after finish of embroidery, perform
origin return (p.9-3) manually.


#### **FRAME MODE**

Set the embroidery frame to flat frame/cap frame/cylindrical frame.


#### 1. Switch to "FRAME SETTING"




#### 2. Switching of item to be displayed



#### 3. Select frame type




#### 4. Set



#### 5. INITIAL



#### 6. Completion



Setting value: FLAT, CAP, CYLNDR, BORDER

- When setting the frame mode, the screen will return to the initial screen. When changing frame type, the position of the origin will change. Press "SET" to perform "INITIAL" operation.
- Range in which it is possible to perform embroidery is limited by frame type.

Frame type	X-axis	Y-axis
Normal/tu-	±250 mm	±180 mm
bular goods		
frame		
Cap frame	±180 mm	+43 mm
		-35 mm
Cylindrical	±65 mm	±90 mm
frame		




#### **INITIAL**

This setting performs origin search at turning on the power to return the frame to the position where the power was shut off.


#### 1. Switch to "FRAME SETTING"



#### 2. Switching of item to be displayed



#### 3. Select initial



#### 4. Selection of the setting value



#### **5.** Set



#### 6. Completion



"Initial" operation searches the center of the embroidery frame.

Origin of frame differs depending on frame type.


Setting value: ON/OFF
ON: To search the origin when the power switch is turned "ON"
OFF: Not to search origin

- When changing "INITIAL" to set to "ON", the screen will return to the initial screen.

  Pressing "SET" will perform origin
  - search to cause the screen to become "EMB START" screen.
- "INITIAL" operation is required in the following cases:
  - 1. Frame type has been changed
  - 2. When the power was shut off in process of embroidery
  - 3. When installing each software from floppy disk
  - 4. When installing PANEL software from PC

## 9. MANUAL OPERATION

MANUAL COLOR CHANGE	9-2
MANUAL ORIGIN RETURN	9-3
TRACE	9-4
OFFSET (SETTING FOR POSITION)	9-5
OFFSET (CHANGE OF POSITION)	9-6
OFFSET (FRAME TRAVEL)	9-7
MANUAL THREAD TRIMMING	9-8
FRAME BACK/FORWARD (FEED UNIT)	9-9
FRAME BACK/FORWARD (N-STITCH FEED)	9-10
FRAME FORWARD	9-11
FRAME BACK	9-12



#### MANUAL COLOR CHANGE

Slide the needle bar case to perform color change.


# CAUTION

- When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.
- 1. Switch to manual color change





#### 2. Select needle bar







#### 3. Set



#### 4. Completion



### Manual→Return to automatic



When switching from automatic to manual, the lamp will light.



- It is not available for use in 1-needle machine.
- Pressing the "SET" key will cause the needle bar case to slide.

When switching from manual to automatic, the lamp will be unlit.



#### **MANUAL ORIGIN RETURN**

Return the embroidery frame to design start position.




When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.

#### 1. Select origin return



#### 2. Confirm



#### 3. Completion



- When performing origin return in process of embroidery, it will become impossible to continue embroidery.
- When pressing "SET", the frame will move to the position of the origin.



#### **TRACE**

Move the embroidery frame along with embroidery space (the maximum size of X and Y directions) of design data.

## CAUTION



When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.

#### 1. Select trace







#### In process of tracing

**	****	TRACE	*****
1	CAJIMA1	L2.DST	<b>\$</b> 1
Х	$size \rightarrow$	54.0	mm
Y	$size \rightarrow$	10.7	mm
l			



- For details of trace, refer to p.10-7.
- It is not possible to perform tracing in process of embroidery.
- Pressing the trace key will cause trace start position to become design start position.
- Embroidery size of design will be displayed during tracing.

GC03 9-4

### **OFFSET (SETTING FOR POSITION)**

Set offset position.


# **A** CAUTION

When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.


#### 1. Select offset




#### 2. Setting for offset position




#### 3. Set



#### 4. Completion



### **U**Return to the original position




- When changing frame type, the offset position will return to (0, 0).
- Use the frame travel key to set the offset position. Frame travel position is displayed with coordinate values.
- When pressing "SET", the set position will be registered to the machine, and this position will be applied to all design data.
- When setting offset of frame setting to auto, the frame will move to the offset position when the machine stops temporarily or after completion of embroidery. At this moment, the screen shown left will be displayed. The screen shows that the machine stops at the offset position.
- When pressing the offset key, the frame will return to the previous position before frame travel.

### **OFFSET (CHANGE OF POSITION)**

Change offset position.


# **A** CAUTION




#### 1. Select offset




#### 2. Change offset position




#### 3. Set



#### 4. Completion



### Return to the original position



- When changing frame type, the offset position will return to (0, 0).
- Move the frame to the registered offset position. Set a new position using the frame travel key.
- When pressing "SET", the moved position will be registered to the machine.

When pressing the offset key, the frame will return to the previous position before frame travel.


### **OFFSET (FRAME TRAVEL)**

This operation moves the frame to offset position/the current position.


## **A** CAUTION

When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.

#### 1. Move to the offset position



### Return to the original position



When pressing the offset key, the frame will move to the registered offset position.

When pressing the offset key, the frame will return to the previous position before frame travel. Pressing the start switch will make the frame return to the original position and will start embroidery.




#### MANUAL THREAD TRIMMING


Perform thread trimming.



- When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.
- 1. Select ATH (thread trimming)



#### 2. Confirm




When selecting ATH, the main shaft will rotate. When tie stitching (p.7-12) is set, the machine will embroider for one stitch to perform thread trimming.

#### FRAME BACK/FORWARD (FEED UNIT)

This operation performs frame back/forward by set feed unit.




- When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.
- 1. Select mode (color change unit)





2. Frame forward by color change unit







3. Completion

\*\*\*\*\* EMB PAUSE \*\*\*\*
TAJIMA12.DST \$1
100/ 1027
01/15:123456789AB<D>


- Setting value:1, 10, 100, C, n-stitch
  1: 1 stitch unit
  10: 10 stitch unit
  100: 100 stitch unit
  C: Color change unit
  n: Stitch position input by numerical key
- When keeping on pressing "FOR-WARD/BACK" for one or more seconds, frame traveling will be performed to color change even if the key is released.
- When pressing "FORWARD", frame travel will be performed to the stitch position of color change. Every pressing the key will perform frame forward to the next color change position.

### FRAME BACK/FORWARD (N-STITCH FEED)

This operation performs frame back/forward to input stitch position.




- When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.
- 1. Select mode (n stitch)







#### 2. Input the number of stitches







#### 3. Move the frame to stitch position







#### 4. Completion

\*\*\*\*\* EMB PAUSE \*\*\*\*
TAJIMA12.DST \$n ST
3856/ 19428
01/15:123456789AB<0>

- Setting value:1, 10, 100, C, n-stitch
  1: 1 stitch unit
  10: 10 stitch unit
  100: 100 stitch unit
  C: Color change unit
  n: Stitch position input by numerical
- When the input number of stitches is larger than the current number of stitches, frame forward will be performed. When it is smaller than the current number of stitches, frame back will be performed.
- When pressing "SET", frame forward (frame travel) will be performed to the input stitch position.

#### FRAME FORWARD

Perform frame forward.



- When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.
- 1. Select forward



2. Keep on pressing the forward key



3. Stop at color change position

```
**** EMB PAUSE ****
TAJIMA12.DST $1
655/ 1027
01/15:123456789AB<D>
```

- When 1 stitch unit is set, pressing "FORWARD" once will perform frame forward for one stitch.
- When keeping on pressing "FOR-WARD" for one or more seconds, frame travel will be performed to color change even if the key is released.

  To stop the machine, press the stop

To stop the machine, press the sto switch.



#### **FRAME BACK**

Perform frame back.

# **A** CAUTION


- When performing this operation, do not put your hands under the needle or on the machine table. If your hands are under the needle or on the machine table, you may be injured by the needle or the moving frame.
- 1. Select back



2. Keep on pressing the back key




3. Stop at color change position



- When 1 stitch unit is set, pressing "BACK" once will perform frame forward for one stitch.
- When keeping on pressing "BACK" for one or more seconds, frame travel will be performed to color change even if MANUAL key is released. To stop the machine, press the stop switch.
- Frame back will be performed to color change position.

## **10. OUTLINE OF FUNCTIONS**

ROTATE	10-2
MIRROR	10-2
REPEAT	10-3
OFFSET	10-4
SATIN ADJUSTMENT	10-6
TRACE	10-7



## П


#### **ROTATE**


This function rotates design of which data has been set.

The design is rotated centering the design start position.

Rotation unit: 90°

<Example: 90° rotation>






#### **MIRROR**

This function reverses design of which data has been set.


The design is reversed on X/Y-axis based on the design start position as the base line.


Reversing axis: X (Symmetric with respect to the X-axis)/Y (Symmetric with respect to the Y-axis)

<Example: Y-axis reversion>;



<Example:90°-rotation and X-axis reversion>






When both rotation and REVERSE are set, the order of priority becomes rotation → reverse (reversion).


#### **REPEAT**

This function performs embroidery repeatedly using design of which data has been set. Set embroidery direction, the number of times of repeat, and design interval.

It is possible to rotate and/or reverse (mirror) the design repeatedly arranged.
 The order of priority: Repeat → rotation → reverse


<Example: Direction  $\rightarrow$  X-axis, The number of repeats  $\rightarrow$  4, Interval  $\rightarrow$  55 mm>






When performing "Trace" after setting "Repeat", it will be possible to confirm the whole embroidery space. Adjust start position, the number of repeats, interval, etc. so that the embroidery space does not exceed the frame.


<Example: Direction  $\rightarrow$  X-axis, The number of repeats  $\rightarrow$  3, Interval  $\rightarrow$  60 mm, Rotation  $\rightarrow$  90°, Reverse  $\rightarrow$  Y>



Direction: X-axis (Even if setting is made to X-axis, embroidery is performed along Y-axis because the design is rotated by 90°.)



If reverse is applied on X-axis in the repeat setting above, the order of embroidery will become in reverse.



FDII 10-3



#### **OFFSET**

This function makes the frame move to the position set by offset, and return the frame to the original position after working.


Offset includes manual/automatic setting (frame setting).

#### 1. Manual offset

Pressing "OFFSET" at machine stop will cause the frame to move to the offset position. Pressing the "OFFSET" once more will cause the frame to return to the original position.


<Example: Placing applique>

(1) Stop the machine




(2) Move the frame to the offset position






(4) Press the offset button to return the frame to the original position (When pressing the start button, the frame will return to the original position to restart the embroidery).



When placing applique, etc., it is convenient if temporary stop (p.5-5) is set at color change.




#### 2. Automatic offset


This setting makes the frame move to the offset position automatically when embroidery is finished if offset position is set and offset of frame setting is set to auto.

<Example: Exchange of frame>


(1) Embroidery is finished




(2) Move the frame to the offset position




(3) Change the frame



(4) New frame (Re-stretching of cloth)



- (5) When pressing the start button, the frame will move to the design start position and embroidery will start.
- When embroidering the same design, to perform embroidery from the same start position, set frame setting "START POINT (Origin Return)" (p.8-4) to auto.




FDII 10-5



#### **SATIN ADJUSTMENT**

This function expands satin stitch length.



To expand satin stitch length, set satin adjustment of machine setting.

Setting value: OFF,  $1\sim5$ 

Although 1.5 mm and longer stitches are adjusted by setting value of satin adjust, regarding less than 1.5 mm long stitches the adjusting value will become small.


When switching the DIP switch (2DSWS: p.2-6) on the operation panel, it is possible to apply satin adjust to 0.6 mm and longer stitches.

#### **TRACE**


This function makes the frame move along the square embroidery space of design of which data has been set.

When tracing the set design, the frame will move from the design start position to four corners (right, rear, left, and front) of the embroidery space and then return to the design start position.


When repeat is set, the machine will trace the whole embroidery space.



If mirror: Y is set to the repeat shown above, the machine will perform trace as shown below.




Pressing the trace key will cause trace start position to become design start position.



GC03 10-7

### 11. ELECTRO-COMPONENT PARTS

POWER SUPPLY BOX	11-2
POWER CARD	11-2
CONSOLE 1 CARD	11-3
COMPUTER CARD	11-3
CONSOLE 2 CARD	11-4






### **CAUTION**



O not block wind flow of the cooling fan. Inside of the box will overheat to lead to breakdown.


#### **POWER SUPPLY BOX**


- 1:Cooling fan
- 2: DC power supply
- 3:Glass tube fuse (250V / 6.3A) For power supply
- 4: Glass tube fuse (250V / 8A) For power supply



#### **POWER CARD**

5: Glass tube fuse (125V / 20A) For DC power supply 24 V







GC12 11-2

#### **CONSOLE 1 CARD**


#### 6: DIP switch






#### **COMPUTER CARD**

- 7: DIP switch
- 8: DIP switch







#### **CONSOLE 2 CARD**


9: DIP switch

10: DIP switch

11: DIP switch


12: DIP switch

The console 2 card is located in the operation panel.



## 12. TROUBLESHOOTING AND MAINTENANCE

WHEN THE MACHINE IS STOPPED DURING OPERAT	TION 12-2
WHEN TROUBLE OCCURS	12-4
DAILY MAINTENANCE	12-5





### WHEN THE MACHINE IS STOPPED DURING OPERATION

There are two main machine stop factors: one is stop by occurrence of error and another is stop by normal stop factor. When the machine operation is interrupted with code number displayed on the screen, carry out the troubleshooting referring to the code chart below.

# \*\*\*\*EMB PAUSE\*\*\*\* THREAD BREAK (291)

Example of stop by occurrence of error

### 1. Stop by occurrence of error

- When releasing the error display
  - (1) Confirm the contents of error.
  - (2) Take proper action. If a code number of 300 series is displayed, contact the distributor.
  - (3) Press the stop button to release the error.

Code num- ber	Stop Factor	Corrective Action			
211	The main shaft has stopped deviating from the fixed position	Adjust the stop position of the main shaft (p.12-3) so that it is located at the fixed position.			
225	Stitching outside the embroidery space.	Move the frame manually so that the design fits in the embro dery area.			
281	The target needle position is not detected even after 15 seconds after start of color change.	<ul> <li>Adjust needle position (p.12-3).</li> <li>Check or replace the potentiometer (needle position sensor</li> <li>Correct mis-input of needle position.</li> </ul>			
291	The machine detected thread breakage.	Check upper thread/under thread.			
2BA	Input of design data exceeding memory capacity.	<ul> <li>Press the ESC key to stop data input.  Imput the design data again after deleting unnecessary design data.</li> <li>Press the SET key to perform data set without data input to make embroidery possible.  Imput the power is shut off on the way of embroidery, data will be lost.</li> </ul>			
2CF	Stop by emergency stop switch	Release the lock of the emergency stop switch.			
2FC	Abnormal temperature in the machine	Check if the room temperature is too high. Check the cooling fan.			
316	A main shaft motor error signal is detected.	Replace the power card, main shaft motor.			
322	An X-axis motor error signal is detected.	Replace the power card, X-axis motor.			
323	A Y-axis motor error signal is detected.	Replace the power card, Y-axis motor.			
3A6	Incorrect ATH movable knife retractable position	Check the position of ATH movable knife.			
3B5	Communication error in the controller	Turn on the power again.			
3B6	Communication error with the external device	Check the connecting cable, external device.			
3D5	RAM memory error	<ul><li>Install the operation program again.</li><li>Replace the Console 1 card.</li></ul>			
B01	Floppy disk format has an error.	<ul><li>Format the floppy disk.</li><li>Replace with a new formatted floppy disk.</li></ul>			
B04	No floppy disk has been inserted.	Insert a floppy disk.			
BC1	No design is registered on the floppy disk.	Insert the floppy disk in which design data is registered.			
	Disk driver has abnormality.	Replace the disk driver.			
BC3	Sector of floppy disk has broken.	Format floppy disk.			
	It is not possible to read floppy disk.	Replace with a new formatted floppy disk.			
C01	The FDD does not work.	Check if the floppy disk is inserted to the fixed position. Check the FDD connector. If there is no problem with the connection, replace the FDD unit.			

**12-2** 

#### 2. Maintenance stop

Maintenance stop is stop for maintenance. It is not caused by occurrence of error.

The message is displayed when embroidery starts (pressing the start button).

When the message shown right is displayed on the screen, supply oil to the specified spots (p.12-7). After the lubrication, press the stop button to release the maintenance mode to continue working.

\*\*MAINT.REQUIRD\*\*
One drop of oil

As per Inst. Manual


\*\*CAUTION:Grease Cams Take-up, Presser

| CAUTION:Grease Cams Take-up, Presser
| As per Inst. Manual

#### 3. Adjustment of needle position

When the change cam deviates from the fixed position, the machine will not work. Adjust needle position with the following operations.

(1) Rotate the handle of color change system so that the fixing screw comes to the top.




When the fixing screw of the handle is positioned at the top, odd-numbered needle bars are selected.

#### 4. Adjustment of stop position of main shaft



When the main shaft stops deviating from the fixed position, black squares as shown in the left illustration will blink. Perform manual color change (p.9-2) to rotate the main shaft to return stop position to the fixed position. After stop position returns to the fixed position, perform manual color change once again to return to the original needle bar.

When rotating the main shaft handle to the position where black squares disappear, the position is the stop position of the main shaft. Rotate the main shaft handle while pushing it.



GC12 12-3



### WHEN TROUBLE OCCURS

## **A** CAUTION

Adjustment includes some complicated works. Consult your local distributor before working.

Examples for causes and adjustments when trouble(s) occur are described below.

	Cause	Adjust		
	Loose or broken belts	Adjust the belt tension or replace the belt.		
Machine cannot start	Needle position signal, NOT detected.	Adjust needle position (p.12-3) so that normal needle position signal is displayed at the column of needle position display of the operation panel.		
	Poor connection of connector	Securely connect the connectors.		
Ston mosition	Loose or soiled belt	Adjust the belt tension or clean the belt.		
Stop position error	Galling of driving parts	Adjust or replace the needle bar drive system and/or rotary hook.		
	Stop position is incorrect.	Adjust the position.		
Incorrect color	Position of take-up lever is wrong.	Adjust the position of the take-up lever at the stop position so that its position is the same as others.		
changing	Needle position NOT detected.	Adjust needle position so that normal needle position signal is displayed at the column of needle position display of the operation panel (p.12-3).		
Jump error	Incorrect positioning of parts related to needle bar drive system	Adjust the attaching position of the needle bar reciprocator set with the upper dead point stopper.		
	Incorrect positioning of frame drive belt	Adjust the belt tension.		
	Malfunctioning of frame drive system	Replace/adjust the parts.		
Design displaced	Overall frame weight is excessive.	Lower the r.p.m. of the main shaft.		
	Drive unit (V. V. avec.) defeative	Replace the drive unit.		
	Drive unit (X, Y-axes) defective	Replace the X-axis/Y-axis drivers.		
	Wrong needle-rotary hook timing or improper gap	Adjust the timing or gap.		
	Wrong needle bar lower dead point	Readjust the lower dead point.		
Thread breakage	Scratches on thread passing area	Remove the scratches.		
	Incorrect upper/lower thread tension	Adjust the tension.		
	Repeated stitching at the same point	Correct the data.		
	Incorrect take-up lever timing	Readjust the take-up lever driving cam timing.		
ATH	Thread is not trimmed.	Adjust the ATH knife position.		
	•			

GC03 12-4

#### **DAILY MAINTENANCE**

#### 1. WARNINGS AND CAUTIONS

### **WARNING**

To prevent accidents resulting in injury or death and physical damage, the following must be observed when performing daily maintenance (cleaning, lubrication, greasing, and/or inspection).

The maintenance operations must be performed by properly trained personnel.

When restarting the machine after maintenance operation, attach all covers etc. which were removed for maintenance operation.

### **A** CAUTION

- Perform daily maintenance in the specified schedule.

  If the daily maintenance is not observed, the machine may fail to operate correctly. Since the loss incurred by ignoring the daily maintenance instructions can be judged "not covered by guarantee".
- If the machine is not used for a long period, turn the power switch ON in regular intervals. Although each card of the machine has a backup battery, data may be lost for about one month because voltage of the battery will come down gradually due to discharge when the power switch is turned off.
- Assure enough illumination.


  Assure 300 lux or more for working areas including underneath part of the machine table when changing under threads or performing daily maintenance.

HB10 12-5



### 2. Cleaning

### **WARNING**




The maintenance operations must be performed by properly trained personnel.

When restarting the machine after maintenance operation, attach all covers etc. which were removed for maintenance operation.

Cleaning area	Cleaning cycle		
(1)Case linear section	Once/week		
(2) ATH section	Everyday		
(3) X/Y-axis drive system	Once/2 weeks		

1-needle machine does not have case linear.



**12-6** 

#### 3. Lubrication

### **WARNING**


During machine lubrication, turn OFF the power switch. You could sustain severe injuries due to being entangled by moving machine units.

### **A** CAUTION


- Neep the lubrication cycles as shown below. Deviated lubrication cycles may cause thread breakage.
- When supplying lubricating oil, use only Tajima's genuine SF oil or equivalent (#150 spindle oil: ISO viscosity grade = VG18).


Lubrication Points	Lubrication Cycle		
(1) Rail on rotary hook	Every 3 to 4 hours of operation		
(2) Drive shaft of presser foot reciprocator (3) Needle bar drive shaft	Once/day		
<ul><li>(4) Presser foot drive shaft</li><li>(5) Inside the arm</li><li>(6) Needle bar</li><li>(7) Felt packing (needle bar)</li></ul>	Once/week		
(8) Inside the cylinder bed	Once/3 months		

When supplying oil to 1-needle machine, remove the top cover of the needle bar case.



As the guidance persuading the operator to perform lubrication to the rail section of rotary hook, the machine has a function to display maintenance information (p.12-3) on the operation panel. When the maintenance information is displayed, turn OFF the power switch and supply oil to the rail section of rotary hook. For other lubrication cycles, refer to the chart shown above.





When lubricating the lubrication hole (red mark) of the rotary hook, attach the accessory lubricating nozzle to the tip of the oiler. Cut the tip of the nozzle according to necessary length.





### 4. Greasing

### **WARNING**

During machine greasing, turn OFF the power switch. You could sustain severe injuries due to being entangled by moving machine units.

### **A** CAUTION


Please contact the distributor for further information about greasing.


When greasing, use only high quality mineral oil based lithium grease or equivalent.

Greasing Points	Greasing Cycle		
<ul><li>(1) Presser foot cam</li><li>(2) Take-up lever drive cam</li><li>(3) Roller of take-up lever</li></ul>	Once/3 months		
(4) X/Y-axis drive system	Once/6 months		

As the guidance persuading the operator to perform greasing, the machine has a function to display maintenance information (p.12-3) on the operation panel.

When the maintenance information is displayed, turn OFF the power switch and perform greasing to the specified spots. For other greasings, refer to the chart shown above.





**12-8** 

#### 5. Inspections

### WARNING

During machine inspection, turn OFF the primary power supply. (Before disconnecting the primary power supply, turn OFF the power switch.) You could sustain severe injuries due to being entangled by moving machine units.

Inspection Point	Contents	Cycle
(1) Each belt of main shaft drive system	Tension and wear of belt, Existence of crack	
(2) Each belt of X/Y-axis drive system	Tension and wear of belt, Existence of crack	Once/3 months
(3) Rotating and sliding sections	Degree of wear	

#### 6. Repair

### **WARNING**

To prevent accidents resulting in injury or death and physical damage, the following must be observed when performing the repairs of the machine.


- Before starting repair of the machine, be sure to disconnect the primary power supply to the machine and wait for 4 minutes. (Before disconnecting the primary power supply, turn OFF the power switch.) It takes 4 minutes until the machine becomes completely discharged.
- If the machine needs repairs, the repairs must be done only by the service personnel assigned and trained by Tajima or qualified technician. (Consult the distributor.) Do not change the specification nor modify the parts of the machine. Such modification could risk the operational safety.
- When restarting the machine after repairs, attach all covers, etc., which were removed for the repair operation.


# CAUTION

For the machine repairs, use TAJIMA genuine parts for replacement.


FD11 12-9


### **ELECTRO-RELATIVE DRAWING**







### 1. Layout of electrical parts






### 2. Layout of electrical parts (1-needle machine)





### 3. Electric system diagram

1-needle machine uses thread sweep solenoid instead of thread holding solenoid and it does not have color change motor and potentiometer.



1st Edition July, 2002
2nd Edition November, 2002
3rd Edition March, 2003
4th Edition June, 2003
5th Edition December, 2003
6th Edition October, 2004
7th Edition September, 2005

### ■ Manufactured by:

Tokai Industrial Sewing Machine Co., Ltd.

NO.1800, Ushiyama-cho, Kasugai, Aichi-pre., 486-0901, Japan Telephone:568-33-1161 Fax:568-33-1191

### ■ Distributed by:

Tajima Industries Ltd.

19-22, Shirakabe, 3-chome, Higashi-ku, Nagoya, 461-0011, Japan Telephone:52-932-3444 Fax:52-932-2457

Authorized Distributor:						

• Copy, reprint and reform of a part or whole of this manual without our permission is prohibited.