

# IPS110

*Version 1.0*

**Intelligent Stepper  
Minidrive for Step and  
Brushed DC Motors**



T E C H N O S O F T

**Intelligent Stepper Minidrive**

**Technical  
Reference**



TECHNOSOFT

**IPS110 v1.0**  
**Technical Reference**

P091.045.IPS110.UM.0808

**Technosoft S.A.**

Buchaux 38

CH-2022 Bevaix, NE

Switzerland

Tel.: +41 (0) 32 732 5500

Fax: +41 (0) 32 732 5504

[contact@technosoftmotion.com](mailto:contact@technosoftmotion.com)

[www.technosoftmotion.com](http://www.technosoftmotion.com)



---

## Read This First

Whilst Technosoft believes that the information and guidance given in this manual is correct, all parties must rely upon their own skill and judgment when making use of it. Technosoft does not assume any liability to anyone for any loss or damage caused by any error or omission in the work, whether such error or omission is the result of negligence or any other cause. Any and all such liability is disclaimed.

All rights reserved. No part or parts of this document may be reproduced or transmitted in any form or by any means, electrical or mechanical including photocopying, recording or by any information-retrieval system without permission in writing from Technosoft S.A.

The information in this document is subject to change without notice.

### ***About This Manual***

This book is a technical reference manual for the **IPS110** family of intelligent servo drives **version 1.0**, including the following products:

<b>IPS110, RS232</b> (p/n P045.001.E001) - Minidrive for Step and Brushed DC motors.
<b>IPS110, CAN</b> (p/n P045.001.E002) - Minidrive for Step and Brushed DC motors. Standard execution using Technosoft TMLCAN protocol on CANbus
<b>IPS110, CANopen</b> (p/n P045.001.E012) - Minidrive for Step and Brushed DC motors using CANopen protocol on CANbus

In order to operate the IPS110 drives, you need to pass through 3 steps:

- ❑ **Step 1 Hardware installation**
- ❑ **Step 2 Drive setup** using Technosoft **EasySetUp** software for drive commissioning
- ❑ **Step 3 Motion programming** using one of the options:
  - ❑ A **CANopen master**
  - ❑ The drive **built-in motion controller** executing a Technosoft Motion Language (**TML**) program developed using Technosoft **EasyMotion Studio** software
  - ❑ A **TML\_LIB motion library for PCs** (Windows or Linux)
  - ❑ A **TML\_LIB motion library for PLCs**
  - ❑ A **distributed control** approach which combines the above options, like for example a host calling motion functions programmed on the drives in TML



---

This manual covers **Step 1** in detail. It describes the IPS110 hardware including the technical data, the connectors and the wiring diagrams needed for installation. The manual also presents an overview of the following steps, and includes the scaling factors between the real SI units and the drive internal units. For detailed information regarding the next steps, refer to the related documentation.

### **Notational Conventions**

This document uses the following conventions:

**TML** – Technosoft Motion Language

**SI units** – International standard units (meter for length, seconds for time, etc.)

**IU units** – Internal units of the drive

**IPS110** – all products described in this manual

**IPS110 CANopen** – the CANopen execution from IDM family

**IPS110 CAN** – IPS110, CAN standard executions

### **Related Documentation**

**Help of the EasySetUp software** – describes how to use **EasySetUp** to quickly setup any Technosoft drive for your application using only 2 dialogues. The output of EasySetUp is a set of setup data that can be downloaded into the drive EEPROM or saved on a PC file. At power-on, the drive is initialized with the setup data read from its EEPROM. With EasySetUp it is also possible to retrieve the complete setup information from a drive previously programmed. EasySetUp includes a firmware programmer with allows you to update your drive firmware to the latest revision. **EasySetUp can be downloaded free of charge from Technosoft web page**

**CANopen Programming (part no. P091.063.UM.xxxx)** – explains how to program the Technosoft intelligent drives using **CANopen** protocol and describes the associated object dictionary for the **DS-301** communication profile and the **DSP-402** device profile

**Help of the EasyMotion Studio software** – describes how to use the EasyMotion Studio to create motion programs using in Technosoft Motion Language (TML). EasyMotion Studio platform includes **EasySetUp** for the drive/motor setup, and a **Motion Wizard** for the motion programming. The Motion Wizard provides a simple, graphical way of creating motion programs and automatically generates all the TML instructions. *With EasyMotion Studio you can fully benefit from a key advantage of Technosoft drives – their capability to execute complex motions without requiring an external motion controller, thanks to their built-in motion controller.* **A demo version of EasyMotion Studio (with EasySetUp part fully functional) can be downloaded free of charge from Technosoft web page**

**TML\_LIB v2.0 (part no. P091.040.v20.UM.xxxx)** – explains how to program in **C, C++,C#, Visual Basic or Delphi Pascal** a motion application for the Technosoft intelligent drives using TML\_LIB v2.0 motion control library for PCs. The TML\_lib includes ready-to-run examples that can be executed on **Windows** or **Linux** (x86 and x64).

---

**TML\_LIB\_LabVIEW v2.0 (part no. P091.040.LABVIEW.v20.UM.xxxx)** – explains how to program in **LabVIEW** a motion application for the Technosoft intelligent drives using TML\_LIB\_Labview v2.0 motion control library for PCs. The TML\_Lib\_LabVIEW includes over 40 ready-to-run examples.

**TML\_LIB\_S7 (part no. P091.040.S7.UM.xxxx)** – explains how to program in a PLC **Siemens series S7-300 or S7-400** a motion application for the Technosoft intelligent drives using TML\_LIB\_S7 motion control library. The TML\_LIB\_S7 library is **IEC61131-3 compatible**.

**TML\_LIB\_CJ1 (part no. P091.040.CJ1.UM.xxxx)** – explains how to program a PLC **Omron series CJ1** a motion application for the Technosoft intelligent drives using TML\_LIB\_CJ1 motion control library for PCs. The TML\_LIB\_CJ1 library is **IEC61131-3 compatible**.

**TechnoCAN (part no. P091.063.TechnoCAN.UM.xxxx)** – presents TechnoCAN protocol – an extension of the CANopen communication profile used for TML commands

### ***If you Need Assistance ...***

<b>If you want to ...</b>	<b>Contact Technosoft at ...</b>
Visit Technosoft online	World Wide Web: <a href="http://www.technosoftmotion.com/">http://www.technosoftmotion.com/</a>
Receive general information or assistance (see Note)	World Wide Web: <a href="http://www.technosoftmotion.com/">http://www.technosoftmotion.com/</a> Email: <a href="mailto:contact@technosoftmotion.com">contact@technosoftmotion.com</a>
Ask questions about product operation or report suspected problems (see Note)	Fax: (41) 32 732 55 04 Email: <a href="mailto:hotline@technosoftmotion.com">hotline@technosoftmotion.com</a>
Make suggestions about, or report errors in documentation (see Note)	Mail: Technosoft SA Buchaux 38 CH-2022 Bevaix, NE Switzerland



---

## Contents

<b>Read This First .....</b>	<b>I</b>
<b>1. Safety information.....</b>	<b>1</b>
1.1. Warnings .....	1
1.2. Cautions .....	2
<b>2. Product Overview.....</b>	<b>3</b>
2.1. Introduction.....	3
2.2. Key Features .....	4
2.3. Supported Motor-Sensor Configurations .....	5
2.4. IPS110 Dimensions .....	7
2.5. Electrical Specifications.....	8
<b>3. Step 1. Hardware Installation .....</b>	<b>13</b>
3.1. Mounting.....	13
3.2. Connectors and Connection Diagrams.....	13
3.2.1. Connectors Layout.....	13
3.2.2. Identification Labels .....	15
3.2.3. J1 Connector pinout.....	16
3.2.4. J2 Connector pinout.....	17
3.2.5. Supply connection.....	18
3.2.6. Motor connections.....	20
3.2.7. Feedback connections .....	22
3.2.8. Digital I/O connections .....	24
3.2.9. Analog Inputs connection.....	27
3.2.10. Serial RS-232 Communication connections .....	28
3.2.11. CAN Communication connection.....	29
3.2.12. Connectors Type and Mating Connectors .....	31
3.3. Jumper and solder joints configuration .....	32
3.4. First Power-Up .....	36
<b>4. Step 2. Drive Setup.....</b>	<b>37</b>

---

4.1.	Installing EasySetUp .....	37
4.2.	Getting Started with EasySetUp .....	37
4.2.1.	Establish communication .....	38
4.2.2.	Setup drive/motor.....	39
4.2.3.	Download setup data to drive/motor .....	41
4.2.4.	Evaluate drive/motor behaviour (optional) .....	41
4.3.	Changing the drive Axis ID .....	41
4.4.	Setting CANbus rate.....	42
4.5.	Creating an Image File with the Setup Data .....	43
<b>5.</b>	<b>Step 3. Motion Programming .....</b>	<b>44</b>
5.1.	Using a CANopen Master (for IPS110 CANopen execution).....	44
5.1.1.	DS-301 Communication Profile Overview.....	44
5.1.2.	TechnoCAN Extension (for IPS110 CAN executions).....	45
5.1.3.	DSP-402 and Manufacturer Specific Device Profile Overview.....	45
5.1.4.	Checking Setup Data Consistency .....	46
5.2.	Using the built-in Motion Controller and TML .....	46
5.2.1.	Technosoft Motion Language Overview .....	46
5.2.2.	Installing EasyMotion Studio.....	47
5.2.3.	Getting Started with EasyMotion Studio .....	47
5.2.4.	Creating an Image File with the Setup Data and the TML Program .....	53
5.3.	Combining CANopen /or other host with TML .....	54
5.3.1.	Using TML Functions to Split Motion between Master and Drives.....	54
5.3.2.	Executing TML programs.....	54
5.3.3.	Loading Automatically Cam Tables Defined in EasyMotion Studio .....	54
5.3.4.	Customizing the Homing Procedures (for IPS110 CAN executions) .....	55
5.3.5.	Customizing the Drive Reaction to Fault Conditions (for IPS110 CAN executions).....	55
5.4.	Using Motion Libraries for PC-based Systems.....	56
5.5.	Using Motion Libraries for PLC-based Systems.....	56
<b>6.</b>	<b>Scaling Factors .....</b>	<b>57</b>
6.1.	Position units .....	57
6.1.1.	DC brushed motor with quadrature encoder on motor.....	57
6.1.2.	Stepper motor open-loop control. No feedback device .....	57

---

6.1.3.	Stepper motor closed-loop control. Incremental encoder on motor .....	58
6.1.4.	Stepper motor open-loop control. Incremental encoder on load .....	58
6.2.	Speed units .....	58
6.2.1.	DC brushed motor with quadrature encoder on motor .....	58
6.2.2.	Stepper motor open-loop control. No feedback device .....	59
6.2.3.	Stepper motor open-loop control. Incremental encoder on load .....	59
6.2.4.	Stepper motor closed-loop control. Incremental encoder on motor .....	59
6.3.	Acceleration units .....	60
6.3.1.	DC brushed motor with quadrature encoder on motor .....	60
6.3.2.	Stepper motor open-loop control. No feedback device .....	60
6.3.3.	Stepper motor open-loop control. Incremental encoder on load .....	61
6.3.4.	Stepper motor closed-loop control. Incremental encoder on motor .....	61
6.4.	Jerk units .....	62
6.4.1.	DC brushed motor with quadrature encoder on motor .....	62
6.4.2.	Stepper motor open-loop control. No feedback device .....	62
6.4.3.	Stepper motor open-loop control. Incremental encoder on load .....	63
6.4.4.	Stepper motor closed-loop control. Incremental encoder on motor .....	63
6.5.	Current units .....	63
6.6.	Voltage command units .....	63
6.7.	Voltage measurement units .....	64
6.8.	Time units .....	64
6.9.	Master position units .....	64
6.10.	Master speed units .....	65
6.11.	Motor position units .....	65
6.11.1.	DC brushed motor with quadrature encoder on motor .....	65
6.11.2.	Stepper motor open-loop control. No feedback device .....	65
6.11.3.	Stepper motor open-loop control. Incremental encoder on load .....	66
6.11.4.	Stepper motor closed-loop control. Incremental encoder on motor .....	66
6.12.	Motor speed units .....	66
6.12.1.	DC brushed motor with quadrature encoder on motor .....	66
6.12.2.	Stepper motor open-loop control. No feedback device or incremental encoder on load .....	67
6.12.3.	Stepper motor closed-loop control. Incremental encoder on motor .....	67
<b>7.</b>	<b>Memory Map .....</b>	<b>68</b>

---



---

## 1. Safety information

Read carefully the information presented in this chapter before carrying out the drive installation and setup! It is imperative to implement the safety instructions listed hereunder.

This information is intended to protect you, the drive and the accompanying equipment during the product operation. Incorrect handling of the drive can lead to personal injury or material damage.

Only qualified personnel may install, setup, operate and maintain the drive. A “qualified person” has the knowledge and authorization to perform tasks such as transporting, assembling, installing, commissioning and operating drives.

The following safety symbols are used in this manual:



**WARNING!**

***SIGNALS A DANGER TO THE OPERATOR WHICH MIGHT CAUSE BODILY INJURY. MAY INCLUDE INSTRUCTIONS TO PREVENT THIS SITUATION***



**CAUTION!**

***SIGNALS A DANGER FOR THE DRIVE WHICH MIGHT DAMAGE THE PRODUCT OR OTHER EQUIPMENT. MAY INCLUDE INSTRUCTIONS TO AVOID THIS SITUATION***



**CAUTION!**

***INDICATES AREAS SENSITIVE TO ELECTROSTATIC DISCHARGES (ESD) WHICH REQUIRE HANDLING IN AN ESD PROTECTED ENVIRONMENT***

### 1.1. Warnings



**WARNING!**

***THE VOLTAGE USED IN THE DRIVE MIGHT CAUSE ELECTRICAL SHOCKS. DO NOT TOUCH LIVE PARTS WHILE THE POWER SUPPLIES ARE ON***



**WARNING!**

***TO AVOID ELECTRIC ARCING AND HAZARDS, NEVER CONNECT / DISCONNECT WIRES FROM THE DRIVE WHILE THE POWER SUPPLIES ARE ON***



**WARNING!** *THE DRIVE MAY HAVE HOT SURFACES DURING OPERATION.*



**WARNING!** *DURING DRIVE OPERATION, THE CONTROLLED MOTOR WILL MOVE. KEEP AWAY FROM ALL MOVING PARTS TO AVOID INJURY*

## 1.2. Cautions



**CAUTION!** *THE POWER SUPPLIES CONNECTED TO THE DRIVE MUST COMPLY WITH THE PARAMETERS SPECIFIED IN THIS DOCUMENT*



**CAUTION!** *TROUBLESHOOTING AND SERVICING ARE PERMITTED ONLY FOR PERSONNEL AUTHORISED BY TECHNOSOFT*



**CAUTION!** *THE DRIVE CONTAINS ELECTROSTATICALLY SENSITIVE COMPONENTS WHICH MAY BE DAMAGED BY INCORRECT HANDLING. THEREFORE THE DRIVE SHALL BE REMOVED FROM ITS ORIGINAL PACKAGE ONLY IN AN ESD PROTECTED ENVIRONMENT*

To prevent electrostatic damage, avoid contact with insulating materials, such as synthetic fabrics or plastic surfaces. In order to discharge static electricity build-up, place the drive on a grounded conductive surface and also ground yourself.

---

## 2. Product Overview

### 2.1. Introduction

The **IPS110** is a family of intelligent stepper minidrive, based on the latest DSP technology and they offer unprecedented drive performance combined with an embedded motion controller.

Suitable for control of brushed DC and step motors, the IPS110 drives accept as position feedback incremental encoders (quadrature).

All drives perform position, speed or torque control and work in either single-, multi-axis or stand-alone configurations. Thanks to the embedded motion controller, the IPS110 drives combine controller, drive and PLC functionality in a single compact unit and are capable to execute complex motions without requiring intervention of an external motion controller. Using the high-level Technosoft Motion Language (**TML**) the following operations can be executed directly at drive level:

- ❑ Setting various motion modes (profiles, PVT, PT, electronic gearing<sup>2</sup> or camming<sup>1</sup>, etc.)
- ❑ Changing the motion modes and/or the motion parameters
- ❑ Executing homing sequences<sup>1</sup>
- ❑ Controlling the program flow through:
  - Conditional jumps and calls of TML functions
  - TML interrupts generated on pre-defined or programmable conditions (protections triggered, transitions on limit switch or capture inputs, etc.)
  - Waits for programmed events to occur
- ❑ Handling of digital I/O and analogue input signals
- ❑ Executing arithmetic and logic operations
- ❑ Performing data transfers between axes
- ❑ Controlling motion of an axis from another one via motion commands sent between axes
- ❑ Sending commands to a group of axes (multicast). This includes the possibility to start simultaneously motion sequences on all the axes from the group
- ❑ Synchronizing all the axes from a network

Using **EasyMotion Studio** for TML programming you can really distribute the intelligence between the master and the drives in complex multi-axis applications, reducing both the development time and the overall communication requirements. For example, instead of trying to command each movement of an axis, you can program the drives using TML to execute complex motion tasks and inform the master when these tasks are done. Thus, for each axis control the master job may be reduced at: calling TML functions stored in the drive EEPROM (with possibility to abort their execution if needed) and waiting for a message, which confirms the TML functions execution.

---

<sup>1</sup> Optional for the IPS110 CANopen execution

---

Apart from a CANopen master, the IPS110 drives can also be controlled from a PC or PLC using the family of **TML\_LIB** motion libraries.

For all motion programming options, the IPS110 commissioning for your application is done using **EasySetUp**.

## 2.2. Key Features

- Digital drives for control of brushed DC and step motors with built-in motion controller and high-level TML motion language
- Position, speed or torque control
- Various motion programming modes:
  - Position profiles with trapezoidal or S-curve speed shape
  - Position, Velocity, Time (PVT) 3<sup>rd</sup> order interpolation
  - Position, Time (PT) 1<sup>st</sup> order interpolation
  - Electronic gearing and camming<sup>1</sup>
  - External analogue or digital reference<sup>1</sup>
  - 33 Homing modes
- Dual incremental encoder interface: 5V single-ended or open-collector
- Pulse & direction interface (5V or 24V single-ended, open-collector or RS-422 differential) for external (master) digital reference<sup>1</sup>
- Linear Halls sensor interface
- Digital I/Os:
  - 2 digital input-output lines (TTL compatible) shared with 2 analog inputs (0 ... 3.3V)
  - RESET input
  - 2 Limit Switches (LSP and LSN)
- RS-232 serial communication up to 115kbaud
- CAN-bus 2.0A / 2.0B up to 1Mbit/s, with selectable communication protocol:
  - CANopen<sup>2</sup> – compatible with CiA standards: DS301 and DSP402
  - TMLCAN<sup>2</sup> – compatible with all Technosoft drives with CANbus interface
- 1.5K×16 SRAM for data acquisitions and 8K×16 E<sup>2</sup>ROM for setup data and TML programs
- Hardware Axis ID selection – solder joints
- Nominal PWM switching frequency<sup>3</sup>: 20 kHz
- Nominal update frequency for torque loop<sup>3</sup>: 10 kHz
- Update frequency for speed/position loop<sup>4</sup>: 1-10 kHz
- Continuous output current: 0.5 A<sub>RMS</sub>
- Peak output current: 1A
- Logic power supply: 5 VDC

---

<sup>1</sup> Optional for the IPS110 CANopen execution

<sup>2</sup> Available only for the IPS110 CANopen execution

<sup>3</sup> Nominal values cover all cases. Higher values are possible in specific configurations. For details contact Technosoft


<sup>4</sup> 1-2kHz cover all cases. Higher values equal with torque loop update frequency are possible with quadrature encoders



- Motor power supply: 12÷45 VDC
- Minimal load inductance: 25µH @12V, 100 µH @ 45 V
- Operating ambient temperature<sup>1</sup>: 0-40°C


## 2.3. Supported Motor-Sensor Configurations

1. Position, speed or torque control of a **DC brushed rotary motor** with an **incremental quadrature encoder** on its shaft. Scaling factors take into account the transmission ratio between motor and load (rotary or linear). Therefore, the motion commands (for position, speed and acceleration) expressed in SI units (or derivatives) refer to the load, while the same commands, expressed in IU units, refer to the motor.



**Figure 2.1.** DC brushed rotary motor. Position/speed/torque control. Quadrature encoder on motor


2. Open-loop control of a 2-phase **step motor** in position or speed. Scaling factors take into account the transmission ratio between motor and load (rotary or linear). Therefore, the motion commands (for position, speed and acceleration) expressed in SI units (or derivatives) refer to the load, while the same commands, expressed in IU units, refer to the motor.



**Figure 2.2.** No position or speed feedback. Open-loop control: motor position or speed .


<sup>1</sup> For higher ambient temperatures see the de-rating information below

- 
3. Closed-loop control of **load position using an encoder on load**, combined with open-loop control of a **2 phase step motor** in speed, with speed reference provided by the position controller. The motion commands in both SI and IU units refer to the load.



**Figure 2.3.** Encoder on load. Closed-loop control: load position, open-loop control: motor speed


4. Closed-loop control of a **2-phase step motor** in position, speed or torque. Scaling factors take into account the transmission ratio between motor and load (rotary or linear). Therefore, the motion commands expressed in SI units (or derivatives) refer to the load<sup>1</sup>, while the same commands, expressed in IU units refer to the motor.



**Figure 2.4.** Encoder on motor shaft. Closed-loop control: motor position, speed or torque

## 2.4. IPS110 Dimensions

The next figure presents the IPS110 drives dimensions.



**Figure 2.5.** IPS110 drives dimensions

## 2.5. Electrical Specifications

All parameters measured under the following conditions (unless otherwise noted):

- $T_{amb} = 0...40^{\circ}\text{C}$ , logic supply  $V_{LOG} = 5 V_{DC}$ , motor supply  $V_{MOT} = 24 V_{DC}$ ;
- Supplies start-up / shutdown sequence: -any- ;
- Load current  $0.5 A_{RMS}$
- External DC-bus capacitor located 10cm from J1

### Logic Supply Input

Measured between +V <sub>LOG</sub> and GND.		Min.	Typ.	Max.	Units
Supply voltage	Nominal values	4,8	5	5,2	V <sub>DC</sub>
	Absolute maximum values, continuous <sup>†</sup>	-0.5		5,2	V <sub>DC</sub>
Supply current	Normal operation		180	250	mA

### Motor Supply Input

Measured between +V <sub>MOT</sub> and GND.		Min.	Typ.	Max.	Units
Supply voltage IPS110	Operating voltages, including ripple & braking-induced over-voltage	12		45	V <sub>DC</sub>
	Absolute maximum values, continuous	0		48	V <sub>DC</sub>
	Absolute maximum values, surge <sup>†</sup> (duration ≤ 10mS)	-0.5		50	V
DC-bus capacitor value	DC-bus capacitor connected between +V <sub>MOT</sub> and GND	220			μF
DC-bus capacitor location	Wire length from DC-bus capacitor to J1 pins	0	10	20	cm

### Motor Outputs

All voltages referenced to GND.		Min.	Typ.	Max.	Units
Motor output current	Continuous operation	-		+0.5	A <sub>RMS</sub>
Motor output current, peak		-		+1	A
Short-circuit protection threshold		Programmable			
Short-circuit protection delay		Programmable			
On-state voltage drop	Output current = ±0.5A	-	±0.6	-	V
Off-state leakage current		-1	±0.1	+1	mA
Motor inductance	F <sub>PWM</sub> = 20kHz, +V <sub>MOT</sub> = 12V	50			μH
	F <sub>PWM</sub> = 20kHz, +V <sub>MOT</sub> = 45V	200			μH

### 5V Digital Inputs

		All voltages referenced to GND.	Min.	Typ.	Max.	Units
Input voltage		Logic "LOW"	-	-	0.8	V
		Logic "HIGH"	2	-	5	
		Absolute maximum, surge (duration ≤ 1S) <sup>†</sup>	-		+5.6	
Input current	IO#35, IO#36	Logic "HIGH"; Internal pull-up to +5V	0	0	0	μA
		Logic "LOW"	-	-	90	
	PULS+, DIR+, ENCA, ENCB, RESET	Logic "HIGH"; Internal pull-up to +5V	0	0	0	
		Logic "LOW"	-	-	1000	
	PULS-, DIR-	Logic "HIGH"			1500	
		Logic "LOW"			700	
Input frequency			0		5	MHz
Minimum pulse width			150			nS
ESD Protection		Human Body Model (100 pF, 1.5 KΩ)			±2	KV

### 3.3V Digital Outputs

All voltages referenced to GND.		Min.	Typ.	Max.	Units
Output voltage	Logic "LOW"	0	-	0.4	V
	Logic "HIGH"	2.4	-	3.3	
Output current		-4		+4	mA
Output impedance			470		Ω
ESD Protection	Human Body Model (100 pF, 1.5 KΩ)			±2	KV

### Encoder Inputs

		Min.	Typ.	Max.	Units
Standards compliance		Differential / RS422			
Low level input current	Internal 1 k $\Omega$ pull-ups to +5 V <sub>DC</sub>		5	6	mA
Input frequency			2.5		MHz
Input hysteresis		0.1	0.2	0.5	V

## Encoder 2 Inputs

		Min.	Typ.	Max.	Units
Standards compliance		TTL / CMOS / open-collector			
Input frequency			20		KHz
Input threshold voltage	In single-ended mode (TTL / CMOS / open-collector)		1.65		V
Input hysteresis		0.1	0.2	0.5	V

## Analog Inputs

	Referenced to GND	Min.	Typ.	Max.	Units
Voltage range		0		3.3	V
Input impedance			50		K $\Omega$
Resolution			10		bits
Differential linearity	Guaranteed 10-bit no-missing-codes			0.09	% FS <sup>1</sup>
Offset error			±0.1	±0.2	% FS <sup>1</sup>
Gain error		±2		±1.6	% FS <sup>1</sup>
Bandwidth (-3dB)			20		KHz
ESD Protection	Human Body Model (100 pF, 1.5 K $\Omega$ )			±2	KV

## RS-232

		Min.	Typ.	Max.	Units
Standards compliance		TIA/EIA-232-C			
Bit rate	Depending on software settings	9600		115200	Baud
ESD Protection	Human Body Model (100 pF, 1.5 K $\Omega$ )			±15	KV
Input voltage	RX232 input	-25	-	+25	V
Output short-circuit withstand	TX232 output to GND	Guaranteed			

## CAN-Bus


	All voltages referenced to GND	Min.	Typ.	Max.	Units
Standards compliance		CAN-Bus 2.0B error active; ISO 11898-2			
Recommended transmission line impedance	Measured at 1MHz	90	120	150	$\Omega$
Bit rate	Depending on software settings	125K		1M	Baud
Number of network nodes	Depending on software settings			64	-
ESD Protection	Human Body Model (100 pF, 1.5 K $\Omega$ )			±15	KV

## Others


		Min.	Typ.	Max.	Units
Temperature	Operating	0		40	°C
	Storage (not powered)	-40		85	°C
Humidity (Non-condensing)	Operating	0		90	%RH
	Storage	0		100	%RH
Altitude / pressure <sup>7</sup>	Altitude (referenced to sea level)			+4	Km
	Ambient Pressure	0.64	0.9 ÷ 1	4.0	atm
Dimensions	Length x Width x Height	50 x 26.5 x 11.5			mm
Weight			50		g

<sup>1</sup> "FS" stands for "Full Scale"

† Stresses beyond those listed under "absolute maximum ratings" may cause permanent damage to the device. Exposure to absolute maximum-rated conditions for extended periods may affect device reliability.



**Figure 2.6. De-rating with ambient temperature<sup>8 9</sup>**




**Figure 2.7. De-rating with altitude**


<sup>7</sup> At altitudes over 1,000m, current and power rating are reduced due to thermal dissipation efficiency at higher altitudes. See Figure 2.7 - De-rating with altitude

<sup>8</sup>  $I_{NOM}$  – the nominal current

<sup>9</sup> Stand-alone operation, vertical mounting



**Figure 2.8.** Current De-rating with PWM frequency




**Figure 2.9.** Output Voltage De-rating with PWM frequency<sup>10</sup>




**CAUTION!**

**For PWM frequencies less than 20kHz, correlate the PWM frequency with the motor parameters in order to avoid possible motor damage.**



**Figure 2.10.** Power De-rating with PWM frequency<sup>11</sup>



**Figure 2.11.** Over-current diagram

<sup>10</sup>  $V_{OUT}$  – the output voltage,  $V_{MOT}$  – the motor supply voltage

<sup>11</sup>  $P_{NOM}$  – the nominal power




---

## 3. Step 1. Hardware Installation

### 3.1. Mounting

The IPS110 drive was designed to be cooled by natural convection. It shall be mounted horizontally on a printed circuit board.



*Figure 3.1. Recommended mounting of IPS110 on a printed circuit board*

### 3.2. Connectors and Connection Diagrams

#### 3.2.1. Connectors Layout




Figure 3.2. IPS110 connectors layout

---

### 3.2.2. Identification Labels



**Figure 3.3.** *IPS110, RS232 Identification Label*



**Figure 3.4.** *IPS110, CAN Identification Label*



**Figure 3.5.** *IPS110, CANopen Identification Label*


### 3.2.3. J1 Connector pinout

Pin	Pin name	TML name	Type	Function / Alternate function / Comments
1	<b>+V<sub>MOT</sub></b>	-	I	Positive terminal of the <b>motor supply</b> : 12 to 45 V <sub>DC</sub>
2	<b>+V<sub>MOT</sub></b>	-	I	Positive terminal of the <b>motor supply</b> : 12 to 45 V <sub>DC</sub>
3	<b>A+</b>	-	O	<b>Phase A+</b> for step motors <b>Motor+</b> for DC brush motors
4	<b>A-</b>	-	O	<b>Phase A-</b> for step motors <b>Motor-</b> for DC brush motors
5	<b>B+</b>	-	O	<b>Phase B+</b> for step motors <b>Motor+</b> for DC brush motors
6	<b>B-</b>	-	O	<b>Phase B-</b> for step motors <b>Motor-</b> for DC brush motors
7	<b>GND</b>	-	-	<b>Ground</b>
8	<b>GND</b>	-	-	<b>Ground</b>
9	<b>+5V</b>	-	I	Positive terminal of the <b>logic supply</b> : 5 V <sub>DC</sub>
10	<b>TX232</b>	-	O	<b>RS-232 Data Transmission</b>
11	<b>RX232</b>	-	I	<b>RS-232 Data Reception</b>
12	<b>RESET</b>	-	I	<b>RESET</b> signal – connect to GND to reset the board

### 3.2.4. J2 Connector pinout

Pin	Pin name	TML name	Type	Function / Alternate function / Comments
1	ENCA	-	I	<b>Encoder A</b> signal
2	ENCB	-	I	<b>Encoder B</b> signal
3	Puls+	IN#38 / PULSE	I	<ul style="list-style-type: none"> <li>Positive and negative terminals of <b>IN#38/PULSE</b> input are RS-422 compatible.</li> <li>Can be used as <b>PULSE</b> input in Pulse &amp; Direction motion mode.</li> </ul>
4	Puls-		I	
5	Dir+	IN#37 / DIR	I	<ul style="list-style-type: none"> <li>Positive and negative terminals of <b>IN#37/DIR</b> input are RS-422 compatible.</li> <li>Can be used as <b>DIRECTION</b> input in Pulse &amp; Direction motion mode.</li> </ul>
6	Dir-		I	
7	IO#35 / Sin / LSP / CAPI	IO#35 / CAPI	I	<ul style="list-style-type: none"> <li><b>IO#35</b> - digital I/O (TTL compatible)</li> <li><b>Sin</b> – 3.3V analog input for Linear Hall sensor</li> <li><b>Limit Switch - Positive</b> (TTL compatible)</li> <li><b>CAPI</b> - Encoder Z signal (TTL compatible)</li> </ul>
8	IO#36 / Cos / LSN / CAPI2	IO#36 / CAPI2	I	<ul style="list-style-type: none"> <li><b>IO#35</b> - digital I/O (TTL compatible)</li> <li><b>Cos</b> – 3.3V analog input for Linear Hall sensor</li> <li><b>Limit Switch - Negative</b> (TTL compatible)</li> <li><b>CAPI2</b> – Second encoder index (TTL compatible)</li> </ul>
9	Reference	AD5	I	0...3.3 V analog input. May be used as analog position, speed, or torque reference.
10	Feedback	AD2	I	0...3.3 V analog input. May be used as analog position or speed feedback (from a tachometer).
11	CAN_H	-	I/O	CAN-Bus positive line (positive during dominant bit). Not connected on the no-CAN execution of the IPS110 drive (P045.001.E001)
12	CAN_L	-	I/O	CAN-Bus negative line (negative during dominant bit) Not connected on the no-CAN execution of the IPS110 drive (P045.001.E001)

### 3.2.5. Supply connection



**Figure 3.6.** J1 – Supplies connection

#### 3.2.5.1 Recommendations for Supply Wiring

1. Use short, thick wires between the IPS110 and the motor power supply. If the wires are longer than 2 meters, use twisted wires for the supply and ground return. For wires longer than 20 meters, add a capacitor of at least 1,000  $\mu\text{F}$  (rated at an appropriate voltage) right on the terminals of the IPS110.
2. When the same motor power supply is used for multiple drives, do a “star” connection centered (electrically) around the supply outputs. Connect each drive to the common motor supply using separate wires for plus and return.

#### 3.2.5.2 Recommendations to limit over-voltage during braking

During abrupt motion brakes or reversals the regenerative energy is injected into the motor power supply. This may cause an increase of the motor supply voltage (depending on the power supply characteristics). If the voltage bypasses the  $U_{\text{MAX}}$  value, the drive over-voltage protection is triggered and the drive power stage is disabled.

In order to avoid this situation **add a capacitor on the motor supply** big enough to absorb the overall energy flowing back to the supply. The capacitor must be rated to a voltage equal or bigger than the maximum expected over-voltage and can be sized with the formula:

$$C \geq \frac{2 \times E_M}{U_{MAX}^2 - U_{NOM}^2}$$

where:

$U_{MAX}$  - is the over-voltage protection limit expressed in [V]. You can read this value in the "Drive Info" dialogue, which can be opened from the "Drive Setup".

$U_{NOM}$  - is nominal motor supply voltage expressed in [V]. You can read this value in the "Drive Info" dialogue, which can be opened from the "Drive Setup".

$E_M$  - the overall energy flowing back to the supply in Joules. In case of a rotary motor and load,

$E_M$  can be computed with the formula:

$$E_M = \underbrace{\frac{1}{2}(J_M + J_L)\omega_M^2}_{\text{Kinetic energy}} + \underbrace{(m_M + m_L)g(h_{\text{initial}} - h_{\text{final}})}_{\text{Potential energy}} - \underbrace{3I_M^2 R_{Ph} t_d}_{\text{Copper losses}} - \underbrace{\frac{t_d \omega_M}{2} T_F}_{\text{Friction losses}}$$

where:

$J_M$  – total rotor inertia [kgm<sup>2</sup>]

$J_L$  – total load inertia as seen at motor shaft after transmission [kgm<sup>2</sup>]

$\omega_M$  – motor angular speed before deceleration [rad/s]

$m_M$  – motor mass [kg] – when motor is moving in a non-horizontal plane

$m_L$  – load mass [kg] – when load is moving in a non-horizontal plane

$g$  – gravitational acceleration i.e. 9.8 [m/s<sup>2</sup>]

$h_{\text{initial}}$  – initial system altitude [m]

$h_{\text{final}}$  – final system altitude [m]

$I_M$  – motor current during deceleration [ $A_{RMS}$ /phase]

$R_{Ph}$  – motor phase resistance [ $\Omega$ ]

$t_d$  – time to decelerate [s]

$T_F$  – total friction torque as seen at motor shaft [Nm] – includes load and transmission

In case of a linear motor and load, the motor inertia  $J_M$  and the load inertia  $J_L$  will be replaced by the motor mass and the load mass measured in [kg], the angular speed  $\omega_M$  will become linear speed measured in [m/s] and the friction torque  $T_F$  will become friction force measured in [N].

**Remark:** If the above computation of  $E_M$  can't be done due to missing data, a good starting value for the capacitor can be 10 000  $\mu F$  / 100V.

### 3.2.6. Motor connections





Figure 3.7. J1 – Step motor connection






**Figure 3.8.** J2 – DC brushed motor connection


### 3.2.6.1 Recommendations for Motor Wiring

- Avoid running the motor wires in parallel with other wires for a distance longer than 2 meters. If this situation cannot be avoided, use a shielded cable for the motor wires. Connect the cable shield to the IPS110 GND pin. Leave the other end disconnected.
- The parasitic capacitance between the motor wires must not bypass 100nF. If very long cables (hundreds of meters) are used, this condition may not be met. In this case, add series inductors between the IPS110 outputs and the cable. The inductors must be magnetically shielded (toroidal, for example), and must be rated for the motor surge current. Typically the necessary values are around 100  $\mu$ H.
- A good shielding can be obtained if the motor wires are running inside a metallic cable guide.

### 3.2.7. Feedback connections



**Figure 3.9.** *Single-ended / open-collector encoder connection*



**Figure 3.10.** Master - Slave connection using second encoder input

### 3.2.7.1 Recommendations for Feedback Devices Wiring

- Keep the ground connection between an encoder and the IPS110 even if the encoder supply is not provided by the drive. When using shielded cable, connect the cable shield to the GND at the IPS110 side. Leave the shield unconnected at the encoder side. **Never use the shield as a conductor carrying a signal, for example as a ground line!** This situation can lead to a worse behavior than a non-shielded cable
- Always use shielded cables to avoid capacitive-coupled noise when using cable lengths over 1 meter. Connect the cable shield to the earth potential, at only one end. This point could be either the IPS110 (using the GND pin) or the encoder / motor. Do not connect the shield at both ends.

## 3.2.8. Digital I/O connections

### 3.2.8.1 5V Digital Inputs connection




Figure 3.11. 5V Digital Inputs connection

**Remark:** IO#35, Sin(in), LSP(in) and CAPI(in) lines are shared, also the IO#36, Cos(in), LSN(in) and CAPI2(in) lines are shared. You cannot use these lines simultaneously as analog input and digital input/output.



**CAUTION!** WHEN USING PINS 7/J2 AND 8/J2 AS INPUTS, DO NOT PROGRAM THE IO#35 AND IO#36 AS OUTPUT PINS IN ORDER TO AVOID POSSIBLE DRIVE DAMAGE.



**CAUTION!** THE I/O CONNECTOR SIGNALS ARE ELECTRO-STATICALLY SENSITIVE . THE IPS110 SHALL BE HANDLED ONLY IN AN ESD PROTECTED ENVIRONMENT.

### 3.2.8.2 Pulse & Direction Inputs connection




Figure 3.12. Pulse & Direction Inputs connection

#### Remarks:

1. When IN#38/PULSE is used as PULSE input in Pulse & Direction motion mode, on each rising edge the reference (or feedback) is incremented / decremented.
2. When IN#37/DIR is used as DIRECTION input in Pulse & Direction motion mode, the reference (or feedback) is **incremented** if this pin is **pulled low**.

3. Use one twisted pair for each differential group of signals as follows: Puls+ with Puls- and Dir+ with Dir-. Also connect the GND between the IPS110 and the P&D generator.



**CAUTION!** WHEN USING THE IO#35, IO#36 AS INPUTS, DO NOT PROGRAM THEM AS OUTPUT PINS IN ORDER TO AVOID POSSIBLE DRIVE DAMAGE.

### 3.2.8.3 Digital outputs connection




Figure 3.13. Digital outputs connection

#### Remarks:

1. IO#35 and IO#36 must be programmed as outputs for this operating mode.
2. IO#35, Sin(in), LSP(in) and CAPI(in) lines are shared, also the IO#36, Cos(in), LSN(in) and CAPI2(in) lines are shared. You cannot use these lines simultaneously as analog input and digital input/output.

### 3.2.9. Analog Inputs connection





Figure 3.14. Analog Inputs connection

#### 3.2.9.1 Recommendations for Analogue Signals Wiring

- Use a shielded cable as follows: inner wire connects the live signal to the drive analog input ; shield connects the signal ground to the drive GND.
- If the signal source output voltage is out of the range 0-3.3V, use a 2-resistor differential divider, located near the IPS110 I/O connector. Choose the divider resistances as low as possible, close to the signal source output current limit, to minimize the noise

### 3.2.10. Serial RS-232 Communication connections



**Figure 3.15.** Serial RS-232 connection

#### 3.2.10.1 Recommendations for RS-232 Wiring

- Always power-off all the IPS110 supplies before inserting/removing the RS-232 serial connector.
- Use a 9-wire standard 1-to-1 (non-inverting) shielded cable, preferable with metallic or metallized shells (casings)



**CAUTION! DO NOT CONNECT/DISCONNECT THE RS-232 CABLE WHILE THE DRIVE IS POWERED ON. THIS OPERATION CAN DAMAGE THE DRIVE**



### 3.2.11. CAN Communication connection




Figure 3.16. CAN connection



**CAUTION! THE CANBUS CONNECTOR SIGNALS ARE ELECTRO-STATICALLY SENSITIVE. THE IPS110 SHALL BE HANDLED ONLY IN AN ESD PROTECTED ENVIRONMENT.**


#### Remarks:

1. The CAN network requires two 120 $\Omega$  termination resistors even for short cables. These resistors are not included on the drive.
2. Both CAN signals are NOT insulated from all other IPS110 circuits .
3. CAN signals (CAN\_H and CAN\_L pins of J2 connector) are **not connected** pins on the IPS110 drive execution P045.001.E001.

#### 3.2.11.1 Recommendations for CAN Wiring

- a) Build CAN network using cables with 2-pairs of twisted wires (2 wires/pair) as follows: one pair for CAN\_H with CAN\_L and the other pair for CAN\_V+ with CAN\_GND. The cable impedance must be 105 ... 135 ohms (120 ohms typical) and a capacitance below 30pF/meter.
- b) When total CAN bus length is over 40 meters, it is mandatory to use shielded twisted cables. Connect the cable shield to earth/shield.
- c) When using a printed circuit board (PCB) motherboard based on FR-4 material, build the CAN network using a pair of 12mil (0.012") tracks, spaced 8 to 10mils (0.008"...0.010") apart, placed over a local ground plane (microstrip) which extends at least 1mm left and right to the tracks.

- d) Whenever possible, use daisy-chain links between the CAN nodes. Avoid using stubs. A stub is a "T" connection, where a derivation is taken from the main bus. When stubs can't be avoided keep them as short as possible. For 1 Mbit/s (worst case), the maximum stub length must be below 0.3 meters.
- e) The 120Ω termination resistors must be rated at 0.2W minimum. Do not use winded resistors, which are inductive.



**Figure 3.17. Multiple-Axis CAN network<sup>12</sup>**


<sup>12</sup> The maximum value of the AXISID is 127 for the IPS110 CANopen execution and 255 for IPS110 CAN executions

---

### 3.2.12. Connectors Type and Mating Connectors

Connector	Mating connector		On board connector	
	Manufacturer and part number	Details	Manufacturer and part number	Details
J1, J2	FISCHER ELEKTRONIK BL 5 12	Precision female socket 2.54 mm pitch	FISCHER ELEKTRONIK SL 1 053 012 G	Standard header square pin 0.635 x 0.635 mm; 2.54 mm pitch

### 3.3. Jumper and solder joints configuration



**Figure 3.18.** Jumpers (JP1 and JP2) and solder joints

- **JP1:** Auto / Ext
  - **SHORT:** IPS110 in Autorun (stand-alone) mode. After reset, automatically executes a program from the internal E<sup>2</sup>ROM.
  - **OPEN:** IPS110 in External (slave) mode. After reset, waits for commands from an external device.
- **JP2:** FU / Norm
  - **SHORT:** Enable firmware update
  - **OPEN:** Normal operation
- **ID5...ID0:** Axis ID solder-joints

These solder-joints are sampled during power-up, and the Axis ID is configured accordingly. See *Table 3.1*.

**Table 3.1.** Axis ID configuration

Axis ID solder-joints						Axis ID
ID5	ID4	ID3	ID2	ID1	ID0	
OPEN	OPEN	OPEN	OPEN	OPEN	OPEN	255
OPEN	OPEN	OPEN	OPEN	OPEN	SHORT	62
OPEN	OPEN	OPEN	OPEN	SHORT	OPEN	61
OPEN	OPEN	OPEN	OPEN	SHORT	SHORT	60

Axis ID solder-joints						
ID5	ID4	ID3	ID2	ID1	ID0	Axis ID
OPEN	OPEN	OPEN	SHORT	OPEN	OPEN	59
OPEN	OPEN	OPEN	SHORT	OPEN	SHORT	58
OPEN	OPEN	OPEN	SHORT	SHORT	OPEN	57
OPEN	OPEN	OPEN	SHORT	SHORT	SHORT	56
OPEN	OPEN	SHORT	OPEN	OPEN	OPEN	55
OPEN	OPEN	SHORT	OPEN	OPEN	SHORT	54
OPEN	OPEN	SHORT	OPEN	SHORT	OPEN	53
OPEN	OPEN	SHORT	OPEN	SHORT	SHORT	52
OPEN	OPEN	SHORT	SHORT	OPEN	OPEN	51
OPEN	OPEN	SHORT	SHORT	OPEN	SHORT	50
OPEN	OPEN	SHORT	SHORT	SHORT	OPEN	49
OPEN	OPEN	SHORT	SHORT	SHORT	SHORT	48
OPEN	SHORT	OPEN	OPEN	OPEN	OPEN	47
OPEN	SHORT	OPEN	OPEN	OPEN	SHORT	46
OPEN	SHORT	OPEN	OPEN	SHORT	OPEN	45
OPEN	SHORT	OPEN	OPEN	SHORT	SHORT	44
OPEN	SHORT	OPEN	SHORT	OPEN	OPEN	43
OPEN	SHORT	OPEN	SHORT	OPEN	SHORT	42
OPEN	SHORT	OPEN	SHORT	SHORT	OPEN	41
OPEN	SHORT	OPEN	SHORT	SHORT	SHORT	40
OPEN	SHORT	SHORT	OPEN	OPEN	OPEN	39
OPEN	SHORT	SHORT	OPEN	OPEN	SHORT	38
OPEN	SHORT	SHORT	OPEN	SHORT	OPEN	37
OPEN	SHORT	SHORT	OPEN	SHORT	SHORT	36
OPEN	SHORT	SHORT	SHORT	OPEN	OPEN	35
OPEN	SHORT	SHORT	SHORT	OPEN	SHORT	34
OPEN	SHORT	SHORT	SHORT	SHORT	OPEN	33
OPEN	SHORT	SHORT	SHORT	SHORT	SHORT	32
SHORT	OPEN	OPEN	OPEN	OPEN	OPEN	31
SHORT	OPEN	OPEN	OPEN	OPEN	SHORT	30
SHORT	OPEN	OPEN	OPEN	SHORT	OPEN	29
SHORT	OPEN	OPEN	OPEN	SHORT	SHORT	28
SHORT	OPEN	OPEN	SHORT	OPEN	OPEN	27
SHORT	OPEN	OPEN	SHORT	OPEN	SHORT	26
SHORT	OPEN	OPEN	SHORT	SHORT	OPEN	25
SHORT	OPEN	OPEN	SHORT	SHORT	SHORT	24

Axis ID solder-joints						Axis ID
ID5	ID4	ID3	ID2	ID1	ID0	
SHORT	OPEN	SHORT	OPEN	OPEN	OPEN	23
SHORT	OPEN	SHORT	OPEN	OPEN	SHORT	22
SHORT	OPEN	SHORT	OPEN	SHORT	OPEN	21
SHORT	OPEN	SHORT	OPEN	SHORT	SHORT	20
SHORT	OPEN	SHORT	SHORT	OPEN	OPEN	19
SHORT	OPEN	SHORT	SHORT	OPEN	SHORT	18
SHORT	OPEN	SHORT	SHORT	SHORT	OPEN	17
SHORT	OPEN	SHORT	SHORT	SHORT	SHORT	16
SHORT	SHORT	OPEN	OPEN	OPEN	OPEN	15
SHORT	SHORT	OPEN	OPEN	OPEN	SHORT	14
SHORT	SHORT	OPEN	OPEN	SHORT	OPEN	13
SHORT	SHORT	OPEN	OPEN	SHORT	SHORT	12
SHORT	SHORT	OPEN	SHORT	OPEN	OPEN	11
SHORT	SHORT	OPEN	SHORT	OPEN	SHORT	10
SHORT	SHORT	OPEN	SHORT	SHORT	OPEN	9
SHORT	SHORT	OPEN	SHORT	SHORT	SHORT	8
SHORT	SHORT	SHORT	OPEN	OPEN	OPEN	7
SHORT	SHORT	SHORT	OPEN	OPEN	SHORT	6
SHORT	SHORT	SHORT	OPEN	SHORT	OPEN	5
SHORT	SHORT	SHORT	OPEN	SHORT	SHORT	4
SHORT	SHORT	SHORT	SHORT	OPEN	OPEN	3
SHORT	SHORT	SHORT	SHORT	OPEN	SHORT	2
SHORT	SHORT	SHORT	SHORT	SHORT	OPEN	1

Technosoft drives can be set with axis ID values from 1 to 255. In CANopen protocol the maximum axis number is 127. When CANopen protocol is used, the CAN communication sees the drives axis ID modulo 128. The correspondence is given in Table 3.1. In order to avoid having multiple devices with the same Axis ID, do not use in the same CANopen network drives having the same Axis ID in modulo 128. Put in other words, the difference between any two Axis ID values should not be 128.

**Remark:** The Axis ID modulo 128 applies only for CAN communication with CANopen protocol. The serial communication and the TMLCAN protocol use the complete axis ID value.

**Table 3.1.** *Axis ID modulo 128 seen in CANopen communication*

Real axis ID of the drive	Axis ID seen in CANopen communication
129	1
130	2
...	...
140	12
...	...
200	72
...	...
255	127

When CANopen protocol is selected, the drives can also communicate using *TechnoCAN* protocol – an extension of the CANopen. The TechnoCAN protocol is used to get/send TML commands. TechnoCAN protocol can coexist with CANopen protocol on the same physical network, because it uses ID areas not covered by CANopen. TechnoCAN protocol offers the possibility to inspect the status of ALL Technosoft drives connected on a CANopen network. This operation is done using EasySetUp or EasyMotion Studio and a single RS-232 link with any of the drives from the CANopen network. The inspection / data acquisition can be done while the main application is running.

In TechnoCAN protocol the maximum axis number is 31. When TML commands are exchanged using TechnoCAN protocol, the CAN communication sees the drives axis ID modulo 32. The correspondence is given in Table 3.2. In order to avoid having multiple devices with the same Axis ID, do not use TechnoCAN in a CANopen network with drives having the same Axis ID in modulo 32. Put in other words, the difference between any two Axis ID values should not be a multiple of 32. Note that this restriction applies only when EasySetUp or EasyMotion Studio are used for inspection/debugging. During normal CANopen operation the modulo 32 restriction do not apply.

**Table 3.2.** *Axis ID modulo 32 seen in TechnoCAN communication*

Real axis ID of the drive	Axis ID seen in CANopen communication
33	1
34	2
...	...
200	8
...	...
255	31

---

### 3.4. First Power-Up

In order to setup the drive for your application you need to communicate with it. The easiest way is via an RS-232 serial link between your PC and the drive. Therefore, before the first power-up, check the following:

- Power supply connections and their voltage levels
- Motor connections
- Serial cable connections
- Axis-ID solder joints configuration
- EasySetUp is installed on the PC which is serially connected with the drive (see chapter Step 2. Drive Setup)



---

## 4. Step 2. Drive Setup

### 4.1. Installing EasySetUp

**EasySetUp** is a PC software platform for the setup of the Technosoft drives. It can be downloaded **free of charge** from Technosoft web page. EasySetUp comes with an **Update via Internet tool** through which you can check if your software version is up-to-date, and when necessary download and install the latest updates. EasySetUp includes a firmware programmer through which you can update your drive firmware to the latest revision.

EasySetUp can be installed independently or together with **EasyMotion Studio** platform for motion programming using TML. You will need EasyMotion Studio only if you plan to use the advance features presented in Section 5.3 Combining CANopen /or other host with TML. A **demo version of EasyMotion Studio** including the **fully functional version of EasySetUp** can be downloaded free of charge from Technosoft web page.

On request, EasySetUp can be provided on a CD too. In this case, after installation, use the update via internet tool to check for the latest updates. Once you have started the installation package, follow its indications.

### 4.2. Getting Started with EasySetUp

Using EasySetUp you can quickly setup a drive for your application. The drive can be:

- directly connected with your PC via a serial RS 232 link
- any drive from a CANbus network where the PC is serially linked with one of the other drives.

The output of EasySetUp is a set of *setup data*, which can be downloaded into the drive EEPROM or saved on your PC for later use.

EasySetUp includes a set of evaluation tools like the Data Logger, the Control Panel and the Command Interpreter which help you to quickly measure, check and analyze your drive commissioning.

EasySetUp works with **setup** data. A **setup** contains all the information needed to configure and parameterize a Technosoft drive. This information is preserved in the drive EEPROM in the *setup table*. The setup table is copied at power-on into the RAM memory of the drive and is used during runtime. With EasySetUp it is also possible to retrieve the complete setup information from a drive previously programmed.

Note that with EasySetUp you do only your drive/motor commissioning. For motion programming you have the following options:


- Use a **CANopen** master
- Use **EasyMotion Studio** to create and download a **TML** program into the drive/motor memory
- Use one of the **TML\_LIB** motion libraries to control the drives/motors from your host/master. If your host is a **PC**, TML\_LIB offers a collection of high level motion functions which can be

called from applications written in C/C++, Visual Basic, Delphi Pascal or LabVIEW. If your host is a **PLC**, TML\_LIB offers a collection of function blocks for motion programming, which are **IEC61131-3 compatible** and can be integrated in your PLC program.

- **Implement** on your master the TML commands you need to send to the drives/motors using one of the supported communication channels. The implementation must be done according with Technosoft communication protocols.
- **Combine** TML programming at drive level with one of the other options (see Section 5.3)

#### 4.2.1. Establish communication

EasySetUp starts with an empty window from where you can create a **New** setup, **Open** a previously created setup which was saved on your PC, or **Upload** the setup from the drive/motor.




Before selecting one of the above options, you need to establish the communication with the drive you want to commission. Use menu command **Communication | Setup** to check/change your PC communication settings. Press the **Help** button of the dialogue opened. Here you can find detailed information about how to setup your drive and do the connections. Power on the drive, then close the Communication | Setup dialogue with OK. If the communication is established, EasySetUp displays in the status bar (the bottom line) the text “**Online**” plus the axis ID of your


drive/motor and its firmware version. Otherwise the text displayed is “Offline” and a communication error message tells you the error type. In this case, return to the Communication | Setup dialogue, press the Help button and check troubleshoots

**Remark:** When first started, EasySetUp tries to communicate via RS-232 and COM1 with a drive having axis ID=255 (default communication settings). If your drive is powered with all the DIP switches OFF and it is connected to your PC port COM1 via an RS-232 cable, the communication shall establish automatically. If the drive has a different axis ID and you don't know it, select in the Communication | Setup dialogue at “Axis ID of drive/motor connected to PC” the option **Autodetected**.

#### 4.2.2. Setup drive/motor




Press **New** button and select your drive type.



The selection continues with the motor technology (for example: 2 phase closed loop) and type of feedback device (Incremental encoder).

The selection opens 2 setup dialogues: for **Motor Setup** and for **Drive setup** through which you can configure and parameterize a Technosoft drive, plus several predefined control panels customized for the product selected.




In the **Motor setup** dialogue you can introduce the data of your motor and the associated sensors. Data introduction is accompanied by a series of tests having as goal to check the connections to the drive and/or to determine or validate a part of the motor and sensors parameters. In the **Drive setup** dialogue you can configure and parameterize the drive for your application. In each dialogue you will find a **Guideline Assistant**, which will guide you through the whole process of introducing and/or checking your data. Close the Drive setup dialogue with **OK** to keep all the changes regarding the motor and the drive setup.

---

#### 4.2.3. Download setup data to drive/motor



Press the **Download to Drive/Motor** button to download your setup data in the drive/motor EEPROM memory in the *setup table*. From now on, at each power-on, the setup data is copied into the drive/motor RAM memory which is used during runtime. It is also possible to



**Save** the setup data on your PC and use it in other applications.

To summarize, you can define or change the setup data in the following ways:

- create a new setup data by going through the motor and drive dialogues
- use setup data previously saved in the PC
- upload setup data from a drive/motor EEPROM memory

#### 4.2.4. Evaluate drive/motor behaviour (optional)

You can use the **Data Logger** or the **Control Panel** evaluation tools to quickly measure and analyze your application behavior. In case of errors like protections triggered, use the Drive Status control panel to find the cause.

### 4.3. Changing the drive Axis ID

The axis ID of an IPS110 drive can be set in 2 ways:

- Hardware (H/W) – according with the solder joints configuration in the range 1 to 31 or 255 (see 3.3 Jumper and solder joint configuration)
- Software – any value between 1 and 255, stored in the setup table

The axis ID is initialized at power on, using the following algorithm:

- a) If a valid setup table exists, with the value read from it. This value can be an axis number 1 to 255 or can indicate that axis ID will be set according with DIP switch selection
- b) If the setup table is invalid, with the last value set with a valid setup table. This value can be an axis number 1 to 255 or can indicate that axis ID will be set according with DIP switch selection
- c) If there is no axis ID set by a valid setup table, according with the solder joints configuration

**Remark:** If a drive axis ID was previously set by software and its value is not anymore known, you can find it by selecting in the *Communication | Setup* dialogue at "Axis ID of drive/motor connected to PC" the option **Autodetected**. Apply this solution only if this drive is connected

directly with your PC via an RS-232 link. If this drive is part of a CANbus network and the PC is serially connected with another drive, use the menu command **Communication / Scan Network**

#### 4.4. Setting CANbus rate

The IPS110 drives can work with the following rates on the CAN: 125kHz, 250kHz, 500kHz, 1MHz. In the Drive Setup dialogue you can choose the initial CAN rate after power on. This information is stored in the setup table. The CAN rate is initialized using the following algorithm:

If a valid setup table exists, with the CAN rate value read from it. This can be any of the supported rates or can indicate to use the firmware default (F/W default) value, which is 500kHz

If the setup table is invalid, with the last CAN rate value set with a valid setup table. This can be any of the supported rates or can indicate to use the firmware default (F/W default) value

If there is no CAN rate value set by a valid setup table, with the firmware default value i.e. 500kHz

## 4.5. Creating an Image File with the Setup Data

Once you have validated your setup, you can create with the menu command **Setup | Create EEPROM Programmer File** a software file (with extension **.sw**) which contains all the setup data to write in the EEPROM of your drive.

A software file is a text file that can be read with any text editor. It contains blocks of data separated by an empty row. Each block of data starts with the block start address, followed by data values to place in ascending order at consecutive addresses: first data – to write at start address, second data – to write at start address + 1, etc. All the data are hexadecimal 16-bit values (maximum 4 hexadecimal digits). Each row contains a single data value. When less than 4 hexadecimal digits are shown, the value must be right justified. For example 92 represent 0x0092.

The **.sw** file can be programmed into a drive:

- from a CANopen master, using the communication objects for writing data into the drive EEPROM
- from a host PC or PLC, using the TML\_LIB functions for writing data into the drive EEPROM

- 
- using the EEPROM Programmer tool, which comes with EasySetUp but may also be installed separately. The EEPROM Programmer was specifically designed for repetitive fast and easy programming of **.sw** files into the Technosoft drives during production.

## 5. Step 3. Motion Programming

### 5.1. Using a CANopen Master (for IPS110 CANopen execution)

The IPS110 drive supports the CiA draft standard **DS-301 v4.02** CANopen Application Layer and Communication Profile. It also conforms with the CiA draft standard proposal **DSP-402 v2.0** CANopen Device Profile for Drives and Motion Control. For details see CANopen Programming manual (part no. P091.063.UM.xxxx)

#### 5.1.1. DS-301 Communication Profile Overview

The IPS110 drive accepts the following basic services and types of communication objects of the CANopen communication profile DS 301 v4.02:

- **Service Data Object (SDO)**

Service Data Objects (SDOs) are used by CANopen master to access any object from the drive's Object Dictionary. Both expedited and segmented SDO transfers are supported (see DS301 v4.02 for details). SDO transfers are confirmed services. The SDOs are typically used for drive configuration after power-on, for PDOs mapping and for infrequent low priority communication between the CANopen master with the drives.

- **Process Data Object (PDO)**

Process Data Objects (PDO) are used for high priority, real-time data transfers between CANopen master and the drives. The PDOs are unconfirmed services which are performed with no protocol overhead. Transmit PDOs are used to send data from the drive, and receive PDOs are used to receive on to the drive. The IPS110 accepts 4 transmit PDOs and 4 receive PDOs. The contents of the PDOs can be set according with the application needs using the dynamic PDO-mapping. This operation can be done during the drive configuration phase using SDOs.

- **Synchronization Object (SYNC)**

The SYNC message provides the basic network clock, as the SYNC producer broadcasts the synchronization object periodically. The service is unconfirmed. The IPS110 supports both SYNC consumer and producer.

- **Time Stamp Object (TIME)**

The Time Stamp Object is not supported by the IPS110 device.

- **Emergency Object (EMCY)**

Emergency objects are triggered by the occurrence of a drive internal error situation. An emergency object is transmitted only once per 'error event'. As long as no new errors occur, the drive will not transmit further emergency objects.



---

- **Network Management Objects (NMT)**

The Network Management is node oriented and follows a master-slave structure. NMT objects are used for executing NMT services. Through NMT services the drive can be initialized, started, monitored, reset or stopped. The IPS110 is a NMT slave in a CANopen network.

- **Module Control Services** – through these unconfirmed services, the NMT master controls the state of the drive. The following services are implemented: Start Remote Node, Stop Remote Node, Enter Pre-Operational, Reset Node, Reset Communication
- **Error Control Services** – through these services the NMT master detects failures in a CAN-based network. Both error control services defined by DS301 v4.02 are supported by the IPS110: Node Guarding (including Life Guarding) and Heartbeat
- **Bootup Service** - through this service, the drive indicates that it has been properly initialized and is ready to receive commands from a master

### 5.1.2. TechnoCAN Extension (for IPS110 CAN executions)

In order to take full advantage of the powerful Technosoft Motion Language (TML) built into the IPS110, Technosoft has developed an extension to CANopen, called TechnoCAN through which TML commands can be exchanged with the drives. Thanks to TechnoCAN you can inspect or reprogram any of the Technosoft drives from a CANopen network using EastSetUp or EasyMotion Studio and an RS-232 link between your PC and anyone of the drives.

TechnoCAN uses only identifiers outside of the range used by the default by the CANopen predefined connection set (as defined by CiA DS301 v4.02). Thus, TechnoCAN protocol and CANopen protocol can co-exist and communicate simultaneously on the same physical CAN bus, without disturbing each other.

### 5.1.3. DSP-402 and Manufacturer Specific Device Profile Overview

The IPS110 supports the following CiA DSP402 v2.0 modes of operation:

- **Profile position mode**
- **Profile velocity mode**
- **Homing mode**
- **Interpolated position mode**

Additional to these modes, there are also several manufacturer specific modes defined:

- **External reference modes (position, speed or torque)**
- **Electronic gearing position mode<sup>13</sup>**
- **Electronic camming position mode<sup>1</sup>**

---

<sup>13</sup> Optional for IPS110 CANopen execution

---

#### 5.1.4. Checking Setup Data Consistency

During the configuration phase, a CANopen master can quickly verify using the checksum objects and a reference **.sw** file (see 4.5 and 5.2.4 for details) whether the non-volatile EEPROM memory of an IPS110 drive contains the right information. If the checksum reported by the drive doesn't match with that computed from the **.sw** file, the CANopen master can download the entire **.sw** file into the drive EEPROM using the communication objects for writing data into the drive EEPROM.

### 5.2. Using the built-in Motion Controller and TML

One of the key advantages of the Technosoft drives is their capability to execute complex motions without requiring an external motion controller. This is possible because Technosoft drives offer in a single compact package both a state of art digital drive and a powerful motion controller.

#### 5.2.1. Technosoft Motion Language Overview

Programming motion directly on a Technosoft drive requires to create and download a TML (Technosoft Motion Language) program into the drive memory. The TML allows you to:

- Set various motion modes (profiles, PVT, PT, electronic gearing<sup>14</sup> or camming<sup>1</sup>, etc.)
- Change the motion modes and/or the motion parameters
- Execute homing sequences<sup>15</sup>
- Control the program flow through:
  - Conditional jumps and calls of TML functions
  - TML interrupts generated on pre-defined or programmable conditions (protections triggered, transitions on limit switch or capture inputs, etc.)
  - Waits for programmed events to occur
- Handle digital I/O and analogue input signals
- Execute arithmetic and logic operations
- Perform data transfers between axes
- Control motion of an axis from another one via motion commands sent between axes
- Send commands to a group of axes (multicast). This includes the possibility to start simultaneously motion sequences on all the axes from the group
- Synchronize all the axes from a network

In order to program a motion using TML you need EasyMotion Studio software platform.

---

<sup>14</sup> Optional for the IPS110 CANopen execution

<sup>15</sup> The customization of the homing routines is available only for IPS110 CAN executions

---

### 5.2.2. Installing EasyMotion Studio

**EasyMotion Studio** is an integrated development environment for the setup and motion programming of Technosoft intelligent drives. It comes with an **Update via Internet tool** through which you can check if your software version is up-to-date, and when necessary download and install the latest updates.

A **demo version of EasyMotion Studio** including the **fully functional version of EasySetUp** can be downloaded free of charge from Technosoft web page.

EasyMotion Studio is delivered on a CD. Once you have started the installation package, follow its indications. After installation, use the update via internet tool to check for the latest updates. Alternately, you can first install the demo version and then purchase a license. By introducing the license serial number in the menu command **Help | Enter registration info...**, you can transform the demo version into a fully functional version.

### 5.2.3. Getting Started with EasyMotion Studio

Using EasyMotion Studio you can quickly do the setup and the motion programming of a Technosoft a drive according with your application needs. The drive can be:

- directly connected with your PC via a serial RS 232 link
- any drive from a CANbus network where the PC is serially linked with one of the other drives.

The output of the EasyMotion Studio is a set of setup data and a motion program, which can be downloaded to the drive/motor EEPROM or saved on your PC for later use.

EasyMotion Studio includes a set of evaluation tools like the Data Logger, the Control Panel and the Command Interpreter which help you to quickly develop, test, measure and analyze your motion application.

EasyMotion Studio works with **projects**. A project contains one or several **Applications**.

Each application describes a motion system for one axis. It has 2 components: the **Setup** data and the **Motion** program and an associated axis number: an integer value between 1 and 255. An application may be used either to describe:

1. One axis in a multiple-axis system
2. An alternate configuration (set of parameters) for the same axis.


In the first case, each application has a different axis number corresponding to the axis ID of the drives/motors from the network. All data exchanges are done with the drive/motor having the same address as the selected application. In the second case, all the applications have the same axis number.

The setup component contains all the information needed to configure and parameterize a Technosoft drive. This information is preserved in the drive/motor EEPROM in the *setup table*. The setup table is copied at power-on into the RAM memory of the drive/motor and is used during runtime.


The motion component contains the motion sequences to do. These are described via a TML (Technosoft Motion Language) program, which is executed by the drives/motors built-in motion controller.

### 5.2.3.1 Create a new project

EasyMotion Studio starts with an empty window from where you can create a new project or open a previously created one.




When you start a new project, EasyMotion Studio automatically creates a first application. Additional applications can be added later. You can duplicate an application or insert one defined in another project.




Press **New** button to open the “New Project” dialogue. Set the axis number for your first application equal with your drive/motor axis ID. The initial value proposed is

255 which is the default axis ID of the drives having all the axis ID switches OFF (see 4.3 Changing the drive Axis ID). Press **New** button and select your drive type. Depending on the product chosen, the selection may continue with the motor technology (for example: 2 phase Stepper – closed loop) and the type of feedback device (Incremental encoder).



Click on your selection. EasyMotion Studio opens the Project window where on the left side you can see the structure of a project. At beginning both the new project and its first application are named “Untitled”. The application has 2 components: **S** Setup and **M** Motion (program).





### 5.2.3.2 Step 2 Establish communication

If you have a drive/motor connected with your PC, now its time to check the communication. Use menu command **Communication | Setup** to check/change your PC communication settings. Press the **Help** button of the dialogue opened. Here you can find detailed information about how to setup your drive/motor and the connections. Power on the drive, then close the Communication | Setup dialogue with OK. If the communication is established, EasyMotion Studio displays in the status bar (the bottom line) the text “**Online**” plus the axis ID of your drive/motor and its firmware version. Otherwise the text displayed is “**Offline**” and a communication error message tells you the error type. In this case, return to the Communication | Setup dialogue, press the Help button and check troubleshoots.

**Remark:** When first started, EasyMotion Studio tries to communicate via RS-232 and COM1 with a drive having axis ID=255 (default communication settings). If your drive is powered with all the DIP switches OFF and it is connected to your PC port COM1 via an RS-232 cable, the communication shall establish automatically.

### 5.2.3.3 Setup drive/motor

In the project window left side, select “S Setup”, to access the setup data for your application.



Press **View/Modify** button. This opens 2 setup dialogues: for **Motor Setup** and for **Drive Setup** (same like on EasySetUp) through which you can configure and parameterize a Technosoft drive. In the **Motor setup** dialogue you can introduce the data of your motor and the associated sensors. Data introduction is accompanied by a series of tests having as goal to check the connections to the drive and/or to determine or validate a part of the motor and sensors parameters. In the **Drive setup** dialogue you can configure and parameterize the drive for your application. In each dialogue you will find a **Guideline Assistant**, which will guide you through the whole process of introducing and/or checking your data.




Press the **Download to Drive/Motor** button to download your setup data in the drive/motor EEPROM memory in the *setup table*. From now on, at each power-on, the setup data is copied into the drive/motor RAM memory which is used during runtime. It is also possible to save the setup data on your PC and use it in other applications. Note that you can upload the complete setup data from a drive/motor.

To summarize, you can define or change the setup data of an application in the following ways:

- create a new setup data by going through the motor and drive dialogues
- use setup data previously saved in the PC
- upload setup data from a drive/motor EEPROM memory

#### 5.2.3.4 Program motion

In the project window left side, select “**M Motion**”, for motion programming. This automatically activates the **Motion Wizard**.





---

The Motion Wizard offers you the possibility to program all the motion sequences using high level graphical dialogues which automatically generate the corresponding TML instructions. Therefore with Motion Wizard you can develop motion programs using almost all the TML instructions without needing to learn them. A TML program includes a main section, followed by the subroutines used: functions, interrupt service routines<sup>16</sup> and homing procedures<sup>1</sup>. The TML program may also include cam tables used for electronic camming applications<sup>17</sup>.

When activated, Motion Wizard adds a set of toolbar buttons in the project window just below the title. Each button opens a programming dialogue. When a programming dialogue is closed, the associated TML instructions are automatically generated. Note that, the TML instructions generated are not a simple text included in a file, but a motion object. Therefore with Motion Wizard you define your motion program as a collection of motion objects.

The major advantage of encapsulating programming instructions in motion objects is that you can very easily manipulate them. For example, you can:

- Save and reuse a complete motion program or parts of it in other applications
- Add, delete, move, copy, insert, enable or disable one or more motion objects
- Group several motion objects and work with bigger objects that perform more complex functions

As a starting point, push for example the leftmost Motion Wizard button – Trapezoidal profiles, and set a position or speed profile. Then press the **Run** button. At this point the following operations are done automatically:

- A TML program is created by inserting your motion objects into a predefined template
- The TML program is compiled and downloaded to the drive/motor
- The TML program execution is started

For learning how to send TML commands from your host/master, using one of the communication channels and protocols supported by the drives use menu command **Application | Binary Code Viewer...** Using this tool, you can get the exact contents of the messages to send and of those expected to be received as answers.

#### 5.2.3.5 Evaluate motion application performances

EasyMotion Studio includes a set of evaluation tools like the **Data Logger**, the **Control Panel** and the **Command Interpreter** which help you to quickly measure and analyze your motion application.

#### 5.2.4. Creating an Image File with the Setup Data and the TML Program

Once you have validated your application, you can create with the menu command **Application | Create EEPROM Programmer File** a software file (with extension **.sw**) which contains all the data to write in the EEPROM of your drive. This includes both the setup data and the motion

---

<sup>16</sup> The customization of the interrupt service routines and homing routines is available only for IPS110 CAN executions

<sup>17</sup> Optional for IPS110 CANopen execution

---

program. For details regarding the **.sw** file format and how it can be programmed into a drive, see paragraph 4.5

### 5.3. Combining CANopen /or other host with TML

Due to its embedded motion controller, an IPS110 offers many programming solutions that may simplify a lot the task of a CANopen master. This paragraph overviews a set of advanced programming features which arise when combining TML programming at drive level with CANopen master control. A detailed description of these advanced programming features is included in the **CANopen Programming (part no. P091.063.CANopen.UM.xxxx)** manual. All features presented below require usage of EasyMotion Studio as TML programming tool

**Remark:** *If you don't use the advanced features presented below you don't need EasyMotion Studio. In this case the IPS110 is treated like a standard CANopen drive, whose setup is done using EasySetUp.*

#### 5.3.1. Using TML Functions to Split Motion between Master and Drives

With Technosoft intelligent drives you can really distribute the intelligence between a CANopen master and the drives in complex multi-axis applications. Instead of trying to command each step of an axis movement, you can program the drives using TML to execute complex tasks and inform the master when these are done. Thus for each axis, the master task may be reduced at: calling TML functions (with possibility to abort their execution) stored in the drives EEPROM and waiting for a message, which confirms the finalization of the TML functions execution.

#### 5.3.2. Executing TML programs

The distributed control concept can go on step further. You may prepare and download into a drive a complete TML program including functions, homing procedures<sup>18</sup>, etc. The TML program execution can be started by simply writing a value in a dedicated object,

#### 5.3.3. Loading Automatically Cam Tables Defined in EasyMotion Studio

The IPS110 CAN executions offers others motion modes like<sup>19</sup>: electronic gearing, electronic camming, external modes with analogue or digital reference etc. When electronic camming is used, the cam tables can be loaded in the following ways:

- a) The master downloads the cam points into the drive active RAM memory after each power on;
- b) The cam points are stored in the drive EEPROM and the master commands their copy into the active RAM memory
- c) The cam points are stored in the drive EEPROM and during the drive initialization (transition to Ready to Switch ON status) are automatically copied from EEPROM to the active RAM

---

<sup>18</sup> The customization of the interrupt service routines and homing routines is available only for IPS110 CAN executions


<sup>19</sup> Optional for the IPS110 CANopen execution

For the last 2 options the cam table(s) are defined in EasyMotion Studio and are included in the information stored in the EEPROM together with the setup data and the TML programs/functions.

**Remark:** The cam tables are included in the .sw file generated with EasyMotion Studio. Therefore, the drives can check the cam presence in the drive EEPROM using the same procedure as for testing of the setup data.

#### 5.3.4. Customizing the Homing Procedures (for IPS110 CAN executions)

The IPS110 supports all homing modes defined in DSP-402 device profile. If needed, any of these homing modes can be customized. In order to do this you need to select the Homing Modes from your EasyMotion Studio application and in the right side to set as “User defined” one of the Homing procedures. Following this operation the selected procedure will occur under Homing Modes in a subtree, with the name *HomeX* where X is the number of the selected homing.



If you click on the *HomeX* procedure, on the right side you'll see the TML function implementing it. The homing routine can be customized according to your application needs. It's calling name and method remain unchanged.

#### 5.3.5. Customizing the Drive Reaction to Fault Conditions (for IPS110 CAN executions)

Similarly to the homing modes, the default service routines for the TML interrupts can be customized according to your application needs. However, as most of these routines handle the drive reaction to fault conditions, it is mandatory to keep the existent functionality while adding your application needs, in order to preserve the correct protection level of the drive. The procedure for modifying the TML interrupts is similar with that for the homing modes.

---

## 5.4. Using Motion Libraries for PC-based Systems

A **TML Library for PC** is a collection of high-level functions allowing you to control from a PC a network of Technosoft intelligent drives. It is an ideal tool for quick implementation on PCs of motion control applications with Technosoft products.

With the TML Motion Library functions you can: communicate with a drive / motor via any of its supported channels (RS-232, CAN-bus, etc.), send motion commands, get automatically or on request information about drive / motor status, check and modify its setup parameters, read inputs and set outputs, etc.

The TML Motion Library can work under a **Windows** or **Linux** operating system. Implemented as a .dll/.so, it can be included in an application developed in **C/C++**, **Visual Basic**, **Delphi Pascal** or **Labview**.

Using a TML Motion Library for PC, you can focus on the main aspects of your application, while the motion programming part can be reduced to calling the appropriate functions and getting the confirmation when the task was done.

All Technosoft's TML Motion Libraries for PCs are provided with EasySetUp.

## 5.5. Using Motion Libraries for PLC-based Systems

A **TML Motion Library for PLC** is a collection of high-level functions and function blocks allowing you to control from a PLC the Technosoft intelligent drives. The motion control function blocks are developed in accordance with the IEC61131-3 standard and represent an ideal tool for quick implementation on PLCs of motion control applications with Technosoft products.

With the TML Motion Library functions you can: communicate with a drive/motor via any of its supported channels, send motion commands, get automatically or on request information about drive/motor status, check and modify its setup parameters, read inputs and set outputs, etc. Depending on the PLC type, the communication is done either directly with the CPU unit, or via a CANbus or RS-232 communication module.

Using a TML Motion Library for PLC, you can focus on the main aspects of your PLC application, while the motion programming part can be reduced to calling the appropriate functions and monitoring the confirmations that the task was done.

All these blocks have been designed using the guidelines described in the PLC standards, so they can be used on any development platform that is **IEC 61136 compliant**.

All Technosoft's TML Motion Libraries for PLC are provided with EasySetUp.

---

## 6. Scaling Factors

Technosoft drives work with parameters and variables represented in the drive internal units (IU). These correspond to various signal types: position, speed, current, voltage, etc. Each type of signal has its own internal representation in IU and a specific scaling factor. This chapter presents the drive internal units and their relation with the international standard units (SI).

In order to easily identify them, each internal unit has been named after its associated signal. For example the **position units** are the internal units for position, the **speed units** are the internal units for speed, etc.

### 6.1. Position units

#### 6.1.1. DC brushed motor with quadrature encoder on motor

The internal position units are encoder counts. The correspondence with the load **position in SI units**<sup>20</sup> is:

$$\text{Load\_Position[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{Tr}} \times \text{Motor\_Position[IU]}$$

where:

No\_encoder\_lines – is the encoder number of lines per revolution

#### 6.1.2. Stepper motor open-loop control. No feedback device

The internal position units are motor  $\mu$ steps. The correspondence with the load **position in SI units** is:

$$\text{Load\_Position[SI]} = \frac{2 \times \pi}{\text{No\_}\mu\text{steps} \times \text{No\_steps} \times \text{Tr}} \times \text{Motor\_Position[IU]}$$

where:

No\_steps – is the number of motor steps per revolution

No\_ $\mu$ steps – is the number of microsteps per step. You can read/change this value in the "Drive Setup" dialogue from EasySetUp.

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

---

<sup>20</sup>SI units for position are: [rad] for a rotary movement, [m] for a linear movement

---

### 6.1.3. Stepper motor closed-loop control. Incremental encoder on motor

The internal position units are motor encoder counts. The correspondence with the load **position in SI units**<sup>21</sup> is:

$$\text{Load\_Position[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{Tr}} \times \text{Motor\_Position[IU]}$$

where:

No\_encoder\_lines – is the motor encoder number of lines per revolution

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

### 6.1.4. Stepper motor open-loop control. Incremental encoder on load

The internal position units are load encoder counts. The transmission is rotary-to-rotary. The correspondence with the load position in SI units is:

$$\text{Load\_Position[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines}} \times \text{Load\_Position[IU]}$$

where:

No\_encoder\_lines – is the rotary encoder number of lines per revolution

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

## 6.2. Speed units

The internal speed units are internal position units / (slow loop sampling period) i.e. the position variation over one slow loop sampling period

### 6.2.1. DC brushed motor with quadrature encoder on motor

The internal speed units are encoder counts / (slow loop sampling period). The correspondence with the load **speed in SI units**<sup>22</sup> is:

$$\text{Load\_Speed[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{Tr} \times T} \times \text{Motor\_Speed[IU]}$$

where:

No\_encoder\_lines – is the encoder number of lines per revolution

---

<sup>21</sup> SI units for position are [rad] for a rotary movement, [m] for a linear movement

<sup>22</sup> SI units for speed are [rad/s] for a rotary movement, [m/s] for a linear movement

---

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

### 6.2.2. Stepper motor open-loop control. No feedback device

The internal speed units are motor  $\mu$ steps / (slow loop sampling period). The correspondence with the load **speed in SI units** is:

$$\text{Load\_Speed[SI]} = \frac{2 \times \pi}{\text{No\_}\mu\text{steps} \times \text{No\_steps} \times \text{Tr} \times \text{T}} \times \text{Motor\_Speed[IU]}$$

where:

No\_steps – is the number of motor steps per revolution

No\_ $\mu$ steps – is the number of microsteps per step. You can read/change this value in the “Drive Setup” dialogue from EasySetUp.

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

### 6.2.3. Stepper motor open-loop control. Incremental encoder on load

The internal speed units are load encoder counts / (slow loop sampling period). The transmission is rotary-to-rotary. The correspondence with the load speed in SI units is:

$$\text{Load\_Speed[rad/s]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{T}} \times \text{Load\_Speed[IU]}$$

where:

No\_encoder\_lines – is the rotary encoder number of lines per revolution

Tr – transmission ratio between the motor displacement in [rad] and load displacement in [rad] or [m]

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”.

### 6.2.4. Stepper motor closed-loop control. Incremental encoder on motor

The internal speed units are motor encoder counts / (slow loop sampling period). The correspondence with the load **speed in SI units**<sup>23</sup> is:

$$\text{Load\_Speed[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{Tr} \times \text{T}} \times \text{Motor\_Speed[IU]}$$

---

<sup>23</sup> SI units for speed are [rad/s] for a rotary movement , [m/s] for a linear movement

---

where:

No\_encoder\_lines – is the motor encoder number of lines per revolution

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”.

### 6.3. Acceleration units

The internal acceleration units are internal position units / (slow loop sampling period)<sup>2</sup> i.e. the speed variation over one slow loop sampling period.

#### 6.3.1. DC brushed motor with quadrature encoder on motor

The internal acceleration units are encoder counts / (slow loop sampling period)<sup>2</sup>. The correspondence with the load **acceleration in SI units**<sup>24</sup> is:

$$\text{Load\_Acceleration[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{Tr} \times T^2} \times \text{Motor\_Acceleration[IU]}$$

where:

No\_encoder\_lines – is the encoder number of lines per revolution

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

#### 6.3.2. Stepper motor open-loop control. No feedback device

The internal acceleration units are motor  $\mu$ steps / (slow loop sampling period)<sup>2</sup>. The correspondence with the load **acceleration in SI units**<sup>25</sup> is:

$$\text{Load\_Acceleration[SI]} = \frac{2 \times \pi}{\text{No\_}\mu\text{steps} \times \text{No\_steps} \times \text{Tr} \times T^2} \times \text{Motor\_Acceleration[IU]}$$

where:

No\_steps – is the number of motor steps per revolution

No\_ $\mu$ steps – is the number of microsteps per step. You can read/change this value in the “Drive Setup” dialogue from EasySetUp.

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

---

<sup>24</sup> SI units for acceleration are [rad/s<sup>2</sup>] for a rotary movement, [m/s<sup>2</sup>] for a linear movement

<sup>25</sup> SI units for acceleration are [rad/s<sup>2</sup>] for rotary movement, [m/s<sup>2</sup>] for linear movement



---

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

### 6.3.3. Stepper motor open-loop control. Incremental encoder on load

The internal acceleration units are load encoder counts / (slow loop sampling period)<sup>2</sup>. The correspondence with the load acceleration in SI units is:

For rotary-to-rotary transmission:

$$\text{Load\_Acceleration[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times T^2} \times \text{Load\_Acceleration[IU]}$$

For rotary-to-linear transmission:

$$\text{Load\_Acceleration[m/s}^2] = \frac{\text{Encoder\_accuracy}}{T^2} \times \text{Load\_Acceleration[IU]}$$

where:

No\_encoder\_lines – is the rotary encoder number of lines per revolution

Encoder\_accuracy – is the linear encoder accuracy i.e. distance in [m] between 2 pulses

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”.

### 6.3.4. Stepper motor closed-loop control. Incremental encoder on motor

The internal acceleration units are motor encoder counts / (slow loop sampling period)<sup>2</sup>. The transmission is rotary-to-rotary. The correspondence with the load **acceleration in SI units**<sup>26</sup> is:

$$\text{Load\_Acceleration[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{Tr} \times T^2} \times \text{Motor\_Acceleration[IU]}$$

where:

No\_encoder\_lines – is the motor encoder number of lines per revolution

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

---

<sup>26</sup> SI units for acceleration are [rad/s<sup>2</sup>] for rotary movement, [m/s<sup>2</sup>] for linear movement

---

## 6.4. Jerk units

The internal jerk units are internal position units / (slow loop sampling period)<sup>3</sup> i.e. the acceleration variation over one slow loop sampling period.

### 6.4.1. DC brushed motor with quadrature encoder on motor

The internal jerk units are encoder counts / (slow loop sampling period)<sup>3</sup>. The correspondence with the load **jerk in SI units**<sup>27</sup> is:

$$\text{Load\_Jerk[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{Tr} \times T^3} \times \text{Motor\_Jerk[IU]}$$

where:

No\_encoder\_lines – is the encoder number of lines per revolution

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

### 6.4.2. Stepper motor open-loop control. No feedback device

The internal jerk units are motor  $\mu$ steps / (slow loop sampling period)<sup>3</sup>. The correspondence with the load **jerk in SI units** is:

$$\text{Load\_Jerk[SI]} = \frac{2 \times \pi}{\text{No\_}\mu\text{steps} \times \text{No\_steps} \times \text{Tr} \times T^3} \times \text{Motor\_Jerk[IU]}$$

where:

No\_steps – is the number of motor steps per revolution

No\_μsteps – is the number of microsteps per step. You can read/change this value in the “Drive Setup” dialogue from EasySetUp.

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

---

<sup>27</sup> SI units for jerk are [rad/s<sup>3</sup>] for a rotary movement, [m/s<sup>3</sup>] for a linear movement

---

### 6.4.3. Stepper motor open-loop control. Incremental encoder on load

The internal jerk units are load encoder counts / (slow loop sampling period)<sup>3</sup>. The transmission is rotary-to-rotary. The correspondence with the load jerk in SI units is:

$$\text{Load\_Jerk[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times T^3} \times \text{Load\_Jerk[IU]}$$

where:

No\_encoder\_lines – is the rotary encoder number of lines per revolution

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”.

### 6.4.4. Stepper motor closed-loop control. Incremental encoder on motor

The internal jerk units are motor encoder counts / (slow loop sampling period)<sup>3</sup>. The correspondence with the load jerk in SI units is:

$$\text{Load\_Jerk[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times \text{Tr} \times T^3} \times \text{Motor\_Jerk[IU]}$$

where:

No\_encoder\_lines – is the motor encoder number of lines per revolution

Tr – transmission ratio between the motor displacement in SI units and load displacement in SI units

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”.

## 6.5. Current units

The internal current units refer to the motor phase currents. The correspondence with the motor currents in [A] is:

$$\text{Current[A]} = \frac{2 \times I_{\text{peak}}}{65520} \times \text{Current[IU]}$$

where I<sub>peak</sub> – is the drive peak current expressed in [A]. You can read this value in the “Drive Info” dialogue, which can be opened from the “Drive Setup”.

## 6.6. Voltage command units

The internal voltage command units refer to the voltages applied on the motor. The significance of the voltage commands as well as the scaling factors, depend on the motor type and control method used.

---

In case of **brushless motors** driven in **sinusoidal** mode, a field oriented vector control is performed. The voltage command is the amplitude of the sinusoidal phase voltages. In this case, the correspondence with the motor phase voltages in SI units i.e. [V] is:

$$\text{Voltage command[V]} = \frac{1.1 \times V_{dc}}{65534} \times \text{Voltage command[IU]}$$

where  $V_{dc}$  – is the drive power supply voltage expressed in [V].

In case of **brushless** motors driven in **trapezoidal** mode, the voltage command is the voltage to apply between 2 of the motor phases, according with Hall signals values. In this case, the correspondence with the voltage applied in SI units i.e. [V] is:

$$\text{Voltage command[V]} = \frac{V_{dc}}{32767} \times \text{Voltage command[IU]}$$

This correspondence is also available for **DC brushed** motors which have the voltage command internal units as the brushless motors driven in trapezoidal mode.

## 6.7. Voltage measurement units

The internal voltage measurement units refer to the drive  $V_{MOT}$  supply voltage. The correspondence with the supply voltage in [V] is:

$$\text{Voltage\_measured[V]} = \frac{V_{dcMaxMeasurable}}{65520} \times \text{Voltage\_measured[IU]}$$

where  $V_{dcMaxMeasurable}$  – is the maximum measurable DC voltage expressed in [V]. You can read this value in the “Drive Info” dialogue, which can be opened from the “Drive Setup”.

**Remark:** the voltage measurement units occur in the scaling of the over voltage and under voltage protections and the supply voltage measurement

## 6.8. Time units

The internal time units are expressed in slow loop sampling periods. The correspondence with the time in [s] is:

$$\text{Time[s]} = T \times \text{Time[IU]}$$

where  $T$  – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”. For example, if  $T = 1\text{ms}$ , one second = 1000 IU.

## 6.9. Master position units

When the master position is sent via a communication channel or via pulse & direction signals, the master position units depend on the type of position sensor present on the master axis.

When the master position is an encoder the correspondence with the international standard (SI) units is:

---


$$\text{Master\_position[rad]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines}} \times \text{Master\_position[IU]}$$

where:

No\_encoder\_lines – is the master number of encoder lines per revolution

## 6.10. Master speed units

The master speed is computed in internal units (IU) as master position units / slow loop sampling period i.e. the master position variation over one position/speed loop sampling period.

When the master position is an encoder, the correspondence with the international standard (SI) units is:

$$\text{Master\_speed[rad/s]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times T} \times \text{Master\_speed[IU]}$$

where:

No\_encoder\_lines – is the master number of encoder lines per revolution

T – is the slave slow loop sampling period, expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”.

## 6.11. Motor position units

### 6.11.1. DC brushed motor with quadrature encoder on motor

The internal motor position units are encoder counts. The correspondence with the motor **position in SI units**<sup>28</sup> is:

$$\text{Motor\_Position[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines}} \times \text{Motor\_Position[IU]}$$

where:

No\_encoder\_lines – is the rotary encoder number of lines per revolution

### 6.11.2. Stepper motor open-loop control. No feedback device

The internal motor position units are motor µsteps. The correspondence with the motor **position in SI units** is:

---

<sup>28</sup>SI units for motor position are: [rad] for a rotary motor, [m] for a linear motor

---


$$\text{Motor\_Position[SI]} = \frac{2 \times \pi}{\text{No\_}\mu\text{steps} \times \text{No\_steps}} \times \text{Motor\_Position[IU]}$$

where:

No\_steps – is the number of motor steps per revolution

No\_μsteps – is the number of microsteps per step. You can read/change this value in the “Drive Setup” dialogue from EasySetUp.

### 6.11.3. Stepper motor open-loop control. Incremental encoder on load

In open-loop control configurations with incremental encoder on load, the motor position is not computed.

### 6.11.4. Stepper motor closed-loop control. Incremental encoder on motor

The internal motor position units are motor encoder counts. The correspondence with the motor position in SI units is:

$$\text{Motor\_Position[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines}} \times \text{Motor\_Position[IU]}$$

where:

No\_encoder\_lines – is the motor encoder number of lines per revolution

## 6.12. Motor speed units

### 6.12.1. DC brushed motor with quadrature encoder on motor

For linear motors: 
$$\text{Motor\_Speed[SI]} = \frac{\text{Encoder\_accuracy}}{T} \times \text{Motor\_Speed[IU]}$$

where:

No\_encoder\_lines – is the rotary encoder number of lines per revolution

Encoder\_accuracy – is the linear encoder accuracy i.e. distance in [m] between 2 pulses

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

---

### 6.12.2. Stepper motor open-loop control. No feedback device or incremental encoder on load

The internal motor speed units are motor  $\mu$ steps / (slow loop sampling period). The correspondence with the motor **speed in SI units**<sup>29</sup> is:

$$\text{Motor\_Speed[SI]} = \frac{2 \times \pi}{\text{No\_}\mu\text{steps} \times \text{No\_steps} \times T} \times \text{Motor\_Speed[IU]}$$

where:

No\_steps – is the number of motor steps per revolution

No\_ $\mu$ steps – is the number of microsteps per step. You can read/change this value in the “Drive Setup” dialogue from EasySetUp.

T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”

### 6.12.3. Stepper motor closed-loop control. Incremental encoder on motor

The internal motor speed units are motor encoder counts / (slow loop sampling period). The correspondence with the load speed in SI units is:

$$\text{Motor\_Speed[SI]} = \frac{2 \times \pi}{4 \times \text{No\_encoder\_lines} \times T} \times \text{Motor\_Speed[IU]}$$

where:

No\_encoder\_lines – is the motor encoder number of lines per revolution


T – is the slow loop sampling period expressed in [s]. You can read this value in the “Advanced” dialogue, which can be opened from the “Drive Setup”.

---

<sup>29</sup> SI units for motor speed are [rad/s] for a rotary motor, [m/s] for a linear motor

## 7. Memory Map

The drive has 2 types of memory: a 1.5K×16 SRAM (internal) memory and an 8K×16 serial E<sup>2</sup>ROM (external) memory.



**Figure 7.1. IPS110 Memory Map**

The SRAM memory is mapped both in the program space (from 8270h to 87FFh) and in the data space (from A70h to FFFh). The data memory can be used for real-time data acquisition and to temporarily save variables during a TML program execution. The program space can be used to download and execute TML programs. It is the user's choice to decide how to split the 1.5-K SRAM into data and program memory.

The E<sup>2</sup>ROM is seen as 8K×16 program memory mapped in the address range 4000h to 5FBEh. It offers the possibility to keep TML programs in a Non-volatile memory. Read and write accesses to the E<sup>2</sup>ROM locations, as well as TML programs downloading and execution, are done from the



---

user's point of view similarly to those in the SRAM program memory. The E<sup>2</sup>ROM SPI serial access is completely transparent to the user.

***Remark:*** *EasyMotion Studio handles automatically the memory allocation for each motion application. The memory map can be accessed and modified from the main folder of each application*

---

*This page is empty*



T E C H N O S O F T

