

Wireless D.I.Y. Alarm Kit

General


The Wireless DIY kit, is a pre-programmed, ready-to-use alarm system. Once the system is armed, via the remote control, the system will indicate which of the motion detectors have been triggered by a series of beeps. (see “*general operation*” section)

The system has an optional siren output should you wish to connect an external siren. This output will be activated if the panic button is pressed or a detector is triggered and the system is armed.

The motion detectors are equipped with a tamper and battery low, detection sensitivity adjustment and pet immunity (see “*advanced options*” for programming)

Please note that all detectors and remote controls must be on 433Mhz

Kit contents



Control Unit (1)



Wireless Motion detectors (2)



Remote control (1)




Power Supply (1)




Doorguard (optional)

Getting Started



1
connect power supply to mains power and apply power to control unit



2
turn on the detectors by pulling the tag out








3
mount detector with mounting bracket (see below)



4
arm system by pressing the BLUE button

Mounting of detector

The detector and control unit have a range of up to 200m in open space, this will be reduced indoors depending on the material of obstructions such as walls, floors, doors etc.



General operation

The remote control has 2 buttons, a red button and a blue button.

RED BUTTON (panic):

If you have a siren connected to the control unit, the RED button (panic button) will activate the siren for 3 minutes and sound the onboard buzzer (until disarmed - see below)

BLUE BUTTON (arm/disarm) :

The blue button is used to Arm and Disarm the system.

When the system is **armed**, 1 beep will be heard and the red LED light will turn on.

When the system is **disarmed**, 2 beeps will be heard and the red LED light will turn off.

ARMED:

If a detector is triggered and the system is in the armed state, the siren output will activate for 3 minutes and the onboard buzzer will indicate which detector was triggered as follows:

The buzzer will sound continuously for one long beep, followed by short beeps indicating which detector has been triggered (until disarmed)



DISARMED:

Battery low indication

Each detector has a built-in battery low detection.


Triggering a detector that has a low battery will cause the onboard buzzer of the control unit to sound for one long beep. See the “*replacing batteries*” section for instructions how to replace batteries. See “*advanced options*” for disabling the battery low option.

Tamper

Each detector has a tamper switch to detect when the unit is opened.

See the “*advanced options*” section to enable this option.

If a tamper occurs, the onboard buzzer will continuously beep indicating which detector was tampered with. To silence the unit press the blue button on the remote control



MULTIPLE DETECTORS

A total of 20 detectors per alarm sound may be added.

DEFAULTING THE SYSTEM


Short out the two round holes below detector button 3 on the control unit until the LEDs start to flash. This may be accomplished by using a pair of tweezers. This will remove all detectors and remote control stored on the unit.

ALL DETECTORS AND REMOTE CONTROLS WILL HAVE TO BE RE-LEARNED


PLEASE NOTE:

By default if the motion detector is triggered, it requires at least 3 minutes of **no movement** to re-trigger. This is done in order to get the maximum life span out of the batteries


Detector number buttons on control unit




REPLACING BATTERIES




Loosen bottom screw




Open cover




Unclip batteries pushing the battery clip outwards




Replace both batteries ensuring each is 'clicked' into place



Press button to test.
RED LED will illuminate




Close cover




Tighten bottom screw


Adding additional detectors




Loosen bottom screw



Open detector cover





Open control unit cover




Hold down the associated detector number button on the control unit until the onboard LED lights up.

Detector number buttons



Press button on detector to learn it to the control unit. Successful learning is indicated by the LED on the control unit turning off and a single beep is heard.


Ensure that bit number 4 of the dipswitch is set to ON.



Close detector cover




Tighten bottom screw




Close control unit cover

Adding additional remotes



Open control unit cover




Hold down button 1 and button 2 until both LEDs turn on




Press blue button on remote control.

Successful learning is indicated by both LEDs on the control unit turning off and a single beep.




Close control unit cover


Adding wireless doorguards




Open control unit




Open door guard



Hold down detector number button until LED on control unit illuminates



Press button 2. A beep will be heard on the control unit



Close Control unit and Doorguard

ADVANCED OPTIONS

To set advanced options on motion detector it is required to open the detector. Follow steps 1 & 2 on the previous page to open the detector

Enabling/Disabling tamper detection

Enable: Dipswitch 8 UP
Disable: Dipswitch 8 DOWN

Enabling/Disabling battery low detection

Enable: Dipswitch 7 UP
Disable: Dipswitch 7 DOWN

Changing sensitivity


High sensitivity: JP1 = IN
Low sensitivity: JP1 = OUT

Pet Immunity up to 15kg


Enable: JP2 = IN
Disable: JP2 = OUT



Loosen bottom screw



Open detector cover




Adding a soundbomb to the control unit


A siren may be added to the system should it be required. The siren will activate for 3 minutes if either the panic is pressed or a detector is activated and the system was armed.

To do this requires to open the control unit and locate the power and soundbomb connector in the top left corner of the board.

Connect the soundbomb as indicated
(NB 1Amp Max)



Motion detector lenses (optional)



Technical specifications

	Control Unit	Motion detector	Remote control
Supply voltage	12V	6V or 9V	12V
Standby current	17mA	6uA	off
Transmitting current	n/a	20mA	20mA
Output relay rating	12V / 1A	n/a	n/a

Troubleshooting

Problem: The system does not arm or disarm, no beeps are heard, external LED does not change.

Solution: Make sure power is connected. To confirm this, the external LED will either solidly on or flash fast every 2seconds.

Re-learn the remote control to the system (see page 7)

Problem: The system does not sound when a detector is triggered

Solution: Ensure that power is connected and the system is in the armed state (external LED is on)
Ensure that the unit has been learned into the control unit (page 6)

Ensure that the control unit and detector are less than 100m apart (This may be as low as 20m depending on the material of the obstacles between them)

