


Mitsubishi Programmable Controller

MELSEC **Q** series

MELSEC-Q Current Transformer Input Module User's Manual

-Q68CT



● SAFETY PRECAUTIONS ●

(Read these precautions before using this product.)

Before using this product, please read this manual and the relevant manuals carefully and pay full attention to safety to handle the product correctly.

The precautions given in this manual are concerned with this product only. For the safety precautions of the programmable controller system, refer to the user's manual for the CPU module used.

In this manual, the safety precautions are classified into two levels: "⚠ WARNING" and "⚠ CAUTION".



Indicates that incorrect handling may cause hazardous conditions, resulting in death or severe injury.



Indicates that incorrect handling may cause hazardous conditions, resulting in minor or moderate injury or property damage.

Under some circumstances, failure to observe the precautions given under "⚠ CAUTION" may lead to serious consequences.

Observe the precautions of both levels because they are important for personal and system safety.

Make sure that the end users read this manual and then keep the manual in a safe place for future reference.

[Design Precautions]

⚠ WARNING

- Do not write any data to the "system area" and "write-protect area" of the buffer memory in the intelligent function module. Also, do not use any "use prohibited" signal as an output signal from the CPU module to the intelligent function module. Doing so may cause malfunction of the programmable controller system.

⚠ CAUTION

- Do not install the control lines or communication cables together with the main circuit lines or power cables. Failure to do so may result in malfunction due to noise.

[Installation Precautions]

CAUTION

- Use the programmable controller in an environment that meets the general specifications in the user's manual for the CPU module used. Failure to do so may result in electric shock, fire, malfunction, or damage to or deterioration of the product.
- To mount the module, while pressing the module mounting lever located in the lower part of the module, fully insert the module fixing projection(s) into the hole(s) in the base unit and press the module until it snaps into place. Incorrect interconnection may cause malfunction, failure, or drop of the module. When using the programmable controller in an environment of frequent vibrations, fix the module with a screw. Tighten the screws within the specified torque range. Undertightening can cause drop of the screw, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may result in damage to the product. A module can be replaced online (while power is on) on any MELSECNET/H remote I/O station or in the system where a CPU module supporting the online module change function is used. Note that there are restrictions on the modules that can be replaced online, and each module has its predetermined replacement procedure. For details, refer to the relevant chapter in this manual.
- Do not directly touch any conductive parts and electronic components of the module. Doing so can cause malfunction or failure of the module.

[Wiring Precautions]

WARNING

- After installation and wiring, attach the included terminal cover to the module before turning it on for operation. Failure to do so may result in electric shock.

CAUTION

- Individually ground the FG terminal of the programmable controller with a ground resistance of 100Ω or less. Failure to do so may result in electric shock or malfunction.
- Tighten the terminal screws within the specified torque range. Undertightening can cause short circuit, fire, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.
- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring. Do not remove the film during wiring. Remove it for heat dissipation before system operation.

[Startup and Maintenance Precautions]

WARNING

- Do not touch any terminal while power is on. Doing so will cause electric shock or malfunction.
- Shut off the external power supply (all phases) used in the system before cleaning the module or retightening the terminal screws or module fixing screws. Failure to do so may result in electric shock or cause the module to fail or malfunction. Undertightening can cause drop of the screw, short circuit, or malfunction. Overtightening can damage the screw and/or module, resulting in drop, short circuit, or malfunction.

CAUTION

- Do not disassemble or modify the modules.
Doing so may cause failure, malfunction, injury, or a fire.
- Shut off the external power supply (all phases) used in the system before mounting or removing the module. Failure to do so may cause the module to fail or malfunction. A module can be replaced online (while power is on) on any MELSECNET/H remote I/O station or in the system where a CPU module supporting the online module change function is used. Note that there are restrictions on the modules that can be replaced online, and each module has its predetermined replacement procedure. For details, refer to the relevant chapter in this manual.
- After the first use of the product, do not mount/remove the module to/from the base unit, and the terminal block to/from the module more than 50 times (IEC 61131-2 compliant) respectively.
Exceeding the limit of 50 times may cause malfunction.
- Before handling the module, touch a grounded metal object to discharge the static electricity from the human body. Failure to do so may cause the module to fail or malfunction.

[Disposal Precautions]

CAUTION

- When disposing of this product, treat it as industrial waste.

● CONDITIONS OF USE FOR THE PRODUCT ●

- (1) Mitsubishi programmable controller ("the PRODUCT") shall be used in conditions;
 - i) where any problem, fault or failure occurring in the PRODUCT, if any, shall not lead to any major or serious accident; and
 - ii) where the backup and fail-safe function are systematically or automatically provided outside of the PRODUCT for the case of any problem, fault or failure occurring in the PRODUCT.

- (2) The PRODUCT has been designed and manufactured for the purpose of being used in general industries.

MITSUBISHI SHALL HAVE NO RESPONSIBILITY OR LIABILITY (INCLUDING, BUT NOT LIMITED TO ANY AND ALL RESPONSIBILITY OR LIABILITY BASED ON CONTRACT, WARRANTY, TORT, PRODUCT LIABILITY) FOR ANY INJURY OR DEATH TO PERSONS OR LOSS OR DAMAGE TO PROPERTY CAUSED BY the PRODUCT THAT ARE OPERATED OR USED IN APPLICATION NOT INTENDED OR EXCLUDED BY INSTRUCTIONS, PRECAUTIONS, OR WARNING CONTAINED IN MITSUBISHI'S USER, INSTRUCTION AND/OR SAFETY MANUALS, TECHNICAL BULLETINS AND GUIDELINES FOR the PRODUCT.

("Prohibited Application")

Prohibited Applications include, but not limited to, the use of the PRODUCT in;

- Nuclear Power Plants and any other power plants operated by Power companies, and/or any other cases in which the public could be affected if any problem or fault occurs in the PRODUCT.
- Railway companies or Public service purposes, and/or any other cases in which establishment of a special quality assurance system is required by the Purchaser or End User.
- Aircraft or Aerospace, Medical applications, Train equipment, transport equipment such as Elevator and Escalator, Incineration and Fuel devices, Vehicles, Manned transportation, Equipment for Recreation and Amusement, and Safety devices, handling of Nuclear or Hazardous Materials or Chemicals, Mining and Drilling, and/or other applications where there is a significant risk of injury to the public or property.

Notwithstanding the above, restrictions Mitsubishi may in its sole discretion, authorize use of the PRODUCT in one or more of the Prohibited Applications, provided that the usage of the PRODUCT is limited only for the specific applications agreed to by Mitsubishi and provided further that no special quality assurance or fail-safe, redundant or other safety features which exceed the general specifications of the PRODUCTS are required. For details, please contact the Mitsubishi representative in your region.

INTRODUCTION

Thank you for purchasing the Mitsubishi MELSEC-Q series programmable controllers.

This manual describes the operating procedure, system configuration, parameter settings, functions, programming, and troubleshooting of the Q68CT current transformer input module (hereafter abbreviated as CT input module).

Before using this product, please read this manual and the relevant manuals carefully and develop familiarity with the functions and performance of the MELSEC-Q series programmable controller to handle the product correctly.

When applying the program examples introduced in this manual to an actual system, ensure the applicability and confirm that it will not cause system control problems.

■ Relevant module: Q68CT

Remark

- Unless otherwise specified, this manual describes the program examples in which the I/O numbers of X/Y00 to X/Y0F are assigned for a CT input module.
For I/O number assignment, refer to the following manuals.
 - 📖 QnUCPU User's Manual (Function Explanation, Program Fundamentals)
 - 📖 Qn(H)/QnPH/QnPRHCPU User's Manual (Function Explanation, Program Fundamentals)
- Operating procedures are explained using GX Works2. When using GX Developer, refer to the following.
 - When using GX Developer (👉 Page 251, Appendix 2)

COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES

(1) Method of ensuring compliance

To ensure that Mitsubishi programmable controllers maintain EMC and Low Voltage Directives when incorporated into other machinery or equipment, certain measures may be necessary. Please refer to one of the following manuals.

- QCPU User's Manual (Hardware Design, Maintenance and Inspection)
- Safety Guidelines

(This manual is included with the CPU module or base unit.)

The CE mark on the side of the programmable controller indicates compliance with EMC and Low Voltage Directives.

(2) Additional measures

No additional measures are necessary for the compliance of this product with EMC and Low Voltage Directives.

RELEVANT MANUALS

(1) CPU module user's manual

Manual name <manual number (model code)>	Description
QCPU User's Manual (Hardware Design, Maintenance and Inspection) <SH-080483ENG, 13JR73>	Specifications of the hardware (CPU modules, power supply modules, base units, extension cables, and memory cards), system maintenance and inspection, troubleshooting, and error codes
QnUCPU Users Manual (Function Explanation, Program Fundamentals) <SH-080807ENG, 13JZ27>	Functions, methods, and devices for programming
Qn(H)/QnPH/QnPRHCPU User's Manual (Function Explanation, Program Fundamentals) <SH-080808ENG, 13JZ28>	

(2) Programming manual

Manual name <manual number (model code)>	Description
MELSEC-Q/L Programming Manual (Common Instruction) <SH-080809ENG, 13JW10>	Detailed description and usage of instructions used in programs

(3) Operating manual

Manual name <manual number (model code)>	Description
GX Works2 Version1 Operating Manual (Common) <SH-080779ENG, 13JU63>	System configuration, parameter settings, and online operations (common to Simple project and Structured project) of GX Works2
GX Developer Version 8 Operating Manual <SH-080373E, 13JU41>	Operating methods of GX Developer, such as programming, printing, monitoring, and debugging

Memo

CONTENTS

SAFETY PRECAUTIONS	1
CONDITIONS OF USE FOR THE PRODUCT	4
INTRODUCTION	5
COMPLIANCE WITH EMC AND LOW VOLTAGE DIRECTIVES	5
RELEVANT MANUALS	6
MANUAL PAGE ORGANIZATION	12
TERM.	15
PACKING LIST	15
<hr/>	
CHAPTER 1 OVERVIEW	16
<hr/>	
1.1 Features	17
<hr/>	
CHAPTER 2 SYSTEM CONFIGURATION	19
<hr/>	
2.1 Applicable Systems	19
2.2 How to Check the Function Version and Serial Number	24
<hr/>	
CHAPTER 3 SPECIFICATIONS	26
<hr/>	
3.1 General Specifications	26
3.2 Performance Specifications	27
3.2.1 Performance specifications list	27
3.2.2 I/O conversion characteristics	29
3.2.3 Accuracy	31
3.2.4 Number of parameter settings	32
3.3 Function list	33
<hr/>	
CHAPTER 4 FUNCTIONS	35
<hr/>	
4.1 Processing Each Function	35
4.2 Input Range Setting	36
4.3 Conversion Enable/Disable Function	37
4.4 Sampling Cycle Switching Function	37
4.5 Digital Conversion Method	38
4.5.1 Operations of digital conversion methods	38
4.5.2 Setting procedures for digital conversion methods	43
4.6 Input Signal Error Detection Function	44
4.7 Peak Current Detection Function	46
4.8 Dropout Function	49
4.9 Scaling Function	50
4.10 Warning Output Function	53
4.11 Maximum Value/Minimum Value Hold Function	59
4.12 Logging Function	60
4.13 Set Value Backup Function	72
4.14 Default Setting Registration Function	73
4.15 Error History Function	74
4.16 Module Error Collection Function	77
4.17 Error Clear Function	78

CHAPTER 5 I/O SIGNALS ASSIGNED TO THE CPU MODULE	79
5.1 I/O Signal List	79
5.2 Details of I/O Signals	80
5.2.1 Input signal	80
5.2.2 Output signal	89
CHAPTER 6 BUFFER MEMORY	91
6.1 List of Buffer Memory Addresses	91
6.2 Details of Buffer Memory Addresses	106
CHAPTER 7 SETTINGS AND THE PROCEDURE BEFORE OPERATION	138
7.1 Handling Precautions	138
7.2 Settings and the Procedure Before Operation	139
7.3 Part Names	140
7.4 Wiring	142
7.4.1 Wiring precautions	142
7.4.2 External wiring	143
CHAPTER 8 VARIOUS SETTINGS	144
8.1 Adding a Module	144
8.2 Switch Setting	145
8.3 Parameter Setting	146
8.4 Auto Refresh	149
8.5 Offset/gain Setting	150
8.5.1 Setting from "Offset/Gain Setting" of GX Works2	150
8.5.2 Setting from a program	153
CHAPTER 9 PROGRAMMING	157
9.1 Programming Procedure	157
9.2 When Using the Module in a Standard System Configuration	158
9.2.1 Program example when using parameters of the intelligent function module	160
9.2.2 Program example when not using parameters of the intelligent function module	164
9.3 When Using the Module on the Remote I/O Network	167
9.3.1 Program example when using parameters of the intelligent function module	175
9.3.2 Program example when not using parameters of the intelligent function module	177
CHAPTER 10 ONLINE MODULE CHANGE	182
10.1 Precautions on Online Module Change	182
10.2 Conditions for Online Module Change	183
10.3 Online Module Change Operations	184
10.4 Online Module Change Procedure	185

10.5	When a Factory Default Range Is Used and Parameters Are Set Using the Configuration Function	187
10.6	When a Factory Default Range Is Used and Parameters Are Set Using a Sequence Program	193
10.7	When a User Range Is Used and Parameters Are Set Using the Configuration Function (with Another System)	200
10.8	When a User Range Is Used and Parameters Are Set Using a Sequence Program (with Another System)	206
10.9	When a User Range Is Used and Parameters Are Set Using the Configuration Function (without Another System)	213
10.10	When a User Range Is Used and Parameters Are Set Using a Sequence Program (without Another System)	220
10.11	Range Reference Table	227

CHAPTER 11 TROUBLESHOOTING	228
-----------------------------------	------------

11.1	Error Code List	228
11.2	Alarm Code List	235
11.3	Troubleshooting	236
11.3.1	When the RUN LED flashes or turns off	236
11.3.2	When the ERR. LED turns on or flashes	236
11.3.3	When the ALM LED turns on or flashes.	237
11.3.4	When a digital output value cannot be read.	237
11.3.5	When Conversion completed flag does not turn on in the normal mode	238
11.4	Checking the CT Input Module Status on GX Works2 System Monitor	239

APPENDICES	240
-------------------	------------

Appendix 1	Dedicated Instruction	240
Appendix 1.1	G(P).OFFGAN.	241
Appendix 1.2	G(P).OGLOAD	243
Appendix 1.3	G(P).OGSTOR	247
Appendix 2	When Using GX Developer	251
Appendix 2.1	Operation of GX Developer	251
Appendix 3	Online Module Change Procedure (When Using GX Developer)	253
Appendix 3.1	Precautions on online module change	253
Appendix 3.2	Conditions for online module change	254
Appendix 3.3	Online module change operations	255
Appendix 3.4	Online module change procedure	256
Appendix 3.5	When a factory default range is used and initial settings are configured using a sequence program.	257
Appendix 3.6	When a user range is used and initial settings are configured using a sequence program (with another system)	263
Appendix 3.7	When a user range is used and initial settings are configured using a sequence program (without another system)	269
Appendix 4	External Dimensions	275

INDEX	276
-------	-----

REVISIONS	278
WARRANTY	279

MANUAL PAGE ORGANIZATION

In this manual, pages are organized and the symbols are used as shown below.

The following illustration is for explanation purpose only, and should not be referred to as an actual documentation.

"" is used for window names and items.

1. shows operating procedures.

shows mouse operations.*1

[] is used for items in the menu bar and the project window.

shows setting or operating examples.

shows reference manuals.

shows reference pages.

shows notes that require attention.

shows useful information.

CHAPTER 7 VARIOUS SETTINGS

7.1.1 Setting method

(1) Setting parameters

(a) Operating procedure

1. Open the "PLC Parameter" dialog box.
Project window => [Parameter] => [PLC parameter]

2. Select the "I/O Assignment" tab.

Item	Description	Reference
Type	Select the type of the connected module.	Page 74, Section 7.1.2
Model Name	Select the model name of the connected module.	Page 74, Section 7.1.3
Points	Set the number of points assigned to each slot.	Page 74, Section 7.1.4
Start XY	Specify a start I/O number for each slot.	Page 74, Section 7.1.5
[Switch Setting]	Configure the switch setting of the built-in I/O or intelligent function modules.	Page 74, Section 7.1.6
[Detailed Setting]	Set the following: - Error Time Output Mode - PLC Operation Mode at HW Error - I/O Response Time	Page 75, Section 7.1.7

Setting "Start XY" enables modification on the start I/O numbers assigned to connected modules.

When "1000" is specified in "Start XY" to the slot where a 16-point module is connected, the assignment range of an input module is changed to X1000 to X100F.

For details, refer to the following
SELSEC-L CPU Module User's Manual (Function Explanation, Program Fundamentals)

Set the type of the connected module in "Type". Setting a different type results in "SPLIMIT LAY ERR" (see the intelligent function module, the I/O points must also be the same in addition to the I/O assignment setting. Page 30, Section 4.2.2)

When an intelligent module is connected, I/O assignment can be omitted by selecting connected modules from "Intelligent Function Module" in the Project window.

73

*1 The mouse operation example is provided below.

Menu bar

[Online] => [Write to PLC...]
Select [Online] on the menu bar, and then select [Write to PLC...].

A window selected in the view selection area is displayed.

Project window => [Parameter]
=> [PLC Parameter]
Select [Project] from the view selection area to open the Project window.
In the Project window, expand [Parameter] and select [PLC Parameter].

View selection area

Pages describing instructions are organized as shown below.

The following illustration is for explanation purpose only, and should not be referred to as an actual documentation.

Instruction name

6.4.2 Disconnecting a connection (SP.SOCCLDSE)

Execution condition of the instruction

Structure of the instruction in the ladder mode

Setting side
User : Device value is set by the user.
System: Device value is set by the CPU module.

Setting data

Setting data	Internal device		R, ZR	JCH		UD/GD	Zn	Constant K, H	Others
	Bit	Word		Bit	Word				
Ⓜ	—	○	○	—	—	—	—	○	—
Ⓜ	—	△ ¹	△ ¹	—	—	—	—	—	—
Ⓜ	△ ¹	—	△ ¹	—	—	—	—	—	—

*1 File registers set for each local device or program cannot be used.

6

Descriptions of setting data and data type

Setting data	Description	Set by	Data type
UD	Dummy	—	Character string
Ⓜ	Connection number (Setting range: 1 to 16)	User	BIN 16-bit
Ⓜ	Start number of the device from which control data are stored	—	Device name
Ⓜ	Start number of the device which turns on for one scan upon completion of the instruction Ⓜ+1 also turns on when failed.	System	Bit

Descriptions of control data (if any)

Device	Item	Description	Setting range	Set by
Ⓜ+0	System area	—	—	—
Ⓜ+1	Completion status	Completion status is stored 0000: Completed Other than 0000: Failed (Error code)	—	System

63

Detailed descriptions of the instruction

(3) Function

This instruction closes a connection specified in Ⓜ. (Disconnection of a connection)
The result of the SP.SOCCLDSE instruction can be checked with the completion device, Ⓜ+0 and Ⓜ+1.

- Completion device Ⓜ+0
Turns on in the END processing of a scan after completion of the SP.SOCCLDSE instruction, and turns off in the next END processing.
- Completion device Ⓜ+1
Turns on or off according to the result of the SP.SOCCLDSE instruction.

State	Description
When completed	Remains off.
When failed	Turns on in the END processing of a scan after completion of the SP.SOCCLDSE instruction, and turns off in the next END processing.

Conditions for the error and error codes
For the errors not described in this manual, refer to the following.
QCPU User's Manual (Hardware Design, Maintenance and Inspection)

(4) Error

A detection of an operation error turns on the Error flag (SM0) and a corresponding error code is stored in SD0 when:

- The connection number specified for Ⓜ is other than 1 to 16. (Error code: 4101)
- The device numbers specified for Ⓜ and Ⓜ+1 exceed the device point range. (Error code: 4101)
- An invalid device is specified. (Error code: 4004)

Simple program example(s) and descriptions of the devices used

(5) Program example

When M2000 is turned on or when the connected device disconnects connection No. 1, connection No. 1 is disconnected by the following program:

Device number	Application
SD1262	Open completion signal
SD1264	Open request signal
D200	SP.SOCCLDSE instruction control data
M200	SP.SOCCLDSE instruction completion device

```

• Program
SD1262 SP.SOCCLDSE [PULSE] M161 3 Processing for disconnection of
M200 SD1264 M200 SP.SOCCLDSE "1" K1 D200 M200 1 Connection No. 1 close
M161 [SET] M210 3 Setting SP.SOCCLDSE
M200 [SET] M202 3 setting flag
M201 [SET] M202 3 Normal completion
M202 [SET] M202 3 Error completion
M203 [SET] M210 3 Resetting SP.SOCCLDSE
[END] M210 3 setting flag
[END]
  
```

- Instructions can be executed under the following conditions.

Execution condition	Any time	During on	On the rising edge	During off	On the falling edge
Symbol	No symbol				

- The following devices can be used.

Setting data	Internal device (system, user)		File register	Link direct device J□\□		Intelligent function module device U□\G□	Index register Zn	Constant *3	Others *3
	Bit	Word		Bit	Word				
Applicable device *1	X, Y, M, L, SM, F, B, SB, FX, FY *2	T, ST, C, D, W, SD, SW, FD, @□	R, ZR	-	-	U□\G□	Z	K, H, E, \$	P, I, J, U, D, X, DY, N, BL, TR, BLIS, V

*1 For details on each device, refer to the following.

 QnUCPU User's Manual (Function Explanation, Program Fundamentals)

 Qn(H)/QnPH/QnPRHCPU User's Manual (Function Explanation, Program Fundamentals)

*2 FX and FY can be used for bit data only, and FD for word data only.

*3 In the "Constant" and "Others" columns, a device(s) that can be set for each instruction is shown.

- The following data types can be used.

Data type	Description
Bit	Bit data or the start number of bit data
BIN 16-bit	16-bit binary data or the start number of word device
BIN 32-bit	32-bit binary data or the start number of double-word device
BCD 4-digit	Four-digit binary-coded decimal data
BCD 8-digit	Eight-digit binary-coded decimal data
Real number	Floating-point data
Character string	Character string data
Device name	Device name data

TERM

Unless otherwise specified, this manual uses the following terms.

Term	Description
CT input module	The abbreviation for the Q68CT current transformer input module
CT	Another term for a current transformer
QCPU	Another term for the MELSEC-Q series CPU module
Process CPU	A generic term for the Q02PHCPU, Q06PHCPU, Q12PHCPU, and Q25PHCPU
Redundant CPU	A generic term for the Q12PRHCPU and Q25PRHCPU
GX Works2	Product name of the software package for the MELSEC programmable controllers
GX Developer	
Programming tool	Generic term for GX Works2 and GX Developer
CT input value	An alternating current value measured using a CT. This manual describes a primary current value as a CT input value.
Factory default range	A generic term for factory-default input ranges (0 to 5AAC, 0 to 50AAC, 0 to 100AAC, 0 to 200AAC, 0 to 400AAC, and 0 to 600AAC)
User range	A generic term for user-defined input ranges (0 to 5AAC, 0 to 50AAC, 0 to 100AAC, 0 to 200AAC, 0 to 400AAC, and 0 to 600AAC)
Buffer memory	The memory of an intelligent function module used to store data (such as setting values and monitored values) for communication with a CPU module.

PACKING LIST

The product package contains the following.

Model	Product	Quantity
Q68CT	Q68CT current transformer input module	1
-	Before Using the Product (BCN-P5901)	1

CHAPTER 1 OVERVIEW

(1) CT

A CT means "Current Transformer" and is a current sensor which is necessary to measure an alternating current.


A CT is used for the following purposes widely.

- To control a load or monitor an operation of equipment and devices
- To control or monitor of an electric power system

When a high current is measured in an electric power receiving facility, measurement devices cannot be wired directly. A CT is used for such a situation.

(a) Mechanism of a CT

A CT utilizes characteristics of an alternating current.



Primary and secondary coils wound on an iron core are isolated electrically. When a primary current (\$I_1\$) is applied to the iron core, a secondary current (\$I_2\$) can be extracted depending on the turn ratio (current transformation ratio).

The following shows the relationship of a primary current, a secondary current, and windings

$$\text{Primary current } (I_1) \times \text{Windings } (T_1) = \text{Secondary current } (I_2) \times \text{Windings } (T_2)$$

$$\left(\text{Current transformation ratio (CT ratio)} \right) = \frac{\text{Primary current } (I_1)}{\text{Secondary current } (I_2)} = \frac{\text{Secondary windings } (T_2)}{\text{Primary windings } (T_1)}$$

There are two CT types: the contact type and noncontact type. The noncontact type is classified into the window-type and split-type which is easy to be retrofitted.

(2) Operation of a CT input module


A CT input module measures an alternating current by converting a secondary current input from a CT to a digital value after carrying out an effective value operation.

The above flows are defined as "digital conversion" in this manual.

1.1 Features

(1) Alternating current measurement of eight points (eight channels) by one module

One module can measure an alternating current with eight points (eight channels).



A CT input range can be selected for each channel.

(2) Reliability by high accuracy

A CT input module can achieve the high accuracy of $\pm 0.5\%$ (when the ambient temperature is $25 \pm 5^\circ\text{C}$) and $\pm 1.0\%$ (when the ambient temperature is 0 to 55°C) at the maximum digital output value.

(3) Operation of a digital output value by the scaling function


The scaling function can represent a digital output value in an easily understandable value depending on a purpose.

(4) Monitoring of a measured target

By using the input signal error detection function, warning output function, or dropout function, the status of a measured target can be monitored easily.

(5) Detection of the peak current

- By setting the peak current detection value and peak current detection time, the peak current occurred excessively at a system start-up or an overload of devices can be detected. Doing so improves maintainability of devices and the failure diagnosis for a measured target.



- The number of peak current detection is recorded in a non-volatile memory. Therefore the number of peak current detection is not cleared after turning off the power supply or resetting the CPU module.

(6) Logging function

5000 data can be collected for each channel. The analysis of the collected data can improve maintainability of the system used.

(7) Backup of a set value to a non-volatile memory

Initial settings in the buffer memory can be backed up to a non-volatile memory. Initial settings do not need to be reset when the power supply is turned on or the CPU module is reset.

(8) Changeable slope of I/O conversion characteristics

A slope of I/O conversion characteristics can be changed by configuring the offset/gain settings.

(9) Easy setting with GX Works2


Sequence programming is reduced since initial settings or an auto refresh setting can be configured on the screen. In addition, setting status and operating status of modules can be checked easily.

(10) Online module change

This module can be replaced without stopping the system.

(11) Reduced man-hours and costs (A signal converter is not needed.)

A CT can be connected to a programmable controller directory using a CT input module; as a result, a signal converter installed outside is not required. Therefore man-hours and costs are reduced.



CHAPTER 2 SYSTEM CONFIGURATION

This chapter describes the system configuration of the CT input module.

2.1 Applicable Systems

This section describes applicable systems.

(1) Applicable CPU modules and base units, and number of mountable modules

(a) When mounted with a CPU module

The following table lists CPU modules and base units applicable to the CT input module and the number of mountable CT input modules.

Depending on the combination with other modules or the number of mounted modules, power supply capacity may be insufficient.

Select the power supply capacity according to the module to be used.

If the power supply capacity is insufficient, change the combination of the modules.

Applicable CPU module		Number of modules *1	Applicable base unit*2		
CPU type	CPU model		Main base unit	Extension base unit	
Programmable controller CPU	Basic model QCPU	Q00JCPU	Up to 16	○	○
		Q00CPU	Up to 24		
		Q01CPU			
	High Performance model QCPU	Q02CPU	Up to 64	○	○
		Q02HCPU			
		Q06HCPU			
		Q12HCPU			
		Q25HCPU			
	Process CPU	Q02PHCPU	Up to 64	○	○
		Q06PHCPU			
		Q12PHCPU			
		Q25PHCPU			
	Redundant CPU	Q12PRHCPU	Up to 53	×	○
		Q25PRHCPU			
	Universal model QCPU	Q00UJCPU	Up to 16	○	○
		Q00UCPU	Up to 24		
		Q01UCPU			
		Q02UCPU	Up to 36		
		Q03UDCPU	Up to 64		
Q04UDHCPU					
Q06UDHCPU					
Q10UDHCPU					
Q13UDHCPU					
Q20UDHCPU					
Q26UDHCPU					

Applicable CPU module		Number of modules ^{*1}	Applicable base unit ^{*2}		
CPU type	CPU model		Main base unit	Extension base unit	
Programmable controller CPU	Universal model QCPU	Q03UDECPU	Up to 64	○	○
		Q04UDEHCPU			
		Q06UDEHCPU			
		Q10UDEHCPU			
		Q13UDEHCPU			
		Q20UDEHCPU			
		Q26UDEHCPU			
		Q50UDEHCPU			
	Q100UDEHCPU				
Safety CPU	QS001CPU	N/A	×	× ^{*3}	
C Controller module	Q06CCPU-V	Up to 64	○	○	
	Q06CCPU-V-B				
	Q12DCCPU-V				

○: Applicable, ×: N/A

*1 Limited within the range of I/O points for the CPU module.

*2 Can be mounted to any I/O slot of a base unit.

*3 Connection of an extension base unit is not available with any safety CPU.

Remark

To use a C Controller module with the CT input module, refer to the C Controller Module User's Manual.

(b) When mounted on MELSECNET/H remote I/O station

The following table lists the network modules and base units applicable to the CT input module and the number of mountable CT input modules.

Depending on the combination with other modules or the number of mounted modules, power supply capacity may be insufficient.

Select the power supply capacity according to the module to be used.

If the power supply capacity is insufficient, change the combination of the modules.

Applicable network module	Number of modules ^{*1}	Applicable base unit ^{*2}	
		Main base unit of remote I/O station	Extension base unit of remote I/O station
QJ72LP25-25	Up to 64	○	○
QJ72LP25G			
QJ72LP25GE			
QJ72BR15			

○: Applicable, ×: N/A

*1 Limited within the range of I/O points for the network module.

*2 Can be mounted to any I/O slot of a base unit.

Remark

The Basic model QCPU or C Controller module cannot configure the MELSECNET/ H remote I/O net.

(2) For multiple CPU system

The function version of the first released CT input module is C, and the CT input module supports multiple CPU systems.

When using the CT input module in a multiple CPU system, refer to the following.

 QCPU User's Manual (Multiple CPU System)

(a) Intelligent function module parameters

Write intelligent function module parameters to only the control CPU of the CT input module.

(3) For online module change

The CT input module supports online module change. For details on online module change, refer to the following.

ONLINE MODULE CHANGE ( Page 182, CHAPTER 10)

Online Module Change Procedure (When Using GX Developer) ( Page 253, Appendix 3)

(4) Applicable software packages

The following table lists systems that use a CT input module and applicable software packages.
A programming tool is required to use a CT input module.

Item		Software version	
		GX Developer* ¹	GX Works2
Q00J/Q00/Q01CPU	Single CPU system	Version 7 or later	Version 1.77F or later
	Multiple CPU system	Version 8 or later	
Q02/Q02H/Q06H/Q12H/Q25HCPU	Single CPU system	Version 4 or later	
	Multiple CPU system	Version 6 or later	
Q02PH/Q06PHCPU	Single CPU system	Version 8.68W or later	N/A
	Multiple CPU system		
Q12PH/Q25PHCPU	Single CPU system	Version 7.10L or later	
	Multiple CPU system		
Q12PRH/Q25PRHCPU	Redundant system	Version 8.45X or later	
Q00UJ/Q00U/Q01UCPU	Single CPU system	Version 8.76E or later	
	Multiple CPU system		
Q02U/Q03UD/Q04UDH/ Q06UDHCPU	Single CPU system	Version 8.48A or later	
	Multiple CPU system		
Q10UDH/Q20UDHCPU	Single CPU system	Version 8.76E or later	
	Multiple CPU system		
Q13UDH/Q26UDHCPU	Single CPU system	Version 8.62Q or later	
	Multiple CPU system		
Q03UDE/Q04UDEH/Q06UDEH/ Q13UDEH/Q26UDEHCPU	Single CPU system	Version 8.68W or later	
	Multiple CPU system		
Q10UDEH/Q20UDEHCPU	Single CPU system	Version 8.76E or later	
	Multiple CPU system		
Q50UDEH/Q100UDEHCPU	Single CPU system	N/A	
	Multiple CPU system		
If installed in a MELSECNET/H remote I/O station		Version 6 or later	

*1 When using GX Developer, create a sequence program for initial settings and auto refresh setting.

(5) Products prepared by user**(a) CT**

Manufacturer	Model name	Input range	Secondary winding
Multi Measuring Instruments Sales Co., Ltd.	CTF-5A	0 to 5AAC	3000 turns
	CTF-50A	0 to 50AAC	3000 turns
	CTF-100A	0 to 100AAC	3000 turns
	CTF-200A	0 to 200AAC	3000 turns
	CTF-400A	0 to 400AAC	6000 turns
	CTF-600A	0 to 600AAC	9000 turns
U.R.D.,LTD.	CTL-10-3FC ^{*1}	0 to 5AAC, 0 to 50AAC	3000 turns
	CTL-16-3FC ^{*1}	0 to 100AAC	3000 turns
	CTL-24-3FC ^{*1}	0 to 200AAC	3000 turns
	CTL-36-6SC ^{*1}	0 to 400AAC	6000 turns
	CTT-36-9SC	0 to 600AAC	9000 turns
Mitsubishi Electric Corporation	EMU-CT50	0 to 50AAC	3000 turns
	EMU-CT100	0 to 100AAC	3000 turns
	EMU-CT400	0 to 400AAC	6000 turns
	EMU-CT600	0 to 600AAC	9000 turns

*1 The following connection cable is available for a connection with the CT input module.

Manufacturer	Model name
U.R.D.,LTD.	CABLE-4

(b) Connection cable

Use a shielded twisted pair cable for a connection between the CT input module and CT. The shielded twisted pair cable must satisfy the input specifications described in the performance specifications.


Performance Specifications (☞ Page 27, Section 3.2)

2.2 How to Check the Function Version and Serial Number

The function version and serial number of a CT input module can be checked on the rating plate, front part of the module, or system monitor of the programming tool.


(1) Checking on the rating plate

The rating plate is on the side of the CT input module.



(2) Checking on the front part (bottom part) of module

The function version and serial number on the rating plate are also shown on the front part (bottom part) of the module.



(3) Checking on the system monitor

The function version and serial number can be checked on the "Product Information List" window.



Base	Slot	Type	Series	Model Name	Point	I/O Address	Master PLC	Serial No.	Ver	Production Number
0	CPU	CPU	Q	Q06UDHCPU	-	-	-	140120000000000	B	091013092955015-B
0	0	Intelli.	Q	Q68CT	16Point	0000	-	140110000000000	C	-
0	1	-	-	Empty	-	-	-	-	-	-
0	2	-	-	Empty	-	-	-	-	-	-
0	3	-	-	Empty	-	-	-	-	-	-
0	4	-	-	Empty	-	-	-	-	-	-
0	5	-	-	Empty	-	-	-	-	-	-
0	6	-	-	Empty	-	-	-	-	-	-
0	7	-	-	Empty	-	-	-	-	-	-

(a) Displaying product number

For the CT input module, "-" is displayed since the product number display is not supported.

Point

The serial number displayed on the product information list of a programming tool may differ from that on the rating plate and on the front part of the module.

- The serial number on the rating plate and front part of the module indicates the management information of the product.
- The serial number displayed on the product information list of a programming tool indicates the function information of the product. The function information of the product is updated when a new function is added.

CHAPTER 3 SPECIFICATIONS

This chapter describes general specifications, performance specifications, I/O conversion characteristics, accuracy, and functions.

3.1 General Specifications

For the general specifications of the CT input module, refer to the following.

 QCPU User's Manual (Hardware Design, Maintenance and Inspection)

3.2 Performance Specifications

This section describes the performance specifications of the CT input module.

3.2.1 Performance specifications list

The following table lists the performance specifications of the CT input module.

Item		Specifications			
Number of input points		8 points (8 channels)			
Operation method		Effective value operation			
Input range		0 to 5AAC	0 to 50AAC	0 to 100AAC	
		0 to 200AAC	0 to 400AAC	0 to 600AAC	
Digital output	Converted current value	0 to 12000			
	Scaling value	-32768 to 32767			
Input frequency		50/60Hz			
Excessive input		200% for 1 minute, 150% for continuous time			
I/O characteristics, maximum resolution		Input range	Digital output value		Maximum resolution
		0 to 5AAC	0 to 10000		0.5mA
		0 to 50AAC			5mA
		0 to 100AAC			10mA
		0 to 200AAC			20mA
		0 to 400AAC			40mA
		0 to 600AAC			60mA
Accuracy (accuracy for the maximum digital output value) ^{*1*2}	Ambient temperature 25 ± 5°C	Within ± 0.5% (±50 digits)			
	Ambient temperature 0 to 55°C	Within ± 1.0% (±100 digits)			
Sampling cycle ^{*3}		10ms/8CH	20ms/8CH	50ms/8CH	100ms/8CH
Response time ^{*4}		0.4s or less			
Number of access to the non-volatile memory		Up to 10 ¹² times			
Isolation method		Between input terminals and the programmable controller power supply: Transformer Between input channels: No isolation			
Dielectric withstand voltage		Between I/O terminals and the programmable controller power supply: 1500VACrms for 1 minute			
Insulation resistance		Between I/O terminals and the programmable controller power supply: 500VDC 10MΩ or higher			
Number of occupied I/O points		16 points (I/O assignment: 16 points for intelligent)			
External connection system		18-point terminal block			
Applicable wire size		0.3 to 0.75mm ²			
Applicable solderless terminal		R1.25-3 (Do not use a solderless terminal with an insulation sleeve.)			
Internal current consumption (5VDC)		0.35A			
Weight		0.19kg			

- *1 Except in case when the CT input module is influenced by noise
- *2 The accuracy when a CT is connected is a sum of the CT input module's accuracy and the CT's accuracy.
The following is the formula to calculate accuracy.
 $(\text{Accuracy}) = (\text{Accuracy of the CT input module}) + (\text{Accuracy of the CT to be used})$
For the accuracy of the CT to be used, contact its manufacturer.
- *3 The default value is 10ms/8CH.
- *4 Response time complies with IEC 60688.
The larger one of the following
 - The time from when the CT input changes from 0 to 90% till when the converted digital value reaches $90\% \pm 1\%$
 - The time from when the CT input changes from 100 to 10% till when the converted digital value reaches $10\% \pm 1\%$

3.2.2 I/O conversion characteristics

An I/O conversion characteristic is expressed with the slope of the line connecting an offset value and gain value when a CT input value (current) is converted to a digital value.

(1) Offset value


This is the CT input value (current) converted to the digital output value of 0.

(2) Gain value

This is the CT input value (current) converted to the digital output value of 10000.

(3) I/O conversion characteristics

The following graph shows the I/O conversion characteristics.



No.	Input range setting	Offset value	Gain value	Digital output value ^{*1}	Maximum resolution
1)	0 to 5AAC	0A	5A	0 to 10000	0.5mA
2)	0 to 50AAC	0A	50A		5mA
3)	0 to 100AAC	0A	100A		10mA
4)	0 to 200AAC	0A	200A		20mA
5)	0 to 400AAC	0A	400A		40mA
6)	0 to 600AAC	0A	600A		60mA

*1 If an analog value is input exceeding the digital output range, the digital output value is fixed to the maximum (12000) or minimum (0).

- Use the CT input module so that the input and output are within the specified practical ranges. If a value is out of the range, the maximum resolution and accuracy may not fall within the range described in performance specifications. (Avoid values on the dotted line region in the graph of I/O conversion characteristics.)
- For each input range, avoid inputting a value that exceeds the one in the following table to the CT. (Avoid inputting the value that is 150% or more over the maximum input range.) Elements may be damaged.

Input range setting	CT input value (primary current value of a CT)
0 to 5AAC	7.5A or more
0 to 50AAC	75A or more
0 to 100AAC	150A or more
0 to 200AAC	300A or more
0 to 400AAC	600A or more
0 to 600AAC	900A or more


3.2.3 Accuracy

The accuracy of the CT input module is measured for the maximum digital output value.

Even if the offset/gain setting or input range was changed to change input characteristics, the accuracy remains the same, and is kept within the range described in performance specifications.

The following graph shows the fluctuation range of accuracy when the range of 0 to 200AAC is selected.

The accuracy is $\pm 0.5\%$ (± 50 digits) when the ambient temperature is $25 \pm 5^\circ\text{C}$, and $\pm 1.0\%$ (± 100 digits) when the ambient temperature is 0 to 55°C (excluding the case under noise effect).



3.2.4 Number of parameter settings

Set initial settings and auto refresh settings of the CT input module so that the number of parameters, including those of other intelligent function modules, does not exceed the number of parameters that can be set in the CPU module. For the maximum number of parameters that can be set in the CPU module, refer to the following.

 QCPU User's Manual (Hardware Design, Maintenance and Inspection)

(1) Number of CT input module parameters


For a CT input module, the following number of parameters can be set.

Model	Initial setting	Auto refresh setting
Q68CT	14	89 (maximum)

(2) Checking method

The maximum number of parameter settings and the number of parameter settings set for the intelligent function module can be checked on the following.

 Project window ⇨ [Intelligent Function Module] ⇨ Right-click
⇨ [Intelligent Function Module Parameter List...]



No.	Description
1)	The total number of parameters in initial settings checked on the window
2)	The maximum number of parameter settings in initial settings
3)	The total number of parameters in the auto refresh setting checked on the window
4)	The maximum number of parameter settings in the auto refresh setting

3.3 Function list

The following is the function list of the CT input module.

Item		Description	Reference	
Input range setting		An input range can be selected for each channel depending on a measured target from the following ranges. <ul style="list-style-type: none"> • Factory default ranges (0 to 5AAC, 0 to 50AAC, 0 to 100AAC, 0 to 200AAC, 0 to 400AAC, and 0 to 600AAC) • User ranges (0 to 5AAC, 0 to 50AAC, 0 to 100AAC, 0 to 200AAC, 0 to 400AAC, and 0 to 600AAC) 	Page 36, Section 4.2	
Conversion enable/disable function		Digital conversion can be enabled or disabled for each channel.	Page 37, Section 4.3	
Sampling cycle switching function		A sampling cycle can be selected from 10ms/8CH, 20ms/8CH, 50ms/8CH, or 100ms/8CH.	Page 37, Section 4.4	
Digital conversion method	Sampling processing	CT input values are converted to digital values in each sampling cycle. The converted values are stored as digital output values in the buffer memory.	Page 38, Section 4.5.1 (1)	
	Averaging process	Time average	Digital conversion is performed for a set time, and a sum of the converted values except the maximum and minimum values is averaged. The averaged values are stored in the buffer memory.	Page 39, Section 4.5.1 (2) (a)
		Count average	Digital conversion is performed the set number of times, and a sum of the converted values except the maximum and minimum values is averaged. The averaged values are stored in the buffer memory.	Page 39, Section 4.5.1 (2) (b)
		Moving average	Digital output values for the specified number of times are averaged in each sampling cycle. The averaged values are stored in the buffer memory.	Page 40, Section 4.5.1 (2) (c)
Primary delay filter		Depending on the set time constant, digital output values with smoothed noise can be obtained.	Page 41, Section 4.5.1 (3)	
Input signal error detection function		Overrange of a CT input value (excess of a peak value) can be detected. Since a CT input module can detect that a high current out of range flew through a measured target, an error on the measured target is monitored easily.	Page 44, Section 4.6	
Peak current detection function		When digital output values exceed the set peak current detection value consecutively for the duration of the peak current detection time set in advance, an error can be detected.	Page 46, Section 4.7	
Dropout function		When an input current is around 0A, a CT's conversion accuracy is low. To avoid digital output of such an unstable CT input value, digital output values within the set value can be dropped to 0 forcibly.	Page 49, Section 4.8	
Scaling function		A digital output value can be scaled into a value within the range of the set scaling upper limit value to lower limit value. The sequence programming for scale conversion can be omitted.	Page 50, Section 4.9	
Warning output function	Process alarm	When a digital output value enters the alert output range set in advance, an alert is output.	Page 53, Section 4.10 (1)	
	Rate alarm	When a change rate of a digital output value is equal to or more than the rate alarm upper limit value (%/s) or that is equal to or less than the rate alarm lower limit value (%/s), an alert is output.	Page 55, Section 4.10 (2)	
Maximum value/minimum value hold function		The maximum and minimum of digital output values or scaling values are stored to the buffer memory for each channel.	Page 59, Section 4.11	
Logging function		A digital output value or scaling value can be logged. 5000 data can be logged for each channel.	Page 60, Section 4.12	

Item	Description	Reference
Set value backup function	Set values in the buffer memory can be backed up into the non-volatile memory. Since backup data are restored at the next start-up, programs for initial settings are not required after the set value backup function was executed.	Page 72, Section 4.13
Default setting registration function	Values in the buffer memory can be changed back to the default.	Page 73, Section 4.14
Offset/gain setting	A slope of I/O conversion characteristics can be changed.	Page 150, Section 8.5
Error history function	Errors and alarms occurred in the CT input module are stored up to the latest 16 records in the buffer memory.	Page 74, Section 4.15
Module error collection function	Errors and alarms occurred in the CT input module can be collected into the CPU module.	Page 77, Section 4.16
Error clear function	When an error occurs, the error can be cleared on the system monitor.	Page 78, Section 4.17
Online module change	A module can be replaced without stopping the system.	Page 182, CHAPTER 10


CHAPTER 4 FUNCTIONS

This chapter describes the details of the CT input module's function, and the setting procedures for the functions. For details on I/O signals and the buffer memory, refer to the following.

- Details of I/O Signals (☞ Page 80, Section 5.2)
- Details of Buffer Memory Addresses (☞ Page 106, Section 6.2)

4.1 Processing Each Function

A CT input value and digital value are processed in the following order. If multiple functions are enabled, the output of the first-processed function is used as the input for the next function.



(1) CT input value

This is an alternating current value measured using a CT. This is a primary current which a CT imports.

(2) Digital output value

A digital value after the sampling processing or an averaging process was performed.

(3) Scaling value

This is a digital output value which was performed scale conversion.

(4) Maximum and minimum values

Either of the following are stored.

- The maximum and minimum digital output values (when the scaling function is disabled.)
- The maximum and minimum scaling values (when the scaling function is enabled.)

(5) Logging data

A digital output value or scaling value is collected.

4.2 Input Range Setting

An input range can be selected for each channel depending on the CT to be connected.

Select a factory default range normally. If the slope of I/O conversion characteristics is changed, select a user range and configure the offset/gain setting.

Point

- Select an input range depending on the CT to be connected. In case of excessive input, safety problems such as heat generation may occur.
- If a set input value is not supported by the CT to be connected, and Operating condition setting request (Y9) is turned on then off, an input signal error may occur.
If an input signal error occurs, check if the input range setting is supported by the connected CT. If the input range setting is incorrect, reset the setting.
For details on the input signal error detection function, refer to the following.
 - Input Signal Error Detection Function ( Page 44, Section 4.6)

(1) Setting procedure

1. Set values to CH□ Input range setting (Un\G150 to Un\G157) depending on the CT to be connected.

	Input range	Setting value
Factory default range	0 to 5AAC	0000 _H
	0 to 50AAC	0001 _H
	0 to 100AAC	0002 _H
	0 to 200AAC	0003 _H
	0 to 400AAC	0004 _H
	0 to 600AAC	0005 _H
User range	0 to 5AAC	0010 _H
	0 to 50AAC	0011 _H
	0 to 100AAC	0012 _H
	0 to 200AAC	0013 _H
	0 to 400AAC	0014 _H
	0 to 600AAC	0015 _H

2. Turn on then off Operating condition setting request (Y9).

(2) When using a user range

- Set 0010_H to 0015_H to CH□ Input range setting (Un\G150 to Un\G157) depending on the CT to be connected.
- Configure the offset/gain setting. For the offset/gain setting, refer to  Page 150, Section 8.5.
- One offset value and one gain value are saved in the CT input value as the user range setting for each channel. When connecting a new CT to a channel where a user range was set with a different CT before, configure the offset/gain setting again.

4.3 Conversion Enable/Disable Function

Set whether to enable or disable the digital conversion for each channel.

(1) Setting procedure

1. Set Enable (0) or Disable (1) to Conversion enable/disable setting (Un\G0).
2. Turn on then off Operating condition setting request (Y9).

4.4 Sampling Cycle Switching Function

A sampling cycle can be selected from one of the following.

- 10ms/8CH
- 20ms/8CH
- 50ms/8CH
- 100ms/8CH

(1) Setting procedure

1. Set a sampling cycle to Sampling cycle setting (Un\G26).

Item	Setting
Sampling cycle setting (Un\G26)	<ul style="list-style-type: none"> • 10ms/8CH (0) • 20ms/8CH (1) • 50ms/8CH (2) • 100ms/8CH (3)

2. Turn on then off Operating condition setting request (Y9).

Point

Digital conversion is performed in the set sampling cycle regardless of the number of conversion enabled channels.

4.5 Digital Conversion Method

One of the following digital conversion methods can be set for each channel.

- Sampling processing
- Averaging process
- Primary delay filter

For the operation of each digital conversion method, refer to the following.

- Operations of digital conversion methods (☞ Page 38, Section 4.5.1)

For the setting procedure for each digital conversion method, refer to the following.

- Setting procedures for digital conversion methods (☞ Page 43, Section 4.5.2)

4.5.1 Operations of digital conversion methods

(1) Sampling processing

CT input values are converted to digital values in each set sampling cycle. The converted values are stored as digital output values in the buffer memory.

(2) Averaging process

Digital output values are averaged for each channel. The averaged values are stored as digital output values in the buffer memory.

There are three types of averaging process as follows:

- Time average
- Count average
- Moving average

(a) Time average

Digital conversion is performed for the duration of the set time, and a sum of the converted values except the maximum and minimum values is averaged. The averaged value is stored in the buffer memory.

The number of processing within the duration of the set time varies depending on the set time and sampling cycle.

$$\text{Number of processing} = \frac{\text{Set time}}{\text{Sampling cycle}}$$

Ex. The number of processing is as follows in case of the settings below.

Item	Setting
Sampling cycle	50ms/8CH
Set time	380ms

$$\frac{380}{50} = 7.6 \text{ (times)} \cdot \cdot \cdot \text{Figures after the decimal point are omit.}$$

→ Conversion is processed seven times to output the average value.

Point

The valid lower limit setting value for a time average is calculated as: "(Minimum 4 times) × (Sampling cycle)".

Ex. When the sampling cycle is 50ms/8CH:

$$4 \times 50 = 200\text{ms}$$

If the number of processing is less than four due to the set time, the error (error code: 20□) occurs and the digital output value becomes 0.

(b) Count average

Digital conversion is performed the set number of times, and a sum of the converted values except the maximum and minimum values is averaged. The averaged value is stored in the buffer memory.

The processing time that takes to store the averaged value of count average in the buffer memory varies depending on the sampling cycle.

$$\text{Processing time} = \text{Set number of times} \times \text{Sampling cycle}$$

Ex. The processing time is as follows in case of the settings below.

Item	Setting
Sampling cycle	50ms/8CH
Set number of times	20 times

$$20 \times 50 = 1000 \text{ (ms)} \rightarrow \text{The averaged value is output in each 1000ms.}$$

Point


Since the count average requires a sum of at least two digital conversions besides the maximum and minimum values, the set number of times must be four or more.

(c) Moving average

Digital output values of the number of specified times are averaged in each sampling cycle. The averaged values are stored in the buffer memory.

Digital output values to be averaged move one by one in each sampling cycle as below.

Ex. Moving average processing of when the set number of times is four



(3) Primary delay filter

Depending on the set time constant, digital output values with smoothed noise can be obtained. A smoothing degree varies by setting the time constant.

The following are the relational expressions of time constants and digital output values.

$$[n = 1]^*1$$

$$Y_n = 0$$

$$[n = 2]$$

$$Y_n = y_{n-1} + \frac{\Delta t}{\Delta t + TA} (y_n - y_{n-1})$$

$$[n \geq 3]$$

$$Y_n = Y_{n-1} + \frac{\Delta t}{\Delta t + TA} (y_n - Y_{n-1})$$

Y_n : Present digital output value y_n : Digital output value before smoothing

Y_{n-1} : Last digital output value y_{n-1} : Last digital output value before smoothing

n : Number of sampling processing Δt : Sampling cycle

TA : Time constant^{*2} (ms)


*1 When n is 2 or larger, Conversion completed (1) is stored in Conversion completed flag (Un\G10).

*2 Set a value which is equal to or larger than the sampling cycle. If the time constant is smaller than the sampling cycle, the error (error code: 32□) occurs, and the digital output value becomes 0.

Ex. 1: Change of digital output values under the following conditions


- Input range: 0 to 100AAC
- Sampling cycle: 10ms/8CH
- Time constant setting: 1000ms (1s)
- CT input value: changed from 0A to 100A

When 1000ms passes after the CT input value reaches 100A, the digital output value with a primary delay filter reaches 63.2% of the digital output value in the sampling process.



Ex. 2: When CT input values form a ringing waveform, change of digital output values in the following conditions

- Time constant setting: 2000ms (2s)
- Time constant setting: 1000ms (1s)
- Moving average processing: 16 times



4.5.2 Setting procedures for digital conversion methods

(1) Sampling processing

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set Sampling processing (0) to Averaging process setting (Un\G24, Un\G25).
3. Turn on then off Operating condition setting request (Y9).

(2) Averaging process and primary delay filter

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set digital conversion methods to Averaging process setting (Un\G24, Un\G25).

Item	Setting
Averaging process setting (Un\G24, Un\G25)	<ul style="list-style-type: none"> • Time average (1) • Count average (2) • Moving average (3) • Primary delay filter (4)

3. Set values to CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)


Item	Processing	Setting range
CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)	Time average	40 to 5000 (ms) ^{*1}
	Count average	4 to 500 (times)
	Moving average	2 to 1000 (times)
	Primary delay filter	10 to 10000 (ms) ^{*1}

- *1 Set an integral multiple of the sampling cycle. If not, digital output values are averaged in the maximum cycle that satisfies both of the following.
- Duration of the set time or less
 - Integral multiple of the sampling cycle
- In addition, set a value per 10ms unit. A value per 1ms unit is rounded off.

4. Turn on then off Operating condition setting request (Y9).

4.6 Input Signal Error Detection Function

Overrange of a CT input value (excess of a peak value) can be detected. Since a CT input module can detect that a high current out of range flew through a measured target, an error on the measured target is monitored easily.



(1) Detection level of Input signal errors

The level of current that is detected as an input signal error depends on the input range setting. The current level is about 125% of the gain value for the input range.


Input range setting	Detection level
Factory default range 0 to 5AAC User range 0 to 5AAC	Approximately 6.25AAC
Factory default range 0 to 50AAC User range 0 to 50AAC	Approximately 62.5AAC
Factory default range 0 to 100AAC User range 0 to 100AAC	Approximately 125AAC
Factory default range 0 to 200AAC User range 0 to 200AAC	Approximately 250AAC
Factory default range 0 to 400AAC User range 0 to 400AAC	Approximately 500AAC
Factory default range 0 to 600AAC User range 0 to 600AAC	Approximately 750AAC

(2) Notifying an input signal error

When a CT input value exceeds the input range, an input signal error is notified as follows.

- Input signal error (1) is stored in Input signal error detection flag (Un\G49).
- Input signal error detection signal (XC) turns on.
- The ALM LED flashes.
- Alarm code 110□ is stored in Latest error code (Un\G19).

Alarm codes are stored as below.



(3) Operation of the input signal error detection function

In addition, Converting or unused (0) is stored in Conversion completed flag (Un\G10) on the corresponding channel, and Conversion completed flag (XE) turns off.

When the CT input value returns within the input range, the digital conversion resumes regardless of reset of Input signal error detection flag (Un\G49) and Input signal error detection signal (XC). Conversion completed (1) is stored in Conversion completed flag (Un\G10) on the corresponding channel after the first update of a digital output value. (The ALM LED is flashing.)

(4) Detection cycle

This function is executed in each sampling cycle.

(5) Clearing the input signal error detection

After the CT input value returns within the input range, turn on then off Error clear request (YF).

When the input signal error is cleared, the CT input module results in the following states:

- Input signal error detection flag (Un\G49) is cleared.
- Input signal error detection signal (XC) turns off.
- The ALM LED turns off.
- The alarm code 110□ which is stored in Latest error code (Un\G19) is cleared.

(6) Setting procedure

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set Enable (0) to Input signal error detection setting (Un\G47).
3. Turn on then off Operating condition setting request (Y9).

4.7 Peak Current Detection Function


An abnormal current value from a CT can be detected. The peak current occurred excessively at a system start-up or an overload of devices can be detected using the peak current detection function. Doing so improves maintainability of devices and the failure diagnosis for a measured target.

(1) Notifying the peak current detection


When CH□ Digital output value (Un\G11 to Un\G18) exceeds set CH□ Peak current detection value (Un\G326 to Un\G333) consecutively for the duration of set CH□ Peak current detection time (Un\G318 to Un\G325), an error is notified as follows.

- Peak current detected (1) is stored in Peak current detection flag (Un\G301).
- Peak current detection signal (X7) turns on.
- The ALM LED flashes.
- Alarm code 120□ is stored in Latest error code (Un\G19).

Alarm codes are stored as below.




However, digital conversion on the channel where an error is notified was held.



(2) Counting the peak current detection

- The number of peak current detection is stored in CH□ Peak current detection count (Un\G334 to Un\G341).
- When a peak current is detected, 1 is added in CH□ Peak current detection count (Un\G334 to Un\G341). However, next addition is not performed unless a digital output value falls below the peak current detection value once.
- CH□ Peak current detection count (Un\G334 to Un\G341) is saved automatically in the non-volatile memory in the CT input module. When the module starts up by turning off then on, or resetting the CPU module, the saved detection count is read in CH□ Peak current detection count (Un\G334 to Un\G341). Therefore, the number of peak current detection is not cleared even after the power supply was turned off then on, or the CPU module was reset.
- The count range of CH□ Peak current detection count (Un\G334 to Un\G341) is 0 to 32767. When the number of peak current detection exceeds the upper limit of the count range, the number returns to 0.




Point

When a digital output value has exceeded the peak current detection value at power on, the number of peak current detection is added 1.

(a) Resetting the number of peak current detection

To reset the number of peak current detection, store Reset requested (1) in CH□ Peak current detection count reset request (Un\G302 to Un\G309). 0 is stored in CH□ Peak current detection count (Un\G334 to Un\G341). After the reset was completed, Reset request completed (1) is stored in CH□ Peak current detection count reset complete (Un\G310 to Un\G317).



(3) Peak current detection time

The setting range of CH□ Peak current detection time (Un\G318 to Un\G325) is 10 to 10000ms.

Set CH□ Peak current detection time (Un\G318 to Un\G325) to an integral multiple of the sampling cycle.

When CH□ Peak current detection time (Un\G318 to Un\G325) is not set as the integral multiple of the sampling cycle, the peak current is detected in the maximum cycle that satisfy both of the following.

- Peak current detection time or less
- Integral multiple of the sampling cycle

Ex. When the sampling cycle setting and peak current detection time is set to 100ms/8CH and 950ms, the peak current is detected in 900ms intervals (integral multiple of 100ms).

(4) Clearing the notification of the peak current detection

Check that a digital output value is the peak current detection value or less, and turn on then off Error clear request (YF).

When the notification of the peak current detection is cleared, the CT input module results in the following states:

- Peak current detection flag (Un\G301) is cleared.
- Peak current detection signal (X7) turns off.
- The ALM LED turns off.
- The alarm code 120□ which is stored in Latest error code (Un\G19) is cleared.

Point

When Error clear request (YF) is turned on then off in the condition where a digital output value exceeds the peak current detection value, the peak current detection is notified again after a lapse of the peak current detection time.

(5) Detection target

CH□ Digital output value (Un\G11 to Un\G18) is a target regardless of the use of the scaling function.

(6) Setting procedure

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set Enable (0) to Peak current detection setting (Un\G300).
3. Set values to CH□ Peak current detection time (Un\G318 to Un\G325) and CH□ Peak current detection value (Un\G326 to Un\G333).

Item	Setting range
CH□ Peak current detection time (Un\G318 to Un\G325)	10 to 10000 (ms) ^{*1}
CH□ Peak current detection value (Un\G326 to Un\G333)	0 to 11999

*1 Set an integral multiple of the sampling cycle. If not, the peak current is detected in the maximum cycle that satisfies both of the following.

- Peak current detection time or less
- Integral multiple of the sampling cycle

In addition, set a value per 10ms unit. A value per 1ms unit is rounded off.

4. Turn on then off Operating condition setting request (Y9).

4.8 Dropout Function

When an input current is around 0A, a CT's conversion accuracy is low. To avoid digital output of such an unstable CT input value, digital output values within the set value can be dropped to 0 forcibly.

(1) Operation of the dropout function

When the value in CH□ Digital output value (Un\G11 to Un\G18) is equal to or less than the set value in CH□ Dropout value (Un\G162 to Un\G169) in advance, 0 is stored in CH□ Digital output value (Un\G11 to Un\G18).

(2) Setting procedure

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set Enable (0) to Dropout detection setting (Un\G160).
3. Set values to CH□ Dropout value (Un\G162 to Un\G169).

Item	Setting range
CH□ Dropout value (Un\G162 to Un\G169)	1 to 10000

4. Turn on then off Operating condition setting request (Y9).

Remark

To check whether the dropout function is enabled or disabled, refer to the following.

- Dropout status flag (Un\G161) (☞ Page 121, Section 6.2 (23))

4.9 Scaling Function

A digital output value can be scaled into a value within the range of the set scaling upper limit value to lower limit value. The sequence programming for scale conversion can be omitted. The scale-converted values are stored in CH□ Scaling value (Un\G54 to Un\G61).

(1) Concept of scaling setting

Set values corresponding to the lower limit value (0) of the input range to CH□ Scaling lower limit value (Un\G62, Un\G64, Un\G66, Un\G68, Un\G70, Un\G72, Un\G74, Un\G76).

Set values corresponding to the upper limit value (10000) of the input range to CH□ Scaling upper limit value (Un\G63, Un\G65, Un\G67, Un\G69, Un\G71, Un\G73, Un\G75, Un\G77).

(2) Calculation method for a scaling value

A value is performed scale conversion using the following formula. The scaled values after the decimal point are rounded off.

$$\text{Scaling value} = \frac{D_x \times (S_H - S_L)}{D_{\text{Max}}} + S_L$$

Item	Description
D _x	Digital output value
D _{Max}	Maximum digital output value for the used input range (10000)
S _H	Scaling upper limit value
S _L	Scaling lower limit value

(3) Setting procedure

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set Enable (0) to Scaling enable/disable setting (Un\G53).
3. Set values to CH1 Scaling lower limit value (Un\G62) to CH8 Scaling upper limit value (Un\G77).

Item	Setting range
CH□ Scaling lower limit value (Un\G62, Un\G64, Un\G66, Un\G68, Un\G70, Un\G72, Un\G74, Un\G76)	-32000 to 32000
CH□ Scaling upper limit value (Un\G63, Un\G65, Un\G67, Un\G69, Un\G71, Un\G73, Un\G75, Un\G77)	

4. Turn on then off Operating condition setting (Y9).

Point


- The maximum resolution does not change regardless of the scaling upper limit value and the scaling lower limit value to be set.
Performance specifications (☞ Page 27, Section 3.2.1)
- Digital output values can be scaled in a negative slope so that the values become as follows: Scaling lower limit value > Scaling upper limit value

(4) Example settings of the scaling

Ex. 1: Setting values as: Scaling upper limit value > Scaling lower limit value

- Input range: 0 to 100AAC
- CH Scaling upper limit value (Un\G63, Un\G65, Un\G67, Un\G69, Un\G71, Un\G73, Un\G75, Un\G77): 20000
- CH Scaling lower limit value (Un\G62, Un\G64, Un\G66, Un\G68, Un\G70, Un\G72, Un\G74, Un\G76): 0

The digital output values and scaling values are as follows:




CT input value (A)	Digital output value	Scaling values
0	0	0
25	2500	5000
50	5000	10000
75	7500	15000
100	10000	20000

Ex. 2: Setting values as: Scaling upper limit value lower < Scaling lower limit value

- Input range: 0 to 100AAC
- CH□ Scaling upper limit value (Un\G63, Un\G65, Un\G67, Un\G69, Un\G71, Un\G73, Un\G75, Un\G77): -10000
- CH□ Scaling lower limit value (Un\G62, Un\G64, Un\G66, Un\G68, Un\G70, Un\G72, Un\G74, Un\G76): 0

The digital output values and scaling values are as follows:




CT input value (A)	Digital output value	Scaling values
0	0	0
25	2500	-2500
50	5000	-5000
75	7500	-7500
100	10000	-10000

4.10 Warning Output Function

(1) Process alarm

When a digital output value enters the alert output range set in advance, an alert is output.


When the scaling function is enabled, scaling values are applied to the warning detection.



(a) Operation of warning output

If a digital output value enters the alert output range (process alarm upper upper limit value or more, or process alarm lower lower limit value or less), an alert is output as follows.

- Alarm ON (1) is stored in Warning output flag (Process alarm) (Un\G50).
- Warning output signal (X8) turns on.
- The ALM LED turns on.
- Alarm code 10△□ is stored in Latest error code (Un\G19).
Alarm codes are stored as below.



However, the digital conversion continues on the channel where an alert was output.

(b) Operation after an alert was output

After an alert was output, when a digital output value is less than the process alarm upper lower limit value or more than process alarm lower upper limit value, Normal (0) is stored in the corresponding bit of Warning output flag (Process alarm) (Un\G50) for the channel.

When digital output values in all channels are within the setting range, Warning output signal (X8) turns off, and the ALM LED turns off.

However, the alarm code 10△□ which is stored in Latest error code (Un\G19) is not cleared. Clear the alarm code 10△□ by turning on then off.

(c) Warning detection period

When time average is specified, the function is executed per set average time. When count average is specified, the function is executed per set average count.

For other digital conversion methods, the function is executed in each sampling cycle.

(d) Warning detection target

When the scaling function is enabled, CH□ Scaling value (Un\G54 to Un\G61) is applied to the warning detection.

For CH1 Process alarm lower lower limit value (Un\G86) to CH8 Process alarm upper upper limit value (Un\G117), set values considering the scale conversion.

(e) Setting procedure

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set Enable (0) to Warning output setting (Un\G48).
3. Set values in CH1 Process alarm lower lower limit value (Un\G86) to CH8 Process alarm upper upper limit value (Un\G117).

Item	Setting range
CH□ Process alarm upper upper limit value (Un\G89, Un\G93, Un\G97, Un\G101, Un\G105, Un\G109, Un\G113, Un\G117)	-32768 to 32767
CH□ Process alarm upper lower limit value (Un\G88, Un\G92, Un\G96, Un\G100, Un\G104, Un\G108, Un\G112, Un\G116)	
CH□ Process alarm lower upper limit value (Un\G87, Un\G91, Un\G95, Un\G99, Un\G103, Un\G107, Un\G111, Un\G115)	
CH□ Process alarm lower lower limit value (Un\G86, Un\G90, Un\G94, Un\G98, Un\G102, Un\G106, Un\G110, Un\G114)	

4. Turn on then off Operating condition setting request (Y9).


Point

Set the warning output setting as follows:

Process alarm upper upper limit value \geq Process alarm upper lower limit value \geq Process alarm lower upper limit value \geq Process alarm lower lower limit value

(2) Rate alarm

When a change rate of a digital output value is equal to or more than the rate alarm upper limit value (%/s) or that is equal to or less than the rate alarm lower limit value (%/s), an alert is output.




(a) Operation of warning output

Digital output values are monitored in each set rate alarm warning detection period. A change rate of the digital output value compared to the previous value is equal to or more than the rate alarm upper limit value (%/s) or that equal to or less than the rate alarm lower limit value (%/s), an alert is output as follows.

- Alarm ON (1) is stored in Warning output flag (Rate alarm) (Un\G51).
- Warning output signal (X8) turns on.
- The ALM LED turns on.
- Alarm code 10△□ is stored in Latest error code (Un\G19).

Alarm codes are stored as below.



However, the digital conversion continues on the channel where an alert was output.

(b) Operation after an alert was output

When a digital output value is less than the rate alarm upper limit value or more than the rate alarm lower limit value, Normal (0) is stored in the corresponding bit of Warning output flag (Rate alarm) (Un\G51) for the channel after an alert was output.

When digital output values in all channels are within the setting range, Warning output signal (X8) turns off, and the ALM LED turns off.

However, the alarm code 10△□ which is stored in Latest error code (Un\G19) is not cleared. Clear the alarm code 10△□ by turning on then off.

(c) Warning detection period

Set a rate alarm warning detection period to CH□ Rate alarm warning detection period (Un\G118 to Un\G125).

Set an integral multiple of the conversion cycle as the rate alarm warning detection period for each digital conversion method. If not, change rates are detected in the maximum cycle that satisfies both of the following.

- Rate alarm warning detection period or less
- Integral multiple of the conversion cycle

Ex. Rate alarm warning detection period in case of the following conditions

- Digital conversion method: Count average
- Average times: 10
- Sampling cycle: 100ms/8CH
- Rate alarm warning detection period: 4500ms

The conversion cycle is 1000ms (10 (times) × 100 (ms)), and a digital output value is compared in 4000ms intervals to check the change rate.

(d) Judgement of rate alarm

A change rate is judged that the rate alarm upper limit value and the rate alarm lower limit value are converted to digital values per rate alarm warning detection period. Set a rate alarm upper limit value and rate alarm lower limit value to the following buffer memory areas.

- CH□ Rate alarm upper limit value (Un\G126, Un\G128, Un\G130, Un\G132, Un\G134, Un\G136, Un\G138, Un\G140)
- CH□ Rate alarm lower limit value (Un\G127, Un\G129, Un\G131, Un\G133, Un\G135, Un\G137, Un\G139, Un\G141)

Conversion formula of judgement value for the rate alarm is as follows:

$$\text{Judgement value for rate alarm detection (digit)} = \left(\frac{R_H \text{ or } R_L}{1000} \right) \times D_{\text{Max}} \times \left(\frac{\Delta t}{1000} \right)$$

Item	Description
R _H	Rate alarm upper limit value (Unit: 0.1%/s)
R _L	Rate alarm lower limit value (Unit: 0.1%/s)
D _{Max}	Maximum digital output value of the input range: 10000
Δt	Rate alarm warning detection period (Unit: ms)

Ex. Judgement value in case of the following conditions

- Sampling cycle: 10ms/8CH
- Rate alarm warning detection period: 10 (10ms)
- Rate alarm upper limit value: 300 (30%/s)

$$\left(\frac{300}{1000}\right) \times 10000 \times \left(\frac{10}{1000}\right) = 30 \text{ [digit]}$$

The present value is compared to the previous value in 10ms intervals, and is checked if the value increased by 30 digits (0.3%).

(e) Warning detection target

CH□ Digital output value (Un\G11 to Un\G18) is a target regardless of the use of the scaling function.

(f) Setting procedure

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set Enable (0) to Warning output setting (Un\G48).
3. Set values to CH□ Rate alarm warning detection period (Un\G118 to Un\G125).

Item	Setting range
CH□ Rate alarm warning detection period (Un\G118 to Un\G125)	10 to 5000 (ms) ^{*1}

- *1 Set an integral multiple of the conversion cycle for each digital conversion method. If not, change rates are detected in the maximum cycle that satisfies both of the following.
- Rate alarm warning detection period or less
 - Integral multiple of the conversion cycle
- In addition, set a value per 10ms unit. A value per 1ms unit is rounded off.

4. Set values to CH1 Rate alarm upper limit value (Un\G126) to CH8 Rate alarm lower limit value (Un\G141).


Item	Setting range
CH□ Rate alarm upper limit value (Un\G126, Un\G128, Un\G130, Un\G132, Un\G134, Un\G136, Un\G138, Un\G140)	-32768 to 32767 (-3276.8%/s to 3276.7%/s)
CH□ Rate alarm lower limit value (Un\G127, Un\G129, Un\G131, Un\G133, Un\G135, Un\G137, Un\G139, Un\G141)	

5. Turn on then off Operating condition setting request (Y9).


(g) Examples to use a rate alarm

The change rate of digital output values in a limited range can be monitored easily as follows:


Ex. 1: To monitor that a rising rate of a digital output value is within the specified range



Ex. 2: To monitor a drop rate of a digital output value is within the specified range



Ex. 3: To monitor a change rate of a digital output value is within the specified range



4.11 Maximum Value/Minimum Value Hold Function

The maximum and minimum of digital output values or scaling values are stored in the buffer memory for each channel.

When time average or count average is specified as the averaging process, the values are updated in each averaging process cycle. For other digital conversion methods, the values are updated in each sampling cycle.

For buffer memory addresses where the values are stored, refer to the following.

- List of Buffer Memory Addresses (☞ Page 91, Section 6.1)

(1) Resetting maximum and minimum values

The maximum and minimum values are updated to the present value when Maximum value/minimum value reset request (YD) or Operating condition setting request (Y9) is turned on then off.

(2) Corresponding maximum and minimum values

When the scaling function is enabled, the maximum and minimum of scaling values are stored.

For details on the scaling function, refer to the following.

- Scaling Function (☞ Page 50, Section 4.9)

4.12 Logging Function

Data can be collected consecutively in a set cycle and stored in the buffer memory. Using the data stored in the buffer memory, debugging can be performed and data variation can be checked periodically. In addition, the time-series data that are imported as logs can be checked easily.

(1) Logging function

(a) Collectable data

The following types of data can be collected.

- Digital output value
- Scaling value

(b) Number of collectable data

The maximum 5000 logging data can be stored for each channel.

(c) Collection cycle


The data can be collected in 10ms at the minimum and in 3600s at the maximum intervals.


For details on the collection cycle, refer to the following.

- Setting procedure (Page 62, Section 4.12 (3))

(d) Storing the collected data

Logging data are stored orderly in the logging data storage area of the buffer memory, starting from the head area.



(2) Logging procedure**Point**

Logging data can also be checked without stopping logging. For details, refer to the following.

- To check logging data without stopping logging (☞ Page 71, Section 4.12 (10))

(3) Setting procedure

Follow the procedure below.

1. Set Enable (0) to Conversion enable/disable setting (Un\G0).
2. Set Enable (0) to CH□ Logging enable/disable setting (Un\G1000 to Un\G1007).
3. Set the type of data to be logged to CH□ Logging data setting (Un\G1024 to Un\G1031).

Item	Setting value
CH□ Logging data setting (Un\G1024 to Un\G1031)	<ul style="list-style-type: none"> • Digital output value (0) • Scaling value (1)

4. Set the cycle in which logging data are stored to CH□ Logging cycle setting value (Un\G1032 to Un\G1039).

5. Set the unit of the logging cycle in CH□ Logging cycle unit setting (Un\G1040 to Un\G1047).

Logging cycle unit	Setting value of CH□ Logging cycle unit setting (Un\G1040 to Un\G1047)	Setting range of CH□ Logging cycle setting value (Un\G1032 to Un\G1039)
Update cycle	0	The value is ignored.
ms	1	10 to 32767
s	2	1 to 3600

The actual logging cycle is an integral multiple of the conversion cycle for each conversion method.
The following table lists the conversion cycle for each conversion method.

Conversion method	Conversion cycle
Sampling processing	Sampling cycle
Time average	$\left(\frac{\text{Time set to CH□ Average time/Average number of times/ Moving average/Time constant settings (Un\G1 to Un\G8)}}{\text{Sampling cycle}} \right)^{*1} \times \text{Sampling cycle}$
Count average	(Setting of CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8) × Sampling cycle)
Moving average	Sampling cycle
Primary delay filter	Sampling cycle

*1 The value after the decimal point is rounded off.

If the set logging cycle is not an integral multiple of the conversion cycle shown above, the logging function operates in the maximum cycle of an integral multiple within the set range.

Ex. 1: When setting as below in CH1 to CH8:




- Averaging process setting (Un\G24, Un\G25): Sampling processing (0)
- Sampling cycle setting (Un\G26): 100ms/8CH (3)
- CH□ Logging data setting (Un\G1024 to Un\G1031): Digital output value (0)
- CH□ Logging cycle setting value (Un\G1032 to Un\G1039): 1950
- CH□ Logging cycle unit setting (Un\G1040 to Un\G1047): ms (1)

The conversion cycle is 100ms. The actual logging cycle is 1900ms (an integral multiple of 100ms).

6. In CH□ Logging points after trigger (Un\G1048 to Un\G1055), set the number of data to be collected from when the logging stop request (hold trigger) occurs until the logging stops. The setting range of CH□ Logging points after trigger (Un\G1048 to Un\G1055) is as below.

Item	Setting range
CH□ Logging points after trigger (Un\G1048 to Un\G1055)	1 to 5000

7. In CH□ Level trigger condition setting (Un\G1056 to Un\G1063), select any of the following.

Setting value	Description										
Disable (0)	Select this not to set the condition to stop logging. (Logging can be stopped at any time).										
Above (1)	<p>The logging stops when "Trigger data < Trigger setting value" changes to "Trigger data > Trigger setting value".</p>  <p>Example When the trigger setting value is 70</p> <table border="1" data-bbox="1101 649 1244 851"> <thead> <tr> <th>Trigger data</th> </tr> </thead> <tbody> <tr><td>64</td></tr> <tr><td>66</td></tr> <tr><td>67</td></tr> <tr><td>69</td></tr> <tr><td>70</td></tr> <tr><td>71</td></tr> <tr><td>72</td></tr> <tr><td>74</td></tr> <tr><td>...</td></tr> </tbody> </table> <p>← Trigger occurs at this point</p>	Trigger data	64	66	67	69	70	71	72	74	...
Trigger data											
64											
66											
67											
69											
70											
71											
72											
74											
...											
Below (2)	<p>Select this to set the condition to stop logging. (When a value in the buffer memory areas become the set condition, the logging stops.)</p> <p>The logging stops when "Trigger data > Trigger setting value" changes to "Trigger data < Trigger setting value".</p>  <p>Example When the trigger setting value is 70</p> <table border="1" data-bbox="1101 1008 1244 1209"> <thead> <tr> <th>Trigger data</th> </tr> </thead> <tbody> <tr><td>74</td></tr> <tr><td>72</td></tr> <tr><td>71</td></tr> <tr><td>70</td></tr> <tr><td>69</td></tr> <tr><td>67</td></tr> <tr><td>66</td></tr> <tr><td>64</td></tr> <tr><td>...</td></tr> </tbody> </table> <p>← Trigger occurs at this point</p>	Trigger data	74	72	71	70	69	67	66	64	...
Trigger data											
74											
72											
71											
70											
69											
67											
66											
64											
...											
Pass through (3)	<p>The logging stops when the trigger data passes the trigger setting value. (Either of the following (1) or (2)).</p> <p>(1) When "Trigger data < Trigger setting value" changes to "Trigger data > Trigger setting value"</p> <p>(2) When "Trigger data > Trigger setting value" changes to "Trigger data < Trigger setting value"</p> 										

4

4.12 Logging Function

8. When a setting value other than Disable (0) is selected in CH□ Level trigger condition setting (Un\G1056 to Un\G1063), set a logging stop condition to CH□ Trigger data (Un\G1064 to Un\G1071) and CH□ Trigger setting value (Un\G1082 to Un\G1089).

Item	Description	Setting range
CH□ Trigger data (Un\G1064 to Un\G1071)	Set a buffer memory address monitored as an occurrence condition to stop logging.*1	0 to 4999
CH□ Trigger setting value (Un\G1082 to Un\G1089)	Set a value of the buffer memory to stop logging.	-32768 to 32767

*1 By setting Level data □ (Un\G1072 to Un\G1081) as a monitoring target, a device value of a CPU module can be set as trigger data.

For details on the level data, refer to the following.

- Level data □ (☞ Page 132, Section 6.2 (41))

9. Turn on then off Operating condition setting request (Y9).

Point 

- If CH□ Logging cycle setting value (Un\G1032 to Un\G1039) and the logging cycle set in CH□ Logging cycle unit setting (Un\G1040 to Un\G1047) is shorter CH□ Digital output value (Un\G11 to Un\G18) and the conversion cycle of CH□ Scaling value (Un\G54 to Un\G61), the error (error code: 202□) occurs and the logging cannot be performed.
- When the logging function turns invalid
When any of the following error occurs after the logging function is enabled and Operating condition setting request (Y9) is turned on then off, the logging function turns disabled.
 - Error code (20□): Setting error of CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)
 - Error code (30□): Setting error of CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)
 - Error code (31□): Setting error of CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)
 - Error code (32□): Setting error of CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)
 - Error code (350): Setting error of Sampling cycle setting (Un\G26)
 - Error code (200□ to 206□): Setting error of a parameter setting item for the logging function

(4) Starting logging

Turn on then off Operating condition setting request (Y9). Data is logged in set logging cycle.

(5) Stopping logging

Use a hold trigger to stop logging. When the hold trigger is detected, the CT input module stops logging after the number of logging data set in advance were collected.

The logging stopping method is as below.

1. Set ON (1) to CH□ Logging hold request (Un\G1008 to Un\G1015).


When Disable (0) is set to CH□ Level trigger condition setting (Un\G1056 to Un\G1063), the set number of logging data are collected and the logging stops.

When CH□ Level trigger condition setting (Un\G1056 to Un\G1063) is set to Above (1), Below (2), or Pass through (3), the set number of logging data are collected after the conditions of CH□ Trigger data (Un\G1064 to Un\G1071) and CH□ Trigger setting value (Un\G1082 to Un\G1089) are satisfied, and the logging stops.


Point

- When Operating condition setting request (Y9) is turned on, the logging stops regardless of ON or OFF of the hold trigger. All the logging data stored before Operating condition setting request (Y9) is turned on are cleared.
- Check that CH□ Logging hold flag (Un\G1016 to Un\G1023) turned ON (1), and set OFF (0) to CH□ Logging hold request (Un\G1008 to Un\G1015). If CH□ Logging hold request (Un\G1008 to Un\G1015) is set OFF (0) before hold, the logging does not stop.
- After CH□ Logging hold request (Un\G1008 to Un\G1015) is set ON (1), the following delay occurs at the maximum until the CT input module receives a hold trigger.
Trigger delay = Logging cycle (Cycle at which the logging is actually performed) + Scan time of CPU module

Ex. When CH□ Level trigger condition setting (Un\G1056 to Un\G1063) is set to Disable (0) and CH1 Digital output value (Un\G11) is logged



Ex. When CH□ Level trigger condition setting (Un\G1056 to Un\G1063) is set to a value other than Disable (0) and CH1 Digital output value (Un\G11) is logged



(6) Checking the stop of the logging

Check that CH□ Logging hold flag (Un\G1016 to Un\G1023) turns ON (1).

(7) Checking trigger detection time

The time at that the hold trigger was detected can be checked in the buffer memory.*1

Even when the logging cycle is set as less than 1s, the minimum time unit recorded in CH□ Trigger detection time (Un\G1154 to Un\G1185) is second. Use trigger detection time as an indication to refer to the logging data.

*1 When the hold trigger is detected as soon as turning on the programmable controller, the CT input module may not obtain the time in the CPU module. If the module could not obtain the time, the trigger detection time is recorded "0:0:0 on January 1st, 2000".

Trigger detection time is stored in the following buffer memory areas.

Channel	Address for trigger detection time
CH1	CH1 Trigger detection time (Un\G1154 to Un\G1157)
CH2	CH2 Trigger detection time (Un\G1158 to Un\G1161)
CH3	CH3 Trigger detection time (Un\G1162 to Un\G1165)
CH4	CH4 Trigger detection time (Un\G1166 to Un\G1169)
CH5	CH5 Trigger detection time (Un\G1170 to Un\G1173)
CH6	CH6 Trigger detection time (Un\G1174 to Un\G1177)
CH7	CH7 Trigger detection time (Un\G1178 to Un\G1181)
CH8	CH8 Trigger detection time (Un\G1182 to Un\G1185)

Ex. For CH1 Trigger detection time (Un\G1154 to Un\G1157)

	b15 to b8	b7 to b0
Un\G1154	First two digits of the year	Last two digits of the year
Un\G1155	Month	Day
Un\G1156	Hour	Minute
Un\G1157	Second	Day of the week

Item	Stored data	Storage example *1
First two digits of the year/Last two digits of the year	Stored in BCD code.	2011 _H
Month/Day		329 _H
Hour/Minute		1035 _H
Second		40 _H
Day of the week	The value that corresponds to the day of the week is stored in BCD code. <ul style="list-style-type: none"> • Sunday: 00 • Monday: 01 • Tuesday: 02 • Wednesday: 03 • Thursday: 04 • Friday: 05 • Saturday: 06 	02 _H


*1 Those are values when a hold trigger was detected at 10:35:40 on Tuesday, March 29th, 2011.

(8) Checking logging data

Logging data are stored in the following buffer memory areas.

Channel	Collectable data		Storage area of logging data	
	Buffer memory name	Buffer memory address	Buffer memory name	Buffer memory address
CH1	CH□ Digital output value	Un\G11	CH□ Logging data	Un\G5000 to Un\G9999
CH2		Un\G12		Un\G10000 to Un\G14999
CH3		Un\G13		Un\G15000 to Un\G19999
CH4		Un\G14		Un\G20000 to Un\G24999
CH5		Un\G15		Un\G25000 to Un\G29999
CH6		Un\G16		Un\G30000 to Un\G34999
CH7		Un\G17		Un\G35000 to Un\G39999
CH8		Un\G18		Un\G40000 to Un\G44999
CH1	CH□ Scaling value	Un\G54		Un\G5000 to Un\G9999
CH2		Un\G55		Un\G10000 to Un\G14999
CH3		Un\G56		Un\G15000 to Un\G19999
CH4		Un\G57		Un\G20000 to Un\G24999
CH5		Un\G58		Un\G25000 to Un\G29999
CH6		Un\G59		Un\G30000 to Un\G34999
CH7		Un\G60		Un\G35000 to Un\G39999
CH8		Un\G61		Un\G40000 to Un\G44999

1. Check the number of valid logging data with CH□ Number of logging data (Un\G1106 to Un\G1113).




2. Check where the latest data and the oldest data are stored.

The places can be checked in the following buffer memory areas.


- CH□ Head pointer (Un\G1090 to Un\G1097) (☞ Page 133, Section 6.2 (43))
- CH□ Latest pointer (Un\G1098 to Un\G1105) (☞ Page 134, Section 6.2 (44))

Ex. When data was collected 5001 times or more



3. Check the storage place of when the logging stopped in CH□ Trigger pointer (Un\G1114 to Un\G1121).

- Ex.** When the logging stopped under the following conditions
 CH□ Logging points after trigger (Un\G1048 to Un\G1055): 1505 points
 Logging hold request: At the 3500th data
 (The hold place is determined as the 5th data.)




(9) Resuming the logging

To resume the logging, set OFF (0) to CH□ Logging hold request (Un\G1008 to Un\G1015). The logging resumes from the head of the logging data storage area.


At this time, the head pointer, latest pointer, number of logging data, and trigger pointer are cleared, and OFF (0) is stored in CH□ Logging hold flag (Un\G1016 to Un\G1023).

(a) Precautions

- It may take some time from when ON (1) is stored in CH□ Logging hold request (Un\G1008 to Un\G1015) till when ON (1) is set to CH□ Logging hold flag (Un\G1016 to Un\G1023). To resume the logging, set OFF (0) to CH□ Logging hold request (Un\G1008 to Un\G1015) after checking ON (1) is stored in CH□ Logging hold flag (Un\G1016 to Un\G1023).



- When OFF (0) is set to CH□ Logging hold request (Un\G1008 to Un\G1015) before ON (1) is stored in CH□ Logging hold flag (Un\G1016 to Un\G1023), the logging does not stop.



(b) Each buffer memory when logging resumes

When the logging resumes, the value in each buffer memory area is as below.

Buffer memory	Value status
CH□ Head pointer (Un\G1090 to Un\G1097)	Values are initialized (Initial value: 0).
CH□ Latest pointer (Un\G1098 to Un\G1105)	
CH□ Number of logging data (Un\G1106 to Un\G1113)	
CH□ Trigger pointer (Un\G1114 to Un\G1121)	
CH□ Logging data (Un\G5000 to Un\G44999)	The values before the logging resumption are stored.* ¹

*¹ After the logging resumed, values are stored starting from the head area of the logging data storage area. The values before the logging resumption are stored in CH□ Logging data (Un\G5000 to Un\G44999). To refer to the logging data, check the valid data with CH□ Number of logging data (Un\G1106 to Un\G1113).

(10) To check logging data without stopping logging

Logging data can be checked during the logging. When checking the logging data on a display device, the data can be checked easily by monitoring the buffer memory without stopping logging on the display device.

To check the logging data, adjust the logging cycle to prevent the logging data from being updated during read.

(a) Checking method

Read the logging data monitoring the storage places of the latest data and the oldest data in the following buffer memory areas.

Buffer memory	Description	Reference
CH□ Head pointer (Un\G1090 to Un\G1097)	Check where the oldest data is stored counting from the head address in the logging data storage area.	Page 133, Section 6.2 (43)
CH□ Latest pointer (Un\G1098 to Un\G1105)	Check where the latest data is stored counting from the head address in the logging data storage area.	Page 134, Section 6.2 (44)
CH□ Number of logging data (Un\G1106 to Un\G1113)	Check the number of data stored in the logging data storage area.	Page 134, Section 6.2 (45)

(b) Precautions

- Set CH□ Logging cycle setting value (Un\G1032 to Un\G1039) so that the data can be checked and read before the logging data are updated. If the logging cycle is short, logging data may be updated while the data are checked or read.
- After the necessary data are logged, monitor the change of the head pointer and the number of logging data, and obtain logging data after the stored value changes.
- If the update of the data and the data being checked do not synchronize due to the logging cycle and the scan time of the CPU module, adjust the logging cycle.
- To check data regardless of the logging cycle, use the logging hold.

4.13 Set Value Backup Function

Set values in the buffer memory can be backed up into the non-volatile memory.

The backup data are restored to the buffer memory when the power is turned off then on or when the CPU module is reset. Therefore, the Initial setting program does not need to be reset.

(1) Condition

Use the set value backup function in a condition where no digital conversion is performed; set Disable (1) to Conversion enable/disable setting (Un\G0) for all channels.

Check that digital conversion is disabled by confirming Converting or unused (0) is stored in Conversion completed flag (Un\G10).

If the set value backup function is used when digital conversion is in process in even one channel, the error code (115) is stored in Latest error code (Un\G19), and Error flag (XF) turns on. In this case, the set values are not backed up.

(2) Corresponding buffer memory data

Buffer memory areas that correspond to this function are marked with ○ in the list of buffer memory addresses ( Page 91, Section 6.1).

(3) How to use

1. Set Disable (1) to Conversion enable/disable setting (Un\G0) for all channels.
2. Turn on then off Operating condition setting request (Y9).
3. Turn on then off Set value backup request (Y6).

For details on Set value backup request (Y6), refer to the following.

- Output signal ( Page 89, Section 5.2.2)

(4) Precautions after executing the set value backup function

After the set value backup function was executed, the data restored to the buffer memory when the power was turned off then on or when the CPU module was reset, are overwritten if the parameter settings on GX Works2 are changed.

Do not change parameter settings on GX Works2 after executing the set value backup function.

4.14 Default Setting Registration Function

Values in the buffer memory can be changed back to the default.

(1) Condition

Use the default setting registration function in a condition where no digital conversion is performed; set Disable (1) to Conversion enable/disable setting (Un\G0) for all channels.

Check that digital conversion is disabled by confirming Converting or unused (0) is stored in Conversion completed flag (Un\G10).

If the default setting registration function is used when digital conversion is in process in even one channel, the error code (116) is stored in Latest error code (Un\G19), and Error flag (XF) turns on. In this case, the values in the buffer memory do not change back to the default.

(2) Corresponding buffer memory data and default values

Buffer memory areas that correspond to this function are marked with ○ in the list of buffer memory addresses (☞ Page 91, Section 6.1); the corresponding data are the same as those for the set value backup function. Also, the default values are listed in the same table.

(3) How to use

1. Set Disable (1) to Conversion enable/disable setting (Un\G0) for all channels.
2. Turn on then off Operating condition setting request (Y9).
3. Turn on then off Default setting request (Y5). (This operation reads default values to the buffer memory.)
4. Change values in the buffer memory if necessary.
5. Activate the set data by turning on then off Operating condition setting request (Y9).

For details on Default setting request (Y5), refer to the following.

- Output signal (☞ Page 89, Section 5.2.2)

4.15 Error History Function

Errors and alarms that occurred in the CT input module are stored in the buffer memory (Un\G1810 to Un\G1969) as a history.

The maximum of 16 errors and alarms can be stored.

(1) Process of the error history function

The error code and the error time are stored in the buffer memory area, starting from Error history No.1 (start address: Un\G1810) in order. Error time is stored as follows.

Ex. For error history No. 1

	b15	to	b8	b7	to	b0
Un\G1810	Error code					
Un\G1811	First two digits of the year			Last two digits of the year		
Un\G1812	Month			Day		
Un\G1813	Hour			Minute		
Un\G1814	Second			Day of the week		
Un\G1815	System area					
⋮						
⋮						
Un\G1819						

Item	Stored data	Example *1
First two digits of the year/Last two digits of the year	Stored in BCD code.	2011 _H
Month/Day		329 _H
Hour/Minute		1035 _H
Second		40 _H
Day of the week	The value that corresponds to the day of the week is stored in BCD code. • Sunday: 00 • Monday: 01 • Tuesday: 02 • Wednesday: 03 • Thursday: 04 • Friday: 05 • Saturday: 06	02 _H

*1 This is the example of error occurrence at 10:35:40 on Tuesday, March 29th, 2011.

Point


- The process for an alarm is the same as the one for an error.
- Once the error history storage is full, existing data are overwritten, starting from those in Error history No.1 (Un\G1810 to Un\G1819) in order; a new error history replaces existing one.
- The stored error history is cleared when the power is turned off or the CPU module is reset.

(2) Checking the error history

The start address of the latest error history can be checked in Latest address of error history (Un\G1800).


Ex. 1: When the third error occurred

The third error is stored in Error history No.3, and the value "1830" (start address of error history No.3) is stored in Latest address of error history (Un\G1800).




Ex. 2: When the 17th error occurred

The 17th error is stored in Error history No.1, and the value "1810" (start address of error history No.1) is stored in Latest address of error history (Un\G1800).



4.16 Module Error Collection Function

Errors and alarms occurred in the CT input module can be collected into the CPU module. The error information of the CT input module can be held in a CPU module memory as a module error history, even when the power is turned off or the CPU module is reset.



[Example of screen display]

No.	Error Code	Date and Time	Model Name	Start I/O
00189	0065	2012/02/13 04:24:28	Q68CT	0000
00187	0141	2012/02/13 01:58:55	Q68CT	0000
00186	0141	2012/02/13 01:58:35	Q68CT	0000
00185	0141	2012/02/13 01:58:16	Q68CT	0000
00172	04B1	2012/02/08 22:02:12	Q68CT	0000
00171	0407	2012/02/08 20:58:19	Q68CT	0000
00170	0407	2012/02/08 20:58:19	Q68CT	0000



For details on the module error collection function, refer to the following.
 QnUCPU Module User's Manual (Function Explanation, Program Fundamentals)

(1) Compatible version

The following table lists the versions of CPU modules and GX Works2 compatible with the module error collection function.

Item	Version
CPU module	Universal model QCPU with a serial number (first five digits) of "11043" or later
GX Works2	Version 1.09K or later

4.17 Error Clear Function

When an error occurs, the error can be cleared on the system monitor.


By clicking the **Error Clear** button in the system monitor, the latest error code stored in Latest error code (Un\G19) is cleared, and the ERR. LED turns off. This operation is the same as the one that uses Error clear request (YF).

However, the error history cannot be cleared with the button.

For the error clearing method using Error clear request (YF), refer to the following.

- Error clear request (YF) (👉 Page 90, Section 5.2.2 (7))

🖱️ [Diagnostics] ⇨ [System Monitor...] ⇨ Error Module



CHAPTER 5 I/O SIGNALS ASSIGNED TO THE CPU MODULE

This chapter describes the CT input module I/O signals assigned to the CPU module.

5.1 I/O Signal List

The following shows the list of the CT input module I/O signals.

The device numbers (X/Y) in the following table show the case that the start I/O number of the CT input module is set to 0.

For the details of I/O signals, refer to the following.

- Details of I/O Signals (☞ Page 80, Section 5.2)

Input signal		Output signal	
Device number	Signal name	Device number	Signal name
X0	Module READY	Y0	Use prohibited
X1	Use prohibited	Y1	
X2		Y2	
X3		Y3	
X4			Y4
X5	Default setting completed flag	Y5	Default setting request
X6	Set value backup completed flag	Y6	Set value backup request
X7	Peak current detection signal	Y7	Use prohibited
X8	Warning output signal	Y8	
X9	Operating condition setting completed flag	Y9	Operating condition setting request
XA	Offset/gain setting mode flag	YA	User range write request
XB	Channel change completed flag	YB	Channel change request
XC	Input signal error detection signal	YC	Use prohibited
XD	Maximum value/minimum value reset completed flag	YD	Maximum value/minimum value reset request
XE	Conversion completed flag	YE	Use prohibited
XF	Error flag	YF	Error clear request

5.2 Details of I/O Signals

The following describes the details of the CT input module I/O signals assigned to the CPU modules.

The I/O numbers (X/Y) described below show the case that the start I/O number of the CT input module is set to 0.

5.2.1 Input signal

(1) Module READY (X0)

Module READY (X0) turns on to indicate the preparation for the digital conversion is completed at the power-on or reset operation of the CPU module.


Module READY (X0) turns off in the following cases.

- When the offset/gain setting mode is set (The digital conversion processing is executed.)
- When a watchdog timer error occurs in the CT input module (The digital conversion processing is not executed.)

(2) Default setting completed flag (X5)

Use Default setting completed flag (X5) as an interlock condition to turn on then off Default setting request (Y5). When the buffer memory settings return to the default by turning on Default setting request (Y5), Default setting completed flag (X5) turns on. When Default setting request (Y5) is turned off, Default setting completed flag (X5) also turns off.

The buffer memory areas which return to the default value are with ○ in the "Set value backup area" in the List of Buffer Memory Addresses (☞ Page 91, Section 6.1).



Point

The setting of buffer memory areas whose default value is read becomes valid by changing the value as necessary and turning on then off Operating condition setting request (Y9).


(3) Set value backup completed flag (X6)

Use Set value backup completed flag (X6) as an interlock condition to turn on then off Set value backup request (Y6).

The buffer memory areas whose set values are backed up are with ○ in "Set value backup area" in the List of Buffer Memory Addresses (☞ Page 91, Section 6.1).

(a) When writing succeeded

When the set value of each buffer memory area is written to the non-volatile memory by turning on Set value backup request (Y6), Set value backup completed flag (X6) turns on. When Set value backup request (Y6) is turned off, Set value backup completed flag (X6) also turns off.




(b) When writing fails

When writing the set value of each buffer memory area failed by turning on Set value backup request (Y6), the error (error code: 114) occurs and the CT input module operates as follows.

- Set value backup completed flag (X6) turns on.
- Error flag (XF) turns on.
- The ERR. LED turns on.

When Set value backup request (Y6) is turned off, Set value backup completed flag (X6) also turns off.



(4) Peak current detection signal (X7)

Peak current detection signal (X7) turns on when a peak current is detected.

A peak current is detected only when the peak current detection function is enabled.

For details on the peak current detection function, refer to the following.

- Peak Current Detection Function (📖 Page 46, Section 4.7)


(a) Turning on Peak current detection signal (X7)

When digital output values exceed the set peak current detection value consecutively for the duration of the peak current detection time set in advance, Peak current detection signal (X7) turns on. The ALM LED also flashes.

(b) Turning off Peak current detection signal (X7)

Peak current detection signal (X7) turns off by turning on then off Error clear request (YF).

In addition, Latest error code (Un\G19) is cleared and the ALM LED turns off.



(5) Warning output signal (X8)

Warning output signal (X8) turns on when the process alarm or rate alarm has been detected. The process alarm and rate alarm can be detected only when the warning output function is enabled. For details on the warning output function, refer to the following.


- Warning Output Function (☞ Page 53, Section 4.10)

(a) Process alarm

- Warning output signal (X8) turns on when a digital output value exceeds the set range for CH1 Process alarm lower limit value (Un\G86) to CH8 Process alarm upper limit value (Un\G117). The ALM LED also turns on along with the on of the signal.
- Warning output signal (X8) turns off when the digital output value falls within the setting range for all the digital conversion enabled channels. The ALM LED also turns off.

(b) Rate alarm

- Warning output signal (X8) turns on when a digital output value exceeds the change rate of CH1 Rate alarm upper limit value (Un\G126) to CH8 Rate alarm lower limit value (Un\G141). The ALM LED also turns on.
- Warning output function turns off when the change of the digital output value falls within the setting range for all the digital conversion enabled channels. The ALM LED also turns off.




(6) Operating condition setting completed flag (X9)

When changing the following settings, use Operating condition setting completed flag (X9) as an interlock condition to turn on then off Operating condition setting request (Y9).

- Conversion enable/disable setting (Un\G0)
- CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)
- Averaging process setting (Un\G24, Un\G25)
- Sampling cycle setting (Un\G26)
- Input signal error detection setting (Un\G47)
- Warning output setting (Un\G48)
- Scaling enable/disable setting (Un\G53)
- CH□ Scaling lower limit value (Un\G62, Un\G64, Un\G66, Un\G68, Un\G70, Un\G72, Un\G74, Un\G76)
- CH□ Scaling upper limit value (Un\G63, Un\G65, Un\G67, Un\G69, Un\G71, Un\G73, Un\G75, Un\G77)
- CH□ Process alarm lower lower limit value (Un\G86, Un\G90, Un\G94, Un\G98, Un\G102, Un\G106, Un\G110, Un\G114)
- CH□ Process alarm lower upper limit value (Un\G87, Un\G91, Un\G95, Un\G99, Un\G103, Un\G107, Un\G111, Un\G115)
- CH□ Process alarm upper lower limit value (Un\G88, Un\G92, Un\G96, Un\G100, Un\G104, Un\G108, Un\G112, Un\G116)
- CH□ Process alarm upper upper limit value (Un\G89, Un\G93, Un\G97, Un\G101, Un\G105, Un\G109, Un\G113, Un\G117)
- CH□ Rate alarm warning detection period (Un\G118 to Un\G125)
- CH□ Rate alarm upper limit value (Un\G126, Un\G128, Un\G130, Un\G132, Un\G134, Un\G136, Un\G138, Un\G140)
- CH□ Rate alarm lower limit value (Un\G127, Un\G129, Un\G131, Un\G133, Un\G135, Un\G137, Un\G139, Un\G141)
- CH□ Input range setting (Un\G150 to Un\G157)
- Mode switching setting (Un\G158, Un\G159)
- Dropout detection setting (Un\G160)
- CH□ Dropout value (Un\G162 to Un\G169)
- Peak current detection setting (Un\G300)
- CH□ Peak current detection time (Un\G318 to Un\G325)
- CH□ Peak current detection value (Un\G326 to Un\G333)
- CH□ Logging enable/disable setting (Un\G1000 to Un\G1007)
- CH□ Logging data setting (Un\G1024 to Un\G1031)
- CH□ Logging cycle setting value (Un\G1032 to Un\G1039)
- CH□ Logging cycle unit setting (Un\G1040 to Un\G1047)
- CH□ Logging points after trigger (Un\G1048 to Un\G1055)
- CH□ Level trigger condition setting (Un\G1056 to Un\G1063)
- CH□ Trigger data (Un\G1064 to Un\G1071)
- CH□ Trigger setting value (Un\G1082 to Un\G1089)

When Operating condition setting completed flag (X9) is off, the digital conversion processing is not executed. Operating condition setting completed flag (X9) turns off in the following status.

- When Operating condition setting request (Y9) is on




(7) Offset/gain setting mode flag (XA)

(a) Offset/gain setting mode

When registering the value which was adjusted with the offset/gain setting to the module, use Offset/gain setting mode flag (XA) as an interlock condition to turn on then off User range write request (YA).

For the offset/gain setting, refer to the following.

- Offset/gain Setting (☞ Page 150, Section 8.5)




(b) Normal mode

At the user range setting restoration, use Offset/gain setting mode flag (XA) as an interlock condition to turn on then off User range write request (YA).

For the user range setting restoration, refer to the following.

- ONLINE MODULE CHANGE (☞ Page 182, CHAPTER 10)




(8) Channel change completed flag (XB)

When changing a channel to perform the offset/gain setting, use Channel change completed flag (XB) as an interlock condition to turn on then off Channel change request (YB).

For the offset/gain setting, refer to the following.

- Offset/gain Setting (☞ Page 150, Section 8.5)



(9) Input signal error detection signal (XC)

Input signal error detection signal (XC) turns on when an input signal error is detected.

An input signal error is detected only when the input signal error detection function is enabled.

For details on the input signal error detection function, refer to the following.

- Input Signal Error Detection Function (☞ Page 44, Section 4.6)

(a) Turning on Input signal error detection signal (XC)

Input signal error detection signal (XC) turns on when the CT input value exceeds the input range.

The CT input module results in the following states:


- Converting or unused (0) is stored in Conversion completed flag (Un\G10) in the corresponding channel.
- For the error detected channel, the digital output value just before the error detection is held in the buffer memory.
- ALM LED flashes.

(b) Turning off Input signal error detection signal (XC)

When the CT input value falls within the input range, turn on then off Error clear request (YF) to turn off Input signal error detection signal (XC).

The CT input module results in the following states:

- ALM LED turns off.
- Latest error code (Un\G19) is cleared.



Point


When the CT input value falls within the input range, the digital conversion resumes regardless of the status of Input signal error detection flag (Un\G49) and Input signal error detection signal (XC). After the first update of the digital output value, Conversion completed (1) is stored in Conversion completed flag (Un\G10) in the corresponding channel. (ALM LED remains flashing.)

Averaging processing starts over after the digital conversion resumed.

(10) Maximum value/minimum value reset completed flag (XD)

Maximum value/minimum value reset completed flag (XD) turns on after the maximum or minimum values stored in the following buffer memory areas by turning on then off Maximum value/minimum value reset request (YD).

- CH□ Maximum value (Un\G30, Un\G32, Un\G34, Un\G36, Un\G38, Un\G40, Un\G42, Un\G44)
- CH□ Minimum value (Un\G31, Un\G33, Un\G35, Un\G37, Un\G39, Un\G41, Un\G43, Un\G45)




(11) Conversion completed flag (XE)

Conversion completed flag (XE) turns on when the first digital conversion is completed in all conversion enabled channels.

(12) Error flag (XF)

Error flag (XF) turns on when an error occurs.



(a) Clearing the latest error code and Error flag (XF)

Turn on then off Error clear request (YF).

5.2.2 Output signal

(1) Default setting request (Y5)

Turn on then off Default setting request (Y5) to return the present set value of buffer memory areas to the default value.

For the buffer memory areas which return to the default value, refer to the following.

- List of Buffer Memory Addresses (☞ Page 91, Section 6.1)

For the timing of turning on then off the signal, refer to the following.

- Default setting completed flag (X5) (☞ Page 80, Section 5.2.1 (2))

When turning off then on Default setting request (Y5), set Disable (1) to the setting values of Conversion enable/disable setting (Un\G0) in all the channels and confirm that the digital conversion of the CT input module stops in all channels.

At stopping the digital conversion, confirm if Converting or unused (0) is stored in Conversion completed flag (Un\G10).

If Default setting request (Y5) is turned off then on for any of the channels while the digital conversion is performed, the error code (116) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. The present set values of the buffer memory areas do not return to the default value.

(2) Set value backup request (Y6)

Turn on then off Set value backup request (Y6) to backup the present set value of the buffer memory areas to the non-volatile memory.

For the buffer memory areas in which the set value is backed up, refer to the following.

- List of Buffer Memory Addresses (☞ Page 91, Section 6.1)

For the timing of turning on then off the signal, refer to the following.

- Set value backup completed flag (X6) (☞ Page 81, Section 5.2.1 (3))

When turning off then on Set value backup request (Y6), set Disable (1) to the setting values of Conversion enable/disable setting (Un\G0) in all the channels and confirm that the digital conversion of the CT input module stops in all channels.

At stopping the digital conversion, confirm if Converting or unused (0) is stored in Conversion completed flag (Un\G10).

If Set value backup request (Y6) is turned off then on for any of the channels while the digital conversion is performed, the error code (115) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. The set value is not backed up.

(3) Operating condition setting request (Y9)

To enable the initial settings of the CT input module, turn on then off Operating condition setting request (Y9).

For the contents of the initial settings to be enabled and the timing of turning on then off the signal, refer to the following.

- Operating condition setting completed flag (X9) (☞ Page 84, Section 5.2.1 (6))

(4) User range write request (YA)

(a) Offset/gain setting mode

Turn on then off User range write request (YA) to register the adjusted offset/gain values in the CT input module.

The data is written to the non-volatile memory at the timing when this signal is turned off then on.

For the timing of turning on then off the signal, refer to the following.

- Offset/gain setting mode flag (XA) (☞ Page 85, Section 5.2.1 (7))

(b) Normal mode

Turn on then off User range write request (YA) to perform the user range restoration.

For the timing of turning on then off the signal, refer to the following.

- Offset/gain setting mode flag (XA) (☞ Page 85, Section 5.2.1 (7))

(5) Channel change request (YB)

Turn on then off Channel change request (YB) to change a channel for which the offset/gain setting is set.

For the timing of turning on then off the signal, refer to the following.

- Channel change completed flag (XB) (☞ Page 86, Section 5.2.1 (8))

(6) Maximum value/minimum value reset request (YD)

Turn on then off Maximum value/minimum value reset request (YD) to clear the values of the following buffer memory areas.

- CH□ Maximum value (Un\G30, Un\G32, Un\G34, Un\G36, Un\G38, Un\G40, Un\G42, Un\G44)
- CH□ Minimum value (Un\G31, Un\G33, Un\G35, Un\G37, Un\G39, Un\G41, Un\G43, Un\G45)

For the timing of turning on then off the signal, refer to the following.

- Maximum value/minimum value reset completed flag (XD) (☞ Page 88, Section 5.2.1 (10))

(7) Error clear request (YF)

To clear the following contents, turn on then off Error clear request (YF).

- Peak current detection signal (X7)
- Input signal error detection signal (XC)
- Error flag (XF)
- Latest error code (Un\G19)

For the timing to clear the contents, refer to the following.

- Peak current detection signal (X7) (☞ Page 82, Section 5.2.1 (4))
- Input signal error detection signal (XC) (☞ Page 87, Section 5.2.1 (9))
- Error flag (XF) (☞ Page 88, Section 5.2.1 (12))
- Latest error code (Un\G19) (☞ Page 88, Section 5.2.1 (12))

CHAPTER 6 BUFFER MEMORY

This chapter describes the buffer memory of the CT input module.

6.1 List of Buffer Memory Addresses

The following shows the list of the CT input module buffer memory addresses.

For details of buffer memory addresses, refer to the following.

- Details of Buffer Memory Addresses (☞ Page 106, Section 6.2)

Point

Do not write data to the system area and the area where the data cannot be written from the sequence program in the buffer memory.

Writing data to those areas may lead the module to malfunction.

(1) Un\G0 to Un\G1799

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3
0	0 _H	Conversion enable/disable setting	00FF _H	R/W	—
1	1 _H	CH1 Average time/Average number of times/Moving average/Time constant settings	0	R/W	○
2	2 _H	CH2 Average time/Average number of times/Moving average/Time constant settings	0	R/W	○
3	3 _H	CH3 Average time/Average number of times/Moving average/Time constant settings	0	R/W	○
4	4 _H	CH4 Average time/Average number of times/Moving average/Time constant settings	0	R/W	○
5	5 _H	CH5 Average time/Average number of times/Moving average/Time constant settings	0	R/W	○
6	6 _H	CH6 Average time/Average number of times/Moving average/Time constant settings	0	R/W	○
7	7 _H	CH7 Average time/Average number of times/Moving average/Time constant settings	0	R/W	○
8	8 _H	CH8 Average time/Average number of times/Moving average/Time constant settings	0	R/W	○
9	9 _H	System area	—	—	—
10	A _H	Conversion completed flag	0000 _H	R	—
11	B _H	CH1 Digital output value	0	R	—
12	C _H	CH2 Digital output value	0	R	—
13	D _H	CH3 Digital output value	0	R	—
14	E _H	CH4 Digital output value	0	R	—
15	F _H	CH5 Digital output value	0	R	—
16	10 _H	CH6 Digital output value	0	R	—
17	11 _H	CH7 Digital output value	0	R	—

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3
18	12 _H	CH8 Digital output value	0	R	—
19	13 _H	Latest error code	0	R	—
20	14 _H	System area	—	—	—
21	15 _H				
22	16 _H	Offset/gain setting mode Offset specification	0000 _H	R/W	—
23	17 _H	Offset/gain setting mode Gain specification	0000 _H	R/W	—
24	18 _H	Averaging process setting (CH1 to CH4)	0000 _H	R/W	○
25	19 _H	Averaging process setting (CH5 to CH8)	0000 _H	R/W	○
26	1A _H	Sampling cycle setting	0000 _H	R/W	○
27 to 29	1B _H to 1D _H	System area	—	—	—
30	1E _H	CH1 Maximum value	0	R	—
31	1F _H	CH1 Minimum value	0	R	—
32	20 _H	CH2 Maximum value	0	R	—
33	21 _H	CH2 Minimum value	0	R	—
34	22 _H	CH3 Maximum value	0	R	—
35	23 _H	CH3 Minimum value	0	R	—
36	24 _H	CH4 Maximum value	0	R	—
37	25 _H	CH4 Minimum value	0	R	—
38	26 _H	CH5 Maximum value	0	R	—
39	27 _H	CH5 Minimum value	0	R	—
40	28 _H	CH6 Maximum value	0	R	—
41	29 _H	CH6 Minimum value	0	R	—
42	2A _H	CH7 Maximum value	0	R	—
43	2B _H	CH7 Minimum value	0	R	—
44	2C _H	CH8 Maximum value	0	R	—
45	2D _H	CH8 Minimum value	0	R	—
46	2E _H	System area	—	—	—
47	2F _H	Input signal error detection setting	00FF _H	R/W	○
48	30 _H	Warning output setting	FFFF _H	R/W	○
49	31 _H	Input signal error detection flag	0000 _H	R	—
50	32 _H	Warning output flag (Process alarm)	0000 _H	R	—
51	33 _H	Warning output flag (Rate alarm)	0000 _H	R	—
52	34 _H	System area	—	—	—
53	35 _H	Scaling enable/disable setting	00FF _H	R/W	○
54	36 _H	CH1 Scaling value	0	R	—
55	37 _H	CH2 Scaling value	0	R	—
56	38 _H	CH3 Scaling value	0	R	—
57	39 _H	CH4 Scaling value	0	R	—
58	3A _H	CH5 Scaling value	0	R	—

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3
59	3B _H	CH6 Scaling value	0	R	—
60	3C _H	CH7 Scaling value	0	R	—
61	3D _H	CH8 Scaling value	0	R	—
62	3E _H	CH1 Scaling lower limit value	0	R/W	○
63	3F _H	CH1 Scaling upper limit value	0	R/W	○
64	40 _H	CH2 Scaling lower limit value	0	R/W	○
65	41 _H	CH2 Scaling upper limit value	0	R/W	○
66	42 _H	CH3 Scaling lower limit value	0	R/W	○
67	43 _H	CH3 Scaling upper limit value	0	R/W	○
68	44 _H	CH4 Scaling lower limit value	0	R/W	○
69	45 _H	CH4 Scaling upper limit value	0	R/W	○
70	46 _H	CH5 Scaling lower limit value	0	R/W	○
71	47 _H	CH5 Scaling upper limit value	0	R/W	○
72	48 _H	CH6 Scaling lower limit value	0	R/W	○
73	49 _H	CH6 Scaling upper limit value	0	R/W	○
74	4A _H	CH7 Scaling lower limit value	0	R/W	○
75	4B _H	CH7 Scaling upper limit value	0	R/W	○
76	4C _H	CH8 Scaling lower limit value	0	R/W	○
77	4D _H	CH8 Scaling upper limit value	0	R/W	○
78 to 85	4E _H to 55 _H	System area	—	—	—
86	56 _H	CH1 Process alarm lower lower limit value	0	R/W	○
87	57 _H	CH1 Process alarm lower upper limit value	0	R/W	○
88	58 _H	CH1 Process alarm upper lower limit value	0	R/W	○
89	59 _H	CH1 Process alarm upper upper limit value	0	R/W	○
90	5A _H	CH2 Process alarm lower lower limit value	0	R/W	○
91	5B _H	CH2 Process alarm lower upper limit value	0	R/W	○
92	5C _H	CH2 Process alarm upper lower limit value	0	R/W	○
93	5D _H	CH2 Process alarm upper upper limit value	0	R/W	○
94	5E _H	CH3 Process alarm lower lower limit value	0	R/W	○
95	5F _H	CH3 Process alarm lower upper limit value	0	R/W	○
96	60 _H	CH3 Process alarm upper lower limit value	0	R/W	○
97	61 _H	CH3 Process alarm upper upper limit value	0	R/W	○
98	62 _H	CH4 Process alarm lower lower limit value	0	R/W	○
99	63 _H	CH4 Process alarm lower upper limit value	0	R/W	○
100	64 _H	CH4 Process alarm upper lower limit value	0	R/W	○
101	65 _H	CH4 Process alarm upper upper limit value	0	R/W	○
102	66 _H	CH5 Process alarm lower lower limit value	0	R/W	○
103	67 _H	CH5 Process alarm lower upper limit value	0	R/W	○
104	68 _H	CH5 Process alarm upper lower limit value	0	R/W	○

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3
105	69 _H	CH5 Process alarm upper upper limit value	0	R/W	○
106	6A _H	CH6 Process alarm lower lower limit value	0	R/W	○
107	6B _H	CH6 Process alarm lower upper limit value	0	R/W	○
108	6C _H	CH6 Process alarm upper lower limit value	0	R/W	○
109	6D _H	CH6 Process alarm upper upper limit value	0	R/W	○
110	6E _H	CH7 Process alarm lower lower limit value	0	R/W	○
111	6F _H	CH7 Process alarm lower upper limit value	0	R/W	○
112	70 _H	CH7 Process alarm upper lower limit value	0	R/W	○
113	71 _H	CH7 Process alarm upper upper limit value	0	R/W	○
114	72 _H	CH8 Process alarm lower lower limit value	0	R/W	○
115	73 _H	CH8 Process alarm lower upper limit value	0	R/W	○
116	74 _H	CH8 Process alarm upper lower limit value	0	R/W	○
117	75 _H	CH8 Process alarm upper upper limit value	0	R/W	○
118	76 _H	CH1 Rate alarm warning detection period	0	R/W	○
119	77 _H	CH2 Rate alarm warning detection period	0	R/W	○
120	78 _H	CH3 Rate alarm warning detection period	0	R/W	○
121	79 _H	CH4 Rate alarm warning detection period	0	R/W	○
122	7A _H	CH5 Rate alarm warning detection period	0	R/W	○
123	7B _H	CH6 Rate alarm warning detection period	0	R/W	○
124	7C _H	CH7 Rate alarm warning detection period	0	R/W	○
125	7D _H	CH8 Rate alarm warning detection period	0	R/W	○
126	7E _H	CH1 Rate alarm upper limit value	0	R/W	○
127	7F _H	CH1 Rate alarm lower limit value	0	R/W	○
128	80 _H	CH2 Rate alarm upper limit value	0	R/W	○
129	81 _H	CH2 Rate alarm lower limit value	0	R/W	○
130	82 _H	CH3 Rate alarm upper limit value	0	R/W	○
131	83 _H	CH3 Rate alarm lower limit value	0	R/W	○
132	84 _H	CH4 Rate alarm upper limit value	0	R/W	○
133	85 _H	CH4 Rate alarm lower limit value	0	R/W	○
134	86 _H	CH5 Rate alarm upper limit value	0	R/W	○
135	87 _H	CH5 Rate alarm lower limit value	0	R/W	○
136	88 _H	CH6 Rate alarm upper limit value	0	R/W	○
137	89 _H	CH6 Rate alarm lower limit value	0	R/W	○
138	8A _H	CH7 Rate alarm upper limit value	0	R/W	○
139	8B _H	CH7 Rate alarm lower limit value	0	R/W	○
140	8C _H	CH8 Rate alarm upper limit value	0	R/W	○
141	8D _H	CH8 Rate alarm lower limit value	0	R/W	○
142 to 149	8E _H to 95 _H	System area	—	—	—
150	96 _H	CH1 Input range setting	0000 _H	R/W	○

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3
151	97 _H	CH2 Input range setting	0000 _H	R/W	○
152	98 _H	CH3 Input range setting	0000 _H	R/W	○
153	99 _H	CH4 Input range setting	0000 _H	R/W	○
154	9A _H	CH5 Input range setting	0000 _H	R/W	○
155	9B _H	CH6 Input range setting	0000 _H	R/W	○
156	9C _H	CH7 Input range setting	0000 _H	R/W	○
157	9D _H	CH8 Input range setting	0000 _H	R/W	○
158	9E _H	Mode switching setting	0	R/W	—
159	9F _H				
160	A0 _H	Dropout detection setting	00FF _H	R/W	○
161	A1 _H	Dropout status flag	0000 _H	R	—
162	A2 _H	CH1 Dropout value	50	R/W	○
163	A3 _H	CH2 Dropout value	50	R/W	○
164	A4 _H	CH3 Dropout value	50	R/W	○
165	A5 _H	CH4 Dropout value	50	R/W	○
166	A6 _H	CH5 Dropout value	50	R/W	○
167	A7 _H	CH6 Dropout value	50	R/W	○
168	A8 _H	CH7 Dropout value	50	R/W	○
169	A9 _H	CH8 Dropout value	50	R/W	○
170 to 201	AA _H to C9 _H	System area	—	—	—
202	CA _H	CH1 Factory default setting offset value	0	R/W	—
203	CB _H	CH1 Factory default setting gain value	0	R/W	—
204	CC _H	CH2 Factory default setting offset value	0	R/W	—
205	CD _H	CH2 Factory default setting gain value	0	R/W	—
206	CE _H	CH3 Factory default setting offset value	0	R/W	—
207	CF _H	CH3 Factory default setting gain value	0	R/W	—
208	D0 _H	CH4 Factory default setting offset value	0	R/W	—
209	D1 _H	CH4 Factory default setting gain value	0	R/W	—
210	D2 _H	CH5 Factory default setting offset value	0	R/W	—
211	D3 _H	CH5 Factory default setting gain value	0	R/W	—
212	D4 _H	CH6 Factory default setting offset value	0	R/W	—
213	D5 _H	CH6 Factory default setting gain value	0	R/W	—
214	D6 _H	CH7 Factory default setting offset value	0	R/W	—
215	D7 _H	CH7 Factory default setting gain value	0	R/W	—
216	D8 _H	CH8 Factory default setting offset value	0	R/W	—
217	D9 _H	CH8 Factory default setting gain value	0	R/W	—
218	DA _H	CH1 User range setting offset value	0	R/W	—
219	DB _H	CH1 User range setting gain value	0	R/W	—
220	DC _H	CH2 User range setting offset value	0	R/W	—

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3
221	DD _H	CH2 User range setting gain value	0	R/W	—
222	DE _H	CH3 User range setting offset value	0	R/W	—
223	DF _H	CH3 User range setting gain value	0	R/W	—
224	E0 _H	CH4 User range setting offset value	0	R/W	—
225	E1 _H	CH4 User range setting gain value	0	R/W	—
226	E2 _H	CH5 User range setting offset value	0	R/W	—
227	E3 _H	CH5 User range setting gain value	0	R/W	—
228	E4 _H	CH6 User range setting offset value	0	R/W	—
229	E5 _H	CH6 User range setting gain value	0	R/W	—
230	E6 _H	CH7 User range setting offset value	0	R/W	—
231	E7 _H	CH7 User range setting gain value	0	R/W	—
232	E8 _H	CH8 User range setting offset value	0	R/W	—
233	E9 _H	CH8 User range setting gain value	0	R/W	—
234 to 299	EA _H to 12B _H	System area	—	—	—
300	12C _H	Peak current detection setting	00FF _H	R/W	○
301	12D _H	Peak current detection flag	0000 _H	R	—
302	12E _H	CH1 Peak current detection count reset request	0	R/W	—
303	12F _H	CH2 Peak current detection count reset request	0	R/W	—
304	130 _H	CH3 Peak current detection count reset request	0	R/W	—
305	131 _H	CH4 Peak current detection count reset request	0	R/W	—
306	132 _H	CH5 Peak current detection count reset request	0	R/W	—
307	133 _H	CH6 Peak current detection count reset request	0	R/W	—
308	134 _H	CH7 Peak current detection count reset request	0	R/W	—
309	135 _H	CH8 Peak current detection count reset request	0	R/W	—
310	136 _H	CH1 Peak current detection count reset complete	0	R	—
311	137 _H	CH2 Peak current detection count reset complete	0	R	—
312	138 _H	CH3 Peak current detection count reset complete	0	R	—
313	139 _H	CH4 Peak current detection count reset complete	0	R	—
314	13A _H	CH5 Peak current detection count reset complete	0	R	—
315	13B _H	CH6 Peak current detection count reset complete	0	R	—
316	13C _H	CH7 Peak current detection count reset complete	0	R	—
317	13D _H	CH8 Peak current detection count reset complete	0	R	—
318	13E _H	CH1 Peak current detection time	1000	R/W	○
319	13F _H	CH2 Peak current detection time	1000	R/W	○
320	140 _H	CH3 Peak current detection time	1000	R/W	○
321	141 _H	CH4 Peak current detection time	1000	R/W	○
322	142 _H	CH5 Peak current detection time	1000	R/W	○
323	143 _H	CH6 Peak current detection time	1000	R/W	○
324	144 _H	CH7 Peak current detection time	1000	R/W	○

Address (decimal)	Address (hexadecimal)	Name	Default value ^{*1}	Read/Write ^{*2}	Set value backup area ^{*3}
325	145 _H	CH8 Peak current detection time	1000	R/W	○
326	146 _H	CH1 Peak current detection value	0	R/W	○
327	147 _H	CH2 Peak current detection value	0	R/W	○
328	148 _H	CH3 Peak current detection value	0	R/W	○
329	149 _H	CH4 Peak current detection value	0	R/W	○
330	14A _H	CH5 Peak current detection value	0	R/W	○
331	14B _H	CH6 Peak current detection value	0	R/W	○
332	14C _H	CH7 Peak current detection value	0	R/W	○
333	14D _H	CH8 Peak current detection value	0	R/W	○
334	14E _H	CH1 Peak current detection count	0	R	—
335	14F _H	CH2 Peak current detection count	0	R	—
336	150 _H	CH3 Peak current detection count	0	R	—
337	151 _H	CH4 Peak current detection count	0	R	—
338	152 _H	CH5 Peak current detection count	0	R	—
339	153 _H	CH6 Peak current detection count	0	R	—
340	154 _H	CH7 Peak current detection count	0	R	—
341	155 _H	CH8 Peak current detection count	0	R	—
342 to 999	156 _H to 3E7 _H	System area	—	—	—
1000	3E8 _H	CH1 Logging enable/disable setting	1	R/W	○
1001	3E9 _H	CH2 Logging enable/disable setting	1	R/W	○
1002	3EA _H	CH3 Logging enable/disable setting	1	R/W	○
1003	3EB _H	CH4 Logging enable/disable setting	1	R/W	○
1004	3EC _H	CH5 Logging enable/disable setting	1	R/W	○
1005	3ED _H	CH6 Logging enable/disable setting	1	R/W	○
1006	3EE _H	CH7 Logging enable/disable setting	1	R/W	○
1007	3EF _H	CH8 Logging enable/disable setting	1	R/W	○
1008	3F0 _H	CH1 Logging hold request	0	R/W	—
1009	3F1 _H	CH2 Logging hold request	0	R/W	—
1010	3F2 _H	CH3 Logging hold request	0	R/W	—
1011	3F3 _H	CH4 Logging hold request	0	R/W	—
1012	3F4 _H	CH5 Logging hold request	0	R/W	—
1013	3F5 _H	CH6 Logging hold request	0	R/W	—
1014	3F6 _H	CH7 Logging hold request	0	R/W	—
1015	3F7 _H	CH8 Logging hold request	0	R/W	—
1016	3F8 _H	CH1 Logging hold flag	0	R	—
1017	3F9 _H	CH2 Logging hold flag	0	R	—
1018	3FA _H	CH3 Logging hold flag	0	R	—
1019	3FB _H	CH4 Logging hold flag	0	R	—
1020	3FC _H	CH5 Logging hold flag	0	R	—

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3
1021	3FD _H	CH6 Logging hold flag	0	R	—
1022	3FE _H	CH7 Logging hold flag	0	R	—
1023	3FF _H	CH8 Logging hold flag	0	R	—
1024	400 _H	CH1 Logging data setting	1	R/W	○
1025	401 _H	CH2 Logging data setting	1	R/W	○
1026	402 _H	CH3 Logging data setting	1	R/W	○
1027	403 _H	CH4 Logging data setting	1	R/W	○
1028	404 _H	CH5 Logging data setting	1	R/W	○
1029	405 _H	CH6 Logging data setting	1	R/W	○
1030	406 _H	CH7 Logging data setting	1	R/W	○
1031	407 _H	CH8 Logging data setting	1	R/W	○
1032	408 _H	CH1 Logging cycle setting value	300	R/W	○
1033	409 _H	CH2 Logging cycle setting value	300	R/W	○
1034	40A _H	CH3 Logging cycle setting value	300	R/W	○
1035	40B _H	CH4 Logging cycle setting value	300	R/W	○
1036	40C _H	CH5 Logging cycle setting value	300	R/W	○
1037	40D _H	CH6 Logging cycle setting value	300	R/W	○
1038	40E _H	CH7 Logging cycle setting value	300	R/W	○
1039	40F _H	CH8 Logging cycle setting value	300	R/W	○
1040	410 _H	CH1 Logging cycle unit setting	0	R/W	○
1041	411 _H	CH2 Logging cycle unit setting	0	R/W	○
1042	412 _H	CH3 Logging cycle unit setting	0	R/W	○
1043	413 _H	CH4 Logging cycle unit setting	0	R/W	○
1044	414 _H	CH5 Logging cycle unit setting	0	R/W	○
1045	415 _H	CH6 Logging cycle unit setting	0	R/W	○
1046	416 _H	CH7 Logging cycle unit setting	0	R/W	○
1047	417 _H	CH8 Logging cycle unit setting	0	R/W	○
1048	418 _H	CH1 Logging points after trigger	2500	R/W	○
1049	419 _H	CH2 Logging points after trigger	2500	R/W	○
1050	41A _H	CH3 Logging points after trigger	2500	R/W	○
1051	41B _H	CH4 Logging points after trigger	2500	R/W	○
1052	41C _H	CH5 Logging points after trigger	2500	R/W	○
1053	41D _H	CH6 Logging points after trigger	2500	R/W	○
1054	41E _H	CH7 Logging points after trigger	2500	R/W	○
1055	41F _H	CH8 Logging points after trigger	2500	R/W	○
1056	420 _H	CH1 Level trigger condition setting	0	R/W	○
1057	421 _H	CH2 Level trigger condition setting	0	R/W	○
1058	422 _H	CH3 Level trigger condition setting	0	R/W	○
1059	423 _H	CH4 Level trigger condition setting	0	R/W	○
1060	424 _H	CH5 Level trigger condition setting	0	R/W	○

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3
1061	425 _H	CH6 Level trigger condition setting	0	R/W	○
1062	426 _H	CH7 Level trigger condition setting	0	R/W	○
1063	427 _H	CH8 Level trigger condition setting	0	R/W	○
1064	428 _H	CH1 Trigger data	54	R/W	○
1065	429 _H	CH2 Trigger data	55	R/W	○
1066	42A _H	CH3 Trigger data	56	R/W	○
1067	42B _H	CH4 Trigger data	57	R/W	○
1068	42C _H	CH5 Trigger data	58	R/W	○
1069	42D _H	CH6 Trigger data	59	R/W	○
1070	42E _H	CH7 Trigger data	60	R/W	○
1071	42F _H	CH8 Trigger data	61	R/W	○
1072	430 _H	Level data 0	0	R/W	○
1073	431 _H	Level data 1	0	R/W	○
1074	432 _H	Level data 2	0	R/W	○
1075	433 _H	Level data 3	0	R/W	○
1076	434 _H	Level data 4	0	R/W	○
1077	435 _H	Level data 5	0	R/W	○
1078	436 _H	Level data 6	0	R/W	○
1079	437 _H	Level data 7	0	R/W	○
1080	438 _H	Level data 8	0	R/W	○
1081	439 _H	Level data 9	0	R/W	○
1082	43A _H	CH1 Trigger setting value	0	R/W	○
1083	43B _H	CH2 Trigger setting value	0	R/W	○
1084	43C _H	CH3 Trigger setting value	0	R/W	○
1085	43D _H	CH4 Trigger setting value	0	R/W	○
1086	43E _H	CH5 Trigger setting value	0	R/W	○
1087	43F _H	CH6 Trigger setting value	0	R/W	○
1088	440 _H	CH7 Trigger setting value	0	R/W	○
1089	441 _H	CH8 Trigger setting value	0	R/W	○
1090	442 _H	CH1 Head pointer	0	R	—
1091	443 _H	CH2 Head pointer	0	R	—
1092	444 _H	CH3 Head pointer	0	R	—
1093	445 _H	CH4 Head pointer	0	R	—
1094	446 _H	CH5 Head pointer	0	R	—
1095	447 _H	CH6 Head pointer	0	R	—
1096	448 _H	CH7 Head pointer	0	R	—
1097	449 _H	CH8 Head pointer	0	R	—
1098	44A _H	CH1 Latest pointer	0	R	—
1099	44B _H	CH2 Latest pointer	0	R	—
1100	44C _H	CH3 Latest pointer	0	R	—
1101	44D _H	CH4 Latest pointer	0	R	—

Address (decimal)	Address (hexadecimal)	Name	Default value *1	Read/Write *2	Set value backup area *3	
1102	44E _H	CH5 Latest pointer	0	R	—	
1103	44F _H	CH6 Latest pointer	0	R	—	
1104	450 _H	CH7 Latest pointer	0	R	—	
1105	451 _H	CH8 Latest pointer	0	R	—	
1106	452 _H	CH1 Number of logging data	0	R	—	
1107	453 _H	CH2 Number of logging data	0	R	—	
1108	454 _H	CH3 Number of logging data	0	R	—	
1109	455 _H	CH4 Number of logging data	0	R	—	
1110	456 _H	CH5 Number of logging data	0	R	—	
1111	457 _H	CH6 Number of logging data	0	R	—	
1112	458 _H	CH7 Number of logging data	0	R	—	
1113	459 _H	CH8 Number of logging data	0	R	—	
1114	45A _H	CH1 Trigger pointer	0	R	—	
1115	45B _H	CH2 Trigger pointer	0	R	—	
1116	45C _H	CH3 Trigger pointer	0	R	—	
1117	45D _H	CH4 Trigger pointer	0	R	—	
1118	45E _H	CH5 Trigger pointer	0	R	—	
1119	45F _H	CH6 Trigger pointer	0	R	—	
1120	460 _H	CH7 Trigger pointer	0	R	—	
1121	461 _H	CH8 Trigger pointer	0	R	—	
1122	462 _H	CH1 Logging cycle monitoring value	(s)	0	R	—
1123	463 _H		(ms)	0	R	—
1124	464 _H		(μs)	0	R	—
1125	465 _H	CH2 Logging cycle monitoring value	(s)	0	R	—
1126	466 _H		(ms)	0	R	—
1127	467 _H		(μs)	0	R	—
1128	468 _H	CH3 Logging cycle monitoring value	(s)	0	R	—
1129	469 _H		(ms)	0	R	—
1130	46A _H		(μs)	0	R	—
1131	46B _H	CH4 Logging cycle monitoring value	(s)	0	R	—
1132	46C _H		(ms)	0	R	—
1133	46D _H		(μs)	0	R	—
1134	46E _H	CH5 Logging cycle monitoring value	(s)	0	R	—
1135	46F _H		(ms)	0	R	—
1136	470 _H		(μs)	0	R	—
1137	471 _H	CH6 Logging cycle monitoring value	(s)	0	R	—
1138	472 _H		(ms)	0	R	—
1139	473 _H		(μs)	0	R	—
1140	474 _H	CH7 Logging cycle monitoring value	(s)	0	R	—
1141	475 _H		(ms)	0	R	—
1142	476 _H		(μs)	0	R	—

Address (decimal)	Address (hexadecimal)	Name		Default value *1	Read/Write *2	Set value backup area *3	
1143	477 _H	CH8 Logging cycle monitoring value	(s)	0	R	—	
1144	478 _H		(ms)	0	R	—	
1145	479 _H		(μs)	0	R	—	
1146 to 1153	47A _H to 481 _H	System area		—	—	—	
1154	482 _H	CH1 Trigger detection time	First two digits of the year	Last two digits of the year	0	R	—
1155	483 _H		Month	Day	0	R	—
1156	484 _H		Hour	Minute	0	R	—
1157	485 _H		Second	Day of the week	0	R	—
1158	486 _H	CH2 Trigger detection time	First two digits of the year	Last two digits of the year	0	R	—
1159	487 _H		Month	Day	0	R	—
1160	488 _H		Hour	Minute	0	R	—
1161	489 _H		Second	Day of the week	0	R	—
1162	48A _H	CH3 Trigger detection time	First two digits of the year	Last two digits of the year	0	R	—
1163	48B _H		Month	Day	0	R	—
1164	48C _H		Hour	Minute	0	R	—
1165	48D _H		Second	Day of the week	0	R	—
1166	48E _H	CH4 Trigger detection time	First two digits of the year	Last two digits of the year	0	R	—
1167	48F _H		Month	Day	0	R	—
1168	490 _H		Hour	Minute	0	R	—
1169	491 _H		Second	Day of the week	0	R	—
1170	492 _H	CH5 Trigger detection time	First two digits of the year	Last two digits of the year	0	R	—
1171	493 _H		Month	Day	0	R	—
1172	494 _H		Hour	Minute	0	R	—
1173	495 _H		Second	Day of the week	0	R	—
1174	496 _H	CH6 Trigger detection time	First two digits of the year	Last two digits of the year	0	R	—
1175	497 _H		Month	Day	0	R	—
1176	498 _H		Hour	Minute	0	R	—
1177	499 _H		Second	Day of the week	0	R	—
1178	49A _H	CH7 Trigger detection time	First two digits of the year	Last two digits of the year	0	R	—
1179	49B _H		Month	Day	0	R	—
1180	49C _H		Hour	Minute	0	R	—
1181	49D _H		Second	Day of the week	0	R	—

(2) Un\G1800 to Un\G4999 (Error history)

Address (decimal)	Address (hexadecimal)	Name			Default value*1	Read/Write *2	Set value backup area *3	
1800	708 _H	Latest address of error history			0	R	—	
1801 to 1809	709 _H to 711 _H	System area			—	—	—	
1810	712 _H	No. 1	Error code		0	R	—	
1811	713 _H		Error time	First two digits of the year	Last two digits of the year	0	R	—
1812	714 _H			Month	Day	0	R	—
1813	715 _H			Hour	Minute	0	R	—
1814	716 _H			Second	Day of the week	0	R	—
1815 to 1819	717 _H to 71B _H	System area			—	—	—	
1820 to 1829	71C _H to 725 _H	No. 2	Same as No. 1					
1830 to 1839	726 _H to 72F _H	No. 3	Same as No. 1					
1840 to 1849	730 _H to 739 _H	No. 4	Same as No. 1					
1850 to 1859	73A _H to 743 _H	No. 5	Same as No. 1					
1860 to 1869	744 _H to 74D _H	No. 6	Same as No. 1					
1870 to 1879	74E _H to 757 _H	No. 7	Same as No. 1					
1880 to 1889	758 _H to 761 _H	No. 8	Same as No. 1					
1890 to 1899	762 _H to 76B _H	No. 9	Same as No. 1					

Address (decimal)	Address (hexadecimal)	Name		Default value *1	Read/Write *2	Set value backup area *3
1900 to 1909	76C _H to 775 _H	No. 10	Same as No. 1			
1910 to 1919	776 _H to 77F _H	No. 11	Same as No. 1			
1920 to 1929	780 _H to 789 _H	No. 12	Same as No. 1			
1930 to 1939	78A _H to 793 _H	No. 13	Same as No. 1			
1940 to 1949	794 _H to 79D _H	No. 14	Same as No. 1			
1950 to 1959	79E _H to 7A7 _H	No. 15	Same as No. 1			
1960 to 1969	7A8 _H to 7B1 _H	No. 16	Same as No. 1			
1970 to 4999	7B2 _H to 1387 _H	System area		—	—	—

*1 Default value set at factory shipment

*2 This shows whether read or write from sequence program is possible.

R: Readable W: Writable

*3 This shows that whether write to the non-volatile memory by the set value backup function and read by the default setting registration function is possible.

○: Writable and readable —: Unwritable and unreadable

For details on the set value backup function, refer to  Page 72, Section 4.13.

For details on the default setting registration function, refer to  Page 73, Section 4.14.

6.2 Details of Buffer Memory Addresses

The following describes the details of buffer memory addresses.


(1) Conversion enable/disable setting (Un\G0)

Set whether to enable or disable the conversion for each channel.

After setting CH□ Input range setting (Un\G150 to Un\G157) depending on the CT connected, set Enable (0).

For details on the conversion enable/disable function, refer to the following.

- Conversion Enable/Disable Function (☞ Page 37, Section 4.3)



(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value

All channels are set to Disable (1).

(2) CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)

Set the time average, count average, moving average, and time constant of the primary delay filter for each channel for which the averaging processing is specified.

For details on the digital conversion method, refer to the following.

- Digital Conversion Method (👉 Page 38, Section 4.5)
- The following shows the setting range.

Digital conversion method	Setting range
Time average	40 to 5000 (ms) ^{*1}
Count average	4 to 500 (times)
Moving average	2 to 1000 (times)
Primary delay filter	10 to 10000 (ms) ^{*1}

*1 Set an integral multiple of the sampling cycle. If the time average and primary delay filter are not set as the integral multiple, the time average and Primary delay filter are averaged at the maximum cycle satisfying "the set time or less and the integral multiple of the sampling cycle". In addition, configure per 10ms unit. A value per 1ms unit is rounded off.

- When the value out of the setting range above is written in a channel, an error occurs in the channel. The error code (20□, 30□, 31□, or 32□) corresponding to Latest error code (Un\G19) is stored, and Error flag (XF) turns on. The conversion processing is performed based on the setting before the error occurs.
- When a value is set to the channel for which the sampling processing is specified, the set value is ignored.

(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value


All channels are set to 0.

Point

Since 0 is set as the default value, change the setting value depending on the digital conversion method.

(3) Conversion completed flag (Un\G10)

The conversion status can be checked with this flag for each channel.




(a) Conversion completion

When the first digital conversion is completed for the channel for which Enable is set, Conversion completed (1) is stored.

Conversion completed flag (XE) turns on when the digital conversion of all the channels for which Enable is set is completed.

When Operating condition setting request (Y9) is turned on then off, Converting or unused (0), which is the default setting, is stored. When the first digital conversion is completed, Conversion completed (1) is stored again.

Ex. When CH1 and CH2 are set to Enable and the conversion of CH1 and CH2 is completed, 0003_H(3) is stored in Conversion completed flag (Un\G10), as shown below.



(4) CH□ Digital output value (Un\G11 to Un\G18)

The digital output value after digital conversion is stored in each channel.

(a) Updating cycle

When the average processing is performed, the value is updated in each specified averaging process cycle.
When the average processing is not performed, the value is updated in each sampling cycle.

(5) Latest error code (Un\G19)

The latest error code or alarm code detected by the CT input module is stored.

For details on the error code and alarm code, refer to the following.

- Error Code List (📖 Page 228, Section 11.1)
- Alarm Code List (📖 Page 235, Section 11.2)

(a) Clearing an error

Turn on then off Error clear request (YF).

(6) Offset/gain setting mode Offset specification (Un\G22), Offset/gain setting mode Gain specification (Un\G23)

Specify the channel to adjust the offset/gain setting.

- Offset/gain setting mode Offset specification (Un\G22): channel to adjust the offset
- Offset/gain setting mode Gain specification (Un\G23): channel to adjust the gain

	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
Offset/gain setting mode Offset specification (Un\G22)	0	0	0	0	0	0	0	0	CH8	CH7	CH6	CH5	CH4	CH3	CH2	CH1
Offset/gain setting mode Gain specification (Un\G23)	0	0	0	0	0	0	0	0	CH8	CH7	CH6	CH5	CH4	CH3	CH2	CH1

b8 to b15 are fixed to "0".

0: Not specified
1: Specified channel

(a) Default value

All channels are set to Not specified (0).

Point

- Multiple channels can be simultaneously set. In that case, set Not specified (0) to either of Offset/gain setting mode Offset specification (Un\G22) and Offset/gain setting mode Gain specification (Un\G23). When the settings for both of them are configured at the same time, the offset/gain setting mode error (error code: 500) occurs.
- If the user range is not used in CH□ Input range setting (Un\G150 to Un\G157) when the offset/gain setting is set, the error (error code: 51□) occurs.
- For details on the offset/gain setting, refer to the following.
 - Offset/gain Setting (☞ Page 150, Section 8.5)

(7) Averaging process setting (Un\G24, Un\G25)

Set these areas when selecting sampling or averaging processing for each channel.

Averaging processing includes time average, count average, moving average, and primary delay filter.

For details on the digital conversion method, refer to the following.

- Digital Conversion Method (👉 Page 38, Section 4.5)

Averaging process setting (CH1 to CH4) (Un\G24)	b15 to b12	b11 to b8	b7 to b4	b3 to b0
Averaging process setting (CH5 to CH8) (Un\G25)	CH4	CH3	CH2	CH1
	CH8	CH7	CH6	CH5

Digital conversion method	Setting value
Sampling processing	0 _H
Time average	1 _H
Count average	2 _H
Moving average	3 _H
Primary delay filter	4 _H

- When the value out of the setting range above is written in a channel, an error occurs in the channel. The error code (33□) is stored in Latest error code (Un\G19), and Error flag (XF) turns on. The conversion processing is performed based on the setting before the error occurs.

(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value

All channels are set to Sampling processing (0).

(8) Sampling cycle setting (Un\G26)

Set the sampling cycle shared by all the channels.

For details on the sampling cycle switching function, refer to the following.

- Sampling Cycle Switching Function (👉 Page 37, Section 4.4)

Sampling cycle	Setting value
10ms/8CH	0 _H
20ms/8CH	1 _H
50ms/8CH	2 _H
100ms/8CH	3 _H

- When the value out of the setting range above is written in a channel, an error occurs in the channel. The error code (350) is stored in Latest error code (Un\G19), and Error flag (XF) turns on. The sampling cycle performs in the setting before the error occurs.

(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value

10ms/8CH (0) is set as the default value.

(9) CH1 Maximum value (Un\G30) to CH8 Minimum value (Un\G45)

The maximum and minimum values of the digital value digital-converted for each channel are stored as signed 16-bit binary.

For details on the maximum and minimum values hold function, refer to the following.

- Maximum Value and Minimum Values Hold Function (☞ Page 59, Section 4.11)

CH1 Maximum value (Un\G30) to CH8 Minimum value (Un\G45) are updated to the present value when either of the following operations is performed:

- When the setting is changed after Operating condition setting request (Y9) is turned on then off
- When Maximum value/minimum value reset request (YD) is turned on then off

Point


- When the time average method is specified, the maximum and minimum values are stored in each average time specified. When the count average method is specified, the maximum and minimum values are stored in each count average specified. When one of other digital conversion methods is specified, the maximum and minimum values are stored in each sampling cycle.
- When the scaling function is used, the maximum and minimum values after scale conversion are stored.

(10) Input signal error detection setting (Un\G47)

Set whether to enable or disable the input signal error detection for each channel.

For details on the input signal error detection function, refer to the following.

- Input Signal Error Detection Function (☞ Page 44, Section 4.6)



(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.


(b) Default value

All channels are set to Disable (1).

(11) Warning output setting (Un\G48)

Set whether to enable or disable the warning output (process alarm and rate alarm) for each channel.
For details on the warning output function, refer to the following.

- Warning Output Function (☞ Page 53, Section 4.10)



(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value


All channels are set to Disable (1).

(12) Input signal error detection flag (Un\G49)

Input signal status can be checked with this flag for each channel.

For details on the input signal error detection function, refer to the following.

- Input Signal Error Detection Function (☞ Page 44, Section 4.6)



(a) Input signal error detection flag (Un\G49) status

- When a CT input value out of the input range is detected, Input signal error detection flag (Un\G49) corresponding to each channel turns to Input signal error (1).
- When an error is detected in any channels in which the digital conversion or input signal error detection is enabled, Input signal error detection signal (XC) turns on.

(b) Clearing Input signal error detection flag (Un\G49)

To clear Input signal error detection flag (Un\G49), turn on then off Error clear request (YF) when the CT input value is within the measurement range.

Input signal error detection flag (Un\G49) is also cleared by turning on then off Operating condition setting request (Y9).

(13)Warning output flag (Process alarm) (Un\G50), Warning output flag (Rate alarm) (Un\G51)

The process alarm and rate alarm can be checked whether the alarm is the upper limit alarm or lower limit alarm for each channel.

For details on the warning output function, refer to the following.

- Warning Output Function (☞ Page 53, Section 4.10)

	b15	b14	b13	b12	b11	b10	b9	b8	b7	b6	b5	b4	b3	b2	b1	b0
Warning output flag (Process alarm) (Un\G50)	CH8 Lower limit value	CH8 Upper limit value	CH7 Lower limit value	CH7 Upper limit value	CH6 Lower limit value	CH6 Upper limit value	CH5 Lower limit value	CH5 Upper limit value	CH4 Lower limit value	CH4 Upper limit value	CH3 Lower limit value	CH3 Upper limit value	CH2 Lower limit value	CH2 Upper limit value	CH1 Lower limit value	CH1 Upper limit value
Warning output flag (Rate alarm) (Un\G51)	CH8 Lower limit value	CH8 Upper limit value	CH7 Lower limit value	CH7 Upper limit value	CH6 Lower limit value	CH6 Upper limit value	CH5 Lower limit value	CH5 Upper limit value	CH4 Lower limit value	CH4 Upper limit value	CH3 Lower limit value	CH3 Upper limit value	CH2 Lower limit value	CH2 Upper limit value	CH1 Lower limit value	CH1 Upper limit value

0: Normal
1: Alarm ON

(a) Status of Warning output flag (Process alarm) (Un\G50) and Warning output flag (Rate alarm) (Un\G51)

When an alarm is detected due to any of the following, Alarm ON (1) is stored in Warning output flag corresponding to each channel.

- The digital output value exceeds the setting range of CH1 Process alarm lower lower limit value (Un\G86) to CH8 Process alarm upper upper limit value (Un\G117).
- The digital output value exceeds the change rate of CH1 Rate alarm upper limit value (Un\G126) to CH8 Rate alarm lower limit value (Un\G141).

When an error is detected in any channels in which the digital conversion or input signal error detection is enabled, Warning output signal (X8) turns on.

(b) Clearing Warning output flag (Process alarm) (Un\G50) and Warning output flag (Rate alarm) (Un\G51)

The alarms are cleared by any of the following.


- The digital output value or the change rate of the digital output value returns within the setting range.
- Turn on then off Operating condition setting request (Y9)

(14)Scaling enable/disable setting (Un\G53)

Set whether the scaling is enabled or disabled for each channel.

For details on scaling function, refer to the following.

- Scaling Function (☞ Page 50, Section 4.9)



Point!

When Scaling enable/disable setting (Un\G53) is disabled, 0 is stored in CH□ Scaling value (Un\G54 to Un\G61).

(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.


(b) Default value

All channels are set to Disable (1).

(15)CH□ Scaling value (Un\G54 to Un\G61)

The digital output values after scale conversion by the scaling function are stored for each channel.

The scaling values are stored with 16-bit signed binary.



(16)CH1 Scaling lower limit value (Un\G62) to CH8 Scaling upper limit value (Un\G77)

Set the range of scale conversion for each channel.

For details on scaling function, refer to the following.

- Scaling Function (👉 Page 50, Section 4.9)

(a) Setting range

- Setting range: -32000 to 32000
- In the channel where a value other than the above is set, an error occurs. The error code (90□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. The scaling upper limit value and scaling lower limit value in the channel for which an error occurred operate in the setting before the error occurs.
- When Disable (1) is set to Scaling enable/disable setting (Un\G53), the setting for CH1 Scaling lower limit value (Un\G62) to CH8 Scaling upper limit value (Un\G77) is ignored.
- Setting the scaling lower limit value more than the scaling upper limit value allows scale conversion with a negative slope.

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 0.

Point

Since 0 is set as the default value, change the set value to use the scaling function.

(17)CH1 Process alarm lower lower limit value (Un\G86) to CH8 Process alarm upper upper limit value (Un\G117)

Set the alert output range of the digital output value for each channel. Configure the 4-step setting of process alarm upper upper limit value, process alarm upper lower limit value, process alarm lower upper limit value and process alarm lower lower limit value.

For details on the warning output function (process alarm), refer to the following.

- Warning Output Function (Process Alarm) (☞ Page 53, Section 4.10 (1))

(a) Setting range

- Setting range: -32768 to 32767
- The setting must satisfy the following condition: process alarm upper upper limit value \geq process alarm upper lower limit value \geq process alarm lower upper limit value \geq process alarm lower lower limit value. In the channel where the condition is not satisfied, an error occurs. The error code (6△□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. The process alarm operates in the setting before the error occurs.
- When using the scaling function, set values considering the scale conversion. For details on the scaling function, refer to the following.

Scaling Function (☞ Page 50, Section 4.9)

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 0.

Point

Since 0 is set as the default value, change the set value to use the process alarm.

(18)CH□ Rate alarm warning detection period (Un\G118 to Un\G125)

Set the cycle for checking the change rate of digital output values for each channel.

For details on the warning output function (rate alarm), refer to the following.

- Warning Output Function (Rate Alarm) (☞ Page 55, Section 4.10 (2))

(a) Setting range

- Setting range: 10 to 5000ms
- Configure per 10ms unit. A value per 1ms unit is rounded off.
- In the channel where a setting value other than the above is set, an error occurs. The error code (70□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. The time average, count average, and rate alarm operate in the setting before the error occurs.
- Set an integral multiple of the conversion cycle on each digital conversion method. If these areas are not set as the integral multiple, an alert is output at the maximum cycle satisfying the rate alarm warning detection period or less and the integral multiple of the conversion cycle.

Ex. Rate alarm warning detection period for the following condition

- Digital conversion method: Count average
- Count average: 10 times
- Sampling cycle: 100ms/8CH

The conversion cycle is 1000ms (10 (times) × 100 (ms)). Therefore, set an integral multiple of 1000ms, such as 1000ms or 2000ms for the rate alarm warning detection period.

Remark

When a small value is set for the rate alarm upper limit value or the rate alarm lower limit value, even a slight disturbance may cause the alert output to turn on. To prevent this, set a long rate alarm warning detection period.

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 0.

Point

Since 0 is set as the default value, change the set value to use the rate alarm.

(19)CH1 Rate alarm upper limit value (Un\G126) to CH8 Rate alarm lower limit value (Un\G141)

Set the change rate range of the digital output value for each channel.

For details on the warning output function (rate alarm), refer to the following.

- Warning Output Function (Rate Alarm) (☞ Page 55, Section 4.10 (2))

(a) Setting range

- Setting range: -32768 to 32767 (-3276.8 to 3276.7%/s) (Set in 0.1%/s)

Ex. To set the rate alarm upper limit value to 30%/s, store 300 in the buffer memory.

- The range must satisfy the following condition: rate alarm upper limit value \geq rate alarm lower limit value.
In the channel where the condition is not satisfied, an error occurs. The error code (34□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. The rate alarm operates in the setting before the error occurs.

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 0.

Point

Since 0 is set as the default value, change the set value to use the rate alarm.

(20)CH□ Input range setting (Un\G150 to Un\G157)

Set the CT input range for each channel.

For details on the input range setting, refer to the following.

- Input Range Setting (☞ Page 36, Section 4.2)

	Input range	Setting value
Factory default range	0 to 5AAC	0000 _H
	0 to 50AAC	0001 _H
	0 to 100AAC	0002 _H
	0 to 200AAC	0003 _H
	0 to 400AAC	0004 _H
	0 to 600AAC	0005 _H
User range	0 to 5AAC	0010 _H
	0 to 50AAC	0011 _H
	0 to 100AAC	0012 _H
	0 to 200AAC	0013 _H
	0 to 400AAC	0014 _H
	0 to 600AAC	0015 _H

- In the channel where a setting value other than the above is set, an error occurs. The error code (10□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. The setting range before the error occurs is applied.

(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value

All channels are set to 0 to 5AAC (factory default range) (0000_H).

Point

Since 0 to 5AAC (factory default range) (0000_H) is set as the default value, change the setting depending on the connected CT.

(21) Mode switching setting (Un\G158, Un\G159)

Set the value for the mode to be switched to.

Mode	Setting value	
	Un\G158	Un\G159
Normal mode	0964 _H	4144 _H
Offset/gain setting mode	4144 _H	0964 _H

Point

When a value out of the setting range above is written, the mode is not switched and only the operating condition is changed.

(a) Mode switching

To perform the mode switching, turn off then on Operating condition setting request (Y9).

(b) After the mode is switched

When the mode is switched, these areas are cleared and Operating condition setting completed flag (X9) turns off.

After checking that Operating condition setting completed flag (X9) is off, turn off Operating condition setting request (Y9).

(c) Default value


The default value is set to 0.

(22) Dropout detection setting (Un\G160)

Set whether to enable or disable the dropout detection for each channel.

For details on the dropout function, refer to the following.

- Dropout Function (☞ Page 49, Section 4.8)



(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.


(b) Default value

All channels are set to Disable (1).

(23) Dropout status flag (Un\G161)

The setting status of the dropout function can be checked for each channel.
For details on the dropout function, refer to the following.

- Dropout Function (☞ Page 49, Section 4.8)

**(a) Dropout status flag (Un\G161) status**

- When the dropout function is enabled, Dropout enabled (1) is stored in Dropout status flag (Un\G161).
- When the dropout function is disabled, Dropout disabled (0) is stored in Dropout status flag (Un\G161).

(24) CH□ Dropout value (Un\G162 to Un\G169)

Set the digital output value which is dropped out for each channel.
For details on the dropout function, refer to the following.

- Dropout Function (☞ Page 49, Section 4.8)

(a) Setting range

- Setting range: 1 to 10000
- When the value after digital conversion is the dropout value or less, 0 is stored in CH□ Digital output value (Un\G11 to Un\G18).

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 50.

(25)CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233)

These are the areas for restoring the offset/gain setting value in the user range.

Data for restoring the offset/gain setting value of the user range is stored (saved) at operations below.

- Writing the initial setting by a programming tool
- Turning off then on Operating condition setting request (Y9)^{*1}
- Turning off then on User range write request (YA) (in offset/gain setting mode)

*1 The data is not saved when the setting value is written to Mode switching setting (Un\G158, Un\G159).

When restoring the offset/gain setting value in the user range, set the data saved in these areas to the same area in the CT input module where the data is restored.

(a) Procedure for saving offset/gain values into the buffer memory area

- 1. Turn off then on Operating condition setting request (Y9).**
- 2. Compare CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233) with the values in the range reference table. For the range reference table, refer to the following.**
 - Range Reference Table (☞ Page 227, Section 10.11)
- 3. If the values are proper, save the values in CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233).**

For setting procedure of the offset/gain values, refer to the following.

- Offset/gain Setting (☞ Page 150, Section 8.5)

(b) Default value


All channels are set to 0.

(26) Peak current detection setting (Un\G300)

Set whether to enable or disable the peak current detection for each channel.

For details on the peak current detection function, refer to the following.

Peak Current Detection Function (☞ Page 46, Section 4.7)

**(a) Enabling the setting**

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value


All channels are set to Disable (1).

(27) Peak current detection flag (Un\G301)

The peak current status can be checked with this flag for each channel.

For details on the peak current detection function, refer to the following.

Peak Current Detection Function (☞ Page 46, Section 4.7)

**(a) Peak current detection flag (Un\G301) status**

- When CH□ Digital output value (Un\G11 to Un\G18) exceeds set CH□ Peak current detection value (Un\G326 to Un\G333) consecutively for the duration of CH□ Peak current detection time (Un\G318 to Un\G325) set in advance, Peak current detected (1) is stored in Peak current detection flag (Un\G301) of the corresponding channel.
- When a peak current is detected in even one of the channels for which the digital conversion or peak current detection are enabled, Peak current detection signal (X7) turns on.

(b) Clearing Peak current detection flag (Un\G301)

To clear Peak current detection flag (Un\G301), turn on then off Error clear request (YF) when the digital output value is the peak current detection value or less.

Peak current detection flag (Un\G301) is also cleared by turning on then off Operating condition setting request (Y9).

(28)CH□ Peak current detection count reset request (Un\G302 to Un\G309)

To set the number of peak current detection to 0, set Reset requested (1) for each channel.

For details on the peak current detection function, refer to the following.

- Peak Current Detection Function (☞ Page 46, Section 4.7)

Peak current detection count reset request	Setting value
Reset not requested	0
Reset requested	1

(a) Default value

All channels are set to Reset not requested (0).

(29)CH□ Peak current detection count reset complete (Un\G310 to Un\G317)

The number of peak current detection can be checked for completion for each channel.

For details on the peak current detection function, refer to the following.

- Peak Current Detection Function (☞ Page 46, Section 4.7)

When Reset requested (1) is set to CH□ Peak current detection count reset request (Un\G302 to Un\G309) and Peak current detection count (Un\G334 to Un\G341) is reset, Reset request completed (1) is stored in Peak current detection count reset complete (Un\G310 to Un\G317).

When Reset not requested (0) is set to CH□ Peak current detection count reset request (Un\G302 to Un\G309), Reset not requested (0) is stored in CH□ Peak current detection count reset complete (Un\G310 to Un\G317).

(30)CH□ Peak current detection time (Un\G318 to Un\G325)

Set the unit time (in ms) for peak current detection for each channel.

For details on the peak current detection function, refer to the following.

- Peak Current Detection function (☞ Page 46, Section 4.7)

(a) Setting range

- Setting range: 10 to 10000ms
- Configure per 10ms unit. A value per 1ms unit is rounded off.
- Set an integral multiple of the sampling cycle. If these areas are not set as the integral multiple, the peak current is detected at the maximum cycle satisfying "the peak current detection time or less and the integral multiple of the sampling cycle".

Ex. The actual peak current detection time for the following setting is 900ms (integral multiple of 100ms).

- Sampling cycle setting: 100ms/8CH
- Peak current detection time: 950ms

- In the channel where a value of the sampling cycle or lower is set, an error occurs. The error code (36□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. The peak current detection time before the error occurs is applied.
- When Disable (1) is set to Peak current detection setting (Un\G300), the setting of CH□ Peak current detection time (Un\G318 to Un\G325) is ignored.

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 1000 (ms).

(31)CH□ Peak current detection value (Un\G326 to Un\G333)

Set the digital output value detected as peak current for each channel.

For details on the peak current detection function, refer to the following.

- Peak Current Detection Function (☞ Page 46, Section 4.7)

(a) Setting range

- Setting range: 0 to 11999
- When Disable (1) is set to Peak current detection setting (Un\G300), the setting of CH□ Peak current detection value (Un\G326 to Un\G333) is ignored.

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 0.



Since 0 is set as the default value, change the set value to use the peak current detection function.

(32)CH□ Peak current detection count (Un\G334 to Un\G341)

These are the areas for storing the number of peak current detection for each channel.

For details on the peak current detection function, refer to the following.

- Peak Current Detection Function (☞ Page 46, Section 4.7)

(a) Counting the number of peak current detection

- When a digital output value exceeds set CH□ Peak current detection value (Un\G326 to Un\G333) consecutively for the duration of CH□ Peak current detection time (Un\G318 to Un\G325) set in advance, 1 is added to CH□ Peak current detection count (Un\G334 to Un\G341). However, after the addition to the peak current detection count, 1 is not added unless the digital output value becomes less than the peak current detection value.
- The number of peak current detection is stored automatically in the non-volatile memory in the CT input module. The number of peak current detection continues to be counted until the reset of the number of the detection.

(b) Resetting the number of peak current detection

By setting Reset requested (1) to CH□ Peak current detection count reset request (Un\G302 to Un\G309), 0 is stored in CH□ Peak current detection count (Un\G334 to Un\G341).

(c) Measurement range of the number of peak current detection

- Measurement range: 0 to 32767

When the upper limit of the measurement range is exceeded, 0 is set again.

(33)CH□ Logging enable/disable setting (Un\G1000 to Un\G1007)

Set whether to enable or disable the logging function for each channel.

For details on the logging function, refer to the following.

- Logging Function (☞ Page 60, Section 4.12)

Logging enable/disable setting	Setting value
Enable	0
Disable	1

In the channel where a setting value other than the above is set, an error occurs. The error code (200□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. Also, logging cannot be performed.

(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value

All channels are set to Disable (1).

(34)CH□ Logging hold request (Un\G1008 to Un\G1015)

Use Logging hold request (Un\G1008 to Un\G1015) as a trigger to hold (stop) the logging at any timing during the logging for each channel.

For details on the logging function, refer to the following.

- Logging Function (☞ Page 60, Section 4.12)

Logging hold request	Setting value
OFF	0
ON	1

- In the channel where a setting value other than the above is set, an error occurs. The error code (207□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. However, the logging continues.
- When Disable (1) is set to CH□ Logging enable/disable setting (Un\G1000 to Un\G1007), the setting for CH□ Logging hold request (Un\G1008 to Un\G1015) is ignored.

(a) Operation of the logging hold processing

When Disable (0) is set to CH□ Level trigger condition setting (Un\G1056 to Un\G1063)

- When ON (1) is set to CH□ Logging hold request (Un\G1008 to Un\G1015), the logging hold processing starts.

When Above (1), Below (2), or Pass through (3) is set to CH□ Level trigger condition setting (Un\G1056 to Un\G1063)

- When the trigger condition is satisfied after ON (1) is set to CH□ Logging hold request (Un\G1008 to Un\G1015), the logging hold processing starts. When the level trigger is enabled, use Logging hold request (Un\G1008 to Un\G1015) as an interlock to generate the level trigger.

If CH□ Logging hold request (Un\G1008 to Un\G1015) is turned OFF (0), the hold status (stop) is cleared. Also, the logging resumes.

(b) Default value

All channels are set to OFF (0).

(35)CH□ Logging hold flag (Un\G1016 to Un\G1023)

Logging hold status can be checked with this flag for each channel.

For details on the logging function, refer to the following.

- Logging Function (☞ Page 60, Section 4.12)

Logging hold status	Stored value
OFF	0
ON	1

- When the logging status changes to the stop (hold) from the execution, ON (1) is stored.
- When the logging is resumed, OFF (0) is stored.

(36)CH□ Logging data setting (Un\G1024 to Un\G1031)

Set whether the logging target is the digital output value or the scaling value for each channel.

For details on the logging function, refer to the following.

- Logging Function (📖 Page 60, Section 4.12)

Logging target	Setting value
Digital output value	0
Scaling value	1

- In the channel where a setting value other than the above is set, an error occurs. The error code (203□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. Also, logging cannot be performed.
- When Disable (1) is set to CH□ Logging enable/disable setting (Un\G1000 to Un\G1007), the setting for CH□ Logging data setting (Un\G1024 to Un\G1031) is ignored.

(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value

All channels are set to Scaling value (1).

(37)CH□ Logging cycle setting value (Un\G1032 to Un\G1039), CH□ Logging cycle unit setting (Un\G1040 to Un\G1047)

Set the cycle of storing the logging data for each channel.

Set a value for one cycle in CH□ Logging cycle setting value (Un\G1032 to Un\G1039).

Set a unit of one cycle in CH□ Logging cycle unit setting (Un\G1040 to Un\G1047).

For details on the logging function, refer to the following.

- Logging Function (📖 Page 60, Section 4.12)

(a) Setting range

- The setting range of CH□ Logging cycle setting value (Un\G1032 to Un\G1039) depends on the setting for CH□ Logging cycle unit setting (Un\G1040 to Un\G1047).

Logging cycle unit	Setting value of CH□ Logging cycle unit setting (Un\G1040 to Un\G1047)	Setting range of CH□ Logging cycle setting value (Un\G1032 to Un\G1039)
Update cycle	0	The setting is ignored.
ms	1	10 to 32767
s	2	1 to 3600

- If a setting above is outside the setting range, an error occurs. The error code (201□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. Also, logging cannot be performed.
- If the set logging cycle is shorter than the update cycle of the data to be logged, an error occurs. The error code (202□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. Also, logging cannot be performed.
- When Disable (1) is set to CH□ Logging enable/disable setting (Un\G1000 to Un\G1007), the setting value is ignored.

(b) Actual logging cycle

The actual logging cycle is an integral multiple of the conversion cycle of digital output value or scaling value. The conversion cycle of each conversion method is as follows.

Digital conversion method	Conversion cycle
Sampling processing	Sampling cycle
Time average	$\left(\frac{\text{Time set to CH}\square \text{ Average time/Average number of times/ Moving average/Time constant settings (Un}\backslash\text{G1 to Un}\backslash\text{G8)}}{\text{Sampling cycle}} \right)^{*1} \times \text{Sampling cycle}$
Count average	(Times set in (CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)) × Sampling cycle
Moving average	Sampling cycle
Primary delay filter	Sampling cycle

*1 The value after the decimal point is rounded off.

If the set logging cycle is not an integral multiple of the conversion cycle, the logging function operates in the maximum cycle of an integral multiple within the setting range.

Ex. The processing time for the following settings is calculated below:

- Averaging process setting (Un\G24, Un\G25): Sampling processing (0)
- Sampling cycle setting (Un\G26): 100ms/8CH (3)
- CH□ Logging data setting (Un\G1024 to Un\G1031): Digital output value (0)
- CH□ Logging cycle setting value (Un\G1032 to Un\G1039): 1950
- CH□ Logging cycle unit setting (Un\G1040 to Un\G1047): ms (1)

The conversion cycle is 100ms. The actual logging cycle is 1900ms (an integral multiple of 100ms).

Point

When Update cycle (0) is set to Logging cycle unit setting, the logging is performed in the conversion cycle of the logging target data. In this case, the setting of CH□ Logging cycle setting value (Un\G1032 to Un\G1039) is ignored.

(c) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(d) Default value

- For CH□ Logging cycle setting value (Un\G1032 to Un\G1039), all channels are set to 300.
- For CH□ Logging cycle unit setting (Un\G1040 to Un\G1047), all channels are set to Update cycle (0).

(38)CH□ Logging points after trigger (Un\G1048 to Un\G1055)

Set the data points recorded from hold trigger occurs until logging holds (stops) for each channel.

For details on the logging function, refer to the following.

- Logging Function (👉 Page 60, Section 4.12)

(a) Setting range

- Setting range: 1 to 5000
- In the channel where a setting value out of the above setting range is set, an error occurs. Then the error code (204□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. Also, logging cannot be performed.
- When Disable (1) is set to CH□ Logging enable/disable setting (Un\G1000 to Un\G1007), the setting for CH□ Logging points after trigger (Un\G1048 to Un\G1055) is ignored.

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 2500.

(39)CH□ Level trigger condition setting (Un\G1056 to Un\G1063)

When the level trigger is used with the logging function, set the occurrence condition of the hold trigger for each channel.

For details on the logging function, refer to the following.

- Logging Function (👉 Page 60, Section 4.12)

Setting	Setting value
Disable	0
Above	1
Below	2
Pass through	3

- In the channel where a setting value other than the above is set, an error occurs. The error code (205□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. Also, logging cannot be performed.
- When Disable (1) is set to CH□ Logging enable/disable setting (Un\G1000 to Un\G1007), the setting for CH□ Level trigger condition setting (Un\G1056 to Un\G1063) is ignored.

(a) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(b) Default value

All channels are set to Disable (0).

(40)CH□ Trigger data (Un\G1064 to Un\G1071)

Set a buffer memory address monitored for the occurrence condition of level trigger.

For details on the logging function, refer to the following.

- Logging Function (☞ Page 60, Section 4.12)

(a) Setting range

- Setting range: 0 to 4999
- In the channel where a setting value other than the above is set, an error occurs. The error code (206□) is stored in Latest error code (Un\G19) and Error flag (XF) turns on. Also, logging cannot be performed.

Point!

Set the following buffer memory addresses in the trigger data.

- CH□ Digital output value (Un\G11 to Un\G18): 11 to 18
- CH□ Scaling value (Un\G54 to Un\G61): 54 to 61
- Level data □ (Un\G1072 to Un\G1081): 1072 to 1081
- Buffer memory address with "R" in List of Buffer Memory Addresses

For details on the buffer memory address, refer to the following.

List of Buffer Memory Addresses (☞ Page 91, Section 6.1)

Do not set the buffer memory addresses with "R/W" or "W" or system area in List of Buffer Memory Addresses. If they are set, the normal operation of the CT input module may not be ensured.

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

Channel	Default value	Buffer memory to be monitored
CH1	54	CH1 Scaling value (Un\G54)
CH2	55	CH2 Scaling value (Un\G55)
CH3	56	CH3 Scaling value (Un\G56)
CH4	57	CH4 Scaling value (Un\G57)
CH5	58	CH5 Scaling value (Un\G58)
CH6	59	CH6 Scaling value (Un\G59)
CH7	60	CH7 Scaling value (Un\G60)
CH8	61	CH8 Scaling value (Un\G61)

(41) Level data □ (Un\G1072 to Un\G1081)

These are the areas for storing the data to be monitored when the level trigger of the logging function is used. 10 types of data are available: Level data 0 (Un\G1072) to Level data 9 (Un\G1081)

Use Level data □ to monitor device values in other than the CT input module such as the CPU module.

For details on the logging function, refer to the following.

- Logging Function (📖 Page 60, Section 4.12)

(a) Setting range

Setting range: -32768 to 32767

(b) Default value

All are set to 0.

(c) Example of use

To monitor data register D100 in the CPU module and generate the level trigger in CH1, create a program as follows.

1. Set 1073 (Level data 1) to CH1 Trigger data (Un\G1064) (When Level data 1 is used).
2. Store the storage data of D100 in the program in Level data 1 (Un\G1073) as needed. (The start I/O number is set to 0_H in the following program example.)



(42) CH□ Trigger setting value (Un\G1082 to Un\G1089)

Set a value where a level trigger is generated for each channel in the logging function.

For details on the logging function, refer to the following.

- Logging Function (📖 Page 60, Section 4.12)

(a) Setting range

Setting range: -32768 to 32767

(b) Enabling the setting

Turn on then off Operating condition setting request (Y9) to enable the setting.

(c) Default value

All channels are set to 0.


(44)CH□ Latest pointer (Un\G1098 to Un\G1105)

The buffer memory address where the latest data is stored can be checked in CH□ Logging data (Un\G5000 to Un\G44999) for each channel. The difference between the buffer memory address where the latest data is stored and the start address in CH□ Logging data (Un\G5000 to Un\G44999) is stored.

For details on the logging function, refer to the following.

Logging Function (☞ Page 60, Section 4.12)

Ex. When the value of CH2 Latest pointer (Un\G1099) is 3550



Point

- CH□ Latest pointer (Un\G1098 to Un\G1105) moves one by one each time data is stored from when the logging starts.
- When CH□ Logging hold request (Un\G1008 to Un\G1015) is turned OFF (0), CH□ Latest pointer (Un\G1098 to Un\G1105) is cleared.

(45)CH□ Number of logging data (Un\G1106 to Un\G1113)

The number of data stored in the logging data storage area can be checked for each channel during the logging. For details on the logging function, refer to the following.

Logging Function (☞ Page 60, Section 4.12)

Point

- The number of logging data is added one by one each time data is stored from when the logging starts.
- When the 5000 data is stored in the logging data storage area, the value is overwritten from the head again. Therefore, CH□ Number of logging data (Un\G1106 to Un\G1113) is fixed to 5000.
- When CH□ Logging hold request (Un\G1008 to Un\G1015) is turned OFF (0), CH□ Number of logging data (Un\G1106 to Un\G1113) is cleared.

(46)CH□ Trigger pointer (Un\G1114 to Un\G1121)


The address of buffer memory which stores the data of when a hold trigger was generated can be checked in CH□ Logging data (Un\G5000 to Un\G44999) for each channel.

The difference between the address of buffer memory which stores the data of when a hold trigger was executed and the start address in CH□ Logging data (Un\G5000 to Un\G44999) is stored.

For details on the logging function, refer to the following.

Logging Function (☞ Page 60, Section 4.12)

Ex. When the value of CH2 Trigger pointer (Un\G1115) is 3550

**Point**

When CH□ Logging hold request (Un\G1008 to Un\G1015) is turned OFF (0), CH□ Trigger pointer (Un\G1114 to Un\G1121) is cleared.

(47)CH□ Logging cycle monitoring value (Un\G1122 to Un\G1145)

These are the areas for storing the actual logging cycle for each channel. The actual logging cycle is calculated from the update cycle of data to be logged.

When Operating condition setting request (Y9) is turned on then off, the logging cycle is stored in CH□ Logging cycle monitoring value (Un\G1122 to Un\G1145) in the corresponding channel where the logging function is enabled.

For details on the logging function, refer to the following.

- Logging Function (☞ Page 60, Section 4.12)

	b15	to	b0
Un\G1122	(s)		
Un\G1123	(ms)		
Un\G1124	(μs)		

Ex. When the calculated value of logging cycle in CH1 is 6960ms

Buffer memory address	Stored value
Un\G1122	6(s)
Un\G1123	960(ms)
Un\G1124	0(μs)

(48)CH□ Trigger detection time (Un\G1154 to Un\G1185)

The time that the hold trigger occurred is recorded for each channel.

For details on the logging function, refer to the following.

- Logging Function (👉 Page 60, Section 4.12)

	b15	to	b8	b7	to	b0
Un\G1154	First two digits of the year			Last two digits of the year		
Un\G1155	Month			Day		
Un\G1156	Hour			Minute		
Un\G1157	Second			Day of the week		

Item	Storage contents	Storage example*1
First two digits of the year/Last two digits of the year	Stored in BCD code.	2011 _H
Month/Day		329 _H
Hour/Minute		1035 _H
Second		40 _H
Day of the week	One of the following values is stored for each day of the week in BCD code. <ul style="list-style-type: none"> • Sunday: 00 • Monday: 01 • Tuesday: 02 • Wednesday: 03 • Thursday: 04 • Friday: 05 • Saturday: 06 	02 _H

*1 Those are values when a hold trigger is detected at 10:35:40 on Tuesday, March 29th, 2011.

Point

- Time units shorter than one second are not recorded.
- When CH□ Logging hold request (Un\G1008 to Un\G1015) is turned OFF (0), CH□ Trigger detection time (Un\G1154 to Un\G1185) is cleared.

(49) Latest address of error history (Un\G1800)

The start address of the latest error history is stored.

For details on the error history function, refer to the following.

- Error History Function (☞ Page 74, Section 4.15)

(50) Error history No. □ (Un\G1810 to Un\G1969)

Up to 16 errors occurred in the module are recorded.

For details on the error history function, refer to the following.

- Error History Function (☞ Page 74, Section 4.15)

	b15	to	b8	b7	to	b0
Un\G1810	Error code					
Un\G1811	First two digits of the year			Last two digits of the year		
Un\G1812	Month			Day		
Un\G1813	Hour			Minute		
Un\G1814	Second			Day of the week		
Un\G1815	System area					
⋮						
Un\G1819						

Item	Storage contents	Storage example* ¹
First two digits of the year/Last two digits of the year	Stored in BCD code.	2011 _H
Month/Day		329 _H
Hour/Minute		1035 _H
Second		40 _H
Day of the week	One of the following values is stored for each day of the week in BCD code. <ul style="list-style-type: none"> • Sunday: 00 • Tuesday: 02 • Thursday: 04 • Saturday: 06 • Monday: 01 • Wednesday: 03 • Friday: 05 	02 _H

*1 Those are values when an error occurs at 10:35:40 on Tuesday, March 29th, 2011.

(51) CH□ Logging data (Un\G5000 to Un\G44999)

These are the areas for storing the logged data for each channel. Up to 5000 data can be stored per channel.

After the 5001st data for CH□ Logging data (Un\G5000 to Un\G44999) for each channel, the logging is continued with the data overwritten from the head.

For details on the logging function, refer to the following.

- Logging Function (☞ Page 60, Section 4.12)

Point

- When Operating condition setting request (Y9) is turned on then off, the logging data in all the channels are cleared.
- Even if CH□ Logging hold request (Un\G1008 to Un\G1015) is turned OFF (0) and the logging resumes, the logged data is not cleared.

CHAPTER 7 SETTINGS AND THE PROCEDURE BEFORE OPERATION

This chapter describes the procedure prior to a CT input module operation, the name of each part of a CT input module, and wiring method.

7.1 Handling Precautions

This section describes the handling precautions for a CT input module.


- Do not drop the module case, or do not subject it to strong impact.
- Do not remove the printed-circuit board from the case. Doing so can cause module failure.
- Do not disassemble the module. Doing so can cause module failure.
- Prevent foreign matter such as dust or wire chips from entering the module. Such foreign matter can cause a fire, failure, or malfunction.
- A protective film is attached to the top of the module to prevent foreign matter, such as wire chips, from entering the module during wiring. Do not remove the film during wiring. Remove it for heat dissipation before system operation.
- Tighten the screws such as a module fixing screw within the specified torque range. Undertightening the screws can cause short circuit or malfunction. Overtightening can damage the screws and/or module, resulting in short circuit or malfunction.

Screw	Tightening torque range
Module fixing screw (M3 screw) ^{*1}	0.36 to 0.48N • m
Terminal block terminal screw (M3)	0.42 to 0.58N • m
Terminal block mounting screw (M3.5)	0.66 to 0.89N • m

^{*1} The module can be easily fixed onto the base unit using the hook at the top of the module. However, it is recommended to secure the module with the module fixing screw if the module is subject to significant vibration.


- To mount the module, while pressing the module mounting lever located in the lower part of the module, fully insert the module fixing projection into the hole in the base unit and press the module until it snaps into place. Incorrect mounting may cause malfunction, failure or drop of the module.
- Before handling the module, touch a grounded metal object to discharge the static electricity from the human body. Failure to do so may cause the module to fail or malfunction.

7.2 Settings and the Procedure Before Operation



7.3 Part Names

This section describes the part names of a CT input module.



(1) Part names

The following table lists the part names of a CT input module.

Number	Name	Description
1)	RUN LED (green)	Indicates the operating status of the CT input module. On: The module is operating normally. Flashing: In the offset/gain setting mode Off: The 5V power off or watchdog timer error has occurred, or online module change enabled.
2)	ERR. LED (red)	Indicates the errors and status of the CT input module. On: An error has occurred except for error code: 112* ¹ Flashing: Error code: 112 is occurring.* ¹ Off: The module is operating normally.
3)	ALM LED (red)	Indicates the alarm status of the CT input module. On: Alarm (process alarm/rate alarm) is occurring.* ² Flashing: Input signal error detection/ peak current detection is occurring.* ² Off: The module is operating normally.
4)	Serial number display	Displays the serial number printed on the rating plate.

*¹ Error Code List (☞ Page 228, Section 11.1)

*² Alarm Code List (☞ Page 235, Section 11.2)

(2) Signal names of the terminal block

The following shows signal names of the terminal block.

CH1 L	CH1 k
CH2 L	CH2 k
CH3 L	CH3 k
CH4 L	CH4 k
CH5 L	CH5 k
CH6 L	CH6 k
CH7 L	CH7 k
CH8 L	CH8 k
NC	NC

Pin number	Signal name	
1	CH1	k
2		l
3	CH2	k
4		l
5	CH3	k
6		l
7	CH4	k
8		l
9	CH5	k
10		l
11	CH6	k
12		l
13	CH7	k
14		l
15	CH8	k
16		l
17	NC	
18	NC	

7.4 Wiring

This section describes the wiring precautions and module connection examples of a CT input module.

7.4.1 Wiring precautions


External wiring that is less likely to be affected by noise is one of the conditions for a highly reliable system that fully utilizes the CT input module.

This section describes the precautions on external wiring.

- Use separate cables for the AC control circuit and the CT input module's external I/O signals to avoid influence of AC side surges and induction.
- Do not locate external wires near the main circuit line, high-voltage circuit lines, and load circuit lines of devices other than programmable controllers. Also, do not bunch external wires with these lines. Otherwise, the external wires are more likely to be affected by noise, surges, and induction.
- Ground shielded cables at one end.
- A solderless terminal with an insulation sleeve cannot be used on the terminal block. It is recommended to put a mark tube or an insulation tube on the wire connection part of a solderless terminal.

7.4.2 External wiring

The following describes the external wiring.



Point

- Set Disable (1) to Conversion enable/disable setting (Un\G0) for unused channels. If Enable (0) is set to Conversion enable/disable setting (Un\G0) and the circuit between two terminals is kept open, an undefined digital value may be output.
- To replace a CT for a channel using a user range, set the offset/gain setting again.

CHAPTER 8 VARIOUS SETTINGS

This chapter describes the setting procedures of the CT input module.

Point

After writing the contents of new module, switch settings, parameter settings and auto refresh settings into the CPU module, reset the CPU module, switch STOP → RUN → STOP → RUN, or switch on the power supply, to validate the setting contents.

8.1 Adding a Module

Add the model name of the CT input module to use on the project.

(1) Addition procedure

Open the "New Module" window.

Project window ⇨ [Intelligent Function Module] ⇨ Right-click ⇨ [New Module...]

Item	Description	
Module Selection	Module Type	Set [Analog Module].
	Module Name	Set the name of the module to mount.
Mount Position	Base No.	Set the base No. where the module is mounted.
	Mounted Slot No.	Set the slot No. where the module is mounted.
	Specify start XY address	The start I/O number (hexadecimal) of the target module is set, according to the mounted slot No. Any start I/O number can be set.
Title Setting	Title	Set any title.


8.2 Switch Setting

Set the operation mode.

(1) Setting procedure

Open the "Switch Setting" window.

 Project window ⇒ [Intelligent Function Module] ⇒ Module name ⇒ [Switch Setting]



Item	Description	Setting value
Drive Mode Setting	Set the operation mode of the CT input module.	<ul style="list-style-type: none"> • Normal (Digital Conversion) Mode • Offset-Gain Setting Mode

8.3 Parameter Setting

Set the parameters for each channel.

Setting parameters on the screen omits the parameter setting in a program.

(1) Setting procedure

Open the "Parameter" window.

1. Start "Parameter".

Project window ⇨ [Intelligent Function Module] ⇨ Module name ⇨ [Parameter]

The screenshot shows a software window titled "0000:Q68CT[]-Parameter" with a "Display Filter" set to "Display All". The window contains a table with columns for "Item" and channels CH1 through CH8. The table is organized into sections: "Basic setting", "Warning output function", "Input signal error detection", and "Scaling function".

Annotations on the left side of the screenshot:

- "Pull-down list type" points to the "Conversion enable/disable" row, where a pull-down menu is open showing "0:Enable" and "1:Disable".
- "Text box type" points to the "Process alarm upper limit value" row, where a text box containing "10000" is highlighted.

Item	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Basic setting								
Conversion enable/disable	0:Enable	1:Disable						
Averaging process setting	0:Enable	0:Sampling Processing						
Average time/Average number of times/Moving average/Time constant settings	0	0	0	0	0	0	0	0
Sampling cycle setting	0:10ms/8CH							
Warning output function								
Process alarm warning output setting	0:Enable	1:Disable						
Process alarm upper limit value	10000	0	0	0	0	0	0	0
Process alarm upper lower limit value	7500	0	0	0	0	0	0	0
Process alarm lower upper limit value	5000	0	0	0	0	0	0	0
Process alarm lower lower limit value	2500	0	0	0	0	0	0	0
Rate alarm warning output setting	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Rate alarm warning detection period	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms	0 ms
Rate alarm upper limit value	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s
Rate alarm lower limit value	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s	0.0 %/s
Input signal error detection								
Input signal error detection setting	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Scaling function								
Scaling enable/disable setting	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Scaling upper limit value	0	0	0	0	0	0	0	0
Scaling lower limit value	0	0	0	0	0	0	0	0

Set whether to 'Enable' or 'Disable' the output of digital value for each channel.
0:Enable
1:Disable

2. Double-click the item to change the setting, and input the setting value.

- Items to input from the pull-down list
Double-click the item to set to display the pull-down list. Select the item.
- Items to input from the text box
Double-click the item to set, and input the setting value.

3. For setting CH2 to CH8, follow the operation of the Step 2.

Item		Setting value		Reference	
Basic setting	Conversion enable/disable setting	0: Enable 1: Disable (default value)		Page 37, Section 4.3	
	Averaging process setting	0: Sampling Processing (default value) 1: Time Average 2: Count Average 3: Moving Average 4: Primary Delay Filter		Page 38, Section 4.5	
	Average time/Average number of times/Moving average/Time constant settings	Time Average	40 to 5000ms (default value: 0)		
		Count Average	4 to 500 Times (default value: 0)		
		Moving Average	2 to 1000 Times (default value: 0)		
Primary Delay Filter		10 to 10000ms (default value: 0)			
Sampling cycle setting	0: 10ms/8CH (default value) 1: 20ms/8CH 2: 50ms/8CH 3: 100ms/8CH		Page 37, Section 4.4		
Warning output function	Process alarm warning output setting	0: Enable 1: Disable (default value)		Page 53, Section 4.10 (1)	
	Process alarm upper upper limit value	-32768 to 32767 (default value: 0)			
	Process alarm upper lower limit value	-32768 to 32767 (default value: 0)			
	Process alarm lower upper limit value	-32768 to 32767 (default value: 0)			
	Process alarm lower lower limit value	-32768 to 32767 (default value: 0)			
	Rate alarm warning output setting	0: Enable 1: Disable (default value)		Page 55, Section 4.10 (2)	
	Rate alarm warning detection period	10 to 5000ms (default value: 0)			
	Rate alarm upper limit value	-3276.8 to 3276.7%/s (default value: 0)			
Rate alarm lower limit value	-3276.8 to 3276.7%/s (default value: 0)				
Input signal error detection	Input signal error detection setting	0: Enable 1: Disable (default value)		Page 44, Section 4.6	
Scaling function	Scaling enable/disable setting	0: Enable 1: Disable (default value)		Page 50, Section 4.9	
	Scaling upper limit value	-32000 to 32000 (default value: 0)			
	Scaling lower limit value	-32000 to 32000 (default value: 0)			
Input range setting	Input range setting	0: Factory Default Range 0 to 5AAC (default value) 1: Factory Default Range 0 to 50AAC 2: Factory Default Range 0 to 100AAC 3: Factory Default Range 0 to 200AAC 4: Factory Default Range 0 to 400AAC 5: Factory Default Range 0 to 600AAC 16: User Range 0 to 5AAC 17: User Range 0 to 50AAC 18: User Range 0 to 100AAC 19: User Range 0 to 200AAC 20: User Range 0 to 400AAC 21: User Range 0 to 600AAC		Page 36, Section 4.2	
Dropout setting	Dropout detection setting	0: Enable 1: Disable (default value)		Page 49, Section 4.8	
	Dropout value	1 to 10000 (default value: 50)			

Item		Setting value	Reference
Peak current detection setting	Peak current detection setting	0: Enable 1: Disable (default value)	Page 46, Section 4.7
	Peak current detection time	10 to 10000ms (default value: 1000)	
	Peak current detection value	0 to 11999 (default value: 0)	
Logging function	Logging enable/disable setting	0: Enable 1: Disable (default value)	Page 60, Section 4.12
	Logging cycle setting value	ms: 10 to 32767 (default value: 300) s: 1 to 3600 (default value: 300)	
	Logging cycle unit setting	0: Update Cycle (default value) 1: ms 2: s	
	Logging data setting	0: Digital Output Value 1: Scaling Value (default value)	
	Logging points after trigger	1 to 5000 (default value: 2500)	
	Level trigger condition setting	0: Disable (default value) 1: Above 2: Below 3: Pass Through	
	Trigger data	0 to 4999 (CH1 default value: 54) (CH2 default value: 55) (CH3 default value: 56) (CH4 default value: 57) (CH5 default value: 58) (CH6 default value: 59) (CH7 default value: 60) (CH8 default value: 61)	
Trigger setting value	-32768 to 32767 (default value: 0)		

8.4 Auto Refresh

This function transfers data in the buffer memory to specified devices.
Programming of reading/writing data is unnecessary.


(1) Setting procedure

Open the "Auto_Refresh" window.

1. Start "Auto_Refresh".

 Project window → [Intelligent Function Module] → Module Name → [Auto_Refresh]

2. Click the item to set, and input the destination device for auto refresh.



Point

Available devices are X, Y, M, L, B, T, C, ST, D, W, R, and ZR.

When a bit device X, Y, M, L, or B is used, set a number that is divisible by 16 points (example: X10, Y120, M16).

Data in the buffer memory are stored in 16 points of devices starting from the set device No. (Example: When X10 is set, the data are stored in X10 to X1F).

8.5 Offset/gain Setting

When using a user range, configure the offset/gain setting with the following operations.

When using a factory default range, the offset/gain setting is not required.

The offset/gain setting can be configured from the following two types of operations.


- Setting from "Offset/Gain Setting" of GX Works2
- Setting from a program

8.5.1 Setting from "Offset/Gain Setting" of GX Works2


(1) Setting procedure


Open the "Offset/Gain Setting" window.


 [Tool]⇒[Intelligent Function Module Tool]⇒[Analog Module]⇄[Offset/Gain Setting...]



1. Select the module to configure the offset/gain setting, and click the  button.







2. Click the  button.



3. Select the channel to use the offset/gain setting, and click the  button.






4. Select a user range according to the type of the CT to be connected, and click the  button. To use the input range set at the beginning of "Offset/Gain Setting", select "Not to Change" and click the  button.

5. Input the offset value current to the target channel terminals, and click the  button.


6. Check that "Offset Status" changed to "Changed", and click the  button.

7. Select "Not to Change", and click the  button.*1

*1 When setting a gain only, set an input range according to the Step 4.



8. Input the gain value current to the target channel terminals, and click the **Yes** button.



9. Check that "Gain Status" changed to "Changed", and click the **Close** button.



10. Click the **Entry** button.



End


Point

The same input range must be selected for an offset setting and gain setting for the same channel.

8.5.2 Setting from a program

(1) Setting procedure

The following is the procedure to configure the offset/gain setting using a sequence program.



*1 The following are the methods to switch modes (normal mode → offset/gain setting mode → normal mode).

- Dedicated Instruction (G(P).OFFGAN (☞ Page 241, Appendix 1.1))
- Setting Mode switching setting (Un\G158, Un\G159) and turning on then off Operating condition setting request (Y9) (☞ Page 120, Section 6.2 (21))
- Intelligent Function Module Switch Setting (☞ Page 145, Section 8.2)

- Configure the offset/gain setting in accordance with the actual use situation.
- Offset and gain values are recorded in the non-volatile memory in the CT input module by turning on then off User range write request (YA). The values are not deleted even after the power is turned off. If the values are written 26 times in succession, an error (error code: 162) occurs and the error code is stored in Latest error code (Un\G19) to prevent an improper write to non-volatile memory.
- Configure the offset/gain setting in the range satisfying the condition described in the following section. If a setting is out of the specified range, the maximum resolution and accuracy of the module may not fall within the range described in the performance specifications list.
 - I/O conversion characteristics (Page 29, Section 3.2.2)
- The offset/gain setting can be configured for multiple channels at the same time; however, the offset setting and gain setting must be configured separately. If the settings are configured at the same time, an error (error code: 500) occurs and the ERR. LED turns on.
- When User range write request (YA) is turned on, the integrity of the offset and gain values are checked. If an error (error code: 40□) occurs in even one channel, the offset and gain values are not written to the module. Check the value in Latest error code (Un\G19), and take the action described in the following section to start over the offset/gain setting.
 - Error Code List (Page 228, Section 11.1)
- When the mode is switched from the offset/gain setting mode to the normal mode by the setting of the dedicated instruction (G(P).OFFGAN) or Mode switching setting (Un\G158, Un\G159), Module READY (X0) turns on. Note that initial settings are processed at this timing if any sequence program is set to configure initial settings when Module READY (X0) turns on.
- To activate the intelligent function module switch setting after writing the setting to the CPU module, reset the CPU module or turn off then on the power supply.
- If a user range is not set in CH□ Input range setting (Un\G150 to Un\G157), an error (error code: 511) occurs.
- When the mode is switched from the offset/gain setting mode to the normal mode, the stored value of the buffer memory is restored to the status before the switching. The CT input module operates with the restored buffer memory values.
- If a gain setting is configured for input whose digital value exceeds 10000, the accuracy of digital values cannot be guaranteed. Configure an offset/gain setting so that the digital values are within 0 to 10000.
- When the mode is switched using the dedicated instruction (G(P).OFFGAN) or Mode switching setting (Un\G158, Un\G159), the digital conversion stops. To resume the digital conversion, turn on then off Operating condition setting request (Y9) after switching the mode to the normal mode.

(2) Program example

(a) Device


Ex. The I/O numbers of the CT input module are X/Y00 to 0F.
The following table lists the devices used in the program example.

Device	Function
M0	Channel selection
M1	Offset setting
M2	Gain setting
M3	Channel change command
M4	Command to write offset/gain setting values to the module
M5	Mode switching
M10	Input range change command
D0	Channel-specified storage device
D1	Storage device for the setting value of the dedicated instruction (G(P).OFFGAN)

(b) Switching the mode using the dedicated instruction (G(P).OFFGAN)

This sequence program executes the following operations.

- Switching the mode from the normal mode to the offset/gain setting mode using the dedicated instruction (G(P).OFFGAN)
- Switching the channels for which the offset/gain settings are configured
- Writing the offset/gain values to the CT input module
- Switching the mode from the offset/gain setting mode back to the normal mode using the dedicated instruction (G(P).OFFGAN)




- *1 Set one of the following values (input range) according to the specifications of the CT to be connected.
- 0 to 5AAC (0010_H)
 - 0 to 50AAC (0011_H)
 - 0 to 100AAC (0012_H)
 - 0 to 200AAC (0013_H)
 - 0 to 400AAC (0014_H)
 - 0 to 600AAC (0015_H)

Point

The program enclosed by the dotted line is the common programs among the following three programs.

- Switching the mode using the dedicated instruction (G(P).OFFGAN)
- Switching the mode by setting Mode switching setting (Un\G158, Un\G159) and using Operating condition setting request (Y9)
- Switching the mode using the intelligent function module switch setting

(c) Switching the mode by setting Mode switching setting (Un\G158, Un\G159) and using Operating condition setting request (Y9)



(d) Switching the mode using the intelligent function module switch setting


The programs other than the common program are not necessary.

CHAPTER 9 PROGRAMMING

This chapter describes the programming procedure and basic programs for the CT input module.

9.1 Programming Procedure


Create a program to execute digital conversion, according to the following procedure.



9.2 When Using the Module in a Standard System Configuration

This section introduces program examples where the following system configuration and conditions apply.

(1) System configuration



(2) Programming condition


Digital output values are read in the following conditions.

- Used channel: CH1 to CH3
- Input range: Factory default range 0 to 5AAC
- Digital conversion method in CH1: Sampling processing
- Digital conversion method in CH2: Count average processing (50 times)
- Digital conversion method in CH3: Primary delay filter (Time constant: 100ms)
- If an error occurs in the module, an error code is displayed in BCD notation

(3) Switch setting

Set the operation mode.

Project window ⇨ [Intelligent Function Module] ⇨ [Q68CT] ⇨ [Switch Setting]



(4) Initial setting**(a) Channel setting**

Item	Setting			
	CH1	CH2	CH3	CH4 to CH8
Conversion enable/disable setting	Enable	Enable	Enable	Disable
Averaging process setting	Sampling Processing	Count Average	Primary Delay Filter	Sampling Processing
Average time/Average number of times/Moving average/Time constant settings	0	50 Times	100ms	0
Sampling cycle setting	10ms/8CH			
Process alarm warning output setting	Disable	Enable	Disable	Disable
Process alarm upper upper limit value	0	7000	0	0
Process alarm upper lower limit value	0	6000	0	0
Process alarm lower upper limit value	0	1500	0	0
Process alarm lower lower limit value	0	1000	0	0
Rate alarm warning output setting	Disable	Disable	Enable	Disable
Rate alarm warning detection period	0	0	50ms	0
Rate alarm upper limit value	0	0	0.3%/s	0
Rate alarm lower limit value	0	0	0.1%/s	0
Input signal error detection setting	Enable	Disable	Disable	Disable
Input range setting	Factory Default Range 0 to 5AAC			
Peak current detection setting	Enable	Disable	Disable	Disable
Peak current detection time	1000ms	1000ms	1000ms	1000ms
Peak current detection value	7000	0	0	0

9.2.1 Program example when using parameters of the intelligent function module

(1) Device for user

Device	Description	
D0	Conversion completed flag	
D1 (D11)	CH1 Digital output value	
D2 (D12)	CH2 Digital output value	
D3 (D13)	CH3 Digital output value	
D6	Warning output flag (Process alarm)	
D7	Warning output flag (Rate alarm)	
D8	Input signal error detection flag	
D9	Peak current detection flag	
D10	Latest error code	
M0	CH1 Conversion completed flag	
M1	CH2 Conversion completed flag	
M2	CH3 Conversion completed flag	
M10 to M25	Warning output flag (Process alarm)	
M30 to M45	Warning output flag (Rate alarm)	
M50 to M57	Input signal error detection flag	
M70 to M77	Peak current detection flag	
X0	Module READY	CT input module (X/Y0 to X/YF)
XC	Input signal error detection signal	
XE	Conversion completed flag	
XF	Error flag	
Y9	Operating condition setting request	
YF	Error clear request	
X10	Digital output value read command input signal	QX10 (X10 to X1F)
X13	Input signal error detection reset signal	
X14	Error reset signal	
Y20 to Y2F	Error code display (BCD 4 digits)	QY10 (Y20 to Y2F)

(2) Parameter setting

Set the contents of initial settings to the parameters.


 Project window ⇨ [Intelligent Function Module] ⇨ [Q68CT] ⇨ [Parameter]

Item	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Basic setting								
Set the digital conversion system.								
Conversion enable/disable setting	0:Enable	0:Enable	0:Enable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Averaging process setting	0:Sampling Processing	2:Count Average	4:Primary Delay Filter	0:Sampling Processing	0:Sampling Processing	0:Sampling Processing	0:Sampling Processing	0:Sampling Process
Average time/Average number of times/Moving average/Time constant settings	0	50 Times	100 ms	0	0	0	0	0
Sampling cycle setting	0:10ms/8CH							
Warning output function								
Set about the warning of digital conversion.								
Process alarm warning output setting	1:Disable	0:Enable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Process alarm upper upper limit value	0	7000	0	0	0	0	0	0
Process alarm upper lower limit value	0	6000	0	0	0	0	0	0
Process alarm lower upper limit value	0	1500	0	0	0	0	0	0
Process alarm lower lower limit value	0	1000	0	0	0	0	0	0
Rate alarm warning output setting	1:Disable	1:Disable	0:Enable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Rate alarm warning detection period	0 ms	0 ms	50 ms	0 ms	0 ms	0 ms	0 ms	0 ms
Rate alarm upper limit value	0.0 %/s	0.0 %/s	0.3 %/s	0.0 %/s				
Rate alarm lower limit value	0.0 %/s	0.0 %/s	0.1 %/s	0.0 %/s				
Input signal error detection								
Set about the input signal of digital conversion.								
Input signal error detection setting	0:Enable	1:Disable						
Scaling function								
Set about the scaling of digital conversion.								
Scaling enable/disable setting	1:Disable							
Scaling upper limit value	0	0	0	0	0	0	0	0
Scaling lower limit value	0	0	0	0	0	0	0	0
Input range setting								
Set about the input range of digital conversion.								
Input range setting	0:Factory Default Range AC0 to 5A							
Dropout setting								
Set about the dropout of digital conversion.								
Dropout detection setting	1:Disable							
Dropout value	50	50	50	50	50	50	50	50
Peak current detection setting								
Set about the peak current detection of digital conversion.								
Peak current detection setting	0:Enable	1:Disable						
Peak current detection time	1000 ms							
Peak current detection value	7000	0	0	0	0	0	0	0
Logging function								
Set about the logging function of digital conversion.								
Logging enable/disable setting	1:Disable							
Logging cycle setting value	300	300	300	300	300	300	300	300

9.2 When Using the Module in a Standard System Configuration
9.2.1 Program example when using parameters of the intelligent function module

(3) Auto refresh setting


Project window ⇨ [Intelligent Function Module] ⇨ [Q68CT] ⇨ [Auto_Refresh]



(4) Writing the parameters of intelligent function module


Write the set parameters to the CPU module, and reset the CPU module or turn off then on the programmable controller power supply.

[Online] ⇨ [Write to PLC...]



or Power OFF → ON

(5) Program example





9.2.2 Program example when not using parameters of the intelligent function module

(1) Device for user

Device	Description	
D11	CH1 Digital output value	
D12	CH2 Digital output value	
D13	CH3 Digital output value	
M0	CH1 Conversion completed flag	
M1	CH2 Conversion completed flag	
M2	CH3 Conversion completed flag	
M10 to M25	Warning output flag (Process alarm)	
M30 to M45	Warning output flag (Rate alarm)	
M50 to M57	Input signal error detection flag	
M70 to M77	Peak current detection flag	
M100	Module READY check flag	
X0	Module READY	CT input module (X/Y0 to X/YF)
X9	Operating condition setting completed flag	
XC	Input signal error detection signal	
XE	Conversion completed flag	
XF	Error flag	
Y9	Operating condition setting request	
YF	Error clear request	
X10	Digital output value read command input signal	QX10 (X10 to X1F)
X13	Input signal error detection reset signal	
X14	Error reset signal	
Y20 to Y2F	Error code display (BCD 4 digits)	QY10 (Y20 to Y2F)

(2) Program example





9.3 When Using the Module on the Remote I/O Network


This section describes the system configuration and program examples of when the CT input module is used on a remote I/O network.

Point

For details on the MELSECNET/H remote I/O network, refer to the following.

 Q Corresponding MELSECNET/H Network System Reference Manual (Remote I/O network)

(1) System configuration



(2) Programming condition

Digital output values are read in the following conditions.

- Used channel: CH1 to CH3
- Input range: Factory default range 0 to 5AAC
- Digital conversion method in CH1: Sampling processing
- Digital conversion method in CH2: Count average processing (50 times)
- Digital conversion method in CH3: Primary delay filter (Time constant: 100ms)
- If an error occurs in the module, an error code is displayed in BCD notation

(3) Switch setting

For the switch setting, refer to the procedure described in the following section.

 Page 171, Section 9.3 (6)

(4) Initial setting

(a) Channel setting


Item	Setting			
	CH1	CH2	CH3	CH4 to CH8
Conversion enable/disable setting	Enable	Enable	Enable	Disable
Averaging process setting	Sampling Processing	Count Average	Primary Delay Filter	Sampling Processing
Average time/Average number of times/Moving average/Time constant settings	0	50 Times	100ms	0
Sampling cycle setting	10ms/8CH			
Process alarm warning output setting	Disable	Enable	Disable	Disable
Process alarm upper upper limit value	0	7000	0	0
Process alarm upper lower limit value	0	6000	0	0
Process alarm lower upper limit value	0	1500	0	0
Process alarm lower lower limit value	0	1000	0	0
Rate alarm warning output setting	Disable	Disable	Enable	Disable
Rate alarm warning detection period	0	0	50ms	0
Rate alarm upper limit value	0	0	0.3%/s	0
Rate alarm lower limit value	0	0	0.1%/s	0
Input signal error detection setting	Enable	Disable	Disable	Disable
Input range setting	Factory Default Range 0 to 5AAC			
Peak current detection setting	Enable	Disable	Disable	Disable
Peak current detection time	1000ms	1000ms	1000ms	1000ms
Peak current detection value	7000	0	0	0

(5) Setting on the master station

1. Create a project on GX Works2.


Select "QCPU (Q mode)" for "PLC Series", and select the CPU module used for "PLC Type".

[Project]⇒[New...]



2. Display the network parameter setting window, and configure the setting as follows.

Project window⇒[Parameter] ⇒ [Network Parameter]⇒ [Ethernet/CC IE/MELSECNET]



9.3 When Using the Module on the Remote I/O Network

3. Display the network range assignment setting window, and configure the setting as follows.

Project window ⇨ [Parameter] ⇨ [Network Parameter] ⇨ [Ethernet/CC IE/MELSECNET]
 ⇨  button

Network Parameter Assign the MNET/10(H) Remote Station Network Range Module No.: 1

Setup common parameters and I/O assignments.

Assignment Method
 Points/Start
 Start/End

Monitoring Time X 10ms
 Total Slave Stations
 Parameter Name
 Switch Screens

Station No.	M Station -> R Station						M Station <- R Station					
	B			B			W			W		
	Points	Start	End	Points	Start	End	Points	Start	End	Points	Start	End
1							512	0000	01FF	256	1000	10FF

Project window ⇨ [Parameter] ⇨ [Network Parameter] ⇨ [Ethernet/CC IE/MELSECNET]
 ⇨  button ⇨ "Switch Screens" ⇨ "XY Setting"

Network Parameter Assign the MNET/10(H) Remote Station Network Range Module No.: 1

Setup common parameters and I/O assignments.


Assignment Method
 Points/Start
 Start/End

Monitoring Time X 10ms
 Total Slave Stations
 Parameter Name
 Switch Screens

Station No.	M Station -> R Station						M Station <- R Station					
	Y			Y			X			X		
	Points	Start	End	Points	Start	End	Points	Start	End	Points	Start	End
1	256	1000	10FF	256	0000	00FF	256	1000	10FF	256	0000	00FF


4. Display the refresh parameter setting window, and configure the setting as follows.

Project window → [Parameter] → [Network Parameter] → [Ethernet/CC IE/MELSECNET]
 →  button



5. Write the set parameters to the CPU module on the master station. Then reset the CPU module or turn off and on the power supply of the programmable controller.

[Online] → [Write to PLC...]




or Power OFF → ON

(6) Setting on the remote I/O station

1. Create a project on GX Works2.


Select "QCPU (Q mode)" for "PLC Series", and select "QJ72LP25/QJ72BR15(RemoteI/O)" for "PLC Type".

[Project] → [New...]




2. Add the Q68CT to the project on GX Works2.

Project window ⇒ [Intelligent Function Module] ⇒ Right-click ⇒ [New Module...]



3. Display the Q68CT "Switch Setting" window, and configure the setting as follows.

Project window ⇒ [Intelligent Function Module] ⇒ [Q68CT] ⇒ [Switch Setting]



4. Display the Q68CT initial setting window, and configure the setting as follows. When creating a program without using parameters of an intelligent function module, skip this procedure.

Project window ⇨ [Intelligent Function Module] ⇨ [Q68CT] ⇨ [Parameter]

0000:Q68CT]-Parameter

Display Filter: Display All


Item	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
Basic setting								
Set the digital conversion system.								
Conversion enable/disable setting	0:Enable	0:Enable	0:Enable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Averaging process setting	0:Sampling	2:Count Average	4:Primary Delay	0:Sampling	0:Sampling	0:Sampling	0:Sampling	0:Sampling
Average time/Average number of times/Moving average/Time constant settings	0	50 Times	100 ms	0	0	0	0	0
Sampling cycle setting	0:10ms/8CH							
Warning output function								
Set about the warning of digital conversion.								
Process alarm warning output setting	1:Disable	0:Enable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Process alarm upper upper limit value	0	7000	0	0	0	0	0	0
Process alarm upper lower limit value	0	6000	0	0	0	0	0	0
Process alarm lower upper limit value	0	1500	0	0	0	0	0	0
Process alarm lower lower limit value	0	1000	0	0	0	0	0	0
Rate alarm warning output setting	1:Disable	1:Disable	0:Enable	1:Disable	1:Disable	1:Disable	1:Disable	1:Disable
Rate alarm warning detection period	0 ms	0 ms	50 ms	0 ms	0 ms	0 ms	0 ms	0 ms
Rate alarm upper limit value	0.0 %/s	0.0 %/s	0.3 %/s	0.0 %/s				
Rate alarm lower limit value	0.0 %/s	0.0 %/s	0.1 %/s	0.0 %/s				
Input signal error detection								
Set about the input signal of digital conversion.								
Input signal error detection setting	0:Enable	1:Disable						
Scaling function								
Set about the scaling of digital conversion.								
Scaling enable/disable setting	1:Disable							
Scaling upper limit value	0	0	0	0	0	0	0	0
Scaling lower limit value	0	0	0	0	0	0	0	0
Input range setting								
Set about the input range of digital conversion.								
Input range setting	0:Factory Default Range AC0 to 5A							
Dropout setting								
Set about the dropout of digital conversion.								
Dropout detection setting	1:Disable							
Dropout value	50	50	50	50	50	50	50	50
Peak current detection setting								
Set about the peak current detection of digital conversion.								
Peak current detection setting	0:Enable	1:Disable						
Peak current detection time	1000 ms							
Peak current detection value	7000	0	0	0	0	0	0	0
Logging function								
Set about the logging function of digital conversion.								
Logging enable/disable	1:Disable							
Logging cycle setting value	300	300	300	300	300	300	300	300

Set whether to 'Enable' or 'Disable' logging function.
 0:Enable
 1:Disable

9.3 When Using the Module on the Remote I/O Network


5. Display the Q68CT auto refresh setting window, and configure the setting as follows. When creating a program without using parameters of an intelligent function module, skip this procedure.

 Project window ⇨ [Intelligent Function Module]⇨ [Q68CT]
 ⇨ [Auto_Refresh]



6. Write the set parameters to the remote I/O module, and reset the remote I/O module.

 [Online]⇨ [Write to PLC...]




9.3.1 Program example when using parameters of the intelligent function module

(1) Device for user

Device	Description	
W1000	Conversion completed flag	
W1001 (D11)	CH1 Digital output value	
W1002 (D12)	CH2 Digital output value	
W1003 (D13)	CH3 Digital output value	
W1006	Warning output flag (Process alarm)	
W1007	Warning output flag (Rate alarm)	
W1008	Input signal error detection flag	
W1009	Peak current detection flag	
W1010	Latest error code	
M0	CH1 Conversion completed flag	
M1	CH2 Conversion completed flag	
M2	CH3 Conversion completed flag	
M10 to M25	Warning output flag (Process alarm)	
M30 to M45	Warning output flag (Rate alarm)	
M50 to M57	Input signal error detection flag	
M70 to M77	Peak current detection flag	
X1000	Module READY	CT input module (X/Y1000 to X/Y100F)
X100C	Input signal error detection signal	
X100E	Conversion completed flag	
X100F	Error flag	
Y1009	Operating condition setting request	
Y100F	Error clear request	
X20	Digital output value read command input signal	QX10 (X20 to X2F)
X23	Input signal error detection reset signal	
X24	Error reset signal	
Y30 to Y3F	Error code display (BCD 4 digits)	QY10 (Y30 to Y3F)

(2) Program example



9.3.2 Program example when not using parameters of the intelligent function module


(1) Device for user


Device	Description	
D1000 to D1326	Device for initial value setting	
D2010	Conversion completed flag	
D2011 (D11)	CH1 Digital output value	
D2012 (D12)	CH2 Digital output value	
D2013 (D13)	CH3 Digital output value	
D2019	Latest error code	
D2049	Input signal error detection flag	
D2050	Warning output flag (Process alarm)	
D2051	Warning output flag (Rate alarm)	
D2301	Peak current detection flag	
M10 to M25	Warning output flag (Process alarm)	
M30 to M45	Warning output flag (Rate alarm)	
M50 to M57	Input signal error detection flag	
M70 to M77	Peak current detection flag	
M100	Master station status check flag	
M101	Initial setting start trigger	
M102	Initial setting start flag	
M103	During initial setting flag	
M104	Initial setting completed flag	
M200 to M219	Z(P).REMTO and Z(P).REMFR instructions completion/result device	
M300, M301		
M310, M311		
M320, M321		
M330, M331		
M340, M341		
X1000	Module READY	CT input module (X/Y1000 to X/Y100F)
X1009	Operating condition setting completed flag	
X100C	Input signal error detection signal	
X100E	Conversion completed flag	
X100F	Error flag	
Y1009	Operating condition setting request	
Y100F	Error clear request	QX10 (X20 to X2F)
X20	Digital output value read command input signal	
X23	Input signal error detection reset signal	
X24	Error reset signal	QY10 (Y30 to Y3F)
Y30 to Y3F	Error code display (BCD 4 digits)	
SB20	Module status	
SB47	Baton pass status of own station	
SB49	Data link status (own station)	
SW70	Baton pass status of each station	
SW74	Cyclic transmission status of each station	

 9.3 When Using the Module on the Remote I/O Network
 9.3.2 Program example when not using parameters of the intelligent function module


Device	Description
SW78	Parameter communication status of each station
T100 to T104	Interlock for own station and other stations


(2) Program example





9.3 When Using the Module on the Remote I/O Network
 9.3.2 Program example when not using parameters of the intelligent function module





Processing when an alert occurs for CH3 Rate alarm lower limit value

Read Input signal error detection flag.

Processing when CH1 Input signal error

Turn on input signal error reset signal.

Output the error code in BCD.

Turn on Error clear request.

Turn off Error clear request.

CHAPTER 10 ONLINE MODULE CHANGE

This chapter describes the online module change procedure using GX Works2.

The online module change procedure with GX Works2 is applicable only when the CT input module is used on a MELSECNET/H remote I/O network. When the CT input module is not used on the MELSECNET/H remote I/O network, perform the online module change using GX Developer ( Page 253, Appendix 3).

When performing an online module change, carefully read the following.

-  QCPU User's Manual (Hardware Design, Maintenance and Inspection)

10.1 Precautions on Online Module Change

This section lists precautions on an online module change.

- Always perform an online module change in the correct procedure ( Page 185, Section 10.4). A failure to do so can cause a malfunction or failure.
- Perform an online module change after making sure that the system outside the programmable controller will not malfunction.
- Provide means such as switches for powering off each of the external power supply and external devices connected to the module to be replaced online. Failure to do so may cause an electric shock and malfunction of operating modules.
- After the module has failed, the buffer memory data may not be saved properly. Prerecord the data to be saved.
- It is recommended to perform an online module change in the actual system in advance to ensure that it would not affect the other modules. For the operational verification, check the following:
 - Means of cutting off the connection to external devices and its configuration are correct.
 - Switching on/off does not bring any undesirable effect.
- After the first use of the product, do not mount/remove the module to/from the base unit, and the terminal block to/from the module more than 50 times (IEC 61131-2 compliant) respectively. Exceeding the limit may cause malfunction.

10.2 Conditions for Online Module Change

To perform an online module change, satisfy the following conditions.

Remark

The function version of the first released CT input module is C, and the CT input module supports the online module change.
.....

(1) Function version of MELSECNET/H remote I/O module

A module of function version D or later is necessary.

(2) Compatible version of GX Works2

GX Works2 of Version 1.40S or later is necessary.

(3) Restrictions of base unit

When the module is mounted on any of the following base units, an online module change cannot be performed.

- Slim type main base unit (Q3□SB)
- Extension base unit (Q5□B) which does not require the power supply module (An online module change cannot be performed for all modules on the base unit.)

10.3 Online Module Change Operations

The following table explains the operations for an online module change.

○: Executed ×: Not executed

User operation	Operation of the CT input module	Operation of the CPU module				Operation of the remote I/O module	
		X/Y refresh	FROM/TO instructions*1	Dedicated instruction	Device test	Parameter setting	Device test
<p>(1) Stop the operation.</p> <p>Turn off all of the Y signals turned on using the sequence program.</p>	The module is operating normally.	○	○	○	○	×	○
<p>(2) Remove the module.</p> <p>Start the online module change using GX Works2.</p> <p>Click the  button on GX Works2 to enable the module to be removed.</p> <p>Remove the module.</p>	<p>The operation of the module stops.</p> <ul style="list-style-type: none"> • The RUN LED turns off. • Conversion disabled. 	×	×	×	×	×	×
<p>(3) Mount a new module.</p> <p>Mount a new module.</p> <p>After mounting the module, click the  button on GX Works2.</p> <p>Check the operation before the control starts.</p>	<p>The X/Y refresh restarts and the module starts up.</p> <ul style="list-style-type: none"> • The RUN LED turns on. • Default operation starts. (Module READY (X0) remains off.) <p>(When there are initial setting parameters, the module starts to operate based on the initial setting parameters at this point.)</p>	○	×	×	×	○	×
<p>(4) Check the operation.</p> <p>Click the  button on GX Works2 to turn off the online mode.</p> <p>On "Device test" on GX Works2, test the operation of the module.</p> <p>(Restore the user range settings by writing of buffer memory addresses at this point.)</p> <p>Operation check is completed.</p>	The module operates based on the test operation.*2	○	×	×	○	×	○
<p>(5) Resume the control.</p> <p>Restart the online module change using GX Works2.</p> <p>Click the  button to resume the control.</p>	<p>Module READY (X0) turns on.</p> <p>↓</p> <p>The module operates based on the initial setting sequence program which runs when Module READY (X0) turns on.*2</p>	○	○	○	○	×	○

*1 An access to Intelligent function module device (U□\G□) is included.

*2 In the absence of the operation marked *2, the operation of the intelligent function module is the operation performed prior to that.

10.4 Online Module Change Procedure


Perform an online module change using GX Works2 connected to a remote I/O module.

This section describes two online module change procedures: setting parameters using GX Works2 and setting parameters using a sequence program.

Range setting	Parameter setting	Another system	Reference
Factory default range	Configuration function	—	Page 187, Section 10.5
	Sequence program	—	Page 193, Section 10.6
User range	Configuration function	Present	Page 200, Section 10.7
		Absent	Page 213, Section 10.9
	Sequence program	Present	Page 206, Section 10.8
		Absent	Page 220, Section 10.10


(1) System configuration

The following system configuration is used to explain the online module change procedure.





(2) Procedure

The following flow shows the online module change procedure.



10.5 When a Factory Default Range Is Used and Parameters Are Set Using the Configuration Function

(1) Stopping operation



(To the next page)

1. Create a new project.

[Project] ⇒ [New...]



2. Select "QJ72LP25/QJ72BR15(RemoteI/O)" in "PLC Type" and click the button.

3. Open the "Transfer Setup" window.

Navigation window ⇒ Connection Destination view ⇒ (Connection destination data name)

4. Configure the settings to access the module on the remote I/O station and click the button.

(From the previous page)



5. Open the "Device/Buffer Memory Batch Monitor" window.

☞ [Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]



6. Enter and display the buffer memory address of Conversion enable/disable setting (Un\G0).

7. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.

8. Turn on then off Operating condition setting request (Y9).

9. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).


(2) Removing a module



1. Open the "System Monitor" window.
2. Select "Online module change" under the "Mode" field and double-click the module name to be changed online.

3. Click the **Execute** button to enable a module change.

4. When the following error window appears, click the **OK** button and perform the operation described in [Page 190, Section 10.5 \(3\)](#).




5. After confirming that the RUN LED of the module has turned off, remove the terminal block.
6. Remove the module.

Point!


Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.

(3) Mounting a new module




1. Mount a new module in the same slot and install the terminal block.
2. After mounting the module, click the  button and make sure that the RUN LED is lit. Module READY (X0) remains off.

(4) Checking operation



1. To check the operation, click the  button to cancel the control start.




2. Click the  button to leave the "Online Module Change" mode.




(To the next page)

(From the previous page)



3. Click the Close button to close the "System Monitor" window.



10



4. Open the "Device/Buffer Memory Batch Monitor" window.
☞ [Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]
5. Monitor Conversion enable/disable setting (Un\G0) to check if the channel to be used is set to Enable (0).
6. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.
7. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (☞ Page 228, CHAPTER 11) and take a corrective action.
 - If the RUN LED is on.
 - If the ERR. LED is off.
 - If Error flag (XF) is off.

10.5 When a Factory Default Range is Used and Parameters Are Set Using the Configuration Function

(5) Resuming operation



1. Open the "Online Module Change" window again.


 [Diagnostics] ⇒ [Online Module Change...]

2. Click the  button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

10.6 When a Factory Default Range Is Used and Parameters Are Set Using a Sequence Program

(1) Stopping operation



1. Create a new project.


[Project] ⇒ [New...]

2. Select "QJ72LP25/QJ72BR15(RemoteI/O)" in "PLC Type" and click the button.



3. Open the "Transfer Setup" window.



Navigation window ⇒ Connection Destination view ⇒ (Connection destination data name)



4. Configure the settings to access the module on the remote I/O station and click the button.

(To the next page)

(From the previous page)



5. Open the "Device/Buffer Memory Batch Monitor" window.

[Online] ⇌ [Monitor] ⇌ [Device/Buffer Memory Batch]


6. Enter and display the buffer memory address of Conversion enable/disable setting (Un\G0).

7. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.

8. Turn on then off Operating condition setting request (Y9).

9. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).


(2) Removing a module



1. Open the "System Monitor" window of the remote I/O module.

[Diagnostics] ⇨ [Online Module Change...]

2. Select "Online Module Change" under the "Mode" field and double-click the module name to be changed online.




3. Click the **Execute** button to enable a module change.

4. When the following error window appears, click the

OK button and perform the operation

described in Page 196, Section 10.6 (3).




5. After confirming that the RUN LED of the module has turned off, remove the terminal block.

6. Remove the module.

Point


Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.

(3) Mounting a new module





1. Mount a new module in the same slot and install the terminal block.
2. After mounting the module, click the  button and make sure that the RUN LED is lit. Module READY (X0) remains off.

(4) Checking operation




1. To check the operation, click the  button to cancel the control start.



2. Click the  button to leave the "Online Module Change" mode.


(To the next page)

(From the previous page)



3. Click the **Close** button to close the "System Monitor" window.

10



4. Open the "Device/Buffer Memory Batch Monitor" window.
5. Enter and display the buffer memory address of Conversion enable/disable setting (Un/G0).

[Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]



(To the next page)

10.6 When a Factory Default Range Is Used and Parameters Are Set Using a Sequence Program



(From the previous page)



Device/Label	Data Type	Setting Value
Y9	Bit	OFF
Y9	Bit	ON
U0\G0	Word[Signed]	F8(H)


6. Set Conversion enable/disable setting (Un\G0) to Enable (0) for the channel used, and turn on then off Operating condition setting request (Y9).
7. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.

8. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (👉 Page 228, CHAPTER 11) and take a corrective action.
 - If the RUN LED is on.
 - If the ERR. LED is off.
 - If Error flag (XF) is off.
9. Since the new module is in the default status, initial settings must be configured using a sequence program after the control resumed. Before the initial setting, check if the initial setting program is proper, satisfying the following.
 - Insert a user device where the initial setting will be set at any timing (initial setting request signal) into the sequence program.
 - Do not create a sequence program which sets the initial setting only one scan after a data link start of the remote I/O network. In this case, the initial setting is not set.

(5) Resuming operation

1. Open the "Online Module Change" window again.



 [Diagnostics] ⇨ [Online Module Change...]

2. Click the  button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

10.7 When a User Range Is Used and Parameters Are Set Using the Configuration Function (with Another System)

(1) Stopping operation



(To the next page)

1. Create a new project.

[Project] ⇒ [New...]



2. Select "QJ72LP25/QJ72BR15(RemoteI/O)" in "PLC Type" and click the button.

3. Open the "Transfer Setup" window.

Navigation window ⇒ Connection Destination view ⇒ (Connection destination data name)

4. Configure the settings to access the module on the remote I/O station and click the button.

(From the previous page)



5. Open the "Device/Buffer Memory Batch Monitor" window.

[Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]



6. Enter and display the buffer memory address of Conversion enable/disable setting (Un\G0).

7. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.

8. Turn on then off Operating condition setting request (Y9).

9. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).

(2) Removing a module



1. Open the "System Monitor" window of the remote I/O module.


[Diagnostics] ⇨ [Online Module Change...]

2. Select "Online Module Change" under the "Mode" field and double-click the module name to be changed online.

3. Click the button to enable a module change.

4. When the following error window appears, click the

button and perform the operation described in Page 203, Section 10.7 (3).



5. After confirming that the RUN LED of the module has turned off, remove the terminal block.


6. Remove the module.

Point!


Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.

(3) Mounting a new module

1. Mount the removed module and new module to the other system.
2. Using the G(P).OGLOAD instruction, save the offset/gain setting values in the user range from the removed module to the CPU device. Refer to  Page 243, Appendix 1.2 for the G(P).OGLOAD instruction.
3. Using the G(P).OGSTOR instruction, restore the offset/gain setting values in the user range to a new module. Refer to  Page 247, Appendix 1.3 for the G(P).OGSTOR instruction.
4. Remove the new module from the other system, mount it to the slot from where the old module was removed in the original system, and install the terminal block.
5. After mounting the module, click the  button and make sure that the RUN LED is lit. Module READY (X0) remains off.





(4) Checking operation



↓
(To the next page)


1. To check the operation, click the  button to cancel the control start.

(From the previous page)



2. Click the  button to leave the "Online Module Change" mode.

3. Click the  button to close the "System Monitor" window.



4. Open the "Device/Buffer Memory Batch Monitor" window.



 [Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]

5. Monitor the buffer memory address of Conversion enable/disable setting (Un\G0) to check if the channel to be used is set to Enable (0).

6. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.

7. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (👉 Page 228, CHAPTER 11) and take a corrective action.

- If the RUN LED is on.
- If the ERR. LED is off.
- If Error flag (XF) is off.

(5) Resuming operation

1. Open the "Online Module Change" window again.



 [Diagnostics] ⇨ [Online Module Change...]

2. Click the  button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

10.8 When a User Range Is Used and Parameters Are Set Using a Sequence Program (with Another System)

(1) Stopping operation



(To the next page)

1. Create a new project.

[Project] ⇒ [New...]



2. Select "QJ72LP25/QJ72BR15(RemoteI/O)" in "PLC Type" and click the button.

3. Open the "Transfer Setup" window.

Navigation window ⇒ Connection Destination view ⇒ (Connection destination data name)

4. Configure the settings to access the module on the remote I/O station and click the button.

(From the previous page)



5. Open the "Device/Buffer Memory Batch Monitor" window.

[Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]



6. Enter and display the buffer memory address of Conversion enable/disable setting (Un\G0).

7. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.

8. Turn on then off Operating condition setting request (Y9).

9. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).

(2) Removing a module



1. Open the "System Monitor" window of the remote I/O module.

[Diagnostics] ⇨ [Online Module Change...]

2. Select "Online Module Change" under the "Mode" field and double-click the module name to be changed online.

3. Click the button to enable a module change.

4. When the following error window appears, click the

button and perform the operation described in Page 209, Section 10.8 (3).



5. After confirming that the RUN LED of the module has turned off, remove the terminal block.


6. Remove the module.

Point


Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.

(3) Mounting a new module

1. Mount the removed module and new module to the other system.
2. Using the G(P).OGLOAD instruction, save the offset/gain setting values in the user range from the removed module to the CPU device. Refer to  Page 243, Appendix 1.2 for the G(P).OGLOAD instruction.
3. Using the G(P).OGSTOR instruction, restore the offset/gain setting values in the user range to a new module. Refer to  Page 247, Appendix 1.3 for the G(P).OGSTOR instruction.
4. Remove the new module from the other system, mount it to the slot from where the old module was removed in the original system, and install the terminal block.
5. After mounting the module, click the  button and make sure that the RUN LED is lit. Module READY (X0) remains off.






(4) Checking operation



↓
(To the next page)


1. To check the operation, click the  button to cancel the control start.

(From the previous page)



(To the next page)

2. Click the  button to leave the "Online Module Change" mode.

3. Click the  button to close the "System Monitor" window.

4. Open the "Device/Buffer Memory Batch Monitor" window.

 [Online] ⇔ [Monitor] ⇔ [Device/Buffer Memory Batch]

5. Enter and display the buffer memory address of Conversion enable/disable setting (UnG0).

(From the previous page)





Device/Label	Data Type	Setting Value
Y9	Bit	OFF
Y9	Bit	ON
U0\G0	Word[Signed]	F8(H)

6. Set Conversion enable/disable setting (Un\G0) to Enable (0) for the channel used, and turn on then off Operating condition setting request (Y9).
7. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.

8. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (☞ Page 228, CHAPTER 11) and take a corrective action.
 - If the RUN LED is on.
 - If the ERR. LED is off.
 - If Error flag (XF) is off.
9. Since the new module is in the default status, initial settings must be configured using a sequence program after the control resumed. Before the initial setting, check if the initial setting program is proper, satisfying the following.
 - Insert a user device where the initial setting will be set at any timing (initial setting request signal) into the sequence program.
 - Do not create a sequence program which sets the initial setting only one scan after a data link start of the remote I/O network. In this case, the initial setting is not set.

(5) Resuming operation



1. Open the "Online Module Change" window again.




 [Diagnostics] ⇨ [Online Module Change...]

2. Click the  button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

10.9 When a User Range Is Used and Parameters Are Set Using the Configuration Function (without Another System)

(1) Stopping operation



(To the next page)

1. Create a new project.

[Project] ⇒ [New...]



2. Select "QJ72LP25/QJ72BR15(RemoteI/O)" in "PLC Type" and click the button.

3. Open the "Transfer Setup" window.

Navigation window ⇒ Connection Destination view ⇒ (Connection destination data name)

4. Configure the settings to access the module on the remote I/O station and click the button.

(From the previous page)



5. Open the "Device/Buffer Memory Batch Monitor" window.

[Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]

6. Enter and display the buffer memory address of Conversion enable/disable setting (Un\G0).

7. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.

8. Turn on then off Operating condition setting request (Y9).

9. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).

10. If the buffer memory data are not recorded, follow the procedures 11 and 12.



11. Compare the values in CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233) with the values in Range Reference Table (Page 227, Section 10.11).

12. If the values are proper, save the values in CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233).

Point


- If the buffer memory values are improper compared to the reference table, the offset/gain values cannot be saved and restored. Before resuming the control, configure an offset/gain setting according to the flowchart (Page 153, Section 8.5.2). Note that if module control is resumed without offset/gain setting being made, operation will be performed with the default values.
- Switch the mode by setting Mode switching setting (Un\G158, Un\G159) and turning on Operating condition setting request (Y9).


(2) Removing a module



1. Open the "System Monitor" window.
 [Diagnostics] ⇨ [Online Module Change...]
2. Select "Online Module Change" under the "Mode" field and double-click the module name to be changed online.

3. Click the  button to enable a module change.

4. When the following error window appears, click the  button and perform the operation described in  Page 216, Section 10.9 (3).




5. After confirming that the RUN LED of the module has turned off, remove the terminal block.
6. Remove the module.

Point


Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.

(3) Mounting a new module





1. Mount a new module in the same slot and install the terminal block.
2. After mounting the module, click the  button and make sure that the RUN LED is lit. Module READY (X0) remains off.

(4) Checking operation



1. To check the operation, click the  button to cancel the control start.




2. Click the  button to leave the "Online Module Change" mode.




(To the next page)

(From the previous page)



3. Click the  button to close the "System Monitor" window.


10



4. Open the "Device/Buffer Memory Batch Monitor" window.

 [Online] [Monitor] ⇨ [Device/Buffer Memory Batch]

5. Display the address of the prerecorded buffer memory area and select it. Then click the

 button.



(To the next page)

10.9 When a User Range Is Used and Parameters Are Set Using the Configuration Function (without Another System)

(From the previous page)



Modify Value

Device/Label Buffer Memory

Device/Label YA

Data Type Bit

ON OFF Switch ON/OFF

Settable Range

Execution Result << Close



Execution Result

Device/Label	Data Type	Setting Value
YA	Bit	OFF
YA	Bit	ON
U0\GO	Word[Signed]	1000(H)

Reflect to Input Column Delete(C)

6. Set the prerecorded data to the buffer memory.
7. Turn User range write request (YA) from off to on to restore the offset/gain setting value in the user range to the module.
8. After confirming that Offset/gain setting mode flag (XA) is on, turn off User range write request (YA).
9. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.

10. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (👉 Page 228, CHAPTER 11) and take a corrective action.
 - If the RUN LED is on.
 - If the ERR. LED is off.
 - If Error flag (XF) is off.

(5) Resuming operation

1. Open the "Online Module Change" window again.



 [Diagnostics] ⇨ [Online Module Change...]

2. Click the  button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

10.10 When a User Range Is Used and Parameters Are Set Using a Sequence Program (without Another System)

(1) Stopping operation



(To the next page)

1. Create a new project.

[Project] ⇒ [New...]



2. Select "QJ72LP25/QJ72BR15(RemoteI/O)" in "PLC Type" and click the button.

3. Open the "Transfer Setup" window.

Navigation window ⇒ Connection Destination view ⇒ (Connection destination data name)

4. Configure the settings to access the module on the remote I/O station and click the button.

(From the previous page)



5. Open the "Device/Buffer Memory Batch Monitor" window.

[Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]

6. Enter and display the buffer memory address of Conversion enable/disable setting (Un\G0).

7. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.

8. Turn on then off Operating condition setting request (Y9).

9. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).

10. If the buffer memory data are not recorded, follow the procedures 11 and 12.



11. Compare the values in CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233) with the values in Range Reference Table (Page 227, Section 10.11).

12. If the values are proper, save the values in CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233).

Point


- If the buffer memory values are improper compared to the reference table, the offset/gain values cannot be saved and restored. Before resuming the control, configure an offset/gain setting according to the flowchart (Page 153, Section 8.5.2). Note that if module control is resumed without offset/gain setting being made, operation will be performed with the default values.
- Switch the mode by setting Mode switching setting (Un\G158, Un\G159) and turning on Operating condition setting request (Y9).

(2) Removing a module



1. Open the "System Monitor" window.
 [Diagnostics] ⇨ [Online Module Change...]
2. Select "Online Module Change" under the "Mode" field and double-click the module name to be changed online.

3. Click the  button to enable a module change.

4. When the following error window appears, click the  button and perform the operation described in  Page 223, Section 10.10 (3).




5. After confirming that the RUN LED of the module has turned off, remove the terminal block.
6. Remove the module.

Point


Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.

(3) Mounting a new module




1. Mount a new module in the same slot and install the terminal block.
2. After mounting the module, click the  button and make sure that the RUN LED is lit. Module READY (X0) remains off.

(4) Checking operation





1. To check the operation, click the  button to cancel the control start.



2. Click the  button to leave the "Online Module Change" mode.

(To the next page)

(From the previous page)



(To the next page)

3. Click the  button to close the "System Monitor" window.


4. Open the "Device/Buffer Memory Batch Monitor" window.

 [Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]

5. Display the address of the prerecorded buffer memory area and select it. Then click the

 button.

(From the previous page)





6. Set the prerecorded data to the buffer memory.
7. Turn User range write request (YA) from off to on to restore the offset/gain setting value in the user range to the module.
8. After confirming that Offset/gain setting mode flag (XA) is on, turn off User range write request (YA).
9. Set Conversion enable/disable setting (Un\G0) to Enable (0) for the channel used.
10. Turn on then off Operating condition setting request (Y9).
11. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.
12. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (Page 228, CHAPTER 11) and take a corrective action.
 - If the RUN LED is on.
 - If the ERR. LED is off.
 - If Error flag (XF) is off.
13. Since the new module is in the default status, initial settings must be configured using a sequence program after the control resumed. Before the initial setting, check if the initial setting program is proper, satisfying the following.
 - Insert a user device where the initial setting will be set at any timing (initial setting request signal) into the sequence program.
 - Do not create a sequence program which sets the initial setting only one scan after a data link start of the remote I/O network. In this case, the initial setting is not set.

10

10.10 When a User Range Is Used and Parameters Are Set Using a Sequence Program (without Another System)

(5) Resuming operation



1. Open the "Online Module Change" window again.

 [Diagnostics] ⇒ [Online Module Change...]

2. Click the  button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

10.11 Range Reference Table

This section lists range reference used for an online module change.

(1) CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233)

Address (Decimal)								Description	Reference value (Hexadecimal)
CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8		
202	204	206	208	210	212	214	216	Factory default setting offset value	00000000 _H
203	205	207	209	211	213	215	217	Factory default setting gain value	00002710 _H
218	220	222	224	226	228	230	232	User range setting offset value	00000000 _H
219	221	223	225	227	229	231	233	User range setting gain value	00002710 _H

CHAPTER 11 TROUBLESHOOTING

This chapter describes errors that may occur in a CT input module and troubleshooting for them.

11.1 Error Code List

This section describes error codes that occur in a CT input module.

(1) Error code checking method

The error codes that occur in a CT input module can be checked by the following.


Choose a method depending on the purpose and application.

- Checking on the "Module's Detailed Information" window ( Page 229, Section 11.1 (1) (a))
- Checking in Latest error code (Un\G19) ( Page 229, Section 11.1 (1) (b))
- Checking through the module error collection function ( Page 230, Section 11.1 (1) (c))


(a) Checking on the "Module's Detailed Information" window

Follow the following procedure.

[Diagnostics] ⇨ [System Monitor...]



1. Select the CT input module in "Main Base", and click the **Detailed Information** button.




2. "Module's Detailed Information" of the CT input module is displayed.

(b) Checking in Latest error code (Un\G19)

Follow the following procedure.

[Online] ⇨ [Monitor] ⇨ [Device/Buffer Memory Batch]



(c) Checking through the module error collection function


The errors occurred in a CT input module are saved in the CPU module through the module error collection function.

Therefore, the error details are kept unerased even if the power is turned off or the CPU module is reset.

- Checking procedure

The CT input module's errors that were collected by the CPU module can be checked on the "Error History" window.

 [Diagnostics] => [System Monitor...] => Click the  button.



The screenshot shows the 'Error History' window with the following details:

- Monitor Status:** STOP icon, Stop Monitor button.
- Connection Channel List:** Serial Port: PLC Module Connection(USB), System Image... button.
- Refine Search:** Match all of the criteria below:
 1. Model Name matching : Q68CT
 2. Start I/O matching : 0000
 Clear Refine Criteria... Enter Refine Criteria...
- Error History:**
 - Error History List: Displayed Errors/Errors: 94/189, Error Code Notation: DEC (selected), HEX.
 - Error Code List Table:**

No.	Error Code	Date and Time	Model Name	Start I/O
00189	0065	2012/02/13 04:24:28	Q68CT	0000
00187	0141	2012/02/13 01:58:55	Q68CT	0000
00186	0141	2012/02/13 01:58:35	Q68CT	0000
00185	0141	2012/02/13 01:58:16	Q68CT	0000
00172	0481	2012/02/08 22:02:12	Q68CT	0000
00171	0407	2012/02/08 20:58:19	Q68CT	0000
00170	0407	2012/02/08 20:58:19	Q68CT	0000
00169	0407	2012/02/08 20:58:19	Q68CT	0000
00168	0407	2012/02/08 20:58:19	Q68CT	0000
00167	0407	2012/02/08 20:58:18	Q68CT	0000
00166	0407	2012/02/08 20:58:18	Q68CT	0000
00165	0407	2012/02/08 20:58:18	Q68CT	0000
00164	0407	2012/02/08 20:58:18	Q68CT	0000
00163	0407	2012/02/08 20:58:18	Q68CT	0000
00162	0407	2012/02/08 20:58:18	Q68CT	0000
00161	0407	2012/02/08 20:58:18	Q68CT	0000
00160	0407	2012/02/08 20:58:18	Q68CT	0000
00159	0407	2012/02/08 20:58:18	Q68CT	0000
00158	0407	2012/02/08 20:58:18	Q68CT	0000
 - Error Details:**
 - Model Name: Q68CT
 - Start I/O: 0000
 - Mount Position: Main Base Slot No. 0
 - Explanation:** CH1 Input range setting (Un)G150 is set to a value outside the range of 0000H to 0005H or 0010H to 0015H.
 - Solution:** Set CH1 Input range setting (Un)G150 to a value within the range of 0000H to 0005H or 0010H to 0015H.

- Errors to be collected

The contents under Error code list ( Page 231, Section 11.1 (2)) are reported to the CPU module.

(2) Error code list

If the following errors occur on the CT input module while data is written to or read from the CPU module, the corresponding error code below is stored in Latest error code (Un\G19).

The error is reported to the CPU module also.

Error code (decimal)	Description and the error cause	Action
10□ ^{*1}	CH□ Input range setting (Un\G150 to Un\G157) is set to a value outside the range of 0000 _H to 0005 _H or 0010 _H to 0015 _H . The channel where the error has occurred fits in □.	Set CH□ Input range setting (Un\G150 to Un\G157) to a value within the range of 0000 _H to 0005 _H or 0010 _H to 0015 _H .
111	A hardware failure has occurred on the module.	Turn the power off then on. If the error occurs again, a failure might have occurred on the module. Please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.
112	A value other than 0 is set to Switch 5 on the intelligent function module switch setting.	Set 0 to Switch 5 on the intelligent function module switch setting in the parameter setting.
113 ^{*1}	The backup data has a problem.	Check the digital output value. If there is a problem of the digital output value, please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.
114 ^{*1}	The writing of backup data went wrong.	Write the backup data. If the error occurs again, a failure might have occurred on the module. Please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.
115 ^{*1}	Since Conversion enable/disable setting (Un\G0) has a channel of conversion enable, the backup data cannot be written.	Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels, then write the backup data.
116 ^{*1}	Since Conversion enable/disable setting (Un\G0) has a channel of conversion enable, the values of buffer memories cannot be restored to default settings.	Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels, then execute the default setting registration function.
120 ^{*1}	An invalid value is set to the offset/gain setting. The channel where the error has occurred cannot be identified.	Start over the offset/gain setting of all channels where the user range setting is used. If the error occurs again, a failure might have occurred on the module. Please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.
12□ ^{*1}	An invalid value is set to offset/gain setting. The channel where the error has occurred fits in □.	Start over the offset/gain setting of the channel where the error has occurred. If the error occurs again, a failure might have occurred on the module. Please consult your local Mitsubishi system service, service center, or representative, explaining a detailed description of the problem.
161 ^{*1*2}	The G(P).OGSTOR instruction was executed in the offset/gain setting mode.	Do not execute the G(P).OGSTOR instruction in the offset/gain setting mode.
162 ^{*1}	<ul style="list-style-type: none"> The G(P).OGSTOR instruction has been consecutively executed. For the offset/gain setting, a setting value has been consecutively written to the non-volatile memory more than 25 times. 	<ul style="list-style-type: none"> Execute the G(P).OGSTOR instruction only once per module. Write the setting value into the non-volatile memory only once for each offset/gain setting.

Error code (decimal)	Description and the error cause	Action
163*1	<ul style="list-style-type: none"> The G(P).OGSTOR instruction has been executed toward a module different from the one on which the G(P).OGLOAD instruction was executed. The G(P).OGSTOR instruction has been executed ahead of the G(P).OGLOAD instruction. 	<ul style="list-style-type: none"> Execute the G(P).OGLOAD and G(P).OGSTOR instructions to the same module. After executing the G(P).OGLOAD instruction on the module from where data is restored, execute the G(P).OGSTOR instruction on the module to where the data is restored.
20□*1	<ul style="list-style-type: none"> The averaging time value set in CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8) is outside the range of 40 to 5000ms. The averaging time value set in CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8) is less than "4 × sampling cycle" (ms). The channel where the error has occurred fits in □.	<ul style="list-style-type: none"> Set the averaging time to a value in the range of 40 to 5000ms. Set the averaging time to a value equal to or more than "4 × sampling cycle" (ms).
30□*1	The averaging count value set in CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8) is outside the range of 4 to 500. The channel where the error has occurred fits in □.	Set the averaging count to a value in the range of 4 to 500.
31□*1	The moving average count value set in CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8) is outside the range of 2 to 1000. The channel where the error has occurred fits in □.	Set the moving average count to a value in the range of 2 to 1000.
32□*1	<ul style="list-style-type: none"> The time constant value set in CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8) is outside the range of 10 to 10000ms. The time constant value set in CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8) is less than sampling cycle (ms). The channel where the error has occurred fits in □.	<ul style="list-style-type: none"> Set the time constant to a value in the range of 10 to 10000ms. Set the time constant to a value equal to or more than sampling cycle (ms).
33□*1	Averaging process setting (Un\G24, Un\G25) is set to a value outside the range of 0 to 4. The channel where the error has occurred fits in □.	Set a value within the range of 0 to 4 in Averaging process setting (Un\G24, Un\G25).
34□*1	In CH1 Rate alarm upper limit value (Un\G126) to CH8 Rate alarm lower limit value (Un\G141), the lower limit is equal to or greater than the upper limit. The channel where the error has occurred fits in □.	Set CH1 Rate alarm upper limit value (Un\G126) to CH8 Rate alarm lower limit value (Un\G141) so that the lower limit value is smaller than the upper limit value.
350*1	The value set in Sampling cycle setting (Un\G26) is outside the range of 0 to 3.	Set one of the following values in Sampling cycle setting (Un\G26). <ul style="list-style-type: none"> 10ms/8CH (0) 20ms/8CH (1) 50ms/8CH (2) 100ms/8CH (3)
36□*1	<ul style="list-style-type: none"> CH□ Peak current detection time (Un\G318 to Un\G325) is outside the range of 10 to 10000ms. CH□ Peak current detection time (Un\G318 to Un\G325) is less than sampling cycle(ms). The channel where the error has occurred fits in □.	<ul style="list-style-type: none"> Set CH□ Peak current detection time (Un\G318 to Un\G325) in the range of 10 to 10000ms. Set CH□ Peak current detection time (Un\G318 to Un\G325) to a value equal to or more than sampling cycle(ms).
37□*1	CH□ Peak current detection value (Un\G326 to Un\G333) is outside the range of 0 to 11999. The channel where the error has occurred fits in □.	Set CH□ Peak current detection value in the range of 0 to 11999ms.
38□*1	CH□ Peak current detection count reset request (Un\G302 to Un\G309) is set to a value other than 0 and 1. The channel where the error has occurred fits in □.	Set Enable (0) or Disable (1) in CH□ Peak current detection count reset request (Un\G302 to Un\G309).

Error code (decimal)	Description and the error cause	Action
39□*1	CH□ Dropout value (Un\G162 to Un\G169) is outside the range of 1 to 10000. The channel where the error has occurred fits in □.	Set CH□ Dropout value (Un\G162 to Un\G169) in the range of 1 to 10000.
40□*1	When a user range is set or restored, the offset value is equal to or greater than the gain value. The channel where the error has occurred fits in □.	Set values so that they meet the following condition: Offset value < Gain value
50□*1	When the offset/gain setting is configured, channels or 0s are set simultaneously in both Offset/gain setting mode Offset specification (Un\G22) and Offset/gain setting mode Gain specification (Un\G23).	Correct the settings in Offset/gain setting mode Offset specification (Un\G22) and Offset/gain setting mode Gain specification (Un\G23).
51□*1	When the offset/gain setting is configured, CH□ Input range setting (Un\G150 to Un\G157) is set to a value outside the range of 0010 _H to 0015 _H . The channel where the error has occurred fits in □.	Set one of the following values in CH□ Input range setting (Un\G150 to Un\G157). <ul style="list-style-type: none"> • User range 0 to 5AAC (0010_H) • User range 0 to 50AAC (0011_H) • User range 0 to 100AAC (0012_H) • User range 0 to 200AAC (0013_H) • User range 0 to 400AAC (0014_H) • User range 0 to 600AAC (0015_H)
6△□*1	The settings in CH1 Process alarm lower lower limit value (Un\G86) to CH8 Process alarm upper upper limit value (Un\G117) are invalid. The channel where the error has occurred fits in □. A value fits in △ indicates that the alarm status is as follows: 2: Process alarm lower lower limit value > Process alarm lower upper limit value 3: Process alarm lower upper limit value > Process alarm upper lower limit value 4: Process alarm upper lower limit value > Process alarm upper upper limit value	Correct the settings in CH1 Process alarm lower lower limit value (Un\G86) to CH8 Process alarm upper upper limit value (Un\G117).
70□*1	<ul style="list-style-type: none"> • CH□ Rate alarm warning detection period (Un\G118 to Un\G125) is outside the range of 10 to 5000ms. • CH□ Rate alarm warning detection period (Un\G118 to Un\G125) is less than conversion cycle of CH□ digital output value (ms). The channel where the error has occurred fits in □.	<ul style="list-style-type: none"> • Set CH□ Rate alarm warning detection period (Un\G118 to Un\G125) to within 10 to 5000ms. • Set CH□ Rate alarm warning detection period (Un\G118 to Un\G125) to a value equal to or multiple of conversion cycle of CH□ digital output value (ms).
90□*1	The values set in CH1 Scaling lower limit value (Un\G62) to CH8 Scaling upper limit value (Un\G77) are outside the range of -32000 to 32000. The channel where the error has occurred fits in □.	Set a value within the range of -32000 to 32000 in CH1 Scaling lower limit value (Un\G62) to CH8 Scaling upper limit value (Un\G77).
200□*1	CH□ Logging enable/disable setting (Un\G1000 to Un\G1007) is set to a value other than 0 and 1. The channel where the error has occurred fits in □.	Set Enable (0) or Disable (1) in CH□ Logging enable/disable setting (Un\G1000 to Un\G1007).
201□*1	A value outside the setting range is set in one or both of CH□ Logging cycle setting value (Un\G1032 to Un\G1039) or/and CH□ Logging cycle unit setting (Un\G1040 to Un\G1047). The channel where the error has occurred fits in □.	Set a value within the setting range in one or both of CH□ Logging cycle setting value (Un\G1032 to Un\G1039) or/and CH□ Logging cycle unit setting (Un\G1040 to Un\G1047). For the setting procedure of a logging cycle, refer to the following. <ul style="list-style-type: none"> • Logging Function (📄 Page 60, Section 4.12)

Error code (decimal)	Description and the error cause	Action
202□*1	The set logging cycle is shorter than the update cycle of the logged value (digital output value or scaling value). The channel where the error has occurred fits in □.	Set CH□ Logging cycle setting value (Un\G1032 to Un\G1039) and CH□ Logging cycle unit setting (Un\G1040 to Un\G1047) so that the logging cycle is equal to or longer than the update cycle of the logged value. For the setting procedure of a logging cycle, refer to the following. • Logging Function (☞ Page 60, Section 4.12)
203□*1	CH□ Logging data setting (Un\G1024 to Un\G1031) is set to a value other than 0 and 1. The channel where the error has occurred fits in □.	Set Digital output value (0) or Scaling value (1) in CH□ Logging data setting (Un\G1024 to Un\G1031).
204□*1	CH□ Logging points after trigger (Un\G1048 to Un\G1055) is set to a value outside the range of 1 to 5000. The channel where the error has occurred fits in □.	Set a value within the range of 1 to 5000 in CH□ Logging points after trigger (Un\G1048 to Un\G1055).
205□*1	CH□ Level trigger condition setting (Un\G1056 to Un\G1063) is set to a value outside the range of 0 to 3. The channel where the error has occurred fits in □.	Set one of the following values in CH□ Level trigger condition setting (Un\G1056 to Un\G1063). • Disable (0) • Above (1) • Below (2) • Pass through (3)
206□*1	CH□ Trigger data (Un\G1064 to Un\G1071) is set to a value outside the range of 0 to 4999. The channel where the error has occurred fits in □.	Set a value within the range of 0 to 4999 in CH□ Trigger data (Un\G1064 to Un\G1071).
207□*1	CH□ Logging hold request (Un\G1008 to Un\G1015) is set to a value other than 0 and 1. The channel where the error has occurred fits in □.	Set OFF (0) or ON (1) in CH□ Logging hold request (Un\G1008 to Un\G1015).

*1 These error codes can be cleared by turning on then off Error clear request (YF).

*2 This error code is not stored in Latest error code (Un\G19) but in the completion status of the G(P).OGSTOR instruction (Ⓢ + 1).

11.2 Alarm Code List

This section describes alarm codes that occur in a CT input module.

(1) Alarm code checking method

Alarms occurred in the CT input module can be checked by the same methods as those for errors. (☞ Page 228, Section 11.1 (1))

(2) Alarm code list

The following table lists alarm codes.

Alarm code (decimal)	Description and the alarm cause	Action
10△□	<p>A process alarm or a rate alarm is occurring. The channel where a process alarm or rate alarm has occurred fits in □.</p> <p>A value fits in △ indicates that the alarm status is as follows: 0: Process alarm upper limit 1: Process alarm lower limit 2: Rate alarm upper limit 3: Rate alarm lower limit</p>	<p>When the digital output value returns to the one within the setting range, the following turns off.</p> <ul style="list-style-type: none"> • The corresponding bit of Warning output flag (Process alarm) (Un\G50) • The corresponding bit of Warning output flag (Rate alarm) (Un\G51) • Warning output signal (X8) <p>The alarm code can be cleared by turning off, on, and off Error clear request (YF) after the digital output value returns to the one within the setting range.</p>
110□	<p>An input signal error is occurring. The channel where an input signal error has occurred fits in □.</p>	<p>The corresponding bit of Input signal error detection flag (Un\G49) and Input signal error detection signal (XC) turn off by turning off, on, and off Error clear request (YF) after the CT input value returns to the one within the setting range.</p>
120□	<p>A peak current was detected. The channel where the peak current has been detected fits in □.</p>	<p>The corresponding bit of Peak current detection flag (Un\G301) and Peak current detection signal (X7) turn off by turning off, on, and off Error clear request (YF) after the CT input value returns to the one within the setting range.</p>

11.3 Troubleshooting

11.3.1 When the RUN LED flashes or turns off

(1) When flashing

Check item	Action
Is the operation in the offset/gain setting mode?	<ul style="list-style-type: none"> • Set the operation mode in the intelligent function module switch setting to the normal mode. Or reset the switch 4 in the intelligent function module switch setting to the normal mode. • Set the operation mode to the normal mode by setting Mode switching setting (Un\G158, Un\G159); set Un\G158 to 0964_H, and Un\G159 to 4144_H.

(2) When off

Check item	Action
Is the power supplied?	Check that the supply voltage of the power supply module is within the rated range.
Is the capacity of the power supply module sufficient?	Calculate the current consumption of the modules mounted on the base unit, such as the CPU module, I/O module, and intelligent function module, and check that the power supply capacity is sufficient.
Is there any watchdog timer error?	Reset the CPU module, and check if the RUN LED turns on. If the RUN LED remains off, the CT input module might fail. Please consult a local Mitsubishi representative.
Is the module mounted on the base unit properly?	Check the mounting condition of the module.
Is a module change enabled during an online module change?	Refer to the following and take the corrective action. <ul style="list-style-type: none"> • ONLINE MODULE CHANGE (🔗 Page 182, CHAPTER 10)

11.3.2 When the ERR. LED turns on or flashes

(1) When on

Check item	Action
Is there any error?	Check the error code, and take the action described in the error code list. <ul style="list-style-type: none"> • Error code list (🔗 Page 231, Section 11.1 (2))

(2) When flashing

Check item	Action
Is a value other than 0 set to Switch 5 of the intelligent function module switch setting?	Set 0 to Switch 5 of the intelligent function module switch setting.

11.3.3 When the ALM LED turns on or flashes

(1) When on

Check item	Action
Is there any alarm output?	Check Warning output flag (Process alarm) (Un\G50) or Warning output flag (Rate alarm) (Un\G51).

(2) When flashing

Check item	Action
Is there any input signal error?	Check Input signal error detection flag (Un\G49).
Is there any peak current detection?	Check Peak current detection flag (Un\G301).

11.3.4 When a digital output value cannot be read

Check item	Action
<ul style="list-style-type: none"> • Are the k terminal and l terminal wired properly? • Is the secondary side of the CT short-circuited? 	Refer to the following, and wire the k terminal and l terminal properly. <ul style="list-style-type: none"> • Wiring ( Page 142, Section 7.4)
Is a connection cable disconnected?	Confirm the faulty part by checking them visually or conducting electricity.
Is the CPU module in the STOP status?	Change the status of the CPU module to RUN.
Is the offset/gain setting correct?	Check if the offset/gain setting is correct. When a user range is selected, change the input range to a factory default range and check if digital conversion is performed. If the digital conversion is performed properly, configure the offset/gain setting again.
Is the input range setting correct?	Check CH□ Input range setting (Un\G150 to Un\G157). If the input range setting is incorrect, start over the setting.
Is Conversion enable/disable setting (Un\G0) set to Disable (1) for the channel to be used?	Check Conversion enable/disable setting (Un\G0), and enable the digital conversion in the sequence program or intelligent function module parameter.
Is Operating condition setting request (Y9) performed?	Turn on then off Operating condition setting request (Y9), and check if digital output values are stored in CH□ Digital output value (Un\G11 to Un\G18). If the values are stored properly, review the sequence program so that Operating condition setting request (Y9) is turned on in the program.
Is the set value correct when an averaging process is specified?	When time average is selected, satisfy the following condition. <ul style="list-style-type: none"> • Set value \geq "4 (times) \times Sampling cycle" If the condition above is not satisfied, 0 is stored in CH□ Digital output value (Un\G11 to Un\G18).

Point

If digital output values cannot be read even after taking the above actions, the module might fail. Please consult a local Mitsubishi representative.

11.3.5 When Conversion completed flag does not turn on in the normal mode

Check item	Action
Is there any input signal error?	Check Input signal error detection flag (Un\G49).

11.4 Checking the CT Input Module Status on GX Works2 System Monitor

To check the LED status or the setting status of the intelligent function module switch setting, select the H/W information of the CT input module on the system monitor of GX Works2.

(1) Hardware LED information

The LED status is displayed.

No.	LED name	Status
1)	RUN LED	0000 _H : Indicates that the LED is off. 0001 _H : Indicates that the LED is on.
2)	ERR. LED	Alternating indication of 0000 _H and 0001 _H : Indicates that the LED is flashing.
3)	ALM LED	(When the CT input module in communication, the LED status is displayed on GX Works2. The values 0000 _H and 0001 _H are not always displayed evenly.)


(2) Hardware switch information

The setting status of the intelligent function module switch setting is displayed.

For details on the setting status, refer to the following.

- Switch Setting (☞ Page 145, Section 8.2)

Item	Intelligent function module switch
—	Switch1
—	Switch2
—	Switch3
MODE	Switch4
—	Switch5



APPENDICES

Appendix 1 Dedicated Instruction

(1) Dedicated instruction

The following table lists dedicated instructions that can be used in a CT input module.

Instruction	Description
G(P).OFFGAN	<ul style="list-style-type: none">• This instruction switches the operation mode to the offset/gain setting mode.• This instruction switches the operation mode to the normal mode.
G(P).OGLOAD	This instruction reads out the offset/gain set values in a user range setting to the CPU module.
G(P).OGSTOR	This instruction restores the offset/gain set values in a user range setting to the CT input module.

Point

When the module is mounted on a MELSECNET/H remote I/O station, the dedicated instructions cannot be used.

Appendix 1.1 G(P).OFFGAN



Setting data	Internal device		R, ZR	J□□		U□\G□	Zn	Constant K, H, \$	Others
	Bit	Word		Bit	Word				
Ⓢ	—	○				—			

(1) Setting data

Device	Description	Setting range	Data type
Un	Start I/O number of the module	0 to FE _H	BIN 16 bits
Ⓢ	Mode change 0: changed to the normal mode 1: changed to the offset/gain setting mode When a value other than above is set, the mode is changed to the offset/gain setting mode.	0, 1	BIN 16 bits

(2) Functions

This instruction switches the operation mode of the CT input module.

- Normal mode → offset/gain setting mode (Offset/gain setting mode flag (XA) is on)
- Offset/gain setting mode → normal mode (Offset/gain setting mode flag (XA) is off)

Point

- When the mode is switched from the offset/gain setting mode to the normal mode, Module READY (X0) turns on. Note that if a sequence program includes the initial settings to be executed at ON of Module READY (X0), this instruction performs the initial setting process.
- When the mode is switched, the digital conversion stops. To resume the digital conversion, turn on then off Operating condition setting request (Y9) after switching the mode to the normal mode.


(3) Errors

The instruction has no errors.


(4) Program example

The following shows the sequence program of the CT input module, installed in I/O number X/Y00 to X/Y0F, with the following conditions.

- Turning on M10 switches the operation mode of the CT input module to the offset/gain setting mode
- Turning off M10 restores the operation mode of the CT input module to the normal mode



Appendix 1.2 G(P).OGLOAD



A

Setting data	Internal device		R, ZR	J□□		U□\G□	Zn	Constant K, H, \$	Others
	Bit	Word		Bit	Word				
Ⓢ	—	○							
Ⓣ		○							

(1) Setting data

Device	Description	Setting range	Data type
Un	Start I/O number of the module	0 to FE _H	BIN 16 bits
Ⓢ	Start number of the device where control data is stored	Within the range of the specified device	Device name
Ⓣ	Device which turns on for one scan at the processing completion of the dedicated instruction. In error completion, Ⓣ+1 also turns on.	Within the range of the specified device	Bit

Appendix 1 Dedicated Instruction
Appendix 1.2 G(P).OGLOAD

(2) Control data*¹

Device	Item	Setting data	Setting range	Set by
Ⓢ	System area	—	—	—
Ⓢ+1	Completion status	The status on instruction completion is stored. 0: normal completion Other than 0: error completion (error code)	—	System
Ⓢ+2	System area	—	—	—
Ⓢ+3	System area	—	—	—
Ⓢ+4	CH1 Factory default setting offset value	—	—	System
Ⓢ+5	CH1 Factory default setting gain value	—	—	System
Ⓢ+6	CH2 Factory default setting offset value	—	—	System
Ⓢ+7	CH2 Factory default setting gain value	—	—	System
Ⓢ+8	CH3 Factory default setting offset value	—	—	System
Ⓢ+9	CH3 Factory default setting gain value	—	—	System
Ⓢ+10	CH4 Factory default setting offset value	—	—	System
Ⓢ+11	CH4 Factory default setting gain value	—	—	System
Ⓢ+12	CH5 Factory default setting offset value	—	—	System
Ⓢ+13	CH5 Factory default setting gain value	—	—	System
Ⓢ+14	CH6 Factory default setting offset value	—	—	System
Ⓢ+15	CH6 Factory default setting gain value	—	—	System
Ⓢ+16	CH7 Factory default setting offset value	—	—	System
Ⓢ+17	CH7 Factory default setting gain value	—	—	System
Ⓢ+18	CH8 Factory default setting offset value	—	—	System
Ⓢ+19	CH8 Factory default setting gain value	—	—	System
Ⓢ+20	CH1 User range setting offset value	—	—	System
Ⓢ+21	CH1 User range setting gain value	—	—	System
Ⓢ+22	CH2 User range setting offset value	—	—	System
Ⓢ+23	CH2 User range setting gain value	—	—	System
Ⓢ+24	CH3 User range setting offset value	—	—	System
Ⓢ+25	CH3 User range setting gain value	—	—	System
Ⓢ+26	CH4 User range setting offset value	—	—	System
Ⓢ+27	CH4 User range setting gain value	—	—	System
Ⓢ+28	CH5 User range setting offset value	—	—	System
Ⓢ+29	CH5 User range setting gain value	—	—	System
Ⓢ+30	CH6 User range setting offset value	—	—	System
Ⓢ+31	CH6 User range setting gain value	—	—	System
Ⓢ+32	CH7 User range setting offset value	—	—	System
Ⓢ+33	CH7 User range setting gain value	—	—	System

Device	Item	Setting data	Setting range	Set by
Ⓔ+34	CH8 User range setting offset value	—	—	System
Ⓔ+35	CH8 User range setting gain value	—	—	System

*1 These control data are unnecessary to be set. When they are set, offset/gain setting values are not correctly read out.

(3) Functions

- This instruction reads out the offset/gain set values in a user range setting of the CT input module to the CPU module.
- The interlock signal of G(P).OGLOAD includes a completion device Ⓔ and a completion status indication device Ⓔ+1.


(a) Completion device

The device turns on at the END processing for the scan where the G(P).OGLOAD instruction is completed, and turns off at the next END processing.

(b) Completion status indication device

This device turns on or off depending on the status of the G(P).OGLOAD instruction completion.

- Normal completion: the device remains off.
- Error completion: the device turns on at the END processing for the scan where the G(P).OGLOAD instruction is completed, and turns off at the next END processing.



(4) Errors


The instruction has no errors.

A


(5) Program example

The following shows the sequence program of the CT input module, installed in I/O number X/Y00 to X/Y0F, with the following conditions.

- Turning on M11 reads out the offset/gain setting value of the CT input module.



Appendix 1.3 G(P).OGSTOR



Setting data	Internal device		R, ZR	J□□		U□\G□	Zn	Constant K, H, \$	Others
	Bit	Word		Bit	Word				
Ⓢ	—	○				—			
ⓓ		○				—			

(1) Setting data

Device	Description	Setting range	Data type
Un	Start I/O number of the module	0 to FE _H	BIN 16 bits
Ⓢ*1	Start number of the device where control data is stored	Within the range of the specified device	Device name
ⓓ	Device which turns on for one scan at the processing completion of the dedicated instruction In error completion, ⓓ+1 also turns on.	Within the range of the specified device	Bit

- *1 Specify the device specified to Ⓢ on execution of the G(P).OGLOAD instruction. Do not change the data which was read out by the G(P).OGLOAD instruction. If the data is changed, the normal operation may not be ensured.

A

(2) Control data

Device	Item	Setting data	Setting range	Set by
⑤	System area	—	—	—
⑤+1	Completion status	The status on instruction completion is stored. 0: normal completion Other than 0: error completion (error code)	—	System
⑤+2	System area	—	—	—
⑤+3	System area	—	—	—
⑤+4	CH1 Factory default setting offset value	—	—	System
⑤+5	CH1 Factory default setting gain value	—	—	System
⑤+6	CH2 Factory default setting offset value	—	—	System
⑤+7	CH2 Factory default setting gain value	—	—	System
⑤+8	CH3 Factory default setting offset value	—	—	System
⑤+9	CH3 Factory default setting gain value	—	—	System
⑤+10	CH4 Factory default setting offset value	—	—	System
⑤+11	CH4 Factory default setting gain value	—	—	System
⑤+12	CH5 Factory default setting offset value	—	—	System
⑤+13	CH5 Factory default setting gain value	—	—	System
⑤+14	CH6 Factory default setting offset value	—	—	System
⑤+15	CH6 Factory default setting gain value	—	—	System
⑤+16	CH7 Factory default setting offset value	—	—	System
⑤+17	CH7 Factory default setting gain value	—	—	System
⑤+18	CH8 Factory default setting offset value	—	—	System
⑤+19	CH8 Factory default setting gain value	—	—	System
⑤+20	CH1 User range setting offset value	—	—	System
⑤+21	CH1 User range setting gain value	—	—	System
⑤+22	CH2 User range setting offset value	—	—	System
⑤+23	CH2 User range setting gain value	—	—	System
⑤+24	CH3 User range setting offset value	—	—	System
⑤+25	CH3 User range setting gain value	—	—	System
⑤+26	CH4 User range setting offset value	—	—	System
⑤+27	CH4 User range setting gain value	—	—	System
⑤+28	CH5 User range setting offset value	—	—	System
⑤+29	CH5 User range setting gain value	—	—	System
⑤+30	CH6 User range setting offset value	—	—	System
⑤+31	CH6 User range setting gain value	—	—	System
⑤+32	CH7 User range setting offset value	—	—	System
⑤+33	CH7 User range setting gain value	—	—	System

Device	Item	Setting data	Setting range	Set by
Ⓔ+34	CH8 User range setting offset value	—	—	System
Ⓔ+35	CH8 User range setting gain value	—	—	System

(3) Functions

- This instruction restores the offset/gain set values in a user range setting to the CT input module.
- There are two interlock signals of G(P).OGSTOR: a completion device Ⓓ and a completion status indication device Ⓓ+1.
- The accuracy on restoration of the offset/gain setting values (when the ambient temperature is $25\pm 5^{\circ}\text{C}$) is within $\pm 1.5\%$ (within ± 150 digit).


(a) Completion device

The device turns on at the END processing for the scan where the G(P).OGSTOR instruction is completed, and turns off at the next END processing.

(b) Completion status indication device

This device turns on or off depending on the status of the G(P).OGSTOR instruction completion.

- Normal completion: the device remains off.
- Error completion: the device turns on at the END processing for the scan where the G(P).OGSTOR instruction is completed, and turns off at the next END processing.



(4) Errors


In the following cases, an error occurs and error code is stored in completion status Ⓔ+1.

Error code	Description of operation error
161	G(P).OGSTOR instruction is executed in the offset/gain setting mode.
162	G(P).OGSTOR instruction is continuously executed.
163	<ul style="list-style-type: none"> • G(P).OGSTOR instruction is executed to the different model from the one to which G(P).OGLOAD instruction is executed. • G(P).OGSTOR instruction has been executed before the execution of G(P).OGLOAD instruction.

(5) Program example

The following shows the sequence program of the CT input module, installed in I/O number X/Y00 to X/Y0F, with the following conditions.

- Turning off M11 writes the offset/gain setting value to the CT input module.



Appendix 2 When Using GX Developer

This chapter describes the operating procedure of GX Developer.

(1) Applicable software packages

For the applicable software version, refer to the following.

 Page 22, Section 2.1 (4)

Appendix 2.1 Operation of GX Developer


Configure the following settings when using GX Developer.

Window name	Application	Reference
I/O assignment	Set the type of the module to be mounted and the I/O signal range.	Page 251, Appendix 2.1 (1)
Switch setting	Configure the switch setting of an intelligent function module.	Page 252, Appendix 2.1 (2)
Offset/gain setting	Configure the setting when using a user range setting for the input range.	Page 153, Section 8.5.2

(1) I/O assignment

Configure the setting on "I/O assignment" in "PLC parameter".

 Parameter ⇨ [PLC parameter] ⇨ [I/O assignment]




Item	Description
Type	Select "Intelli.".
Model name	Enter the model name of the module.
Points	Select "16points".
StartXY	Enter a desired start I/O number of the CT input module.

(2) Intelligent function module switch setting

Configure the setting on "Switch setting" in "PLC parameter".

Parameter ⇨ [PLC parameter] ⇨ [I/O assignment] ⇨ Click the **Switch setting** button.



Select "HEX."

Item	Setting range
Switch 1	0: Fixed (blank) ^{*1}
Switch 2	0: Fixed (blank) ^{*1}
Switch 3	0: Fixed (blank) ^{*1}
Switch 4	<p>0H : Normal (digital conversion processing) mode 1H to FH (A value other than 0H)^{*2} : Offset/gain setting mode</p>
Switch 5	0: Fixed

*1 When a value is set, the set value is ignored.

*2 The operation is the same for all values in the setting range.

Appendix 3 Online Module Change Procedure (When Using GX Developer)

This appendix describes the online module change procedure using GX Developer.

When performing an online module change, carefully read the following.

-  QCPU User's Manual (Hardware Design, Maintenance and Inspection)

Appendix 3.1 Precautions on online module change

This section lists precautions on an online module change.

- Always perform an online module change in the correct procedure. ( Page 256, Appendix 3.4)
A failure to do so can cause a malfunction or failure.
- Perform an online module change after making sure that the system outside the programmable controller will not malfunction.
- Provide means such as switches for powering off each of the external power supply and external devices connected to the module to be replaced online. Failure to do so may cause an electric shock and malfunction of operating modules.
- After the module has failed, the buffer memory data may not be saved properly. Prerecord the data to be saved.
- It is recommended to perform an online module change in the actual system in advance to ensure that it would not affect the other modules.
For the operational verification, check the following:
 - Means of cutting off the connection to external devices and its configuration are correct.
 - Switching on/off does not bring any undesirable effect.
- After the first use of the product, do not mount/remove the module to/from the base unit, and the terminal block to/from the module more than 50 times (IEC 61131-2 compliant) respectively. Exceeding the limit may cause malfunction.

Point!

Dedicated instructions cannot be executed during an online module change. Save and restore the offset/gain setting values in the user range using a dedicated instruction in another system.

Precautions for using another system are as follows:

- To change a module mounted on the remote I/O station online, save and restore the offset/gain setting values in the user range using a dedicated instruction, in another system mounted on the main base unit.
- The offset/gain setting values cannot be saved and restored using a dedicated instruction in another system mounted on the remote I/O station.

If there is no other system, restore the values by writing them to the buffer memory.

Appendix 3.2 Conditions for online module change

To perform an online module change, satisfy the following conditions.

Remark

The function version of the first released CT input module is C, and the CT input module supports the online module change.
.....

(1) CPU module

A Process CPU or Redundant CPU is necessary.

For the precautions on the multiple CPU system configuration, refer to the following.

-  QCPU User's Manual (Multiple CPU System)

For the precautions on the redundant system configuration, refer to the following.

-  QnPRHCPU User's Manual (Redundant System)

(2) Function version of MELSECNET/H remote I/O module

A module of function version D or later is necessary.

(3) Compatible version of GX Developer

GX Developer of Version 7.10L or later is necessary.

To perform an online change on a remote I/O station, GX Developer of Version 8.17T or later is necessary.

The CT input module does not support GX Configurator-AD; therefore, configure initial settings in a sequence program.

(4) Restrictions of base unit

When the module is mounted on any of the following base units, an online module change cannot be performed.

- Slim type main base unit (Q3□SB)
- Extension base unit (Q5□B) which does not require the power supply module (An online module change cannot be performed for all modules on the base unit.)

Appendix 3.3 Online module change operations

The following table explains the operations for an online module change.

○: Executed ×: Not executed

User operation	Operation of the CT input module	Operation of the CPU module			
		X/Y refresh	FROM/TO instructions*1	Dedicated instruction	Device test
<p>(1) Stop the operation.</p> <p>Turn off all of the Y signals turned on using the sequence program.</p>	The module is operating normally.	○	○	○	○
<p>(2) Remove the module.</p> <p>Start the online module change using GX Developer.</p> <p>Click the  button on GX Developer to enable the module to be removed.</p> <p>Remove the module.</p>	<p>The operation of the module stops.</p> <ul style="list-style-type: none"> The RUN LED turns off. Conversion disabled. 	×	×	×	×
<p>(3) Mount a new module.</p> <p>Mount a new module.</p> <p>After mounting the module, click the  button on GX Works2.</p> <p>Check the operation before the control starts.</p>	<p>The X/Y refresh restarts and the module starts up.</p> <ul style="list-style-type: none"> The RUN LED turns on. Default operation starts. (Module READY (X0) remains off.) <p>(When there are initial setting parameters, the module starts to operate based on the initial setting parameters at this point.)</p>	○	×	×	×
<p>(4) Check the operation.</p> <p>Click the  button on GX Developer to turn off the online mode.</p> <p>On "Device test" on GX Developer, test the operation of the module.</p> <p>(Restore the user range settings by writing of buffer memory addresses at this point.)</p> <p>Operation check is completed.</p>	The module operates based on the test operation.*2	○	×	×	○
<p>(5) Resume the control.</p> <p>Restart the online module change using GX Developer.</p> <p>Click the  button to resume the control.</p>	<p>Module READY (X0) turns on.</p> <p>The module operates based on the initial setting sequence program which runs when Module READY (X0) turns on.*2</p>	○	○	○	○

*1 An access to Intelligent function module device (U□\G□) is included.

*2 In the absence of the operation marked *2, the operation of the intelligent function module is the operation performed prior to that.

A

Appendix 3 Online Module Change Procedure (When Using GX Developer)
Appendix 3.3 Online module change operations


Appendix 3.4 Online module change procedure

This section describes three online module change procedures: factory default setting, user range setting with another system, and user range setting without another system.

Range setting	Initial setting	Another system	Reference
Factory default range	Sequence program	—	Page 257, Appendix 3.5
User range	Sequence program	Present	Page 263, Appendix 3.6
		Absent	Page 269, Appendix 3.7


(1) System configuration

The following system is used to explain the online module change procedure.




(2) Procedure

The following flow shows the online module change procedure.



Appendix 3.5 When a factory default range is used and initial settings are configured using a sequence program



(1) Stopping operation



1. Open the "Device test" window.
 [Online] ⇨ [Debug] ⇨ [Device test...]
2. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.
3. Turn on then off Operating condition setting request (Y9).
4. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).

A


(2) Removing a module



1. Open the "Online module change" window.
 [Diagnostics] ⇨ [Online Module Change...]
2. Select "Online module change" under the "Mode" field and double-click the module name to be changed online.

3. Click the  button to enable a module change.

4. When the following error window appears, click the

 button and perform the operation described in

 **Page 259, Appendix 3.5 (3).**




5. After confirming that the RUN LED of the module has turned off, remove the terminal block.
6. Remove the module.

Point

Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.




(3) Mounting a new module



1. Mount a new module in the same slot and install the terminal block.
2. After mounting the module, click the **Execution** button and make sure that the RUN LED is lit. Module READY (X0) remains off.

A

(4) Checking operation




(To the next page)

1. To check the operation, click the  button to cancel the control start.

2. Click the  button to leave the "Online module change" mode.

3. Click the  button to close the "System Monitor" window.

(From the previous page)



4. Open the "Device test" window.
 [Online] ⇨ [Debug] ⇨ [Device test...]
5. Set Conversion enable/disable setting (Un\G0) to Enable (0) for the channel used.
6. Turn on then off Operating condition setting request (Y9).
7. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.

A

8. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (☞ Page 228, CHAPTER 11) and take a corrective action.
 - If the RUN LED is on.
 - If the ERR. LED is off.
 - If Error flag (XF) is off.
9. Since the new module is in the default status, initial settings must be configured using a sequence program after the control resumed. Before the initial setting, check if the initial setting program is proper, satisfying the following.


Normal system configuration

- The sequence program should set the initial setting on the leading edge of Module READY (X0) of the CT input module.
- Do not create a sequence program which sets the initial setting only one scan after RUN. In this case, the initial setting is not set.

When used on remote I/O network

- Insert a user device where the initial setting will be set at any timing (initial setting request signal) into the sequence program.
- Do not create a sequence program which sets the initial setting only one scan after a data link start of the remote I/O network. In this case, the initial setting is not set.

(5) Resuming operation



1. Open the "Online module change" window again.


 [Diagnostics] ⇨ [Online Module Change...]

2. Click the **Execution** button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

Appendix 3.6 When a user range is used and initial settings are configured using a sequence program (with another system)



(1) Stopping operation



1. Open the "Device test" window.
 [Online] ⇌ [Debug] ⇌ [Device test...]
2. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.
3. Turn on then off Operating condition setting request (Y9).
4. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).

A

(2) Removing a module



1. Open the "Online module change" window.
 [Diagnostics] ⇒ [Online Module Change...]
2. Select "Online module change" under the "Mode" field and double-click the module name to be changed online.

3. Click the  button to enable a module change.

4. When the following error window appears, click the  button and perform the operation described in

 Page 265, Appendix 3.6 (3).




5. After confirming that the RUN LED of the module has turned off, remove the terminal block.
6. Remove the module.

Point

Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.




(3) Mounting a new module

1. Mount the removed module and new module to the other system.
2. Using the G(P).OGLOAD instruction, save the offset/gain setting values in the user range from the removed module to the CPU device. Refer to  Page 243, Appendix 1.2 for the G(P).OGLOAD instruction.
3. Using the G(P).OGSTOR instruction, restore the offset/gain setting values in the user range to a new module. Refer to  Page 247, Appendix 1.3 for the G(P).OGSTOR instruction.
4. Remove the new module from the other system, mount it to the slot from where the old module was removed in the original system, and install the terminal block.
5. After mounting the module, click the  button and make sure that the RUN LED is lit. Module READY (X0) remains off.



A

(4) Checking operation




(To the next page)

1. To check the operation, click the  button to cancel the control start.

2. Click the  button to leave the "Online module change" mode.

3. Click the  button to close the "System Monitor" window.

(From the previous page)



4. Open the "Device test" window.
 [Online] ⇨ [Debug] ⇨ [Device test...]
5. Set Conversion enable/disable setting (Un\G0) to Enable (0) for the channel used.
6. Turn on then off Operating condition setting request (Y9).
7. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.

A

8. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (👉 Page 228, CHAPTER 11) and take a corrective action.
 - If the RUN LED is on.
 - If the ERR. LED is off.
 - If Error flag (XF) is off.
9. Since the new module is in the default status, initial settings must be configured using a sequence program after the control resumed. Before the initial setting, check if the initial setting program is proper, satisfying the following.


Normal system configuration

- The sequence program should set the initial setting on the leading edge of Module READY (X0) of the CT input module.
- Do not create a sequence program which sets the initial setting only one scan after RUN. In this case, the initial setting is not set.

When used on remote I/O network

- Insert a user device where the initial setting will be set at any timing (initial setting request signal) into the sequence program.
- Do not create a sequence program which sets the initial setting only one scan after a data link start of the remote I/O network. In this case, the initial setting is not set.

(5) Resuming operation




1. Open the "Online module change" window again.

2. Click the **Execution** button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

Appendix 3.7 When a user range is used and initial settings are configured using a sequence program (without another system)

(1) Stopping operation





1. Open the "Device test" window.
 [Online] ⇄ [Debug] ⇄ [Device test...]
2. Set Conversion enable/disable setting (Un\G0) to Disable (1) for all channels.
3. Turn on then off Operating condition setting request (Y9).
4. Confirm that the digital conversion has stopped with Conversion completed flag (Un\G10).
5. If the buffer memory data are not recorded yet, follow the procedures 6 and 7.
6. Compare the values in CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233) with the values in Range Reference Table ( Page 227, Section 10.11).
7. If the values are proper, save the values in CH1 Factory default setting offset value (Un\G202) to CH8 User range setting gain value (Un\G233).

Point

- If the buffer memory values are improper compared to the reference table, the offset/gain values cannot be saved and restored. Before resuming the control, configure an offset/gain setting according to the flowchart ( Page 153, Section 8.5.2).
 Note that if module control is resumed without offset/gain setting being made, operation will be performed with the default values.
- Switch the mode by setting Mode switching setting (Un\G158, Un\G159) and turning on Operating condition setting request (Y9).

(2) Removing a module



1. Open the "Online module change" window.
 [Diagnostics] ⇨ [Online Module Change...]
2. Select "Online module change" under the "Mode" field and double-click the module name to be changed online.

3. Click the  button to enable a module change.

4. When the following error window appears, click the  button and perform the operation described in

 Page 271, Appendix 3.7 (3).




5. After confirming that the RUN LED of the module has turned off, remove the terminal block.
6. Remove the module.

Point

Always remove the module. If mounting confirmation is made without the module being removed, the module will not start properly and the RUN LED will not be lit.


(3) Mounting a new module




1. Mount a new module in the same slot and install the terminal block.
2. After mounting the module, click the **Execution** button and make sure that the RUN LED is lit. Module READY (X0) remains off.

A


(4) Checking operation



1. To check the operation, click the **Cancel** button to cancel the control start.




2. Click the **OK** button to leave the "Online module change" mode.



3. Click the **Close** button to close the "System Monitor" window.

(To the next page)

(From the previous page)



4. In "Device test", set the prerecorded data to the buffer memory.
 [Online] ⇨ [Debug] ⇨ [Device test...]
5. Turn User range write request (YA) from off to on to restore the user settings to the module.
6. Set Conversion enable/disable setting (Un\G0) to Enable (0) for the channel used.
7. Turn on then off Operating condition setting request (Y9).
8. Monitor CH□ Digital output value (Un\G11 to Un\G18) to check if the digital conversion is performed properly.

9. Before starting the control, check the CT input module for the following. If an error occurs, refer to TROUBLESHOOTING (👉 Page 228, CHAPTER 11) and take a corrective action.

- If the RUN LED is on.
- If the ERR. LED is off.
- If Error flag (XF) is off.

10. Since the new module is in the default status, initial settings must be configured using a sequence program after the control resumed. Before the initial setting, check if the initial setting program is proper, satisfying the following.


Normal system configuration

- The sequence program should set the initial setting on the leading edge of Module READY (X0) of the CT input module.
- Do not create a sequence program which sets the initial setting only one scan after RUN. In this case, the initial setting is not set.

When used on remote I/O network

- Insert a user device where the initial setting will be set at any timing (initial setting request signal) into the sequence program.
- Do not create a sequence program which sets the initial setting only one scan after a data link start of the remote I/O network. In this case, the initial setting is not set.

(5) Resuming operation




1. Open the "Online module change" window again.

2. Click the **Execution** button on the appeared window to resume control. Module READY (X0) turns on.

3. The online module change is complete.

Appendix 4 External Dimensions

The following figure shows the external dimensions of a CT input module.



(Unit: mm)

A

Appendix 4 External Dimensions

INDEX

A	
Accuracy	31
Adding a Module	144
Auto refresh	149
Averaging process setting (Un\G24, Un\G25)	110
C	
CH1 Factory default setting offset value (Un\G202) to CH8 Factory default setting gain value (Un\G217)	122
CH1 User range setting offset value (Un\G218) to CH8 User range setting gain value (Un\G233)	122
Channel change completed flag (XB)	86
Channel change request (YB)	90
CH□ Average time/Average number of times/Moving average/Time constant settings (Un\G1 to Un\G8)	107
CH□ Digital output value (Un\G11 to Un\G18)	108
CH□ Dropout value (Un\G162 to Un\G169)	121
CH□ Head pointer (Un\G1090 to Un\G1097)	133
CH□ Input range setting (Un\G150 to Un\G157)	119
CH□ Latest pointer (Un\G1098 to Un\G1105)	134
CH□ Level trigger condition setting (Un\G1056 to Un\G1063)	130
CH□ Logging cycle monitoring value (Un\G1122 to Un\G1145)	135
CH□ Logging cycle setting value (Un\G1032 to Un\G1039)	128
CH□ Logging cycle unit setting (Un\G1040 to Un\G1047)	128
CH□ Logging data (Un\G5000 to Un\G44999)	137
CH□ Logging data setting (Un\G1024 to Un\G1031)	128
CH□ Logging enable/disable setting (Un\G1000 to Un\G1007)	126
CH□ Logging hold flag (Un\G1016 to Un\G1023)	127
CH□ Logging hold request (Un\G1008 to Un\G1015)	127
CH□ Logging points after trigger (Un\G1048 to Un\G1055)	130
CH□ Maximum value (Un\G30, Un\G32, Un\G34, Un\G36, Un\G38, Un\G40, Un\G42, Un\G44)	111
CH□ Minimum value (Un\G31, Un\G33, Un\G35, Un\G37, Un\G39, Un\G41, Un\G43, Un\G45)	111
CH□ Number of logging data (Un\G1106 to Un\G1113)	134
CH□ Peak current detection count (Un\G334 to Un\G341)	126
CH□ Peak current detection count reset complete (Un\G310 to Un\G317)	124
CH□ Peak current detection count reset request (Un\G302 to Un\G309)	124
CH□ Peak current detection time (Un\G318 to Un\G325)	125
CH□ Peak current detection value (Un\G326 to Un\G333)	125
CH□ Process alarm lower lower limit value (Un\G86, Un\G90, Un\G94, Un\G98, Un\G102, Un\G106, Un\G110, Un\G114)	116
CH□ Process alarm lower upper limit value (Un\G87, Un\G91, Un\G95, Un\G99, Un\G103, Un\G107, Un\G111, Un\G115)	116
CH□ Process alarm upper lower limit value (Un\G88, Un\G92, Un\G96, Un\G100, Un\G104, Un\G108, Un\G112, Un\G116)	116
CH□ Process alarm upper upper limit value (Un\G89, Un\G93, Un\G97, Un\G101, Un\G105, Un\G109, Un\G113, Un\G117)	116
CH□ Rate alarm lower limit value (Un\G127, Un\G129, Un\G131, Un\G133, Un\G135, Un\G137, Un\G139, Un\G141)	118
CH□ Rate alarm upper limit value (Un\G126, Un\G128, Un\G130, Un\G132, Un\G134, Un\G136, Un\G138, Un\G140)	118
CH□ Rate alarm warning detection period (Un\G118 to Un\G125)	117
CH□ Scaling lower limit value (Un\G62, Un\G64, Un\G66, Un\G68, Un\G70, Un\G72, Un\G74, Un\G76)	115
CH□ Scaling upper limit value (Un\G63, Un\G65, Un\G67, Un\G69, Un\G71, Un\G73, Un\G75, Un\G77)	115
CH□ Scaling value (Un\G54 to Un\G61)	114
CH□ Trigger data (Un\G1064 to Un\G1071)	131
CH□ Trigger detection time (Un\G1154 to Un\G1185)	136
CH□ Trigger pointer (Un\G1114 to Un\G1121)	135
CH□ Trigger setting value (Un\G1082 to Un\G1089)	132
Conversion completed flag (Un\G10)	108
Conversion completed flag (XE)	88
Conversion enable/disable function	37
Conversion enable/disable setting (Un\G0)	106
Count average	39
CT input value	35
D	
Default setting completed flag (X5)	80
Default setting registration function	73
Default setting request (Y5)	89
Digital Conversion Method	
Averaging process	38
Primary delay filter	41
Sampling processing	38
Digital conversion method	38
Digital output value	35
Dropout detection setting (Un\G160)	120
Dropout function	49
Dropout status flag (Un\G161)	121
E	
Error clear function	78
Error clear request (YF)	90

Error flag (XF)	88
Error history function	74
Error history No. □ (Un\G1810 to Un\G1969)	137
External wiring	143

G

G(P).OFFGAN	241
G(P).OGLOAD	243
G(P).OGSTOR	247
Gain value	29

H

Hardware LED information	239
Hardware switch information	239

I

I/O assignment	251
I/O conversion characteristics	29
Input signal error detection flag (Un\G49)	112
Input signal error detection function	44
Input signal error detection setting (Un\G47)	111
Input signal error detection signal (XC)	87

L

Latest address of error history (Un\G1800)	137
Latest error code (Un\G19)	108
Level data □ (Un\G1072 to Un\G1081)	132
Logging data	35
Logging function	60

M

Maximum and minimum values	35
Maximum value/minimum value hold function	59
Maximum value/minimum value reset completed flag (XD)	88
Maximum value/minimum value reset request (YD)	90
Mode switching setting (Un\G158, Un\G159)	120
Module error collection function	77
Module READY (X0)	80
Moving average	40

O

Offset value	29
Offset/gain setting	150
Setting from "Offset/Gain Setting" of GX Works2	150
Setting from a program	153
Offset/gain setting mode flag (XA)	85
Offset/gain setting mode Gain specification (Un\G23)	109
Offset/gain setting mode Offset specification (Un\G22)	109
Online module change	182
Online module change procedure (When using GX Developer)	253
Operating condition setting completed flag (X9)	84

Operating condition setting request (Y9)	89
--	----

P

Parameter setting	146
Peak current detection flag (Un\G301)	123
Peak current detection function	46
Peak current detection setting (Un\G300)	123
Peak current detection signal (X7)	82

R

Range reference table	227
---------------------------------	-----

S

Sampling cycle setting (Un\G26)	110
Sampling cycle switching function	37
Scaling enable/disable setting (Un\G53)	114
Scaling function	50
Scaling value	35
Set value backup completed flag (X6)	81
Set value backup function	72
Set value backup request (Y6)	89
Switch setting	145

T

Time average	39
------------------------	----

U

User range write request (YA)	90
---	----

W

Warning output flag (Process alarm) (Un\G50)	113
Warning output flag (Rate alarm) (Un\G51)	113
Warning output function	53
Warning output setting (Un\G48)	112
Warning output signal (X8)	83

WARRANTY

Please confirm the following product warranty details before using this product.

1. Gratis Warranty Term and Gratis Warranty Range

If any faults or defects (hereinafter "Failure") found to be the responsibility of Mitsubishi occurs during use of the product within the gratis warranty term, the product shall be repaired at no cost via the sales representative or Mitsubishi Service Company.

However, if repairs are required onsite at domestic or overseas location, expenses to send an engineer will be solely at the customer's discretion. Mitsubishi shall not be held responsible for any re-commissioning, maintenance, or testing on-site that involves replacement of the failed module.

[Gratis Warranty Term]

The gratis warranty term of the product shall be for one year after the date of purchase or delivery to a designated place.

Note that after manufacture and shipment from Mitsubishi, the maximum distribution period shall be six (6) months, and the longest gratis warranty term after manufacturing shall be eighteen (18) months. The gratis warranty term of repair parts shall not exceed the gratis warranty term before repairs.

[Gratis Warranty Range]

- (1) The range shall be limited to normal use within the usage state, usage methods and usage environment, etc., which follow the conditions and precautions, etc., given in the instruction manual, user's manual and caution labels on the product.
- (2) Even within the gratis warranty term, repairs shall be charged for in the following cases.
 1. Failure occurring from inappropriate storage or handling, carelessness or negligence by the user. Failure caused by the user's hardware or software design.
 2. Failure caused by unapproved modifications, etc., to the product by the user.
 3. When the Mitsubishi product is assembled into a user's device, Failure that could have been avoided if functions or structures, judged as necessary in the legal safety measures the user's device is subject to or as necessary by industry standards, had been provided.
 4. Failure that could have been avoided if consumable parts (battery, backlight, fuse, etc.) designated in the instruction manual had been correctly serviced or replaced.
 5. Failure caused by external irresistible forces such as fires or abnormal voltages, and Failure caused by force majeure such as earthquakes, lightning, wind and water damage.
 6. Failure caused by reasons unpredictable by scientific technology standards at time of shipment from Mitsubishi.
 7. Any other failure found not to be the responsibility of Mitsubishi or that admitted not to be so by the user.

2. Onerous repair term after discontinuation of production

- (1) Mitsubishi shall accept onerous product repairs for seven (7) years after production of the product is discontinued.

Discontinuation of production shall be notified with Mitsubishi Technical Bulletins, etc.
- (2) Product supply (including repair parts) is not available after production is discontinued.

3. Overseas service

Overseas, repairs shall be accepted by Mitsubishi's local overseas FA Center. Note that the repair conditions at each FA Center may differ.

4. Exclusion of loss in opportunity and secondary loss from warranty liability

Regardless of the gratis warranty term, Mitsubishi shall not be liable for compensation of damages caused by any cause found not to be the responsibility of Mitsubishi, loss in opportunity, lost profits incurred to the user by Failures of Mitsubishi products, special damages and secondary damages whether foreseeable or not, compensation for accidents, and compensation for damages to products other than Mitsubishi products, replacement by the user, maintenance of on-site equipment, start-up test run and other tasks.

5. Changes in product specifications

The specifications given in the catalogs, manuals or technical documents are subject to change without prior notice.

Microsoft, Windows, Windows NT, and Windows Vista are registered trademarks of Microsoft Corporation in the United States and other countries.

Pentium is a trademark of Intel Corporation in the United States and other countries.

Ethernet is a trademark of Xerox Corporation.

All other company names and product names used in this manual are trademarks or registered trademarks of their respective companies.

SH(NA)-081033ENG-A(1203)MEE

MODEL: Q68CT-U-E

MODEL CODE: 13JZ66

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

When exported from Japan, this manual does not require application to the
Ministry of Economy, Trade and Industry for service transaction permission.

Specifications subject to change without notice.