

# LCD62 Keypad

User Manual



## Disclaimer:

- 
- ❖ *While every effort has been made to ensure that the information in this manual is accurate and complete, no liability can be accepted for any errors or omissions*
  - ❖ *The manufacturer reserves the right to change the specifications of the equipment described in this manual without notice*
  - ❖ *This document contains information proprietary to the manufacturer. No part of this publication may be reproduced, photocopied, stored on a retrieval system or transmitted, without prior written permission of the manufacturer.*
-

# Contents

## **GENERAL INFORMATION** **5**

**Limited Warranty** **5**

**Warnings** **6**

## **DESCRIPTION** **6**

**Overview** **6**

LED Indication 9

Sound Indication 9

Display 10

Keypad 11

## **OPERATION** **13**

**Arming** **13**

Full 13

Stay 14

Force 15

Instant 16

**Panic** **16**

**Disarming** **17**

**Stopping the Alarm** **17**

**Ambush Code** **17**

**Bypassing** **18**

**System Trouble Review** **19**

**Events Memory Review** **19**

**User Level Programming** **22**

User Code Changing 22

Turning On and Off the Chime Mode 22

|                                   |           |
|-----------------------------------|-----------|
| <b>Manager Level Programming</b>  | <b>23</b> |
| Changing the Manager Code         | 23        |
| Changing User Code and Privileges | 24        |
| Turning On and Off the Chime Mode | 26        |
| Setting the Clock                 | 27        |
| Setting the Date                  | 27        |
| Adding a Proximity Card           | 27        |
| Erasing a Card                    | 27        |

## **General Information**

### **Limited Warranty**

The manufacturer warrants that for period of 12 months from the date of purchase, the product shall be free of defects in material and workmanship under normal use and that in fulfillment of any breach of such warranty, the manufacturer shall, at its opinion, repair or replace the defective equipment upon return of the equipment to its factory. This warranty applies only to defects in parts and workmanship and not to damage incurred in shipping or handling, or damage due to causes beyond the control of the manufacturer such as lightning, excessive voltage, mechanical shock, or damage arising out of abuse, alternation or improper application of the equipment.

The foregoing warranty shall apply only to the original buyer, and is and shall be in lieu of any and all other warranties, whether expressed or implied and of all other obligations or liabilities on the part of the manufacturer. This warranty contains the entire warranty. The manufacturer neither assumes, nor authorizes any other warranty or liability concerning this product.

In no event shall the manufacturer be liable for any direct or indirect or consequential damage, loss of anticipated profits, loss of time or any other losses incurred by the buyer in connection with the purchase, installation or operation or failure of this product.

The manufacturer recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal

tampering or electrical disruption, it is possible for this product to fail to perform as expected.

## Warnings

Before using the LCD62 Keypad, please ensure that you have read and understood the following instructions. Always ensure that the LCD62 Keypad is operated correctly.

Do not attempt to disassemble or alter any part of the equipment that is not expressly described in this guide. Internal inspections, alterations and repairs should be conducted by qualified service personnel only.

Do not use substances containing alcohol, benzene, thinners or other flammable substances to clean or maintain the equipment. The use of these substances may lead to fire.

Do not allow liquids to enter the interior. The equipment is not waterproof.

## Description


### Overview


The LCD62 keyboard provides complete control and information of the CA60Plus control panel:

The control panel can be fully programmed from the LCD 62 keypad.

An LCD display and LED indication visualize alarm and status information.

A buzzer lets the user hear correct and incorrect key entries as well as service and alert sounds.







## LED Indication

| LED           | Lit          | Blinking           |
|---------------|--------------|--------------------|
| Ready (green) | System ready | Programming mode   |
| Arm (red)     | System armed | Entry or exit time |
| Trbl (orange) | -            | Technical problem  |

## Sound Indication

There are seven different sound combinations that indicate seven different conditions:

**Click** – single short beeps indicating button pressing

**Confirm** – two long beeps indicating the system confirmation to executed operation (arming, disarming, settings change, etc.)

**Reject** – single long beep indicating incorrectly executed operation

**Entrance time** – continuous beep indicating intrusion into the entrance zones.

**Exit time** – short beeps indicating the system is armed and the user is required to leave the zone. Ten seconds before the exit time is over beeps frequency is increased.

**Trouble** – two short beeps indicating problem with the system (battery low, no supply voltage, etc.)

**Chime** – short beeps with subsequently increasing period indicating intrusion into a zone with a “Chime” option activated

## Display



Figure 1. LCD Display

- indicates battery condition:
- (static) – battery OK
  - (blinking) – battery low or missing

- indicates power supply status:
- (static) – power supply OK
  - (blinking) – power supply loss
- indicates system trouble (blinking)
- M** – indicates events memory record
- ON** – indicates the system is armed
- OFF** – indicates the system is not armed
- 88:88** – displays various information (time, date, codes, etc.)
- READY** – indicates the system is ready to be operated
- FIRE** – indicates fire alarm
- ALARM** – indicates alarm
- MEMORY** – indicates events memory record (See page 19)
- STAY** – indicates the system is stay armed (See page 13)


**FORCE** – indicates the system is force armed (See page 14)








**INSTANT** – indicates the system is instant armed (See page 15)




– visualizes various alarm and arm conditions

## Keypad



-  arms the system (*See page 13*)
-  bypasses certain zone(s) (*See page 17*)
-  reviews the system troubles (*See page 19*)
-  reviews the event memory (*See page 17*)
-  clears entered data or transfers to previous menu level
-  confirms entered data or transfers to next menu level
-  activates the programming mode (*See page 22*)



scroll the event memory (*See page 17*) or the system troubles (*See page 19*)

enter user codes or other data

## Operation

The system can be operated when the **READY** symbol is displayed on the LCD

## Arming

### Full

Full arming means all zones are secured. Anyone coming into the entrance zone is required to enter a code. Otherwise the alarm is started after the entrance time is over.

Full arming sequence:



Fast full arming key sequence:



LCD displays:



## Stay

Stay arming means the user is allowed to stay in certain zone(s), but the entrance zone is secured. Anyone coming into the entrance zone is required to enter a code. Otherwise the alarm is started after the entrance time is over.

Stay arming key sequence:



Fast stay arming key sequence:



LCD displays:



The number of the zone(s) that are bypassed are replaced with a [ ] symbol on the LCD.

## Force

Force arming means the system is armed despite that in certain zone(s) there may be an obstacle or trouble.

Forced arming key sequence:



Fast forced arming key sequence:



LCD displays:



The number of the zone(s) that are bypassed are replaced with a [ ] symbol on the LCD.

After any of the procedures described above, short beeps and blinking **ON** symbol on the LCD indicate the exit time and the user is required to leave the zone. Ten seconds before the exit time is over beeps frequency is increased.


## Instant

Instant arming means the user is allowed to stay in certain zone(s), but the entrance zone is secured. The difference with the stay arming is that intrusion into the entrance zone immediately starts the alarm.

Instant stay arming key sequence:



Fast instant stay arming key sequence:



LCD displays:



The number of the zone(s) that are bypassed are replaced with a [ ] symbol on the LCD.

The **ON** symbol on the LCD indicates the system is Instant armed.

## Panic

Pressing and holding CLR + ENT sends alarm signal.



## Disarming

Coming into the entrance zone, the user is required to enter a personal code:



A continuous beep indicates the entrance time.

**Note:** Certain users may not be allowed to disarm the system

## Stopping the Alarm

The alarm is stopped by entering a personal code:



## Ambush Code

Ambush code is a personal code that disarms the system, but still sends alarm signal. Its purpose to indicate that the user is forced to disarm the system against his/her will.

The ambush code is produced from a personal code by increasing the last number by one.

If the last number is 9, it is replaced by 0 in the ambush code.

Example:

Personal code: 4615 → Ambush code: 4615

Personal code: 4619 → Ambush code: 4610


## Bypassing

To execute bypass operation the user is required a personal code.



Pressing a numeric key bypasses the respective zone. The zone number is surrounded by the [ ] symbol. Pressing the same key once again de-bypasses the zone. The [ ] symbol is removed. Pressing **ENT** confirms the selection:

Bypassing key sequence:



LCD displays:




## System Trouble Review

To review troubles the user is required a personal code.



LCD displays:



## Events Memory Review


To review the event memory the user is required a personal code.



**Note:** Certain users may not be allowed to review the event memory.

Next event ◀, previous event ▶

To view the code, the time and the date of the event:



| Event Description         | Event Code | Zone / User |
|---------------------------|------------|-------------|
| Alarm activated           | 01         | Zone number |
| Alarm deactivated         | 02         | Zone number |
| Fire alarm activated      | 03         | Zone number |
| Fire alarm deactivated    | 04         | Zone number |
| Panic alarm activated     | 05         | Zone number |
| Panic alarm deactivated   | 06         | Zone number |
| Tamper alarm activated    | 07         | Zone number |
| Tamper alarm deactivated  | 08         | Zone number |
| Medical alarm activated   | 09         | Zone number |
| Medical alarm deactivated | 10         | Zone number |

| Event Description        | Event Code | Zone / User |
|--------------------------|------------|-------------|
| Zone bypassed            | 11         | Zone number |
| Zone de-bypassed         | 12         | Zone number |
| Fire zone bypassed       | 13         | Zone number |
| Fire zone de-bypassed    | 14         | Zone number |
| Panic zone bypassed      | 15         | Zone number |
| Panic zone de-bypassed   | 16         | Zone number |
| Tamper zone bypassed     | 17         | Zone number |
| Tamper zone de-bypassed  | 18         | Zone number |
| Medical zone bypassed    | 19         | Zone number |
| Medical zone de-bypassed | 20         | Zone number |

| Event Description   | Event Code | Zone / User    |
|---------------------|------------|----------------|
| Disarming           | 21         | User number    |
| Remote disarming    | 22         | User number    |
| Disarming by key    | 23         | Zone number    |
| Arming              | 24         | User number    |
| Remote arming       | 25         | User number    |
| Arming by key       | 26         | Zone number    |
| Fast arming         | 27         | Doesn't matter |
| Engineer menu entry | 28         | 17             |
| Engineer menu exit  | 29         | 17             |
| Ambush code entry   | 30         | User number    |

| Event Description     | Event Code | Zone / User |
|-----------------------|------------|-------------|
| Phone line error      | 31         | 0           |
| Phone line recovery   | 32         | 0           |
| Communication error   | 33         | 0           |
| Automatic test        | 34         | 0           |
| Manual test           | 35         | 0           |
| Fuse blown            | 36         | 0           |
| Fuse recovery         | 37         | 0           |
| System reset          | 38         | 0           |
| Power supply loss     | 39         | 0           |
| Power supply recovery | 40         | 0           |

| Event Description      | Event Code | Zone / User |
|------------------------|------------|-------------|
| Battery low or missing | 41         | 0           |
| Battery recovery       | 42         | 0           |

## User Level Programming

Blinking **READY** symbol indicates the system is in programming mode.

## User Code Changing

User is required to enter his/her personal code first before changing it.


User code changing key sequence:




## Turning On and Off the Chime Mode

To turn the chime mode on or off the use is required a personal code.

Turning the chime on and off key sequence:



Pressing any numeric key switches alternatively the chime mode on and off. Pressing **ENT** confirms the selection:



## Manager Level Programming



Blinking **READY** symbol indicates the system is in programming mode.

### Changing the Manager Code

Manager is required to enter his/her personal code first before changing it.


Manager code changing key sequence:



Now the manager can switch using the   keys between code changing mode and remote permissions mode.

Initially the system is in code changing mode.

LCD displays:




The manager is expected to enter a new code.

Entering a new manager code key sequence:




The new code is accepted and the system automatically goes into the remote permissions mode.


LCD displays:



Pressing a numeric key permits the respective operation. The operation number is surrounded by the [ ] symbol. Pressing the same key once again forbids the operation. The [ ] symbol is removed.

Pressing  confirms the selection.


Remote permissions key sequence:



## Changing User Code and Privileges

Manager is required to enter his/her personal code first before user code.

User code changing key sequence:






Now the manager can switch using the ◀ ▶ keys between code changing mode and user permissions mode.

Initially the system is in code changing mode.

LCD displays:


 The number of the [ ] symbols surrounding the figures indicate the number of the code digits left to enter

The manager is expected to enter a new code.

Entering a new user code key sequence:


NEW CODE  →  → NEW CODE   
(4 digits) (2 beeps) (once again)

The new code is accepted and the system automatically goes into the user permissions mode.


 The [ ] symbol surrounding a number indicates the user is allowed to execute the respective operation.

- Bypass
- Review events memory
- Force arm
- Stay arm
- Full arm
- Disarm

Pressing a numeric key permits the respective operation. The operation number is surrounded by the [ ] symbol. Pressing the same key once again forbids the operation. The [ ] symbol is removed.

Pressing  confirms the selection.

User permissions key sequence:




## Turning On and Off the Chime Mode

To turn the chime mode on or off the manager is required a personal code.

Turning the chime on and off key sequence:




Pressing any numeric key switches alternatively the chime mode on and off. Pressing **ENT** confirms the selection.



## Setting the Clock

To set the clock the manager is required a personal code.


Setting the clock key sequence:



## Setting the Date

To set the date the manager is required a personal code.


Setting the date key sequence:



## Adding a Proximity Card

To use proximity cards, the system has to be equipped with proximity card reader


Adding a card key sequence:



The proximity card has to be placed near the card reader at that time.

## Erasing a Card

Erasing a card key sequence:



## Appendix

| Address | J0 | J1 | J2 | JT |
|---------|----|----|----|----|
| 0       | 0  | 0  | 0  | 1  |
| 1       | 0  | 0  | 1  | 0  |
| 2       | 0  | 1  | 0  | 0  |
| 3       | 0  | 1  | 1  | 0  |
| 4       | 1  | 0  | 0  | 0  |
| 5       | 1  | 0  | 1  | 0  |
| 6       | 1  | 1  | 0  | 0  |
| 7       | 1  | 1  | 1  | 0  |

