



# Ethernet Card 75

*User's Guide*



*Network  
Interface  
Card*

## **Océ Ethernet Card 75**

© 2001 by Océ USA, Inc. and Océ Printing Systems, USA, Inc.

ManualVersion  
Ethernet Card 75

Correspondence

Océ USA, Inc.  
5450 N. Cumberland Avenue  
Chicago, IL 60656

Océ Printing Systems, USA, Inc.  
5600 Broken Sound Blvd.  
Boca Raton, FL 33487

### **Acknowledgments**

All brands and product names are trademarks or registered trademarks of their respective companies.

### **Web Site Address on the Internet**

<http://www.oceusa.com>

### **Disclaimer Notice**

Océ USA, Inc. and Océ Printing Systems, USA, Inc. has made every effort to ensure that information in this manual is complete and accurate. However, constant efforts are also being made to improve and update the product. Therefore, Océ USA, Inc. and Océ Printing Systems, USA, Inc. shall not be liable for errors in this manual or for any consequential damages resulting from the use of this manual. Information contained herein is subject to change without notice.

Thank you very much for purchasing the Océ Ethernet Card 75 Network Interface Card.

This User's Guide includes instructions for making prints, handling the machine correctly, and safety precautions. Please read this manual before performing any printing operations or using the equipment in any way.

In order to maintain satisfactory printing performance, please keep this User's Guide readily available for reference.

# SOFTWARE LICENSE AGREEMENT

This package contains the following materials provided by Océ-USA, Inc. / Océ Printing Systems USA, Inc. (Océ): software included as part of the printing system, the digitally-encoded machine-readable outline data encoded in the special format and in the encrypted form ("Font Programs"), other software which runs on a computer system for use in conjunction with the Printing Software ("Host Software"), and related explanatory written materials ("Documentation").

The term "Software" shall be used to describe Printing Software, Font Programs and/or Host Software and also include any upgrades, modified versions, additions, and copies of the Software.

The Software is being licensed to you under the terms of this Agreement.

Océ grants to you a non-exclusive sublicense to use the Software and Documentation, provided that you agree to the following:

1. You may use the Printing Software and accompanying Font Programs for imaging to the licensed output device(s), solely for your own internal business purposes.
2. In addition to the license for Font Programs set forth in Section 1 ("Printing Software") above, you may use Roman Font Programs to reproduce weights, styles, and versions of letters, numerals, characters and symbols ("Typefaces") on the display or monitor for your own internal business purposes.
3. You may make one backup copy of the Host Software, provided your backup copy is not installed or used on any computer. Notwithstanding the above restrictions, you may install the on any number of computers solely for use with one or more printing systems running the Printing Software.
4. You may assign its rights under this Agreement to an assignee of all of Licensee's right and interest to such Software and Documentation ("Assignee") provided you transfer to Assignee all copies of such Software and Documentation Assignee agrees to be bound by all of the terms and conditions of this Agreement.
5. You agree not to modify, adapt or translate the Software and Documentation.
6. You agree that you will not attempt to alter, disassemble, decrypt, reverse engineer or decompile the Software.
7. Title to and ownership of the Software and Documentation and any reproductions thereof shall remain with Océ.
8. Trademarks shall be used in accordance with accepted trademark practice, including identification of the trademark owner's name. Trademarks can only be used to identify printed output produced by the Software. Such use of any trademark does not give you any rights of ownership in that trademark.
9. You may not rent, lease, sublicense, lend or transfer versions or copies of the Software Licensee does not use, or Software contained on any unused media, except as part of the permanent transfer of all Software and Documentation as described above
10. In no event will Océ be liable to you for any consequential, incidental or special damages, including any lost profits or lost saving, even if Océ has been advised of the possibility of such damages, or for any claim by any third party. Some states or jurisdictions do not allow the exclusion or limitation of incidental, consequential or special damages, so the above limitations may not apply to you.
11. Notice to Government End Users: The Software is a "commercial item," as that term is defined at 48 C.F.R. 2.101, consisting of "commercial computer software" and "commercial computer software documentation," as such terms are used in 48 C.F.R. 12.212. Consistent with 48 C.F.R. 12.212 and 48 C.F.R. 227.7202-1 through 227.7202-4, all U.S. Government End Users acquire the Software with only those rights set forth herein.

Macintosh® is a registered trademark of Apple Computer, Inc.

Windows® is a registered trademark of Microsoft Corporation.

## ■ Preface

### ● About this manual

This manual is used for the Océ Ethernet Card 75 Network Interface Card.

This manual describes how to operate and set up the dedicated Océ Print Controller attached to the Océ Ethernet Card 75 Network Interface Card, configured with the exclusive Océ Main Body Printer (Copier) and intended for use as a network printer.

The print controller and the main body printer are separately supplied with instruction manuals. Refer to these manuals as the need arises.

### ● Compliant model

The Ethernet Card 75 is installed in the dedicated print controller to be used.

The Ethernet Card 75 Network Interface Card is intended for use with the following print controller and the main body printer (copier):

Compliant print controller

- Network Print Controller 75

Compliant main body printer (copier)

- Océ 3275 Copier

### ● Package contents

Make sure that the Ethernet Card 75 Network Interface Card package contains the following items:

- Ethernet Card 75 Network Interface Card
- Ethernet Card 75 Network Interface Card Installation Procedure
- Accompanying CD-ROM

### ● FCC Regulations

This equipment has been tested and found to comply with limits for a Class B digital device, pursuant to part 15 of FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from the circuit to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## ● Canadian Department of Communications Regulations

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.  
This Class B digital apparatus complies with Canadian ICES-003.

## ● Registered trademarks

Microsoft, MS and MS-DOS are registered trademarks of U.S. Microsoft Corporation.  
Windows™ is a registered trademark of U.S. Microsoft Corporation.  
Novell and NetWare are registered trademarks of U.S. Novell, Inc.  
Adobe and Acrobat are registered trademarks of U.S. Adobe Systems Incorporated.  
Macintosh, Mac and AppleTalk are registered trademarks of U.S. Apple Computer Inc.  
UNIX is a registered trademark of The Open Group.

The other company names and trademarks used in this document are the registered trademarks and trademarks of the associated companies.

## ● Name of each product in this manual

The following abbreviations are used in this manual:

Ethernet Card 75 Network Interface Card:	network interface card
Network Print Controller 75:	print controller
Océ 3275/750 Copier-Printer:	main body printer
A printing system that combines the above three products:	printing system
Microsoft Windows 95:	Windows 95
Microsoft Windows 98:	Windows 98
Microsoft Windows Me:	Windows Me
Microsoft Windows NT 4.0:	Windows NT 4.0 ( or Windows NT )
Microsoft Windows 2000:	Windows 2000
Above five OSs:	Windows 95/98/Me/NT 4.0/2000 ( or Windows 95/98/Me/NT/2000 )

## ● Important notice


- Be sure to read the Readme.txt file in the accompanying CD-ROM.
- For details about operations with Windows 95/98/Me/NT/2000, Novell NetWare, Macintosh, or other applications, refer to the operating manuals provided with each operating system or software application.
- Océ can accept no responsibility for any loss resulting from the use of this printing system or this manual.
- No part of this manual may be copied or reproduced.
- The contents of this User's Guide is subject to change without prior notice.

## ● Folder structure on the CD-ROM

The folder configuration of the attached CD-ROM differs depending on the print controller you purchased. The following figure describes the folder configuration of the CD-ROM for Network Print Controller 75. Therefore, when your print controller is different from those, use it just for reference to search for a folder or file.

- Each OS folder has its own structure of folders.
- In this manual, folder names and file names are not preceded by the root directory somewhere.
- You may use the file in this English folder only.

### CD-ROM



# CONTENTS

■ Preface .....	iii
● About this manual .....	iii
● Compliant model .....	iii
● Package contents .....	iii
● FCC Regulations .....	iii
● Canadian Department of Communications Regulations .....	iv
● Registered trademarks .....	iv
● Name of each product in this manual .....	iv
● Important notice .....	iv
● Folder structure on the CD-ROM .....	v
<b>Chapter 1 Network Interface Card Overview .....</b>	<b>1-1</b>
■ Features of the Network Interface Card .....	1-2
■ Installation of the Network Interface Card .....	1-2
■ Using the accompanying CD-ROM .....	1-3
■ Network setting procedures .....	1-4
● Windows 95/98/Me configuration (peer-to-peer) .....	1-4
● Windows NT/2000 configuration (LPD/LPR) .....	1-4
● UNIX configuration (lpd/lpr) .....	1-5
● NetWare configuration .....	1-5
● AppleTalk configuration .....	1-5
<b>Chapter 2 Setting Up the Network Interface Card .....</b>	<b>2-1</b>
■ General description of the network setup .....	2-2
● Assigning IP Address .....	2-2
● Accessing Web Utilities .....	2-5
■ Using MAP (Management Access Program) .....	2-6
● Operating requirements .....	2-6
● Installing MAP .....	2-6
● Setting up MAP .....	2-6
● Starting MAP .....	2-7
■ Using Web Utilities .....	2-8
● Network Setup .....	2-8
<b>Chapter 3 Windows 95/98/Me Configuration (Peer-to-Peer Printing) .....</b>	<b>3-1</b>
■ Using IP Peer-to-Peer .....	3-2
● Basic TCP/IP setup .....	3-2
● Installation of IP Peer-to-Peer .....	3-2
● IP Peer-to-Peer setup .....	3-3
● Setting up printer driver .....	3-5
■ Using IPX Peer-to-Peer .....	3-6
● Introduction and preparation .....	3-6
● Installation of IPX Peer-to-Peer .....	3-7
● IPX Peer-to-Peer setup .....	3-8

<b>Chapter 4 Windows NT/2000 Configuration (LPD/LPR Printing)</b> .....	<b>4-1</b>
■ LPD/LPR setup .....	4-2
● Adding a printer port on Windows NT .....	4-2
● Creating a printer port on Windows 2000 .....	4-3
<b>Chapter 5 UNIX Configuration</b> .....	<b>5-1</b>
■ UNIX printing through TCP/IP .....	5-2
● Introduction .....	5-2
● Printing overview .....	5-3
● Configuring IP address to the network interface card .....	5-4
● lpd UNIX Printing .....	5-5
<b>Chapter 6 NetWare Configuration</b> .....	<b>6-1</b>
■ Setup with NWSetup .....	6-2
● How to install .....	6-2
● Using the NWSetup program .....	6-3
■ Setup for NetWare 3.x .....	6-8
■ Setup for NetWare 4.x .....	6-9
● Setup information .....	6-9
● NDS setup .....	6-10
● Setup for Bindery Emulation .....	6-10
<b>Chapter 7 AppleTalk Configuration</b> .....	<b>7-1</b>
■ Setup for printing through AppleTalk .....	7-2
● Configuration for AppleTalk .....	7-2
● Using the NIManage .....	7-2
<b>Chapter 8 Troubleshooting</b> .....	<b>8-1</b>
■ LED Status Indicator .....	8-2
■ Resetting the Network Interface Card to Factory Default .....	8-2
■ Status Page .....	8-3
■ How to Diagnose Problems .....	8-4
● Troubleshooting Network Hardware Connections .....	8-4
● Troubleshooting MAP Problems .....	8-4
● Troubleshooting NetWare Protocol .....	8-5
<b>Appendix</b> .....	<b>Appendix-1</b>
INDEX .....	Index-1

# Chapter 1 Network Interface Card Overview

- Features of the Network Interface Card..... 1-2
- Installation of the Network Interface Card ..... 1-2
- Using the accompanying CD-ROM ..... 1-3
- Network setting procedures ..... 1-4
  - Windows 95/98/Me configuration (peer-to-peer) ..... 1-4
  - Windows NT/2000 configuration (LPD/LPR) ..... 1-4
  - UNIX configuration (lpd/lpr) ..... 1-5
  - NetWare configuration ..... 1-5
  - AppleTalk configuration ..... 1-5

### ■ Features of the Network Interface Card

The network interface card offers the following features:

- Automatic Selection of 100BaseTX (Fast Ethernet) or 10BaseT Ethernet connection
- Multiple protocols (TCP/IP, IPX/SPX and AppleTalk [EtherTalk]) supported
- Peer-to-peer printing over TCP/IP from Microsoft Windows 95/98/Me (by using a dedicated utility, IP-P2P)
- Peer-to-peer printing over IPX/SPX from Microsoft Windows 95/98/Me (by using a dedicated utility, IPX-P2P)
- LPD/LPR printing over TCP/IP for Microsoft Windows NT/2000
- UNIX lpd/lpr printing through TCP/IP
- Both bindery mode and Novell Directory Services (NDS) supported to accommodate Novell NetWare print server features
- AppleTalk printing support for the Macintosh (by using a dedicated utility, NIManage)
- Automatic IP address acquisition by DHCP
- Built-in HTTP server enables printing system management by linking with the management Access Program (MAP) provided and a standard web browser
- NWSsetup utility to set up NetWare from Windows 95/98/Me/NT/2000
- BOOTP Lite utility to assign IP address through Windows 95/98/Me/NT/2000
- UNIX-TCP/IP Programs supports printing from various UNIX systems
- Use of flash memory allows upgrading of firmware through network

### ■ Installation of the Network Interface Card

Request installation of the network interface card from your Océ service representative.

## ■ Using the accompanying CD-ROM

The CD-ROM contains some utility programs used for the network interface card and the User's Guide (same as this) in the form of PDF (Portable Document Format). The CD-ROM is compatible with Windows 95/98/Me/NT/2000 or Mac OS. The English language version software included in the CD-ROM includes the following:

### **MAP (Management Access Program)**

Utility program to let Windows 95/98/Me/NT/2000 identify IP- or IPX-based printing systems on the networks. This also allows you to access the Web Utilities implemented in the network interface card, and make network and printing system settings by using the Web Utilities in conjunction with Web Browsers.

### **IP-P2P**

Program to execute a peer-to-peer printing from Windows 95/98/Me via TCP/IP

### **IPX-P2P**

Program to execute a peer-to-peer printing through Windows 95/98/Me IPX/SPX

### **NWSetup**

Utility program to set up Novell NetWare for the network interface card from Windows 95/98/Me/NT/2000

### **BOOTP Lite**

Utility program to assign IP address to the network interface card through Windows 95/98/Me/NT/2000

### **NIManage**

Program for network administrator to configure TCP/IP settings to the network interface card from Macintosh

### **UNIX-TCP/IP Programs**

Program for printing from various UNIX systems when not running lpd/lpr

### ■ Network setting procedures

Before using the network interface card, you must first connect the network interface card to the network and then perform the setup procedures for the printing system. The setup procedures depend on the system environment.

To connect the network interface card to the network, use the Ethernet connector (RJ45) of the network interface card and a UTP cable (of category 5, recommended).

#### ● Windows 95/98/Me configuration (peer-to-peer)

To print over LAN (Local Area Network) in Windows 95/98/Me, with no print servers installed, you can link your print controllers with a configuration called peer-to-peer connection. In peer-to-peer connections, TCP/IP and IPX/SPX protocols are used, each with a dedicated utility program. Setup procedures are as follows:

##### For IP peer-to-peer connections

1. **Using BOOTP Lite or the arp command, assign IP address to the network interface card.**
2. **Using Web Utilities, make TCP/IP settings of the network interface card.**
3. **Make TCP/IP settings on your computer (Windows 95/98/Me).**
4. **Install IP-P2P from the accompanying CD-ROM.**
5. **Install Printer Driver.**

For more information about steps 1 and 2, refer to “Chapter 2 Setting Up the Network Interface Card”, and for more information about steps 3 to 5, refer to “Chapter 3 Windows 95/98/Me Configuration (peer-to-peer)”.

##### For IPX peer-to-peer connections

1. **Add IPX/SPX Protocol to your computer.**
2. **Install IPX-P2P from the accompanying CD-ROM.**
3. **Install Printer Driver.**

For more information, refer to “Chapter 3 Windows 95/98/Me Configuration (peer-to-peer)”.

#### ● Windows NT/2000 configuration (LPD/LPR)

To print by LPD/LPR from Windows NT/2000 use the following setup procedure:

1. **Using BOOTP Lite or the arp command, assign IP address to the network interface card.**
2. **Using Web Utilities, make the network interface card TCP/IP settings.**
3. **Make TCP/IP settings on your computer (Windows 95/98/Me).**
4. **Add/Create the Printer Port, and install Printer Driver.**

For more information about steps 1 and 2, refer to “Chapter 2 Setting Up the Network Interface Card”, and for more information about steps 3 to 4, refer to “Chapter 4 Windows NT/2000 Configuration (LPD/LPR)”.

### ● UNIX configuration (lpd/lpr)

If you are using UNIX, see “Assigning IP address in Chapter 2 Setting Up the Network Interface Card”, “Chapter 5 UNIX Configuration”, and “Information for the TCP/IP network administrator in Appendix”.

### ● NetWare configuration

To print in a Novell NetWare network, setup procedures depend on the NetWare version and resource management. As shown, each procedure is comprised of two steps. Whichever procedure you choose, refer to “Chapter 2 Setting Up the Network Interface Card”, to learn more about step 1, and “Chapter 6 NetWare Configuration”, to learn more about step 2.

#### With NetWare 3.x

1. **Gain access to Web Utilities of the network interface card through MAP, and set up a server name and others for the network interface card.**
2. **Using PCONSOLE, configure for print server features.**

#### By using NDS with NetWare 4.x

1. **Gain access to Web Utilities of the network interface card through MAP, and set up a server name and others for the network interface card.**
2. **Using PCONSOLE, configure for print server features.**

#### By using bindery emulation with NetWare 4.x

1. **Gain access to Web Utilities of the network interface card through MAP, and set up a server name and others for the network interface card.**
2. **Using PCONSOLE, configure for print server features.**

### ● AppleTalk configuration

To print over AppleTalk from Macintosh, refer to “Chapter 7 AppleTalk Configuration”.

## Chapter 2 Setting Up the Network Interface Card

■ General description of the network setup .....	2-2
● Assigning IP Address .....	2-2
● Accessing Web Utilities .....	2-5
■ Using MAP (Management Access Program) .....	2-6
● Operating requirements .....	2-6
● Installing MAP .....	2-6
● Setting up MAP .....	2-6
● Starting MAP .....	2-7
■ Using Web Utilities .....	2-8
● Network Setup .....	2-10

### ■ General description of the network setup

With the network interface card, there are five ways to print over TCP/IP.

- Use IP/P2P in peer-to-peer printing setup via Windows 95/98/Me
- Use IPX/P2P in peer-to-peer printing setup via Windows 95/98/Me
- Use LPD/LPR via Windows NT/2000
- Use lpd/lpr via UNIX
- Use UNIX-TCP/IP Programs via UNIX

### ● Assigning IP Address

Before printing over TCP/IP, you first need to assign the IP address to the network interface card. There are six ways to assign the IP address to the network interface card.

- Use DHCP (Dynamic Host Configuration Protocol) for automatic IP address assignment
- Use BOOTP Lite from Windows 95/98/Me/NT/2000 for assigning a specific IP address
- Use the arp (Address Resolution Protocol) command from Windows 95/98/Me/NT/2000 for assigning a specific IP address
- Use the arp (Address Resolution Protocol) command from UNIX for assigning a specific IP address
- Use MAP (Management Access Program) for assigning a specific IP address
- Use NIManage from Macintosh for assigning a specific IP address

When initially connecting the network interface card to networks that are not using DHCP, you need to confirm the following information:

- IP address to assign to the network interface card
- Network address of the network interface card (MAC address or Ethernet address)

Check with the network administrator for the IP address assigned to the network interface card. The network (MAC) address of the network interface card is found on the Status Page (network setup list). It is also indicated on the label on the network interface card. The Status Page is output after starting the network interface card.

---

#### MEMO

---

Depending on the network interface card settings, the Status Page can not be output.  
For more information about setup, refer to "Network Setup" in this chapter.

---

### Using DHCP

For networks on which IP addresses managed by a DHCP server, the IP address is automatically assigned to each network interface card. For more information how to use DHCP, refer to "Information for the TCP/IP network administrator in Appendix-5".

### Using BOOTP Lite (Windows 95/98/Me/NT/2000)

From Windows 95/98/Me/NT/2000, you can use the BOOTP Lite program to assign the IP address to the network interface card. TCP/IP must be set up correctly on the computer that will execute this program. To copy/install the program files in the Windows directory perform the following procedure:

1. **Reset the print controller and the main body printer.**

---

#### MEMO

---

The BOOTP Lite program uses the BOOTP protocol. The BOOTP request is for a finite period of time the print controller and the main body printer must be freshly reset for this to work.

---

2. **Double click the Bootpl32.exe icon using the [Explorer].**
3. **Pull down the [Admin] menu to [Configure] option.**
4. **Enter the [IP address] that you want to assign to the network interface card, its [Subnet Mask] (make sure it matches what you are using on your subnet), [Default Gateway] (your router's IP address), and the [MAC address] of the network interface card.**  
Use colons as delimiters as shown on the Status Page rather than the dashes Windows uses.
5. **Click on Go.**
6. **Wait about five minutes. The network interface card should recycle and produce a Status Page showing the IP parameters you have just entered.**
7. **Pull down the [Admin] menu to [Verify].**  
You should get a message back stating that [The Unit is Active]. If you do not get this message, verify that TCP/IP is enabled on the Status Page.
8. **When you get a response that the unit is active, you should be able to ping the network interface card.**

### Using arp command (Windows 95/98/Me/NT/2000)

From Windows 95/98/Me MS-DOS prompt or at Windows NT/2000 command prompt, you can use the arp command to assign the IP address to the network interface card. It is necessary that TCP/IP is set up correctly on the computer that will execute the arp command. Perform the following procedure:

1. **At Windows 95/98/Me, select [MS-DOS prompt] from the [Start] menu. At Windows NT/2000, select [Command prompt] from the [Start] menu.**
2. **Execute the arp command. For example, if the MAC address of the network interface card is 00:11:22:33:44:55 and the IP address to assign is 192.168.0.128, then input as shown below, and then press [Enter].**

```
(Example: C:\>arp -s 192.168.0.128 00-11-22-33-44-55
```

3. **Execute the ping command for the assigned IP address. In this case no response is returned from the network interface card.**

(Example: C:\>ping 192.168.0.128

4. **Turn off the main power supply to the print controller and the main body printer, then turn it back on.**

A Status Page will be output. Check that the IP address is correctly set in the list. Or, when about 5 minutes have passed after having restarted the print controller and the main body printer using the ping command, check that the network interface card responds correctly. The ping command is also executed at Windows 95/98/Me MS-DOS prompt or Windows NT/2000 Command prompt. The example of executing the ping command is shown below:

(Example: C:\>ping 192.168.0.128

### Using arp command (UNIX)

From UNIX you can use the arp command to assign the IP address to the network interface card. Perform the following procedure:

1. **Turn off the print controller and the main body printer.**
2. **Log in as superuser on a host on the same subnet as the network interface card. However, if the server resides on another subnet, complete this procedure to store the IP address in the network interface card.**
3. **Find the MAC address of the network interface card. The address is printed on the Status Page each time you turn on the print controller and the main body printer.**
4. **Edit the hosts file (usually /etc/hosts) or use NIS or DIS to add IP address and node name of the network interface card. See the network administrator for the IP address. For example, a network interface card with a name of printfast and an IP address of 192.9.200.200 has the entry:**

```
192.9.200.200 printfast
```

5. **Add an entry to the arp cache for IP address and Mac address of the network interface card, as:**

```
arp -s 192.9.200.200 0:40:c8:0:0:ff
```

**RS6000 (AIX) requires the ether option after arp -s. For example:**

```
arp -s ether 192.9.200.200 0:40:c8:0:0:ff
```

6. **Check the print controller and the main body printer to see that the network interface card is connected to the network. Turn on the print controller and the main body printer.**
7. **Send a ping command to the network interface card to verify it is running on the network, as for example:**

```
ping 192.9.200.200 or ping printfast
```

**The network interface card will not respond to this ping command but it will read its IP address from the packets.**

8. **Turn off the print controller and the main body printer and back on again and then send the ping command again to verify that the network interface card obtained its IP address. A confirmation message displays as:**

```
192.9.200.200 is alive
```

9. **Remove the entry from the arp cache using the following command. Specify the network interface card either by its IP address or by its name, for example:**

```
arp -d printfast
```

### Using MAP

By using MAP (Management Access Program) included the CD-ROM that comes with the network interface card, you can automatically identify the network interface card on the network and set it up for TCP/IP by using Web Utilities. To use this method to assign the IP address to the network interface card, the following procedure should be performed on computers in advance:

- TCP/IP correctly configured
- IPX/SPX-compatible protocol installed
- MAP installed and MAP setup correctly executed

About how to set up TCP/IP and how to install IPX/SPX-compatible protocol, refer to Windows Help menus for example. For MAP, refer to “Using MAP (Management Access Program)” in this chapter.

---

#### MEMO

---

To change an IP address already assigned to a network interface card, you can not use the arp command. Use Web Utilities instead. These methods also allow you to set up subnet mask and default gateway, etc.

---

### Using NIManage

Refer to “Chapter 7 AppleTalk Configuration”.

## ● Accessing Web Utilities

The network interface card is provided with an HTTP server having Web Utilities. By accessing this server, you can change settings of the printing system. There are two ways to access Web Utilities, through a Web Browser, either through Netscape Navigator, version 4.x or greater or through Internet Explorer, version 4.x or greater.

- Use MAP to have the network interface card on the networks identified automatically, thereby accessing Web Utilities.
- Use a Web Browser to type the IP address assigned to the network interface card, and thereby access the Web Utilities. For example:

`http://192.168.0.128/`

---

#### MEMO

---

If you designate the proxy setting in your Web Browser you cannot access the Web Utilities. For more information see your network administrator.

---

### ■ Using MAP (Management Access Program)

A utility called MAP is provided on the CD-ROM that comes with the network interface card.

This program automatically identifies the network interface cards on the networks and lists them on Web Browser screen. From this Web Browser list you can select a network interface card to change its settings and control Web Utilities.

#### ● Operating requirements

MAP is a utility that runs on Windows 95/98/Me/NT/2000. It identifies the network interface cards on the networks and achieves connection with HTTP servers implemented on the network interface cards. The MAP itself has no interface, so either of the following Web Browsers is required as an interface:

- Netscape Navigator (version 4.x or greater)
- Internet Explorer (version 4.x or greater)

To use Web Browser, it is necessary that a TCP/IP protocol be installed to the Windows compliant computer. And to identify the network interface cards, it is necessary that a TCP/IP protocol or an IPX protocol be set up beforehand both on the network interface cards and on the Windows capable computers.

#### ● Installing MAP

Perform the following steps to install MAP:


1. **Insert the CD-ROM into the CD-ROM drive, and double-click on [Setup.exe] in the [Map] folder.**
2. **A setup program will start. Confirm the display, and click on the [Next] button.**
3. **Confirm a folder to install MAP. By default settings, the folder is C:\Program Files\MAP.**

**When clicking on the [Next] button, necessary files are copied, and then installation is completed.**

#### ● Setting up MAP

As a result of executing the MAP setup program, two programs, "MAP Setup" and "MAP" are installed. The MAP Setup is a program to set up a necessary environment for MAP which identifies the network interface cards. To use the MAP, it is necessary to execute the MAP Setup program first.

To start the MAP Setup program, select [Start]-->[Program]-->[Map]-->[MAP Setup]. When the program starts, the following display will appear.



At the MAP Setup stage, you need to specify protocols used by the network interface cards and a maximum IP hop number. To do this, indicate check-mark next to [Search for IPX based printers] for IPX-based network interface cards, and [Search for IP based printers] for IP-based network interface cards.

When using an IP protocol, specify [MAX Hops for IP Search], in which case you can select a number between 0 and 15. The default number is set to 2. If you select 0, only segments pertaining to computers, which restart the MAP, are found. If you select 2, all networks which are accessible passing through two or less routers are found.


### MEMO

Note that selecting a large number can result in the occurrence of a large volume of traffics at one time.

## ● Starting MAP

To start the MAP, select [Start]-->[Program]-->[Map]-->[MAP].

Once started, MAP searches for the network interface cards existing on the networks according to the MAP setup. When identifying the network interface card, MAP starts a Web Browser specified as standard, and displays a list of available network interface cards. By default, the network interface card is named "OCE\_(serial number)." When you select a desired network interface card from the list, the [Main Page] of Web Utilities is displayed.




### ■ Using Web Utilities

You can use the MAP or specify IP addresses of the network interface cards in a Web Browser to access Web Utilities.

#### ● Network Setup

The Web Utilities allows you to check selected options and change specific settings. The following descriptions explain the function of each item.



---

#### MEMO

---

When settings are changed the print controller must be restarted to reset (restart) the network interface card.

If the print controller is built in the main body printer, it is necessary to turn OFF/ON the main body printer.

---

#### [System]

##### Reset

Resets the network interface card to make newly setup parameters effective but does not reset the main body printer and the print controller. To reset the main body printer and print controller, turn off each main power supply, then turn it back on.

##### Factory Defaults

Switches all settings on the network interface card back to their factory default (or initial) values. When operating a printer in a new environment use this feature to clear all setting values except the serial number and MAC address of the network interface card.

### Unit Status

Displays the status of a protocol effective on a selected network interface card. In the uppermost line, the corresponding protocol (NetWare, TCP/IP or AppleTalk) is displayed whether that protocol is currently enabled or not. You can change settings using [Setup NetWare], [SetupTCP/IP] and [Setup AppleTalk] in the protocols group.

### Network Address

Displays the serial number and MAC address of the selected network interface card.

### Change Password

Allows you to set up or change a password. To change the current password, type it in the [Old Password] Input field, type a new password in the [New Password] Input field, and then type the same new password in the [Retype New Password] field, for confirmation. Finally, click on [Accept Settings] to make the new password effective.

## [Protocols]

### Setup NetWare

For each of the following setup items selected, you can click [Accept Settings] to continue the process, or you can click on [Clear Inputs] to cancel the setup process.

Keep in mind that a valid password is required after you can enter data or change settings on the screen. The default password is [sysadm]. To make new settings effective, be sure to reset the network interface card.

### Enable NetWare

When this box is checked, Novell NetWare (IPX/SPX) is enabled as a protocol for print servers. For print servers on which NetWare is not a primary protocol, be sure to uncheck this box to disable NetWare. This box is unchecked in the default setting.

### Print Server Name

Each Novell print server has its own name, as assigned. For the print server (network interface card), a default name, OCE\_(serial number), is used. The serial number is shown in the Status Page as well as on the label affixed to the back of the network interface card.

If you want to use a name other than the default name or if you want to change the currently assigned name, you can type a new print server name into this field. 63 characters can be typed in half size. It is imperative that the name be identically changed on PCONSOLE as well. Otherwise, your newly entered name will be ineffective.

### Print Server Password

The network administrator assigns passwords to Novell print servers. When passwords are assigned with PCONSOLE or NWADMIN, those passwords should be set up on the print servers. In Bindery mode, only upper case passwords can be used.

When typing a password into this field, it must be identical to the password assigned through PCONSOLE or NWADMIN. The typed password is stored in print server setup memory. For assigning passwords using PCONSOLE, refer to the Novell manual.

When setting up a print server password, type a password into the [Print Server Password] field, and then again type the same password into the [Password Retype] field for confirmation. This password is common to all file servers assigned to the print server.

Clicking the [Accept Settings] button will have no effect unless you type one and the same password both in the [Print Server Password] and [Password Retype] fields.

### Retype Password

Type a password here, for confirmation.

### Preferred File Server

Type a primary file server name in this field to designate a particular file server for your print server to access. This feature allows you to access a desired file server and avoid accessing an undesired file server as when the system is set to search for a file server.

### Preferred NDS Context

If you are using Novell NetWare 4.x Directory Services, type a preferred NDS context here. The preferred NDS context needs to be a complete context name. Do not type a period (".") in the front of the context pass. You do not need to type a container name (print server name) since it is in the name field above. Here are examples of contexts with type:

Complete Context  
o=standard.ou=organization\_1

Or Simple Context  
standard.organization\_1

For further details, check with the system administrator.

### Preferred NDS Tree

If you are using Novell NetWare 4.x Directory Services, type a preferred NDS tree in this field. If you do not know the preferred NDS tree, type WHOAMI from the MS-DOS command line, then press [Enter] for confirmation.

### **Print Queue Scan Rate**

This option lets you select a queue scan rate for adjusting intervals at which the print server (network interface card) poles the networks when searching for new print queue. You can type a number between 1 and 255 (seconds).

### **Ethernet Frame Type**

This option lets you select a frame type appropriate to networks in use. To select [Auto Sense] is to let a proper frame type be automatically selected. To do this, you can either click on the radio button corresponding to the frame type in use or click on [Auto Sense].

### **Disable Bindery**

Bindery Services of Novell NetWare 4.x or greater are disabled when this box is checked and enabled when this box is not checked. When Bindery is disabled, print servers connected to the Bindery file server are not supported.

## **Setup TCP/IP**

For each of the following items selected, click [Accept Settings] to continue the setup process, or click on [Clear Inputs] to cancel the process.

Keep in mind that a valid password is required after you can enter data or change settings on the screen. The default password is [sysadm]. To make new settings effective, be sure to reset the network interface card.

### **IP Address**

Type an IP address of the print server if it is not in the IP address list on the screen. Check the address with the system administrator. The default setting is set to 0.0.0.0, which means no IP address is set up. This does not mean the IP address is set to 0s.

### **Subnet Mask**

Type a subnet mask of the print server if it is not in the list on the screen.

### **Default Gateway**

Type a gateway IP address if necessary. Otherwise you can leave this blank.

### **Domain Name Server**

Type a Domain Name Server IP address if necessary. Otherwise, you can leave this blank.

### **Base Port Number**

You do not need to type anything in this field. All values input will be disabled.

## Chapter 2 Setting Up the Network Interface Card

---

### Enable DHCP

Checking this box allows the network interface card to automatically obtain an IP address from the DHCP server. When you check DHCP, you either need to assign the IP address to 0.0.0.0 or uncheck IP Address in NVRAM.

### IP Address in NVRAM

Check this box to enable the network interface card to store its IP address in NVRAM (non-volatile memory).

### Enable LPD Banner

Checking this box lets the main body printer print out LPD Banner page for each print job only for the LPD/LPR printing.

### Printer Language

Check the box corresponding to the desired printer language.

This lets the resident lpd/lpr modify files intended for other emulations so they can be printed. The menu also allows you to enable or disable banners attached to **lpd/lpr** handled jobs.

The emulation choices are:

- Printer Control Language (PCL)
- PostScript (PS)
- ASCII (simple text)
- Other (any print job not recognized as PCL, PS, or ASCII)

The file modifications and conditions are:

Print Server Setup	Job detected as	Action
PCL, (PostScript)	ASCII	<CR> changed to <CR><LF>
PostScript	PCL, Other	PostScript header added
not PostScript	PostScript	Job discarded
PostScript	ASCII	PostScript header added, <CR> changed to <CR><LF>
PCL, PS, ASCII	any	No action

### Setup AppleTalk

For each of the following items selected, click [Accept Settings] to continue with the setup process, or click [Clear Inputs] to cancel the setup process.

To make new settings effective, be sure to reset the network interface card (restart the print controller and the main body printer) after typing a password and clicking a designated button. A default password is [sysadm].

### Enable AppleTalk

This check box for AppleTalk toggles of the network interface card between disabled and enabled. Check this box to enable AppleTalk.

### Printer Name

This is a printer (network interface card) name used on the AppleTalk network. A default name is OCE\_(serial number).

### Zone Name

Shows a zone in which the network interface card resides. Leave this blank if no zone is created as when using networks that have no seed routers. Printing will not start unless the zone name is designated correctly.

## [Others]

### Test Print

Click on [Start Test] to run a printer test. This required a previously entered password. The default password is [sysadm].

### Configure Status Page

This determines whether or not to output a Status Page (network setup list) when the network interface card has started up. By default, the list is output. After changing this option, you can type a password and click [Accept Settings], thereby enabling the new setting enabled. You can also print out the Status Page by clicking Generate Now button after typing the password. The default password is [sysadm].

---

**MEMO**

---

When printing the Test Print page or the Status Page, make sure to select the appropriate printer language for your current environment.

---

### Printer Status

Displays print controller status.

## Chapter 3 Windows 95/98/Me Configuration (Peer-to-Peer Printing)

■ Using IP Peer-to-Peer .....	3-2
● Basic TCP/IP setup .....	3-2
● Installation of IP Peer-to-Peer .....	3-2
● IP Peer-to-Peer setup .....	3-3
● Setting up printer driver .....	3-5
■ Using IPX Peer-to-Peer .....	3-6
● Introduction and preparation .....	3-6
● Installation of IPX Peer-to-Peer .....	3-7
● IPX Peer-to-Peer setup .....	3-8

This printing system employs peer-to-peer printing, a method which sends the print job directly to the print controller from the Windows 95/98/Me compliant computer, not through the dedicated print server.

### ■ Using IP Peer-to-Peer

As peer-to-peer printing uses the network protocol TCP/IP, the network interface card must be set up for TCP/IP in advance. For each of the Windows 95/98/Me computers that perform peer-to-peer printing, it is necessary to set up TCP/IP, install and set up [IP-P2P] included in the CD-ROM provided, and set up the printer driver.

#### ● Basic TCP/IP setup

Select [Network] from the [Control Panel] of a Windows 95/98/Me computer that uses the main body printer via the network interface card to display the [Network] dialog box. Click the [Configuration] tab and make sure that [TCP/IP] exists in the list of [Current Network Components]. If it is not found, add TCP/IP. See Windows 95/98/Me Help or some other means to add TCP/IP.

When [TCP/IP] exists in the [Current Network Components] list, confirm the accuracy of the values of the IP address, etc. Select [TCP/IP] and click the [Properties] button. The [TCP/IP Properties] dialog box appears. Click the [IP Address] tab and confirm or define the TCP/IP address and subnet mask assigned to the computer. Continue the setup procedure on another screen as necessary. Click the [OK] button to return to the Network dialog box.



#### **Take care to determine the values of parameters.**

Consult the network administrator to determine the values of parameters for the IP address. If the IP address is inadequate, failures may occur in various locations in the network.

---

#### ● Installation of IP Peer-to-Peer

To install the IP-Peer-to-Peer, double click [Setup.exe] in the [IP-P2P] folder of the accompanying CD-ROM. The installer will start up. Install the program according to the instructions displayed on the screen. The [IP Peer-to-Peer Setup] dialog box will appear while installation is still in progress. Set up the necessary items shown in the next paragraph.



When uninstalling the IP-Peer-to-Peer, perform the following procedure.

1. Change the printer port or delete the printing system using IP-Peer-to-Peer from the [Printer] folder.
  2. Delete the [IP-P2P] by using [Add/Delete Applications] from the [Control Panel].
-


### ● IP Peer-to-Peer setup

You can set up the IP Peer-to-Peer while installation is in process.

To change the setting, select [Start] --> [Programs] --> [Ip-p2p] --> [IP-P2P] to start up IP Peer-to-Peer.

#### Setting IP Peer-to-Peer

1. Once IP Peer-to-Peer begins the [IP-Peer To Peer Setup] dialog box appear to enable you to set up the [Max Hops for], [IP Port], and [Printer Names] of the printing system.



#### Max Hops for

IP Peer-to-Peer broadcasts a search for the network interface card on the network.

The default of Max Hops for (0-15) is 2. When the value is set to 0, a search will be exercised only in the segment in which the computer with an activated IP Peer-to-Peer belongs. When the value is 2, up to two network routers will be searched everywhere accessible via up to two routers. Note that the greater the value of Maximum Hop Count, the more traffics generated.

#### IP Port


Currently you do not need to type anything in this field.

#### Printer Names

Designate the network interface card name indicated when you selected the printer port during the printer driver setup. You may use the serial number of the network interface card, IP address, DNS name, or any unit name as the network interface card name.

To change the currently assigned printer name, restart Windows. Then execute the IP Peer-to-Peer again to set up the network interface card for printing via IP Peer-to-Peer. The [Printer] dialog box can be displayed by clicking the [Printer...] button.

2. Click [Printers...] button to display the [Printers] dialog box. Set up the network interface card to print by using the IP Peer-to-Peer. You can search the list available network interface card and manually add or remove network interface cards to the Windows Port Listing.



The following options are available on this screen:

**OK:**

Accepts all changes made to setup and exits to the previous screen.

**Cancel:**

Discards any changes made to setup and exits to the previous screen.

**Add:**

Allows a user to manually add a printer to the [Available Printers] list by inputting the information in the fields to the left of the buttons. By Adding a printer to the list in this manner, the user bypasses the [Search] function. The port is not checked to see if it is actually available on the network.

• **IP Address:**

Enter the IP address of the printer you wish to add to the list manually.

• **Name:**

Enter the name you wish the printer to be listed by in the [Unit Name] field.

• **Port:**

Enter the actual port for communicating with the printer. This defaults to 10001.

• **Description:**

Enter the description you wish listed in the [Description] field for the printer.

**Delete:**

Deletes the highlighted printer(s) from the [Available Printers] list below. Printers deleted in this fashion will no longer be listed in the [PORT] listing when adding a printer. However, This does not actually delete the printer from the network, it only removes it from the list maintained on this computer.

The printer may be re-added to the list by selecting the [Find Printers] button (described below) as long as it remains connected to the network.

**Find Printers:**

Initiates a search routine out to the network. This routine will then list all printers found on the network by the method defined in the previous setup screen. The default method for displaying the list of printers is by IP Address.

**Clear:**

Clears the [Available Printers] list below. This will not clear any printer marked with the [Permanent] flag.

**Select:**

Flags the highlighted printer(s) with the [S] flag. Only 30 printers may be selected at one time. When displaying the [PORT] list during the process of adding or changing a printer, only Selected printers will be displayed.

**Permanent:**

Flags the highlighted printer(s) with the [P] flag. Any printer marked with this flag will not be removed from the [Available Printers] list, even if the printer is physically removed from the network or the [Clear List] button is selected (described above)

**Available Printers:**

List of printers that was detected on the network. This list can be cleared using the [Clear List] button (described above) and this list can be updated or refilled using the [Find Printers] button (described above). Printers in this list are described with three fields:

**• Unit Name:**

Printer Name method defined in the previous screen. The default Printer Name method is by IP address. Printers may also be displayed by the NIC Serial Number, by the DNS Name of the printer, or by the Unit Name. The Unit Name is the [Print Server Name] defined in the NIC.

**• Unit IP:**

Actual IP address of the unit. This is displayed regardless of which Unit Name method is selected.

**• Port Number:**

Currently you do not need to type anything in this field.

**• Description:**

Printer's description. This field usually contains the manufacturer's name and the printer's model.

**• Flags:**

[S], selected or [P], permanent. Any printers marked with an [S] flag will be displayed in the Window's Port Listing. When displaying the Windows port list during the process of adding or changing a printer, only Selected printers will be displayed. Only 30 printers may be selected at one time.

Any printer marked with a [P] flag will not be removed from the [Available Printers] list, even if the printer is physically removed from the network or the [Clear List] button is selected.

3. **Click [OK] when all settings are completed. All setting values are stored when you return to the [IP-Peer to Peer Setup] dialog . If you click the [Cancel] button before clicking [OK], the changed values will not be saved.**

### ● Setting up printer driver

When all settings are completed, install the printer driver. In case of using the IP Peer-to-Peer, specify the connection type as [Local], and the printer name set in the IP-Peer-to-Peer to the [Printer Port].

For more information on installation and setting of the printer driver, refer to the Océ User's Guide designed for your specific print controller model.

### ■ Using IPX Peer-to-Peer

Windows Peer-to-Peer printing allows Windows 95/98/Me computers to print to the printing system without an intervening server and without using IP. The main features of the Windows IPX Peer-to-Peer printing are as follows:

- Runs on Windows 95/98/Me "out of the box".
- Runs on networks that do not have a NetWare file server, as well as those that do.
- Implements IPX peer-to-peer bi-directional printing between Windows PCs and the printing system.

### ● Introduction and preparation

The Peer-to-Peer implementation uses the IPX/SPX stacks that are provided with Windows 95/98/Me. The IPX Peer-to-Peer provided will establish a connection with the printers supporting IPX Peer-to-Peer, without using an intermediate file server, whether or not your network uses Novell NetWare.

When configuring the network capabilities for the Windows computer, you must include the [IPX/SPX Compatible Protocol]. If you are not using NetWare, you do not need to activate any NetWare Client application.

This inclusion of IPX/SPX can also be done after initial Windows installation by going to the [Network] setup function under [Control Panel]. To do this, you will need the Windows CD.

---

#### MEMO

---

Because Peer-to-Peer uses the IPX/SPX Protocol, Novell operation must remain enabled on the network interface card, even if traditional Novell printing facilities are not being used. The name of the Peer-to-Peer printer, as it appears in the Windows Port List, is the same as the Novell Print Server name, and may be changed by changing the Novell Print Server name using the Web Utility or MAP utility.

---

On power up, the network interface card checks the network to see if there is Novell activity. If there is, it will use the same frame type and the local network number that it senses. If, in addition, the network interface card can log on to a file server, it will assume that Novell is normally used and will store this frame type and new number in NVRAM so that, when it comes up again, it will not have to spend the time sensing (which can take some time).

However, if the network interface card cannot attach to a file server, it will use the sensed values, but will not store them.

If the network interface card does not see any Novell activity, it will use 802.2 on 802.3 as a frame type and will assign itself a network number of 0. The frame type and network number being used is reported on the Status Page.

If a network interface card is being moved from a site that had active Novell to a site that does not, the unit should be reset to factory default to clear the frame type and network number information.

## ● Installation of IPX Peer-to-Peer

To install the IPX Peer-to-Peer, perform the following procedure:

1. **Insert the CD-ROM that came with the network interface card into the CD-ROM drive.**
2. **From the Windows main window, click on [Start].**
3. **Click on [Run].**
4. **From [Run], type <CDROM drive>:\NetUtil\IPX-P2P\SETUP.EXE.**
5. **Click on [OK].**
6. **At the [IPX Peer-to-Peer Setup] screen, click on [Next].**

---

### MEMO

---

If setup detected a previous installation of the IPX Peer-to-Peer, it will prompt you to have Setup delete the old driver and continue the installation procedure. Click on [Yes] or [No]. Once the IPX Peer-to-Peer is installed, each printer on the network that supports this peer-to-peer capability will appear as a [Port] under [Printer Properties].

To use the Peer-to-Peer connection, create a logical printer using the [Add Printer Wizard] according to the instructions for the print controller. Set up the printer as a [LOCAL] printer. Use the driver that came with the print controller. When the [Add Printer Wizard] asks you to choose the [Port], select the name of the Peer-to-Peer printer you wish to print to. When you complete the installation, select the [Print Test Page] option.

---



When uninstalling the IPX Peer-to-Peer, perform the following procedure.


1. Delete the printer using IPX Peer-to-Peer from the [Printer] folder.
  2. Delete the [IPX-P2P] by using [Add/Delete Applications] from [Control Panel].
-

### ● IPX Peer-to-Peer setup

IPX Peer-to-Peer printing allows you to print to a network printer for networks without a file server or for networks where you do not want to use the network interface card for printing.

Use peer-to-peer printing on Windows 95/98/Me systems. Click on the [IPX-P2P] menu item in Windows to bring up the [IPX Setup] screen.

An explanation for each field on the screen is described below:



**OK:**

Accepts changes made to setup and exits the program.

**Cancel:**

Discards any changes made to setup and exits the program.

**Clear:**

Clears the [Available Printers] list below. This will not clear any printer marked with the [Permanent] flag.

**Delete:**

Deletes the highlighted printer(s) from the [Available Printers] list below. Printers deleted in this fashion will no longer be listed in the [PORT] listing when adding a printer.

However, this does not actually delete the printer from the network, it only removes it from the list maintained on this computer. The printer may be re-added to the list by selecting the [Find Printers] button (described below) as long as it remains connected to the network.

**Permanent:**

Flags the highlighted printer(s) with the [P] flag. Any printer marked with this flag will not be removed from the [Available Printers] list, even if the printer is physically removed from the network or the [Clear List] button is selected (described above).

**Find Printers:**

Initiates a search routine out to the network. This routine will then list all printers found on the network by their print server name (defined in the printer). The default Print Server Name for a printer is a three letter identifier and the six digit serial number of the network interface card (e.g., OCE\_(serial number)).

**Select:**

Flags the highlighted printer(s) with the "S" flag. Only 30 printers may be selected at one time. When displaying the [PORT] list during the process of adding or changing a printer, only [Selected] printers will be displayed.

**Available Printers:**

List of printers that was detected on the network. This list can be cleared using the [Clear List] button (described above) and this list can be updated or refilled using the [Find Printers] button (described above). Printers in this list are described with three fields:

- **Unit Name:**

This is the print server name defined in the printing system. The default print server name for a printing system is a three letter identifier and the six digit serial number of the network interface card (e.g., OCE\_(serial number)).

- **Description:**

Printer's description. This field usually contains the manufacturer's name and the printer's model.

- **Flags:**

[S], selected or [P], permanent. Any printers marked with an [S] flag will be displayed in the [Window's Port] Listing. When displaying the Windows port list during the process of adding or changing a printer, only [Selected] printers will be displayed. Only 30 printers may be selected at one time.

Any printer marked with a [P] flag will not be removed from the [Available Printers] list, even if the printer is physically removed from the network or the [Clear List] button is selected.

### Add Printers for IPX Peer-To-Peer Printing

You can add printers manually whenever the program cannot find printers automatically because of router setup or hop count setting. In general, this should not be necessary:

#### Step 1: Use IPX-P2P to Add Printers

1. **Click on the IPX-P2P menu item in Windows. The IPX Peer-to-Peer Setup screen appears.**
2. **A list of available IPX-enabled printers is displayed after a brief pause while the program searched the network.**
3. **Highlight the printer(s) you wish to have displayed in the Windows Printer Port listing and click "Select". This will ensure these the printers are included in the Windows Printer Port listing. You may have a maximum of 30 printers selected at any one time.**
4. **Click OK when you have finished selecting all the printers you wish to have displayed in the Windows Printer Port list.**

#### Step 2: Use the Add Printers option in Windows.

1. **Click on the Add Printer button.**
2. **Select Local Printer from the menu.**
3. **Select the make and model of the printer you want to use. A list of printer ports appears. Any IPX peer-to-peer printers that have been selected from IPX-P2P Setup will appear in this list.**
4. **Select the IPX printer you want to use.**
5. **Complete the remainder of the printer setup procedure as you would normally.**

---

### MEMO

---

You may change the printer driver setting at a later time by doing the following:

1. Right click on the printer driver icon and select properties.
  2. Select the Details tab (it may take up to 15 seconds to access).
  3. Click on the arrow in the box labeled Print to the Following Port.
  4. Select the printer address you wish to use.
  5. Click OK.
-

## Chapter 4 Windows NT/2000 Configuration (LPD/LPR Printing)

■ LPD/LPR setup .....	4-2
● Adding a printer port on Windows NT .....	4-2
● Creating a printer port on Windows 2000 .....	4-3

The network interface card is equipped with the standard print server protocol (LPD: Line Printer Daemon) for TCP/IP, which enables you to use network printing service for TCP/IP (LPR: Line Printer Remote) from Windows NT 4.0 (Service Pack 3 or later) or Windows 2000 computers to print.

To use the TCP/IP network protocol for LPD/LPR printing, the network interface card must be set up for TCP/IP in advance.



Confirm that TCP/IP is set up correctly on the Windows NT/2000 computer using the main body printer via the network interface card before setting up the print controller. For TCP/IP setting refer to Windows NT/2000 on-line help, etc.

---

### ■ LPD/LPR setup

#### ● Adding a printer port on Windows NT

To print by LPD/LPR from Windows NT computer, add a printer port and install the printer driver on Windows NT.

##### Before doing

Confirm the following settings to be completed:

- TCP/IP setting to each Windows NT computer
- Installation of [Microsoft TCP/IP Printing]

---

#### MEMO

---

##### Installation of [Microsoft TCP/IP Printing]

Select [Network] from the [Control Panel] of Windows NT 4.0 to display the [Network] dialog box. Click the [Service] tab and make sure that [Microsoft TCP/IP Printing] exists in the list of [Network Services].

If it is not found, add it. For details, see Windows NT on-line help, etc.

To add a various services to Windows NT, the CD-ROM for setting up Windows is required.

---

##### Adding a printer port

To add a printer port perform the following procedure. The accompanying CD-ROM containing the printer driver must be prepared:

1. Click the [Start] button and select [Printers] from [Settings].
2. Double-click [Add Printer] to activate [Add Printer Wizard].
3. Select [My Computer] and then click [Next].
4. Click the [Add Port] button.
5. Select [LPR Port] from [Available Printer Ports] in the [Printer Port] dialog box. Click the [New Port] button.

6. Type the IP address assigned to the network interface card for [Name or address of server providing lpd] in the [Add LPR compatible printer] dialog box.
7. Type [PORT1](upper case) for [Name of printer or print queue on that server], and click the [OK] button.
8. In the list of available ports, put a checkmark next to the LPR port you created and click [Next].
9. You come to the step of installing the printer driver. Follow the wizard information.

For more details on printer driver installation, refer to the Océ User's Guide designed for your specific print controller model.

## ● Creating a printer port on Windows 2000

To print by LPD/LPR from Windows 2000 computer, create a printer port and install the printer driver on Windows 2000.

### Before doing

Confirm the following settings to be completed:

- TCP/IP setting to each Windows 2000 computer
- Installation of [Print Services for Unix]

---

### MEMO

---

#### Installation of [Print Services for Unix]

Select [Network and Dialup Connections] from the [Control Panel] of Windows 2000 to display the [Network and Dialup Connections] dialog box. Then select the [Optional Networking Components] in the [Advanced] menu to indicate the [Optional Components Wizard].

Select the [Other Network File and Print Services] and then click the [Details] button to display the [Other Network File and Print Services] dialog box. Make sure that the [Print Services for Unix] is checked.

If it is not checked, add it. For how to add the [Print Services for Unix], see Windows 2000 on-line help, etc.

To add a various services to Windows 2000, the CD-ROM for setting up Windows is required.

---

### Creating a printer port

To add a printer port perform the following procedure. The accompanying CD-ROM containing the printer driver must be prepared:

1. Click the [Start] button and select [Printers] from [Settings].
2. Double-click [Add Printer] to activate [Add Printer Wizard].
3. Click [Next].
4. Select [Local] and click [Next].

Check [Search for the best driver for your device] off.

5. **Select [Create a new Port] and then choose [LPR Port] from [Type]. Click the [Next] button.**
6. **Type the IP address assigned to the network interface card for [Name or address of server providing lpd] in the [Add LPR compatible printer] dialog box.**
7. **Type [PORT1](upper case) for [Name of printer or print queue on that server], and click the [OK] button.**
8. **You come to the step of installing the printer driver. Follow the wizard information.**

For more details on printer driver installation, refer to the Océ User's Guide designed for your specific print controller model.

## Chapter 5 UNIX Configuration

■ UNIX printing through TCP/IP .....	5-2
● Introduction .....	5-2
● Printing overview .....	5-3
● Configuring IP address to the network interface card .....	5-4
● lpd UNIX printing .....	5-5

## ■ UNIX printing through TCP/IP

### ● Introduction

This section explains how to configure the network interface card and your network for use with TCP/IP communication in various UNIX environments. Independent setup and installation procedures are provided for most popular UNIX systems.

The TCP/IP capability of the network interface card will also operate with lpr spoolers on other systems, and with spooler/supervisor capabilities that communicate raw print jobs to the TCP/IP port of the network interface card. This port number is 10001.

---

---

#### MEMO

---

---

SNMP (Simple Network Management Protocol) is a protocol for network management services. SNMP is supported for Management Information Base (MIB) II over the IP for the network interface card. This support allows you to query MIB II to get system information about the network interface card.

---

---

The network interface card can support UNIX TCP/IP printing in two modes:

- Host-based where a supplied line printer daemon is run on one or more workstations and print data is communicated to the network interface card via a TCP/IP port.
- Printer-based lpd where the print controller appears as a host running a line printer daemon.

Many operating systems provide the option of using host-resident printing or printer-resident printing.

In general, printer-based lpd is easier to use on BSD UNIX systems. This requires an entry in the printcap file once the network interface card has its IP information. Some UNIX System V systems have restrictions on support of remote lpd printers, requiring that the host-based lpd approach be used.

Each printing mode has certain advantages over the other mode, as follows:

- The host-resident method can print the username and filename on its banner page; whereas the printer-resident method prints a banner page with the host's name.
- The printer-resident method requires you to configure the print controller and the network interface card only one time, when you install the network interface card; whereas, the host-resident method requires that a printing daemon be installed on every host that you want to be able to print jobs.

---

---

#### MEMO

---

---

The network interface card will also operate with other host-resident print supervisor/spooler programs that present a print image to the print controller over a TCP/IP port.

---

---

● **Printing overview**

Considering both the host-based and printer-based TCP/IP printing capabilities, the network interface card works with the following systems:

- All UNIX systems that support lpd
- System V Rel. 4 (on 386 platforms)
- DEC ULTRIX RISC Versions 4.3 and 4.4
- DEC OSF/1 Versions 2.0 and 3.0
- Solaris:  
Version 1.1.3 (SunOS 4.1.3),  
Version 2.3 (SunOS 5.3),  
Version 2.4, and  
Version 2
- HP-UX Series 700 and 800 Version 9.01 and Version 10
- IBM AIX Version 3.2.5 and Version 4.0
- SCO UNIX Version 3.2
- AS400

---

---

**MEMO**

If the systems you are using do not run lpd, refer to “Installing UNIX TCP-IP programs, Information for the TCP/IP network administrator, in Appendix”

---

---

---

---

**MEMO**

The UNIX-TCP/IP Programs on accompanying CD-ROM also includes source code so that you can recompose host-based code for configuring on other System V platforms.

---

---

### ● Configuring IP address to the network interface card

Regardless of the printing mode selected, the network interface card must be given the IP address and routing parameters. You can configure the IP address for the network interface card in one of the following ways:

- Use DHCP (Dynamic Host Configuration Protocol).  
See “Using DHCP, Information for the TCP/IP network administrator, in Appendix”.
- Use arp and ping capability.  
See “Assigning IP Address, General Description of the Network Setup, in Chapter 2 Setting Up the Network Interface Card”.
- Use BOOTP (Internet Boot Protocol).  
See “Using BOOTP to assign IP address, Information for the TCP/IP network administrator, in Appendix”.
- Use reverse ARP (rarp) capability (Ethernet II frame type only).  
See “Using rarp to assign IP address, Information for the TCP/IP network administrator, in Appendix”.
- Use arp command, MAP(Management Access Program), or BOOTP Lite for Windows.  
See “Assigning IP Address, General Description of the Network Setup, in Chapter 2 Setting Up the Network Interface Card”.
- Use NIManage for Macintosh.  
See “ Chapter 7 AppleTalk Configuration”.

---

#### MEMO

---

You can use the BOOTP, rarp, or arp and ping procedures only when the network interface card is in its default state (when no IP information has been entered).

---

Depending on the topology, you need to provide the MAC address of the network interface card. The MAC address is the 12-character code that is printed on the Status Page each time the print controller and the main body printer is turned on.

After the network interface card has an IP address, you must use the MAP utility, or other dedicated utilities (for Windows or Macintosh) to change an IP address, Subnet Mask and Default Gateway.

## ● lpd UNIX Printing

**lpd** is an implementation of the standard UNIX line printer daemon that lets you print across a TCP/IP network without the need to install software on your workstation, with all filtering and banners done by the network interface card.

Remote printing uses the same commands (**lpr**, **lpq**, **lpc**) as local printing.

The process begins when the **lpr** call finds the printer on a remote system by looking at the remote (**rm**) entry in the `/etc/printcap` file for that printer.

**lpr** handles a print job for a remote printer by opening a connection with the **lpd** process on the remote system and sending the data file (followed by the control file containing control information for this job) to the remote system.

The printer-based **lpd** then filters the data and prints the job according to information contained in the control file and its own `printcap` file.

The network interface card **lpd** recognizes the format of a certain printer emulation and filters the data, if possible, so it can be printed on the printer you specify.

You can indicate to the network interface card **lpd** what type of print controller it is attached to by either:

- Accepting the default port setting (PCL, PostScript and other), or
- Changing the listed emulations via a standard IP based Web Browser.

The sections that follow give specific **lpd** setup instructions for various systems.

### Setting Up a BSD Remote Printer to Use lpd

To set up a remote printer on the host that sends jobs to the network interface card using printer resident **lpd**, add an entry to the `/etc/printcap` file on your host for each printer you use. Perform the following procedure:

1. **Open the `/etc/printcap` file. Make an entry naming the network interface card as the remote host and `PORT1` as the remote printer name. A typical `printcap` entry is as follows:**

```
<printer_name>\ (for example, lprprinter)
:lp=:\
:rm=<remote_host>:\ (
for example, name as entered in /etc/hosts)
:rp=PORT1:\
:sd=/usr/spool/lpd/<printer_name>:
(for example, spool directory on system used to spool
data and control files)
```

**This entry will send jobs spooled at `/usr/spool/lpd/<printer_name>` to the printer designated `<printer_name>` to be printed at port 1 (the internal connection to the printer) of the network interface card designated as `<remote_host>`.**

2. **Create the spooling directory. For example, type:**

```
mkdir /usr/spool/lpd/<printer_name>
```
3. **To print via the spooler, use the `lpr` command. Type:**

```
lpr-P <printer_name> <file_name>
```

**Installation and testing are done. You are now ready to print.**

### Setting Up an AIX Remote Printer to Use lpd

Use the following procedure to set up a remote printer on the host that sends jobs to the network interface card using the lpd of the network interface card.

1. **At the prompt, type:**  

```
#smit spooler <cr>
```
2. **When a window appears, select Manage Remote Printers.**
3. **When a menu appears, select Client Services.**
4. **Another menu appears, select Remote Printer Queues.**
5. **Another menu appears, select Add a Remote Queue.**
6. **When a window appears, change the values shown to configure the network interface card.**

The values displayed are default values. You must replace the short and long form filter values with the values shown in the following table.

Data Requested	Example	Data Description
Name of queue to add	print1	Name of local printer
queue Destination Host	printfast	NIC IP hostname
Short Form Filter	/usr/lpd/bsdshort	Required value
Long Form Filter	/usr/lpd/bsdlong	Required value
Name of remote printer queue	PORT1	Network interface card
Name of device to add	print1	Name of local queue

7. **After you have supplied all values, press Enter.**

You can now print.

### Setting Up an AIX 4.0 System

Use these procedures to install the network interface card in a AIX 4.0 system:

1. **Run SMIT Printer.**
2. **Select Print Spooling.**
3. **Select Add a Print Queue.**
4. **Select Remote.**
5. **Use Standard Processing.**
6. **Assign a queue name.**
7. **Use the host address of the Océ Print Server for the Remote System.**
8. **Use PORT1 for the queue on the remote system.**
9. **Add a description (optional).**
10. **Press Enter to generate.**

Installation is complete.

Test your printer by executing the following command:

```
lp -d<queue_name> <file_name>
```

### Setting Up an HP/UX Remote Printer to Use lpd

Set up a remote printer on the host that sends jobs to the network interface card using the lpd of the network interface card. To do this:

1. **At the prompt, type:**

```
    sam
```

2. **When a window appears, select Printer/Plotter Manager.**
3. **When the menu appears, select List printer and plotters.**
4. **When a list appears, select Actions in the title bar.**
5. **From the pull-down menu, select Add Remote Printer.**
6. **When a window appears, add values to configure the network interface card. See example below.**

Data Requested	Example	Description of Input Data
Printer Name	myprinter	name to be used in lp command
Remote System Name	fastprint	Print Server hostname as in /etc/hosts
Remote printer Name	PORT1	lpd queue name

7. **At the bottom of the screen, select Remote Printer is on BSD system from the three choices available.**
8. **Click on the OK button.**
9. **Ping the unit to test communications. Type:**

```
    ping <IP address of the network interface card>
```
10. **Ping should confirm your IP address with the message:**

```
    <IP address of the network interface card> is alive
```
11. **If the connection is confirmed, you can now print.**

### Setting Up an AS/400 System to Use lpd

When working with the output queue description (WORKOUTQD), there are several fields that must be defined for the network interface card to function properly as a remote printer device.

Use the following procedure to define fields for the network interface card to make it function as a remote printer:

1. **When prompted for the remote system, type INTNETADR so the AS/400 recognizes the device as an IP device.**
2. **Type:**

```
    PORT1
```
3. **Connection type must be IP.**
4. **Internet address must be the IP address of the network interface card.**
5. **Destination type must be OTHER.**
6. **When prompted for transforming SCS to ASCII, type YES to allow the AS/400 do the character translation.**
7. **Manufacturer type and model must be the print driver that goes with your print controller.**

### Setting Up a DEC ULTRIX 4.3 RISC or OSF1/ALPHA Remote Printer

Use the following procedure to set up a remote printer on the host that sends jobs to the network interface card.

1. At the prompt, type: `lprsetup`, then select `add`.
2. Enter a name for your printer, then press `Enter`.
3. "Do you want more information on specific printer types?" Press `Enter`.  
A list of ULTRIX-supported printers is listed.
4. Type: `remote`, and press `Enter`.
5. Enter a printer synonym (alias) and press `Enter`.
6. Designate a spooler directory and press `Enter`, or accept the default spooler directory displayed and press `Enter`.
7. Designate a remote system name and press `Enter`.
8. Designate `PORT1` as the remote system printer name and press `Enter`.
9. You are asked to enter the name of a printcap symbol from a displayed list. Type: `Q`, and press `Enter`.
10. Your configuration is displayed. You are asked whether these values are final. Type: `Y` or `N`, and press `Enter`. An example is shown below.

Printer #7	Symbol	Type	Representative Value
lp	(line printer)	STR	
rm	(remote host)	STR	Printer Server Card_host
rp	(remote printer)	STR	PORT1
sd	(spooler directory)	STR	/usr/spool/lpd7

11. Add comments to the printcap file. For example, you can type:  
`Lois' printer down the hall <Enter>`
12. Select `exit` to save your configuration, then press `Enter`.

You are now prepared to print.

### Setting Up a SCO UNIX Remote Printer to Use `lpd`

Use the following procedure to set up a remote printer on the host that sends jobs to the network interface card using `lpd`.

1. At the prompt, type: `mkdev rlp`  
You cannot run `mkdev rlp` twice. If you have other printers that need to be configured, use the `rlpconf` command.  
Respond to the series of questions as follows:
2. Do you want to install or remove a remote printer? Type: `I`
3. Do you want to change printer description file `/etc/printcap`? Type: `Y`
4. Write a printer name. For example, type: `lprprinter1`
5. Is `lprprinter1` a remote printer or a local printer? Type: `R`

6. Enter remote host name: type host name entered in printcap for Océ Print Server. For example, type: Lprprinter
7. Confirm the information you have entered. Type: Y
8. Confirm the preceding connection as your system default. Type: Y or N
9. Do you want to start the remote daemon now? Type: Y
10. Enter another printer name or quit setup. Type: Q
11. Using a line editor of your choice,  
 edit the /etc/printcap file by changing :rp= entry to :rp= PORT1. (See example below.)

```
printer1:\
:lp=:\ (used to specify device name for a local printer; field must be empty)
:rm=lprprinter:\ (remote machine name or network name of print server)
:rp=PORT1:\ (remote printer name or the name of the print server)
:sd=/usr/spool/lpd/printer1: (name of the spool directory on the client)
```

### Setting Up System V Release 4 and Solaris 2.X to Use lpd

If your system recognizes the LPSYSTEM command, you do not need to install the dedicated utility, Océ host-side software. Another option is the admintool if your system supports it.

- **LPSYSTEM Installation**

The following procedure must be executed from the Bourne Shell.

Type: **SH** then press Enter to enter the Bourne Shell program.

Use the following procedures to install LPSYSTEM:

1. **lpsystem -t bsd**

Print server host name in /etc/hosts file. Your system may want its IP address instead of the remote host name.

2. **lpadmin -p <local printername> -s <remote host name or IP address>!PORT1**

---

#### MEMO

---

1. There is no space between the remote host name and !PORT.
  2. Enable <local printername>
  3. Accept <local printername>
-

## Chapter 6 NetWare Configuration

- Setup with NWSetup ..... 6-2
  - How to install ..... 6-2
  - Using the NWSetup program ..... 6-3
- Setup for NetWare 3.x ..... 6-8
- Setup for NetWare 4.x ..... 6-9
  - Setup information ..... 6-9
  - NDS setup ..... 6-10
  - Setup for Bindery Emulation ..... 6-10

To print with the printing system equipped with the network interface card by using Novell NetWare, the setup procedures depend on the NetWare version and the method of resource management.

### ■ Setup with NWSetup

To use NWSetup program you must have IPX NetWare connection and the Novell 32-bit client installed. You must be logged in to the NetWare server with administrator access to use it.

NWSetup lets you set up the network interface card on Novell NetWare network using only one program from Windows 95/98/Me/NT/2000. This program combines the following configuration steps:

- Set up Novell file server and queue on the NetWare server, instead of using NetWare utilities.
- Set up the network interface card for network printing.

### ● How to install

To install NWSetup, perform the following procedure:

1. **Insert the CD-ROM into the CD-ROM drive, and double-click on [Setup.exe] in the [NWSETUP] folder.**
2. **A setup program will start. Confirm the display, and click on the [Next] button.**
3. **Confirm a folder to install NWSetup. By default, the folder is C:\Program Files\NWSETUP.**

**When clicking on the [Next] button, necessary files are copied, and then installation is completed.**

Or Install NWSetup directly from the CD-ROM as follows:

1. **Set the CD-ROM into your CD drive.**
2. **Select [RUN] from the Windows [Start] menu.**
3. **Type <CD-Drive>:\NWSETUP\SETUP.EXE**
4. **Follow the instructions in the SETUP program.**

---

#### MEMO

---

If you are configuring for NDS (Novell Directory Services), make sure you are logged into the correct tree and context before you initiate this program.

---

## ● Using the NWSetup program

### Select a Print Server

NWSetup displays a list of all print servers (network interface cards) available on your network after you start the program. The print server appears with its serial number. Once you select the print server you want to configure, the Print Server Settings screen appears. This screen lets you set up your version of NetWare for the print server.

### Setup Novell NetWare

The Print Server Settings are shown below. There are two Print Server Settings screens, which you need to complete to configure the print server for NetWare. Each screen lets you set up your version of NetWare for the print server, including directory and bindery services.

#### Enable NetWare Print Server

Indicates whether the NetWare print server has been enabled.

- If the box is not checked, the print server has not been enabled for NetWare. All other fields on the screen will be shaded.
- If the box is checked, the Network Interface Card has been enabled for NetWare and you can make entries in the other fields.

#### Print Server Name

Indicates the NetWare print server name which the print server uses to log into NetWare. You can enter a name which does not already exist in the network directory or server bindery.

The maximum field length is 48 characters.

#### Print Queue Scan Rate

Specifies the rate at which a print server will poll print queues for a new print job. For example, if you place 1 in the field, the print server should poll for new print jobs every 1 second. The minimum value for this field is 1 and the maximum is 250.

#### Print Server Password and Print Server Password Retype

Indicates the password for a print server which will be used to log into NetWare. When you change this field, NWSetup will set the password in both NetWare and the print server.

The maximum length for this field is 32 characters.

Both the Password and Password Retype fields must be identical before a user is allowed to Finish this screen.

#### Ethernet Frame Type

Indicates the Ethernet frame type that should be used by the NetWare protocol stack by default. Only one frame type can be selected.

### Enable NDS Mode

Indicates whether the print server support Directory Services. When the box is checked, Directory Services is supported.

- If this box is not checked, then all other fields on this screen will not be enabled.

### Preferred NDS Context

Enter a text string to set the NDS directory context for which the print server will use to login to the network. The maximum field length is 128 characters.

===== MEMO =====  
Make sure you enter the whole context, whether typed or typeless.  
=====

### Preferred NDS Tree

Enter a text string to set the NDS tree which the print server will use to login. The maximum field length is 48 characters.

### Enable Bindery Mode

Determines whether the print server should attempt to service the NetWare network in bindery mode.

- If this box is checked, then Bindery Mode is enabled.

===== MEMO =====  
If this field is not enabled, then the Primary File Server field will not be enabled.  
=====

### Primary File Server

Specifies which NetWare file server that the print server should use as the primary file server. If no primary file server has been selected yet, or if a server that is not available is selected, then the first file server in the list is selected.

## Print Server Settings

NWSetup lets you set up each printing system. This information is usually entered using NetWare's NWADMIN or PCONSOLE utility. NWSetup eliminates the need for configuring the print controller and the print server through any NetWare utility. A description of each setting follows:

### Enable Printer

Indicate whether support for the print controller is enabled.

- If this box is checked, then the print controller is enabled.
- If the box is not checked, then the print controller is not enabled. The remaining fields on the screen will not be enabled.

### Printer Name

Displays the name of the printer. This is a read-only field.

### Queues Serviced by Printer

Lists all the queues which are to be serviced by the printing system.

- Queues associated with bindery connections are listed in the format bindery server name: queue name.
- Queues associated with NDS connections are listed by their distinguished names.

Example: If a printer services the queue YOURPTR\_Q on the server OLD\_SERVER which is a bindery server, then the queues would be listed as OLD\_SERVER:YOURPTR\_Q. If an NDS server has a distinguished name such as ENGINEERING.CORP and with a queue name ENGINEERING\_Q servicing the printing system, then the queue would be listed as ENGINEERING\_Q.ENGINEERING.CORP

### Users/Groups Notified by Printer

Lists all users and user groups who will be notified when a printer error is detected.

- Users and groups associated with bindery connections will be listed in the format bindery server name:user/group name.
- Users and groups associated with NDS connections will be listed by their distinguished names.

Example: If a user named Susan on the bindery server OLD\_SERVER is listed on the printer's notify list, then the user would be listed as OLD\_SERVER:SUSAN. If a user named Albert whose NDS context is ENGINEERING.CORP is on the printer's notify list, then the user would be listed as ALBERT.ENGINEERING.CORP When you double click on an entry in this field, the Notify Settings screen appears. See Configuring the Notify Settings later in this section.

---

### MEMO

---

The print server supports the Notify function only in Bindery mode.

---

### Add Queue / Delete Queue

Use the Add and/or Delete queue buttons to make changes.

#### Adding a Queue:

When the user clicks on the [Add Queue] button, a dialog box appears (see above) where the user can add a queue to the printing system. Below is a description of each field:

#### Connection/Server:

Use to select a server connection. This list includes the NDS connection and all of the bindery file server connections which the user has. The NDS connection is always the first one listed, by default. When a new connection is selected, the Queue field is automatically updated.

#### NDS Context:

Specifies an NDS context for the queue. NWSetup lists all the queues within this context or the subcontexts in the Queue field. This field is only enabled when NDS support is enabled. By default, the NDS Context should be set to the preferred NDS context specified in the Print Server Settings screen.

#### Queue:

Lists all the queues available on currently selected connection.

- If an NDS connection is specified, then a list of all queue names in the selected context and, all subcontexts is displayed.
- If you change the context in the NDS Context field, or, change the connection in the Connection Server field, then the queue list is refreshed to reflect the new connection or context.
- If you double click on a queue in the list, the queue is automatically added to the printer's service and you exit this screen.

### **Deleting a Queue:**

Highlight the queue you want to delete and click on the [Delete Queue] button. A confirmation screen appears which asks if you really want to delete the highlighted queue. Press [Yes] to delete, or, [No] to cancel the deletion.

---

### **MEMO**

---

If you delete a queue, you are not physically deleting the object from the file server. In order to delete the queue from a file server, you must use your NetWare utility to remove the queue from the file server queue list.

---

### **Add User/Delete User**

Press the [Add User] or [Delete User] buttons to add or remove Users/ Groups for notification.

Adding Users/Groups:

#### **Connection:**

Select a connection from this field. This list includes the NDS connection and all of the bindery file servers connections to which a user has access. The NDS connection is always listed first, by default. NDS Context specifies the NDS context to use when generating a list of users and/or groups. This field is enabled only for NDS connections. When first displayed, this field lists the preferred NDS context specified in the Print Server Settings screen. If you change this value, then NWSetup verifies that it is correct when the user attempts to move to another field or clicks on [OK].

Users/Groups: Lists all of the user and groups available on the currently selected connection. Any entry on this list can be added to a printer's service list. The list includes (Print job owner) which refers to the user who sent the job currently being printed.

- If an NDS connection is selected, NWSetup generates a list of all users and groups in the currently selected context and all subcontexts.
- When you double click on an entry in the list, the entry is added to the printer's service list.
- The user/group list is updated whenever the Connection or NDS Context fields are changed.

Delay in minutes for first message indicates how long the Network Interface Card should wait before sending a notification message that an error condition has been detected. The field is set to 5 minutes by default. Its minimum value is 1 minute and maximum value is 60 minutes. Delay in minutes for repeat messages indicates how long the print server should wait before sending a repeat notification of an error condition. This field is set to 30 minutes by default. Its minimum value is 1 minute and maximum value is 60 minutes.

Note: The NIC supports the Notify function only in Bindery mode.

### **Create Queue**

Below is a description of each field:

#### **Queue Name:**

Enter the name of the new queue. This field must be completed in order to create a new queue. The maximum field length is 48 characters.

#### **File Server Volume:**

Indicates the volume on which the queue should be created. This field is enabled only if the current connection is an NDS connection. When enabled, it contains a list of all available volumes. For bindery services, the default volume name is SYS. NDS Context: Specifies the NDS context in which the queue is created. This field is enabled only when an NDS connection is being used. When this field first displays, it will list the NDS context specified in the Add Queue dialog. If you change it, NWSetup verifies that the new context exists on the directory tree. Click on OK to start the verification process.

### Configuring the Notify Settings

The Notify Settings screen appears when you double-click on an entry in the Users/Groups Notified by Printer field on the Print Server screen. Use this screen to set up the notify function for the users or groups.

---

---

#### MEMO

---

---

The print server supports the Notify function only in Bindery mode. Below is a description of each field:

---

---

#### **User/Group name**

Indicates the name of the user or group which is being edited. This field cannot be changed.

#### **Delay in minutes for first message**

Indicates how long the print server should wait before sending a notification message to the user that an error condition has occurred. The field is set to 5 minutes by default but can be set to any value between 1 to 60 minutes. Delay in minutes for repeat messages Indicates how long the print server should wait before sending a repeat notification message to a user or group when an error condition has occurred. The field is set to 30 minutes by default but can be set to any value between 1 to 60 minutes.

### ■ Setup for NetWare 3.x

Before setting up NetWare, you have to define the print server name, etc., from the MAP (Web utility). See “Chapter 2 Setting up the Network Interface Card”, for setting up NetWare by MAP. See the manual of Novell NetWare for setting up with PCONSOLE.

The setup procedure of NetWare 3.x is as follows. To perform this procedure, you must be authorized as supervisor.

1. **Start up PCONSOLE and select the file server to use.**
2. **Generate and assign a print queue.**
3. **Define the network interface card as the print server.**
4. **Define the notification list/password as necessary.**
5. **Set up the primary file server as necessary.**

On completion of setup, turn off the main power of the print controller and the main body printer and turn it on again. The main body printer will print out a Status Page indicating the file servers equipped with print server and the queues that the file servers will service.

---

#### MEMO

---

The primary file sever must be defined if the network is of a large scale and connects many sites having more than one file server. PCONSOLE should be used to set up the primary file sever.

---

---

## ■ Setup for NetWare 4.x

Novell NetWare 4.x can operate in two modes, NetWare Directory Service (NDS) and Bindery Emulation Service (Bindery Emulation). Bindery Emulation and NDS will be executed simultaneously. It is also possible to set up the print server so that it operates only in Bindery Emulation mode or in NDS mode.

The print server set up for NDS mode will also service the file server of an old version operating in Bindery mode.



---

If NDS is not set up properly for the print server and Bindery Service mode is not operating, the print server cannot find the file server and Novell NetWare protocol will be indicated as inactive in the Status Page.

---

## ● Setup information

### NDS

Novell Directory Service (NDS) offers a different, more advanced approach to network management than previous NetWare versions. Generally, it stores and tracks all network objects.

As a rule, all 4.x servers must have NDS loaded in order to function. In this way, every NetWare 4.x server is a Directory server, because it services named Directory objects such as printing systems, print server and print queues.

With the appropriate privileges, you can create a print server object, which, once configured in its context (or location) on the network, eliminates the cumbersome setup of print servers on every network server. NDS provides true enterprise networking based on a shared network database rather than individually defined physical sites. The result is a greatly improved print server setup and management.

### Bindery emulation

NetWare 4.x also provides backward compatibility for 3.x and 4.x print service through Bindery emulation. The Directory Information Base (DIB) is used to store information about servers and services, users, printing systems, gateways, etc. It is a distributed database, allowing access to data anywhere on the network wherever it is stored.

Pre-4.x NetWare versions provide the same data found in the DIB but the data is stored in the NetWare Bindery. The DIB was designed with more flexible access, more specific security, and, since it is distributed, it was designed to be partitioned.

The Directory uses an object-oriented structure, rather than the flat-file structure of the Bindery, and offers network-oriented access, rather than server-oriented access found in the Bindery.

The Directory is backward-compatible with the NetWare Bindery through Bindery emulation mode. When Bindery emulation is enabled, Directory Services will accept Bindery requests and respond just as if a Bindery existed on the NetWare server being accessed.

Be aware that information obtained from the Bindery query may not be stored in the server since the Directory is a partitioned and distributed database. Even though the NetWare 4.x server is not operating from a Bindery, the applications making Bindery requests will not know the difference.

### ● NDS setup

#### Web utility

This is used for context setup of the print server (network interface card). See “Chapter 2, Setting up the Network Interface Card”, for more detail.

#### Novell NWADMIN

Novell NWADMIN (NetWare Administration) is used to generate a directory tree and print queue objects in the print server, printing system and tree.

The network interface card is provided with a plug-and-play feature to support NetWare administration utility (NWADMIN) that enables the NDS administrator to perform centralized management of print servers.

Refer to the Novell NetWare manual for details of Setup with NWADMIN.

#### PCONSOLE

NetWare allows the use of PCONSOLE as an alternative of NWADMIN. PCONSOLE is used to set up static information of print servers regarding which queues to service and to whom information is given in case of trouble.

Refer to the Novell NetWare manual for details of setup with PCONSOLE of NDS.

### ● Setup for Bindery Emulation

Make sure of the Bindery Context.

Before connecting the print server (network interface card) to the Novell NetWare 4.x server of bindery mode, make sure that the NetWare server contains the bindery context.

If the bindery context does not exist, the network administrator should modify the AUTOEXEC.NCF file to add an adequate SET command and restart the NetWare server or enter a SET command from the console prompt to make changes.



Note that any command entered following the console prompt is effective immediately but the definition of the autoexec.ncf file becomes effective only after turning off power and on again.

---

---

Setup with PCONSOLE in bindery mode.

If it is sure that the bindery context exists in the file server, you can set up the print server with PCONSOLE.

Refer to the Novell NetWare manual for details of setup with PCONSOLE.



In Bindery mode, only upper-case letters are valid for the printer server password.

---

---

## Chapter 7 AppleTalk Configuration

- Setup for printing through AppleTalk ..... 7-2
  - Configuration for AppleTalk ..... 7-2
  - Using the NIMange ..... 7-2

### ■ Setup for printing through AppleTalk

This section explains how to configure and use the NIManage (NIManage AppleTalk Administration Program) so that printing can be performed from a Macintosh system.

The NIManage is used to perform the following functions:

- Change the network zone and/or change printer names for the printing system.
- Assist Océ Customer Support in diagnosing problems.

### ● Configuration for AppleTalk

The AppleTalk protocol must be enabled before printing can be performed.

Use the MAP utility and Web Utilities for Windows to check or to enable the AppleTalk protocol.

Refer to “Chapter 2, Setting Up the Network Interface Card” for more details.

- Print to the printing system by using Chooser to select the network and printer.
- The network interface card is found in Chooser as OCE\_(serial number) 1, where 1 stands for the print controller.

### ● Using the NIManage

#### How to access the NIManage

The NIManage (NIManage AppleTalk Administration Program) is contained on the CD-ROM supplied with the network interface card.


1. **Copy the NIManage program (folder labeled NIManage) on the CD-ROM to a folder.**  
**For example, place the program in a folder called NIMANAGE or PRINTSERVER.**
2. **Double click on the NIManage Program icon when it appears on the desktop. The Zone and network interface card Device Dialog menu appears.**  
**If your network has no zones, choose only from the network interface card Device field, as no Zone field is displayed.**
3. **Select the Zone that has the network interface card you want to administer.**  
**Available network interface cards on that Zone appear in the network interface card field.**
4. **Select the network interface card you want to use.**

#### Setup the network interface card

Use the options added to the menu bar to configure the network interface card. Depending on your printing system, certain functions may appear grayed out, which indicates that they cannot be selected.

- Use [Printer Setup] to configure your network interface card for PostScript printers.
- Use [Reset] to perform a full reset of the network interface card. When you select [Reset] from the network interface card menu, the network interface card resets automatically.
- Use [Configuration] to change the network interface card name, and the AppleTalk Zone name; and also view the network interface card configuration features. You can change the default name of the network interface card to another one you may prefer. Be sure to recycle the power to the print controller and the main body printer Off, then On; otherwise, the changes you made will not occur.

When you choose [Configuration] the following screen appears:



1. To change the name of the network interface card, click on the name displayed, then enter the new name.
2. To change the [AppleTalk Zone], click on the zone displayed. A menu displays all available zones.
3. Select the new zone from the menu.
4. Click [OK] when you have finished viewing this screen or when you are finished making changes.
5. Turn off the print controller and the main body printer and then turn it on again to make the changes take effect. The Status Page should identify the new printer name and the new zone preference.

### Error Log

The Error Log function is used to view a log of events that the network interface card has registered. The log contains information as well as errors.

Customer Support may need the information on this screen if your network interface card encounters problems.

When you choose the Error Log function, a screen containing the text of the log is displayed. You can print the error log contents by using the Print option under the File menu.

To save the contents of the error log, do one of the following:

- Use [Save As] option from the [File] menu to save the entire log file.
- Use [Edit] option to cut, copy, and paste some or all of the log file.

---

### MEMO

---

This does not enter data into the error log itself. The data is cleared each time the main body printer is power cycled.

---

### Protocol Setup For TCP/IP Users

Protocol Setup is used to set up the protocols on the unit when you do not have access to a Novell NetWare server or workstation.

- Be sure to turn On the protocols you want to use. It is recommended that you turn Off the protocols you are not using.
- TCP/IP users must also enter the IP address, Subnet Mask, and Default Gateway. Entering a value for the Default Gateway enables the network interface card to communicate with other Subnets.
- If the network interface card does not have an IP Address/Subnet Mask established when you display the Protocol Setup screen, the information in the IP Address and Subnet Mask fields will be incorrect.
- Enter the correct IP Address and Subnet Mask.

If incorrect values are supplied, TCP/IP will not be enabled.

In that case, you will not be alerted with an error message.

- After you select protocols, be sure to recycle the power of the network interface card by turning the main body printer Off, then On; otherwise changes will not be made. After choosing the item on the menu, the following screen displays.

---

#### MEMO

---

The default values for the IP address is shown as zeros. However, this represents a “no IP Address” condition, not an IP address.

---

---

### How To Access The HTTP Server With An Web Browser

Access to the HTTP Server allows you to perform all network interface card functions.

Use the following procedure to access HTTP (HyperText Transfer Protocol) with the standard Web Browser, such as Netscape or Internet Explorer.

1. **Assign an IP address to the network interface card.**  
(See “Chapter 2 Setting Up the Network Interface Card”).
2. **Start the Web Browser you normally use.**

When the Browser is up and running, type `http://` followed by the IP address of the unit in the Location field at the top of the Browser screen, or by going to [File] at the menu bar and choosing Open Location.

Example: For a unit with an IP address of 199.9.200.200, type:

```
http://199.9.200.200
```

### Control Options

- When you have no access to Novell NetWare, [Control Options] can be used to enable or disable the display of the [Power-on Status Page].
- When enabled, the Power-on Status Page prints after the print controller and the main body printer is turned on. The default is the [ON] (enable) position.

## Chapter 8 Troubleshooting

■ LED Status Indicator .....	8-2
■ Resetting the Network Interface Card to Factory Default .....	8-2
■ Status Page .....	8-3
■ How to Diagnose Problems .....	8-4
● Troubleshooting Network Hardware Connections .....	8-4
● Troubleshooting MAP Problems .....	8-4
● Troubleshooting NetWare Protocol .....	8-5

## ■ LED Status Indicator

The network interface card has two LED status indicators: amber and green. The amber LED generally indicates job activity; it flashes when a print job is being communicated to the network interface card; it is off when no activity is occurring.

The green LED indicates the operating condition of the network interface card when it is powered on during normal operation. The following table provides the conditions that these two LEDs indicate.

LED Patterns	And the printer is...	THEN THE NETWORK INTERFACE CARD...	Operating Condition
Green LED is steady ON.	First powered on.	Is performing self-tests.	Normal
	Awaiting print jobs.	Is functioning properly.	Normal
Green LED blinks 3 times and stays on.	Finished self-tests.	Prints out status report.	Normal
Green LED blinks rapidly.	Performing self-tests.	Detects defective RAM chip.	Error
Green LED blinks rapidly 4 times then pauses.	Performing self-tests.	Failed the Ethernet hardware self-test. Check the network.	Error
Amber LED blinks short for 10 seconds. Amber LED goes off and the Green LED blinks continuously.	Performing flash memory self-tests.	Did not pass the check-sum test.	Error
Green LED blinks slowly.	Awaiting print jobs sometime after power-on completes.	Some printer interface error.	Error
Green LED blinks rapidly.	Awaiting print jobs.	Has lost its NetWare connection to file server.	Error

## ■ Resetting the Network Interface Card to Factory Default

You can cause the network interface card to restore all parameters to factory default values, so the network interface card appears just as it came from the factory. You may choose to do this when the network interface card is moved to a new location where the environment (NetWare file servers, IP subnets, and so on) is different.

This process is called “Reset to Factory Default”. It can be done with a Web Browser.



Resetting to factory default value means that the network interface card loses all data such as names and IP address. It does not lose its serial number or MAC address.

## ■ Status Page

The Status Page is sent as a print job to the main body printer after the network interface card is started. The sample Status Page described below shows the configuration of the network interface card immediately before the report is printed. You can print the Status Page using the Web utilities.

It is strongly recommended that you review this report and confirm the setting immediately after installation and any time the setup has been changed.

### An example of Status Page

```

-----
Unit Serial No: 123456                               Version: XX.XX
Network Address: 00:11:22:33:44:55
Network Topology: Ethernet                           Connector: RJ45
Network Speed: 100 Megabits

Novell Network Information                            enabled
  Print Server Name: OCE_123456
  Password Defined: No
  Preferred Server Name not defined
  Directory Services Context not defined
  Frame Type: 802.2 On 802.3

Peer-to-Peer Information                             enabled
  Frame Type: 802.2 On 802.3
  Network ID: 0

TCP/IP Network Information                           enabled
  Frame Type: Ethernet II                            Protocol Address: Not Configured
  Subnet Mask: 255.0.0.0                             Default Gateway: 0.0.0.0
  DNS Address: 0.0.0.0

AppleTalk Network Information                        enabled
  Frame Type: 802.2 SNAP On 802.3
  Protocol Address: Net Number 65384                 Node Number 224   Socket Number 129
  Preferred AppleTalk Zone:                           Default Zone

-----

Novell inactive

Peer-to-Peer Connection Information
  Printer Name: OCE_123456

AppleTalk Connection Information
  AppleTalk Printer Name: OCE_123456

```

### ■ How to Diagnose Problems

Use the following list to determine the cause of printing problems:

- 1. Verify that the printing system is functioning properly.**
  - Is the printing system printing? Make sure the printing system is operating properly by generating a test page. For instructions on generating a test page, refer to the Océ User's Guide designed for your specific print controller model.
  - Is the network interface card on-line (green LED should light about 2 minutes after power-on)? Verify that the printer is on-line, otherwise else nothing will print.
  - Does the LCD Touch Screen of the main body printer display an error message? Refer to the Océ User's Manual designed for your specific main body printer.
  - Did you get a Status Page of the network interface card? After starting, the network interface card outputs a status page which contains information that can be useful for troubleshooting. Keep the Status Page available until a problem is resolved.
- 2. Check the LED status indicator of the network interface card to ensure that there is no error condition. See "LED Status Indicator", for more information.**
- 3. Check the Status Page to see what protocols are enabled and active. See the appropriate chapter to confirm that you have installed and configured your network protocol correctly for the network interface card. See An example in "Status Page".**
- 4. Determine if other users can print. If they can't and they are all on the same NOS, go to the troubleshooting section for that NOS operation manual.**
- 5. When you have determined the nature of the problem, use the checklists in the next section.**

### ● Troubleshooting Network Hardware Connections

- For 100BaseTX or 10BaseT, check that the network connector is plugged into the RJ connector on the network interface card.
- Try another cable to make sure you do not use a defective cable.

### ● Troubleshooting MAP Problems

If the MAP cannot detect a target network interface card, check the following:

- Are the network settings on the network interface card correctly made?
- Did you correctly select the MAP settings?
- Are the protocols used by the computer on which the MAP is to run correctly set up?
- Are the Web Browsers used by the computer on which the MAP to run correctly set up?
- If nothing irregular is found, turn off the main power supply to the print controller and the main body printer, then turn it back on, wait about several minutes and try running the MAP again.

## ● Troubleshooting NetWare Protocol

It is recommended that you use MAP to get the NetWare setup and parameter values. If you have not resolved the problem after running MAP, go through the checklists in this section.

### NetWare Checklist

- Is the print server name (network interface card name) entered correctly? The factory default name is OCE\_(serial number). The serial number is informed in the Status Page.
- Did you assign print queues to the printing system? It is recommended that you assign each print queue to only one network interface card-connected printing system. If print queues are assigned to other network printers, the print jobs may be going to another network printer.
- Did you set up the print controller to the type Remote Other/Unknown?
- If the PCONSOLE or NWADMIN settings are correct, the connection between the printing system and network may have been broken. Turn the print controller and the main body printer off and, using PCONSOLE or NWADMIN, wait for the status message “Not Connected”. Turn the print controller and the main body printer on and the status should change to “Waiting for Job”.

### File Server Checklist

- Is there enough disk space on the File Server and is it running?
- Is the correct file server associated with the printing system? Use PCONSOLE or NWADMIN to check this.
- Did you have the proper rights to configure the print controller? (supervisor or administrator)
- Are the File Server and the network interface card communicating? Run NetWare’s COMCHECK utility from any network workstation to check this.
- Are there enough user positions on the File Server?

### Workstation Checklist

- Is the network loaded onto the workstation? See the NetWare documentation.
- Is the application set up to print to the printing system? For instance, are you using the correct driver?
- Is the workstation connected to the correct print queue? Print a file and verify that the file goes to the queue.
- Are the print queues assigned to the network interface card-connected printing system also assigned to another network printer? If they are, the print jobs may be going to that printer.
- From PCONSOLE or NWADMIN, enter a sample print job directly into an assigned queue. Does the job become Active? Is the job printed?
- Is AUTO ENDCAP enabled? Auto Endcap lets you send data to a network printer. Use PCONSOLE or NWADMIN to check. If not, enable it.

### Print Server Configuration Checklist

If all your hardware connections are correct, check the following:

- Use MAP to check the status of the print server. The Unit Status screen shows the status for the selected print server. This report includes a status of file servers and queues assigned to a printing system along with a description of any problems.
- The printer may not be assigned to the correct print queues. Use PCONSOLE or NWADMIN to direct print jobs to the correct queues, then check to see if the print job is in the queue.
- If print servers were added or changed, use PCONSOLE or NWADMIN to make sure you configured the new devices correctly.
- Make sure the print server name has been entered correctly. If you changed the name in MAP, you must also change the name in PCONSOLE or NWADMIN before you can print.
- Use PCONSOLE or NWADMIN to check the Printer Status. Make sure it is not stopped.
- You cannot use PCONSOLE Version 1.0 to configure the print server. Connect Novell Inc. for an upgrade.

### Printer Server/File Server/Printer Checklist

Check the following to see if:

- The print server can log into the file server, and can service jobs from a File Server.
- The print server name is listed on that File Server. Use PCONSOLE or NWADMIN to set up the print server to the File Server.
- The password assigned to the print server through PCONSOLE matches the password assigned through MAP. Use MAP to update the password stored in the print server memory.
- The print job is in the print queue and waiting to be printed. Use PCONSOLE or NWADMIN to check if the print jobs are being sent to the printing system.

### Workstation to Print Server Connection Checklist

To make sure the workstation is communicating with the print server, check the following:

- Print a file from the workstation and make sure the print job gets to the print queue using PCONSOLE or NWADMIN. If the print job does get to the queue, the problem is not with the workstation/print server connection.
- Use CAPTURE to send data to the printing system from a workstation software application. See your NetWare print server manual for information.
- Make sure another printer is not taking the print jobs from the queues before the print server can service the job. To do this, disable the other printer until you can verify the print server-connected printing system setup.

### Print Server Loses Its Novell File Server Connection

If the print server loses its connection to the file server, it can take approximately 5 to 10 minutes to reconnect. If the connection is not made after a reasonable amount of time, check the error conditions to troubleshoot the problem.

### Unable to Print from a Different Context

The print server does not support printing from a context different from the context upon which you are installed. If you want to do this, you must create an alias queue. See your NetWare Manual for more information.

## Appendix

- Network Interface Card specification ..... Appendix-2
- 10/100 Base T UTP cable specifications .... Appendix-3
- Factory Default Settings ..... Appendix-4
- Information for the TCP/IP network administrator ... Appendix-5
  - Using DHCP ..... Appendix-5
  - Using BOOTP to assign IP Address ..... Appendix-6
  - Using rarp to assign IP Address ..... Appendix-7
  - Installing UNIX-TCP/IP Programs ..... Appendix-8

## ■ Network Interface Card specification

Type:	Print Controller Built-in type
Frame Type:	IEEE 802.2/802.3/Ethernet II/IEEE 802.3 SNMP
Ethernet Connection:	10BaseT/100BaseTX
Network Connector:	RJ45
Protocols:	TCP/IP (BOOTP, ARP, RARP, ICMP, DHCP, SNMP, HTTP), IPX/SPX, AppleTalk (EtherTalk)
Compliant OS (NOS):	Novell NetWare (3.x, 4.x), Microsoft Windows 95/98/Me, Microsoft Windows NT 4.0, Microsoft Windows 2000, UNIX, MAC OS 7.x or later
Multiple Protocols:	Automatic selection
Printing Method:	Peer-to-Peer (TCP/IP for Windows 95/98/Me), Pserver (IPX/SPX), LPD/LPR (TCP/IP for Windows NT 4.0/2000), lpd/lpr (TCP/IP), AppleTalk (EtherTalk)
Dedicated Utilities:	IP-P2P, IPX-P2P, MAP (Management Access Program), NWSetup, UNIX-TCP/IP Programs, NIManage
Standard Utilities:	Web Browser (Netscape Navigator, Internet Explorer)
Size:	124 mm x 95 mm
Weight:	110g
Operating Conditions:	0 to 50 degrees Centigrade, 5% to 80% RH
Status Indicators:	Green LED, Yellow (amber) LED (one each)
Settings:	Stored in nonvolatile memory

## ■ 10/100 Base T UTP cable specifications

Use the following universal Ethernet standard when configuring your 10/100BaseT UTP cables to connect to the RJ45 connector on the Network Interface Card. The cable should be Category Type 5 or better (depending on length).

Pin No.	Color	Ethernet
8	Blue/White	
7	Blue	
6	Orange/White	Receive-
5	Green/White	
4	Green	
3	Orange	Receive+
2	Brown/White	Transmit-
1	Brown	Transmit+

## ■ Factory Default Settings

Data transfer speed:		Automatic recognition
Password:		sysadm
TCP/IP:	IP Address	0.0.0.0
	Subnet Mask	255.0.0.0
	Default Gateway	0.0.0.0
	Base Port Number	10001
	DHCP	Enabled
	IP Address	Enabled
	LPD Banner	Enabled
	Ethernet Frame Type	Ethernet II
Novell NetWare:	NetWare (IPX/SPX)	Enabled
	Print Server Name	OCE_(serial number)
	Print Server Password	No Value
	Scan Rate Print Queue	1 Sec.
	Ethernet Frame Type	Auto Search*
	Disable Bindery	Enabled
	Preferred NDS Context	No Value
Preferred NDS Tree	No Value	
AppleTalk:	AppleTalk	Enabled
	Printer Name	OCE_(serial number)
	Ethernet Frame Type	802.2 On 802.3
Peer-to-Peer:	Peer-to-Peer	Enabled
	Printer Name	OCE_(serial number)
	Ethernet Frame Type	Auto Search*

\* If the Network Interface Card can not get the any frame type when starting, [802.2 On 802.3] is to be selected.

## ■ Information for the TCP/IP network administrator

### ● Using DHCP

Dynamic Host Configuration Protocol (DHCP) is a service that provides IP address assignment and maintenance procedures. The network interface card can get IP information from the service.

There are two user-definable variables related with the DHCP functions. You can set up those variables from [Setup TCP/IP] of [Network Administration] provided by the Web utility.

- Enable DHCP
  - Enable IP address defined
- a. If you select [Not enable DHCP], the network interface card does not call for the DHCP service. If no IP address is defined for the network interface card or [Enable IP address defined] is OFF, the network interface card attempts to get an IP address by BOOTP requestor or some other means.
  - b. If DHCP can be used and no IP address is defined for the network interface card or [Enable IP address defined] is OFF, the network interface card calls for the DHCP when reset or power has turned on.
  - c. If DHCP can be used but an IP address is defined for the network interface card and [Enable IP address defined] is ON, the network interface card gets IP information from NVRAM (nonvolatile memory) and does not use DHCP service.

Both of the options [Enable DHCP] and [Enable IP address defined] are ON by default values (employed at shipment time). In this case, if the IP identification information stored in NVRAM is not available, the network interface card generates a DHCP request.



---

When DHCP can be used and the factory default values are set for the network interface card, set up (reserve) to enable the IP address of the network interface card to be used continually on the DHCP server, otherwise the same address might be given to other hosts.

---

## ● Using BOOTP to assign IP Address

The BOOTP daemon is a native TCP/IP option for configuring the IP address of a non-disk network device. To communicate the IP address, use the following procedure:

1. Turn off the print controller and the main body printer.
2. Log in as superuser on a host that is attached on the same network segment as the print server. Confirm the subnet mask is the one you intend to use. However, if the server resides on another subnet, complete this procedure to store the IP address in the print server.
3. Find the MAC address of the network interface card. The address is printed on the Status Page each time you turn the print controller and the main body printer on.
4. Edit the hosts file (usually `/etc/hosts`) or use NIS or DIS to add the IP address and node name of the network interface card. See the network administrator for the IP address. For example, a network interface card named `printfast` with an IP address of `192.9.200.200` has the following entry:

```
192.9.200.200 printfast
```

5. Stop the BOOTP daemon if it is running.
6. Edit the `/etc/bootptab` file and add the following information:

```
Oce_host:\
:ht = hardware type:\
:ha = ethernet address:\
:ip = IP address:\
:sm = subnet mask:\
:gw = gateway address:
```

### Example, for an RFC 1048 system:

```
printfast:\
:ht = ether:\
:ha = 0040AF03AF6E:\
:ip = 192.9.200.200:\
:sm = 255.0.0.0:\
:gw = 192.9.200.10:\
```

### (If running SCO UNIX, add:)

```
:vm = rfc1048:
```

### The same information uses the following format on an RFC 951 system:

host	htype	haddr	iaddr	bootfile
printfast	1	00:40:af:03:af:6e	192.9.200.200	default boot

7. Start the BOOTP daemon by typing:
 

```
bootpd -s
```
8. Check the print controller to verify that the network interface card is connected to the network. Turn on the print controller and the main body printer.
9. Wait until the print controller and the main body printer power up and finish initializing to allow enough time for the IP address to become known and to be saved in nonvolatile memory. The network interface card should re-initialize itself.
10. After the network interface card has re-initialized, send a ping command to verify that the print server obtained its IP address. For example:

```
ping 192.9.200.200
```

If the print server has the address, a confirmation message displays:

```
192.9.200.200 is alive
```

11. Remove your changes to the `/etc/bootptab` file.
12. Stop the BOOTP daemon and, if you want it to run, restart it.

## ● Using rarp to assign IP Address

The Reverse Address Resolution Protocol (rarp) allows network devices to query a server for their IP addresses on start-up. This procedure requires a workstation with a rarp server.

To store the IP address, use the following procedure:

1. Turn off the print controller and the main body printer.
2. Log in as superuser on the rarp server.

If the server resides on another subnet, complete this procedure to store the IP address in the print server. Reconnect the print server anywhere on the network.

3. Find the MAC address of the network interface card. The address is printed on the Status Page when you power on the print controller and the main body printer.
4. Edit the hosts file (usually `/etc/hosts`) or use NIS or DIS to add the IP Address and node name of the network interface card.

See the network administrator for the IP address. For example, a network interface card with the name of `printfast` has the following entry:

```
192.9.200.200 printfast
```

5. Edit the `/etc/ethers` file or use NIS or DIS to add the MAC address.

To continue the example, for the `printfast` card with an MAC address of `00:40:c8:00:00:ff`, make the following entry:

```
0:40:c8:0:0:ff printfast
```

6. If the rarp daemon is running, stop it and restart it. Verify that the daemon is running.
7. Check the print controller to see that the network interface card is connected to the network. Turn on the print controller and the main body printer.
8. Wait until the print controller and the main body printer power up and finish initializing to allow enough time for the IP address to become known and to be saved in nonvolatile memory. The network interface card should then reset itself.
9. After the network interface card has reset, send a ping command to verify that the print server obtained its IP address. For example:

```
ping 192.9.200.200
```

If the print server has the address, a confirmation message displays:

```
192.9.200.200 is alive
```

10. Remove your changes to the `/etc/ethers` file.
11. Stop the rarp daemon and, if you want it to run, restart it.

### ● Installing UNIX-TCP/IP Programs

The CD-ROM provided with the network interface card includes installation scripts, UNIX-TCP/IP Programs, for various UNIX systems.

This section describes how to install UNIX-TCP/IP Programs on the network interface card for any of the following operating systems:

- DEC ULTRIX 4.3 RISC
- System V Rel. 4
- Solaris (Ver. 1.x, 2.x)
- SCO UNIX
- OSF1/ALPHA
- IBM AIX
- HP-UX

Once the network interface card has its IP information loaded, the following steps are necessary for host-side TCP/IP printing:

1. **Load the UNIX-TCP/IP Programs on your workstation. It is presented as a tar file on the accompanying CD-ROM.**
2. **Run the appropriate installation script, if available.**
3. **Complete the configuration for your operating system.**

### Loading the UNIX-TCP/IP Programs

The following procedures are only necessary when using the supplied host-based lpr capability. Loading the software is not necessary if printer-based lpr is used.

1. **Log in as superuser to the system that spools directly to the print server.**
2. **Insert the CD-ROM in to the host CD drive.**
3. **Go to or create the directory in which you want to install the UNIX-TCP/IP Programs. For example:**

```
mkdir /usr/PSC_install
```

---

#### MEMO

---

If you already have a printing system at your site and you are now installing another one, delete the files in the installation directory not (/usr/Oce). If these files remain, they can prevent the installation of a subsequent network interface card.

---

4. Use the tar command to load the UNIX-TCP/IP Programs from the CD-ROM. Choose your UNIX version from the example of the following table, or if not shown, consult the man page for your system:

UNIX Version	Example
BSD/ULTRIX/AIX/SCO	tar -xvf/dev/rfd0
System V	tar -xvf/dev/rdisk/f13ht
System V/Solaris 2.3	tar -xvf/dev/rCDROM

---

### MEMO

---

The device name varies depending on the computer and its peripheral designations. The first BSD floppy device is often called rfd0.

---

5. After performing the tar, the system will display a list of files of the network interface card copied by the tar. At this point, go to the appropriate section in this manual for instructions on running the installation script on your system.

## Filters

There will be certain options in executing the script for various systems.

### PostScript UNIX Printing

The installation script can create an entry in the /etc/printcap file for the print controller and the network interface card:

```
ASCII, PCLfiles
```

If your printing system is not a PostScript printer, the install script uses an input filter (infilter) that supplies CR/LF translation to print ASCII files on a PCL printer.

If your printing system is a PostScript printer, your printcap file will reference **psfilter** which offers easy ASCII-to-PostScript conversion. Normal PostScript format files are not affected. Proprietary and public domain filters are available for broader filtering capabilities.

### PSBanner

The network interface card ships with an input filter called **psbanner**, an output filter to print PostScript banners.

You may change **infilter** or **outfilter** entries in the /etc/printcap file.

The following is a sample printcap entry using these filters:

```
<print_name> | Océ Print Server printer:\
:lp=/dev/nic/<printer_name>:\
:if=/usr/nic/psfilter:\
:of=/usr/nic/psbanner
:sd=/usr/spool/<printer_name>:
```

## Installing and Printing on Ver. 1 Solaris and OSF1 Systems

1. **Run the Installation script by typing: nicinst.**

The script automatically downloads the correct network interface card utilities for your particular system and prompts you for information as needed.

2. **What is the node name of the network interface card?**

Type the node name entered in /etc/hosts.  
For example, type: printfast, then press Enter.

3. **What is the printer name? Type desired printer name, then press Enter.**

4. **The screen displays install script information you provided, as for example:**

```
Node name of the Océ Print Server: printfast
Printer name to be used: <printer_name>
The printer is attached on: PORT1
```

When asked to OK this configuration, type yes or no, then press Enter.

5. **The script creates a printcap entry for the printer just configured.**

The screen displays the entry and asks if you want the script to append it to your /etc/printcap file. See below for a sample printcap file.

```
Type yes or no, then press Enter.
If you type no, you may perform manual edits.
```

In your /etc/printcap file, be sure not to change the name of the device given the network interface card in Step 2. You must reference the same lp: entry you wrote on the lp command line of the printcap file. For example:

```
<printer_name> | Océ Print Server printer:\
:lp=/dev/<printer_name>:\
:if=/usr/nic/infilter:\
:sd=/usr/spool/<printer_name>:
```

Except for the first line, all printcap entries must be prefaced with a tab.

6. **The Installation script creates a spool directory in /usr/spool and starts the daemon for the newly configured printer.**

It also displays the path used in case you need to restart the daemon.

For example:

```
/usr/nic/nic_print /dev/nic/<printer_name> printfast 10001 &
```

7. **Run the ps command so that you can view all your lpd processes.**

```
Type: ps -ax | grep lpd
```

8. **To stop ALL printing, use the kill command on your lpd processes.**

```
Type: kill -9 <Process ID>
```

9. **Restart the daemon.**

```
Type: /usr/lib/lpd
```

10. **Installation for the system is completed.**

When prompted to configure additional printers:

```
Type: yes or no, then press Enter.
```

It is recommended that you ping the network interface card to test communications.

## Installing and Printing on DEC ULTRIX 4.3 System

1. Run the Installation script by typing: `nicinst`.

The script automatically downloads the correct the network interface card utilities for your particular system and prompts you for information as needed.

2. What is the node name of the network interface card?

Type the node name entered in `/etc/hosts`. For example, type `printfast`, then press Enter.

3. What is the printer name?

Type the desired printer name, then press Enter.

4. The screen displays your install script information, as, for example:

```
Node name of the network interface card: printfast
Printer name to be used: <printer_name>
The printer is attached on: PORT1
```

You are asked to OK this configuration. Type `yes` or `no`, then press Enter.

5. The script creates a printcap entry for the printer just configured.

The screen displays the entry (see sample printcap file below) and asks if you want the script to append it to your `/etc/printcap` file.

Type `yes` or `no`, then press Enter. Type `no` to perform manual edits.

```
<printer_name> | Océ Print Server printer:\
:lp=/dev/<printer_name>:\
:if=/usr/nic/infilter:\
:sd=/usr/spool/<printer_name>:
```

6. Installation for the system is completed. When prompted to configure additional printers, type `yes` or `no`, then press Enter. It is recommended that you ping the network interface card to test communications.

Like all BSD systems, ULTRIX uses the `/etc/printcap` file to configure a printer. The interface to the installation script is the same for all BSD systems, however, the printcap entry is different.

If you use the printcap entry generated automatically by the installation script, this will be transparent to you.

### Installing and Printing on HP/UX System

1. Run the Installation script by typing: `nicinst`.

The script automatically downloads the correct network interface card utilities for your particular system and prompts you for information as needed.

2. What is the node name of the network interface card?

Type the node name entered in `/etc/hosts`. For example,

```
type printfast, then press Enter.
```

3. What is the printer name?

Type the desired *printer name*, then press Enter.

4. Your screen displays your install script information, as for example:

```
Node name of the Océ Print Server:   printfast
Printer name to be used:   <printer_name>
The printer is attached on: PORT1
```

When asked to OK this configuration, type *yes* or *no*, then press Enter.

5. The script starts the daemon for the newly configured printer automatically. It also displays the path used should you ever need to restart the daemon. In the following example, the path would be:

```
/usr/nic/nic_print /dev/Océ/printer_name printfast 10001 &
```

This example reflects names supplied to the script earlier.

When the installation script is completed, you must configure the printer and make it known to the `lp` system. The HP/UX `lp` system uses the `lpadmin` maintenance command to configure a printer (there is no `/etc/printcap` file).

Use the following specific commands to configure the printer:

```
lpadmin -p printer_name -v /dev/nic/printer_name
enable printer_name
accept printer_name
```

See HP's alternative SAM method for configuring the printer on the next page.

## Using the SAM Program to Configure the Printer

HP supplies the sam program as an alternative method for configuring the printer. The printer name must be the same as the one you entered during the network interface card installation.

When using sam, specify everything as if the printer were directly connected to /dev/lprprinter/printer\_name.

The software installed with your HP system can satisfy most of your printing needs. HP supplies ASCII-to-PostScript filters, and the system will invoke the filters automatically if you define the content type of the printer as PostScript.

The HP/UX lp system also supplies interface scripts that produce PostScript banners. Use the **lpfilter** command to define new filters and content types if necessary.

The full power and flexibility of the lp print service is now available to you. The fact that you are printing across the network is completely transparent.

### Installing and Printing on System V (Solaris Ver. 2)/System V Rel. 4 386-based Machine

Installation and setup is exactly the same for System V Solaris and SVR4 i386-based machines.

Solution uses a network direct filter called nicfilter. The system invokes nicfilter directly from the printer interface file.

After completing the software download in Loading the Software, you must configure the printer and make it known to the lp system.

**1. Run the Installation script by typing: nicinst.**

**The script automatically downloads the correct the network interface card utilities for your particular system and prompts you for information as needed.**

**2. Select your system by choosing one of the following options:**

- 1) AT&T/SVR4; 386
  - 2) SCO UNIX System V
  - 3) None of the above
- Type 1, 2, or 3, then press Enter.

**3. You have now installed TCP/IP on the Océ Print Server.**

Copy your interface file.  
(/usr/nic is a good place to keep your copy).

**4. Edit the printer interface program this printer uses to redirect output to the Océ Print Server. Then, configure your printer using lpadmin.**

In most cases you would use the default interface script named standard (usually found in the /usr/spool/lp/admins/lp/model directory).

If you wish to use an interface tuned to a specific printer, you must have a copy of the interface file for the port you want to initialize. For example:

```
cp /usr/spool/lp/model/standard /usr/nic/port1_interface
```

Most Version 2 Solaris machines have a shell variable called FILTER that can be changed to invoke nicfilter.

A typical example is:

```
FILTER="/usr/nic/infilter | /usr/nic/nicfilter \  
PSC_name 10001 ${nobanner} \  
${user_name} ${request_id} ${files} "
```

You must specify the network interface card name (PSC\_name) and the port of the network interface card (10001) indicated above to enable the nicfilter to connect to the Océ Print Server unit. The name must be the same as the one you entered in /etc/hosts for this network interface card.

The remaining arguments are optional. The nicfilter uses them to produce a high quality banner. The lp print service user name, request id, file names and options always pass to the interface file. They will be available in any interface script as shell variables, although they may have different names.

If you disable banners in the lp command, the system will set the \${nobanner} option to yes. This will suppress the network interface card banner generation.

If you do not define the FILTER shell variable in your interface file, you can usually modify it to pipe data to nicfilter. The simplest way to accomplish this is to enclose the entire script in parentheses and pipe it to nicfilter, using the arguments described above.

If you wish to use the banner generated by the interface file, simply omit the last four arguments.

---



---

**MEMO**


---



---

These arguments are shell variables from the interface file. They may have different names (names used above are from the standard interface file supplied with most Version 2 and i386 systems).

---



---

## Installing and Printing on SCO UNIX System

Installation and setup is similar for HP/UX and SCO UNIX systems.

The network interface card solution uses a network direct filter called nicfilter. The system invokes nicfilter directly from the printer interface file.

After completing software download in Loading the software, you must configure the print controller + network interface card and make it known to the lp system. Use the following steps:

**1. Run the Installation script by typing: nicinst.**

**The script automatically downloads the correct Océ Print Server utilities for your particular system and prompts you for information as needed.**

**2. Select your system. Choose one from these options:**

- 1) AT&T/SVR4; 386
  - 2) SCO UNIX System V
  - 3) None of the above
- Type 1, 2, or 3 and press Enter.

**3. What is the node name of the Océ Print Server?**

**Type the name assigned in the /etc/hosts file, then press Enter.**

For example, type: printfast

**4. What is the printer name for this Océ Print Server-linked printer?**

**Type a *printer name*, then press Enter.**

**5. The screen displays your install script information. For example:**

```
Node name of the Océ Print Server: printfast
Printer name to be used: <printer_name>
The printer is attached on: PORT1
```

**Do you want to accept this configuration? Type yes or no, then press Enter.**

**6. The script automatically starts the daemon for the newly configured printer. It also displays the path used should you ever need to restart the daemon. In the preceding example, the path would be:**

```
/usr/nic/nic_print /dev/nic/printer_name printfast 10001 &
```

This example reflects names supplied to the script earlier. When the installation script is complete, you must still configure the printer and make it known to the lp system.

The SCO UNIX lp system uses the lpadmin maintenance command to configure a printer (there is no /etc/printcap file).

The specific commands to do this are:

```
lpadmin -p printer_name -v /dev/nic/printer_name
```

NOTE: Your host may require you to specify the model by using the `-i` command.

```
enable printer_name
accept printer_name
```

You can also use other options for the `lpadmin` command. See your system documentation for details. Note that the printer name must be the same as the one you entered during Océ Print Server installation.

The software installed with your SCO system can satisfy most of your printing needs. SCO supplies ASCII to PostScript filters and the system will invoke them automatically if you define the content type of the printer as PostScript.

The SCO UNIX `lp` system also supplies interface scripts that produce PostScript banners. Use the `lpfilter` command to define new filters and content types if necessary. The full power and flexibility of the `lp` print service is now apparent. Your printing across the network is completely transparent.

### Installing and Printing on AIX RISC System/6000

The AIX printing subsystem is driven by the `qdaemon` program.

The `qdaemon` uses configuration information stored in the `/usr/lpd/qconfig` file to manage queues and route jobs to the proper devices. This information includes entries for each virtual printer and physical device known to the system.

An AIX virtual printer is simply a high level software view of a data stream, queue, and device that controls how a given job will be processed. A different virtual printer should be defined for each data stream that a real printer supports. For example, you would use different virtual printers for PostScript and PCL jobs even though they are destined for the same physical printer.

Configuring the print controller and the network interface card on an AIX system approximates configuration of a local printer as closely as possible. The only difference is that the physical device associated with your Océ Print Server printer must be a named pipe used by the print daemon to route data to the Océ Print Server.

The following procedure shows the most straightforward way to add a printer to your system:

- 1. Run the Install script by typing: `nicinst`.**

**The script automatically downloads the correct Océ Print Server utilities for your particular system and prompts you for information as needed.**

- 2. What is the node name of the Print Server unit?**

**Type the node name entered in `/etc/hosts`, for example,**

```
type: printfast, then press Enter.
```

- 3. What is the printer name?**

```
Type: the desired printer name, then press Enter.
```

- 4. The screen will display the install script information you provided, as for example:**

```
Node name of the Océ Print Server: printfast
Printer name to be used: <printer_name>
The printer is attached on: PORT1
```

**When asked to OK this configuration, type yes or no, then press Enter.**

5. **Configure a virtual printer using printer\_name as the physical device, where printer\_name is the same printer name chosen during install.**
6. **Use the following command to shut down the qdaemon and stop all printing:**

```
stopsrc -s qdaemon
```
7. **Edit /etc/qconfig to change the special file for device printer\_name**

```
from:/dev/printer_name
to:/dev/nic/printer_name.
```
8. **Restart the daemon with:**

```
startsrc -s daemon
```

The installation script creates the named pipe and starts the supplied print daemon using the printer name and Océ Print Server information you supplied.

Since the AIX System Management Interface Tool (SMIT) cannot accept a named pipe as a printer device, the installation script creates a null character device in /dev/printer\_name.

### Virtual Printer Commands

By entering the device name printer\_name for configuration purposes, virtual printers can be added either through SMIT or through the mkvirprt command.

During this process you also select a particular printer type for the new printer, which inherits the set of pre-defined attributes for that printer type.

In most cases, this set of attributes will be sufficient, but it can be changed either through SMIT or by using the chvirprt command. If you need to make more extensive changes on your printer, see the AIX RISC System/6000 documentation for information.

Before you edit the files, be sure that the following daemon is running:

```
/usr/nic/nic_print /dev/nic/printer_name printfast 10001 &
```

Use the following procedures to add or change virtual printers:

1. **Run nicinst.**

**When prompted, enter information for the following questions:**

- Nodename (host name in the /etc/hosts file)
- Printer name
- Unit type
- Port number - Enter 1 for parallel port 1

**Answer y to accept the configuration and n when prompted to configure another printer.**

2. **At the prompt, type smit, then press Enter.**
3. **Choose Devices.**
4. **Choose Printer/Plotter.**
5. **Choose Manage Local Printer Subsystem.**
6. **Choose 1. Printer or Plotter attached to Host.**

7. **Enter the Device name.**

Use the same name entered during the install for printer name.

8. **For Type of Printer, enter a number from the printers list, then press Enter.**

9. **Header pages wanted? Type n for none.**

10. **Trailer pages wanted? Type n for none.**

11. **Enter Print Queue name. Type ! to bypass configuration.**

12. **Should this be the default queue?**

Enter y for yes or n for no, then press Enter.

13. **Exit smit.**

14. **Type cd/etc, then press Enter.**

After the virtual printer has been added, there will be a stanza in `/etc/qconfig` for device `printer_name` that looks like the following:

```
printer_name:
file=/dev/printer_name
backend=/usr/lpd/probe
```

Edit `/usr/qconfig` and change the following:

```
file=/dev/printer_name to file=/dev/nic/printer_name
```

15. **Type `stopsrc -s qdaemon`.**

16. **Type `startsrc -s daemon`. Now you can print using the `lp` command.**

### AIX Print Commands

The AIX `lp` command works slightly differently from the `lp` command for other System V Release 4 systems. The following `lp` commands can be used to print files:

```
lp -d <queue_name> <filename> or
lp -d <queue_name>:<device_name> <file_name>
```

# INDEX

## Numbers and Marks

10/100 Base T UTP cable  
specifications ..... Appendix-3

## A

About this manual ..... iii  
 Accessing Web Utilities ..... 2-5  
 Accompanying CD-ROM ..... iii  
 add a printer ..... 3-4  
 Add Printers for  
   IPX Peer-To-Peer Printing ..... 3-9  
 Add Queue/Delete Queue ..... 6-5  
 Add User/Delete User ..... 6-6  
 Adding a printer port ..... 4-2  
 Adding a Queue ..... 6-5  
 Address Resolution Protocol ..... 2-2  
 AppleTalk ..... 7-2  
 AppleTalk Configuration ..... 1-5, 7-1  
 AppleTalk Zone ..... 7-3  
 arp command ..... 1-4, 2-2  
 Assigning IP Address ..... 2-2  
 Available Printers ..... 3-5, 3-8

## B

Base Port Number ..... 2-11  
 Basic TCP/IP setup ..... 3-2  
 Bindery emulation ..... 1-5, 6-9  
 BOOTP Lite ..... 1-3  
 BOOTP Lite program ..... 2-3  
 BOOTP protocol ..... 2-3

## C

Canadian Department of  
   Communications Regulations ..... iv  
 Change Password ..... 2-9  
 Compliant model ..... iii  
 Configuration for AppleTalk ..... 7-2  
 Configure Status Page ..... 2-13  
 Configuring the Notify Settings ..... 6-7

Connection/Server ..... 6-5  
 Create Queue ..... 6-6  
 Creating a printer port ..... 4-3

## D

Default Gateway ..... 2-11  
 Delay in minutes for first message ..... 6-7  
 Deleting a Queue ..... 6-6  
 DHCP ..... 2-2, Appendix-5  
 Disable Bindery ..... 2-11  
 Domain Name Server ..... 2-11

## E

Enable AppleTalk ..... 2-12  
 Enable Bindery Mode ..... 6-4  
 Enable DHCP ..... 2-12  
 Enable LPD Banner ..... 2-12  
 Enable NDS Mode ..... 6-4  
 Enable NetWare ..... 2-9  
 Enable NetWare Print Server ..... 6-3  
 Enable Printer ..... 6-4  
 Error Log ..... 7-3  
 Ethernet connector ..... 1-4  
 Ethernet Frame Type ..... 2-11, 6-3

## F

Factory Default ..... 2-8, 8-2  
 Factory Default Settings ..... Appendix-4  
 FCC Regulations ..... iii  
 Features of the Network Interface Card ... 1-2  
 File Server Volume ..... 6-6  
 Find Printers ..... 3-4, 3-8  
 Flags ..... 3-5, 3-9  
 Folder structure on the CD-ROM ..... v

## G

General description of the network setup .....  
 ..... 2-2

## H

How to Diagnose Problems ..... 8-4  
 HTTP server ..... 2-5

## INDEX

### I

Important notice .....	iv
Information for the TCP/IP	
network administrator .....	Appendix-5
Installation of IP Peer-to-Peer .....	3-2
Installation of IPX Peer-to-Peer .....	3-7
Installation of the	
Network Interface Card .....	1-2
Installing MAP .....	2-6
Installing UNIX-TCP/IP	
Programs .....	Appendix-8
IP Address .....	
2-2, 2-11, 3-4, 5-4, Appendix-6, Appendix-7	
IP Address in NVRAM .....	2-12
IP Peer-to-Peer .....	3-2
IP Peer-to-Peer setup .....	3-3
IP Port .....	3-3
IP-P2P .....	1-3, 1-4, 3-2
IPX Peer-to-Peer .....	3-6
IPX Peer-to-Peer setup .....	3-8
IPX/SPX .....	1-4, 3-6
IPX-P2P .....	1-3, 1-4, 3-7

### L

LAN .....	1-4
LED Status Indicator .....	8-2
LPD .....	4-2
lpd UNIX Printing .....	5-5
LPD/LPR Printing .....	4-1
LPD/LPR setup .....	4-2

### M

main body printer .....	iii
main body printer (copier) .....	ii
Management Access Program .....	2-6
MAP .....	1-3, 2-2, 6-8
MAP -- Operating requirements .....	2-6
Max Hops for .....	3-3
MIB .....	5-2

### N

Name of each product in this manual .....	iv
---	----

NDS .....	1-5, 6-9
NDS Context .....	6-5
NDS setup .....	6-10
NetWare 3.x .....	1-5, 6-8
NetWare 4.x .....	1-5, 6-9
NetWare Configuration .....	1-5, 6-1
Network Address .....	2-9
network interface card .....	iv
Network Interface Card Overview .....	1-1
Network Interface Card	
specification .....	Appendix-2
Network setting procedures .....	1-4
network setup .....	2-2, 2-8
NIMange .....	1-3, 7-2
NWADMIN .....	6-10
NWSetup .....	1-3, 6-2

### O

Others .....	2-13
--------------	------

### P

Package contents .....	iii
PCONSOLE .....	6-8, 6-10
Peer-to-Peer Printing .....	3-1
Peer-to-Peer setup .....	3-8
Permanent .....	3-5, 3-8
Port .....	3-4
Port Number .....	3-5
Preface .....	iii
Preferred File Server .....	2-10
Preferred NDS Context .....	2-10, 6-4
Preferred NDS Tree .....	2-10, 6-4
Primary File Server .....	6-4
print controller .....	ii, iii
Print Queue Scan Rate .....	2-11, 6-3
Print Server Name .....	2-9, 6-3
Print Server Password .....	2-10 6-3
Print Server Settings .....	6-4
printer driver .....	3-5
Printer Language .....	2-12
Printer Name .....	2-13, 6-4
Printer Names .....	3-3

Printer Status ..... 2-13  
 [Printers] dialog box ..... 3-4  
 printing system ..... iv  
 protocol ..... 1-4, 2-9

**Q**

Queue ..... 6-5  
 Queues Serviced by Printer ..... 6-5

**R**

Registered trademarks ..... iv  
 Reset ..... 2-8  
 Reset to Factory Default ..... 8-2  
 Retype Password ..... 2-10  
 RJ45 ..... 1-4

**S**

Setting up MAP ..... 2-6  
 Setting up printer driver ..... 3-5  
 Setting Up the Network Interface Card .... 2-1  
 Setup AppleTalk ..... 2-12  
 Setup for Bindery Emulation ..... 6-10  
 Setup for printing through AppleTalk ..... 7-2  
 Setup NetWare ..... 2-9  
 Setup Novell NetWare ..... 6-3  
 Setup TCP/IP ..... 2-11  
 Setup with NWSetup ..... 6-2  
 SNMP ..... 5-2  
 Starting MAP ..... 2-7  
 Status Page ..... 8-3  
 Subnet Mask ..... 2-11  
 System ..... 2-8

**T**

TCP/IP ..... 1-4, 3-2, 5-2  
 TCP/IP Print Service ..... 4-3  
 Test Print ..... 2-13  
 Troubleshooting ..... 8-1  
 Troubleshooting MAP Problems ..... 8-4  
 Troubleshooting NetWare Protocol ..... 8-5  
 Troubleshooting Network  
   Hardware Connections ..... 8-4

**U**

Unit IP ..... 3-5  
 Unit Name ..... 3-5, 3-9  
 Unit Status ..... 2-9  
 UNIX Configuration ..... 1-5, 5-1  
 UNIX printing through TCP/IP ..... 5-2  
 UNIX-TCP/IP Programs ..... 1-3, Appendix-8  
 User/Group name ..... 6-7  
 Users/Groups Notified by Printer ..... 6-5  
 Using arp command ..... 2-3  
 Using arp command (UNIX) ..... 2-4  
 Using BOOTP ..... Appendix-6  
 Using BOOTP Lite ..... 2-3  
 Using DHCP ..... 2-2, Appendix-5  
 Using IP Peer-to-Peer ..... 3-2  
 Using IPX Peer-to-Peer ..... 3-6  
 Using MAP ..... 2-5, 2-6  
 Using NIManage ..... 2-5  
 Using rarp ..... Appendix-7  
 Using the accompanying CD-ROM ..... 1-3  
 Using the NIManage ..... 7-2  
 Using the NWSetup program ..... 6-3  
 Using Web Utilities ..... 2-8  
 UTP cable ..... 1-4

**W**

Web Utilities ..... 2-8  
 Web utility ..... 6-8  
 Windows 2000 ..... 4-3  
 Windows 95/98/Me Configuration .... 1-4, 3-1  
 Windows 95/98/Me/NT 4.0 (NT)/2000 ..... iv  
 Windows NT ..... 4-2  
 Windows NT/2000 Configuration ..... 1-4, 4-1

**Z**

Zone Name ..... 2-13



Océ USA, Inc.  
5450 N. Cumberland Avenue  
Chicago IL 60656

Océ Printing Systems, Inc.  
5600 Broken Sound Blvd.  
Boca Raton, FL 33487