



User's Manual

Prudent Way Universal Notebook & LCD AC Power Adapter
PWI-AC120LC

Table of Contents

1. Major Features	2
2. Safety & Warning	2
3. Contents.....	2
4. Using your Prudent Way Universal Notebook AC Power Adapter...3, 4	
5. Product Specification.....	5

Thank you for choosing Prudent Way Universal Notebook & LCD AC Power Adapter. Please take the time to read all instructions in this user manual carefully before using the Adapter. Please note that failure to follow the proper instructions may cause fire, electric shock, injury, or damage to electronic devices.

We sincerely hope that you find this quality Adapter provides you with many years of good service.

1. Major Features

- 100-240V AC input provides worldwide power conversion capability.
- Adjustable 12-24V output design fits specific notebook models and LCD needs.
- 13 pieces of tip connector for use with most major notebook brands such as IBM, Dell, Toshiba, Compaq, Asus, Acer, HP, Sony and More¹.
- Extra USB port built in for PDAs, Cell Phones, MP3 Players and more¹.
- RoHS compliancy is friendly to environment.
- High efficiency & full power protection.

2. Safety & Warning

Please read the following information carefully before using the power adapter!

- ! This power adapter is for indoor use only.
- ! This power adapter is for use with information technology equipment.
- ✗ DO NOT disassemble this Adapter. There are HAZARDOUS VOLTAGES inside the power adapter. Disassembling the Adapter may expose you to high voltage or other risks. Incorrectly reassembly may cause electronic shock the next time when the device is used. Warranty will be voided by doing so.
- ✗ DO NOT expose the Adapter and related information technology equipment to water or moist, dusty or extreme temperature environment such as direct sunlight, heat sensitive material or any heat generated sources such as a radiator, stove, or car.
- ✗ DO NOT block the ventilation. The ventilation is designed to protect the Adapter from overheating.
- ✗ DO NOT place the Adapter in a built-in installation, or on a surface such as a bed, sofa, or rug.
- ✗ DO NOT use wet hands to plug or unplug the power cord to avoid electric shock.
- ✓ DO follow all warnings and instructions marked on the product.
- ✓ DO grab the plug instead of cord when you remove the power cord from the wall outlet.
- ✓ DO remove any power sources from this Adapter before attempting any cleaning to avoid electrical shock. Use a dry cloth only.
- ✓ DO place the power cable properly so it will not be stepped on or tripped over.
- ✓ DO unplug the Adapter and contact the dealer from which it was purchased when:
 - The Adapter is damaged.
 - The Adapter does not perform properly.
 - The Adapter has been exposed to water.

3. Contents

	PWI-AC120LC
AC power adapter	120-watt
13 tip connectors	✓
Input and output cables	✓
User manual	✓

4. Using your Prudent Way Universal Notebook & LCD AC Power Adapter



1. AC Socket
2. USB Port
3. LCD Indicator
4. Output Voltage Select Button
5. Blue LED Light
6. Output Cable
7. Tip Connector

Prudent Way Universal Notebook & LCD AC Power Adapter User's Manual
Model: PWI-AC120LC

For notebook computer:

- Step 1. Read the Safety and Warning information above.
- Step 2. Connect the Adapter input power cable to the AC socket of the Adapter (Picture 02a). Then plug the other end of AC power cable to the wall outlet (Picture 02b). For the first time use, the LCD screen will show the default voltage of 12V within 3 seconds. The Blue LED light should flash indicating the Adapter is in standby mode and ready for use.
- Step 3. Please refer to your notebook computer user manual or check on the back of the notebook computer to find the correct output voltage requirement for your notebook computer. Start selecting proper output voltage (12V, 15V, 16V, 18V (18/18.5V), 19V (19/19.5V), 20V (20/20.5V), 22V, and 24V) on the Adapter by pushing the arrow button for 3 seconds (Picture 03a). The flashing voltage now can be adjusted. After selecting the proper voltage, please wait for 5 seconds and the Adapter will memorize the selected voltage as the new default voltage setting.

Please Note!
Once output voltage is selected, the Adapter will automatically memorize the new voltage as the default setting. If different output voltage is needed, please make sure to adjust the voltage by repeating Step 1 to 3 before plugging into different machine.


- Step 4. Choose correct tip connector to fit your notebook power socket and connect it to the Adapter output cable (Picture 04a). These tip connectors are specially design with ridge so they can only be plugged in one direction to the output cable. If you have difficulty to properly plug in, please turn around the tip connector.
- Warning: DO NOT plug Tip L to HP Laptops.**
- Step 5. Connect the tip connector to the power socket of your notebook (Picture 05a).
- Step 6. Turn on your notebook and the Blue LED light should become solid indicating the power is on and ready for use.

For devices with USB interfaces such as MP3, cell phones, iPod, iPhone, iPad and more:

- Step 1. Read the Safety and Warning information above.
- Step 2. Please connect the USB Type A cable provided by your USB device company to the USB port of the Adapter.
- Step 3. Connect the Adapter input power cable to the AC socket of the Adapter (Picture u03a). Then plug the other end of AC power cable to the wall outlet (Picture u03b).
- Step 4. Turn on and use your USB device.



Prudent Way Universal Notebook & LCD AC Power Adapter User's Manual
Model: PWI-AC120LC



2. Product Specification

Prudent Way Universal Notebook & LCD AC Power Adapter User's Manual
Model: PWI-AC120LC

	PWI-AC120LC
FEATURES	
Output Power (Max.)	120W
Overload Protection	Yes
Short Circuit Protection	Yes
Line Regulation	+/- 5%
Load Regulation	+/- 5%
Switching Mode	Universal switching-mode power adapter for notebook & LCDs
Special Connectors	13 pieces tip connector including 3-pin and 4-pin connector, 7.4x5mm for Dell, 7.4x5mm for HP.
Efficiency	> 87% (TYP)
DIMENSIONS	
Unit Size	6.25" x 2.4" x 1.44"
Net Weight	1.1 lb
OUTPUT	
Output Voltage (0/+0.8V No Load)	12V/15V/16V/18V/19V/20V/22V/24V DC12V-24V
	USB Port: 5V
Output Voltage (-0.6/+0.6V @rating load)	12V/15V/16V/18V/19V/20V/22V/24V DC12V-24V
Output Voltage (+/- 5% @typical +/- 0.8V)	
	USB Port: 5V
Output Current	12V/15V/16V/18V/19V/20V @6Amp(max)
	22V/24V @ 5AMP(max)
	USB Port: 2 AMP @ 5V
INPUT	
Rated Input Voltage (50 - 60 Hz)	AC120V or AC230V
Vibration Input Voltage Range (47-63Hz)	AC100V-240V
Input Rated Current	2.2AMP
Input Power	135VA
ENVIRONMENTAL	
Operating Temp.	0 to 40°C
Humidity	20% to 80%
RoHS Compliant	Yes

Prudent Way Universal Notebook & LCD AC Power Adapter User's Manual
Model: PWI-AC120LC

For feedback about this product, please contact
Prudent Way Inc
Toll Free: (866)384-3873
Email: feedback@prudentway.com

For support or general inquiry, please contact
Prudent Way Inc
Toll Free: (866)384-3873
Email: Support@prudentway.com

Made in China

¹ All listing of brand names are registered trademarks of their respective companies.

² Certification

