

## Contents

|                                                                     |           |
|---------------------------------------------------------------------|-----------|
| <b>CAUTION!</b>                                                     | <b>3</b>  |
| <b>GENERAL WARNINGS</b>                                             | <b>3</b>  |
| <b>PRECAUTIONS AND INSTRUCTIONS FOR SAFETY, USE AND MAINTENANCE</b> | <b>3</b>  |
|                                                                     |           |
| <b>INTENDED USE</b>                                                 | <b>4</b>  |
| <b>TECHNICAL DATA</b>                                               | <b>4</b>  |
| <b>MACHINE DESCRIPTION</b>                                          | <b>4</b>  |
|                                                                     |           |
| <b>1 - SWITCHING THE MACHINE ON AND OFF</b>                         | <b>7</b>  |
| <b>2 - MEASURING HEAD BATTERY CHARGER (RADIO VERSION ONLY)</b>      | <b>7</b>  |
| 2.1 - IMPROVING THE LIFE OF THE MEASURING HEAD BATTERIES            | 9         |
| <b>3 - PROGRAM FLOW</b>                                             | <b>10</b> |
| <b>4 - SETTING UP FOR MEASUREMENT</b>                               | <b>11</b> |
| <b>5 - HOME PAGE</b>                                                | <b>11</b> |
| 5.1 - MEASUREMENT WITH 2 MEASURING HEADS                            | 12        |
| 5.2 - MENU                                                          | 13        |
| 5.2.1 - SET-UP                                                      | 13        |
| 5.2.2 - CLIENT DATABASE                                             | 15        |
| <b>6 - VEHICLE DATABASE</b>                                         | <b>16</b> |
| 6.1 - SELECTING THE VEHICLE MAKE                                    | 16        |
| 6.2 - ENTERING NOTES ON THE CLIENT                                  | 16        |
| 6.3 - SELECTING THE VEHICLE MODEL                                   | 17        |
| <b>7 - DISPLAYING THE TECHNICAL DATA OF THE VEHICLE SELECTED</b>    | <b>18</b> |
| 7.1 - IMAGES OF THE ADJUSTMENT POINTS                               | 19        |
| 7.2 - CHASSIS HEIGHT                                                | 20        |
| 7.3 - CUSTOMISING THE VEHICLE DATABASE                              | 21        |
| <b>8 - RUNOUT</b>                                                   | <b>22</b> |
| 8.1 - RUNOUT WITH VEHICLE JACKED UP                                 | 23        |
| 8.2 - RUNOUT WITH VEHICLE ON THE GROUND                             | 26        |
| 8.3 - FINAL OPERATIONS                                              | 28        |
| <b>9 - STEERING</b>                                                 | <b>29</b> |
| 9.1 - FAST STEERING                                                 | 29        |
| 9.2 - 10° OR 20° STEERING                                           | 32        |
| <b>10 - VEHICLE DIAGNOSTICS</b>                                     | <b>36</b> |
| <b>11 - VEHICLE ADJUSTMENT</b>                                      | <b>36</b> |
| 11.1 - NORMAL PROCEDURE                                             | 37        |
| 11.2 - AUDI PROCEDURE                                               | 38        |
| 11.3 - ZOOM                                                         | 40        |
| 11.4 - FREEZING                                                     | 41        |
| <b>12 - SUMMARY OF DIAGNOSTICS AND ADJUSTMENT DATA</b>              | <b>41</b> |
| 12.1 - FINAL MENU                                                   | 42        |
| 12.2 - MAX STEERING                                                 | 43        |
| <b>13 - ALIGNING AND LEVELLING THE MEASURING HEADS</b>              | <b>44</b> |
| <b>14 - SPOILER PROCEDURE</b>                                       | <b>46</b> |
| <b>15 - ERROR MESSAGES</b>                                          | <b>48</b> |
| 15.1 - DATA TRANSMISSION ERROR                                      | 48        |
| 15.2 - INFRARED RAYS BREAK                                          | 48        |
| <b>16 - STORAGE AND SCRAPPING</b>                                   | <b>49</b> |
| <b>17 - MAINTENANCE</b>                                             | <b>49</b> |
| 17.1 - CLEANING                                                     | 49        |
| 17.2 - HOW TO CHECK AND REPLACE THE POWER FUSES                     | 50        |
| 17.3 - HOW TO REPLACE A MEASURING HEAD BATTERY                      | 50        |
| 17.4 - HOW TO ACTIVATE THE VEHICLE DATA                             | 52        |



## **Caution!**

This manual forms an integral part of the product and provides instructions for use of the wheel aligner. Carefully read the manual before using the wheel aligner and each time you need to operate on the machine; keep it in an accessible place for the entire operating lifetime of the machine.

Any damage arising from inobservance of the instructions contained in this manual and from improper use of the machine relieves the manufacturer from all responsibility.

## **General warnings**

- The manual refers to essential aspects of the directives, standards and regulations relating to use of the machine summarising the most significant points.
- In addition to the instructions for use the general rules of law and the binding rules regarding accident prevention and environmental protection must be complied with.
- For all the operations to be carried out with or on the machine, the following rules must be complied with as well as the general accident-prevention rules.
- The user must assure that the machine is always and exclusively used in perfect working conditions and consult the essential safety requirements and the relevant regulations.
- In the event of faults or malfunctioning, the machine must be placed out of service immediately.
- Only trustworthy personnel may work with the machine; the user is responsible for assuring the necessary level of education and training of the qualified personnel.
- If in any doubt over the use and maintenance of the machine consult this manual; if necessary, contact the authorised technical service centres.

## **Precautions and instructions for safety, use and maintenance**

- The data plate bearing the voltage and frequency is located on the rear of the machine. **NEVER CONNECT THE MACHINE TO A VOLTAGE OR FREQUENCY OTHER THAN THOSE INDICATED.**
- This machine is equipped with a 3-pin plug with incorporated ground, which may be inserted in a grounded socket only. If it is not possible to fit the plug in a socket of this kind, consult an electrician. Do not modify the plug or utilise it improperly.
- This machine is not fitted with a manual power cutting device; To cut the power, pull the plug out of the socket or operate the main switch positioned upstream.
- All the operations and repairs on live electrical parts must be carried out after having switched off the main power switch on the electric panel.
- The warning and danger signs in the form of plates, adhesive labels and markings must not be removed or made unrecognisable.
- The warning and danger signs fixed on the machine must be maintained legible.
- All the maintenance and inspection operations must be carried out exclusively by qualified personnel.
- Mechanical and electrical repairs as well as setting operations must be carried out by qualified personnel only.
- Unauthorized persons must not be allowed to work on the machines and equipment of the system.
- In the event of faults that pose a risk to safety and/or reliability of the machine, it must be stopped or in any case not started.
- The electrical system may not be modified or transformed in any way.
- The user will be held responsible for such modifications and the consequences deriving therefrom. In case of doubt, contact the manufacturer before making any modifications.
- Use exclusively original fuses with the prescribed amperage! In the event of electrical power failures, the machine must be switched off immediately.
- Defective fuses must not be repaired or excluded but replaced with fuses of the same type.
- Observe the environmental protection regulations when disposing of waste material and replaced parts.

## Intended use

The alignment line is a machine intended for measuring the characteristic angles of motor vehicles, in particular, the camber angle, toe-in and caster.

## Technical data

### Power supply and consumption

#### Measuring cabinet


|                        |                                                                  |
|------------------------|------------------------------------------------------------------|
| Power supply:          | 230 VAC single-phase 50/60 Hz<br>110 VAC single-phase on request |
| Max. power absorbed:   | 500 W                                                            |
| Max. current absorbed: | 2,17 A                                                           |

#### Sensors

|                         |                                     |
|-------------------------|-------------------------------------|
| Internal power supply : | 7.2 V rechargeable batteries (NimH) |
| External power supply:  | 12 V (via cable)                    |

## Machine description

### Measuring cabinet



#### **NOTE:**

*The image is only an example of the parts. The actual shapes of the cabinet, monitor and printer may differ from the image.*

## Measuring heads

The measuring heads are composed of CCD transducers to measure the horizontal angles and an accelerometer to measure the vertical angles. In the cable version, both the power supply and data transmission is via cable. In the radio version, the power is supplied via rechargeable batteries and, if the batteries are flat, via cable. Data transmission is via radio.


To switch on the measuring heads, press any key on the keypad; to switch them off, hold **OK** down for about 5 seconds.



### NOTE:


*The measuring heads automatically switch off after about 15 minutes if no data is transmitted or when the cabinet is switched off.*

2



1. Soft-touch control keyboard.
2. Set of 3 signalling LEDs for measuring head levelling.
3. Connectors for emergency power supply or battery charger extension cable


3



4. Pin locking knob.

## Measuring head keypad

4



1. Level indicator with red/green/red LEDs



Measuring head level



Measuring head not level



Measuring head not level

2. The menu page is accessed (where present)
  3. Confirms the option selected
  4. In the menu, it moves the selection to the top/goes back to the previous page
  5. In the menu, it moves the selection to the bottom/goes to the next page
- 2;3;4;5 Press any key to switch on each head




### NOTE:

*When switching on a measuring head, one, two or three LEDs come on for about 1 second, depending on the battery charge level.*

### **Wheel clamps**


Wheel clamps type 4-point for 10" to 19" steel and alloy rims. The removable metal claws are included.



1. Knob
2. Claw attachment pin
3. Measuring head coupling flange
4. Measuring pin locking knob

### **Turntables**

310 mm in diameter; capacity of 1000 kg each.



1. Handle
2. Stops
3. Upper plate with non-slip disc
4. Graduated rod
5. Gradual indicator

### **Brake pedal lock**

The brake pedal lock is a tool used to lock the brake pedal when preparing to make measurements.



### **Steering lock**


The steering lock is a tool used to hold the steering wheel in a fixed position; it is positioned before carrying out the vehicle adjustment operations.




## 1 - Switching the machine on and off

Locate the power switch and the reset button on the rear of the cabinet.  
There are two different power switch versions.

9



9a



• To turn on:

1. Set the power switch (1) to ON (I)
2. If the computer does not turn on automatically, press the reset button (2)

• To turn off: set the power switch (1) to OFF (O)

• [only if position (II) is present (figure 9a)] To charge the arm batteries even when the computer is off, set the power switch (1) to “battery” (II).

## 2 - Measuring head battery charger (radio version only)

The measuring heads are powered by rechargeable batteries whose charge is displayed on the home page.

LH FRONT

LH REAR



RH FRONT

RH REAR

The LED graphic bar indicates the power supply voltage and the 4 indicators show the measuring heads in the

respective working positions. If one or more graphic bars are “grey” , it means that the respective measuring head is not connected to the BLUE TOOTH receiver.



LIGHT BLUE INDICATOR: BATTERY RECHARGING (or recharging just completed)



GREEN INDICATOR: GOOD CHARGE



YELLOW INDICATOR: SUFFICIENT CHARGE to complete the measurement in progress



**CAUTION!**

**Connect the power cable leading from the cabinet to the measuring head as soon as possible.**



RED INDICATOR: INSUFFICIENT CHARGE



**CAUTION!**

**Connect the power cable leading from the cabinet to the measuring head before continuing with the measurement.**

When connecting the power cable leading from the cabinet to a measuring head, the head is powered and the batteries charged.

An alignment measurement can be carried out at any time even when the recharge cable is connected to one or more measuring heads.

*For a full recharge:*


- position the wheel clamp/measuring head on the housing on the side of the cabinet (Fig. 9b)
- connect an extension cable for the battery charger ( Fig. 9c).



**CAUTION!**

***In order to charge the batteries, the cabinet and the measuring heads must be switched on while the software can be active in any phase (e.g. on the home page).***

9b



9c



*To terminate recharging:*

- turn off the cabinet with the ON/OFF switch
- or disconnect the measuring head power cable.



**CAUTION:**

***Correct recharging of the batteries is represented by the blue battery indicator or by flashing in sequence of the level indicator LEDs when the measuring heads have been non-operational for a few minutes (e.g. SCREEN-SAVER).***

To save the batteries, the measuring heads automatically switch off after a certain time of inactivity. At the same time, the screen goes black.

To prevent automatic switch-off or to change the time before switch-off  chapter 5.2.1.

*To reactivate the system:*

1. Switch on all the measuring heads (wait about 5 sec. between one and the next)
2. Press any key on the keyboard

## 2.1 - Improving the life of the measuring head batteries

|                       |                                                                                                                                            |
|-----------------------|--------------------------------------------------------------------------------------------------------------------------------------------|
| <b>Applicable to</b>  | All radio models, all series                                                                                                               |
| <b>Addressed to</b>   | All                                                                                                                                        |
| <b>Related topics</b> | How to replace the battery of a measuring head (  17.3) |

### Start here

The battery charge duration in normal conditions is one working day with full-time use or a few working days when occasionally used.

The battery life, if properly managed, is 2-3 years of operation.

Too frequently recharging the batteries or not fully recharging them may compromise the battery life and the charge duration.

*To improve the charge duration and life of the measuring head batteries, follow these guidelines:*


- Recharge the batteries for at least 4 hours, for example overnight, to assure that they are fully recharged.
- Recharge the batteries when the charge indicator on the screen is yellow. If you wait until the indicator turns red, you do not ruin the batteries, but you risk the measuring heads turning off during operation.
- Do not recharge the batteries when the indicator is green in order not to compromise the battery life.

*Other useful tips:*

- If you recharge overnight, make sure that the mains switch is not turned off
- Keeping the batteries connected to the power supply when they are fully charged does NOT ruin the batteries. The measuring heads automatically suspend the recharge when it has been completed.
- Remember that to recharge the batteries:
  - [cabinets with 2-state power button (0,I)] Set the button to I. To recharge the batteries, the computer must remain on.
  - [cabinets with 3-state power button (0,I,II)] Set the button I or II. In the second case, in spite of the batteries charging, the computer remains off in order to reduce consumption and wear. We recommend this option for overnight recharging.
- If after a full recharge the batteries are unable to last through a working day with occasional use, they should be replaced How to replace the battery of a measuring head ( 17.3)

### 3 - Program flow

The program is made up of 8 main pages; to go to the next or previous page, press **F6**, **F5** respectively.



## 4 - Setting up for measurement

To prepare for measurement:

1. Position the vehicle
2. Mount the wheel clamp and the measuring heads on the vehicle wheels
3. Press any key to turn on the 4 measuring heads



**NOTE:**

*Wait about 5 sec. between turning on one measuring head and the next one.*

- 4 Turn on the computer. The following appears:

10



5. Press any key on the keyboard




**NOTE:**

*The measuring heads must be switched on before pressing a key on the keyboard.*

## 5 - Home page

11



**NOTE:**

*The on-screen buttons can be activated with the mouse and with the , ...,  on the keyboard.*

|                                                                                   |                                                                                                                                                          |
|-----------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | : Help                                                                                                                                                   |
|  | : Measurement with two arms                                                                                                                              |
|  | : Menu                                                                                                                                                   |
|  | : goes directly to measurement without vehicle selection  (chapter 8) |
|  | : previous page                                                                                                                                          |
|  | : next page (vehicle make and model selection)  (chapter 6)            |

### 5.1 - Measurement with 2 measuring heads

To save measuring time, the measurement can be made by mounting only the front measuring heads. This method can be used if the front toe-in and camber measurements are sufficient and the steering wheel does not have to be held straight; for example, for small commercial vehicles.

*Operate as follows:*

1. On the home page press . The ball on the screen turns green (  Fig. 3)
2. Press  and continue as normal with the measurement



**NOTE:**


***Using this method, the following will not be executed: runout for the rear wheels, steering, rear adjustment and caster.***

## 5.2 - MENU



Pressing  the following menu appears:

12



: set up machine



: client database



: TEST (reserved for technical service)




: angle calibration (reserved for technical service)

### 5.2.1 - Set-up

Pressing , the following SETUP page is accessed

13



*The following parameters can be modified on this page :*

- 1• DATE
- 2• TIME
- 3• INACTIVITY TIME BEFORE THE BATTERIES AUTOMATICALLY SWITCH OFF
- 4• LANGUAGE
- 5• ANGLE FORMAT (centesimal/sexagesimal)
- 6• ANGLE RESOLUTION
- 7• TOE-IN FORMAT (expressed in degrees / mm / inches)
- 8• TOE-IN RESOLUTION
- 9• KM or MILES (for printing)
- 10• DATA TRANSMISSION VIA RADIO (on/off)
- 11• RUNOUT (on / bypass= the runout page is automatically skipped)
- 12• "F1,...,F7" DISPLAY ON KEYS (on/off)
- 13• MOUSE (on/off)
- 14• KEYBOARD TYPE
- 15• DATABASE
- 16• SETUP PAGE PASSWORD
- 17• PRINTER MODEL
- 18• PRINT OUT-OF-TOLERANCE VALUES IN RED (on/off)
- 19• PRINT HEADER
- 20• PRINT FOOTER



: Help



: saves the settings and exits from setup



: selects the next parameter



+



: selects the previous parameter



/



: scrolls the values of the parameter selected

**Space bar** : displays the possible values of the selected parameter

(confirm with )

When  is pressed, the client database page as shown in *Figure 14* is accessed

The screenshot shows a Windows XP desktop with a blue background. A file explorer window is open, displaying a list of files and folders. A red arrow points to the search icon in the top-left corner of the window. The list includes files like 'a1uc1', 'a1uc2', 'a1uc3', etc., and folders like 'a1uc1', 'a1uc2', 'a1uc3', etc.

| File/Folder Name | Size   | Date       |
|------------------|--------|------------|
| a1uc1            | au111  | 26/08/2004 |
| a1uc2            | au222  | 26/08/2004 |
| a1uc3            | au333  | 26/08/2004 |
| a1uc4            | au444  | 26/08/2004 |
| a1uc5            | au555  | 26/08/2004 |
| a1uc6            | au666  | 26/08/2004 |
| a1uc7            | au777  | 26/08/2004 |
| a1uc8            | au888  | 26/08/2004 |
| a1uc9            | au999  | 26/08/2004 |
| a1uc10           | au1000 | 26/08/2004 |
| a1uc11           | au1111 | 26/08/2004 |
| a1uc12           | au1222 | 26/08/2004 |
| a1uc13           | au1333 | 26/08/2004 |
| a1uc14           | au1444 | 26/08/2004 |
| a1uc15           | au1555 | 26/08/2004 |
| a1uc16           | au1666 | 26/08/2004 |
| a1uc17           | au1777 | 26/08/2004 |
| a1uc18           | au1888 | 26/08/2004 |
| a1uc19           | au1999 | 26/08/2004 |
| a1uc20           | au2000 | 26/08/2004 |
| a1uc21           | au2111 | 26/08/2004 |
| a1uc22           | au2222 | 26/08/2004 |
| a1uc23           | au2333 | 26/08/2004 |
| a1uc24           | au2444 | 26/08/2004 |
| a1uc25           | au2555 | 26/08/2004 |
| a1uc26           | au2666 | 26/08/2004 |
| a1uc27           | au2777 | 26/08/2004 |
| a1uc28           | au2888 | 26/08/2004 |
| a1uc29           | au2999 | 26/08/2004 |
| a1uc30           | au3000 | 26/08/2004 |
| a1uc31           | au3111 | 26/08/2004 |
| a1uc32           | au3222 | 26/08/2004 |
| a1uc33           | au3333 | 26/08/2004 |
| a1uc34           | au3444 | 26/08/2004 |
| a1uc35           | au3555 | 26/08/2004 |
| a1uc36           | au3666 | 26/08/2004 |
| a1uc37           | au3777 | 26/08/2004 |
| a1uc38           | au3888 | 26/08/2004 |
| a1uc39           | au3999 | 26/08/2004 |
| a1uc40           | au4000 | 26/08/2004 |
| a1uc41           | au4111 | 26/08/2004 |
| a1uc42           | au4222 | 26/08/2004 |
| a1uc43           | au4333 | 26/08/2004 |
| a1uc44           | au4444 | 26/08/2004 |
| a1uc45           | au4555 | 26/08/2004 |
| a1uc46           | au4666 | 26/08/2004 |
| a1uc47           | au4777 | 26/08/2004 |
| a1uc48           | au4888 | 26/08/2004 |
| a1uc49           | au4999 | 26/08/2004 |
| a1uc50           | au5000 | 26/08/2004 |

-  : Help
-  : selects the search box or the table
-  : after entering the customer's name or vehicle number plate, the search is started
-  : deletes the selected "customer test" folder
-  : returns to the initial screen
-  /  : selects the desired customer
-  : positions on the first customer whose name starts with the letter entered
-  : confirms and displays the data relating to the selected customer

14a



**ALFA ROMEO**

145 1.4/1.6 TS

4058043- > 1996-1999

| Measured |       |       |                | Adjusted |       |       |  |
|----------|-------|-------|----------------|----------|-------|-------|--|
| Left     | Right | Delta |                | Left     | Right | Delta |  |
| 1°20     |       |       | Total toe-in   | 1°20     |       |       |  |
| 1°00     | 0°20  |       | Partial toe-in | 1°00     | 0°20  |       |  |
| 0°00     |       |       | Set-back       | 0°00     |       |       |  |
| 2°30     | 2°50  | 0°20  | Camber angle   | 2°30     | 2°50  | 0°20  |  |
| ---      | ---   |       | Caster         | ---      | ---   |       |  |
| ---      | ---   |       | SAI            | ---      | ---   |       |  |
| 0°90     | 0°80  | 0°10  | Curve toe-in   | 0°90     | 0°80  | 0°10  |  |
| 0°70     |       |       | Total toe-in   | 0°70     |       |       |  |
| 1°00     | -0°30 |       | Partial toe-in | 1°00     | -0°30 |       |  |
| 0°34     |       |       | Set-back       | 0°34     |       |       |  |
| 2°00     | 1°90  | 0°100 | Camber angle   | 2°00     | 1°90  | 0°100 |  |
| 0°05     |       |       | Thrust angle   | 0°05     |       |       |  |

?

⌵

⌶


<<

>>

## 6 - Vehicle database

### 6.1 - Selecting the vehicle make

15



- F1** : Help
- F2** : to enter notes on the customer
- ↓** / **↑** / **F** : to select the desired make
- F5** : previous page.
- F6** / **Enter** : to confirm the vehicle make selected

### 6.2 - Entering notes on the client

When **F2** is pressed the customer and other details can be entered.

15a

|                            |  |
|----------------------------|--|
| Customer Number            |  |
| Name                       |  |
| Street                     |  |
| City                       |  |
| Telephone                  |  |
| Technician                 |  |
| Work order ID              |  |
| Vehicle (VIN)              |  |
| Plate number               |  |
| First Reg.                 |  |
| Km                         |  |
| Date                       |  |
| Model                      |  |
| Complaint                  |  |
| Tire make                  |  |
| Tire size                  |  |
| Tire pression (cold tires) |  |
| Tire tread depth           |  |

**>>**

|                           |                             |
|---------------------------|-----------------------------|
| <b>Tab</b>                | : selects the next note     |
| <b>Shift</b> + <b>Tab</b> | : selects the previous note |
| <b>F6</b>                 | : saves the notes and exits |

### 6.3 - Selecting the vehicle model

16



#### NOTE:

If the model name is preceded by the symbol , it belongs to the customised database.

|                                |                                                                      |
|--------------------------------|----------------------------------------------------------------------|
| <b>F1</b>                      | : Help                                                               |
| <b>F2</b>                      | : to enter notes on the customer                                     |
| <b>F3</b>                      | : model search by year of registration (results in decreasing order) |
| <b>F4</b>                      | : like above, but results in increasing order                        |
| <b>↓</b> / <b>↑</b> / <b>F</b> | : model selection                                                    |
| <b>F5</b>                      | : previous page (vehicle make selection)                             |
| <b>F6</b> / <b>Enter</b>       | : confirms the model selected and goes to the database               |



Do you have any feedback? Please write to [manuals@enet.it](mailto:manuals@enet.it) specifying the code I 0587-GB

## 7 - Displaying the technical data of the vehicle selected

17

1. Pitch and track measurements.

2. Brand, model, technical name, date of start and end of production.

3. Characteristic angles: minimum/standard/maximum value and difference between right-hand and left-hand wheel. The angles next to the vertical orange line refer to the front wheels while those next to the blue line refer to the rear wheels.

4. If the monkey spanner symbol appears, you can adjust the angle on the vehicle.

5. If the camera symbol appears, you can view explanatory images of the adjustment.

6. Diameter of the rim.

|                   | Min.   | Std    | Max    | Delta |  |  |
|-------------------|--------|--------|--------|-------|--|--|
| Total toe-in      | 0.16°  | 0.33°  | 0.50°  | --    |  |  |
| Camber angle      | -1.00° | -0.83° | -0.66° | 0.33° |  |  |
| Caster            | 9.90°  | 10.40° | 10.90° | 0.50° |  |  |
| SAI               | --     | --     | --     | --    |  |  |
| 20° toe-out       | 0.08°  | 0.58°  | 1.08°  | --    |  |  |
| Max int. steering | 41.50° | 43.00° | 44.50° | --    |  |  |
| Max ext. steering | 32.50° | 34.00° | 35.50° | --    |  |  |
| Total toe-in      | 0.09°  | 0.42°  | 0.59°  | --    |  |  |
| Camber angle      | -1.92° | -1.42° | -0.92° | --    |  |  |

The screen shows the following technical data of the vehicle:

1. Pitch and track measurements.
2. Brand, model, technical name, date of start and end of production.
3. Characteristic angles: minimum/standard/maximum value and difference between right-hand and left-hand wheel. The angles next to the vertical orange line refer to the front wheels while those next to the blue line refer to the rear wheels.
4. If the monkey spanner symbol appears, you can adjust the angle on the vehicle.
5. If the camera symbol appears, you can view explanatory images of the adjustment.
6. Diameter of the rim.



### NOTE:

for some vehicles (e.g. some AUDIs, the toe-in curve data may be present. In this case, the "AUDI" symbol is displayed on the screen ( 11.2).

18

|                   | Min.   | Std    | Max    | Delta |  |  |
|-------------------|--------|--------|--------|-------|--|--|
| Total toe-in      | 0.17°  | 0.33°  | 0.50°  | --    |  |  |
| Camber angle      | -1.50° | -1.08° | -0.67° | 0.50° |  |  |
| Caster            | --     | --     | --     | --    |  |  |
| SAI               | --     | --     | --     | --    |  |  |
| 20° toe-out       | --     | --     | --     | --    |  |  |
| Max int. steering | --     | --     | --     | --    |  |  |
| Max ext. steering | --     | --     | --     | --    |  |  |
| Total toe-in      | 0.10°  | 0.27°  | 0.43°  | --    |  |  |
| Camber angle      | -1.17° | -0.67° | -0.17° | 0.50° |  |  |

F1

: Help

F2

: to display any images relating to the adjustment points

page +, F3

: creating a customised database

F4

: sets the chassis height and displays any additional information



: previous page (vehicle model selection)



: next page



: changes the diameter of the rim of the vehicle measured (obligatory if the toe-in is expressed in mm or inch)



**NOTE:**


*if the toe-in is expressed in mm or inch, it is essential to set the correct rim diameter.*

## 7.1 - Images of the adjustment points



When selecting this option (  /  ) the screen shown in *Figure 19* is displayed:

19



: Help



: displays the image relating to the next adjustment point (if present)




: previous page

## 7.2 - Chassis height F4

This option allows setting some parameters to perfect vehicle diagnostics. It is active only for some vehicles.

1. Selecting (F4 / H↑) ; the following appears:

20




2. With reference to the figure, select the correct chassis height in the table

- F1 : Help
- F3 : shows the data related to the percentage fuel level and positioning of the vehicle load weights
- Tab / Shift + Tab : to activate the selection in the table
- ↓ / ↑ : to select the correct chassis height
- F5 : confirm the data and returns to the vehicle database page

3. Press F3; the following appears:

20a



4. Enter the percentage fuel level and any weight in the passenger and luggage compartments

- F1 : Help
- F2 : returns to the chassis height table
- F5 : returns to the vehicle database page

## 7.3 - Customising the vehicle database F3

Customised vehicles can be created; to access this function, display the data page of a make and a vehicle already in the database:

20b

|                   | Min.   | Std    | Max    | Delta |  |  |
|-------------------|--------|--------|--------|-------|--|--|
| Total toe-in      | 0.16°  | 0.33°  | 0.50°  | ---   |  |  |
| Camber angle      | -1.00° | -0.83° | -0.66° | 0.33° |  |  |
| Caster            | 9.90°  | 10.40° | 10.90° | 0.50° |  |  |
| SAI               | ---    | ---    | ---    | ---   |  |  |
| 20° toe-out       | 0.08°  | 0.58°  | 1.08°  | ---   |  |  |
| Max int. steering | 41.50° | 43.00° | 44.50° | ---   |  |  |
| Max ext. steering | 32.50° | 34.00° | 35.50° | ---   |  |  |
| Total toe-in      | 0.09°  | 0.42°  | 0.59°  | ---   |  |  |
| Camber angle      | -1.92° | -1.42° | -0.92° | ---   |  |  |

page + F3 : in sequence press the keys to access a page dedicated to creating a customised data base

20c

|                   | Min.   | Std    | Max    | Delta | ADJ |
|-------------------|--------|--------|--------|-------|-----|
| Total toe-in      | 0.16°  | 0.33°  | 0.50°  |       | R   |
| Camber angle      | -1.00° | -0.83° | -0.66° | 0.33° | R   |
| Caster            | 9.90°  | 10.40° | 10.90° | 0.50° | R   |
| SAI               |        |        |        |       |     |
| 20° toe-out       | 0.08°  | 0.58°  | 1.08°  |       | N   |
| Max int. steering | 41.50° | 43.00° | 44.50° |       | N   |
| Max ext. steering | 32.50° | 34.00° | 35.50° |       | N   |
| Total toe-in      | 0.09°  | 0.42°  | 0.59°  |       | R   |
| Camber angle      | -1.92° | -1.42° | -0.92° |       | N   |

Tab : (moves forward) Selects the parameter to be customised. Use the keyboard to enter the data relating to the new vehicle to be customised

Shift + Tab : (moves back) Selects the parameter to be customised. Use the keyboard to enter the data relating to the new vehicle to be customised

F1 : selects the desired unit of measure and the tolerance indication (for data input)  
 /60 degrees displayed in sexagesimal format (e.g. 1° 55')  
 /100 degrees displayed in centesimal format (e.g. 1.90°)  
 min/std/max = data in minimum/standard/maximum format  
 std/toll+/toll- = data in standard/upper tolerance/lower tolerance format

F2 : saves the modifications made to the customised vehicle (active only when working in a database of a customised vehicle)


F3 : saves the new vehicle model in the customised database

- F4** : deletes the database of a customised vehicle (active only when working in a database of a customised vehicle)
- F5** : returns to the previous page
- Esc** : after saving the entries in the database, returns to the initial page

## 8 - Runout

The runout procedure is useful to compensate for possible errors in rim/wheel clamp coupling. This procedure can also be skipped going directly to the measuring phase.


21



- F1** : Help
- F2** : choice between runout with 90° or 180° rotation between the two measurements. The yellow indicator on the drawing represents the knob position
- F3** : choice between measuring the runout with the vehicle lifted or on the ground
- F5** : to return to the previous page
- F6** : to skip the runout operation and go to the next page

To change and set the type of runout, press **F3** as said previously and the screen shown in *Figure 22* will appear:

22



- F1** : runout with vehicle jacked up
- F2** : runout with vehicle on the ground



**NOTE:**  
During the runout measurements, secure the measuring heads in horizontal position.




**NOTE:**  
90° rotation must be backward (clockwise for the left-hand wheels and counterclockwise for the right hand wheels); 180° rotation may be in both directions.


### 8.1 - Runout with vehicle jacked up

1. Before measuring this type of runout, the wheel clamps with the measuring heads must have been fitted on the wheels, the vehicle lifted and the plates released.
2. Starting from any measuring head (the right-hand front in this example), turn the wheel until the wheel clamp knob is in the position suggested on the screen: down for 180° runout (Fig. 23), or 90° towards the rear of the vehicle for 90° runout (Fig. 23a).

**23**




**23a**




**NOTE:** The wheel clamp knob is yellow coloured on the screen.

3. Level the measuring head and press the keypad **OK** on it; the following appear in succession:

24




25



4. Turn the wheel 90° or 180° so that the wheel clamp knob moves upward as suggested on the screen.
5. Level the measuring head and press again the keypad **OK** on it; the following appear in succession:

25a






6. Carry out the same operations on the other wheels (if necessary, they can be repeated)
7. lower the vehicle, bed in the suspensions and position the brake pedal lock.



**NOTE:**

*If the system detects an excessive error during the runout phase, the following screen will be displayed:*




Check mounting of the wheel clamps and that they are properly coupled to the measuring heads.

Proceed by following the instructions in  paragraph 8.3.

## 8.2 - Runout with vehicle on the ground

1. Before doing this type of runout, the wheel clamps with the measuring heads should already have been mounted on the wheels and the vehicle positioned in proximity of the locked turntables (half a wheel turn) like described:
  - 180° in front of or behind the turntables (*fig. 27*)
  - 90° behind the turntables (*fig. 27a*)

27




27a




2. Press **OK** on the keypad of any measuring head; the following appear in succession:

28




29



3. Push the vehicle by a half or quarter wheel turn until it is positioned above the plates.
4. Press again **OK** on the measuring head keypad. the following appear in succession:

30



31






**NOTE:**

*If the system detects an excessive error during the runout phase, the following screen will be displayed:*

32




Check mounting of the wheel clamps and that they are properly coupled to the measuring heads.

### **8.3 - Final operations**

Having finished the runout measurements, both with the vehicle lifted and on the ground:

1. Press **F6**; the following appears:

32a



2. Release the plates, fit the brake lock and align the vehicle suspension.

After about 15 seconds, it automatically goes to the next phase.



: goes to the next phase before the 15 seconds have elapsed



Do you have any feedback? Please write to [manuals@enet.it](mailto:manuals@enet.it) specifying the code I 0587-GB

## 9 - Steering

The steering function allows measuring the characteristic steering angles: caster, upright inclination, angle included, cornering toe-out.

It consists of making several measurements with the wheels steered at different steering angles.

You can select from three steering modes:

- FAST steering: recommended because it is fast to execute
- 10° or 20° steering: required only to measure the cornering toe-out or to comply with a procedure of the vehicle manufacturer

To select the type of steering, on the steering page:

1. Press , to access the menu

33



2. Press the key corresponding to the desired steering mode



: 10° steering  Par. 9.2



: 20° steering  Par. 9.2



: Fast steering  Next Par.

### 9.1 - Fast steering

Fast steering allows reducing the time required to execute steering compared to the classic 10° or 20° steering.

To execute fast steering, follow the on-screen instructions:

34



1. Steer to the left until the word '**STOP**' appears

35




2. Without moving the steering wheel, wait for the word '**STOP**' to disappear

36



3. Steer to the left until the word '**STOP**' appears again
4. Without moving the steering wheel, wait for the word '**STOP**' to disappear
5. Steer to the left until a pair of yellow triangles appears

37



6. Steer until the triangles are aligned. The word '**STOP**' appears again.

38



7. Without moving the steering wheel, wait a few seconds.


The vehicle diagnostics screen appears  Chap. 10. Otherwise, steering has been completed.

## 9.2 - 10° or 20° steering

10° or 20° steering is required to measure the cornering toe-out or to comply with a procedure of the vehicle manufacturer. In other cases, it is recommended to use fast steering.

To execute 10° or 20° steering, follow the on-screen instructions:

39




1. Turn the steering wheel to the left until the orange triangle lines up with the vertical bar. The word **STOP** appears:

40



2. Without moving the steering wheel, wait for the word **STOP** to disappear. Depending on the case, the following screen may appear or directly the one shown in Fig. 42a.

41




3. If the above screen appears, turn the steering wheel until the green triangle lines up with the vertical bar. The word **STOP** appears

42



4. Without moving the steering wheel, wait for the word **STOP** to disappear. The following appears:

42a




5. Turn the steering wheel to the right until the green triangle lines up with the vertical bar. The word **STOP** appears

42b




6. Without moving the steering wheel, wait for the word **STOP** to disappear. Depending on the case, the following screen may appear or directly the one shown in Fig. 43.

42c




7. If the above screen appears, turn the steering wheel until the orange triangle lines up with the vertical bar. The word **STOP** appears

42d



8. Without moving the steering wheel, wait for the word **STOP** to disappear. The following appears:

43



9. Turn the steering wheel to the left until both triangles line up with the vertical bar. The word **STOP** appears

44



10. Without moving the steering wheel, wait for the word **STOP** to disappear. The vehicle diagnostics screen appears (👉 next chapter).

👉 Do you have any feedback? Please write to [manuals@enet.it](mailto:manuals@enet.it) specifying the code I 0587-GB

## 10 - Vehicle diagnostics

After having carried out the steering procedure, the diagnostics page is displayed, which summarizes the measurements made on the vehicle.

45



| Database |        |        |       | Measured       |       |        |       |
|----------|--------|--------|-------|----------------|-------|--------|-------|
| Min.     | Std    | Max    | Delta |                | Left  | Right  | Delta |
| 0.16°    | 0.33°  | 0.50°  | --    | Total toe-in   |       | 1°20'  |       |
|          |        |        |       | Partial toe-in | 1°00' | 0°20'  |       |
|          |        |        |       | Set-back       |       | 0°00'  |       |
| -1.00°   | -0.83° | -0.66° | 0.33° | Camber angle   | 2°30' | 2°50'  | 0°20' |
| 9.90°    | 10.40° | 10.90° | 0.50° | Caster         |       |        |       |
|          |        |        |       | SAI            |       |        |       |
|          |        |        |       | Curve toe-in   | 0°30' | 0°20'  | 0°10' |
| 0.09°    | 0.42°  | 0.59°  | --    | Total toe-in   |       | 0°40'  |       |
|          |        |        |       | Partial toe-in | 1°00' | -0°30' |       |
|          |        |        |       | Set-back       |       | 0°34'  |       |
| -1.92°   | -1.42° | -0.92° | --    | Camber angle   | 2°00' | 1°50'  | 0°10' |
|          |        |        |       | Thrust angle   |       | 0°05'  |       |

F1

: Help

F2

: notes on client can be entered

F5

: previous page (steering)


F6

: next page (vehicle adjustment - rear axle)

## 11 - Vehicle adjustment

The following screen appears:

45a



After about 15 seconds, it automatically goes to the next phase.

F6

: goes to the next phase before the 15 seconds have elapsed



### NOTE:

**Before proceeding with vehicle adjustment position the steering wheel straight using the steering lock.**


There are two procedures to adjust the vehicle:

1. "Normal" procedure
2. "Audi" procedure


The software automatically selects the correct procedure for the vehicle.

### 11.1 - Normal procedure


A screen appears indicating the camber angle, toe-in and thrust angle for the rear wheels:



Each angle is shown both as a value



and in graphic form by means of a white pointer on a green and red scale:



1. Adjust the vehicle in such a way that the white pointer is on the green area. The green area of the scale represents the angles within tolerance and the red one the angles out of tolerance.




**N.B.:** If the red and green scales are difficult to see, they can be enlarged (👉 par. 11.3)



**N.B.:** if it is necessary to lift the wheels off the ground to adjust the vehicle, carry out the freeze procedure (👉 par. 11.4)

2. Press **F6**

The front wheel adjustment screen appears:




3. Adjust the camber angle, caster and toe-in of the front wheels until the white pointers are on the green areas.

4. Press **F6**.

## 11.2 - Audi procedure

In certain conditions, but not always, a screen appears for adjustment of the camber angle and caster (not toe-in) of the front wheels.




1. Adjust and press **F6**

The rear adjustment screen appears (similar to Fig. 46).

2. Adjust and press **F6**

The following message appears:

49




If the vehicle falls within one of the cases contemplated in the message, press **F6** and jump to point 4. Otherwise, press **F5** and go to the next point.

3. The front adjustment screen appears (Fig. 47)

Adjust and press **F6**. The procedure has now been completed.

4. The following appears:

49a




Lift the vehicle

5. Fit the adapters to the Audi type chassis

6. Press **F6**

The following appears:


49b



7. Adjust the toe-in.

8. Press **F6**; the following appears:

49c




9. Lift the vehicle and remove the adaptors, then lower the vehicle
10. Press **F6**. The procedure has now been completed.

### 11.3 - Zoom

From any adjustment screen:


1. Press once **OK** to enlarge the camber angle

50



2. Press again **OK** to enlarge the toe-in

50a




Press **OK** a third time to return to normal display.

## 11.4 - Freezing

The measurement freeze function is useful if needing to lift the wheels off the ground to allow adjustment.

1. Press **F2** or click on  to freeze the angles. The following appears:
2. Lift the vehicle

51



3. Press **F2** or click on  to unfreeze the angles
4. Adjust the rear
5. Press **F6** to go to front adjustment
6. Adjust the front
7. Press **F2** or click on  to refreeze the angles
8. Lower the vehicle
9. Press **F2** or click on , unfreeze the angles and finish.

## 12 - Summary of diagnostics and adjustment data

Once the front and rear axles have been adjusted, the following appears:

52

| Measured |       |       |                | Adjusted |       |       |  |
|----------|-------|-------|----------------|----------|-------|-------|--|
| Left     | Right | Delta |                | Left     | Right | Delta |  |
| 1°00     | 0°20  |       | Total toe-in   | 1°00     | 0°20  |       |  |
| 0°00     |       |       | Partial toe-in | 0°00     |       |       |  |
| 2°30     | 2°50  | 0°20  | Set-back       | 0°00     |       |       |  |
| --       | --    |       | Camber angle   | 2°30     | 2°50  | 0°20  |  |
| --       | --    |       | Caster         | --       | --    |       |  |
| --       | --    |       | SAI            | --       | --    |       |  |
| 0°50     | 0°80  | 0°10  | Curve toe-in   | 0°50     | 0°80  | 0°10  |  |
| 0°70     |       |       | Total toe-in   | 0°70     |       |       |  |
| 1°00     | -0°30 |       | Partial toe-in | 1°00     | -0°30 |       |  |
| 0°34     |       |       | Set-back       | 0°34     |       |       |  |
| 2°00     | 1°90  | 0°100 | Camber angle   | 2°00     | 1°90  | 0°100 |  |
| 0°05     |       |       | Thrust angle   | 0°05     |       |       |  |

- F1** : Help
- F2** : to enter client notes (  par. 6.2)
- F3** : final menu page
- F4** : entering the maximum steering values
- F5** : previous page (rear axle measurements)
- F6** : the next page (initial page)

## 12.1 - Final menu


When **F3** is pressed, the final menu is accessed.

53



Press **F5** to display the extra measurements (Fig. 54) with an indication of the axial deviation values, thrust axle and pitch delta in degrees and in mm (the values in mm are present only if the pitch and track values appear in the vehicle database).

54



- |                                                                                   |                                                                                                                                          |
|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------|
|  | : to return to the preliminary operations (  Chapter 8) |
|  | : to return to the steering procedure (  Chapter 9)     |
|  | : to print the test done                                                                                                                 |
|  | : to save the test done                                                                                                                  |
|  | : to display the vehicle extra measurements                                                                                              |

## 12.2 - Max steering

Pressing  you can enter the maximum internal and external steering values for the RH and LH wheels. The values entered appear in the printout:

55




 Do you have any feedback? Please write to [manuals@enet.it](mailto:manuals@enet.it) specifying the code I 0587-GB

### 13 - Aligning and levelling the measuring heads


Before the steering and adjustment procedures, check steering wheel alignment and the level of the measuring heads. Turn the steering wheel to the right or left until the wheels are aligned

56



The wheels are not aligned, steer left (Fig. 57)

57



The wheels are not aligned, steer right (Fig. 58)



58



# THE WHEELS ARE ALIGNED, DO NOT STEER.

Position the measuring heads horizontally until the green LED comes on and lock the knob.

59

|                                                                                   |                                           |     |                          |
|-----------------------------------------------------------------------------------|-------------------------------------------|-----|--------------------------|
|  | green LED on fixed                        | YES | MEASURING HEAD LEVEL     |
|  | green LED on fixed<br>RH red LED on fixed | NO  | MEASURING HEAD NOT LEVEL |
|  | RH red LED on fixed                       | NO  | MEASURING HEAD NOT LEVEL |
|  | green LED on fixed<br>LH red LED on fixed | NO  | MEASURING HEAD NOT LEVEL |
|  | LH red LED on fixed                       | NO  | MEASURING HEAD NOT LEVEL |

This operation must be carried out for all the measuring heads displayed.

After aligning and levelling the measuring heads, the program takes a few seconds to acquire the measurements of the vehicle angles,

60




and then automatically goes to the next phase.

## 14 - SPOILER procedure

The SPOILER procedure consists of lowering two measuring heads to allow the infrared rays to avoid the obstacle it poses.

61



F3 / F4


: activate the Spoiler procedure for the front/rear axle

F5

: to return to the previous page

When F4 is pressed, the procedure is activated and the following screen is displayed:


62



Release and lower the left front measuring head until the transducer on the end of the arm is under the spoiler.


Press **OK** on the keypad and the level indicator will turn green to signal the new level threshold.

63



Lower the right front measuring head until it communicates with the left front measuring head and the level indicator will turn green;

64



Press **OK** on the keypad of the right detector.


 Do you have any feedback? Please write to [manuals@enet.it](mailto:manuals@enet.it) specifying the code I 0587-GB

## 15 - Error messages


### 15.1 - Data transmission error

During normal operation the following screen may appear:

**65** - RADIO version



**65a** - CABLE version



It indicates that a data transmission error has occurred or an error of one or more measuring heads (indicated by the red square).

To restore data transmission, carry out one of the following operations:

for CABLE versions:

- check that the measuring head is on (level LED on)
- disconnect and reconnect the power cable


for RADIO versions:

- check that the measuring head is on (level LED on)
- check the battery charge level and, if necessary, connect the recharging cable
- turn the measuring head off and on again
- press "ESC" to return to the presentation page; press **F11** to reset radio communication
- carry out a new power on procedure (  chapter 4)


### 15.2 - Infrared rays break

During normal operation the following screen may appear:

**66**



**66a**



It indicates that the infrared ray between two measuring heads has encountered an obstacle:

- check for the presence of an obstacle and remove it
- if the obstacle is the spoiler of the vehicle, press **F4** or **F5** to activate the "SPOILER procedure" (  chap. 14)
- If an infrared ray is interrupted between the front and rear heads, the **F1** key allows continuing the adjustment front or rear) disabling the toe-in calculation.

## 16 - Storage and scrapping

### Storage

In the event of long-term storage, disconnect the power supply and protect those parts, such as the printer and monitor, which may be damaged by excessive accumulation of dust. Grease the parts which may be damaged if they dry out.

### Scrapping

If you decide not to use the machine any longer, it is advisable to make it inoperational. It is advisable to render harmless any parts which may constitute a source of risk. Assess the classification of the system in relation to disposal-recycling criteria. Dispose of as scrap metal through specific waste collection centres. If considered special waste, dismantle and separate into uniform groups and dispose of in accordance with the laws in force.

## 17 - Maintenance

### 17.1 - Cleaning

- Clean the monitor with a dry, soft and antistatic cloth; if it is particularly dirty, clean it with a moist cloth and then dry.
- Dust the PC keyboard with a soft brush; when not used, it is advisable to cover it with a dust sheet.
- Clean the optical units of the measuring heads using a moist cloth; do not use solvents.
- Cleaning, cartridge replacement and other operations concerning printer maintenance are described in the manual provided. Consult it carefully before carrying out any maintenance work on the printer.



#### **CAUTION!**

*Any other maintenance operation not described above (for example, testing calibration) is described in the specific installation and calibration manual; these operations should only be performed by specialist and authorised personnel.*

## 17.2 - How to check and replace the power fuses

|                        |                                                                     |
|------------------------|---------------------------------------------------------------------|
| When to replace it     | The computer cabinet does not switch on despite the power being on. |
| Instrument required    | Tester (ohm)                                                        |
| Recommended spareparts | 5x20 6.3A 250V fuses                                                |

1. Identify the power socket on the rear of the cabinet
2. Disconnect the power socket



3. Using a screwdriver, remove the two fuses housed just below the power plug
4. Check that the resistance of both fuses is around 0 Ohm
  - If so, the fuses are intact; refit them; the fault lies elsewhere
  - Otherwise, the fuses are faulty. Replace them with 5x20 6.3A 250V fuses.


## 17.3 - How to replace a measuring head battery

|                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      |
|-------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| When to replace it      | <p>When the battery does not maintain the charge for long enough (one working day with fulltime use or a few working days when occasionally use)</p> <p> <i>If a measuring head does not maintain the charge for long enough it does not necessarily mean that the battery is the cause. Before deciding to replace it try other solutions to this problem</i>  <a href="#">Troubleshooting Section TS</a></p> |
| Recommended spare parts | <p>Original spare battery (Spare part code  <a href="#">Section E</a>)</p> <p>or</p> <p>6-pack of NiMh 1.2V format AA, 2000mAh batteries, available on the market</p>                                                                                                                                                                                                                                                                                                                             |


1. Remove the cover from the measuring head by undoing the 3 screws shown in the figure.




**Do not pull the cover with force as you may damage the connections**



2. Gently remove the battery connector from the board, if necessary with the aid of pliers, and then disconnect the battery



3. If you have a 6-pack of NiMh 1.2V, format AA, 2000mAh batteries available, connect it to the connector of the battery to be replaced
  - a. Cut the cables of the battery to be replaced near the battery itself



- b. Connect the cables to the new battery, carefully insulating the contact
  - c. Remove the Velcro from the battery to be replaced and attach it to the new battery, using some glue if necessary
4. Position the new battery (figure under point 2)
5. Refit the cover on the measuring head (figure under point 1)
6. Dispose of the old battery in a proper manner in accordance with the regulations in force. The procedure is now complete.

Related topics  *Par. 2.1 - Improving the life of the measuring head batteries*

## 17.4 - How to activate the vehicle database

|                      |                                                                                                             |
|----------------------|-------------------------------------------------------------------------------------------------------------|
| <b>When to do it</b> | The message “Invalid DB code” appears on the initial page i.e. you do not have the right to access the data |
| <b>Prerequisites</b> | Obtain the vehicle data activation code from your dealer                                                    |

1. Turn on the system and access the initial page




2. Access the test page

- a. Click **F3**, and again **F3**. The password prompt appears



- b. Click on the white input box and enter the password **2** **4** **6** **7**
- c. Click **Enter** to confirm. The test page appears.



3. Click **F12**. A box appears in which to enter the activation code (1)





***The box (2) contains the machine code. You might need this to request the activation code from your distributor***

4. Click on the box (1) and type in the activation code



***The letters must be in lower case***

5. Click  to save the activation code
6. Turn the system off and on. Access the initial page
  - If the message “Invalid DB code” reappears, it means that you have incorrectly entered the activation code. Repeat the procedure from point 2.
  - If the message “Invalid DB code” does not reappear, you have the right to access the data. The procedure is now complete.



***Do you have any feedback? Please write to [manuals@enet.it](mailto:manuals@enet.it) specifying the code I 0587-GB***