

www.hampton-fire.com

H35 Direct Vent Gas Fireplace

Owners & Installation Manual



MODELS: H35-NG1 Natural Gas H35-LP1 Propane

WARNING:

If the information in these instructions are not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

FOR YOUR SAFETY

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.

Installation and service must be performed by a qualified installer, service agency or the gas supplier.

FOR YOUR SAFETY

What to do if you smell gas:

- Do not try to light any appliance
- Do not touch any electrical switch: do not use any phone in your building.
- Immediately call your gas supplier from a neighbour's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.



Installer: Please complete the details on the back cover and leave this manual with the homeowner.

Homeowner: Please keep these instructions for future reference.


HAMPTON® Direct Vent Freestanding Gas Stove


To the New Owner:


Congratulations!


You are the owner of a state-of-the-art Hampton® Gas Stove by FPI FIREPLACE PRODUCTS INTERNATIONAL LTD. The H35 is a hand crafted appliance and has been designed to provide you with all the warmth and charm of a wood fireplace at the flick of a switch. The model H35 has been approved by Warnock Hersey for both safety and efficiency. As it also bears our own mark, it promises to provide you with economy, comfort and security for many trouble free years to follow. Please take a moment now to acquaint yourself with these instructions and the many features of your Hampton® Stove.

UNIT DIMENSIONS











We recommend that our products be installed and serviced by professionals who are certified in the U.S. by the National Fireplace Institute® (NFI) or in Canada by Wood Energy Technical Training (WETT).


TABLE OF CONTENTS

Unit Dimensions	2	Conversion Kit to Lower BTU Rating	
		Brick Panel	
SAFETY LABEL		Log Set Installation	
57 H = 11 = 2 H = 1		Double Door Installation	
Convert Cofety Labol	4	Decorative Door Grill Installation	
Copy of Safety Label	4	Tile Inset Installation	
		Door Hinge Removal	35
REQUIREMENTS		Wiring Diagrams	36
		Wall Thermostat	37
MA Code - CO Detector		Remote Control	37
(for state of Massachusetts only)	5		
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		OPERATING INSTRUCTIONS	
INSTALLATION			
MOTALLATION		Operating Instructions	38
O a said a said a said	0	Lighting Procedure	38
Specifications	6	Shutdown Procedure	
Information for Mobile / Manufactured	_	First Fire	
Homes After First Sale			
General Safety Information		Final Check	
Installation Checklist		Copy of the Lighting Plate Instructions	
Clearances to Combustibles		Adjusting Flame Height	
Locating Your Gas Stove		Automatic Convection Fan Operation	39
Manufactured Mobile Home Additional Requirement	ıts8		
Combustion and Ventilation Air	8	MAINTENANCE	
Optional Fan Installation			
Venting Introduction	9	Normal Operating Sounds of Gas Appliances	40
Installation Precautions	9	Maintenance Instructions	
Safety Precautions for The Installer		General Vent Maintenance	
Vent Restrictor Position	9	Log Replacement	
Exterior Vent Terminal Locations	10	Class Pontagement	41
Rigid Pipe Venting Components List		Glass Replacement	
Rigid Pipe Venting Systems		Fan Maintenance	
Rotating 45° Elbow for Straight		Removing Valve	
Horizontal Terminations	13	Installing Valve Assembly	42
Venting Arrangements			
Vertical Termination With Co-linear Flex System			
DV Stove Horizontal Vent Kit		PARTS LIST	
Dura-Vent Termination Kit			
Dura-Vent Horizontal Installations		Main Assembly	43
Dura-Vent Vertical Termination		Burner & Log Assembly	
Converting Class-A Metal Chimney or		burner a Log / toothisty	
Masonry Chimney	24		
Cathedral Ceilings		WARRANTY	
High Elevation			
Gas Connection		Warranty	47
		•	
Aeration Adjustment			
Gas Pipe Pressure Testing			
Conversion Kit #791-969 from NG to LP	21		

This is a copy of the label that accompanies each Direct Vent Freestanding Gas Stove. We have printed a copy of the contents here for your review.

NOTE: Hampton® units are constantly being improved. Check the label on the unit and if there is a difference, the label on the unit is the correct one.

COPY OF SAFETY LABEL



For the State of Massachusetts, installation and repair must be done by a plumber or gasfitter licensed in the Commonwealth of Massachusetts.

For the State of Massachusetts, flexible connectors shall not exceed 36 inches in length.

For the State of Massachusetts, the appliances individual manual shut-off must be a t-handle type valve.

The State of Massachusetts requires the installation of a carbon monoxide alarm in accordance with NFPA 720 and a CO alarm with battery back up in the same room where the gas appliance is installed.

MA Code - CO Detector (for the State of Massachusetts only)

5.08: Modifications to NFPA-54, Chapter 10

- (2) Revise 10.8.3 by adding the following additional requirements:
- (a) For all side wall horizontally vented gas fueled equipment installed in every dwelling, building or structure used in whole or in part for residential purposes, including those owned or operated by the Commonwealth and where the side wall exhaust vent termination is less than seven (7) feet above finished grade in the area of the venting, including but not limited to decks and porches, the following requirements shall be satisfied:
- 1. INSTALLATION OF CARBON MONOXIDE DETECTORS. At the time of installation of the side wall horizontal vented gas fueled equipment, the installing plumber or gasfitter shall observe that a hard wired carbon monoxide detector with an alarm and battery back-up is installed on the floor level where the gas equipment is to be installed. In addition, the installing plumber or gasfitter shall observe that a battery operated or hard wired carbon monoxide detector with an alarm is installed on each additional level of the dwelling, building or structure served by the side wall horizontal vented gas fueled equipment. It shall be the responsibility of the property owner to secure the services of qualified licensed professionals for the installation of hard wired carbon monoxide detectors
- a. In the event that the side wall horizontally vented gas fueled equipment is installed in a crawl space or an attic, the hard wired carbon monoxide detector with alarm and battery back-up may be installed on the next adjacent floor level.
- b. In the event that the requirements of this subdivision can not be met at the time of completion of installation, the owner shall have a period of thirty (30) days to comply with the above requirements; provided, however, that during said thirty (30) day period, a battery operated carbon monoxide detector with an alarm shall be installed.
- 2. APPROVED CARBON MONOXIDE DETECTORS. Each carbon monoxide detector as required in accordance with the above provisions shall comply with NFPA 720 and be ANSI/UL 2034 listed and IAS certified.
- 3. SIGNAGE. A metal or plastic identification plate shall be permanently mounted to the exterior of the building at a minimum height of eight (8) feet above grade directly in line with the exhaust vent terminal for the horizontally vented gas fueled heating appliance or equipment. The sign shall read, in print size no less than one-half (1/2) inch in size, "GAS VENT DIRECTLY BELOW. KEEP CLEAR OF ALL OBSTRUCTIONS".
- 4. INSPECTION. The state or local gas inspector of the side wall horizontally vented gas fueled equipment shall not approve the installation unless, upon inspection, the inspector observes carbon monoxide detectors and signage installed in accordance with the provisions of 248 CMR 5.08(2)(a)1 through 4.
- (b) EXEMPTIONS: The following equipment is exempt from 248 CMR 5.08(2)(a)1 through 4:
- 1. The equipment listed in Chapter 10 entitled "Equipment Not Required To Be Vented" in the most current edition of NFPA 54 as adopted by the Board: and
- 2. Product Approved side wall horizontally vented gas fueled equipment installed in a room or structure separate from the dwelling, building or structure used in whole or in part for residential purposes.
- (c) MANUFACTURER REQUIREMENTS GAS EQUIPMENT VENTING SYSTEM PROVIDED. When the manufacturer of Product Approved side wall horizontally vented gas equipment provides a venting system design or venting system components with the equipment, the instructions provided by the manufacturer for installation of the equipment and the venting system shall include:
- 1. Detailed instructions for the installation of the venting system design or the venting system components; and
- 2. A complete parts list for the venting system design or venting system.
- (d) MANUFACTURER REQUIREMENTS GAS EQUIPMENT VENTING SYSTEM NOT PROVIDED. When the manufacturer of a Product Approved side wall horizontally vented gas fueled equipment does not provide the parts for venting the flue gases, but identifies "special venting systems", the following requirements shall be satisfied by the manufacturer:
- 1. The referenced "special venting system" instructions shall be included with the appliance or equipment installation instructions; and
- 2. The "special venting systems" shall be Product Approved by the Board, and the instructions for that system shall include a parts list and detailed installation instructions.
- (e) A copy of all installation instructions for all Product Approved side wall horizontally vented gas fueled equipment, all venting instructions, all parts lists for venting instructions, and/or all venting design instructions shall remain with the appliance or equipment at the completion of the installation.

IMPORTANT MESSAGE SAVE THESE INSTRUCTIONS

The Direct Vent Freestanding Gas Stove must be installed in accordance with these instructions. Carefully read all the instructions in this manual first. Consult the building authority having jurisdiction to determine the need for a permit prior to starting the installation.

Note: Failure to follow the instructions could cause a malfunction of the heater which could result in death, serious bodily injury, and/or property damage. Failure to follow these instructions may also void your fire insurance and/or warranty.

Note: These instructions take precedence over Simpson Dura-Vent instructions.

SPECIFICATIONS

Fuels: H35-NG1 is approved for use with natural gas.

H35-LP1 is approved for use with liquefied petroleum gases (propane).

Electrical: 120V A.C. system.

Circulation Fan: Variable speed, 125/75.

Log Sets: Ceramic fibre, 7 per set.

Vent System: Coaxial (6-5/8" outer / 4" inner liner) rigid flue and termination cap.

The efficiency rating of the appliance is a product thermal efficiency rating determined under continuous operating conditions and was determined independent of any installed system.

INFORMATION FOR MOBILE / MANUFACTURED HOMES AFTER FIRST SALE

This Hampton® product has been tested and listed by ITS Testing Services as a Direct Vent Wall Furnace to the following standards: CGA-2.17-M91, and ANSI Z21.88b-2003/CSA 2.33b-2003.

This Direct Vent System Appliance must be installed in accordance with the manufacturer's installation instructions and the Manufactured

Home Construction and Safety Standard, Title 24 CFR, Part 3280, or the current Standard of Fire Safety Criteria for Manufactured Home Installations, Sites, and Communities ANSI/NFPA501A, and with CAN/CSAZ240-MH Mobile Home Standard in Canada.

This appliance installation must comply with the manufacturer's installation instructions and local codes, if any. In the absence of local codes follow the current National Fuel Gas Code, ANSI Z223.1 and the current National Electrical Code ANSI/NFPA 70 in the U.S.A., and the current CAN/CGA B149 Gas Installation Code and the current Canadian Electrical Code CSA C22.1 in Canada.

This Hampton® Mobile/Manufactured Home Listed appliance comes factory equipped with a means to secure the unit.

This Hampton® Mobile/Manufactured Home listed appliance comes equipped with a dedicated #8 ground lug to which an 18 gauge copper wire from the steel chassis ground must be attached.

This appliance may only be installed in an aftermarket permanently located, manufactured (USA only)or mobile home, where not prohibited by local codes.

This appliance is only for use with the type of gas indicated on the rating plate. This appliance is not convertible for use with other gases, unless a certified kit is used.

BEFORE YOU START

Safe installation and operation of this appliance requires common sense, however, we are required by the Canadian Safety Standards and ANSI Standards to make you aware of the following:

INSTALLATION AND REPAIRS SHOULD BE DONE BY A QUALIFIED SERVICE PERSON. THIS APPLIANCESHOULD BEINSTALLED, REPAIRED, INSPECTED BEFORE USE AND AT LEAST ANNUALLY BY A QUALIFIED SERVICE PERSON. MORE FREQUENT CLEANING MAY BE REQUIRED DUE TO EXCESSIVE LINT FROM CARPETING, ETC. IT IS IMPERATIVE THAT THE CONTROL COMPARTMENT, BURNERS AND CIRCULATING

AIR PASSAGEWAYS OF THE AP-PLIANCE BE KEPT CLEAN.

DUE TO HIGH TEMPERATURES, THE APPLIANCE SHOULD BE LOCATED OUT OF TRAFFIC AND AWAY FROM FURNITURE AND DRAPERIES.

WARNING: FAILURE TO INSTALL THIS APPLIANCE CORRECTLY WILL VOID YOUR WARRANTY AND MAY CAUSE A SERIOUS HOUSE FIRE.

CHILDRENANDADULTS SHOULD BE ALERTED TO THE HAZARDS OF HIGH SURFACE TEMPERATURES, ESPECIALLY THE FIREPLACE GLASS, AND SHOULD STAY AWAY TO AVOID BURNS OR CLOTHING IGNITION.

YOUNG CHILDREN SHOULD BE CAREFULLY SUPERVISED WHEN THEY ARE IN THE SAME ROOM AS THE APPLIANCE.

CLOTHING OR OTHER FLAM-MABLE MATERIAL SHOULD NOT BE PLACED ON OR NEAR THE APPLIANCE.

- Provide adequate clearances for servicing, proper operation and around the air openings into the combustion chamber.
- 2) The appliance must be installed on a flat, solid, continuous surface (e.g. wood, metal, concrete). This may be the floor, or it can be raised up on a platform to enhance its visual impact. The appliance may be installed on carpeting, tile, wood flooring or other combustible material, because the appliance's base extends the full width and depth of the appliance. The Direct Vent Freestanding Gas Stove can be installed in a wide variety of ways and will fit nearly any room layout. It may be installed in a recessed position, framed out into the room, or across a corner.
- 3) The Direct Vent Freestanding Gas Stove is approved for alcove installations, which meet the clearances listed in the "Clearance to Combustibles" section. This unit is approved for manufactured home installations, see the "Manufactured Mobile Home Additional Requirements" section and the "Venting Arrangement" section for the required vent arrangements. If installed into a

manufactured home the unit must be bolted down to the floor.

- 4) This appliance is Listed for bedroom installations when used with a Listed Millivolt Thermostat. Some areas may have further requirements, check local codes before installation.
- 5) This appliance is Listed for Alcove installations, maintain minimum Alcove clearances as follows, minimum width of 40" (1016mm), a maximum depth of 36" (914mm), and minimum ceiling height of 64" (1626mm) from floor to ceiling.
- 6) We recommend that you plan your installation on paper using exact measurements for clearances and floor protection before actually installing this appliance. Have a qualified building inspector review your plans before installation.

GENERAL SAFETY INFORMATION

- 1) The appliance installation must conform with local Canadian Electrical Code.
- 2) The appliance when installed, must be electrically grounded in accordance with local codes, or in the absence of local codes with the current National Electrical Code, ANSI/NFPA 70 or CSA C22.1 Canadian Electrical Code.
- 3) The appliance should be inspected for shipping damage before use and serviced annually by a professional service person. More frequent cleaning may be required due to excessive lint from carpeting, bedding material, etc. It is imperative that control compartments, and circulating air passageways of the appliance be kept clean and free from excessive lint from carpeting.
- 4) See general construction and assembly instructions. The appliance and vent should be enclosed when installed in or passing through a living area, where children may come in contact with it.
- 5) This appliance must be connected to the specified vent and termination cap to the outside of the building envelope. Never vent to another room or inside a building. Make sure that the vent is fitted as per the instructions starting in the "Exterior Vent Terminal Locations" section.
- 6) Inspect the venting system annually for blockage and any signs of deterioration.
- 7) Venting terminals shall not be recessed into a wall or siding.

- 8) Any safety glass removed for servicing must be replaced prior to operating the appliance.
- To prevent injury, do not allow anyone who is unfamiliar with the operation to use the fireplace.

Emissions from burning wood or gas could contain chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

INSTALLATION CHECKLIST

- Locate your appliance. Refer to the following sections:
 - a. Clearances to combustibles
 - b. Locating Your Gas Stove
 - For venting requirements, see "Venting Introduction" to "Venting Arrangements" sections.
- 2) Install Optional Fan. Refer to the "Optional Fan Installation" section.
- Set vent restrictors. Refer to the "Vent Restrictor Position" section.
- **4)** Install venting. Refer to the following sections where applicable:
 - a. Check all venting requirements.
 See "Venting Introduction" to "Venting Arrangements" sections.
 - b. Vertical Termination with Co-linear Flex System
 - c. DV Stove Horizontal Vent Kit
 - d. Dura-Vent Termination Kit.
- 5) Make gas connections. Refer to the "Gas Connection" section

Test the pilot. Must be as per diagram in the "Maintenance Instruction" section.

If converting to Propane, make changes prior see the "Conversion from Natrual Gas to Propane" section.

- **6)** Test Gas Pressure. Refer to the "Gas Pipe Pressure Testing" section.
- 7) Install standard and optional features. Refer to the following sections where applicable:
 - a. Log Set Installation
 - b. Double Door Installation
 - c. Decorative Door Grill Installation
 - d. Tile Inset Installation
 - e. Wall Thermostat
 - f. Remote Control

Final check. Refer to the "Final Check" section.

Before leaving this unit with the customer, the installer must ensure that the appliance is firing correctly and operation fully explained to customer.

This includes:

- Clocking the appliance to ensure the correct firing rate (rate noted on label) after burning appliance for 15 minutes.
- If required, adjusting the primary air to ensure that the flame does not carbon. First allow the unit to burn for 15-20 min. to stabilize.


CAUTION: Any alteration to the product that causes sooting or carboning that results in damage is not the responsibility of the manufacturer.


CLEARANCES TO COMBUSTIBLES

The clearances listed are MINIMUM distances. Measure the clearance to both the appliance and the chimney connector. The farthest distance is correct if the two clearances do not coincide.

For example, if the appliance is set as indicated in one of the figures but the connector is too close, move the stove until the correct clearance to the connector is obtained.

This appliance may be installed only with the clearances as shown in the situations pictured. Do not combine clearances from one type of installation with another in order to achieve closer clearances.






E

LOCATING YOUR GAS STOVE

When selecting a location for your stove, ensure that the clearances listed above are met as well as ensuring that there is adequate accessibility for servicing and proper operation.



- A) Cross Corner
- B) Room Divider
- C) Island
- D) Flat on Wall
- E) Flat on Wall Corner
- F) Flush with Wall/Alcove


For Vent Termination requirements, see the "Exterior Vent Terminal Locations" section.

MANUFACTURED MOBILE HOME ADDITIONAL REQUIREMENTS

- 1) Ensure that structural members are not cut or weakened during installation.
- 2) Ensure proper grounding using the #8 ground lug provided.
- Appliance must be anchored to the floor with the supplied anchoring methods.

COMBUSTION AND VENTILATION AIR

The combustion air from this appliance is drawn from outside the building through the outer flue. Extra provision for combustion air inside the room is not required.




OPTIONAL FAN INSTALLATION


Fan Kit Contains:

Qty. Description

- 1 Fan Speed Controller with nut, and
 - Fan Assembly c/w green wire
 - attached
- Power cord
 - Plastic locking grommet
- 1) Remove the Top Control Panel Assembly by removing the three screws. Diagram 1.



- 2) Remove the nylon hole plug from the control panel.
- 3) Install the fan speed controller onto the control panel and secure with nut. Connect remaining wire harness wires to speed control. NOTE: Speed control wires must be in the down position when control panel is in place.
- 4) Push black knob onto speed control.
- 5) Remove the rear access panel on the back of the stove by removing the 6 screws. Install the fan onto pins as per Diagram 2.




NOTE: Do NOT damage, cut or remove the 3" aluminum air intake pipes.

Hint for pushing fan down onto pins - rub a bit of dish soap on the pins so the grommets will slide down more easily. Check to make sure the fan is seated properly on the pins - try to move the fan back and forth.

6) Push power cord through hole in the rear panel 14" - 16" and tie a loose knot in the cord on the inside to prevent the power cord from being pulled out. Diagram 2.

- Install locking grommet to power cord and push through hole in the rear panel and give a 1/4 turn to secure.
- NOTE: When running wires, keep them clear of valve assembly and tubing to avoid tangling of wires and valve.
- NOTE: Be careful not to cut wires when passing through holes in the firebox.
- 8) Run green ground wire from fan and connect to grounding lug.



- 9) Connect green power cord ground wire to grounding lug.
- **10)** Run the neutral black wire from power cord and connect to fan motor.
- **11)** Run the live black wire from power cord and connect to speed control wire.
- **12)** Connect the white wire of the wire harness to the fan terminal

NOTE: Pull excess wire next to fan to avoid excessive heat from the firebox.

- 13) Ensure all wires are pulled away from firebox to avoid excessive heat and secure with stick-on wire clip.
- **14)** Re-attach control panel with 3 screws, reversing step 1. Re-attach rear access panel with 6 screws, reversing step 5.

NOTE: When power cord is plugged in, speed control is in the ON position and stove is burning, allow 10 - 15 minutes for the thermodisc (temperature switch) to activate and turn on the Fan automatically.

WARNING:

Electrical Grounding Instructions
This appliance is equipped with
a three pronged (grounding) plug
for your protection against shock
hazard and should be plugged
directly into a properly grounded
three-prong receptacle. Do not cut
or remove the grounding prong
from this plug.

VENTING INTRODUCTION

The Horizontal Termination Kit and the Simpson Dura-Vent Direct Vent System Model DV-GS venting systems, in combination with the Direct Vent Freestanding Gas Stoves, H35-NG1, and H35-LP1, have been tested and listed as direct vent heater systems by Warnock Hersey.

These units use the "balanced flue" technology Co-Axial system. The inner liner vents products of combustion to the outside while the outer pipe draws outside combustion air into the combustion chamber thereby eliminating the need to use heated room air for combustion and losing warm room air up the chimney.

Note: These flue pipes must not be connected to any other appliance.

The gas appliance and vent system must be vented directly to the outside of the building, and never be attached to a chimney serving a separate solid fuel or gas burning appliance. Each direct vent gas appliance must use it's own separate vent system. Common vent systems are prohibited.

IMPORTANT

Read all instructions carefully before starting the installation. Failure to follow these instructions may create a fire or other safety hazard, and will void the warranty. Be sure to check the venting and clearance to combustible requirements. Consult your local building codes before beginning installation.

The location of the termination cap must conform to the requirements in the "Exterior Vent Terminal Locations" section.

INSTALLATION PRECAUTIONS

These venting systems are engineered products that have been designed and tested for use with the H35-NG1, and H35-LP1. The warranty will be voided and serious fire, health or other safety hazards may result from any of the following actions:

- 1) Installation of any damaged Direct Vent component
- 2) Unauthorized modification of the Direct Vent System
- Installation of any component part not manufactured or approved by Simpson Dura-Vent or FPI Fireplace Products International Ltd.
- Installation other than as instructed by Simpson Dura-Vent and FPI Fireplace Products International Ltd.

Warning: Always maintain required clearances (air spaces) to nearby combustibles to prevent a fire hazard. Do not fill air spaces with insulation.


Be sure to check the vent termination clearance requirements from decks, windows, soffits, gas regulators, air supply inlets and public walkways as specified in the "Exterior Vent Terminal Locations" section and in your local building codes.

The gas appliance and vent system must be vented directly to the outside of the building, and never be attached to a chimney serving a separate solid fuel or gas-burning appliance. Each direct vent gas appliance must use it's own separate vent system. Common vent systems are prohibited.


VENT RESTRICTOR POSITION

Vent restriction is required for certain venting installations, see the diagrams in "Venting Arrangment" section to determine if they are required for your installation.

To set the Vent restriction as indicated in the diagrams in the "Venting Arrangement" section, simply loosen the screws and push the vent restrictor plate to the correct position. Tighten the screws.



Horizontal Termination: Vent Restrictor setting at 36,000 Btu/h




Vertical Termination: Vent Restrictor setting at 36,000 Btu/h

SAFETY PRECAUTIONS FOR THE INSTALLER

- Wear gloves and safety glasses for protection.
- Exercise extreme caution when using ladders or on roof tops.
- Be aware of electrical wiring locations in walls and ceilings.

EXTERIOR VENT TERMINAL LOCATIONS



- K= Clearance to non-mechanical air supply inlet to building or the combustion air inlet to J= Clearance to service regulator vent outlet *(min. 36"/90cm)
 - M= **Clearance above paved sidewalk or a paved driveway located on public property L= Clearance to a mechanical air supply inlet *(min. 72"/1.8m) any other appliance *(12"/30cm)
 - *(min. 84"/2.1m)

N= Clearance under veranda, porch, deck, or balcony *(min. 12"/30cm)***

- Clearance to outside corner: with AstroCap Termination Cap (min. 6"/15cm), with Dura-
 - G= Clearance to inside corner: with AstroCap Termination Cap (min. 6"/15cm), with Dura-Vent Termination Cap (min.12"/30cm), with Riser Vent (min. 6"/15cm) Vent Termination Cap (min. 12"/30cm), with Riser Vent (min. 6"/15cm)

 - Not to be installed above a meter/regulator assembly within (3/90cm) horizontally from the centerline of the regulator. 분
- Note: * As specified in CGA B149 Installation Code. Note: Local codes or regulations may require different clearances.
- **A vent shall not terminate directly above a sidewalk or paved driveway which is located between two single family dwellings and serves both dwellings.
- ***Only permitted if veranda, porch, deck, or balcony is fully open on a minimum of two sides beneath the floor.

ocal code.

出出

Clearance to unventilated soffit (min. 12"/30cm)


RIGID PIPE VENTING COMPONENTS LIST


All Simpson Dura-Vent components are available directly from FPI.

Description	Simpson Dura-Vent Direct VentGS®	Selkirk Direct-Temp™	Amerivent® Direct Vent	Security Secure Vent®
6" Pipe Length, Galvanized	908	4DT-6	N/A	SV4L6
6" Pipe Length, Black	908B	4DT-6B	N/A	SV4LB6
7" Pipe Length, Galvanized	N/A	N/A	4D7	
, ,				#N/A
7" Pipe Length, Black	N/A	N/A	4D7B	#N/A
9" Pipe Length, Galvanized	907	4DT-9	N/A	#N/A
9" Pipe Length, Black	907B	4DT-9B	N/A	#N/A
12" Pipe Length, Galvanized	906	4DT-12	4D12	SV4L12
12" Pipe Length, Black	906B	4DT-12B	4D12B	SV4LB12
18" Pipe Length, Galvanized	N/A	4DT-18	N/A	SV4LA
18" Pipe Length, Black	N/A	4DT-18B	N/A	SV4LA
24" Pipe Length, Galvanized	904	4DT-24	4D2	SV4L24
24" Pipe Length, Black	904B	4DT-24B	4D2B	
				SV4LB24
36" Pipe Length, Galvanized	903	4DT-36	4D3	SV4L36
36" Pipe Length, Black	903B	4DT-36B	4D3B	SV4LB36
48" Pipe Length, Galvanized	902	4DT-48	4D4	SV4L48
48" Pipe Length, Black	902B	4DT-48B	4D4B	SV4LB48
Adjustable Length, 11"-14", Galv.	911	4DT-AJ	N/A	#N/A
Adjustable Length, 11"-14", Black	911B	4DT-AJB	N/A	#N/A
Adjustable Length, 17"-24", Black	917B	N/A	N/A	SV4LBA24
	N/A	N/A N/A	4D7A	
Adjustable Length, 7" Galvinized				#N/A
Adjustable Length, 7" Black	N/A	N/A	4D7AB	#N/A
Adjustable Length, 12" Galvinized	N/A	N/A	4D12A	SV4LA12
Adjustable Length, 12" Black	N/A	N/A	4D12AB	SV4LBA12
45° Elbow, Galvinized	945	4DT-EL45	4D45L	#N/A
45° Elbow, Black	945B	4DT-EL45B	4D45LB	#N/A
45° Elbow, Swivel, Galvinized	945G	N/A	N/A	SV4E45
45° Elbow, Swivel, Black	945BG	N/A	N/A	
				SV4EB45
90° Elbow, Galvinized	990	4DT-EL90S	4D90LS	#N/A
90° Elbow, Black	990B	4DT-EL90SB	4D90LBS	SV4EBR90-1
90° Elbow, Swivel, Galvinized	990G	N/A	N/A	SV4E90-1
90° Elbow, Swivel, Black	990BG	N/A	N/A	SV4EB90-1
Ceiling Support	949 - n/a from FPI	4DT-CS	4DFSP	SV4SD
Cathedral Support Box	941	4DT-CSS	4DRSB	SV4CSB
Wall Support/Band	988	4DT-WS/B	4DWS	
				SV4BM
Offset Support	989 - n/a from FPI	4DT-OS	N/A	SV4SU
Wall Thimble, Black	942	4DT-WT	4DWT	SV4RSM
Wall Thimble Support Box/Ceiling Support	940	N/A	N/A	SV4PF
Firestop Spacer	963	4DT-FS	4DFSP	SV4BF
Trim Plate, Black	N/A	4DT-TP	4DFPB	SV4LA
Brass Trim for Wall Thimble/Ceiling Support	3951	N/A	N/A	#N/A
Attic Insulation Shield 12"	N/A	N/A	4DAIS12	CV/ADC A
Attic Insulation Shield - Cold Climates 36"	N/A N/A	N/A N/A	4DAIS12 4DAIS36	SV4RSA #N/A
Designation of the second	070	ADT LUC	4DLITECO	
Basic Horizontal Termination Kit (A)	970	4DT-HKA	4DHTK2	SV - SHK
Horizontal Termination Kit (B)	971	4DT-HKB	4DHTK1	SV - HK
Vertical Termination Kit	978	4DT-VKC	4DVTK	SV - FK
High Wind Vertical Cap	991	N/A	N/A	#N/A
High Wind Horizontal Cap	985	N/A	N/A	#N/A
Horizontal Square Termination Cap	984	4DT-HHC	4DHC	SV4CHC-1
Verical Termination Cap	980	4DT-HVC	4DVC	
Storm Collar	980 953	4DT-HVC 4DT-SC	4DVC 4DSC	SV4CGV-1 SV4FC
				O O
Adjustable Flashing, 0/12-6/12	943	4DT-AF6	4DF	SV4FA
Adjustable Flashing, 6/12-12/12	943S	4DT-AF12	4DF12	SV4FB
Vinyl Siding Standoff	950	4DT-VS	N/A	SV4VS
Vinyl Siding Shield Plate	N/A	4DT-VSP	N/A	SV4VS SV4VS
				55
Snorkel Termination 14"	982	4DT-ST14	4D12S	SV4STC14
Snorkel Termination 36"	981	4DT-ST36	4D36S	SV4STC36

RIGID PIPE VENTING SYSTEMS

Horizontal or Vertical Terminations





WARNING:

Do not combine venting components from different venting systems.

However use of the the AstroCap $^{\text{TM}}$ and FPI Riser is acceptable with all systems.

This product has been evaluated by Intertek for use with Duravent Direct-Vent GS, Selkirk Direct-Temp, Ameri Vent Direct venting and Security Secure Vent systems.

The FPI AstroCap[™] and FPI Riser Vent terminal are certified for installations using FPI venting systems as well as Simpson Dura-Vent[®] Direct Vent GS, American Metal Products Ameri Vent Direct Vent, Security Secure Vent[®], Selkirk Direct-Temp. AstroCap[™] is a proprietary trademark of FPI Fireplace Products International Ltd. Dura-Vent® and Direct Vent GS are registered and/or proprietary trademarks of Simpson Dura-Vent Co. Inc.

ROTATING 45° ELBOW FOR STRAIGHT HORIZONTAL TERMINATIONS

1) Remove all 4 screws that secure the elbow to the unit using a 1/4" magnetic nut driver.



- 2) Rotate the elbow 180°
- 3) Secure the elbow by securing it with the 4 screws.



Remove all 4 screws and washers

VENTING ARRANGEMENTS


Horizontal Terminations for All Venting Systems

The shaded areas in the diagram below show all allowable combinations of vertical runs with horizontal terminations. Maximum one 90° elbow (two 45° elbows equal one 90° elbow).

Propane and Natural Gas: Residential, Manufactured and Mobile Homes Installations

The venting arrangements diagrammed below, have a min. of 75% (flue loss) efficiency with Fan Off, as required for manufactured homes. (Actual efficiency may be as high as 85%)

May be installed in Manufactured (Mobile) Homes after first sale.



NOTE: See "Vent Restrictor Position" section for installation instructions for the Vent Restrictor Position.


Vertical Terminations Systems for Residential Manufactured and Mobile Homes


The shaded area in the diagram below shows all allowable combinations of straight vertical and offset to vertical runs with vertical terminations. Maximum two 45° elbows.

If the vent is ENCLOSED in a chase (min. size 9" x 9") maintain a 1-1/4" clearance to combustibles.

May be installed in Manufactured (Mobile) Homes after first sale.


Offset to Vertical Terminations






VENTING ARRANGEMENTS HORIZONTAL TERMINATIONS USING RIGID PIPE

The two diagrams show all allowable combinations of straight horizontal termination using Rigid Pipe. Restrictor position "A".







Dura-Vent Snorkel Termination

Riser Vent Termination

Venting Arrangements -Straight Horizontal Termination at a De-Rated BTU


The diagrams show all allowable combinations of straight horizontal termination using Rigid Pipe. Restrictor position "A". Refer to the "Conversion Kit to Lower BTU Rating" section for de-rating instructions.





Dura-Vent Snorkel Termination

Riser Vent Termination




*If this is an outside corner, the minimum distance between the vent and the outside corner is 6" (15cm). See "F" on the diagram in the "Exterior Vent Terminal Locations" section.

Horizontal Venting with Two (2) 90° Elbows

One 90° elbow = Two 45° elbows.


Option	٧	H + H1	With these options, maxi-	
A)	3' Min.	2' Max.	mum total pipe length is 30	
B)	4' Min.	3' Max.	feet with minimum of 8 feet	
C)	5' Min.	4' Max.	total vertical and maximum 8 feet total horizontal.	
D)	6' Min.	5' Max.	Please note minimum 1	
E)	7' Min.	6' Max.	foot between 90° elbows	
F)	8' Min.	8' Max.	is required.	
Lengths do not include elbow indicated				
Vent restrictor position A (fully open), refer to the "Vent Restrictor Position" section.				



Horizontal Venting with Two (2) 90° Elbows

One 90° elbow = Two 45° elbows.

Option	Н	٧	H + H1	With these options, ma	
A)	1' Max.	2' Min.	3' Max.	total pipe length is 30 fe with min. of 9 feet tot	
B)	2' Max.	3' Min.	5' Max.	vertical and max. 8 fe	
C)	3' Max.	5' Min.	6' Max.	total horizontal.	
D)	4' Max.	7' Min.	7' Max.	Please note min. 1 foor	
E)	5' Max.	9' Min.	8' Max.	between 90° elbows is required.	
Lengths do not include elbow indicated					
Vent restrictor position A (fully open), refer to the "Vent Restrictor Postion" section.					




Vertical Venting with Two (2) 90° Elbows

One 90° elbow = Two 45° elbows.

Option	V	Н	V + V1	With these options, max. total	
A)	1' Min.	3' Max.	2' Min.	pipe length is 30 feet with min.	
B)	2' Min.	4' Max.	3' Min.	of 6 feet total vertical and max. 7 feet total horizontal.	
C)	3' Min.	5' Max.	4' Min.	Please note min. 1 foot	
D)	4' Min.	6' Max.	5' Min.	between 90° elbows is	
E)	5' Min.	7' Max.	6' Min.	required.	
Lengths do not include elbow indicated					

Vent restrictor position A (fully open), refer to the "Vent Restrictor Postion" section.




Vertical Venting with Two (2) 90° Elbows

One 90° elbow = Two 45° elbows.

Option	H + H1	٧	With these options, max. total	
A)	2' Max.	2' Min.	pipe length is 30 feet with min.	
B)	3' Max.	3' Min.	of 6 feet total vertical and max.	
C)	4' Max.	4' Min.	6 feet total horizontal. Please note min. 1 foot	
D)	5' Max.	5' Min.	between 90° elbows is	
E)	6' Max.	6' Min.	required.	
Lengths do not include elbow indicated				
A/ 1 (11 11 11 A/6 II) 6 (II				

Vent restrictor position A (fully open), refer to the "Vent Restrcitor Postion" section.



VERTICAL TERMINATION WITH CO-LINEAR FLEX SYSTEM

THE APPLIANCE MUST NOT BE CONNECTED TO A CHIMNEY FLUE SERVING A SEPARATE SOLID FUEL BURNING APPLIANCE.

This appliance is designed to be attached to two 3" (76mm) co-linear aluminium flex running the full length of the chimney. See the Venting Arrangements chart below for minimum and maximum flue lengths. See chart below for minimum distances from roof. Periodically check that the vent is unrestricted

Minimum vertical distance in ft. (m) from roof up to lowest opening in top

8 (2.4)

7 (2.1)

8 (2.4)

7 (2.1)

8 (1.8)

9 (1.8)

9 (1.8)

9 (1.8)

Masonry chimneys may take various contours which the flexible liner will accommodate. However, **keep the flexible liner as straight as possible**, avoid unnecessary bending.

The Air Intake pipe must be attached to the inlet air collar of the termination cap.

Required Parts:

Part # Description 946-529 Co-linear DV Vertical Termination Cap 948-305 3" Flex - 35 ft.

946-563 Co-Axial to Co-Linear Adapter Kit which contains the following:
Co-linear Flex Adapter (270-585)

Outer Pipe (946-257) Inner Pipe Adapter (946-219)

Alternate Approved Caps


980 Vertical Termination Cap 991 High Wind Cap


923GK 3" Co-linear Adapter with flashing

Venting Arrangements - Vertical Terminations with Co-linear Flex System for both Residential & Manufactured Homes into Masonry Fireplaces


The shaded area in the diagram shows the allowable vertical terminations. Note: Must remove 4 screws from stove collar and rotate 180° to have collar facing straight back. Secure into place with 4 screws.

Straight Vertical Terminations





DV STOVE HORIZONTAL VENT KIT



DV STOVE HORIZONTAL VENT KIT (#946-116 & #946-216) INSTALLATION

Review the following sequence of instructions which are typical of most installations. The sequence may vary depending on wall thickness. See "Exterior Vent Terminal Locations" to "Venting Arrangements" section for vent location and clearance dimensions, and the "Vent Restrictor Position" section to set the Vent Restrictor to the correct position.


45° Elbow (Part #: 946-214)

 Set the unit in its desired location. Check to determine if wall studs will be in the way of the venting system, adjust location until all clearances are met and there are no obstructions.

Note: A1-1/2"(38mm) clearance around the outer pipe must be maintained except that only a 1" (25mm) clearance is needed at the termination end.

IMPORTANT:

Do not locate termination hood where excessive snow or ice buildup may occur. Be sure to check vent termination area after snow falls, and clear to prevent accidental blockage of venting system. When using snow blowers, make sure snow is not directed towards vent termination area.



- 2) Assemble a **trial fit** to determine the vertical center-line for the vent termination.
 - a) Cut a 9-1/2" x 9-1/2" (241mm x 241 mm) square hole on both the interior and exterior wall.


- b) Install wall thimbles on both interior and exterior wall with 4 wood screws (#8 x 1") per thimble.
- c) Attach the 2 piece adjustable pipe section to the vent terminal and slide into position from the exterior. The larger diameter end of the adjustable pipe goes to the vent terminal.
- d) Install the 90° elbow onto the adjustable pipe to determine the vertical centerline.

Note: if the centerline cannot be met, the adjustable sections will have to be cut.

e) Cut the 4 ft. section of rigid pipe to length. Attach the 45° elbow to the rigid pipe, and ensure that the pipe length when cut (with the 45° elbow) will seat onto both the starter collar and the 90° elbow. Crimped section of rigid pipe seats into the 90° elbow. Only cut the uncrimped side of pipe.

Dismantle all pipe sections including vent terminal.

INSTALLATION



#8 x 1/2" Self Tapping, Stainless Steel

 (\mathbf{E})

Qty: 4 Qty: 4

Thimble Thimble

(2 pieces)

AstroCap

Termination

Сар

 (\mathbf{C})

Qty: 4

 (\mathbf{A})

Qty: 31

(A)

Qty: 3

E

Qty: 4

#8 x 1/2" Self Tapping, Black

 (\mathbf{D})

- #8 x 11/2" Drill Point, Stainless Steel
- #8 x 11/2" Drill Point, Black
- #8 x 1" Wood Screws

Adi. Pipe

B)

Trim

Qty: 3 Collar

 \bigcirc


Qty: 1

- 5) Slide the partially connected pipe and vent terminal assembly through the wall thimbles (from the exterior into the interior) and secure the cap to the exterior wall with 4 of the supplied screws (#8 x 1-1/2" drill point, stainless steel). Note: pilot holes will need to be drilled through the wall thimble on all 4 corners.
- Note: The four screws provided for the vent cap should be replaced with appropriate fasteners for stucco, brick, concrete, or other types of sidings.
- 6) A bead of non-hardening mastic should be run around both the termination and vinyl siding standoff to prevent water from entering and to make a tight seal between the cap and the standoff.
- 7) Stretch the 4" dia. flex liner out fully and get a trial fit of the liner onto the 4" dia. starter collar
- 8) Cut the 4" dia. flex liner to the desired size.

Hint: leave an extra 12" to 16" of length, this will make the final assembly easier to work with.

- Secure the 4" dia. flex liner to the 4" adapter with Mill-Pac and 3 of the #8 x 1/2" screws (stainless steel).
- 10) Slide the decorative Thimble Cover over the pipe sections and secure with 4 screws (#8 x 1-1/2" drill point, black) to the wall.
- 11) Slide the 90° elbow (crimp end up), the 45° elbow and the 4 ft. pipe section (crimp end up) over the 4" dia. flex liner.
- 12) Install the spring spacers onto the pipe sections.

- 13) Secure the 4" dia. flex liner with adapter onto the stove collar. Put a bead of Mill-Pac around the appliance adapter and secure with 3 screws (#8 x 1/2, stainless steel).
- 14) Attach the 45° elbow onto the starter collar by sealing with Mill-Pac and/or high temperature silicone and securing with 3 of the #8 x 1/2" (black) screws.
- 15) Attach the pipe section to the 45° elbow by sealing with Mill-Pac and/or high temperature silicone and securing with 3 of the #8 x 1/2" screws (black). Pipe seams should be facing the wall.
- 16) Attach the 90° elbow onto the pipe section by sealing with Mill-Pac and/or high temperature silicone and securing with 3 of the #8 x 1/2" screws (black).
- 17) Slide the adjustable pipe section onto the 90° elbow. Slide the trim collar over the adjustable pipe sections to cover the joint of the telescopic section.) The flex may have to be compressed back in order for the adjustable pipe to properly mate to the elbow. Seal with Mill-Pac and/or high temperature silicone and secure with 3 of the #8 x 1/2" screws (black). Pipe seams facing down.
- 18) Install the trim collar over the starter collar and secure with a #8 x 1/2" screw (black).




If the pipe needs to be touched up, use only Stove Brite High Temperature Metallic Black Stove Paint.

NOTE: All inner joints must be sealed with Mill-Pac. All outer joints may be sealed with high temperature silicone.

- 3) Attach the 4" dia. flex liner to the vent terminal ensuring that the flex overlaps the collar of the vent terminal by a minimum of 1-3/8"(35mm). Use Mill-Pac to seal and secure with 3 of the #8 x 1/2" screws (stainless steel).
- 4) Attach the adjustable pipe section to the vent terminal using Mill-Pac and/or high temperature silicone and attach with 3 of the #8 x 1/2" screws (stainless steel).


Hint: Apply the sealant (Mill-Pac and/or high temperature silicone) to the outer pipe before connecting the inner pipe.

Note: The pipe s e a m Mill-Pac should be facing down



Note: To make the installation more aesthetically pleasing, we recommend framing out a square that the cap can be mounted on.

Note: If installing termination on a siding covered wall, a vinyl siding standoff or furring strips must be used to ensure that the termination is not recessed into the



siding. For vinyl siding standoff installation refer to the Dura-Vent Termination instructions

DURA-VENT TERMINATION KIT

Planning Your Dura-Vent Installation

There are two basic types of Dura-Vent Direct Vent System installations: horizontal termination and vertical termination. Confirm the maximum horizontal run and maximum vertical rise from the diagrams in the "Venting Arrangment" section.

When planning your installation, it will be necessary to select the proper length of vent pipe for your particular requirements. For horizontal installations, determine the minimum clearance from the rear of the unit to the wall. It is also important to note the wall thickness. (The wall

thimble is suitable for 2 x 4 or 2 x 6 wall construction.) Select the amount of vertical rise desired for "vertical-to-horizontal" type installations.

Warning: Always maintain required clearances (air spaces) to nearby combustibles to prevent a fire hazard. Do not fill air spaces with insulation.


The minimum clearance requirements between the outer wall of the vent pipe and nearby combustible surfaces is 1-1/4 inch. Be sure to check the vent termination clearance requirements from decks, windows, soffits, gas regulators, air supply inlets and public walkways as specified in the "Exterior Vent Terminal Locations" section and in your local building codes.

To determine the length of vent pipe required for vertical installations, measure the distance from the unit flue outlet to the ceiling, the ceiling thickness, the vertical rise in an attic or second storey, and allow for sufficient vertical height above the roof line.

For multi-storey applications, fire stops are required at each floor level. If an offset is needed, additional pipe, elbows and supports will be required.


Do not exceed the maximum number of elbows. One 90° for horizontal terminations and two 45° for vertical termination.

Dura-Vent Vertical Termination Installation




DURA-VENT HORIZONTAL INSTALLATIONS

- 1) Set the unit in its desired location. Check to determine if wall studs or roof rafters are in the way when the venting system is attached. If this is the case, you may want to adjust the location of the unit.
- 2) Direct Vent pipe and fittings are designed with special twist-lock connections to connect the venting system to the appliance flue outlet. A twist-lock appliance adapter is installed on the unit at the factory. Assemble the desired combination of pipe and elbows to the appliance adapter with pipe seams oriented towards the wall or ceiling, as much out of view as possible. The final positioning of the pipe and 90° elbow assembly is determined by the mounting orientation of the adapter on the stove and twist-locked for a solid connection.



Note:


a) Twist-lock procedure: Four indentations, located on the female ends of pipes and fittings, are designed to slide straight onto the male ends of adjacent pipes and fittings, by orienting the four pipe indentations so they match and slide in to the four entry slots on the male ends (Diagram 1). Push the pipe sections completely together, then twist-lock one section clockwise approximately one-quarter turn, until the two sections are fully locked. The female locking lugs will not be visible from the outside on the Black Pipe or fittings. They may be located by examining the inside of the female ends. Apply sealant "Mill-Pac" to inner pipe and high temp silicone sealant to outer pipe on every twist-lock joint.




b) Horizontal runs of vent must be supported every three feet. Wall straps are available for this purpose.

Snorkel Terminations:

For installations requiring a vertical rise on the exterior of the building, 14-inch and 36-inch tall Snorkel Terminations and the Riser Vent as shown in Diagrams 2 & 2a are available. Follow the same installation procedures as used for standard Horizontal Termination. NEVER install the snorkel upside down.



*As specified in CGA B149 Installation Code. Local codes or regulations may require different clearances. Dura-Vent Min. 12" Snorkel (305mm) Diagram 2



Below Grade Snorkel Installation

If the Snorkel Termination must be installed below grade, i.e. basement application, proper drainage must be provided to prevent water from entering the Snorkel Termination. Refer to Dura-Vent Installation instructions for details. Do not attempt to enclose the Snorkel within the wall, or any other type of enclosure.

3) With the pipe attached to the stove, slide the stove into its correct location, and mark the wall for a 10" x 10" (inside dimensions) square hole. The center of the square hole should line up with the centerline of the horizontal pipe, as shown in diagram 3. Cut and frame the 10 inch square hole in the exterior wall where the vent will be terminated. If the wall being penetrated is constructed of non-combustible material, i.e. masonry block or concrete, a 7" diameter hole is acceptable.





Diagram 3


INSTALLATION

Note


- a) The horizontal run of vent should have a 1/4 inch rise for every 1 foot of run towards the termination. Never allow the vent to run downward. This could cause high temperatures and may present the possibility of a fire.
- b) The location of the horizontal vent termination on an exterior wall must meet all local and national building codes, and must not be blocked or obstructed. See diagram in the "External Vent Terminal Locations" section.
- 4) If installing the vent termination to a wall with vinyl siding, the Vinyl Siding Standoff must be used. Attach the Vinyl Siding Standoff to the Horizontal Vent Termination, but first run a bead of non-hardening mastic around its outside edges, so as to make a seal between vent cap and the standoff. Install the Vinyl Siding Standoff (Part # 950) between the vent cap and the exterior wall and attach with the four wood screws provided. Seal around the Vinyl Siding Standoff on all four sides. Diagram 6. The arrow on the vent cap should be pointing up. Insure that the 1-1/4" clearances to combustible materials are maintained. See diagram 4.
- Note: If installing termination on a siding covered wall, a vinyl siding standoffor furring strips must be used to ensure that the termination is not recessed into the siding. The four wood screws provided should be replaced with appropriate fasteners for stucco, brick, concrete, or other types of sidings.



- 5) Before connecting the horizontal run of vent pipe to the vent termination, slide the black decorative wall thimble cover over the vent pipe, then slide the Wall Thimble (Part#942) over the vent pipe.
- 6) Slide the appliance and vent assembly towards the wall carefully inserting the vent pipe into the vent cap assembly. It is important that the vent pipe extends into the vent cap a sufficient distance so as to result in a minimum pipe overlap of 1-1/4 inches. Secure the connection between the vent pipe and the vent cap by attaching the two sheet metal strips extending from the vent cap assembly into the outer wall of the vent pipe. Use the two sheet metal screws provided to connect the strips to the pipe. Bend any remaining portion of the sheet metal strip back towards the vent cap, so it will be concealed by the decorative wall thimble cover. See Diagram 5.




- Install wall thimble in the center of the 10" square and attach with wood screws.
- 8) Slide the decorative wall thimble up to the wall surface being careful not to scratch the paint and attach with screws provided. Apply decorative brass or chrome trim if desired. See Diagram 6.




DURA-VENT VERTICAL TERMINATION

1) Maintain the 1-1/4" clearances (air spaces) to combustibles when passing through ceilings, walls, roofs, enclosures, attic rafter, or other nearby combustible surfaces. Do not pack air spaces with insulation. Check the "Exterior Vent Terminal Locations" section for the maximum vertical rise of the venting system and the maximum horizontal offset limitations.




2) Set the gas appliance in its desired location. Drop a plumb bob down from the ceiling to the position of the appliance flue exit, and mark the location where the vent will penetrate the ceiling. Drill a small hole at his point. Next, drop a plumb bob from the roof to the hole previously drilled in the ceiling, and mark the spot where the vent will penetrate the roof. Determine if ceiling joists, roof rafters or other framing will obstruct the venting system. You may wish to relocate the appliance or to offset, as shown in Diagram 8 to avoid cutting load bearing members.


INSTALLATION



3) To install the Round Support Box/Wall Thimble in a flat ceiling, cut a 10 inch square hole in the ceiling centred on the hole drilled in Step 2. Frame the hole as shown in Diagram 9.



4) Assemble the desired lengths of black pipe and elbows necessary to reach from the appliance adapter up though the Round Support Box. Insure that all pipes and elbow connections are in the fully twist-locked position and sealed.



Hint: Apply the sealant (Mill-Pac and/or high temperature silicone) to the outer pipe before connecting the inner pipe.

5) Cut a hole in the roof centred on the small drilled hole placed in the roof in Step 2. The hole should be of sufficient size to meet the minimum requirements for clearance to combustibles of 1-1/4". Slip the flashing under the shingles (shingles should overlap half the flashing) as per Diagram 10.




Diagram 10: The upper half of the flashing is installed under the roofing material and not nailed down until the chimney is installed.

This allows for small adjustments.

- 6) Continue to assemble pipe lengths.
- Note: If an offset is necessary in the attic to avoid obstructions, it is important to support the vent pipe every 3 feet, to avoid excessive stress on the elbows, and possible separation. Wall straps are available for this purpose. See Diagram 5.

Galvanized pipe and elbows may be utilized in the attic as well as above the roofline. The galvanized finish is desirable above the roofline due to its higher corrosion resistance.

Continue to add pipe sections through the flashing until the height of the vent cap meets the minimum height requirements specified in Diagram 11 or local codes. Note that for steep roof pitches, the vertical height must be increased. A poor draft, or down drafting can result from high wind conditions near big trees or adjoining roof lines, in these cases, increasing the vent height may solve the problem.




Diagram 11

Roof Pitch	Minimum \	ent Height/
	Feet	Meters
flat to 7/12	2	0.61
over 7/12 to 8/12	2	0.61
over 8/12 to 9/12	2	0.61
over 9/12 to 10/12	2.5	0.76
over 10/12 to 11/12	3.25	0.99
over 11/12 to 12/12	4	1.22
over 12/12 to 14/12	5	1.52
over 14/12 to 16/12	6	1.83
over 16/12 to 18/12	7	2.13
over 18/12 to 20/12	7.5	2.29
over 20/12 to 21/12	8	2.44

- 7) Ensure vent is vertical and secure the base of the flashing to the roof with roofing rails, slide storm collar over the pipe section and seal with a mastic.
- **8)** Install the vertical termination cap by twist locking it.

Notes:

- a) For multistorey vertical installations, a Ceiling Fire stop (Part # 963) is required at the second floor, and any subsequent floor. Diagram 12. The opening should be framed to 10 " x 10" inside dimensions, in the same manner as shown in Diagram 9.
- Any occupied areas above the first floor, including closets and storage spaces, through which the vertical vent passes, must be enclosed.





Diagram 12

Offset Chart

GS 6"(152mm) Nominal Diameter ID					
Offs	et	t Pipe Length (L)		Heig	ht
inches	mm	inches	mm	inches	mm
4 3/4	121	0	0	13 1/4	337
9	229	6	152	17 1/2	445
11 1/4	286	9	229	19 1/2	495
13 1/4	337	12	305	21 3/4	552
21 3/4	552	24	610	30 1/4	768
30 1/4	768	36	914	39	991
38	965	48	1219	47	1194



CONVERTING CLASS-A METAL CHIMNEY OR MASONRY CHIMNEY TO DIRECT VENT SYSTEM

There are two different types of direct vent conversion systems listed below. Follow the appropriate directions for your installation.

- A) Through an existing factory built metal chimney going through the ceiling: A typical conversion of this type is shown in diagram 1. The concept of direct vent conversion is to connect an adaptor to an Underwriters Laboratories (UL) listed 4 inch diameter aluminum flex pipe which is then passed down through the center of the existing metal chimney system. Three sizes of Top Adaptors are available from Simpson Dura-Vent. The Retro Connector (909B) is attached to the bottom of the flex pipe. The Top Adaptor and the Retro Connector are attached to the existing chimney with sheet metal screws. The appliance is then connected to the chimney with appropriate black direct vent pipe and an adjustable length section.
- B) Through the wall of an existing masonry chimney: A typical conversion of an existing masonry chimney is shown in Diagram 6. A Top Adaptor (985K) and Flashing are used at the top of the masonry chimney. The 4 inch aluminum liner is connected to the adaptor and is passed down the chimney and out through the masonry wall and attached to the Retro Connector (909B). The Retro Connector is attached to the masonry wall and then connected to the direct vent pipe leading to the appliance.

Prior to installation and connection of the vent system to a factory-built or masonry chimney, the chimney must be inspected and thoroughly cleaned by a qualified service person, such as a certified chimney sweep or home inspection service.

The direct vent system must not be connected to a damaged factory-built or masonry chimney.

For factory built, zero clearance, and masonry chimneys cleanout doors and caps or plugs for cleanout tee fittings and ash dumps shall be secured in place and sealed before installing a Direct Vent system within the chimney.


If the appliance shuts off during operation, contact a qualified service person to determine if a negative pressure and/or leaky chimney condition exists. Do not operate the appliance until the problem is corrected.

Appoved for US Installations Only

The use of an existing chimney as an air intake is not covered under the ANSIZ21.88b-1999, CSA 2.33b-M99 test methods and the resulting ITS/WHI product certification. The code Authority Having Jurisdiction must be consulted prior to proceeding with this installation method.

Converting a Factory Built Metal Chimney

- 1) Remove the existing chimney cap.
- 2) Measure the distance from the top end of the chimney to the bottom of the ceiling support box, add 3" (76mm) to this measurement, and cut a section of the 4" (102mm) flex pipe to that length (the flex should already be extended to its nominal length).



 Connect the end of the flex pipe section to the underside of the Top Adaptor using 3 sheet metal screws (refer to Diagram 2).






Diagram 2

4) Pass the flex pipe down through the center of the chimney system, and center the adaptor on the top of the chimney pipe. Drill four 1/8" diameter holes through the adaptor and into the chimney top. Insure that you are in fact, drilling into the metal on the chimney. Twist-lock the Termination Cap (Part# 980 or 991) onto the Adaptor (refer to Diagrams 3 and 4).



- 5) Pull the flex pipe down through the ceiling support box, until it protrudes approximately 3" (76mm). Connect the flex pipe to the Retro Connector by slipping it into the 4-3/4" (121mm) diameter sleeve on the top side of the Connector. Use 3 sheet metal screws to assemble these two parts.
- 6) Push the flex pipe back up into the ceiling supportbox, center the Retro Connector, and attach it to the support box, or decorative sleeve for double wall solid packed pipe, with the sheet metal screws (supplied). The holes in the Retro Connector are prepunched (refer to Diagram 5).




7) The connection between the appliance and the Retro Connector may be completed with sections of black direct vent pipe, together with an adjustable length.

CATHEDRAL CEILINGS

Round Support (RDS) & Square Support (SQS)

If your home has a cathedral ceiling (no attic space between the ceiling and the roof), install the chimney and support as follows.

- Situate the chimney in a convenient location as near as possible to the appliance outlet. Cut and frame a hole in the roof for the support. The sides of this hole must be vertical with 1 1/4" (32mm) clearance.
- Place the support in the opening. Lower it to the correct height as determined by the table and diagram below.



Slope	"X"
0/12 - 2/12	4"
2/12 - 7/12	5-1/2"
7/12 - 12/12	6-3/4"
12/12 - 24/12	7-1/2"
24/12+	12-1/2"

Using a level, make sure the support is vertical. If the support extends above the roof, cut it flush with the top of the roof. Nail the support to the frame opening using (8) 3" spiral nails or #8 x 1-1/2" screws.

Note: If you are using a 6" square support you may find it difficult to screw it in place because it is fairly small inside.

Simpson Dura-Vent has provided angle brackets with this support which can be screwed to the outside of the support box and nailed to surrounding framing as required. Use a minimum of four #8 x 1/2" screws per bracket. In some cases these brackets may need to be trimmed (e.g.: to fit under a flashing). Place the Finish Collar around the support and fasten it to the ceiling using the screws provided.

3) Use appropriate roof flashing. Place the flashing under the upper shingles and on top of the lower shingles approximately half of the flashing should be under the shingles.

- 4) Assemble the desired lengths of Black Pipe and Elbows necessary to reach from the appliance adapter up through the support box and flashing to proper height as per Diagram 12, local codes or the "Exterior Vent Terminal Locations" section. Ensure that all pipe and elbow connections are in their fully twist lock position.
- Ensure vent is vertical and secure flashing to the roof with roofing nails. Slide the storm collar over the pipe section and seal with a mastic.
- 6) Twist lock the vent cap on to the last section.

Support Extensions - Round (RDSE) or Square (SQSE)

Steep pitched cathedral ceilings may require the use of a support extension. This piece fits down inside the support and can be adjusted to increase the support's length by up to 22" (559mm). The extension is attached to the support using the eight metal screws provided. Be sure there is at least a 2" (51mm) overlap where the extension joins the support.

HIGH ELEVATION

This unit is approved in Canada for altitude to 4500 ft. (CAN/CGA-2.17-M91). For Natural Gas installations above 4500 ft. follow current CAN/CGA-B149.1.

GAS CONNECTION

The gas connection is a 3/8" NPT 90° elbow. The gas line can be rigid pipe or to make installation easier, use a listed flexible connector and/or copper tubing if allowed by local codes. Since some municipalities have additional local codes it is always best to consult with your local authorities and the CAN/CGA B149 installation codes.

For USA installations follow local codes and/or the current National Fuel Gas Code, ANSI Z223.1.

When using copper or flex connectors use only approved fittings. Always provide a union so that gas lines can be easily disconnected for burner and/or valve servicing. Flare nuts for copper lines and flex connectors are usually considered to meet this requirement.

IMPORTANT: ALWAYS CHECK FOR GAS LEAKS WITH A SOAP AND WATER SOLUTION OR GAS LEAK DETECTOR. DO NOT USE OPEN FLAME FOR LEAK TESTING.

Note: Prior to any pressure testing of the gas supply piping system that exceeds test pressures of 1/2 psig, this appliance must be disconnected from the piping system. If test pressures equal to or less than 1/2 psig are used then this appliance must be isolated from the piping system by closing its individual manual shut-off valve during the testing.

SYSTEM DATA - H35 For 0 to 4500 feet altitude

Natural Gas

Max. Input Rating 36,000 Btu/h Min. Input Rating 18,000 Btu/h Orifice Size #33 DMS

Convertible to:

Max. Input Rating 30,000 Btu/h Min. Input Rating 14,300 Btu/h Orifice Size #37 DMS

Propane

Max. Input Rating 34,000 Btu/h Min. Input Rating 17,500 Btu/h Orifice Size #51 DMS

Convertible to:

Max. Input Rating 28,500 Btu/h
Min. Input Rating 15,000 Btu/h
Orifice Size #52 DMS

Supply Pressure

Natural Gas min. 5.0" w.c.
Propane min. 12.0" w.c.

Manifold Pressure


Natural Gas 3.8" +/- 0.2" w.c. Propane 11" +/- 0.2" w.c.

AERATION ADJUSTMENT

The burner aeration is factory set but may need adjusting due to either the local gas supply, air supply or altitude.

Natural Gas 1/4" (6.4 mm)
Propane 3/8" (9.5 mm)

The aeration adjustment gears are located on the right side of the burner box. Remove the Hampton® Logo plate on the right side of the unit to access the adjustment gears.



To adjust the aeration: use the allen key to turn the turning gear which will adjust the air shutter. Open the air shutter for a blue flame or close it for a yellower flame.

GAS PIPE PRESSURE TESTING

The appliance must be isolated from the gas supply piping system by closing its individual manual shut-off valve during any pressure testing of the gas supply piping system at test pressures equal to or less than 1/2 psig. (3.45 kPa). Disconnect piping from valve at pressures over 1/2 psig.

The manifold pressure is controlled by a regulator built into the gas control, and should be checked at the pressure test point.

Note: To properly check gas pressure, both inlet and manifold pressures should be checked using the valve pressure ports on the valve.


- Make sure the valve is in the "OFF" position.
- Loosen the "IN" and/or "OUT" pressure tap(s), turning counterclockwise with a 1/8" wide flat screwdriver.
- Attach manometer to "IN" and/or "OUT" pressure tap(s) using a 5/16" ID hose.
- Light the pilot and turn the valve to "ON" position. Read manometer.

- 5) The pressure check should be carried out with the unit burning and the setting should be within the limits specified on the safety label.
- 6) When finished reading manometer, turn off the gas valve, disconnect the hose and tighten the screw (clockwise) with a 1/8" flat screwdriver. Note: Screw should be snug, but not overtightened.

Valve Description

- 1) Gas on/off knob
- 2) Manual high/low adjustment
- 3) Pilot Adjustment
- 4) Thermocouple Connection
- 5) Main Operator
- 6) Outlet Pressure Tap (Manifold Pressure)
- 7) Inlet Pressure Tap (Supply Pressure)
- 8) Pilot Outlet
- 9) Main Gas Outlet
- 10) Flange Securing Screw Holes
- 11) Alternative TC Connection Point
- 12) Thermoelectric Unit
- 13) Additional Valve Mounting Hole







Caution: Carbon will be produced if the air shutter is closed too much.

Note: Any damage due to carboning resulting from improperly setting the aeration controls is NOT covered under warranty.

Note: Aeration Adjustment should only be performed by an authorized Hampton® Installer at the time of installation or service.





CONVERSION KIT #791-969 FROM NG TO LP

THIS CONVERSION MUST BE DONE BY A QUALIFIED GAS FITTER IF IN DOUBT DO NOT DO THIS CONVERSION!!

Each Kit contains one LPG Conversion Kit and one DC Sparker Kit.

LPG Conversion Kit Contains:

Qty. Part #		Description		
1	904-529	5/32" Allen Key		
1	904-645	Burner Orifice #51		
1	918-590	Label "Converted to		
		LPG"		
1	908-528	Red "LPG" label		
1	910-037	LP Injector (Pilot Orifice)		
1	918-487	Instruction Sheet		

DC Sparker Kit Contains:

DC Sb	arker Kit Co	ntains:
Qty. P	art #	Description
1	820-475	Bracket DC Sparker
1	820-476	Bracket DC Sparker
1	904-153	Washer #8 External Star
1	904-330	Nut 8-32 Hex
1	904-438	Plug Nylon 0.750 Hole, Black
1	904-531	Bushing Split Plastic 0.500 in.
1	904-543	Screw 8-32 x 3/4 Pan Head
2	904-553	Screw #8 x 1/2 Type "B", Black Oxide
1	910-073	Spark Generator Battery Holder
1	910-074	Spark Generator Switch C/W Wire
1	910-078	Battery Size AA Energizer En91
2	910-199	Clip Wire Holder
1	910-903	Wire Fan To Power Cord Ground 30 in.
	904-781	Velcro Hook, Black
	904-782	Velcro Hook, Black

Installation of LPG Conversion Kit:

- 1) Shut off the gas supply.
- H35-1: Lift off the Cast Top and remove the glass front. Also, open up the control panel door.
 - **P90-1:** Remove the facade if it is installed. Remove the glass door (refer to the glass door section in the manual).
- Remove the logs, embers, and brick panels (if used).

4) Remove the 2 screws holding the Burner Assembly to the firebox base. Push the Burner Assembly to the left and lift out.




Remove the 2 screws, push Burner Assembly to the left and lift out.

5) Pull off the pilot cap to expose the pilot orifice.



6) Unscrew the pilot orifice with the allen key and replace with the LP pilot orifice in the kit and replace pilot cap.



7) Remove burner orifice with a 1/2" wrench and discard. Use another wrench to hold on to the elbow behind the orifice.



Burner Orifice

8) Reinstall new burner orifice LP stamped #51 and tighten.

- 9) Turn control knob to the "OFF" position.
- **10)** Remove the black protection cap by hand from the high-low knob (Fig.1).




Fig. 1

 Insert a 5/32" or 4mm Allen wrench into the hexagonal key-way of the screw (Fig. 2), rotate it counterclockwise until it is free and extract it.



Fig.2

- 12) Check that the screw is clean and if necessary remove dirt.
- 13) Flip the screw (Fig. 3).



INSTALLATION

14) Using the Allen wrench as shown in Fig.4, rotate the screw clockwise until snug, do not overtighten.




WARNING!

Do not overtighten the screw.

Recommended to
grip the wrench by the short side.

15) Verify that if the conversion is from NG to LPG, the screw must be reassembled with the red o-ring visible (Fig. 5).



16) Reassemble the black protection cap (Fig. 6).



Fig. 6

WARNING!
Also check that the pilot and main burner injectors are appropriate for the gas type.

- 17) Reverse steps 4) to 2).
- 18) Attach clear label "This unit has been converted to LPG" near or on top of the serial # decal.
- **19)** Replace yellow "Natural Gas" label with red "LPG" label.

Installation of the DC Sparker for the H35-1 Units Only:

 Remove the control panel by unscrewing the 2 screws.




 First, remove the Piezo Ignition Wire from the Piezo Ignitor. Then remove the Piezo Ignitor from the control panel.



Plug up the Piezo hole with the plastic bushing.



 Attach the DC sparker generator connector to the valve with a screw.





Remove the stove's rear panel by unscrewing the two screws.



Attach the ground wire to the grounding stud.




Before



After

Attach the Piezo ignition wire to the DC Sparker.



8) Insert both the ground wire and the DC sparker generator wire through the hole of the DC spark heat shield.



Install the plastic bushing over the outside of the hole.



10) Attach the ground wire to the DC spark mounting bracket.




11) Attach the DC sparker generator wires to the DC sparker.




12) Install the supplied battery into the DC Sparker Box by opening the battery compartment.

NOTE: The battery in the DC Sparker Box will need to be replaced annually.




13) Attach the heat shield to the DC sparker, then mount this onto the stove.

Note: We recommend attaching the DC sparker box to the bottom rear of the stove (or place this in a convenient location, away from the heat source).



14) Tie up the loose wire with the wire clip.




Installation of the DC Sparker for the P90 Units Only:

1) Locate the Piezo Ignitor situated at the side of valve.




Piezo Ignitor

 Remove the Piezo Ignitor by unscrewing the nut at the back of the mounting bracket.



 Disconnect the ignitor wire from the Piezo Ignitor and connect it to the DC Sparker.




4) Install the 3/4" nylon plug to cover up the hole on the mounting bracket.



INSTALLATION


 Connect the DC spark generator wires to the SIT Valve with the screw, which is provided in the kit.



6) Locate the ground lug at the receptical box, left of the unit.



 Connect one end of the supplied green ground wire to the lug with the nut and washer from the kit.



Install the 1/2" bushing to the heat shield.



Run the other end of the ground wire and DC spark generator wires through the bushing on the heat shield.

Heat Shield



10) Plug the DC spark generator wires to the DC Sparker.




11) Connect the ground wire to the DC Sparker mounting bracket.



12) Install the supplied battery into the DC Sparker Box by opening the battery compartment.


NOTE: The battery in the DC Sparker Box will need to be replaced annually.



13) Mount the heat shield to the DC Sparker. Secure into place with the velcro, which is provided in the kit.



- **14)** Find a location which is not too hot and is easy to reach for changing the battery.
- 15) Tie up the loose wire with the wire clip.



- 16) Check for gas leaks.
- 17) Check inlet and outlet pressures.
- 18) Check operation of flame control.
- **19)** Check for proper flame appearance and glow on logs.

Installer Notice:
These instructions must be left with the appliance.

CONVERSION KIT TO LOWER BTU RATING NATURAL GAS - KIT #: 740-950 PROPANE - KIT # 740-952

THIS CONVERSION MUST BE DONE BY A QUALIFIED GAS FITTER IF IN DOUBT DO NOT DO THIS CONVERSION!!


Natural Gas Conversion Kit 740-950 Contains:

Qty	. Part#	Description
1	904-240	Burner Orifice #37 (Natural Gas)
1	918-034	Decal "Converted to 30,000 Btu"
1	918-148	Instruction Sheet

Propane Conversion Kit 740-952 Contains:


Qty	/. Part #	Description
1	904-390	Burner Orifice #52 (Propane)
1	918-149	Decal "Converted to 28,500 Btu"
1	918-148	Instruction Sheet

- 1) Shut off the gas supply.
- Open the front door. Carefully remove the logs and lava rock. (Refer to manual for more detailed instructions.)
- Remove burner by removing 2 screws, sliding the burner to the left and lift out. See diagram below.




Note: Use a magnetic type screwdriver if possible.


 Remove Rear Log Bracket by removing 2 screws. See diagram below.



5) Unscrew the 2 Rear Log Pins and move to the front hole position.



- 6) Reinstall Rear Log Bracket.
- 7) Remove burner orifice with a 1/2" wrench and discard.




Burner Orifice

- Reinstall new burner orifice (NG stamped #37 or LP stamped #52) and tighten.
- 9) Reverse steps 3) and 2).

INSTALLATION

10) Adjust Vent restrictor setting: To set the Vent restriction as indicated in the diagram, simply loosen the screws and push the vent restrictor plate to the correct position. Tighten the screws.

Unit	Btu/h	Restrictor Opening
H35 NG	30,000	A 1-3/4" (45mm)
H35 LP	28,500	A 1-3/4" (45mm)




Vent Restrictor setting at Low Btu for Straight Horizontal Venting


- 11) Attach the label "This unit has been converted to ... " on top of the Serial # decal over the higher Btu information.
- 12) Check for gas leaks.
- 13) Check inlet and outlet pressures.
- 14) Check operation of flame control. Check for proper flame appearance and glow on logs.

OPTIONAL BRICK PANEL


- 1) Remove the cast top and glass front (see Glass Replacement section in this manual for instructions).
- 2) Remove the log set if installed.
- 3) Insert the back brick panel first by carefully slipping it between the back wall of the firebox and the rear log bracket.




Before installing the side brick panels, loosen the screws for the brick tabs enough so that you can slide the brick tabs on to the screws easily but that the tabs are secure. For the location of the side brick tab screws see Diagram 1.



5) Put the side panels in next. Slide them in from the front and push them flat up against the wall. Be very careful not to scratch them on the firebox hardware.



6) Install the brick tabs (refer to Diagram 2).



IMPORTAN1

YOUR BRICK PANELS ARE MANUFACTURED FROM A SPECIAL HEAT REFLECTIVE CERAMIC MATERIAL HANDLE WITH CARE (DO NOT FORCE INTO POSITION)

LOG SET INSTALLATION

Read the instructions below carefully and refer to the diagrams. If logs are broken do not use the unit until they are replaced. Broken logs can interfere with the pilot operation.

The gas log kit contains the following:

- **a)** 02-43 Rear Log **b)** 02-56 Middle Left Log Front Left Log 02-44 c) Left Top Log d) 02-46 Front Right Log e) 02-45 Center Log f) 02-47 g) 02-48 Middle Right Log h) Embers i) Lava
- A) 02-43 D) 02-46 G) 02-48 E) 02-45

C) 02-44 B) 02-56 F) 02-47

The "02" refer numbers (i.e. 02-43) are molded into the rear of each log.


- 1) Carefully remove the logs from the box and unwrap them. The logs are fragile, handle with care - do not force into position.
- 2) Lift off the Cast Top and remove the glass front (refer to the "Glass Replacement" section in this manual).
- 3) Sprinkle the embers on the left and right sides of the firebox base.



Embers Embers

INSTALLATION

4) Place Rear Log A)02-43 on the two pins on the rear log support.



Pins on Rear Log Support

5) Place the Middle Left Log B)02-56 on the two pins as shown.



6) Sprinkle some lava rock just in front of B) 02-56 on the burner holes.




lava rock

7) Place Front Left Log C)02-44 onto the 2 front pins as shown.



8) Place the Left Top Log D)02-46 on the pin on Log B)02-56 and on top of the cutout on Log A)02-43.



Pin Cutout


9) Place Front Right Log E)02-45 on the two pins as shown.



10) Place the lava rock in the area between the left and right logs, leaving a space in the middle for log (F) 02-47.




11) Place the notch in Center Log F)02-47 over Log E)02-45 and across the cutout on Log A)02-43.




Notch Cutout

12) Position notch in Front Right Log G)02-48 on Log F)02-47 and push the bottom right edge against the bracket on the burner tray.



Notch



Bracket

The bottom right edge of Log G)02-48 must sit snugly against the bracket. (Front Log 02-45 has been removed so that the bracket can be seen.)

13) Test fire to ensure proper light off (make sure flame flows smoothly from one end of burner to the other. If there is any flame hesitation, check that area for any blockage of the burner port.



DOUBLE DOOR INSTALLATION

1) Secure the Top Door Clip into the Top Front Casting.



2) Pull all four door hinges out from the sides of the Front Casting.




 Fasten the Right Door to the 2 right hinges (2 screws per hinge). Repeat for the Left Door.



DECORATIVE DOOR GRILL INSTALLATION

- Hook the Top Clip on the Decorative Door Grill into the top lip of the Front Casting.
- Lift the Decorative Door Grill slightly and drop the Bottom Clips into the bottom lip of the Front Casting.







TILE INSET INSTALLATION

Side Tile Inset

 Slide the Standard Side Tile Inset out towards the back of the unit.



- 2) Slide the Optional Side Tile Inset into the side panel, over the spring clip.
- 3) Repeat for other side.

Top Tile Inset

1) Lift the Cast Top off the unit.



- Place the Cast Top face down on a soft surface. Take care not to scratch the finish on the Top.
- 3) Remove the Tile Clips holding the Standard Tile Insets in place.



Tile Clip

 Place the Optional Tile Insets into position and secure with a top and bottom Tile Clip.



5) Replace the Cast Top on the unit.

DOOR HINGE REMOVAL

1) Remove the cast top by lifting it off of the stove.



2) Release the catches on the left and right side of the stove that secure the glass.



Release catch by pulling up.


3) Remove the glass by sliding it up and out.



4) Pull all four door hinges out from the sides of the front casting.



5) Use a 7/16" wrench to remove the screws that secure the door hinges.



Remove screws.

WIRING DIAGRAMS

If any of the original wires as supplied with the appliance must be replaced, it must be replaced with CSA type SEW (200°C) or its equivalent.

This heater does not require a 120V A.C. supply for operation. In case of a power failure, the burner switch and the optional remote control/thermostat will continue to operate. However, a 120V A.C. power supply is needed for the fan/blower operation.


Caution: Ensure that the wires do not touch any hot surfaces and are away from sharp edges.

CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

WARNING: Electrical Grounding Instructions


This appliance is equipped with a three pronged (grounding) plug for your protection against shock hazard and should be plugged directly into a properly grounded three-prong receptacle. Do not cut or remove the grounding prong from this plug.

For NATURAL GAS Units and Units NOT Equipped with DC Spark Boxes



For PROPANE Units and Units Equipped with DC Spark Boxes*

*For installation of the DC Spark Box refer to the LP Conversion instructions in this manual.



WALL THERMOSTAT

A wall thermostat may be installed if desired. Connect the wires as per the wiring diagrams. Note that the wires are connected to the "TH" on the gas valve. Use table below to determine the maximum wire length:

Note: Preferable if the thermostat is installed on an interior wall.


Hampton® offers an optional programmable thermostat but any 250-750 millivolt rated non-anticipator type thermostat that is CSA, ULC or UL approved may be used.

CAUTION

Do not connect the millivolt wall thermostat wires to the 120V wires.

Thermostat Wire Table Recommended Maximum Lead Length

(Two-Wire) When Using Wall Thermostat (CP-2 System)					
Wire Size	Max. Length				
14 GA.	50 Ft.				
16 GA.	32 Ft.				
18 GA.	20 Ft.				
20 GA.	12 Ft.				
22 GA.	9 Ft.				



REMOTE CONTROL

Use the Hampton® Remote Control Kit approved for this unit. Use of other systems may void your warranty.

The remote control kit comes with a hand held transmitter, a receiver and a wall mounting plate.

OPERATING INSTRUCTIONS

- Choose a convenient location on the wall to install the receiver and the receptacle box (protection from extreme heat is very important). Run wires from the fireplace to that location, use Thermostat Wire Table.
- 2) Connect the wires as per the wiring diagram below

CAUTION Do not connect the millivolt remote control wires to the 120V wires.

3) Install 3 AAA alkaline batteries in transmitter and 4 AA alkaline batteries in the receiver. Install the receiver and its cover in the wall. Switch the remote receiver to "remote" mode. The remote control is now ready for operation.

FINAL CHECK

Before leaving this unit with the customer, the installer must ensure that the appliance is firing correctly. This includes:

- Clocking the appliance to ensure the correct firing rate (rate noted on label) at 15 minutes.
- If required, adjusting the primary air to ensure that the flame does not carbon. First allow the unit to burn for 15 min. to stabilize.
- 3) Check for proper draft.


CAUTION

Any alteration to the product that causes sooting or carboning that results in damage to the exterior facia is not the responsibility of the manufacturer.

OPERATING INSTRUCTIONS

- Read and understand these instructions before operating this appliance.
- 2) Check to see that all wiring is correct and enclosed to prevent possible shock.
- 3) Check to ensure there are no gas leaks.
- 4) Make sure the glass in the door frame is properly positioned. Never operate the appliance with the glass removed. Never strike the glass or slam the door shut.
- 5) Verify that the venting and cap are unobstructed.
- 6) Verify log placement. If the pilot cannot be

- seen when lighting the unit the logs have been incorrectly positioned.
- The unit should never be turned off, and on again without a minimum of a 60 second wait.



LIGHTING PROCEDURE

IMPORTANT

To ignite or reignite the pilot, the door to the firebox must be opened.

Only when the pilot holds, without pressure being applied to the control knob, should the door to the firebox be closed. The unit *must never* be operated with the glass or door open.

NOTE: For all propane units and units equipped with electric spark boxes, see "Copy of Lighting Plate Instructions" section for more details.

IMPORTANT: Gas on/off knob cannot be turned from "PILOT" to "OFF" unless it is partially depressed.

- Turn stove OFF using the Burner "ON/OFF" switch remote or thermostat.
- Turn gas control knob so indicator points to "OFF" position and allow 5 minutes for any gas in the combustion chamber to escape.
- 3) Turn gas control knob counterclockwise so indicator points to the "PILOT" position. Depress the gas control knob fully. Depress the igniter button several times until the pilot lights. After approximately one minute, release the gas control knob. The pilot flame should continue to burn. If the pilot does not remain lit, repeat operation allowing a longer period before releasing gas control knob.

- 4) When the pilot stays lit, turn the gas knob further counterclockwise to the "ON" position.
- 5) Use the thermostat or remote control to turn on the unit.
- **6)** Rotate the flame height regulator to adjust the flame height higher or lower.

SHUTDOWN PROCEDURE

- Use the thermostat or remote control to turn off the main burner.
- 2) Turn the main gas control clockwise to the "OFF" position to turn off the pilot (push knob in slightly).
- Turn off all electric power to appliance if service is to be performed.

FIRST FIRE

The FIRST FIRE in your stove is part of the paint curing process. To ensure that the paint is properly cured, it is recommended that you burn your fireplace for at least four (4) hours the first time you use it with the fan on. When first operated, the unit will release an odour caused by the curing of the paint and the burning off of any oils remaining from manufacturing. Smoke detectors in the house may go off at this time. Open a few windows to ventilate the room for a couple of hours. The glass may require cleaning.

DO NOT ATTEMPT TO CLEAN THE GLASS WHILE IT IS STILL <u>HOT</u>!

Note: When the glass is cold and the appliance is lit, it may cause condensation and fog the glass. This condensation is normal and will disappear in a few minutes as the glass heats up.

DO NOT BURN THE APPLIANCE WITHOUT THE GLASS FRONT IN PLACE.

During the first few fires, a white film may develop on the glass front as part of the curing process. The glass should be cleaned or the film will bake on and become very difficult to remove. Use a non-abrasive cleaner and NEVER clean the glass while it is hot.

COPY OF THE LIGHTING PLATE INSTRUCTIONS

FOR YOUR SAFETY READ BEFORE LIGHTING

This appliance must be installed in accordance with local codes, if any; if none, follow the National Fuel Gas Code, ANSI Z223.1/ NFPA 54, or Natural Gas and Propane Installation Codes, CSA B149.1. (Australia: AS5601-2004, New Zealand: NZS 5261)

WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage personal injury or loss of life. Improper installation, adjustment, alteration, service or maintenance can cause injury or property damage. Refer to the owner's information manual provided with this appliance. For assistance or additional information consult a qualified installer, service agency or gas supplier.

- This appliance has a pilot which must be lighted by hand, following the instructions below exactly.
- B) BEFORE LIGHTING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

WHAT TO DO IF YOU SMELL GAS

- Do not try to light any appliance
- Do not touch any electric switch, do not use any phone in your building
- Immediately call your gas supplier from a neighbors phone. Follow the gas supplier's instructions. If you cannot reach your gas supplier, call the fire department.
- C) Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it, call a qualified service technician. Force or attempted repair may result in a fire or explosion.
- D) Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been under water.
- This appliance needs fresh air for safe operation and must be installed so there are provisions for adequate combustion and ventilation air.


CAUTION: Hot while in operation. Do not touch. Severe Burns may result. Due to high surface temperatures keep children, clothing and furniture, gasoline and other liquids having fammable vapors away. Keep burner and control compartment clean. See installation and operating instructions accompanying appliance

LIGHTING INSTRUCTIONS

STOP! Read the safety information above on this label.

FOR UNITS NOT EQUIPPED WITH ELECTRIC SPARK:

Push in gas control knob slightly and turn clockwise to "OFF". Knob cannot be turned from "PILOT" to "OFF" unless knob is pushed in slightly. Do not force.




- 2) Wait five (5) minutes to clear out any gas. If you then smell gas STOP! follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
- 3) Turn knob on gas control counterclockwise <
- Push in control knob all the way and hold in. Immediately push black button on spark igniter until pilot lights. Continue to hold the control knob in for about 1/2 minute after the pilot is lit. Release knob and it will p

- If knob does not pop up when released, stop and immediately call your service technician or gas supplier. If the pilot will not stay lit after several tries, turn the gas control knob to "OFF" and call your service technician or gas supplier.
- 5) Turn gas control knob counterclockwise
- 6) Use rocker switch to operate main burner

FOR ALL PROPANE LINITS AND **EQUIPPED WITH ELECTRIC SPARK BOXES:**

- 1) Push in gas control knob slightly and turn to "PILOT" position.
- 2) Push in control knob all the way and hold in until the pilot lights up. Continue to hold the control knob in for about 20 seconds after the pilot is lit. Release knob.
- 3) Push in gas control knob slightly and turn to "ON" position.
- 4) Turn ON the flame switch.



TO TURN OFF GAS APPLIANCE

- Turn off the flame switch. Push in the gas control knob slightly and turn clockwise \frown to "OFF". Turn off all electric power to the appliance if service is to be performed. to "OFF". Do not force.

You may shut off the pilot during prolonged non use periods to conserve fuel

DO NOT REMOVE THIS INSTRUCTION PLATE

918-474a

ADJUSTING FLAME **HEIGHT**

Your heater has an adjustable flame to tailor the look and heat output to your specific needs. It is adjusted by turning the flame adjustment dial on the gas control valve.

Turn clockwise to adjust the flame higher, counterclockwise for a lower flame.



AUTOMATIC CONVECTION **FAN OPERATION**

The fan operates automatically - turn the knob at the top right rear corner to adjust to the desired speed. The fan will turn on as the stove comes up to operating temperature. After the unit has been turned off and the unit cooled to below a useful heat output range the fan will shut off automatically.

NORMAL OPERATING **SOUNDS OF** GAS APPLIANCES

It is possible that you will hear some sounds from your gas appliance. This is perfectly normal due to the fact that there are various gauges and types of steel used within your appliance. Listed below are some examples. All are normal operating sounds and should not be considered as defects in your appliance.

Blower:

Hampton® gas appliances use high tech blowers to push heated air farther into the room. It is not unusual for the fan to make a "whirring" sound when ON. This sound will increase or decrease in volume depending on the speed setting of your fan speed control.

Burner Tray:

The burner tray is positioned directly under the burner tube(s) and logs and is made of a different gauge material from the rest of the firebox and body. Therefore, the varying thicknesses of steel will expand and contract at slightly different rates which can cause "ticking" and "cracking" sounds. You should also be aware that as there are temperature changes within the unit these sounds will likely re-occur. Again, this is normal for steel fireboxes.

Blower Thermodisc:

When this thermally activated switch turns ON it will create a small "clicking" sound. This is the switch contacts closing and is normal.

Pilot Flame:

While the pilot flame is on it can make a very slight "whisper" sound.

Gas Control Valve:

As the gas control valve turns ON and OFF, a dull clicking sound may be audible, this is normal operation of a gas regulator or valve.

Unit Body/Firebox:

Different types and thicknesses of steel will expand and contract at different rates resulting in some "cracking" and "ticking" sounds will be heard throughout the cycling process.

MAINTENANCE INSTRUCTIONS

1) Always turn off the valve before cleaning. For relighting, refer to lighting instructions. Keep the burner and control compartment clean by brushing and vacuuming at least once a year. When cleaning the logs, use a soft clean paint brush as the logs are fragile and easily damaged.

- 2) Clean glass (never when unit is hot), appliance, and door with a damp cloth. Never use an abrasive cleaner.
- 3) The heater is finished in a porcelain finish or with a heat resistant paint and should only be refinished with heat resistant paint (not with wall paint).

Never use an abrasive cleaner on the porcelain finish as it may scratch the surface.

- Make a periodic check of burner for proper position and condition. Visually check the flame of the burner periodically, making sure the flames are steady; not lifting or floating. If there is a problem, call a qualified service person.
- 5) CAUTION: Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.
- The appliance and venting system must be inspected before use, and at least annually, by a qualified field service person, to ensure that the flow of combustion and ventilation air is not obstructed.
 - During the annual service call, the burners should be removed from the burner tray and cleaned. Replace the embers but do not block the pilot.
- 7) Keep the area near the appliance clear and free from combustible materials, gasoline. and other flammable vapours and liquids.

WARNING: CHILDREN AND ADULTS SHOULD BE ALERTED TO THE HAZARDS OF HIGH SURFACE TEMPERATURE AND SHOULD STAY AWAY TO AVOID BURNS OR CLOTHING IGNITION. YOUNG CHILDREN SHOULD **BE CAREFULLY SUPERVISED** WHEN THEY ARE IN THE SAME ROOM AS THE APPLIANCE.

DO NOT USE THIS APPLIANCE IF ANY PART HAS BEEN UNDER WATER. IMMEDIATELY CALL A QUALIFIED SERVICE TECHNI-CIAN TO INSPECT THE APPLI-ANCE AND TO REPLACE ANY PART OF CONTROL SYSTEM AND ANY GAS CONTROL WHICH HAS BEEN UNDER WATER.

CAUTION: ANY SAFETY SCREEN OR GUARD REMOVED FOR SERVICING AN APPLIANCE MUST BE REPLACED PRIOR TO OPERATING THE APPLIANCE.


CLOTHING OR OTHER FLAM-**MABLE MATERIAL SHOULD NOT** BE PLACED ON OR NEAR THE APPLIANCE.

8) Each time the appliance is lit, it may cause condensation and fog the glass. This condensation and fog is normal and will disappear in a few minutes as the glass heats up.

Never operate the appliance without the glass properly secured in place.


Periodically check the pilot flames. Correct flame pattern has three strong blue flames: 1 flowing around the thermopile and 1 around the thermocouple, and 1 flowing across the rear of the burner (it does not have to be touching the burner).

Note: If you have an incorrect flame pattern, contact your Hampton® dealer for further instructions.



Front of Burner Top View of pilot flame

Incorrect flame pattern will have small, probably yellow flames, not coming into proper contact with the rear of the burner or thermopile.



Top View of pilot flame

GENERAL VENT MAINTENANCE

Conduct an inspection of the venting system semi-annually. Recommended areas to inspect as follows:

- Check the Venting System for corrosion in areas that are exposed to the elements. These will appear as rust spots or streaks, and in extreme cases, holes. These components should be replaced immediately.
- Remove the Cap, and shine a flashlight down the Vent. Remove any bird nests, or other foreign material.
- 3) Check for evidences of excessive condensation, such as water droplets forming in the inner liner, and subsequently dripping out the joints, Continuous condensation can cause corrosion of caps, pipe, and fittings. It may be caused by having excessive lateral runs, too many elbows, and exterior portions of the system being exposed to cold weather.
- 4) Inspect joints, to verify that no pipe sections or fittings have been disturbed, and consequently loosened. Also check mechanical supports such as Wall Straps, or plumbers' tape for rigidity.

LOG REPLACEMENT

The unit should never be used with broken logs. Turn off the gas valve and allow the unit to cool before opening door to carefully remove the logs. The pilot light generates enough heat to burn someone. If for any reason a log should need replacement, you must use the proper replacement log. The position of these logs must be as shown in the diagram under Log Installation.

Note: Improper positioning of logs may create carbon build-up and will alter the unit's performance which is not covered under warranty.

GLASS REPLACEMENT

Your stove is supplied with high temperature, 5 mm Neoceram ceramic glass that will withstand the highest heat that your unit will produce. In the event that you break your glass by impact, purchase your replacement door from an authorized Hampton® dealer only, and follow our step-by-step instructions for replacement.

1) Lift off the Cast Top.



2) Open the 2 latches of the Glass Front.



Latches

3) Lift the Glass Front Assembly up.



- 4) Remove the glass and replace with the new glass.
- 5) Replace the door and Cast Top.

Replacement Part # 940-324 Glass

WARNING: Do not operate appliance with glass panel removed, cracked or broken. Replacement of the glass should be done by a licensed or qualified service person.

Note: Wearing gloves will protect your hands while handling glass.

FAN MAINTENANCE

If your fan requires maintenance or replacement, access to the fan is through the rear access panel on the back of the unit. NOTE: the unit MUST NOT be operated without the fan access panel securely in place and correctly sealed.

IMPORTANT: These fans collect a lot of dust from within your home. Ensure you maintain these fan motors on a regular basis by vacuuming out the fan squirrel cages, around the motor, and around the grills on the back of the stove.


WARNING:

Electrical Grounding Instructions
This appliance is equipped with
a three pronged (grounding) plug
for your protection against shock
hazard and should be plugged
directly into a properly grounded
three-prong receptacle. Do not cut
or remove the grounding prong from
this plug.

IMPORTANT Disconnect power supply before servicing


To remove fan:

- 1) Unplug or disconnect power source to stove.
- 2) Remove the 6 screws holding the access panel in place.



- Unclip the black and white wires from the fan motor.
- 4) Lift fan off of the 2 pins, tip back and pull through rear panel. Do not tear or damage the flex pipe when removing the fan. Disconnect the green ground wire from the right side of the fan as soon as you can reach it


MAINTENANCE



Replacing the Fan:

Reverse the above steps (1 - 4). Make sure the fan wires and the ground wire are reattached.

Hint for pushing fan down onto pins - rub a bit of dish soap on the grommet so it will slide more easily onto the pin. Check to make sure the fan is seated properly on the pins - try to move the fan back and forth, there should be no noise, if there is check that the grommets haven't come loose.




REMOVING VALVE


If your valve requires maintenance or replacement, use the following instructions:

Note: Always close off the gas supply before removing the valve.


- If optional fan is installed, disconnect power source to stove.
- 2) Remove access panel.




- 3) Disconnect gas line to stove.
- Disconnect 3/8" NPT pipe from 90° elbow on valve.
- Disconnect the two (2) switch wires from valve.




- 6) Disconnect piezo wire.
- Lift off the Cast Top and lift out the front door.
- Carefully remove the logs, embers and rockwool.
- 9) Remove burner (see diagram below).



10) Remove all 18 screws holding the burner tray assembly in place.



11) Carefully lift the burner tray assembly out.



12) To replace the burner tray assembly, simply reverse these instructions.

To remove valve from valve assembly, continue.

- 13) Remove two (2) thermopile wires.
- **14)** Remove thermocouple with a 9 mm (metric) wrench.
- 15) Remove pilot nut with an 11 mm wrench.
- 16) Remove valve to orifice nut with a 13/16" wrench.
- **17)** Remove inlet pipe with pipe wrench. Note orientation of 90° elbow.
- **18)** Remove two (2) phillips head M5 screws on each side of the valve.
- **19)** Remove valve and remove gas out 90° brass fitting. Note orientation of fitting.


INSTALLING VALVE ASSEMBLY

- To install a new valve assembly, reverse instructions for removing valve. See assembly steps 1-12.
- Check for leaks and manifold pressure. See Gas Pressure Test instructions.
- **3)** To reinstall valve, reverse instructions for removing valve assembly, steps 13-19.

MAIN ASSEMBLY

	Part #	Description		Part #	Description		Part #	Description
1)	942-301**	Casting - Top	56)	W842051	Gasket - Upper Air		908-106	Decal-Rear Control Panel
2)	942-311**	Casting - Top Grill	,		Passage Top			
3)	942-321**	Casting - Left Side	57)	W260108	Gasket - Upper Air		260-917	Fan Assembly (Option)
4)	942-331**	Casting - Right Side			Passage Bottom	,	910-331/P	Fan Blower
5)	942-341**	Casting - Front	58)	630-009	Gasket - Lower Air	,	910-330	Fan Speed Control (120 V)
6) 8)	740-931** 942-371**	Casting - Double Door	EO)	*	Passage Upper Air Passage Assy	144)	904-569 910-794	Knob - Fan Speed Control Power Cord (120 V)
9)	942-371	Casting - Bottom Skirt Casting - Leg	59)		Opper All Passage Assy		310-734	1 0WC1 0014 (120 V)
10)	942-391**	Casting - Insert Plate - Top	61)	945F	Direct Vent Adaptor		918-518	Manual
11)	942-401**	Casting - Insert Plate -	/					
,		Side			Rear Panel Assembly	*Not	e: Not availa	ble as a replacement part.
12)	948-219	Hampton® Logo Plate	114)	*	Wire Tie Wrap			
14)	740-062	Top Insert Bracket	115)	*	Wire Tie Mount Button			t number indicated colour:
15) 16)	904-209 740-069	Concealed Hinge Cast Door Catch - Top	118)	910-897	High Temperature Wire Harness - Fan End		narcoai Grey ne Brown.	, 2=Slate Blue, 4=Ivory, 5=Tim
17)	740-009	Cast Door Catch - Top	119)	*	Grommet for Power Cord	DCIIII	ic brown.	
.,,	140 001	Cast Bool Caton Lower	,	740-049	Rear Panel			
	740-542	Front Door Assembly	135)		Rear Control Panel			
18)	740-051	Door Support	136)	910-241	Burner ON/OFF Switch			
19)	740-055	Door Frame	137)		Hole Plug 0.375			
22)	41225	Gasket - Tadpole	,	630-021	Fan Access Panel			
23) 24)	940-324/P 740-056	Replacement Glass Glass Bracket	139)	910-233	Fan Thermodisc Auto On/Off			
25)	948-255	Latch			Auto On/On			
20)	0.10.200	Laten						
26)	740-548	Relief Door Assembly						
27)	740-059	Gasket - Mounting Relief			10		-1	
201	740 004**	Frank Orill (Ontional)			14———	14	-1.1	
38) 39)	740-921** *	Front Grill (Optional) Firebox			14	\geq_{10}	14	144
55)		I II CDOX			14			/143 🔏 137
		Baffle Restrictor Assembly			1 54			134
44)	730-029	Restrictor				53		134
45)	740-048	Baffle for Firebox				 52		
46)	*	Heat Exchanger Assy		3			(<u>)</u>	115
47)	*	Transition Box Assy	6			~ 51	56 /	138
48)	740-061	Side Insert Bracket	1	4 4	80 11	- 50		O- 57
49)	740-063	Side Insert Spring	ľ		49	10	55	59
					46			~ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\
==>		Top Relief Door Assembly	4		25	Ĭ,		114 119
50)	W260260	Top Relief Frame Gasket		44				
51) 52)	942-117 W260280	Top Relief Frame Top Relief Plate Gasket		45	25	, ,		141 98
53)	290-021	Top Relief Plate		"		_	·47 58	3
54)	*	Capscrew 1/4 x 1-3/4 NC			39	1	139	
							· .	- 11 118
55)	*	Gasket - Transition Box/Air						48 -4
		Passage		No.				
					18	1:5	49	
		~			24 27	6		
				12	26 17 9			
		Ô C			9 📆 🕊			12
					23		<u> </u>	
		1 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7 7		- 46	22 9	9 }	ļ	
		16 1/ 	\	19 A.	N/			
				15	5	•		
		A Committee of the second						
		I ■ ⁸		38				
	6	-						

BURNER & LOG ASSEMBLY



NOTES

NOTES



Hampton® Fireplace Products are designed with reliability and simplicity in mind. In addition, our internal Quality Assurance Team carefully inspects each unit thoroughly before it leaves our facility. FPI Fireplace Products International Ltd. is pleased to extend this limited lifetime warranty to the <u>original purchaser</u> of a Waterford Product. This warranty is not transferable.

The Warranty: Limited Lifetime

External casting, not directly in contact with the fire, such as hobs, sides, ash lips, legs, fronts and fire doors, are covered against cracks and warps resulting from manufacturer defects, parts and subsidized labour* for three (3) years from the date of purchase and parts only thereafter.

The combustion chamber, heat exchanger, burner tubes/pans and logs are covered under the Limited Lifetime Warranty for five (5) years for parts and subsidized labour* and parts only thereafter.

Glass is covered for lifetime against thermal breakage only, parts and subsidized labour* for five (5) years and parts only thereafter from date of purchase.

Electrical and mechanical components such as blowers, switches, wiring, thermodiscs, FPI remote controls, spill switches, thermopiles, thermocouples, pilot assembly components, and gas valves are covered for one year parts and subsidized labour* from the date of purchase. Blowers and valves replaced under warranty are considered repairs and continue as if new with appliance. ie. twelve (12) months from original purchase date of appliance with a minimum of three (3) months coverage from date of replacement.

FPI venting components are covered parts and subsidized labour* for three (3) years from date of purchase.

Simpson Dura-Vent venting components are covered by Simpson Dura-Vent Inc. warranty.

Conditions:

Porcelain/Enamel - Absolute perfection is neither guaranteed nor commercially possible. Any chips must be reported and inspected by an authorized dealer within three days of installation. Reported damage after this time will be subject to rejection.

Any part or parts of this unit which in our judgement show evidence of such defects will be repaired or replaced at FPI's option, through an accredited distributor or agent provided that the defective part be returned to the distributor or agent <u>Transportation Prepaid</u>, if requested.

It is the general practice of FPI to charge for larger, higher priced replacement parts and issue credit once the replaced component has been returned to FPI and evaluated for manufacturer defect.

The authorized selling dealer is responsible for all in-field service work carried out on your Waterford product. FPI will not be liable for results or costs of workmanship from unauthorized service persons or dealers.

At all times FPI reserves the right to inspect product in the field which is claimed to be defective.

All claims must be submitted to FPI by authorized selling dealers. It is essential that all submitted claims provide all of the necessary information including customer name, purchase date, serial #, type of unit, problem, and part or parts requested, without this information the warranty will be invalid.

Exclusions:

This limited Lifetime Warranty does not extend to or include paint (charcoal units), porcelain (including pinholes, scratches and minor shade mismatch), door or glass gasketing or trim.

At no time will FPI be liable for any consequential damages which exceed the purchase price of the unit. FPI has no obligation to enhance or modify any unit once manufactured. ie. as products evolve, field modifications or upgrades will not be performed.

FPI will not be liable for travel costs for service work.

Installation and environmental problems are not the responsibility of the manufacturer and therefore are not covered under the terms of this warranty policy.

Embers, door and glass, gaskets, door handles, paint are not covered under the terms of this warranty policy.

Any unit which shows signs of neglect or misuse is not covered under the terms of this warranty policy.

The warranty will not extend to any part which has been tampered with or altered in any way, or in our judgment has been subject to misuse, improper installation, negligence or accident, spillage or downdrafts caused by environmental or geographical conditions, inadequate ventilation, excessive offsets, negative air pressure caused by mechanical systems such as furnaces, fans, clothes dryer, etc.

Freight damage to stoves and replacement parts is not covered by warranty and is subject to a claim against the freight carrier by the dealer.

FPI will not be liable for acts of God, or acts of terrorism, which cause malfunction of the appliance.

Performance problems due to operator error will not be covered by this warranty policy.

Products made or provided by other manufacturers and used in conjunction with the operation of this appliance without prior authorization from Waterford, may nullify your warranty on this product.

Any alteration to the unit which causes sooting or carboning that results in damage to the interior / exterior facia is not the responsibility of FPI.

* Subsidy according to job scale as predetermined by FPI.

Hampton® fireplace products are designed with reliability and simplicity in mind. In addition, our internal Quality Assurance Team carefully inspects each unit thoroughly before it leaves our door.

FPI Fireplace Products International Ltd. is pleased to extend this Limited Lifetime Warranty to the original purchaser of a Hampton® Product.

See the inside back cover for details.

Register your Hampton® online at http://www.hampton-fire.com

Installer: Please complete the following information		
Dealer Name & A	ddress:	
Installer:		
Phone #:		
Date Installed: _		
Serial No.:		