

**INTELLIGENT SERVO DRIVE
FOR BRUSHLESS MOTORS**

ISD300R SERIES

- USER MANUAL -

DOCUMENT NUMBER : ISD.MMR.M001
INTERNAL REFERENCE : ISD.142.SP
EDITION : 01
AUTHOR : L. DI STEFANO
DATE : 20 OCTOBER 1996

The material in this manual is for informational purposes only and is subject to change without notice. PRIMA ELECTRONICS S.p.A assumes no responsibility for errors or omissions, neither is any liability assumed for damages resulting from the use of the information contained herein.

COPYRIGHT 1995 - PRIMA ELECTRONICS S.p.A.

All rights reserved. This document shall not be reproduced, either entirely or in part, without written authorization.

DOCUMENT INFORMATION

edition	data	versione
0	7 August 1996	preliminary version
1	20 October 1996	first edition

INTELLIGENT SERVO DRIVE ISD300R SERIES

DESCRIPTION

This servoamplifiers is a PWM controlled converter with three-phase power stage configuration, suitable for driving brushless motors with resolver transducer.

The controller parameters are set by mean of a personal computer (PC) with specialized software. The PC is connected with a serial interface to the drive.

The converter is built using IGBT transistors for the power stage, has an integrated switching power supply, integrated controller and protection circuits. The power ground and the signal ground are galvanically insulated.

The converter generates an encoder simulation output, with two quadrature signals and a 0 marker, with a programmable resolution from 62256 to 1024 pulses/turn.

The reference input is set through a $\pm 10V$ analog input, all the other input signals are +24V optically coupled signals. A potential free contact is available for FAULT signal (drive OK).

The power supply and the control for an electromagnetic brake is incorporated in the drive.

PRODUCT IDENTIFICATION

An identification label is applied on the side of the unit, with the relevant identification data.

When contacting the customer service, please report the Model, Serial number and Part number, which are indicated on the label.

Model: ISD300R05

Serial nr.: 96/48-00101-00

Part nr.: 2XAR00D00106BCF0



MODEL SPECIFICATION

Different models (5 sizes) are available: specification depending on size are shown in the table below

Ratings	Dim	ISD300T05	ISD300T10	ISD300T15	ISD300T20	ISD300T30
Peak current (trapezoidal)	A	15	25	35	50	60
Rated current (trapezoidal)	A	5	10	15	20	30
Peak current (sinusoidal)	A	10	20	30	40	50
Rated current (sinusoidal)	A	4	8	12	16	24
Power loss at rated current (with electromechanical brake)	W	79	122	152	195	240
Quiscent power loss (disabled)	W	22	22	22	22	22
Quiscent power loss (with electromechanical brake)	W	40	40	40	40	40
Efficiency at rated current	%	96	96,5	97	97	97,5
PWM switching frequency	kHz	18	18	18	18	6
Mechanical specification	Dim	ISD300T05	ISD300T10	ISD300T15	ISD300T20	ISD300T30
Weight	kg	3,2	3,2	3,6	3,6	3,6
Dimensions	mm	268x53x230	268x53x230	268x63x230	268x63x230	268x63x230

TECHNICAL CHARACTERISTICS

Main supply

- Three phase input 230 Vac +10% ÷ -20%
- DC bus nominal voltage 310Vdc
- Internal switching power supply for the control circuitry
- Maximum output voltage to the motor: $\approx 95\%$ of the DC bus (310Vdc)
- Galvanic insulation between the control circuitry and the power stage

Auxiliary supply

- Auxiliary supply 110-230Vac, 30VA (optional, selectable through jumpers on the base board)

The auxiliary supply is needed when the status of the LED indicators and the encoder simulation function should be maintained active also after removing the main power supply (220Vac three phase)

When using the auxiliary supply, the input voltage on the main supply can be reduced up to 35 Vac three phase minimum, by eliminating the undervoltage protection via a dedicated jumper on the base board. (see Jumpers), for usage with low voltage motors.

Enclosure

The drive has a metallic enclosure (protection grade IP20), suitable for vertical fixing through two M5 screws on a panel.

WARNING

The drive operates with high voltage, only qualified personnel should be allowed to operate on the drive. ATTENTION, DANGEROUS VOLTAGES MAY REMAIN ON DRIVE TERMINALS AND INSIDE THE DRIVE ENCLOSURE UP TO 5 MINUTES AFTER THE POWER HAS BEEN SWITCHED OFF.

Clamping circuit

- clamp (ballast) circuit short circuit protected.
- DC voltage threshold set at 400Vdc

The braking resistor should be located externally and connected to the relevant screw terminals on the front panel.

An internal Ixt circuit protects the clamping resistor, limiting the average power to the value shown in the table below.

Install the appropriate resistor according to the drive model, as shown:

MODEL	CLAMPING RESISTOR.	PEAK POWER (1 second)	AVERAGE POWER
R05	33Ω	4,6 kW	100 W
R10	15Ω	10,6 kW	240 W
R15	15Ω	10,6 kW	240 W
R20	10Ω	16 kW	420 W
R30	10Ω	16 kW	420 W

Electromagnetic brake

- the brake can be connected on front panel terminals
- internal power supply for the brake 24Vdc, 0.8A max.
- brake release/lock is automatically operated by the drive
- connections for an optional emergency switch (potential free contact) in series with the brake are available

Dynamic braking

The drive is capable of braking the motor shorting its windings, and controlling the motor current at a presettable level

This feature is automatic in case of a fault or drive disable.

This feature can be disabled by connecting to +24V the input 24VSBLO (pin 11 of connector JP2). If an electromagnetic brake is connected to the drive, the brake is also energized (released).

Resolver

- reference frequency 12kHz
- reference voltage selectable up to 7.1 Vrms (100 mA max)
- required input voltage for sin and cos signals: 2Vrms \pm 10%
- digital phase shift compensation between reference and sin/cos inputs (resolver and cable compensation)
- digital phasing of the resolver with respect to the motor shaft

Input / Output signals

- digital input for power enable(ENABLE) 15÷24V 20mA
- FAULT output (potential free contact) 24V 1A Max
- power supply output ±15V 50mA
- analog reference input ±10V (differential) 1kΩ impedance
- digital output for encoder emulation : A, B, Z (RS422 5V differential) with selectable resolution
- analog input (0÷10V, unipolar, 1kΩ impedance) for setting the limit of the output current from 0% (0V) to 100% (10V) of the rated current of the drive. Option.

Protections

- under/overvoltage on DC bus
- short circuit between motor terminals and/or ground
- overcurrent
- resolver connection fault (wire broken) or overvoltage on resolver input signals
- overspeed
- drive overtemperature
- motor overtemperature

In case of intervention of any of the above protection, the FAULT contact is opened. The protections are cleared by cycling the ENABLE input off and on again.

- Ixt protection circuit

The peak current can be sourced for no more than 0,5 second. After this time the Ixt protection trips, and the output current is automatically limited to the rated current. The protection do not cause the opening of the FAULT contact.


Ixt protection is automatically reset after 10 seconds, provided that the rated continuous current is set at least 7% less than the Ixt threshold. Otherwise it stays latched until the power is removed to the unit.

Operating temperature

- Operating temperature: 10°C ÷ 40°. For sizes 15, 20 and 30, forced ventilation is necessary for operation in the full temperature range at the rated current. (see Cooling requirements)
- Storage temperature: -10°C ÷ 70°C

Others

- Current loop bandwidth: 3 kHz
- Speed loop bandwidth: 200 Hz
- Linearity better than 0.6%



STUDIO TECNICO PALEOLOGO COMM 10139 CAD 755 30/06/94 DISEGNO VISTO DAL LATO COMPONENTI PRIMA ELECTRONICS CST492 SERIGRAFIA LC

Fig. 1.: Printed circuit board layout (base board)




Fig. 2.: Printed circuit board layout (interface board)

CONNECTIONS

The present chapter illustrates the external connections of the ISD300 servoamplifier, both towards the brushless motor and toward the numerical control.





Fig. 3.: Front Panel





Itemref	Quantity	Designation, material, dimension etc			Tolerance (if not otherwise specified)	Drawing number			
		—			—	ISD/100			
Designed by		Checked by	Approved by - date		Filename	Date	Sheet Size	Scale	
M.Badalotti					ISD_100.DWG	22/10/96	A4	1:1	
Owner					Title/Name				
 PRIMA ELECTRONICS S.p.A. Moncalieri - Torino - Italy					ISD300 Wiring Diagram				
					Article No./Reference			Edition	Sheet
								00	1/1

Fig. 4.: Wiring diagram


MAIN SUPPLY CONNECTIONS

TB3




When the line transformer has a rated power higher than 6kVA, we recommend to limit the inrush current as shown:

For further informations about inrush current suppressors, please contact your vendor.




MOTOR CONNECTIONS



screw connection, max. 4mm² terminals


Note: an optional noise suppressor ferrite clamp has been foreseen for motor cable

CLAMP RESISTOR CONNECTIONS



screw connection, max. 1.5mm² terminals


BRAKE AND AUX. CONNECTIONS



screw connection, max. 1mm² terminals

Note: The drive automatically cuts off power and releases the electromechanic brake when connection between pins 3 and 4 is open
Connect a potential free contact emergency switch between pins 3 and 4, or jumper them.

CONNECTIONS TO THE CONTROL UNIT




JP2 - SIGNALS TOWARDS THE CONTROL UNIT		
pin	reference	description
1	FAULT2	error signal input (relay contact)
2	+24VOUT	auxiliary voltage output (24Vdc 0.8A max.)
3	ENABLE	power enable input
4		DO NOT CONNECT
5	VREF+	velocity (or current) reference input (+)
6	+15VOUT	auxiliary voltage output (50mA max.)
7	INILIMIT*	current limit analog input (0÷10V) (option)
8		DO NOT CONNECT
9		DO NOT CONNECT
10	FAULT1	error output (relay contact)
11	24VSBLO	manual brake unlock
12	GND24V	auxiliary voltage ground (24Vdc)
13	INCOM	ENABLE signal common
14	SHIELD	cable shield
15	VREF-	velocity (or current) reference input (-)
16	-15VOUT	auxiliary voltage output (50mA max.)
17	GND	analog ground
18		DO NOT CONNECT
19	ENCA+	RS422 encoder signal
20	ENCA-	RS422 encoder signal
21	ENCB+	RS422 encoder signal
22	ENCB-	RS422 encoder signal
23	ENCZ+	RS422 encoder signal
24	ENCZ-	RS422 encoder signal
25	GND	analog ground
26		DO NOT CONNECT

Note: signals marked with "*" are optional and supplied on request

Note: connecting 24VSBLO to +24OUT, the electromagnetic brake is unlocked and motor's dynamic braking is disabled.

CONNECTIONS TO RESOLVER




Male 9 pin Sub-D connector

JP1 - SIGNALS TO RESOLVER		
pin	reference	description
1	THERMAL2	motor thermal protection*
2	n.c	not connected
3	+REFRES	positive resolver reference
4	SIN HIGH	positive resolver sinus signal
5	COS HIGH	positive resolver cosinus signal
6	THERMAL1	motor thermal protection*
7	-REFRES	negative resolver reference
8	SIN LOW	negative resolver sinus signal
9	COS LOW	negative resolver cosinus signal

* Connect the thermostatic potential free contact (n.c.), or PTC resistor between these pins

CONNECTIONS TO THE PERSONAL COMPUTER (SERIAL LINE)



Female 9 pin Sub-D connector

JPC - SERIAL LINE CONNECTION		
pin	reference	description
1		not connected
2	RS232-RX	RS232 receive
3	RS232-TX	RS232 transmit
4		not connected
5	RS232-GND	Rs232 ground
6		not connected
7		not connected
8		not connected
9		not connected

TABLE OF CONDUCTORS SECTION V.S CONVERTER SIZE

Connector	Function	R05	R10, R15	R20, R30
TB1	clamp resistor cable	1,5 mm ²		
TB2	motor cable	1,5 mm ²	2,5 mm ²	4 mm ²
TB3	power supply cable	1,5 mm ²	2,5 mm ²	4 mm ²
TB4	brake cable, brake supply and services	0,5 ÷ 1 mm ²		
JP1	motor signal cable	0,14 ÷ 0,22 mm ²		
JP2	control unit signal cable	0,14 mm ²		

LEDS DESCRIPTION


On the front of the drive 6 LEDs are mouted to display the status

The green LEDs are normally on and their meaning is :

- L6 : 24Vdc supply to the brake
- L5 : 220V tri-phase power on
- L4 : Auxiliary power supply on
- L3 : power enable digital input (ENABLE) on
- L2 : reference enable digital input (ARMO) on

The red LED is normally off and it displays a fault when lit :

- L1 : a fault occurred, power has been cut-off



7-SEGMENT DISPLAY

On the front of the drive is located a 7-segment display for status information. The display shows the actual status of the drive, and in case of a fault, the code of the fault. Depending on the operating phase the display have different meanings.

Power up

-	internal self check in progress
A	internal powerup error
1,2,3,4	internal self check errors
b	missing operating code

The powerup condition is indicated by the absence of the decimal dot blinking on the display. All the errors in this situation are not recoverable, the converter is not operating properly, the ISD interface on the PC cannot be operated.

Normal operation

After powerup is completed, the decimal dot starts blinking, indicating that the drive has successfully completed the self test phase. The ISD interface on the PC works properly.

In this operating condition, three different fault classes are displayed. If more than one fault of different classes is present, the display shows the fault belonging to the most severe class.

Hardware faults (most severe)

1	n.a.
2	overvoltage
3	undervoltage
4	overcurrent
5	motor thermal protection
6	overvoltage of the resolver excitation signal
7	undervoltage of the resolver excitation signal

All these faults will shut down the power. In case more of a single fault is actually present, the highest priority fault is displayed (1= highest priority)

Software faults

P (blinking)	wrong data in parameter storage (drive is disabled)
1 (blinking)	Ixt protection. The output current is limited automatically to the preset Cont Current level. 10 seconds after the average current is returned below 7% of the threshold, the previous operating conditions are restored and the fault indication is cleared
2 (blinking)	n.a.
3 (blinking)	drive thermal protection (drive is disabled)
4 (blinking)	drive overspeed protection (drive is disabled)

I/O related faults (least severe)

-	Brake 24V supply is missing (drive is disabled)
=	Manual brake release (the dynamic braking is disabled)
-	End of stroke 1 (n.a.)
-	End of stroke 2 (n.a.)
-	both End of strokes active (n.a.)

TEST POINTS DESCRIPTION

On the front of the drive test points are accessible :

- TP4 ○ CURR (instantaneous motor current)
- TP3 ○ REF (reference voltage Vref)
- TP2 ○ TACHO (speed)
- TP1 ○ GND (analog ground)

The voltage on REF test point depends on the Reference amplitude adjust setting. With 100% amplitude the voltage on the test point is 4V with 10V input to the drive reference input.

The voltage on TACHO test point depends from the resolution set for the resolver converter, according to the following table:

RESOLUTION	TACHO [V/krpm]
12 bit	0,5
14 bit	2
16 bit	8

The voltage on the test point CURR depends on the drive's model, according to the following table:

Model	CURR [V/A]
R05	0.3
R10	0.2
R15	0.1
R20	0.082
R30	0.082

JUMPERS

The following jumpers on the base board and on the interface board are factory settings, and do not need to be changed by the user. These jumpers are not accessible and require opening the enclosure.

The following jumpers are on the base board:

- P0, P1, P9 : used for testing purposes (normally open)
- P2 : undervoltage disable
- P3 : connects GND24V to GND (GND24V is normally floating)
- P4 : used for testing purposes (normally open)
- P5-P6 : set the internal switchmode supply to operate from the auxiliary 110 Vac supply input
- P7-P8 : set the internal switchmode supply to operate from the 310 Vdc power bus (these jumpers are mutually exclusive with P5, P6)

The following jumpers are on the interface board:

- JP1, JP2, JP3 : used for testing only (normally closed).

THE ISD-PC INTERFACE

The ISD-PC interface allows to properly setup all drive parameters to fit the final user application. The interface, running under Windows on a PC, is a friendly and easy to use environment either for setting application parameters and for verification of the correct installation during commissioning.

ISD-PC SOFTWARE INSTALLATION

PC requirements

386DX33 or faster cpu, with at least 4M of RAM

Color monitor recommended

Runs under Windows 3.1, 3.11, Windows'95, Windows NT

RS232 serial line (COM1 or COM2) for connecting the drive

Pointing device (mouse or equivalent)

Installation

First copy the ISD.INI file supplied with the ISD-PC to your current Windows directory.

Edit the line **"port=com1"** in the ISD.INI file to set the serial line you are currently using to connect the drive (COM1 or COM2 are supported)

Attention: DO NOT CHANGE the parameters of the serial line (baud rate, parity etc.) otherwise it will not be able to connect the drive.

Run the ISD.EXE executable file. The PC_ISD window appears. Execute the **Connect** command, from the commands pull-down menu' to connect the drive. The interface is now active.

USING THE ISD-PC INTERFACE

The ISD-PC interface startup windows is shown in fig.6. Most of the common settings are shown on the main windows.




Fig 6 : Startup window

On these windows are shown the most important identification data of the converter: Model (I1), Size (I2), Serial Number (I3), Sw versions (I4, I5) the Configuration (I6) and Motor Poles (I7). These data cannot be modified by the user, except for the Configuration (I6) and Motor Poles (I7) fields.

Use the I7 field for storing the name of the configuration file currently in use on the drive. This will give simple way of identification of the current set of parameters in use on the drive.

Three lamps show the status of Enable (L1), Armo (L2), Fault (L3). Nine smaller smaller red lamps show the actual faults. An indication of the fault occurred is shown passing on the lamp icon with the pointing device.

Selector icon (S1), Trimmer icons (T1..T3) and Parameter icons (P1..P4) are used for parameter setting.

Other windows are available by clicking on the picture of the drive, or through the **Block analyzer** command in the **Tools** pulldown menu (fig. 7)




Fig 7 : Block diagram window

Clicking the appropriate function block, other windows become available.

Monitoring fields show the current value of drive variables. The value is updated every second when the ISD-PC interface is connected to the drive.




Fig 8 : Command generator window

This window shows a block diagram of the drive command generator block. . Most of the settings relevant to the speed loop are presented here.

Trimmer icons T4..T5 are shown, selectors S2..S6 are shown and Switch SW1 is shown

Two more windows can be accessed directly from here, clicking the functional block icons: **Power driver** window (fig. 4) and **Resolver converter** window (fig. 5).




Fig 9 : Power driver window

In this windows are shown Enable switch SW2, Clear protection switch SW3 and Fault switch SW4. Enable switch SW2 should always be on to allow enabling the drive. Switches SW3 and SW4 should always stay off for normal operations.




Fig 5 : Resolver converter window

This window shows the block diagram of the resolver conversion circuitry on the drive.

In this windows Trimmer icons T6..T9 and selector S7 are shown. Note that Trimmer T8 (Velocity offset) is set in the factory to the correct value and should not be adjusted.

Lamp L4 Sincross is used for Resolver Phase adjust.

Parameters settings

Listed below are the parameter that can be set through the interface. Setting is performed by clicking on the corresponding icon. A dialog box appears, with either a selection of choices or a digital trimmer with arrows icons for incrementing or decrementing the value.

After adjusting the value, push the Set button to set the value and the Done to exit the dialog box.

Warning: parameters are stored in volatile RAM until the configuration is saved in FLASH EPROM via the Freeze configuration command (see Saving and restoring settings). If the drive is switched off before saving, all the current configuration is lost.

Startup window

Continuous current (P1) - Coarse/fine setting of the continuous current. This is the current output level that is automatically set when Ixt protection has tripped.

Peak current (P2) - Coarse/fine setting of the peak current. Available also in the Command generator window.

Brake current (P3) - Value of the current set during the dynamic braking.

Ixt threshold (P4) - Threshold for tripping the Ixt protection.

Reference offset compensation (T1) - coarse/fine adjust of the reference offset. Applicable only in speed mode. Trimmer T3 is available also in the Command generator window.

Speed reference (T2) - coarse/fine adjust of the speed reference. It sets the speed of the motor when a full scale command is applied to the drive. The full scale command is affected by the Reference amplitude adjust parameter. The range is 5V(200%) to 10V(100%). Applicable only in speed mode. Trimmer T2 is available also in the Command generator window.

Gain adjust (T3) - coarse/fine adjust of the speed loop gain, This trimmer can only increase the gain. Trimmer T3 is available also in the Command generator window.

Encoder resolution setting (S1) - Four different resolutions are available, depending on the resolver resolution selected. The table below shows the min/Max range for each resolution:

RESOLUTION	ENCODER PULSES/TURN	
	min	max
12	128	1024
14	512	4096
16	2048	16384

These tables are valid for two pole resolvers. If your resolver has a different number of poles, you must multiply the pulses per turn by $\frac{\text{resolver's poles number}}{2}$.

Motor Poles (I7) - selection of the number of motor poles. 4, 6, 8 poles motor are available. This setting has no effects until the power is switched off and on again. Remember to freeze the parameters before switching the drive off.

Resolver converter window

Resolver excitation level (T7) - Value of the excitation signal [Vrms]. Set this value taking into account the resolver transformer ratio. The input level for Sin, Cos signal should be 2Vrms +/- 10%.

Resolver phase adjust (T6) - Phase adjust of the resolver signals Sin Cos against excitation to compensate resolver and cabling phase shift. Adjust this trimmer by looking at the L4 lamp. Increase the value until the lamp toggles. Across the toggle point of the lamp there is the optimal value. **Note:** remember that you should issue the **Connect** command to have the refresh of the indicators active (see ISD-PC software Installation).

Resolver resolution (S7) - Selects the resolution of the resolver converter. Note the resolution affects the maximum tracking speed of the resolver, and therefore the maximum allowed speed of the motor.

RESOLUTION	RPM MAX
12	
14	
16	

Resolver phase adder (T9) - Adjust the mechanical phasing of the resolver with respect to the motor shaft. The correct value (degrees) should be determined following the **Application note no. 003**, using procedure B for point **3. Resolver positioning**. Procedure A do not work with ISD300 drives.

Command generator window

Armo (SW1) - when cleared to 0 set the input reference to 0. When active allows the input referenceto be fed to the drive command generator. Its status is shown by L2 lamp.

Reference bandwidth (S2) - insert a low pass filter on the reference input when low. Should be set to high when current command is used.

Reference amplitude adjust (T4) - adjust the amplitude of the reference for maximum command. It allows 100% to 200% regulation, to work with NC which have from $\pm 5V$ to $\pm 10V$ full scale output.

Reference selection (S3) - sets the input reference for the command generator to external, internal (n.a.) or ramp. If set to ramp adjust the ramp duration with Trimmer T5.

Ramp duration (T5) - Coarse/fine setting of the ramp duration.

Speed loop pole placement (S4) - set the position of the compensation of the PI loop.

Speed loop gain (S5) - set the minimum gain of the speed loop. Set to **Low** first, than increase the Gain adjusting trimmer T3. If the gain increase is not sufficient for the application, set S5 to **High**, and readjust the Gain adjust trimmer T3.

Gain adjust (T3) - coarse/fine adjust of the speed loop gain, This trimmer can only increase the gain. Trimmer T3 is available also in the Startup window.

Mode select (S6) - Selects operating mode either speed mode or current mode.

Saving and restoring settings

After that the drive is set according to the desired application, parameter should be permanently stored in the non volatile memory of the drive.

To accomplish this use the **Freeze** command in the **Command** pull-down menu. The interface asks also for a file name to be written on the disk with the parameter set.

It is possible to store the current application parameters also to a file on the disk, using the **Save as** command in the File pull-down menu. The file saved can be stored on the PC disk for documentation and for initializing new drives with the same parameters.

To accomplish this use the command **Open** in the File pull-down menu. The selected file is transferred to the drive. Remember to **Freeze** the settings to store them in the non volatile memory.

In case of a wrong setting of parameters, the default values (factory setting) of the drive parameter can be recalled through the **Restore default** command in the **Command** pull-down menu

Scope and waveform generator function

This function can be accessed through the **Waveform generator** command in the **Tools** pull-down menu.

The scope shows like the front panel of a common digital scope. Buttons are available for selecting trigger level, slope, trigger position, trigger channel.

The scope starts pushing the Start button. The Trigger lamp (L5) is lit when trigger condition is met. The Ready lamp (L6) is lit when the buffer is filled. After that, by clicking on the scope graticule, the selected waveforms are displayed on the screen.

The drive stores internally the samples of 8 channels (2ms sampling time for 1024 samples buffer). Data are transferred to the screen by clicking on the graticule screen. Displayed channels are selected through the buttons on top of the graticule: Up to 8 different channels are displayed.

The waveform and scope window is shown in fig. 6




Fig 6 : Scope and waveform generator window

The waveform generator allows to connect to the drive an internally generated input waveform, depending on the control mode (speed or current) selected. The user can select the amplitude, the shape and the period of the waveform. For safety reason, when the waveform generator is stopped, the drive is disabled. To enable again, use the **Enable** switch in the **Power driver** window of the block analyzer.

COOLING REQUIREMENTS

NATURAL CONVECTION

In single axis application the unit is used with its lateral heatsink (standard). The following condition apply:

SIZE	MAX CONTINUOUS CURRENT
R05	5A
R10	10A
R15	10A
R20	10A
R30	10A

The above table applies with an ambient temperature of 40°C, and unit mounted vertically with 40 mm free space on both sides and 200 mm above and below to ensure air circulation.

FORCED VENTILATION

The unit has an internal temperature limit switch, set at 80°C. In the following table is shown the temperature rise ΔT of the heatsink at an ambient temperature of 40°C, using a fan model PAPST multifan 4314 (119x119 mm):

SIZE	THRESHOLD	CURRENT	Δ TEMPERATURE
R05	80°C	5A	15°C
R10	80°C	10A	20°C
R15	90°C	15A	35°C
R20	90°C	20A	40°C
R30	90°C	30A	40°C


The above table applies with an ambient temperature of 40°C, and unit mounted vertically with 20 mm free space on both sides and 200 mm above and below to ensure air circulation. The fan should be installed below the unit, with 100mm maximum spacing from the drive. The required airflow is 100 m³/h.

When using a 24Vdc fan, as the above mentioned PAPST fan, its power supply can be obtained from the drive, using the brake 24V supply (TB4 connector, pin B+, B-). It should be checked that if the brake is used, the total current consumption on this power supply (brake+fan) is less than 0.8 A.

DIMENSIONS AND FIXING

As already pointed, the dimensions of the mono-axis applications with lateral heatsink are different from the multi-axis ones with rear dissipation. The following figures show this two cases.

LATERAL HEATSINK APPLICATION



Note : to guarantee an adequate air flow, it is needed to leave a 40 mm clearae between the units in the multi-axis application.

EMC PRESCRIPTION

FOREWORD

The converter is a product designed to be incorporated in a more complex equipment .

Therefore elettromagnetic compatibility depends by factors that are not totally under control of the manufacturer but depends on the installation, wiring and grounding of the equipment.


In this manual are given instructions for installation in order to obtain conformity with actual standards for elettromagnetic compatibility. This information have been collected after a comprehensive test campaign and their purpose is to make the job of the end user as easy as possible.

REFERENCE STANDARDS

Generic Standard EN 50081-2 e EN 50082-2 (industrial environment)

- EN61000-4-2 Electrostatic discharge
- EN61000-4-4 Electrical fast transient burst
- EN61000-4-5 Surge immunity (FULL-LIGHTNING)
- EN61000-4-8 Power frequency magnetic field
- ENV50140 High frequency elettromagnetic fields
- ENV50204 Elettromagnetic field at 900 MHz with ON/OFF modulation
- ENV50141 Radiofrequency
- EN55011 Radiated and conducted emission
- EN61800-3 Semiconductor power converters for adjustable speed electric drive system

INSTALLATION WITH SPECIAL FILTER FOR CONVERTER




- Supply cable(A): no prescription
- Motor cable(B): to prevent emission of the motor cable is recommended to use shielded cable. The shielding must be connected to the ground of the converter and to the ground terminal of the motor.
In this configuration due to the characteristics of the special filter for converter, it is allowed to use unshielded cable. The cable length must be less or equal 25m.
- Transformer: must be shielded between primary and secondary windings and its rated power must be adequate for equipment requirements.
- Clamp resistor (C): connected through twisted cable with length less or equal 2m.
- Motor signal cable (D): shielded cable with length less or equal 25m.
- Control connections (E): shielded cable with length less or equal 3m.
- EMI filter: special filter for converter code 2SMPM3338/OC (cable is included).

Conformity

In this configuration the converter is compliant with the regulations referenced above .

INSTALLATION WITHOUT SPECIAL FILTER FOR CONVERTER




- Supply cable(A): no prescription
- Motor cable(B): to prevent emission of the motor cable is recommended to use of shielded cable. The shield must be connected to the converter ground terminal and to the ground terminal of the motor. The cable length must be less or equal 25m.
- Transformer: must be shielded between primary and secondary windings and its rated power must be adequate for equipment requirements.
- Clamp resistor (C): connected through twisted cable with length less or equal 2m.
- Motor signal cable (D): shielded cable with length less or equal 25m.
- Control connections (E): shielded cable with length less or equal 3m.
- Network filter: Siemens B84143-B XXR with following characteristics:
 - Nominal voltage: 440/250 Vac, 50/60Hz
 - Phase number: 3
 - Temperature range: -25...+40 gradi
 - Nominal current: range XX = 8-12-16-25-36A for different models
- Cabinet: All equipments should be installed in metal cabinet closed over all sides.

Conformity

In this configuration the converter is compliant with the regulations referenced above .

INSTALLATION WITHOUT FILTERS



- Supply cable(A): no prescription. Install a suppression ferrite KITAGAWA SFC10 (F)
- Motor cable(B): to prevent emission of the motor cable is recommended to use of shielded cable. The shield must be connected to the converter ground terminal and to the ground terminal of the motor. The cable length must be less or equal 25m. Install a suppression ferrite KITAGAWA SFC10 (F)
- Transformer: must be shielded between primary and secondary windings and its rated power must be adequate for equipment requirements.
- Clamp resistor (C): connected through twisted cable with length less or equal 2m.
- Motor signal cable (D): shielded cable with length less or equal 25m.
- Control connections (E): shielded cable with length less or equal 3m.

Conformity

In this configuration the converter is compliant with all the regulation referenced above regarding immunity (EN50082-2).

In this configuration the converter is not compliant to the emission regulation EN55011 (Emission, Generic standard).

In this configuration the converter is compliant to the product specific regulation EN61800-3 for the class "Restricted distribution" and "Second environment".

Note:

Restricted distribution: the mode of sales distribution in which the manufacturer restricts the supply of equipment to supplier, customer or users who separately or jointly have technical competence in the EMC requirements of the application drives.

Second environment: the environment which includes all establishment other than those directly connected to a low voltage power supply network which supplies building used for domestic purposes.

It is available on request the documentation of the radiated and conducted emission measurements to perform adequate action.

If this equipment must work in the first environment please contact the manufacturer.

INDEX

INTELLIGENT SERVO DRIVE ISD300R SERIES	3
DESCRIPTION	3
PRODUCT IDENTIFICATION	3
MODEL SPECIFICATION.....	4
TECHNICAL CHARACTERISTICS	5
Main supply	5
Auxiliary supply	5
Enclosure	5
Clamping circuit.....	6
Electromagnetic brake	6
Dynamic braking	6
Resolver	6
Input / Output signals	7
Protections	7
Operating temperature.....	7
Others	7
CONNECTIONS	10
MAIN SUPPLY CONNECTIONS	12
MOTOR CONNECTIONS.....	13
CLAMP RESISTOR CONNECTIONS	13
BRAKE AND AUX. CONNECTIONS	13
CONNECTIONS TO THE CONTROL UNIT.....	14
CONNECTIONS TO RESOLVER.....	15
CONNECTIONS TO THE PERSONAL COMPUTER (SERIAL LINE)	15
TABLE OF CONDUCTORS SECTION V.S CONVERTER SIZE	16
LEDS DESCRIPTION	16
7-SEGMENT DISPLAY	17
Power up	17
Normal operation.....	17
TEST POINTS DESCRIPTION.....	18
JUMPERS.....	19
THE ISD-PC INTERFACE	20
ISD-PC SOFTWARE INSTALLATION	20

PC requirements	20
Installation	20
USING THE ISD-PC INTERFACE.....	21
Parameters settings	26
Startup window.....	26
Resolver converter window	27
Command generator window	27
Saving and restoring settings.....	28
Scope and waveform generator function	29
COOLING REQUIREMENTS	30
NATURAL CONVECTION	30
FORCED VENTILATION	30
DIMENSIONS AND FIXING	31
LATERAL HEATSINK APPLICATION	31
EMC PRESCRIPTION.....	32
FOREWORD	32
REFERENCE STANDARDS.....	32
INSTALLATION WITH SPECIAL FILTER FOR CONVERTER.....	33
Conformity.....	33
INSTALLATION WITHOUT SPECIAL FILTER FOR CONVERTER	34
Conformity.....	34
INSTALLATION WITHOUT FILTERS	35
Conformity.....	35