

RX113 Family

Capacitive Touch API User's Manual

EU00162
Rev.1.00
December 5, 2014

Introduction

The Renesas Capacitive Touch Application Program Interface (API) has been created to allow users of the Capacitive Touch Sensing Unit (CTSUS) on the RX113 Group devices to easily add capacitive touch handling capability into their application. This application note focuses on using the API and integrating it with your application program.

This API requires the hardware configuration for the CTSUS module.

The API source files comply with the Renesas RX compiler only.

Target Device

The following is a list of devices able to use this API:

- **RX113 Group**

When using this application note with other Renesas MCUs, careful evaluation is recommended after making modifications to comply with the alternate MCU.

Related Documents

- Firmware Integration Technology User's Manual (R01AN1833EU)
- Board Support Package Firmware Integration Technology Module (R01AN1685EU)
- Adding Firmware Integration Technology Modules to Projects (R01AN1723EU)
- RX113 Capacitive Touch Evaluation System Quick Start Guide (EU00161)

Contents

1. Overview	2
2. API Information.....	3
3. Usage Notes.....	5
4. Demo Project.....	11
Website and Support.....	12

1. Overview

This API is written to configure the CTSU peripheral on the Renesas MCUs. The API also provides the user with ability to perform simple processing on measurements made by the CTSU for each channel and then treat each channel as a Touch Button, or group channels and use them as linear or circular sliders. The API inherently depends on the user to provide valid configuration values for each Special Function Register (SFR) of the CTSU. The user should obtain these values by performing calibration with software such as **Workbench 6**. The demonstration projects provided with this API provide an example of how the API uses the calibrated configuration values, a simple filter technique to smooth data measured for each channel, and determine if a channel is being touched. The user can evaluate these demonstrations with the RX113 CapTouch MCU Board and its daughter boards.

1.1 Features

Below is a list of the features supported by the Touch API.

- Initialize the CTSU hardware
- Configure for either self-capacitance measurement or mutual capacitance measurement mode
- Provide hooks to use parameters generated by Capacitive Touch calibration software
- Read and modify internal threshold and filtering parameters
- Selectively enable and disable channels
- Enable and disable drift compensation

1.2 Overall File structure

The API structure is as follows:

`r_ctsu_rel` – Contains a modified Workbench6 project as a base for driving the overall capacitive touch sensing solution.

`r_touch` – The lower layer containing calls into the `r_ctsu_rel` layer which is responsible for controlling the CTSU operation.

`r_touch_button` – Layer which uses the functions and variables located in `r_touch` and `r_ctsu_rel` to monitor and report the status of touch sensing channels which are intended to operate as buttons.

`r_touch_slider` – Layer which uses the functions and variables located in `r_touch` and `r_ctsu_rel` to monitor and report the status of touch sensing channels which are logically and physically grouped to operate as linear slider or circular slider (wheel).

2. API Information

This Middleware API follows the Renesas API naming standards.

2.1 Hardware Requirements

This middleware requires your MCU support the following peripherals:

- CTSU module peripheral

2.2 Hardware Resource Requirements

This section details the hardware peripherals that this middleware requires. Unless explicitly stated, these resources must be reserved for the middleware and the user cannot use them

- Capacitive Touch Sensing Unit (CTSU)

2.3 Software Requirements

The API uses a modified Workbench 6 project located under `r_ctsu_rel`.

2.4 Supported Toolchains

This middleware is tested and working with the following toolchains:

- Renesas RX Toolchain v2.10

2.5 Header Files

There are three header files which contain API calls available to the user. These are:

- `r_touch_if.h`
- `r_touch_button_if.h`
- `r_touch_slider_if.h`

The API configuration header files allow the user to change the following parameters. The effect of modifying these files reflects in the private files for each layer. The configuration files are as follows:

- `r_touch_config.h` – Allows the user to enable or disable parameter checks
- `r_touch_button_config.h` – Allows the user to specify individual or default values for the following:
 - Transmit and Receive channel number for each button
 - Debounce counter
 - Repeat delay counter
 - Repeat rate count
 - Number of scans for which button is determined as pressed before generating a short hold event
 - Number of scans for which button is determined as pressed before generating a long hold event
 - Enable/disable events for press, short press-and-hold, long press-and-hold, repeat events on press periodically
 - Function to call when an event occurs
- `r_touch_slider_config.h` – Allows the user to specify default values used in the slider position calculations. The values configured are the following:
 - Slider type – Linear or Circular
 - Channels used for the slider
 - Maximum value generated after normalization
 - Apply normalization to the channel data
 - Value used for normalization

- Weight of running average for each channel, used to smooth data.
- Weight of running average for previous sum of focus channels used as cutoff threshold.
- Absolute threshold for sum of slider values

3. Usage Notes

The R_Touch API is intended to be used with a workbench 6 project which configures the CTSU for measurement and updates variables which monitor the status of touch on Touch Sense channels which are enabled.

3.1 R_Touch

The R_Touch layer is responsible for controlling the CTSU operation and generates data to be used by higher layers. The R_Touch layer accesses functions and variables defined in the r_otsu_rel layer to control operation of the CTSU. The user can access some of the important configuration settings created by workbench through the **R_Touch_Open** functions using arguments. Values returned to the user include settings for initial thresholds, hysteresis, and SFR values for diffusion control, offset0, and offset1 which are unique for each channel. The user may also specify a callback function which will be executed once a single scan cycle is completed. The callback function is called from an interrupt. The user is therefore advised to avoid while loops and limit the amount of processing performed within this function. The callback function should be ideally used to unlock semaphores and indicate to other entities that a scan has completed. The R_Touch_Open function also initializes the CTSU by means of the r_otsu_rel layer.

After the CTSU has been initialized, the user must call the **R_Touch_Process** periodically with the option TOUCH_OPTION_AUTO_SCAN to enable a new scan cycle after all post measurement processing is complete. If the user provides the first argument which is not a NULL pointer, then the function returns the location which contains the raw result data.

Additionally, the **R_Touch_Read** function allows the user to access the current value of variables such as the difference between the reference count and the sensor count (delta count), or the Touch judgment counter.

3.2 R_Touch_Button

The R_Touch_Button layer is created to process data from a channel and treat it as a button. Global variables present within the r_otsu_rel directory are constantly modified when the CTSU is operational. The R_Touch_Button layer accesses the needed values from the lower layers and determines whether a channel is being touched. Depending upon the configuration of each button, multiple events can be triggered when the corresponding conditions are valid. The primary tasks that a user may need are detailed below.

3.2.1 Adding a button

In order to add a button, one needs to first configure/calibrate a CTSU channel as a button using the Workbench 6 software. The lower level functions which process buttons are KeyProcess(), and KeyCalibrationProcess(). These functions eventually update bits in g_real_touch_info and g_touch_result depending upon whether a channel is being touched. The API will fail to report the correct status of the button if configuration and calibration of the CTSU channel is not performed using Workbench 6.

Once calibration and configuration with Workbench 6 has been performed, the user can then modify the configuration files controlling the API. The configuration file for buttons is **r_touch_button_config.h** and should be located under the **r_config** directory. One may use the r_touch_button_config_reference.h file as a starting point which uses the *RX113 Captouch Wheel/Slider/Buttons* daughter board configuration.

To add a new button in Self-Capacitance mode, simply add to the configuration file the following statement:

```
#define TOUCH_BUTTON_CFG_BUTTONn_CHANNEL_RX      (m)
```

Where **n** is a number from 0 to the maximum number of channels available with the CTSU (and configured with Workbench 6). And **m** is the touch sensor channel number (TSM).

To add a new button in mutual capacitance mode, add the following two statements to the configuration file:

```
#define TOUCH_BUTTON_CFG_BUTTONn_CHANNEL_TX      (p)
```

```
#define TOUCH_BUTTON_CFG_BUTTONn_CHANNEL_RX      (m)
```

Where **p** is the channel acting as the transmit electrode for the button with **m** ≠ **p**.

Repeat this procedure for all buttons configured in Workbench 6.

3.2.2 Configuring a button

Once a button has been added, additional configuration options are available to further modify the behavior of all or each individual button. If all buttons are expected to exhibit similar behavior then preprocessor definitions under basic configuration options should be modified. These adjustments are as below:

TOUCH_BUTTON_CFG_DEFAULT_DEBOUNCE_COUNT – Defines the number of consecutive iterations for which the lower layers must determine a channel is touched before a button is considered as pressed.

TOUCH_BUTTON_CFG_DEFAULT_RPT_DELAY_COUNT – Defines the number of iterations between the press event and the first repeat event.

TOUCH_BUTTON_CFG_DEFAULT_RPT_RATE_COUNT – Defines the number of iterations after which a channel determined to be touched executes the repeat event.

TOUCH_BUTTON_CFG_DEFAULT_SH_HOLD_COUNT – Defines the number of iterations after which a short hold event is generated while a button is considered touched.

TOUCH_BUTTON_CFG_DEFAULT_LG_HOLD_COUNT – Defines the number of iterations after which a long hold event is generated while a button is considered touched.

TOUCH_BUTTON_CFG_DEFAULT_STUCK_COUNT – Defines the number of iterations after which an event for stuck button is generated as a button is considered to be touched.

TOUCH_BUTTON_CFG_DEFAULT_RELEASE_EVENT – Defines whether the button event generation is enable when the channel is determined to be not touched after being touched.

TOUCH_BUTTON_CFG_DEFAULT_PRESS_EVENT – Defines whether the button event generation is enabled when the channel is touched and considered as pressed.

TOUCH_BUTTON_CFG_DEFAULT_REPEAT_EVENT – Defines whether repetitive button event generation is enabled while button is considered pressed.

TOUCH_BUTTON_CFG_DEFAULT_SHORTHOLD_EVENT – Defines whether an event is generated when channel is touched for the duration of SH_HOLD_COUNT.

TOUCH_BUTTON_CFG_DEFAULT_LONGHOLD_EVENT – Defines whether an event is generated when channel is touched for the duration of LG_HOLD_COUNT.

TOUCH_BUTTON_CFG_DEFAULT_CALLBACK – Defines the function which gets called when an event occurs. This function gets passed the event type and the button/key identifier as arguments.

3.2.3 Advanced configuration options

When creating buttons which behave differently from each other, the user needs to specify parameters other than the basic default parameters as mentioned above. To assign unique parameters to individual buttons, enable the preprocessor **TOUCH_BUTTON_CFG_ADV_DEFAULT** and assign as shown below

```
#define TOUCH_BUTTON_CFG_BUTTONn_xxxxxxxx (yyy)
```

Where n is 0 ... number of channels configured as buttons.

These unique values will replace the corresponding default values for button n in the file `r_touch_button_private.h`.

The user is advised to take a quick look at `r_touch_button_private.h` for further understanding.

3.2.4 Evaluating button state

Once a button has been properly configured, the user can call the function **R_Touch_Button_Open** to initialize the buttons. If the user chooses to provide arguments other than NULL to the open function, then the particular values for the configuration will be overridden.

After the button has been configured and initialized, the user must periodically call **R_Touch_Button_Handler** to check if the button has changed states and if any events have occurred. Arguments passed to the handler are button handles and the number of handles passed (as an array). Handles to all buttons are obtained as a return value through **R_Touch_Button_Open** when no arguments are passed to it. When arguments are passed to the handler, only those buttons are checked for which handles are passed. The following is an example code for checking only 3 channels out of a total of 12 configured as buttons using basic configuration in self-capacitance mode.

```

#include <stddef.h>
#include "r_touch_if.h"
#include "r_touch_button_if.h"

touch_button_hdl_t* all_button_handles;
touch_button_key_t last_button;

void R_Touch_Button_Callback( touch_button_key_t key, touch_button_event_t event )
{
    /* Verify by placing a breakpoint at the nop */
    nop();
}

void main(void)
{
    /* Find out how many buttons are currently in use,
     * and get the configuration location */
    all_button_handles = R_Touch_Button_Open(&last_button, NULL, NULL);

    while(1)
    {
        /* Check only buttons 9, 10, and 11. */
        if( g_ctsu_soft_mode == CTSU_FINISH_MODE
            || g_ctsu_soft_mode == CTSU_READY_MODE )
        {
            R_Touch_Button_Handler(&all_button_handles[9],3);
        }
    }
}

```

Figure 1: Test code for R_Touch_Button

```

#define TOUCH_BUTTON_CFG_BUTTON0_CHANNEL_RX (0)
#define TOUCH_BUTTON_CFG_BUTTON1_CHANNEL_RX (1)
#define TOUCH_BUTTON_CFG_BUTTON2_CHANNEL_RX (2)
#define TOUCH_BUTTON_CFG_BUTTON3_CHANNEL_RX (3)
#define TOUCH_BUTTON_CFG_BUTTON4_CHANNEL_RX (4)
#define TOUCH_BUTTON_CFG_BUTTON5_CHANNEL_RX (5)
#define TOUCH_BUTTON_CFG_BUTTON6_CHANNEL_RX (6)
#define TOUCH_BUTTON_CFG_BUTTON7_CHANNEL_RX (7)
#define TOUCH_BUTTON_CFG_BUTTON8_CHANNEL_RX (8)
#define TOUCH_BUTTON_CFG_BUTTON9_CHANNEL_RX (9)
#define TOUCH_BUTTON_CFG_BUTTON10_CHANNEL_RX (10)
#define TOUCH_BUTTON_CFG_BUTTON11_CHANNEL_RX (11)

```

Figure 2: Button Channel Configuration

3.3 R_Touch_Slider

In capacitive touch sensing, a slider is a collection of closely located electrodes with a pattern that allows estimating an interpolated location of a touch. For example, if the user is touching a position midway between two elements of a two channel slider, then the position of the touch should be at 50% of the maximum absolute output. The R_Touch layer activates layers below it to run the CTSU to perform measurements on the channels and update related global data variables. The R_Touch_Slider layer selectively uses some of these global variables to compute the position of the touched location on a collection of channels. The R_Touch_Slider allows the user to create two types of sliders, linear sliders and circular sliders in Self-Capacitance mode only.




Figure 3: Self Capacitance Demonstration Board

The primary tasks a user may need to accomplish with a slider are detailed in the following material.

3.3.1 Adding a Slider

In order to add a slider, the user must first configure/calibrate the CTSU using the Workbench 6 software. This allows the variables in the lower levels to be activated and updated when the CTSU is operational. The `R_Touch_Slider` primarily uses the `g_dcount` variable array which is updated by the lower levels to determine the position. Without proper configuration with Workbench 6, this variable may not be updated periodically.

After configuration and calibration is performed with Workbench 6, the user can then modify the configuration files controlling the API. The configuration file for buttons is `r_touch_slider_config.h` and should be located under the `r_config` directory. One may use the `r_touch_slider_config_reference.h` file as a starting point which uses the *RX113 Captouch Wheel/Slider/Buttons* daughter board configuration.

To add a slider add the following equivalent statements to `r_touch_slider_config.h`.

```
#define TOUCH_SLIDER_CFG_SLIDERn_TYPE          (m)
```

Where **n** = 1 to number of sliders to use, and **m** is the type of slider. If **m** = 0, then the calculations on channel readings assume a linear slider. If **m** = 1, then the calculations on channel readings assume a circular slider/wheel.

After declaring the type for slider 'n', the user needs to define the channels used for the slider position calculations. This is done as follows:

```
#define TOUCH_SLIDER_CFG_SLIDERn_CHANNELp      (q)
```

Where **p** = is the element number (0 to number of channels part of the slider), and **q** = channel used for element **p**.

3.3.2 Configuring a slider

Once a slider has been added, additional configuration options allow the user to change the behavior of the calculations performed for the position. For example, the user may want to configure a circular slider to report the position of touch as an absolute value from 0° to 360°. Basic configuration options available are as follows:

`TOUCH_SLIDER_CFG_DEFAULT_USE_NORM` – Defines if normalization is performed on each channel.

`TOUCH_SLIDER_CFG_DEFAULT_NORM` – Defines the divisor value used to normalize a channel measurement.

TOUCH_SLIDER_CFG_NORM_MAX – Indicates the maximum value generated for a channel measurement after normalization. This value is co-dependent on divisor values used for each channel.

TOUCH_SLIDER_CFG_DEFAULT_CH_AVG_WEIGHT – Weight of running average for each channel, used to smooth data.

TOUCH_SLIDER_CFG_DEFAULT_PREV_SUM_WEIGHT – Weight of running average for previous sum of focus channels.

TOUCH_SLIDER_CFG_DEFAULT_THRESHOLD – Cumulative sums below this value will not be registered as a touch.

TOUCH_SLIDER_CFG_DEFAULT_CUTOFF – Indicates how far sum of slider values should fall below running average to indicate inactive touch.

3.3.3 Advanced options

If the user needs to specify unique parameters for each individual slider, the user needs to set the preprocessor statement TOUCH_SLIDER_CFG_ADV_DEFAULT to 0 for selecting advanced settings for each slider. When using the advanced configuration option, the user can define and override individual configuration parameters for each slider with the prefix to a preprocessor statement as shown below:

```
#define TOUCH_SLIDER_CFG_SLIDER1_xxxxxxx (yyy)
```

Note that the user can also define normalizations for individual slider channels as

```
#define TOUCH_SLIDER_CFG_SLIDERn_NORMp (zzzz)
```

Providing these advanced options will affect structure instances defined in `r_touch_slider_private.h`. The user is recommended to take a quick look at how changes in the configuration file affect these instances.

3.3.4 Evaluating a slider

In order to acquire the position of a touch, the user must first call the initialization function **R_Touch_Slider_Open** and provide the necessary arguments for each slider defined in the configuration. Necessary arguments include the mode of operation of the slider, i.e. absolute or relative, the maximum value of the slider (in terms of position), a pointer which gets assigned the location of the slider configuration, and the identifier for the slider i.e. TOUCH_SLIDERn, where n is 1 to last slider number defined in configuration file. If the configuration of the slider is performed correctly, then the Open function will make the slider ready for operation.

The user must then call **R_Touch_Slider_Read** periodically with the handle and pointer to a 16-bit signed integer passed as an argument to retrieve the current position of touch. The return value from the Read function indicates if the slider is currently being touched with position being reported in the integer. The following shows a snippet of code demonstrating the usage of the API for a slider:

```
/* Capacitive Touch Sensing Unit initial setup */
R_Touch_Open(NULL, NULL);

/*Initialize the slider API for linear/vertical slider */
R_Touch_Slider_Open(TOUCH_SLIDER_MODE_ABSOLUTE, 1024, TOUCH_SLIDER1,
&g_touch_v_slider_hdl);

/*Initialize the slider API for circular slider */
R_Touch_Slider_Open(TOUCH_SLIDER_MODE_ABSOLUTE, 360, TOUCH_SLIDER2,
&g_touch_w_slider_hdl);


















LedInitialization();

while (1U)
{
    if( g_ctsu_soft_mode == CTSU_FINISH_MODE || g_ctsu_soft_mode == CTSU_READY_MODE )
    {
        R_Touch_Process(NULL, TOUCH_OPTION_AUTO_SCAN);
        g_touch_v_slider_err = R_Touch_Slider_Read(g_touch_v_slider_hdl,
&g_slider_position);
        g_touch_w_slider_err = R_Touch_Slider_Read(g_touch_w_slider_hdl,
&g_wheel_position);
    }
}
```

Figure 4: Slider API usage

4. Demo Project

An e2studio project archive which demonstrates features provided by the API is included with this API User's Manual. The project is designed to run with the Renesas RX113 CapTouch Demonstration Kit, and demonstrates operation of Buttons, wheel, and sliders in self-capacitance mode and demonstrates operation of buttons in mutual-capacitance mode. The figure below shows the initial contents after importing the project with e2studio.

Name	Date modified	Type	Size
 r_touch_slider	12/3/2014 12:54 PM	File folder	
 r_touch_button	12/3/2014 12:54 PM	File folder	
 r_touch	12/3/2014 12:53 PM	File folder	
 r_ctsu_rel	12/3/2014 11:30 AM	File folder	
 r_config	12/3/2014 11:30 AM	File folder	
 r_bsp	12/3/2014 11:30 AM	File folder	
 .settings	12/3/2014 11:30 AM	File folder	
 .cheat	12/3/2014 11:30 AM	File folder	
 RX113_CapTouch_Demo_SelfMode.launch	12/3/2014 11:35 AM	LAUNCH File	10 KB
 RX113_CapTouch_Demo_MutualMode.launch	12/3/2014 11:40 AM	LAUNCH File	10 KB
 makefile.init	12/3/2014 12:51 PM	INIT File	1 KB
 custom.bat	10/30/2014 4:16 PM	Windows Batch File	0 KB
 .SelfModelinker	11/3/2014 11:23 AM	SELFMODELINKER...	2 KB
 .project	12/3/2014 11:30 AM	PROJECT File	1 KB
 .MutualModelinker	11/3/2014 10:33 AM	MUTUALMODEL...	2 KB
 .info	12/3/2014 11:53 AM	INFO File	1 KB
 .cproject	12/3/2014 11:40 AM	CPROJECT File	45 KB

The project contains two build configurations, namely SelfMode, and MutualMode. The .cheat folder contains parameter files which replace files in the r_ctsu_rel/TouchBase folder. When replacing the parameter file, remove the suffix _ref_xxxx.h. Ensure that the file being replaced is for the correct build configuration. Proper operation of the project is not guaranteed if you replace with r_ctsu_parameter_common_ref_self.h when building in MutualMode configuration.

To import the project into e2studio, open an e2studio workspace (click the **go to workbench** button, if a new workspace is created), right click in blank space within the **Project Explorer** tab and select **Import** → **Import**. Then select the option **General** → **Existing Projects into Workspace**. Then select **Next**. Use the option **Select archive file** and navigate to the zip file location using **Browse...** and select the file. The project should then appear in the Projects section with the name **RX113_CapTouch_Demos**. Ensure the checkbox against the name is checked. The option for **Copy projects into workspace** should be active. Select **Finish**. The project should now be visible in the Project Explorer tab.

To change build configurations, simply change the current configuration through the **Project** → **Build configurations** → **Set Active** option.

To enable debugging the project, first build the configuration. Then select a debugging session which matches the build configuration from those available under **Run** → **Debug Configurations** → **Renesas GDB Hardware Debugging**. Ensure that the correct Debug hardware is selected under the tab **Debugger** for the selected hardware debugging session.

Website and Support

Renesas Electronics Website

<http://www.renesas.com/>

Inquiries

<http://www.renesas.com/inquiry>

All trademarks and registered trademarks are the property of their respective owners.

Revision Record

Rev.	Date	Description	
		Page	Summary
1.00	December.05.14	—	First edition issued

Notice

1. Descriptions of circuits, software and other related information in this document are provided only to illustrate the operation of semiconductor products and application examples. You are fully responsible for the incorporation of these circuits, software, and information in the design of your equipment. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from the use of these circuits, software, or information.
2. Renesas Electronics has used reasonable care in preparing the information included in this document, but Renesas Electronics does not warrant that such information is error free. Renesas Electronics assumes no liability whatsoever for any damages incurred by you resulting from errors in or omissions from the information included herein.
3. Renesas Electronics does not assume any liability for infringement of patents, copyrights, or other intellectual property rights of third parties by or arising from the use of Renesas Electronics products or technical information described in this document. No license, express, implied or otherwise, is granted hereby under any patents, copyrights or other intellectual property rights of Renesas Electronics or others.
4. You should not alter, modify, copy, or otherwise misappropriate any Renesas Electronics product, whether in whole or in part. Renesas Electronics assumes no responsibility for any losses incurred by you or third parties arising from such alteration, modification, copy or otherwise misappropriation of Renesas Electronics product.
5. Renesas Electronics products are classified according to the following two quality grades: "Standard" and "High Quality". The recommended applications for each Renesas Electronics product depends on the product's quality grade, as indicated below.

"Standard": Computers; office equipment; communications equipment; test and measurement equipment; audio and visual equipment; home electronic appliances; machine tools; personal electronic equipment; and industrial robots etc.

"High Quality": Transportation equipment (automobiles, trains, ships, etc.); traffic control systems; anti-disaster systems; anti-crime systems; and safety equipment etc.

Renesas Electronics products are neither intended nor authorized for use in products or systems that may pose a direct threat to human life or bodily injury (artificial life support devices or systems, surgical implantations etc.), or may cause serious property damages (nuclear reactor control systems, military equipment etc.). You must check the quality grade of each Renesas Electronics product before using it in a particular application. You may not use any Renesas Electronics product for any application for which it is not intended. Renesas Electronics shall not be in any way liable for any damages or losses incurred by you or third parties arising from the use of any Renesas Electronics product for which the product is not intended by Renesas Electronics.
6. You should use the Renesas Electronics products described in this document within the range specified by Renesas Electronics, especially with respect to the maximum rating, operating supply voltage range, movement power voltage range, heat radiation characteristics, installation and other product characteristics. Renesas Electronics shall have no liability for malfunctions or damages arising out of the use of Renesas Electronics products beyond such specified ranges.
7. Although Renesas Electronics endeavors to improve the quality and reliability of its products, semiconductor products have specific characteristics such as the occurrence of failure at a certain rate and malfunctions under certain use conditions. Further, Renesas Electronics products are not subject to radiation resistance design. Please be sure to implement safety measures to guard them against the possibility of physical injury, and injury or damage caused by fire in the event of the failure of a Renesas Electronics product, such as safety design for hardware and software including but not limited to redundancy, fire control and malfunction prevention, appropriate treatment for aging degradation or any other appropriate measures. Because the evaluation of microcomputer software alone is very difficult, please evaluate the safety of the final products or systems manufactured by you.
8. Please contact a Renesas Electronics sales office for details as to environmental matters such as the environmental compatibility of each Renesas Electronics product. Please use Renesas Electronics products in compliance with all applicable laws and regulations that regulate the inclusion or use of controlled substances, including without limitation, the EU RoHS Directive. Renesas Electronics assumes no liability for damages or losses occurring as a result of your noncompliance with applicable laws and regulations.
9. Renesas Electronics products and technology may not be used for or incorporated into any products or systems whose manufacture, use, or sale is prohibited under any applicable domestic or foreign laws or regulations. You should not use Renesas Electronics products or technology described in this document for any purpose relating to military applications or use by the military, including but not limited to the development of weapons of mass destruction. When exporting the Renesas Electronics products or technology described in this document, you should comply with the applicable export control laws and regulations and follow the procedures required by such laws and regulations.
10. It is the responsibility of the buyer or distributor of Renesas Electronics products, who distributes, disposes of, or otherwise places the product with a third party, to notify such third party in advance of the contents and conditions set forth in this document, Renesas Electronics assumes no responsibility for any losses incurred by you or third parties as a result of unauthorized use of Renesas Electronics products.
11. This document may not be reproduced or duplicated in any form, in whole or in part, without prior written consent of Renesas Electronics.
12. Please contact a Renesas Electronics sales office if you have any questions regarding the information contained in this document or Renesas Electronics products, or if you have any other inquiries.

(Note 1) "Renesas Electronics" as used in this document means Renesas Electronics Corporation and also includes its majority-owned subsidiaries.

(Note 2) "Renesas Electronics product(s)" means any product developed or manufactured by or for Renesas Electronics.



SALES OFFICES

Renesas Electronics Corporation

<http://www.renesas.com>

Refer to "<http://www.renesas.com/>" for the latest and detailed information.

Renesas Electronics America Inc.
2801 Scott Boulevard Santa Clara, CA 95050-2549, U.S.A.
Tel: +1-408-588-6000, Fax: +1-408-588-6130

Renesas Electronics Canada Limited
1101 Nicholson Road, Newmarket, Ontario L3Y 9C3, Canada
Tel: +1-905-898-5441, Fax: +1-905-898-3220

Renesas Electronics Europe Limited
Dukes Meadow, Millboard Road, Bourne End, Buckinghamshire, SL8 5FH, U.K.
Tel: +44-1628-585-100, Fax: +44-1628-585-900

Renesas Electronics Europe GmbH
Arcadiastrasse 10, 40472 Düsseldorf, Germany
Tel: +49-211-6503-0, Fax: +49-211-6503-1327

Renesas Electronics (China) Co., Ltd.
Room 1709, Quantum Plaza, No.27 ZhiChunLu Haidian District, Beijing 100191, P.R.China
Tel: +86-10-8235-1155, Fax: +86-10-8235-7679

Renesas Electronics (Shanghai) Co., Ltd.
Unit 301, Tower A, Central Towers, 555 Langao Road, Putuo District, Shanghai, P. R. China 200333
Tel: +86-21-2226-0888, Fax: +86-21-2226-0999

Renesas Electronics Hong Kong Limited
Unit 1601-1613, 16/F., Tower 2, Grand Century Place, 193 Prince Edward Road West, Mongkok, Kowloon, Hong Kong
Tel: +852-2265-6688, Fax: +852 2886-9022/9044

Renesas Electronics Taiwan Co., Ltd.
13F, No. 363, Fu Shing North Road, Taipei 10543, Taiwan
Tel: +886-2-8175-9600, Fax: +886-2-8175-9670

Renesas Electronics Singapore Pte. Ltd.
80 Bendemeer Road, Unit #06-02 Hyflux Innovation Centre, Singapore 339949
Tel: +65-6213-0200, Fax: +65-6213-0300

Renesas Electronics Malaysia Sdn.Bhd.
Unit 906, Block B, Menara Amcorp, Amcorp Trade Centre, No. 18, Jln Persiaran Barat, 46050 Petaling Jaya, Selangor Darul Ehsan, Malaysia
Tel: +60-3-7955-9390, Fax: +60-3-7955-9510

Renesas Electronics Korea Co., Ltd.
12F., 234 Teheran-ro, Gangnam-Ku, Seoul, 135-920, Korea
Tel: +82-2-558-3737, Fax: +82-2-558-5141