


Pneumatic Positioner Series 58

User's Manual



Right Valve, Right Application, Right Now!

J Flow Controls, LLC
14 De Camp • Cincinnati, OH 45216
Phone: 513-731-2900 • Fax 513-731-6939
www.jflowcontrols.com

Introduction

Thank you for choosing a J Flow Controls, LLC product. Each product is fully inspected after the production to offer you the highest quality. In order to fully utilize the product, we strongly recommend users read this manual carefully.

- The manual should be given to the end user.
- The manual can be changed or revised without prior notice. Any changes in the product's specifications, structure, and/or any components may not result in immediate revision of the manual.
- The manual should not be duplicated or reproduced for any purpose without approval from J Flow Controls, LLC.

Manufacturer's Warranty

For your safety, it is imperative you follow the instructions in the manual. It is no the manufacturer's liability for any damages which is caused by user's negligence.

It is not the manufacturer's liability for any damages or accidents which resulted by alteration or modification of the product and parts. If alteration or modification is necessary, please contact the manufacturer directly.

Manufacturer warrants the product from the date of original retail purchase of the product for one (1) year, except as otherwise stated.

Manufacturer warranty will not cover the product if it has been subjected to abuse, accident, alteration, modification, tampering, negligence, misuse, faulty installation, lack of reasonable care, repair or service, or if the model or serial number has been altered, tampered with, defaced or removed; damages that occur in shipment, due to an Act of God, failure due to power surge and cosmetic damage. Improper or incorrectly performed maintenance voids this limited warranty.


For detailed warranty information, please contact J Flow Controls, LLC.

Product Description


Main Features and Functions

- The product can operate normally in very extreme environment, such as vibration.
- The durability has been proven after testing of 1 million times
- Response time is very short and accurate
- Simple part change can set 1/2 Split Range
- It is economical due to less air-consumption
- Direct/Reverse action can be set easily Zero & Span adjustment process is simple
- Feedback Connection is easy

Operation Logic



Series 58



Series 58R

Bellows (1) push flapper (2) if input pressure increases. Then the gap between nozzle (3) and flapper (2) increases, which results pressure in upper spool (5) exhaustion. This would cause spool (5) to rise upward. As the spool (5) rises, it pushes format (8) and the air pressure will be supplied to the actuator (10). As the actuator's inner pressure increases, the actuator stem (12) will move. For graphical diagram, please refer to Figure 1.




Figure 1

Label Description

MODEL NO: SERIES 58
 INPUT SIGNAL 3~15psi (0.2 ~ 1.0kgf/cm²)
 SUP. PRESSURE: 20~100psiG (1.4~7.0kgf/cm²G)
 SERIAL NO: 1234567890

P/P POSITIONER

Model Number: Indicates model name and any options
 Input Signal: Indicates current input signal range
 Supply Pressure: Indicates the range of supply pressure
 Serial Number: Indicates unique serial number

Suffix Symbol

Series 58 follows suffix symbols as follows:

Series 58 **1** **2** **3** **4** **5**

1 Motion Type	L	:	Linear
	R	:	Rotary
2 Acting Type	S	:	Single
	D	:	Double
3 Feedback Lever Series 58L	1	:	10 ~ 40mm
	2	:	30 ~ 70mm
	3	:	60 ~ 100mm
	4	:	100 ~ 150mm
Feedback Lever Series 58R	1	:	M6 x 40L
	2	:	M6 x 63L
	3	:	M8 x 40L
	4	:	M8 x 63L
	5	:	NAMUR
4 Connection Type	1	:	PT
	2	:	NPT
5 Ambient Temp	S	:	-4° F ~ 158° F
	H	:	-4° F ~ 248° F
	L	:	-40° F ~ 158° F



* For special specifications, contact our sales department

Specification


Category	Series 58		Series 58	
	Single	Double	Single	Double
Input Signal	0.2 ~ 1.0 kgf/cm ² (3 ~ 15 psi)			
Supply Pressure	10 ~ 150mm		0 ~ 90°	
Air Connection	PT (NPT) 1/4			
Gauge Connection	PT (NPT) 1/8			
Protection	IP66			
Cam	Linear			
Ambient Temp	Standard: -4° F ~ 158° F High: -4° F ~ 248° F Low: -40° F ~ 158° F			
Linearity	±1.0% F.S.		±2.0% F.S.	
Hysteresis	±0.75% F.S.		±1.0% F.S.	
Sensitivity	±0.2% F.S.		±0.5% F.S.	
Repeatability	±0.3% F.S.		±0.5% F.S.	
Air Consumption	3.0 LPM (Sup=1.4kgfcm ²), 11LPM (Sup=4.0kgf/cm ²)			
Flow Capacity	80LPM (Sup=1.4kgf/cm ²), 200LPM (Sup=4.0kgf/cm ²)			
Material	Aluminum Die casting			
Weight	3.75 pounds			

* Test under ambient temperature of -4° F, absolute pressure of 760mmHG, and humidity of 65%. Please contact us for more detailed information.


Parts and Assembly



Dimensions



Series 58 Dimension



Series 58 Dimension

Installation

Safety Warning

When installing positioner, please ensure to read and follow safety instructions.

All input and supply pressure to valve, actuator, and other related devices must be turned off.

Use bypass valve or other equipment to avoid entire system “shut down”.

Make sure there no remaining pressure in the actuator

Tools for Installation

- ① Hexagonal wrench
- ② Screw drivers (=) & (-)
- ③ Spanners for hexagonal head bolts

Series 58 Installation

The Series 58 should be installed on linear motion valve such as a globe valve or gate valve using spring return type diaphragm or piston actuator. Before installation, be sure to check for the following installation components.

- ① Series 53 main body
- ② Feedback lever and lever spring
- ③ Flange nut (bottom of Series 58)
- ④ 4 pieces of hexagon head bolts (M8 x 1.25SP)
- ⑤ 4 pieces of M8 plate washer

Installation Steps

(1) Proper bracket must be made in order to attach positioner on the actuator yoke. Please consider the following when making a bracket:

- ① Feedback lever should be leveled at 50% of valve stroke. (Refer to step 7)
- ② Feedback lever connection bar of actuator clamp should be installed at the position that the valve stroke and numbers which indicated on the feedback lever must be fitted (Refer to Step 8)

(2) Attach Series 58 to the bracket, which was produced in an earlier step, by using bolts. <Figure 1> Please refer to backside of the product for size of bolts. The standard size of bolt is M8 x 1.25SP, and other bolt sizes are available. Please contact J Flow Controls, LLC.




Figure <1>

(3) Attach Series 58 (with bracket) to the actuator yoke - DO NOT TIGHTEN COMPLETELY.

(4) Connect Series 58 feedback lever to the actuator clamp. The gap on the Series 58 feedback lever is 2.55". The connection bar thickness should be less than 2.48". <Figure 2>




Figure <2>

(5) Connect air filter regulator to the actuator temporarily. Set supply pressure of the regulator in order to position to the actuator clamp at 50% of valve stroke. <Figure 3>




Figure <3>

(6) Insert connection bar into the Series 58 feedback lever. The connection bar should be inserted at the 50% point of the feedback lever, which would help to reduce hysteresis. <Figure 4>






Figure <4>

(7) If connection bar does not point to 50% point, then adjust bracket or feedback link bar position. Failure to position at 50% will lower the linearity of the positioner. <Figure 5>




(8) Check valve stroke. The stroke numbers are indicated on the feedback lever. Position connection bar at the number on the feedback lever according to the valve stroke. <Figure 6> To adjust, move the bracket or connection bar.



Note

After installing Series 58 operate the valve from 0% to 100% stroke by using air filter regulator on the actuator. Both of 0% and 100%, the feedback lever should not touch the lever stopper, which is located on the backside of Series 58. <Figure 7> If the feedback lever touches the lever stopper, Series 58 should be installed further away from the center of the yoke.

(9) After the proper installation, tighten all of the bolts on the bracket, the feedback lever, and the connection bar.





Series 58 Installation

The Series 58 should be used for rotary motion valves, that is ball valve, butterfly valve using rack and pinion, scotch yoke and pinion, scotch yoke or complete type actuator, which its stem rotates 90 degrees. Before installation, be sure to check for the following installation components.

- ① Series 58 main body
- ② Fork lever and lever spring
- ③ 1 set of bracket (3 pieces)
- ④ 4 pieces of hexagon head bolt M8 x 1.25 SP
- ⑤ 4 pieces of M8 plate washer

Series 58 Install Layout



Bracket Information

Series 58 is supplied with standard bracket. The bracket can be used for Fork lever and NAMUR bracket. See <Figure 8> for more detailed information.




Figure <8>

(1) Standard actuator stem height (H) is 0.79", 1.18" or 1.97". After checking "H", assemble with the bracket as shown in <Figure 8 & 9>




Figure <9>

(2) Attach bracket Series 58 to the actuator by using hexagon-headed and wrench bolts. Size of the bracket hole is 0.236". When tightening bolts, use spring washer or similar for firm attachment to the actuator, so Series 58 will not shake by vibration or any other impact. The direction of bracket is different by the operating condition, but normally the position is installed as shown in <Figure 10>.




Figure <10>

(3) Set rotation position of the actuator stem at zero point, 0%. For a single type of actuator, it is easy to check zero point, because the actuator is positioned at zero point when there is no supply pressure. If double acting actuator is used, check actuator stem's rotation direction (clockwise or counter-clockwise) by supply pressure.

(4) Install the fork lever as shown in <Figure 11> after setting actuator stem at zero point. Check the direction of the actuator stem - clockwise or counter clockwise. Installation angle of the fork lever should be 45 degrees based on the linear shaft. For NAMUR shaft, the angle does not matter.




Figure <11>

(5) After setting fork lever position, lock nuts which are assembled on bottom of the fork lever.

(6) Attach Series 58 to the bracket. Fix the clamping pin on the main shaft of Series 58 and insert connection bar into the fork lever slot, so it can be locked to the fork lever spring.

Series 58 and center of the actuator stem. Bad alignment of the main shaft and the actuator stem lowers Series 58 durability, because too much force will be on the main shaft of Series 58 <Figure 12>.




Figure <12>

(7) Tighten Series 58 base and the bracket with hexagon-headed bolts and plate washer. It is recommended to tighten four bolts after checking Series 58 position (Figure 13>.




Figure <13>

Piping Connection

Note

- To avoid moisture, oil or dust into the product, please carefully make selection of supply pressure compressor.
- It is recommended to attach air filter regulator before supply port of Series 58.

Supply Pressure Condition

1. Dry air with at least 50°F lower than ambient temperature.
2. Avoid dusty air. Filter can only sort 5 micron or larger.
3. Avoid any oil.
4. Comply with ANSI/ISA-57.3 1975 (R188); ISA S7.3-1975 (R1981)
5. Not to be used beyond the range of 1.4 - 7 kgf/cm² (140 - 700 kPA)
6. Set air filter regulator's supplied pressure 10% higher than actuator's spring range pressure.

Pipe Condition

1. Make sure inside of pipe is emptied.
2. Do not use pipeline that is squeezed or has hole.
3. To maintain flow rate, use the pipeline that has more than 0.24 inches inner diameter. (0.39 inches outer diameter).
4. Do not use extremely long pipeline system. It may affect flow rate due to the friction inside of the pipeline.

Piping connection with actuator

Single Acting Actuator

Series 58 Series single acting type is set to use OUT1 port. OUT1 port should be connected with supply pressure port from actuator when using single acting type of spring return actuator <Figure 14 & 15>.




Figure <14>




Figure <15>

Double Acting Actuator

For Series 58 double acting type, when inputting current signal, supply pressure is out from OUT1. Please refer to <Figure 16 & 17>.




Figure <16>: Series 58




Figure <17>: Series 58

Adjustments

Adjustment - Cam

1. Direction of actuator's stem rotation must be checked when supply signal is supplied. When actuator's stem rotates clockwise, the face of cam must be shown "DA". On the other hand, when the stem rotates counter-clockwise, adjust cam so "RA" shows on the face of cam.
2. Check whether actuator's angle is at the initial point.
3. After checking the initial point, release the hexagonal flange nut and adjust the position of the bearing so it is a 0 point <Figure 18>.
4. When produced, the cam is set as "RA".






Figure <18>

Adjustment - Zero Point


1. Set supply signal at 3 psi and rotate adjuster clockwise or counter-clockwise to adjust actuator's rotation angle <Figure 19>.
2. When adjusting zero for single actuator, rotation angle is equal to positioner's pressure gauge.

**Adjustment - Span****Figure <20>**

1. After setting zero, rotate Span screw so supply signal reaches at the span point on the indicator.
2. Changing span point affects zero point setting. So zero setting must be set again. After setting zero point, confirm the span point. This step must be repeated until both points are properly set.
3. If 1/2 split range is used, Series 58 can be used after span and zero point are set. For Series 58 with 1/2 split range, the span spring must be changed.
4. After setting is completed, tighten Lock Screw. <Figure 20>.

Adjustment - A/M Switch (Auto/Manual)

1. A/M switch adjusts the valve operation to automatic or manual.
2. When produced, Series 58 is set at the "A (Automatic)". If user prefers the positioner's setting as "M (Manual)". The setting can be changed by turning the switch counter-clockwise. <Figure 21>
3. If it is set as "M (Manual)", the air pressure will be supplied to the actuator directly. Always set back to "A (Automatic)" after setting change.
4. If OUT2 in single acting actuator or double acting actuator is used, A/M Switch will not operate.

**Adjustment - Seat Adjuster**

1. Seat adjuster is set according to the customer's request before the positioner is delivered. Please do not adjust the Seat Adjuster.
2. Seat Adjuster is used for double acting actuator always. Please do not touch the Seat Adjuster because it can affect the positioner's performance.

Trouble Shooting

Positioner does not respond to the input signal

1. Check supply pressure level. The level must be at least 1.4 kgf/cm².
2. Check if input signal is properly supplied to the positioner. The signal should be 3-15 psi.
3. Check if the positioner's nozzle has been blocked. Also, check if the pressure is supplied to the positioner and the pressure is being exhausted through the nozzle. If the nozzle has been blocked by any substances, please send the product to J Flow for repair.
4. Check if feedback lever has been installed properly.

The pressure of OUT1 reaches exhausting pressure level and does not come back down.

1. Check A/M Switch. If the switch has been damaged, replace the switch or pilot relay-valve.
2. Check for a gap or damages between the nozzle and the flapper. If damaged, please send the product to J Flow for repair.

The pressure is exhausted only by A/M Switch

1. Check if the positioner's nozzle has been blocked. Also, check if the pressure is supplied to the positioner and the pressure is being exhausted through the nozzle. If the nozzle has been blocked by any substances, please send the product to J Flow for repair.

Hunting occurs

1. Check if safety spring has been displaced. (Next to Pilot Relay Valve).
2. Check if the size of actuator is too small. If so, insert an orifice in order to reduce the pressure flow rate.
3. Check if there is any friction between the valve and the actuator. If so, increase actuator's size or reduce the friction level.

Actuator only operates by On/Off

1. Check pipe connection.
2. Check Cam direction.

Linearity is too low

1. Check if the feedback lever is properly installed. Especially check if the feedback lever is parallel to the ground at 50% point.
2. Check if zero and span have been properly adjusted, that is not too low or not too high.
3. Check if supply air pressure level is stable from the regulator. If the level is unstable, replace the regulator.

Hysteresis is too low

1. In case of double acting actuator, check if seat adjustment has been properly done. Please contact J Flow Controls for any further inquiries regarding the seat adjustment.
2. Backlash can occur when feedback lever and lever spring is loosen. To avoid backlash, adjust the lever spring.
3. Check if the connection bar to the feedback lever is tightly fastened.



Right Valve, Right Application, Right Now!

J Flow Controls, LLC

14 de Camp Avenue
Cincinnati, OH 45216

Phone: 513-731-2900

Fax: 513-731-6939

www.jflowcontrols.com